

# Premium and Atrium using Unity Pro Asynchronous serial link User manual

eng September 2004



---

# Table of Contents



---

<b>Safety Information</b>	<b>11</b>
<b>About the Book</b>	<b>13</b>
<b>Part I Introduction to Modbus, Character Mode and Uni-telway communications</b>	<b>15</b>
At a Glance	15
<b>Chapter 1 Introduction to Modbus, Character Mode and Uni-telway communications</b>	<b>17</b>
Introduction to communications	17
<b>Part II Hardware installation for Modbus, Character Mode and Uni-Telway communications</b>	<b>19</b>
At a Glance	19
<b>Chapter 2 Introduction to hardware installation</b>	<b>21</b>
Communication function devices	21
<b>Chapter 3 Terminal port and TSX P ACC 01 device</b>	<b>23</b>
At a Glance	23
3.1 Introduction to the terminal port	24
At a Glance	24
Introduction to the terminal port	25
Communication with a programming/adjustment terminal	27
Communicating with a man-machine interface console	28
Uni-Telway master/slave communication	30
Character string communication	31
3.2 Connections	32
At a Glance	32
Connections	33
Programming/Adjustment terminal	34
Man-machine interface console	35
Programming/adjustment terminal and man-machine interface console	36

---

---

	Modem on terminal port . . . . .	37
	Master Uni-Telway . . . . .	39
	Slave Uni-Telway . . . . .	40
	Inter-PLC Uni-Telway . . . . .	41
	Inter-device Uni-Telway . . . . .	43
	Master PLC type TSX model 40 . . . . .	44
	Character string . . . . .	45
	Summary table of terminal port connections . . . . .	48
3.3	Appendices . . . . .	51
	At a Glance . . . . .	51
	Characteristics of the terminal port . . . . .	52
	Terminal port connector pin configuration . . . . .	54
3.4	Introduction to TSX P ACC 01 . . . . .	55
	At a Glance . . . . .	55
	Functionalities . . . . .	56
	External appearance . . . . .	57
3.5	Hardware installation . . . . .	58
	At a Glance . . . . .	58
	Dimensions and mounting . . . . .	59
	Internal view . . . . .	60
	Connection to Uni-Telway Buses . . . . .	61
	Connecting to Premium and Atrium PLCs . . . . .	62
	Switch configuration . . . . .	63
	TSX P ACC 01 connector pin configuration . . . . .	64
3.6	Example of topologies . . . . .	65
	At a Glance . . . . .	65
	Connecting devices . . . . .	66
	Uni-Telway master mode . . . . .	68
	Uni-Telway slave mode . . . . .	70
	Connection between two PLCs . . . . .	71
<b>Chapter 4</b>	<b>Installing TSX SCY 11601/21601 modules . . . . .</b>	<b>73</b>
	At a Glance . . . . .	73
4.1	At a Glance . . . . .	74
	At a Glance . . . . .	74
	Introduction . . . . .	75
	Operating standards . . . . .	76
4.2	Description . . . . .	77
	Description . . . . .	77
4.3	Built-in Channel Specifications . . . . .	80
	Built-in Channel Specifications . . . . .	80
4.4	TSX SCY 21601 module's host channel compatibility . . . . .	81
	TSX SCY 21601 Host Channel Compatibility . . . . .	81
4.5	Installation . . . . .	82
	Installation . . . . .	82
4.6	Operation . . . . .	84

---

	Operation . . . . .	84
4.7	Module Visual Diagnostics . . . . .	85
	Visual module diagnostics . . . . .	85
4.8	Built-in Channel Connection . . . . .	86
	At a Glance . . . . .	86
	At a Glance . . . . .	87
	Connection of TSX SCY 21601 to Uni-Telway field bus . . . . .	89
	Reminder on adapting RS 485 distributed line for the TSX SCY 21601 . . . . .	91
	Example of Uni-Telway architecture . . . . .	93
	Connection of TSX SCY 11601/21601 modules to the Modbus field bus . . . . .	94
	Reminder on single line polarization in RS 485 . . . . .	95
	Example of Modbus architecture . . . . .	97
	Connecting the TSX SCA 50 unit . . . . .	98
	Character Mode connection for TSX SCY 21601 . . . . .	99
	Consumption of TSX SCY 11601/21601 modules . . . . .	100
<b>Chapter 5</b>	<b>Implementation of PCMCIA cards . . . . .</b>	<b>101</b>
	At a Glance . . . . .	101
5.1	At a Glance . . . . .	102
	At a Glance . . . . .	102
5.2	Description . . . . .	104
	Description . . . . .	104
5.3	Connecting the PCMCIA card reception channel . . . . .	105
	At a Glance . . . . .	105
	Precautions to be taken when connecting PCMCIA card . . . . .	106
	Connection of PCMCIA cards . . . . .	107
	Product references for PCMCIA cards and installation . . . . .	108
	Mounting cards and cables . . . . .	109
	PCMCIA card operation display . . . . .	111
	Visual diagnostics of PCMCIA cards . . . . .	112
5.4	Connection of the TSX SCP 111 card . . . . .	113
	At a Glance . . . . .	113
	Point to point connection in Character Mode (DTE ↔ DTE) . . . . .	114
	Uni-Telway, Modbus or Character Mode via Modem . . . . .	115
5.5	Connection of the TSX SCP 112 card . . . . .	116
	At a Glance . . . . .	116
	Connection of the TSX SCP 112 card . . . . .	117
	Connecting in point to point mode . . . . .	118
	Multidrop connection . . . . .	119
	Dynamic performance . . . . .	120
	TSX SCP 112 connection with April 5000/7000 PLCs . . . . .	122
5.6	Connection of the TSX SCP 114 card . . . . .	128
	At a Glance . . . . .	128
	Connection to the Uni-Telway network . . . . .	129
	Connecting to the Modbus bus . . . . .	132
	Multi-protocol asynchronous link connection RS 422 . . . . .	135

---

5.7	Summary of connection devices . . . . .	137
	Summary of PCMCIA card connection devices . . . . .	137
5.8	Precautions when connecting PCMCIA cards . . . . .	138
	Precautions for connecting PCMCIA cards . . . . .	138
5.9	Consumption of PCMCIA cards . . . . .	139
	Consumption of PCMCIA cards . . . . .	139
<b>Chapter 6</b>	<b>TSX SCA 64 connection device . . . . .</b>	<b>141</b>
	At a Glance . . . . .	141
6.1	General Introduction . . . . .	142
	General Introduction . . . . .	142
6.2	Physical Description . . . . .	144
	Physical Description . . . . .	144
6.3	Dimensions and Mounting . . . . .	146
	Dimensions and Mounting . . . . .	146
6.4	Installation . . . . .	148
	Installation . . . . .	148
6.5	Bus Cable Shield Cabling . . . . .	149
	At a Glance . . . . .	149
	Local Grounding the Bus: General. . . . .	150
	Connecting the Shield to the Local Ground and to the Two Ends of the Cable (Recommended Cable Type). . . . .	151
	Connecting the Shield to the Local Ground at One End of the Cable and to the Local Ground via a Surge Suppressor at the Other End . . . . .	152
	Connecting the Shielding to the Local Ground at One End and Isolating it From the Ground at the Other End. . . . .	153
6.6	Device Configuration and Transmission Pair Polarization. . . . .	154
	At a Glance . . . . .	154
	2-wire Configuration with Data Pair Polarization by a Station . . . . .	155
	2-Wire Configuration with Data Pair Polarization via a 5VDC External Power Supply. . . . .	157
	4-wire Configuration with Polarization of One Pair by the Master Station and the Other by a Slave Station. . . . .	159
	4-wire Configuration with 2-pair Polarization via 5VDC External Power Supply . . . . .	162
6.7	Adapting the Line End . . . . .	163
	At a Glance . . . . .	163
	Line End Adaptation. . . . .	164
	Signals on the JM and JS SUB-D15 Pin Connectors . . . . .	167
<b>Part III</b>	<b>Software implementation of Modbus, Character Mode and Uni-Telway communications . . . . .</b>	<b>169</b>
	At a Glance . . . . .	169
<b>Chapter 7</b>	<b>Installation methodology . . . . .</b>	<b>171</b>
	Overview . . . . .	171

---

<b>Chapter 8</b>	<b>Software implementation of Modbus communication</b>	<b>175</b>
	At a Glance	175
8.1	General	176
	At a Glance	176
	About Modbus	177
	Compatibilities	178
	Compatibility between a Premium PLC and a series 1000 PLC	179
	Performance	181
	Operating Mode	182
8.2	Modbus communication configuration	183
	At a Glance	183
	How to access the Modbus parameters of the built-in channel of the TSX SCY 11601/21601 modules	184
	How to access PCMCIA Modbus card parameters	186
	Modbus Configuration Screen	188
	Accessible Modbus Functions	190
	Application linked Modbus Parameters	191
	Transmission linked Modbus Parameters	193
8.3	Modbus communication programming	196
	At a Glance	196
	Modbus master communication function	197
	Modbus slave communication function	198
	Using the SEND_REQ communication function	200
	Example 1: SEND_REQ function with Echo request	201
	Example 2: SEND_REQ function with word Read request	202
	Example 3: SEND_REQ Function with Bit Read Request	204
	Example 3: READ_VAR function for reading bits	206
8.4	Debugging of a Modbus communication	207
	At a Glance	207
	Modbus debugging screen	208
	Modbus Master debugging screen	210
	Debug screen in Modbus slave type	211
	How to test a communication channel	212
<b>Chapter 9</b>	<b>Software implementation of communication using Character Mode</b>	<b>215</b>
	At a Glance	215
9.1	General	216
	At a Glance	216
	About Character Mode	217
	Flow Control	218
	Compatibilities	220
	Performance	221
	Operating Mode	223
9.2	Character Mode communication configuration	224

	At a Glance .....	224
	How to access the Terminal Port parameters .....	225
	How to access the parameters of the built-in channel of the TSX SCY 21601 module in character mode .....	226
	How to access the parameters of the PCMCIA cards in character mode .....	227
	Character mode configuration screen .....	229
	Accessible functions in character mode. ....	231
	Transmission parameters in character mode. ....	232
	Message end parameters in character mode .....	234
	Flow control parameters in character mode. ....	236
	Additional parameters .....	237
9.3	Character Mode communication programming .....	239
	Available communication functions .....	239
9.4	Debugging of a communication using Character Mode .....	241
	At a Glance .....	241
	Debugging screen in character mode .....	242
	Debugging parameters in character mode. ....	244
	How to test a communication channel .....	246
<b>Chapter 10</b>	<b>Software implementation of Uni-Telway communication ..</b>	<b>247</b>
	At a Glance .....	247
10.1	General .....	248
	At a Glance .....	248
	Presentation .....	249
	Compatibility .....	250
	Performance .....	251
	Operating Mode .....	253
	Addresses of a slave PLC .....	254
10.2	Uni-Telway communication configuration .....	255
	At a Glance .....	255
	How to access the Terminal Port parameters .....	256
	How to access the parameters of the built-in channel of the TSX SCY 21601 module .....	257
	How to access the parameters of the PCMCIA Uni-Telway cards. ....	258
	Configuration Screen of the Uni-Telway link .....	260
	Accessible functions in Uni-Telway .....	262
	Application linked Uni-Telway Parameters .....	263
	Transmission linked Uni-Telway Parameters. ....	265
10.3	Uni-Telway communication programming .....	267
	At a Glance .....	267
	Available communication functions .....	268
	Writing command words .....	269
	Master to Slave exchanges .....	270
	Slave to Master exchanges .....	272
	Example of an exchange from a slave to the Master system .....	275
	Example of a direct exchange from a slave to the Master system. ....	277




	Slave to Slave exchanges . . . . .	278
	Example of an exchange from a slave to a slave server . . . . .	280
	Example of an exchange from a slave to a slave application . . . . .	282
	Example 2 of an exchange from a slave to a slave system . . . . .	283
	Example of a direct exchange from a slave to a slave system . . . . .	285
	Example of one slave setting another slave to Stop . . . . .	286
	Event data managed by the master . . . . .	287
10.4	Debugging of a Uni-Telway communication . . . . .	288
	At a Glance . . . . .	288
	Uni-Telway debugging screen . . . . .	289
	Uni-Telway debugging screen . . . . .	291
	Requests available for the communication channel test . . . . .	292
	How to test a channel with Identification and Mirror requests . . . . .	293
	How to test a channel with requests . . . . .	294
<b>Chapter 11</b>	<b>Software Implementation of Specific Protocol Communication (FCS SCP 111/114 cards) . . . . .</b>	<b>295</b>
	At a Glance . . . . .	295
11.1	General Points . . . . .	296
	At a Glance . . . . .	296
	Presentation . . . . .	297
	Operating Mode . . . . .	298
11.2	Configuration of Specific Protocol Communication . . . . .	299
	At a Glance . . . . .	299
	How to Access the Parameters of Specific Protocol PCMCIA Cards . . . . .	300
	Configuration Screen for the Generic Protocol Function . . . . .	302
11.3	Debugging a Specific Protocol Communication . . . . .	304
	Debug Screen for the Generic Protocol Function . . . . .	304
<b>Chapter 12</b>	<b>Language objects of Modbus, Character Mode and Uni-Telway communications . . . . .</b>	<b>307</b>
	At a Glance . . . . .	307
12.1	Language objects and IODDTs of Modbus, Character Mode and Uni-Telway communications . . . . .	308
	At a Glance . . . . .	308
	Presentation of the language objects for Modbus, Character Mode and Uni-Telway communications . . . . .	309
	Implicit Exchange Language Objects Associated with the Application-Specific Function . . . . .	310
	Explicit exchange language objects associated with the application-specific function . . . . .	311
	Management of exchanges and reports with explicit objects . . . . .	313
12.2	General language objects and IODDTs for all communication protocols . . . . .	317
	At a Glance . . . . .	317
	Details of IODDT implicit exchange objects of type T_COM_STS_GEN . . . . .	318

	Details of IODDT explicit exchange objects of type T_COM_STS_GEN. . . . .	319
12.3	Language objects and IODDTs associated with Modbus communication. . . . .	321
	At a Glance . . . . .	321
	Details of the implicit exchange objects of the T_COM_MB type IODDT . . . . .	322
	Details of the explicit exchange objects of the T_COM_MB type IODDT . . . . .	323
	Details concerning explicit exchange language objects for a Modbus function. . . . .	325
	Details of language objects associated with configuration Modbus mode. . . . .	326
12.4	Language objects and IODDTs associated with Character	
	Mode communication. . . . .	327
	At a Glance . . . . .	327
	Details of the implicit exchange objects of the T_COM_CHAR type IODDT for	
	PCMCIA cards . . . . .	328
	Details of the explicit exchange objects of the T_COM_CHAR type IODDT for	
	PCMCIA. . . . .	329
	Details concerning explicit exchange language objects for communication in	
	Character Mode . . . . .	331
	Details of language objects associated with configuration in Character Mode . . . . .	332
12.5	Language objects and IODDTs associated with Uni-Telway communication . . . . .	334
	At a Glance . . . . .	334
	Details of the implicit exchange objects of the T_COM_UTW_M type	
	IODDT for PCMCIA cards . . . . .	335
	Details of the explicit exchange objects of the T_COM_UTW_M type	
	IODDT for PCMCIA cards . . . . .	337
	Details concerning explicit exchange language objects for a master	
	Uni-Telway function . . . . .	340
	Details of language objects associated with configuration in master	
	Uni-Telway mode. . . . .	341
	Details of the implicit exchange objects of the T_COM_UTW_S type	
	IODDT for PCMCIA cards . . . . .	343
	Details of the explicit exchange objects of the T_COM_UTW_S type	
	IODDT for PCMCIA cards . . . . .	344
	Details of language objects associated with configuration in slave	
	Uni-Telway mode. . . . .	346
12.6	Language Objects Associated with the Specific Protocol . . . . .	347
	Details of the Language Objects Associated with Specific Protocols . . . . .	347
12.7	The IODDT type T_GEN_MOD applicable to all modules . . . . .	348
	Details of the Language Objects of the IODDT of type T_GEN_MOD . . . . .	348
<b>Index</b>	<b>.....</b>	<b>349</b>

---

## Safety Information



---

### Important Information

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



### DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, **will result** in death, serious injury, or equipment damage.



### WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.



### CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

**PLEASE NOTE**

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When controllers are used for applications with technical safety requirements, please follow the relevant instructions.

No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. This document is not intended as an instruction manual for untrained persons.


© Schneider Electric 2004

All rights reserved.

---

---

## About the Book



---

### At a Glance

**Document Scope** This manual describes the principle for hardware and software implementation of Character Mode, Modbus and Uni-Telway communication for Premium and Atrium PLCs.

**Validity Note** The data and illustrations found in this documentation are not binding. We reserve the right to modify our products in line with our policy of continuous product development.  
The information in this document is subject to change without notice and should not be construed as a commitment by Schneider Electric.

### Related Documents

Title of Documentation	Reference Number
Communication architectures and services	Included in the documentation CD-ROM

**Product Related  
Warnings**

Schneider Electric assumes no responsibility for any errors that may appear in this document. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product.

For reasons of safety and to ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When controllers are used for applications with technical safety requirements, please follow the relevant instructions.

Failure to observe this product related warning can result in injury or equipment damage.

---


**User Comments**

We welcome your comments about this document. You can reach us by e-mail at [TECHCOMM@modicon.com](mailto:TECHCOMM@modicon.com)

---

---

# Introduction to Modbus, Character Mode and Uni-telway communications.



---

## At a Glance

**In This Chapter** This part provides an introduction to Modbus, Character Mode and Uni-telway communications.

**What's in this Part?** This part contains the following chapters:

Chapter	Chapter Name	Page
1	Introduction to Modbus, Character Mode and Uni-telway communications	17





---

# Introduction to Modbus, Character Mode and Uni-telway communications

# 1

---

## Introduction to communications

<b>At a Glance</b>	<p>The communication function is used to exchange data between all devices connected on a bus or network.</p> <p>This function applies:</p> <ul style="list-style-type: none"><li>• to specific in-rack mounted communication modules,</li><li>• to processors via the terminal port or via PCMCIA cards.</li></ul>
<b>Type of communication</b>	<p>The communication functions covered in this manual are:</p> <ul style="list-style-type: none"><li>• The Modbus function,</li><li>• The Character Mode function,</li><li>• The Uni-Telway function.</li></ul>
<b>Hardware installation</b>	<p>The three functions all require the installation of the following hardware devices:</p> <ul style="list-style-type: none"><li>• the module <b>TSX SCY 21601</b>,</li><li>• the PCMCIA cards <b>TSX SCP 111, 112, 114</b>.</li></ul> <p>The Modbus function is also provided by the <b>TSX SCY 11601</b> module.</p>
<b>Software installation</b>	<p>The section on software installation in this manual is identical to that for Premium and Atrium PLCs.</p>



---

# Hardware installation for Modbus, Character Mode and Uni-Telway communications



---

## At a Glance

**In This Chapter** This part provides an introduction to hardware installation for Modbus, Character Mode and Uni-Telway communications.

**What's in this Part?** This part contains the following chapters:

Chapter	Chapter Name	Page
2	Introduction to hardware installation	21
3	Terminal port and TSX P ACC 01 device	23
4	Installing TSX SCY 11601/21601 modules	73
5	Implementation of PCMCIA cards	101
6	TSX SCA 64 connection device	141



---

## Introduction to hardware installation

# 2

---

### Communication function devices

#### General

The three communication functions (Modbus, Character Mode and Uni-Telway) use different devices.

Device	Role	Modbus	Character Mode	Uni-Telway
Terminal port	used to connect a programming/adjustment terminal and an MMI console Terminal port (See <i>Modem on terminal port</i> , p. 37)	-	X	X
TSX SCY 21601 module	used to host PCMCIA communication cards and features a built-in communication channel TSX SCY 21601 (See <i>Installing TSX SCY 11601/21601 modules</i> , p. 73)	X	X	X
TSX SCY 11601 module	features a built-in communication channel TSX SCY 11601 (See <i>Installing TSX SCY 11601/21601 modules</i> , p. 73)	X	-	-
PCMCIA cards	support the different communication protocols TSX SCP 111/112/114 (See <i>Implementation of PCMCIA cards</i> , p. 101)	X	X	X
Key:				
X	Yes			
-	No			

---



---

# Terminal port and TSX P ACC 01 device



---

## At a Glance

### Subject of this Chapter

This chapter introduces the functions of the terminal port and **TSX P ACC 01** connection device of Premium and Atrium processors.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Introduction to the terminal port	24
3.2	Connections	32
3.3	Appendices	51
3.4	Introduction to TSX P ACC 01	55
3.5	Hardware installation	58
3.6	Example of topologies	65

## 3.1 Introduction to the terminal port

---

### At a Glance

#### Aim of this Section

This Section introduces the communication function from the Terminal port of a PLC.

---

#### What's in this Section?

This section contains the following topics:

Topic	Page
Introduction to the terminal port	25
Communication with a programming/adjustment terminal	27
Communicating with a man-machine interface console	28
Uni-Telway master/slave communication	30
Character string communication	31

---




## Introduction to the terminal port

### At a Glance

The terminal port uses master Uni-Telway, slave Uni-Telway and character string communication methods.

### Premium PLCs

The terminal port on Premium processors is a non-insulated RS 485 link made up of two 8-pin mini-DIN connectors. These two connectors function identically and are found on the processor. They are marked with TER and AUX and are used to physically connect two pieces of equipment together at the same time, such as a programming/adjustment terminal and a man-machine interface console.



The TER connector also allows power to be supplied to a device which does not have its own power supply (RS 485/RS 232 connecting cable converter, insulating device **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55), etc).


The terminal port functions by default in master Uni-Telway mode. Via configuration it is possible to switch to Uni-Telway slave or character mode.

**Note:** The communication mode (e.g. master Uni-Telway, Uni-Telway slave or character mode) is the same on both the TER and AUX connectors.

**Note:** TSX P57 554 and TSX P57 5634 processors do not have an AUX port. Using a **TSX P ACC 01** insulating device makes it possible to duplicate the terminal port in order to use two TER and AUX ports.

## Atrium PLCs

Atrium processors have one single TER terminal port which is identical in all respects to the TER terminal port on Premium PLCs. This is a non-insulated RS 485 link which is made up of a 8-pin mini DIN connector which is used to physically link up a device, such as a programming/adjustment terminal or a man-machine interface console.



This connector is used to supply power to a device which does not have its own power supply (connecting cable converter RS 485/RS 232, insulating device **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55), etc).

The terminal port functions by default in master Uni-Telway mode. Via configuration it is possible to switch to Uni-Telway slave or character mode.


**Note:** Using a **TSX P ACC 01** insulating device makes it possible to duplicate the terminal port in order to use two TER and AUX ports like on the Premium PLC processor.

## Communication with a programming/adjustment terminal


### General

Configured in master Uni-Telway (default function), the terminal port is used to connect a programming/adjustment terminal.

Premium station:



Atrium station:



**Note:** When using an Atrium Station, the programming terminal is generally the PC which accepts the PCI 57 processor. However, as for a Premium station, the programming terminal can also be a PC type terminal connected to the processor port.

## Communicating with a man-machine interface console

---


### General

Configured in master Uni-Telway mode (default function), the terminal port makes it possible to manage man-machine interface device.


The man-machine interface device uses UNI-TE protocol to communicate with the local PLC and the other stations on the network architecture.

When using a Premium PLC, the man-machine interface terminal should be connected to the AUX connector in order to free the TER connector for possible connection of a programming/adjustment terminal.

Premium station:



Atrium station:




## Uni-Telway master/slave communication

---

### General

The default communication mode for the terminal port is master Uni-Telway. It is mainly used to link up a programming terminal and a slave man-machine interface console.




**Note:** When using an Atrium PLC or if the processor only has one terminal port, this type of connection can be made by using a **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55) device.

## Character string communication

### General

This mode is used to connect up a printer or specialized console (screen control, table controller etc.) to the terminal port of a Premium or Atrium PLC.

Illustration



## 3.2 Connections

---

### At a Glance

**Aim of this Section** This Section deals with the different connections of the Terminal port.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
Connections	33
Programming/Adjustment terminal	34
Man-machine interface console	35
Programming/adjustment terminal and man-machine interface console	36
Modem on terminal port	37
Master Uni-Telway	39
Slave Uni-Telway	40
Inter-PLC Uni-Telway	41
Inter-device Uni-Telway	43
Master PLC type TSX model 40	44
Character string	45
Summary table of terminal port connections	48

---



## Connections

### General


The connector marked TER is used to connect any device which supports Uni-Telway protocol, in particular devices which do not have their own power supply (RS 485/RS 232 connector cable converters, **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55) isolation device, etc).

The connector marked AUX (only on Premium PLCs other than TSX P57 554/5634) only enables devices which have a power supply to be connected (e.g. man-machine interface console, third-party devices, etc).

The terminal port has three function modes:

- Master Uni-Telway (default configuration),
- Slave Uni-Telway,
- Character string.

Illustration:



**Note:** For Premium PLCs with two connectors (TER and AUX), the operating mode defined in configuration (master Uni-Telway, slave Uni-Telway, character mode) is the same for both connectors.

### Methods of connection

According to the operating mode selected in configuration, the terminal port is used to connect:

- Premium PLC programming and adjustment terminals,
- Man-machine interface devices,
- Another PLC, using the **TSX P ACC 01** connection device,
- Uni-Telway devices (sensors/actuators, speed controller, etc.),
- A printer or a control screen (link in character string mode),
- A modem.

**Note:** Connecting a Premium/Atrium PLC slave to a UNI-TELWAY Bus requires the use of a **TSX P ACC 01** device.

## Programming/Adjustment terminal

### General

Terminals with their own power supply (FTX 417, FTX 517) can be connected to both TER and AUX connectors on Premium processors.



If a terminal does not have its own power supply, it must be connected to the processor TER connector.

If the PLC is connected to a network architecture, the transparency network enables the programming terminal to reach all the devices in the architecture.


The product reference for the different connection cables is given below.

Examples of connection:




#### Premium




OR



#### TSX RKY



OR



## Man-machine interface console


### General

The man-machine interface device uses UNI-TE protocol to communicate with the local PLC and the other stations in the network architecture.

A man-machine console with its own power supply on a Premium PLC must be connected to the AUX port (except on TSX P57 554/5634) in order to leave the TER port free for a terminal which needs a power supply (FTX 117 Adjust for example).

The product references for connector cables between the terminal port and a Magelis man-machine interface console are given below.

Examples of connection:




## Programming/adjustment terminal and man-machine interface console

---

### General

The terminal port on a Premium processor can manage two devices in multidrop: the programming/adjustment terminal and a man-machine interface console. Each of the two connectors on the processor can receive one of these devices. Examples of connection:



**Note:** Each connected terminal can be disconnected without disrupting the operation of the other. When using an Atrium PLC or if the processor only has one terminal port, this type of connection can be made by using a **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55) device.

## Modem on terminal port

---

### General

The terminal port on Premium PLCs is compatible with a modem connection in all protocols: Master Uni-Telway, Slave Uni-Telway and Character string.

---

### Modem characteristics

The modem which is to be connected must have the following characteristics:


1. Support 10 or 11 bits per character if the terminal port is used in Uni-Telway mode:
  - 1 bit for Start
  - 8 bits of Data
  - 1 bit for Stop
  - Odd parity or without parity
2. Operate without any data compression if the terminal port is used in Uni-Telway.
3. Be able to be "forced DTR signal" configured for its RS 232 serial port (if the modem is used in response mode), as this signal is not connected by the cable.
4. Operate without flow control (neither hardware: RTS/CTS, or software: XON/XOFF) for its RS 232 serial port, as the cable to be used for the terminal port can only carry TX, RX and GND signals.
5. Operate without data carrier check. Warning: this operating mode also uses RTS and CTS control signals.
6. Accept an incoming telephone call while characters arrive at its RS 232 serial port (if a modem/telephone network is used in response mode on a terminal port configured in master Uni-Telway).

**Note:** It is **strongly recommended** that you check with your dealer that the above-mentioned characteristics are offered by the intended modem.

---

## Examples

Connecting to a Premium PLC:



Note: Connection on an Atrium is identical.

- In Master Uni-Telway mode with the terminal port connected to a modem/telephone network in response mode, this modem must have all the above characteristics (1 to 6).
- In character string mode with the terminal port connected to a modem via a specialized line, this modem must have the characteristics of 3 to 5 above.

---

## Configuring the terminal port

In Uni-Telway mode the following parameters must be observed and set in the configuration in Unity Proware:

- The wait timeout must be between 100 and 250 ms
  - In master mode the number of configured slaves must correspond to the actual number of slaves present on the bus.
  - In slave mode the number of addresses must correspond to those used.
-


## Master Uni-Telway

### General

This is the terminal port default operating mode. It is principally used for:

- Connecting a programming/adjustment terminal and a man-machine interface console if a Premium PLC is used.
- Connecting a programming/adjustment terminal or man-machine interface console in the case of an Atrium PLC or Premium P57 554/5634 PLCs with only one terminal port.

Examples of connection:



**Note:** When using an Atrium station where the processor only has one terminal port, this type of connection can be made by using a **TSX P ACC 01** device.

### Important information

The master can scan up to eight link addresses:

- Link addresses 1,2 and 3 are reserved for the programming terminal.
- The five other addresses are available for connecting a device such as a man-machine interface, slave PLC, sensors/actuators or any other slave device which supports UNI-TE protocol. Addresses 4 and 5 are reserved for a man-machine interface console, if one is used (addresses are forced by using a **XBT-Z 968** cable).

This functioning mode is immediately operational. Within the limits of the default configuration, no installation phase is required to connect a device to this type of link.





## Inter-PLC Uni-Telway


### General

The terminal port on Premium processors allows two PLCs to be connected, one the master and the other the slave.

For this connection to be possible it is **essential** to use a **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55) connection device. The different options for connecting this device are given below.


### Example of connecting two Premium PLCs

Illustration:



**Example of  
connecting a  
Premium PLC  
and an Atrium  
PLC**

Illustration:



## Inter-device Uni-Telway


### General

The terminal port on Premium/Atrium PLCs enables them to be connected to a Uni-Telway bus in order to communicate with devices such as speed controllers, sensor/actuators or with other PLCs.

Connecting a Premium/Atrium (master or slave) PLC to a Uni-Telway bus requires the use of a **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55) device.

### Example

Examples of connection:



The connected devices communicate with the PLC using UNI-TE protocol.

Communication between the different components is allowed.

The programming terminal can directly access all these devices to carry out adjustments and diagnostics functions.


**Note:** To install **TSX SCA 50** and **TSX SCA 62** devices, consult the TSX DG UTW manual: *Uni-Telway Bus communication*.

## Master PLC type TSX model 40

### General

A TSX/PMX model 40 PLC can also be configured in master mode on a Uni-Telway bus and can control slave Premium/Atrium PLCs.

Example of connection




**Note:** To install **TSX SCA 50** and **TSX SCA 62** devices, consult the TSX DG UTW manual: *Uni-Telway Bus communication*

## Character string

---

**General points**      The terminal port, when configured in character mode, can be used to connect a device such as a printer, display screen or a specialized console (table controller for example).

Examples of connection:



**Note:** To allow all types of connection, the **TSX PCX 1130** cable is delivered with a **TSX CTC 09** adapter/converter (9-pin male to 25-pin male).

**Precautions for use**

The **TSX PCX 1031** cable allows RS 485/RS 232 conversion and provides 'peripheral slave' information for the printer. It does not work on the AUX port and **the connected device must handle the RTS signal.**

To use the **TSX PCX 1031** cord, one of the following TER port configurations must be used:

- 7 data bits + 1 or 2 stop bits + 1 parity bit,
- 7 data bits + 2 stop bits,
- 8 data bits + 1 stop bit + 0 or 1 parity bit,
- 8 data bits + 2 stop bits.

The **TSX PCX 1031** and **TSX PCX 1130** cables should only be connected to the PLC's TER port in order to supply power to the RS 485/RS 232 conversion device. To avoid signal conflicts, no devices should be connected to the PLC's AUX port.

---

## Summary table of terminal port connections

### General

The table below can be used to define which cable links the terminal port connectors of a Premium/Atrium PLC to peripheral devices.

Connection cable	TER Port	AUX Port	Example of connected devices
<b>TSX CB 1020</b> <b>TSX CB 1050</b>	-	X	<b>TSX P ACC 01.</b>
<b>T FTX CBF 020</b>	X	X	FTX 517, FTX 417.
<b>TSX PCX 1031</b>	X	-	FT 2100, RS 232 programming and adjustment terminals. Graphics terminals and printers managing RTS signal. Devices not handling DTE<-->DTE type RTS signals: RS 232 programming terminals, printers.
<b>XBT-Z938</b>	X	X	Magelis.
<b>TSX P ACC 01</b>	X	-	Connection to Uni-Telway.
<b>TSX PCX 1130</b>	X	-	Devices not handling DTE<-->DCE type RTS signals: Modem.
<b>TSX PCX 3030</b>	X	X	Programming and adjustment terminals with a USB port.
Key:			
X	Available		
-	Not available		



**Configuring the  
TSX PCX 1031  
and TSX PCX  
1130 cables**


The two cables **TSX PCX 1031** and **TSX PCX 1130** convert RS 485 and RS 232 signals. They allow the terminal port to be connected to RS 232 devices that do not handle RTS.

Both are equipped with a switch that enables the PLC to be set to either Master of Slave mode. The switch is accessible internally by removing the metal cover containing the electronics.

The management of the switch is as follows:

	Unity Pro Master Uni-Telway configuration	Unity Pro Slave Uni-Telway configuration	Unity Pro Character Mode configuration
Switch position M	Uni-Telway Master with Unity Pro configuration	Uni-Telway Master with default configuration	Uni-Telway Master with default configuration
Switch position S	Uni-Telway Slave with default configuration	Uni-Telway Slave with Unity Pro configuration	Character Mode with Unity Pro configuration

Illustration:



**Configuring the  
TSX PCX 3030  
cable**

The **TSX PCX 3030** cable is a USB/RS-485 serial link converter. It is used to connect a device with a USB port to a PLC's terminal or AUX port.

The **TSX PCX 3030** cable is fitted with a switch that selects the communication mode. The switch is used to set the PLC's communication mode as either Master or Slave.

It is accessible under the metal cover containing the electronics.

The following table shows how the switch operates.

Switch Position	Function	Link in Mode
0	Uni-Telway PLC master communication.	Multi-point
1	Other types of communication.	Multi-point
2	Uni-Telway PLC master communication according to PLC configuration.	Point to point
3	Other types of communication according to PLC configuration.	Point to point

<b>Note:</b> To program a PLC you must set the switch to position 0 or 2.
---

<b>Note:</b> You must install a (See Communication Drivers, Installation manual, The drivers of the TSX PCX 3030 cable)virtual COM driver to use the <b>TSX PCX 3030</b> cable.
---

---

# 3.3 Appendices

---

## At a Glance

**Aim of this Section** This Section contains the appendices relating to the Terminal port.

**What's in this Section?** This section contains the following topics:

Topic	Page
Characteristics of the terminal port	52
Terminal port connector pin configuration	54

## Characteristics of the terminal port

### General

The characteristics of the terminal port are given in the table below:

		Uni-Telway master or slave mode	Character Mode
<b>Structure</b>	Physical interface	Non-insulated RS 485	Non-insulated RS 485
<b>Transmission</b>	Protocol	Master/slave multidrop	Without protocol
	Binary flow	19200 bits/s by modifiable default of 1200 to 19200 bits/s (1 start bit; 8 data bits; even parity, odd parity or without parity; 1 bit stop).	9600 bits/s by modifiable default of 1200 to 19200 bits/s (7 or 8 data bits; even parity, odd parity or without parity; with or without echo).
	Binary digit rate for loading of a project	TSX P57 1●/2●/5●: 19200 bits/s. TSX P57 3●/4●: 115 000 bits/s.	
<b>Configuration</b>	Number of devices	Eight maximum (eight addresses managed by the master). In slave mode addresses 4, 5, 6 are selected by default. In master mode the reserved addresses are: <ul style="list-style-type: none"> <li>● 1, 2, and 3 for the programming terminal,</li> <li>● 4 and 5 if a Magelis is present.</li> </ul> The other addresses are available.	A device (point to point)
	Length	10 meters maximum	10 meters maximum

		Uni-Telway master or slave mode	Character Mode
Utilities	UNI-TE	Requests in point to point with report of 128 octets maximum initiated by any connected device. There is nothing broadcast from the master.	Character string 129 octets maximum. Messages must end with \$R (carriage return).
	Other functions	Transparency of communication with all devices in a network architecture via the master.	-
	Safety	A character check on each frame, acknowledgment and repeat option.	No error indication.
	Monitoring	Table of bus state, status of devices, error counters can be accessed on the slaves	No flow monitoring

**Note:** Using a **TSX P ACC 01** (See *Introduction to TSX P ACC 01*, p. 55) connection device enables the RS 485 link to be used in remote mode.

## Terminal port connector pin configuration

### General

The terminal port connectors marked TER and AUX are 8-pin mini-DIN which can be locked.

The signals are given below:



**TER**

- 1 D (B)
- 2 D (A)
- 3 not connected
- 4 /DE
- 5 /DTP (1 = master)
- 6 not connected
- 7 0 volts
- 8 5 volts



**AUX**

- 1 D (B)
- 2 D (A)
- 3 not connected
- 4 /DE
- 5 /DTP (1 = master)
- 6 not connected
- 7 0 volts
- 8 not connected

**Note:** The operation of the terminal port depends on two parameters:

- Signal status/DTP (0 or 1), fixed by cabling accessory (**TSX P ACC 01** cable).
- Software configuration of the terminal port defined in Unity Pro.

The table below defines the functioning mode of the terminal port according to these two parameters:

Unity Pro configuration	Signal /DTP = 0	Signal /DTP = 1
Uni-Telway master	Terminal port in Uni-Telway slave mode (default)	Terminal port in Uni-Telway master mode
Slave Uni-Telway	Terminal port in Uni-Telway slave mode	Terminal port in Uni-Telway master mode (default)
Character mode	Terminal port in character mode	Terminal port in Uni-Telway master mode (default)

---

# 3.4 Introduction to TSX P ACC 01

---

## At a Glance

---

**Subject of this Section** This section describes the general characteristics of the **TSX P ACC 01** device.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
Functionalities	56
External appearance	57

---

## Functionalities

---

### General

The **TSX P ACC 01** unit is a cabling accessory that connects to the TER connector of the Premium/Atrium PLC processor via an integral cable fitted with a mini-DIN connector at one end.

This is used to:

- Connect several devices to the terminal port of Premium/Atrium PLCs. For this purpose, it is fitted with two mini-DIN connectors, marked TER and AUX, which are functionally identical to the TER and AUX connectors of the Premium PLC processors.
- Isolate Uni-Telway signals in order to extend Premium PLC terminal port links to over 10 meters for the purpose of connecting the PLC to a Uni-Telway bus.
- Adapt the bus when the unit is connected to one of the ends of the Uni-Telway bus.
- Set the operating mode of the terminal port:
  - Uni-Telway master
  - Uni-Telway slave or Character Mode

**Note:** The TER and AUX ports of the **TSX P ACC 01** unit are not isolated from one another, nor from the TER port of the supplying PLC.

**Note:** We strongly recommend that, after use, you do not leave a TSX PCU 103• or TSX PCX 1031 cable connected to the Uni-telway bus at one end and unconnected at the other.




## External appearance

### General

This device is made from zamak and of the same type as Uni-Telway branching or connection devices (**TSX SCA 50** and **TSX SCA 62**). It is designed to be mounted in a cabinet. Its protection index is IP20.

Illustration:



# 3.5                    Hardware installation

---

## At a Glance

**Aim of this Section**                    This Section deals with installing hardware for connection devices **TSX P ACC 01**.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
Dimensions and mounting	59
Internal view	60
Connection to Uni-Telway Buses	61
Connecting to Premium and Atrium PLCs	62
Switch configuration	63
TSX P ACC 01 connector pin configuration	64


---

## Dimensions and mounting

### General

The **TSX P ACC 01** device is installed on a **AM1-PA...** perforated board or on a DIN rail with a **LA9 D09976** mounting plate.


Illustration:



## Internal view

---

### Illustration



**S1** Selects functioning mode (master or slave),

**S2** Adapts the line end,

**JA and JB** Connection terminals on the Uni-Telway Bus.


---

## Connection to Uni-Telway Buses

### General

The **TSX P ACC 01** device is connected to the Uni-Telway Bus using connection terminals JA and JB as shown below:

Illustration:




## Connecting to Premium and Atrium PLCs

---

### General

When the **TSX P ACC 01** device has to be supplied, it must be connected by its built-in cable to the TER connector on the PLC processor.  
The device can be connected and disconnected when the PLC is switched on.  
Illustration:



Note:

Only one **TSX P ACC 01** device can be connected to a Premium/Atrium PLC.

---

## Switch configuration

### General


- **Configuring line end adaptation**

Line ends are adapted by the S2 switch as indicated below.

- **Configuring the operating mode**

The operating mode is selected by switch S1 as indicated below.

Illustration:




**Note:** The operating mode selected only concerns the connection cable leading to the TER connector on the PLC processor.

## TSX P ACC 01 connector pin configuration

---


### General

The **TSX P ACC 01** device has two parallel connectors, marked TER and AUX.  
The signals are given below :



**TER**

- 1 D(B)
- 2 D(A)
- 3 not connected
- 4 not connected
- 5 not connected
- 6 not connected
- 7 0 V
- 8 5 V



**AUX**

- 1 D(B)
- 2 D(A)
- 3 not connected
- 4 not connected
- 5 not connected
- 6 not connected
- 7 not connected
- 8 not connected



---

## 3.6 Example of topologies

---

### At a Glance

**Aim of this Section** This Section introduces examples of how to use the **TSX P ACC 01** device.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
Connecting devices	66
Uni-Telway master mode	68
Uni-Telway slave mode	70
Connection between two PLCs	71

---

## Connecting devices

---


### General

The two TER and AUX ports on the **TSX P ACC 01** device have the same standard functions as the TER and AUX connectors on Premium/Atrium PLC station processors.


- The TER connector on the device is used to connect any device which supports Uni-Telway protocol, and in particular link up devices without their own power supply (RS 485/RS 232 cable converter, etc)
- The AUX connector on the device is only used to connect devices with a power supply (man-machine interface console, third-party devices etc).

**Note:** The **TSX P ACC 01** device is supplied from the TER connector on the PLC to which it is connected. As a result, the TER connector on the device enables devices with their own power supply (Magelis, etc) or without their own power supply (RS 485/RS 232 cable converter, etc) to be supplied. If the user wants to connect the terminal port of a second PLC to one of the ports on the **TSX P ACC 01** device, the AUX connectors (on the device and PLC) must be used to avoid power supply conflicts on the two PLCs.

Example 1:



Example 2:




## Uni-Telway master mode

### Example

A **TSX P ACC 01** device is connected to a Uni-Telway link master PLC as in the example below.

Switches S1 and S2 must be positioned on OFF (master mode).

Example on a Premium station:






## Uni-Telway slave mode

### Example

A **TSX P ACC 01** device is connected to a Uni-Telway link slave PLC as in the example below.

**Note: for a PLC to be able to operate in slave mode it must be connected to a TSX P ACC 01 device by its built-in cable.**

Illustration:



## Connection between two PLCs

### Reminders


If the user wants to connect the terminal port of a second PLC on one of the ports of the **TSX P ACC 01** device, the AUX port must be used to avoid power supply conflicts in the two PLCs.

**Note: for a PLC to be able to operate in slave mode it must be connected to a TSX P ACC 01 device by its built-in cable.**

In the example given below the **TSX P ACC 01** device must therefore be connected to the Uni-Telway slave PLC by the device's integrated cable. Its S1 switch must be positioned on ON

If the device is not placed on a Uni-Telway bus, the position of the S2 switch does not matter.

Illustration:







---

# Installing TSX SCY 11601/21601 modules



---

## At a Glance

**Subject of this Chapter** This chapter deals with the hardware installation of **TSX SCY 11601/21601** modules.

**What's in this Chapter?** This chapter contains the following sections:

Section	Topic	Page
4.1	At a Glance	74
4.2	Description	77
4.3	Built-in Channel Specifications	80
4.4	TSX SCY 21601 module's host channel compatibility	81
4.5	Installation	82
4.6	Operation	84
4.7	Module Visual Diagnostics	85
4.8	Built-in Channel Connection	86

---

# 4.1                    At a Glance

---

## At a Glance

---

**Aim of this Section**                    This section introduces the **TSX SCY 11601/21601** modules.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
Introduction	75
Operating standards	76

---

## Introduction

---

### **TSX SCY 11601: General**

The **TSX SCY11601** communication module allows communication via a Modbus link.  
It consists of a communication channel, channel 0, mono-protocol, RS485 isolated asynchronous serial link supporting the Modbus protocol.

---

### **TSX SCY 21601: General**

The **TSX SCY 21601** module can take PCMCIA communication cards.  
It has two communication channels:

- A multi-protocol built-in channel (channel 0), RS485 isolated asynchronous serial link, supporting Uni-Telway, Modbus or Character Mode protocols.
  - A PCMCIA host channel (channel 1) which supports the following protocols:
    - Uni-Telway, Modbus and Character Mode on an RS 232-D, Current Loop, or RS 485 link, corresponding to cards **TSX SCP 111**, **112** and **114**.
    - Fipway cell network corresponding to the **TSX FPP 20** card.
- 

### **Notes for the two modules**

**Note:** : The built-in channel on **TSX SCY 11601/21601** modules is only compatible with a two wire RS 485 link.

## Operating standards

---

### General

The **TSX SCY 11601/21601** modules and **PCMCIA** communication cards comply with the following international norms and standards:

- US Standards: UL508, IEC 1131-2
- CANADA Standards: CSA C22.2/1 42
- Compliance with rule: FCC-B
- EC labeling
- PCMCIA mechanical standard type III E
- PCMCIA 2.01

The link built into the **TSX SCY 21601** module complies with communication standards:

- Uni-Telway
- Modbus
- X-Way

The link built into the **TSX SCY 11601** module complies with communication standards:

- Jbus/Modbus
- X-Way

**TSX SCP 111, 112, 114** PCMCIA cards comply with communication standards:

- Uni-Telway protocols, Modbus
  - PCMCIA
  - X-Way
-

## 4.2 Description


### Description

#### TSX SCY 11601 module: General

The **TSX SCY 11601** module is a simple format module which can be inserted into one of the slots on a Premium/Atrium PLC station rack.

**Note:** The X-Bus remote is not authorized for this module.

Illustration:



This TSX SCY 11601 module is made up of the following components:


Number	Description
1	Three indicator LEDs on the front of the module: <ul style="list-style-type: none"> <li>● RUN and ERR show the module's status,</li> <li>● CH0 displays the status of the built-in serial link channel (channel 0) communication.</li> </ul>
2	Built-in channel (Channel 0) has a 25 pin SUB-D female connector, half duplex mode (channel 0) RS 485 base link: <ul style="list-style-type: none"> <li>● Modbus.</li> </ul>

**TSX SCY 21601**  
**module: General**

The **TSX SCY 21601** module is a simple format module which can be inserted into one of the slots on a Premium/Atrium PLC station rack.

**Note:** The X-Bus remote is not authorized for this module.


Illustration:



This module is made up of the following elements:

Number	Description
1	Three indicator LEDs on the front of the module: <ul style="list-style-type: none"><li>● RUN and ERR show the module's status.</li><li>● CH0 displays the status of the built-in serial link channel (channel 0) communication.</li></ul>
2	Built-in channel has a 25 pin SUB-D female connector, half duplex mode (channel 0) RS 485 base link: <ul style="list-style-type: none"><li>● Uni-Telway</li><li>● Modbus</li><li>● Character Mode</li></ul>
3	PCMCIA type III (channel 1) host channel.

**Insertable cards** Different communication cards which can be built into the TSX SCY 21601 module's host channel:

Type	Description	Illustration
<b>TSX SCP 111</b>	Multiprotocol card (Uni-Telway, Modbus, Character Mode), RS 232 D, 9 non-isolated signals.	
<b>TSX SCP 112</b>	Multiprotocol card (Uni-Telway, Modbus, Character Mode), current loop (BC 20 mA).	
<b>TSX SCP 114</b>	Multiprotocol card (Uni-Telway, Modbus, Character Mode), RS 485, RS 422 compatible isolated.	
<b>TSX FPP 20</b>	Fipway network cards	

# 4.3 Built-in Channel Specifications

## Built-in Channel Specifications

### General

The built-in channel of TSX SCY 11601/21601 modules includes:

- An RS 485 Physical Interface,
- A twisted double pair medium,
- The TSX SCY 11601 includes: Modbus protocol,
- The TSX SCY 21601 includes: Uni-Telway, Modbus and Character Mode protocols.

### Specifications

Specifications of the built-in link for the following 3 protocols:

	Uni-Telway (21601)	Modbus	Character Mode (21601)
Type	Master/Slave	Master/Slave	Half duplex
Flow	9600 bits/sec. Parameters can be set from 1200 to 19200 bits/sec.	9600 bits/sec. Parameters can be set from 1200 to 19200 bits/sec.	9600 bits/sec. Parameters can be set from 1200 to 19200 bits/sec.
Number of devices	28	32	-
Number of slave addresses	98	98 for the 21601, 247 for the 11601,	-
Length of bus without branching	1000 m	1300 m	1000 m
Message Size	240 bytes	256 bytes	4 Kb
Utilities	Message handling: Master/Slave. Slave/Slave. UNI-TE requests.	Read words/bits. Write words/bits. Diagnostics.	Send character strings. Receive character strings.



## 4.4 TSX SCY 21601 module's host channel compatibility

---

### TSX SCY 21601 Host Channel Compatibility

---

#### General

The cards supported by the host channel are:

- PCMCIA cards: **TSX SCP 111, 112, 114** which communicate with Premium/ Atrium, and Modicon PLCs and other Uni-Telway, Modbus and Character Mode compatible products. PCMCIA cards are also Jbus/Modbus compatible with 1000 Series PLCs
- The **TSX FPP 20** card is compatible with the following Fipway devices:
  - Model 40 PLCs (**TSX 47-455, TSX 67-455**, etc) in versions later than 5.0.
  - TSX 17 PLCs
  - PC compatible devices connected with **TSX FPC10** and **TSX FPC 20** cards.

<b>Note:</b> The <b>TSX FPP 10</b> card is not supported by the host channel.
---

---

## 4.5 Installation

---

### Installation

---

#### General

The **TSX SCY 11601/21601** modules are installed in a Premium/Atrium PLC station rack.

These are included in an X-Way network architecture based on 7 Series, Micro, Premium and Atrium PLCs.

The **TSX SCY 11601** communication module adds the following features to a PLC station:

- A Modbus isolated mono-protocol RS 485 communication channel.

The **TSX SCY 21601** communication module adds the following features to a PLC station:

- A multi-protocol isolated RS 485 communication channel,
- A standard PCMCIA communication card slot.

The **TSX SCY 11601/21601** modules can be installed in any available slot in a Premium/Atrium PLC station rack.

---

**Maximum  
number**

A **TSX SCY 11601** module supports a maximum of 1 discrete RS 485 type communication channel built into the module.

A **TSX SCY 21601** module supports a maximum of 2 discrete communication channels:

- one RS 485 channel built into the module,
- one channel from PCMCIA card which can be integrated into the module.

Since the maximum number of discrete channels managed by a PLC station is related to the type of processor installed, the number of **TSX SCY 11601** or **TSX SCY 21601** modules in a station will therefore rely on:

- The type of processor installed,
- The number of discrete channels already used, other than communication channels.

Consequently, the user must perform a global memory usage on his/her PLC station in order to know how many discrete channels are already in use, and thus determine the number of **TSX SCY 11601** or **TSX SCY 21601** modules which may be used.

**Note:** Discrete channel recognition is defined in the Premium (See Premium and Atrium using Unity Pro Manual, Processors, racks and power supply modules, Catalog of TSX 57 Processors)/Atrium (See Premium and Atrium using Unity Pro Manual, Processors, racks and power supply modules, Catalog of Atrium Processors) PLC installation Manual.

**Connection/  
Disconnection**

**TSX SCY 11601/21601** modules can be **connected or disconnected whilst the power is on**. These devices **do not have** a memory save function.

When one of the two modules is disconnected from the rack, its internal memory is wiped. The module goes through an initialization phase once it is reconnected.

A **TSX SCY 21601** module which has a PCMCIA card installed may be disconnected when the power is on.

**Note:** Conversely, PCMCIA cards, used in TSX SCY 21601 may not **be disconnected** while the power is on.

## 4.6 Operation

---

### Operation

---

**TSX SCY 11601  
module: General**

The **TSX SCY 11601** module manages a communication channel (channel 0):

- channel 0: Modbus protocol on an RS 485 half duplex isolated, standardized physical link, with a speed limited to 19200 bits per second.

---

**TSX SCY 21601:  
General**

The **TSX SCY 21601** module manages two independent communication channels which each have their own functions:

- Channel 0 deals with Uni-Telway, Modbus and Character Mode protocols on an isolated physical link, and with standardized RS 485 half duplex with a speed limited to 19200 bits per second.
- Channel 1 receives one of the following PCMCIA communication cards:
  - Field Bus: **TSX SCP 111** (RS232), **TSX SCP 112** (current loop), **TSX SCP 114** (RS 422/RS 485) Uni-Telway, Modbus and Character mode cards.
  - Cell network: **TSX FPP 20** Fipway card.

The choice of PCMCIA card and protocol is made when the **TSX SCY 21601** module's communication channels are configured using Unity Proware.


---

## 4.7 Module Visual Diagnostics

### Visual module diagnostics

#### General

Three LEDs are located on the front panel of **TSX SCY 11601/21601** modules. These LEDs display information on the **module's operating status** and on the **communication status** of the **built-in** serial link.



RUN (green)  
ERR (red)  
CH0 (yellow)

The host channel's communication status is set by the ERR and COM LEDs in the PCMCIA cards (See *Visual diagnostics of PCMCIA cards*, p. 112) on the serial or Fipway link.

LED meaning:

RUN	ERR	CH0	Comments
○	(1)	(1)	Module powered-down or module failure
●	○	○	No communication on the built-in channel.
●	○	● (2)	Communication on built-in channel.
●	●	(1)	Serious fault on built-in channel.
●	○	○	Configuration fault. No device OK on the channel.
●	○	○	Device fault on built-in channel (only for TSX SCY 21601).
○	○	○	Self-tests running.
Key:			
○ Off		○ Flashing	
● On		(1) Neutral status. (2) Line activity display.	

## 4.8 Built-in Channel Connection

---

### At a Glance

#### Aim of this Section

This section describes the different ways to connect the built-in channel of **TSX SCY 11601/21601** modules.

---

#### What's in this Section?

This section contains the following topics:

Topic	Page
At a Glance	87
Connection of TSX SCY 21601 to Uni-Telway field bus	89
Reminder on adapting RS 485 distributed line for the TSX SCY 21601	91
Example of Uni-Telway architecture	93
Connection of TSX SCY 11601/21601 modules to the Modbus field bus	94
Reminder on single line polarization in RS 485	95
Example of Modbus architecture	97
Connecting the TSX SCA 50 unit	98
Character Mode connection for TSX SCY 21601	99
Consumption of TSX SCY 11601/21601 modules	100

---


## At a Glance

### TSX SCY 11601 module: General

Cabling accessories designed to connect the **TSX SCY 11601** module's RS 485 base link allow the following connection:

- Connection to the Modbus network via a **TSX SCA 50** device by a **TSX SCY CM 6030** cable or a **TSX SCA 64** device by a **TSX SCY CM 6530** cable.

Illustration:




**TSX SCY 11601  
module: General**

Cabling accessories designed to connect the **TSX SCY 21601** module's RS 485 base link allow the following connections:

- Connection to the Uni-Telway network via a **TSX SCA 50** device by a **TSX SCY CU6030** cable or a **TSX SCA 62** device by a **TSX SCY CU 6530** cable.
- Connection to the Modbus network via a **TSX SCA 50** device by a **TSX SCY CM 6530** cable.
- Connection to standard RS 485 devices using a link adapted connector via the **TSX SCY CU 6030** or **TSX SCY CM 6030** cable.

Illustration:






## Connection of TSX SCY 21601 to Uni-Telway field bus

### General


The module's built-in communication channel is connected to the Uni-Telway field bus by the **TSX SCY CU 6030** connection cable, via the **TSX SCA 50** connection device.

Illustration:




Description of leads

Lead TSX SCY CU 6030:




Lead TSX SCY CU 6530:



## Reminder on adapting RS 485 distributed line for the TSX SCY 21601

### General

This adaptation is used for Uni-Telway networks.  
Diagram of normal Uni-Telway network architecture:



### Connection of network units

The network is made up of one shielded twisted pair. The connection of the network's different units is carried out as follows:

STEP	INSTRUCTION
1	Link all outputs labeled + (Tx+, Rx+) to the network wire labeled: L+.
2	Link all outputs labeled - (Tx-, Rx-) to the network wire labeled: L-.
3	Adapt the network's impedance using two adaptation nodes (Zc) located on the two end stations of the network.
4	For of distributed polarization of the network, link the L+ 5 V wire to the L- 0 V wire via two polarization resistors (Pr = 4,7 KΩ). Do this for each station. This polarization will keep the network stable while not in use.


**Integral  
Characteristics**

Integral characteristics are:

- Up to 32 stations
  - Maximum range: about 1300 m
  - Bus Topology
  - $\leq 15$  m Branching
  - 2 wire half duplex
  - Adapting the line end on end units
  - Adapting the  $P_r = 4.7 \text{ K}\Omega$  distributed line
-

## Example of Uni-Telway architecture


### Example



## Connection of TSX SCY 11601/21601 modules to the Modbus field bus


### General Points

The built-in channel is linked to the bus via the **TSX SCA 50** device through the **TSX SCY CM 6030** connection cable.  
Illustration of **TSX SCY 21601**:



### Lead description


Description of the TSX SCY CM 6030 cable



## Reminder on single line polarization in RS 485

### General

Single line polarization is the polarization used for Modbus type networks.  
General architecture diagram of a RS 485 network:



**Connection of network units**

The network is made up of one shielded twisted pair. The connection of the network's different units is carried out as follows:

STEP	INSTRUCTION
1	Link all outputs labeled + (Tx+, Rx+) to the network wire labeled: L+.
2	Link all outputs labeled - (Tx-, Rx-) to the network wire labeled: L-
3	Adapt the impedance of the network to the average of the two adaptation elements (Rc) located on the two end stations of the network.
4	Connect the wire L+ to 5 V and the wire L- to 0.V via the two polarization resistors ( $R_p = 470 \Omega$ ) to achieve distributed polarization of the network. This polarization continuously circulates a current in the network. Adaptation can be anywhere on the network (in practice it is generally done at master level). There must be single polarization for the entire network, whatever its range.

**Integral Characteristics**


Integral characteristics are:

- Up to 32 stations,
  - Maximum range: about 1300 m,
  - Bus topology,
  - $\leq 15$  m Branching,
  - 2 wire half duplex,
  - Adapting the line end on end units,
  - Distributed line adaptation  $R_p = 470 \Omega$ .
-



## Example of Modbus architecture

### Example



## Connecting the TSX SCA 50 unit


### Important

- Note:** on a Modbus bus you must:

  - Polarize the line, in general in only one spot (usually on the master device) with  $470\ \Omega$  resistance. Connect  $R_{\text{pull-down}}$  to EMI- (D(A)) and  $R_{\text{pull-up}}$  to EMI+ (D(B)).
  - Adapt the line on the two end devices with a resistance of  $150\ \Omega$  between EMI+ and EMI- (EMI+ is already connected internally by the card).


### Modbus without line adaptation

The following diagram shows the wiring of a slave in intermediate position to the Modbus network:



### Modbus with line adaptation and polarization

The following diagram shows the wiring of a master, placed at the end of the Modbus network:



## Character Mode connection for TSX SCY 21601


---

### General

The **TSX SCY CM 6030** cable should be used to connect the **TSX SCY 21601** module with an RS 485 standard device.

Users should connect the Character Mode **TSX SCY 21601** to a Half duplex RS 485 standard device using the **TSX SCY CM 6030** connection cable, adding a connector adapted for the intended device to the end of the cable, and linking the necessary signals (see lead connection in *Connecting the TSX SCA 50 unit, p. 98*).

Illustration:



## Consumption of TSX SCY 11601/21601 modules

---

### Values

This table shows the consumption of **TSX SCY 11601** and **TSX SCY 21601** modules without a PCMCIA card (for 21601) or connection to the built-in channel:

Voltage	Typical Current	Maximum Current	Power dissipation
5 Volts	350 mA	420 mA	2.1 W max.

---

---

# Implementation of PCMCIA cards

# 5

---

## At a Glance

### Aim of this Chapter

This Chapter provides an overview of the hardware implementation for PCMCIA communication cards on Premium/Atrium PLCs.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
5.1	At a Glance	102
5.2	Description	104
5.3	Connecting the PCMCIA card reception channel	105
5.4	Connection of the TSX SCP 111 card	113
5.5	Connection of the TSX SCP 112 card	116
5.6	Connection of the TSX SCP 114 card	128
5.7	Summary of connection devices	137
5.8	Precautions when connecting PCMCIA cards	138
5.9	Consumption of PCMCIA cards	139

## 5.1 At a Glance

### At a Glance

#### General


Premium/Atrium PLC stations connect to communication networks, buses and links through PCMCIA communication cards.

The card to be connected is a metal device whose dimensions comply with PCMCIA extended type III.

PCMCIA cards are installed in the host slot of the processor and/or **TSX SCY 21601** module in PLCs from the Premium family.

PCMCIA cards can also be used in devices which have slots for type III cards, such as **FT 2100** terminals or PC-compatible third-party devices, for example.

Illustration:




**Note:** It is prohibited to connect PCMCIA cards when the power is switched on.

PCMCIA cards are installed, operated and maintained using Unity Pro programming and operation software for all PLCs in the Premium family.

**TSX SCP 11•  
cards.**

Series link PCMCIA cards.

Each **TSX SCP 111, 112, 114** PCMCIA card supports a different physical layer. This family comprises three products:

Product reference	Physical layer	Illustration
<b>TSX SCP 111</b>	RS 232-D link.	
<b>TSX SCP 112</b>	Current loop link (20 mA).	
<b>TSX SCP 114</b>	RS 485 link (RS 422 compatible)	

All three cards, **TSX SCP 111, 112** and **114**, support the following communication protocols:

- Modbus protocol,
- Uni-Telway protocol,
- Character Mode asynchronous link.

## 5.2 Description


### Description

**General** PCMCIA type III (extended) communication cards are built into a metal case with the following dimensions:

- Length: 85.5 mm.
- Width: 51 mm.
- Height: 10 mm.

The front of the card is designed to display communication status and provides the physical connection to the network.

**Mechanical configuration** The mechanical configuration of the card must be adapted by mounting a removable cover, depending on the type of installation desired:

Type of installation	Configuration	Illustration
Installation on a Premium type processor or on a <b>TSX SCY 21601</b> communication module.	Removable cover with wings. Screws are provided to fix it to the host module (marked <b>3</b> on illustration).	
Installation on an Atrium type processor.	Removable cover with wings. Screws are provided to fix it to the Atrium processor (marked <b>2</b> on illustration).	
Installation onto a PC compatible device.	Removable cover (marked <b>1</b> on illustration).	

**Note:** The covers with wings, mounted on PCMCIA cards, prevent any accidental removal when switched on and guarantee that the card remains in good working order. The two covers **1** and **3** are provided with the PCMCIA card. Cover **2** is provided with the Atrium processor.

Connection to the network is achieved by connecting the link cable to the front of the card. A guidance system is used to prevent anything being mounted incorrectly. The product reference label informs the user of the type of physical layer supported by the card.



---

## 5.3 Connecting the PCMCIA card reception channel

---

### At a Glance

#### Aim of this Section

This Section describes the installation of PCMCIA cards in the reception channel of the **TSX SCY 21601** module.

#### What's in this Section?


This section contains the following topics:

Topic	Page
Precautions to be taken when connecting PCMCIA card	106
Connection of PCMCIA cards	107
Product references for PCMCIA cards and installation	108
Mounting cards and cables	109
PCMCIA card operation display	111
Visual diagnostics of PCMCIA cards	112

## Precautions to be taken when connecting PCMCIA card

---

### General

	<b>CAUTION</b>
	The PCMCIA card <b>must be handled with the power switched off</b> <b>Failure to follow this precaution can result in injury or equipment damage.</b>

When removing or inserting the card, the unit is not guaranteed to be operational. There is no procedure for a warm start between the PCMCIA card and the **TSX SCY 21601** host device.

In the event that the operating environment does not allow the application to be stopped by switching off the PLC processor, you are recommended to remove the **TSX SCY 21601** module with the PCMCIA card.

The PCMCIA card must be equipped with a PLC version cover and be screwed into the **TSX SCY 21601** host module before the unit is switched on Mechanical configuration (See *Mechanical configuration*, p. 104)).

---

## Connection of PCMCIA cards

### General

Connecting PCMCIA cards requires specific cables and connection devices, depending on the type of models.

### Series link cards

Product references of cables and branch devices to be used with series link PCMCIA cards according to the different protocols:

PCMCIA card	Uni-Telway	Modbus	Character Mode
<b>TSX SCP 111</b> (RS 232)	<b>TSX SCP CD 1030/1100</b> in point to point mode	<b>TSX SCP CD 1030/1100</b> in point to point mode	<b>TSX SCP CD 1030/1100</b>
	<b>TSX SCP CC 1030</b> in multidrop mode via a modem	<b>TSX SCP CC 1030</b> in multidrop mode via a modem	
<b>TSX SCP 112</b> (Current Loop)	<b>TSX SCP CX 2030</b>	<b>TSX SCP CX 2030</b>	<b>TSX SCP CX 2030</b>
<b>TSX SCP 114</b> (RS 422/RS 485)	<b>TSX SCP CU 4030</b> and <b>TSX SCA 50</b>	<b>TSX SCP CM 4030</b> and <b>TSX SCA 50</b>	<b>TSX SCP CU 4030</b> and <b>TSX SCP CM 4030</b>

## Product references for PCMCIA cards and installation

---

### Installation

Table showing options for installing PCMCIA cards in processor host channels and in the **TSX SCY 21601** module:

Product references	Processor host channel	TSX SCY 21601 host channel
TSX SCP 111	Yes	Yes
TSX SCP 112	Yes	Yes
TSX SCP 114	Yes	Yes

### Application-specific channels and network connections

Table showing the number of application-specific channels or network connections used by PCMCIA cards:

Product references	Number of application-specific channels	
	Card in the processor	Card in the TSX SCY 21601 module
TSX SCP 111	0	1
TSX SCP 112	0	1
TSX SCP 114	0	1

### Maximum number of application-specific channels per processor type


Number of "application-specific" channels supported:

- Premium (See Premium and Atrium using Unity Pro Manual, Processors, racks and power supply modules, Catalog of TSX 57 Processors)
  - Atrium (See Premium and Atrium using Unity Pro Manual, Processors, racks and power supply modules, Catalog of Atrium Processors)
-

## Mounting cards and cables

### Details about PCMCIA cards

Illustration:




PCMCIA cards are made up of the following elements:

Number	Designation	Comments
1	Equipped card	Receives electronic components.
2	Body made of zamac	-
3	PCMCIA connector	Connector with 20 connection points.
4	Upper cover	Houses the product reference label which shows the type of PCMCIA card
5	Removable cover	Ensures the card is displayed in its slot. The names of the two LEDs are printed on the front of the removable cover. This cover is also used to fix the PCMCIA card on the processor or on the <b>TSX SCY 21601</b> module.
6	Linking cable with ferule	The ferule placed on the end of the PCMCIA card cable side prevents the cable being pinched by the removable cover. This ferule also eliminates the risk of causing a bending radius which can damage the quality of the link.

Assembly

To assemble the transmission support for the card first remove the cover which is screwed on the device then follow the instructions below:

Step	Instruction	Illustration
1	Connect the cable	<div>Host on processor or TSX SCY 21601</div> 
2	Place the appropriate cover on the device, taking care to insert the ferule in the slot provided in order to fix the cable to the card.	
3	Screw on the cover	
4	Insert the card in the slot provided in the host device.	
5	Screw in the card to stop it being moved when switched on, and to ensure it functions effectively.	

# PCMCIA card operation display

**General** Two diagnostics LEDs are located on the front of the card. They inform the user on how exchanges between the device supporting the PCMCIA card and the related device are functioning.

**Illustration**

Number	Description	Diagram
1	Error "ERR" LED (normally off) displays errors. This is red.	A line drawing of a PCMCIA card. On the left side of the card, there are two LEDs. The top LED is labeled 'ERR' and the bottom LED is labeled 'COM'. Two lines with numbers point to these LEDs: line 1 points to the 'ERR' LED and line 2 points to the 'COM' LED. The card is shown at an angle, with its top edge towards the top right of the diagram.
2	The "COM" communication LED displays the line activity. This LED is yellow on <b>TSX SCP 111/112/114</b> cards.	













## Visual diagnostics of PCMCIA cards

### General

Depending on their state, LEDs of the PCMCIA card indicate the operating mode for communication, as well as the card diagnostics.

### TSX SCP 111/ 112/114 cards

State of LEDs:

ERR	COM	Meaning	Corrective actions
		Device switched off No dialog	Check the power supply, Card not operational.
		Operating normally	-
	(1)	Serious error	Change the card.
		Functional fault	Check the configuration and the connection to the communication bus.
		Functional fault	Check the configuration.
<b>Key:</b>			
	Off		
	On		
	Flashing		
(1)	Neutral status		



---

## 5.4 Connection of the TSX SCP 111 card

---

### At a Glance

---

**Subject of this Section** This section deals with the hardware installation of **TSX SCP 111** PCMCIA cards.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
Point to point connection in Character Mode (DTE ´ DTE)	114
Uni-Telway, Modbus or Character Mode via Modem	115

---


## Point to point connection in Character Mode (DTE ´ DTE)

### General

The **TSX SCP 111** RS 232 D physical support card is inserted either in the processor or in the **TSX SCY 21601** module. It is connected to the related device with the **TSX SCP CD 1030/1100** cable.

The devices to be connected are DTE to DTE (Data Terminal Equipment ). For example: terminal, printer, etc.


Illustration:



### Description of TSX SCP CD 1030 cable

Illustration:

The PCMCIA 20-pin mini-connector supports the signals:




## Uni-Telway, Modbus or Character Mode via Modem

### General

The PCMCIA card is connected to a Uni-Telway, Modbus or Character Mode bus, via a modem and a telephone link (DTE/DCE type), using a **TSX SCP CC 1030** cable.

The connected devices are DCE type, for example a modem or a converter.

Illustration:



### Description of the TSX SCP CC 1030 cable

Illustration:

The PCMCIA 20-pin mini-connector supports the signals:

Connector  
SUB-D 25M



# 5.5                      Connection of the TSX SCP 112 card

---

## At a Glance

**Subject of this Section**                      This section deals with the hardware installation of **TSX SCP 112** PCMCIA cards.

---

**What's in this Section?**                      This section contains the following topics:

Topic	Page
Connection of the TSX SCP 112 card	117
Connecting in point to point mode	118
Multidrop connection	119
Dynamic performance	120
TSX SCP 112 connection with April 5000/7000 PLCs	122

---

## Connection of the TSX SCP 112 card

### General


The **PCMCIA TSX SCP 112** card is used to connect a Premium/Atrium PLC station to a loop link with a current of 20 mA in point to point or multidrop.

**Note:** In all cases the power supply is:  $24\text{ V} \pm 20\%$ , external to the **TSX SCP 112** card, and must provide the current required for the current loop supply .

The **TSX SCP CX 2030** cable is used for this type of connection (length 3 m).

Description of the TSX SCP CX 2030 cable:

The PCMCIA 20-pin mini-connector supports the signals:




**Note:** A screw terminal block needs to be installed to connect the **TSX SCP 112** card.

## Connecting in point to point mode

### General

The diagram below describes the wiring principles for **TSX SCP 112** loop current PCMCIA cards in point to point. Point to point is only carried out according to 20 mA mode when idle.

Illustration:




**Note: Important:** the cable shielding must be connected at the shortest point in the junction blocks.

## Multidrop connection

### General

Multidrop is only carried out in 0 mA idle mode. The send cable and receive cable are set in parallel. The master is set by the software.

Example of connection of n TSX SCP 112 cards:



**Note: the cable shielding must be connected at the shortest point in the junction blocks.**

## Dynamic performance

### General


The flow of a current loop link is limited by the cross-section and the length or the cable used.

The user should refer to the two charts below to evaluate the performance which can be obtained using this application.

### Point to point

These curves are given for a shielded two pair cable (send through one pair, reception through the other) while observing all the precautions of use.


speed in Kbps



### Multidrop

The chart below is given for a shielded cable with a conductor cross-section of 0.34 mm<sup>2</sup>. The connection is made according to the parallel multidrop diagram below. Using conductors with a larger cross-section improves the quality of the signals transmitted:

Number of connected stations





Multidrop link performance is optimized when there are more connected stations. The line is busier, which improves the quality of the transmitted signal.

When the connection is made according to the diagram above (See *General*, p. 119), the number of stations can be increased artificially (to a maximum of 16 stations) by loading the line at one of its ends.

This can be carried out by incorporating a load resistance.

This load resistance can be connected to any junction block providing it is between pins 17 and 19 of cards **TSX SCP 112**.

The value of  $R_L$  resistance simulating the load of "N" stations is determined by the formula:

$$R_c = \frac{U}{N \times 20}$$

$R$  in  $K\Omega$

$U$  = external supply voltage

$N$  = station number to be simulated

Example:

An installation is physically made up of 6 stations connected in multidrop with an external 24 V supply.

The performance of the line is that of 10 stations, simulating the load of 4 additional stations by a resistance:

$$R_c = \frac{24}{4 \times 20} = 0,3 K\Omega$$

**Note:** The load resistance must not have an inductive effect or there is a risk that it will not operate.

Use a thick layer of resistance.

---

## TSX SCP 112 connection with April 5000/7000 PLCs

### General


PCMCIA card **TSX SCP 112** 20 mA current loop is used to connect April communication modules **JBU0220** and **JBU0250**. The **multidrop connection** of PCMCIA card **TSX SCP 112** to modules **JBU0220** and **JBU0250** is carried out in **series mode**. To connect April modules refer to reference manual TEM60000F.

**Note: Important:** You must configure card **TSX SCP 112** in **point to point mode** in the Unity Pro configuration screen, for both the point to point or the multidrop series.

**Note:** The current loop authorizes a current of 20 mA when idle, in point to point as well as in multidrop mode.  
If a slave is switched off the sender of this slave become active and the line is available.  
If the loop supply is offset on one of the slaves, switching this slave off will cause communication to be interrupted.


### Point to point link: Module JBU0220 or active JBU0250

#### Illustration




**Point to point  
link: active  
TSX SCP 112  
card**

Illustration:



**Mixed terminal  
links**

Illustration:




**Multidrop type link**


The following examples describe the different wiring possibilities for card **TSX SCP 112** with modules **JBU0220/0250**.

**Note:** The 24 V supply of each TSX SCP 112 present on the loop must be connected, whether passively or actively, otherwise the link will not function. These supplies must not have any shared (potential) point between them. Do not connect the -24 V supply to the earth.


Example 1: Active master TSX SCP 112 multidrop




### Example 2: active send/receive JBU0220/0250 multidrop



Example 3: Multidrop master JBU0220/0250 active send/receive - slaves  
TSX SCP 112



## Example 4: Multidrop active master TSX SCP 112



# 5.6 Connection of the TSX SCP 114 card

---

## At a Glance

**Subject of this Section** This section deals with the hardware installation of **TSX SCP 114** PCMCIA cards.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
Connection to the Uni-Telway network	129
Connecting to the Modbus bus	132
Multi-protocol asynchronous link connection RS 422	135

---



## Connection to the Uni-Telway network

---

### General

The **TSX SCP 114** RS 485 physical support card, connects to the UNI-TELWAY network by the **TSX SCP CU 4030** cable via the **TSX SCA 50** connection device, or by the **TSX SCP CU 4530** cable (provided with SUB-D 15 pin connector) via device **TSX SCA 62**. The card is inserted in the processor or in the module **TSX SCY 21601**.


The **TSX SCA 50** is passive and made up of a printed circuit board fitted with 3 sets of screw terminal blocks. It is used to connect a station by branching on the main section of a Uni-Telway bus. It ensures continuing operation of electrical signals, shielding and end of line adaptation function.

---

### Type of connection

The cable of the PCMCIA card has bare wires at its ends which the user must connect to the terminal located inside the device.

Illustration:




**Note:** The branching device configures the wiring system of the card and a branching type of connection system.

---


**Description of  
TSX SCP CU 4030  
cable**

Illustration:  
The PCMCIA 20-pin mini-connector  
supports the signals:




**Connection via a  
TSX SCA 62  
device**

Illustration:



**Description of  
TSX SCP CU 4530  
cable****Illustration:**

The PCMCIA 20-pin mini-connector  
supports the signals:



## Connecting to the Modbus bus

---

### General


The **TSX SCP 114** PCMCIA card is connected to the Modbus bus using the **TSX SCP CM 4030** link cable. This cable is connected to the branching device **TSX SCA 50**.

---

### Type of connection

The cable of the PCMCIA card has bare wires at its ends which the user must connect to the terminal located inside the device.

Illustration:




**Note:** The length of the cable used (3 m), makes it possible to link a device to a **TSX SCA 50** connection device located within a 3 meter radius of the card. This length ensures connection inside a standard cabinet

---

### Description of the TSX SCP CM 4030 cable

Illustration:

The PCMCIA 20-pin mini-connector supports the signals:




**Note: Important:** on a Modbus bus you must:

- Polarize the line, in general in only one spot (usually on the master device) with 470  $\Omega$  resistance. Connect  $R_{\text{pull-down}}$  to EMI- (D(A)) and  $R_{\text{pull-up}}$  to EMI+ (D(B)).
- Adapt the line on the two end devices with a resistance of 150  $\Omega$  between EMI+ and EMI- (EMI+ is already connected internally by the card).


**Important:** to connect **TSX SCP 114** card to a PLC Series 1000 (S1000), EMI+ must be connected to L-.

Connecting  
Modbus to  
TSX SCA 50  
device

Connection with no line terminator:



Connection of a SCA 50 with line terminator:



## Multi-protocol asynchronous link connection RS 422

---

### General

Connecting the **TSX SCP 114** card in Character Mode does not require any specific accessories.


The product reference for the RS 485/RS 422 PCMCIA card linking cable is **TSX SCP CX 4030**. It is 3 meters in length.

---

### Type of connection

The **TSX SCP 114** PCMCIA card is connected in point to point to an RS 422A standard device VAX station type.


Illustration:



**Description of the  
TSX SCP CX 4030  
cable**

Illustration:

The PCMCIA 20-pin mini-connector supports the signals:



See also *Character Mode connection for TSX SCY 21601, p. 99*  
(TSX SCY 21601 module integrated link)



## 5.7 Summary of connection devices

### Summary of PCMCIA card connection devices

#### TSX SCP 111

Type of cable	Product reference	Designation
Modem cable	TSX SCP CC 1030	Connection cable via Modem DTE/ DCE 9 signals RS 232D, L = 3 m.
Standard cable	TSX SCP CD 1030 TSX SCP CD 1100	Connection cable DTE/DTE RS 232D, L = 3 m or 10 m.

#### TSX SCP 112

Type of cable	Product reference	Designation
Current loop cable	TSX SCP CX 2030	Current loop cable 20 mA, L = 3 m.

#### TSX SCP 114

Type of cable	Product reference	Designation
Universal cable	TSX SCP CX 4030	Universal cable type RS 485 and RS 422A, L=3 m.
Uni-Telway cable	TSX SCP CU 4030	Cable type RS 485, L=3 m.
Modbus cable	TSX SCP CM 4030	Cable type RS 485, L=3 m.
Connection device	TSX SCA 50	Connection device screwed to bus for RS 485 series link.
Connection device	TSX SCA 62	Connection device via connector to bus for RS 485 series link.
Converter device	TSX SCA 72	RS 232D/RS 485 converter device.

## 5.8                    Precautions when connecting PCMCIA cards

---

### Precautions for connecting PCMCIA cards

---

**Important**

Cards must be connected or disconnected in the host device (processor or **TSX SCY 21601**) **when the device is switched off.**

The ferule, placed in direct contact with the PCMCIA card device, is used to handle electrical interference carried by the link cable braids.

---

---

## 5.9 Consumption of PCMCIA cards

---

### Consumption of PCMCIA cards

---

#### TSC SCP 111

Table of consumption:

Voltage	Typical Current	Maximum Current	Power dissipation
5 volts	140 mA	300 mA	1.5 W max.

---

#### TSC SCP 112

Table of consumption:

Voltage	Typical Current	Maximum Current	Power dissipation
5 volts	120 mA	300 mA	1.5 W max.

---

#### TSC SCP 114

Table of consumption:

Voltage	Typical Current	Maximum Current	Power dissipation
5 volts	150 mA	300 mA	1.5 W max.

---



---

# TSX SCA 64 connection device



---

## At a Glance

### Aim of this Chapter

This Chapter introduces the functions of the **TSX SCA 64** connection device.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
6.1	General Introduction	142
6.2	Physical Description	144
6.3	Dimensions and Mounting	146
6.4	Installation	148
6.5	Bus Cable Shield Cabling	149
6.6	Device Configuration and Transmission Pair Polarization	154
6.7	Adapting the Line End	163

## 6.1 General Introduction

### General Introduction


**General Points** The **TSX SCA 64** unit is a cabling accessory, which allows a 2 or 4 wire mode communication module to be connected to a Modbus, Jbus or Jnet.

**In 2-Wire Mode** In this mode, connectable communication interfaces are:

- The built-in channel of the TSX SCY 11601/21601 modules, via a TSX CM 6530 cable,
- The TSX SCP/JNP 114 PCMCIA card, via a TSX SCP CM 6530 cable.

**Note:** Connection can be made to either the JM or the JS connector, regardless of channel configuration (master or slave).

**Illustration** This diagram shows the general principal for connecting in 2-wire mode for a TSX SCY 21601.



**In 4-Wire Mode**

In this mode, the connectable communication interface is:


- A PCMCIA TSX SCP/JNP 114 card, via a TSX SCP CM 4530 cable, through a TSX SCP CM 6530 cable.

Connect the TSX SCP CM 6530 cable to the:

- JM connector if the PCMCIA card channel is configured in master mode,
- JS connector if the PCMCIA card channel is configured in slave mode.

**Illustration**

This diagram shows the general principal for connecting in 4-wire mode.




## 6.2 Physical Description

### Physical Description

**Illustration**

This diagram shows the assembly plan for the TSX SCA 64 connection device.





**Nodes**

The following table describes the different nodes, which make up the connection device.

No	Description
1	Cover screws
2	Device cover
3	Screws fixing restart ground clamps
4	Restart ground clamps
5	Metallic part providing the ground link between the 2 cables
6	SUB D 15 pin female (JM) connector able to receive: <ul style="list-style-type: none"> <li>● In 2-wire mode: the male connector of a TSX SCY CM 6530 or TSX SCP CM 4530 connection cable, whether the channel is master or slave,</li> <li>● In 4-wire mode: the male connector of a TSX SCP CM 4530 connection cable, if the channel is master,</li> <li>● Or a TSX SCA 10 line terminator if the device is located at the beginning or end of the line,</li> <li>● Or a male analyzer connection cable connector</li> </ul>
7	1 micro-switch allowing configuration in 2-or 4-wire operation
8	SUB D 15 pin female (JS) connector able to receive: <ul style="list-style-type: none"> <li>● In 2-wire mode: the male connector of a TSX SCY CM 6530 or TSX SCP CM 4530 connection cable, whether the channel is master or slave,</li> <li>● In 4-wire mode: the male connector of a TSX SCP CM 4530 connection cable, if the channel is slave,</li> <li>● Or a TSX SCA 10 line terminator if the device is located at the beginning or end of the line,</li> <li>● Or a male analyzer connection cable connector</li> </ul>
9	4 micro-switches allowing polarization mode to be configured
10	Terminal to connect green/yellow ground wire
11	Connection terminals for the main connection cables providing bus continuity
12	Device Connection Base
13	Screw holes (4 diameter) to fix the device to a board or panel (60mm apart)
14	Main 2 or 3 pair cable providing bus continuity (max. 10 diameter), for connection to JA
15	5VDC power supply cable (for external polarization if required) for connection to JC
16	Main 2 or 3 pair cable providing bus continuity (max. 10 diameter), for connection to JB
17	Green/yellow device grounding cable
18	Main cable with corresponding ground format connected to local ground via a surge suppressor
19	Power supply cable and green/yellow ground wire
20	Main cable with corresponding ground format connected to local ground


**Note:** Nodes 14 and 16 are not included with the TSX SCA 64 device.

## 6.3 Dimensions and Mounting

### Dimensions and Mounting

#### Dimensions

This diagram shows the dimensions of the TSX SCA 64 connection device.




#### Mounting/Fixing

The device can be mounted either:

- on a board or panel, secured with 2 M4 screws (min. length 20mm),
- on a DIN profile - Refs. AM1-DP 200 or AM1-DE 200 (Schneider catalog references).

**Drilling Template** This diagram shows the plan for mounting on a board or panel.



(1) Screw hole diameter must be suitable for M4 screw

## 6.4 Installation

### Installation

#### Required Hardware

Installing the TSX SCA 64 device requires:

- a 2.5mm wide flat tipped screwdriver,
- a cross tipped screwdriver (PZ01).

#### Procedure

The labels in the text below correspond with those found in the description of the device.

Step	Action
1	Unscrew screw <b>1</b> with a PZ01 screwdriver, open cover <b>2</b> .
2	Fix device connection base to its support: <ul style="list-style-type: none"> <li>• either a DIN AM1-DP200 or AM1-DE 200 profile,</li> <li>• or a board or panel, and secure with 2 M4 screws (min. length 20mm).</li> </ul>
3	Prepare main cables <b>14</b> and <b>16</b> according to the connection type selected, as indicated on the following pages.
4	Position the ground clamps <b>4</b> onto the cables.
5	Position the ground link <b>5</b> , if necessary, according to the type of connection selected, as indicated on the following pages.
6	Connect the main cables (and the power supply cable if necessary) to terminal <b>11</b> according to the type of connection selected, as indicated on the following pages. The cable wires should have DZ5-CE005 cable ends (for the main cables) and DZ5-CE007 cable ends (for the power supply cable). Use a 2.5mm wide flat tipped screwdriver. Torque on terminal screw $\leq 0.25$ N.m.
7	Screw on the ground clamps and link with the screws <b>3</b> , using a cross tipped PZ01 screwdriver.
8	Connect the green/yellow ground wire <b>17</b> to connection terminal <b>10</b> .
9	Secure the cables with nylon clips. (Attach the green/yellow wire to the power supply cable if it is present).
10	Set the micro-switches <b>7</b> and <b>9</b> to the desired configuration; see configurations on following pages.
11	Break the scored tabs on the cover <b>2</b> to make way for the cables.
12	Mount the cover <b>2</b> and secure it with the screw <b>1</b> using a cross tipped PZ01 screwdriver.

---

# 6.5                      Bus Cable Shield Cabling

---

## At a Glance

---

**Aim of this Section**

This section describes the different local grounding principles for the bus.

**What's in this Section?**

This section contains the following topics:

Topic	Page
Local Grounding the Bus: General	150
Connecting the Shield to the Local Ground and to the Two Ends of the Cable (Recommended Cable Type)	151
Connecting the Shield to the Local Ground at One End of the Cable and to the Local Ground via a Surge Suppressor at the Other End	152
Connecting the Shielding to the Local Ground at One End and Isolating it From the Ground at the Other End.	153

---

## Local Grounding the Bus: General

### Introduction

The bus can be grounded in three different ways:

- connecting the shield to the local ground and to the two ends of the cable,
- connecting the shield to the local ground at one end and to the local ground via a surge suppressor at the other end,
- connecting the shielding to the local ground at one end and isolating it from the ground at the other end.

### Principle


Opposite each main cable path, a copper pad grounds the cable shields:

- The path shown **20** locally grounds the cable shielding.
- The path shown **18** locally grounds the cable shielding via a surge suppressor.

### Illustration

This diagram shows the principle for locally grounding the device as a whole.

#### TSX SCA 64




### Cable Preparation Template: Introduction

Certain precautions must be taken in order to ensure correct placement of the bus cables:

- following the stripping template,
- using the following cable ends:
  - DZ5-CE005 for the main cables,
  - DZ5-CE007 for the power supply cable.

This diagram shows the local grounding principle for the device as a whole.




## Connecting the Shield to the Local Ground and to the Two Ends of the Cable (Recommended Cable Type)

### Principle


The two grounding tracks should be linked via the ground link **5** shown. End devices differ in that they only have one cable. Where this is the case, the ground link **5** shown is not required as long as the cable is positioned in slot **20** shown in the diagram.

### Illustration

This diagram shows the principle for locally grounding the cable.



Connecting several devices together:



## Connecting the Shield to the Local Ground at One End of the Cable and to the Local Ground via a Surge Suppressor at the Other End


### Principle

Only cable **16** shown is connected to the local ground, cable **14** shown is connected to the local ground via a surge suppressor.


**Note:** Ground link **5** shown is not used

### Illustration

This diagram shows the principle for locally grounding the cable.



Connecting several devices together:





## Connecting the Shielding to the Local Ground at One End and Isolating it From the Ground at the Other End.



### Principle

Only cable **16** shown is connected to the local ground, cable shielding **14** shown is isolated from the ground by a thermo-retractable tube (not included).

**Note:** In this case, ground link **5** shown is not used.

### Illustration

This diagram shows the principle for locally grounding the cable.



---

# 6.6 Device Configuration and Transmission Pair Polarization

---

## At a Glance

**Aim of this Section** This section contains the different configurations of the TSX SCA 64 device.

**What's in this Section?** This section contains the following topics:

Topic	Page
2-wire Configuration with Data Pair Polarization by a Station	155
2-Wire Configuration with Data Pair Polarization via a 5VDC External Power Supply	157
4-wire Configuration with Polarization of One Pair by the Master Station and the Other by a Slave Station	159
4-wire Configuration with 2-pair Polarization via 5VDC External Power Supply	162

## 2-wire Configuration with Data Pair Polarization by a Station

### Introduction

Main cables **14** and **16** are 2-pair cables:


- One RXD1, RXD0, pair.
- One COMMON, COMMON, pair

Green/yellow wire **17** is connected to the module's ground terminal.

**Note:** This pair is only polarized once on the whole bus.

### Illustration

This diagram shows a configuration with shielding connection at one end only.



**Position of the Switches**

This table shows the switch positions.

Switches	Position on	
	master station device	slave stations
S1	2W	2W
S2	ON	OFF
S3	OFF	OFF
S4	OFF	OFF
S5	OFF	OFF

---

## 2-Wire Configuration with Data Pair Polarization via a 5VDC External Power Supply

### Introduction

Main cables **14** and **16** are 2-pair cables:

- One RXD1, RXD0, pair.
- One COMMON, COMMON, pair


Power supply cable **15** is linked to an external 5VDC power supply.

Green/yellow wire **17** is connected to the module's ground terminal.

**Note:** The pair must only be polarized once on the whole bus.

### Illustration

This diagram shows a configuration with shielding connection at one end only.



**Position of the Switches**

This table shows the switch positions.

Switches	Position on	
	Device receiving power supply	Other devices
S1	2W	2W
S2	OFF	OFF
S3	OFF	OFF
S4	ON	OFF
S5	OFF	OFF

---

## 4-wire Configuration with Polarization of One Pair by the Master Station and the Other by a Slave Station

### Introduction

Main cables **14** and **16** are 3-pair cables:

- One RXD1, RXD0, pair.
- One TXD1, TXD0, pair.
- One COMMON, COMMON, pair


Green/yellow wire **17** is connected to the module's ground terminal.

#### Note:

- Each pair must only be polarized once on the whole bus,
- These diagrams show a configuration with shielding connection at one end only.

### Illustration

This diagram shows a configuration with RXD1, RXD0 pair polarization by the master station connected to JM.




Position of the Switches

This table shows the switch positions.

Switches	Positions on
	master station device
S1	4W
S2	ON
S3	OFF
S4	OFF
S5	OFF

Illustration

This diagram shows a configuration with TXD1 and TXD0 pair polarization by one of the slave stations connected to JS.





**Position of the  
Switches**

This table shows the switch positions.

Switches	Positions on	
	one of the slave stations	other slave stations
S1	4W	4W
S2	OFF	OFF
S3	OFF	OFF
S4	OFF	OFF
S5	ON	OFF

## 4-wire Configuration with 2-pair Polarization via 5VDC External Power Supply

### Introduction

Main cables **14** and **16** are 3-pair cables:

- One RXD1, RXD0, pair.
- One TXD1, TXD0, pair.
- One COMMON, COMMON, pair


Power supply cable **15** is linked to an external 5VDC power supply.

Green/yellow wire **17** is connected to the module's ground terminal.

**Note:** Each pair must only be polarized once on the whole bus.

### Illustration

This diagram shows a configuration with shielding connection at one end only.



### Position of the Switches

This table shows the switch positions.

Switches	Position on	
	Device receiving power supply	Other devices
S1	4W	4W
S2	OFF	OFF
S3	ON	OFF
S4	ON	OFF
S5	OFF	OFF

---

# 6.7                    Adapting the Line End

---

**At a Glance**

**Aim of this Section**                    This section contains information on line end adaptations on TSX SCA 64 devices.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
Line End Adaptation	164
Signals on the JM and JS SUB-D15 Pin Connectors	167

---

## Line End Adaptation

---

### At a Glance


Each end of the bus cable must have a line end jack adaptor. This line end jack adaptor can be plugged into free connectors on either JM (master) or JS (slave) on TSX SCA 64 devices, located at the ends of the bus.

A TSX SCA 10 kit consisting of 2 SUB D 15 pin connectors plus accessories (cover, screws, wiring etc.) enables the user to configure and set up the line end jacks.

---


### Illustration

This view shows a line end jack.




### TSX SCA 64 Mounting Example

This example shows a communication bus with 4 TSX SCA 64 connection devices.



**Installing Line  
End Jacks:  
At a Glance**

The configuration is attained by plugging each SUB D 15 pin 2-wire connector (supplied) into the sockets, enabling line adaptation.  
This diagram shows the configuration:




**Mounting  
Procedure**

Installation

Status	Action
1	Plug the wires supplied into the SUB D 15 pin connectors as shown above.
2	Put the connector into place in one of the half-covers (the connector can be either way up).
3	Attach the latch screw.
4	Put the sleeve into place.
5	Cover it all with the other half-cover, taking care not to damage the wires.
6	Screw in or clip on the two half-covers (depending upon the type included).
7	Use the blank labels provided to show utilization. <b>Note:</b> Cable clamps and/or other accessories should not be used.

**Connecting an Analyzer**

The JM or JS connectors on the TSX SCA 64 device can support a frame analyzer, which is connected by a SUB D 15 (male) pin connector. Signals relating to each pair are available on the device connectors as indicated in the diagram below. This diagram shows the connections for different pairs of the analyzer cable.



## Signals on the JM and JS SUB-D15 Pin Connectors

**At a Glance** The table below presents the different signals for each of the connectors:


<b>JM Sub-D15: Master</b>				<b>JS Sub-D15: Slave</b>	
Names (modbus.org)	Function	Pin	Interface	Names (modbus.org)	Function
RXD1	Master D1 bus signal to slaves	1	Bus	RXD1	Master D1 bus signal to slaves
LT0	TXD pair RC terminator	2	Bus	LT0	TXD pair RC terminator
LT1	TXD pair R terminator (not used)	3	Bus	LT1	TXD pair R terminator (not used)
RXD0	Master D0 bus signal to slaves	4	Bus	RXD0	Master D0 bus signal to slaves
TXD1	Slave D1 bus signal to master	5	Bus	TXD1	Slave D1 bus signal to master
RXD0M	RXD0 reception from master	6	Device	RXD0S	RXD0 reception from slave
TXD0M	TXD0 transmission from master	7	Device	TXD0S	TXD0 transmission from slave
Common	Bus 0V common	8		Common	Bus 0V common
LR0	RXD pair RC terminator	9	Bus	LR0	RXD pair RC terminator
LR1	RXD pair R terminator (not used)	10	Bus	LR1	RXD pair R terminator (not used)
TXD0	Slave D0 bus signal to master	11	Bus	TXD0	Slave D0 bus signal to master
PR0	For RXD0 polarization by device	12	Device	PT0	For TXD0 polarization by device
RXD1M	RXD1 reception from master	13	Device	RXD1S	RXD1 reception from slave
TXD1M	TXD1 transmission from master	14	Device	TXD1S	TXD1 transmission from slave
PR1	For RXD1 polarization by device	15	Device	PT1	For TXD1 polarization by device





---

# Software implementation of Modbus, Character Mode and Uni-Telway communications



---

## At a Glance

**In This Chapter** This part presents the software implementation of Modbus, Character Mode and Uni-Telway communications with Unity Pro.

**What's in this Part?** This part contains the following chapters:

Chapter	Chapter Name	Page
7	Installation methodology	171
8	Software implementation of Modbus communication	175
9	Software implementation of communication using Character Mode	215
10	Software implementation of Uni-Telway communication	247
11	Software Implementation of Specific Protocol Communication (FCS SCP 111/114 cards)	295
12	Language objects of Modbus, Character Mode and Uni-Telway communications	307



---

# Installation methodology

# 7

---

## Overview

### Introduction

The software installation of the application-specific modules is carried out from the various Unity Pro editors:

- in offline mode,
- in online mode.

If you do not have a processor to connect to, Unity Pro allows you to carry out an initial test using the simulator. In this case the installation (See *Implementation phases with simulator*, p. 173) is different.

The following order of installation phases is recommended but it is possible to change the order of certain phases (for example, starting with the configuration phase).

---

**Installation  
phases with  
processor**

The following table shows the various phases of installation with the processor.

Phase	Description	Mode
Declaration of variables	Declaration of IODDT-type variables for the application-specific modules and variables of the project.	Offline (1)
Programming	Project programming.	Offline (1)
Configuration	Declaration of modules.	Offline
	Module channel configuration.	
	Entry of configuration parameters.	
Association	Association of IODDTs with the channels configured (variable editor).	Offline (1)
Generation	Project generation (analysis and editing of links).	Offline
Transfer	Transfer project to PLC.	Online
Adjustment / Debugging	Project debugging from debug screens, animation tables.	Online
	Modifying the program and adjustment parameters.	
Documentation	Building documentation file and printing miscellaneous information relating to the project.	Online (1)
Operation/ Diagnostic	Displaying miscellaneous information necessary for supervisory control of the project.	Online
	Diagnostic of project and modules.	
Key:		
(1)	These various phases can also be performed in the other mode.	

## Implementation phases with simulator

**Note:** the simulator is only used for the discrete or analog modules.

The following table shows the various phases of installation with the simulator.

Phase	Description	Mode
Declaration of variables	Declaration of IODDT-type variables for the application-specific modules and variables of the project.	Offline (1)
Programming	Project programming.	Offline (1)
Configuration	Declaration of modules.	Offline
	Module channel configuration.	
	Entry of configuration parameters.	
Association	Association of IODDTs with the modules configured (variable editor).	Offline (1)
Generation	Project generation (analysis and editing of links).	Offline
Transfer	Transfer project to simulator.	Online
Simulation	Program simulation without inputs/outputs.	Online
Adjustment/ Debugging	Project debugging from debug screens, animation tables.	Online
	Modifying the program and adjustment parameters.	
<b>Key:</b>		
(1)	These various phases can also be performed in the other mode.	



---

# Software implementation of Modbus communication



---

## At a Glance

### Subject of this Chapter

This chapter presents the software implementation of Modbus communication.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
8.1	General	176
8.2	Modbus communication configuration	183
8.3	Modbus communication programming	196
8.4	Debugging of a Modbus communication	207

# 8.1                    General

---

## At a Glance

**Subject of this Section**                    This section presents the general points relating to Modbus communication and its services.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
About Modbus	177
Compatibilities	178
Compatibility between a Premium PLC and a series 1000 PLC	179
Performance	181
Operating Mode	182

---



## About Modbus

---

### Introduction

Communicating via Modbus allows the data exchange between all the devices which are connected on the bus. The Modbus protocol is a protocol that creates a hierarchical structure (one master and several slaves).

The master manages all exchanges according to two types of dialog:

- the master exchanges with the slave and awaits a response,
  - the master exchanges with all the slaves without waiting for a response (general broadcast).
-

## Compatibilities

---

### Hardware

This type of communication is available for Premium PLCs via:

- the host slot of the processor and/or the **TSX SCY 21601** module, with:
  - a **TSX SCP 111** PCMCIA card associated with the RS232 physical layer,
  - a **TSX SCP 112** PCMCIA card associated with 20 mA current loops,
  - a **TSX SCP 114** PCMCIA card associated with physical layers RS 422 and RS 485,
- a Built-in Link with a **TSX SCY 11601/21601** module associated with the RS485 physical layer.

---

### Software

The maximum frame size is 256 bytes.

The PCMCIA cards and the built-in link of the **TSX SCY 11601/21601** can process 8 communication functions simultaneously in Modbus master.

The `READ_VAR` communication function can read up to 1000 consecutive bits in any remote device. To read in excess of 1000 bits, the `SEND_REQ` communication function must be used.

<b>Note:</b> Premium PLCs cannot send over 1000 bits following a read request.
--

---

## Compatibility between a Premium PLC and a series 1000 PLC

### At a Glance

Using `READ_VAR` and `WRITE_VAR` functions enables you to read and write objects contained in series 1000 PLCs. These can be words, double words, floating points or character strings.

### Memory addressing

The address of the object in the series 1000 PLC memory determines the type of object to be accessed.

This table presents the access addresses for an APRIL 5000 PLC from the series 1000 range, with memory extension.

Variable type	APRIL 5000 with extension	
	PLC address	Access address (in hexa.)
Internal bits %M	%M0	A000
	%M4095	AFFF
Data words %MW	%MW0	0
	%MW24999	61A7
Data words %MD	%MD25000	61A8
	%MD26998	6976
Data words %FD	%FD27000	6978
	%FD28998	7146
Data words %CH	%CH29000	7148
	%CH43903	AB7F

### Programming rules

When you want to access the objects of a series 1000 PLC, the index of the first object to read (or write) is the access address.

Example:

- Read the bit %M0  
`READ_VAR(ADDR('0.0.1.3'), '%M', 16#A000, 1, ...)`
- Read the word %MD25000  
`READ_VAR(ADDR('0.0.1.3'), '%MW', 16#61A8, 2, ...)`

Furthermore, these communication functions do not allow you to exchange double words or character strings using Modbus protocol. Where necessary, the transfer can be made in %MW form. Here, **the project is in charge of the direction of the word ranking.**

The diagnostics functions can be accessed using the `SEND_REQ` function.

**Compatibility  
between a  
Premium PLC  
and a Quantum  
PLC or  
Micrologic  
device**

Descriptive table:

Premium	Quantum	Micrologic
%M0	00001	%M1
%MW0	40001	%MW1

## Performance

### At a Glance

The following tables enable you to evaluate typical exchange times according to different criteria.

The results displayed correspond to an average operation period of the `READ_VAR` function in ms.

### Exchange time for 1 word

Number of objects read: 1 word

Speed in bits/s	T cycle (ms)	Average duration (ms) TSX SCP 114	Average duration (ms) TSX SCY 11601/21601
4800	cyclic	105	120
4800	10	133	140
4800	50	152	172
9600	cyclic	74	90
9600	10	86	110
9600	50	149	172
19200	cyclic	57	75
19200	10	60	90
19200	50	100	118

### Exchange time for 100 words

Number of objects read: 100 words

Speed in bits/s	T cycle (ms)	Average duration (ms) TSX SCP 114	Average duration (ms) TSX SCY 11601/21601
4800	cyclic	616	630
4800	10	637	650
4800	50	700	730
9600	cyclic	357	375
9600	10	367	390
9600	50	405	425
19200	cyclic	215	228
19200	10	216	239
19200	50	251	280

## Operating Mode

---


### At a Glance

The following graphics show operating modes for PCMCIA Modbus cards, built-in links in **TSX SCY 11601/21601** modules and for the Terminal Port.

---

### General chart

The operating mode is as follows:



### Operation

- After power-up the module self-tests. During this stage the warning indicators flash.
  - If there is no Unity Pro application in the PLC, the module awaits configuration.
  - If there is a Unity Pro application in the PLC, the application's configuration is transmitted to the module, and then the module starts up.
  - When there is a power outage, the PLC processor carries out a hot restart. The module then restarts its auto-test procedures.
-

---

## 8.2 Modbus communication configuration

---

### At a Glance

---

**Subject of this Section**

This section describes the Configuration process used when implementing Modbus communication.

---

**What's in this Section?**

This section contains the following topics:

Topic	Page
How to access the Modbus parameters of the built-in channel of the TSX SCY 11601/21601 modules	184
How to access PCMCIA Modbus card parameters	186
Modbus Configuration Screen	188
Accessible Modbus Functions	190
Application linked Modbus Parameters	191
Transmission linked Modbus Parameters	193

---

## How to access the Modbus parameters of the built-in channel of the TSX SCY 11601/21601 modules

---

### At a Glance

This operation describes how to access the configuration screen of the built-in channel Modbus link (channel 0) of modules **TSX SCY 11601/ 21601** for Premium PLCs.



**Note:** For **TSX SCY 11601**, given that there is only one channel (Channel 0) and one link ( Modbus/JBUS ), channel 0 is configured by default.

---



**How to access the link**

The following table shows the steps to follow in order to access the Modbus link:

Step	Action
1	Open the hardware configuration editor.
2	Double click on the TSX SCY 11601 or TSX SCY 21601 module.
3	Select channel 0. <b>Result:</b> 
4	Select the function <b>JBUS MODBUS LINK</b> . For TSX SCY 11601, the Modbus function is set by default. <b>Example:</b> 

## How to access PCMCIA Modbus card parameters



### At a Glance

This operation describes how to access the configuration screen of a PCMCIA card Modbus link for Premium PLCs.

### How to access the link

The following table shows the steps to follow in order to access the Modbus link:


Step	Action																						
1	Open the hardware configuration editor.																						
2	<p>Double click on the PCMCIA card slot. <b>Result:</b> the card type selection window appears.</p> <div><div>Add/Replace a submodule</div><table><tr><th>Product reference</th><th>Description</th></tr><tr><td> - Communication</td><td></td></tr><tr><td> - FCS SCP 111</td><td>RS232 OPEN PCMCIA CARD</td></tr><tr><td> - FCS SCP 114</td><td>RS485 OPEN PCMCIA CARD</td></tr><tr><td> - TSX FPP 20</td><td>FIPWAY PCMCIA CARD</td></tr><tr><td> - TSX FPP 200</td><td>FIPWAY PCMCIA CARD</td></tr><tr><td> - TSX JNP 112</td><td>BC JNET PCMCIA CARD</td></tr><tr><td> - TSX JNP 114</td><td>RS485 JNET PCMCIA CARD</td></tr><tr><td> - TSX SCP 111</td><td>RS232 MP PCMCIA CARD</td></tr><tr><td> - TSX SCP 112</td><td>BC MP PCMCIA CARD</td></tr><tr><td> - TSX SCP 114</td><td>RS485 MP PCMCIA CARD</td></tr></table></div>	Product reference	Description	- Communication		- FCS SCP 111	RS232 OPEN PCMCIA CARD	- FCS SCP 114	RS485 OPEN PCMCIA CARD	- TSX FPP 20	FIPWAY PCMCIA CARD	- TSX FPP 200	FIPWAY PCMCIA CARD	- TSX JNP 112	BC JNET PCMCIA CARD	- TSX JNP 114	RS485 JNET PCMCIA CARD	- TSX SCP 111	RS232 MP PCMCIA CARD	- TSX SCP 112	BC MP PCMCIA CARD	- TSX SCP 114	RS485 MP PCMCIA CARD
Product reference	Description																						
- Communication																							
- FCS SCP 111	RS232 OPEN PCMCIA CARD																						
- FCS SCP 114	RS485 OPEN PCMCIA CARD																						
- TSX FPP 20	FIPWAY PCMCIA CARD																						
- TSX FPP 200	FIPWAY PCMCIA CARD																						
- TSX JNP 112	BC JNET PCMCIA CARD																						
- TSX JNP 114	RS485 JNET PCMCIA CARD																						
- TSX SCP 111	RS232 MP PCMCIA CARD																						
- TSX SCP 112	BC MP PCMCIA CARD																						
- TSX SCP 114	RS485 MP PCMCIA CARD																						
3	<p>From the menu, click on one of the following PCMCIA cards then validate by clicking <b>OK</b>.</p> <ul style="list-style-type: none"><li>● <b>TSX SCP 111</b></li><li>● <b>TSX SCP 112</b></li><li>● <b>TSX SCP 114</b></li></ul>																						

Step	Action												
4	<p>Double click again on the PCMCIA card slot.</p> <p><b>Result:</b></p>  <table border="1"><thead><tr><th colspan="2">CHARACTERISTICS</th></tr></thead><tbody><tr><td>Type of bus</td><td>Uni-Telway, Modbus</td></tr><tr><td>Structure</td><td></td></tr><tr><td>Physical interface</td><td>20mA CL</td></tr><tr><td>Baud rate</td><td>0.3-19.2 Kb</td></tr><tr><td>Services</td><td>Uni-Telway :</td></tr></tbody></table>	CHARACTERISTICS		Type of bus	Uni-Telway, Modbus	Structure		Physical interface	20mA CL	Baud rate	0.3-19.2 Kb	Services	Uni-Telway :
CHARACTERISTICS													
Type of bus	Uni-Telway, Modbus												
Structure													
Physical interface	20mA CL												
Baud rate	0.3-19.2 Kb												
Services	Uni-Telway :												
5	Select channel 1.												
6	<p>Select the function <b>MODBUS LINK</b>.</p> <p><b>Example:</b></p> 												

## Modbus Configuration Screen

**General** The configuration screen is used to configure the parameters required for a Modbus link.

**Illustration** The diagram below shows a configuration screen.



**Description**

The following table shows the different elements of the configuration screen and their functions.

Address	Element	Function
1	Tabs	<p>The tab to the front indicates which mode is currently in use (<b>Config</b> in this example). Each mode can be selected by the corresponding tab. The modes available are:</p> <ul style="list-style-type: none"> <li>● <b>Configuration</b> ,</li> <li>● <b>Debugging</b> accessible only in online mode,</li> <li>● <b>Diagnostic</b> only accessible in online mode.</li> </ul>
2	<b>Module</b> zone	Uses LEDs to provide a reminder of the module and module status in online mode.
3	<b>Channel</b> field	<p>Is used:</p> <ul style="list-style-type: none"> <li>● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select the channel,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> zone	<p>Enables you to choose the general parameters associated with the channel:</p> <ul style="list-style-type: none"> <li>● <b>Function:</b> according to the channel, the available functions are Modbus, Character mode and Uni-Telway. By default, <b>No</b> function is configured.</li> <li>● <b>Task:</b> defines the <b>MAST</b> task in which the channel implicit exchange objects will be exchanged.</li> </ul>
5	<b>Configuration</b> zone	<p>Is used to configure the channel configuration parameters. Some selections may be locked and appear grayed out. It is broken down into two types of information:</p> <ul style="list-style-type: none"> <li>● application parameters,</li> <li>● transmission parameters.</li> </ul>

## Accessible Modbus Functions

---

### At a Glance

Depending on the communication media chosen, certain parameters cannot be modified. These are grayed out.

---

### Accessible Functions

The summary table below shows the various selections possible:

Functions	SCP 111	SCP 112	SCP 114	SCY 11601/21601	Terminal Port
Master	Yes	Yes	Yes	Yes	No
Slave	Yes	Yes	Yes	Yes	Yes
Current loop (PSR)	No	Yes	No	No	No
Transmission speed	Yes	Yes	Yes	Yes	Yes
Delay between characters	Yes	Yes	Yes	Yes	Yes
Data	<ul style="list-style-type: none"><li>● ASCII</li><li>● RTU</li></ul>	<ul style="list-style-type: none"><li>● ASCII</li><li>● RTU</li></ul>	<ul style="list-style-type: none"><li>● ASCII</li><li>● RTU</li></ul>	<ul style="list-style-type: none"><li>● ASCII</li><li>● RTU</li></ul>	RTU only
Stop	<ul style="list-style-type: none"><li>● 1 bit</li><li>● 2 bits</li></ul>	<ul style="list-style-type: none"><li>● 1 bit</li><li>● 2 bits</li></ul>	<ul style="list-style-type: none"><li>● 1 bit</li><li>● 2 bits</li></ul>	<ul style="list-style-type: none"><li>● 1 bit</li><li>● 2 bits</li></ul>	<ul style="list-style-type: none"><li>● 1 bit</li><li>● 2 bits</li></ul>
Parity	<ul style="list-style-type: none"><li>● Odd</li><li>● Even</li><li>● None</li></ul>	<ul style="list-style-type: none"><li>● Odd</li><li>● Even</li><li>● None</li></ul>	<ul style="list-style-type: none"><li>● Odd</li><li>● Even</li><li>● None</li></ul>	<ul style="list-style-type: none"><li>● Odd</li><li>● Even</li><li>● None</li></ul>	<ul style="list-style-type: none"><li>● Odd</li><li>● Even</li><li>● None</li></ul>
RTS / CTS delay	Yes	No	No	No	No
Data carrier management (DCD)	Yes	No	No	No	No

### Specific Functions

The additional **Immediate server** function is only available where a TSX SCP 114 card has been inserted into the TSX SCY 21601 module.

---

## Application linked Modbus Parameters

---

### At a Glance


After configuring the communication channel, you need to enter the application parameters.

These are split into four windows:

- the **Type** window,
  - the **Master** window,
  - the **Slave** window,
  - and the **Current loop (PSR)** window.
- 

### Type Parameter

This window looks like this:




It enables you to select the type of Modbus Protocol the module uses:


- **Master**: selects Modbus Master where the station is master,
- **Slave**: selects Modbus Slave where the station is slave,
- **Immediate server**: allows UNI-TE requests to be directed to the SERVER function and not to the processor's main server.

**Note:** The **Immediate server** parameter requires the communication function to be programmed in Unity Pro SERVER (See Unity Pro, Communication Block Library Manual, UNITE\_SERVER function).

It is valid until the box is checked.



**Master Function** This window is only accessible by selecting **Master**:



Master

Number of retries


Response time  X 10 ms

This allows you to enter:

- the **Number of retries**: number of connection attempts made by the master before defining the slave as absent.
  - the default value is 3,
  - possible values between 0 and 15,
  - value 0 indicates no retries by the Master.
- the **Response time**: time elapsed between the request made by the Master and a repeat attempt if the slave does not respond. It corresponds with the maximum time between the transmission of the last character of the Master's request and receipt of the first character of the request sent back by the slave.
  - the default value is 1s (100\*10ms),
  - possible values between 10ms and 10s,

---

**Slave Function** This window is only accessible by selecting **Slave**:



Slave

Slave Number


This allows you to fill in the **Slave number** of the device:

- TSX SCY 21601:
  - the default value is 98,
  - possible values lie between 1 and 98.
- TSX SCY 11601:
  - the default value is 247,
  - possible values lie between 1 and 247.

---

**Current Loop Function**

This window looks like this:



Current loop (PSR)

☐ Multidrop ☒ Point-to-Point

It allows you to select a:

- **Multidrop** (Current Loop) communication,
  - **Point to point** (Current Loop) communication.
-



## Transmission linked Modbus Parameters

### At a Glance


After configuring the communication channel, you need to enter the transmission parameters.

These are split into six windows:

- the **Transmission speed** window,
- the **Delay between characters** window,
- the windows specific to **Data** and **Stop**,
- the **Parity** window,
- the **RTS/CTS delay** window.

### Transmission speed

This window looks like this:




This enables you to select the transmission speed of the Modbus protocol used by the module. This complies with the other devices:

- the default speed is 9600 bits/s,
- other available speeds are 1200, 2400, 9600 and 19200 bits/s,
- the speeds 300 and 600 bits/s are only available using the PCMCIA TSX SCP 111 card.

### Delay between characters

This window looks like this:



This is the time taken to detect the end delimiter and the maximum time separating two characters on reception. It is managed when the PLC (master or slave) is receiving messages.

You are advised to use default values for configurations without a modem or intermediary devices. Otherwise, greater values must be used.

**Note:** The default value depends on the transmission speed:

**Note:** A **restriction** is applied to the delay between characters value for channel 0 of modules **TSX SCY 11601/21601** (see table below).


The table below shows the maximum delay between characters values, according to transmission speed:

Speed (bit/s)	Max. DBC (ms)	Max. DBC (number of characters)
1200	212	23
2400	106	23
4800	53	23
9600	26	23
19200	13	22

---

## Data

This window looks like this:



The **Data** field is used to fill in the type of coding used to communicate in Modbus. This field must be set according to the other devices:


- **RTU** mode:
  - the characters are coded over 8 bits,
  - the beginning and end of the frame are detected by a silence of at least 3.5 characters,
  - the integrity of the frame is checked using the CRC checksum contained within the frame.
- **ASCII** mode:
  - the characters are coded over 7 bits,
  - the beginning of the frame is detected by the reception of ":" characters or by a silence greater than the delay between characters.  
The end of the frame is detected by CR and LF (carriage return and line feed), or by a silence greater than the delay between characters.

**Note:** The value 1000 in ASCII mode corresponds to an infinite delay between characters.

---

**Stop**

This window looks like this:



Stop  
☒ 1 bit  
☐ 2 bits

The **Stop** field allows you to fill in the number of stop bits used for communication in Modbus. The possible values are 1 or 2 stop bits. This field is set according to the other devices.

**Note:** The default value is 1 stop bit.

**Parity**

This window looks like this:




Parity  
☒ Even ☐ Odd ☐ None

This field is used to set whether a parity bit is added or not, as well as its type. The possible values are Even, Odd or none (Even by default). This field is set according to the other devices.

**RTS / CTS delay**

This window looks like this:



RTS / CTS delay  
 X100 ms ☐ Carrier (DCD)

Before a character string is transmitted, the module activates the RTS (Request To Send) signal and waits for the CTS (Clear To Send) signal to be activated.

This allows you to enter:

- the maximum waiting time between the two signals. When this value is timed-out, the request is not transmitted on the bus.
  - the value is expressed in hundreds of milliseconds,
  - the default value is 0 ms,
  - the possible values are 0s to 10s,
  - the value 0 specifies an absence of delay management between the two signals.
- data carrier management (DCD signal - Data Carrier Detected) is only used for communication with a modem with a controlled data carrier:
  - if the option is selected, the characters are only valid on reception if the DCD signal is detected,
  - if the option is not selected, all characters received are taken into account.

# 8.3 Modbus communication programming

---

## At a Glance

**Subject of this Section** This section describes the Programming process used when implementing Modbus communication.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
Modbus master communication function	197
Modbus slave communication function	198
Using the SEND_REQ communication function	200
Example 1: SEND_REQ function with Echo request	201
Example 2: SEND_REQ function with word Read request	202
Example 3: SEND_REQ Function with Bit Read Request	204
Example 3: READ_VAR function for reading bits	206

---

## Modbus master communication function

### At a Glance

This page describes the services available on master Premium stations of a Modbus linkGeneral functions (See Unity Pro, Communication services and architectures Reference manual, Interoperability).

### Exchange of data

The following requests are addressed to the slave device with which you wish to carry out read or write operations of variables.

These requests use the `READ_VAR`, `SEND_REQ` and `WRITE_VAR` communication functions. (See Unity Pro, Communication Block Library Manual, `READ_VAR`: Reading variables) and (See Unity Pro, Communication Block Library Manual, `WRITE_VAR`: Schreiben von Variablen ).

Modbus request	Function code	Communication function
Read bits	16#01	<code>READ_VAR</code>
Read words	16#03	<code>READ_VAR</code>
Writing a bit or n bits	16#05 or 16#0F	<code>WRITE_VAR</code>
Writing a word or n words	16#06 or 16#10	<code>WRITE_VAR</code>
Input bits reading	16#02	<code>SEND_REQ</code>
Read input words	16#04	<code>SEND_REQ</code>

**Note:** Write utilities can be sent in transmission. In this case no response is returned to the transmitter. It is therefore recommendable to configure a time-out to acknowledge the activity bit of the function.

### Example of reading words

The example applies to the reading of word 4 (%MW4) in the Modbus slave 3.

```
READ_VAR (ADDR('0.0.1.3'), '%MW', 4, 1, %MW200:4, %MW100:1)
```

### Diagnostics and maintenance

The diagnostics and maintenance information of Modbus slaves uses the `SEND_REQ` communication function. (See Unity Pro, Communication Block Library Manual, `SEND_REQ`: Sending requests)

Modbus request	Function code / Sub function code	Communication function
Exception status	16#07	<code>SEND_REQ</code>
Diagnostics	16#08/16#xx	<code>SEND_REQ</code>
Event counter	16#0B	<code>SEND_REQ</code>
Connection event	16#0C	<code>SEND_REQ</code>
Slave identification	16#11	<code>SEND_REQ</code>

## Modbus slave communication function

---

**Introduction** This page describes the services managed by the slave modules for a Modbus link.

---

**Data exchanges** The slave module manages the following requests:

Modbus request	Function code / sub-function code	PLC object
Read n output bits	16#01	%M
Read n input bits	16#02	%M
Read n output words	16#03	%MW
Read n input words	16#04	%MW
Write an output bit	16#05	%M
Write an output word	16#06	%MW
Write n output bits	16#0F	%M
Write n output words	16#10	%MW

---

**Diagnostics and maintenance**

The diagnostics and maintenance information which are accessible from a Modbus link are shown below:

<b>Designation</b>	<b>Function code / sub-function code</b>
Read exception status	16#07
Echo	16#08 / 16#00
Initialize module	16#08 / 16#01
Read the diagnostic registers of the PLC	16#08 / 16#02
Change end of frame delimiter (ASCII mode)	16#08 / 16#03
Switch to listening mode	16#08 / 16#04
Reset counters	16#08 / 16#0A
Number of messages received without CRC error	16#08 / 16#0B
Number of frames received with CRC error	16#08 / 16#0C
Number of exceptional responses	16#08 / 16#0D
Number of messages addressed to the PLC	16#08 / 16#0E
Number of broadcast messages received	16#08 / 16#0F
Number of correct responses	16#08 / 16#10
Number of messages received in listening mode	16#08 / 16#11
Number of invalid characters received	16#08 / 16#12
Read event counter	16#0B
Read connection event	16#0C
Read identification	16#11

## Using the SEND\_REQ communication function

---

### At a Glance

The UNI-TE Action-object request (request code 16#9F) is used to transmit all Modbus functions. (See Unity Pro, Communication Block Library Manual, SEND\_REQ: Sending requests).

After executing this request, the report is always **16#CF00**.

To check the exchange, it is also necessary to test the content of the first word in the reception table.

#### Possible values of the first word:

- 0 : indicates that the exchange has been performed,
- 1: indicates that the exchange has not been performed.

The transmission buffer should contain the following information:

- first word:
  - Byte 0: function code,
  - Byte 1: sub-function code.
- second word: Modbus function identifier, which is always 16#0296,
- third word = 0: reserved,
- fourth word: Modbus function parameters,
- fifth word: Modbus function parameters,
- n th word: Modbus function parameters.

<b>Note:</b> This function is not available in Modbus master mode on the Terminal port.
---

---



## Example 1: SEND\_REQ function with Echo request

### At a Glance

The example deals with the **Echo** diagnostics function. This function requests the interrogated slave to return the entire message sent by the master.

### Question

The communication function is as follows:

```
SEND_REQ (ADDR ( '0.0.1.x' ), 16#9F, %MW10:10, %MW100:4, %MW50:30)
```

Before sending the function it is necessary to initialize the following words:

Words	Value of the words	Description
%MW10	:= 16#0008	corresponds to the Echo function (byte 0 = 16#08, byte 1 =16#00).
%MW11	:= 16#0296	corresponds to the identification of the Modbus function.
%MW12	:= 0	reserved.
%MW13	:= 16#1234	corresponds to the Echo function parameter. For this example, the slave must send return the value 16#1234.
%MW103	:=8 (bytes)	length of the data to be transmitted in bytes.

### Response

The slave response, contained in the %MW50:30 reception buffer, is of type:

Value of %MW50	Value of %MW51	Description
:= 0 if action taken	:= 16#0008	corresponds to the Echo function (byte 0 = 16#08, byte 1 =16#00) %MW52 to %MW79 contain the Modbus response data. For this example %MW52:= 1234
:= 1 if action not taken	:= 16#0007	incorrect request parameters
	:= 16#0004	incorrect question parameters
	:= 16#0688	byte 0 =16#80 + function code (16#08 for Echo) byte 1 = 16#06 Modbus error code (the slave is busy)
	:= 16#0188	byte 0 =16#80 + function code (16#08 for Echo) byte 1 = 16#01 Modbus error code (the function is unknown)
	:= 16#0388	byte 0 =16#80 + function code (16#08 for Echo) byte 1 = 16#03 Modbus error code (the data is invalid)

## Example 2: SEND\_REQ function with word Read request

---

**At a Glance**      The example deals with the read of 4 input words at address 10 of a third-party device. These words are then copied in %MW52:5.

---

**Question**      The communication function is as follows:  
SEND\_REQ (ADDR ( '0.0.1.x' ) , 16#9F, %MW10:10, %MW100:4, %MW50:30)

---

Before sending the function it is necessary to initialize the following words:

Words	Value of the words	Description
%MW10	:= 16#0004	corresponds to the read function of n input words (byte 0 = 16#04, byte 1 = 16#00)
%MW11	:= 16#0296	corresponds to the identification of the Modbus function
%MW12	:= 0	reserved
%MW13	:= 16#0A00	address of the first word to read (1)
%MW14	:= 16#0400	number of words to read (1)
%MW103	:=10 (bytes)	length of the data to be transmitted in bytes
Key:		
(1)	the most significant bytes and the least significant bytes must be inverted.	

---

**Response**      The slave response, contained in the %MW50:30 reception buffer, is of type:

Value of %MW50	Value of %MW51	Description
:= 0 if action taken	:= 16#0004	<p>corresponds to the read function of n input words (byte 0 = 16#04, byte 1 = 16#00)</p> <p>%MW52 to %MW79 contain the Modbus response data:</p> <ul style="list-style-type: none"> <li>• %MW52:= PF<sub>0</sub> 0A <ul style="list-style-type: none"> <li>• byte 0 = 16#0A: length received in bytes (10 bytes)</li> <li>• byte 1 = PF<sub>0</sub>: most significant byte of first word</li> </ul> </li> <li>• %MW53:= PF<sub>1</sub> pf<sub>0</sub> <ul style="list-style-type: none"> <li>• byte 0 = pf<sub>0</sub>: least significant byte of first word</li> <li>• byte 1 = PF<sub>1</sub>: most significant byte of second word</li> </ul> </li> <li>• %MW54:= PF<sub>2</sub> pf<sub>1</sub> <ul style="list-style-type: none"> <li>• byte 0 = pf<sub>1</sub>: least significant byte of second word</li> <li>• byte 1 = PF<sub>2</sub>: most significant byte of third word</li> </ul> </li> </ul>
:= 1 if action not taken	:= 16#0007	incorrect request parameters
	:= 16#0004	incorrect question parameters
	:= 16#0688	<p>byte 0 =16#80 + function code (16#08 for Echo)</p> <p>byte 1 = 16#06 Modbus error code (the slave is busy)</p>
	:= 16#0188	<p>byte 0 =16#80 + function code (16#08 for Echo)</p> <p>byte 1 = 16#01 Modbus error code (the function is unknown)</p>
	:= 16#0388	<p>byte 0 =16#80 + function code (16#08 for Echo)</p> <p>byte 1 = 16#03 Modbus error code (the data is invalid)</p>

**Note:** To retrieve the read bits, we use the ROR1\_ARB (See Unity Pro, Obsolete Block Library Manual, RORI\_ARB function) instruction.

### Example 3: SEND\_REQ Function with Bit Read Request

---

**At a Glance**                      The example shows the reading of 2 output bits from address 0 by a third-party device whose slave address is 5.

---

**Question**                        The communication function is as follows:  
SEND\_REQ (ADDR ( ' 0 . 3 . 0 . 5 ' ) , 16#9F, %MW300:50, %MW450:4, %MW400:50)  
Before sending the function it is necessary to initialize the following words:

Words	Value of the words	Description
%MW300	:= 16#0001	Corresponds to the read function of n output bits (byte 0 = 16#01, byte 1 = 16#00)
%MW301	:= 16#0296	Corresponds to the identification of the Modbus function
%MW302	:= 0	Reserved
%MW303	:= 16#0000	Address of the first bit to read (1)
%MW304	:= 16#0200	Number of bits to read (1)
%MW453	:=10 (bytes)	Length of the data to be transmitted in bytes
Legend:		
(1)	The most significant bytes and the least significant bytes must be inverted.	

---

**Response**            The slave response, contained in the %MW400:50 reception buffer, is of type:

Word	Value	Description
%MW400		: = 0 if action taken : = 1 if action not taken
%MW401 if %MW400:= 0	: = 16#0001	Corresponds to the read function of n output bits (byte 0 = 16#01, byte 1 = 16#00)
%MW401 if %MW400:= 1	: = 16#0007	Incorrect request parameters
	: = 16#0004	Incorrect question parameters
	: = 16#0681	Byte 0 = 16#80 + function code (16#01) Byte 1 = <ul style="list-style-type: none"><li>● 16#06 Modbus error code (the slave is busy)</li><li>● 16#01 Modbus error code (the function is unknown)</li><li>● 16#03 Modbus error code (the data is invalid)</li></ul>
%MW402	: = 16#xx01	Contains the Modbus response data: Byte 0 = 16#01: length received in bytes (1 byte) Byte 1 = 16#xx: value of the bits For example, if bit 1 = 1 and bit 2 = 1, then byte 1 = 16#03

### Example 3: READ\_VAR function for reading bits

---

#### General

Programming exchanges with Modbus slave devices is done with the help of the READ\_VAR and WRITE\_VAR communication functions only (the SEND\_REQ function is not supported on the TER port).

---

#### Example with READ\_VAR

Description of the objects used in the example:

Object		Description
%MW0.0		Transmission demand of the request
%M20		Request in progress
%MW100:10		Reception buffer
%MW200:203		Report zone:
	%MW200	Session and activity bit number (X0)
	%MW201	Error code
	%MW202	Time-out in units of 10 ms
%M30		Bit set to 1 after a successful exchange
%MW204		Counter of requests sent
%MW205		Counter of good requests
%MW206		Counter of bad requests
%MW207		Error code of the last bad request

Presentation of the program:

```
!(*Read of the bits %M0 to %M8 from the Nano at address 37 *)
IF %MW0.0 AND NOT %M20 THEN
  %MW200:4:=0;%MW202:=50;SET %M20;
  READ_VAR(ADDR('0.0.0.37'),'M',0,8,%MW200:4,%MW100:10);
  (*8 bits %M0..%M7 are read in the slave 37 and placed in the
  %MW100 word of the master*)
END_IF;

!(*Analysis of the results*)
IF %M20 AND NOT %MW200.0 THEN
  INC %MW204;RESET %M20;RESET %MW0.0;
  IF %MW201=0 THEN INC %MW205;SET %M30;
  ELSE INC %MW206;%MW207:=%MW201;RESET %M30;
END_IF;
```

---

## 8.4 Debugging of a Modbus communication

---

### At a Glance

**Aim of this sub-section**

This sub-section describes the Debugging process during set-up of Modbus communication.

---

**What's in this Section?**

This section contains the following topics:


Topic	Page
Modbus debugging screen	208
Modbus Master debugging screen	210
Debug screen in Modbus slave type	211
How to test a communication channel	212

---

## Modbus debugging screen

**At a Glance** This screen, which is split into various zones, is used to choose the communication channel and to access the debugging parameters for a Modbus link.

**Illustration** The figure below shows a sample Modbus communication debugging screen.





**Description**

The table below shows the various elements of the debugging screen and their functions.

Address	Element	Function
1	Tabs	The front tab shows the current mode ( <b>Debugging</b> in this example). Each mode can be selected by the corresponding tab. The modes available are: <ul style="list-style-type: none"> <li>● <b>Debugging</b> accessible only in online mode,</li> <li>● <b>Diagnostics</b> accessible only in online mode,</li> <li>● <b>Configuration</b>.</li> </ul>
2	<b>Module</b> zone	Specifies the shortened name of the module.
3	<b>Channel</b> field	Is used: <ul style="list-style-type: none"> <li>● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select the channel,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> zone	Shows the communication channel parameters: <ul style="list-style-type: none"> <li>● <b>Function</b>: shows the configured communication function. This information cannot be modified.</li> <li>● <b>Task</b>: shows the configured <b>MAST</b> task. This information cannot be modified.</li> </ul>
5	<b>Display and command</b> zone	Is used to access a Modbus link's debugging parameters. It is different according to the type of Modbus function which is configured: <ul style="list-style-type: none"> <li>● either Modbus master,</li> <li>● or Modbus slave.</li> </ul>

**Note:** LEDs and commands not available appear grayed out.

## Modbus Master debugging screen

---

### At a Glance

The specific part is divided into three windows:

- the **Type** window,
- the **Counters** window,
- the **Channel test** window.

### Type Window


This window looks like this:



It recalls the type of Modbus function configured (master).

### Counters Window


This window looks like this:



This window displays the different counters (in slave configuration).  
The **Reset Counters** button resets these counters to zero.

### Channel Test window

This window looks like this:



This window enables you to test a communication channel by transmitting a request to one of the stations present on the bus.  
For the integrated channel of the TSX SCY 11601 module, the values of the slave number to be queried are between 1 and 247. For the other channels supporting Modbus master, the values are between 1 and 98.

## Debug screen in Modbus slave type

---

### At a Glance

The specific part is divided into three windows:

- the **Type** window,
  - the **Counters** window,
  - the **Channel test** window: this window cannot be used in this mode.
- 

### Type Window

The window looks like this:




A small window titled 'Type' with a dropdown menu showing 'Slave'.

It recalls the type of Modbus function configured (slave).

---

### Counters Window

The window looks like this:



A window titled 'Counters' with a table of counters and a 'Reset counters' button.

Counters	
Received without CRC error	0
Received with exception code	0
Reception broadcast	0
Slave Bus counter or listen only mode:	0
Received with CRC error	0
Message for the CPU	0
Sent with NACK	0
Character error	0

Reset counters

This window displays the different counters (in slave configuration).

The **Reset Counters** button resets these counters to zero.

Slave Bus counter or listen only mode:

- slave bus: this counter is incremented by the slave when it receives a request from the master while in the process of processing another request. This happens when the master sends a request. It does not wait for a response from the slave and may send another request,
  - Listen only mode: this is the operating mode of a slave which is only in listen mode. It never responds to frames sent by the master. In this case, this counter indicates the number of frames received by the slave.
-

## How to test a communication channel

---

### At a Glance

This page describes the procedure for testing a communication channel from the debugging screen.

---

### How to identify a station



The following procedure is used to identify a designated station.

Step	Actions
1	Select the address of the slave to be interrogated using the <b>Slave</b> field.
2	<div>Click on the <b>Identification</b> button. <b>Result:</b> the response appears in the <b>Receive Response</b> window: <div><div>Response reception</div><div>.....TSX 57204.....0....</div><div><div></div><div></div></div><div><input checked="" type="radio"/> ASCII <input type="radio"/> Hex.</div></div></div>

---

## How to send a request

The following procedure is used to send a request, other than those provided by the command buttons, to a designated station. The example deals with transmission of the Echo request (function code: 08; sub-function code: 00; data to be sent 1144).

Step	Action
1	Select the address of the slave to be interrogated using the <b>Slave</b> field.
2	Click on the <b>Enter Request</b> button. <b>Result:</b> the following window appears. 
3	Enter the function code (coded in hexadecimal on one byte), corresponding to the request that you want to send.
4	Enter the sub-function code (coded in hexadecimal on one byte), corresponding to the request that you want to send.
5	Enter the data to be sent by encoding all the data in hexadecimal on 2 bytes (4 characters). Enter the data continuously without any intervening spaces.
6	Click on the Send button. <b>Result:</b> the response appears in the <b>Receive Response</b> window:  The response contains: <ul style="list-style-type: none"><li>• the function code on 2 bytes (08 00),</li><li>• the sub-function code on 2 bytes (00 00),</li><li>• the data on 2 bytes (11 44),</li></ul>



---

# Software implementation of communication using Character Mode



---

## At a Glance

### Subject of this Chapter

This chapter presents the software implementation of communication using Character Mode.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
9.1	General	216
9.2	Character Mode communication configuration	224
9.3	Character Mode communication programming	239
9.4	Debugging of a communication using Character Mode	241

# 9.1                    General

---

## At a Glance

**Subject of this Section**                    This section presents the general points relating to communication using character mode and its services.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
About Character Mode	217
Flow Control	218
Compatibilities	220
Performance	221
Operating Mode	223

---



## About Character Mode

---

### Introduction

Communication via character mode enables dialog and communication functions to be carried out between the PLCs and their environment.


- common peripherals: printers, keyboard-screen, workshop terminal,
  - specialized peripherals: bar code readers,
  - link to a checking or production management calculator,
  - data transmission between heterogeneous devices (numerical commands, variable speed controllers, etc),
  - link to an external modem.
-

## Flow Control

### At a Glance

Flow Control enables you to manage exchanges on a serial link (in this case a Character Mode link) between two devices.

Data is transmitted by the Tx1 transmitter to the Rx2 receiver. The data transmission is checked by Flow Control signals Scf1 and Scf2.



Address	Description
1	The transmitter activates its Scf1 signal to signify it is ready to send.
2	The receiver activates its Scf2 signal to authorize the data transmission.
3	Data transmission
4	The data transmission is finished, the Scf1 and Scf2 control signals are disabled

To perform the Flow Control, there are two possible methods:

- either using hardware:
  - RTS/CTS,
  - RTS/DCD.
- or using software (Xon/Xoff).

**Note:** Software Flow Control is more commonly used. In the event that this control is not available, the hardware control is performed.

**RTS/CTS**

Here, the control signals are RTS/CTS signals. Of all the hardware flow controls, this mode is the most commonly used.

The Tx transmitter output is connected to the Rx receiver input and vice versa. The CTS transmitter signal is connected to the RTS receiver signal and vice versa.

The transmitter is authorized to transmit data when it receives the RTS receiver signal on its CTS input.

---

**RTS/DCD**

Here, the control signals are RTS/DCD signals. This Flow Control mode is not widely used. It can, however, be used for communication with a lower-performance printer.

The Tx transmitter output is connected to the Rx receiver input and vice versa. The DCD transmitter signal is connected to the DTR receiver signal, and the RTS transmitter signal is connected to the CTS receiver signal.

The transmitter is authorized to transmit data when it receives the RTS receiver signal on its CTS input.

---

**Xon/Xoff**

In the case, this flow control is performed using software, with the Xon/Xoff characters. In this case, the devices are only connected by two wires.

The Tx transmitter output is connected to the Rx receiver input and vice versa.

The transmitter is authorized to transmit data when it receives the Xon character on its Rx input, and must stop transmission when it receives the Xoff character on its Rx input.

---

## Compatibilities

---

### Hardware

This type of communication is available for Premium PLCs:

- Via the Terminal Port associated with the RS485 physical layer,
- Via the host channel of the processor or **TSX SCY 21601** module, with:
  - a PCMCIA **TSX SCP 111** card associated with the RS232 physical layer,
  - a **TSX SCP 112** PCMCIA card associated to 20 mA current loops,
  - a **TSX SCP 114** PCMCIA card associated with physical layers RS422 and RS485,
- Via the built-in link of the **TSX SCY 21601** module associated with the RS485 physical layer,

### Software

The Terminal port on Premium processors can only process one communication function of type:

- INPUT\_CHAR
- PRINT\_CHAR
- OUT\_IN\_CHAR

For communication via a Terminal port, the maximum frame size is 120 bytes per communication function.

The PCMCIA cards can process 8 communication functions simultaneously in Premium PLCs.

The built-in link of the **TSX SCY 21601** module can process 8 communication functions simultaneously.

For communication via a PCMCIA card or built in link, the maximum frame size is 4K bytes per communication function.

---

## Performance

---

### At a Glance

The following tables enable you to evaluate typical exchange times in Character Mode for:

- PCMCIA cards and the built-in link of the TSX SCY 21601 module,
- the Terminal Port.

The results displayed correspond to an average operation period of the `PRINT_CHAR` function in ms.

---

### Time with PCMCIA cards

Average duration according to the programmed cycle time and the number of characters transmitted:

Message length		80 characters		960 characters	
Speed in bits/s	T cycle in ms	Average duration		Average duration	
		PCMCIA	SCY 21601	PCMCIA	SCY 21601
4800	10	190	210	2100	2200
4800	25	200	220	2166	2300
4800	50	200	230	2300	2400
9600	10	108	125	1120	1200
9600	25	118	135	1147	1230
9600	50	137	157	1148	1240
19200	10	62	90	604	700
19200	25	75	105	696	800
19200	50	100	120	698	810

---

**Time with the Terminal Port**

Average duration according to the programmed cycle time and the transmission of 80 characters for Premium PLCs:

Speed in bits/s	T cycle in ms	Average duration
1200	10	939
1200	20	945
1200	50	948
1200	100	1000
1200	255	1018
4800	10	242
4800	20	242
4800	50	249
4800	100	299
4800	255	455
9600	10	129
9600	20	139
9600	50	149
9600	100	199
9600	255	355
19200	10	65
19200	20	75
19200	50	105
19200	100	155
19200	255	285

---

## Operating Mode

---


### At a Glance

The following graphics show the operating modes in Character Mode for PCMCIA Modbus cards, the built-in link of the TSX SCY 21601 module and the Terminal Port.

---

### General chart

The operating mode is as follows:



### Operation

- After power-up the module self-tests. During this stage the warning indicators flash.
  - If there is no Unity Pro application in the PLC, the module awaits configuration.
  - If there is a Unity Pro application in the PLC, the application's configuration is transmitted to the module, and then the module starts up.
  - When there is a power outage, the PLC processor carries out a hot restart. The module then restarts its auto-test procedures.
-

## 9.2 Character Mode communication configuration

---

### At a Glance

**Subject of this Section** This section describes the Configuration process used when implementing Character Mode communication.

---

**What's in this Section?** This section contains the following topics:

Topic	Page
How to access the Terminal Port parameters	225
How to access the parameters of the built-in channel of the TSX SCY 21601 module in character mode	226
How to access the parameters of the PCMCIA cards in character mode	227
Character mode configuration screen	229
Accessible functions in character mode	231
Transmission parameters in character mode	232
Message end parameters in character mode	234
Flow control parameters in character mode	236
Additional parameters	237

---




## How to access the Terminal Port parameters

### At a Glance

This part describes how to access the configuration parameters of the character mode link through the Terminal Port.

### How to access the link

The following table shows the steps to follow in order to access the character mode link:

Step	Action
1	Open the hardware configuration editor.
2	Double click on the Terminal Port slot on the CPU.
3	Select the function <b>CHARACTER MODE LINK</b> . <b>Example:</b> 



## How to access the parameters of the built-in channel of the TSX SCY 21601 module in character mode

### At a Glance

This part describes how to access the configuration parameters of the character mode link through a TSX SCY 21601 module for Premium PLCs.

### How to access the link

The following table shows the steps to follow in order to access the character mode link:

Step	Action
1	Open the hardware configuration editor.
2	Double click on the TSX SCY 21601 module.
3	Select channel 0. <b>Result:</b> 
4	Select the function <b>CHARACTER MODE LINK</b> . <b>Example:</b> 


## How to access the parameters of the PCMCIA cards in character mode



### At a Glance

This part describes how to access the configuration parameters of the character mode link through PCMCIA cards.

### How to access the link

The following table shows the steps to follow in order to access the character mode link:


Step	Action																						
1	Open the hardware configuration editor.																						
2	<p>Double click on the PCMCIA card slot.  <b>Result:</b> the card type selection window appears.</p>  <table border="1"> <thead> <tr> <th>Product reference</th><th>Description</th></tr> </thead> <tbody> <tr> <td>[-] Communication</td><td></td></tr> <tr> <td>[-] FCS SCP 111</td><td>RS232 OPEN PCMCIA CARD</td></tr> <tr> <td>[-] FCS SCP 114</td><td>RS485 OPEN PCMCIA CARD</td></tr> <tr> <td>[-] TSX FPP 20</td><td>FIPWAY PCMCIA CARD</td></tr> <tr> <td>[-] TSX FPP 200</td><td>FIPWAY PCMCIA CARD</td></tr> <tr> <td>[-] TSX JNP 112</td><td>BC JNET PCMCIA CARD</td></tr> <tr> <td>[-] TSX JNP 114</td><td>RS485 JNET PCMCIA CARD</td></tr> <tr> <td>[-] TSX SCP 111</td><td>RS232 MP PCMCIA CARD</td></tr> <tr> <td>[-] TSX SCP 112</td><td>BC MP PCMCIA CARD</td></tr> <tr> <td>[-] TSX SCP 114</td><td>RS485 MP PCMCIA CARD</td></tr> </tbody> </table>	Product reference	Description	[-] Communication		[-] FCS SCP 111	RS232 OPEN PCMCIA CARD	[-] FCS SCP 114	RS485 OPEN PCMCIA CARD	[-] TSX FPP 20	FIPWAY PCMCIA CARD	[-] TSX FPP 200	FIPWAY PCMCIA CARD	[-] TSX JNP 112	BC JNET PCMCIA CARD	[-] TSX JNP 114	RS485 JNET PCMCIA CARD	[-] TSX SCP 111	RS232 MP PCMCIA CARD	[-] TSX SCP 112	BC MP PCMCIA CARD	[-] TSX SCP 114	RS485 MP PCMCIA CARD
Product reference	Description																						
[-] Communication																							
[-] FCS SCP 111	RS232 OPEN PCMCIA CARD																						
[-] FCS SCP 114	RS485 OPEN PCMCIA CARD																						
[-] TSX FPP 20	FIPWAY PCMCIA CARD																						
[-] TSX FPP 200	FIPWAY PCMCIA CARD																						
[-] TSX JNP 112	BC JNET PCMCIA CARD																						
[-] TSX JNP 114	RS485 JNET PCMCIA CARD																						
[-] TSX SCP 111	RS232 MP PCMCIA CARD																						
[-] TSX SCP 112	BC MP PCMCIA CARD																						
[-] TSX SCP 114	RS485 MP PCMCIA CARD																						
3	<p>From the menu, click on one of the following PCMCIA cards then validate by clicking <b>OK</b>.</p> <ul style="list-style-type: none"> <li>● <b>TSX SCP 111</b></li> <li>● <b>TSX SCP 112</b></li> <li>● <b>TSX SCP 114</b></li> </ul>																						

Step	Action												
4	<p>Double click again on the PCMCIA card slot.</p> <p><b>Result:</b></p>  <table border="1"><thead><tr><th colspan="2">CHARACTERISTICS</th></tr></thead><tbody><tr><td>Type of bus</td><td>Uni-Telway, Modbus</td></tr><tr><td>Structure</td><td></td></tr><tr><td>Physical interface</td><td>20mA CL</td></tr><tr><td>Baud rate</td><td>0.3-19.2 Kb</td></tr><tr><td>Services</td><td>Uni-Telway :</td></tr></tbody></table>	CHARACTERISTICS		Type of bus	Uni-Telway, Modbus	Structure		Physical interface	20mA CL	Baud rate	0.3-19.2 Kb	Services	Uni-Telway :
CHARACTERISTICS													
Type of bus	Uni-Telway, Modbus												
Structure													
Physical interface	20mA CL												
Baud rate	0.3-19.2 Kb												
Services	Uni-Telway :												
5	Select channel 1.												
6	<p>Select the function <b>CHARACTER MODE LINK</b>.</p> <p><b>Example:</b></p> 												

# Character mode configuration screen

**At a Glance** This screen is used to declare the communication channel and to configure the parameters needed for a character mode link.

**Illustration** The diagram below shows a configuration screen.



**Description**

The following table shows the different elements of the configuration screen and their functions.

Address	Element	Function
1	Tabs	The tab to the front indicates which mode is currently in use ( <b>Configuration</b> in this example). Each mode can be selected by the corresponding tab. The modes available are: <ul style="list-style-type: none"> <li>● <b>Configuration</b> ,</li> <li>● <b>Debugging</b> accessible only in online mode,</li> <li>● <b>Diagnostic</b> only accessible in online mode.</li> </ul>
2	<b>Module</b> zone	Provides an abbreviation as a reminder of the module and module status in online mode (LEDs).
3	<b>Channel</b> field	Is used: <ul style="list-style-type: none"> <li>● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select the channel,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> zone	Enables you to choose the general parameters associated with the channel: <ul style="list-style-type: none"> <li>● <b>Function</b>: according to the channel, the available functions are Modbus, Character mode and Uni-Telway. By default, <b>No</b> function is configured.</li> <li>● <b>Task</b>: defines the <b>MAST</b> task in which the channel implicit exchange objects will be exchanged.</li> </ul>
5	<b>Configuration</b> zone	Is used to configure the channel configuration parameters. Some selections may be locked and appear grayed out. It is broken down into four types of information: <ul style="list-style-type: none"> <li>● application parameters,</li> <li>● message end detection parameters,</li> <li>● flow control parameters,</li> <li>● additional parameters.</li> </ul>

## Accessible functions in character mode

### At a Glance

Depending on the communication media chosen, certain parameters cannot be modified. These are grayed out.

### Accessible Functions

The summary table below shows the various selections possible:

Functions	SCP 111	SCP 112	SCP 114	SCY 21601	Terminal Port
Flow control	<ul style="list-style-type: none"> <li>RTS/CTS</li> <li>RTS/DCD</li> <li>Xon/Xoff</li> <li>None</li> </ul>	No	No	No	No
Echo	<ul style="list-style-type: none"> <li>On reception</li> <li>Restart from 1st. char.</li> <li>CR-&gt;CRLF</li> </ul>	<ul style="list-style-type: none"> <li>On reception</li> <li>Restart from 1st. char.</li> <li>CR-&gt;CRLF</li> </ul>	No	No	On reception
Current loop (PSR)	No	Yes	No	No	No
Stop on reception	Yes	Yes	Yes	Yes	<ul style="list-style-type: none"> <li>CR/LF with 1 Micro</li> <li>No with 1 Premium</li> </ul>
Full duplex	No	No	Yes	No	No
Transmission speed	Yes	Yes	Yes	Yes	Yes
Stop on silence	Yes	Yes	Yes	Yes	No
Data / Stop	Yes	Yes	Yes	Yes	Yes
Parity	Yes	Yes	Yes	Yes	Yes
RTS / CTS delay Carrier (DCD)	Yes	No	No	No	No

**Beep** and **Backspace** management are accessible whatever the media type being used.

## Transmission parameters in character mode

---

### At a Glance


After configuring the communication channel, you need to enter the transmission parameters.

These are split into four windows:

- the **Transmission speed** window,
- the windows specific to **Data** and **Stop**,
- the **Parity** window,
- the **Retard RTS/CTS** window.

### Transmission speed

This window looks like this:




You can use it to select the transmission speed of the character mode protocol used by the module:

- The default speed is 9600 bits/s,
- Other available speeds are 1200, 2400, 9600 and 19200 bits/s,
- The speeds 300 and 600 bits/s are only available using the PCMCIA TSX SCP 111 card,
- You are advised to adjust the transmission speed according to the remote device in use.

### Data

This window looks like this:




The **Data** field specifies the size of the data exchanged over the line. The possible values are 7 and 8 bits. You are advised to adjust the number of data bits according to the remote device in use.

**Note:** The default value is 8 bits.



**Stop**

This window looks like this:



The **Stop** field allows you to fill in the number of stop bits used for communication in character mode. The possible values are 1 or 2 stop bits. You are advised to adjust the number of stop bits according to the remote device in use.

**Note:** The default value is 1 stop bit.

**Parity**


This window looks like this:



This field is used to set whether a parity bit is added or not, as well as its type. The possible values are Even, Odd or none (Odd by default). You are advised to adjust the parity according to the remote device in use.

**RTS / CTS delay**

This window looks like this:



Before a character string is transmitted, the module activates the RTS (Request To Send) signal and waits for the CTS (Clear To Send) signal to be activated.

This allows you to enter:

- the maximum waiting time between the two signals. When this value is timed-out, the request is not transmitted on the bus.
  - the value is expressed in hundreds of milliseconds,
  - the default value is 0 ms,
  - the value is between 0 and 10 s.
  - the value 0 specifies an absence of delay management between the two signals.
- data carrier management (DCD signal - Data Carrier Detected) is only used for communication with a modem with a controlled data carrier:
  - If the option is selected, the characters are only valid on reception if the DCD signal is detected,
  - If the option is not selected, all characters received are taken into account.

## Message end parameters in character mode

---

### At a Glance

After configuring the communication channel, you need to enter the message end detection parameters.

It is split into two windows:

- the **Stop on reception** window: stop on reception of a special character,
- the **Stop on silence** windows: stop on reception of silence.

### Condition of use

The activation of one of these conditions leads to the following:

- the communication function **INPUT\_CHAR** does not allow you to read a defined number of characters. The parameter **Number of characters to be read** must be 0.
  - the possibility of using the communication function **OUT\_IN\_CHAR** on reception. Selecting stop on silence means that stop on reception is deselected. Similarly, selecting stop on reception deselects the stop on silence function.
-

**Stop on reception**

This window looks like this:

A reception request can be terminated once a specific character is received. The following parameters allow you to define up to two message end characters:

- **Stop**: enables you to activate stop on reception by a message end character,
- **CR**: enables you to detect the end of the message by a carriage return,
- **LF**: enables you to detect the end of the message by a line feed,
- a data entry field: enables you to identify a message end character (decimal value) that is different from the CR or LF characters,

Possible values are:

- 0 to 255 if data is coded on 8 bits,
- 0 to 127 if data is coded on 7 bits,
- **Character included**: check this box if you want to include the message end character(s) in the reception table of the Unity Pro PLC application.

**Stop on silence**

This window looks like this:

This parameter allows you to detect the end of a message on reception by the absence of message end characters over a given time.

Stop on silence is validated by checking the **Stop** box. The duration of the silence (expressed in milliseconds) is set using the data entry field.

**Note:** The possible values are 1 ms to 10000 ms.

## Flow control parameters in character mode

---


### At a Glance

After configuring the communication channel, you need to enter the Flow Control (See *Flow Control*, p. 218) parameters.

---

### Flow control window

This window looks like this:



The control flow is selected according to the remote device in use:

- **RTS/CTS Hardware:** if the device manages this flow control,
  - **RTS/DCD Hardware:** if the device manages this flow control,
  - **Xon/Xoff:** if the device manages this flow control,
  - **None:** if the device does not manage flow control.
-

## Additional parameters

---


### At a Glance

When configuring a link in character mode, it is necessary to configure the following four parameters:

- the **Echo** window,
  - the **Beep Management** parameter,
  - the **Backspace management** parameter,
  - the **Full Duplex (RS 422)** parameter.
- 

### Echo

This window enables you to select and configure echo management on reception.



All characters received by the PLC are immediately retransmitted over the line as an echo (thus enabling the remote device to perform a control).

To validate echo management, check the **On reception** box.

If a write request is transmitted by the PLC during reception, the reception echo is interrupted. Once the write request is finished, the echo is reset in two distinct ways:

- either from the first character received (for this, check **Restart on 1st char.**),
- or from the last character before interruption (for this, uncheck **Restart on 1st char.**).

By selecting **CR --> CR LF** it is possible, on reception of the carriage return character (CR = 16#0D), to send as part of the echo the carriage return character followed automatically by the line feed character (LF = 16#0A).

---

### Beep Management

Checking **Beep Management** causes a beep to sound when the module's reception buffer is empty or full.



Uncheck this box if the card is connected to an operator dialog terminal.

---

**Backspace management**

Checking **Backspace management** enables you not to store each backspace character received, and cancel the preceding character.

Moreover, if the echo option On reception is enabled, the PLC transmits three characters in the following order:

- Backspace (= 16#08)
- Space (= 16#20)
- Backspace (= 16#08)

If the box is unchecked, all backspace characters received are stored like any other character.

---

**Full Duplex (RS 422)**

Checking this box enables you to carry out Full Duplex communication, otherwise communication is Half Duplex. The activation of this function depends on the type of remote device in use.

☐ Full Duplex  
(RS 422)

---

## 9.3 Character Mode communication programming

---

### Available communication functions

---

**At a Glance** This page describes the communication functions available in character mode and gives an example of communication between two stations (Micro and Premium).

---


**Available functions** Three specific communication functions are defined to send and receive data to a communication channel in character mode:

- `PRINT_CHAR`: send a character string. (See Unity Pro, Communication Block Library Manual, `PRINT_CHAR`: Sending character strings).
- `INPUT_CHAR`: request character string read. (See Unity Pro, Communication Block Library Manual, `INPUT_CHAR`: Receiving character strings).
- `OUT_IN_CHAR`: send a character string followed by a read request. (See Unity Pro, Communication Block Library Manual, `OUT_IN_CHAR`: Senden/Empfangen von Zeichenketten ).


<b>Note:</b> The use of these functions must be consistent with the configuration.
--

---

**Example** A station at address {20.1} on a Fipway network wants to send then receive a character string to/from a video terminal connected to the built-in link of a station's TSX SCY 21601 module at address {20.3}.



Programming the communication function:



(1) OUT\_IN\_CHAR(ADDR ('{20.3}0.0.0.SYS'), 1, Str\_1, %MW170:4, Str\_2)

The following table describes the function's different parameters:

Parameter	Description
ADDR ('{20.3}0.0.0.SYS')	Address of the message's destination device
1	Send, receive
Str_1	Content of the message received. Variable of type STRING.
%MW170:4	Exchange report, length of the string sent, then that of the string received
Str_2	Content of the message to send. Variable of type STRING.

**Note:** Before each function launch, the number of characters to be sent must be entered in the length parameter (in bytes). In the example: %MW173 = 10. At the end of the exchange, this will contain the number of characters received (in bytes). The value 0 enables you to send the entire character string.



## 9.4                      Debugging of a communication using Character Mode

---

### At a Glance

**Aim of this sub-section**

This sub-section describes the Debugging process during set-up of character mode communication.

---

**What's in this Section?**

This section contains the following topics:

Topic	Page
Debugging screen in character mode	242
Debugging parameters in character mode	244
How to test a communication channel	246

---


## Debugging screen in character mode

### At a Glance

This screen, split into two zones, is used to declare the communication channel and to configure the parameters required for a character mode link.

### Illustration

The figure below shows a sample debugging screen dedicated to character mode communication.



**Description**

The table below shows the various elements of the debugging screen and their functions.

Address	Element	Function
1	Tabs	The front tab shows the current mode ( <b>Debugging</b> in this example). Each mode can be selected by the corresponding tab. The modes available are: <ul style="list-style-type: none"> <li>● <b>Debugging</b> accessible only in online mode,</li> <li>● <b>Diagnostics</b> (default) accessible only in online mode,</li> <li>● <b>Configuration</b>.</li> </ul>
2	<b>Module</b> zone	Specifies the shortened name of the module.
3	<b>Channel</b> field	Is used: <ul style="list-style-type: none"> <li>● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select the channel,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> zone	Shows the communication channel parameters: <ul style="list-style-type: none"> <li>● <b>Function</b>: shows the configured communication function. This information cannot be modified.</li> <li>● <b>Task</b>: shows the configured <b>MAST</b> task. This information cannot be modified.</li> </ul>
5	<b>Display and command</b> zone	is used to access the debugging parameters of a character mode link (See <i>Debugging parameters in character mode</i> , p. 244).

**Note:** LEDs and commands not available appear grayed out.

## Debugging parameters in character mode

---


### At a Glance

The specific part is split into four windows:

- the **Errors** window,
  - the **Request transmission** window,
  - the **Message sent** window,
  - the **Message received** window,
- 

### Errors Window

This window looks like this:



The Errors window interface shows a title bar 'Errors' with a close button. Below the title bar, there are two rows of labels and input fields: 'On transmission' with a text box containing '0', and 'On reception' with a text box containing '0'. At the bottom of the window is a button labeled 'Reset Counters'.

This window indicates the number of communication errors counted by the communication module.


- **On transmission:** corresponds to the number of errors on transmission (image of %MWr.m.c.4 word)
- **On reception:** corresponds to the number of errors on reception (image of %MWr.m.c.5 word)

The **Reset Counters** button resets these counters to zero.

---

### Request Transmission window

This window looks like this:



The Request Transmission window interface has a title bar 'Send request' with a close button. Below the title bar, there are three buttons stacked vertically: 'Transmission', 'Reception', and 'Send / Receive'.

This window is used to test a communication channel by transmission and/or reception of a character string.


- The **Send** button transmits a character string.
- The **Receive** button is used to receive a character string.
- The **Send/Receive** button is used to send a character string and wait for a reply.

**Note:** Reception can be stopped by pressing the Escape button, or if a message is received.

---

**Message Sent  
window**

This window looks like this:


The screenshot shows a window titled "Message Sent". It contains a text input field with the text "Test for sending a character string!". Below the input field is a horizontal scrollbar.

This window is used to enter a message to be sent during a communication test using the **Send** and **Send/Receive** buttons.

---

**Message  
Received  
window**

This window looks like this:

The screenshot shows a window titled "Message Received". It has a label "Number of characters received" followed by a text box containing the value "0". Below this is a large text area for the received message. To the right of the text area are two radio buttons: "ASCII" (which is selected) and "Hex".

This window is used to read a received message as a result of a communication test by using the **Receive** and **Send/Receive** buttons.  
The **ASCII** and **Hex.** buttons are used to display the text in ASCII or in hexadecimal.

---

## How to test a communication channel

---

### Introduction

This page describes the procedure for testing a communication channel from the debugging screen.

---

### How to send a character string

The following procedure is used to send a character string with a remote device.

Step	Actions
1	Enter the character string to be sent in the <b>Message sent</b> window. <b>Note:</b> Special characters can also be sent. They must begin with the \$ character (example using carriage return character: \$0D).
2	Click on the <b>Send</b> button. <b>Result</b> If the exchange is correct, a window specifying that the exchange is correct appears. On the remote device display, check whether the string has been transmitted.

---

### How to receive a character string

The following procedure is used to receive a character string with a remote device. For efficient operation, you must remember that this test requires stop on reception to be configured either via a special character, or via a silence.

Step	Action
1	Click on the <b>Receive</b> button.
2	Send the character string with the frame end character from the remote device. <b>Note:</b> In this example, stop on reception is performed after a carriage return character (16#0D).
3	Display the number of characters and the character string received in the <b>Message received</b> window.

---

---

# Software implementation of Uni-Telway communication

10

---

## At a Glance

### Subject of this Chapter

This chapter presents the software implementation of Uni-Telway communication.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
10.1	General	248
10.2	Uni-Telway communication configuration	255
10.3	Uni-Telway communication programming	267
10.4	Debugging of a Uni-Telway communication	288

# 10.1            General

---

## At a Glance

**Subject of this Section**            This section presents the general points relating to Uni-Telway communication and its services.

---

**What's in this Section?**            This section contains the following topics:

Topic	Page
Presentation	249
Compatibility	250
Performance	251
Operating Mode	253
Addresses of a slave PLC	254

---



## Presentation

---

### Introduction

Communicating via Uni-Telway allows the exchange of data between all the devices which are connected on the bus. The Uni-Telway standard is a UNI-TE protocol which creates a hierarchical structure (one master and several slaves). The master device is the bus manager.

Uni-Telway enables equal communication and authorizes the sending of messages:

- from master to slave,
  - from slave to master,
  - from slave to slave.
-

## Compatibility

---

### Hardware

This type of communication is available for Premium PLCs:

- Via the Terminal Port associated with the RS485 physical layer,
- Via the host channel of the processor or **TSX SCY 21601** module, with:
  - a **TSX SCP 111** PCMCIA card associated with the RS232 physical layer,
  - a **TSX SCP 112** PCMCIA card associated with 20 mA current loops,
  - a **TSX SCP 114** PCMCIA card associated with physical layers RS422 and RS485,
- Via the built-in link of the **TSX SCY 21601** module associated with the RS485 physical layer,

### Software

The Terminal Port of Premium processors allows processing:

- in Uni-Telway master mode:
  - 4 messages transmitted to the bus,
  - 4 received messages,
- in Uni-Telway slave mode:
  - 4 transactions at server address Ad0,
  - 4 transactions at server address Ad1,
  - 4 receptions at application address Ad2.

For communication via a Terminal port, the maximum frame size is 128 bytes per communication function.

PCMCIA cards and the link built into **TSX SCY 21601** modules authorizes processing of:

- in Uni-Telway master mode:
  - 8 messages transmitted to the bus,
  - 8 received messages,
- in Uni-Telway slave mode:
  - 6 transactions at server address Ad0,
  - 1 transaction at server address Ad1,
  - 8 receptions at application address Ad2.

For communication via a PCMCIA card or built in link, the maximum frame size is 240 bytes per communication function.

The `READ_VAR` communication function can read up to 1000 consecutive bits in any remote device. To read in excess of 1000 bits, the `SEND_REQ` communication function must be used.

<b>Note:</b> Premium PLCs cannot send over 1000 bits following a read request.
--

---

## Performance

---

### At a Glance

The following tables enable you to evaluate typical exchange times in Uni-Telway mode for:

- PCMCIA cards and the built-in link of the TSX SCY 21601 module,
- the Terminal Port.

The results displayed correspond to an average operation period of the `READ_VAR` function in ms.

---

### Time with PCMCIA cards

Number of objects read: 1 word

Speed in bits/s	T cycle in ms	Average duration TSX SCP 114	Average duration TSX SCY 21601
4800	cyclic	131	152
4800	10	160	172
4800	50	180	200
9600	cyclic	95	110
9600	10	107	120
9600	50	167	190
19200	cyclic	64	84
19200	10	67	87
19200	50	107	130

Number of objects read: 100 words

Speed in bits/s	T cycle in ms	Average duration TSX SCP 114	Average duration TSX SCY 21601
4800	cyclic	620	638
4800	10	640	660
4800	50	710	730
9600	cyclic	363	387
9600	10	373	395
9600	50	402	428
19200	cyclic	213	230
19200	10	214	240
19200	50	249	272

---

**Time with the  
Terminal Port**

**Exchange time for Premium PLCs**

Transmission speed = 19200 bits/s and number of objects read = 40 words

<b>T cycle in ms</b>	<b>Average duration</b>
10	135
20	150
50	185
100	210
255	340

**Recommen-  
dations for use**

To improve connection phase performance when connecting a slave device to Uni-Telway, we recommend you configure the number of slaves according to the number of slaves present and select the addresses starting with 1.

---

## Operating Mode

---


### At a Glance

The following graphics show operating modes for PCMCIA Uni-Telway cards, built-in links in TSX SCY 21601 modules and for the Terminal Port.

---

### General chart

The operating mode is as follows:



### Operation

- After power-up the module self-tests. During this stage the warning indicators flash.
  - If there is no Unity Pro application in the PLC, the module awaits configuration.
  - If there is a Unity Pro application in the PLC, the application's configuration is transmitted to the module, and then the module starts up.
  - When there is a power outage, the PLC processor carries out a hot restart. The module then restarts its auto-test procedures.
-

## Addresses of a slave PLC

---

### At a Glance

A slave PLC can have up to three Uni-Telway addresses:

- a server address **Ad0**,
- a client application address **Ad1**,
- a listening application address **Ad2**.

---

### Address Ad0

A server address, called **Ad0**, is obligatory and coded in the configuration. It enables access to the PLC system for adjustment, diagnostics or reading functions or writing variables, program loading and unloading, etc.

---

### Address Ad1

A client application address, called **Ad1**, is supplied optionally by the slave module configuration. This enables requests or messages requiring a response or not to be sent to another device connected on the Uni-Telway bus.

---

### Address Ad2

A listening application address, called **Ad2**, is supplied optionally by the slave module configuration. This enables Unsolicited Data (16#FC) requests to be received from another device connected on the Uni-Telway bus.

---

### Usage constraints

Addresses Ad1 and Ad2 are consecutive to the address Ad0 ( $Ad1 = Ad0 + 1$  and  $Ad2 = Ad0 + 2$ ).

### Example

Uni-Telway link address	Logical entities	
Ad0 = 6	System	responds to questions
Ad1 = 7	Client application	sends questions to a Uni-Telway server device
Ad2 = 8	Listening application	receives the "Unsolicited Data" request sent to the application

**Note:** when the Uni-Telway master is an SCM (series 7 PLCs), the application contained in the master must use the destination slave address (Premium) increased by 100 (16#0064).

---

# 10.2

# Uni-Telway communication configuration

## At a Glance

### Subject of this Section

This section describes the Configuration process used when implementing Uni-Telway communication.

### What's in this Section?

This section contains the following topics:

Topic	Page
How to access the Terminal Port parameters	256
How to access the parameters of the built-in channel of the TSX SCY 21601 module	257
How to access the parameters of the PCMCIA Uni-Telway cards	258
Configuration Screen of the Uni-Telway link	260
Accessible functions in Uni-Telway	262
Application linked Uni-Telway Parameters	263
Transmission linked Uni-Telway Parameters	265


## How to access the Terminal Port parameters

### At a Glance

This part describes how to access the configuration parameters of the Uni-Telway link through the Terminal Port of the Premium PLC.

### How to access the link

The following table shows the steps to follow in order to access the Uni-Telway link:

Step	Action
1	Open the hardware configuration editor.
2	Double click on the Terminal Port slot on the CPU.
3	Select the function <b>Uni-Telway</b> . <b>Example:</b> 





# How to access the parameters of the built-in channel of the TSX SCY 21601 module

## At a Glance

This part describes how to access the configuration parameters of the Uni-Telway link through the built-in channel of a **TSX SCY 21601** module for the Premium.

## How to access the link

The following table shows the steps to follow in order to access the Uni-Telway link:

Step	Action
1	Open the hardware configuration editor.
2	Double click on the TSX SCY 21601 module.
3	Select channel 0. <b>Result:</b> 
4	Select the function <b>UNI-TELWAY LINK</b> . <b>Example:</b> 


## How to access the parameters of the PCMCIA Uni-Telway cards



### At a Glance

This part describes how to access the configuration parameters of the Uni-Telway link through PCMCIA cards for Premium PLCs.

### How to access the link

The following table shows the steps to follow in order to access the Uni-Telway link:


Step	Action
1	Open the hardware configuration editor.
2	<div>Double click on the PCMCIA card slot. <b>Result:</b> the card type selection window appears.</div> <div></div>
3	<div>From the menu, click on one of the following PCMCIA cards then validate by clicking <b>OK</b>.</div> <ul style="list-style-type: none"><li>● <b>TSX SCP 111</b></li><li>● <b>TSX SCP 112</b></li><li>● <b>TSX SCP 114</b></li></ul>

Step	Action
4	<p>Double click again on the PCMCIA card slot.</p> <p><b>Result:</b></p> 
5	<p>Select channel 1.</p>
6	<p>Select the function <b>UNI-TELWAY LINK</b>.</p> <p><b>Example:</b></p> 

## Configuration Screen of the Uni-Telway link

**At a Glance** This screen, split into two areas, is used to register the communication channel and to configure the necessary parameters for a Uni-Telway link.

**Illustration** The diagram below shows a configuration screen.



**Description**

The following table shows the different elements of the configuration screen and their functions.

Address	Element	Function
1	Tabs	<p>The tab to the front indicates which mode is currently in use ( <b>Configuration</b> in this example). Each mode can be selected by the corresponding tab. The modes available are:</p> <ul style="list-style-type: none"> <li>● <b>Configuration</b> ,</li> <li>● <b>Debugging</b>, accessible only in Online mode,</li> <li>● <b>Diagnostics</b>, accessible only in Online mode.</li> </ul>
2	<b>Module</b> zone	Provides an abbreviation as a reminder of the module and module status in online mode (LEDs).
3	<b>Channel</b> field	<p>Is used:</p> <ul style="list-style-type: none"> <li>● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select the channel,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> zone	<p>Enables you to choose the general parameters associated with the channel:</p> <ul style="list-style-type: none"> <li>● <b>Function:</b> according to the channel, the available functions are Modbus, Character mode and Uni-Telway. By default, <b>No</b> function is configured.</li> <li>● <b>Task:</b> defines the <b>MAST</b> task in which the channel implicit exchange objects will be exchanged.</li> </ul>
5	<b>Configuration</b> zone	<p>Is used to configure the channel configuration parameters. Some selections may be locked and appear grayed out. It is broken down into two types of information:</p> <ul style="list-style-type: none"> <li>● application parameters,</li> <li>● transmission parameters.</li> </ul>

## Accessible functions in Uni-Telway

---

### At a Glance

Depending on the communication media chosen, certain parameters cannot be modified. These are grayed out.

---

### Accessible Functions

The summary table below shows the various selections possible:

Functions	SCP 111	SCP 112	SCP 114	SCY 21601	Terminal Port
Master - Event data	Yes	Yes	Yes	No	No
Master - Number of slaves	Yes	Yes	Yes	Yes	Yes
Slave	Yes	Yes	Yes	Yes	Yes
Boucle de courant (PSR)	No	Yes	No	No	No
Transmission speed	Yes	Yes	Yes	Yes	Yes
Wait Time	Yes	Yes	Yes	Yes	Yes
Data / Stop	Stop	Stop	Stop	Stop	No
Parity	Yes	Yes	Yes	Yes	Yes
RTS / CTS delay	Yes	No	No	No	No
Data carrier management (DCD)	Yes	No	No	No	No

---

## Application linked Uni-Telway Parameters

---

### At a Glance

After configuring the communication channel, you need to enter the application parameters.


These are split into four windows:

- the **Type** window,
- the **Master** window,
- the **Slave** window,
- and the **Current loop (PSR)** window.

---

### Type Parameter

This window looks like this:




It enables you to select the type of Uni-Telway Protocol the module uses:

- **Master**: selects the Uni-Telway master,
- **Slave**: selects the Uni-Telway slave.

---

### Master Function

This window is only accessible by selecting **Master**:




This allows you to enter:

- the **Event data**: used to select the number of bytes for the Event Data:
    - the default value is 0 bytes,
    - the possible values are 0, 4 or 8 bytes.
  - the **Number of slaves**: used to select the number of slaves the master PLC will have to scan:
    - for a PCMCIA card and the built-in link, the possible values are 0 to 98,
    - for the Terminal Port, the possible values are 3 to 8,
    - the default value depends on the communication channel: 31 for a PCMCIA card and built-in link and 3 for the Terminal Port.
-

## Slave Function

This window is only accessible by selecting **Slave**:

A dialog box titled "Slave" with a close button (X) in the top right corner. It contains two input fields: "Server Address (AD0)" with a value of "1" and "Number of addresses" with a value of "1". Both fields have up and down arrow buttons on their right sides.

This allows you to enter:

- the **Server address (AD0)**: used to select the server address Ad0 of the device,
  - the possible values are between 1 and 98.
- the **Number of addresses**: used to assign up to three slave addresses to the same device. This option is offered , for example, to PLCs that can have Server (Ad0), Client (Ad1) and Listening Application (Ad2) addresses,
  - the possible values are 1 to 3 (1 for Ad0 only, 2 for Ad0 and Ad1, 2 for Ad0, Ad1 and Ad2).

---

## Current Loop Function

This window looks like this:

A dialog box titled "Current loop (PSR)" with a close button (X) in the top right corner. It contains two radio buttons: "Multidrop" and "Point-to-Point". The "Point-to-Point" radio button is selected.

It allows you to select a:

- **Multidrop** (Current Loop) communication,
- **Point to point** (Current Loop) communication.



## Transmission linked Uni-Telway Parameters

---

### At a Glance


After configuring the communication channel, you need to enter the transmission parameters.

These are split into six windows:

- the **Transmission speed** window,
  - the **Time wait** window,
  - the windows specific to **Data** and **Stop**,
  - the **Parity** window,
  - the **RTS/CTS Delay** window.
- 

### Transmission speed

This window looks like this:




You can use it to select the transmission speed of the Uni-Telway protocol used by the module:

- the default speed is 9600 bits/s,
  - other available speeds are 1200, 2400, 9600 and 19200 bits/s,
  - the speeds 300 and 600 bits/s are only available using the PCMCIA TSX SCP 111 card.
- 

### Wait time

This window looks like this:



This parameter allows you to select the wait time in milliseconds (timeout), at the end of which the target station, if it does not reply, is considered absent:

- the possible values are X to 255 ms (for the Terminal Port) or X to 10000 ms (for a PCMCIA card and built-in link). X is the minimum value. This depends on the set transmission speed,
- the default value is 30 ms.

For the Terminal Port, you can choose the wait time in seconds. The possible values are between X and 10 s.

---

## Data

This window looks like this:




A small window titled "Data" with two radio buttons. The first radio button is labeled "8 bits" and is selected. The second radio button is labeled "7 bits" and is not selected.

The **Data** field is used to fill in the type of coding used to communicate in Uni-Telway. All characters are coded over 8 bits.

---

## Stop

This window looks like this:



A small window titled "Stop" with two radio buttons. The first radio button is labeled "1 bit" and is selected. The second radio button is labeled "2 bits" and is not selected.

The **Stop** field allows you to fill in the number of stop bits used for communication in Uni-Telway. The possible values are 1 or 2 stop bits.


---

**Note:** The default value is 1 stop bit.

---

## Parity

This window looks like this:




A small window titled "Parity" with three radio buttons. The first radio button is labeled "Even" and is selected. The second radio button is labeled "Odd" and is not selected. The third radio button is labeled "Without" and is not selected.

This field is used to set whether a parity bit is added or not, as well as its type. The possible values are Even, Odd or without (Odd by default).

---

## RTS/CTS Delay

This window looks like this:



A configuration window titled "RTS/CTS Delay". It contains a text input field with the value "1" followed by "X100 ms". To the right of this field is a checkbox labeled "Data carrier (DCD)" which is checked.

Before a character string is transmitted, the module activates the RTS signal and waits for the CTS signal to be activated.

This allows you to enter:

- the maximum waiting time between the two signals. When this value is timed-out, the request is not transmitted on the bus.
    - The value is expressed in milliseconds,
    - the default value is 0 ms,
    - the possible values are 0s to 10s,
    - the value 0 specifies an absence of delay management between the two signals.
  - data carrier management (DCD signal) for communication with a modem having a controlled data carrier.
    - If the option is selected, the characters are only valid on reception if the DCD signal is detected,
    - If the option is not selected, all characters received are taken into account.
-

# 10.3

# Uni-Telway communication programming

---

## At a Glance

### Subject of this Section

This section describes the Programming process used when implementing Uni-Telway communication.

### What's in this Section?

This section contains the following topics:

Topic	Page
Available communication functions	268
Writing command words	269
Master to Slave exchanges	270
Slave to Master exchanges	272
Example of an exchange from a slave to the Master system	275
Example of a direct exchange from a slave to the Master system	277
Slave to Slave exchanges	278
Example of an exchange from a slave to a slave server	280
Example of an exchange from a slave to a slave application	282
Example 2 of an exchange from a slave to a slave system	283
Example of a direct exchange from a slave to a slave system	285
Example of one slave setting another slave to Stop	286
Event data managed by the master	287

## Available communication functions

---

### At a Glance

This page describes the available communication functions in Uni-Telway mode.

---

### Available functions

Five specific communication functions are defined to send and receive data to a master or slave Uni-Telway device:

- **READ\_VAR**: reading basic language objects (words, bits, double words, floating points, constant words, system bits and words, timer, monostable, drum). (See Unity Pro, Communication Block Library Manual, **READ\_VAR**: Reading variables).
- **WRITE\_VAR**: writing basic language objects (words, bits, double words, floating points, constant words, system bits and words). (See Unity Pro, Communication Block Library Manual, **WRITE\_VAR**: Schreiben von Variablen ).
- **SEND\_REQ**: exchanging a UNI-TE request. (See Unity Pro, Communication Block Library Manual, **SEND\_REQ**: Sending requests).
- **DATA\_EXCH**: sending and/or receiving text type data. (See Unity Pro, Communication Block Library Manual, **DATA\_EXCH**: Exchanging data between applications).
- **Dialog operator functions**: exchanging different specific communication functions in operator dialog (**Send\_Msg**, **Send\_alarm**, **Ask\_Msg**, **Ini\_Buttons**, **Control\_Leds**, **Command**).

**Note:** The availability of these functions varies with the type of exchanges and hardware versions (see different exchange types).

---

## Writing command words

---

### At a Glance

The instruction `WRITE_CMD` is used for explicit writing in the module or the communication channel, or in the built-in interface of the associated command words.

For a Uni-Telway link, this instruction will mainly be used for communication with an external modem.

**Example:** switching from Uni-Telway mode to character mode for the dialing phase.

---

### Syntax

The syntax of the instruction is as follows:

```
WRITE_CMD ( IODDT_VAR1 )  
where IODDT_VAR1 is type T_COM_STS_GEN
```

---

### Recommendations for use

Before executing a `WRITE_CMD`, test whether an exchange is currently underway using the language object `%MWr.m.c.0`. To do this, you must perform a `READ_STS` to read the word.

You then need to modify the value of the command language object in order to perform the required command. For a Uni-Telway link, the language object is the internal word `%MWr.m.c.15`.

**Example:** To switch from Uni-Telway mode to character mode, `%MWr.m.c.15` is also set to `16#4000` (`%MWr.m.c.15.6 = 1`).


**Note:** A single command bit must then be switched from 0 to 1 before transmitting a `WRITE_CMD`.

Finally, a `WRITE_CMD` must be executed to acknowledge the command.

---

## Master to Slave exchanges

**At a Glance**      The Master station carries out exchanges to the Slave station:



### Exchange to address Ad0

An exchange from the Master to Ad0, as seen at point 1 in the diagram above, is used for communication from the Master application program to the Slave system (access to the different objects, etc.).

The functions `READ_VAR`, `WRITE_VAR` and `SEND_REQ` can be used to communicate to Ad0.

The function address is type `ADDR('r.m.c.x')`, where:

Parameters	Description
r	Rack number
m	Module number
c	Channel number
x	Ad0 Slave address

### Example

`ADDR('0.0.1.Ad0')` for a slave connected to a PCMCIA card in the Master PLC,

**Exchange to  
address Ad2**

An exchange from the Master to Ad2, as seen at point 2 in the diagram above, is used for sending messages from the Master application program to the Slave application program.

The functions `SEND_REQ` and `DATA_EXCH` can be used to communicate to Ad2.

The function address is type `ADDR('r.m.c.x')`, where:

Parameter	Description
r	Rack number
m	Module number
c	Channel number
x	Ad2 Slave address.

**Example**


`SEND_REQ(ADDR('0.0.1.Ad2'), 16#FC, %MW.....)`

Here: use of the request code, 16#FC, unsolicited data.

## Slave to Master exchanges

---

**At a Glance**      The Slave station carries out exchanges to the Master station:



---

**Exchanges to the master station**      An exchange from the Slave Ad1 to the Master, as seen at point 1 in the diagram above, is used for communication from the Slave application program to the Master system (access to the different objects, etc.).

---

**Exchanges to the application**      An exchange from the Slave Ad1 to the Master, as seen at point 2 in the diagram above, is used for sending messages from the Slave application program to the Master application program.

---



**Communication function**

Usage of the `SEND_REQ` function by a slave requires the introduction of a table of 6 bytes corresponding to the destination address at the beginning of the transmission buffer.

The first six bytes of the transmission buffer are coded as follows:

	Byte 1 (most significant)	Byte 0 (least significant)
Word 1	station	network
Word 2	module number or selector	gate number
Word 3	reference if gate 8	channel number

To send to the Master system identified by gate 0:

	Byte 1 (most significant)	Byte 0 (least significant)
Word 1	16#FE	16#00
Word 2	16#00	16#00
Word 3	16#00	16#00

To send to the Master application identified by gate 16:

	Byte 1 (most significant)	Byte 0 (least significant)
Word 1	16#FE	16#00
Word 2	16#00	16#10
Word 3	16#00	16#00

**Note:** For a TSX 47-10 master, the gate number is 16 + text block number

To send to the system of a remote PLC (network 2 station 3):

	Byte 1 (most significant)	Byte 0 (least significant)
Word 1	16#03	16#02
Word 2	16#00	16#00
Word 3	16#00	16#00

**Addressing**

When a slave uses the `SEND_REQ` function, the syntax used is as follows:

```
SEND_REQ(ADDR('r.m.c.x'), request number, , %MW1:size)
```

The address of the function transmitter is type `ADDR('r.m.c.x')`, where:

Parameter	Description
r	Rack number
m	Module number
c	Channel number
x	Ad1 client address of the transmitter


`%MW1:size` is a table of words containing the destination address structured as follows:

If access to Master system	If access to Master application
%MW1 = FE 00	%MW1 = FE 00
%MW2 = 00 00	%MW2 = 00 10
%MW3 = 00 00	%MW3 = 00 00
%MW4 = request parameters	%MW4 = request parameters
%MW ... = ...	%MW ... = ...

# Example of an exchange from a slave to the Master system

## At a Glance

The slave transmits a communication function to the Master system:



**Transmission**

Send the identification request:

```
SEND_REQ(ADDR('0.0.1.7'), 15, %MW0:3, %MW40:4, %MW10:30)
```

Parameters of the request:

Parameters	Description
ADDR('0.0.1.7')	<ul style="list-style-type: none"><li>● 0 : rack</li><li>● 0 : module</li><li>● 1 : channel 1</li><li>● 7 : transmitting address Ad1</li></ul>
15 or 16 #0F	identification request
%MW0 = 16#FE 00	access to the Master system gate
%MW1 = 16#00 00	
%MW2 = 16#00 00	
%MW43 = 6	transmission of 3 words (= 6 bytes)

---

**Reception**

After the exchange:

Parameters	Description
%MW40 = 16# 11 00	-
%MW41 = 16# 3F 00	16#3F = report >0 (request code + 16#30)
%MW42 = 16# 00 00	-
%MW43 = 16# 00 14	reception of 14 bytes from %MW10


---

## Example of a direct exchange from a slave to the Master system

---

### At a Glance

The host channel of the TSX SCY 21601 module equipped with the PCMCIA card (TSX SCP 111, 112, 114) enables you to use the `READ_VAR` and `WRITE_VAR` communication functions to communicate with the server of a master:



### Transmission

From module TSX SCY 21601 in position 0 of the slave rack and through the built-in link, the server of the master can be accessed:


```
READ_VAR(ADDR('0.2.0.0'), '%MW', 0, 5, %MW50:4, %MW20:5)
```

---

## Slave to Slave exchanges

### Introduction

The slave station makes exchanges with another slave station:



### Ad1 to Ad0 exchange

Exchange of slave Ad1 with slave Ad0, identified by address mark 1, allows the sender slave application program to communicate with the destination slave system (access to different objects, etc.).

**Note:** In all cases, the requests transit via the master in total transparency.

### Exchange with the application

Exchange of slave Ad1 with slave Ad2, identified by the address mark 2, is used to send messages from the sender slave application program to the destination slave application program.

**Communication  
function**

Use of the `SEND_REQ` function by the slave requires a 6 byte table to be placed at the start of the transmission buffer which corresponds to the destination address. The first six bytes of the transmission buffer are coded as follows:

	Byte 1 (most significant)	Byte 0 (least significant)
Word 1	16#FE	16#00
Word 2	16#FE	16#05
Word 3	16#00	number of destination slave (Ad0 or Ad2)


---

## Example of an exchange from a slave to a slave server

---

### At a Glance

The Slave transmits a communication function to the slave server:





# Transmission

Write a 5-word table in Slave 9 by slaves 6/7/8 using the word %MW50:  
SEND\_REQ(ADDR('0.0.1.7'), 16#0037, %MW100:11, %MW130:4,  
%MW120:1)

Parameters of the request:

Parameters	Description
ADDR('0.0.1.7')	<ul style="list-style-type: none"> <li>0 : rack</li> <li>0 : module</li> <li>1 : channel 1</li> <li>7 : transmitting address Ad1</li> </ul>
16 #0037	object write request
%MW100 = 16#FE 00	destination slave address (Ad0 = 9)
%MW101 = 16#FE 05	
%MW102 = 16#00 09	
%MW103 = 16#07 68	<ul style="list-style-type: none"> <li>type of object = 07 (16 bit integer)</li> <li>segment = 68 (internal words)</li> </ul>
%MW104 = 50	in decimal, origin of the table of words to write
%MW105 = 05	in decimal, number of words to write
%MW106 to %MW110	content of words to write to the destination
%MW133 = 22	length of the data to transmit = 11 words (%MW100 to %MW110) therefore 22 bytes
%MW120:1	no response: length 1 byte

## Example of an exchange from a slave to a slave application

---

### At a Glance

The Slave transmits a communication function to the slave application (Ad2).

---

### Transmission

The PLC sender generates an unsolicited data request:

```
SEND_REQ(ADDR('0.0.1.7'), 16#00FC, %MW100:10, %MW130:4,  
%MW120:1)
```

Parameters of the request:

Parameters	Description
ADDR('0.0.1.7')	<ul style="list-style-type: none"><li>● 0 : rack</li><li>● 0 : module</li><li>● 1 : channel 1</li><li>● 7 : transmitting address Ad1</li></ul>
16 #00FC	unsolicited data request
%MW100 = 16#FE 00	destination slave address (Ad2 = 11)
%MW101 = 16#FE 05	
%MW102 = 16#00 0B	
%MW103 to %MW109	application data to transmit

---

### Reception

The PLC data receiver:

```
DATA_EXCH(ADDR('0.0.1.11'), 3, %MW10:1, %MW100:4, %MW20:10)
```

Parameters of the request:

Parameters	Description
ADDR('0.0.10.11')	<ul style="list-style-type: none"><li>● 0 : rack</li><li>● 0 : module</li><li>● 1 : channel 1</li><li>● 11 : address Ad2</li></ul>
3	receipt request
%MW20 = 16#FE 00	xx: exchange number of the transmitter function
%MW21 = 16#FE xx	
%MW23 to %MW29	
%MW102 = 16#00 00	received application data

---

## Example 2 of an exchange from a slave to a slave system

**At a Glance** The slave address Ad1 = 7 reads a 5-word table, using the function SEND\_REQ, in the slave PLC with the address Ad0 = 9.

**Transmission** The PLC sender generates a request with the code 16#0036 (read objects):  
 SEND\_REQ(ADDR('0.0.1.7'), 16#0036, %MW200:6, %MW220:4, %MW210:6)

Parameters of the request:

Parameters	Description
ADDR('0.0.1.7')	<ul style="list-style-type: none"> <li>0 : rack</li> <li>0 : module</li> <li>1 : channel 1</li> <li>7 : transmitting address Ad1</li> </ul>
16 #0036	unsolicited data request
%MW200 = 16#FE 00	destination slave address (Ad0 = 9)
%MW201 = 16#FE 05	
%MW202 = 16#00 09	
%MW203 = 16#07 68	<ul style="list-style-type: none"> <li>type of object = 07 (16 bit integer)</li> <li>segment = 68 (internal words)</li> </ul>
%MW204 = 50	in decimal, origin of the table of words to read
%MW223 = 12	transmission of 6 words (12 bytes)

**Note:** Once the function has finished execution, the length word in the report is: %MW223 = 11 (reception of 11 bytes = 10 (5 words) + 1 (object type)).

**Reception table**      Table of read words:

	<b>Byte 1</b>	<b>Byte 0</b>
%MW210 =	Least significant byte of first word	07 : type of objects read
%MW211 =	Least significant byte of second word	Most significant byte of first word
%MW212 =	Least significant byte of third word	Most significant byte of second word
%MW213 =	Least significant byte of fourth word	Most significant byte of third word
%MW214 =	Least significant byte of fifth word	Most significant byte of fourth word
%MW215 =	not significant	Most significant byte of fifth word

The least significant byte of the first word read contains the type of objects read, the reception table is thus shifted by 1 byte.

An additional word must therefore be provided in the reception table. The data processing requires an algorithm for processing this shift. For Premium PLCs, this algorithm is provided by the function `ROR1_ARB` (See Unity Pro, Obsolete Block Library Manual, `RORI_ARB` function).


---

## Example of a direct exchange from a slave to a slave system

---

### At a Glance

The host channels of processors TSX 37 V2.0 and module TSX SCY 21601 equipped with PCMCIA cards (TSX SCP111, 112, 114 version 1.5) enable you to use the communication functions `READ_VAR` and `WRITE_VAR` from a slave of the same Uni-Telway link:



### Transmission

From module SCY 21601 in position 0 of the slave rack and through the built-in link, access to the server of slave 8:


```
READ_VAR(ADDR('0.2.0.8'), '%MW', 0, 5, %MW50:4, %MW20:5)
```

---

## Example of one slave setting another slave to Stop

### At a Glance

PLC with address Ad1= 7 setting slave PLC with address (Ad0 = 8) to STOP:



### Transmission

`SEND_REQ(ADDR('0.0.1.7'), 16#0025, %MW0:3, %MW40:4, %MW10:1)`

Parameters of the request:

Parameters	Description
ADDR('0.0.1.7')	<ul style="list-style-type: none"><li>● 0 : rack</li><li>● 0 : module</li><li>● 1 : channel 1</li><li>● 7 : transmitting address Ad1</li></ul>
16 #0025	STOP request code
%MW0 = 16#FE 00	destination slave address (Ad0 = 8)
%MW1 = 16#FE 05	
%MW2 = 16#00 08	
%MW43 = 6	length of the data to transmit = 3 words (therefore 6 bytes)

## Event data managed by the master

### Event data

Event data is data that is transmitted to the master from a server slave station.

### Operating principles

The following table describes the processing phases in event data communication:

Phases	Description
1	The slave station transmits event data to the PCMCIA card of the master station.
2	When the card receives the data, a bit from words %IW0.0.1.2 or %IW0.0.1.3 is initialized. Each bit of the input words is associated with a link address.
3	On detecting one of the bits, the application transmits a <code>SEND_REQ</code> communication function with code 16#32 to the PCMCIA card of the master station for the data to be read.

### Communication function

The Uni-Telway request: 16#82 is used to read event data by accessing the Uni-Telway PCMCIA server:

```
SEND_REQ(ADDR('0.0.1.SYS'), 16#0082, %MW20:10, %MW100:4, %MW50:30)
```

The transmission buffer contains the following data:

Word	Byte 1 (most significant)	Byte 0 (least significant)
%MW21	16#31	16#06
%MW22	16#01	16#00
%MW23	Slave number	16#00
%MW24	16#FF	16#00
%MW25	16#00	Number of slaves

The buffer corresponds to the following coding:

Parameters	Size	Value
Segment number	1 byte	16#06
Family number	2 bytes	16#0031
Type number	2 bytes	16#0001
Address	1 byte	Slave number
Type of access	2 bytes	16#00FF
Quantity	2 bytes	16#00 No. of slaves

# 10.4                    Debugging of a Uni-Telway communication

---

## At a Glance

**Aim of this sub-section**                    This sub-section describes the Debugging process during set-up of Uni-Telway communication.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
Uni-Telway debugging screen	289
Uni-Telway debugging screen	291
Requests available for the communication channel test	292
How to test a channel with Identification and Mirror requests	293
How to test a channel with requests	294

---



# Uni-Telway debugging screen


## At a Glance

This screen, split into two zones, is used to declare the communication channel and to configure the necessary parameters for a Uni-Telway link.

**Note:** This screen is not operational when connected **remotely** on a Uni-Telway slave

## Illustration

The figure below shows a sample debugging screen dedicated to Uni-Telway communication.



**Description**

The table below shows the various elements of the debugging screen and their functions.

Address	Element	Function
1	Tabs	The front tab shows the current mode ( <b>Debugging</b> in this example). Each mode can be selected by the corresponding tab. The modes available are: <ul style="list-style-type: none"><li>● <b>Debugging</b> accessible only in online mode,</li><li>● <b>Diagnostics</b> accessible only in online mode,</li><li>● <b>Configuration</b>.</li></ul>
2	<b>Module</b> zone	Specifies the shortened name of the module.
3	<b>Channel</b> field	Is used: <ul style="list-style-type: none"><li>● By clicking on the reference number, to display the tabs:<ul style="list-style-type: none"><li>● <b>Description</b> which gives the characteristics of the device.</li><li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li><li>● <b>Fault</b> which shows the device faults (in online mode).</li></ul></li><li>● To select the channel,</li><li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li></ul>
4	<b>General parameters</b> zone	Shows the communication channel parameters: <ul style="list-style-type: none"><li>● <b>Function</b>: shows the configured communication function. This information cannot be modified.</li><li>● <b>Task</b>: shows the configured <b>MAST</b> task. This information cannot be modified.</li></ul>
5	<b>Display and command</b> zone	is used to access the debugging parameters for a Uni-Telway link.

<b>Note:</b> LEDs and commands not available appear grayed out.
---

---

## Uni-Telway debugging screen

### At a Glance

The specific part is divided into three windows:

- the **Type** window,
- the **Counters** window,
- the **Channel test** window.

### Type Window


This window looks like this:



It shows the type of Uni-Telway function which is configured (master or slave).

### Counters Window


This window looks like this:



This window displays the communication module's different error counters. The **Reset Counters** button resets these counters to zero.

### Channel Test window

This window looks like this:



This window is used to test a communication channel by sending a UNI-TE request to one of the stations on the bus.

## Requests available for the communication channel test

---

### At a Glance

This page describes the different possibilities for testing a communication channel from the debugging screen.

---

### Test conditions

Sending a request to an non-server or unconnected slave address results in an error message.

When the module has been configured in Uni-Telway master mode, the debugging window can be used to send a UNI-TE request to one of the slaves on the bus.

When the module has been configured Uni-Telway slave mode, the channel test is limited to the master device.

---

### Available requests

The Channel Test window allows the following requests:

- **Identification:** prompts the Identification request to be sent to the designated slave,
  - **Enter request:** allows a UNI-TE request, other than those provided by the command buttons, to be sent to the designated slave. Selecting this function gives access to a screen that allows you to select the parameters that are specific to the request (request code must be coded in hexadecimal),
  - **Mirror:** allows a mirror request to be sent to the designated slave. Selecting this function gives access to a screen that allows you to select the length of the character string to be sent (a maximum of 80 characters ). The PLC then sends this character string (ABCD.) to the destination device. The latter automatically sends the character string that was received back to the sender.
-


# How to test a channel with Identification and Mirror requests

## At a Glance

This page indicates the procedure for testing a communication channel by means of Identification and Mirror requests.



## How to identify a station

The following procedure is used to identify a designated station.

Step	Actions
1	Select the server address (Ad0)of the slave to be interrogated using the <b>Slave</b> field.
2	Click on the <b>Identification</b> button. <b>Result:</b> the response appears in the <b>Receive Response</b> window: 

## How to send the Mirror request

The following procedure is used to send the Mirror request and thus to test the routing of information between two devices.

Step	Action
1	Select the server address (Ad0)of the slave to be interrogated using the <b>Slave</b> field.
2	Click on the <b>Mirror</b> button. <b>Result:</b> the following window appears. 
3	Enter the length of data to be sent (maximum 80 characters).
4	Click on the <b>Send</b> button. <b>Result:</b> the response appears in the <b>Receive Response</b> window:  The response contains: <ul style="list-style-type: none"> <li>the character string ABCDEFGH that corresponds to the length of data sent 8.</li> </ul>



## How to test a channel with requests

### At a Glance

This page indicates the procedure for testing a communication channel from the debugging screen using different requests.

### How to send a request

The following procedure is used to send a request, other than those provided by the command buttons, to a designated station.

Step	Action
1	Select the address of the slave to be interrogated using the <b>Slave</b> field.
2	<p>Click on the <b>Enter Request</b> button.</p> <p><b>Result:</b> the following window appears.</p> <div data-bbox="673 576 1057 781"></div> <p>The data sent in this example is coded on 3 bytes.</p>
3	Enter the function code (coded in hexadecimal on one byte), corresponding to the request that you want to send.
4	Enter the data to be sent by coding all the data in hexadecimal. Enter the data continuously without any intervening spaces.
5	<p>Click on the Send button.</p> <p><b>Result:</b> the response appears in the <b>Request Response</b> window:</p> <div data-bbox="680 1036 1052 1154"></div> <p>the response from the example has data on 3 bytes (12 43 DB).</p>

---

# Software Implementation of Specific Protocol Communication (FCS SCP 111/114 cards)

11

---

## At a Glance

### Subject of this Chapter

This chapter describes software implementation for specific protocol communication using **FCS SCP 111/114** PCMCIA cards.

### What's in this Chapter?

This chapter contains the following sections:

Section	Topic	Page
11.1	General Points	296
11.2	Configuration of Specific Protocol Communication	299
11.3	Debugging a Specific Protocol Communication	304

# 11.1                    General Points

---

## At a Glance

---

**Subject of this Section**                    This section presents the general points relating to specific protocol communication.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
Presentation	297
Operating Mode	298

---



## Presentation

---

### At a Glance

The **FCS SCP111/114** PCMCIA cards enable third-parties to implement specific protocols for physical supports RS232 or RS485.

Unity Pro is used to configure and debug PCMCIA cards integrating specific protocols.

Contact your Schneider Electric sales office to obtain a list of companies accredited to develop the protocol to be implemented.

---

### Protocols

This type of communication is available for Premium PLCs via the host slot of the processor and/or the **TSX SCY 21601** module, using:

- An **FCS SCP 111** PCMCIA card associated with the RS232 physical layer,
  - An **FCS SCP 114** PCMCIA card associated with the RS485 physical layer.
-

## Operating Mode

---


### At a Glance

The following graph describes the operating modes of the **FCS SCP 111/114** PCMCIA cards.

---

### General Chart

The operating mode is as follows:



### Operation

- After power-up the module self-tests. During this stage the warning indicators flash.
  - If there is no Unity Pro application in the PLC, the module awaits configuration.
  - If there is a Unity Pro application in the PLC, the application's configuration is transmitted to the module, and then the module starts up.
  - When there is a power outage, the PLC processor carries out a warm restart. The module then restarts its self-test procedures.
-

## 11.2 Configuration of Specific Protocol Communication

---

### At a Glance

**Subject of this Section**

This section describes the Configuration process used when implementing Specific Protocol communication.

---

**What's in this Section?**

This section contains the following topics:

Topic	Page
How to Access the Parameters of Specific Protocol PCMCIA Cards	300
Configuration Screen for the Generic Protocol Function	302

---

## How to Access the Parameters of Specific Protocol PCMCIA Cards



### At a Glance

This operation describes how to declare and define the type of function for **FCS SCP 111/114** PCMCIA cards for Premium PLCs.

### How to Define the Function

The following table shows the procedure for selecting the card and choosing the generic protocol function:


Step	Action																						
1	Open the hardware configuration editor.																						
2	<div>Double-click on the PCMCIA card slot (processor or TSX SCY 21601 module). <b>Result:</b> the card type selection window appears.</div> <div><div>Add/Replace Submodule</div><table><tr><th>Product reference</th><th>Description</th></tr><tr><td> Communication</td><td></td></tr><tr><td> FCS SCP 111</td><td>OPEN RS232 PCMCIA CARD</td></tr><tr><td> FCS SCP 114</td><td>OPEN RS485 PCMCIA CARD</td></tr><tr><td> TSX FPP 20</td><td>FIPWAY PCMCIA CARD</td></tr><tr><td> TSX FPP 200</td><td>FIPWAY PCMCIA CARD</td></tr><tr><td> TSX JNP 112</td><td>BC JNET PCMCIA CARD</td></tr><tr><td> TSX JNP 114</td><td>RS485 JNET PCMCIA CARD</td></tr><tr><td> TSX SCP 111</td><td>RS232 MP PCMCIA CARD</td></tr><tr><td> TSX SCP 112</td><td>BC MP PCMCIA CARD</td></tr><tr><td> TSX SCP 114</td><td>RS485 MP PCMCIA CARD</td></tr></table></div>	Product reference	Description	Communication		FCS SCP 111	OPEN RS232 PCMCIA CARD	FCS SCP 114	OPEN RS485 PCMCIA CARD	TSX FPP 20	FIPWAY PCMCIA CARD	TSX FPP 200	FIPWAY PCMCIA CARD	TSX JNP 112	BC JNET PCMCIA CARD	TSX JNP 114	RS485 JNET PCMCIA CARD	TSX SCP 111	RS232 MP PCMCIA CARD	TSX SCP 112	BC MP PCMCIA CARD	TSX SCP 114	RS485 MP PCMCIA CARD
Product reference	Description																						
Communication																							
FCS SCP 111	OPEN RS232 PCMCIA CARD																						
FCS SCP 114	OPEN RS485 PCMCIA CARD																						
TSX FPP 20	FIPWAY PCMCIA CARD																						
TSX FPP 200	FIPWAY PCMCIA CARD																						
TSX JNP 112	BC JNET PCMCIA CARD																						
TSX JNP 114	RS485 JNET PCMCIA CARD																						
TSX SCP 111	RS232 MP PCMCIA CARD																						
TSX SCP 112	BC MP PCMCIA CARD																						
TSX SCP 114	RS485 MP PCMCIA CARD																						
3	<div>From the menu, click on one of the following PCMCIA cards then validate by clicking <b>OK</b>.</div> <ul style="list-style-type: none"><li>● <b>FCS SCP 111</b></li><li>● <b>FCS SCP 114</b></li></ul>																						

Step	Action
4	<div>Double click again on the PCMCIA card slot. Result:</div> <div></div>
5	<div>Select channel 1.</div>
6	<div>Select the <b>GENERIC PROTOCOL</b> function. Example:</div> <div></div>

## Configuration Screen for the Generic Protocol Function

**General Points** The configuration screen is used to set up the necessary parameters for the Generic Protocol function.

**Illustration** The figure below represents a configuration screen.



**Description**

The following table shows the various elements of the configuration screen and their functions.


Number	Element	Function
1	Tabs	The tab in the foreground indicates which mode is currently in use ( <b>Config</b> in this example). Select each mode by clicking on the corresponding tab. The available modes are: <ul style="list-style-type: none"> <li>● <b>Configuration</b>,</li> <li>● <b>Debug</b> which can be accessed only in online mode,</li> <li>● <b>Fault</b> which can be accessed only in online mode.</li> </ul>
2	<b>Module</b> area	Uses LEDs to provide a reminder of the module and module status in online mode.
3	<b>Channel</b> area	Is used: <ul style="list-style-type: none"> <li>● By clicking on the device reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select the channel you wish to configure,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> area	Enables you to choose the general parameters associated with the channel: <ul style="list-style-type: none"> <li>● <b>Function:</b> the <b>Generic Protocol</b> function is proposed. By default, <b>No</b> function is configured.</li> <li>● <b>Task:</b> defines the <b>MAST</b> task in which the channel implicit exchange objects will be exchanged.</li> </ul>
5	<b>Configuration</b> area	Is used to configure the channel configuration parameters (%KW). Each value can be entered in decimal, hexadecimal or binary format, depending on the selection made in the <b>Base</b> window. For information on the meaning of the %KWs, refer to the PCMCIA card supplier documentation.

# 11.3 Debugging a Specific Protocol Communication

## Debug Screen for the Generic Protocol Function

**At a Glance** This screen, divided into several areas, is used to display the status and input/output %MWs, and send requests.

**Illustration** The figure below shows an example of a debug screen for the Generic Protocol function.





**Description**

The table below shows the various elements of the debug screen and their functions.

Number	Element	Function
1	Tabs	The tab in the foreground indicates the mode in progress ( <b>Debug</b> in this example). Each mode can be selected using the respective tab. The available modes are: <ul style="list-style-type: none"> <li>● <b>Debug</b> which can be accessed only in online mode,</li> <li>● <b>Fault</b> which can be accessed only in online mode,</li> <li>● <b>Configuration</b>.</li> </ul>
2	<b>Module</b> area	Specifies the abbreviated heading of the module.
3	<b>Channel</b> area	Is used: <ul style="list-style-type: none"> <li>● By clicking on the reference number, to display the tabs: <ul style="list-style-type: none"> <li>● <b>Description</b> which gives the characteristics of the device.</li> <li>● <b>I/O Objects</b> (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) which is used to presymbolize the input/output objects.</li> <li>● <b>Fault</b> which shows the device faults (in online mode).</li> </ul> </li> <li>● To select a channel,</li> <li>● To display the <b>Symbol</b>, name of the channel defined by the user (using the variable editor).</li> </ul>
4	<b>General parameters</b> area	Shows the communication channel parameters: <ul style="list-style-type: none"> <li>● <b>Function:</b> provides a reminder of the configured communication function. This heading is frozen.</li> <li>● <b>Task:</b> shows the configured <b>MAST</b> task. This heading is frozen.</li> </ul>
5	<b>Viewing and control</b> area	It is used to: <ul style="list-style-type: none"> <li>● Select and display: <ul style="list-style-type: none"> <li>● Status words,</li> <li>● Input words,</li> <li>● Output words (modifiable).</li> </ul> </li> <li>● Set the card counter to zero with the <b>Reset Counters</b> button,</li> <li>● Send requests from the protocol managed by the card, and display the responses according to an operating mode defined in the card documentation.</li> </ul>



---

# Language objects of Modbus, Character Mode and Uni-Telway communications

12

---

## At a Glance

**Subject of this Chapter**

This chapter describes the language objects associated with Modbus, Character Mode and Uni-Telway communications, and the different ways of using them.

**What's in this Chapter?**

This chapter contains the following sections:

Section	Topic	Page
12.1	Language objects and IODDTs of Modbus, Character Mode and Uni-Telway communications	308
12.2	General language objects and IODDTs for all communication protocols	317
12.3	Language objects and IODDTs associated with Modbus communication	321
12.4	Language objects and IODDTs associated with Character Mode communication	327
12.5	Language objects and IODDTs associated with Uni-Telway communication	334
12.6	Language Objects Associated with the Specific Protocol	347
12.7	The IODDT type T_GEN_MOD applicable to all modules	348

12.1

Language objects and IODDTs of Modbus,  
Character Mode and Uni-Telway communications

---

At a Glance

---

Subject of this  
Section

This section presents the general points relating to language objects and IODDTs of Modbus, Character Mode and Uni-Telway communications.

---

What's in this  
Section?

This section contains the following topics:

Topic	Page
Presentation of the language objects for Modbus, Character Mode and Uni-Telway communications	309
Implicit Exchange Language Objects Associated with the Application-Specific Function	310
Explicit exchange language objects associated with the application-specific function	311
Management of exchanges and reports with explicit objects	313

---

## Presentation of the language objects for Modbus, Character Mode and Uni-Telway communications

---

### General

IODDTs are predefined by the manufacturer, and contain input/output language objects belonging to an application-specific module.

Modbus, Character Mode and Uni-Telway communications have five associated IODDTs:

- T\_COM\_STS\_GEN which applies to all communication protocols
- T\_COM\_MB which is specific to Modbus communication
- T\_COM\_CHAR which is specific to Character Mode communication
- T\_COM\_UTW\_M which is specific to Uni-Telway master communication
- T\_COM\_UTW\_S which is specific to Uni-Telway slave communication

**Note:** IODDT variables can be created in two different ways:

- Using the **I/O objects** (See Unity Pro, Operating Modes Manual, I/O Objects Tab for a Module) tab,
- Data Editor (See Unity Pro, Operating Modes Manual, Creation of an IODDT type data instance).

### Types of language objects

In each IODDT we find a set of language objects that enable us to control them and check their correct operation.

There are two types of language objects:

- **implicit exchange objects**, which are automatically exchanged at each cycle of the task associated with the module,
- **explicit exchange objects**, which are exchanged when requested to do so by the application, using explicit exchange instructions.

The implicit exchanges concern module status, communication signals, slaves, etc. The explicit exchanges are used to set the module and perform diagnostics.

---

## Implicit Exchange Language Objects Associated with the Application-Specific Function

---

### At a Glance

An integrated application-specific interface or the addition of a module automatically enhances the language objects application used to program this interface or module.

These objects correspond to the input/output images and software data of the module or integrated application-specific interface.

### Reminders

The module inputs (%I and %IW) are updated in the PLC memory at the start of the task, the PLC being in RUN or STOP mode.


The outputs (%Q and %QW) are updated at the end of the task, only when the PLC is in RUN mode.

**Note:** When the task occurs in STOP mode, either of the following are possible, depending on the configuration selected:

- Outputs are set to fallback position (fallback mode),
- Outputs are maintained at their last value (maintain mode).

### Figure

The following diagram shows the operating cycle of a PLC task (cyclical execution).



## Explicit exchange language objects associated with the application-specific function

---

### At a Glance

Explicit exchanges are exchanges performed at the user program's request, and using instructions:

- READ\_STS (See Unity Pro, I/O Management Manual, READ\_STS)  
(read status words),
- WRITE\_CMD (See Unity Pro, I/O Management Manual, WRITE\_CMD)  
(write command words),
- WRITE\_PARAM (See Unity Pro, I/O Management Manual, WRITE\_PARAM)  
(write adjustment parameters),
- READ\_PARAM (See Unity Pro, I/O Management Manual, READ\_PARAM)  
(read adjustment parameters),
- SAVE\_PARAM (See Unity Pro, I/O Management Manual, SAVE\_PARAM)  
(save adjustment parameters),
- RESTORE\_PARAM (See Unity Pro, I/O Management Manual, RESTORE\_PARAM) (restore adjustment parameters).


These exchanges apply to a set of %MW objects of the same type (status, commands or parameters) that belong to a channel.

<p><b>Note:</b> These objects provide information about the module (e.g.: type of channel fault, etc.), can be used to command them (e.g.: switch command) and to define their operating modes (save and restore adjustment parameters in the process of application).</p>
--

---

**General principle  
for using explicit  
instructions**

The diagram below shows the different types of explicit exchanges that can be made between the processor and module.




(1) Only with READ\_STS and WRITE\_CMD instructions.

**Managing  
exchanges**

During an explicit exchange, it is necessary to check its performance in order that data is only taken into account when the exchange has been correctly executed.

- To do this, two types of information is available:
- information concerning the exchange in progress (See *Execution indicators for an explicit exchange: EXCH\_STS*, p. 316),
  - the exchange report (See *Explicit exchange report: EXCH\_RPT*, p. 316).
- The following diagram describes the management principle for an exchange





# Management of exchanges and reports with explicit objects


## At a Glance

When data is exchanged between the PLC memory and the module, the module may require several task cycles to acknowledge this information. All IODDTs use two words to manage exchanges:

- EXCH\_STS (%MWr.m.c.0): exchange in progress,
- EXCH\_RPT (%MWr.m.c.1): report.

## Illustration

The illustration below shows the different significant bits for managing exchanges:



**Description of the significant bits**

Each bit of the words EXCH\_STS (%MWr.m.c.0) and EXCH\_RPT (%MWr.m.c.1) is associated with a type of parameter:


- Rank 0 bits are associated with the status parameters:
  - the STS\_IN\_PROGR bit (%MWr.m.c.0.0) indicates whether a read request for the status words is in progress,
  - the STS\_ERR bit (%MWr.m.c.1.0) specifies whether a read request for the status words is accepted by the module channel.
- Rank 1 bits are associated with the command parameters:
  - the CMD\_IN\_PROGR bit (%MWr.m.c.0.1) indicates whether command parameters are being sent to the module channel,
  - the CMD\_ERR bit (%MWr.m.c.1.1) specifies whether the command parameters are accepted by the module channel.
- Rank 2 bits are associated with the adjustment parameters:
  - the ADJ\_IN\_PROGR bit (%MWr.m.c.0.2) indicates whether the adjustment parameters are being exchanged with the module channel (via WRITE\_PARAM, READ\_PARAM, SAVE\_PARAM, RESTORE\_PARAM),
  - the ADJ\_ERR bit (%MWr.m.c.1.2) specifies whether the adjustment parameters are accepted by the module. If the exchange is correctly executed, the bit is set to 0.
- rank 15 bits indicate a reconfiguration on channel c of the module from the console (modification of the configuration parameters + cold start-up of the channel).

**Note:** **r** corresponds to the number of the rack and **m** to the position of the module in the rack, while **c** corresponds to the channel number in the module.

**Note:** Exchange and report words also exist at module level EXCH\_STS (%MWr.m.MOD) and EXCH\_RPT (%MWr.m.MOD.1) as per IODDT type T\_GEN\_MOD.


**Example**

Phase 1: Sending data by using the `WRITE_PARAM` instruction.



When the instruction is scanned by the PLC processor, the **Exchange in progress** bit is set to 1 in `%MWr.m.c`.

Phase 2: Analysis of the data by the I/O module and report



When the data is exchanged between the PLC memory and the module, acknowledgement by the module is managed by the `ADJ_ERR` bit (`%MWr.m.c.1.2`): Report (0 = correct exchange, 1 = faulty exchange).

**Note:** There is no adjustment parameter at module level.

**Execution indicators for an explicit exchange: EXCH\_STS**

The table below shows the control bits of the explicit exchanges : EXCH\_STS (%MWr.m.c.0):

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Command parameters exchange in progress	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjust parameters exchange in progress	%MWr.m.c.0.2
RECONF_IN_PROGR	BOOL	R	Reconfiguration of the module in progress	%MWr.m.c.0.15

**Explicit exchange report: EXCH\_RPT**

The table below shows the report bits : EXCH\_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Error reading channel status words (1 = failure)	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during a command parameter exchange (1 = failure)	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during an adjust parameter exchange (1 = failure)	%MWr.m.c.1.2
RECONF_ERR	BOOL	R	Error during reconfiguration of the channel (1 = failure)	%MWr.m.c.1.15

---

# 12.2            General language objects and IODDTs for all communication protocols

---

## At a Glance

---

**Subject of this Section**            This section presents the general language objects and IODDTs that apply to all communication protocols.

---

**What's in this Section?**            This section contains the following topics:

Topic	Page
Details of IODDT implicit exchange objects of type T_COM_STS_GEN	318
Details of IODDT explicit exchange objects of type T_COM_STS_GEN	319

---

## Details of IODDT implicit exchange objects of type T\_COM\_STS\_GEN

---

**At a Glance**            The following table presents the IODDT implicit exchange objects of type T\_COM\_STS\_GEN applicable to all communication protocols except Fipio.

---

**Error bit**                The table below presents the meaning of the error bit CH\_ERROR (%lr.m.c.ERR).

Standard symbol	Type	Access	Meaning	Address
CH_ERROR	EBOOL	R	Communication channel error bit.	%lr.m.c.ERR

---

## Details of IODDT explicit exchange objects of type T\_COM\_STS\_GEN

### At a Glance

This section presents the T\_COM\_STS\_GEN type IODDT explicit exchange objects applicable to all communication protocols except Fipio. It includes the word type objects whose bits have a specific meaning. These objects are presented in detail below.

Sample Variable Declaration: **IODDT\_VAR1** of type T\_COM\_STS\_GEN.

### Observations

- In general, the meaning of the bits is given for bit status 1. In specific cases an explanation is given for each status of the bit.
- Not all bits are used.

### Execution flags of an explicit exchange: EXCH\_STS

The table below shows the meaning of channel exchange control bits from channel EXCH\_STS (%MWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress.	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Current parameter exchange in progress.	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjustment parameter exchange in progress.	%MWr.m.c.0.2

### Explicit exchange report: EXCH\_RPT

The table below presents the meaning of the exchange report bits EXCH\_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Reading error for channel status words.	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during command parameter exchange.	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during adjustment parameter exchange.	%MWr.m.c.1.2

**Standard  
channel faults,  
CH\_FLT**

The table below shows the meaning of the bits of the status word CH\_FLT (%MWr.m.c.2). Reading is performed by a **READ\_STS(ODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
NO_DEVICE	BOOL	R	No device is working on the channel.	%MWr.m.c.2.0
1_DEVICE_FLT	BOOL	R	A device on the channel is faulty.	%MWr.m.c.2.1
BLK	BOOL	R	Terminal block fault (not connected).	%MWr.m.c.2.2
TO_ERR	BOOL	R	Time out error (defective wiring).	%MWr.m.c.2.3
INTERNAL_FLT	BOOL	R	Internal error or channel self-testing.	%MWr.m.c.2.4
CONF_FLT	BOOL	R	Different hardware and software configurations.	%MWr.m.c.2.5
COM_FLT	BOOL	R	Problem communicating with the PLC.	%MWr.m.c.2.6
APPLI_FLT	BOOL	R	Application error (adjustment or configuration error).	%MWr.m.c.2.7

---



---

# 12.3                    Language objects and IODDTs associated with Modbus communication

---

## At a Glance

---

**Subject of this Section**                    This section presents the language objects and IODDTs associated with Modbus communication.

---

**What's in this Section?**                    This section contains the following topics:

Topic	Page
Details of the implicit exchange objects of the T_COM_MB type IODDT	322
Details of the explicit exchange objects of the T_COM_MB type IODDT	323
Details concerning explicit exchange language objects for a Modbus function	325
Details of language objects associated with configuration Modbus mode	326

---

## Details of the implicit exchange objects of the T\_COM\_MB type IODDT

---

### At a Glance

The following tables present the implicit exchange objects of the T\_COM\_MB type IODDT which apply to Modbus communication.

---

### Error bit

The following table presents the meaning of the error bit CH\_ERROR (%I\_r.m.c.ERR).

Standard symbol	Type	Access	Meaning	Address
CH_ERROR	EBOOL	R	Communication channel error bit.	%I_r.m.c.ERR

---

### Word objects in Modbus master mode

The table below shows the meaning of the bits of the INPUT\_SIGNALS word (%IWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
DCD	BOOL	R	Data carrier detection signal.	%IWr.m.c.0.0
RI	BOOL	R	Ring indicator signal.	%IWr.m.c.0.1
CTS	BOOL	R	Ready to send signal.	%IWr.m.c.0.2
DSR	BOOL	R	Data ready signal.	%IWr.m.c.0.3

---

### Word object in Modbus slave mode

The language objects are identical to those of the Modbus master function. Only the objects in the following table differ

The table below shows the meaning of the bit of the INPUT\_SIGNALS word (%IWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
LISTEN_ONLY	BOOL	R	List mode only signal.	%IWr.m.c.0.8

---

## Details of the explicit exchange objects of the T\_COM\_MB type IODDT

### At a Glance

This part presents the explicit exchange objects of the T\_COM\_MB type IODDT which apply to Modbus communication. It includes the word type objects whose bits have a specific meaning. These objects are described in detail below.

Example of variable declaration: **IODDT\_VAR1** of type T\_COM\_MB

### Observations

- In general, the meaning of the bits is given for bit status 1. In specific cases, each bit status is explained.
- Not all the bits are used.

### Explicit exchange operation indicators: EXCH\_STS

The table below shows the meaning of channel exchange control bits from channel EXCH\_STS (%MWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress.	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Current parameter exchange in progress.	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjustment parameter exchange in progress.	%MWr.m.c.0.2

### Explicit exchange report: EXCH\_RPT

The table below shows the meaning of report bits EXCH\_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Reading error for channel status words.	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during command parameter exchange.	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during adjustment parameter exchange.	%MWr.m.c.1.2

**Standard channel errors, CH\_FLT**

The table below shows the meanings of the bits of the CH\_FLT (%MWr.m.c.2) status word. Reading can be done via a **READ\_STS (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
NO_DEVICE	BOOL	R	No device is working on the channel.	%MWr.m.c.2.0
1_DEVICE_FLT	BOOL	R	A device on the channel is faulty.	%MWr.m.c.2.1
BLK	BOOL	R	Terminal block fault (not connected).	%MWr.m.c.2.2
TO_ERR	BOOL	R	Time out error (defective wiring).	%MWr.m.c.2.3
INTERNAL_FLT	BOOL	R	Internal error or channel self-testing.	%MWr.m.c.2.4
CONF_FLT	BOOL	R	Different hardware and software configurations.	%MWr.m.c.2.5
COM_FLT	BOOL	R	Problem communicating with the PLC.	%MWr.m.c.2.6
APPLI_FLT	BOOL	R	Application error (adjustment or configuration error).	%MWr.m.c.2.7

**Specific channel status, %MWr.m.c.3**

The table below introduces the meanings of the PROTOCOL (%MWr.m.c.3) channel status word. Reading can be done via a **READ\_STS (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
PROTOCOL	INT	R	Byte 0 = 16#06 for Modbus master function.	%MWr.m.c.3
PROTOCOL	INT	R	Byte 0 = 16#07 for Modbus slave function.	%MWr.m.c.3

**Command**

The table below shows the meaning of the bits of the CONTROL word (%MWr.m.c.15). The command is made by a **WRITE\_CMD**, e.g.: **WRITE\_CMD (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
-	BOOL	R/W	Reset counter.	%MWr.m.c.15.0
DTR_ON	BOOL	R/W	DTR signal (Data Terminal Ready) ON.	%MWr.m.c.15.8
DTR_OFF	BOOL	R/W	DTR signal (Data Terminal Ready) OFF.	%MWr.m.c.15.9
MB_TO_CHAR	BOOL	R/W	Modbus change to character mode (modem).	%MWr.m.c.15.14
CHAR_TO_MB	BOOL	R/W	Character mode (modem) change to Modbus.	%MWr.m.c.15.15

# Details concerning explicit exchange language objects for a Modbus function

## At a Glance

The following tables present the language objects for communication in master and slave Modbus mode. These objects are not integrated in the IODDTs.

## List of explicit exchange objects for Master mode

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%MWr.m.c.4	INT	R	Number of responses received without CRC error.
%MWr.m.c.5	INT	R	Number of responses received with CRC error.
%MWr.m.c.6	INT	R	Number of responses received with an exception code.
%MWr.m.c.7	INT	R	Number of master messages sent without response.
%MWr.m.c.8	INT	R	Number of transmissions broadcast.
%MWr.m.c.9	INT	R	Number of receipts with NACK.
%MWr.m.c.10	INT	R	Number of master messages repeated.
%MWr.m.c.11	INT	R	Number of character errors.

## List of explicit exchange objects for slave mode

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%MWr.m.c.7	INT	R	Number of messages for the CPU.
%MWr.m.c.8	INT	R	Number of receipts broadcast.
%MWr.m.c.10	INT	R	Number of messages received during Slave busy or LOM.

## Details of language objects associated with configuration Modbus mode

---

### At a Glance

The following tables present all configuration language objects for communication Modbus mode. These objects are not integrated in the IODDTs, and may be displayed by the application program.

---

### List of explicit exchange objects for Master mode

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KWr.m.c.0	INT	R	Byte 0 = 16#06 for Modbus master function.
%KWr.m.c.1	INT	R	Byte 0 = speed <ul style="list-style-type: none"><li>128 = 300 bits/s, 129 = 600 bits/s TSX SCP 111 only.</li><li>00 = 1200 bits/s,..., 04 = 19200 bits/s,</li></ul> Byte 1 = format <ul style="list-style-type: none"><li>bit 8: number of bits (1 = 8 bits, 0 = 7 bits),</li><li>bit 9 = 1: parity management (1 = with, 0 = without).</li><li>bit 10: Parity Type (1 = odd, 0 = even),</li><li>bit 11: stop bit (1 = 1 bit, 0 = 2 bits).</li></ul>
%KWr.m.c.2	INT	R	Value in ms from 2 ms to 10000 ms.
%KWr.m.c.3	INT	R	Wait Time in ms from 10 ms to 10000 ms
%KWr.m.c.4	INT	R	Byte 0 = number of retries (default being 3). Byte 1 = Signal Management <ul style="list-style-type: none"><li>bit 8: 1 if PSR signal management (TSX SCP 112),</li><li>bit 10 = 1 if DCD Data Carrier management (TSX SCP 111).</li></ul>
%KWr.m.c.5	INT	R	Delay time in hundreds of ms, only for TSX SCP 111 (default value 0 ms).

### List of explicit exchange objects for slave mode

The language objects for the Modbus slave function are identical to those of the Modbus master function. The only difference is for the following object:

Address	Type	Access	Meaning
%KWr.m.c.3	INT	R	Byte 0 = slave number value (0 to 98).

---

---

# 12.4                      Language objects and IODDTs associated with Character Mode communication

---

## At a Glance

---

**Subject of this Section**                      This section presents the language objects and IODDTs associated with Character Mode communication.

---

**What's in this Section?**                      This section contains the following topics:

Topic	Page
Details of the implicit exchange objects of the T_COM_CHAR type IODDT for PCMCIA cards	328
Details of the explicit exchange objects of the T_COM_CHAR type IODDT for PCMCIA	329
Details concerning explicit exchange language objects for communication in Character Mode	331
Details of language objects associated with configuration in Character Mode	332

---

## Details of the implicit exchange objects of the T\_COM\_CHAR type IODDT for PCMCIA cards

---

### At a Glance

The tables below present the implicit exchange objects of the IODDT of the T\_COM\_CHAR type which apply to Character Mode communication with PCMCIA cards.

---

### Error bit

The following table presents the meaning of the error bit CH\_ERROR (%lr.m.c.ERR).

Standard symbol	Type	Access	Meaning	Address
CH_ERROR	EBOOL	R	Communication channel error bit.	%lr.m.c.ERR

---

### Signal objects on input

The table below shows the meaning of the bits of the INPUT\_SIGNALS word (%lWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
DCD	BOOL	R	Data Carrier Detection signal.	%lWr.m.c.0.0
RI	BOOL	R	Ring indicator signal.	%lWr.m.c.0.1
CTS	BOOL	R	Ready to send signal.	%lWr.m.c.0.2
DSR	BOOL	R	Data ready signal.	%lWr.m.c.0.3

---

### Signal objects on output

The following table presents the meaning of the bit of the STOP\_EXCH word (%QWr.m.c.0.0).

Standard symbol	Type	Access	Meaning	Address
STOP_EXCH	BOOL	R	rising edge at 1: all exchanges in progress are stopped.	%QWr.m.c.0.0

---



## Details of the explicit exchange objects of the T\_COM\_CHAR type IODDT for PCMCIA

### At a Glance

This part presents the explicit exchange objects of the IODDT of the T\_COM\_CHAR type which apply to Character Mode communication with PCMCIA cards. It includes the word type objects whose bits have a specific meaning. These objects are described in detail below.

Sample Variable Declaration: **IODDT\_VAR1** of type T\_COM\_CHAR

### Observations

- In general, the meaning of the bits is given for bit status 1. In specific cases an explanation is given for each status of the bit.
- Not all bits are used.

### Explicit exchange execution flag: EXCH\_STS

The following table presents the meanings of the exchange control bits of the channel EXCH\_STS (%MWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress.	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Current parameter exchange in progress.	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjustment parameter exchange in progress.	%MWr.m.c.0.2

### Explicit exchange report: EXCH\_RPT

The table below presents the meaning of the exchange report bits EXCH\_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Reading error for channel status words.	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during command parameter exchange.	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during adjustment parameter exchange.	%MWr.m.c.1.2

**Standard  
channel faults,  
CH\_FLT**

The following table presents the meanings of the bits of the CH\_FLT status word (%MWr.m.c.2). The reading is performed by a **READ\_STS (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
NO_DEVICE	BOOL	R	No device is working on the channel.	%MWr.m.c.2.0
1_DEVICE_FLT	BOOL	R	A device on the channel is faulty.	%MWr.m.c.2.1
BLK	BOOL	R	Terminal block fault (not connected).	%MWr.m.c.2.2
TO_ERR	BOOL	R	Time out error (defective wiring).	%MWr.m.c.2.3
INTERNAL_FLT	BOOL	R	Internal error or channel self-testing.	%MWr.m.c.2.4
CONF_FLT	BOOL	R	Different hardware and software configurations.	%MWr.m.c.2.5
COM_FLT	BOOL	R	Problem communicating with the PLC.	%MWr.m.c.2.6
APPLI_FLT	BOOL	R	Application error (adjustment or configuration error).	%MWr.m.c.2.7

---

**Specific channel  
status,  
%MWr.m.c.3**

The table below shows the meanings of the PROTOCOL (%MWr.m.c.3) channel status word. Reading can be done via a **READ\_STS (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
PROTOCOL	INT	R	Byte 0 = 16#03 for Character Mode function.	%MWr.m.c.3

---

**Command**

The table below shows the meaning of the bits of the CONTROL word (%MWr.m.c.15). The command is made by a **WRITE\_CMD**, e.g.: **WRITE\_CMD (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
-	BOOL	R/W	Reset counter.	%MWr.m.c.15.0
DTR_ON	BOOL	R/W	DTR signal (Data Terminal Ready) ON.	%MWr.m.c.15.8
DTR_OFF	BOOL	R/W	DTR signal (Data Terminal Ready) OFF.	%MWr.m.c.15.9

---

# Details concerning explicit exchange language objects for communication in Character Mode

**At a Glance** The following tables present all configuration language objects for communication in Character Mode. These objects are not integrated in the IODDTs.

**List of explicit exchange objects**

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%MWr.m.c.4	INT	R	Error in transmitted characters.
%MWr.m.c.5	INT	R	Error in received characters.

## Details of language objects associated with configuration in Character Mode

---

### At a Glance

The following tables present all configuration language objects for communication in Character Mode. These objects are not integrated in the IODDTs, and may be displayed by the application program.

---

### List of explicit exchange objects for PCMCIA cards

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KWr.m.c.0	INT	R	Byte 0 = 16#03 for Character Mode function.
%KWr.m.c.1	INT	R	Byte 0 = speed <ul style="list-style-type: none"><li>● 00 = 1200 bits/s,..., 04 = 19200 bits/s,</li><li>● bit 8: number of bits (1 = 8 bits, 0 = 7 bits),</li><li>● bit 9 = 1: parity management,</li><li>● bit 10: Parity Type (1 = odd, 0 = even),</li><li>● bit 11: stop bit (1 = 1 bit, 0 = 2 bits).</li></ul>
%KWr.m.c.2	INT	R	Value in ms (0 = not active).
%KWr.m.c.3	INT	R	<ul style="list-style-type: none"><li>● bit 0 = 1: echo on reception,</li><li>● bit 1 = 1: echo restart on first character 1,</li><li>● bit 2 = 1: automatic transmission of L,</li><li>● bit 3 = 1: back-space management,</li><li>● bit 4 = 1: Xon/Xoff flow control active,</li><li>● bit 5 = 1: RTS/DCD flow control active,</li><li>● bit 6 = 1: beep management,</li><li>● bit 7 = 1: RTS/CTS flow control active,</li></ul>
%KWr.m.c.4	INT	R	<ul style="list-style-type: none"><li>● bit 0...7: reserved,</li><li>● bit 8 = 1 if PSR signal management (TSX SCP 112),</li><li>● bit 9 = 1 if Full Duplex management,</li><li>● bit 10 = 1 if DCD Data Carrier management (TSX SCP 111)</li></ul>
%KWr.m.c.5	INT	R	Delay time in hundreds of ms (default value 0 ms)
%KWr.m.c.6	INT	R	<ul style="list-style-type: none"><li>● bit 0 = 1 end character 1 enabled,</li><li>● bit 1 = 1 end character 1 included,</li></ul> Byte 1: value of the end character in decimal.
%KWr.m.c.7	INT	R	<ul style="list-style-type: none"><li>● bit 0 = 1 end character 2 enabled,</li><li>● bit 1 = 1 end character 2 included,</li></ul> Byte 1: value of the end character in decimal.

---

**List of explicit  
exchange  
objects for  
Terminal Port**

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KW0.0.0.0 or %KW0.1.0.0 (1)	INT	R	Byte 0 = 16#03 for Character Mode function.
%KW0.0.0.1 or %KW0.1.0.1 (1)	INT	R	Byte 0 = speed <ul style="list-style-type: none"> <li>● 00 = 1200 bits/s,..., 04 = 19200 bits/s,</li> <li>● bit 8: number of bits (1 = 8 bits, 0 = 7 bits),</li> <li>● bit 9 = 1: parity management,</li> <li>● bit 10: Parity Type (1 = odd, 0 = even),</li> <li>● bit 11: stop bit (1 = 1 bit, 0 = 2 bits),</li> <li>● bit 12 = 1: echo on reception,</li> <li>● bit 13 = 1: beep management,</li> <li>● bit 14 = 1: back-space management.</li> </ul>
Legend:			
(1): in the event that the power supply takes up 2 slots, the processor is placed in slot 1 on the rack.			

## 12.5 Language objects and IODDTs associated with Uni-Telway communication

---

### At a Glance

---

#### Subject of this Section

This section presents the language objects and IODDTs associated with Uni-Telway communication.

---

#### What's in this Section?

This section contains the following topics:

Topic	Page
Details of the implicit exchange objects of the T_COM_UTW_M type IODDT for PCMCIA cards	335
Details of the explicit exchange objects of the T_COM_UTW_M type IODDT for PCMCIA cards	337
Details concerning explicit exchange language objects for a master Uni-Telway function	340
Details of language objects associated with configuration in master Uni-Telway mode	341
Details of the implicit exchange objects of the T_COM_UTW_S type IODDT for PCMCIA cards	343
Details of the explicit exchange objects of the T_COM_UTW_S type IODDT for PCMCIA cards	344
Details of language objects associated with configuration in slave Uni-Telway mode	346

---

## Details of the implicit exchange objects of the T\_COM\_UTW\_M type IODDT for PCMCIA cards

### At a Glance

The following tables present the implicit exchange objects of the IODDT of the T\_COM\_UTW\_M type which apply to a Uni-Telway master communication with PCMCIA cards.

### Error bit

The following table presents the meaning of the error bit CH\_ERROR (%Ir.m.c.ERR).

Standard symbol	Type	Access	Meaning	Address
CH_ERROR	EBOOL	R	Communication channel error bit.	%Ir.m.c.ERR

### Signal objects on input

The table below shows the meaning of the bits of the INPUT\_SIGNALS word (%IW.r.m.c.0).

Standard symbol	Type	Access	Meaning	Address
DCD	BOOL	R	Data Carrier Detection signal.	%IW.r.m.c.0.0
RI	BOOL	R	Ring indicator signal.	%IW.r.m.c.0.1
CTS	BOOL	R	Ready to send signal.	%IW.r.m.c.0.2
DSR	BOOL	R	Data ready signal.	%IW.r.m.c.0.3

### General slave status object

The following table presents the meaning of the bit of the SLAVES\_ERR word (%IW.r.m.c.1).

Standard symbol	Type	Access	Meaning	Address
SLAVES_ERR	EBOOL	R	=1 if at least one slave does not respond.	%IW.r.m.c.1.0

**Status object for event data**      The following table presents the meaning of the bits of the EVT\_STS\_0\_15 word (%IWrr.m.c.2). For slaves 0 to 15

Standard symbol	Type	Access	Meaning	Address
EVT_STS_0	EBOOL	R	=1 slave 0 has transmitted data.	%IWrr.m.c.2.0
EVT_STS_1	EBOOL	R	=1 slave 1 has transmitted data.	%IWrr.m.c.2.1
EVT_STS_2	EBOOL	R	=1 slave 2 has transmitted data.	%IWrr.m.c.2.2
EVT_STS_3	EBOOL	R	=1 slave 3 has transmitted data.	%IWrr.m.c.2.3
EVT_STS_n	EBOOL	R	=1 slave n has transmitted data.	%IWrr.m.c.2.n
EVT_STS_15	EBOOL	R	=1 slave 15 has transmitted data.	%IWrr.m.c.2.15

---

**Status object for event data**      The following table presents the meaning of the bits of the EVT\_STS\_16\_31 word (%IWrr.m.c.2). For slaves 16 to 31

Standard symbol	Type	Access	Meaning	Address
EVT_STS_16	EBOOL	R	=1 slave 16 has transmitted data.	%IWrr.m.c.3.0
EVT_STS_17	EBOOL	R	=1 slave 17 has transmitted data.	%IWrr.m.c.3.1
EVT_STS_18	EBOOL	R	=1 slave 18 has transmitted data.	%IWrr.m.c.3.2
EVT_STS_19	EBOOL	R	=1 slave 19 has transmitted data.	%IWrr.m.c.3.3
EVT_STS_n	EBOOL	R	=1 slave n has transmitted data.	%IWrr.m.c.3.i
EVT_STS_31	EBOOL	R	=1 slave 31 has transmitted data.	%IWrr.m.c.3.15

---



## Details of the explicit exchange objects of the T\_COM\_UTW\_M type IODDT for PCMCIA cards

### At a Glance

This part presents the explicit exchange objects of the IODDT of the T\_COM\_UTW\_M type which apply to Uni-Telway master communication with PCMCIA cards. It includes the word type objects whose bits have a specific meaning. These objects are described in detail below.

Sample Variable Declaration: **IODDT\_VAR1** of type T\_COM\_UTW\_M

### Observations

- In general, the meaning of the bits is given for bit status 1. In specific cases an explanation is given for each status of the bit.
- Not all bits are used.

### Execution flags of an explicit exchange: EXCH\_STS

The table below shows the meaning of channel exchange control bits from channel EXCH\_STS (%MWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress.	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Current parameter exchange in progress.	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjustment parameter exchange in progress.	%MWr.m.c.0.2

### Explicit exchange report: EXCH\_RPT

The table below presents the meaning of the exchange report bits EXCH\_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Reading error for channel status words.	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during command parameter exchange.	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during adjustment parameter exchange.	%MWr.m.c.1.2

**Standard  
channel faults,  
CH\_FLT**

The table below shows the meaning of the bits of the status word `CH_FLT` (%MWr.m.c.2). Reading is performed by a **READ\_STS(ODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
NO_DEVICE	BOOL	R	No device is working on the channel.	%MWr.m.c.2.0
1_DEVICE_FLT	BOOL	R	A device on the channel is faulty.	%MWr.m.c.2.1
BLK	BOOL	R	Terminal block fault (not connected).	%MWr.m.c.2.2
TO_ERR	BOOL	R	Time out error (defective wiring).	%MWr.m.c.2.3
INTERNAL_FLT	BOOL	R	Internal error or channel self-testing.	%MWr.m.c.2.4
CONF_FLT	BOOL	R	Different hardware and software configurations.	%MWr.m.c.2.5
COM_FLT	BOOL	R	Problem communicating with the PLC.	%MWr.m.c.2.6
APPLI_FLT	BOOL	R	Application error (adjustment or configuration error).	%MWr.m.c.2.7

**Specific channel  
status,  
%MWr.m.c.3**

The table below shows the meanings of the `PROTOCOL` (%MWr.m.c.3) channel status word. Reading can be done via a **READ\_STS (ODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
PROTOCOL	INT	R	Byte 0 = 16#00 for the master Uni-Telway function.	%MWr.m.c.3

**Status of slaves**

The table below presents the meanings of the slave status words. Reading can be done via a **READ\_STS (ODDT\_VAR1)**. For details on the bits of these status words, follow the principle described in the table (See *Status of slaves*, p. 339).

Standard symbol	Type	Access	Meaning	Address
SLAVE_STS_0_15	INT	R	Status of slaves 0 to 15.	%MWr.m.c.8
SLAVE_STS_16_31	INT	R	Status of slaves 16 to 31.	%MWr.m.c.9
SLAVE_STS_32_47	INT	R	Status of slaves 32 to 47.	%MWr.m.c.10
SLAVE_STS_48_63	INT	R	Status of slaves 48 to 63.	%MWr.m.c.11
SLAVE_STS_64_79	INT	R	Status of slaves 64 to 79.	%MWr.m.c.12
SLAVE_STS_80_95	INT	R	Status of slaves 80 to 95.	%MWr.m.c.13
SLAVE_STS_96_111	INT	R	Status of slaves 96 to 111.	%MWr.m.c.14

**Status of slaves** The table below presents the meanings of the status word bits for slaves SLAVE\_STS\_0\_15 (%MWr.m.c.8). Reading can be done via a **READ\_STS** (IODDT\_VAR1).

Standard symbol	Type	Access	Meaning	Address
SLAVE_STS_0	BOOL	R	=1, slave 0 is responding.	%MWr.m.c.8.0
SLAVE_STS_1	BOOL	R	=1, slave 1 is responding.	%MWr.m.c.8.1
SLAVE_STS_2	BOOL	R	=1, slave 2 is responding.	%MWr.m.c.8.2
SLAVE_STS_3	BOOL	R	=1, slave 3 is responding.	%MWr.m.c.8.3
SLAVE_STS_n	BOOL	R	=1, slave n is responding.	%MWr.m.c.8.n
SLAVE_STS_15	BOOL	R	=1, slave 15 is responding.	%MWr.m.c.8.15

**Status of slaves** The table below presents the meanings of the status word bits for slaves SLAVE\_STS\_16\_31 (%MWr.m.c.9). Reading can be done via a **READ\_STS** (IODDT\_VAR1).

Standard symbol	Type	Access	Meaning	Address
SLAVE_STS_16	BOOL	R	=1, slave 16 is responding.	%MWr.m.c.9.0
SLAVE_STS_17	BOOL	R	=1, slave 17 is responding.	%MWr.m.c.9.1
SLAVE_STS_18	BOOL	R	=1, slave 18 is responding.	%MWr.m.c.9.2
SLAVE_STS_19	BOOL	R	=1, slave 19 is responding.	%MWr.m.c.9.3
SLAVE_STS_n	BOOL	R	=1, slave n is responding.	%MWr.m.c.9.i
SLAVE_STS_31	BOOL	R	=1, slave 31 is responding.	%MWr.m.c.9.15

The above principle also applies for slaves 32 to 111 with the corresponding status (See *Status of slaves, p. 338*) words.

**Command** The table below shows the meaning of the bits of the CONTROL word (%MWr.m.c.15). The command is made by a WRITE\_CMD, e.g.: **WRITE\_CMD** (IODDT\_VAR1).

Standard symbol	Type	Access	Meaning	Address
-	BOOL	R/W	Reset counter.	%MWr.m.c.15.0
DTR_ON	BOOL	R/W	DTR signal (Data Terminal Ready) ON.	%MWr.m.c.15.8
DTR_OFF	BOOL	R/W	DTR signal (Data Terminal Ready) OFF.	%MWr.m.c.15.9
UTW_TO_CHAR	BOOL	R/W	Uni-Telway change to character mode (modem).	%MWr.m.c.15.14
CHAR_TO_UTW	BOOL	R/W	Character Mode change to Uni-Telway (modem).	%MWr.m.c.15.15

## Details concerning explicit exchange language objects for a master Uni-Telway function

---

### At a Glance

The following tables present the language objects for communication in master Uni-Telway mode. These objects are not integrated in the IODDTs.

---

### List of objects for PCMCIA cards

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%MW <sub>r</sub> .m.c.4	INT	R	Number of messages sent and not acknowledged.
%MW <sub>r</sub> .m.c.5	INT	R	Number of messages sent and refused.
%MW <sub>r</sub> .m.c.6	INT	R	Number of messages received and not acknowledged.
%MW <sub>r</sub> .m.c.7	INT	R	Number of messages received and refused.

---

### List of objects for Terminal Port

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%MW <sub>0.0.0.4</sub>	INT	R	Status of slaves. Each Xi word bit is dedicated to each slave. If Xi = 1, the slave from address i responds.

---

## Details of language objects associated with configuration in master Uni-Telway mode

### At a Glance

The following tables present all configuration language objects for communication in master Uni-Telway. These objects are not integrated in the IODDTs, and may be displayed by the application program.

### Internal constants for PCMCIA cards

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KWr.m.c.0	INT	R	Byte 0 = 16#06 for the master Uni-Telway function.
%KWr.m.c.1	INT	R	Byte 0 = speed <ul style="list-style-type: none"> <li>16#50 = 300 bits/s, 16#51 = 600 bits/s TSX SCP 111 only,</li> <li>16#00 = 1200 bits/s,...,16# 04 = 19200 bits/s,</li> </ul> Byte 1 = format <ul style="list-style-type: none"> <li>bit 8: number of bits (1 = 8 bits, 0 = 7 bits),</li> <li>bit 9 = 1: parity management,</li> <li>bit 10: Parity Type (1 = odd, 0 = even),</li> <li>bit 11: stop bit (1 = 1 bit, 0 = 2 bits).</li> </ul>
%KWr.m.c.2	INT	R	Wait Time in ms from 5 ms to 10000 ms
%KWr.m.c.3	INT	R	Number of slaves, value between 1 and 98.
%KWr.m.c.4	INT	R	Byte 0 = values 0, 4 or 8 bytes of event data, Byte 1 = Signal Management, <ul style="list-style-type: none"> <li>bit 8: 1 if PSR signal management (TSX SCP 112),</li> <li>bit 10 = 1 if DCD Data Carrier management (TSX SCP 111).</li> </ul>
%KWr.m.c.5	INT	R	Delay time in hundreds of ms (default value 0 ms)

**Internal  
constants for  
Terminal Port**

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KW0.0.0.0 or %KW0.1.0.0 (1)	INT	R	Byte 0 = 16#06 for the master Uni-Telway function. Byte 1 = speed ● 16#00 = 1200 bits/s,...,16# 04 = 19200 bits/s.
%KW0.0.0.1 or %KW0.1.0.1 (1)	INT	R	Wait Time in ms from 5 ms to 10000 ms
%KW0.0.0.2 or %KW0.1.0.2 (1)	INT	R	Number of slaves, value between 1 and 98.
Legend:			
(1): in the event that the power supply takes up 2 slots, the processor is placed in slot 1 on the rack.			

---

## Details of the implicit exchange objects of the T\_COM\_UTW\_S type IODDT for PCMCIA cards

**PCMCIA card objects** The following tables present the implicit exchange objects of the T\_COM\_UTW\_S type IODDT which apply to Uni-Telway slave communication with PCMCIA cards.

**Error bit** The following table presents the meaning of the error bit CH\_ERROR (%Ir.m.c.ERR).

Standard symbol	Type	Access	Meaning	Address
CH_ERROR	EBOOL	R	Communication channel error bit.	%Ir.m.c.ERR

**Signal objects on input** The table below shows the meaning of the bits of the INPUT\_SIGNALS word (%IW.r.m.c.0).

Standard symbol	Type	Access	Meaning	Address
DCD	BOOL	R	Data Carrier Detection signal.	%IW.r.m.c.0.0
RI	BOOL	R	Ring indicator signal.	%IW.r.m.c.0.1
CTS	BOOL	R	Ready to send signal.	%IW.r.m.c.0.2
DSR	BOOL	R	Data ready signal.	%IW.r.m.c.0.3

**Address status objects** The following table presents the meaning of the bits of the STS\_ADDR word (%IW.r.m.c.1).

Standard symbol	Type	Access	Meaning	Address
AD0_FLT	EBOOL	R	=1 no polling of the master on the slave with an address (AD0).	%IW.r.m.c.1.0
AD1_FLT	EBOOL	R	=1 no polling of the master on the slave with an address (AD1).	%IW.r.m.c.1.1
AD2_FLT	EBOOL	R	=1 no polling of the master on the slave with an address (AD2).	%IW.r.m.c.1.2

## Details of the explicit exchange objects of the T\_COM\_UTW\_S type IODDT for PCMCIA cards

---

### At a Glance

This part presents the explicit exchange objects of the IODDT of the T\_COM\_UTW\_M type which apply to Uni-Telway slave communication with PCMCIA cards. It includes the word type objects whose bits have a specific meaning. These objects are described in detail below.

Sample Variable Declaration: **IODDT\_VAR1** of type T\_COM\_UTW\_S

---

### Observations

- In general, the meaning of the bits is given for bit status 1. In specific cases an explanation is given for each status of the bit.
  - Not all bits are used.
- 

### Execution flags of an explicit exchange: EXCH\_STS

The table below shows the meaning of channel exchange control bits from channel EXCH\_STS (%MWr.m.c.0).

Standard symbol	Type	Access	Meaning	Address
STS_IN_PROGR	BOOL	R	Reading of channel status words in progress.	%MWr.m.c.0.0
CMD_IN_PROGR	BOOL	R	Current parameter exchange in progress.	%MWr.m.c.0.1
ADJ_IN_PROGR	BOOL	R	Adjustment parameter exchange in progress.	%MWr.m.c.0.2

---

### Explicit exchange report: EXCH\_RPT

The table below presents the meaning of the exchange report bits EXCH\_RPT (%MWr.m.c.1).

Standard symbol	Type	Access	Meaning	Address
STS_ERR	BOOL	R	Reading error for channel status words.	%MWr.m.c.1.0
CMD_ERR	BOOL	R	Error during command parameter exchange.	%MWr.m.c.1.1
ADJ_ERR	BOOL	R	Error during adjustment parameter exchange.	%MWr.m.c.1.2

---



### Standard channel faults, CH\_FLT

The table below shows the meaning of the bits of the status word `CH_FLT` (%MWr.m.c.2). Reading is carried out by a **READ\_STS (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
NO_DEVICE	BOOL	R	No device is working on the channel.	%MWr.m.c.2.0
1_DEVICE_FLT	BOOL	R	A device on the channel is faulty.	%MWr.m.c.2.1
BLK	BOOL	R	Terminal block fault (not connected).	%MWr.m.c.2.2
TO_ERR	BOOL	R	Time out error (defective wiring).	%MWr.m.c.2.3
INTERNAL_FLT	BOOL	R	Internal error or channel self-testing.	%MWr.m.c.2.4
CONF_FLT	BOOL	R	Different hardware and software configurations.	%MWr.m.c.2.5
COM_FLT	BOOL	R	Problem communicating with the PLC.	%MWr.m.c.2.6
APPLI_FLT	BOOL	R	Application error (adjustment or configuration error).	%MWr.m.c.2.7

### Specific channel status, %MWr.m.c.3

The table below shows the meanings of the `PROTOCOL` (%MWr.m.c.3) channel status word. Reading can be done via a **READ\_STS (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
PROTOCOL	INT	R	Byte 0 = 16#01 for the slave Uni-Telway function.	%MWr.m.c.3

### Command

The table below shows the meaning of the bits of the `CONTROL` word (%MWr.m.c.15). The command is made by a **WRITE\_CMD**, e.g.: **WRITE\_CMD (IODDT\_VAR1)**.

Standard symbol	Type	Access	Meaning	Address
DTR_ON	BOOL	R/W	DTR signal (Data Terminal Ready) ON.	%MWr.m.c.15.8
DTR_OFF	BOOL	R/W	DTR signal (Data Terminal Ready) OFF.	%MWr.m.c.15.9
UTW_TO_CHAR	BOOL	R/W	Change from Uni-Telway to character mode (modem).	%MWr.m.c.15.14
CHAR_TO_UTW	BOOL	R/W	Change from Character Mode (modem) to Uni-Telway.	%MWr.m.c.15.15

## Details of language objects associated with configuration in slave Uni-Telway mode

### At a Glance

The following tables present all configuration language objects for communication in slave Uni-Telway. These objects are not integrated in the IODDTs, and may be displayed by the application program.

---

### Internal constants for PCMCIA cards

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KW <sub>r</sub> .m.c.0	INT	R	Byte 0 = 16#06 for the slave Uni-Telway function.
%KW <sub>r</sub> .m.c.3	INT	R	Byte 0: value of slave address Ad0. Byte 1 = number of consecutive addresses from 1 to 3.
%KW <sub>r</sub> .m.c.4	INT	R	Byte 0 = reserved, Byte 1 = Signal Management, ● bit 8: 1 if PSR signal management (TSX SCP 112).

---

### Internal constants for Terminal Port

The table below shows the explicit exchange objects.

Address	Type	Access	Meaning
%KW <sub>0</sub> .0.0.0	INT	R	Byte 0 = 0 for the slave Uni-Telway function. Byte 1 = speed ● 16#00 = 1200 bits/s,...,16# 04 = 19200 bits/s.
%KW <sub>0</sub> .0.0.1	INT	R	Wait Time in ms from 5 ms to 10000 ms
%KW <sub>0</sub> .0.0.2	INT	R	Byte 0: value of slave address Ad0. Byte 1 = number of consecutive addresses from 1 to 3.

---

# 12.6 Language Objects Associated with the Specific Protocol

## Details of the Language Objects Associated with Specific Protocols

**At a Glance** The following tables show the language objects associated with the **FCS SCP 111/114** cards. These objects are not integrated in the IODDTs. Their precise meaning is given in the PCMCIA card documentation. The `T_COM_STS_GEN` (See *General language objects and IODDTs for all communication protocols*, p. 317) IODDT can also be applied to specific protocols.

**List of Objects with Implicit Exchanges** The table below shows the implicit exchange objects.

Number	Type	Access	Meaning
%lWr.m.c.0 to %lWr.m.c.7	INT	R	Input signals.
%QWr.m.c.0 to %QWr.m.c.7	INT	R	Output signals.

**List of Objects with Explicit Exchanges** The table below shows the explicit exchange objects.

Number	Type	Access	Meaning
%MWr.m.c.2	INT	R	Channel standard status.
%MWr.m.c.3 to %MWr.m.c.15	INT	R	Specific channel or counter status.
%MWr.m.c.16	INT	R	Command

**List of Configuration Objects** The table below shows the configuration objects

Number	Type	Access	Meaning
%KWr.m.c.0 to %KWr.m.c.15	INT	R	Parameters.

## 12.7 The IODDT type T\_GEN\_MOD applicable to all modules

---

### Details of the Language Objects of the IODDT of type T\_GEN\_MOD

---

**At a Glance** All the modules of Premium PLCs have an associated IODDT of type T\_GEN\_MOD.

---

**Notes**

- The meaning of a bit is generally given for the status of the bit when set to 1. In specific cases an explanation is given for each status of the bit.
- Not all bits are used.

---

**List of objects** The table below shows the objects of the IODDT


Standard symbol	Type	Access	Meaning	Number
MOD_ERROR	BOOL	R	Module error bit	%I.r.m.MOD.ERR
EXCH_STS	INT	R	Module exchange control word.	%MWr.m.MOD.0
STS_IN_PROGR	BOOL	R	Reading of status words of the module in progress.	%MWr.m.MOD.0.0
EXCH_RPT	INT	R	Exchange report word.	%MWr.m.MOD.1
STS_ERR	BOOL	R	Fault when reading module status words.	%MWr.m.MOD.1.0
MOD_FLT	INT	R	Internal error word of the module.	%MWr.m.MOD.2
MOD_FAIL	BOOL	R	Internal error, module failure.	%MWr.m.MOD.2.0
CH_FLT	BOOL	R	Faulty channel(s).	%MWr.m.MOD.2.1
BLK	BOOL	R	Terminal block fault.	%MWr.m.MOD.2.2
CONF_FLT	BOOL	R	Hardware or software configuration fault.	%MWr.m.MOD.2.5
NO_MOD	BOOL	R	Module missing or off.	%MWr.m.MOD.2.6

---

---

## Index

---



### A

- Accessible Functions
  - Character mode, 231
  - Modbus, 190
- Accessible functions
  - Uni-Telway, 262
- Address
  - Uni-Telway, 254

### B

- Built-in Channel Specifications
  - TSX SCY 11601, 80
  - TSX SCY 21601, 80

### C

- Characteristics
  - Terminal port, 52
- Communication
  - Character string, 31
  - Man-machine interface console, 28
  - Uni-Telway master/slave, 30
  - With terminal, 27
- Communication channel test
  - Modbus, 212
  - Uni-Telway, 292
- Communication function
  - Modbus, 197, 198
- Compatibilities
  - Character Mode, 220

- Compatibility
  - Uni-Telway, 250
- Configuration
  - Character Mode, 224
  - Modbus, 183
  - Specific protocols, 299
  - Uni-Telway, 255
- Configuration Access
  - Character mode, 225, 226, 227
  - Modbus, 184, 186
  - Specific protocols, 300
  - Uni-Telway, 256, 257, 258
- Configuration objects, 346
  - Character Mode, 332
  - Modbus, 326
  - Uni-Telway, 341
- Configuration Parameters
  - Modbus, 191, 193
  - Uni-Telway, 263, 265
- Configuration parameters
  - Character mode, 232, 234, 236, 237
- Configuration Screen
  - Character mode, 229
  - Modbus, 188
  - Uni-Telway, 260
- Configuration screen
  - Specific protocols, 302

**Connection**

- Character Mode, 99
- TSX SCA 50, 98
- TSX SCP 111, 113
- TSX SCP 112, 116
- TSX SCP 114, 128

**Connection devices**

- TSX SCP 111, 137
- TSX SCP 112, 137
- TSX SCP 114, 137

**Connection precautions**

- PCMCIA cards, 106

**Connection to the field bus**

- TSX SCY 11601, 94
- TSX SCY 21601, 94

**Connection to the TSX SCA 64 unit**

- 2-wire mode, 142

**Connection to TSX SCA 64 unit**

- 4-wire mode, 143

**Consumption**

- TSX SCP 111, 139
- TSX SCP 112, 139
- TSX SCP 114, 139
- TSX SCY 11601, 100
- TSX SCY 21601, 100

**D****Debug parameters**

- Modbus, 211

**Debug screen**

- Specific protocols, 304

**Debugging Parameters**

- Modbus, 210

**Debugging parameters**

- Character mode, 244
- Uni-Telway, 291

**Debugging screen**

- Character mode, 242
- Modbus, 208
- Uni-Telway, 289

**Description**

- PCMCIA cards, 104
- TSX SCY 11601, 77
- TSX SCY 21601, 77

**F**

FCS SCP 111, 295

FCS SCP 114, 295

Flow Control, 218

**H****Host Channel Compatibility**

- TSX SCY 21601, 81

**I****Identification**

- Uni-Telway, 293

INPUT\_CHAR, 239

**Installation**

- Overview, 171
- TSX SCY 11601, 82
- TSX SCY 21601, 82

**Introduction**

- TSX SCY 11601, 75
- TSX SCY 21601, 75

**IODDT**

- Character Mode, 327
- Communication, 317
- Modbus, 321
- Module, 348
- Uni-Telway, 334

**L****Language Objects**

- Implicit Exchange, 310

**Language objects**

- Explicit exchange, 311, 319, 323, 329, 337, 344
- Implicit exchange, 318, 322, 328, 335, 343
- Management of exchanges, 313
- Specific protocols, 347

**M****Mirror**

- Uni-Telway, 293

Modbus  
  Compatibilities, 178  
  Presentation, 177

Mounting  
  PCMCIA, 109

## O

Operating Mode  
  Character Mode, 223  
  Modbus, 182  
  Uni-Telway, 253

Operating mode  
  Specific protocols, 298

Operating standards  
  TSX SCY 11601, 76  
  TSX SCY 21601, 76

Operation  
  TSX SCY 11601, 84  
  TSX SCY 21601, 84

OUT\_IN\_CHAR, 239

## P

Pair transmission configuration and polarization  
  2 wires with data pair polarization via a 5VDC external power supply, 157  
  2 wires with polarization of M+, M- pair by the master station or a slave station, 155  
  4 wires with 2-pair polarization via external power supply, 162  
  4 wires with one pair polarization by the master station, the other by a slave station, 159

PCMCIA cards, 101  
  Connections, 107  
  Visual diagnostics, 112

Performance  
  Character Mode, 221  
  Modbus, 181  
  Uni-Telway, 251

Physical description of TSX SCA 64 device, 144

Polarization  
  TSX SCY 11601, 95  
  TSX SCY 21601, 95

Presentation  
  Character Mode, 217  
  Specific Protocols, 297  
  Uni-Telway, 249

PRINT\_CHAR, 239

Programming  
  Character Mode, 239  
  Modbus, 196  
  Uni-Telway, 267

## R

Requests  
  Uni-Telway, 294

## S

Serial communication  
  Devices, 21  
  Introduction, 17

Simulator  
  Overview, 171

Specific Protocols  
  Presentation, 297

## T

T\_COM\_CHAR  
  Explicit exchange, 329  
  Implicit exchange, 328

T\_COM\_MB, 322, 323

T\_COM\_STS\_GEN, 318, 319

T\_COM\_UTW\_M  
  Explicit exchange, 337  
  Implicit exchange, 335

T\_COM\_UTW\_S  
  Explicit exchange, 344  
  Implicit exchange, 343

T\_GEN\_MOD, 348

Terminal port  
  Connector pin configuration, 54  
  on Premium and Atrium, 25

- Terminal Port Connections
  - Summary table, 48
- Terminal port connections, 33
  - Character string, 45
  - Inter-device Uni-Telway, 43
  - Inter-PLC Uni-Telway, 41
  - Man-machine interface console, 35
  - Master Uni-Telway, 39
  - Model 40 PLCs, 44
  - Modem, 37
  - Programming terminal, 34
  - Slave Uni-Telway, 40
- Testing a communication channel
  - Character mode, 246
- TSX P ACC 01, 55
  - Connecting devices, 66
  - Connecting to Premium/Atrium PLCs, 62
  - Connection between 2 PLCs, 71
  - Connector pin configuration, 64
  - Dimensions, 59
  - External appearance, 57
  - Functionalities, 56
  - Internal view, 60
  - Master Uni-Telway, 68
  - Slave Uni-Telway, 70
  - Switches, 63
  - Uni-Telway Bus connection, 61
- TSX SCA 64
  - Cable Template, 150
  - cabling principles, 150
  - Dimensions, 146
  - installation, 148
  - Line end adaptation, 164
  - Mounting / Fixing, 146
- TSX SCA 64 connection device, 141
- TSX SCY 11601, 73
- TSX SCY 21601, 73
  - Uni-Telway bus Connection, 89
- Visual diagnostics
  - TSX SCY 11601, 85
  - TSX SCY 21601, 85

## V

- Various objects
  - Character Mode, 331
  - Modbus, 325
  - Uni-Telway, 340