

# **Reference Manual**

# **Temperature Calibrator**

**JOFRA ATC-155/156/157/320/650 A/B**

© Copyright 2002 AMETEK DENMARK A/S

# About this manual....

---

- **The structure of the manual**

This reference manual is aimed at users who are familiar with Ametek calibrators, as well as those who are not. The manual is divided into 9 chapters. These describe how to set up, operate, service and maintain the calibrator. The technical specifications are described and accessories may be ordered from the list of accessories.

Along with the calibrator, you should have received a multi-lingual user manual, which sets out the operating instructions for the instrument. It is designed to provide a quick reference guide for use in the field.

- **Safety symbols**

This manual contains a number of safety symbols designed to draw your attention to instructions that must be followed when using the instrument, as well as any risks involved.



## **Warning**

Events that may compromise the safe use of the instrument and result in considerable personal or material damage.



## **Caution...**

Events that may compromise the safe use of the instrument and result in slight personal or material damage.



## **Note...**

Special situations which demand the user's attention.

# List of contents

---

<b>1.0</b>	<b>Introduction .....</b>	<b>5</b>
<b>2.0</b>	<b>Safety instructions .....</b>	<b>7</b>
<b>3.0</b>	<b>Setting up the calibrator .....</b>	<b>8</b>
3.1	Receipt of the calibrator .....	8
3.2	Preparing the calibrator .....	10
3.3	Choice of insertion tube .....	11
3.4	Inserting the sensors .....	12
<b>4.0</b>	<b>Operating the Calibrator .....</b>	<b>15</b>
4.1	Keyboard, display and standard connections.....	15
4.2	Input module (B versions only) .....	18
4.3	Display readouts .....	19
4.3.1	Main screen temperature values .....	20
4.3.2	Stability of temperature values .....	20
4.4	SET temperature menu .....	21
4.5	Calibration menu.....	21
4.5.1	Running a calibration .....	22
4.5.2	Showing calibration results .....	25
4.5.3	Displaying calibration information .....	26
4.6	Switch test menu .....	27
4.6.1	Running a switch test.....	29
4.6.2	Showing switch test results.....	30
4.7	Auto step menu.....	32
4.7.1	Running an Auto step calibration .....	33
4.7.2	Auto step test results .....	34
4.8	Setup menu.....	36
4.8.1	Loading a setup .....	36
4.8.2	Saving a setup .....	37
4.8.3	Adjusting the display contrast.....	37
4.8.4	Altering temperature display settings.....	37
4.8.5	Setting the sensor input parameters (B versions only).....	40
4.8.6	Altering Stability criteria .....	42
4.8.7	Setting the access code.....	43
4.8.8	Resetting the calibrator setup to factory defaults .....	43
4.8.9	About the calibrator .....	44
4.9	Simulation or training .....	44
<b>5.0</b>	<b>Storing and transporting the calibrator .....</b>	<b>46</b>

<b>6.0</b>	<b>Replacing the main fuses .....</b>	<b>48</b>
6.1	Returning the calibrator for service.....	49
<b>7.0</b>	<b>Maintenance.....</b>	<b>51</b>
7.1	Cleaning.....	51
7.2	Adjusting and calibrating the instrument.....	52
7.2.1	Introduction to AmeTrim-ATC Software.....	52
7.2.2	Installing the AmeTrim-ATC Software .....	53
7.2.3	Connecting the PC and the Calibrator.....	53
7.2.4	Starting the AmeTrim-ATC Software .....	53
7.2.5	Temperature Adjustment .....	55
7.2.6	Input Adjustment (B versions only) .....	60
7.2.7	Reference Sensor .....	65
7.2.8	Managing DTI sensor coefficients .....	67
7.2.9	Setup Printer .....	68
<b>8.0</b>	<b>Technical specifications.....</b>	<b>69</b>
<b>9.0</b>	<b>List of accessories .....</b>	<b>88</b>

# 1.0 Introduction

---

## ***Congratulations on your new Ametek Jofra ATC Calibrator!***

With this Ametek Jofra calibrator, you have chosen an extremely effective instrument, which we hope will live up to all your expectations. Over the past many years, we have acquired extensive knowledge of industrial temperature calibration. This expertise is reflected in our products, which are all designed for daily use in an industrial environment. Please note that we would be very interested in hearing from you if you have any ideas or suggestions for changes to our products.

This reference manual applies to the following instruments:

- **Jofra ATC-155 A - Cooling calibrator**
- **Jofra ATC-155 B - Cooling calibrator with input panel**
- **Jofra ATC-156 A - Cooling calibrator**
- **Jofra ATC-156 B - Cooling calibrator with input panel**
- **Jofra ATC-157 A - Cooling calibrator**
- **Jofra ATC-157 B - Cooling calibrator with input panel**
- **Jofra ATC-320 A - Heating calibrator**
- **Jofra ATC-320 B - Heating calibrator with input panel**
- **Jofra ATC-650 A - Heating calibrator**
- **Jofra ATC-650 B - Heating calibrator with input panel**

 **ISO-9001 certified**



Ametek Denmark A/S was awarded the ISO-9001 certificate in September 1994 by BVQI - Bureau Veritas Quality International.



## **CE-label**



Your new calibrator bears the CE label and conforms to the EMC directive and the Low-voltage Directive.



## **Technical assistance**

Please contact the dealer from whom you acquired the instrument if you require technical assistance.



## **Guarantee**

1 year's factory warranty.

This guarantee only covers defects in manufacture and becomes void if the instrument has been subject to unauthorised intervention and/or misuse.

## 2.0 Safety instructions

---



### Read this manual carefully before using the instrument!

Please follow the instructions and procedures described in this manual. They are designed to allow you to get the most out of your calibrator and avoid any personal injuries and/or damage to the instrument.



### Warning

- The calibrator **must not** be used for any purposes other than those described in this manual.
- The calibrator is designed for **interior use only** and should **not be used in risk-prone areas**, where vapour or gas leaks, etc. may constitute an explosives hazard.



### Caution – Hot surface

This symbol is engraved in the grid plate.

- **Do not touch** the grid plate, the well or the insertion tube as the calibrator is heating up – they may be very hot.
- **Do not touch** the handle of the calibrator during use – it may be very hot.



### Note...

The product liability **only** applies if the instrument is subject to a manufacturing defect. This liability becomes void if the user fails to follow the maintenance instructions set out in this manual or uses unauthorised spare parts.

## 3.0 Setting up the calibrator

---

### 3.1 Receipt of the calibrator


#### When you receive the instrument...

- Carefully unpack and check the calibrator and the accessories.
- Check the parts against the list shown below.


If any of the parts are missing or damaged, please contact the dealer who sold the calibrator.

#### You should receive:

- 1 calibrator



- 1 mains cable




- 2 sets of test cables (2 black, 2 red – B versions only)



- 1 insertion tube (user specified)




- 3 pcs. insulation plugs for 6, 10, 16 mm sensors (ATC-155 A/B and ATC-156 A/B only) or 3 pcs. insulation plugs for 5, 8, 11 mm sensors (ATC-157 A/B only)







- 1 CD-ROM containing software package "AmeCal Temperature" and "AmeTrim-ATC" adjustment software
- 




- 1 RS 232 serial cable
- 




- 1 tool for insertion tube
- 




- 1 traceable certificate (A versions)
- 




- 2 traceable certificates (B versions)
- 



- 1 reference manual
- 



- 1 user manual
- 



When reordering, please specify the parts number found in the list of accessories, section 9.0.

## 3.2 Preparing the calibrator



### Warning

- The calibrator must **not** be used in areas prone to explosives hazards.
- The calibrator **must** be kept clear within an area of 20 cm on all sides and 1 metre above the calibrator.



### Note...

The instrument must **not** be exposed to draughts.




Fig. 1

### When setting up the calibrator, you must...

- ① Place the calibrator on an even horizontal surface in the spot you intend to use it.



### Caution...

**Do not** use the instrument if the ventilator is out of order.

- ② Ensure a free supply of air to the ventilator located at the bottom of the instrument.
- ③ Check the voltage of the power control switch (on/off switch (230V/115V)). If the voltage of the power control switch differs from the line voltage, you must adjust the voltage of the power control switch as follows (see Fig. 1):
  - A. Open the fuse box lid using a screwdriver.
  - B. Take out the fuse box.
  - C. Remove both fuses and insert two new fuses. These must be identical and should correspond to the line voltage. See section 9.0.
  - B. Turn the fuse box 180° and slide it into place.
- ④ Check that the earth connection for the instrument is present and attach the cable.
- ⑤ Select an insertion tube with the correct bore diameter. See section 3.3 for information on how to select insertion tubes.

The calibrator is now ready for use.

## 3.3 Choice of insertion tube



### Caution...

**Before** using new insertion tubes for calibration, the insertion tubes **must** be heated up to maximum temperature - 320°C (608°F) / 650°C (1202°F) - for a period of minimum 30 minutes.

In order to ensure the best calibration of your sensors please **avoid** using insertion tubes in the ATC-320 calibrator which have been used in the ATC-650 calibrator.

Insertion tubes are selected on the basis of the diameter of the sensor to be calibrated.

Use the table for insertion tubes in section 9.0 to find the correct parts number.

Alternatively, you may order an undrilled insertion tube and drill the required hole yourself. The finished dimensions should be as follows:

- Sensor diameter  $+0.2 \text{ } +0.05/-0 \text{ mm}$ .

### 3.4 Inserting the sensors

Before inserting the sensors and switching on the calibrator, please note the following important warning:



#### Warning

- **Never** use heat transfer fluids such as silicone, oil, paste, etc.  
These fluids may penetrate the calibrator and cause damage or create poisonous fumes.

Insert the sensors as shown in Fig. 2.




Fig. 2



## Caution...

- The well and the insertion tube **must** be clean before use.
- Scratches and other damage to the insertion tubes should be avoided by storing the insertion tubes carefully when not in use.
- The insertion tube must **never** be forced into the well. The well could be damaged as a result, and the insertion tube may get stuck.
- **Do not touch** the grid plate, the well or the insertion tube while the calibrator is heating up – they may be very hot.
- **Do not touch** the tip of the sensor when it is removed from the insertion tube/well – it may be very hot.

- **Do not touch** the handle of the calibrator during use – it may be very hot.

## 4.0 Operating the Calibrator

### 4.1 Keyboard, display and standard connections

#### Keyboard




Fig. 3

Pos.	Description
------	-------------

- |   |  |
|---|--|
| ① | LCD.   |
| ② | SOFT KEYS used to select menu options displayed in the LCD.  |
| ③ | ENTER KEY used to accept selected options or entered values. |
| ④ | NUMERIC KEYS used to type in values.                         |

- ⑤ INFORMATION KEY used to display the status of the parameters involved with the function currently selected.
- ⑥ ESC KEY (escape key) used to cancel a selection/edit or return to previous menu.

## Display




Fig. 4

The Display is divided into four separate areas:

- **Heading:** informs you of the current function selected.
- **Icon:** indicates graphically the status of the calibrator
- **Information:** provides the bulk of information and data in the selection.
- **Functions:** informs you of the soft keys' functions.



## Standard connections (all versions)




Fig. 5

Pos.	Description
------	-------------

- |   |   |
|---|---|
| ① | Power control switch with a cable connection and on/off switch. It also contains the main fuse. See section 6.1 for information on how to change the fuses and section 3.2 to adjust the voltage setting of the power control switch.   |
| ② | Connection for synchronization output.<br><br>The state of the synchronization output is determined by the READ or TRUE temperature (dependent on the choice of reference sensor) by the following guidelines: <ul style="list-style-type: none"><li>• when the extended stability time is = 0 minute, the relay is switched on for 2 seconds when the stability is achieved.</li><li>• when the extended stability time <math>\geq 1</math> minute for the internal reference sensor (READ), the relay is switched on in the last minute of the extended stability time.</li></ul> |

- ③ Connection for RS232 communication.

## 4.2 Input module (B versions only)



### Warning

- The sockets on the input module must **NEVER** be connected to voltages exceeding 5V for the TC/RTD sockets and 45V for the mA/V sockets proportional to ground.
- Thermostats must not be connected to any other voltage source during a test

### Description of sockets for external connections




Fig. 6

Pos.	Description
①	Input for RTD sensor (2, 3 or 4 wire).
②	Connection to chassis (earth/ground).
③	Input for reference sensor.
④	Voltage input.
⑤	Passive mA input.
⑥	Active mA input with 24V supply for transmitter.
⑦	Connection for thermostat test. <b>Note</b> that this connection is for dead switches.
⑧	TC connection for thermocouples.


One of the inputs either ①, ④, ⑤, ⑥ or ⑧ can be selected displaying the “SENSOR” temperature in the Setup and ③ can be displayed as “TRUE” temperature.

**Note:** Only the sensor type, which is to be tested, should be connected to the input panel.

## 4.3 Display readouts



Switch on the calibrator using the power control switch (pos. 1 in Fig. 5). The start up menu is displayed for approximately 2 seconds and is then replaced with the main menu screen:



The functions are available using the soft keys and are described in sections 4.4 to 4.8.

### 4.3.1 Main screen temperature values

Two temperatures are displayed (A and B versions):

- READ temperature: this is the temperature measured by the internal reference sensor.
- SET temperature: this is the target temperature for the well. SET temperature displays the last value entered. If no value has been entered previously, "Not Activated" is displayed.

Additional temperatures displayed (B versions only):

- SENSOR temperature: this is the temperature measured by the sensor being measured
- TRUE temperature: this is the temperature measured by an external reference sensor. This is only displayed when an external reference sensor is used and replaces READ temperature.

### 4.3.2 Stability of temperature values

The stability of the READ, TRUE and SENSOR temperatures are indicated by the following messages:

- "Not stable": indicates that the measured temperature is not yet within the specified stability criteria.
- "Time to stable": indicates that the temperature changes are within the specified stability criteria (see section 8.0) and states a time (in minutes) when the stable situation can be achieved.
- "✓": indicates that the "stable" situation is achieved.



- SENSOR temperature cannot indicate "✓" unless the READ or the TRUE temperature is stable.
- If External reference (TRUE) is selected, the stability criteria will refer to this. As default the criteria are as follows:

The temperature must be within a range of  $\pm 0.03^{\circ}\text{C}$  /  $0.05^{\circ}\text{F}$  in 10 minutes to be stable. The criteria can be changed, however, if the temperature is set wider or the time is set shorter the calibrator may not reach the SET temperature.

## 4.4 SET temperature menu



Press . A cursor appears in the SET temperature field.



Use the numeric keys to enter a new value, or to edit the existing value.



Press to accept the value and return to the main menu screen.

## 4.5 Calibration menu



### Note...

This Calibration function is for B versions only.

This function enables you to perform automatic calibrations of multiple temperature sensors. The calibration procedure is semi-automatic, using parameters and settings which are defined in work orders. These work orders are created and edited using the "AmeCal-Temperature" PC program. If multiple calibrations, using identical or similar settings, are required, the work orders can be replicated in the calibrator and labelled with a unique name.



Press to select the Calibration menu.

CALIBRATION				
Select calibration topic				
ESC Previous menu		Main menu ←→		
Run calibration	Show results			
F1	F2	F3	F4	F5

**Note:** Calibration information is available in several places throughout the calibration menus. The content of this information is described in section 4.5.3.

### 4.5.1 Running a calibration



Press **F1** to select the Run calibration menu.

RUN CALIBRATION		
Select work order:		
Work order:	As found	As left
Ambient sensor	✓	✓
Control sensor		
Inlet sensor	✓	
Outlet sensor		
ESC Previous menu		Next ←→
▲	▼	Copy Info Next →
F1	F2	F3     F4     F5



Use **F1** and **F2** to scroll through the list and highlight an existing work order.



Press **F3** to continue the calibration using the highlighted work order

or,

Press **F3** to create a copy of the work order. Then press **F1** to accept the new name. (Copies have the same name as the original work orders, but contain a suffix number, making the name unique.)

RUN CALIBRATION				
Basic parameters:				
As found/As left: As found				
Ambient temperature: 0.0°C				
Sensor under test:				
Serial No.: N/A				
Tag No.: N/A				
Tag location No.: N/A				
ESC Previous menu				
← Back	Edit		Info	Next →
F1	F2	F3	F4	F5



Press to continue the calibration without editing the basic parameters

or,



Press to start the editor.




RUN CALIBRATION				
Basic parameters:				
As found/As left: As found				
Ambient temperature: 23.0°C				
Sensor under test:				
Serial No.: 0124598-00325				
Tag No.: 4569				
Tag location No.: 13				
ESC Previous menu				
← Back	Edit		Info	Next →
F1	F2	F3	F4	F5

Make the necessary changes, exit the editor by pressing and continue the calibration by pressing .

If the sensor under test is a thermocouple sensor and the manual compensation mode is selected in work orders, a cold junction temperature must be defined.


MANUAL INPUT				
Thermocouple input cold junction compensation				
Manual: 0.00°C				
ESC Previous menu				
← Back	Edit		Info	Next →
				Next ←

Default value is 0,00°C (32°F) as if an ice bath is available.



Otherwise press  to enter another value. Make the necessary changes, exit the editor by pressing  and continue the calibration by pressing .

RUN CALIBRATION				
<p><b>*** Warning! ***</b>  Existing calibration  will be overwritten  Continue?</p>				
ESC Cancel				
← Back			Yes	No
F1	F2	F3	F4	F5





Press  if you wish to overwrite the existing calibration and continue.




If the work order is defined as a manual input,  or  are used to determine when the values are to be entered.

MANUAL INPUT				
<p>Manual input of sensor data</p> <p><b>Select input mode:</b></p> <p><b>Manual inputs entered during calibration</b>  — or —  <b>Manual inputs entered after calibration</b></p>				
ESC Cancel				
← Back			During calibration	After calibration

-  – to enter values during the calibration.
-  – to enter values after the calibration.



Follow the instructions on screen to connect the sensors and press  to start the calibration.





The calibration can be stopped at any time, but this will erase calibration data.

Follow the instructions on screen for repositioning the sensors (if an external manual heat source is used) and entering the step values (if manual input is required).



When the calibration is complete, press **F5** or **F6** to store the results in the calibrator. The results can be viewed using the instructions in section 4.5.2.

## 4.5.2 Showing calibration results



Press **F2** to select the Show calibration menu.

SHOW CALIBRATION RESULTS			
Work order:		As found / As left	
DEMO 6 mm Cable / 4 wire-1		As found	
DEMO 6 mm Cable / 4 wire-1		As left	
DEMO 12 mm Cable / 4 wire-1		As left	
ESC Previous menu		Main menu <b>F5</b>	
▲	▼	Result	Info
<b>F1</b>	<b>F2</b>	<b>F3</b>	<b>F4</b> <b>F5</b>



Use **F1** and **F2** to scroll through the list and highlight a specific work order.



Press **F3** to display the calibration details for the selected work order.

The calibration results can be uploaded with the “AmeCal Temperature” PC program. This enables you to print out the results on a certificate.

## Calibration result details


This screen enables you to scroll through the calibration steps and view the actual SET, READ/TRUE and SENSOR temperatures for the individual calibration steps, together with the deviation and Pass/Fail status.



Press **F3** to exit the calibration details and return to the Show calibration results menu.

### 4.5.3 Displaying calibration information

Calibration information is defined within the work orders created on the PC using "AmeCal-Temperature". This information is divided in to six pages of information:



Use **F1** and **F5** to scroll through the pages.

The scroll wraps around, allowing you to go from page 6 to page 1 and vice versa.

### **Scenario (page 1)**

This shows the calibration setup in a graphic format. The parameters for this setup are defined in the work order created using the PC program.

### **Basic parameters (page 2)**

This informs you how the calibration was registered, either "as found" or "as left" and the ambient air temperature (entered manually) at the time of the calibration.

### **Notes (page 3)**

Information entered, via the PC program, when the work order is created.

### **Sensor under test (page 4)**

If a Digital Temperature Indicator (DTI) is used, the "Measurement" field will display the DTI channel used.

### **External reference sensor (page 5)**

This screen is only available when an external reference sensor is used. If a DTI is used, the "Measurement" field will display the DTI channel used.

### **Calibration procedure (page 6)**

This shows the pre-defined temperature steps for the calibration.

## **4.6 Switch test menu**



### **Note...**

This Switch test function is for B versions only.

Switch test automatically locates the switch temperatures of a thermostat.

Three parameters are required:

- Start temperature ( $T_1$ )
- End temperature ( $T_2$ )
- Rate of change in temperature (slope rate).

The graph illustrates the temperature ( $T$ ) in  $^{\circ}\text{C}/^{\circ}\text{F}$  versus time ( $t$ ) in minutes for a thermostat calibration process. The temperature profile shows a heating cycle followed by a cooling cycle, with a hysteresis range ( $T_{\text{Hyste}}$ ) between the opening and closing temperatures.

Key temperatures and regions are labeled:

- $T_{\text{Start}}$ : Initial temperature.
- $T_1$ : Temperature at the start of the heating slope.
- $T_{\text{Close}}$ : Temperature at which the thermostat closes (switches off heating).
- $T_{\text{Open}}$ : Temperature at which the thermostat opens (switches on heating).
- $T_2$ : Maximum temperature reached.
- $T_{\text{Hyste}}$ : Hysteresis range between  $T_{\text{Open}}$  and  $T_{\text{Close}}$ .

The graph is divided into three main regions:

- Calibrator stable**: The initial heating phase from  $T_{\text{Start}}$  to  $T_1$ .
- Heating with Slope Rate**: The linear heating phase from  $T_1$  to  $T_2$ .
- Cooling with Slope Rate**: The linear cooling phase from  $T_2$  to  $T_{\text{Close}}$ .

The "Calibrator stable" region is further subdivided into:

- Calibrator stable**: The initial part of the heating phase.
- Shifting temperature**: The part of the heating phase where the temperature is changing (indicated by a cross symbol).

The "Expected switch range for thermostat" is indicated by a bracket between  $T_{\text{Open}}$  and  $T_{\text{Close}}$ .

Legend:

- Calibrator stable
- ⊗ Shifting temperature





105446 02

## 4.6.1 Running a switch test



Press **F1** to select Run switch test.

SWITCH TEST SETUP 				
Switch test setup				
<b>T<sub>1</sub>:</b> 50.0°C				
<b>T<sub>2</sub>:</b> 60.0°C				
<b>Hysteresis:</b> Yes				
<b>Slope rate:</b> 0.5°C/min				
ESC Previous menu				
T <sub>1</sub>	T <sub>2</sub>	Hysteresis	Slope rate	Start
<b>F1</b>	<b>F2</b>	<b>F3</b>	<b>F4</b>	<b>F5</b>

The small graph illustrates the current T<sub>1</sub>, T<sub>2</sub> and hysteresis selections. Note that T<sub>1</sub> can be greater than T<sub>2</sub>.



Press a function soft key (**F1** – **F5**) to enable the editor.

**F1** – To edit the first set temperature (T<sub>1</sub>).

**F2** – To edit the second set temperature (T<sub>2</sub>).

**F3** – To determine hysteresis, toggle between "Yes" (a two temperature measurement) and "No" (a single temperature measurement).

**F4** – To edit the slope rate. The permitted range is 0.1 – 9.9°C/min. / 0.2 – 17.8°F/min.

Note: the slope rate should be set so that the thermostat sensor can follow the temperature in the calibrator's well.



Make the necessary changes and exit the editor by pressing



Press **F5** to start the switch test.

While the switch test is in progress, three functions are available:

**F1** – To show the current switch test results. This is described in section 4.6.2.

**F2** – To review the switch test set up (no editing is possible).

**F5** – To stop the switch test.

## The calibrator's switch test procedure

1. Once the switch test is started, the calibrator starts working towards  $T_1$  as quickly as possible. The calibrator's temperature changes (heating or cooling) and switch status are shown in the display.
2. When  $T_1$  is achieved and the temperature is stable, a "✓" is displayed for one second.
3. The calibrator now starts working towards  $T_2$  at the specified slope rate.
4. In a normal situation, the thermostat changes state before  $T_2$  is achieved. If  $T_2$  is achieved and the temperature is stable, "No Shift" result is displayed.
5. When hysteresis is not selected (single temperature change), the finished switch test result is displayed, see section 4.6.2.

When hysteresis is selected (two switch changes), the calibrator starts working towards  $T_1$  at the specified slope rate.

6. Normally, the thermostat changes state before  $T_1$  is achieved. If  $T_1$  is reached and the temperature is stable, "No Shift" result is displayed.
7. The finished switch test results are displayed, see section 4.6.2.

### 4.6.2 Showing switch test results

Two types of switch test results are available:

- Results during a switch test.
- Results of a finished switch test.

## Results during a switch test



Press to select Show result.

SWITCH TEST				
Switch test result until now				
Close : 52.1°C				
Open :				
Hysteresis:				
ESC Previous menu				
Back to sw. test				
F1	F2	F3	F4	F5

This shows the results that are currently available. These results change as the test progresses.



Press to return to the switch test.

## Finished switch test results

At the end of a switch test the results are displayed. These show the final result of the test and are known as the finished results.

SWITCH TEST 1 RESULT	
Switch test result	
Close : 52.1°C	
Open : 50.9°C	
Hysteresis: +1.1°C	
ESC Previous menu	
	Setup
	Finished
F1	F2
F3	F4
F5	

**Note:** A hysteresis value is only displayed when hysteresis is selected. If either the first or second temperature displays "No shift", hysteresis displays "Error". For details, see section 6.0.

When you exit the switch test, either by pressing or , these results are stored in the calibrator's memory.  
By pressing the results are not stored in the calibrator's memory.

## To view stored finished switch test results



Press **F7** to select Show results.

SHOW SWITCH TEST RESULTS				
Select switch test result to view				
Switch test 1 is newest, switch test 5 is oldest				
ESC Previous menu		Main menu <b>F5</b>		
1	2	3	4	5
<b>F1</b>	<b>F2</b>	<b>F3</b>	<b>F4</b>	<b>F5</b>



Press a function soft key (**F1** – **F5**) to select the results for one of the last five tests. The data in the information field is the same as that displayed at the end of the switch test.

## 4.7 Auto step menu

Auto step is used to step automatically between a range of different calibration temperatures. This is useful when calibrating sensors in places that are difficult to reach and sensors where the output is displayed in a different location.




Fig. 8





Press to select the Auto step menu.

AUTO STEP				
Select auto step topic				
ESC Main menu		Main menu		
Run auto step	Show results			
F1	F2	F3	F4	F5

Two functions are available using the soft keys

### 4.7.1 Running an Auto step calibration




Press to select Run auto step.

AUTO STEP SETUP				
 No. of steps: <b>5</b> Mode: <b>Two-way</b> Hold time: <b>0 min</b>	T <sub>1</sub>	35.0 °C	T <sub>11</sub>	°C
	T <sub>2</sub>	50.0 °C	T <sub>12</sub>	°C
	T <sub>3</sub>	75.0 °C	T <sub>13</sub>	°C
	T <sub>4</sub>	100.0 °C	T <sub>14</sub>	°C
	T <sub>5</sub>	155.0 °C	T <sub>15</sub>	°C
	T <sub>6</sub>	°C	T <sub>16</sub>	°C
	T <sub>7</sub>	°C	T <sub>17</sub>	°C
	T <sub>8</sub>	°C	T <sub>18</sub>	°C
	T <sub>9</sub>	°C	T <sub>19</sub>	°C
	T <sub>10</sub>	°C	T <sub>20</sub>	°C
ESC Cancel		Start		
Edit				Start
F1	F2	F3	F4	F5




Press to enable the editor to change the Auto step setup and step temperature values.


- **No of steps:** the number of temperature steps per direction (T<sub>1</sub> ➡ T<sub>x</sub>) can be set using integers from 1 – 20. When a Two-way mode is selected, the same number of steps are used for the second direction (T<sub>x</sub> ➡ T<sub>1</sub>).
- **Mode:** toggle between "One-way" and "Two-way".
- **Hold time:** defines the time (in minutes) the temperature is maintained (after it is stable) for each step.
- **T step values:** must be set within the sensors permitted range.

Make the necessary changes and exit the editor by pressing .





Press  to start the Auto step test.



While the step test is in progress, several functions are available:


 – To review the Auto step result (no editing is possible).

 – To pause the test.

 and  – Force the test to jump a step (previous or next), regardless of the temperature step's stability.

 – To stop the Auto step test.

When the Auto step test is complete the results are displayed. Press  or  to finish the test and store the results in the calibrator. The results can be viewed using the instructions in section 4.7.2.

By pressing  the results are not stored in the calibrator's memory.

## 4.7.2 Auto step test results

At the end of a Auto step test the results are displayed and stored in the calibrators memory.

AUTO STEP RESULT				
Step	SET	READ	SENSOR	
	°C	°C	°C	
1	35.0	35.0	34.8	
2	50.0	50.0	49.9	
3	75.0	75.0	74.9	
4	100.0	100.0	99.9	
5	155.0	155.0	154.9	
6	100.0	100.0	100.1	
ESC Previous menu				
Back to auto step	Setup		▲	▼
F1	F2	F3	F4	F5

The measured READ or TRUE and SENSOR temperatures for each step are displayed.

## To view stored switch test results



Press **F2** to select Show results.

SHOW AUTO STEP RESULTS				
Select auto step result to view				
Auto step 1 is newest, auto step 5 is oldest				
ESC Previous menu			Main menu <b>F5</b>	
1	2	3	4	5
<b>F1</b>	<b>F2</b>	<b>F3</b>	<b>F4</b>	<b>F5</b>



Press a function soft key (**F1** – **F5**) to select one of the last five Auto step tests stored in the calibrator.

## 4.8 Setup menu



Press **F5** to select the Setup menu.

Nine functions are available. These are divided into three separate pages. Use the function key(s) labelled "more" to change page. Use the soft keys (**F1** – **F5**) to select the individual functions:

SETUP				
Select setup topic				
ESC Main menu		Main menu <b>F5</b>		
Load setup	Save setup	Display contrast	Temperature	more <b>F5</b> →

page 1

ESC Main menu		Main menu <b>F5</b>		
← more	Input	Stability criteria	Access code	more <b>F5</b> →

page 2

ESC Main menu		Main menu <b>F5</b>		
← more	Factory defaults	About		

page 3

| **F1** | | **F2** | | **F3** | | **F4** | | **F5** |

### 4.8.1 Loading a setup



Loading a setup causes all the parameters in the setup menu to be overwritten.



Press **F1** (setup page 1) to select Load setup.



Use the keyboard to select a calibrator setup number (1–9).



Press **F5** to load the selected setup. A warning informs you that the active setup will be overwritten.



Press **F1** if you are sure you want to overwrite the existing setup and return to the setup menu.

## 4.8.2 Saving a setup



Saving a setup, saves all the parameters in the Setup menu.



Press **F2** (setup page 1) to select Save setup to registry.



Use the keyboard to select a register number (1–9).



Press **F3** to save the current setup in the selected register and return to the setup menu.

## 4.8.3 Adjusting the display contrast



Press **F3** (setup page 1) to select Display contrast.



Press **F1** to make the display darker or **F2** to make the display lighter.



Press **Enter** to accept the new setting and return to the setup menu.

## 4.8.4 Altering temperature display settings











Press **F2** (setup page 1) to select the Temperature menu.

TEMPERATURE				
Select temperature topic				
				Main menu ←
Unit	Resolution	Max SET temp.	Conv. to temp.	
<b>F1</b>	<b>F2</b>	<b>F3</b>	<b>F4</b>	<b>F5</b>


Use the function soft keys to set the parameters displayed.










## Setting the temperature units

-  Press  to select Unit.
-  Press a function soft key to select the temperature units:
  -  - To select Celsius.
  -  - To select Fahrenheit.
  -  - To select Kelvin
-  Press  to accept the new setting.





## Setting the temperature resolution





-  Press  to select temperature resolution.

TEMPERATURE RESOLUTION				
Select type of temperature				
				Main menu 
SET	READ	TRUE	SENSOR	
F1	F2	F3	F4	F5

-  Press a function soft key ( – ) to select the temperature type.
-  Press a function soft key to set the resolution.
  -  – 1° resolution.
  -  – 0.1° resolution.
  -  – 0.01° resolution.
-  Press  to accept the new setting and return to the temperature resolution menu.







## Setting the max. SET temperature

-  Press  to select Max. SET temperature.
-  Press . A cursor appears in the Max. SET temperature value.













-  Use the numeric keys to enter a new value, or press  to edit the existing value.
-  Press  to accept the new setting and return to the Max. SET temperature menu.

## Converting electrical inputs to temperatures

-  Press  to select the Conversion to temperatures menu.

CONVERSION TO TEMP.				
Select type of input				
				Main menu 
Voltage 0-4V	Voltage 0-12V	Current 4-20mA	Cold junc. compens.	
 F1	 F2	 F3	 F4	 F5

## Setting voltage or current input conversions from the electric signal to a temperature reading.

-  Press a function soft key ( – ) to select the type of input.
-  Press a function soft key to select a parameter and start the editor.
  -  – Low input (voltage or current).
  -  – Low input temperature that corresponds to the low level electrical signal.
  -  – High input (voltage or current).
  -  – High input temperature that corresponds to the high level electrical signal.
-  Use the numeric keys to set a new value or press  to edit the existing value.
-  Make the necessary changes and press  to accept the new setting(s), and to return to the Conversion to temperatures menu.

## Setting cold junction compensation temperatures



When the automatic mode is selected, the calibrator measures the temperature in the T/C connector and uses this for the cold junction compensation of the thermocouple.



Press **F1** to select Cold junction compensation.



Press a function soft key to enable the editor:

**F1** - To select compensation mode; toggle between Automatic and Manual.

**F2** - To define a Manual temperature for the cold junction compensation. This can be used when an external cold junction temperature can be established.



Make the necessary changes and press **F3** to accept the new setting(s) and return to the Cold junction compensation menu.

### 4.8.5 Setting the sensor input parameters (B versions only)



Press **F2** (setup page 2) to select Input.

INPUT				
Select input topic				
ESC Previous menu		Main menu <b>F3</b>		
Reference sensor	Sensor u. test			
<b>F1</b>	<b>F2</b>	<b>F3</b>	<b>F4</b>	<b>F5</b>

### Selecting the reference sensor input




Press **F1** to select Reference sensor.




Press a function soft key to enable the editor:

**F1** - To select Internal reference source. Results in displaying the reference as READ.



 - To select External reference source (reference input on front panel). Results in displaying the reference as TRUE and the Internal reference is displayed as READ (a secondary value).

 - To change Convert to temperature function.  
Yes sets the readout of the External reference as a temperature.

No sets the readout of the External reference in  $\Omega$  values.


 - To change SET follows TRUE; toggle between On and Off.

This function enables you to reach an exact TRUE temperature measured by the External reference sensor.

**Note** that when ON is selected, the calibrator will let the temperature be set by the TRUE temperature. This means it will take longer before the calibrator indicates stable.

**Note:** Set follows TRUE is only relevant when the External reference sensor is displayed in temperature units.



Make the necessary changes and press  to accept the new setting(s) and return to the Input menu.

**Note** that when SET follows TRUE is on, it is indicated by a



-symbol at the SET temperature.

## Selecting the input from the sensor under test



Press  to select Sensor under test.





Press  to select type of sensor.



Press a function soft key to select a specific type of sensor.


 – For voltage sensors (0 – 4V or 0 – 12V).

 – For a 4 – 20mA sensor.

 – For RTD sensors (Pt10, Pt50, Pt100, Pt500, Pt1000, Cu50 or Cu100).

 – For thermocouple sensors (E, J, K, L, N, R, S, T, U or


XK).

 – For None (no sensor connected).



Press a function soft key to select a specific sensor and return to the Sensor under test menu, which now displays the selected sensor and the Convert to temperature status.




Press  to select Convert to temperature. This toggles between Yes (where inputs are converted to temperatures) and No (where no conversion is made). The temperature conversion factors for the 0–4V, 0–12V and 4–20mA inputs are set in the Temperature menu, see section 4.8.4.



Press  to accept the new settings and return to the Input menu.

## 4.8.6 Altering Stability criteria



Press  (setup page 2) to select Stability criteria.

STABILITY CRITERIA				
<b>Internal reference (READ)</b>				
Extended stability time: 20 min.				
<b>External reference (TRUE)</b>				
Stability interval: $\pm 18.00^{\circ}\text{F}$				
Stability time: 19 min.				
<b>Sensor under test (SENSOR)</b>				
Use stability criteria: No				
Stability interval: $\pm 18.00^{\circ}\text{F}$				
Stability time: 19 min.				
<hr/>				
Edit				
F1	F2	F3	F4	F5

The parameters displayed depend on the sensor selected.


When none of the parameters displayed are active, then the calibrator's internal reference criteria provide the "time to stable" value. Stability values defined in the menu above are added to the internal reference stability criteria.



Press  to select the editor.


- Stability Time and Extended Stability Time can be set (in minutes) using integers from 0 – 120.
- Stability intervals can be set in  $0.01^{\circ}$  steps from  $\pm 0.01$  –  $\pm 99.99$ .



Make the necessary changes and press  to accept the new setting(s) and exit the editor.

#### 4.8.7 Setting the access code



Press  (setup page 2) to select Access code.

ACCESS CODE				
Select access code				
0000				
Entering "0000" as code disables access control.				
Back- + space				
F1	F2	F3	F4	F5

The following features can be protected by an access code:

- Resetting the calibrator to Factory default settings.
- Setting the Maximum SET Temperature.
- Editing the Access code while it is enabled.





Press  to change the Access code.



Use the numeric keys to type in a value from 0000 to 9999. Typing 0000 disables the access code function.




Press  to accept the new access code and exit the editor by pressing  again.

#### 4.8.8 Resetting the calibrator setup to factory defaults



Resetting to the factory default settings changes the setup to the initial settings.



Press  (setup page 3) to restore Factory defaults.



## Caution...

By pressing **F1** (Yes) the following will be deleted :

- Work orders
- Setup parameters
- Autostep results
- Switch test results



Press **F1** to restore Default factory settings.

## 4.8.9 About the calibrator



Press **F3** (setup page 3) to select About.

This informs you about the calibrator type, the software version installed and the date when it was last calibrated.




Press **ESC** or **F5** to return to the Setup menu.

## 4.9 Simulation or training



Press and hold **F1** while you start the calibrator.



The calibrator will start in the simulation state.

This mode is used to train personnel. The simulation differs from the standard setting in the following ways:

- The instrument does not actually heat up or cool down the well.
- The heating and cooling processes are simulated at exaggerated speeds.
- Data is not stored in the calibrators memory.

The calibrator will remain in simulation mode until it is switched off.

## 5.0 Storing and transporting the calibrator



### Caution...

The following guidelines should always be observed when storing and transporting the calibrator. This will ensure that the instrument and the sensor remain in good working order.

Switch off the calibrator using the power control switch.

Note that the calibration procedure may be interrupted at any time using the power control switch. Turning off the calibrator during the calibration process will not damage either the instrument or the sensor.




Fig. 9

The following routine must be observed **before the insertion tube is removed** and the instrument switched off:



### Over 100°C/212°F

If the calibrator has been heated up to temperatures above 100°C/212°F, you must wait until the instrument reaches a temperature **below 100°C/212°F** before you switch it off.

### Below 0°C/32°F (applies only to the ATC-155/156/157 A/B models)

If the calibrator has reached a temperature below 0°C/32°F, ice crystals may form on the insertion tube and the well. This, in turn, may cause verdigris to form on the material.

To prevent this from happening, simply heat up the calibrator to 50°C/122°F.

Remove the insertion tube from the calibrator using the tool for insertion tube supplied with the instrument (see Fig. 9).



### Caution...

- The insertion tube must **always** be removed from the calibrator after use.  
The humidity in the air may cause verdigris to form on the insertion tube inside the instrument. There is a risk that the insertion tube may become stuck if this is allowed to happen.
- The insertion tube **must** be removed to avoid damage to the instrument if the calibrator is to be transported long distances.



### Warning

**Never** leave hot insertion tubes that have been removed from the calibrator unsupervised – they may constitute a fire hazard.

If you intend to store the calibrator in the optional aluminium carrying case after use, you **must** ensure that the instrument has cooled to a temperature **below 100°C/212°F** before placing it in the carrying case.

## 6.0 Replacing the main fuses



### Warning

- The fuse box must not be removed from the power control switch until the mains cable has been disconnected.
- The two main fuses must be identical and correspond to the chosen voltage.




Fig. 10

- ① Locate the main fuses in the fuse box in the power control switch.
- ② Open the lid of the fuse box using a screwdriver.
- ③ Remove the fuse box.
- ④ Replace the fuses.
  - **ATC-155/156/157:** 115V, 5AT = 60B315 / 230V, 2.5AT = 123690
  - **ATC-320/650:** 115V, 10AF = 60B302 / 230V, 5AF = 60B301

If the fuses blow immediately after you have replaced them, the calibrator should be returned to the manufacturer for service.



## 6.1 Returning the calibrator for service

When returning the calibrator to the manufacturer for service, please enclose a fully completed service information form. Simply copy the form on the following page and fill in the required information. The calibrator should be returned in the original packing.



### **Note...**

If the software detects an error during operation, the error will be shown in the display.

Make a note of the error message and contact your distributor or Ametek Denmark's service department.

Ametek Denmark's liability ceases if:

- parts are replaced/repared using spare parts which are not identical to those recommended by the manufacturer.
- non-original parts are used in any way when operating the instrument.

Ametek Denmark's liability is restricted to errors that originated from the factory.

# Service info

**Customer data:****Date:**

Customer name and address: \_\_\_\_\_

Attention and Dept.: \_\_\_\_\_

Fax no./Phone no.: \_\_\_\_\_

Your order no.: \_\_\_\_\_

Delivery address: \_\_\_\_\_

Distributor name: \_\_\_\_\_

---

**Instrument data:**

Model and Serial no.: \_\_\_\_\_

Warranty claimed    Yes: \_\_\_\_ No: \_\_\_\_    Original invoice no.: \_\_\_\_\_

Temp.  
calibrationSensor  
input**Service request:****This instrument is sent for  
(please tick off):**☐☐

\_\_\_ Calibration as left

\_\_\_ Check

☐☐

\_\_\_ Calibration as found and as left

\_\_\_ Service

☐☐

\_\_\_ Accredited calibration as left

\_\_\_ Repair

☐☐

\_\_\_ Accredited calibration as found and as left.

---

**Diagnosis data/cause for return:**

Diagnosis/Fault description: \_\_\_\_\_

Special requests: \_\_\_\_\_

---

Safety precautions: if the product has been exposed to any hazardous substances, it must be thoroughly decontaminated before it is returned to Ametek. Details of the hazardous substances and any precautions to be taken must be enclosed.

## 7.0 Maintenance

---

### 7.1 Cleaning



#### Caution...

Before cleaning the calibrator, you **must** switch it off, allow it to cool down and remove all cables.

Users should/must carry out the following cleaning procedures as and when required:

- **The exterior of the instrument** - Clean using water and a soft cloth.  
The cloth should be wrung out hard to avoid any water penetrating the calibrator and causing damage.  
The keyboard may be cleaned using isopropyl alcohol when heavily soiled.
- **The insertion tube** - Must **always** be clean and should be regularly wiped using a soft, lint-free, dry cloth.  
You must ensure there are no textile fibres on the insertion tube when it is inserted in the well. The fibres may adhere to the well and damage it.
- **The well** - Must **always** be clean. Dust and textile fibres should be removed from the well using e.g. compressed air.

**REMEMBER! Wear goggles when using compressed air!**

## 7.2 Adjusting and calibrating the instrument

You are advised to return the calibrator to Ametek Denmark A/S or an accredited laboratory at least once a year for calibration.

Alternatively, you can calibrate/adjust the calibrator yourself using the AmeTrim-ATC Adjust and Calibration Software. This software is divided into 3 separate processes:

- **Temperature Adjustment:** this checks the accuracy of the heat source and internal sensor in the calibrator, (section 7.2.5).
- **Input Adjustment:** this checks the accuracy of the calibrator's electrical inputs (for B versions only), (section 7.2.6).
- **Reference Sensor:** this ensures that the electrical values from the reference sensor correspond to the correct temperature values. The calibration values of the sensor can be downloaded to the calibrator. (B versions only), (section 7.2.7).
- **DTI Sensor:** Use this feature to manage the coefficients of the sensors in an AMETEK Digital Temperature Indicator (DTI) instrument.

### 7.2.1 Introduction to AmeTrim-ATC Software

This software is supplied on the AmeCal Temperature CD-ROM. It can be run directly from this CD-ROM and requires no special installation. It is possible to make a disk containing the AmeTrim-ATC software. From this disk AmeTrim-ATC can be installed on the harddisk of the computer, but the disk has to be in the disk drive when running the software.

To use the software, you need:

#### PC hardware requirements

- IBM compatible PC with 486 or higher processor (Pentium 90 MHz recommended).
- 16 MB of RAM (32 MB recommended).
- 4 MB available hard-disk space.
- SVGA monitor (640 x 480, 16 colours), (800 x 600, 256 colours recommended).
- Microsoft Windows<sup>®</sup> 95/98 or Microsoft Windows NT<sup>®</sup> compatible mouse.

- CD-ROM drive.
- One vacant RS 232 Serial Port (Two are necessary if the DTI is used for the calibration)

### **PC software requirements**

- Microsoft Windows® 95/98 or Microsoft Windows NT®.
- System font: MS Sans Serif and Arial.

## **7.2.2 Installing the AmeTrim-ATC Software**

The software comes on a CD-ROM and is ready to run – no installation is required. Simply insert the CD-ROM and run the ATC-adjustment program.

## **7.2.3 Connecting the PC and the Calibrator**



### **Caution...**

1. Ensure that both the PC and the calibrator are switched off at the mains. Failure to do so may result in your equipment being damaged.
2. Connect the serial cable provided to the “RS 232” port on the front of the calibrator and to the COM port on the PC.
3. Switch on the PC and the calibrator.

## **7.2.4 Starting the AmeTrim-ATC Software**



### **Note...**

Before starting this software, the PC and the calibrator must be connected together and the calibrator switched on (see section 7.2.3).


The calibrator must not be performing any tasks like switch test, autostep or workorders. That means that the calibrator must be in the main menu before starting the software.

Use the normal Windows procedure to start the AmeTrim-ATC software.

If you are unsure of how to start software programs, refer to your Windows Help

As the software starts, it detects the type of calibrator connected to the PC and reads its serial number.

This information plus the COM port the calibrator is connected to is displayed at the bottom of the AmeTrim-ATC window.




If the calibrator is not switched on or is not one of the models covered by this manual, then the software closes automatically.



### **Note...**

When software is used to control the calibrator, the calibrator's keyboard is disabled and the display indicates that the calibrator is remote controlled.



### 7.2.5 Temperature Adjustment

This enables you to check the accuracy of the heat source and the internal sensor in the calibrator.

This can be done in 3 ways:

- Using the external reference sensor on the ATC (B-version) to measure the TRUE temperature, AmeTrim-ATC can perform a fully automatic calibration and adjustment of the internal sensor. The calibrated reference sensor should then be connected to the reference input.
- Using a Digital Temperature Indicator (DTI) AmeTrim-ATC can read the TRUE temperature from the DTI and also make a fully automatic calibration and adjustment of the internal sensor. The DTI must be connected to a vacant serial COM port. See Fig. 11.
- Using any other reference instrument, AmeTrim-ATC will set the temperature sequence and the TRUE values can be entered as they occur as manual inputs.





Fig. 11



In AmeTrim-ATC main menu, click Temperature adjustment.







Click a radio button to select the scenario that should be used, depending on which calibrated temperature reference that is available.



Click a radio button to select the desired temperature units.



Click a radio button to select whether the calibration only should be performed as an “As Found” which means without adjusting the internal sensor, or if it should be both as an “As found” measurement followed by and adjustment of the sensor and a final “As Left” calibration after the adjustment.

After the calibration measurement reports on both calibrations can be printed.



Enter the ambient temperature and the operator initials. These are to be used on the printed measurement reports.

**Enter information**

Calibrator serial number  
Serial No. 016038-00008

Ambient temperature  
Ambient  °C

Operator Initials  
Operator


Ok Cancel

Ensure that the precision thermometer is positioned correctly and ready to measure the temperatures.




Confirm that the calibration should be started.

Information on the last calibration date for the reference input is read from the calibrator and given to help you ensuring an adequate calibrated reference.



Click Yes. The calibrator immediately starts working towards the temperature defined in the first step.

A new dialogue containing a table with pre-defined temperature steps is displayed. The calibrator type determines the range of these steps.



When using the external reference sensor input on the calibrator, or when using a DTI, the calibration and adjustment will now run automatically.

## Adjusting with manual inputs

If manual inputs is selected in the adjustment Scenario menu, the calibration will be performed in a little different way.



Enter the data to be used on the printed measurement reports and click Ok.

**Enter information**

Calibrator serial number  
Serial No. 016038-00008

Ambient temperature  
Ambient [ ] °C

Operator Initials  
Operator [ ]

Decimals  
True values [ ]

Reference equipment  
[ ]

Ok Cancel



When the True temperature is stable click “Enter value”. In the new dialogue, type in the correct “TRUE temperature” value read from the external precision thermometer.

**AmeTrim-ATC v.1.00**

**Manual temperature adjustment**  
Instrument type: ATC-155 B, Serial: Not Assigned

Steps	Read temp.	True temp.
-15		
0		
25		
50		
75		
100		
125		
155		

**Interaction**  
Enter value  
Calculate  
Download  
Exit  
Stop

**Info**  
Select the button "Enter value", when the "True" temperature is stable on the external readout. When all temperatures have been measured, you can calculate a new set of coefficients and download them to the calibrator, and you can print the measured data.

Exit

CDM:1 Type: ATC-155 B, Serial no: Not Assigned, Last cal. date: 2000-01-01/2000-01-01



Click OK. The READ temperature measured by the calibrator and the TRUE value are entered in the table.

The calibrator now starts working towards the next temperature level.



Repeat these steps until READ and TRUE values have been entered for each temperature step.



Click Calculate to provide a new set of calibration coefficients for the calibrator.



### **Note...**

If you want a record of the measured TRUE and READ values, you *must* click Print now. These values are not saved once you return to the AmeTrim Main Menu.



### **Note...**

Downloading new coefficients to the calibrator overwrites the existing ones already resident in the calibrator.

To prevent unintentional overwriting of existing coefficients, a warning appears requiring you to confirm the download.



When you are satisfied with the measured and calculated values, click Download to send the correction values to the calibrator.



Click Done to exit the Temperature adjustment option.

## **7.2.6 Input Adjustment (B versions only)**

This option allows you to check the accuracy of the calibrator's electrical inputs (for B versions only - see Fig. 6). In addition to the equipment already described in sections 7.2.1 and 7.2.3, you also require a calibrated reference signal source. For Cold Junction compensation, you will also require a stable temperature source, for example an ice bath, and a conversion table to provide the sensor's corresponding  $\mu\text{V}$  value for the bath's temperature.



### **Note...**

Before calibrating/adjusting the inputs the calibrator must have been turned on for at least half an hour with the SET temperature "Not Activated" (the initial mode when turned on).

In order to calibrate the inputs the following calibrated signals must be used:

<b>Nominal values</b>	<b>Accepted range</b>
<ul style="list-style-type: none"> <li>RTD and Reference Inputs: <ul style="list-style-type: none"> <li>50Ω</li> <li>176Ω</li> <li>345Ω</li> </ul> </li> <li>RTD inputs: <ul style="list-style-type: none"> <li>1000Ω</li> <li>2700Ω</li> </ul> </li> <li>mA inputs: <ul style="list-style-type: none"> <li>0 mA</li> <li>10 mA</li> <li>20 mA</li> </ul> </li> <li>V Inputs: <ul style="list-style-type: none"> <li>0 V</li> <li>5 V</li> <li>10 V</li> </ul> </li> <li>mV inputs: <ul style="list-style-type: none"> <li>0 mV</li> <li>35 mV</li> <li>70 mV</li> </ul> </li> <li>Cold Junction compensation:</li> </ul>	<ul style="list-style-type: none"> <li>(45 to 70Ω)</li> <li>(150 to 200Ω)</li> <li>(330 to 350Ω)</li> <li>(800 to 1200Ω)</li> <li>(2300 to 2900Ω)</li> <li>(-1 to +1 mA)</li> <li>(9 to 11 mA)</li> <li>(18 to 22 mA)</li> <li>(-1 to +1 V)</li> <li>(3 to 7 V)</li> <li>(9 to 11 V)</li> <li>(-1 to +1 mV)</li> <li>(25 to 45 mV)</li> <li>(63 to 77 mV)</li> <li>N-type thermocouple and a reference junction, for example an ice bath.</li> </ul>

Note that Cold Junction compensation is only possible when "Measure/Adjust/Calibrate" is selected.

The number and type of electrical inputs to be checked is user-definable. You can also define if you want to check the inputs by just measuring them or to measure, adjust and then calibrate the electrical inputs.

Cold Junction compensation requires a special setup, using a calibrated temperature source, for example an ice bath. This and the measurement principles are shown briefly below:





Fig. 12

If at any point you do not wish to continue, click Stop. The software exits this option and returns to the Main Menu.



In AmeTrim-ATC main menu, click Input adjustment.



By clicking the Calibration Date button, you can view the last calibration dates for each of the inputs.

## To view the current Input values



Click the radio button Only measuring.



Use the check box list to select the inputs to be measured.

If you have selected more than one input to be measured, the measurements occur in the same order as they appear in the check box list.



Use the check box list to select the inputs to be measured.



Connect the reference signal source to the appropriate input(s) when prompted.



Click Start and follow the instructions on screen.

The software starts measuring the first of the selected inputs. Ensure that the correct reference signal source is connected when prompted.



When all the selected inputs have been measured a new dialogue appears.

Measurement report ID: [text field]

Mark report as:  
☒ As found ☐ As left

Calibration/adjustment date:  
dd [17] - mm [01] - yyyy [2000]

[Printer setup] [OK] [Cancel]



Type a unique name for the measurements. Click As found and ensure that the date is correct. This information will appear in a measurement report displayed on screen.



Click OK to view the measurement report.



### Note...

These results are not saved electronically. If you require a record of these measurements, click Print while it is displayed.



When you are finished viewing or printing the report, click Close. This returns you to the first dialogue in the Temperature adjustment option.



If you do not require any further measurements, click Done to return to the Main Menu.

## To view, adjust and calibrate the current Input values



### Note...

If you select Cold Junction compensation, either you must also select the mV (TC) Input or be sure that the (TC) Input is calibrated.



Click the radio button Measure/Adjust/Calibrate.



Use the check box list to select the inputs to be measured.

If you have selected more than one check box, the measurements occur in the same order as they appear in the check box list.



Connect the reference signal source to the appropriate input(s) (when prompted).



Click Start and follow the instructions on screen.

Each input has several pre-set input values. Ensure that the reference signal source is adjusted correctly when prompted.

For Cold Junction compensation, ensure the corresponding  $\mu\text{V}$  value for the calibrated junction temperature is entered ( $0\mu\text{V} @ 0^{\circ}\text{C}$ ).



The software measures the pre-set values for the selected input, adjusts the settings and then re-calibrates the calibrator's inputs. All this is done before moving on to the next selected input.



When all the selected inputs have been measured, adjusted and re-calibrated a new dialogue appears.



Type a unique name for the measurements. Click As left and ensure that the date is correct. This information will appear in a measurement report displayed on screen.



Click OK to view the measurement report.



### Note...

These results are not saved electronically. If you require a record of these measurements, click Print while the report is displayed.



When you are finished viewing or printing the report, click Close. This returns you to the first dialogue in the Temperature adjustment option.



If you do not require any further measurements, click Done to return to the Main Menu.

## 7.2.7 Reference Sensor

This option enables you to view the calibration values currently loaded in the calibrator for the reference sensor as well as enter and download values for new reference sensors. In addition to the equipment already described in sections 7.2.1 and 7.2.3, you also require the calibration certificate for the new reference sensor.



In AmeTrim-ATC main menu, click Reference sensor.

A new dialogue with a table containing the calibration of corresponding temperatures and resistances of the reference sensor. If none are present in the calibrator, then the default values are displayed.

Step	Ref. Temp	Ohm
Step 1	-25,000	90,190
Step 2	0,000	100,000
Step 3	100,000	138,510
Step 4	200,000	175,860
Step 5	300,000	212,050



Click a radio button to select the desired temperature units.

## To view current values in the Calibrator



Click Upload values. The current reference sensor values stored in the calibrator are displayed.



Click Done when you are finished viewing the values. This returns you to the AmeTrim-ATC Main Menu.

## To enter values for a new reference sensor



Type in a unique and descriptive name for the reference sensor.

Use the mouse to position the pointer in the boxes in the table.



Type in the temperature and resistance values from the Calibration Certificate supplied with the reference sensor.



If the calibration data fills more than the steps currently displayed, click Add step. If it fills less than the number of steps displayed, click Delete step.



When all the values from the Calibration Certificate have been entered, click Download values.  
When the values are downloaded they overwrite the ones stored in the calibrator.

## Default values

This option downloads a set of default values, which are stored in the AmeTrim-ATC software.

## 7.2.8 Managing DTI sensor coefficients

This dialog enables you to type in coefficient values for the reference sensor connected to the DTI



### Note...

These coefficients are not saved. Therefore, they must be typed in and downloaded when they need to be used.

The screenshot shows the 'AmeTrim-ATC v.0.15' window. Inside, there is a 'DTI sensor Data' dialog box. The 'Sensor position' section has two radio buttons: 'Sensor 1' (selected) and 'Sensor 2'. Below this, the 'Sensor name' field contains 'Test 4'. There are four input fields for coefficients: 'Ro:' with value '1.000584E+02', 'B:' with value '-5.771973E-07', 'A:' with value '3.918022E-03', and 'C:' with value '-1.445963E-11'. To the right of the dialog is an 'Interaction' panel with three buttons: 'Upload', 'Download', and 'Default'. At the bottom right of the main window is an 'Exit' button. The status bar at the bottom of the window displays: 'DDM:1 Type: ATC-650 B, Serial no. Not Assigned, Last cal. date: 2000-01-01/2000-01-01'.



Select the channel that is used to connect this sensor to the DTI.



Type in the correct coefficients for the selected sensor



When you are satisfied with all the values, click Download.

Default values can be selected by using The Default button.

### **7.2.9 Setup Printer**

This option provides a standard Windows® procedure which enables you to edit the settings for the current printer or change to another printer.

If you are unsure how to use these settings, refer to your Windows® Help.

## 8.0 Technical specifications

---

The illustration below shows the setup that forms the basis for the technical specifications.




Fig. 13

Pos.	Description
①	Calibrator
②	Ø4.2 mm insertion tube
③	Ø4 mm Pt 100 sensor with traceable certificate
④	DTI 1000 reference precision thermometer with traceable certificate

## TECHNICAL SPECIFICATIONS – ALL MODELS

*All specifications are given with an ambient temperature of 23°C/73.4°F ± 3°C/5.4°F*

### GENERAL SPECIFICATIONS

#### MECHANICAL SPECIFICATIONS

Dimensions l × w × h	352 × 156 × 360 mm	(13.9 x 6.1 x 14.2 inch)
Weight	ATC-155 A:	12.3 kg / 27.1 lb
	ATC-155 B:	12.4 kg / 27.3 lb
	ATC-156 A:	12.1 kg / 26.7 lb
	ATC-156 B:	12.2 kg / 26.9 lb
	ATC-157 A:	13.0 kg / 28.7 lb
	ATC-157 B:	13.1 kg / 28.9 lb
	ATC-320 A:	10.1 kg / 22.3 lb
	ATC-320 B:	10.2 kg / 22.5 lb
	ATC-650 A:	12.0 kg / 26.5 lb
	ATC-650 B:	12.1 kg / 26.7 lb
Bore diameter/depth of well	ATC-155 / 156 A/B:	ø 30 mm / 150 mm ø 1.18 inch / 5.91 inch
	ATC-157 A/B:	ø 20 mm / 150 mm ø 0.79 inch / 5.91 inch
	ATC-320 / 650 A/B:	ø 30 mm / 160 mm ø 1.18 inch / 6.3 inch

## MECHANICAL SPECIFICATIONS

Weight non-drilled insert	ATC-155 / 156 A/B:	290 g / 9 oz
	ATC-157 A/B:	130 g / 4.6 oz
	ATC-320 / 650 A/B:	940 g / 33.2 oz

## POWER SUPPLY

Line voltage/frequency	ATC-155 / 156 / 157 / 320 A/B:	90-127VAC / 180-254VAC 45-65 Hz
	ATC-650 A/B:	100-127VAC / 200-254VAC 45-65 Hz
Power consumption	ATC-155 A/B:	200 VA
	ATC-156 A/B:	300 VA
	ATC-157 A/B:	300 VA
	ATC-320 / 650 A/B:	1150 VA

## RS232 COMMUNICATION INTERFACE

Type of connection	9 pole D-sub male
--------------------	-------------------

## OTHER CONNECTIONS

Synchronisation relay output	3,5 mm mini jack.
------------------------------	-------------------

## ENVIRONMENT

Ambient operating temperature range	0-40°C / 32-104°F
Storage temperature range	-20-50°C / -4-122°F
Humidity range	0-90% RH.
Protection class	IP10

## READOUT SPECIFICATIONS

Resolution	0.01°C / 0.01°F / 0.01 K
Temperature units	°C / °F / K

## THERMAL SPECIFICATIONS

### ATC-155 A/B

---

Maximum temperature	155°C / 311°F
Minimum temperature	-40°C / -40°F @ ambient temperature 0°C / 32°F
	-24°C / -11.2°F @ ambient temperature 23°C / 73.4°F
	-12°C / -10.4°F @ ambient temperature 40°C / 104°F

## THERMAL SPECIFICATIONS

### Well specifications

## ATC-155 A/B

---

40 mm / 1.57 inch axial homogeneity :

0.05°C / 0.09°F @155°C / 311°F

0.05°C / 0.09°F @-15°C / 5°F

50 mm / 1.97 inch axial homogeneity :

0.10°C / 0.18°F @155°C / 311°F

0.10°C / 0.18°F @-15°C / 5°F

60 mm / 2.36 inch axial homogeneity :

0.20°C / 0.36°F @155°C / 311°F

0.20°C / 0.36°F @-15°C / 5°F

70 mm / 2.76 inch axial homogeneity :

0.35°C / 0.63°F @155°C / 311°F

0.30°C / 0.54°F @-15°C / 5°F

80 mm / 3.15 inch axial homogeneity :

0.50°C / 0.90°F @155°C / 311°F

0.50°C / 0.90°F @-15°C / 5°F

Difference between borings :

0.02°C / 0.04°F

Influence from load :

0.26°C / 0.47°F @155°C / 311°F

0.13°C / 0.23°F @-20°C / -4°F

Influence from load with

Ext. Reference :

0.01°C / 0.02°F @155°C / 311°F

0.01°C / 0.02°F @-20°C / -4°F

Long term drift (1 year) :

±0.05°C / ±0.09°F

Calibration accuracy (test limit)

±0.08°C / ±0.14°F

Temperature coefficient

5ppm/°C (0-40°C) / (32-104°F)

Stability

±0.02°C / ±0.04°F

Reference accuracy

±0.10°C / ±0.18°F

Total accuracy

±0.19°C / ±0.34°F



**THERMAL SPECIFICATIONS**

Heating time incl. insert

Time to stability

Cooling time incl. insert

**ATC-155 A/B**

---

-24°C / -11.2°F to 23°C / 73.4°F :	4 min.
23°C / 73.4°F to 100°C / 212°F:	10 min.
100°C / 212°F to 155°C / 311°F:	13 min.
23°C / 73.4°F to 155°C / 311°F :	23 min.
-24°C / -11.2°F to 155°C / 311°F :	27 min.
10 min.	
155°C / 311°F to 100°C / 212°F :	3 min.
100°C / 212°F to 23°C / 73.4°F:	10 min.
155°C / 311°F to 23°C / 73.4°F :	13 min.
23°C / 73.4°F to 0°C / 32°F:	7 min.
0°C / 32°F to -20°C / -4°F:	15 min.
23°C / 73.4°F to -24°C / -11.2°F :	37 min.
155°C / 311°F to -24°C / -11.2°F :	50 min.

**THERMAL SPECIFICATIONS**

Maximum temperature

Minimum temperature

**ATC-156 A/B**

---

155°C / 311°F
-40°C / -40°F @ ambient temperature 0°C / 32°F
-24°C / -11.2°F @ ambient temperature 23°C / 73.4°F
-12°C / -10.4°F @ ambient temperature 40°C / 104°F

## THERMAL SPECIFICATIONS

Well specifications

## ATC-156 A/B

---

40 mm / 1.57 inch axial homogeneity :

0.05°C / 0.09°F @155°C / 311°F

0.05°C / 0.09°F @-24°C / -11.2°F

50 mm / 1.97 inch axial homogeneity :

0.10°C / 0.18°F @155°C / 311°F

0.10°C / 0.18°F @-24°C / -11.2°F

60 mm / 2.36 inch axial homogeneity :

0.15°C / 0.27°F @155°C / 311°F

0.15°C / 0.27°F @-24°C / -11.2°F

70 mm / 2.76 inch axial homogeneity :

0.25°C / 0.45°F @155°C / 311°F

0.25°C / 0.45°F @-24°C / -11.2°F

80 mm / 3.15 inch axial homogeneity :

0.40°C / 0.72°F @155°C / 311°F

0.40°C / 0.72°F @-24°C / -11.2°F

Difference between borings :

0.02°C / 0.04°F

Influence from load :

0.10°C / 0.18°F @155°C / 311°F

0.10°C / 0.18°F @-24°C / -11.2°F

Influence from load with

Ext. Reference :

0.01°C / 0.02°F @155°C / 311°F

0.01°C / 0.02°F @-24°C / -11.2°F

Long term drift (1 year) :

±0.05°C / ±0.09°F

Calibration accuracy (test limit)

±0.08°C / ±0.14°F

Temperature coefficient

5ppm/°C (0-40°C) / (32-104°F)

Stability

±0.02°C / ±0.04°F

Reference accuracy

±0.10°C / ±0.18°F

Total accuracy

±0.19°C / ±0.34°F

## THERMAL SPECIFICATIONS

Heating time incl. insert

Time to stability

Cooling time incl. insert

### ATC-156 A/B

---

-24°C / -11.2°F to 23°C / 73.4°F :	4 min.
23°C / 73.4°F to 100°C / 212°F:	9 min.
23°C / 73.4°F to 155°C / 311°F :	19 min.
100°C / 212°F to 155°C / 311°F:	10 min.
-24°C / -11.2°F to 155°C / 311°F :	23 min.
10 min.	
155°C / 311°F to 100°C / 212°F:	4 min.
155°C / 311°F to 23°C / 73.4°F :	13 min.
100°C / 212°F to 23°C / 73.4°F:	9 min.
23°C / 73.4°F to 0°C / 32°F:	6 min.
23°C / 73.4°F to -24°C / -11.2°F :	29 min.
0°C / 32°F to -20°C / -4°F:	13 min.
155°C / 311°F to -24°C / -11.2°F :	42 min.

## THERMAL SPECIFICATIONS

Maximum temperature

Minimum temperature

### ATC-157 A/B

---

155°C / 311°F
-57°C / -70.6°F @ ambient temperature 0°C / 32°F
-45°C / -49°F @ ambient temperature 23°C / 73.4°F
-31°C / -23.8°F @ ambient temperature 40°C / 104°F

## THERMAL SPECIFICATIONS

### Well specifications

## ATC-157 A/B

---

40 mm / 1.57 inch axial homogeneity :

0.05°C / 0.09°F @155°C / 311°F

0.05°C / 0.09°F @-45°C / -49°F

50 mm / 1.97 inch axial homogeneity :

0.10°C / 0.18°F @155°C / 311°F

0.15°C / 0.27°F @-45°C / -49°F

60 mm / 2.36 inch axial homogeneity :

0.15°C / 0.27°F @155°C / 311°F

0.20°C / 0.36°F @-45°C / -49°F

70 mm / 2.76 inch axial homogeneity :

0.20°C / 0.36°F @155°C / 311°F

0.35°C / 0.63°F @-45°C / -49°F

80 mm / 3.15 inch axial homogeneity :

0.30°C / 0.54°F @155°C / 311°F

0.55°C / 0.99°F @-45°C / -49°F

Difference between borings :

0.02°C / 0.04°F

Influence from load :

0.10°C / 0.18°F @155°C / 311°F

0.12°C / 0.18°F @-45°C / -49°F

Influence from load with

Ext. Reference :

0.01°C / 0.02°F @155°C / 311°F

0.01°C / 0.02°F @-45°C / -49°F

Long term drift (1 year) :

±0.05°C / ±0.09°F

Calibration accuracy (test limit)

±0.08°C / ±0.14°F

Temperature coefficient

5ppm/°C (0-40°C) / (32-104°F)

Stability

±0.02°C / ±0.04°F

Reference accuracy

±0.10°C / ±0.18°F

Total accuracy

±0.19°C / ±0.34°F

**THERMAL SPECIFICATIONS**

Heating time incl. insert

Time to stability

Cooling time incl. insert

**ATC-157 A/B**

---

-45°C / -49°F to 23°C / 73.4°F :	6 min.
23°C / 73.4°F to 100°C / 212°F:	8 min.
100°C / 212°F to 155°C / 311°F:	9 min.
23°C / 73.4°F to 155°C / 311°F :	17 min.
-45°C / -49°F to 155°C / 311°F :	23 min.
10 min.	
155°C / 311°F to 100°C / 212°F:	3 min.
155°C / 311°F to 23°C / 73.4°F :	9 min.
100°C / 212°C to 23°C / 73.4°F:	6 min.
23°C / 73.4°F to 0°C / 32°F:	3 min.
23°C / 73.4°F to -30°C / -22°F :	12 min.
0°C / 32°F to -30°C / -22°F:	9 min.
155° / 311°F to -30°C / -22°F :	21 min.
-30°C / -22°F to -45°C / -49°F:	15 min.

**THERMAL SPECIFICATIONS**

Maximum temperature

Minimum temperature

**ATC-320 A/B**

---

320°C / 608°F
10°C / 50°F @ ambient temperature 0°C / 32°F
33°C / 91°F @ ambient temperature 23°C / 73.4°F
50°C / 122°F @ ambient temperature 40°C / 104°F

## THERMAL SPECIFICATIONS

### Well specifications

## ATC-320 A/B

---

40 mm / 1.57 inch axial homogeneity :

0.20°C / 0.36°F @320°C / 608°F

0.10°C / 0.18°F @155°C / 311°F

0.05°C / 0.09°F @50°C / 122°F

50 mm / 1.97 inch axial homogeneity :

0.20°C / 0.36°F @320°C / 608°F

0.10°C / 0.18°F @155°C / 311°F

0.05°C / 0.09°F @50°C / 122°F

60 mm / 2.36 inch axial homogeneity :

0.25°C / 0.45°F @320°C / 608°F

0.15°C / 0.27°F @155°C / 311°F

0.05°C / 0.09°F @50°C / 122°F

70 mm / 2.76 inch axial homogeneity :

0.40°C / 0.75°F @320°C / 608°F

0.20°C / 0.36°F @155°C / 311°F

0.05°C / 0.09°F @50°C / 122°F

80 mm / 3.15 inch axial homogeneity :

0.60°C / 1.08°F @320°C / 608°F

0.30°C / 0.54°F @155°C / 311°F

0.10°C / 0.18°F @50°C / 122°F

Difference between borings :

0.01°C / 0.02°F

Influence from load :

0.15°C / 0.27°F @320°C / 608°F

Influence from load with

Ext. Reference :

0.03°C / 0.05°F @320°C / 608°F

Long term drift (1 year) :

±0.05°C / ±0.09°F

**THERMAL SPECIFICATIONS**

Calibration accuracy (test limit)

Temperature coefficient

Stability

Reference accuracy

Total accuracy

Heating time incl. insert

Time to stability

Cooling time incl. insert

**ATC-320 A/B**

---

 $\pm 0.10^{\circ}\text{C} / \pm 0.18^{\circ}\text{F}$ 5ppm/ $^{\circ}\text{C}$  (0-40 $^{\circ}\text{C}$ ) (32-104 $^{\circ}\text{F}$ ) $\pm 0.02^{\circ}\text{C} / \pm 0.04^{\circ}\text{F}$  $\pm 0.10^{\circ}\text{C} / \pm 0.18^{\circ}\text{F}$  $\pm 0.26^{\circ}\text{C} / \pm 0.47^{\circ}\text{F}$ 50 $^{\circ}\text{C}$  / 122 $^{\circ}\text{F}$  to 320 $^{\circ}\text{C}$  / 608 $^{\circ}\text{F}$  : 7 min.

10 min.

320 $^{\circ}\text{C}$  / 608 $^{\circ}\text{F}$  to 100 $^{\circ}\text{C}$  / 212 $^{\circ}\text{F}$  : 22 min.320 $^{\circ}\text{C}$  / 608 $^{\circ}\text{F}$  to 50 $^{\circ}\text{C}$  / 122 $^{\circ}\text{F}$  : 42 min.**THERMAL SPECIFICATIONS**

Maximum temperature

Minimum temperature

**ATC-650 A/B**

---

650 $^{\circ}\text{C}$  / 1202 $^{\circ}\text{F}$ 10 $^{\circ}\text{C}$  / 50 $^{\circ}\text{F}$  @ ambient temperature 0 $^{\circ}\text{C}$  / 32 $^{\circ}\text{F}$ 33 $^{\circ}\text{C}$  / 91 $^{\circ}\text{F}$  @ ambient temperature 23 $^{\circ}\text{C}$  / 73.4 $^{\circ}\text{F}$ 50 $^{\circ}\text{C}$  / 122 $^{\circ}\text{F}$  @ ambient temperature 40 $^{\circ}\text{C}$  / 104 $^{\circ}\text{F}$

## THERMAL SPECIFICATIONS

### Well specifications

## ATC-650 A/B

---

40 mm / 1.57 inch axial homogeneity :

0.40°C / 0.72°F @650°C / 1202°F

0.30°C / 0.54°F @320°C / 608°F

0.10°C / 0.18°F @50°C / 122°F

50 mm / 1.97 inch axial homogeneity :

0.65°C / 1.17°F @650°C / 1202°F

0.40°C / 0.72°F @320°C / 608°F

0.10°C / 0.18°F @50°C / 122°F

60 mm / 2.36 inch axial homogeneity :

1.00°C / 1.80°F @650°C / 1202°F

0.60°C / 1.08°F @320°C / 608°F

0.10°C / 0.18°F @50°C / 122°F

70 mm / 2.76 inch axial homogeneity :

1.40°C / 2.52°F @650°C / 1202°F

0.80°C / 1.44°F @320°C / 608°F

0.15°C / 0.27°F @50°C / 122°F

80 mm / 3.15 inch axial homogeneity :

2.00°C / 3.60°F @650°C / 1202°F

1.10°C / 1.98°F @320°C / 608°F

0.20°C / 0.36°F @50°C / 122°F

Difference between borings :

0.05°C / 0.09°F

Influence from load :

0.15°C / 0.27°F @650°C / 1202°F

Influence from load with

Ext. Reference :

0.10°C / 0.18°F @650°C / 1202°F

Long term drift (1 year) :

±0.15°C / ±0.27°F



## THERMAL SPECIFICATIONS

## ATC-650 A/B

Calibration accuracy (test limit)	$\pm 0.10^{\circ}\text{C}$ / $\pm 0.18^{\circ}\text{F}$
Temperature coefficient	5ppm/ $^{\circ}\text{C}$ (0-40 $^{\circ}\text{C}$ ) (32-104 $^{\circ}\text{F}$ )
Stability	$\pm 0.03^{\circ}\text{C}$ / $\pm 0.05^{\circ}\text{F}$
Reference accuracy	$\pm 0.10^{\circ}\text{C}$ / $\pm 0.18^{\circ}\text{F}$
Total accuracy	$\pm 0.39^{\circ}\text{C}$ / $\pm 0.70^{\circ}\text{F}$
Heating time incl. insert	50 $^{\circ}\text{C}$ / 122 $^{\circ}\text{F}$ to 650 $^{\circ}\text{C}$ / 1202 $^{\circ}\text{F}$ : 27 min.
Time to stability	10 min.
Cooling time incl. insert	650 $^{\circ}\text{C}$ / 1202 $^{\circ}\text{F}$ to 100 $^{\circ}\text{C}$ / 212 $^{\circ}\text{F}$ : 43 min. 650 $^{\circ}\text{C}$ / 1202 $^{\circ}\text{F}$ to 50 $^{\circ}\text{C}$ / 122 $^{\circ}\text{F}$ : 68 min.

## STANDARDS

**The following standards are observed according to the EMC-directive (89/336)**

EN61326:1997/A1:1998 : Electrical equipment for measurement, control and laboratory use – EMC requirements

**The following standards are observed according to the low voltage-directive (73/23)**

EN61010-1:1993/A2:1995 : Safety requirements for electrical equipment for measurement, control and laboratory use, part 1: general requirement

## TECHNICAL SPECIFICATIONS – B MODELS ONLY

## INPUT SPECIFICATIONS

### mA input

Signal range	0 – 24 mA
Internal power supply	24 V, max. 28 mA
Resolution	0.001mA / 0.01 $^{\circ}\text{C}$ / 0.01 $^{\circ}\text{F}$
Accuracy	$\pm(0.010\%$ of rdg. + 0.015% of F.S.)
Temperature coefficient	7 ppm/ $^{\circ}\text{C}$ (0-40 $^{\circ}\text{C}$ ) (32-104 $^{\circ}\text{F}$ )
Input impedance	< 10 $\Omega$
Type of connection	4 mm safety sockets

## INPUT SPECIFICATIONS

---

### Voltage input

Signal range	0 – 12 V
Resolution	0.001V / 0.01°C / 0.01°F
Accuracy	±(0.005% of rdg. + 0.015% of F.S.)
Temperature coefficient	5 ppm/°C (0-40°C) (32-104°F)
Input impedance	> 1 MΩ
Type of connection	4 mm safety sockets

### Thermocouple input

Signal range	-78mV – 78 mV
Resolution	0.001mV / 0.01°C / 0.01°F
Accuracy	±(0.010% of rdg. + 0.005% of F.S.), see page 85-86 for accuracy in °C/°F
Temperature coefficient	5 ppm/°C (0-40°C) (32-104°F)
Input impedance	> 1 MΩ
Type of connection	Mini TC-connector

### RTD-input (2-, 3- or 4-wire)

Signal range	0-350 Ω (Pt10/Pt50/Pt100) 0-2900 Ω (Pt500/Pt1000)
Internal power supply	Excitation current 0,4 mA
Resolution	0.001Ω / 0.01°C / 0.01°F (Pt10/Pt50/Pt100), see page 87 for accuracy in °C/°F 0.01Ω / 0.01°C / 0.01°F (Pt500/Pt1000), see page 87 for accuracy in °C/°F
Accuracy (3- or 4-wire)	±(0.005% of rdg. + 0.005% of F.S.)
Accuracy (2-wire)	±(0.005% of rdg. + 0.005% of F.S. + 50mΩ)
Temperature coefficient	5 ppm/°C (0-40°C) (32-104°F)
Type of connection	4 mm safety sockets

### Switch test input

Signal range	on : 0-10kΩ / off : >100kΩ
Internal power supply	5 V (open)
Type of connection	4 mm safety sockets

## INPUT SPECIFICATIONS

---

### Reference input

Signal range	$0\Omega - 350\Omega$
Internal power supply	Measuring current 0.8 mA
Resolution	$0.001\Omega / 0.01^{\circ}\text{C} / 0.01^{\circ}\text{F}$
Accuracy	$\pm(0.003\% \text{ of rdg.} + 0.002\% \text{ of F.S.})$ , see page 88 for accuracy in $^{\circ}\text{C}/^{\circ}\text{F}$
Temperature coefficient	$5 \text{ ppm}/^{\circ}\text{C} (0\text{-}40^{\circ}\text{C}) (32\text{-}104^{\circ}\text{F})$
Type of connection	LEMO-connector

**INPUT SPECIFICATIONS****ACCURACY IN °C/°F**

---

Accuracy thermocouple type E input (excluding sensor accuracy)	$\pm 0.08^{\circ}\text{C}(\pm 0.14^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ $\pm 0.07^{\circ}\text{C}(\pm 0.12^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$ $\pm 0.07^{\circ}\text{C}(\pm 0.12^{\circ}\text{F}) @ 155^{\circ}\text{C}(311^{\circ}\text{F})$ $\pm 0.08^{\circ}\text{C}(\pm 0.14^{\circ}\text{F}) @ 320^{\circ}\text{C}(592^{\circ}\text{F})$ $\pm 0.11^{\circ}\text{C}(\pm 0.20^{\circ}\text{F}) @ 650^{\circ}\text{C}(1202^{\circ}\text{F})$ $\pm 0.15^{\circ}\text{C}(\pm 0.28^{\circ}\text{F}) @ 1000^{\circ}\text{C}(1832^{\circ}\text{F})$
Accuracy thermocouple type J input (excluding sensor accuracy)	$\pm 0.10^{\circ}\text{C}(\pm 0.17^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ $\pm 0.08^{\circ}\text{C}(\pm 0.14^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$ $\pm 0.08^{\circ}\text{C}(\pm 0.15^{\circ}\text{F}) @ 155^{\circ}\text{C}(311^{\circ}\text{F})$ $\pm 0.10^{\circ}\text{C}(\pm 0.17^{\circ}\text{F}) @ 320^{\circ}\text{C}(592^{\circ}\text{F})$ $\pm 0.12^{\circ}\text{C}(\pm 0.22^{\circ}\text{F}) @ 650^{\circ}\text{C}(1202^{\circ}\text{F})$ $\pm 0.19^{\circ}\text{C}(\pm 0.34^{\circ}\text{F}) @ 1200^{\circ}\text{C}(2192^{\circ}\text{F})$
Accuracy thermocouple type K input (excluding sensor accuracy)	$\pm 0.11^{\circ}\text{C}(\pm 0.20^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ $\pm 0.10^{\circ}\text{C}(\pm 0.17^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$ $\pm 0.11^{\circ}\text{C}(\pm 0.20^{\circ}\text{F}) @ 155^{\circ}\text{C}(311^{\circ}\text{F})$ $\pm 0.12^{\circ}\text{C}(\pm 0.22^{\circ}\text{F}) @ 320^{\circ}\text{C}(592^{\circ}\text{F})$ $\pm 0.16^{\circ}\text{C}(\pm 0.28^{\circ}\text{F}) @ 650^{\circ}\text{C}(1202^{\circ}\text{F})$ $\pm 0.28^{\circ}\text{C}(\pm 0.50^{\circ}\text{F}) @ 1372^{\circ}\text{C}(2502^{\circ}\text{F})$
Accuracy thermocouple type T input (excluding sensor accuracy)	$\pm 0.12^{\circ}\text{C}(\pm 0.22^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ $\pm 0.10^{\circ}\text{C}(\pm 0.18^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$ $\pm 0.09^{\circ}\text{C}(\pm 0.16^{\circ}\text{F}) @ 155^{\circ}\text{C}(311^{\circ}\text{F})$ $\pm 0.09^{\circ}\text{C}(\pm 0.17^{\circ}\text{F}) @ 320^{\circ}\text{C}(592^{\circ}\text{F})$ $\pm 0.10^{\circ}\text{C}(\pm 0.17^{\circ}\text{F}) @ 400^{\circ}\text{C}(752^{\circ}\text{F})$
Accuracy thermocouple type R input (excluding sensor accuracy)	$\pm 1.31^{\circ}\text{C}(\pm 2.35^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ $\pm 0.78^{\circ}\text{C}(\pm 1.40^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$ $\pm 0.50^{\circ}\text{C}(\pm 0.90^{\circ}\text{F}) @ 155^{\circ}\text{C}(311^{\circ}\text{F})$ $\pm 0.42^{\circ}\text{C}(\pm 0.75^{\circ}\text{F}) @ 320^{\circ}\text{C}(592^{\circ}\text{F})$ $\pm 0.41^{\circ}\text{C}(\pm 0.74^{\circ}\text{F}) @ 650^{\circ}\text{C}(1202^{\circ}\text{F})$ $\pm 0.50^{\circ}\text{C}(\pm 0.90^{\circ}\text{F}) @ 1760^{\circ}\text{C}(3200^{\circ}\text{F})$

**INPUT SPECIFICATIONS****ACCURACY IN °C/°F**

Accuracy thermocouple type S input  
(excluding sensor accuracy)

$\pm 0.98^{\circ}\text{C}(\pm 1.77^{\circ}\text{F})$  @  $-50^{\circ}\text{C}(-58^{\circ}\text{F})$   
 $\pm 0.78^{\circ}\text{C}(\pm 1.40^{\circ}\text{F})$  @  $0^{\circ}\text{C}(32^{\circ}\text{F})$   
 $\pm 0.50^{\circ}\text{C}(\pm 0.90^{\circ}\text{F})$  @  $155^{\circ}\text{C}(311^{\circ}\text{F})$   
 $\pm 0.46^{\circ}\text{C}(\pm 0.83^{\circ}\text{F})$  @  $320^{\circ}\text{C}(592^{\circ}\text{F})$   
 $\pm 0.45^{\circ}\text{C}(\pm 0.81^{\circ}\text{F})$  @  $650^{\circ}\text{C}(1202^{\circ}\text{F})$   
 $\pm 0.52^{\circ}\text{C}(\pm 0.94^{\circ}\text{F})$  @  $1768^{\circ}\text{C}(3214^{\circ}\text{F})$

Accuracy thermocouple type B  
(excluding sensor accuracy)

$\pm 1.57^{\circ}\text{C}(\pm 2.83^{\circ}\text{F})$  @  $250^{\circ}\text{C}(482^{\circ}\text{F})$   
 $\pm 0.99^{\circ}\text{C}(\pm 1.78^{\circ}\text{F})$  @  $320^{\circ}\text{C}(592^{\circ}\text{F})$   
 $\pm 0.69^{\circ}\text{C}(\pm 1.23^{\circ}\text{F})$  @  $650^{\circ}\text{C}(1202^{\circ}\text{F})$   
 $\pm 0.48^{\circ}\text{C}(\pm 0.86^{\circ}\text{F})$  @  $1820^{\circ}\text{C}(3308^{\circ}\text{F})$

Accuracy thermocouple type N  
(excluding sensor accuracy)

$\pm 0.16^{\circ}\text{C}(\pm 0.29^{\circ}\text{F})$  @  $-50^{\circ}\text{C}(-58^{\circ}\text{F})$   
 $\pm 0.15^{\circ}\text{C}(\pm 0.27^{\circ}\text{F})$  @  $0^{\circ}\text{C}(32^{\circ}\text{F})$   
 $\pm 0.14^{\circ}\text{C}(\pm 0.24^{\circ}\text{F})$  @  $155^{\circ}\text{C}(311^{\circ}\text{F})$   
 $\pm 0.14^{\circ}\text{C}(\pm 0.25^{\circ}\text{F})$  @  $320^{\circ}\text{C}(592^{\circ}\text{F})$   
 $\pm 0.16^{\circ}\text{C}(\pm 0.28^{\circ}\text{F})$  @  $650^{\circ}\text{C}(1202^{\circ}\text{F})$   
 $\pm 0.17^{\circ}\text{C}(\pm 0.31^{\circ}\text{F})$  @  $800^{\circ}\text{C}(1472^{\circ}\text{F})$

Accuracy thermocouple type XK  
(excluding sensor accuracy)

$\pm 0.07^{\circ}\text{C}(\pm 0.13^{\circ}\text{F})$  @  $-50^{\circ}\text{C}(-58^{\circ}\text{F})$   
 $\pm 0.06^{\circ}\text{C}(\pm 0.11^{\circ}\text{F})$  @  $0^{\circ}\text{C}(32^{\circ}\text{F})$   
 $\pm 0.06^{\circ}\text{C}(\pm 0.12^{\circ}\text{F})$  @  $155^{\circ}\text{C}(311^{\circ}\text{F})$   
 $\pm 0.07^{\circ}\text{C}(\pm 0.13^{\circ}\text{F})$  @  $320^{\circ}\text{C}(592^{\circ}\text{F})$   
 $\pm 0.11^{\circ}\text{C}(\pm 0.19^{\circ}\text{F})$  @  $650^{\circ}\text{C}(1202^{\circ}\text{F})$   
 $\pm 0.12^{\circ}\text{C}(\pm 0.22^{\circ}\text{F})$  @  $800^{\circ}\text{C}(1472^{\circ}\text{F})$

Accuracy thermocouple type U  
(excluding sensor accuracy)

$\pm 0.12^{\circ}\text{C}(\pm 0.21^{\circ}\text{F})$  @  $-50^{\circ}\text{C}(-58^{\circ}\text{F})$   
 $\pm 0.10^{\circ}\text{C}(\pm 0.18^{\circ}\text{F})$  @  $0^{\circ}\text{C}(32^{\circ}\text{F})$   
 $\pm 0.09^{\circ}\text{C}(\pm 0.17^{\circ}\text{F})$  @  $155^{\circ}\text{C}(311^{\circ}\text{F})$   
 $\pm 0.09^{\circ}\text{C}(\pm 0.17^{\circ}\text{F})$  @  $320^{\circ}\text{C}(592^{\circ}\text{F})$   
 $\pm 0.10^{\circ}\text{C}(\pm 0.19^{\circ}\text{F})$  @  $600^{\circ}\text{C}(1112^{\circ}\text{F})$

Accuracy automatic cold junction  
compensation

$\pm 0.40^{\circ}\text{C}(\pm 0.72^{\circ}\text{F})$  @ ambient temperature  $0^{\circ}\text{C}$   
to  $40^{\circ}\text{C}$ .

**INPUT SPECIFICATIONS****ACCURACY IN °C/°F**

---

Accuracy RTD Pt1000	$\pm 0.046^{\circ}\text{C}(\pm 0.083^{\circ}\text{F})$ @ $-50^{\circ}\text{C}(-58^{\circ}\text{F})$
(excluding sensor accuracy)	$\pm 0.050^{\circ}\text{C}(\pm 0.090^{\circ}\text{F})$ @ $0^{\circ}\text{C}(32^{\circ}\text{F})$
	$\pm 0.061^{\circ}\text{C}(\pm 0.110^{\circ}\text{F})$ @ $155^{\circ}\text{C}(311^{\circ}\text{F})$
	$\pm 0.071^{\circ}\text{C}(\pm 0.127^{\circ}\text{F})$ @ $320^{\circ}\text{C}(592^{\circ}\text{F})$
	$\pm 0.087^{\circ}\text{C}(\pm 0.156^{\circ}\text{F})$ @ $500^{\circ}\text{C}(932^{\circ}\text{F})$
Accuracy RTD Pt500	$\pm 0.083^{\circ}\text{C}(\pm 0.149^{\circ}\text{F})$ @ $-50^{\circ}\text{C}(-58^{\circ}\text{F})$
(excluding sensor accuracy)	$\pm 0.087^{\circ}\text{C}(\pm 0.157^{\circ}\text{F})$ @ $0^{\circ}\text{C}(32^{\circ}\text{F})$
	$\pm 0.100^{\circ}\text{C}(\pm 0.180^{\circ}\text{F})$ @ $155^{\circ}\text{C}(311^{\circ}\text{F})$
	$\pm 0.111^{\circ}\text{C}(\pm 0.200^{\circ}\text{F})$ @ $320^{\circ}\text{C}(592^{\circ}\text{F})$
	$\pm 0.130^{\circ}\text{C}(\pm 0.235^{\circ}\text{F})$ @ $500^{\circ}\text{C}(932^{\circ}\text{F})$
Accuracy RTD Pt100	$\pm 0.054^{\circ}\text{C}(\pm 0.097^{\circ}\text{F})$ @ $-50^{\circ}\text{C}(-58^{\circ}\text{F})$
(excluding sensor accuracy)	$\pm 0.058^{\circ}\text{C}(\pm 0.104^{\circ}\text{F})$ @ $0^{\circ}\text{C}(32^{\circ}\text{F})$
	$\pm 0.069^{\circ}\text{C}(\pm 0.124^{\circ}\text{F})$ @ $155^{\circ}\text{C}(311^{\circ}\text{F})$
	$\pm 0.079^{\circ}\text{C}(\pm 0.142^{\circ}\text{F})$ @ $320^{\circ}\text{C}(592^{\circ}\text{F})$
	$\pm 0.106^{\circ}\text{C}(\pm 0.191^{\circ}\text{F})$ @ $650^{\circ}\text{C}(1202^{\circ}\text{F})$
	$\pm 0.112^{\circ}\text{C}(\pm 0.202^{\circ}\text{F})$ @ $700^{\circ}\text{C}(1292^{\circ}\text{F})$
Accuracy RTD Pt50	$\pm 0.098^{\circ}\text{C}(\pm 0.176^{\circ}\text{F})$ @ $-50^{\circ}\text{C}(-58^{\circ}\text{F})$
(excluding sensor accuracy)	$\pm 0.103^{\circ}\text{C}(\pm 0.185^{\circ}\text{F})$ @ $0^{\circ}\text{C}(32^{\circ}\text{F})$
	$\pm 0.116^{\circ}\text{C}(\pm 0.209^{\circ}\text{F})$ @ $155^{\circ}\text{C}(311^{\circ}\text{F})$
	$\pm 0.128^{\circ}\text{C}(\pm 0.230^{\circ}\text{F})$ @ $320^{\circ}\text{C}(592^{\circ}\text{F})$
	$\pm 0.161^{\circ}\text{C}(\pm 0.290^{\circ}\text{F})$ @ $650^{\circ}\text{C}(1202^{\circ}\text{F})$
	$\pm 0.169^{\circ}\text{C}(\pm 0.303^{\circ}\text{F})$ @ $700^{\circ}\text{C}(1292^{\circ}\text{F})$
Accuracy RTD Pt10	$\pm 0.453^{\circ}\text{C}(\pm 0.815^{\circ}\text{F})$ @ $-50^{\circ}\text{C}(-58^{\circ}\text{F})$
(excluding sensor accuracy)	$\pm 0.462^{\circ}\text{C}(\pm 0.831^{\circ}\text{F})$ @ $0^{\circ}\text{C}(32^{\circ}\text{F})$
	$\pm 0.495^{\circ}\text{C}(\pm 0.891^{\circ}\text{F})$ @ $155^{\circ}\text{C}(311^{\circ}\text{F})$
	$\pm 0.524^{\circ}\text{C}(\pm 0.943^{\circ}\text{F})$ @ $320^{\circ}\text{C}(592^{\circ}\text{F})$
	$\pm 0.610^{\circ}\text{C}(\pm 1.098^{\circ}\text{F})$ @ $650^{\circ}\text{C}(1202^{\circ}\text{F})$
	$\pm 0.620^{\circ}\text{C}(\pm 1.116^{\circ}\text{F})$ @ $700^{\circ}\text{C}(1292^{\circ}\text{F})$
Accuracy RTD Cu100	$\pm 0.050^{\circ}\text{C}(\pm 0.090^{\circ}\text{F})$ @ $-50^{\circ}\text{C}(-58^{\circ}\text{F})$
(excluding sensor accuracy)	$\pm 0.052^{\circ}\text{C}(\pm 0.094^{\circ}\text{F})$ @ $0^{\circ}\text{C}(32^{\circ}\text{F})$
	$\pm 0.060^{\circ}\text{C}(\pm 0.108^{\circ}\text{F})$ @ $150^{\circ}\text{C}(302^{\circ}\text{F})$

**INPUT SPECIFICATIONS****ACCURACY IN °C/°F**

---

Accuracy RTD Cu50

 $\pm 0.090^{\circ}\text{C}(\pm 0.162^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ 

(excluding sensor accuracy)

 $\pm 0.093^{\circ}\text{C}(\pm 0.167^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$  $\pm 0.100^{\circ}\text{C}(\pm 0.180^{\circ}\text{F}) @ 150^{\circ}\text{C}(302^{\circ}\text{F})$ 

Accuracy Pt100 reference input

 $\pm 0.024^{\circ}\text{C}(\pm 0.042^{\circ}\text{F}) @ -50^{\circ}\text{C}(-58^{\circ}\text{F})$ 

(excluding sensor accuracy)

 $\pm 0.026^{\circ}\text{C}(\pm 0.046^{\circ}\text{F}) @ 0^{\circ}\text{C}(32^{\circ}\text{F})$  $\pm 0.032^{\circ}\text{C}(\pm 0.057^{\circ}\text{F}) @ 155^{\circ}\text{C}(311^{\circ}\text{F})$  $\pm 0.038^{\circ}\text{C}(\pm 0.068^{\circ}\text{F}) @ 320^{\circ}\text{C}(592^{\circ}\text{F})$  $\pm 0.047^{\circ}\text{C}(\pm 0.084^{\circ}\text{F}) @ 650^{\circ}\text{C}(1202^{\circ}\text{F})$  $\pm 0.056^{\circ}\text{C}(\pm 0.101^{\circ}\text{F}) @ 700^{\circ}\text{C}(1292^{\circ}\text{F})$

## 9.0 List of accessories

---

All parts listed in the list of accessories can be obtained from the factory through our dealers.

Please contact your dealer for assistance if you require parts which do not appear on the list.

---

### List of accessories

---

Accessories	Parts no.
Fuse 115V, 10AF (ATC-320/650)	60B302
Fuse 230V, 5AF (ATC-320/650)	60B301
Fuse 115V, 5AT (ATC-155/156/157)	60B315
Fuse 230V, 2.5AT (ATC-155/156/157)	123690
User manual	105447
Reference manual	105446
Tool for insertion tube	60F170
Heat shield	105496
Carrying case	105805
Mains cable, 115V, US, type B	60F135
Mains cable, 240V, UK, type C	60F136
Mains cable, 220V, South Africa, type D	60F137
Mains cable, 220V, Italy, type E	60F138
Mains cable, 240V, Australia, type F	60F139
Mains cable, 230V, Europe, type A	60F140
Mains cable, 230V, Denmark, type G	60F141
Mains cable, 220V, Switzerland, type H	60F142
Mains cable, 230V, Israel, type I	60F143
Thermocouple male plug type K	120517
Thermocouple male plug type N	120514
Thermocouple male plug type T	120515
Thermocouple male plug type Cu-Cu	120519
Extension cable for reference probe, lemo to lemo	122801
Extension cable for external probe, banana to lemo	122823



---

## List of accessories

---

Accessories	Parts no.
Connector, Lemo male for reference input cable (4.3 to 5.1 mm diameter)	60D711 + 60D712
RS – 232 Interface cable	105366
AmeCal Temperature PC software	105813
AmeTrim-ATC PC software	105816
Mini Jack connector	122771
Cleaning brush ø4mm	122832
Cleaning brush ø6mm	60F174
Cleaning brush ø8mm	122822
Insulation plug, kit (ATC-155/156)	105810
Insulation plug, kit (ATC-157)	123374
Calibration accessories kit, BASIC (ATC-155/156)	122833
Calibration accessories kit, BASIC (ATC-157)	123685
Calibration accessories kit, BASIC (ATC-320/650)	122834
Set of test cables	104203
Reference probe, with accredited certificate	STS-100A901AA
Reference probe, no certificate	STS-100A901CA

PARTS NO. FOR STANDARD INSERTION TUBES			
Sensor size	ATC-155/156 A/B (Aluminium tubes)	ATC-157 A/B (Aluminium tubes)	ATC-320/650 A/B (Brass tubes)
Undrilled	122720	123286	122719
Undrilled	122722	123285	122721
with ref.			
1/8"	105677	123279	105676
3/16"	105679	123280	105678
1/4"	105681	123281	105680
5/16"	105683	123282	105682
3/8"	105685	123283	105684
7/16"	105687	123301**	105686
1/2"	105689	123302**	105688
9/16"	105691	-	105690
5/8"	105693	-	105692

PARTS NO. FOR STANDARD INSERTION TUBES			
Sensor size	ATC-155/156 A/B (Aluminium tubes)	ATC-157 A/B (Aluminium tubes)	ATC-320/650 A/B (Brass tubes)
3 mm	105623	123270	105622
4 mm	105625	123271	105624
5 mm	105627	123272	105626
6 mm	105629	123273	105628
7 mm	105631	123274	105630
8 mm	105633	123275	105632
9 mm	105635	123276	105634
10 mm	105637	123277	105636
11 mm	105639	123278	105638
12 mm	105641	123299**	105640
13 mm	105643	123300**	105642
14 mm	105645	-	105644
15 mm	105647	-	105646
16 mm	105649	-	105648

\*\* Inserts are delivered without 4 mm reference hole, but with matching insulation plugs.

PART NO. FOR STANDARD INSERTION TUBES – MULTI-HOLE			
Description (metric)	ATC-155/156 A/B	ATC-157 A/B	ATC-320/650 A/B
Type 1	122751	123294	122750
Type 2	122753	123295	122752
Type 3	122755	123296	122754
Type 4	122757	-	122756

PART NO. FOR STANDARD INSERTION TUBES – MULTI-HOLE			
Description (inch)	ATC-155/156 A/B	ATC-157 A/B	ATC-320/650 A/B
Type 4	-	123297	-
Type 5	122759	123298	122758
Type 6	122761	-	122760

NOTE: All multi-hole insertion tubes (metric and inches) for ATC-155/156/157 are supplied with a matching insulation plug.