

USER MANUAL

PLUS4

CUSTOM[®]

CUSTOM S.p.A.
Str. Berettine 2
43010 Fontevivo (PARMA) - Italy
Tel. : +39 0521-680111
Fax : +39 0521-610701
http: www.custom.biz

Customer Service Department:
Email : support@custom.it

© 2013 CUSTOM S.p.A. – Italy.
All rights reserved. Total or partial reproduction of this manual in whatever form, whether by printed or electronic means, is forbidden. While guaranteeing that the information contained in it has been carefully checked, CUSTOM S.p.A. and other entities utilized in the realization of this manual bear no responsibility for how the manual is used.
Information regarding any errors found in it or suggestions on how it could be improved are appreciated. Since products are subject to continuous check and improvement, CUSTOM S.p.A. reserves the right to make changes in information contained in this manual without prior notification.

The pre-installed multimedia contents are protected from Copyright CUSTOM S.p.A. Other company and product names mentioned herein may be trademarks of their respective companies. Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. CUSTOM S.p.A. assumes no responsibility with regard to the performance or use of these products.

THE IMAGES USED IN THIS MANUAL ARE USED AS AN ILLUSTRATIVE EXAMPLES. THEY COULDN'T REPRODUCE THE DESCRIBED MODEL FAITHFULLY.

UNLESS OTHERWISE SPECIFIED, THE INFORMATION GIVEN IN THIS MANUAL ARE REFERRED TO ALL MODELS IN PRODUCTION AT THE ISSUE DATE OF THIS DOCUMENT.



The format used for this manual improves use of natural resources reducing the quantity of necessary paper to print this copy.

GENERAL SAFETY INFORMATION

Your attention is drawn to the following actions that could compromise the characteristics of the product:

- Read and retain the instructions which follow.
- Follow all indications and instructions given on the device.
- Make sure that the surface on which the device rests is stable. If it is not, the device could fall, seriously damaging it.
- Make sure that the device rests on a hard (non-padded) surface and that there is sufficient ventilation.
- When positioning the device, make sure cables do not get damaged.
- Use the type of electrical power supply indicated on the device label. If uncertain, contact your dealer.
- Make sure the electrical system that supplies power to the device is equipped with a ground wire and is protected by a differential switch.
- Do not block the ventilation openings.
- Do not insert objects inside the device as this could cause short-circuiting or damage components that could jeopardize printer functioning.
- Do not carry out repairs on the device yourself, except for the normal maintenance operations given in the user manual.
- Make sure that there is an easily-accessible outlet with a capacity of no less than 10A closely to where the device is to be installed.
- Periodically perform scheduled maintenance on the device to avoid dirt build-up that could compromise the correct, safe operation of the unit.
- Before any type of work is done on the machine, disconnect the power supply.
- Do not touch the head heating line with bare hands or metal objects. Do not perform any operation inside the printer immediately after printing because the head and motor tend to become very hot.

GENERAL INSTRUCTIONS

CUSTOM S.p.A. declines all responsibility for accidents or damage to persons or property occurring as a result of tampering, structural or functional modifications, unsuitable or incorrect installations, environments not in keeping with the equipment's protection degree or with the required temperature and humidity conditions, failure to carry out maintenance and periodical inspections and poor repair work.



THE CE MARK AFFIXED TO THE PRODUCT CERTIFY THAT THE PRODUCT SATISFIES THE BASIC SAFETY REQUIREMENTS.

The device is in conformity with the essential Electromagnetic Compatibility and Electric Safety requirements laid down in Directives 2006/95/CE and 2004/108/CE inasmuch as it was designed in conformity with the provisions laid down in the following Standards:


- EN 55022 Class B (*Limits and methods of measurements of radio disturbance characteristics of Information Technology Equipment*)
- EN 55024 (*Information Technology Equipment – Immunity characteristics – Limits and methods of measurement*)
- EN 60950-1 (*Safety of information equipment including electrical business equipment*)



GUIDELINES FOR THE DISPOSAL OF THE PRODUCT

The crossed-out rubbish bin logo means that used electrical and electronic products shall NOT be mixed with unsorted municipal waste. For more detailed information about recycling of this product, refer to the instructions of your country for the disposal of these products.

- Do not dispose of this equipment as miscellaneous solid municipal waste, but arrange to have it collected separately.
- The re-use or correct recycling of the electronic and electrical equipment (EEE) is important in order to protect the environment and the wellbeing of humans.
- In accordance with European Directive WEEE 2002/96/EC, special collection points are available to which to deliver waste electrical and electronic equipment and the equipment can also be handed over to a distributor at the moment of purchasing a new equivalent type.
- The public administration and producers of electrical and electronic equipment are involved in facilitating the processes of the re-use and recovery of waste electrical and electronic equipment through the organisation of collection activities and the use of appropriate planning arrangements.
- Unauthorised disposal of waste electrical and electronic equipment is punishable by law with the appropriate penalties.



For details on the commands,
refer to the manual with code **77200000002100**

TABLE OF CONTENTS

1	INTRODUCTION	9
1.1	Document structure	9
1.2	Explanatory notes used in this manual	9
2	DESCRIPTION	11
2.1	Unpacking the device	11
2.2	Device component: external views	12
2.3	Device component: internal view	14
2.4	Product label	14
2.5	Key functions	15
2.6	Status led flashes	16
3	INSTALLATION	17
3.1	“EASYLOCK” fastening	17
3.2	Fixing with screws (model without interconnection module)	19
3.3	Connections	20
3.4	Pinout (model without interconnection module)	22
3.5	Pinout (model with interconnection module)	24
3.6	Serial port setting (model without interconnection module)	27
3.7	Parallel port setting (model with interconnection module)	28
3.8	Driver and SDK	32
4	OPERATION	33
4.1	Adjusting paper width	33
4.2	Paper roll insertion	35
5	CONFIGURATION	37
5.1	Configuration mode	37
5.2	Setup report	39
5.3	Printer status	40
5.4	Printer parameters	41
5.5	Hexadecimal dump	44
6	MAINTENANCE	45
6.1	Planning of cleaning operations	45
6.2	Cleaning	46
6.3	Firmware upgrade	49

7	SPECIFICATIONS	51
7.1	Hardware specifications	51
7.2	Character specifications in ESC/POS™ emulation	54
7.3	Device dimensions	54
7.4	Power supply dimensions cod.963GE020000003 (optional)	57
7.5	Character sets in ESC/POS™ emulation	58
8	CONSUMABLES	59
9	ACCESSORIES	61
9.1	Interconnection module (models without interconnection module).....	62
10	TECHNICAL SERVICE	63

1 INTRODUCTION

1.1 Document structure

This document includes the following chapters:

1	INTRODUCTION	information about this document
2	DESCRIPTION	general description of device
3	INSTALLATION	information required for a correct installation of the device
4	OPERATION	information required to make the device operative
5	CONFIGURATION	description of the configuration parameters of the device
6	MAINTENANCE	information for a correct periodic maintenance
7	SPECIFICATION	technical specification for the device and its accessories
8	CONSUMABLES	description and installation of the available consumables for the device
9	ACCESSORIES	description and installation of the available accessories for the device
10	ALIGNMENT	information required for managing the paper alignment
11	TECHNICAL SERVICE	information required for contacting the technical service
12	ADVANCED FUNCTIONS	information about special functions available with the device

1.2 Explanatory notes used in this manual

NOTE:

Gives important information or suggestions relative to the use of the device

ATTENTION:

Gives information that must be carefully followed to guard against damaging the device

DANGER:

Gives information that must be carefully followed to guard against operator injury or damage


2 DESCRIPTION

2.1 Unpacking the device

Remove the device from its carton being careful not to damage the packing material so that it may be re-used if the printer is to be transported in the future.

Make sure that all the components illustrated below are present and that there are no signs of damage. If there are, contact Customer Service.

1. Paper adjustment guides
(already assembled)
2. Fixing hooks
3. Paper roll (already inserted into
the device)
4. Installation instruction
5. Device




- Open the device packaging.
- Remove the packing frame content and remove the packing frame.
- Take out the device.
- Keep the box, trays and packing materials in the event the printer must be transported/shipped in the future.

2.2 Device component: external views


Model without interconnection module

1. Frontal cover
2. Paper output
3. Serrated blade for manual tear off
4. Release lever for cover
5. Status led
6. FEED key
7. Seat for fixing hook
8. Connector for interconnection module (optional)
9. USB interface connector (miniUSB)
10. Power supply connector
11. RS232/TTL serial interface connector
12. Switch for serial interface setting




Model with interconnection module

1. Frontal cover
2. Paper output
3. Serrated blade for manual tear off
4. Release lever for cover
5. Status led
6. FEED key
7. Seat for fixing hook
8. RS232/TTL serial interface connector
9. Parallel interface connector
10. USB interface connector (type B)
11. Power supply connector
12. Connector for external device (optional)




2.3 Device component: internal view

1. Printing roller
2. Printing head with temperature sensor
3. Sensors for detecting paper presence




2.4 Product label

- PC = Product code (14 digits)
SN = Serial number
HW = Hardware release








2.5 Key functions

The following figures show the functions of key according to the operating condition of the device.



2.6 Status led flashes

The status led indicates hardware status of device. Given in the table below are the various led signals and the corresponding device status.

STATUS LED		DESCRIPTION	
-		OFF	PRINTER OFF
GREEN		ON	PRINTER ON: NO ERROR
GREEN COMMUNICATION STATUS		x 1	RECEIVE DATA
		x 2	RECEPTION ERRORS (PARITY, FRAME ERROR, OVERRUN ERROR)
		x 3	COMMAND NOT RECOGNIZED
		x 4	COMMAND RECEPTION TIME OUT
YELLOW RECOVERABLE ERROR		x 2	HEADING OVER TEMPERATURE
		x 3	PAPER END
		x 4	PAPER JAM
		x 5	POWER SUPPLY VOLTAGE INCORRECT
RED UNRECOVERABLE ERROR		x 6	COVER OPEN
		3 x	RAM ERROR



3 INSTALLATION

3.1 “EASYLOCK” fastening


The device includes two plastic hooks for the “Easylock” fastening. This system allows to fix the device to panels of variable thickness from a minimum of 3mm and a maximum of 8mm and requires no tools.

To use the fixing hooks, proceed as follows:

NOTE: All the dimensions shown in following figures are in millimetres.



4




To remove the fixing hooks
lift the lever shown in figure
with a small screwdriver

3.2 Fixing with screws (model without interconnection module)

The device is provided with six fixing holes in the back side.


To install the device on a panel it is possible to use three M3 threaded screws into the holes indicated by the letter A or three screws for plastic $d = 3$ (length 6 mm) into the holes indicated by the letter B (see following figure).



3.3 Connections

The following figures show the possible connections for device.


Model without interconnection module



ATTENTION: In some using conditions, we recommend the installation of a ferrite core on the power supply cable.

NOTE: If RS232 and USB connectors are inserted, communication port is USB.


Model with interconnection module



ATTENTION: In some using conditions, we recommend the installation of a ferrite core on the power supply cable.

NOTE: If RS232 and USB connectors are inserted, communication port is USB.

3.4 Pinout (model without interconnection module)




POWER SUPPLY
JST male connector 90° (S4B-XH-A-1)



ATTENTION:
Respect power supply polarity.

NOTE: Power supply cable
The following figure shows the connector pinout of the power supply cable for the device:




MINI USB INTERFACE
Female MINI USB type B connector





RS232/TTL SERIAL INTERFACE

Molex male connector 53261 series (90°)




NOTES:

Given the presence of the RS232 standard, logic value "0" corresponds to a voltage level of between +3Vdc and +15Vdc and logic value "1" corresponds to a voltage level of between -3Vdc and -15Vdc.

DEVICE > PC connection

The following picture shows an example of connection between the device and a personal computer using a 9 pin RS232 serial connector:



When use a serial cable, we recommend the installation of a ferrite core on the power supply cable.

3.5 Pinout (model with interconnection module)





POWER SUPPLY
Tripolar female connector

J2	1	GND
	2	+VRE
	3	GND
	4	Frame GND
	5	Frame GND


ATTENTION:
Respect power supply polarity.

NOTE: Power supply cable
The following figure shows the connector pinout of the power supply cable for the device:



USB INTERFACE
Female USB type B connector

J5	1	VPLUG	(in)
	2	D0-	(in/out)
	3	D0+	(in/out)
	4	GND	
	SH1	GND	
	SH2	GND	



RS232 SERIAL INTERFACE

DB9 female connector


J3	1	n.c.	
	2	TX	During transmission, takes the value "0" and "1", depending on data
	3	RX	During reception, takes the value "0" and "1", depending on data
	4	n.c.	
	5	GND	
	6	n.c.	
	7	n.c.	
	8	RTS	When "1", printer is ready to receive data
	9	n.c.	
	SH1	GND	
	SH2	GND	

NOTES:


Given the presence of the RS232 standard, logic value "0" corresponds to a voltage level of between +3Vdc and +15Vdc and logic value "1" corresponds to a voltage level of between -3Vdc and -15Vdc.

DEVICE > PC connection

The following picture shows an example of connection between the device and a personal computer using a 9 pin RS232 serial connector:



When use a serial cable, we recommend the installation of a ferrite core on the power supply cable.




PARALLEL CENTRONICS/TTL INTERFACE
DB25 female connector

J7	1	STROBE	(in)
	2	AD0	(in)
	3	AD1	(in)
	4	AD2	(in)
	5	AD3	(in)
	6	AD4	(in)
	7	AD5	(in)
	8	AD6	(in)
	9	AD7	(in)
	10	ACK	(out)
	11	BUSY	(out)
	12	PAP-END	(out)
	13	VCP	(out)
	14	n.c.	
	15	ERROR	(out)
	16	n.c.	
	17	GND	
	18	n.c.	
	19	GND	
	20	GND	
	21	GND	
	22	GND	
	23	GND	
	24	GND	
	25	GND	
SH1	GND		
SH2	GND		

3.6 Serial port setting (model without interconnection module)

To set the serial port of the device, slide the switch shown in figure in the correct position:



In the serial protocol, the signals which distinguish the communication are TD, RD, and RTS if the RTS/CTS protocol has been selected while, if the XON/XOFF protocol has been selected, the signals are TD and RD.


Transmission format




NOTES:

- (1) : Bit 7 is present if only in the printer set-up is enabled 8 bit/char as data length.
- (2) : Parity Bit is present if only in the printer set-up the parity is enabled.


RTS/CTS Protocol






3.7 Parallel port setting (model with interconnection module)

To set the parallel port of the device, proceed as follows:




2




Unscrew the 3 fixing screws
and remove the rear cover

3




Unscrew the 3 fixing screws
and remove the interconnection board

4




Rotate the interconnection board

5



Close the jumpers JP1 and JP2 as shown in figure according to the desired setting

6




SEE PREVIOUS STEPS


Assemble the device
by reversing the previous steps

For models with parallel TTL interface, the communication signals are: 8 bit DATA BUS, STROBE (indicate the data validity) and BUSY (indicate that the device is ready to receive data).

Transmission format



Flow diagram



3.8 Driver and SDK

The drivers are available for the following operating system:

OPERATING SYSTEM	DESCRIPTION	INSTALLATION PROCEDURE
Windows	Driver per Windows XP	From the START menu, press Run and type-in the path where the SW was saved on your PC, then click OK. Follow the instructions that appear on the screen to install the driver.
	Driver per Windows VISTA (32/64bit)	
	Driver per Windows 7 (32/64bit)	
	Driver per Windows 8 (32/64bit)	
Linux		Follow the instruction get back on the README.TXT file. You can find it in the software package downloaded in advance.
Android	Library for CustomAndroidAPI	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the library.

NOTA:


All drivers can be found in the DOWNLOAD section of the web site www.custom.biz.

4 OPERATION

4.1 Adjusting paper width


The device includes two plastic guides for the adjustment of paper width to 144mm or 112mm. To adjust the paper width proceed as follows.

1




Lift the release lever and completely open the frontal cover to the maximum opening position

2



Check the number impressed on the visible side of guides.
If the number does not match the paper width desired, proceed with the following steps



2



ATTENTION:
While using the screwdriver,
be careful not to damage the
two guides and the paper
compartment

Remove the two guides by gently levering with a small screwdriver
at the point shown in the figure

4




Rotate the guides and hook them into the seat of the paper compartment
with the correct side facing inwards

NOTE:
The assembly procedure for the adapter guides is the same for all the device models.

4.2 Paper roll insertion

At every change of paper roll, check inside the device. To change the paper roll, proceed as follows:


1



SEE PREVIOUS PARAGRAPHS


Adjust the paper width

2



Insert the paper roll so that it unrolls correctly as shown in figure

3





Pull out of the paper compartment a few centimeters of paper and close the frontal cover

5 CONFIGURATION



5.1 Configuration mode

To enter the configuration mode and print a SETUP report with the operating parameters of the device, proceed as follows.

1




Models without interconnection module



Models with interconnection module


While pressing the FEED key,
switch on the device by inserting the power supply cable.

2



The device prints the report with parameters for settings

3



**Enter
setup**

Press the FEED key to enter the configuration mode

5.2 Setup report

The following figure shows the setup report of the device. The shown values for parameters are sample values; for the list and the description of device parameters see the following paragraphs.

<p><i>PRINTER NAME and FIRMWARE MODULE RELEASE</i> {</p>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>PLUS4 printer SCODE. <code> - rel 1.00</p> </div> <p>RS232 Handshaking : Xon/Xoff</p>
<p><i>PRINTING HEAD STATUS</i> {</p>	<p style="text-align: center;">PRINTER SETTINGS</p> <p>PRINthead SELFTEST 1 832</p> <p>PRINthead WORKING GOOD!</p>
<p><i>DEVICE STATUS</i> {</p>	<p>PRINTER TYPEPLUS4 PRINTING HEAD TYPE<type> INTERFACEUSB PROGRAM MEMORY TEST.....OK DYNAMIC RAM TEST.....OK EEPROM TEST.....OK HEAD VOLTAGE [V] = 07,00 HEAD TEMPERATURE [°C] = 25 POWER ON COUNTER = 4 PAPER PRINTED [cm] = 40</p>
<p><i>PRINTER PARAMETERS</i> {</p>	<p>Printer Emulation : ESC/POS (TM) RS232 Baud Rate : 115200 bps RS232 Data Length : 8 bits/chr RS232 Parity : None RS232 Handshaking : Xon/Xoff Busy Condition : RxFull USB Address Number : 0 Print Mode : Normal Autofeed : CR Enabled Chars / inch : A=20 B=15 cpi Code Table [num] : 00 Chinese Font : Disabled Speed / Quality : High Quality Print Width : 104 mm PaperEnd Buffer Clear : Disabled PrintHead Test PowerOn : Disabled Print Density : 0%</p>
<p><i>KEYS FUNCTIONS</i> {</p>	<p>[PUSH] to enter setup [FAST PUSH] to skip setup</p>

5.3 Printer status

Device operating status is indicated in the configuration print-out in which, next to the name of the components displayed, the following information is given:

PRINTER TYPE	<i>device model</i>
PRINTING HEAD TYPE	<i>print head model</i>
INTERFACE	<i>interface present</i>
PROGRAM MEMORY TEST	<i>OK appears if functioning and NOT OK if faulty</i>
DYNAMIC RAM TEST	<i>OK appears if functioning and NOT OK if faulty</i>
EEPROM TEST	<i>OK appears if functioning and NOT OK if faulty</i>
HEAD VOLTAGE	<i>voltage of the head</i>
HEAD TEMPERATURE	<i>temperature of the head</i>
POWER ON COUNTER	<i>number of power-ups made</i>
PAPER PRINTED	<i>centimetres of paper printed</i>

5.4 Printer parameters

This device allows the configuration of the parameters listed in the following table.

The parameters marked with the symbol ^D are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile memory.

PRINTER EMULATION	<i>Available emulations for the device:</i> <i>ESC/POS™^D</i>
--------------------------	--

RS232 BAUD RATE	<i>Communication speed of the serial interface:</i> <i>115200^D 9600</i> <i>57600 4800</i> <i>38400 2400</i> <i>19200 1200</i>
	<i>NOTE: Parameter valid only with serial interface.</i>

RS232 DATA LENGTH	<i>Number of bit used for characters encoding:</i> <i>7 bits/car</i> <i>8 bits/car^D</i>
	<i>NOTE: Parameter valid only with serial interface.</i>

RS232 PARITY	<i>Bit for the parity control of the serial interface:</i> <i>None^D = parity bit omitted</i> <i>Even = even value for parity bit</i> <i>Odd = odd value for parity bit</i>
	<i>NOTE: Parameter valid only with serial interface.</i>

RS232 HANDSHAKING	<i>Handshaking:</i> <i>XON/XOFF^D = software handshaking</i> <i>Hardware = hardware handshaking (CTS/RTS)</i>
	<i>NOTES:</i> <i>Parameter valid only with serial interface.</i> <i>When the receive buffer is full, if handshaking is set to XON/XOFF, the printer sends the XOFF (\$13) on the serial port. When the receive buffer has cleared once again, if handshaking is set to XON/XOFF, the printer sends the XON (\$11) on the serial port.</i>

BUSY CONDITION	<i>Activation mode for Busy signal:</i> <i>OffLine/ RXFull = Busy signal is activated when the printer is both in OffLine status and the buffer is full</i> <i>RXFull^D = Busy signal is activated when the buffer is full</i>
	<i>NOTE: Parameter valid only with serial interface.</i>

USB ADDRESS NUMBER *Numerical address code for the univocal identification of the USB device (in case of more than a USB device connected with the same PC):*

<i>0^D</i>	<i>2</i>	<i>4</i>	<i>6</i>	<i>8</i>
<i>1</i>	<i>3</i>	<i>5</i>	<i>7</i>	<i>9</i>

PRINT MODE *Printing mode:*

Normal^D = enables printing in normal writing way
Reverse = enables printing rotated 180 degrees

AUTOFEED *Setting of the Carriage Return character:*

CR disabled = Carriage Return disabled
CR enabled^D = Carriage Return enabled

CHARS / INCH *Font selection:*

A = 11 cpi, B = 15 cpi
A = 15 cpi, B = 20 cpi
A = 20 cpi, B = 15 cpi^D

NOTES:
CPI = Characters Per Inch

CODE TABLE [num] *Identifier number of the character code table to use.*
The numeric value of the identifier is made up with the following two parameters for the setting of two digits for the tens and the units:

Setting the digit for tens:

CODE TABLE [num x 10]	<i>0^D</i>	<i>2</i>	<i>4</i>
	<i>1</i>	<i>3</i>	<i>5</i>

Setting the digit for units:

CODE TABLE [num x 1]	<i>0^D</i>	<i>2</i>	<i>4</i>	<i>6</i>	<i>8</i>
	<i>1</i>	<i>3</i>	<i>5</i>	<i>7</i>	<i>9</i>

NOTE:
See the paragraph 7.5 to learn about the character tables corresponding to the identification numbers set with this parameter.
The character tables set with this parameter are the same set with the command \$1B \$74 (refer to the Commands Manual of the device).

CHINESE FONT *Setting of the chinese font:*

Disabled^D = Disables the use of the chinese extended font GB18030-2000
Enabled = Enables the use of the chinese extended font GB18030-2000

NOTE: When the chinese font is enabled, the selection of the character code table is suspended (parameter "CODE TABLE"). When the Chinese fonts is disabled, it returns the character code table previously in use (parameter "CODE TABLE").

SPEED / QUALITY

Setting of printing speed and printing quality:

High Quality^D

Normal

PRINT WIDTH

Width of printing area:

<i>76mm</i>	<i>82mm</i>	<i>88mm</i>	<i>94mm</i>	<i>100mm</i>
<i>78mm</i>	<i>84mm</i>	<i>90mm</i>	<i>96mm</i>	<i>102mm</i>
<i>80mm</i>	<i>86mm</i>	<i>92mm</i>	<i>98mm</i>	<i>104mm^D</i>

**PAPEREND BUFFER
CLEAR**

Cleaning mode of the data in receive buffer, if the printing is stopped due to lack of paper:

Disabled^D = The data remain in the receive buffer. When the paper runs out, the printer keeps the remaining data in the receive buffer and prints the remaining portion of the ticket after that the new paper is loaded.

Enabled = When the paper runs out, all data in the receive buffer are deleted.

**PRINTHEAD TEST
POWERON**

Setting of the performing of the print head test:

Disabled^D = the test is performed only during the printing of the setup report

Enabled = the test is performed at each power on

PRINT DENSITY

Adjusting the printing density:

<i>-50%</i>	<i>-12%</i>	<i>+25%</i>
<i>-37%</i>	<i>0^D</i>	<i>+37%</i>
<i>-25%</i>	<i>+12%</i>	<i>+50%</i>

5.5 Hexadecimal dump

This function is used for the diagnosis of the characters received from the communications port. Characters are printed as hexadecimal code and the corresponding ASCII code (see below). Each line is preceded by a counter in hexadecimal that indicates the number of bytes received.

During the startup, if you hold down the FEED key, the printer enters the self-test routine and print the setup report. The printer remains in standby until a key is pressed or characters are received through the communication port (Hexadecimal Dump mode). For each character sent, the ticket shows the hexadecimal value and the ASCII codes (if the characters are underlined, the receive buffer is full). Shown below is an example of a Hexadecimal Dump:

HEXADECIMAL DUMP						
31	32	33	34	35	...	12345 ...
39	30	31	32	33	...	90123 ...
37	38	39	75	69	...	789ui ...
68	6B	6A	73	64	...	hkjsd ...
73	64	66	6B	6A	...	sdfkj ...
66	73	64	66	6B	...	fsdfk ...
65	69	6F	79	75	...	eioyu ...
6F	72	69	75	77	...	oriuw ...
6F	75	77	65	72	...	ouwer ...
77	65	72	69	6F	...	werio ...
72	69	6F	75	77	...	riouw ...
6B	6C	73	64	66	...	kl sdf ...
64	66	6B	73	64	...	dfksd ...
73	64	66	6B	6A	...	sdfkj ...
66	6B	F2	6A	73	...	fk>j ...
6A	6B	6C	68			jklh

6 MAINTENANCE

6.1 Planning of cleaning operations

The regular cleaning of the device keeps the print quality and extends its life. The following table shows the recommended planning for the cleaning operations.

EVERY PAPER CHANGE	
Printhead	Use isopropyl alcohol
Rollers	Use isopropyl alcohol
EVERY 5 PAPER CHANGES	
Paper compartment	Use compressed air or tweezers
Sensors	Use compressed air
EVERY 6 MONTHS OR AS NEEDED	
Printer case	Use compressed air or a soft cloth

For specific procedures, see the following pages.

NOTE:


If you use the device in dusty environments, you must reduce the intervals between the cleaning operations.

6.2 Cleaning

For periodic cleaning of the printer, see the instructions below.


Sensors

1







Disconnect the power supply cable and open the frontal cover of the device (see par. 4.1)

2




Clean the device sensor by using compressed air.

ATTENTION:
Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the device.




Paper compartment

1







Disconnect the power supply cable and open the frontal cover of the device (see par. 4.1)

2




Remove any scraps of paper and the accumulated paper dust into the paper compartment by using compressed air

ATTENTION:
Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the device.




Printing head

1



Disconnect the power supply cable and open the fronal cover of the device (see par. 4.1)

2




Clean the printing head by using a non-abrasive cloth moistened with isopropyl

ATTENTION:
Do not use solvents, or hard brushes.
Do not let water or other liquids get inside the machine.




Printing roller

1



Disconnect the power supply cable and open the frontal cover of the device (see par. 4.1)

2




Clean the printing roller by using a non-abrasive cloth moistened with isopropyl.

ATTENTION:
Do not use solvents, or hard brushes.
Do not let water or other liquids get inside the machine.




1



Disconnect the power supply cable

2



To clean the device, use compressed air or a soft cloth

ATTENTION:

Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the device.



6.3 Firmware upgrade

ATTENTION:

During communication between PC and device for the firmware update it is strictly forbidden to disconnect the communication cable or to remove the power supply of the devices not to endanger the proper functioning of the machine.

Only during the firmware update, the connection between PC and device must be direct, without the use of HUB device.

Only during the firmware update, do not connect or disconnect other USB devices.

NOTES:


The latest firmware of the device is available in the download area of the web site www.custom.biz

Install on the PC used for printer upgrading the UPG-CEPRN software available in the download area of the web site www.custom.biz.


For communication via USB you must install on PC the printer driver available in the download area of the web site www.custom.biz.

Proceed as follows:


1. Write down the product code (14 digits) printed on the product label (see par.2.4).
2. Go to the web site www.custom.biz and download the appropriate firmware release from the DOWNLOAD area.
3. Print the SETUP report (see chapter 5).
4. Switch OFF the device.
5. Connect the device to the PC using a USB cable (see par.3.3).
6. Switch ON the device.
7. Launch the software UPGCEPRN.
8. Select the update file .PSW location:



9. Select item USB and then select the USB device among those proposed (e.g. PLUS4):



10. After a few minutes a message on the screen warns that the update is completed.



11. Print a new SETUP report to verify the new firmware release (see chapter 5).

7 SPECIFICATIONS

7.1 Hardware specifications

GENERAL	
Sensors	Paper presence, printing head temperature
MTBF ⁽¹⁾	118 000 hours
Emulations	ESC/POS™
Printing driver	Windows XP, Windows VISTA (32/64bit), Windows 7 (32/64bit), Windows 8 (32/64bit), Linux, Android
INTERFACES	
<i>models without interconnection module</i>	
USB connector	12 Mbit/sec (USB 2.0 full speed)
Serial RS232/TTL connector	from 1200 to 115200 bps
<i>models with interconnection module</i>	
Serial RS232 connector	from 1200 to 115200 bps
USB connector	12 Mbit/sec (USB 2.0 full speed)
Centronics/TTL connector	up to 2MB/sec
MEMORIES	
Receive buffer	2 Kbytes
Flash memory	1 Mbytes internal + 4 Mbytes external (of which 1Mbytes available)
RAM memory	128 Kbytes internal + 8Mbytes external
PRINTER	
Resolution	203 dpi (8 dot/mm)

Printing method	Thermal, fixed head
Printing width	from 76mm to 104mm (2mm step)
Printing mode	Normal, 90°, 180°, 270°
Printing format	Height/width from 1 to 8, bold, reverse, underlined, italic
Character fonts	54 character code tables (see par.7.5) Extended Chinese GB18030-2000
Printable barcode	UPCA, UPCE, EAN13, EAN8, CODE39, ITF CODABAR, CODE93, CODE128, CODE32
Printing speed ^{(2) (3)}	High Quality = 50 mm/sec Normal = 70 mm/sec

PAPER

Type of paper	Thermal paper rolls, thermal side on outside of roll
Paper width	112 mm, 114 mm
Paper weight	from 50 g/m2 to 60 g/m2
Recommended types of paper	KANZAN KF50
Paper end	Not attached to roll core
External roll diameter	max. 50 mm
Internal roll core diameter	12 mm
Core type	Cardboard or plastic

DEVICE ELECTRICAL SPECIFICATIONS

Power supply	
<i>models without interconnection module</i>	from 5 Vdc to 8 Vdc (optional external power supply)
<i>models with interconnection module</i>	from 9 Vdc to 42 Vdc (optional external power supply)
Medium consumption ⁽³⁾	
<i>models without interconnection module</i>	from 1 A to 1,37 A
<i>models with interconnection module</i>	from 0,85 A to 0,20 A

Stand-by consumption

models without interconnection module

0,085 A

models with interconnection module

0,097 A

ELECTRICAL SPECIFICATIONS POWER SUPPLY cod.963GE020000003 (OPTIONAL)

Power supply voltage

from 100 Vac to 240 Vac

Frequency

from 50 Hz to 60 Hz

Current (output)

2.5 A

Power

60W

ENVIRONMENTAL CONDITIONS

Operating temperature

from 0°C to +60°C

Relative humidity

from 10% Rh to 85% Rh

Storage temperature

from -20 °C to +70 °C

Storage relative humidity

from 10% Rh to 90% Rh

NOTES:

(1) : Control board.

(2) : Respecting the regular schedule of cleaning for the device components.

(3) : Referred to a standard CUSTOM receipt (L=10cm, Density = 12,5% dots on).

7.2 Character specifications in ESC/POS™ emulation






Character set	3		
Character density	11 cpi	15 cpi	20 cpi
Number of columns	46	59	83
Chars / sec	402	516	726
Lines / sec	8,75	8,75	8,75
Characters (L x H mm)-Normal	2,25 x 3	1,625 x 3	1,25 x 3

7.3 Device dimensions






Length	148 mm
Height	97,8 mm
Width	
<i>models without interconnection module</i>	71,7 mm
<i>models with interconnection module</i>	89,1 mm
Weight	
<i>models without interconnection module</i>	390 g
<i>models with interconnection module</i>	510 g

NOTE: All the dimensions shown in following figures are in millimetres.

Models without interconnection module




Models with interconnection module



7.4 Power supply dimensions cod.963GE020000003 (optional)

Length	127 mm
Height	35,5 mm
Width	56 mm

NOTE:
All the dimensions shown in following figures are in millimetres.



7.5 Character sets in ESC/POS™ emulation

The device has 3 fonts of varying width (11, 15 and 20 cpi) which may be related one of the coding tables provided on the device.

To know the coding tables actually present on the device, you need to print the font test (see par.2.5).


You can set font and coding table by using the commands (see the Commands Manual of the device) or using the “Code Table” and the “Chars / Inch” parameters during the Setup procedure (see par.5.4).

The following is the full list of coding tables that can be installed on the device.

<Code Table>	Coding table	<Code Table>	Coding table
0	PC437: Usa, Standard Europe	33	WPC775: Baltic Rim
1	Katakana	34	PC855: Cyrillic
2	PC850: Multilingual	35	PC861: Icelandic
3	PC860: Portuguese	36	PC862: Hebrew
4	PC863: Canadian-Frech	37	PC864: Arabic
5	PC865: Nordic	38	PC869: Greek
11	PC851: Greek	39	ISO8859-2: Latin2
12	PC853: Turkish	40	ISO8859-15: Latin9
13	PC857: Turkish	41	PC1098: Farsi
14	PC737: Greek	42	PC1118: Lithuanian
15	ISO8859-7: Greek	43	PC1119: Lithuanian
16	WPC1252	44	PC1125: Ukrainian
17	PC866: Cyrillic #2	45	WPC1250: Latin2
18	PC852: Latin2	46	WPC1251: Cyrillic
19	PC858: Euro	47	WPC1253: Greek
20	KU42: Thai	48	WPC1254: Turkish
21	TIS11: Thai	49	WPC1255: Hebrew
26	TIS18: Thai	50	WPC1256: Arabic
30	TCVN-3: Vietnamese	51	WPC1257: Baltic Rim
31	TCVN-3: Vietnamese	52	WPC1258: Vietnamese
32	PC720: Arabic	53	KZ-1048: Kazakhstan





8 CONSUMABLES

The following table shows the list of available consumables for device:

DESCRIPTION	CODE
<p>THERMAL PAPER ROLL</p> <p>wight = 55g/m² width = 112mm Ø external = 48mm Ø core = 12mm</p>	<p>67300000000309</p> 

9 ACCESSORIES

The available accessories for the device are listed in the following table:


DESCRIPTION	CODE
POWER SUPPLY (for technical specification, see paragraph 7.1)	963GE020000003 
<i>models without interconnection module</i>	
CABLES KIT POWER SUPPLY + SERIAL/TTL INTERFACE 5-8 VOLT	44000000002500 
INTERCONNECTION MODULE (see paragraphs 9.1)	976GJ020000001 
<i>models with interconnection module</i>	
POWER SUPPLY CABLE	22600000000012 

9.1 Interconnection module (models without interconnection module)

An interconnection module kit (cod.976GJ02000001) is available for the device.

The kit includes (see figure):

1. Interconnection board
2. No.3 fixing screws for interconnection board
3. No.3 fixing screws for rear cover
4. Rear cover
5. Instruction sheet



NOTE:

To assemble the interconnection module, refer to the instruction sheet provided with the kit.

10 TECHNICAL SERVICE


In case of failure, contact the Technical Service by sending an e-mail to support@custom.it detailing:

1. Product code
2. Serial number
3. Hardware release
4. Firmware release

To get the necessary data, proceed as follows:

1

XXXXXXXXXXXXXXXXX Rx



00000000000000000000

Write down the data printed on the product label (see paragraph 2.4)

2

FW

PLUS4 printer

SCODE. <code> rel 1.00

PRINTER SETTINGS

PRINthead SELFTEST
1 832

PRINthead WORKING GOOD!

PRINter TYPEPLUS4
PRINting HEAD TYPE<type>
INTERFACEUSB
PROGRAM MEMORY TEST.....OK
DYNAMIC RAM TEST.....OK
EEPROM TEST.....OK
HEAD VOLTAGE [V] = 07,00

Print a Setup report (see paragraph 5.1)
The Setup report shows the firmware release

3



↓

support@custom.it
Customer Service Department

Send an e-mail to the Technical Service, with the data collected

CUSTOM[®]

CUSTOM S.p.A.

World Headquarters

Via Berettine, 2 - 43010 Fontevivo, Parma ITALY

Tel. +39 0521 680111 - Fax +39 0521 610701

info@custom.biz - www.custom.biz

All rights reserved

www.custom.biz