



Loop-IP6700

TDMoEthernet

User's Manual

LOOP TELECOMMUNICATION INTERNATIONAL, INC.
8F, NO. 8, HSIN ANN RD.
SCIENCE-BASED INDUSTRIAL PARK
HSINCHU, TAIWAN
Tel: +886-3-578-7696
Fax: +886-3-578-7695

© 2007 Loop Telecommunication International, Inc. All rights reserved.

Loop-IP is a trade mark of Loop Telecommunication International, Inc.

Version 8, 20 MAR 2007

TABLE OF CONTENTS

1	PRODUCT DESCRIPTION.....	1
1.1	Description.....	1
1.3	Applications	2
1.4	Specification	3
2	INSTALLATION	4
2.1	Site Selection.....	4
2.2	Mechanical Installation	5
3	OPERATION	23
3.1	Quick Start for Loop-IP6700.....	23
3.1.1	Power On	23
3.2	Self Test.....	23
3.3	Return to Default	23
3.4	Using Terminal	23
3.5	System Configuration	24
3.5.1	Console Port	24
3.6	Alarm	24
3.7	Reports	25
3.8	LED.....	26
3.9	Management Port (SNMP Port).....	27
3.10	User Data Port (Ethernet).....	27
4	MAINTENANCE.....	28
4.1	Self-Test	28
4.2	Near End Loopback.....	28
4.2.1	E1/T1 Line Loopback.....	28
4.2.2	E1/T1 Payload Loopback.....	28
4.3	Far End Loopback	29
5	FRONT PANEL OPERATION	30
5.1	Configuration	36
5.1.1	System	36
5.1.1.1	Ethernet	36
5.1.1.2	Lan Port	36
5.1.1.3	Bun ACT Timer	37
5.1.1.4	LPT Timer	37
5.1.1.5	Lan Rate	37
5.1.1.6	CAS Idle code	38
5.1.1.7	Remote loss	38
5.1.1.8	IP	38
5.1.1.9	Date	39
5.1.1.10	Time	39
5.1.1.11	SNMP	39
5.1.1.12	Device Name	40
5.2	Bundle Setup	41
5.2.1	Source IP	41
5.2.2	Source subnet.....	41
5.2.3	Gateway IP	41
5.2.4	Port Select	42
5.2.5	Bundle ID	42
5.2.6	Action	42

5.2.7	UDP number43
5.2.8	Timeslot from43
5.2.9	Timeslot num44
5.2.10	Destination IP44
5.2.11	Cell in bundle44
5.2.12	Jitter delay44
5.2.13	Jitter size45
5.2.14	Vlan45
5.2.15	Vlan1 ID45
5.2.16	Vlan1 priority46
5.2.17	Vlan2 ID46
5.2.18	Vlan2 priority46
5.2.19	Bundle status46
5.2.20	Confirm?47
5.3	Bundle Status47
5.3.1	Classifi pack RX47
5.3.2	Byte received48
5.3.3	Byte transmitted48
5.3.4	Packet received48
5.3.5	Packet transmitted48
5.3.6	LAN WAN SNMP49
5.4	Alarm49
5.4.1	Alarm setup49
5.4.1.1	Alarm clock49
5.4.1.2	Alarm link50
5.4.2	Alarm status50
5.4.3	Alarm clear51
5.5	Information51
5.5.1	Software Version51
5.5.2	Hardware Version51
5.5.3	Serial number52
5.6	Miscellaneous52
5.6.1	Store Config52
5.6.2	Retrieve Config52
5.6.3	Load Default53
5.6.4	System reset53
5.7	E3/DS3 Menu54
5.7.1	Config Setup54
5.7.1.1	Tx Length54
5.7.1.2	Xmt AIS54
5.7.2	Port Status55
5.7.2.1	LOS XMT AIS55
5.7.2.2	BPV ES55
5.7.3	Port Alarm55
5.7.3.1	Alarm setup55
5.7.3.2	Port History57
5.7.3.3	Alarm clear58
5.7.4	Port lookback58
5.7.4.1	Local Loopback58
5.7.5	Clock Source59
5.7.5.1	Master Clock59
5.7.5.2	Second Clock60
5.7.5.3	Current Clock61
5.7.5.4	Recover Clock61
5.7.5.5	Clock Status62
5.8	E1-CARD Menu63
5.8.1	Config Setup63
5.8.1.1	Frame63

5.8.1.2	Code	63
5.8.1.3	CRC	64
5.8.1.4	RAI	64
5.8.1.5	AIS	64
5.8.1.6	CAS	65
5.8.1.7	OOS	65
5.8.1.8	FDL	66
5.8.1.9	Sa_bit	66
5.8.1.10	IDLE	67
5.8.2	Port Status	67
5.8.2.1	LOF LOS	67
5.8.2.2	RCV AIS RCV RAI	67
5.8.2.3	XMT AIS XMT RAI	68
5.8.2.4	BPV ES	68
5.8.3	Port Alarm	68
5.8.3.1	Alarm Setup	68
5.8.3.2	Port History	70
5.8.3.3	Alarm Clear	73
5.8.4	Port Loopback	73
5.8.4.1	Local Loopback	74
5.8.4.2	Remote Loopback	74
5.8.4.3	Send Bert	75
5.8.5	Clock Source	76
5.8.5.1	Master Clock	76
5.8.5.2	Second Clock	77
5.8.5.3	Current Clock	78
5.8.5.4	Recover Clock	79
5.8.5.5	Clock status	79
5.9	T1-CARD Menu	80
5.9.1	Config Setup	80
5.9.1.1	Frame	80
5.9.1.2	Code	80
5.9.1.3	CRC	81
5.9.1.4	RAI	81
5.9.1.5	AIS	81
5.9.1.6	CAS	82
5.9.1.7	OOS	82
5.9.1.8	FDL	83
5.9.1.9	Sa_bit	83
5.9.1.10	IDLE	84
5.9.2	Port Status	84
5.9.2.1	LOF LOS	84
5.9.2.2	RCV AIS RCV RAI	84
5.9.2.3	XMT AIS XMT RAI	85
5.9.2.4	BPV ES	85
5.9.3	Port Alarm	85
5.9.3.1	Alarm Setup	85
5.9.3.2	Port History	87
5.9.3.3	Alarm Clear	90
5.9.4	Port Loopback	90
5.9.4.1	Local Loopback	91
5.9.4.2	Remote Loopback	91
5.9.4.3	Send Bert	92
5.9.5	Clock Source	94
5.9.5.1	Master Clock	94
5.9.5.2	Second Clock	95
5.9.5.3	Current Clock	96
5.9.5.4	Recover Clock	96

5.9.5.5	Clock status	97
5.10	DTE Menu.....	98
5.10.1	Config Setup	98
5.10.1.1	Mode	98
5.10.1.2	Rate	98
5.10.1.3	Tx clock	99
5.10.1.4	Rx clock	99
5.10.1.5	DATA	99
5.10.1.6	RTS	100
5.10.1.7	TTM	100
5.10.1.8	DCD	100
5.10.2	Port Status	101
5.10.2.1	Exit RTS LOS	101
5.10.2.2	CLK LOS DSR	101
5.10.2.3	CTS DCD	102
5.10.2.4	DSR RTS	102
5.10.3	Port Alarm	102
5.10.3.1	Alarm Setup	102
5.10.3.2	Alarm History	103
5.10.3.3	Alarm Clear	103
5.10.4	Port Loopback	104
5.10.4.1	Local Loopback	104
5.10.5	Clock Source	104
5.10.5.1	Master Clock	104
5.10.5.2	Second Clock	106
5.10.5.3	Current Clock	107
5.10.5.4	Recover Clock	107
5.10.5.5	Clock status	107
6	TERMINAL OPERATION.....	109
6.1	Main Menu.....	109
6.1.1	System Setup	110
6.1.1.1	System	110
6.1.1.2	Inband Management	111
6.1.1.3	Password.....	112
6.1.1.4	Port Speed Setup	112
6.1.1.5	Logoff	113
6.1.1.6	Logon	113
6.1.2	Time Slot IP Assignment	113
6.1.2.1	Bundle IP Setup	114
6.1.2.2	Time Slot IP Assignment	114
6.1.3	Firmware Transfer.....	117
6.1.3.1	Download Mainboard Firmware	118
6.1.3.2	Download Boot Strapper	118
6.1.3.3	Download Current Configuration.....	119
6.1.3.4	Upload Current Configuration from FLASH	119
6.1.4	Store/Retrieve Configuration.....	120
6.1.5	Clock Source Setup	121
6.1.6	System Alarm Setup	122
6.1.7	System Configuration.....	122
6.1.8	Display MAP IP Assignment	123
6.1.9	Clock source Configuration.....	123
6.1.10	Byte and Packet Counters	124
6.1.11	Alarm Queue.....	124
6.1.12	Load Default Configuration	125
6.1.13	Reset.....	125
6.1.14	Clear Alarm Queue & History	126
6.1.15	Alarm Cut Off	126
6.2	E1 Sub-Menu.....	127

6.2.1	System Setup.....	127
6.2.2	Loopback Setup	128
6.2.3	Alarm Setup	129
6.2.4	Chose Port	130
6.2.5	Clear Performance Data	130
6.2.6	Clear Alarm History	130
6.2.7	1-Hour Performance Report	131
6.2.8	24-Hour Performance Report	132
6.2.9	Line Availability	133
6.2.10	Unit Configuration	133
6.2.11	Unit Status	134
6.2.12	Unit Alarm History	134
6.3	T1 Sub-Menu	135
6.3.1	System Setup.....	135
6.3.2	Loopback Setup	136
6.3.3	Alarm Setup	136
6.3.4	Bert Test	137
6.3.5	Clear Performance Data	137
6.3.6	Clear Alarm History	137
6.3.7	1-Hour Performance Report	138
6.3.8	24-Hour Performance Report	138
6.3.9	Line Availability	139
6.3.10	Unit Configuration	139
6.3.11	Unit Status	140
6.3.12	Unit Alarm History	140
6.4	DTE (V.35) Sub-Menu	141
6.4.1	DTE Configuration	141
6.4.2	DTE Status.....	142
6.4.3	Alarm History	142
6.4.4	System Setup.....	143
6.4.5	Loopback Tsst.....	143
6.4.6	Alarm Setup	144
6.4.7	Clear Alarm History	144
6.5	DS3/E3 Sub-Menu	145
6.5.1	DS3/E3 System Setup	145
6.5.2	DS3/E3 Loopback Test	146
6.5.3	Clear Performance Data	146
6.5.4	DS3/E3 Alarm Setup	147
6.5.5	Clear Alarm History	147
6.5.6	DS3/E3 1-Hour Performance Report	148
6.5.7	DS3/E3 24-Hour Performance Report	149
6.5.8	DS3/E3 Line Availability	150
6.5.9	DS3/E3 System Setup	151
6.5.10	DS3/E3 Status	151
6.5.11	DS3/E3 Alarm History	152
7	STEP BY STEP OPERATION	153
7.1	Time Slot IP Assignment	153
7.1.1	Time Slot IP Assignment (Add bundle).....	153
7.1.2	Time Slot IP Assignment (Delete bundle).....	154
7.1.3	Time Slot IP Assignment (Delete all)	155
7.2	Password Setup	155
7.2.1	Enter old password	155
7.2.2	Enter new password	156
7.2.3	Confirmation of new password	156
7.3	Clock source setup	157
7.3.1	Application	158
7.3.1.1	Example of clock source	158
	For the clock source there are two examples to show as the table below.....	158

8	FUNCTIONAL DESCRIPTION	159
8.1	TDMoEthernet Packet Format.....	159
8.1.1	VLAN Option	160
8.1.2	UDP/IP Header	161
8.1.3	TDMoEthernet Control Word	162
8.1.4	TDMoEthernet Payload.....	163
8.2	AAL1 PAYLOAD TYPE MACHINE.....	164

LIST OF FIGURES

FIGURE 1- 1 APPLICATION DIAGRAM	2
FIGURE 2- 1 FRONT PANEL VIEW (WITH LCD).....	5
FIGURE 2- 2 FRONT PANEL VIEW (WITHOUT LCD).....	5
FIGURE 2- 3 REAR PANEL VIEWS	6
FIGURE 2- 4 MAIN BOARD JUMPERS SETTING-E1, RJ (120 OHM).....	8
FIGURE 2- 5 MAIN BOARD JUMPERS SETTING-E1, BNC (75 OHM).....	9
FIGURE 2- 6 MAIN BOARD JUMPERS SETTING - T1	10
FIGURE 2- 7 DAUGHTER BOARD JUMPERS SETTING - E1, RJ (120 OHM)	11
FIGURE 2- 8 DAUGHTER BOARD JUMPERS SETTING - E1, BNC (75 OHM).....	12
FIGURE 2- 9 DAUGHTER BOARD JUMPERS SETTING – T1	13
FIGURE 2- 10 INSTALLATION DIAGRAM (SINGLE)	14
FIGURE 2- 11 INSTALLATION DIAGRAM (DOUBLE)	14
FIGURE 2- 12 CHASSIS GROUNDING	15
FIGURE 3- 1 MANAGEMENT PORT	27
FIGURE 3- 2 ETHERNET PORT	27
FIGURE 4- 1 LOOPBACK BLOCK DIAGRAM	28
FIGURE 4- 2 FAR END DIAGRAM	29
FIGURE 8- 4 UDP/IP HEADER.....	161
FIGURE 8- 5 AAL1 PROCESSING.....	164
FIGURE 8- 6 AAL1 PROCESSING FOR STRUCTURED WITHOUT CAS BUNDLES	166

LIST OF TABLES

TABLE 2- 1 JUMPER SETTING FOR MAIN BOARD	7
TABLE 2- 2 JUMPER SETTING FOR DAUGHTER BOARD	11
TABLE 2- 3 DB9S CONSOLE PORT PIN ASSIGNMENT	15
TABLE 2- 4 SNMP PORT	15
TABLE 2- 5 ALARM RELAY CONNECTOR	16
TABLE 2- 6 POWER CONNECTOR	16
TABLE 2- 7 E1/ RJ48C LINE CONNECTOR	16
TABLE 2- 8 RJ-45 FOR ETHERNET PORT	16
TABLE 2- 9 V.35/DB25 DTE PORT PIN DEFINITION	17
TABLE 2- 10 EIA530/DB25 DTE PORT PIN DEFINITION	18
TABLE 2- 11 X.21/DB15 DTE PORT PIN DEFINITION	18
TABLE 2- 12 RS449/DB37 DTE PORT PIN DEFINITION	19
TABLE 2- 13 RS422 DTE PORT PIN DEFINITION	20
TABLE 2- 14 DEFAULT SOFTWARE CONFIGURATION	21
TABLE 3- 1 CONSOLE PORT SETTING	24
TABLE 3- 2 ALARM DEFAULT - FOR SYSTEM AND LINE	24
TABLE 3- 3 PERFORMANCE PARAMETER LIST - LINE	25
TABLE 3- 4 PERFORMANCE REPORT OPTIONS	25
TABLE 3- 5 LED INDICATION FOR MAIN UNIT	26
TABLE 7- 1 EXAMPLE 1: UNIQUE CLOCK SOURCE (FROM IP6700-1 LINE CLOCK OF PORT A)	158
TABLE 7- 2 EXAMPLE 2: INDEPENDENT CLOCK SOURCE	158
TABLE 8- 3 ETHERNET PACKET STRUCTURE	159
TABLE 8- 4 ETHERNET PACKET STRUCTURE (CONT.)	160
TABLE 8- 5 IP HEADER STRUCTURE	161
TABLE 8- 6 UDP HEADER STRUCTURE	162
TABLE 8- 7 TDMoETHERNET CONTROL WORD STRUCTURE	163
TABLE 8- 8 AAL1 HEADER STRUCTURE	165

- D** Bitte führen Sie das Gerät am Ende seiner Lebensdauer den zue Verfügung stehenden Rückgabe und Sammelsystemen zu.
- GB** At the end of the product's useful life, please dispose of it at appropriate collection points provided in your country
- F** Une fois le produit en fin de vie, veuillez le déposer dans un point de recyclage approprié.
- ES** Para preservar el medio ambiente, al final de la vida útil de su producto, depositelo en los lugares destinados a ello de acuerdo con la legislación vigente.
- P** No final de vida útil do producto, por favor coloque no ponto de recolha apropriado.
- I** Onde tutelare l'ambiente, non buttate l'apparecchio tra i normali rifiuti al termine della sua vita utile, ma portatelo presso i punti di raccolta specifici per questi rifiuti previsti dalla normativa vigente.
- NL** Wij raden u aan het apparatuur aan het einde van zijn nuttige levensduur, niet bij gewone huisafval te deponeren, maar op de daarvoor bestemde adressen.
- DK** Når produktet er udtaget, bør det bortskaffes via de særlige indsamlingssteder i landet.
- N** Ved slutten av produktets levetid bør det avhendes på en kommunal miljøstasjon eller leveres til en elektroforhandler.
- S** Lämna väntigen in produkten på lämplig återvinningsstation när den är förbrukad.
- FIN** Hävitä tuote käytöän päättymisessä viemällä se asianmukaiseen keräyspisteeseen.
- PL** Gdy produkt nie nadaje się dalszego użytka, należy go w jednym ze specjalnych punktów zajmujących się zbiórka zużytych produktów w wybranych miejscowościach na terenie kraju.
- CZ** Po skončení jeho životnosti odložte prosím výrobek na příslušném sběrném místě zřízeném dle předpisů ve vaší zemi.
- SK** Po skončení jeho životnosti odovzdajte prosím zariadenie na príslušnom zbernom mieste podľa platných miestnych predpisov a noriem.
- SLO** Ko se izdelku izteče življenska doba, ga odnesite na ustrezno zbirno mesto oziroma ga odvrzite v skladu z veljavnimi predpisi.
- GR** Στο Τέλος της λειτουργικής Ζωής του προϊόντος παρακαλώ Πετέτε το στα ειδικά σημεία που Παρέχονται από χωρα σας.
- PRC** 當產品使用壽命結束，請在你的國家所提供的適當地點做好回收處理



1 PRODUCT DESCRIPTION

1.1 Description

Loop-IP6700 TDMoEthernet is designed to transport E1/T1/DTE/E3/DS3 signal with timing plus Ethernet traffic over IP network, electrical or optical. This is a cost effective way of migrating to IP network from existing voice and data network using existing TDM based equipment.

TDMoEthernet is a system that could be used to transport multiple E1, T1, DTE, E3, DS3, and 10/100BT Ethernet traffic through 10/100BT Ethernet. The number of E1/T1/DTE/DS3 interfaces can be factory optioned from 1 to 4 (4 T1 / 4 E1 / 2 DTEs / 1 E3 / 1 DS3 Max.). TDMoEthernet has built-in AC or DC power, console port, Ethernet port, and SNMP port with inband management for remote.


1.2 Features

The features for Loop-IP6700:

- Support- E1 / T1 on the main board
 - E1 / T1 / V.35 / E3 / DS3 on the daughter board
- E1/T1 interfaces: 1 to 4 framed or unframed with BNC/RJ connectors
- LAN interface: one 10/100 BT Ethernet
- WAN interface: 10/100 Base-Tx UTP or standard open Fiber slot for SFP Transceiver
- Each port timing source can be chosen from:
 - (a) Internal
 - (b) External (for low speed card only)
 - (c) from its own or other's line/ WAN
- Alarm relay
- Console port, Ethernet, SNMP
- Inband management: through any time slot of the transported E1
- Support VLAN packet transparency i.e. up to Max 1536 bytes
- Multi-color LED indicators
- LCD/Keypad


1.3 Applications

For Low Speed



Management

For High Speed



Management

Figure 1- 1 Application Diagram

Chapter 2 Installation

1.4 Specification

Network Interface (E1):

Line rate	2.048 Mbps ± 50ppm	Input signal	ITU G.703
Framing	ITU G.704	Output signal	ITU G.703
Line code	AMI/HDB3	Jitter	ITU G.823
Connector	BNC and RJ48C	Electrical	75 ohm coax/120 ohm twisted pair

Network Line Interface (T1):

Line rate	1.544 Mbps ± 32 ppm	Input signal	DS-1 from 0 dB to -26 dB w/ALBO
Framing	D4/ ESF/ ESF&T1.403/ NONE (Clear Channel)	Output signal	DSX-1, DS-1
Line code	AMI / B8ZS	Surge Protection	FCC Part 68 Sub-Part D
Connector	RJ48C	Pulse Template	Per AT&T TR 62411

NOTE:

Large configurable jitter buffers, on a per bundle basis, that compensate for the delay variation introduced by the IP/MPLS network, with the following maximal depths:

For E1: up to 256 ms

For unframed T1: up to 340 ms

For framed T1: up to 256 ms

For framed T1 with CAS: up to 192 ms

Ethernet (WAN)

Connector	RJ45
Speed	10/100 Base T

Optical (WAN)

Connector	SFP 3.3V
Speed	10/100 Base-FX

DTE Interface (V.35)

Data Rate	n x 56 (n= 1 to 31)
Data Rate	n x 64 Kbps (n= 1 to 32)
Connector	DB25S for V.35
Standard	

External Clock

Input signal	ITU G.703
Connector	BNC
Input signal	

Network Management

Console Port

Connector	DB9 at Front Panel
Electrical	RS232 interface
Protocol	Menu driven VT-100 terminal

Alarm Relay

Alarm Relay	Fuse alarm, performance alarm
Connector	3 pin terminal block

SNMP Port

Connector	RJ45 at front panel
Protocol	Telnet (VT100) and Embedded SNMP

Inband Management

Any 64 Kbps DS0 can be assigned for management
HDLC Management Protocol

Performance monitor(T1,E1)

Performance store	The last 24 hours performance in 15-minute intervals
Monitor registers	Line, user and remote site
Performance reports	Date &Time, Error second, Degraded minutes, Unavailable second, Bursty error second, severe error second, controlled slip second, and loss of frame count
Alarm history	Date & time, alarm type(i.e. master clock loss, RAI, AIS, LOS, BPV, ES, CSS)
Threshold	Second, degrade minutes

Diagnostics test(T1, E1)

Loopback	Line loopback, payload loopback and local loopback
Remote loopback	Line loopback and payload loopback

Front Panel

Keypad / LCD (future option)

LED

Physical

Dimensions	212.6 x 43.7 x 197 mm. (WxHxD)	Power	Single AC power or DC power.
Temperature	0 -50 °C	DC: 20 to 72 Vdc	
Humidity	0-95% RH (NON-CONDENSING)	AC: 100 to 240 Vac, 50/60Hz	
Mounting	Desk-top stackable, wall mount	Power Consumption: 10W Max	

Compliance Standard:

G.823/G.824, G.826, TDMoEthernet for structured traffic, SATOP for unstructured traffic

2 INSTALLATION

2.1 Site Selection

The following list indicates a site selection guideline. Users need to follow this guideline to select a proper installation site.

Location of the Loop-IP6700 unit should be part of the central office equipment layout design. Considerations should be given to entrance cable routing.

The installation site should provide proper room for adequate ventilation and cable routing. Reserve at least 0.5 m at the rear of the unit for human access, cables, and air flow.

The site should provide a stable environment. The operating area should be clean and free from extremes of temperature, humidity, shock, and vibration.

Relative humidity should stay between 0 and 95%.

Chapter 2 Installation

2.2 Mechanical Installation

Loop-IP6700 is a desk top unit, which offers installation for power supply: on board fixed. The front panel is shown in Figure 2-1, and the rear panel is shown in Figure 2-2.




Figure 2- 1 Front Panel View (with LCD)




Figure 2- 2 Front Panel View (without LCD)

Chapter 2 Installation

There are 4 models of Loop IP6700 available. The models are shown in the following figures.

Rear Panel





Figure 2-3 Rear Panel Views

Chapter 2 Installation


Table 2- 1 Jumper Setting for Main Board

PORT	A			B		
PART	JP6, JP8, JP10, JP11	JP5	JP22	JP14, JP16, JP18, JP19	JP13	JP22
E1 120	PIN (2,3) ON	OFF	PIN (1,2) OFF PIN (3,4) OFF	PIN (2,3) ON	OFF	PIN (5,6) OFF PIN (7,8) OFF
E1 75	PIN (1,2) ON	PIN (2,3) ON	PIN (1,2) OFF PIN(3,4) ON	PIN (1,2) ON	PIN (2,3) ON	PIN (5,6) OFF PIN (7,8) ON
T1 100	PIN (2,3) ON	PIN (1,2) ON	PIN (1,2) ON PIN (3,4) OFF	PIN (2,3) ON	PIN (1,2) ON	PIN (5,6) ON PIN (7,8) OFF
No card			PIN (1,2) ON PIN (3,4) ON			PIN (1,2) ON PIN (3,4) ON




Main Board

RJ (120 ohm) E1






ON OFF

Figure 2- 4 Main Board Jumpers Setting-E1, RJ (120 ohm)



Main Board

BNC (75 ohm) E1



ON OFF

Figure 2- 5 Main Board Jumpers Setting-E1, BNC (75 ohm)




Figure 2- 6 Main Board Jumpers Setting - T1

Chapter 2 Installation

Table 2- 2 Jumper Setting for Daughter Board

PORT C OR D	T1/E1 Daughter Card	JP1	JP2	JP12	JP4
PART	JP5, JP7, JP9, JP10	JP1	JP2	JP12	JP4
E1 120	PIN (2,3) ON	OFF	OFF	ON	OFF
E1 75	PIN (1,2) ON	OFF	ON	ON	PIN (2,3) ON
T1 100	PIN (2,3) ON	ON	OFF	ON	PIN (1,2) ON




Figure 2- 7 Daughter Board Jumpers Setting - E1, RJ (120 ohm)




Figure 2- 8 Daughter Board Jumpers Setting - E1, BNC (75 ohm)




Figure 2- 9 Daughter Board Jumpers Setting – T1

Chapter 2 Installation




Figure 2- 10 Installation Diagram (Single)




Figure 2- 11 Installation Diagram (Double)

Chapter 2 Installation

Chassis Grounding

The chassis is grounded when rack mounted. However, for stand alone units or extra grounding protection for rack mounted units, a dedicated chassis ground screw and lock washer is provided. The chassis ground screw is located on the right side of rear panel.

When attaching a ground wire to the chassis ground screw, please follow these instructions:

- Use copper grounding conductors of 18 AWG
- Conductors should not be of dissimilar metals.
- The bare conductors should be coated with anti-oxidant before crimp connections are made.
- Unplated connection surfaces, connectors, braided strap and bus bars must be bought to a bright finish and coated with anti-oxidant before connections are made.
- Listed connectors and fastening hardware must be used.




Figure 2- 12 Chassis Grounding

Console port can be connected via RS232 interface to a configuration device a VT100 terminal or equivalent. Pin definition and pin connection of the console port are listed in the following table.

Table 2- 3 DB9S Console Port Pin Assignment

Pin Number	Signal	Description
1	Data Carrier Detect	To DTE
2	Receive Data	To DTE
3	Transmit Data	From DTE
4	Unassigned	
5	Signal Ground	
6	Data Set Ready	To DTE
7	Unassigned	
8	Clear to send	To DTE
9	Unassigned	

Table 2- 4 SNMP Port

Pin Number	Signal	Description
1	TPTX+	TP Driver Output
2	TPTX-	
3	TPRX+	TP Receive Input
6	TPRX-	
7	Chassis GND	
8	Chassis GND	

Chapter 2 Installation

Table 2- 5 Alarm Relay Connector

Pin Number	Signal	Description
1	NC	Normal Close
2	COM	Common
3	NO	Normal Open

Table 2- 6 Power Connector

Pin Number	Signal	Description
1	-V	-DC 48 Volts
2	+V	+DC Return
3	⏚	Chassis Ground

Table 2- 7 T1/ E1/ RJ48C Line Connector

Pin Number	Signal	Signal Direction
1	Receive Ring	Input to IP6700
2	Receive Tip	Input to IP6700
4	Transmit Ring	Output from IP6700
5	Transmit Tip	Output from IP6700
7	Unassignment	
8	Unassignment	

Table 2- 8 RJ-45 for Ethernet Port

Pin Number	Signal	Signal Direction
1	Transmit Data +	Output from IP6700
2	Transmit Data -	Output from IP6700
3	Receive Data +	Input to IP6700
4	No Connection	
5	No Connection	
6	Receive Data -	Input to IP6700
7	No Connection	
8	No Connection	

Chapter 2 Installation

The DTE port is configured as a DCE device. There are 5 different DTE boards: V.35/DB25, EIA530/DB25, X.21/DB15, RS449/DB37 and RS422. Pin definitions are defined in Table 2-9 to 2-13.

Table 2- 9 V.35/DB25 DTE Port Pin Definition

Pin Number	Signal	Source
1	Cable Shield	
2	Transmit Data	DTE
3	Receive Data	DCE
4	Request To Send	DTE
5	Clear To Send	DCE
6	Data Set Ready	DCE
7	Signal Ground	
8	Data Carrier Detect	DCE
9	Receive Clock Return	DCE
10	Unassigned	
11	External Clock Return	DTE
12	Transmit Clock Return	DCE
13	Unassigned	
14	Transmit Data Return	DTE
15	Transmit Clock	DCE
16	Receive Data Return	DCE
17	Receive Clock	DCE
18	Local Loopback	DTE
19	Unassigned	
20	Data Terminal Ready	DTE
21	Remote Loopback	DTE
22	Unassigned	
23	Unassigned	
24	External Clock	DTE
25	Test Mode	DCE

Chapter 2 Installation

Table 2- 10 EIA530/DB25 DTE Port Pin Definition

Pin Number	Signal	Source
1	Cable Shield	
2	Transmit Data	DTE
3	Receive Data	DCE
4	Request To Send	DTE
5	Clear To Send	DCE
6	Data Set Ready	DCE
7	Signal Ground	
8	Data Carrier Detect	DCE
9	Receive Clock Return	DCE
10	Data Carrier Detect Return	DCE
11	External Clock Return	DTE
12	Transmit Clock Return	DCE
13	Clear To Send Return	DCE
14	Transmit Data Return	DTE
15	Transmit Clock	DCE
16	Receive Data Return	DCE
17	Receive Clock	DCE
18	Local Loopback	DTE
19	Request To Send Return	DTE
20	Data Terminal Ready	DTE
21	Remote Loopback	DTE
22	Data Set Ready Return	DCE
23	Data Terminal Ready Return	DTE
24	External Clock	DTE
25	Test Mode	DCE

Table 2- 11 X.21/DB15 DTE Port Pin Definition

Pin Number	Signal	Source
1	Cable Shield	
2	Transmit Data	DTE
3	Control	DTE
4	Receive Data	DCE
5	Indication	DCE
6	Signal Timing	DCE
7	External Clock	DTE
8	Signal Ground	
9	Transmit Data Return	DTE
10	Control Return	DTE
11	Receive Data Return	DCE
12	Indication Return	DCE
13	Signal Timing Return	DCE
14	External Clock Return	DTE
15	Unassigned	

Chapter 2 Installation

Table 2- 12 RS449/DB37 DTE Port Pin Definition

Pin Number	Signal	Source
1	Cable Shield	
2	Unassigned	
3	Unassigned	
4	Transmit Data	DTE
5	Transmit Clock	DCE
6	Receive Data	DCE
7	Request To Send	DTE
8	Receive Clock	DCE
9	Clear To Send	DCE
10	Local Loopback	DTE
11	Data Set Ready	DCE
12	Data Terminal Ready	DTE
13	Data Carrier Detect	DCE
14	Remote Loopback	DTE
15	Unassigned	
16	Unassigned	
17	External Clock	DTE
18	Test Mode	DCE
19	Signal Ground	
20	Unassigned	
21	Unassigned	
22	Transmit Data Return	DTE
23	Transmit Clock Return	DCE
24	Receive Data Return	DCE
25	Request To Send Return	DTE
26	Receive Clock Return	DCE
27	Clear To Send Return	DCE
28	Unassigned	
29	Data Set Ready Return	DCE
30	Data Terminal Ready Return	DTE
31	Data Carrier Detect Return	DCE
32	Unassigned	
33	Unassigned	
34	Unassigned	
35	External Clock Return	DTE
36	Unassigned	
37	Unassigned	

Chapter 2 Installation

Table 2- 13 RS422 DTE Port Pin Definition

Pin Number	Signal	Source
1	Cable Shield	
2	Transmit Data	DTE
3	Receive Data	DCE
4	Request To Send	DTE
5	Clear To Send	DCE
6	Data Set Ready	DCE
7	Signal Ground	
8	Data Carrier Detect	DCE
9	Receive Clock Return	DCE
10	Data Carrier Detect Return	DCE
11	External Clock Return	DTE
12	Transmit Clock Return	DCE
13	Clear To Send Return	DCE
14	Transmit Data Return	DTE
15	Transmit Clock	DCE
16	Receive Data Return	DCE
17	Receive Clock	DCE
18	Unassigned	
19	Request To Send Return	DTE
20	Data Terminal Ready	DTE
21	Unassigned	
22	Data Set Ready Return	DCE
23	Data Terminal Ready Return	DTE
24	External Clock	DTE
25	Unassigned	

Chapter 2 Installation

Table 2- 14 Default Software Configuration

Configuration	Option	Default
E1 Line	Frame	ON:OFF
	Code	HDB3, AMI
	CRC	ON, OFF
	RAI	ON:OFF
	FDL	OFF, FDL, HDLC
	IDLE	0-ff
	S-Bit	Sa4, Sa5....Sa8, Sa4+5
	CAS	ON:OFF
	I/F	RJ, BNC
Clock	Master Clock	Line, Internal, External, Bundle 0
	2nd Clock	Line, Internal, External, Bundle 0
	Current Clock	Master, 2 nd , Internal
	Clock_Recover_Mode	MANUAL, AUTO
Console port	Baud rate	2400, 4800, 9600, 19200, 38400
	Data length	8-bits, 7-bits
	Stop bits	1-bit, 2-bits
	Parity	NONE, EVEN, ODD
Ethernet port		
Speed/Duplex	SNMP	AUTO, FULL_100M, HALF_100M, FULL_10M, HALF_10M
	WAN	AUTO, FULL_100M, HALF_100M, FULL_10M, HALF_10M
	LAN	AUTO, FULL_100M, HALF_100M, FULL_10M, HALF_10M
Network management	IP address	0.0.0.0
	Subnet mask	0.0.0.0
	Gateway IP	0.0.0.0
SNMP	Trap IP	0.0.0.0
	Community Name	Public
	Device name	IP6700

Note:

1.Frame

For the E1 line interface, the frame format is ITU G.704. Either 2-frame, or 16-frame structure can be selected. E1 supports clear channel mode, called E1 FRAME OFF mode, which can map to E1 same mode.

2.Code

For the E1 line interface, either AMI (Alternate Mark Inverting) or HDB3 (high density bipolar of length 3) line code format can be chosen, be sure this setting matches that of the network.

Chapter 2 Installation

3. CRC

For the E1 line interface, the frame format is ITU G.704. Either 2-frame, or 16-frame structure can be selected. Only the 16-frame provides CRC (Cycle Redundancy Check).

For two frame mode, set CRC to OFF. For multiframe mode, set CRC to ON.

E1 can be used in two frames or multiframe mode. If CRC is OFF, 2 frame format results. If CRC is ON, 16 frame format results. For E1, the cyclic redundancy check function can be turned ON or OFF. Unlike bipolar violation, which can monitor only one span, CRC allows error monitoring through multiple spans of DS0 lines. For E1, if CAS is ON, a 16-frame structure is used, which is independent of the 16-frame structure for CRC. A proprietary facility data link is implemented in both modes to facilitate remote system control and performance and statistics monitoring.

4. RAI

Remote Alarm Indication, transmits a return signal back out to indicate loss of signal and loss of frame sync at the receiving side if the port. This action can be turned ON or OFF.

5. AIS

AIS, alarm indication signal, notify the far end that a loopback and diagnostic test are in progression. Thus customer signals are blocked. The AIS can be sent two ways. In the framed mode, all time slots will have all ones sent but the framing pattern will be preserved. In the unframed mode, all ones are sent for all time slots.

6. CAS

CAS (Channel-Associated Signaling) is a method for sending signaling information where time slot 16 of the E1 format is shared for each of 30 other time slots within the same E1. Off designation is for CAS disabled. For E1, when disabled, the 256N multiframe is used when time slot 16 is available to the user. The maximum number of time slots available for payload is 31. ON designation is for CAS enabled. When enabled, the 256S multiframe is used when time slot 16 is reserved for the transmission for end-to-end signaling using CAS. The maximum number of time slots available for payload is then 30.

7.CGA

Carrier Group Alarm, CGA, is necessary for proper operation of the switched network in the face of possible faults of the transport system. In the “normal” option, when a carrier facility fails, the switching system must be notified so that it should cease to use that facility until repair is made. In the “transparent” option, the signaling bits are left alone in fault conditions.

8.OOS

Out Of Service Signaling, for normal CGA option, when failure of the facility occurs, if there are calls in progress, the billing system should be notified to stop charging the customer at the time of facility failure.

9.FDL

FDL for E1 is used to achieve remote system Loopback.

10.IDLE

Any DS0 time slot, which is not assigned is an idle time slot. An idle code is transmitted on idle DS0 time slots. The idle time slot may be programmed to any bit pattern from 0x00 to 0Xff.

11.INTF

E1 interface only display 120 Ohm twisted pair / 75 Ohm BNC.

3 OPERATION

This chapter describes the Loop-IP6700 configuration options and operational functions. User should refer to CHAPTER 6: TERMINAL OPERATION for detailed operation.

3.1 Quick Start for Loop-IP6700

After installation, the user may want to familiarize with the equipment immediately. The following abbreviated instructions will give the user a quick start.

3.1.1 Power On

Turn power on by attaching power cable at the rear of the unit.

Return to Default Setting.

The unit is shipped with factory default setting.

3.2 Self Test

If password is enabled, users must enter the password when logging in to gain the privilege to change system configurations on the terminal. The default condition is password disabled. The default password is LOOP. To change the password for the first time, enter the default password when prompted for the old password. If the password is forgotten, the only recourse is to return to the factory setting of LOOP.

3.3 Return to Default

The unit is shipped with factory default setting.

To restore to factory setting in the future, immediately after power on, and during the display of "ESC" on the LCD, press ESC key followed by pressing ENTER when "RET" is displayed. Unit will confirm with LOAD DEFAULT CONFIGURATION.

3.4 Using Terminal

Management from a Telnet or Network Management System (NMS) can be effected through a LAN. Use the DB9S console port of IP6700's rear panel to connect a VT100 terminal to configure the unit. The VT100 terminal can be a PC running a VT100 emulator software.

Upon connection, press ENTER and ESC alternately to bring the main menu into view.

Under the "Main Menu", press "O" (Log On) to see the full menu.

Under the "Main Menu", press "S" to change the system configuration.

For more detail information, see also the chapter 6 in this menu.

3.5 System Configuration

3.5.1 Console Port

The console port allows the user either to use a local VT-100 terminal or use a remote VT-100 terminal via modem for system configuration, diagnostics, polling status reports, etc. The console port Baud rate, data bit length, stop bit length, and parity bit length are defaulted, as shown below.

Table 3- 1 Console Port Setting

Item	Fixed Setting
Baud	9600
Data Length	8-Bits
Stop Bit	1-Bits
Parity	NONE

3.6 Alarm

When the Loop-IP6700 reports an alarm condition, such as loss of synchronization, the ALARM will cause the LED on the front panel to light. Each alarm can be individually enabled or disabled. The alarm types are listed in the table as below.

Table 3- 2 Alarm Default - for System and Line

Alarm		Option	Default
E1 Line	RAI	DISABLE, ENABLE	MAJOR
	AIS	DISABLE, ENABLE	MAJOR
	LOS	DISABLE, ENABLE	MAJOR
	LOF	DISABLE, ENABLE	MAJOR
	BPV	Alarm	DISABLE, ENABLE
		Threshold	10E- (5, 6, 7, 8, 9)
	ES	Alarm	DISABLE, ENABLE
		Threshold	1-900
	UAS	Alarm	DISABLE, ENABLE
		Threshold	1-900
E1	CSS	Alarm	DISABLE, ENABLE
		Threshold	1-900
	Bundle	Status	DISABLE, ENABLE
	Mac	Change	DISABLE, ENABLE
T1 (future option)			
DTE (future option)	V.35		
Ethernet			

3.7 Reports

For DS1 line receiver, Loop-IP6700 has three sets of performance registers. These are line, user, and far-end. The line performance register tracks the DS1 line receiver performance status. The user performance register tracks the DS1 line receiver as well, but user may clear at any time. The far-end performance register tracks the far-end DS1 receiver status. The performance parameters are listed in the following tables. Each performance parameter has ninety six sets of registers to record 24 hours history in 15 minute intervals.

Table 3- 3 Performance Parameter List - LINE

Performance Parameter	Description	Definition 2-Frame/Multiframe	Definition 16-Frame/Multiframe
BPV	Bipolar Violation	Bipolar Error Count	Bipolar Error Count
ES	Error Second	$\text{BPV} \geq 1$, $\text{OOF} \geq 1$, or $\text{CS} \geq 1$.	$\text{CRC} \geq 1$, $\text{OOF} \geq 1$, or $\text{CS} \geq 1$.
UAS	Unavailable Second	≥ 10 consecutive SES	≥ 10 consecutive SES

Below lists the types of reports available, performance parameters provided by each report, and the reset commands for each report.

Table 3- 4 Performance Report Options

Report Type [Menu Command]	Category	Report					
		ES	BES	SES	UAS	AS	EFS
1-Hour Terminal Reports Menu Option [1]	USER [Network]	Y	Y	Y	Y	Y	Y
	LINE [Network]	N/C	N/C	N/C	N/C	N/C	N/C
24-Hour Terminal Reports Menu Option [2]	USER [Network]	Y	Y	Y	Y	Y	Y
	LINE [Network]	N/C	N/C	N/C	N/C	N/C	N/C

Y = Report available and can be cleared by front panel "RESET" or admin terminal command "Y".

X = Report available and can be cleared by front panel "RESET" or admin terminal command "X".

N/C = No clear. Report available, but counts cannot be cleared by the user.

- = Report not available.

3.8 LED

The front panel of the Loop-IP6700 has multi-color LEDs for operation and error indications. The indication is either off, steady on, or flickering. The following table lists each LED and its color and the meaning it represents. Note that when powering up and self test is in progress, the unit front panel LEDs are also used to indicate fault conditions.

Table 3- 5 LED Indication for Main Unit

LED		Color	Indication
POWER		Off	Power off, self-test failure
SNMP /WAN/ LAN	LINK/A CT	Flashing Green	Normal operation
		Red	Alarm occurs
E1 V.35 (A, B, C, D)	10/100	Green	Link. A valid network connection on the RJ-45 SNMP port.
		Flashing Green	Activity. Data is being transmitted or received through the RJ-45 SNMP port.
E1 V.35 (A, B, C, D)	10/100	Off	10Mbps
		Green	100Mbps
		Green	Normal (Line in Sync)
		Flashing Green	Testing
E1 V.35 (A, B, C, D)	10/100	Red	Loss of Frame (LOF) or Loss of Signal (LOS)
		Flashing Red	Alarm Indication Signal (AIS)

3.9 Management Port (SNMP Port)

As two IP6700s are connected: one is set as local unit, the other is set as remote unit. See also the following diagram.




Figure 3- 1 Management Port

3.10 User Data Port (Ethernet)

IP6700's User Data Port is used to transmit or receive data only no matter IP6700 is set as Ethernet.




Figure 3- 2 Ethernet Port

4 MAINTENANCE

4.1 Self-Test

When the Loop-IP6700 is powered up, a complete self-test routine is run to check all I/O ports, read/write memory, and data paths to validate system integrity. During system self test, "TESTING" message and testing code are shown on the VT100 terminal screen. If any error is found, a testing code is shown on the VT100 terminal display. Various system diagnostic methodology can be found in the following paragraphs.

4.2 Near End Loopback

The near end loopbacks such as digital local loopback, and line loopback are activated by the Loop-IP6700. The loopbacks are at the near end facility. The following paragraph describes each loopback in detail.

4.2.1 E1/T1 Line Loopback

Line loopback is illustrated in Figure 4-1. The incoming optical line signal is loopback to the outgoing optical signal before the optical mapper. This loopback is used to isolate the local equipment from a troubled optical transmission line. Line loopback test can be activated from the terminal.

4.2.2 E1/T1 Payload Loopback

Payload loopback is illustrated in Figure 4-1. The incoming signal is loopback to the outgoing line signal after the optical mapper. This loopback is used to isolate the TSI from the troubled transmission line. Payload loopback test can be activated from the front panel and terminal.




Figure 4- 1 Loopback Block Diagram

4.3 Far End Loopback

Far-end loopbacks (remote line loopback, remote payload loopback, remote channel loopback, U-PORT loopback, and HDSL loopback) can be activated by the local IP6700 to cause a remote loopback commands to the far-end facility. Inband code words are supported by FDL (facility data link) to initiate the loopback in the case of the DS1 line, and either M channel in the case of the U-interface line. When using FDL messages, FDL must be turned ON. All remote loopback can be activated from the terminal.

If the remote facility responds to a remote loopback activate command, a LOOPED message appears in the lower left corner of the display. If the remote facility responds to a remote loopback deactivate command, a NO LOOP message appears. If the remote activation/deactivation fails, an error message appears.

Either proprietary remote loopback commands can be used, or the industry standard V.54 loopback codes can be used.

It is best to use remote loopbacks in conjunction with PRBS diagnostics testing to measure the DS1 network line or U line integrity. The procedure is as follows:

1. Send a remote loopback command to cause the remote facility to perform a loopback.
2. Activate the PRBS or QRSS diagnostics test.
3. The far end loopback is illustrated in Figure 4-2.




Figure 4- 2 Far End Diagram

5 FRONT PANEL OPERATION

The front panel LCD utilizes a 2-line by 16-character display and four keys labeled ESC, ENTER, left arrow '<', and right arrow '>', as shown in Figure 5-1. The ENTER key is to enable a selection, while the left and right arrow keys move the cursor to the left and right respectively. The ESC key returns to the next higher level of selection or to the main menu without performing any operation. When the menu selected has no further sub-menus, the current item selected is indicated by '*'.

NOTE: For each selection or change, ENTER key must be pressed to confirm.




Figure 5-1 Front Panels

Chapter 6 TERMINAL OPERATION

The entire LCD menu tree is shown below. By successively selecting the menu item at each level, the desired operation or display can be obtained. Use left or right key to select the desired main menu branch and press ENTER.




Figure 5- 2 LCD Menu Tree

Chapter 6 TERMINAL OPERATION




Figure 5- 3 E3/DS3 LCD Menu Tree

Chapter 6 TERMINAL OPERATION




Figure 5- 4 E1 LCD Menu Tree

Chapter 6 TERMINAL OPERATION




Figure 5- 5 T1 LCD Menu Tree

Chapter 6 TERMINAL OPERATION




Figure 5- 6 DTE LCD Menu Tree

5.1 Configuration

Configuration group includes System and Console Port menus.

IP-6700
System

5.1.1 System

Press ENTER from the above menu to enter into the System menu, which includes Ethernet, Lan port, Bun ACT Timer, LPT Timer Lan Rate, CAS Idle code, Remote loss, IP, Date, Time, and SNMP submenus.

System
Configuration

5.1.1.1 Ethernet

Presses ENTER from the System menu. Use arrow keys to select ENABLE or DISABLE, then press ENTER. Please refer to the 6.1.7 for detail information.

System
Ethernet

Ethernet
ENABLE

Ethernet
DISABLE

5.1.1.2 Lan Port

Press ENTER from the System menu. Use arrow keys to select Lan Port, then press ENTER. Please refer to the 6.1.1.1 for detail information.

System
Lan Port

Lan Port
Data_only

Data_only
D+S S-on




```
Data_only  
D+S S-off
```

5.1.1.3 Bun ACT Timer

Press ENTER from the System menu. Use arrow keys to select Bun ACT Timer, then press ENTER. Bun ACT Timer is used to setup the regular time to do activation. When the local side sets up a bundle, a signal is sent to see if the remote side is online or not. When the local side and the Remote side are both on line, the activation can be done.



```
System  
Bun ACT Timer
```




```
Bun ACT Timer  
1-9999(number)
```

5.1.1.4 LPT Timer

Press ENTER from the System menu. Use arrow keys to select LPT Timer, then press ENTER. When remote side through FDL ask to do Loopback, Local side will do time setup. After time setup it will cancel Loopback automatically.



```
System  
LPT Timer
```




```
LPT Timer  
1-9999(number)
```

5.1.1.5 Lan Rate

Press ENTER from the System menu. Use arrow keys to select Lan Rate, then press ENTER. The speed of LAN+WAN is 100M. The user can setup the speed of LAN in order to keep the WAN rate.



```
System  
Lan Rate
```




```
Lan Rate  
1-9999(number)
```

Chapter 6 TERMINAL OPERATION


5.1.1.6 CAS Idle code

Press ENTER from the System menu. Use arrow keys to select CAS Idle code, then press ENTER. The code of CAS Rate can choose the number form 1 to 15.




5.1.1.7 Remote loss

Press ENTER from the System menu. Use arrow keys to select Remote loss, then press ENTER. When the user cannot receive bundle packet from others, it will still send user's bundle packet. After the user presses the stop, the user will not send any information to others. In addition, the user will stop send information to others.



5.1.1.8 IP

The IP menu allows modification of device IP address, IP address for Subnet Mask and Gateway, and IP interface. Each IP address can be modified by moving the cursor to the desired position and selecting a number. After making all changes, select YES to save the changes.





5.1.1.9 Date

Press ENTER from the System menu. Use arrow keys to select Date, then press ENTER. This is used to setup the system data.




5.1.1.10 Time

This menu is used to setup the system time.



5.1.1.11 SNMP

This menu is used to select SNMP. Under Main menu, use left or right key to select SNMP menu. Under SNMP sub-menu, use arrow keys to select a desired option. Its sub-menus include these options: Trap IP1, Trap IP2, TrapIP3, Trap IP4, Trap IP5, Community get and Community set.



Chapter 6 TERMINAL OPERATION

Trap IP2
000.000.000.000

Trap IP3
000.000.000.000

Trap IP4
000.000.000.000

Trap IP5
000.000.000.000

Community get
XXXXX(test)

Community set
XXXXX(test)

5.1.1.12 Device Name

This menu is used to setup the Device Name.

System
Device Name

To rename the device name, use arrow keys to select a desired number or character, press ENTER. Then move the cursor at OK, press ENTER to enable the device name.

Device Name
XXXXX(test)


5.2 Bundle Setup

The menus are used to configure console port to select Source IP, Source subnet, Gateway IP, Port select, Bundle ID, Action, UDP number, Timeslot from, Timeslot num, Destination IP, Cell in bundle, Jitter delay, Jitter size, Vlan, Vlan1 ID, Vlan1 priority, Vlan2 ID, Vlan2 priority, Bundle status, and Confirm. Under Bundle setup menu, use left or right key to select Console Port menu. Press ENTER to enter into its submenus.




5.2.1 Source IP

Under IP menu, move the cursor to the Source-IP option; the system will show Source IP Address as below.




5.2.2 Source subnet

Under IP menu, move the cursor to the Source-subnet option; the system will show Source Subnet Address as below.



5.2.3 Gateway IP

If source IP and destination IP are not in a LAN the user must setup the LAN router address to the Getway IP.




5.2.4 Port Select

Under Port Select menu, the user can select what port they want to setup.



5.2.5 Bundle ID

Move the cursor to select Bundle ID, press ENTER. Please refer to 6.1.2.2 (table of Maximum Bundle Allocation) for detail information.



5.2.6 Action

The Action has two options, "Add bundle" and "Delete bundle". Move the cursor to select action, press ENTER.



Action
Delete bundle

Action
Delete all

Action
Active all

Action
Change bundle

Action
Stop Tx bundle

5.2.7 UDP number

There are 4 ports to have UDP number from 1 to 8063. If one port gets UDP number such as 100, another port cannot use same UDP number (refer to Figure 6-1 for detail). Move the cursor to select UDP number, press ENTER.

Bundle Setup
UDP number

UDP number
1-8063(number)

5.2.8 Timeslot from

To modify the Timeslot from, first move the cursor to the digit to be modified. Press enter.

Bundle Setup
Timeslot from

Timeslot from
1-31(number)

5.2.9 Timeslot num

To modify the Timeslot num, first move the cursor to the digit to be modified. Press enter.

Bundle Setup
Timeslot num

Timeslot num
1-31(number)

5.2.10 Destination IP

The Destination Address field identifies the station or stations that are to receive the packet. The Source Address identifies the station that originated the packet. A Destination Address may specify either an "individual address" destined for a single station, or a "multicast address" destined for a group of stations. A Destination Address of all 1 bits refers to all stations on the LAN and is called a "broadcast address". Move the cursor to select Destination IP, press ENTER.

Bundle Setup
Destination IP

Destination IP
000.000.000.000

5.2.11 Cell in bundle

In one bundle, how many cell will include (refer to Figure 8-5 for detail). Move the cursor to select Cell in bundle, press ENTER.


Bundle Setup
Cell in bundle

Cell in bundle
1-31(number)

5.2.12 Jitter delay

Move the cursor to select Jitter delay, press ENTER. The number is from 1 to 512. Total delay buffer n × 0.5 ms max.

Bundle Setup
Jitter delay



```
Jitter delay  
1-512(number)
```

5.2.13 Jitter size

Move the cursor to select Jitter size, the number is from 1-512, press ENTER. Packet delay cannot $\geq n \times 0.5$ ms.



```
Bundle Setup  
Jitter size
```



```
Jitter size  
1-512(number)
```

5.2.14 Vlan

Move the cursor to select Current Vlan press ENTER. Under Vlan sub-menu, use arrow keys to select a desired option.


Their submenu includes these options: OFF, 1-VLAN and 2-VLAN



```
Bundle Setup  
Vlan
```



```
Vlan  
OFF
```



```
Vlan  
1-VLAN
```



```
Vlan  
2-VLAN
```

5.2.15 Vlan1 ID

To modify the Vlan1 ID, first move the cursor to the digit to be modified. Press enter.



```
Bundle Setup  
Vlan1 ID
```

```
Vlan1 ID  
1-4095(number)
```

5.2.16 Vlan1 priority

To modify the Vlan1 priority, first move the cursor to the digit to be modified. Press enter.

```
Bundle Setup  
Vlan1 priority
```

```
vlan1 priority  
1-7(number)
```

5.2.17 Vlan2 ID

To modify the Vlan2 ID, first move the cursor to the digit to be modified. Press enter.

```
Bundle Setup  
Vlan2 ID
```

```
Vlan2 ID  
1-4095(number)
```

5.2.18 Vlan2 priority

To modify the Vlan2 priority, first move the cursor to the digit to be modified. Press enter.

```
Bundle Setup  
Vlan2 priority
```

```
Vlan2 priority  
1-7(number)
```

5.2.19 Bundle status

Bundle status menu shows the current parity selection of Deactive, NONE, or Active. To active or deactivate Bundle status, move cursor to a desired selection and press ENTER.

```
Bundle Setup  
Bundle status
```

Bundle status
Deactive

Bundle status
NONE

Bundle status
Active

5.2.20 Confirm?

Move the cursor to confirm, press ENTER. Move the cursor to NO or YES to confirm the Bundle setup.

Bundle Setup
Confirm?

Confirm?
No

Confirm?
YES

5.3 Bundle Status

The menus are used to configure Bundle status to select Classifi pack RX, Byte received, Byte transmitted, Packet received, Packet transmitted and LAN WAN SNMP. Under Bundle status menu, use left or right key to select Console Port menu. Press ENTER to enter into its submenus.

Configuration
Bundle Status

5.3.1 Classifi pack RX

To modify the Classifi pack RX, first move the cursor to the digit to be modified. Press enter.

Bundle Status
Classifi pack RX

```
Classifi pack RX  
0(number)
```

5.3.2 Byte received

To modify the Byte received, first move the cursor to the digit to be modified. Press enter.

```
Bundle Status  
Byte received
```

```
Byte received  
0(number)
```

5.3.3 Byte transmitted

To modify the Byte transmitted, first move the cursor to the digit to be modified. Press enter.

```
Bundle Status  
Byte transmitted
```

```
Byte transmitted  
0(number)
```

5.3.4 Packet received

To modify the Packet received, first move the cursor to the digit to be modified. Press enter.

```
Bundle Status  
Packet received
```

```
Packet received  
0(number)
```

5.3.5 Packet transmitted

To modify the Packet transmitted, first move the cursor to the digit to be modified. Press enter.

```
Bundle Status  
Packet transmitted
```

```
Packet transmitted  
0(number)
```

5.3.6 LAN WAN SNMP

Move the cursor to select LAN WAN SNMP, press ENTER.

```
Bundle Status  
LAN WAN SNMP
```

```
LAN WAN SNMP  
Down Down UP
```

5.4 Alarm

The menus are used to select Alarm in order to setup alarm, clear alarm and to clear alarm. Under Alarm menu, use left or right key to select Console Port menu. Press ENTER to enter into its submenus.

```
Configuration  
Alarm
```

5.4.1 Alarm setup

Move the cursor to NEXT or PREV to view alarm, then go to EDIT option with pressing ENTER to do alarm setup.

```
Alarm  
Alarm setup
```

5.4.1.1 Alarm clock

The setup menu is used to setup clock alarm. The clock alarm occur when the clock source change.

```
Alarm setup  
Alarm clock
```

```
Alarm clock  
DISABLE
```

Alarm clock
MAJOR

Alarm clock
CRITICAL

Alarm clock
MINOR

5.4.1.2 Alarm link

Press ENTER from the Alarm link menu. Use arrow keys to select alarm link, then press ENTER. Their submenu includes these options: DISABLE, MAJOR< CRITICAL and MINOR.

Alarm setup
Alarm link

Alarm link
DISABLE

Alarm link
MAJOR

Alarm link
CRITICAL

Alarm link
MINOR

5.4.2 Alarm status

Move the cursor to select alarm status, press ENTER. Move the cursor to NO or YES to confirm the alarm status.

Alarm
Alarm status

CLOCK LINK
NO YES

5.4.3 Alarm clear

Pressing enter when cursor is on NEXT will move to the next alarm item. To confirm the existing option, move cursor to EDIT and press ENTER. Then move cursor to the desired option and press ENTER. The alarm queue can be cleared.




5.5 Information

The menus are used to select Software version, Hardware version and Serial number. Under Information menu, use left or right key to select Console Port menu. Press ENTER to enter into its submenus.





5.5.1 Software Version

Move the cursor to select Software Version, press ENTER.



5.5.2 Hardware Version

To modify the Hardware version, first move the cursor to the text to be modified. Press enter.



5.5.3 Serial number

To modify the Serial number, first move the cursor to the text to be modified. Press enter.

Information
Serial number

Serial number
xxxx(text)

5.6 Miscellaneous

The Miscellaneous group includes: Store Config, Retrieve Config, Load Default, and System reset.

Configuration
Miscellaneous

5.6.1 Store Config

Pressing enter when cursor is on NEXT will move to the next Store Config item. To confirm the existing option, press ENTER.

Miscellaneous
Store Config

Store Config
Confirm?

5.6.2 Retrieve Config

Pressing enter when cursor is on NEXT will move to the next Retrieve Config item. To confirm the existing option, press ENTER

Miscellaneous
Retrieve Config

Retrieve Config
Confirm?


5.6.3 Load Default

Pressing enter when cursor is on NEXT will move to the next Load Default item. To confirm the existing option, press ENTER. **Note:** Load Default will causes reboot.



5.6.4 System reset

Pressing enter when cursor is on NEXT will move to the next System reset item. To confirm the existing option, press ENTER.



5.7 E3/DS3 Menu

Config setup includes Tx Length and Xmt AIS menus.

IP6700
DS3-CARD PORT A

5.7.1 Config Setup

Move the cursor to select Config Setup, press ENTER.

DS3-CARD PORT A
Config Setup

5.7.1.1 Tx Length

Move the cursor to select Tx Length, press ENTER. The Length of TX could be from 0-255 or 255 to 450.

Config Setup
Tx Length

Tx Length
0-255

Tx Length
255-450

5.7.1.2 Xmt AIS

Move the cursor to select Xmt AIS, press ENTER. This action can be turned ON or OFF. When los happened, the Xmt AIS decide to transmitted AIS to line or not. When los sent AIS, use arrow keys to select ON. If the los do not send AIS, use arrow keys to select OFF.

Config Setup
Xmt AIS

Xmt AIS
ON

Xmt AIS
OFF

5.7.2 Port Status

Move the cursor to select Port Status, press ENTER.



```
Config Setup
Port Status
```

5.7.2.1 LOS XMT AIS

Under Port Status menu to select LOS XMT AIS, then Move the cursor to NO or YES to setup LOS XMT AIS, press ENTER.



```
Port Status
LOS XMT AIS
```



```
LOS XMT AIS
No     YES
```

5.7.2.2 BPV ES

To setup the BPV ES, first move the cursor to the digit to be modified. Press enter.



```
Port Status
BPV ES
```



```
BPV ES
000 000
```

5.7.3 Port Alarm

Move the cursor to select Port Alarm, press ENTER.



```
Config Setup
Port Alarm
```

5.7.3.1 Alarm setup


Move the cursor to NEXT or PREV to view alarm, then go to EDIT option with pressing ENTER to do alarm setup.



```
Port Alarm
Alarm setup
```

5.7.3.1.1 Alarm Type


Move the cursor to select Alarm Type, press ENTER. The alarm types include LOS, LCV, LES, SEFS, UAS, BUNDLE and MAC.



5.7.3.1.2 Threshold

Move the cursor to select Current Threshold press ENTER. Under Threshold sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: DS3 LCV, DS3 LES, DS3 SEFS and ES3 UAS. Then move the cursor to the digit to be modified. Press enter.



DS3 SEFS
1-65535(number)

DS3 UAS
1-65535(number)

5.7.3.2 Port History

Move the cursor to select Current Port History, press ENTER. Under Port History sub-menu, use arrow keys to select a desired option. The menu is used to show Alarm History.

Their submenu includes these options: PORT A LOS, PORT A LCV, PORT A LES, PORT A SEFS, PORT A UAS, PORT A BUNDLE and PORT A MAC.

Config setup
Port History

PORT A LOS
OK MAJOR 0000

PORT A LCV
OK MAJOR 0000

PORT A LES
OK MAJOR 0000

PORT A SEFS
OK MAJOR 0000

PORT A UAS
OK MAJOR 0000

PORT A BUNDLE
OK MAJOR 0000

PORT A MAC
OK MAJOR 0000

5.7.3.3 Alarm clear

Pressing enter when cursor is on NEXT will move to the next alarm item. To confirm the existing option, move cursor to EDIT and press ENTER. Then move cursor to the desired option and press ENTER.
The alarm queue can be cleared.



5.7.4 Port lookback

Move the cursor to select Port Loopback, press ENTER.



5.7.4.1 Local Loopback

Move the cursor to select Current Local Loopback press ENTER. Under Local Loopback sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: OFF, LOCAL, PLB and LLB.



5.7.5 Clock Source

Move the cursor to select Clock Source, press ENTER.

Config Setup
Clock Source

5.7.5.1 Master Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to select Master Clock press ENTER.

Clock Source
Master Clock

Master Clock
INTERNAL

Master Clock
EXTERNAL

Master Clock
PORT A (LINE)

Master Clock
PORT B (LINE)

Master Clock
PORT C (LINE)

Master Clock
PORT D (LINE)

Master Clock
PORT A (BUNDLE 0)

Master Clock
PORT B (BUNDLE 0)

Master Clock
PORT C (BUNDLE 0)

Master Clock
PORT D (BUNDLE 0)

5.7.5.2 Second Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to select Second Clock press ENTER.

Clock Source
Second Clock

Second Clock
INTERNAL

Second Clock
EXTERNAL

Second Clock
PORT A (LINE)

Second Clock
PORT B (LINE)

Second Clock
PORT C (LINE)

Second Clock
PORT D (LINE)

Second Clock
PORT A (BUNDLE 0)

Second Clock
PORT B (BUNDLE 0)

Second Clock
PORT C (BUNDLE 0)

Second Clock
PORT D (BUNDLE 0)

5.7.5.3 Current Clock

Move the cursor to select Current Clock press ENTER. Its sub-menus include these options: Current Clock, MASTER_CLK, SECOND_CLK and INTERNAL.

Clock Source
Current Clock

Current Clock
MASTER_CLK

Current Clock
SECOND_CLK

Current Clock
INTERNAL

5.7.5.4 Recover Clock

Move the cursor to select Current Clock press ENTER. Under Recover clock sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: MANUAL and AUTOMATIC

Clock Source
Recover Clock


Recover Clock
AUTOMATIC

Recover Clock
MANUAL

Chapter 6 TERMINAL OPERATION

5.7.5.5 Clock Status

Move the cursor to select Clock Status press ENTER. Moving the arrow keys to Normal and pressing ENTER must conclude this operation.



5.8 E1-CARD Menu

Config setup includes Frame, Code, CRC, RAI, CIS, CAS, OOS, FDL, Sa_bit and IDLE menus.

IP6700
E1-CARD PORT B

5.8.1 Config Setup

Move the cursor to select Config Setup, press ENTER.

E1-CARD PORT B
Config Setup

5.8.1.1 Frame

Move the cursor to select Frame, press ENTER. To enable it, move the cursor to ON and press ENTER. To disable it, move the cursor to OFF and press ENTER.

Config Setup
Frame

Frame
OFF

Frame
ON

5.8.1.2 Code

To select the coding scheme, use the arrow keys cycle through to a proper selection and press ENTER. The choices for E1 are AMI and HDB3. Using the arrow keys to change the setting, and press ENTER. Be sure that this setting matches that of the network.

Config Setup
Code

Code
AMI

Code
HDB3

5.8.1.3 CRC

The cyclic redundancy check function can be turned on or off. Unlike bipolar violation, which can monitor only one span, CRC menu allows error monitoring through multiple spans of E1 line. For two frame mode, set CRC to OFF. For multi-frame mode, set CRC to ON.



5.8.1.4 RAI

Remote Alarm Indication, transmits a return signal back out to indicate loss of signal and loss of frame sync at the receiving side if the port. This action can be turned ON or OFF.

Use arrow keys to select ON or OFF, then press ENTER to enable or disable the option.



5.8.1.5 AIS

Under CIS submenu, use arrow keys to select ON or OFF, then press ENTER to enable or disable the option.





5.8.1.6 CAS

Signaling is either CAS (channel associated signalling) or out-of-band such as CCIS (common channel interoffice signalling). To change the signaling type, use the arrow keys to choose from CAS ON or CAS OFF and press ENTER.




5.8.1.7 OOS

To change the OOS protocol, use the arrow keys to cycle through to the proper selection and Press ENTER.




5.8.1.8 FDL

FDL menu shows the facility data link. Move the cursor at a desired option, press ENTER to confirm it.



5.8.1.9 Sa_bit

To change a channel for FDL, move cursor to Sabit, and use left or right arrow keys to select a channel, press ENTER.





5.8.1.10 IDLE

Press ENTER for the Line Idle Code menu. The user can enter number from 0-255 to the Idle menu.



5.8.2 Port Status

Under the E1 card menu, move the cursor to Port Status option, then the system will show as below.




5.8.2.1 LOF LOS

Under Port Status menu to select LOF LOS, and move the cursor to NO to setup LOF LOS then press ENTER.



5.8.2.2 RCV AIS RCV RAI


Under Port Status menu to select RCV AIS RCV RAI, press ENTER, move the cursor to NO to setup RCV AIS RCV RAI, then press ENTER.



Chapter 6 TERMINAL OPERATION


5.8.2.3 XMT AIS XMT RAI

Under Port Status menu to select XMT AIS XMT RAI, press ENTER, move the cursor to NO to setup XMT AIS XMT RAI, then press ENTER.



5.8.2.4 BPV ES

To setup the BPV ES, first move the cursor to the digit to be modified. Press enter.



5.8.3 Port Alarm

Move the cursor to select Port Alarm, press ENTER.




5.8.3.1 Alarm Setup

Move the cursor to NEXT or PREV to view alarm, then go to EDIT option with pressing ENTER to do alarm setup.



5.8.3.1.1 Alarm Type

Move the cursor to select Alarm Type, press ENTER. The alarm types include RAI, AIS, LOS, LOF, BPV, ES, UAS, CSS, BUNDEL and MAC.




Chapter 6 TERMINAL OPERATION



5.8.3.1.2 Threshold

Move the cursor to select Current Threshold press ENTER. Under Threshold sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: E1 BPV, E1 ES, E1 UAS, and E1 CSS. Then move the cursor to the digit to be modified.





5.8.3.2 Port History

Move the cursor to select Current Port History, press ENTER. Under Port History sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: RAI, AIS, LOS, LOF, BPV, ES, UAS, CSS, BUNDLE and MAC.



5.8.3.2.1 RAI

Move the cursor to select RAI, press ENTER.

Note: 1. CRITI is Critical

2. If the RAI alarm have ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.8.3.2.2 AIS

AIS menu shows the configuration set for the alarm indication signal. Move the cursor to select AIS, press ENTER.

Note: 1. CRITI is Critical

2. If the AIS alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



Chapter 5 Front Panel Operation

5.8.3.2.3 LOS

Move the cursor to select LOS, press ENTER.

Note: 1. CRITI is Critical

2. If the LOS alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.8.3.2.4 LOF

Move the cursor to select LOF, press ENTER.

Note: 1. CRITI is Critical

2. If the LOF alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.8.3.2.5 BPV

Move the cursor to select BPV, press ENTER.

Note: 1. CRITI is Critical

2. If the BPV alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?




Chapter 5 Front Panel Operation

5.8.3.2.6 ES

Move the cursor to select ES, press ENTER.

Note: 1. CRITI is Critical

2. If the ES alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?




5.8.3.2.7 UAS

Move the cursor to select UAS, press ENTER.

Note: 1. CRITI is Critical

2. If the UAS alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?




5.8.3.2.8 CSS

Move the cursor to select CSS, press ENTER.

Note: 1. CRITI is Critical

2. If the CSS alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



Chapter 5 Front Panel Operation

5.8.3.2.9 BUNDLE

Move the cursor to select BUNDLE, press ENTER.

Note: 1. CRITI is Critical

2. If the BUNDLE alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.8.3.2.10 MAC

Move the cursor to select MAC, press ENTER.

Note: 1. CRITI is Critical

2. If the MAC alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.8.3.3 Alarm Clear


Pressing enter when cursor is on NEXT will move to the next alarm item. To confirm the existing option, move cursor to EDIT and press ENTER. Then move cursor to the desired option and press ENTER.

The alarm queue can be cleared.



5.8.4 Port Loopback

Move the cursor to select Port Loopback, press ENTER.



5.8.4.1 Local Loopback

Move the cursor to select Current Local Loopback press ENTER. Under Local Loopback sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: OFF, LOCAL, PLB and LLB.



5.8.4.2 Remote Loopback

E1 remote loopback is used to activate E1 line remote loopback test. To activate or deactivate E1 remote loopback, use left or right arrow keys cycle through to a desired selection and press ENTER.



Chapter 5 Front Panel Operation

5.8.4.3 Send Bert

Move the cursor to select Send Bert, press ENTER.

Port Loopback
Send Bert

5.8.4.3.1 Bert Type

Move the cursor to select Current Bert Type press ENTER. Under Bert Type sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: OFF, PRBS_FULL and N*64K.

Send Bert
Bert Type

Bert Type
OFF

Bert Type
PRBS_FULL

Bert Type
N*64K

5.8.4.3.2 Bert Direct

Move the cursor to select Bert Direct, press ENTER. Its sub-menus include these options: LINE and PCM. The user can send their packet to LINE or to PCM side.

Send Bert
Bert Direct

Bert Direct
LINE

Bert Direct
PCM

5.8.4.3.3 Timeslot from

To modify the Timeslot from, first move the cursor to the digit to be modified. Press enter.

Send Bert
Timeslot from

Timeslot from
1-32

5.8.4.3.4 Timeslot to

To modify the Timeslot to, first move the cursor to the digit to be modified. Press enter.

Send Bert
Timeslot to

Timeslot to
1-32

5.8.5 Clock Source

Move the cursor to select Clock Source, press ENTER.

E1-CARD PORT B
Clock Source


5.8.5.1 Master Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to select Master Clock press ENTER. Please refer to 6.1.5 for detail information.

Clock Source
Master Clock


Master Clock
INTERNAL

Master Clock
EXTERNAL



5.8.5.2 Second Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to Second Clock, press ENTER. Please refer to 6.1.5 for detail information.



Second Clock
EXTERNAL

Second Clock
PORT A (LINE)

Second Clock
PORT B (LINE)

Second Clock
PORT C (LINE)

Second Clock
PORT D (LINE)

Second Clock
PORT A (BUNDLE 0)

Second Clock
PORT B (BUNDLE 0)

Second Clock
PORT C (BUNDLE 0)

Second Clock
PORT D (BUNDLE 0)

5.8.5.3 Current Clock

Move the cursor to select Current Clock, press ENTER. Please refer to 6.1.5 for detail information.

Clock Source
Current Clock

Current Clock
MASTER_CLK

Current Clock
SECOND_CLK

Current Clock
INTERNAL

5.8.5.4 Recover Clock

Move the cursor to select Recover Clock, press ENTER. Please refer to 6.1.5 for detail information.

Clock Source
Recover Clock

Recover Clock
AUTOMATIC

Recover Clock
MANUAL

5.8.5.5 Clock status

Move the cursor to select Clock status, press ENTER. Please refer to 6.1.5 for detail information.

Clock Source
Clock status

Clock status
NORMAL

5.9 T1-CARD Menu

Config setup includes Frame, Code, YEL, AIS, CAS, OOS, INBAND, IDLE, INTE, LBO and FDL menus.

IP6700
T1-CARD PORT C

5.9.1 Config Setup

Move the cursor to select Config Setup, press ENTER.

T1-CARD PORT C
Config Setup

5.9.1.1 Frame

Move the cursor to select Frame, press ENTER. The current selection is highlighted by an asterisk (*). To enable it, move the cursor to ON and press ENTER. To disable it, move the cursor to OFF and press ENTER.

Config Setup
Frame

Frame
*OFF

Frame
ON

5.9.1.2 Code

To select the coding scheme, use the arrow keys cycle through to a proper selection and press ENTER. The choices for T1 are AMI and HDB3. An asterisk (*) is placed by the currently selected item. Using the arrow keys to change the setting, and press ENTER. Be sure that this setting matches that of the network.

Config Setup
Code

Code
*HDB3

Code
AMI

5.9.1.3 CRC

For two frame mode, set CRC to OFF. For multiframe mode, set CRC to ON. Move the cursor to select CRC, press ENTER. The current selection will be highlighted by an asterisk (*).



5.9.1.4 RAI

Use arrow keys to select ON or OFF, then press ENTER to enable or disable the option. The current selection will be highlighted by an asterisk (*).



5.9.1.5 AIS

Move the cursor to select AIS, press ENTER. To enable it, move the cursor to ON and press ENTER. To disable it, move the cursor to OFF and press ENTER.





5.9.1.6 CAS

Signaling is either CAS (channel associated signalling) or out-of-band such as CCIS (common channel interoffice signalling). To change the signaling type, use the arrow keys to choose from CAS ON or CAS OFF and press ENTER.



5.9.1.7 OOS


To change the OOS protocol, use the arrow keys to cycle through to the proper selection and Press ENTER.



Chapter 6 TERMINAL OPERATION


5.9.1.8 FDL

FDL menu shows the facility data link. To enable FDL by moving cursor to ON, while to disable it by moving cursor to OFF, and press ENTER. The current selection is highlighted by an asterisk "*".



5.9.1.9 Sa_bit

To change a channel for FDL, move cursor to Sa_bit, and use left or right arrow keys to select a channel, press ENTER. The current selection is highlighted by an asterisk (*).






5.9.1.10 IDLE


Press ENTER for the Line Idle Code menu.

The Idle menu shows the transmission idle code when a DS0 time slot is in idle mode. To change the idle code, press ENTER to cycle through the selections. This operation must be concluded by moving the arrow keys to YES position and pressing ENTER to enable the changes.




5.9.2 Port Status

Move the cursor to select Port Status, press ENTER.



5.9.2.1 LOF LOS

Under Port Status menu to select LOF LOS, and move the cursor to NO or YES to setup LOF LOS then press ENTER.




5.9.2.2 RCV AIS RCV RAI

Under Port Status menu to select RCV AIS RCV RAI, and move the cursor to NO to setup RCV AIS RCV RAI then press ENTER.




Chapter 6 TERMINAL OPERATION




RCV AIS RCV RAI
NO NO

5.9.2.3 XMT AIS XMT RAI

Under Port Status menu to select XMT AIS AMT RAI, and move the cursor to NO to setup XMT AIS AMT RAI then press ENTER.



Port Status
XMT AIS XMT RAI



XMT AIS XMT RAI
NO NO

5.9.2.4 BPV ES

To setup the BPV ES, first move the cursor to the digit to be modified. Press enter.




Port Status
BPV ES



BPV ES
000 000

5.9.3 Port Alarm


Move the cursor to select Port Alarm, press ENTER.



T1-CARD PORT C
Port Alarm

5.9.3.1 Alarm Setup

Move the cursor to select Alarm Setup, press ENTER.



Port Alarm
Alarm Setup

Chapter 6 TERMINAL OPERATION

5.9.3.1.1 Alarm Type


Move the cursor to select Alarm Type, press ENTER. The alarm types include YEL, AIS, LOS, LOF, BPV, ES, UAS, CSS, BUNDLE and MAC. The current selection is highlighted by an asterisk (*).



5.9.3.1.2 Threshold

Move the cursor to select Current Threshold press ENTER. Under Threshold sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: T1 BPV, T1 ES, T1 UAS, and T1 CSS. Then move the cursor to the digit to be modified.



T1 ES OK
*0001 (1-65535)

T1 UAS OK
*00001 (1-65535)

T1 CSS OK
*00001 (1-65535)

5.9.3.2 Port History

Move the cursor to select Current Port History, press ENTER. Under Port History sub-menu, use arrow keys to select a desired option. The menu is used to show the Alarm History.

Their submenu includes these options: RAI, AIS, LOS, LOF, BPV, ES, UAS, CSS, BUNDLE and MAC.

Port Alarm
Port History

5.9.3.2.1 RAI

Move the cursor to select RAI, press ENTER. The menu shows the RAI alarm status.

Note: 1. MAJOR is Alarm Type

2. If the RAI alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?

Port History
PORT B RAI

PORT B RAI
MAJOR OK 0000

5.9.3.2.2 AIS

AIS menu shows the configuration set for the alarm indication signal. Move the cursor to select AIS, press ENTER.

Note: 1. MAJOR is Alarm Type

2. If the AIS alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?

Port History
PORT B AIS



5.9.3.2.3 LOS

Move the cursor to select LOS, press ENTER. The menu shows the LOS alarm status.

Note: 1. MAJOR is Alarm Type

2. If the LOS alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.9.3.2.4 LOF

Move the cursor to select LOF, press ENTER. The menu shows the LOF alarm status.

Note: 1. MAJOR is Alarm Type

2. If the LOF alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



5.9.3.2.5 BPV

Move the cursor to select BPV, press ENTER. The menu shows the BPV alarm status.

Note: 1. MAJOR is Alarm Type

2. If the BPV alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?



Chapter 6 TERMINAL OPERATION

5.9.3.2.6 ES

Move the cursor to select ES, press ENTER. The menu shows the ES alarm status.

Note: 1. MAJOR is Alarm Type

- 2. If the ES alarm has ever happened, it will show alm. If it is not, will show OK.
- 3. 0000 shows how many times have it ever happened?



5.9.3.2.7 UAS

Move the cursor to select UAS, press ENTER. The menu shows the UAS alarm status.

Note: 1. MAJOR is Alarm Type

- 2. If the UAS alarm has ever happened, it will show alm. If it is not, will show OK.
- 3. 0000 shows how many times have it ever happened?



5.9.3.2.8 CSS

Move the cursor to select CSS, press ENTER. The menu shows the CSS alarm status.

Note: 1. MAJOR is Alarm Type

- 2. If the CSS alarm has ever happened, it will show alm. If it is not, will show OK.
- 3. 0000 shows how many times have it ever happened?



Chapter 5 Front Panel Operation

5.9.3.2.9 BUNDLE

Move the cursor to select BUNDLE, press ENTER. The menu shows the BUNDLE alarm status.

Note: 1. MAJOR is Alarm Type

2. If the BUNDLE alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?

Port History
PORT B BUNDLE

PORT B BUNDLE
MAJOR OK 0000

5.9.3.2.10 MAC

Move the cursor to select MAC, press ENTER. The menu shows the MAC alarm status.

Note: 1. MAJOR is Alarm Type

2. If the MAC alarm has ever happened, it will show alm. If it is not, will show OK.
3. 0000 shows how many times have it ever happened?

Port History
PORT B MAC

PORT B MAC
MAJOR OK 0000

5.9.3.3 Alarm Clear

Pressing enter when cursor is on NEXT will move to the next alarm item. To confirm the existing option, move cursor to EDIT and press ENTER. Then move cursor to the desired option and press ENTER.

The alarm queue can be cleared.

Port Alarm
Alarm Clear

Alarm Clear
Confirm?

5.9.4 Port Loopback

Move the cursor to select Port Loopback, press ENTER.

T1-CARD PORT C
Port Loopback

5.9.4.1 Local Loopback

Move the cursor to select Current Local Loopback press ENTER. Under Local Loopback sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: OFF, LOCAL, PLB and LLB. . The current selection is highlighted by an asterisk (*).

Port Loopback
Local Loopback

Local Loopback
*OFF

Local Loopback
LOCAL

Local Loopback
PLB

Local Loopback
LLB

5.9.4.2 Remote Loopback

T1 remote loopback is used to activate T1 line remote loopback test. To activate or deactivate T1 remote loopback, use left or right arrow keys cycle through to a desired selection and press ENTER. The current selection is highlighted by an asterisk (*).

Port Loopback
Remote Loopback

Remote Loopback
*ACTIVE-IN-BAND

Remote Loopback
ACTIVE-AT&T-P

Remote Loopback
ACTIVE-ANSI-P

Remote Loopback
ACTIVE-ANSI-L

Remote Loopback
DEACTIVE-IN-BAN

Remote Loopback
DEACTIVE-AT&T-P

Remote Loopback
DEACTIVE-ANSI-P

Remote Loopback
DEACTIVE-ANSI-L

5.9.4.3 Send Bert

Move the cursor to select Send Bert, press ENTER.

Port Loopback
Send Bert

5.9.4.3.1 Bert Type

Move the cursor to select Current Bert Type press ENTER. Under Bert Type sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: OFF, PRBS_FULL and N*64K. The current selection is highlighted by an asterisk (*).

Send Bert
Bert Type

Bert Type
*OFF

Bert Type
PRBS_FULL

```
Bert Type  
N*64K
```

5.9.4.3.2 Bert Direct

Move the cursor to select Bert Direct, press ENTER. Its sub-menus include these options: LINE and PCM. The current selection is highlighted by an asterisk (*).

```
Send Bert  
Bert Direct
```

```
Bert Direct  
*LINE
```

```
Bert Direct  
PCM
```

5.9.4.3.3 Timeslot from

To modify the Timeslot from, first move the cursor to the digit to be modified. Press enter. The current selection is highlighted by an asterisk (*).

```
Send Bert  
Timeslot from OK
```

```
Timeslot from OK  
*01 (1-24)
```

5.9.4.3.4 Timeslot to

To modify the Timeslot to, first move the cursor to the digit to be modified. Press enter.

```
Send Bert  
Timeslot to OK
```

```
Timeslot to OK  
*01 (1-24)
```

5.9.5 Clock Source

Move the cursor to select Clock Source, press ENTER.

T1-CARD PORT C
Clock Source

5.9.5.1 Master Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to select Master Clock, press ENTER. The current selection is highlighted by an asterisk (*).

Clock Source
Master Clock

Master Clock
*INTERNAL

Master Clock
EXTERNAL

Master Clock
PORT A (LINE)

Master Clock
PORT B (LINE)

Master Clock
PORT C (LINE)

Master Clock
PORT D (LINE)

Master Clock
PORT A (BUNDLE 0)

Master Clock
PORT B (BUNDLE 0)

Master Clock
PORT C (BUNDLE 0)

Master Clock
PORT D (BUNDLE 0)

5.9.5.2 Second Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to Second Clock, press ENTER. The current selection is highlighted by an asterisk (*).

Clock Source
Second Clock

Second Clock
* INTERNAL

Second Clock
EXTERNAL

Second Clock
PORT A (LINE)

Second Clock
PORT B (LINE)

Second Clock
PORT C (LINE)

Second Clock
PORT D (LINE)

Second Clock
PORT A (BUNDLE 0)

Second Clock
PORT B (BUNDLE 0)

Second Clock
PORT C (BUNDLE 0)

Second Clock
PORT D (BUNDLE 0)

5.9.5.3 Current Clock

Move the cursor to select Current Clock, press ENTER. The current selection is highlighted by an asterisk (*).

Clock Source
Current Clock

Current Clock
*MASTER_CLK

Current Clock
SECOND_CLK

Current Clock
INTERNAL

5.9.5.4 Recover Clock

Move the cursor to select Current Clock press ENTER. Under Recover clock sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: MANUAL and AUTOMATIC
The current selection is highlighted by an asterisk (*).

Clock Source
Recover Clock

Recover Clock
*AUTOMATIC

Chapter 6 TERMINAL OPERATION

Recover Clock
MANUAL

5.9.5.5 Clock status

Move the cursor to select Clock status, press ENTER.

Clock Source
Clock status

Clock status
NORMAL

5.10 DTE Menu

Config setup includes Mode, Rate, Tx clock, Rx clock, Data, RTS, TTM and DCD menus.




5.10.1 Config Setup

Move the cursor to select Config Setup, press ENTER.




5.10.1.1 Mode

The Mode menu shows the current Mode is either FULL or 64 Kbps. To change the Mode data rate, move cursor to the desired selection and press ENTER. The current selection will be highlighted by an asterisk (*).



5.10.1.2 Rate

The Rate menu shows the current DTE data rate is either 64 or 56 Kbps. To change the DTE data rate, move cursor to the desired selection and press ENTER. The current selection will be highlighted by an asterisk (*).



5.10.1.3 Tx clock

The Data menu shows the current DTE Tx clock polarity (either normal or inverted) by placing an asterisk (*) at the appropriate selection. To change the DTE Tx clock polarity, move cursor to the desired selection and press ENTER.



5.10.1.4 Rx clock

The Data menu shows the current DTE Rx clock polarity (either normal or inverted) by placing an asterisk (*) at the appropriate selection. To change the DTE Rx clock polarity, move cursor to the desired selection and press ENTER.



5.10.1.5 DATA

The Data menu shows the current DTE data polarity (either normal or inverted) by placing an asterisk (*) at the appropriate selection. To change the DTE data polarity, move cursor to the desired selection and press ENTER.





5.10.1.6 RTS

The RTS menu shows the current DTE RTS operation mode (either activate or permanent) by placing an asterisk (*) at the appropriate selection. To change the DTE RTS operation mode, move cursor to the desired selection and press ENTER.



5.10.1.7 TTM

TTM menu shows the current DTE terminal timing mode (either OFF or ON) by placing an asterisk (*) at the appropriate selection. To change the DTE terminal timing mode, move cursor to the desired selection and press ENTER.



5.10.1.8 DCD


DCD menu shows the current DTE DCD mode (either Normal or On) by placing an asterisk (*) at the appropriate selection. To change the DTE DCD mode, move cursor to the desired selection and press ENTER.





5.10.2 Port Status

Move the cursor to select Config Setup, press ENTER.



5.10.2.1 Exit RTS LOS

Under Port Status menu to select Exit RTS LOS, and move the cursor to NO or YES to setup Exit RTS LOS then press ENTER.



5.10.2.2 CLK LOS DSR


Under Port Status menu to select CLK LOS DSR, and move the cursor to NO to setup Exit CLK LOS DSR then press ENTER.



Chapter 6 TERMINAL OPERATION


5.10.2.3 CTS DCD

Under Port Status menu to select CTS DCD, and move the cursor to NO to setup CTS DCD then press ENTER.




5.10.2.4 DSR RTS

Under Port Status menu to select DSR RTS, and move the cursor to NO to setup DSR RTS then press ENTER.




5.10.3 Port Alarm

Move the cursor to select Port Alarm, press ENTER.



5.10.3.1 Alarm Setup

Move the cursor to NEXT or PREV to view alarm, then go to EDIT option with pressing ENTER to do alarm setup.



Chapter 6 TERMINAL OPERATION

5.10.3.1.1 Alarm Type

Move the cursor to select Alarm Setup, press ENTER.

Alarm Setup
Alarm Type

5.10.3.1.2 Threshold

Move the cursor to select Threshold, press ENTER.

Alarm Setup
Threshold

5.10.3.2 Alarm History

Move the cursor to select Alarm History, press ENTER.

Port Alarm
Alarm History

Alarm History
OK MAJOR 0001

5.10.3.3 Alarm Clear

Pressing enter when cursor is on NEXT will move to the next alarm item. To confirm the existing option, move cursor to EDIT and press ENTER. Then move cursor to the desired option and press ENTER.
The alarm queue can be cleared.

Port Alarm
Alarm Setup

Alarm Setup
Alarm Clear

Alarm Clear
Confirm?

5.10.4 Port Loopback

Move the cursor to select Port Loopback, press ENTER.

V35-CARD PORT D
Port Loopback

5.10.4.1 Local Loopback

Under Port Loopback menu, use left or right key to select Local Loopback menu. Under Local Loopback sub-menu, use arrow keys to select a desired option.

Its sub-menus includes these options: OFF, TO_DTE and TO_WAN. The current selection is highlighted by an asterisk (*).

Port Loopback
Local Loopback

Local Loopback
*OFF

Local Loopback
TO-DTE

Local Loopback
TO-WAN

5.10.5 Clock Source

Move the cursor to select Clock Source, press ENTER.

V35-CARD PORT D
Clock Source

5.10.5.1 Master Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to select Master Clock press ENTER. The current selection is highlighted by an asterisk (*).


Clock Source
Master Clock

Chapter 6 TERMINAL OPERATION

- Master Clock**
*INTERNAL
- Master Clock**
EXTERNAL
- Master Clock**
PORT A (LINE)
- Master Clock**
PORT B (LINE)
- Master Clock**
PORT C (LINE)
- Master Clock**
PORT D (LINE)
- Master Clock**
PORT A (BUNDLE 0)
- Master Clock**
PORT B (BUNDLE 0)
- Master Clock**
PORT C (BUNDLE 0)
- Master Clock**
PORT D (BUNDLE 0)

5.10.5.2 Second Clock

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D). Move the cursor to select Second Clock press ENTER. The current selection is highlighted by an asterisk (*).



5.10.5.3 Current Clock

Move the cursor to select Current Clock, press ENTER. The current selection is highlighted by an asterisk (*).

Clock Source
Current Clock

Current Clock
*MASTER_CLK

Current Clock
SECOND_CLK

Current Clock
INTERNAL

5.10.5.4 Recover Clock

Move the cursor to select Current Clock press ENTER. Under Recover clock sub-menu, use arrow keys to select a desired option.

Their submenu includes these options: MANUAL and AUTOMATIC. The current selection is highlighted by an asterisk (*).

Clock Source
Recover Clock

Recover Clock
*AUTOMATIC

Recover Clock
MANUAL

5.10.5.5 Clock status

Move the cursor to select Clock status, press ENTER.

Clock Source
Clock status

Chapter 6 TERMINAL OPERATION



6 TERMINAL OPERATION

Loop-IP6700 provides comprehensive and enhanced configuration and test capability through the console port. A VT-100 type terminal or a modem can be connected to the console port on the front of the Loop-IP6700. By use of single-character commands and arrow keys, the Loop-IP6700 can be configured and tested. The single-character commands are not case sensitive. On each screen, the available commands and the configurable fields are highlighted. When the Loop-IP6700 is powered on, user has not logged on yet a main menu will show as below:

NOTE: On the upper right corner of the screen, a time-of day display indicates the time the current screen is shown. User may hit any key other than ESC to update the screen.

6.1 Main Menu

If the terminal screen is illegible, press the “enter” and “esc” key alternatively to bring up the main menu. This is particularly needed if the terminal is connected to the controller while the power is already applied. If the main menu still fails to appear, check to see that the terminal is configured as 9600,9, n, 1, and that a proper null modem or a null modem cable is used.

```
LOOP IP6700           === Main Menu ===          18:12:17 03/14/2000
Serial Number : -10485744
Hardware Version: Ver.B          Start Time : 15:49:05 03/14/2000
Software Version: V1.01.01 03/14/2006

[DISPLAY]                                [SETUP]
C -> System Configuration      S -> System Setup
J -> Time Slot IP Assignment    P -> Choose Port
B -> Clock source Configuration   T -> Time Slot IP Assignment
D -> Link Status                 W -> Firmware Transfer
Q -> Alarm Queue                V -> Store/Retrieve Configuration
                                   K -> Clock Source Setup
                                   M -> System Alarm Setup

[LOG]                                     [MISC]
F -> Log Off [SETUP],[MISC] Menu    Y -> Return To Default
O -> Log On  [SETUP],[MISC] Menu    Z -> Reset
                                       X -> Clear Alarm Queue & History
                                       A -> Alarm Cut Off

>>SPACE bar to refresh or enter a command ===>
```

Chapter 6 TERMINAL OPERATION

6.1.1 System Setup

Press "S" from the "Main Menu" to view the system setup. The screen will show as below.

```
LOOP IP6700          === System Setup ===          00:00:29#01/01/UU93

A -> System
B -> Inband System Setup
C -> Password
D -> Port Speed Setup

<< Press ESC key to return to Main Menu or enter a command >>
```

6.1.1.1 System

Press "A" from the "System Setup" to display the current status for system and console port. Refer to the table below to see the differences when SNMP uses different ports.

```
LOOP IP6700          === System Setup (SYSTEM) ===          15:07:22 10/03/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS
Time/Date      :15:07:26 10/03/2006  Ethernet Port:ENABLE  Lan Port: Data_only
IP Addr.:010.002.003.055 Subnet Mask:255.255.000.000 Gateway IP:000.000.000.000
Community:(Get)public           Community(Set)public           Wan Port: WAN_only
Trap IP Address1:000.000.000.000  Community1:public
Trap IP Address2:000.000.000.000  Community2:public
Trap IP Address3:000.000.000.000  Community3:public
Trap IP Address4:000.000.000.000  Community4:public
Trap IP Address5:000.000.000.000  Community5:public
Device Name     :LOOP IP6700
System Location:8F, No.8, HSIN ANN ROAD
                  SCIENCE-BASED INDUSTRIAL PARK
                  HSINCHU, 30077 TAIWAN

System Contact :Name: FAE    Tel:+886-3-5787696  Fax:+886-3-5787695
                  E-mail:FAE@loop.com.tw

Active bundle Timer (s) : 00000090      Loopback Timer (s) : 00000060
LAN Rate Setup : 0100 x32K           CAS Idle Code : 01
[CONSOLE port]
Baud Rate :9600   Data Length :8-Bits   Stop Bit :1-Bit   Parity :NONE

<< Press ESC key to return to previous menu >>
```

Note:

1. IP address: device IP address
2. Gateway IP: company's DNS server value
3. Trap IP address: the user can setup no more than 5 Trap IP addresses.
4. In any situation, the user cannot connect any two ports in one LAN. When SNMP is setup at the SNMP port, the WAN port and the LAN port act as switches. When SNMP is setup at the WAN port, the SNMP port will shut down. No matter what the user does in any setup, the LAN port and the WAN port act as switches.

	SNMP Port	LAN Port	WAN Port
When SNMP uses SNMP port	Enable	Data_only	WAN_only
When SNMP uses LAN port	×	D+S, S-on D+S, S-off	WAN_only
When SNMP uses WAN port	× (Shut down)	× (Data_only)	WAN +S

6.1.1.2 Inband Management

Press "B" from the "System Setup" to setup Inband Management. It is to manage remote device from local device. For example: one E1 assign one timeslot to manage other device. Please refer to Figure 6-1 for detail.

```

LOOP IP6700           === Inband Management ===      13:12:52 12/06/2005
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

Inband      : OFF
Port        : PORT_A
Time Slot   : 00

<< Press ESC key to return to previous menu >>

```

- Note:**
1. When Inband is on, the user needs to create a bundle.
 2. Inband management can manage a pair only
 3. Three ports in IP6700 cannot connect together in same switch. It will cause Ethernet Loop.




Figure 6- 1 Inband management Diagram

Chapter 6 TERMINAL OPERATION

6.1.1.3 Password

Press "B" from the "System Setup" to enter into the password setup screen. This menu is used to enable, disable, and change password. Use TAB key to roll up the desired options, then press ENTER to confirm the setting.

```
LOOP IP6700          === Password Setup ===      14:08:45 12/06/2005
ARROW KEYS: CURSOR MOVE, BACKSPACE to edit, ESC to abort

Enable Password : YES
Change Password : YES
Old     Password : XXXX_____
New     Password : XXXX_____
Confirm Password: _____
>> Please input new password again to confirm, then press ENTER .
```

6.1.1.4 Port Speed Setup

Press "D" from the "System Setup" to setup port speed.

```
LOOP IP6700          === Speed Management ===      16:19:27 04/24/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

LAN   : AUTO
WAN   : AUTO
SNMP  : AUTO

<< Press ESC key to return to previous menu >>
```

6.1.1.5 Logoff

After completing the system setup or clear history data, user should log off to prevent accidentally changing the system configuration. Enters “F” to logoff.

6.1.1.6 Logon

To show a full menu, user has to logon. If the password option is turned on, a prompt asking for password is shown.

```
==>> Enter password :
```

Only after a valid password is entered, the full menu is shown, otherwise user is asked to enter the correct password again.

```
>> Invalid input of password ! Try again ?[Y/N]
```

6.1.2 Time Slot IP Assignment

Press "T" from the “Main Menu” to view the Time Slot IP Assignment. The screen will show as below.

```
LOOP IP6700          === MAP Setup ===          11:33:38 11/14/2006

V -> Bundle IP setup
W -> Time Slot IP Assignment

<< Press ESC key to return to Main Menu or enter a command >>
```

Chapter 5 Front Panel Operation

6.1.2.1 Bundle IP Setup

Press "V" to get the screen of Bundle IP Setup.

```
LOOP IP6700          === Bundle IP Setup ===      15:54:38 11/03/2006
ARROW KEYS: CURSOR MOVE, Please Input: nnn.nnn.nnn.nnn, BACKSPACE to edit

Src. IP Address :000.000.000.000
Subnet Mask    :000.000.000.000
Gatway IP      :000.000.000.000

<< Press ESC key to return to previous menu >>
```

Note: The Src. IP Address should be IP 6700 WAN IP

6.1.2.2 Time Slot IP Assignment

Press "T" to get into the screen of Time Slot IP Assignment

```
LOOP IP6700          === System Setup (MAP) ===      11:33:53 11/14/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

Port      : PORT_A          PO/TS TS PO/TS TS BNDL ID/UDP NUM Dest IP Address
===== == ===== == ===== ===== ===== ===== ===== ===== =====
Bundle ID : 0
Action     : Add bundle
UDP Number: 0000
Time Slot : 00
Time Slot#: 00
Dest IP Addr: 000.000.000.000
Cell in Bundle: 05
Jitter Delay: 020
Jitter Size: 256
VLAN: OFF
VLAN1 ID: 0000
VLAN1 priority: 0
VLAN2 ID: 0000
VLAN2 priority: 0
Confirm? Yes

Cell Num Jitter Delay Jitter Size
===== ===== ===== =====
```


<< Press ESC key to return to main menu or save system setup >>

Note:

1. For SW Version 1.01.07 or over, User needs to setup Bundle from Bundle 0 because only Bundle 0 can transfer clock.

Chapter 6 TERMINAL OPERATION

2. Bundle ID	refer to table of Maximum Bundle Allocation below
UDP number	There are 4 ports to have UDP number from 1 to 8063. If one port gets UDP number such as 100, another port cannot use same UDP number (refer to Figure 6-1 for detail).
Cell in Bundle	In one bundle, how many cell will include (refer to Figure 8-5 for detail)
Jitter Delay	Total delay buffer $n \times 0.5$ ms max.
Jitter Size	Packet delay cannot $\geq n \times 0.5$ ms



* Delay should be smaller than size. Also, the difference between size and delay should be larger than the time that it takes to reconstruct a packet (otherwise an overrun may occur when the packet arrives). Configuring the Jitter Buffer parameters correctly avoids under-run and overrun situation. Under-run occurs when the Jitter Buffer is empty (the entering rate is lower than the exiting one). In case of an under-run event, the chip transmits conditioning data instead of actual data towards the TDM interface. Overrun occurs when the jitter buffer is full and there is no room for new data to enter (the entering rate exceeds the exiting one). Under-run and overrun require special treatment from the chip HW, depending on the bundle type.

Figure 6- 2 Jitter Buffer Diagram

After configured it. Press “Y” or “N” to confirm it.

Are you sure [Y/N] ?

After confirmed to save the configuration.

Chapter 6 TERMINAL OPERATION

```

LOOP IP6700      === System Setup(MAP) ===      11:39:48 11/14/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

          PO/TS TS  PO/TS TS  BNDL ID/UDP NUM Dest IP Address
Port      : PORT_A
          ===== == ===== = ====== ====== =====
          Bundle ID : 00          A 1 1 A 17 17 0           1 010.003.013.004
Action    : Delete bundle   A 2 2 A 18 18
          UDP Number: 0001        A 3 3 A 19 19 Cell Num Jitter Delay Jitter Size
          Time Slot : 01         A 4 4 A 20 20
          Time Slot#: 31        A 5 5 A 21 21 5           20          256
          Dest IP Addr: 010.003.013.004 A 6 6 A 22 22
          Cell in Bundle: 05     A 7 7 A 23 23
          Jitter Delay: 020      A 8 8 A 24 24
          Jitter Size: 256       A 9 9 A 25 25
          VLAN: OFF             A 10 10 A 26 26
          VLAN1 ID: 0000         A 11 11 A 27 27
          VLAN1 priority: 0      A 12 12 A 28 28
          VLAN2 ID: 0000         A 13 13 A 29 29
          VLAN2 priority: 0      A 14 14 A 30 30
          Confirm? Yes           A 15 15 A 31 31
          A 16 16

<< Press ESC key to return to main menu or save system setup >>

```

After configured it. Press “Y” or “N” to confirm it.

Are you sure [Y/N] ?

NOTE:

Configuration		Option	Default
E1 Line	Port	PORT_A, PORT_B, PORT_C, PORT_D	PORT_A
	Action	Add bundle, Delete bundle, Delete all, Active all, change bundle, stop to bundle	Add bundle
	Bundle ID	0-31	0
	Time Slot	1-31	1
	Time Slot#	1-31	1
	Payload	AAL1	AAL1
	UDP Number	1-8063	1
	IP Address	Range of valid IP	000.000.000.000
	Confirm?	NO, YES	NO

The Action has two options, “Add bundle” and “Delete bundle”. When user choose “Add bundle” option, the bundle ID must be unique for the particular port. When user choose “Delete bundle” option, the particular bundle must already been created. The UDP number need to unique for all the ports.

The chip supports up to 64 bundles. The maximum number of bundles that can be allocated per port is configured as below

Chapter 6 TERMINAL OPERATION

Maximum Bundle Allocation

Allocation No	Port 1	Port 2	Port 3	Port 4
1.	32	Disabled	32	Disabled
2.	32	Disabled	16	16
3.	16	16	32	Disabled
4.	16	16	16	16

The highest priority of Allocation Number is descended from Allocation No 4 to Allocation No1.

6.1.3 Firmware Transfer

Under the Main Menu, press "W" to enter in the screen of File Transfer as below. Press "A" to download mainboard firmware, "B" to upload mainboard firmware, and "R" to copy firmware to redundant.

```
LOOP IP6700           ==File Transfer== 13:38:13 12/06/2005

A -> Download Mainboard Firmware
B -> Download Boot Strapper
C -> Download Current Configuration
D -> Upload Current Configuration from FLASH

<< Press ESC key to return to Main Menu or enter a command >>
```

Chapter 5 Front Panel Operation

6.1.3.1 Download Mainboard Firmware

```
LOOP IP6700      === Download Firmware === 13:38:34 12/06/2005
ARROW KEYS: CURSOR MOVE, Please Input: nnn.nnn.nnn.nnn, BACKSPACE to edit

Firmware 1 Version : Empty or Invalid ver
Firmware 2 Version : Empty or Invalid ver
Current Firmware Bank: 1
Next Boot Firmware : 1
TFTP Server IP     : 000.000.000.000
Firmware File Name : 

<< Press ESC key to return to previous menu >>
```

6.1.3.2 Download Boot Strapper

```
LOOP IP6700      === Download Bootup Code === 18:11:15 12/06/2005
ARROW KEYS: CURSOR MOVE, Please Input: nnn.nnn.nnn.nnn, BACKSPACE to edit

TFTP Server IP     : 000.000.000.000
Download File Name : 

<< Press ESC key to return to previous menu >>
```

Chapter 6 TERMINAL OPERATION

6.1.3.3 Download Current Configuration

```
LOOP IP6700      === Download Current Configuration === 13:39:27 12/06/2005
ARROW KEYS: CURSOR MOVE, Please Input: nnn.nnn.nnn.nnn, BACKSPACE to edit
```

```
TFTP Server IP      : 000.000.000.000
Config File Name    :
```

```
<< Press ESC key to return to previous menu >>
```

6.1.3.4 Upload Current Configuration from FLASH

```
LOOP IP6700      === Upload Current Configuration === 13:45:49 12/06/2005
ARROW KEYS: CURSOR MOVE, Please Input: nnn.nnn.nnn.nnn, BACKSPACE to edit
```

```
TFTP Server IP      : 000.000.000.000
Config File Name    :
```

```
<< Press ESC key to return to previous menu >>
```

6.1.4 Store/Retrieve Configuration

Under the Main Menu, press "V" to store or retrieve the current configuration as the following screen shows. Use TAB key to select STORE or RETRIEVE, press ENTER. The current selection will be highlighted by an asterisk (*).

Store Configuration:

```
LOOP IP6700      ===Store/Retrieve Configuration== 13:53:07 12/06/2005
>> Select ?    *STORE      RETRIEVE
>> Store Current Configuration ? [Y/N]
```

Retrieve Configuration:

```
LOOP IP6700      ===Store/Retrieve Configuration== 13:53:57 12/06/2005
>> Select ?    STORE      *RETRIEVE
>> Retrieve Last Stored Configuration ? [Y/N]
```

Chapter 6 TERMINAL OPERATION

6.1.5 Clock Source Setup

Under the "MainMenu Setup" menu, press "K" to setup clock source as below.

```
==>> Input the E1 port number (A~D) : A
```

The screen of clock will show as below after input E1 port number.

```
E1 Port A      === System Setup (CLOCK-Normal Mode) === 13:57:00 12/06/2005
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS
```

```
Master_Clk Source : INTERNAL
Second_Clk Source : INTERNAL
Current Clock     : MASTER_CLK
Clk_Recover_Mode : MANUAL
Clock Status      : NORMAL
```

```
<< Press ESC key to return to previous menu >>
```

NOTE:

Configuration	Option	Default
Master_Clk Source	INTERNAL, EXTERNAL, PORT A(E1-LINE), PORT B(E1-LINE), PORT C(E1-LINE), PORT D(E1-LINE), PORT A(WAN), PORT B(WAN), PORT C(WAN), PORT D(WAN)	INTERNAL
Second_Clk Source	INTERNAL, EXTERNAL, PORT A(E1-LINE), PORT B(E1-LINE), PORT C(E1-LINE), PORT D(E1-LINE), PORT A(WAN), PORT B(WAN), PORT C(WAN), PORT D(WAN)	Add bundle
Current Clock	MASTER_CLK,SECOND_CLK,INTERNAL	MASTER_CLK
Clk_Recover_Mode	MANUAL, AUTOMATIC	AUTO
Clock Status	NORMAL	NORMAL

Chapter 6 TERMINAL OPERATION

6.1.6 System Alarm Setup

Press "M from the Main Menu, the screen of System Alarm Setup will show as below.

```
LOOP IP6700          === System Alarm Setup ===      14:58:14 12/06/2005
```

```
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS
```

```
[TYPE]           [ALARM]  
CLK Change      DISABLE
```

```
<< Press ESC key to return to previous menu >>
```

6.1.7 System Configuration

Press "C" from the Main Menu, the screen of System Configuration will show as below.

```
LOOP IP6700          === System Configuration ===     13:58:21 12/06/2005
```

```
[System]
```

```
IP Address       :000.000.000.000          Ethernet Port   :DISABLE  
Trap IP Address:000.000.000.000          Subnet Mask    :000.000.000.000  
Community(Get)  :public                 Gateway IP     :000.000.000.000  
Device Name     :LOOP IP6700            Community(Set) :private  
System Location:8F, No.8, HSIN ANN ROAD  
                  SCIENCE-BASED INDUSTRIAL PARK  
                  HSINCHU, 30077 TAIWAN
```

```
System Contact  :Name: FAE      Tel:+886-3-5787696  Fax:+886-3-5787695  
                  E-mail:FAE@loop.com.tw
```

```
IP Interface    :ETHERNET_PORT
```

```
Lan Rate Setup :100 x32K
```

```
[CONSOLE port]
```

```
Baud Rate      :9600  
Data Length    :8-Bits  
Stop Bit       :1-Bit
```

```
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 6 TERMINAL OPERATION

6.1.8 Display MAP IP Assignment

Press "J" from the Main Menu Configuration Menu, the screen will show as below.

```
LOOP IP6700          === System Setup (MAP) ===      13:59:40 12/06/2005
Port Bundle UDP Cells Jitter   IP Address       Time Slot
ID     Num   Num size/Delay
===== ===== = == ===== ===== ===== ===== =====
A      0      1    5    20   256 000.000.000.000 0,1,2,3,4,5,6,7,8,9,10,11,12,
                           13,14,15,16,17,18,19,20,21,22,
                           23,24,25,26,27,28,29,30,31

<< SPACE bar to refresh or ESC key return to main menu >>
```

The bundle entries are shown on the terminal as above. If the displaying entries are more than one page, hit space key other view the next page. To return to main menu, hit "ESC" key.

6.1.9 Clock source Configuration

Press "B" from the Main Menu, the screen of Clock Source Configuration will show as below.

```
LOOP IP6700          === Clock Source Setup ===      14:00:21 12/06/2005

Master_Clk Source : INTERNAL
Second_Clk Source : INTERNAL
Current Clock     : MASTER_CLK
Clk_Recover_Mode : MANUAL
Clock Status      : NORMAL

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 5 Front Panel Operation

6.1.10 Byte and Packet Counters

Press "D" from the Main Menu, the screen of Byte and Packet Counters will show as below.

```
LOOP IP6700      === Byte and Packet Counters === 18:02:03 05/15/2006
```

```
-- Transwitch Counters
TXC Classified Packets Received : 0
TXC Byte Received : 0
TXC Byte Transmitted : 1008
TXC Packets Received : 0
TXC Packets Transmitted : 24
LAN Port Link Status : Link Down
WAN Port Link Status : Link Down
SNMP Port Link Status : Link Down
```

```
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.1.11 Alarm Queue

Press "Q" from the Main Menu, the Alarm Queue Configuration will show as below.

```
LOOP IP6700      === Unit Alarm Queue === 18:56:30 03/14/2000
```

```
1 -- Port D E1: MAJOR      UAS remove-----18:49:08 03/14/00
2 -- Port C E1: MAJOR      UAS remove-----18:49:08 03/14/00
3 -- Port A E1: MAJOR      UAS remove-----18:49:08 03/14/00
4 -- Port D E1: MAJOR      UAS-----18:49:07 03/14/00
5 -- Port C E1: MAJOR      UAS-----18:49:07 03/14/00
6 -- Port A E1: MAJOR      UAS-----18:49:07 03/14/00
7 -- Port A E1: MAJOR      UAS remove-----18:40:24 03/14/00
8 -- Port A E1: MAJOR      UAS-----18:40:23 03/14/00
9 -- Port A E1: MAJOR      LOF-----18:40:15 03/14/00
10 -- Port A E1: MAJOR     LOS-----18:40:15 03/14/00
11 -- Port A E1: MAJOR     ES remove----18:40:15 03/14/00
12 -- Port A E1: MAJOR     ES -----18:40:14 03/14/00
13 -- Port D E1: MAJOR     UAS remove-----18:34:08 03/14/00
14 -- Port C E1: MAJOR     UAS remove-----18:34:08 03/14/00
15 -- Port D E1: MAJOR     UAS-----18:34:07 03/14/00
16 -- Port C E1: MAJOR     UAS-----18:34:07 03/14/00
17 -- Port D E1: MAJOR     UAS remove-----18:19:08 03/14/00
18 -- Port C E1: MAJOR     UAS remove-----18:19:08 03/14/00
19 -- Port D E1: MAJOR     UAS-----18:19:07 03/14/00
20 -- Port C E1: MAJOR     UAS-----18:19:07 03/14/00
```

```
<< ESC key return to previous menu or SPACE bar to change page
```

NOTE:

The latest 40 alarm entries are shown on the terminal as above in two pages of 20 entries each. If there are more than 20 entries, hit any key other than "ESC" to view the second page. To return to main menu, hit "ESC" key.

Chapter 6 TERMINAL OPERATION

6.1.12 Load Default Configuration

Press "Y" to return to default, then confirm it by pressing "Y" or "N".

```
LOOP IP6700      === Main Menu === 18:56:56 03/14/2000
Serial Number : -10485744
Hardware Version: Ver.B          Start Time : 15:49:05 03/14/2000
Software Version: V1.01.01 03/14/2006

[DISPLAY]           [SETUP]
C -> System Configuration   S -> System Setup
J -> Time Slot IP Assignment P -> Choose E1 Port
B -> Clock source Configuration T -> Time Slot IP Assignment
D -> Link Status             W -> Firmware Transfer
Q -> Alarm Queue             V -> Store/Retrieve Configuration
                             K -> Clock Source Setup
                             M -> System Alarm Setup

[LOG]                [MISC]
F -> Log Off [SETUP], [MISC] Menu Y -> Return To Default
O -> Log On  [SETUP], [MISC] Menu Z -> Reset
                             X -> Clear Alarm Queue & History
                             A -> Alarm Cut Off

>> Return to default - are you sure ? [Y/N]
```

6.1.13 Reset

Under Port Menu, press "Z" to reset unit. Press "Y" or "N" to confirm it.

```
LOOP IP6700      === Main Menu === 13:34:54 12/06/2005
Serial Number : -10485744
Hardware Version: Ver.B          Start Time : 11:09:23 12/06/2005
Software Version: V1.00.01 11/28/2005

[DISPLAY]           [SETUP]
C -> System Configuration   S -> System Setup
J -> Time Slot IP Assignment E -> E1 Setup
B -> Clock source Configuration T -> Time Slot IP Assignment
D -> Counters Page          W -> Firmware Transfer
Q -> Alarm Queue             V -> Store/Retrieve Configuration
                             K -> Clock Source Setup
                             M -> System Alarm Setup

[LOG]                [MISC]
F -> Log Off [SETUP], [MISC] Menu Y -> Return To Default
O -> Log On  [SETUP], [MISC] Menu Z -> Reset
                             X -> Clear Alarm Queue & History
                             A -> Alarm Cut Off

Reset - are you sure ? [Y/N]
```

Chapter 6 TERMINAL OPERATION

6.1.14 Clear Alarm Queue & History

Under Port Menu, press "X" to clear alarm queue and history. Press "Y" or "N" to confirm it.

```
LOOP IP6700           === Main Menu ===          14:58:59 12/06/2005
Serial Number : -10485744
Hardware Version: Ver.B      Start Time : 11:09:23 12/06/2005
Software Version: V1.00.01 11/28/2005

[DISPLAY]                      [SETUP]
C -> System Configuration    S -> System Setup
J -> Time Slot IP Assignment E -> E1 Setup
B -> Clock source Configuration T -> Time Slot IP Assignment
D -> Counters Page           W -> Firmware Transfer
Q -> Alarm Queue             V -> Store/Retrieve Configuration
                             K -> Clock Source Setup
                             M -> System Alarm Setup

[LOG]                           [MISC]
F -> Log Off [SETUP], [MISC] Menu Y -> Return To Default
O -> Log On  [SETUP], [MISC] Menu Z -> Reset
                             X -> Clear Alarm Queue & History
                             A -> Alarm Cut Off

>> Clear alarm queue - are you sure ? [Y/N]
```

6.1.15 Alarm Cut Off

Press "A" to show alarm cut off screen.

```
LOOP IP6700           === Main Menu ===          16:15:49 04/24/2006
Serial Number : -10485744
Hardware Version: Ver.B      Start Time : 15:37:33 04/24/2006
Software Version: V1.01.01 03/29/2006

[DISPLAY]                      [SETUP]
C -> System Configuration    S -> System Setup
J -> Time Slot IP Assignment P -> Choose E1 Port
B -> Clock source Configuration T -> Time Slot IP Assignment
D -> Link Status              W -> Firmware Transfer
Q -> Alarm Queue             V -> Store/Retrieve Configuration
                             K -> Clock Source Setup
                             M -> System Alarm Setup

[LOG]                           [MISC]
F -> Log Off [SETUP], [MISC] Menu Y -> Return To Default
O -> Log On  [SETUP], [MISC] Menu Z -> Reset
                             X -> Clear Alarm Queue & History
                             A -> Alarm Cut Off

>> Cut off alarm - are you sure (Y/N) ?
```

Chapter 6 TERMINAL OPERATION

6.2 E1 Sub-Menu

When P is selected and E1 port number is entered, the following Port Menu will show up.

=>> Input the E1 port number (A~D): A

```
E1 Port A          === Port Menu ===          13:22:34 12/06/2005

[DISPLAY]
1 -> 1-Hour Perf. Report
2 -> 24-Hour Perf. Report
A -> Line Availability
C -> Configuration
I -> Status
H -> Alarm History

[SETUP]
L -> Loopback Setup
S -> System Setup
K -> Clear Performance Data
M -> Alarm Setup
X -> Clear Alarm History

[LOG]
P -> Choose Port
F -> Log Off [SETUP], [MISC] Menu
O -> Log On  [SETUP], [MISC] Menu
E -> Return to Main Menu

>>SPACE bar to refresh or enter a command ===>
```

6.2.1 System Setup

To view the unit configuration, press "C" from Port Menu, then the screen will show as below.

```
E1 Port A          === Port System Setup ===          13:29:13 12/06/2005

FRAME      = OFF
CODE       = HDB3
CRC        = ON
RAI        = ON
AIS        = FRAMED
CAS        = OFF
SIGNALLING= TRANS
CGA        = NORM
OOS        = BUSY
FDL        = OFF
Sa_bit     = Sa4
IDLE      = 0
INTF      = 120 Ohm

<< ESC key to return to previous menu, SPACE bar to refresh >
```

6.2.2 Loopback Setup

Under Port Menu, press "L" to do Loopback Test, then the screen will show as below. Use arrow keys to move the cursor, press ENTER key to select items.

```
E1 Port A          === Port Loopback Test ===      15:49:31#01/01/01/0093
ARROW KEYS : CURSOR MOVE , ENTER KEY : ITEM SELECT

- NEAR-END LOOPBACK   : *OFF LOCAL PLB LLB
- SEND LOOPBACK ACTIVATE CODE TO FAR-END:
  *PAYLOAD LINE
- SEND LOOPBACK DEACTIVATE CODE TO FAR-END:
  *PAYLOAD LINE
- SEND TEST PATTERN:
  *OFF PRBS-FULL

- STATUS:

<< Press ESC key to return to previous menu >>
```

NOTE:

a. Near end loop-backs

1. Local loop-back: the out-going signal is looped back to the device to verify the device integrity.
2. Line loop-back: the entire incoming signal is looped back towards the line to isolate the device from the line
3. Payload loop-back: the payload of the incoming signal is looped back towards the line. This is done after the framer framed on the incoming signal.

b. Far end loop-backs

1. Remote line loop-back: the signal received by the remote unit is looped back towards the local device to verify line integrity.
2. Remote payload loop-back: the payload of the signal received by the remote unit is looped back towards the local device to verify the payload integrity.

c. Loop-back timer

The period of time from the activation of a loop-back to its de-activation is controlled by a timer. The default value of this timer is 60 seconds.

d. Diagnostics

Pseudo-random patterns are commonly used for diagnostic tests of digital systems. For E1, a 15-bit register PRBS (pseudo-random binary sequence) pattern is standard practice. This pattern is available for testing local system integrity by local loopback test, and for measuring the line quality. The diagnostics scenario is as follows:

1. First, send a remote loopback command to cause the remote facility to loopback DS0 time slots.
2. Then, activate the local PRBS diagnostics operation by using the Test command to enable the pattern and choose for test all time slots, or only idle time slots.
3. The FULL diagnostic uses a framed pattern. This is useful for testing full E1 loopback at the far-end.

Chapter 6 TERMINAL OPERATION

When the PRBS pattern sync is found, a bit error counter tracks total bit errors. It is advised to send the pattern for more than 15-minute interval to evaluate the quality of loop condition and facility reliability.

User may utilize the ‘>’ key to inject a single error, the ‘<’ key to reset error counter, and ‘ESC’ to terminate the test. Read the performance report to understand the type of errors that occur.

6.2.3 Alarm Setup

To do alarm setup, press “M” from Port Menu, then the following screen will show up.

```
E1 Port A          === Port Alarm Setup ===      13:33:25 12/06/2005
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

[TYPE]      [THRESHOLD]  [ALARM]
RAI          MAJOR
AIS          MAJOR
LOS          MAJOR
LOF          MAJOR
BPV          10E-5     MAJOR
ES           001       MAJOR
UAS          001       MAJOR
CSS          001       MAJOR
BUNDLE STATUS MAJOR
MAC CHANGE   MAJOR

<< Press ESC key to return to previous menu >>
```

NOTE:

Configuration		Options	Default
E1 Line	RAI	DISABLE, MAJOR, CRITICAL, MINOR	MAJOR
	AIS	DISABLE, MAJOR, CRITICAL, MINOR	MAJOR
	LOS	DISABLE, MAJOR, CRITICAL, MINOR	MAJOR
	LOF	DISABLE, MAJOR, CRITICAL, MINOR	MAJOR
	BPV	Alarm	DISABLE, MAJOR, CRITICAL, MINOR
		Threshold	10E- (5, 6, 7, 8, 9)
	ES	Alarm	DISABLE, MAJOR, CRITICAL, MINOR
		Threshold	1-900
	UAS	Alarm	DISABLE, MAJOR, CRITICAL, MINOR
		Threshold	1-900
	CSS	Alarm	DISABLE, MAJOR, CRITICAL, MINOR
		Threshold	1-900
	Bundle	Status	DISABLE, MAJOR, CRITICAL, MINOR
	Mac	Change	DISABLE, MAJOR, CRITICAL, MINOR

For description of acronym, please refer to Glossary

Chapter 6 TERMINAL OPERATION

6.2.4 Choose Port

Under Port Menu, press “P” to choose port, press ENTER to get into port menu.

```
E1 Port B           === Port Menu ===          00:40:11#01/01/UU93

[DISPLAY]
1 -> 1-Hour Perf. Report
2 -> 24-Hour Perf. Report
A -> Line Availability
C -> Configuration
I -> Status
H -> Alarm History
Q -> Alarm Queue

[LOG]
P -> Choose Port
F -> Log Off [SETUP],[MISC] Menu
O -> Log On [SETUP],[MISC] Menu
E -> Return to Main Menu

Port : A

[SETUP]
L -> Loopback Setup
S -> System Setup
K -> Clear Performance Data
M -> Alarm Setup
X -> Clear Alarm Queue & History
D -> Upgrade Firmware

[MISC]
Y -> Load Default Config
Z -> Reset
```

6.2.5 Clear Performance Data

Press “K” from Port Menu to clear performance data, the screen will show as below. Press “Y” or “N” to confirm the command.

```
=>> Clear Performance Data (Y/N) ?
```

6.2.6 Clear Alarm History

Under Port Menu, press “X” to clear alarm queue and history, then press “Y” or “N” to confirm it.

```
>> Clear alarm history - are you sure? [Y/N]
```

Chapter 5 Front Panel Operation

6.2.7 1-Hour Performance Report

Press "1" from E1 Port Menu to view the 1-hour performance report. Use TAB key to select register type, USER or LINE. The current selection will be highlighted by an asterisk (*).

>> Select Register Type ? *USER LINE

After pressing ENTER from the above screen, the following screen will show up

```
E1 Port A      === Port 1-Hour Stat. Report === 13:26:57 12/06/2005
Start Time = 11:09:23 12/06/2005
USER
-- Valid Seconds in Current 15-Min Interval : 293 seconds
          (ES)   (UAS)   (BES)   (SES)   (DM)   (CSS)
Current 15-Min Interval   : 0       293     0       0       0       0
1st Nearest 15-Min Interval : 0       900     0       0       0       1
2nd Nearest 15-Min Interval : 0       900     0       0       0       0
3rd Nearest 15-Min Interval : 0       900     0       0       0       0
4th Nearest 15-Min Interval : 0       900     0       0       0       0

-- Valid 15-Min Intervals in Current 24-Hour Interval: 14
          (ES)   (UAS)   (BES)   (SES)   (DM)   (CSS)
Current 24-Hour Interval   : 0       12600    0       0       0       1
12/05/2005      : ----- -----
12/04/2005      : ----- -----
12/03/2005      : ----- -----
12/02/2005      : ----- -----
12/01/2005      : ----- -----
11/30/2005      : ----- -----
11/29/2005      : ----- -----
```

<< TAB key to show Statistics Report >>
<< ESC key to return to previous menu, SPACE bar to refresh >>

NOTE:

Performance Parameter	Description	Definition 2-Frame/Multiframe	Definition 16-Frame/Multiframe
ES	Error Second	BPV \geq 1, OOF \geq 1, or CS \geq 1.	CRC \geq 1, OOF \geq 1, or CS \geq 1.
UAS	Unavailable Second	\geq 10 consecutive SES	\geq 10 consecutive SEC
BES	Bursty Error Second	$1 < \text{BPV} < 2048$	$1 < \text{CRC} < 805$
SES	Severe Error Second	BPV \geq 2048, or OOF \geq 1	CRC \geq 805, or OOF \geq 1.
DM	Degraded Minute	BPV \geq 123	CRC \geq 47
CSS	Controlled Slip Second	Frame slip \geq 1	Frame slip \geq 1

6.2.8 24-Hour Performance Report

Press "2" from E1 Port Menu to view the 24-hour performance report, use TAB key to select register type, USER or LINE, press ENTER.

```
>> Select Register Type ? *USER LINE
>> Select Parameter ? *ES UAS BES SES CSS DM AS EFS BPV
```

Use the cursor to select the desired parameter. The current selection will be highlighted by an asterisk (*) and press ENTER key to view the report as follows.

```
E1 Port A      === Port 24-Hour Perf. Report === 13:27:55 12/06/2005
Start Time = 11:09:23 12/06/2005
USER ES
-- Valid Seconds in Current 15-Min Interval : 384 seconds
-- Valid 15-Min Intervals in Current 24-Hour Interval: 14
                                         (ES)    (UAS)    (BES)    (SES)    (DM)    (CSS)
Current 15-Min Interval     : 0        384       0        0        0        0
Current 24-Hour Interval   : 0       12600       0        0        0        1

-- USER, ES, Last 96 15-Min Interval :
01-08 > 0      0      0      0      0      0      0
09-16 > 0      0      0      0      0      0      -
17-24 > -      -      -      -      -      -      -
25-32 > -      -      -      -      -      -      -
33-40 > -      -      -      -      -      -      -
41-48 > -      -      -      -      -      -      -
49-56 > -      -      -      -      -      -      -
57-64 > -      -      -      -      -      -      -
65-72 > -      -      -      -      -      -      -
73-80 > -      -      -      -      -      -      -
81-88 > -      -      -      -      -      -      -
89-96 > -      -      -      -      -      -      -
<< TAB key to show Statistics Report >>
<< ESC key to return to previous menu, SPACE bar to refresh
```

NOTE

Performance Parameter	Description	Definition 2-Frame/Multiframe	Definition 16-Frame/Multiframe
ES	Error Second	BPV \geq 1, OOF \geq 1, or CS \geq 1.	CRC \geq 1, OOF \geq 1, or CS \geq 1.
UAS	Unavailable Second	\geq 10 consecutive SES	\geq 10 consecutive SES
BES	Bursty Error Second	$1 < \text{BPV} < 2048$	$1 < \text{CRC} < 805$
SES	Severe Error Second	BPV \geq 2048, or OOF \geq 1	CRC \geq 805, or OOF \geq 1.
CSS	Controlled Slip Second	Frame slip \geq 1	Frame slip \geq 1
DM	Degraded Minute	BPV \geq 123	CRC \geq 47
AS	Available Second	Frame slip \geq 1	Frame slip \geq 1
EFS	Error Free Second	Error Free Second	Error Free Second
BPV	Bipolar Violation	Bipolar Error Count	Bipolar Error Count

Chapter 6 TERMINAL OPERATION

6.2.9 Line Availability

Under Port Menu, press “A” to view the line availability as the following screen shows, The information, based on user performance register set, includes the valid seconds, available seconds, unavailable seconds and the line availability.

```
E1 Port A      === Port Line Availability === 13:28:51 12/06/2005
Start Time      : 11:09:23 12/06/2005
-- Line Availability during Last 24-Hour:
Valid Seconds   : 13071 seconds
Available Seconds : 0 seconds
Unavailable Seconds: 13071 seconds
Line Availability : 0.0 %

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.2.10 Unit Configuration

To view the unit configuration, press “C” from Port Menu, then the screen will show as below.

```
E1 Port A      === Port System Setup === 13:29:13 12/06/2005
FRAME          = OFF
CODE           = HDB3
CRC            = ON
RAI            = ON
AIS            = FRAMED
CAS            = OFF
SIGNALLING    = TRANS
CGA             = NORM
OOS             = BUSY
FDL             = OFF
Sa_bit         = Sa4
IDLE           = 0
INTF           = 120 Ohm

<< ESC key to return to previous menu, SPACE bar to refresh >
```

Chapter 6 TERMINAL OPERATION

6.2.11 Unit Status

Press "I" from Port Menu, to show the screen of Status as below.

```
E1 Port A           === Port Status ===      13:31:14 12/06/2005

-- LINE --
LOS      : YES
LOF      : NO
RCV AIS : NO
RCV RAI : NO
XMT AIS : NO
XMT RAI : NO
BPV ERROR COUNT : 0
ES   ERROR COUNT : 0

-- TEST --
PATTERN TRANSMITTED : OFF
NEAR-END LOOPBACK    : OFF

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.2.12 Unit Alarm History

To view the unit alarm history, press "H" from Port Menu.

```
E1 Port A           === Port Alarm History ===      13:31:31 12/06/2005
LOCAL
[ALARM-TYPE]      [THRESHOLD]     [CURR-STATE]    [COUNT]    [ALARM]
RAI                OK             0              MAJOR
AIS                OK             0              MAJOR
LOS               ALM            1              MAJOR
LOF                OK             0              MAJOR
BPV          10E-5        OK             0              MAJOR
ES                  1             OK             1              MAJOR
UAS                1             OK             15             MAJOR
CSS                1             OK             1              MAJOR
BUNDLE STATUS      OK             0              MAJOR
MAC CHANGE         OK             0              MAJOR

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 6 TERMINAL OPERATION

6.3 T1 Sub-Menu

Under the Controller Menu, press "P" to choose port. The user can choose port B to do setup. Then the following Port Menu of T1 will show.

T1 Port B	==== Port Menu ====	15:09:53 10/03/2006
[DISPLAY]	[SETUP]	
1 -> 1-Hour Perf. Report	S -> System Setup	
2 -> 24-Hour Perf. Report	L -> Loopback Setup	
A -> Line Availability	K -> Clear Performance Data	
C -> Configuration	M -> Alarm Setup	
I -> Status	X -> Clear Alarm History	
H -> Alarm History	B -> Send Bert	
[LOG]		
P -> Choose Port		
F -> Log Off [SETUP], [MISC] Menu		
O -> Log On [SETUP], [MISC] Menu		
E -> Return to Main Menu		
>>SPACE bar to refresh or enter a command ==>		

6.3.1 System Setup

By Pressing "S", the system setup menu is displayed as follows.

1 Port B	==== Port System Setup ====	15:10:21 10/03/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS		
FRAME	= NONE	
CODE	= B8ZS	
YEL	= ON	
AIS	= OFF	
CAS	= OFF	
SIGNALLING	= TRANS	
CGA	= NORM	
OOS	= BUSY	
INBAND	= ON	
IDLE	= 0	
INTF	= LONG HAUL	
LBO	= 0 dB	
FDL	= OFF	
<< Press ESC key to return to previous menu >>		

Chapter 6 TERMINAL OPERATION

6.3.2 Loopback Setup

To enter the T1 status menu, press "L". The following screen appears.

```
T1 Port B          === Port Loopback Test ===      15:11:15 10/03/2006
ARROW KEYS : CURSOR MOVE , ENTER KEY : ITEM SELECT

- NEAR-END LOOPBACK   : *OFF LOCAL PLB LLB

- SEND LOOPBACK ACTIVATE CODE TO FAR-END:
    *IN-BAND AT&T-P ANSI-P ANSI-L
- SEND LOOPBACK DEACTIVATE CODE TO FAR-END:
    *IN-BAND AT&T-P ANSI-P ANSI-L

- STATUS:

<< Press ESC key to return to previous menu >>
```

6.3.3 Alarm Setup

Press "M" to view the alarm history.

```
T1 Port B          === Port Alarm Setup ===      15:12:00 10/03/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

[TYPE]      [THRESHOLD]  [ALARM]
YEL          MAJOR
AIS          MAJOR
LOS          MAJOR
LOF          MAJOR
BPV          10E-5     MAJOR
ES           001       MAJOR
UAS          001       MAJOR
CSS          001       MAJOR
BUNDLE STATUS MAJOR
MAC CHANGE   MAJOR

<< Press ESC key to return to previous menu >>
```

Chapter 6 TERMINAL OPERATION

6.3.4 Bert Test

Press "B" to test the system.

```
T1 Port B      === Bert test ===          15:12:19 10/03/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS
```

```
Type      = OFF
Direct   = LINE
TimeSlot From = 1
TimeSlot Num  = 1
```

```
<< Press ESC key to return to previous menu >>
```

6.3.5 Clear Performance Data

Press K to show Clear Performance Data screen.

```
=>> Clear Performance Data (Y/N) ?
```

6.3.6 Clear Alarm History

Press X to show Clear Alarm History screen.

```
>> Clear alarm history - are you sure ? [Y/N]
```

Chapter 6 TERMINAL OPERATION

6.3.7 1-Hour Performance Report

Under Port Menu, press "1" to view the 1-hour performance report.

```
T1 Port B      === Port 1-Hour Stat. Report === 15:15:29 10/03/2006
Start Time = 15:07:14 10/03/2006
USER
-- Valid Seconds in Current 15-Min Interval : 0 seconds
          (ES)   (UAS)   (BES)   (SES)   (CSS)
Current 15-Min Interval : 0       0       0       0       0
1st Nearest 15-Min Interval : ----- -----
2nd Nearest 15-Min Interval : ----- -----
3rd Nearest 15-Min Interval : ----- -----
4th Nearest 15-Min Interval : ----- -----
-- Valid 15-Min Intervals in Current 24-Hour Interval: 0
          (ES)   (UAS)   (BES)   (SES)   (CSS)
Current 24-Hour Interval : -----
10/02/2006      : -----
10/01/2006      : -----
09/30/2006      : -----
09/29/2006      : -----
09/28/2006      : -----
09/27/2006      : -----
09/26/2006      : -----
<< TAB key to show Statistics Report >>
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.3.8 24-Hour Performance Report

Under Port Menu, press "2" to view the 24-hour performance report.

```
T1 Port B      === Port 24-Hour Perf. Report === 15:29:02 10/03/2006
Start Time = 15:20:16 10/03/2006
USER ES
-- Valid Seconds in Current 15-Min Interval : 0 seconds
-- Valid 15-Min Intervals in Current 24-Hour Interval: 0
          (ES)   (UAS)   (BES)   (SES)   (CSS)
Current 15-Min Interval : 0       0       0       0       0
Current 24-Hour Interval : -----
-- USER, ES, Last 96 15-Min Interval :
01-08 > -----
09-16 > -----
17-24 > -----
25-32 > -----
33-40 > -----
41-48 > -----
49-56 > -----
57-64 > -----
65-72 > -----
73-80 > -----
81-88 > -----
89-96 > -----
<< TAB key to show Statistics Report >>
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 6 TERMINAL OPERATION

6.3.9 Line Availability

Under Port Menu, press "A" to view line availability as the following screen shows.

T1 Port B === Port Line Availability === 15:29:18 10/03/2006

Start Time : 15:20:16 10/03/2006

-- Line Availability during Last 24-Hour:

Valid Seconds : 0 seconds

Available Seconds : 0 seconds

Unavailable Seconds: 0 seconds

Line Availability : 21474836.48 %

6.3.10 Unit Configuration

To view the unit configuration, press "C" from Port menu, then the screen will show as below.

To view the unit configuration, press **C** from Port menu, then the **Setup**

T1 Port B ===== Port 1-Hour Stat. Report === 15:15:29

Start Time = 15:07:14 10/03/2006

USER

-- Valid Seconds in Current 15-Min Interval : 0 seconds

	(ES)	(UAS)	(BES)	(SES)	(CSS)
Current 15-Min Interval	: 0	0	0	0	0
1st Nearest 15-Min Interval	: -----	-----	-----	-----	-----
2nd Nearest 15-Min Interval	: -----	-----	-----	-----	-----
3rd Nearest 15-Min Interval	: -----	-----	-----	-----	-----
4th Nearest 15-Min Interval	: -----	-----	-----	-----	-----

-- Valid 15-Min Intervals in Current 24-Hour Interval: 0

	(ES)	(UAS)	(BES)	(SES)	(CSS)
Current 24-Hour Interval	: -----	-----	-----	-----	-----
10/02/2006	: -----	-----	-----	-----	-----
10/01/2006	: -----	-----	-----	-----	-----
09/30/2006	: -----	-----	-----	-----	-----
09/29/2006	: -----	-----	-----	-----	-----
09/28/2006	: -----	-----	-----	-----	-----
09/27/2006	: -----	-----	-----	-----	-----
09/26/2006	: -----	-----	-----	-----	-----

<< TAB key to show Statistics Report >>

<< ESC key to return to previous menu, SPACE bar to refresh >>

Chapter 6 TERMINAL OPERATION

6.3.11 Unit Status

Press I from the port menu, to show the screen of Unit Status as below.

```
T1 Port B           === Port Status ===      16:06:08 10/03/2006

-- LINE --
LOS      : LOS
LOF      : NO
RCV AIS : NO
RCV YEL : NO
XMT AIS : NO
XMT YEL : NO
BPV ERROR COUNT : 0
ES   ERROR COUNT : 0

-- TEST --
PATTERN TRANSMITTED : OFF
NEAR-END LOOPBACK    : OFF

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.3.12 Unit Alarm History

To view the unit alarm history, press "H" from the Port Menu.

```
T1 Port B           === Port Alarm History ===      16:06:27 10/03/2006
LOCAL
[ALARM-TYPE]      [THRESHOLD]      [CURR-STATE]      [COUNT]      [ALARM]
RAI                OK              0                  MAJOR
AIS                OK              0                  MAJOR
LOS               ALM             1                  MAJOR
LOF                OK              0                  MAJOR
BPV          1.0E-5        OK              0                  MAJOR
ES                 1              OK              0                  MAJOR
UAS                1              OK              0                  MAJOR
CSS                1              OK              0                  MAJOR
BUNDLE STATUS      OK              0                  MAJOR
MAC CHANGE         OK              0                  MAJOR

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 6 TERMINAL OPERATION

6.4 DTE (V.35) Sub-Menu

Under the Controller Menu, press "P" to choose port. The user can choose either port C or port D to do setup. Then the following Port Menu of DTE (V.35) port will show.

```
DTE Port C           === Port Menu ===      15:32:48 06/15/2006

[DISPLAY]
C -> DTE Configuration
I -> DTE Status
H -> Alarm History

[SETUP]
S -> System Setup
L -> Loopback Test
M -> Alarm Setup
X -> Clear Alarm History

[LOG]
P -> Choose Port
F -> Log Off
O -> Log On
E -> Return to Main Menu

>>SPACE bar to refresh or enter a command ===>
```

6.4.1 DTE Configuration

By Pressing "C", the unit setup menu is displayed as follows.

```
DTE Port C           === Port Status ===      09:23:36 07/17/2006

DTE Port C

[----- LOCAL -----]
Channel   : 31
mode       : N*64K
Rate        : 64KBps
TX_Clock   : Normal
RX_Clock   : Normal
Data       : Normal
RTS        : Active
TTM        : Off
DCD        : Normal
intf       : V35

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 6 TERMINAL OPERATION

6.4.2 DTE Status

To enter the DTE status menu, press "I". The following screen appears.

```
DTE Port C      === Port Status === 11:44:12 07/07/2006
```

```
[----- LOCAL -----]
```

```
DTE-3 existed : YES
RTS LOSS       : YES
EXT_CLK LOSS   : NO
DSR : NO
CTS : NO
DCD : NO
DTR : NO
RTS : NO
```

```
[Loopback Status]
```

```
DTE Loopback   : OFF
BERT           : OFF
```

```
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.4.3 Alarm History

Press "H" to view the alarm history.

```
LOOP IP6700      === Alarm History === 11:45:24 07/07/2006
```

```
[Port]  [State]  [Count]  [Alarm]
C       ALARM     1        MAJOR
```

```
<< ESC to return to previous menu, SPACE to refresh, U key to change unit >>
```

Chapter 6 TERMINAL OPERATION

6.4.4 System Setup

Press "S" to setup the system.

```
LOOP IP6700           === Alarm History ===      11:45:24 07/07/2006
[Port] [State] [Count] [Alarm]
C :     ALARM       1    MAJOR

<< ESC to return to previous menu, SPACE to refresh, U key to change unit >>
```

6.4.5 Loopback Test

To enter the Loopback and Test screen, press "L". The following screen appears.

```
LOOP IP6700           === Unit Loopback and Test ===      10:28:46 07/07/2006
ARROW KEYS: CURSOR MOVE; ENTER KEY: ITEM SELECT;

DTE Port C

[TEST MENU]
DTE Loopback          : *OFF   TO-DTE   TO-WAN

<< Press ESC key to return to previous menu >>
```

Chapter 6 TERMINAL OPERATION

6.4.6 Alarm Setup

To set up the alarm configuration, press “M”. The following screen is displayed.

```
LOOP IP6700      === Alarm Setup === 10:29:36 07/07/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS
```

```
[Port] [Alarm]
C : MAJOR
```

```
<< Press ESC key to return to previous menu >>
```

6.4.7 Clear Alarm History

Under Port Menu, press “X” to clear alarm history, then press “Y” or “N” to confirm it.

```
>> Clear alarm history - are you sure ? [Y/N]
```

Chapter 6 TERMINAL OPERATION

6.5 DS3/E3 Sub-Menu

The user can choose either DS3 or E3 to do setup. When the user plug in the DS3 card, all machine is for port A only. In addition, DS3 Card needs to plug in Port C.

```
DS3/E3 menu          14:08:38 02/07/2007

[DISPLAY]
1 -> 1-Hour Perf. Report
2 -> 24-Hour Perf. Report
A -> Line Availability
C -> Configuration
I -> Status
H -> Alarm History

[SETUP]
S -> System Setup
L -> Loopback Setup
K -> Clear Performance Data
M -> Alarm Setup
X -> Clear Alarm History

[LOG]
F -> Log Off [SETUP],[MISC] Menu
O -> Log On  [SETUP],[MISC] Menu
E -> Return to Main Menu

>>SPACE bar to refresh or enter a command ==>
```

6.5.1 DS3/E3 System Setup

By Pressing "S", the system setup menu is displayed as follows.

```
==== DS3/E3 System Setup ====        14:10:03 02/07/2007
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

CARD TYPE = DS3
TX-LENGTH = 0-225
XMT-AIS   = ON

<< Press ESC key to return to previous menu >>
```

6.5.2 DS3/E3 Loopback Test

To enter the Loopback and Test screen, press "L". The following screen appears.

```
==== DS3/E3 Loopback Test ==== 14:10:41 02/07/2007
ARROW KEYS : CURSOR MOVE , ENTER KEY : ITEM SELECT
- NEAR-END LOOPBACK : *OFF LLB LOCAL-A LOCAL-D

<< Press ESC key to return to previous menu >>
```

6.5.3 Clear Performance Data

Under DS3/E3 Menu, press "K" to clear performance data, then press "Y" or "N" to confirm it.

```
=>> Clear Performance Data (Y/N) ?
```

Chapter 5 Front Panel Operation

6.5.4 DS3/E3 Alarm Setup

To set up the alarm configuration, press "M". The following screen is displayed.

```
== DS3/E3 Alarm Setup == 14:11:16 02/07/2007
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS
```

[TYPE]	[THRESHOLD]	[ALARM]
LOS		MAJOR
LCV	10E-5	MAJOR
LES	001	MAJOR
SEFS	001	MAJOR
UAS	001	MAJOR
BUNDLE STATUS		MAJOR
MAC CHANGE		CRITICAL

```
<< Press ESC key to return to previous menu >>
```

6.5.5 Clear Alarm History

Under DS3/E3 Menu, press "X" to clear alarm history, then press "Y" or "N" to confirm it.

```
>> Clear alarm history - are you sure ? [Y/N]
```

Chapter 5 Front Panel Operation

6.5.6 DS3/E3 1-Hour Performance Report

Press “1” from the DS3/E3 menu, the following screen is displayed. To view 1-hour performance report by selecting register type, USER or LINE. The current selection will be highlighted by an asterisk (*).

```
==== DS3/E3 1-Hour Perf. Report ==== 14:14:38 02/07/2007
```

```
>> Select Register Type ? *USER LINE
```

```
==== DS3/E3 1-Hour Stat. Report ==== 14:11:45 02/07/2007  
Start Time = 14:04:55 02/07/2007
```

```
USER
```

```
-- Valid Seconds in Current 15-Min Interval : 407 seconds  
                                (LES)   (UAS)   (SEFS)   (LCV)  
Current 15-Min Interval : 0       0       0       0  
1st Nearest 15-Min Interval : ----- ----- ----- -----  
2nd Nearest 15-Min Interval : ----- ----- ----- -----  
3rd Nearest 15-Min Interval : ----- ----- ----- -----  
4th Nearest 15-Min Interval : ----- ----- ----- -----
```

```
-- Valid 15-Min Intervals in Current 24-Hour Interval: 0  
                                (LES)   (UAS)   (SEFS)   (LCV)  
Current 24-Hour Interval : ----- ----- ----- -----  
02/06/2007 : ----- ----- ----- -----  
02/05/2007 : ----- ----- ----- -----  
02/04/2007 : ----- ----- ----- -----  
02/03/2007 : ----- ----- ----- -----  
02/02/2007 : ----- ----- ----- -----  
02/01/2007 : ----- ----- ----- -----  
01/31/2007 : ----- ----- ----- -----
```

```
<< TAB key to show Statistics Report >>  
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 5 Front Panel Operation

6.5.7 DS3/E3 24-Hour Performance Report

Press "2" from the DS3/E3 menu, the following screen is displayed. To view 24-hour performance report by selecting register type, USER or LINE. The current selection will be highlighted by an asterisk (*).

```
==== DS3/E3 24-Hour Perf. Report === 14:15:08 02/07/2007
```

```
>> Select Register Type ? *USER LINE
```

```
==== DS3/E3 24-Hour Perf. Report === 14:12:36 02/07/2007
```

```
>> Select Register Type ? *USER LINE  
>> Select Parameter ? *LES UAS SEFS LCV
```

Chapter 6 TERMINAL OPERATION

```
==== DS3/E3 24-Hour Perf. Report === 14:15:51 02/07/2007
Start Time = 14:04:55 02/07/2007
USER LES
-- Valid Seconds in Current 15-Min Interval : 653 seconds
-- Valid 15-Min Intervals in Current 24-Hour Interval: 0
-- (LES) (UAS) (SEFS) (LCV)
Current 15-Min Interval : 0 0 0 0
Current 24-Hour Interval : ----- ----- ----- -----

-- USER, LES, Last 96 15-Min Interval :
01-08 > -----
09-16 > -----
17-24 > -----
25-32 > -----
33-40 > -----
41-48 > -----
49-56 > -----
57-64 > -----
65-72 > -----
73-80 > -----
81-88 > -----
89-96 > -----
<< TAB key to show Statistics Report >>
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.5.8 DS3/E3 Line Availability

Under DS3/E3 Menu, press "A" to view the line availability as the following screen shows.

```
==== DS3/E3 Line Availability === 14:16:36 02/07/2007
Start Time : 14:04:55 02/07/2007

-- Line Availability during Last 24-Hour:
Valid Seconds : 698 seconds
Available Seconds : 698 seconds
Unavailable Seconds: 0 seconds
Line Availability : 100.0 %

<< ESC key to return to previous menu, SPACE bar to refresh >>
```

Chapter 5 Front Panel Operation

6.5.9 DS3/E3 System Setup

To setup DS3/E3 system, press "S" from DS3/E3 Menu, then the following screen will show up.
Use arrow keys to move the cursor, TAB key to roll up options.

```
==== DS3/E3 System Setup === 14:16:59 02/07/2007
```

```
CARD TYPE = DS3  
TX-LENGTH = 0-225  
XMT-AIS = ON
```

```
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.5.10 DS3/E3 Status

Press "I" from DS3/E3 Menu, to show the screen of DS3//E3 Status as below.

```
==== DS3/E3 Status === 14:17:17 02/07/2007
```

```
-- LINE --  
LOS : NO  
XMT AIS : NO  
BPV ERROR COUNT : 0  
ES ERROR COUNT : 0
```

```
<< ESC key to return to previous menu, SPACE bar to refresh >>
```

6.5.11 DS3/E3 Alarm History

To view alarm history, press "H" from the DS3/E3 menu, then the following screen will show as below.

==== DS3/E3 Alarm History ===					14:17:42 02/07/2007
LOCAL	[ALARM-TYPE]	[THRESHOLD]	[CURR-STATE]	[COUNT]	[ALARM]
LOS			OK	0	MAJOR
LCV		10E-5	OK	0	MAJOR
LES		1	OK	0	MAJOR
SEFS		1	OK	0	MAJOR
UAS		1	OK	0	MAJOR
BUNDLE STATUS			ALM	0	MAJOR
MAC CHANGE			OK	0	CRITICAL

<< ESC key to return to previous menu, SPACE bar to refresh >>

7 STEP BY STEP OPERATION

7.1 Time Slot IP Assignment

7.1.1 Time Slot IP Assignment (Add bundle)

Under the Main Menu, press "T" to get into the screen of Time Slot IP Assignment, then choose "Add bundle" from the Action menu to create a new bundle.

```
LOOP IP6700      === System Setup (MAP) ===      15:09:10 10/03/2006
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

Port      : PORT_A          PO/TS TS PO/TS TS BNDL ID/UDP NUM Dest IP Address
Bundle ID : 00              ===== == ===== = ===== Cell Num Jitter Delay Jitter Size
Action    : Add bundle      UDP Number: 0001
Time Slot : 00              Time Slot# : 32
Time Slot# : 32             Dest IP Addr: 010.002.003.004
Cell in Bundle: 05          Cell in Bundle: 05
Jitter Delay: 020           Jitter Delay: 020
Jitter Size: 256            Jitter Size: 256
VLAN: OFF                  VLAN: OFF
VLAN1 ID: 0000              VLAN1 ID: 0000
VLAN1 priority: 0          VLAN1 priority: 0
VLAN2 ID: 0000              VLAN2 ID: 0000
VLAN2 priority: 0          VLAN2 priority: 0
Confirm? No                 Confirm? No

<< Press ESC key to return to main menu or save system setup >>
```

Note: if it is unframe allocation, the bundle ID must be 0 and the Time Slot, Time Slot# will be skipped to disallow user set up.

If the IP Address is invalid. The error message will display.

```
Can not get target mac address
```

After confirm the configuration. Press "Y" or "N" to re-confirm it.

```
Are you sure [Y/N] ?
```

After save the configuration, the screen will refresh and display as follow

```
LOOP IP6700      === System Setup (MAP) ===      13:35:55 12/06/2005
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

Port      : PORT_A          PO/TS TS PO/TS TS BNDL ID/UDP NUM     IP Address
Action    : Add bundle      A 1 1 A 17 17 0           1 000.000.000.000
Bundle ID : 0              A 2 2 A 18 18
UDP Number: 1              A 3 3 A 19 19 Cell Num Jitter Size Jitter Delay
Time Slot : 01             A 4 4 A 20 20 ===== ===== =====
Time Slot# : 01            A 5 5 A 21 21 5           20 256
IP Address: 000.000.000.000 A 6 6 A 22 22
Cell in Bundle: 5          A 7 7 A 23 23
Jitter Delay: 20           A 8 8 A 24 24
Jitter Size: 256           A 9 9 A 25 25
Confirm? Yes               A 10 10 A 26 26
                           A 11 11 A 27 27
                           A 12 12 A 28 28
                           A 13 13 A 29 29
                           A 14 14 A 30 30
                           A 15 15 A 31 31
                           A 16 16

<< Press ESC key to return to main menu or save system setup >>
```

Chapter 6 TERMINAL OPERATION

To show all the information of time slot assignment which user has configured, Press "J" from the Main Menu Configuration Menu.

```
LOOP IP6700          === System Setup (MAP) ===      13:59:40 12/06/2005
Port Bundle UDP Cells Jitter    IP Address      Time Slot
ID      Num  Num size/Delay
=====
A       0     1   5    20  256 192.168.0.1    0,1,2,3,4,5,6,7,8,9,10,11,12,
                                                13,14,15,16,17,18,19,20,21,22,
                                                23,24,25,26,27,28,29,30,31
B       0     2   5    20  256 192.168.0.2    0,1,2,3,4,5,6,7,8,9,10,11,12,
                                                13,14,15,16,17,18,19,20,21,22,
                                                23,24,25,26,27,28,29,30,31

<< SPACE bar to refresh or ESC key return to main menu >>
```

7.1.2 Time Slot IP Assignment (Delete bundle)

Choose the "Delete bundle" option from the Action menu. Then enter the valid bundle ID at the Bundle ID field.

```
LOOP IP6700          === System Setup (MAP) ===      15:44:10 12/19/2005
Please Input decimal number (0-31), BACKSPACE to edit

Port      : PORT_A          PO/TS TS  PO/TS TS  BNDL ID/UDP NUM    IP Address
Action    : Delete bundle   ===== ==  ===== ==  ===== ===== =====
Bundle ID : 0               1      17
Bundle ID : 0_              2      18
UDP Number: 1               3      19    Cell Num Jitter Size Jitter Delay
Time Slot : 01              4      20
Time Slot# : 01             5      21
IP Address: 192.168.0.1     6      22
Cell in Bundle: 5           7      23
Jitter Delay: 20            8      24
Jitter Size: 256            9      25
Confirm?    Yes             10     26
                           11     27
                           12     28
                           13     29
                           14     30
                           15     31
                           16

<< Press ESC key to return to main menu or save system setup >>
```

If the value which user has entered is invalid, the error message will display.

```
Bundle ID not existed!
```

After confirm the configuration. Press "Y" or "N" to re-confirm it.

```
Are you sure [Y/N] ?
```

Chapter 6 TERMINAL OPERATION

7.1.3 Time Slot IP Assignment (Delete all)

Choose the “Delete all” option from the Action menu. This option is used to clear all the bundles setup which has been created.

```
LOOP IP6700      === System Setup (MAP) ===      17:28:14 12/19/2005
ARROW KEYS: CURSOR MOVE, TAB: ROLL OPTIONS

Port      : PORT_A          PO/TS TS PO/TS TS BNDL ID/UDP NUM   IP Address
Action    : Delete all      ===== == ===== = ===== ===== ===== =====
Bundle ID : 00              Cell Num Jitter Size Jitter Delay
UDP Number: 0001            ===== = ===== = ===== = =====
Time Slot : 01              Time Slot# : 01
Time Slot# : 01
IP Address: 000.000.000.000
Cell in Bundle: 05
Jitter Delay: 020
Jitter Size: 256
Confirm? Yes

<< Press ESC key to return to main menu or save system setup >>
```

After confirm the configuration. Press “Y” or “N” to re-confirm it.

```
Are you sure [Y/N]?
```

7.2 Password Setup

Press “S” from the main menu to get into System Setup. Then press “C” to get into password setup.

7.2.1 Enter old password

Before making change of new password, user need to fill in the old password, the default password is “LOOP”.

```
LOOP IP6700      === Password Setup ===      18:17:53 12/19/2005
ARROW KEYS: CURSOR MOVE, BACKSPACE to edit, ESC to abort

Enable Password : YES
Change Password : YES
Old Password : _____
>> Please input old password, then press ENTER .
```

Chapter 5 Front Panel Operation

7.2.2 Enter new password

Enter the valid old password, then press ENTER, the new password will be required to enter.

```
LOOP IP6700      === Password Setup ===      18:17:53 12/19/2005
ARROW KEYS: CURSOR MOVE, BACKSPACE to edit, ESC to abort
```

```
Enable Password : YES
Change Password : YES
Old    Password : XXXX-----
New    Password : XXXX-----
```

```
>> Please input new password, then press ENTER .
```

7.2.3 Confirmation of new password

After confirm new password. Press "Y", or "N" to save new password.

```
LOOP IP6700      === Password Setup ===      18:37:32 12/19/2005
ARROW KEYS: CURSOR MOVE, BACKSPACE to edit, ESC to abort
```

```
Enable Password : YES
Change Password : YES
Old    Password : XXXX-----
New    Password : XXXX-----
Confirm Password: XXXX-----
```

```
>> Save new password (Y/N) ?
```

7.3 Clock source setup

The IP6700 provide operator to setup each port's clock source from internal, external, line (from A/B/C/D), or WAN (from A/B/C/D).




Figure 7- 1 Clock Source

7.3.1 Application

The application diagram of IP6700 clock source shows below.




Figure 7- 2 Application Diagram of clock source

7.3.1.1 Example of clock source

For the clock source there are two examples to show as the table below.

Table 7- 1 Example 1: unique clock source (from IP6700-1 line clock of Port A)

	Port A	Port B	Port C	
IP6700-1	Line clock A	Line clock A	Line clock A	
IP6700-2	WAN clock A			
IP6700-3	WAN clock A			
IP6700-4	WAN clock A			

Table 7- 2 Example 2: independent clock source

	Port A	Port B	Port C	
IP6700-1	Line clock A	Line clock B	Line clock C	
IP6700-2	WAN clock A			
IP6700-3	WAN clock A			
IP6700-4	WAN clock A			

8 Functional Description

8.1 TDMoEthernet Packet Format

To transport TDM data through packet switched networks, the PacketTrunk-4 encapsulates it into Ethernet packets, as depicted in Figure 8-1. TDMoEthernet Encapsulation in an Ethernet Packet.




Figure 8- 3 TDMoEthernet Encapsulation in an Ethernet Packet

Table 8- 3 Ethernet Packet Structure

Field	Description
Preamble	A sequence of 56 bits (alternating 1 and 0 values) used for synchronization. Gives components in the network time to detect the presence of a signal.
Start frame delimiter	A sequence of 8 bits (10101011) that indicates the start of the packet.
Destination and source addresses	The Destination Address field identifies the station or stations that are to receive the packet. The Source Address identifies the station that originated the packet. A Destination Address may specify either an "individual address" destined for a single station, or a "multicast address" destined for a group of stations. A Destination Address of all 1 bits refers to all stations on the LAN and is called a "broadcast address".

Table 8- 4 Ethernet Packet Structure (Cont.)

Field	Description
Type	Protocol type
Data and padding	This field contains the data transferred from the source station to the destination station or stations. The maximum size of this field is 1500 bytes. If the size of this field is less than 46 bytes, then padding is used to bring the packet size up to the minimum length. A minimum Ethernet packet size is 64 bytes from the Destination Address field through the Frame Check Sequence.
Frame check sequence	This field contains a 4-byte cyclical redundancy check (CRC) value used for error checking. When a source station assembles a packet, it performs a CRC calculation on all the bits in the packet from the Destination Address through the Pad fields (that is, all fields except the preamble, start frame delimiter, and frame check sequence). The source station stores the value in this field and transmits it as part of the packet. When the packet is received by the destination station, it performs an identical check. If the calculated value does not match the value in this field, the destination station assumes an error has occurred during transmission and discards the packet.

8.1.1 VLAN Option

The original Ethernet standards defined the minimum packet size as 64 bytes and the maximum as 1518 bytes. These numbers include all bytes from the Destination Address field through the Frame Check Sequence field. The Preamble and Start Frame Delimiter fields are not included when quoting the size of a packet. The IEEE 802.3ac standard released in 1998 extended the maximum allowable packet size to 1522 bytes to allow a VLAN tag to be inserted into the Ethernet packet format. If present, the 2-byte VLAN tag is set to 0x8100, a reserved Type field assignment indicating the presence of the VLAN tag and a ‘traditional’ Type field 4 bytes further into the packet.

The 2-byte VLAN Tag Control field consists of:

First 3 bits User Priority field, used to assign a priority level to the Ethernet packet

Next 1 bit Canonical Format Indicator indicating the presence of a Router Information Field

Last 12 bits VLAN Identifier, uniquely identifying the VLAN to which the Ethernet packet belongs.

The packet may contain two VLAN tags to support VLAN stacking.

Chapter 6 TERMINAL OPERATION

8.1.2 UDP/IP Header




Figure 8- 4 UDP/IP Header

Table 8- 5 IP Header Structure

Field	Description
IPVER	IP version number, e.g. for IPv4 IPVER=4
IHL	Length in 32-bit words of the IP header, IHL=5
IP TOS	IP type of service
Total length	Length in octets of header and data
Identification	IP fragmentation identification
Flags	IP control flags; must be set to 010 to avoid fragmentation
Fragment offset	Indicates where in the datagram the fragment belongs; not used for TDMoEthernet
Time to live	IP time to live field; datagrams with zero in this field are to be discarded
Protocol	Must be set to 0x11 to signify UDP
IP Header checksum	Checksum for the IP header
Source IP address	IP address of the source
Destination IP address	IP address of the destination

Chapter 5 Front Panel Operation

Table 8- 6 UDP Header Structure

Field	Description
VER	TDMoEthernet version number. Presently VER=001
Bundle number	This field is usually dedicated to the Source Port Number, but here identifies the unique data stream emanating from a given trunk and sharing a common destination. This nonstandard use of a UDP port number is similar to RTP/RTCP's use of port numbers to uniquely identify sessions, and the common practice (sanctioned in H.225) of randomly allocating port numbers for VoIP sessions. Here placing the bundle identifier in the UDP header rather than the application area enables fast switching. Possible values are: 1-8063: valid bundle numbers 0: reserved 8191 (1FFF): used for OAM control messages the 127 ports 8064-8190: reserved.
Destination port number	Set to 0x085E (2142), the user port number which has been assigned to TDMoEthernet by the Internet Assigned Numbers Authority (IANA)
UDP length	Length in octets of UDP header and data
UDP checksum	Checksum of UDP/IP header and data. If not computed it must be set to zero.

8.1.3 TDMoEthernet Control Word




Table 8- 7 TDMoEthernet Control Word Structure

Field	Description
FORMID	Format Identifier: 1100 AAL1 unstructured 1101 AAL1 structured 1110 AAL1 structured with CAS 1111 HDLC
L	Local loss of sync failure. This bit is set by the CPU. A set L bit indicates that the source has detected or has been informed of a TDM physical layer fault impacting the data to be transmitted. This bit can be used to indicate physical layer LOS that should trigger AIS generation at the far end. Once set, if the TDM fault is rectified, the L bit must be cleared.
R	Remote receive failure. This bit is set by the CPU. A set R bit indicates that the source is not receiving packets at the Ethernet port, i.e., there is a failure of that direction of the bi-directional connection. This indication can be used to signal congestion or other network related faults. Receiving remote failure indication may trigger fall-back mechanisms for congestion avoidance. The R bit must be set after a preconfigured number of consecutive packets are not received, and must be cleared once packets are once again received.
RES	Reserved bits. Must be set to zero.
Length	The length of the TDMoEthernet packet (control word and payload), in case padding is employed to meet minimum transmission unit requirements of the PSN. It is used if the total packet length (including PSN, control word, and payload) is less than 64 bytes. Otherwise, it is set to zero.
Sequence number	TDMoEthernet sequence number, defined separately for each bundle and incremented by one for each TDMoEthernet packet sent for that bundle. The initial value of the sequence number is random (unpredictable) for security purposes, and the value is incremented modulo 2 ¹⁶ separately for each bundle. Used by the receiver to detect packet loss and restore packet sequence.

8.1.4 TDMoEthernet Payload

This field can contain the following payload types:

- AAL1

The AAL1 payload type detail is provided in the "AAL1 Payload Type Machine as below.

8.2 AAL1 PAYLOAD TYPE MACHINE

For the prevalent case for which the timeslot allocation is static and no activity detection is performed, the payload can be efficiently encoded using constant bit rate AAL1 adaptation.

In the TDM to Ethernet direction, the AAL1 Payload Type machine concatenates the bundle's timeslots payload into structures and then slices it into 48-octet AAL1 cells. After adding the AAL1 header, the cells are concatenated into the Ethernet packet payload.




Figure 8- 5 AAL1 Processing

Table 8- 8 AAL1 Header Structure

Field	Length [bits]	Description
C	1	Indicates if there is a pointer in the 2nd octet of the cell. When set, a pointer exists.
SN	3	Cell sequence number
CRC	3	Error cyclic redundancy code on C and SN
P	1	Even parity bit on C, SN and CRC or the even byte parity LSB for the sequence number octet (P format cells only)
E	1	(P format cells only) Even byte parity MSB for pointer octet
Pointer	7	(P format cells only) Indicates the next structure boundary. It is always located at the first possible position in the sequence number cycle, in which a structure boundary occurs. The pointer indicates one of 93 octets (46 octets of the current cell + 47 octets of the next cell). P=0 indicates that the first octet of the current cell's payload is the first octet of the structure. P=93 indicates that the last octet of the next cell is the final octet of the structure.

The AAL1 block supports the following bundle types:

- Unstructured
- Structured without CAS
- Structured with CAS.

Unstructured bundles, as part of the E1/T1 interface, support rates of $N \times 64$ kbps, where N is the number of timeslots configured to be assigned to a bundle. Unstructured bundles may also carry traffic of the whole low-speed interface (up to 4.6 Mbps), T1 interface (1.544 Mbps) and high-speed interface (up to 51.84 Mbps).

The 47-octet AAL1 type cell's payload contains 376 bits of pure TDM bit stream, without synchronization. Each cell has a one-byte header containing sequence number and protection fields.

Structured without CAS bundles, as part of the E1/T1 interface, support rates of

$N \times 64$ kbps, where N is the number of timeslots configured to be assigned to a bundle. For this format, the timeslots belonging to the bundle are sequentially placed in a structure, one octet per timeslot, until all 47 octets are filled. The 47th octet may contain a timeslot other than the last one in the bundle. Therefore the 1st octet of the next cell will contain the next timeslot of the same bundle.




Figure 8- 6 AAL1 Processing for Structured without CAS Bundles

This means that each cell can start with a different timeslot. In order for the far end to recognize the first timeslot in the bundle, a pointer to it is sent periodically in one of the 8 cells of every SN cycle. When this pointer is sent, a P-format cell is used.

Structured with CAS bundles as part of the E1/T1 interface, support rates of $N \times 64$ kbps, where N is the number of timeslots configured to be assigned to a bundle. For this format, the AAL1 header is identical with the previously explained one. The addition of CAS only affects the structure contents. CAS data of one timeslot is 4 bits long, meaning one octet can contain CAS data of 2 timeslots. Bundles containing an odd number of timeslots need a padding of 4 zeroes in the last CAS octet. For example, a 3-timeslot bundle of an E1 frame with CAS will yield the following structure octet sequence: TS1, TS2, TS3 repeated 16 times and then CAS1+CAS2, CAS3+padding.

In the Ethernet to TDM direction, cells/packets of a bundle are being received only after the synchronization process. The synchronization process includes cell SN synchronization, packet SN synchronization and pointer synchronization. Cells with CRC or parity errors in their header are discarded. Pointer mismatch imposes jitter buffer under-run and bundle resynchronization. Cell header errors or pointer errors may be ignored depending on per-bundle configuration. Missing cells or packets are detected and restored in the jitter buffer.

Glossary

AIS	Alarm Indication Signal
AS	Available Second
BES	Bursty Error Second
BPV	Bipolar Violation
CRC	Cyclical Redundancy Check
CSS	Controlled Slip Second
DM	Degraded Minute
DS1	Digital Signal, Level One - E1 or T1
DS3	Digital Signal, Level Three – E3 or T3
DTE	Data Terminal Equipment-an end-user machine. Eg. PC or workstation
EFS	Error Free Second
ES	Error Second
FDL	Facility Data Link
IP	Internet Protocol
LCD	Liquid Crystal Display
LAN	Local Area Network
LED	Light Emitting Diode
LIU	Line Interface Unit
LOF	Loss of Frame
LOS	Loss of Signal
NMS	Network Management System
PRBS	Pseudo Random Binary Sequence
QRSS	Quasi Random Signal Sequence
RAI	Remote Alarm Indication
SAToP	Structure Agnostic TDM over Packet
SES	Severe Error Second
SNMP	Simple Network Management Protocol
TDM	Time Division Multiplexing
UAS	Unavailable Second
VLAN	Virtual LAN Area Network
WAN	WAN wide Area Network