

Operating Manual

Electronic Balance

Thank You For Choosing Our Electronic Balance!

Contents

1. Environment Conditions	2
2. Operation	2
3. Calibration	2
4. Weighing	3
5. Tare	3
6. Backlight	3
7. Zero-Tracking & Auto. Tare	3
8. Other Functions	4
8.1 Units Conversion	4
8.2 Counting	4
8.3 Percentage	4
8.4 Print	4
8.5 Speed adjustment of weighing	5
8.6 Low voltage indication	5
9. Note	6
10. Maintenance	6
11. Accessories	7

One. Environment Conditions

1. Place the balance in stably and smooth away vibration, sunlight, airflow and strong electromagnetic wave .
2. Temperature: 5°C ~35°C Temperature Fluctuation: ≤5°C/h
Humidity : 50%~85%

Two. Operation

1. Plug in the electronic balance and warm up 10 minutes better.
2. Turn-on. It displays "8.8.8.8.8.8.", "Maximum capacity", "S-CAL" in turns. Under weighing mode, it shows "0", "0.0", "0.00" or "0.000".

Three. Calibration

1. Single-range calibration
Press <CAL> for 3 seconds → Show "CAL*** " → "g" flicker → Put a standard weight on the pan → Show "-CAL- " → Show weight value → Enter into weighing mode. After calibration, if you found it still shows not exactly, please re-calibrating.
2. Mult-range calibration
Press <CAL> for 3 seconds → Press "CAL" again and again, it will show different weight value and "CAL L", you can choose one kind of weight values to calibrate on the basis of single-range calibration, or you also can choose "CAL L" to perform the linear calibration.

When the screen shows "no CAL", it means you did not put weight on the pan in 10 seconds. It will leave calibration mode automatically.

Four. Weighing

1. Read the value on the screen after the black spot what is at the bottom left disappeared. (That means the value is stable)
2. The Max weighing is the showing largest value after turn on add 9d

(e=10d,"d" is minimum reading). If overloading, it will show "-----" and you must take away the goods at once, or the balance (load cell, especially) will be broken.

Five. Tare

Press <TARE>, the balance pan can be tared if the blank spot disappears. But if there is the black spot, the tare function is no effect.

Six. Backlight

Press <BL> to turn on/off the backlight.

Seven. Zero-Tracking and Auto Tare

1. Turn off the balance, one hand press and hold <CAL> at the same time, another hand turn on the balance again, "-Zero-" will show, then loose the key, and press <TARE>. It will show "Zero*d". Press <TARE> can adjust the "*" from 0 to 5, "Zero0d" means no Zero-tracking function (sensitivity is the highest), "Zero5d" means Zero-tracking is the largest. "Zero5d" is factory-set.
2. Then press <CAL>, it will show "-tArE-", press <TARE>, "tArE*d" will be shown, press <TARE> can adjust the "*" from 0 to 9. "tArE0d" means no Auto Tare, "tArE9d" means Auto Tare Function is the largest. "tArE9d" is factory-set.
3. Press <BL>, the setting is done after it shows "0" or "0.0" or "0.00" or "0.000".

It is convenient to use because the electronic balance can remember the latest setting when you turn on next time.

Eight. Other Functions

1. Units Conversion

Press <MODE> about 3 seconds till "Unit" flashing. Then press <TARE> to confirm. Press <MODE> to select units and press <TARE> to confirm.

2. Counting

Press <MODE> 3 scends till "Unit" flashing. Press <MODE> to choose "Count". Then press <TARE> to confirm, show "pcs". Press <MODE>, "pcs" can be changed from "10pcs" to "500pcs". The larger number, the higher count accuracy. Put the relevant goods on the balance pan, then press <TARE> to confirm. It will show "-----". Setting Counting is done.
When the counting unit weight < 2d, it will show "no-Cou". In this case, you should choose several goods together as a Unit and reset.

3. Percentage

Press <MODE> about 3 scends till "Unit" flashing. Press <MODE> to choose "PER". Then press <TARE> to confirm, show "100%" unit. Put the goods on the pan and press <TARE>, the goods are set as a unit "100%". Take away the goods and put on other goods, it will display "###%".
When the set goods weight what is divided by 100 is less than 2d, it cannot work and only show "no-PER". It should add to goods weight.

4. Print

Press <MODE> about 3 scends till "Unit" flashing. Press <MODE> to choose "Prt". Then press <TARE> to confirm. Press <MODE> to choose "hAnd", "AUto" or "Contin". And press <TARE> to confirm.

"hAnd". (Means Printer just will print one time).

"AUto". (Means when the objects placed on the pan is >3d, and only the value is stable, Printer will print automatically)

"Contin" (Means no matter how heavy the object on the pan, and no matter whether the value is stable or not, Printer will print continuously)

RS232 Data Frame Format:

Symbol (+/-) + Data + Unit + Last Frame

1. Data Symbol: 1 Byte ASCII: "+" or "-"
2. Data Field: 7 Bytes ASCII: One is Decimal Point ".", which has the same position with Display.

3. 3 Bytes ASCII: Units< 3 bits, Supplementary with Space

4. Last Frame: ENTER ASCII, 0DH, 0AH.

Units:

LB: 6C 62	OZ: 6F 7A	GN: 47 4E	KG: 6B 67	+ : 2B	- : 2D
-----------	-----------	-----------	-----------	--------	--------

Example:

38.25g, Stable

+	0	0	3	8	.	2	5		g				
2B	30	30	33	38	2E	32	35	20	67	20	20	0D	0A

30.00ct, Unstable

+	0	0	0	0	3	0	.		c	t			
2B	30	30	30	30	33	30	2E	20	63	74	20	0D	0A

60 pcs Counting, Stable

+	0	0	0	0	0	0			p	c	s		
2B	30	30	30	30	30	30	20	70	63	73	0D	0A	

26% Percentage, Stable

+	0	0	0	0	2	6			%				
2B	30	30	30	30	32	36	20	25	20	20	0D	0A	


Serial Port:

Computer (9 Cores)

Balance (9 Cores)

2 ----- 2
5 ----- 5

Baud Rate (bpc): 9600 bps



Pin 2: TXD; Pin 3: RXD; Pin 5: GND

(Note: K Series Balances do not have RS232 Interface)

5. Speed adjustment of weighing

Press <TARE> for 3 seconds, it will show "SPEED!", drop the key, and enter weighing model. Although the speed is slow, the accuracy is good. The same way, if you choose "SPEED2", the speed is faster, but less accuracy.

6. Low voltage indication

When the screen shows battery symbol in the upper left side, it is time to replace the new battery.

Nine. Note in use

1. Warm up 30 minutes before using and calibration
2. The tare and object weight must not be beyond the limit.
3. If the weighing results are not exact, calibration again.

Ten. Maintenance

Failure	Cause	Remedy
No light	·Scale is not connected with power ·Power switch is off ·Adapter is broken ·PCB is broken	·To plug in the power ·To press "turn-on" key ·To change new adapter ·To change new PCB
Upper "----" only	·over-load ·load cell wire loose	·To decrease load ·To re-connect the wire
S-CAL	·load cell wire loose ·No connect load cell wire	·To connect load cell wire
Value unstable	·Big air ·Working stage is unstable ·Big change of room temperature ·Load cell is broken	·To shut door or window ·To put scale on stable stage ·To control temperature ·To check load cell
Value inaccuracy or big error	·No clear zero before weight ·No calibrate or calibration weight is inaccuracy ·Wrong voltage ·Big error in four corners of load cell ·Load cell is broken	·To press <TARE> key ·To re-calibrate ·To use right voltage ·To check error of four corners ·To check load cell

Stay or show wrong symbols	·Short distracting outside	·To reboot or re-plug in power ·To reboot after 30 minutes
Show "•" on the left all long or repeatedly	·Bad operation environment (such as big air, vibration, big change in room temperature and so on.)	·To control working temperature
Show "No Cou"	·No set constant before counting ·constant is too big or small	·To set average value constant ·To re-calibrate
No data	·Distracted (by static...) and crash	·To reboot or re-plug in power
No back to zero	·Wires loose	·To check all wires
No calibration	·PCB is broken ·Load cell is broken ·Wires loose	·To change PCB ·To check load cell ·To check all wires
No Backlight	·Backlight is broken	·To change new backlight

Eleven. Accessories:

Scale Main Frame	1unit
Scale Pan	1unit
User's Manual	1unit
AC Adapter	1unit

OPT:

Calibration Weight	1unit
Windshield	1unit