

Important Product Information

March 15, 2010

GFK-0608F

Read This Information First

Product:

Series 90™–70 PLC CPU Module Update Kit

IC697CPU782DU Version 4.02

Hardware Identification: CPHA1 44A729676–G01 R12 or later

Software Identification: EPROM Label

- (Location U72): 397–015B 4.02
- (Location U73): 397–016B 4.02
- (Location U74): 397–014B 4.02
- (Location U75): 397–013B 4.02

Replaces IC697CPU782C

This is the release of the version 4.02 firmware update kit for the Series 90–70 Model 782 CPU module. The purpose of this release is to provide the new functions described under "New Features and Functionality".

Update Strategy:

An update kit is available for updating IC697CPU782C to release 4.02.

Field Update Kit:

44A731217–G03 for upgrading IC697CPU782C to IC697CPU782DU Version 4.02.

Documentation:

IPI: GFK-0608F; Data Sheet: GFK-0555; User's Manual: GFK-0262D

Read this document before installing or attempting to use the Series 90–70 Model 781 PLC CPU Module, IC697CPU781DU with your Series 90–70 PLC system. For more information, refer to GFK-0262, *Series 90–70 Programmable Controller Installation manual*, GFK-0263, *Logicmaster 90 Programming Software User's Manual*, and GFK-0265, *Series 90–70 Programmable Controller Reference Manual*.

TMSeries 90 is a trademark of GE Intelligent Platforms North America, Inc.

Operating Notes:

Logicmaster Compatibility

1. This release of the PLC CPU module is compatible with Logicmaster 90-70 version 2.04 or later. However, version 4.01 or later is required to gain access to all of the CPU's features and functionality. To work around a compatibility problem with serial Logicmaster 90-70, the PLC will return 3.42 as its version to all serial Logicmaster 90-70 products (WSI and Standard COM) release 3.04 and earlier.

Reference Tables

2. When this CPU module is used with release 4 or later of Logicmaster 90-70, reference tables will not be changed during any STORE operation unless the user specifically selects storing of reference tables.

Foreign VME Modules

3. Logicmaster 90-70 Release 4 allows foreign VME modules to be configured for four modes: BUS INTERFACE, INTERRUPT ONLY, FULL MAIL, and REDUCED MAIL. However, the Release 4 CPU module supports only the BUS INTERFACE MODULE mode. The other three modes should not be configured.

Maximum PLC Sweep

4. In systems configured for Genius Bus Redundancy a complete PLC sweep must be executed every 500 ms or less, even though it is possible to configure the watchdog timer to higher limits. This means that resetting of the watchdog timer with Service Request #8 cannot be done indefinitely.

Serial Communications

5. The following operational restrictions exist for the Serial Communications feature:
 1. Serial communications may add up to 5 ms of time to any given sweep. This should be taken into account when setting the watchdog timer.
 2. The following procedure is recommended when changing baud rates in the PLC and the WSI board. First enter the configuration package and change the baud rate on the PLC, then store the new configuration. Now power off the PLC and then go to the WSI setup screen and change the WSI baud rate. Finally, power the PLC back on.
 3. The link idle time setting in Logicmaster 90-70 Config for Serial Communications should not be set to less than 10 seconds – otherwise a communications failure will occur when storing the config to the PLC.

LM90/WSI Attach

6. Do not connect or disconnect the WSI/BTM cable while the PC/Workmaster host is powered-on. This action may cause a running PLC to Stop.

Expansion Rack ID

7. The expansion racks for the Series 90-70 PLC are shipped with the rack ID strapped for rack 0 (the main rack). If the rack jumper is not changed the PLC will not recognize the rack at all and may not properly identify the error.

GFK-0608F

Expansion Rack Cable

8. Do not connect or disconnect the expansion rack cable while the CPU is running. This will cause the PLC to go to the STOP/HALT mode.

Expansion Rack Power

9. Expansion racks should not be powered up at the same time that the main rack is powered up, or they should be powered up after the main rack has completed its power-up initialization.

Memory Usage

10. A general rule-of-thumb for memory usage is 48 bytes per I/O point plus register memory in bytes.

Timer Operation

11. Care should be taken when timers (ONDTR, TMR, and OFDTR) are used in sub-blocks that are NOT called every sweep. The timers accumulate time across calls to the sub-block unless they are reset. This means that they function like timers operating in a program with a much slower sweep than the timers in the main program block. For program blocks that are inactive for large periods of time, the timers should be programmed in such a manner as to account for this catch up feature.

Similar to this are timers that are skipped because of the use of the JUMP instruction. Timers that are skipped will NOT catch up and will therefore not accumulate time accurately.

STOP I/O SCAN

12. When a Release 1 folder is converted to Release 3, the STOP mode changes from STOP/IODISABLED to STOP/IOSCAN. To change this, zoom into the PLC CPU slot in I/O configuration and change the STOP mode.

Large Programs

13. Logic programs that were very close to the maximum size limit in Release 2 may not store to a Release 3 or 4 PLC. To work around this you must make the program smaller.

Constant Sweep

14. Constant Sweep time, when used, should be set to about 10 ms greater than the normal sweep time to avoid any oversweep conditions when monitoring or performing on-line changes with the programmer. The smallest valid constant sweep time setting is 9 milliseconds. Window completion faults will occur if the constant sweep setting is not high enough.

Interaction of Logicmaster 90-70 with Closed Programming Window

15. The Logicmaster 90-70 Sweep Control and Monitor screen cannot be used to change the PLC's Sweep Modes or timers (Constant Sweep Time, Program Window Times, etc.) while the program window is closed. Use Service Requests #1 through #4 to perform these functions.

Caution

Also, Logicmaster 90-70 cannot be used to change the PLC mode (STOP, RUN, etc.) while the programming window is closed. Use the toggle switch on the CPU module instead.

Bus Transmitter

16. Bus Transmitter Module, version IC697BEM713A, should be installed to the right of all other interrupt source modules (*Genius Bus Controllers, Series 90-70 discrete Input modules, and Programmable Coprocessor Modules*) to avoid an informational System Configuration Mismatch Fault "Board to right of Rev A BTM" from being logged into the fault table and a single scan 50 ms scan time increase from occurring. The frequency of this scan increase is 1 to 2 times per hour for single rack systems and increases with additional racks and interrupt sources. This condition exists only with the "A" version of the BTM and has been corrected in the IC697BEM713B and later versions.

Problems Resolved by this Upgrade:

1. Series 90-30 and 90-70 PLCs will now work on the SNP multidrop cable when their configurations for parity are not the same. However, version 3.03 or later of the Series 90-30 PLC is required.
2. The PLC no longer ignores the comm buffer size specified by the SNP master device. Therefore, SNP masters can use comm buffers that are smaller than 8K bytes.
3. The T3 and T3' SNP timeouts are now enabled.
4. The PLC now responds correctly to the SNP masters's inquiry message.
5. The PLC now sends a receive ACK to the SNP master when the PLC requires more than 10 seconds to respond to a request.
6. System status bit FST_EXE (%S121) will no longer appear to be overridden ON when a program block executes an excessive number of recursive calls to itself.
7. Smart modules now get logged as "Additional, Reset, or Extra" modules in the PLC fault table when power is cycled on the main rack only and the modules are not part of the configuration that was stored from Logicmaster 90-70.
8. The PLC will now power-up in STOP/NOIO if the toggle switch is in the STOP position and Logicmaster 90-70 had commanded the PLC to STOP/NOIO before power-down. This occurs even when the PLC is configured for STOP/IOSCAN.
9. The PLC no longer loses communications with an SNP master when the master sends an abort request during a load/store operation.
10. Serial Logicmaster 90-70 no longer loses communications with the PLC when a fault table is cleared.
11. Transitional contacts now work correctly when associated with references in the Q output array of the Shift Left/Right and Rotate Left/Right functions..
12. The Mixed Multiply and Divide functions will now log an "Indirect Reference Out of Range" fault when an indirect reference out of range condition occurs on a double word parameter.

GFK-0608F

13. Executing a call to a program block inside a program block that was called by an I/O interrupt will now cause a diagnostic application fault instead of crashing the PLC. The processing of the interrupt is aborted and the PLC continues to execute in RUN mode.
14. The MOD_DINT function now produces the correct result when parameter I1 = 0 and parameter I2 is >32,767.
15. The PLC will now operate correctly when the IN parameter on the Shift Register Word function is a constant.
16. PCMs in expansion racks will now power-up properly when the expansion rack is power-cycled while the main rack maintains power.
17. The PLC will no longer fail when the number of declared program blocks is four more than a multiple of eight.
18. The PID function's CV output now ramps up/down at the expected rate.
19. The execution of an I/O interrupt no longer sets the wrong %I bit when the program logic is stored to the PLC before the configuration is stored to the PLC.
20. The PLC no longer allows an OEM key to be set when passwords are disabled.

New Features and Functionality:

Genius Redundancy

1. The PLC will now support Genius Bus Controller redundancy (two GBCs in the same CPU sharing blocks) in hot-standby and dual-bus configurations. The hot-standby configuration protects against bus controller failures. The dual-bus configuration protects against bus controller and media failures. Release 4 or later of the Genius Bus Controller is required by this feature.

BackgroundChecksum

2. The PLC will continuously calculate a checksum over the user's program to ensure the integrity of the program. The user can use the Logicmaster 90-70 Configuration software or the Service Request function block to regulate the amount of the checksum that is calculated each sweep.

C Program Blocks

3. You can now program your applications with Microsoft C 6.00. Program Block calls in the main block and LD program blocks can call program blocks that have been programmed in the C language. Up to seven parameter pairs can be passed to the C block.

Performance Improvements

4. The sweep time impact of the Genius Bus Controller has been reduced. For all CPU models, the sweep time impact for GBC overhead has been reduced by 50%. The sweep impact due to Genius blocks has not changed.

The sweep time impact of most function blocks has been improved. In particular, timers and counters have been improved by 12% and the MOVE function has been improved by 22%.

User Fault Logging

5. The user can log a fault in the PLC fault table from the ladder program. The SVC_REQ function now allows the user to define a fault that will place an ASCII text message in the fault table and optionally set a bit in %SA memory.

Single-Sweep Debug

6. The PLC now has the ability to execute a single sweep of the user program. This provides the user with a tool to check out the execution of the program one sweep at a time. This sweep can be executed as a normal sweep or as a first scan sweep.

Timed Interrupts

7. The PLC will support the execution of program blocks on a timed, periodic basis. A program block declared in this manner will periodically interrupt the normal sweep to execute one sweep of the program block. This feature is very much like the existing I/O interrupt feature except that the program block execution is triggered by a free-running timer instead of the transition of an input point.

Array Move Function

8. This function allows the user to extract one or more elements from a data array and copy them to another array. It supports arrays of data elements of the following types: BYTE, INT, WORD, UINT, DWORD, and DINT.

Array Search Function

9. This set of functions allows the user to search an array for a data element that is equal, not equal, greater than, greater or equal, less than, or less than or equal to a specified value. These functions support the same data types that are supported by the Array Move function.

FOR/NEXT Function

10. This function allows the user to iteratively execute any number of ladder logic rungs within a program block. The EXIT_FOR function provides a way to prematurely terminate the iterations.

New VME Access Functions

11. The VME_CONFIG_RD and VME_CONFIG_WRT functions allow foreign VME modules to be accessed by one of five methods: word, byte, odd byte only, single word, and single byte. The access method, AM code, and VME address for the VME module are specified when the module is configured with LogiMaster 90-70. These functions are being offered in addition to the existing VME Read and Write functions.

GFK-0608F

Restrictions and Open Problems:

1. If an expansion rack powers up while the CPU in the main rack is in the RUN mode, the slot fault contacts will prematurely indicate that the modules in the expansion rack are not faulted *before* they complete their power up.
2. In a multi-rack system, false LOSS OF RACK faults may occur when the system loses power. If this fault is configured to be fatal, the system will power-up in STOP mode.
3. The SORT function cannot be used in an interrupt block and in another part of the program at the same time. If a SORT function is interrupted by an interrupt block that executes a SORT function, the SORT in the interrupt block will log a User Application fault, but not execute. The interrupted SORT in the other part of the program will produce the correct result.
4. If a program block that is activated by an I/O interrupt calls another program block, a User Application fault will occur and the PLC will go to STOP mode.
5. Since there are no tasks that run in the PLC's background window, changes made to the Background Window Timer with Logicsmaster 90-70 will have no effect.
6. When there is no logic stored in a CPU module the %Q and %M tables will be cleared when the CPU is placed in RUN mode. In this context "no logic stored" means that no program had ever been stored or that the clear function on Logicsmaster 90-70 had been used to clear logic and configuration.
7. Option modules will not be able to return the completion status for COMM_REQ functions when the PLC has a password set at level 2.
8. If the CPU's toggle switch is moved to STOP and back to RUN while a C block is sending text out the serial port, the serial port will stop working. The CPU will have to be power cycled to make SNP and C block messages work again.
9. When the Bit Sequencer sequences from one step to another, the negative transitional contact that corresponds to the original step is not set. The transition contact for the new step is set and remains set until the sequencer sequences to the next step. This operation is identical to the operation of the previous versions of the CPU firmware.
10. If multiple faults exist in a Series 90-70 remote drop and one of them is corrected, a FAULT contact that uses the remote drop's module reference will incorrectly indicate that no fault exists at the remote drop.
11. When power is cycled on an expansion rack in a system that is running a large sweep time when Logicsmaster 90-70 is not connected, Genius Bus Controllers in that rack may not be properly configured. This can be corrected by cycling power on the main and expansion racks.
12. When a Release 3 or earlier Genius Bus Controller is present in a PLC, but is not present in the configuration stored to the PLC from Logicsmaster 90-70, the Bus Controller will log on to the Genius Bus at serial bus address 0. Release 4 or later Bus Controllers will not log on to the bus at all in this situation.