


USER MANUAL



Power Factor Correction Regulator

BLR-CX 6 to 14 steps

Installation:

For installation, all valid standards and safety precautions have to be kept!


1) Check that the measurement and control voltage, supply frequency and current transformer rating comply with the ratings given on the rear of the relay.

2) Mount the relay in the switch panel by means of two fixing brackets.

3) Connect the protection earth to PE-connection on metal case.

4) Connect up in accordance with the wiring diagram.

5) Remove the link of the CT terminals.



Commissioning:

BLR-CX is preset:

After BLR-CX is powered-on, a countdown of 90 sec is running. After countdown is finished, the discharging time blockade of the capacitors is active. During these two delays, no control outputs of BLR-CX can be active. The countdown can be interrupted by pushing ◀ (esc) button, in this case also the discharging time blockade starts before the regulation starts with the preset parameters.

BLR-CX is not preset:

During the countdown is running, automatic initialization of BLR-CX can be started by pushing ▶ (↵) button. After the discharge blocking time (default 75s), the controller is detecting not used switching outputs and lock them out. For the case of a faulty connection of the polarity for voltage and current, the controller detects it and corrects it.

After automatic initialization is finished, BLR-CX starts its control function and is recognizing capacitor size during standard operation. Settings of c/k values and switching program are not necessary. When mains conditions are not suitable for automatic initialization, it will be interrupted. BLR-CX is showing then error code:

“Ai Abrt“. If multiple repeat shows no results, then the setting instructions of reference manual should be considered. (not scope of delivery).


Display “Auto“: Message “Auto“ shows, that control function is working. When „Auto“ is not displayed, then control function is stopped. Reasons for this are: manual operation is active, control function is switched-off, meas. current is less than 15mA, temperature is too high, voltage is out of range or harmonic level of voltage is too high.

Over- and undervoltage monitoring: BLR-CX is equipped with over- and undervoltage monitoring. The allowed range of voltage depends on nominal voltage. When nominal voltage is out of range, message U Alarm is shown. Then the setting of nominal voltage has to be adjusted to local ratings.

Default is ULL 400V

Activation of measuring value display: To enable the display of all possible measurement values the CT ratio has to be set. Otherwise the measurement menu of the BLR-CX only contains values which are only depending to the voltage.


Display and Operation:



INFO: capacitor database
AUTO: automatic control is running
MANUAL: manual mode
SETUP: setup menu
ALARM: blinking during alarm
NT: 2. target-pf is activ
EXPORT: export of active energy
1 – 14: control outputs

Operation of BLR-CX is done by 4 keys.

In main menu level, you can choose by pushing ▲ or ▼ the main menus. Selection by ►(←) is opening submenus. By pushing of ◀ (esc) the menu is left to next higher level.




Measuring values (by pushing ▲ and ▼ the measuring values can be selected):

voltage U_{Ph-Ph} , voltage U_{Ph-N} , current I , active power P , reactive power Q , reactive power to reach target ΔQ , apparent power S , **THD U**, **3.-15. Harmonic** of voltage, displacement power factor **cosφ**, power factor **PF** (Δ), average power factor **APF**, frequency **F**, temperature **t**, max. temperature **thi**, operating hours **OPh**

INFO capacitor database: **Attention: The state of the outputs is not shown in this menu!**

By pushing ▲ and ▼ the steps can be chosen. The chosen step is flashing in step indication. By pressing ►(←) the information for the selected step is shown. Using the up and down buttons can be browsed through the values.



It's possible to have capacitive steps as well as inductive steps. The power is always rated according to selected nominal voltage.

Possible step types: Auto, Fon (Fix on), Foff (Fix off), Defective, AL (Alarm, e.g. for fan control)

MANUAL operation: **Attention: In manual operation, automatic control is not active!**
To avoid that control stops accidentally, this function can only be entered by pushing ►(←) for 3 sec. to enter this menu.

After calling manual mode, the regulator freezes the outputs in actual position. By pushing ▲ and ▼ key, the individual steps can be chosen. The state of the outputs is changed by pushing ►(←) key. The state of the outputs is shown. In manual mode, switching time delay is not working but capacitor discharge lock time is working. When leaving manual mode, BLR-CX continues controlling without switching-off all steps before.

SETUP:

Setup/Expert menu is structured in 6 submenus (100 – 600). Only menu 100 can be reached by calling Setup with short pushing of enter. If enter is pushed for 3 sec, the Expert-menu is started. By pushing ▲ und ▼ the sub-menus or parameters are chosen. By pushing ►(←) submenus are opened or parameters are switched to edit mode. By pushing ◀ (esc) the next higher level is reached. In edit mode, the cursor is blinking. By pushing ▲ and ▼ the values can be changed, by pushing ◀ and ► the cursor can be moved.

To save the settings, ►(←) must be pushed, when cursor is on right position.

To refuse the settings, ◀ (esc) can be pushed, when cursor is on left position.

Menu structure:

The table gives an overview about parameters of BLR-CX. Settings in menus 200 to 600 should be done only by using the reference manual.

Menu 100:

Un nominal voltage (is necessary for over- and undervoltage monitoring and is reference for capacitor database)

Ct CT-ratio (when CT-ratio is not set, only values which are only depending on voltage are shown)

Pt VT-ratio

Ai start of automatic initialization (this function is running only, when "Auto" is shown in LCD)

PFC PF-control ON/OFF (all "Auto" steps are off) / HOLD (steps are frozen)

CP1 target-PF 1 After the value for target cos phi is entered, it can be choose between target cos phi inductive (l is flashing – default) or capacitive (c is flashing – exception)


St switching time delay

Out Type of exit: step 1... max. 14

MENU	FUNCTION	DEFAULT
100	QUICK START SETUP	
Un	Nominal voltage (phase-phase)	400V
Ct	CT-ratio	1
Pt	VT-ratio	1
Ai	Start automatic initializing	
PFC	Start/Stop/Hold PF-control	On
CP1	Target-PF 1	1,00
St	Switching time delay	10s
Out	Type of exit: step 1...max. 14	Auto
200	SETUP MEASURING SYSTEM	
201	Nominal voltage (phase-phase)	400V
202	CT-ratio	1
203	VT-ratio	1
204	Tolerance nominal voltage	10%
205	Voltage measuring Ph-N	N
206	Phase-offset	0
207	Start automatic initializing	
208	Activate Ai by every start of BLR-CX-V	Y
209	Synchronisation to frequency	Auto
210	Temperature offset	0°C
300	SETUP CONTROL SYSTEM	
301	Switching threshold	60%
302	Target-PF 1	1,00
303	Target-PF 2	0,95
304	Target-PF 2 at KW-export	N
305	Switching time delay	10s
306	Switching time delay for fine control	2s
307	Fine control active	N
308	Stop automatic capacitor size detection	N
309	Blocking of defective capacitors	Y
310	Start/Stop/Hold PF-control	On
311	Control algorithm	1
312	Reactive-power offset	0
313	Asymmetrical switching time delay	1
314	Switch-off capacitors in leading condition	N
















MENU	FUNCTION	DEFAULT
400	SETUP CAPACITOR DATABASE	
401	Discharging time	75s
402	Capacitor size: step 1...max. 14	5var
403	Type of exit: step 1...max. 14	Auto
404	Switching operations: step 1...max. 14	0
500	SETUP ALARM SYSTEM	
501	Alarm storage	N
502	THD alarm	N
503	Threshold THD	20%
504	Disconnect capacitors when THD >	N
505	Delay time THD Alarm / Temp. threshold 2	60sec
506	Freeze exits when I = 0	N
507	Service alarm	N
508	Max. operations per step	262k
509	Max. operation hours of BLR-CX-V	65,5k
510	Use temp. sensor as digital input	n
511	digital input active at high signal	n
512	Temperature alarm active	n
513	Temp. threshold level 1 (fan control, type of exit: AL)	30°C
514	Temp. threshold level 2, disconnect capacitors	55°C
515	Control alarm (target cannot be reached)	N
516	Defective steps alarm	N
517	Loss of power alarm	N
600	RESET	
601	Reset to default values	
602	Reset capacitor database to default	
603	Reset operation hours	
604	Reset average PF	
605	Reset max. temperature	
606	Reset alarm	
607	1.04	

Technical Data

Measuring- and supply voltage:	90 – 550V AC, single phase, 45-65HZ, 5VA, max. fuse 6A VT-ratio from 1,0 – 350,0
Current measuring:	15mA – 6A, single phase, burden 20mOhm, ct-ratio from 1-9600
Control Outputs:	Up to 14 relays, n/o, with common point, max. fuse 6A breaking capacity: 250V AC / 5A
Temperature measuring:	By NTC
Alarm contact:	Relay, volt free, life contact, max. fuse 6A, breaking capacity: 250V AC / 5A
Fan control:	By using one switching exit defined as "Alarm"
Interface:	TTL, rear
Ambient temperature:	Operation: -20°C – 70°C, storage: -40°C – 85°C
Humidity:	0% - 95%, without moisture condensation
Voltage class:	II, dirt class 3 (DIN VDE 0110, part 1 / IEC60664-1)
Standards:	DIN VDE 0110 part 1 (IEC 60664-1:1992) VDE 0411 part 1 (DIN EN 61010-1 / IEC 61010-1:2001) VDE 0843 part 20 (DIN EN 61326 / IEC 61326: 1997 + A1:1998 +A2: 2000)
Conformity and listing:	
Connection	Pluggable terminal block, screw type max. 4qmm
Case:	Front: instrument case PC/ABS (UL94-VO), Rear: metal
Protection class:	Front: IP50, (IP54 by using a gasket), Rear: IP20
Weight:	ca. 0,6kg
Dimension:	144x144x58mm h x w x d, cut out 138 (+0,5) x 138 (+0,5)mm

Alarms:

BLR-CX has an extended alarm system. All possible settings are shown in menu structure. When an alarm is active, the sign ALARM in the display is blinking. An error code is shown in LCD. Possible error codes are:

 ALARM	Measuring voltage is out of tolerance
 ALARM	Measuring current is less 15mA (please check current path)
 ALARM	Measuring current is too high.
 ALARM	Target cannot be reached
 ALARM	THD U alarm (harmonic alarm)
 ALARM /  ALARM	One or more steps are defective. The defective steps are blinking together with the ALARM sign.
 ALARM /  ALARM	One or more steps have less than 50% of original size. Number of step and alarm text are blinking alternately.
 ALARM	Over temperature alarm. The steps will be switched-off step by step.
 ALARM	Max. allowed operating hours are reached.
 ALARM /  ALARM	Max. allowed number of switch cycles of one or more steps is reached.
 / 	Abort of automatic initialization due to not suitable load conditions

Customer settings

Menu	Factory setting	Customer setting	Menu	Factory setting	Customer setting
100			400		
Un	400 V		401	75 s	
Ct	1		402	5 var (1-max.)	
Pt	1		403	AUTO (1-max.)	
Ai	NO		404	0 (1-max.)	
PFC	ON		500		
CP1	1		501	NO	
St	10 s		502	NO	
200			503	20 %	
201	400 V		504	NO	
202	1		505	60 s	
203	1		506	NO	
204	10%		507	NO	
205	NO		508	262.1 k	
206	0		509	65.5 k h	
207	NO		510	NO	
208	YES		511	NO	
209	AUTO		512	NO	
210	0 °C		513	30 °C	
300			514	55 °C	
301	60%		515	NO	
302	1		516	NO	
303	0,95 i		517	NO	
304	NO		600		
305	10 s		601	NO	
306	2 s		602	NO	
307	NO		603	NO	
308	NO		604	NO	
309	YES		605	NO	
310	ON		606	NO	
311	1		607	1.xx	
312	0				
313	1				
314	NO				

THE COMPANY


HEADQUARTERS

SCHRACK TECHNIK GMBH
Seybelgasse 13, 1230 Wien
TEL +43(0)1/866 85-0
FAX +43(0)1/866 85-1560
E-MAIL info@schrack.com




AUSTRIAN QUARTERS

CARINTHIA
Ledererstraße 3
9020 Klagenfurt
TEL +43(0)463/333 40-0
FAX +43(0)463/333 40-15
E-MAIL klagenfurt@schrack.com



UPPER AUSTRIA
Franzosenhausweg 51b
4030 Linz
TEL +43(0)732/376 699-0
FAX +43(0)732/376 699-20
E-MAIL linz@schrack.com




SALZBURG
Bachstraße 59-61
5023 Salzburg
TEL +43(0)662/650 640-0
FAX +43(0)662/650 640-26
E-MAIL salzburg@schrack.com



SCHRACK COMPANIES

BELGIUM
SCHRACK TECHNIK B.V.B.A
Twaalfapostelenstraat 14
BE-9051 St-Denijs-Westrem
TEL +32 9/384 79 92
FAX +32 9/384 87 69
E-MAIL info@schrack.be



CROATIA
SCHRACK TECHNIK D.O.O.
Zavrtnica 17
HR-10000 Zagreb
TEL +385 1/605 55 00
FAX +385 1/605 55 66
E-MAIL schrack@schrack.hr



POLAND
SCHRACK TECHNIK
POLSKA SP.Z.O.O.
ul. Annopol 3
PL-03-236 Warszawa
TEL +48 22/331 48 31
FAX +48 22/331 48 33
E-MAIL se@schrack.pll



STYRIA, BURGENLAND
Kärntnerstraße 341
8054 Graz
TEL +43(0)316/283 434-0
FAX +43(0)316/283 434-64
E-MAIL graz@schrack.com

TYROL
Richard Bergerstraße 12
6020 Innsbruck
TEL +43(0)512/392 580-0
FAX +43(0)512/392 580-30
E-MAIL innsbruck@schrack.com

VORARLBERG
Wallenmahd 23
6850 Dornbirn
TEL +43(0)5572/238 33-0
FAX +43(0)5572/238 33-14
E-MAIL dornbirn@schrack.com

ROMANIA
SCHRACK TECHNIK SRL
Str. Simion Barnutiu nr. 15
RO-3700 Oradea
TEL +40 259/435 887
FAX +40 259/412 892
E-MAIL schrack@schrack.ro

SERBIA
SCHRACK TECHNIK D.O.O.
Kumodraska 260
YU-11000 Beograd
TEL +38 1/11 309 2600
FAX +38 1/11 309 2620
E-MAIL office@schrack.co.yu

SLOVAC REPUBLIC
SCHRACK TECHNIK SPOL. SR.O.
Langsfeldova 2
SK-03601 Martin
TEL +42 1/43 422 16 41
FAX +42 1/43 423 95 56
E-MAIL martin@schrack.sk

**VIENNA, LOWER AUSTRIA,
BURGENLAND**
Seybelgasse 13
1230 Wien
TEL +43(0)1/866 85-500
FAX +43(0)1/866 85-441
E-MAIL wien@schrack.com

NETZWERKTECHNIK
Seybelgasse 13, 1230 Wien
TEL +43(0)1/866 85-180
FAX +43(0)1/866 85-136
E-MAIL netzwerktechnik@schrack.com

LICHTTECHNIK
Seybelgasse 13, 1230 Wien
TEL +43(0)1/866 85-543
FAX +43(0)1/866 85-561
E-MAIL lichttechnik@schrack.com

SLOVENIA
SCHRACK TECHNIK D.O.O.
Glavni trg 47
SLO-2380 Slovenj Gradec
TEL +38 6/2 883 92 00
FAX +38 6/2 884 34 71
E-MAIL schrack.sg@schrack.si

CZECH REPUBLIC
SCHRACK TECHNIK SPOL. SR.O.
Dolnhomecholupska 2
CZ-10200 Praha 10 – Hostivar
TEL +42(0)2/810 08 264
FAX +42(0)2/810 08 462
E-MAIL praha@schrack.cz

HUNGARY
SCHRACK TECHNIK KFT.
Vidor u.
H-1172 Budapest
TEL +36 1/253 14 01
FAX +36 1/253 14 91
E-MAIL schrack@schrack.hu