



EX1200-7600

5 W PROGRAMMABLE RESISTOR LADDER

USER'S MANUAL

**P/N: 82-0127-006
Released September 8, 2010**

VTI Instruments Corp.

**2031 Main Street
Irvine, CA 92614-6509
(949) 955-1894**

TABLE OF CONTENTS

TABLE OF CONTENTS.....	2
Certification	4
Warranty	4
Limitation of Warranty	4
Trademarks	4
Restricted Rights Legend.....	4
GENERAL SAFETY INSTRUCTIONS	5
Terms and Symbols	5
Warnings.....	5
SUPPORT RESOURCES	7
SECTION 1	9
INTRODUCTION	9
Overview.....	9
Features.....	9
Fault Sensing	9
EX1200-7600 Specifications	11
Explanation of Specifications	12
Switching Time	12
Setting Accuracy	12
SECTION 2	13
USING THE INSTRUMENT.....	13
Unpacking.....	13
Determine System Power Requirements	13
Plug-in Module Installation	13
Maximizing Measurement Performance	14
Warm Up Time.....	14
Connector Pin/Signal Assignment	15
BPL_INSFAIL Behavior	17
SECTION 3	19
PROGRAMMING THE INSTRUMENT	19
Introduction	19
Related Software Components.....	19
Using the Driver	19
USING THE EX1200-7600.....	20
Initializing\Closing the Instrument.....	20
Option Strings.....	20
Basic Operation	21
Driver Interfaces	24
APPLICATION EXAMPLE	25
SECTION 4	27
SFP OPERATION	27
Introduction	27
General Web Page Operation	28
VTI Instruments Logo	29
EX1200-7600 Soft Front Panel	29

Monitor and Control Tab	30
Failure Indicator LEDs	30
Resistance Field	30
Output Source	30
Backplane Line Source	31
Device Information Tab	31
SECTION 5	33
THEORY OF OPERATION	33
Introduction	33
INDEX	35

CERTIFICATION

VTI Instruments Corp. (VTI) certifies that this product met its published specifications at the time of shipment from the factory. VTI further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (formerly National Bureau of Standards), to the extent allowed by that organization's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

The product referred to herein is warranted against defects in material and workmanship for a period of one year from the receipt date of the product at customer's facility. The sole and exclusive remedy for breach of any warranty concerning these goods shall be repair or replacement of defective parts, or a refund of the purchase price, to be determined at the option of VTI.

For warranty service or repair, this product must be returned to a VTI Instruments authorized service center. The product shall be shipped prepaid to VTI and VTI shall prepay all returns of the product to the buyer. However, the buyer shall pay all shipping charges, duties, and taxes for products returned to VTI from another country.

VTI warrants that its software and firmware designated by VTI for use with a product will execute its programming when properly installed on that product. VTI does not however warrant that the operation of the product, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The warranty shall not apply to defects resulting from improper or inadequate maintenance by the buyer, buyer-supplied products or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

VTI Instruments Corp. shall not be liable for injury to property other than the goods themselves. Other than the limited warranty stated above, VTI Instruments Corp. makes no other warranties, express or implied, with respect to the quality of product beyond the description of the goods on the face of the contract. VTI specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

TRADEMARKS

Java Runtime Environment™ are trademarks or registered trademarks of Sun Microsystems, Inc. or its subsidiaries in the United States and other countries. LabVIEW™ and LabWindows/CVI™ are trademarks of National Instruments Corporation. Visual Basic®, Windows®, and Internet Explorer® are registered trademarks of the Microsoft Corporation or its subsidiaries. Linux® is a registered trademark of the Linux Foundation. IVI™ is a trademark of the IVI Foundation. Bonjour™ is a trademark of Apple, Inc.

RESTRICTED RIGHTS LEGEND

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subdivision (b)(3)(ii) of the Rights in Technical Data and Computer Software clause in DFARS 252.227-7013.

VTI Instruments Corp.
2031 Main Street
Irvine, CA 92614-6509 U.S.A.

GENERAL SAFETY INSTRUCTIONS

Review the following safety precautions to avoid bodily injury and/or damage to the product. These precautions must be observed during all phases of operation or service of this product. Failure to comply with these precautions, or with specific warnings elsewhere in this manual, violates safety standards of design, manufacture, and intended use of the product. Note that this product contains no user serviceable parts or spare parts.

Service should only be performed by qualified personnel. Disconnect all power before servicing.

TERMS AND SYMBOLS


These terms may appear in this manual:

- WARNING** Indicates that a procedure or condition may cause bodily injury or death.
- CAUTION** Indicates that a procedure or condition could possibly cause damage to equipment or loss of data.

These symbols may appear on the product:



ATTENTION - Important safety instructions



Frame or chassis ground



Indicates that the product was manufactured after August 13, 2005. This mark is placed in accordance with *EN 50419, Marking of electrical and electronic equipment in accordance with Article 11(2) of Directive 2002/96/EC (WEEE)*. End-of-life product can be returned to VTI by obtaining an RMA number. Fees for take-back and recycling will apply if not prohibited by national law.

WARNINGS

Follow these precautions to avoid injury or damage to the product:

- Use Proper Power Cord** To avoid hazard, only use the power cord specified for this product.
- Use Proper Power Source** To avoid electrical overload, electric shock, or fire hazard, do not use a power source that applies other than the specified voltage.

The mains outlet that is used to power the equipment must be within 3 meters of the device and shall be easily accessible.

WARNINGS (CONT.)

Avoid Electric Shock

To avoid electric shock or fire hazard, do not operate this product with the covers removed. Do not connect or disconnect any cable, probes, test leads, etc. while they are connected to a voltage source. Remove all power and unplug unit before performing any service. ***Service should only be performed by qualified personnel.***

Ground the Product

This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground.

Operating Conditions

To avoid injury, electric shock or fire hazard:

- Do not operate in wet or damp conditions.
- Do not operate in an explosive atmosphere.
- Operate or store only in specified temperature range.
- Provide proper clearance for product ventilation to prevent overheating.
- DO NOT operate if any damage to this product is suspected. ***Product should be inspected or serviced only by qualified personnel.***

Improper Use



The operator of this instrument is advised that if the equipment is used in a manner not specified in this manual, the protection provided by the equipment may be impaired. Conformity is checked by inspection.

SUPPORT RESOURCES

Support resources for this product are available on the Internet and at VTI Instruments customer support centers.

**VTI Instruments Corp.
World Headquarters**

VTI Instruments Corp.
2031 Main Street
Irvine, CA 92614-6509

Phone: (949) 955-1894
Fax: (949) 955-3041

**VTI Instruments
Cleveland Instrument Division**

5425 Warner Road
Suite 13
Valley View, OH 44125

Phone: (216) 447-8950
Fax: (216) 447-8951

**VTI Instruments
Lake Stevens Instrument Division**

3216 Wetmore Avenue, Suite 1
Everett, WA 98201

Phone: (949) 955-1894
Fax: (949) 955-3041

**VTI Instruments, Pvt. Ltd.
Bangalore Instrument Division**

642, 80 Feet Road
Koramangala IV Block
Bangalore – 560 034
India

Phone: +91 80 4040 7900
Phone: +91 80 4162 0200
Fax: +91 80 4170 0200

Technical Support

Phone: (949) 955-1894
Fax: (949) 955-3041
E-mail: support@vtiinstruments.com



Visit <http://www.vtiinstruments.com> for worldwide support sites and service plan information.

SECTION 1

INTRODUCTION

OVERVIEW

The EX1200-7600 is a single channel, programmable resistor ladder. It is designed for applications such as RTD or other resistance-based sensor simulation, process control, ATE calibration, and controlled loading of device under test (DUT). It contains internal, high-precision 5 W power resistors that are switched via electromechanical relays. The EX1200-7600 is capable of producing any resistance value between 0.5 Ω to 1,500,000 Ω and can be adjusted in 0.1 Ω increments via program commands. It is designed for terminal voltages from 0 V to 200 V dc and for currents up to 0.5 A.

The EX1200-7600 is part of the EX1200 family of products and can be mixed and matched with other EX1200 series modules to configure high-density measurement and switching systems.

FEATURES

Fault Sensing

After power up, reset, or a fault condition, the input will be internally disconnected and the resistance will be set to its maximum value. This open circuit configures the EX1200-7600 to its highest resistance, removing the load from the device under test. A fault condition is the result of exceeding the maximum current, maximum voltage or maximum temperature for the module. Additionally, the module will respond to the chassis BPL_INSFAIL circuit, which can be used to open all relays on all cards in a chassis simultaneously. A voltage sense out signal provides a scaled indication of the voltage across the resistance, and a current sense out signal provides a scaled indication of the current through the circuit, both of which can be monitored by an external measurement device (such as an EX1200 series DMM). This can be used to force all relays open if a set voltage or current is exceeded thereby protecting the unit under test.




FIGURE 1-1: LOGICAL BLOCK DIAGRAM

EX1200-7600 SPECIFICATIONS

GENERAL SPECIFICATIONS	
MODEL TYPE	Programmable resistor load
CHANNELS	1
SWITCHING TIME	< 5 ms
RATED SWITCH OPERATIONS	
Mechanical	5 x 10 ⁶
Electrical	1 x 10 ⁵ (full-load)
OVER-TEMPERATURE PROTECTION	
PCB surface temperature	102 °C (215.6 °F)
POWER SPECIFICATIONS	
MAXIMUM SWITCHING VOLTAGE	200 V ac rms
MAXIMUM SWITCHING CURRENT	0.5 A
MAXIMUM SWITCHING/CARRY POWER	5 W
POWER CONSUMPTION	
3.3 V	0.129 A
5 V	0.0041 A (add 24 mA for each relay closure)
24 V	0.2 A (maximum value)
RESISTOR PERFORMANCE	
VOLTAGE OUTPUT RANGE/GAIN	40:1 ±1% full-scale
CURRENT OUTPUT RANGE/GAIN	100:1 ±1% full-scale
SETTINGS ACCURACY	
0.5 – 60.0 Ω	±0.15 Ω
60.1 – 1,499,999 Ω	±0.25 % of programmed value
1,499,999.1 Ω - 2,097,152.6 Ω	Not specified
MINIMUM INCREMENT (RESOLUTION)	0.1 Ω
CONNECTOR INFORMATION	
MATING CONNECTOR	
VTI Part Number	27-0076-015
Manufacturer/Part Number	Positronic HDC15F20000
CONNECTOR BACKSHELL	
VTI Part Number	27-0086-015
Manufacturer/Part Number	Amp 5-747099-1

EXPLANATION OF SPECIFICATIONS

This section provides explanatory notes to certain elements of the EX1200-7600 specification that may be misunderstood.

Switching Time

This specification defines the amount of time needed for the resistance value to settle to the commanded value. The resistance value may increase or decrease during this time. If the connected, external equipment is sensitive to these this variance in resistance, it may be necessary to take any needed precautions, such as connecting an external capacitor to reduce the effect of the step changes.

Setting Accuracy

The accuracy of the EX1200-7600 is dependent on the amount of resistance that is programmed. The specification indicates the accuracy for each of three ranges of resistance. Note that, although the EX1200-7600 can be set to values above 1,499,999 Ω , the accuracy for these loads is not specified.

SECTION 2

USING THE INSTRUMENT

UNPACKING

When an EX1200-7600 is unpacked from its shipping carton, the contents should include the following items:

- An EX1200-7600
- *LXI Quick Start Guide*
- *EX1200-7600 User's Manual* (this manual)
- *EX1200-7600 IVI, Linux, or LabView Driver* (included on Distribution CD)

All components should be immediately inspected for damage upon receipt of the unit. ESD precautions should be observed while unpacking and installing the instrument into an EX1200 series mainframe.

DETERMINE SYSTEM POWER REQUIREMENTS

The power requirements of the EX1200 mainframes are provided in the *Specifications* section of *Section 1*. It is imperative that the mainframe provide adequate power for the modules installed. For more information on EX1200 mainframe power consumption, please refer to *the EX1200 Series User's Manual* (P/N: 82-0127-000) for more information. The user should confirm that the power budget for the system (for the chassis and all modules installed therein) is not exceeded on any voltage line.



It should be noted that if the mainframe cannot provide adequate power to the module, the instrument might not perform to specification and possibly damage the power supply. In addition, if adequate cooling is not provided, the reliability of the instrument will be jeopardized and permanent damage may occur. Damage found to have occurred due to inadequate cooling will void the warranty on the instrument in question.

NOTE

For more information on power requirement calculations, refer to and review *Appendix B* in the *EX1200 Series User's Manual* to ensure that the current limits of the power supply are not exceeded.

PLUG-IN MODULE INSTALLATION

Before installing a plug-in module into an EX1200 system, make sure that the mainframe is powered down. Insert the module into the base unit by orienting the module so that the metal cover of the module can be inserted into the slot of the base unit. Position the cover so that it fits into the module's slot groove. Once the module is properly aligned, push the module back and firmly insert it into the backplane connector. See Figure 2-1 for guidance.




FIGURE 2-1: MODULE INSTALLATION (EX1200-3048 USED AS EXAMPLE)

MAXIMIZING MEASUREMENT PERFORMANCE

This section discusses tips and procedures that can help maximize the actual performance realized with the EX1200-7600 and aid the user in avoiding some common pitfalls associated with making measurements.

Warm Up Time

The specified warm-up time for an EX1200 system is 30 minutes. If, however, the unit is being subjected to an ambient temperature change greater than 5 °C, extra stabilization time is recommended to achieve maximum performance.

CONNECTOR PIN/SIGNAL ASSIGNMENT

The connector pins and their signal assignments are shown in Table 2-1 and Figure 2-1 below. For mating connector and accessory information, please see the *EX1200-7600 Specifications*.




FIGURE 2-2: EX1200-7600 FRONT PANEL DETAIL

Pin	Signal
1	RES1A
2	RES1A
3	UNUSED
4	GND_C
5	UNUSED
6	FP_OPEN
7	V_SENSE_OUT
8	I_SENSE_OUT
9	AGND
10	AGND
11	UNUSED
12	UNUSED
13	FP_GND
14	SENSE_RET
15	SENSE_RET

TABLE 2-1: EX1200-7600 CONNECTOR PIN SIGNAL ASSIGNMENT

The purpose of each signal is defined in Table 2-2.

Signal	Description
RES1A	Input at the resistor terminals.
GND_C	The chassis ground. This pin is usually connected to cable shield.
AGND	The analog ground. This pin can be used when the user's signal has its own ground separate from chassis ground mentioned above.
FP_OPEN	A Low signal at this pin opens up all the relays and the resistance path is open. when FP-OPEN is restored high, it return back to the previous set relay driver status.
FP_GND	Ground pin for the FP_OPEN signal.
V_SENSE_OUT	The voltage sense line. This pin provides access to the scaled-down input voltage of RES1A. The resistance is scaled down 40:1 \pm 1% of the full-scale setting.
I_SENSE_OUT	The current sense line. This pin provides access to the scaled-down input current of RES1A. The resistance is scaled down 100:1 \pm 1% of the full-scale setting.
SENSE_RET	The return path for voltage/current sense lines.

TABLE 2-2: SIGNAL PIN DEFINITIONS




FIGURE 2-3: INTERNAL CONNECTIVITY OF THE FRONT PANEL PINS

Note that there are two RES1A and AGND terminals. These connections are provided to facilitate the use of 4-wire resistance simulations. For example, to simulate a 4-wire RTD, these terminals act as the excitation and sense terminals. Electrically, both RES1A and AGND terminals are parallel, and, therefore, interchangeable. While using a 2-wire resistor, these terminals can be shorted externally to provide lower contact resistance.

BPL_INSFAIL BEHAVIOR

The EX1200 platform backplane has a BPL_INSFAIL line that indicates to all modules that a severe failure has occurred. When this line is asserted, all of the relays on the EX1200-7600 will be opened, leaving the circuit open.

SECTION 3

PROGRAMMING THE INSTRUMENT

INTRODUCTION

This section provides programming examples for the EX1200-7600. Additional information can be found in the driver help file. If the instrument will be used on a Linux system, a .chm viewer must be installed on the host PC (examples of these programs can be found at the following URL: <http://www.linux.com/news/software/applications/8209-chm-viewers-for-linux>.)

NOTE	Programming examples are installed with the IVI Driver – VarRes, typically located in the “<HDD Designation>\Program Files\IVI Foundation\IVI\Drivers\VTEXVarRes\Examples“ folder.
-------------	--

RELATED SOFTWARE COMPONENTS

IVI-COM Driver
 IVI-C Driver
 LabView Driver
 Linux C++ Driver

USING THE DRIVER

The EX1200-7600 may be used in a variety of environments including: Visual Basic, C#, C++, LabView. VTI instruments provides a IVI-C and IVI-COM compliant driver as well as a shared object that can be used on Linux systems that comply with the Linux Standard Base (Version 3.1).

Here is how to use the driver in each environment:

- 1) **Visual Studio C++**

```
#import "IviDriverTypeLib.dll" no_namespace
#import "VTEXVarRes.dll" no_namespace
```
- 2) **C#**
 Add a reference to VTEXVarRes.dll in the project. Include the following at the top of any code file that will access the driver:


```
using VTI.VTEXVarRes.Interop;
```
- 3) **C/C++ on Windows**
 Link against VTEXVarRes.lib and include VTEXVarRes.h in the file.
- 4) **C++ on Linux**
 Link against /opt/vti/lib/libvarres.so and include all the headers in /opt/vti/include in the source file.
- 5) **LabView**
 Copy the driver package to the <Labview>/instr.lib directory and access all relevant VIs

USING THE EX1200-7600

INITIALIZING\CLOSING THE INSTRUMENT

The base interface of the EX1200-7600 IVI driver, VTEXVarRes (LibVarRes on Linux), is used to open and close connections to the instrument as well as containing pointers to all other interfaces to access the functionality of the instrument.

Initialization

Prior to using the EX1200-7600, an instrument driver connection must be made to the EX1200-7600. Once a connection is made using the Initialize call, the user can execute their test code. Before the program exits, the user should release the resources using the Close call. Users familiar with other VTI Instrument Drivers for the EX1200 series should find this driver is very similar to ones they have used before.

C++

```
#import "IviDriverTypeLib.dll" no_namespace
#import "VTEXVarRes.dll" no_namespace

int main() {
    ::CoInitialize(NULL); // start COM layer
    // try/catch so driver not found situations are properly handled
    try {
        IVTEXVarResPtr varres(__uuidof(VTEXVarRes));
        try { // second error layer for failed initialize
            /* using an empty options string here; see Option Strings below
            for more information;also using Reset bit to get a clean init */
            varres->Initialize("TCPIP::10.1.4.55::INSTR", VARIANT_TRUE,
                VARIANT_TRUE, "");

            // test code goes here

            varres->Close();
        } catch (_com_error &e) {
            ::MessageBox(NULL, e.Description(), e.ErrorMessage(),
                MB_ICONERROR);
        }
    } catch (...) {
        // handle errors here, depending on needs
    }
}
```

Option Strings

The VTEX drivers provide option strings that can be used when Initializing an instrument. The option string values exist to change the behavior of the driver. The following options strings are available on VTI IVI drivers:

- **Simulate:** Allows the user to run a program without commanding switch card or instruments. This option is useful as a debugging tool.
- **Cache:** Per the IVI specification, this option “specifies whether or not to cache the value of attributes.” Caching allows IVI drivers to maintain certain instrument settings to avoid sending redundant commands. The standard allows for certain values to be cached always or never. In VTI IVI-drivers, all values used are of one of these types. As such, any values entered have no effect.
- **QueryInstrumentStatus:** Queries the instrument for errors after each call is made. As implemented in the VTI IVI drivers, instruments status is always queried regardless of the value of this property.

- **DriverSetup:** Must be last, and contains the following properties:
 - **LogFile:** Allows the user to specify a file to which the driver can log calls and other data.
 - **Logmode:** Specifies the mode in which the log file is opened. The allowed modes are:
 - **w:** truncates the file to zero length or creates a text file for writing.
 - **a:** opens the file for adding information to the end of the file. The file is created if it does not exist. The stream is positioned at the end of the file.
 - **LogLevel:** Allows the user to determine the severity of a log message by providing a level-indicator to the log entry.
 - **Slots:** This is the most commonly used option and it allows for a slot number or a slot number and a card model to be specified.
 - "Slots=(2)" - Just slot 2.
 - "Slots=(2=EX1200_3048)" - slot and card model
 - "Slots=(2,3)" - Multiple slots
- **InterchangeCheck:** Boolean option that enables/disables IVI Interchangeability checking. As implemented in the VTI IVI drivers, values entered for this property have no effect.
- **RangeCheck:** Boolean option that enables or disables driver validation of user-submitted values. As implemented in the VTI IVI drivers, validation of user inputs is always performed at the firmware level regardless of this property's value.
- **RecordCoercions:** Boolean option that enables driver recording of coercions. As implemented in the VTI IVI drivers, coercions are handled in the firmware and cannot be recorded.

BASIC OPERATION

The EX1200-7600 has single channel that is capable of producing resistance values between 0.5 Ω to 1,499,999 Ω in 0.1 Ω increments with specified accuracy. All relays will be opened unless the Enabled property of channel is set to true.

Resistance

This example covers the main functionality of the device: setting a resistance to be used as a load. Note that, although resistance is set on a per-channel basis, the EX1200-7600 has only one channel: "CH1". Also note that the resistance should be set first, then enabled. This prevents enabling the channel with the default resistance enabled, which is the maximum value.

C++

```
#using <microsoft.dll>
#import "IviDriverTypeLib.dll" no_namespace
#import "VTEXVarRes.dll" no_namespace

int main() {
    ::CoInitialize(NULL); // start COM layer
    // try/catch so driver not found situations are properly handled
    try {
        IVTEXVarResPtr varres(__uuidof(VTEXVarRes));
        try { // second error layer for failed initialize
            /* using an empty options string here; check the manual for
            available options strings;
            also using Reset bit to get a clean init */
            varres->Initialize("TCPIP::10.1.4.55::INSTR", VARIANT_TRUE,
                VARIANT_TRUE, "");

            // only channel on this device is "CH1"
            IVTEXVarResChannelPtr chl = varres->Channels->Item["CH1"];

            // setting an output coerces it to the nearest possible
            value
            chl->Output = 3.0;
            chl->Enabled = VARIANT_TRUE;
        }
    }
}
```

```

        // retrieving it will return its actual setting
        double actual_output;
        actual_output = ch1->Output;

        varres->Close();
    } catch (_com_error &e) {
        ::MessageBox(NULL, e.Description(), e.ErrorMessage(),
            MB_ICONERROR);
    }
} catch (...) {
    // handle errors here, depending on needs
}
}

```

Configuring Channels and Backplane Trigger

This example shows how to set the switch mode, resistance, and configure the backplane trigger. This stimulates a 1 k Ω resistance in BBM switching mode and raises a backplane0 line if any fault conditions (voltage/current/temperature) occur.

C++

```

// The relay switch mode to BBM.
VarRes->Channels->Item["CH1"]->SwitchMode = VTEXVarResSwitchModeBreakBeforeMake;

// The resistance value to 1k Ohm.
VarRes->Channels->Item["CH1"]->Output = 1000.0;

// Enable relays of a channel.
VarRes->Channels->Item["CH1"]->Enabled = true;

// Check the over-current state
if(VarRes->Channels->Item["CH1"]->OverCurrent)
{
    //The channel is in an over-current state, so action should be taken here.
}

// Configure to assert a backplane trigger line, BPL0 in any error condition.
VarRes->Trigger->BackplaneOutput = VTEXVarResBackplaneTriggerBPL0;
VarRes->Trigger->OutputSource = VTEXVarResOutputSourceAny;

```

Fail-safe

The EX1200-7600 has several fail-safe modes: Backplane, using BPL_INSFAIL; OverVoltage, using the onboard voltage sensor; OverCurrent, using the onboard current sensor; and OverTemperature, using a collection of six thermistors mounted on the board. Each of these can be checked individually or can be programmatically routed to a backplane line to signal other devices when a fail-safe condition occurs.

Once a fail-safe condition has occurred, it is latched. Fail-safe conditions can only be cleared by calling the EX1200-7600's Reset function. Note that, for backplane and temperature fail-safe conditions to be cleared when Reset is called, the user must also remove the stimulus. If the stimulus is still present, the condition is immediately re-asserted. For voltage and current fail-safe conditions, the condition will not recur until the Enabled state of the channel is set to True.

C++

```

#include <mcorlib.dll>
#import "IviDriverTypeLib.dll" no_namespace
#import "VTEXVarRes.dll" no_namespace

int main() {
    ::CoInitialize(NULL); // start COM layer
}

```

```

// try/catch so driver not found situations are properly handled
try {
    IVTEXVarResPtr varres(__uuidof(VTEXVarRes));
    try { // second error layer for failed initialize
        /* using an empty options string here; check the manual for
        available options strings;
        also using Reset bit to get a clean init */
        varres->Initialize("TCPIP::10.1.4.55::INSTR", VARIANT_TRUE,
        VARIANT_TRUE, "");

        /* BackplaneFailsafe will be true if the failsafe trigger has
        occurred since the last reset;
        this trigger prevents damage to the card by locking open all
        relays under well-defined conditions
        like extreme temperatures or excess voltage. */
        bool bpl_fail = varres->BackplaneFailsafe == VARIANT_TRUE;
        if (bpl_fail) {
            /* OverTemperature is a bitmask; each bit represents a temp
            sensor on the board,
            and is 1 if that sensor has gone over temperature since the
            last reset, 0 otherwise */
            int overtemp = varres->OverTemperature;

            varres->Utility->Reset();

            /* It is possible for BackplaneFailsafe to remain true
            through a reset, if the condition that caused a failsafe
            continues to exist. It will not reset to a usable state
            until it can do so safely. */
        }

        varres->Close();
    } catch (_com_error &e) {
        ::MessageBox(NULL, e.Description(), e.ErrorMessage(),
        MB_ICONERROR);
    }
} catch (...) {
    // handle errors here, depending on needs
}
}

```

Odometers

The EX1200-7600 also offers a set of relay odometers that allows users to track relay wear. This is made available programmatically via the driver.

C++

```

#include <microsoftlib.dll>
#include "IviDriverTypeLib.dll" no_namespace
#include "VTEXVarRes.dll" no_namespace

int main() {
    ::CoInitialize(NULL); // start COM layer
    // try/catch so driver not found situations are properly handled
    try {
        IVTEXVarResPtr varres(__uuidof(VTEXVarRes));
        try { // second error layer for failed initialize
            /* using an empty options string here; check the manual for
            available options strings;
            also using Reset bit to get a clean init */
            varres->Initialize("TCPIP::10.1.4.55::INSTR", VARIANT_TRUE,
            VARIANT_TRUE, "");

            /* The physical properties of electromechanical relays dictate
            that they wear over time,

```

```

        becoming less reliable and eventually unusable. The odometer check
        is used to determine
        when the relays on the card are approaching end of life by keeping
        a count of switch events. */

        /* The GetOdometers function populates a SAFEARRAY with the
        odometer counts for the relays specified as a comma separated list
        of relay names in BSTR. */

        _bstr_t relays = "K1, K2, K13";
        SAFEARRAY* odoms = NULL;
        varres->GetOdometers(relays, &odoms);

        varres->Close();
    } catch (_com_error &e) {
        :MessageBox(NULL, e.Description(), e.ErrorMessage(),
        MB_ICONERROR);
    }
} catch (...) {
    // handle errors here, depending on needs
}
}

```

DRIVER INTERFACES

The following is a list of programmatic interfaces to the EX1200-7600 with a description of the functionality they provide. Please refer to the help file installed with the driver for a programming reference that includes all methods with their parameters as well as all enumerations.

- **IVTEXVarRes:** Used to open and close connections to the instrument. Also contains Failsafe information that is per-card, such as Temperature.
- **Channels:** Used to configure or query individual channel state such as resistance value, relay switching mode or over voltage/current status.
- **DriverOperation:** IVI standard. Provides control over the manner in which the driver operates.
- **Identity:** IVI standard. Provides detailed version information about the driver, connected hardware, and firmware versions.
- **Platform:** Used to Log driver function calls and to retrieve the serial number of the instrument.
- **Trigger:** Used to configure trigger condition and select a backplane trigger line to be asserted.
- **Utility:** IVI standard. Provides useful functionality not specific to this driver, such as Reset.

APPLICATION EXAMPLE

This example simulates PT100 RTD using EX1200-7600. The temperature range is simulated from -200 °C to 850 °C.

```
// RTD Simulation using EX1200-7600(2).cpp : main project file.

#include "stdafx.h"
using <mscorlib.dll>
#import "IviDriverTypeLib.dll" no_namespace
#import "VTEXVarRes.dll" no_namespace
using namespace System;

double const START_TEMP = -200;           //starting temperaure range
double const END_TEMP = 850;             //ending temperature range

double const A= 3.9083* pow(10.0F,(int)-3); //RTD material constant
double const B = -5.775* pow(10.0F,(int)-7); //RTD meterial constant
double const Ro = 100;                   //Temperature at 0'C
int _tmain()
{
    ::CoInitialize(NULL); //Start the COM layer
    /*We want to instantiate a pointer to the driver in a try/catch block so that we
    fail properly if the driver is not found in the COM registry*/
    try
    {
        IVTEXVarResPtr VarRes(__uuidof(VTEXVarRes));
        /*We want to do the Initialization a try/catch block so that our test
        code doesn't run if we fail to initialize.*/
        try
        {
            double temperature;
            std::cout<<"RTD Simulation using EX1200-7600 programmable
resistance card"<<std::endl;
            /*We chose to give the driver an empty options string. You
may want to give your driver options - check the manual to see the available settings.
change the Instrument ID string accordingly*/
            VarRes-
>Initialize("TCPIP::10.30.1.45::INSTR",VARIANT_TRUE,VARIANT_TRUE, "");
            VarRes->Channels->Item["CH1"]->Enabled = true;
                //Enabling the channel for use
            VarRes->Channels->Item["CH1"]->SwitchMode =
VTEXVarResSwitchModeBreakBeforeMake; // Break(to high resistance) before setting the
resistance

            std::cout<<"Enter the temperature value to be set(-200'C to
850'C):";

            std::cin>>temperature;
            if(temperature>= START_TEMP && temperature <=END_TEMP)
            {
                //Temperature to resistance as per Callendar-Van
                double C = temperature<0?(-4.183* pow(10.0F,(int)-
12)):0;
                VarRes->Channels->Item["CH1"]->Output = (Ro * (1 + A*
temperature + B*pow(temperature,2) + C*(temperature-100)* pow(temperature,3)));
                std::cout<<"Actual set Resistance:"<<VarRes-
>Channels->Item["CH1"]->Output<<std::endl;//Retrivers the acutal resistance from the
device
            }
            //Close the initialized session
            VarRes->Close();
        }
        catch(_com_error &e)
        {
    
```

```
                ::MessageBox(NULL, e.Description(), e.ErrorMessage(),
MB_ICONERROR);
            }
        }
        catch(...)
        {
            //We put this here to catch any error the program generates.
            //Do something to intelligently deal with errors
        }
        return 0;
    }
}
```

SECTION 4

SFP OPERATION

INTRODUCTION

EX1200s offer an embedded web page which provides network configuration control, time configuration, and the ability to perform firmware upgrades. To facilitate discovery of the mainframe, VTI provides the **L**AN **I**nstrument **C**onnection and **U**grade (**LInC-U**) utility on the *VTI Instruments Corp. Drivers and Product Manuals CD* included with the EX1200 mainframe in the *EX Platforms Requisites* directory.

To open the embedded web page, start the **LInC-U** utility by navigating to **Start** → **Programs** → **VTI Instruments Corporation** → **LInC-U Utility** → **LInC-U Utility**. Once the utility is run, LInC-U will scan the network to discover all LAN-based VTI instruments. Once the scan is complete, the **Discovery Devices** tab will appear and show the instruments that were discovered, as shown in Figure 4-1. To open the web page, click on the hostname hyperlink in the **Discover Devices** tab. The IP address of the EX1200 can also be viewed from this window as well as its firmware version.




FIGURE 4-1: LINC-U DISCOVERY TAB WITH AN EX1268 SELECTED

Alternatively, the EX1200 may also be discovered using Internet Explorer's Bonjour for Windows plug-in, by entering the mainframe's IP address into the address bar of any web browser to view the embedded web page, or using VXI-11. For more information on discovery methods, refer to the *EX1200 Series User's Manual* (P/N: 82-0127-000).

GENERAL WEB PAGE OPERATION

When initial connection is made to the EX1200, the instrument home page, **Index**, appears (see). This page displays instrument-specific information including:

- Model
- Manufacturer
- Serial Number
- Description
- LXI Class
- LXI Version
- Hostname
- MAC Address
- IP Address
- Netmask
- Instrument Address String
- Firmware Version
- IEEE-1588 Time




FIGURE 4-2: EX1200 MAIN WEB PAGE

The **Index** is accessible from any other instrument page by clicking on the EX1200 web page header. The EX1200 **Command Menu** is displayed on the left-hand side of every internal web page. The entries on the command menu represent three types of pages:

- Status** This type of page performs no action and accepts no entries. It provides operational status and information only. The **Index** page is an example of a status page.
- Action** This type of page initiates a command on the instrument, but does not involve parameter entry. The **Reboot** page is an example of an action page.
- Entry** This type of page displays and accepts changes to the configuration of the instrument. The **Time Configuration** page is an example of an entry page.

Use of the entry-type web pages in the EX1200 are governed by a common set of operational characteristics:

- Pages initially load with the currently-entered selections displayed.
- Each page contains a **Submit** button to accept newly entered changes. Leaving a page before submitting any changes has the effect of canceling the changes, leaving the instrument in its original state.
- Navigation through a parameter screen is done with the **Tab** key. The **Enter** key has the same function as clicking the **Submit** button and cannot be used for navigation.

Notes on Web Page Use

If a window needs to be resized, this should be done when the window opens. Resizing requires a refresh which causes the current state to be lost.

VTI Instruments Logo

The VTI Instruments logo that appears on the upper left of all EX1200 web pages is a link to the VTI Instruments corporate website: <http://www.vtiinstruments.com>.

The remainder of this discussion will focus on the EX1200-7600 soft front panel. For more information on other EX1200 soft front panel elements, please refer to the *EX1200 Series User's Manual*.

EX1200-7600 SOFT FRONT PANEL

To navigate to the EX1200-7600 soft front panel, click on **Soft Front Panel** in the **Command Menu** (see Figure 4-3). Next, select **ex1200-7600 Variable Resistance** from the list of cards installed in the EX1200.




FIGURE 4-3: EX1200 SOFT FRONT PANEL MAIN PAGE

MONITOR AND CONTROL TAB

By default, the EX1200-7600 SFP opens to the **Monitor and Control** view. From this view, the user can define the load's resistance value and set up how failure events are communicated. Although the SFP does not expose the entire functionality of the resistance load, the SFP can be used to set up the EX1200-7600 for most applications.




FIGURE 4-4: EX1200-7600 SOFT FRONT PANEL

Failure Indicator LEDs

The EX1200-7600 SFP provides four LED indicators to alert the user to specific failure conditions: **OverCurrent**, **OverTemperature**, **OverVoltage**, and **Backplane Failsafe**. When an LED turns red, this indicates that a failure condition has occurred. Failures can be communicated by the EX1200-7600 to the EX1200 by configuring the **Output Source** and **Backplane Lines** fields.

Resistance Field

The **Resistance** field is used to configure the resistance value of the desired load. The EX1200-7600 can be set to a value between 0.5 Ω and 1,499,999 Ω in 0.1 Ω increments with specified accuracy. The **Enable** slider allows the user to enable and disable the EX1200-7600's resistance channels. Note that the EX1200-7600 can be set to resistance values up to 2,097,152.6 Ω , but the accuracy of the values above 1,499,999 Ω are not specified.

Output Source

The **Output Source** field specifies the output signal that will be used when a failure condition is detected. When an Output Source is selected, the signal is sent to the EX1200 backplane line indicated by the **Backplane Line** field.

- **No Source Selected:** When selected, this indicates that no output will be generated if a failure condition is met.
- **OverVoltage:** Indicates that, when an over-voltage condition occurs, that an output will be generated on the selected backplane line. An overvoltage condition is defined as an input exceeding 200 V ac rms.
- **OverCurrent:** Indicates that, when an over-current condition occurs, that an output will be generated on the selected backplane line. An overcurrent condition is defined as an input exceeding 0.5 A.

- **OverTemperature:** Indicates that, when an over-temperature condition occurs, that an output will be generated on the selected backplane line. An over temperature condition is defined as an when the EX1200-7600 board exceeds a surface temperature of 102 °C (215.6 °F).
- **Backplane Failsafe:** Indicates that, when a backplane failsafe condition occurs, an output will be generated on the selected backplane line.
- **Any Failsafe Condition:** When selected, any of the above failure conditions will generate a signal on the selected backplane line.

Backplane Line Source

The **Backplane Line** field specifies the backplane line that will be used if an failure condition occurs. Selecting **BPL0-BPL7** will send the failure signal to the EX1200 backplane on the selected line. When **None** is selected, failures signals are not sent.

DEVICE INFORMATION TAB

If the **Device Info** tab is clicked, information regarding the selected instrument will be displayed including the versions of the SFP, firmware, and hardware.




FIGURE 4-5: DEVICE INFORMATION WEB PAGE

SECTION 5

THEORY OF OPERATION

INTRODUCTION

This instrument contains internal, high-precision 5 W power resistors that are switched in and out via mechanical relays. It is capable of producing any resistance value between 0.5Ω to $1,499,999 \Omega$ and can be adjusted in 0.1Ω increments via external commands. Values above this, up to $2,097,152.6 \Omega$, can be generated as well with an unspecified accuracy. The EX1200-7600 is designed for terminal voltages from 0 V to 200 V dc and for currents up to 0.5 A.




FIGURE 5-1: EX1200-7600 SCHEMATIC

To enable the programmable load resistance, **K33** and **K34** must be closed.

The module's resistance value is set by opening the relays corresponding to the resistors required to create the desired programmed value. For example, a programmed resistor value of 0.6 Ω will result when **K1** and **K35** is opened and all other relays are closed. Note this is due to a native 0.5 Ω resistance.

Paralleled relays must be closed in order to ensure that the high tolerances of this module's resistance values are achieved. For example, if **K1/K35** and **K2/K36** are closed, then **K32** must be closed as well. If **K13** through **K25** are closed, then **K26** must also be closed. These paralleled relays are automatically closed by the driver.

After power up, reset, or after fault condition, all relays on the EX1200-7600 are open. A fault condition is defined as exceeding the maximum current, maximum voltage, or maximum temperature for this module.

The *V Sense Out* signal provides an indication of the voltage across the programmed resistance. The relationship between *V Sense Out* and the voltage across the resistor load is determined by using the following equation:

$$40 \times (\text{V Sense Out}) = \text{Voltage across the resistor load (in volts)}$$

For example, if *V Sense Out* reads 2.5 V, then the voltage across the resistor load is 100 V. The maximum voltage reading is 200 V.

The *I Sense Out* signal provides an indication of the current across the programmed resistance. The relationship between *I Sense Out* and the current across the resistor load is determined by using the following equation:

$$100 \times (\text{I Sense Out}) = \text{Current across the resistor load (in milliamps)}$$

For example, if *I Sense Out* reads 2.5 V, then the current across the resistor load is 250 mA. The maximum current reading is 500 mA.

INDEX

A

accuracy 12

B

BPL_INSFAIL line 17

C

closing 20

connector pin/signal assignment 15

signal pin definitions 16

cooling 13

current scaling 34

D

driver interfaces 24

F

fail-safe modes 22

OverCurrent 22

OverTemperature 22

OverVoltage 22

fault condition 9

fault sensing 9

firmware version 28

I

IEEE-1588 time 28

index web page 28

initializing 20

IP address 28

L

LAN Instrument Connection and Upgrade utility 27

LnC-U *See* LAN Instrument Connection and Upgrade

LXI class 28

LXI version 28

M

mating connector 11

monitor and control webpage 30, 31

O

odometers 23

option strings 20

P

plug-in module

installation 13

power 13

power consumption 13

programming 19

closing 20

fail-safe 22

initializing 20

odometers 23

resistance 21

RTD simulation 25

S

SFP

any failsafe condition indicator 31

backplane failsafe indicator 31

backplane line source 31

failure indicator LEDs 30

monitor and control page 30, 31

output source field 30

OverCurrent indicator 30

OverTemperature indicator 31

OverVoltage indicator 30, 31

resistance field 30

soft front panel *See* SFP

specifications 11, 12

switching time 12

T

theory of operation 33

U

using the driver 19

V

voltage scaling 34

W

warm-up 14

WEEE 5