

Zeversolar Service Line

China (incl. Hongkong, Macau)

Jiangsu Zeversolar New Energy Co., Ltd.

Tel.: +86 512 6937 0998-8866

E-mail: service.china@zeversolar.com

Add.: Building 9, No.198 Xiangyang Road, Suzhou 215011, China

Australia

Zeversolar Australia

Tel.: +61(0)1300101883

E-mail: service.apac@zeversolar.com

Add.: Suite 2.23 Level 2, 838 Collins Street, Melbourne, Docklands Vic 3008, Australia

Europe Region

Zeversolar GmbH

Tel.: +49(0) 2102 420 944

E-mail: service.eu@zeversolar.net

Add.: Luxemburger Straße 59, 50674 Köln, Germany


United Kingdom:

Tel.: +44 (0) 800 731 0899

E-mail: service.eu@zeversolar.net

Rest of the world

E-mail: service.row@zeversolar.com



Installation and Operating Instructions

ComBox

zeversolar

Contents

1. About this Manual	3
1.1 Scope of Application	3
1.2 Target Reader	3
1.3 Abbreviations	3
2. Introduction	4
2.1 Product Overview	4
2.2 Function and Feature	4
2.3 Scope of Application	4
2.4 Scope of Delivery	5
2.5 Environment and Attention	5
2.6 Safety Symbols	5
3. Mounting	6
3.1 Preparation	6
3.2 Assemble the ComBox	6
4. Connect to Internet	7
4.1 Connecting via Ethernet	7
4.2 * Connecting via WiFi	8
5. Web Server	10
5.1 Visiting the Web Server	10
5.2 Home	11
5.3 Ethernet	11
5.4 Advanced	12
5.5 *Wireless	20
6. Solarcloud	22
6.1 Account Registration	22
6.2 Create a PV plant	24
6.3 Browse PV plant	26
6.4 Add a ComBox	26
6.5 PV Plant Sharing	27
6.6 Configuration Report	27
6.7 Mobile device Monitoring	28

Contents

7. Trouble Shooting.....	30
7.1 LED Indication of Network Interface	30
7.2 FAQ	31
8. Technical Parameters.....	32
9. Disposal	33
10. ContactUs	34

1. About this Manual

This manual contains a detailed description of the ComBox, including precautions, methods of installation and operating instructions.

The specifications described in this document apply to the current version of the product. We reserve the right to make changes or update our product to introduce new functions and overall improvements. This specification is subject to change without prior notice. Please contact Zeversolar to confirm the latest revision.

1.1 Scope of Application

This manual applies to the ComBox firmware version 15430-408R+15429-407R and later versions.

1.2 Target Reader

This manual is intended for authorized skilled installers, who have knowledge of electrical safety. Safety warnings can be found in section 2.6. Please read this manual carefully before installing.

1.3 Abbreviations

Table 1-1: Abbreviations

Abbreviation	Designation
E-Today	Daily Energy
E-Total	Total Energy
LAN	Local Area Network
WAN	Wide Area Network
WLAN	Wireless Local Area Network
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name Server
PV	Photovoltaic
Pac	Alternating Current Output Power

2. Introduction

The monitoring system plays an important role in the PV plant. Users can view the PV Plants power generation data and fault information to avoid unnecessary loss of power and non-scheduled downtime. Users can also maximize the energy generating efficiency according to power generating data and report. ComBox has two versions: ComBox and ComBox WiFi.

2.1 Product Overview

The ComBox is an integrated monitoring device, which can be installed inside the inverter, and collects the inverter's data and events in the PV plant. When an Internet connection is present, the ComBox will upload the collected data to the Solarcloud to facilitate on-line web monitoring and data analysis. The system structure shows in Fig. 2-1.




Fig.2-1: System structure

2.2 Function and Feature

- PV Plant monitoring via the Solarcloud
- Remote monitoring via Ethernet or WiFi
- Power Management Capability
- Support Micro SD card save data
- Integrated memory
- Online firmware updating

2.3 Scope of Application

ComBox can be installed in the following inverters:

- Zeverlution 1000S-3000S
- Zeverlution 3000SE-3680SE



The sections marked with a * apply to the WiFi version.

2.4 Scope of Delivery

The details information about Scope of Delivery please refer to the ComBox Quick Installation Guide.

2.5 Environment and Attention

The ComBox operational ambient temperature is -25 ° C to 75 ° C.

2.6 Safety Symbols

Please pay attention to the following safety symbols in the manual:



Information

Provides information about installation or use.



Notice

Indicates the instructions must be followed in the correct order to prevent problems.



Warning

Indicates the instructions must be followed in order to prevent serious problems or injuries.

3. Mounting

3.1 Preparation

Table 3-1: Preparation

Type	Requirements	Quantity
Network cable	1. Comply with the standards for structured cabling according to EIA/TIA-568. 2. Shielded Ethernet cable (CAT-5E or higher). 3. UV resistant if used outdoors.	Max. 100m

3.2 Assembling the ComBox

3.2.1 Electrical Checks

Risk of lethal electric shock when opening the inverter may cause death or serious injury. Therefore before assembly, ensure that the inverter is isolated from all sources of AC and DC power (see inverter Installation Guide).

Electrostatic discharge can damage the inverter. Please ground yourself before touching components by touching the protective conductor (PE) or a non-coated part of the inverter enclosure.



1. In order to ensure safety, before assembly, please read the inverter user manual carefully.
 2. Assembly is strictly prohibited when the inverter connected to electricity or is in operation.
-

3.2.2 Assembly

For details regarding mounting please refer to the ComBox Quick Installation Guide.

4. Connecting to the Internet

The ComBox requires an Internet connection in order to provide remote monitoring via Ethernet or WiFi.

The ComBox uses network port #6655 and #80 to communicate with the Solarcloud. Both of these two ports must be opened otherwise the ComBox cannot connect to the Solarcloud and upload data.



If the IP address of the ComBox is different from the network segment assigned by the router,

Troubleshooting:

1. Make sure the DHCP service of router has been activated if ComBox use DHCP function.
 2. Check the connection between the ComBox and the router.
 3. Check whether the ComBox was using a fix IP address.
 4. If the ComBox cannot obtain an IP address from the router, it will use 169.254.1.100 or 0.0.0.0
-

4.1 Connecting via Ethernet

The ComBox is connected to the Ethernet by simply connecting the Ethernet cable from the router to the Ethernet port. The connection between the ComBox and the Internet is shown in Fig. 4-1.



Fig. 4-1: Network connection

The ComBox obtains an IP address from the router via DHCP automatically and displays it on the LCD of the inverter. The time it takes to connect to the Internet depends on the network communication conditions. At the same time the router needs to support DHCP services and the DHCP services must be activated if the ComBox has been set up to use the DHCP function.

Connecting to the Internet

4.2 * Connecting via WiFi

If users use the ComBox's WiFi to connect the router for remote monitoring, the connection diagram is shown in Fig. 4-2.



Fig. 4-2: WiFi connection

In order to achieve remote monitoring reliably, the following steps must be taken.

Step1: Power on the inverter, which will also power ComBox, and use a mobile device or laptop to search for the wireless access point (AP) of the Combox WiFi. A new AP of ZEVEVSOLAR -XXXX is displayed, Select this AP to connect. The password is "zeversolar". As shown in Fig. 4-3.



Fig. 4-3 WiFi connection page



1. "XXXX" stands for the last four digits in the Registry ID of the Combox.

Step2: Start the web browser and enter <http://160.190.0.1>. The internal website opens.

Step3: Select the wireless page and select a wireless local network in the area to connect. The Password/Security Key dialog box opens, as shown in Fig. 4-4.



Fig. 4-4 connect to router

Step4: Enter the password of the wireless local network that you wish to connect to. Do not enter the password of the router.

Step5: After approximately one minute the WiFi of the ComBox will connect to the wireless local network. The status indicator on the Wireless page should display the  icon, as shown in Fig. 4-5.




Fig. 4-5 WiFi Connection Instructions

5. Web Server

The ComBox has an integrated internal web server. The running state of the inverter can be checked from the internal web server page. You can also enable some advanced functions such as output power limitation and adjusting the inverter's safety parameters.

The interface structure of the built-in web server is shown in Fig. 5-1.




Fig. 5-1: Structure of the web server

5.1 Visiting the Web Server

There are two ways to visit the internal web server of the ComBox: via Ethernet or via WiFi (if the ComBox is equipped with the WiFi module).

5.1.1 Visiting via Ethernet

Input the IP address of the ComBox (shown on the inverter's LCD) in the browser's address bar. For example, if the IP address shown on the inverter is 192.168.10.13, then enter 192.168.10.13 in the browser's address bar and press the Enter key to open the web page, as shown in Fig. 5-2.

5.1.2 *Visiting via WiFi

You also can visit the web page via WiFi, please refer to section 4.2. Once you are wirelessly connected to the ComBox, input "160.190.0.1" in the browser's address bar, press the Enter key to display the internal web page of ComBox, as shown in Fig. 5-2.




Fig. 5-2: ComBox Web Server

5.2 Home

This page shows the information and state of the ComBox. It also shows the state of the inverter. See Fig. 5-2.

If the inverter is working normally, it shows a green  icon; otherwise the red  icon will be shown.

5.3 Ethernet

Clicking the "Ethernet" tab will open the Ethernet page. On this page you can set the Ethernet port parameters. You can set the ComBox using a static IP address or obtaining the IP address automatically.

HomeEthernetAdvancedWireless

Local Area Connection

☒ Obtain an IP address automatically

IP Address

192.168.10.13

Subnet Mask

255.255.255.0

Gateway

192.168.10.1

MAC Address

EA-B9-61-53-00-10

☒ Obtain DNS server address automatically

DNS Address

192.168.9.20

Ok

Fig. 5-3: Ethernet page

5.4 Advanced

The Advanced web page shows the advanced settings of the ComBox, Such as the power management and safety setting.

In addition, the firmware of the ComBox and Inverter can be upgraded from this webpage.

5.4.1 Power Management

The ComBox will regulate the active power of inverter according to value of the installed PV module capacity or the installed inverter capacity or the energy meter reading, which are set by the user. Enter the fit to values in Fig. 5-4.

a) Active Power Limit

There are two modes of active power limitation can be selected and five values need to set.

☒ Active Power Limit

Solar DC Capacity

3680

Wp

Inverter AC Capacity

3680

W

☐ Output power

<=

100

%

Limit output power based on the installed Solar DC capacity

☒ Output power

<=

100

%

Limit output power based on the installed inverter AC capacity

Fig. 5-4: Set Active Power Limitation Method

The following ways will introduce how to configure the two types of power limitation.

~12~

■ Based on the installed Solar DC capacity

In this method the AC output of the PV system will not exceed a set percentage of the installed solar DC capacity. For example, if a 20 % limitation on a 1,5 kWp PV system connected to an Eversol TL2000 (2 kWac inverter) has been set then the AC output will not exceed 1.2 kWac.

The Fig.5-5 shows the system diagram of power limitation based on the installed solar DC capacity




Fig. 5-5 System diagram based on the installed solar DC capacity

For this method position 1 in Fig. 5-6 should be ticked.

For correct operation of this method there are three parameters that must be entered, please refer to Fig. 5-6:

Item a – installed solar DC capacity of PV system in Wp;

Item b – total inverter AC capacity of PV system in W;

Item c – Limitation value of solar DC capacity in %.

Click “OK” button in bottom-right of this web page to ensure the setting parameters take effect.

☒ Active Power Limit

Solar DC Capacity

a

3680

Wp

a=a1+a2

Inverter AC Capacity

b

3680

W

b=Rated Power(INV_1)+Rated Power(INV_2)

1

☒

 Output power

c

<=

100

%

Limit output power based on the installed Solar DC capacity

☐ Output power

<=

100

%

Limit output power based on the installed inverter AC capacity

The Fig. 5-6 Set parameters based on the installed solar DC capacity

The “output power” value is value a multiplied by value c when $P \geq a \times c$,
Table 5-1: The indicator of the Item

Parameter	Definition
a	The combined peak power of the PV array (Wp)
b	The sum of the rated powers of all inverters in the PV plant (Wac)
c	The Percentage of output power limitation based on parameter a
P	The sum of the real time output power of all inverters in the PV plant

Parameter b: This parameter is the key value of power limitation, please ensure that it is correct

■ Based on the Installed Inverter AC Capacity

In this method the AC output of the PV system will not exceed a set percentage of the installed inverter AC capacity regardless of the installed DC capacity. For example, if a 20 % limitation on a 2 kWp PV system connected to an Eversol TL2000 (2 kWac inverter) has been set then the AC output will not exceed 1.6 kWac.

Fig. 5-7 is shows the system diagram of power limitation based on the installed AC (inverter) capacity

For this method position 2 in Fig. 5-7, should be ticked.
For correct operation of this method there are two parameters that must be entered, please refer to Fig. 5-7:

- Item b – total inverter AC capacity of PV system in W;
- Item d – Limitation value of AC capacity in %.

Click the “OK” button in bottom-right of this web page to ensure the setting parameters take effect.

☒ Active Power Limit

Solar DC Capacity	3680	Wp
Inverter AC Capacity	b 3680	W $b = \text{Rated Power(INV_1)} + \text{Rated Power(INV_2)}$
☐ Output power	$\leq$ 100	% Limit output power based on the installed Solar DC capacity
2 ☒ Output power d	$\leq$ 100	% Limit output power based on the installed inverter AC capacity

The Fig. 5-7 Set parameters based on the installed solar DC capacity

The “output power” value is value b multiplied by value d when $P \geq b \cdot d$

Table 5-2: The indicator of the Item

Parameter	Designation
b	The sum of the rated power of all inverters in the PV plant (Wac)
d	The percentage of power output limitation based on parameter b
P	The sum of the real time output power of all inverters in the PV plant

Parameter b: This parameter is the key value of power limitation. Please ensure that it is correct

b) Reactive Power Limit

There are four modes of reactive power limitation can be selected.

- Cos(phi) fix mode: In this mode, the ComBox will regulate the reactive power of inverter according to the Cos(phi) value which is set by the user. Enter the Cos(phi) value and choose the phase as shown in Fig.5-8.

Choose Mode **Fixed Cos(phi)**

Cos(phi) (0.8~1) Phase **Leading**

Fig. 5-8: Cos(phi) fix mode

- Cos(phi) variable mode: In this mode, the ComBox will produce a curve according to the “P/Pn”, “Cos(phi)” and the phase of points 1,2,3 and 4, and will regulate the reactive power according to this curve, as shown in Fig. 5-9.

Choose Mode Variable Cos(phi) ▾

Point 1: P/Pn	20	% (0-100%)	Cos(phi)	0.95	(0.8~1)	Phase	Leading ▾
Point 2: P/Pn	40	% (0-100%)	Cos(phi)	1	(0.8~1)	Phase	Leading ▾
Point 3: P/Pn	60	% (0-100%)	Cos(phi)	1	(0.8~1)	Phase	Leading ▾
Point 4: P/Pn	80	% (0-100%)	Cos(phi)	0.95	(0.8~1)	Phase	Lagging ▾
Response time	5	s	(0~60s)				

Fig. 5-9: Cos(phi) variable mode




Fig. 5-10: Cos(phi) variable Cure

- Q fix mode: In this mode, the ComBox will regulate the reactive power of the inverter according to the Q value which is set by the user. You need to input the Q value and choose the phase as shown in Fig. 5-11.

Choose Mode Fixed Q ▾

Q 90 % (0-100%) Phase Leading ▾

Ok

Fig. 5-11: Q fix mode

- Q variable mode: In this mode, the ComBox will produce a curve according to the “U/Un”, “Q value” and phase position of points 1,2,3 and 4, and will regulate the reactive power according to this curve, as shown in Fig. 5-12.

Choose Mode Variable Q ▾

Point 1: U/Un	96	% (0~120%)	Q	50	% (0~100%)	Phase	Lagging ▾
Point 2: U/Un	100	% (0~120%)	Q	100	% (0~100%)	Phase	Leading ▾
Point 3: U/Un	108	% (0~120%)	Q	100	% (0~100%)	Phase	Leading ▾
Point 4: U/Un	112	% (0~120%)	Q	50	% (0~100%)	Phase	Leading ▾
Response time	5	s (0~60s)					

Fig. 5-12: Q variable mode




Fig. 5-13: Q variable Cure

To cancel the output power limit function untick the checkbox and click the “OK” button.



Please ensure that the inverter supports the Output Power Limit function.

5.4.2 Safety Setting

The ComBox also supports setting the safety parameters of the inverter. Choose the safety standard and then set the protect threshold below. And press the “OK” button.

Safety Setting			
Standard DE VDE-AR-N 4105			
OVP3:	264.5	V(240~295)	120 ms(20~5100)
OVP2:	264.5	V(240~295)	120 ms(20~720000)
OVP1:	264.5	V(240~295)	120 ms(20~720000)
OVPR:	253.0	V(230~OVP1)	
UVPR:	195.5	V(UVP1~230)	
UVP1:	184.0	V(110~230)	120 ms(20~720000)
UVP2:	184.0	V(110~230)	120 ms(20~720000)
UVP3:	184.0	V(110~230)	120 ms(20~5100)
OFF3:	51.50	Hz(45~65)	160 ms(20~5100)
OFF2:	51.50	Hz(45~65)	160 ms(20~720000)
OFF1:	51.50	Hz(45~65)	160 ms(20~720000)
OFFR:	50.05	Hz(45~OFF1)	
UFPR:	47.53	Hz(UFP1~65)	
UFP1:	47.50	Hz(45~65)	160 ms(20~720000)
UFP2:	47.50	Hz(45~65)	160 ms(20~720000)
UFP3:	47.50	Hz(45~65)	160 ms(20~5100)
10-minute mean	253.0	V(220~300)	

Ok

Fig. 5-14: Safety Parameters

5.4.3 Updating Firmware

The ComBox can update the firmware of itself, and can also update the firmware of the connected inverter.

The ComBox can distinguish the update file type and update it automatically.

■ Update ComBox firmware

Enter the Advanced page and click the “choose file” button and select the new firmware of ComBox and then click the “OK” button to update.




Fig. 5-15: Update Firmware

■ Update inverter firmware

Enter the Advanced page and click the “choose file” button and select the new firmware of inverter and then click the “OK” button to update. It similar the Fig. 5-15, but you should choose the relevant inverter firmware file.

5.4.4 Restart

Enter the Advanced page of the ComBox and click the “OK” button at the Restart section to restart the device.



Fig. 5-16: Restart the device

5.4.5 Restore to Factory

Enter the Advanced page of the ComBox and click the “OK” button in the Restore to Factory section to restore all the parameters of the ComBox to the factory settings.



Fig. 5-17: Restore to Factory



This operation will delete all user data

5.5 *Wireless

This page shows the wireless network of ComBox. You can also configure the wireless network. If you want to change the connected WiFi network, please refer to section 4.2.

Wireless Network:

D-Link_DIR_615		
1234567		
zeversolar-ef		
ZEVERSOLAR-3F-1		
HETAO		
ZTE-9340E0		
Zeversolar-SZ		
jerrylaptop		
ZEVERSOLAR-0024		

Refresh

Fig. 5-18: Wireless Network

The wireless network IP information was shown as below. To change these settings please refer to section 5.3.

Wifi Connected

AND-TEST-HUAWEI 	
☒ Obtain an IP address automatically	
IP Address	192.168.6.135
Subnet Mask	255.255.255.0
Gateway	192.168.6.1
MAC Address	C8-93-46-45-5A-0D
☒ Obtain DNS server address automatically	
DNS Address	192.168.9.20
Ok	

Fig. 5-19: Wireless IP information

6. Solarcloud

The Solarcloud is a cloud service platform for users provided by Zeversolar. The ComBox transfers the operation data to the Solarcloud server via the Internet to enable the users to monitor their PV plants and inverters remotely through a computer or a mobile device.

You can visit Solarcloud via the following website on a PC:

<http://solarcloud.zeversolar.com>. For the Android application, search for "Solarcloud" in Google play to download and install Solarcloud for on your mobile device. For the iPhone or iPad application, search for "Solarcloud" in the App store of the Apple Corporation and install it on your iPhone or iPad.



To monitor the PV plant and inverter with Solarcloud, the ComBox and Internet must be functioning normally.

6.1 Account Registration

Users who use Solarcloud for the first time are required to register an account in Solarcloud. Monitoring can then be performed after the user has registered.

Step 1: Input <http://solarcloud.zeversolar.com> in the browser and open the main page of Solarcloud as shown in Fig. 6-1.



Fig. 6-1: Registration and login page

Step 2: Click the button marked with a “1” in Fig .5-1, click “Register” to enter the registration page, and register a user account according to the prompts.

Step 3: After the registration has been completed, Solarcloud will send an activation email. Activate your Solarcloud account according to the information in the email. If there is no activation mail in your inbox, please check your spam box.



If you did not receive an email from Solarcloud, it could be:

1. The email was identified as junk mail. Please check the spam folder. If the email from Solarcloud was identified as junk mail, please add the address of Solarcloud into your white list to avoid future emails from Solarcloud being identified as junk mail.
2. You may have input an email address which is different from the one you used for registration. Please confirm if the email was sent to another email address. Please reregister if you entered an unknown email address when entering account information.

6.2 Create a PV plant

Step1: Enter <http://solarcloud.zeversolar.com> in the address bar of the browser and open the home page of Solarcloud as shown in Fig. 6-1.

Step2: Input your user name and password in the area marked with a “1” in Fig. 6-1 to login to Solarcloud. If the login is successful you will enter the web page with a PV plant list as shown in Fig. 6-2.




Fig. 6-2: Setting up a new PV plant

Step3: Click Position 1 in Fig. 6-2 to enter the PV plant establishing page as shown in Fig. 6-3. Follow the prompts on the page to establish a PV plant.

Plant icon

* Serial Number:

* Registry Key:

Serial number and Registry key can be found on the label of Monitor, as shown below.

Plant Info

* Plant Name:

Installed Capacity: KW

Commissioning:

Company/Organization:

* Country: Please select a country.

* State: Please select State / Province

* City:

Street/No.:

Zip Code:

Longitude: E ° ' "

Latitude: N ° ' "

Altitude: m

Angle of Inclination: °

* CO2 Avoided Factor: 0.8 Kg/KWh

* Currency:

* Yield Factor: 0.7 [\$/KWh]

1

* Timezone:

Field marked with an asterisk(*) are required.

OK

Fig. 6-3: Enter the ComBox and PV plant information to finish the creation of PV plant



During PV plant creation, it is very important to choose the correct time zone. Please select the correct time zone where the PV plant is located in Position 1 shown in Fig. 6-3.



When establishing a PV plant, it is necessary to input the registry ID and registry number of the ComBox. This information can be found on the ComBox web page.

6.3 Browse PV plant

You can enter any PV plant by clicking the plant list. This allows you to view the power generation data of the PV plant as well as inverter events. The menu structure is shown in Fig. 6-4:




Fig. 6-4: Menu structure of PV plant monitor page

6.3.1 Overview

This menu provides information such as E-Today, E-Total and the Yield of the entire PV plant. It also provides the power generation graph and events of the PV plant.

6.3.2 Graphs

This menu provides detailed graphs such as power& energy, yield and CO₂ avoided of each inverter in the PV plant.

6.3.3 Config

In this menu, you can check all of the detailed information of the ComBox and the inverter and also add or remove ComBoxes and inverters. In addition, email addresses can be configured to share information about the PV plant to other users.

6.3.4 User

Here you can modify your user information and the login password of Solarcloud.

6.4 Add a ComBox

A ComBox can be added to a PV plant as follows:

Step1: Login to Solarcloud and enter Config→Device Management page.

Step2: Enter the registry ID and registry key of the ComBox into the textbox shown in Fig. 5-5.

Fig. 6-5: Add more ComBox s to the PV plant

Step3: Click the “Add monitor” button and the new ComBox will be added.

6.5 PV Plant Sharing

Your PV plant can be shared with other Solarcloud users, to enable other users to view your PV plant. You can also configure the sharing authority when sharing it.

Step1: Login into Solarcloud and enter the Config→Shared Config page.

Account	First Name	Last Name	Plant Config	Device Management	Report Config	
long...@zeversolar.com	...	ma	☒	☒	☒	✕
...@zeversolar.com	Zever	Solar	☒	☒	☒	✕
...@zeversolar.com	...	Yang	☐	☐	☐	✕
...@zeversolar.com	...	solar	☐	☐	☒	✕
+						

Fig. 6-6: PV plant sharing

Step2: Click , an “Add a shared user window” will appear; enter the user account that needs to be shared.


Step3: In the check box in Fig. 6-6, you can configure the authorities of the shared users.

6.6 Configuration Report

Solarcloud can email you the daily and monthly operation state of the PV plant, including the amount of generated energy, yield, CO₂ emission reduction and other information. In addition it can also inform you of events of the PV plant by email. This function can be configured as follows:

Step1: Login to Solarcloud and enter Config→Report Config page.

Step2: First click “Active” to activate this function as shown in Fig. 6-7. Next input the email address in the text box, separate addresses with “;” if you are entering more than one email address. Select a time to send the email every day in “Send Report at” option.



The screenshot shows a web interface for configuring reports. At the top, there are three tabs: "Daily", "Monthly", and "Event". The "Daily" tab is selected. Below the tabs is a form with three rows: "Status" with radio buttons for "Active" (selected) and "Inactive"; "E-mail" with a text box containing "zeva@zeversolar.com;...;ang@zeversolar.com" and a note "(separate with \";)"; and "Send Report at" with a dropdown menu showing "Daily" and "21:00". At the bottom of the form are two buttons: "Send Report" and "Save".

Fig. 6-7: Activate the configuration report

Step3: After the above steps, click the “Save” button to save your settings, then click “Send Report” button to send to an email immediately.



The way of monthly report setting is similar to daily report setting method.

6.7 Mobile device Monitoring

After installing Solarcloud on your mobile device, you can retrieve information about the PV plant anytime whenever you have an Internet connection. Follow these steps to monitor your PV plant on your mobile device:

Step1: Search for “Solarcloud” in Google play to download and install the Solarcloud APP on your mobile device on the Android system. Or search “Solarcloud” in the App Store of Apple Inc., download Solarcloud and install it on your iPhone or iPad.

Step2: Login with your registered account. Using the navigation menu, you can view the power generation data and events in different pages.



Fig. 6-8: Solarcloud interface on smart phone

7. Trouble Shooting

7.1 LED Indication of Network Interface

LED	Status	Description	Solutions
Yellow light(link)	Off	No connection established	Check whether the connection between router and ComBox is normal. Ensure the router is turned on.
	On	Connection established	NA
Green light (activity)	off	Communication is abnormal	Check whether the connections between router/switch and ComBox are normal.
	Flashing	Data is being transmitted or received	NA

7.2 FAQ

Q1. How can I confirm whether the ComBox is successfully connected to Solarcloud?

Check the LCD on the Inverter. If it shows "Connected", it means the ComBox is successfully connected to the Solarcloud. "Disconnected" means the ComBox is disconnected from the Solarcloud.

Q2. Why can't I open the web page of the ComBox's web server?

Check whether the IP address displayed on the LCD of Inverter and the IP address of the computer are in the same network segment. If not, please use a computer that is in the same network segment with the ComBox to login.

8. Technical Parameters

Model	A10080-00	A10080-10
Electrical Data		
Power supply	Inverter	Inverter
Max. power consumption	1.0W	2.0W
Communication		
Communicate with router	Ethernet	Ethernet
WiFi communication	--	2.4GHz 802.11 b/g/n WEP/WPA/WPA2 PSK
Interface		
Ethernet	10/100 Mbit/s, RJ45	10/100 Mbit/s, RJ45
Micro SD Card	Max. 16GB	Max. 16GB
Max. communication range		
Ethernet	100m	100m
Environmental conditions		
Operation	-25℃ to +75℃	-25℃ to +75℃
Storage and shipment	-30℃ to +80℃	-30℃ to +80℃
Relative air humidity	5% to 95%, non-condensing	5% to 95%, non-condensing

9. Disposal

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your old equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment.



The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

10.ContactUs

If you have any technical problems concerning our products, please contact Zeversolar service.

Jiangsu Zeversolar New Energy Co., Ltd.

Tel.: +86 512 6937 0998

Fax: +86 512 6937 3159

E-mail: service.china@zeversolar.com

Factory add.: No.588 Gangxing Road, Yangzhong Jiangsu, China

Headquarters add.: Building 9 No.198 Xiangyang Road, Suzhou 215011, China