

User Manual

ASR-5300I

Command Line Interface

ADVANTECH

Enabling an Intelligent Planet

Copyright

The documentation and the software included with this product are copyrighted 2011 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Product Warranty (3 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Declaration of Conformity

CE

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from Advantech. Please contact your local supplier for ordering information.

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Class B

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FM

This equipment has passed the FM certification. According to the National Fire Protection Association, work sites are classified into different classes, divisions and groups, based on hazard considerations. This equipment is compliant with the specifications of Class I, Division 2, Groups A, B, C and D indoor hazards.

Technical Support and Assistance

1. Visit the Advantech website at <http://support.advantech.com> where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Warnings, Cautions and Notes

Warning! *Warnings indicate conditions, which if not observed, can cause personal injury!*



Caution! *Cautions are included to help you avoid damaging hardware or losing data. e.g.*



There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Note! *Notes provide optional additional information.*



Document Feedback

To assist us in making improvements to this manual, we would welcome comments and constructive criticism. Please send all such - in writing to: support@advantech.com

Packing List

Before setting up the system, check that the items listed below are included and in good condition. If any item does not accord with the table, please contact your dealer immediately.

- Item XXXXXXXXX
- Box XXXXXXXXX

Safety Instructions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment does not work well, or you cannot get it to work according to the user's manual.
 - The equipment has been dropped and damaged.
 - The equipment has obvious signs of breakage.
15. **DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -20° C (-4° F) OR ABOVE 60° C (140° F). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.**
16. **CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER, DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.**

The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

DISCLAIMER: This set of instructions is given according to IEC 704-1. Advantech disclaims all responsibility for the accuracy of any statements contained herein.

Safety Precaution - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- To avoid electrical shock, always disconnect the power from your PC chassis before you work on it. Don't touch any components on the CPU card or other cards while the PC is on.
- Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

Contents

Chapter 1	About This Manual	1
1.1	About This Manual	2
Chapter 2	Installation and Syntax	3
2.1	Installing and Activating the CLI	4
2.1.1	Activating the CLI on Windows OS	4
2.1.2	Activating the CLI on Linux OS	4
2.2	Command Entering Modes	5
2.2.1	Interactive Mode	5
2.2.2	Single Line Mode	5
2.2.3	Script Mode	6
2.3	Command Syntax	7
2.3.1	Parameter Syntax	7
2.3.2	Option syntax	7
2.3.3	Parameter/Option Order	8
2.3.4	Case Sensitivity	8
2.3.5	Abbreviation (Short Form)	8
	Table 2.1: List of short forms	8
2.3.6	Using the Filename Parameter as the File Path	9
2.4	Return Codes	10
Chapter 3	Summaries	11
3.1	Summary of Commands	12
3.1.1	! ~ Connect	12
3.1.2	Create	12
3.1.3	Delete	12
3.1.4	Disconnect ~ Select	13
3.1.5	Set	13
3.1.6	Show	14
3.1.7	Shutdown ~ Update	15
3.2	Summary of ASR-5300I Commands	16
3.2.1	! ~ Connect	16
3.2.2	Create	16
3.2.3	Delete	16
3.2.4	Disconnect ~ Select	17
3.2.5	Set	17
3.2.6	Show	19
3.2.7	Shutdown ~ Update	20
3.3	Summary of Commands by Functionalities	21
3.3.1	System Commands > Basic Commands	21
3.3.2	System Commands > Network Commands	21
3.3.3	System Commands > Component Commands	21
3.3.4	System Commands > Configuration Commands	22
3.3.5	System Commands > Log and Event Commands	22
3.3.6	Controller and Disk Commands > Controller Commands	23
3.3.7	Controller and Disk Commands > Disk Commands	24
3.3.8	Channel Commands	24
3.3.9	Logical Drive Commands	25
3.3.10	Logical Volume and Partition Commands > Logical Volume Commands	25
3.3.11	Logical Volume and Partition Commands > Partition Commands ..	

3.3.12	Host Commands	26
3.3.13	iSCSI Commands	26
3.3.14	Firmware Download Commands	27
3.3.15	Application Commands > Snapshot Commands	27
3.3.16	Application Commands > Replication Commands	27
3.3.17	Application Commands > Agent Function Commands	27

Chapter 4 Descriptions 29

4.1	Descriptions of Commands	30
4.1.1	!	30
4.1.2	?	30
4.1.3	Connect	31
4.1.4	Create IQN	32
4.1.5	Create iSNS	33
4.1.6	Create Logical Drive	34
4.1.7	Create Logical Volume	35
4.1.8	Create Map	36
4.1.9	Create Partition	38
4.1.10	Create Replication	40
4.1.11	Create Schedule	42
4.1.12	Create SED Keyfile	42
4.1.13	Create Snapshot Image	43
4.1.14	Create SNMPtrap	43
4.1.15	Create Trunk	44
4.1.16	Create WWN	44
4.1.17	Delete Event	44
4.1.18	Delete History	45
4.1.19	Delete IQN	45
4.1.20	Delete iSNS	45
4.1.21	Delete Logical Drive	46
4.1.22	Delete Logical Volume	46
4.1.23	Delete Map	47
4.1.24	Delete Partition	48
4.1.25	Delete Replication	48
4.1.26	Delete Schedule	49
4.1.27	Delete Snapshot Image	49
4.1.28	Delete SNMPtrap	49
4.1.29	Delete Trunk	50
4.1.30	Delete WWN	50
4.1.31	Disconnect	50
4.1.32	Exit	51
4.1.33	Export Configuration	51
4.1.34	Export NVRAM	51
4.1.35	Export Support	51
4.1.36	Help	52
4.1.37	Import NVRAM	52
4.1.38	Man	52
4.1.39	Mute	53
4.1.40	Reset Controller	53
4.1.41	Runscript	53
4.1.42	Scan Array	54
4.1.43	Select	55
4.1.44	Set Cache	55
4.1.45	Set Channel	56
4.1.46	Set Controller Date	57
4.1.47	Set Controller Default	57
4.1.48	Set Controller Name	58

4.1.49	Set Controller Parameter	58
4.1.50	Set Controller Trigger	59
4.1.51	Set Controller Uid	60
4.1.52	Set Device Flash	60
4.1.53	Set Disk Clear	60
4.1.54	Set Disk Clone	61
4.1.55	Set Disk Copy	61
4.1.56	Set Disk Flash	62
4.1.57	Set Disk Parameter	62
4.1.58	Set Disk Read-Write Test	63
4.1.59	Set Disk Saving	64
4.1.60	Set Disk Scan	64
4.1.61	Set Disk SMART Test	65
4.1.62	Set Disk Spare	65
4.1.63	Set History	65
4.1.64	Set Host	66
4.1.65	Set IQN	67
4.1.66	Set Log	68
4.1.67	Set Logical Drive	68
4.1.68	Set Logical Drive Add	68
4.1.69	Set Logical Drive Expand	69
4.1.70	Set Logical Drive Migrate	69
4.1.71	Set Logical Drive Parity	70
4.1.72	Set Logical Drive Rebuild	70
4.1.73	Set Logical Drive Saving	71
4.1.74	Set Logical Drive Scan	72
4.1.75	Set Logical Drive SED Disable	72
4.1.76	Set Logical Drive SED Enable	73
4.1.77	Set Logical Drive SED Unlock	73
4.1.78	Set Logical Drive Shutdown	73
4.1.79	Set Logical Drive Undelete	74
4.1.80	Set Logical Volume	74
4.1.81	Set Logical Volume Expand	75
4.1.82	Set Logical Volume Threshold	75
4.1.83	Set Logical Volume Tier-Enable	76
4.1.84	Set Logical Volume Multi-Tier	76
4.1.85	Set Logical Volume Tier-Migrate	77
4.1.86	Set Logical Volume Tier-Disable	77
4.1.87	Set Net	78
4.1.88	Set Partition	79
4.1.89	Set Partition Expand	80
4.1.90	Set Partition Purge	80
4.1.91	Set Partition Reclaim	80
4.1.92	Set Password	81
4.1.93	Set Replication	82
4.1.94	Set RS232	83
4.1.95	Set SED Erase	83
4.1.96	Set SED Password	83
4.1.97	Set Session	84
4.1.98	Set Snapshot Image	84
4.1.99	Set Snapshot Image Rollback	84
4.1.100	Set SNMPtrap	85
4.1.101	Set SSD-Cache Add	85
4.1.102	Set SSD-Cache Remove	85
4.1.103	Set SSD-Cache SED Disable	86
4.1.104	Set SSD-Cache SED Enable	86
4.1.105	Set SSD-Cache SED Unlock	86
4.1.106	Set SSD-Cache Service	87
4.1.107	Set Task	87
4.1.108	Show Access Mode	87

4.1.109	Show Array	87
4.1.110	Show Cache	87
4.1.111	Show Channel	88
4.1.112	Show CLI	88
4.1.113	Show Configuration	88
4.1.114	Show Controller	88
4.1.115	Show Controller Date	89
4.1.116	Show Controller Parameter	89
4.1.117	Show Controller Redundancy	89
4.1.118	Show Controller Trigger	89
4.1.119	Show Controller Uid	89
4.1.120	Show Device	90
4.1.121	Show Diagnostic	90
4.1.122	Show Disk	90
4.1.123	Show Disk Parameter	91
4.1.124	Show Disk Saving	91
4.1.125	Show Disk SMART	91
4.1.126	Show Disk Spare	91
4.1.127	Show Enclosure	91
4.1.128	Show Event	92
4.1.129	Show History	92
4.1.130	Show Host	92
4.1.131	Show IQN	92
4.1.132	Show iSNS	92
4.1.133	Show License	92
4.1.134	Show Logical Drive	93
4.1.135	Show Logical Drive Deleted	93
4.1.136	Show Logical Drive Saving	93
4.1.137	Show Logical Volume	93
4.1.138	Show Logical Volume Logical Drive	94
4.1.139	Show Logical Volume Threshold	94
4.1.140	Show Logical Volume Tier	94
4.1.141	Show Map	95
4.1.142	Show Net	95
4.1.143	Show Partition	96
4.1.144	Show Partition Purge	96
4.1.145	Show Replication	97
4.1.146	Show RS232	97
4.1.147	Show Schedule	97
4.1.148	Show Shutdown Status	97
4.1.149	Show Snapshot Image	98
4.1.150	Show SNMPtrap	98
4.1.151	Show SSD-Cache	98
4.1.152	Show Statistics	99
4.1.153	Show Stripe	100
4.1.154	Show Task	100
4.1.155	Show Trunk	100
4.1.156	Show WWN	100
4.1.157	Shutdown Controller	100
4.1.158	Update Firmware	101
4.1.159	Update Firmware and Boot Record	101
4.2	Descriptions of Options	102

Appendix A **Creating a Remote Replication Pair Using CLI 103**

A.1	Handling Multiple Subsystems with CLI (Remote Replication)	104
A.2	Preparing the Environment	105
A.3	Connecting the Subsystems	106

A.4	Assigning a Target Subsystem Partition as the Remote Disk.....	107
A.5	Confirming the Remote Disk in the Source Side.....	108
A.6	Pairing the Remote Disk with a Source Subsystem Partition.....	109

Chapter 1

About This Manual

1.1 About This Manual

This manual describes Command Line Interface for ASR-5300I.

For the following subjects, consult other resources for more information:

- Components that are not user-serviceable: Contact our support sites.
- Hardware operation: Consult the Hardware Manual in the CD-ROM.

Chapter 2

Installation and Syntax

The Command Line Interface (CLI) allows you to manage (create, view, modify, and delete) configurations of Infortrend's RAID controllers from a simple command terminal. In this chapter you will learn the installation procedure and syntax of the CLI.

2.1 Installing and Activating the CLI

The CLI is an optional feature; if you need to install it, send a request to customer support. See page 3, Contact Information, for reference.

2.1.1 Activating the CLI on Windows OS

1. Upon receiving the CLI file package, save it to an installation folder of your choice (for example, Program Files\Infortrend\CLI).
2. Open a command terminal, such as Program Files > Accessories > Command Prompt.
3. Enter into the CLI installation folder and run RunCLI.bat.

```
C:\> "C:\Program Files\Infortrend\CLI\RunCLI"
```

4. The CLI will be activated with the "RAIDCmd:" CLI prompt. You may start typing in the commands.

```
RAIDCmd: >
```

2.1.2 Activating the CLI on Linux OS

1. Upon receiving the CLI file package, save it to an installation folder of your choice (for example, Local\Infortrend\CLI).
2. Open the command shell.
3. Enter the CLI installation folder and run RunCLI.sh.

```
# /usr/local/Infortrend/CLI/RunCLI.sh
```

4. The CLI will be activated with the "RAIDCmd:" CLI prompt. You may start typing in the commands.

```
RAIDCmd:>
```

2.2 Command Entering Modes

Depending on your needs, you may enter a series of commands (Interactive mode), a single command (Single Line mode), or a script file including a batch of commands (Script mode).

2.2.1 Interactive Mode

If you want to enter a series of commands one by one, follow these steps.

1. Make sure the CLI has been activated with the “RAIDCmd” prompt appearing on the screen.

```
RAIDCmd:>
```

2. Enter a command and its parameter(s), for example connect 192.168.1.1. (Connects the RAID controller to the host computer at IP address 192.168.1.1)

```
RAIDCmd:> connect 192.168.1.1
```

3. The CLI will run the command and return the result as well as the Return code, which shows the current status.

```
CLI: Successful: Device 1 (UID:1, Name:, Model:F16F-R2A2A) selected
Return: 0x0000
```

4. Repeat the above process. To exit the CLI, enter exit.

```
RAIDCmd:> exit
CLI: Successful
Return: 0x0000
```

2.2.2 Single Line Mode

You can enter the CLI mode and run a command at the same time. This mode is useful when you want to run only a single command.

1. Enter the CLI installation folder (the following example is for Windows OS).

```
C:\> "C:\Program Files\Infortrend\CLI"
```

2. Execute RUNCLI.exe followed by the IP address of the RAID controller port and the command.

```
RunCLI RunCLI [[IP-Address]:port | hostname] ["index={device-
index}"| "uid={ID}"] ["password={secret}"] command
```

For example, if you want to execute set ctrl date command for a controller at IP address 192.168.1.1, you need to type:

```
RunCLI 192.168.1.1 "set ctrl date 20050101 180000 gmt=+8"d
```

3. The CLI will run the command and return the result as well as the Return code, which shows the current status.

```
CLI: Successful: Device (UID:8010d, Name:, Model: ASR-5300I-
16A1E) selected.
Return: 0x0000
CLI: Successful
Return: 0x0000
```

4. Unlike the Interactive mode, you do NOT need to exit the CLI mode (the exit Command) when you are done.

Using the Host Name and Account Instead of the IP Address

You may use the host name and login account instead of the IP address to specify the subsystem. The syntax will be as follows. If you select hostname in the first part, you need to specify the parameters in the second part.

```
[[IP-Address]:port | hostname] ["index={device-index}" |  
"uid={ID}"] ["password={secret}"]
```

hostname

Here you may select the host name of the subsystem or agent instead of the IP address. If not specified, the localhost address (127.0.0.1) and default port will be used.

"index={device-index}"

Specifies the device index of the array. If several arrays are in-band connected within the host, we can connect and select the specific array with a single connect command. If there is only one device (or via out-of-band connection), the parameter could be ignored. For Windows, the double quote (") symbol is required.

"uid=ID"

Specifies the controller unique ID of the subsystem.

"password={secret}"

Specifies the password of the subsystem (if necessary).

2.2.3 Script Mode

Instead of entering each command line by line, you can create and run a script file including multiple commands. The format is as follows.

```
RunCLI -f [script file] -o [log file]
```

("-f" and "-o" are options for specifying input file and output file.)

1. Create a script file. The format and extension of the file can be user-defined, as long as it is written in ASCII text. For example, sample.script can contain the following commands.

```
connect 192.168.1.1  
set ctlr date 20050101 180000 gmt=+8  
set ctlr name ASRStorArray  
show cli
```

2. Enter the CLI installation folder (the following example is for Windows OS).

```
C:\> "C:\Program Files\Infortrend\CLI"
```

3. Execute RUNCLI.exe followed by the file option and script file. You may also specify an output file (sample.log for example).

```
RunCLI -f sample.script -o sample.log
```

4. The CLI will run all commands included in sample.script and outputs the result to sample.log.

2.3 Command Syntax

A command is comprised of three parts: command, parameter(s), and option(s), each separated by a space. In the example below, `create isns` is the command, `[IP-address]` is the parameter, and `[-r] [-y]` are the options.

```
create isns [IP-addresses] [-r] [-y]
```

If you enter real values, the above command should look like this.

```
create isns 192.168.1.1, 192.168.1.2 -r -y
```

The parameters and options work similarly: add context-specific information to the command.

- Parameters are command-specific and might be required or optional.
- Options are common among all commands and are always optional.

2.3.1 Parameter Syntax

In syntax descriptions, parameters are surrounded by square brackets as in `[parameter]`. When you type in the real value, you need to replace the whole part, including the brackets. Here are parameter types and how to enter real values.

<code>[ParA]</code>	<p>A parameter surrounded by a pair of square brackets <code>[]</code> is a required parameter. Example of an entry:</p> <pre>create isns [IP-addresses] → create isns 192.168.1.1</pre> <p>You might not always need to enter the required parameter(s). In such cases, a default value will be chosen automatically. For details, refer to the description of each command.</p>
<code>[ParA={ParA}]</code>	<p>A pair of curly brackets <code>{ }</code> within a pair of square brackets <code>[]</code> show that the parameter is optional. Example of an entry:</p> <pre>scan array [ip={IP address}] → scan array ip=192.168.1.1</pre>
<code>[ParA ParB]</code> <code>[ParA={ParA} ParB={ParB}]</code>	<p>The vertical bar shows that either of the two types of parameters is a valid entry (You cannot enter both). Example of an entry:</p> <pre>connect [[IP]:port hostname] → connect 192.168.1.1 Or connect 2001:f18::50</pre>

2.3.2 Option syntax

Parameters are (mostly) command-specific but options are common for all commands.

In syntax descriptions, options are surrounded by square brackets as in `[- r]`. When you type in the real value, you only have to remove the brackets.

<code>[Option]</code>	<p>An option should be entered after all parameters have been entered.</p> <pre>create isns [IP-addresses] [-r] → create isns 192.168.1.1 -r</pre>
-----------------------	--

2.3.3 Parameter/Option Order

You can change:

- Optional parameters
- Options

You cannot change:

- Required parameters

Note! *The safest practice is to enter the parameters and options in the order shown in the syntax description.*



2.3.4 Case Sensitivity

Commands, parameters, and options are not case-sensitive. Thus, the following examples all work fine.

```
connect 192.168.1.1 index=3 password=123
```

Or

```
Connect 192.168.1.1 Index=3 Password=123
```

Or

```
CONNECT 192.168.1.1 INDEX=3 PASSWORD=123
```

2.3.5 Abbreviation (Short Form)

You may use an abbreviated version (short form) for some commands. For example, the command “delete” can be shortened into “del.”

```
delete logical-drive
```

Can be written as:

```
del logical-drive
```

You may also combine two or more abbreviations if applicable. In the above example, “logical-drive” can also be shortened into “ld.” Therefore, it can become:

```
del ld
```

The short form is noted in each command description when it is available.

Table 2.1: List of short forms

Abbreviation	Example
channel → ch	set channel → set ch
configuration → config	show configuration → show config
controller → ctr	set controller date → set ctr date
delete → del	delete part → del part
logical-drive → ld	create logical-drive → create ld
logical-volume → lv	set logical-volume expand → set lv expand
partition → part	show partition → show part
snapshot-image → si	show snapshot-image → show si
virtual-volume → vv	create virtual-volume → create vv

2.3.6 Using the Filename Parameter as the File Path

The parameter “filename” can include the file path (relative and absolute) and follow CLI conventions. That means, if the path + filename can be recognized in shell mode (Linux shell or Windows DOS mode), it should be also valid and recognizable in CLI.

Upper vs. Lower Case	<ul style="list-style-type: none"> ■ Windows: no difference ■ Linux: different
Relative Path Examples (Linux)	<pre>./filename.ext (= filename.ext) ../filename.ext ../Test/filename.ext Test/filename.ext</pre>
Absolute Path Examples	<p>Linux</p> <pre>/Test/filename.ext /filename.ext</pre> <p>Windows</p> <pre>\Test\filename.ext \filename.ext</pre>
Other Examples	<p>Drive Letter</p> <pre>C:\Test\filename.ext</pre> <p>(Windows) Share folder URL</p> <pre>\\server\share\filename.ext</pre> <p>Path Containing Spaces</p> <p>“Double quote” the directory as follows.</p> <pre>“C:\Program Files\Test\filename.ext” (Windows) “Program Files/Test/filename.ext” (Linux)</pre>

2.4 Return Codes

Here is the list of return codes and their meanings.

Hex value	Return code	Description
0x0000	SYS_SUCCESSFUL	Successful
0x0001	SYS_FAILED	Failed (general)
0x0002	CMD_INCOMPLETE	Incomplete command
0x0003	CMD_NO_REQUIRED_PARM	No required parameter
0x0004	CMD_UNKNOWN_PARAM	Unknown parameter
0x0005	CMD_INVAILOGICAL- DRIVE_PARAM	Invalid parameter (Parameter format error, out-of-range or mistype)
0x0006	CMD_UNKNOWN	Unknown command
0x0007	DEV_NONE	No device
0x0008	DEV_NO_SELECTION	No array for selection (connected)
0x0009	DEV_NOT_CONNECTED	Device not connected
0x000a	DEV_AUTH_FAILED	Authentication failed
0x000b	SYS_NOT_EXIST	System does not exist (no such item)
0x000c	DEV_NOT_SELECTED	No selected device
0x000d	DEV_LOCK_FAILED	Device lock failed
0x000e	SYS_NOT_SUPPORT	Current system not supported
0x000f	SYS_INVALID_STATUS	Invalid status (Source target or destination status incorrect)
0x0010	SYS_IN_PROGRESS	Operation is in progress
0x0011	SYS_USER_ABORTED	User aborted
0x0012	SYS_FILE_OPEN_FAILED	Failed to open a file
0x0013	SYS_INVALID_TARGET	Invalid target (Type or model not compatible)
0x0014	SYS_INVALID_CONFIG	Invalid configuration (Configuration incorrect or operation not allow)
0x0015	SYS_FW_EXCEPTION	Controller firmware (EI) exception
0x0020	APP_INVALID_LICENSE	No valid license key
0x0021	APP_LICENSE_EXPIRED	License expired
0x0022	APP_EXCEED_LICENSE	License limitation exceeded

Chapter 3

Summaries

Click the command name to jump to detailed descriptions.

3.1 Summary of Commands

3.1.1 ! ~ Connect

!	Runs a previously executed command.
?	Provides a simple help for selected commands.
Connect	Connects the RAID controller to the host computer.

3.1.2 Create

Create IQN	Creates an IQN (iSCSI-Qualified Name).
Create iSNS	Creates an iSNS server.
Create Logical Drive	Creates a logical drive.
Create Logical Volume	Creates a logical volume.
Create Map	Maps a partition or snapshot image to a host computer.
Create Partition	Creates a partition in a logical volume.
Create Replication	Creates a replication job and then replicate the data from the source to the target.
Create Schedule	Schedules a task.
Create Snapshot Image	Takes a snapshot image.
Create Trunk	Creates an iSCSI trunk group.
Create WWN	Creates a WWN and associates it with a host.

3.1.3 Delete

Delete Event	Clears the entire event log.
Delete History	Deletes the record of previously executed commands.
Delete IQN	Deletes the configurations of an IQN.
Delete iSNS	Deletes an iSNS server.
Delete Logical Drive	Deletes a logical drive.
Delete Logical Volume	Deletes a logical volume.
Delete Map	Deletes a map.
Delete Partition	Deletes a partition.
Delete Replication	Deletes a replication job.
Delete Schedule	Deletes a task schedule.
Delete SNMPtrap	Deletes an SNMP trap receiver.
Delete Trunk	Deletes a trunk group.
Delete WWN	Deletes a WWN.

3.1.4 Disconnect ~ Select

Disconnect	Closes a CLI session.
Exit	Exits the CLI.
Export Configuration	Exports the system configuration data to a local file.
Export NVRAM	Exports the NVRAM data in the controller to a local file.
Export Support	Exports support information to a local file.
Help	Provides a simple help for selected commands.
Import NVRAM	Imports the NVRAM data to the controller from a local file.
Man	Provides manuals for selected commands.
Mute	Mutes the controller's audible alarm.
Reset Controller	Resets the controller.
Runscript	Runs a command script batch file.
Scan Array	Discovers all drive arrays with in-band and out-of-band connection.
Select	Selects a device.

3.1.5 Set

Set Cache	Configures the write operation (write-back or write-through).
Set Channel	Configures a host or drive channel.
Set Controller Date	Configures the controller's date, time, and time zone.
Set Controller Default	Restores the NVRAM of the controller to factory setting.
Set Controller Name	Specifies the controller's name.
Set Controller Parameter	Configures the controller parameters.
Set Controller Trigger	Configures the controller to trigger an action when an event occurs.
Set Controller Uid	Specifies the identifier of the controller.
Set Device Flash	Toggles the service LED of the controller.
Set Disk Clear	Removes the reserved space of a disk.
Set Disk Clone	Clones a hard drive.
Set Disk Copy	Copies the content of a disk to another disk.
Set Disk Flash	Flashes a disk's LED to help identify it.
Set Disk Parameter	Configures disk parameters.
Set Disk Read-Write Test	Tests the read/write capability of a disk.
Set Disk Saving	Configures the power saving mode for disks.
Set Disk Scan	Scans the disks.
Set Disk SMART Test	Sets disk to perform SMART self-test.
Set Disk Spare	Configures spare disks.
Set History	Defines the size of the command history buffer.
Set Host	Configures the host controller.
Set IQN	Configures an IQN (iSCSI initiator).
Set Log	Enables or disables logging commands into a file.
Set Logical Drive	Configures a logical drive.
Set Logical Drive Add	Adds disks to a logical drive.
Set Logical Drive Expand	Expands a logical drive.
Set Logical Drive Migrate	Migrates a logical drive to a different RAID level.

Set Logical Drive Parity	Configures the parity of a logical drive.
Set Logical Drive Rebuild	Rebuilds a logical drive.
Set Logical Drive Saving	Configures the power saving mode for a logical drive.
Set Logical Drive Scan	Scans a logical drive for bad blocks.
Set Logical Drive Shutdown	Shuts down a logical drive.
Set Logical Drive Undelete	Recovers (undeletes) a deleted logical drive.
Set Logical Volume	Configures a logical volume.
Set Logical Volume Expand	Expands the capacity of a logical volume.
Set Logical Volume Threshold	Configures the space threshold of a logical volume.
Set Net	Configures the system network interface for out-of-band management or iSCSI data channels.
Set Partition	Configures a partition.
Set Password	Specifies the controller password.
Set RS232	Configures the RS-232 interface.
Set Session	Switches the current operation environment to another session.
Set Task	Aborts tasks in progress.

3.1.6 Show

Show Access Mode	Shows the management interface: FC/SCSI channels (in-band) or Ethernet (out-of-band).
Show Array	Shows the connected drive arrays.
Show Cache	Shows the cache write policy of the controller.
Show Channel	Shows the configurations of host and drive channels.
Show CLI	Shows the CLI configurations.
Show Configuration	Shows the entire system configurations.
Show Controller	Shows the controller configurations.
Show Controller Date	Shows the time, date, and time zone of the controller.
Show Controller Parameter	Shows the controller parameters.
Show Controller Redundancy	Shows if the redundant controllers are working properly.
Show Controller Trigger	Shows the event trigger configuration of the controller.
Show Controller Uid	Shows the controller unique identifier.
Show Device	Shows the list of devices (RAID controllers and JBODs).
Show Diagnostic	Shows the result of network diagnostic for remote replication pairs.
Show Disk	Shows the list of disk drives.
Show Disk Parameter	Shows the disk parameters.
Show Disk Saving	Shows the power-saving mode status of disk drives.
Show Disk SMART	Shows the disk SMART information.
Show Disk Spare	Shows the list of spare disks.
Show Enclosure	Shows the enclosure configuration.
Show Event	Shows the past events.
Show History	Shows past executed commands.
Show Host	Shows the host computer configurations.
Show IQN	Shows the configurations of iSCSI initiator IQNs.
Show iSNS	Shows the configurations of iSNS servers.
Show License	Shows the license status of the system.
Show Logical Drive	Shows the list of logical drives.

Show Logical Drive Deleted	Shows the list of deleted (but recoverable) logical drives.
Show Logical Drive Saving	Shows the power saving status of logical drives.
Show Logical Volume	Shows the configurations of logical volumes.
Show Map	Shows all existing host mappings.
Show Net	Shows the configurations of a RAID interface.
Show Partition	Shows the configurations of partitions.
Show Partition Purge	Shows the purge rules of partitions.
Show RS232	Shows the configurations of the RS232 interface.
Show Schedule	Lists scheduled tasks.
Show Shutdown Status	Shows the progress of shutdown operation.
Show SNMPtrap	Shows configurations of the SNMP trap service.
Show Statistics	Shows status and performance of hardware components.
Show Stripe	Shows the stripe block size for a RAID level.
Show Task	Shows all tasks in progress.
Show Trunk	Shows the list of trunk groups.
Show WWN	Shows the list of WWNs.

3.1.7 Shutdown ~ Update

Shutdown Controller	Shuts the RAID controller down and stops I/O processing.
Update Firmware	Updates the controller firmware.
Update Firmware and Boot Record	Updates the controller firmware and boot record.

3.2 Summary of ASR-5300I Commands

3.2.1 ! ~ Connect

!	Runs a previously executed command.
?	Provides a simple help for selected commands.
Connect	Connects the RAID controller to the host computer.

3.2.2 Create

Create IQN	Creates an IQN (iSCSI-Qualified Name).
Create iSNS	Creates an iSNS server.
Create Logical Drive	Creates a logical drive.
Create Logical Volume	Creates a logical volume.
Create Map	Maps a partition or snapshot image to a host computer.
Create Partition	Creates a partition in a logical volume.
Create Replication	Creates a replication job and then replicate the data from the source to the target.
Create Schedule	Schedules a task.
Create SED Keyfile	Creates a new key file with random password for Self Encrypting Drives (SED).
Create Snapshot Image	
Takes a snapshot image.	
Create SNMPtrap	Creates an SNMP trap receiver.
Create Trunk	Creates an iSCSI trunk group.
Create WWN	Creates a WWN and associates it with a host.

3.2.3 Delete

Delete Event	Clears the entire event log.
Delete History	Deletes the record of previously executed commands.
Delete IQN	Deletes the configurations of an IQN.
Delete iSNS	Deletes an iSNS server.
Delete Logical Drive	Deletes a logical drive.
Delete Logical Volume	Deletes a logical volume.
Delete Map	Deletes (unmaps) a partition or snapshot image.
Delete Partition	Deletes a partition.
Delete Replication	Deletes a replication job.
Delete Schedule	Deletes a task schedule.
Delete Snapshot Image	Deletes a snapshot image.
Delete SNMPtrap	Deletes an SNMP trap receiver.
Delete Trunk	Deletes a trunk group.
Delete WWN	Deletes a WWN.

3.2.4 Disconnect ~ Select

Disconnect	Closes a CLI session.
Exit	Exits the CLI.
Export Configuration	Exports the system configuration data to a local file.
Export NVRAM	Exports the NVRAM data in the controller to a local file.
Help	Provides a simple help for selected commands.
Import NVRAM	Imports the NVRAM data to the controller from a local file.
Man	Provides manuals for selected commands.
Mute	Mutes the controller's audible alarm.
Reset Controller	Resets the controller.
Runscript	Runs a command script batch file.
Scan Array	Discovers all drive arrays with in-band and out-of-band connection.
Select	Selects a device.

3.2.5 Set

Set Cache	Configures the write operation (write-back or write-through).
Set Channel	Configures a host or drive channel.
Set Controller Date	Configures the controller's date, time, and time zone.
Set Controller Default	Restores the NVRAM of the controller to factory setting.
Set Controller Name	Specifies the controller's name.
Set Controller Parameter	Configures the controller parameters.
Set Controller Trigger	Configures the controller to trigger an action when an event occurs.
Set Controller Uid	Specifies the identifier of the controller.
Set Device Flash	Toggles the service LED of the controller.
Set Disk Clear	Removes the reserved space of a disk.
Set Disk Clone	Clones a hard drive.
Set Disk Copy	Copies the content of a disk to another disk.
Set Disk Flash	Flashes a disk's LED to help identify it.
Set Disk Parameter	Configures disk parameters.
Set Disk Read-Write Test	Tests the read/write capability of a disk.
Set Disk Saving	Configures the power saving mode for disks.
Set Disk Scan	Scans the disks.
Set Disk SMART Test	Sets disk to perform SMART self-test.
Set Disk Spare	Configures spare disks.
Set History	Defines the size of the command history buffer.
Set Host	Configures the host controller.
Set IQN	Configures an IQN (iSCSI initiator).
Set Log	Enables or disables logging commands into a file.
Set Logical Drive	Configures a logical drive.
Set Logical Drive Add	Adds disks to a logical drive.
Set Logical Drive Expand	Expands a logical drive.
Set Logical Drive Migrate	Migrates a logical drive to a different RAID level.
Set Logical Drive Parity	Configures the parity of a logical drive.

Set Logical Drive Rebuild	Rebuilds a logical drive.
Set Logical Drive Saving	Configures the power saving mode for a logical drive.
Set Logical Drive Scan	Scans a logical drive for bad blocks.
Set Logical Drive SED Disable	Disable the SED function for the specified logical drive(s).
Set Logical Drive SED Enable	Enable the SED function for the specified logical drive(s).
Set Logical Drive SED Unlock	Unlock specified logical drive(s) lock status.
Set Logical Drive Shutdown	Shuts down a logical drive.
Set Logical Drive Undelete	Recovers (undeletes) a deleted logical drive.
Set Logical Volume	Configures a logical volume.
Set Logical Volume Expand	Expands the capacity of a logical volume.
Set Logical Volume Multi-Tier	Enables the multi-tiering function of a logical volume.
Set Logical Volume Threshold	Configures the space threshold of a logical volume.
Set Logical Volume Tier-Enable	Enables the tiering function of a logical volume.
Set Logical Volume Tier-Migrate	Executes data tier migration.
Set Logical Volume Tier-Disable	Disables the tiering function of a logical volume.
Set Net	Configures the system network interface for out-of-band management or iSCSI data channels.
Set Partition	Configures a partition.
Set Partition Expand	Expands the capacity of a partition.
Set Partition Purge	Configures the purge rule of a partition.
Set Partition Reclaim	Reclaims the space for a partition.
Set Password	Specifies the controller password.
Set Replication	Configures a replication job.
Set RS232	Configures the RS-232 interface.
Set SED Erase	Set to quick erase the specified SED disk.
Set SED Password	Set or change the SED password (A-Key).
Set SSD-Cache Add	Adds one or a list of SSD disks to the SSD cache pool.
Set SSD-Cache Remove	Removes one or a list of member disks from the SSD cache pool.
Set SSD-Cache SED Disable	Disables the SED function for SSD cache pool.
Set SSD-Cache SED Enable	Enables the SED function for SSD cache pool.
Set SSD-Cache SED Unlock	Unlock the SED function for SSD cache pool.
Set SSD-Cache Service	Toggle SSD cache pool function (enable / disable)
Set Session	Switches the current operation environment to another session.
Set Snapshot Image	Configures a snapshot image.
Set Snapshot Image Rollback	Recovers (rolls back) a snapshot image.
Set SNMPtrap	Configures the SNMP trap service.
Set Task	Aborts tasks in progress.

3.2.6 Show

Show Access Mode	Shows the management interface: FC/SCSI channels (in-band) or Ethernet (out-of-band).
Show Array	Shows the connected drive arrays.
Show Cache	Shows the cache write policy of the controller.
Show Channel	Shows the configurations of host and drive channels.
Show CLI	Shows the CLI configurations.
Show Configuration	Shows the entire system configurations.
Show Controller	Shows the controller configurations.
Show Controller Date	Shows the time, date, and time zone of the controller.
Show Controller Parameter	Shows the controller parameters.
Show Controller Redundancy	Shows if the redundant controllers are working properly.
Show Controller Trigger	Shows the event trigger configuration of the controller.
Show Controller Uid	Shows the controller unique identifier.
Show Device	Shows the list of devices (RAID controllers and JBODs).
Show Diagnostic	Shows the result of network diagnosis for remote replication pairs.
Show Disk	Shows the list of disk drives.
Show Disk Parameter	Shows the disk parameters.
Show Disk Saving	Shows the power-saving mode status of disk drives.
Show Disk SMART	Shows the disk SMART information.
Show Disk Spare	Shows the list of spare disks.
Show Enclosure	Shows the enclosure configuration.
Show Event	Shows the past events.
Show History	Shows past executed commands.
Show Host	Shows the host computer configurations.
Show IQN	Shows the configurations of iSCSI initiator IQNs.
Show iSNS	Shows the configurations of iSNS servers.
Show License	Shows the license status of the system.
Show Logical Drive	Shows the list of logical drives.
Show Logical Drive Deleted	Shows the list of deleted (but recoverable) logical drives.
Show Logical Drive Saving	Shows the power saving status of logical drives.
Show Logical Volume	Shows the configurations of logical volumes.
Show Logical Volume Logical Drive	Shows the configurations of logical drives inside the logical volume.
Show Logical Volume Threshold	Shows the space thresholds of logical volumes.
Show Logical Volume Tier	Shows tiering information of logical volumes.
Show Map	Shows host mappings of partitions or channels.
Show Net	Shows the configurations of a RAID interface.
Show Partition	Shows the configurations of partitions.
Show Partition Purge	Shows the purge rules of partitions.
Show Replication	Shows the configurations of replication jobs.
Show RS232	Shows the configurations of the RS232 interface.
Show Schedule	Lists scheduled tasks.
Show Shutdown Status	Shows the progress of shutdown operation.
Show Snapshot Image	Shows configurations of snapshots.
Show SNMPtrap	Shows configurations of the SNMP trap service.
Show SSD-Cache	Show member disks of SSD cache pool.

Show Statistics	Shows status and performance of hardware components.
Show Stripe	Shows the stripe block size for a RAID level.
Show Task	Shows all tasks in progress.
Show Trunk	Shows the list of trunk groups.
Show WWN	Shows the list of WWNs.

3.2.7 Shutdown ~ Update

Shutdown Controller	Shuts the RAID controller down and stops I/O processing.
Update Firmware	Updates the controller firmware.
Update Firmware and Boot Record	Updates the controller firmware and boot record.

3.3 Summary of Commands by Functionalities

3.3.1 System Commands > Basic Commands

Command	Description	ASR-5300I
!	Runs a previously executed command.	√
?	Provides a simple help for selected commands.	√
Connect	Connects to the controller.	√
Disconnect	Closes a CLI session.	√
Exit	Exits the CLI.	√
Help	Provides a simple help for selected commands.	√
Man	Provides manuals for selected commands.	√
Runscript	Runs a command script batch file.	√
Scan Array	Discovers all drive arrays with in-band and out-of-band connection.	√
Select	Selects a device.	√
Set Device Flash	Toggles the service LED of the controller.	√
Set Session	Switches the current operation environment to another session.	√
Show Array	Shows the connected drive arrays.	√
Show CLI	Shows the CLI configurations.	√
Show Device	Shows the list of devices (RAID controllers and JBODs).	√

3.3.2 System Commands > Network Commands

Command	Description	ASR-5300I
Set Net	Configures the system network interface for out-of-band management or iSCSI data channels.	√
Set RS232	Configures the RS-232 interface.	√
Show Net	Shows the management interface: FC/SCSI channels (in-band) or Ethernet (out-of-band).	√
Show Configuration	Shows the configurations of a RAID interface.	√
Show RS232	Shows the configurations of the RS232 interface.	√

3.3.3 System Commands > Component Commands

Command	Description	ASR-5300I
Show Enclosure	Shows the enclosure configuration.	√

3.3.4 System Commands > Configuration Commands

Command	Description	ASR-5300I
Export Configuration	Exports the system configuration data to a local file.	√
Export NVRAM	Exports the NVRAM data in the controller to a local file.	√
Export Support	Exports system support information to a local file.	√
Import NVRAM	Imports the NVRAM data to the controller from a local file.	√
Show Configuration	Shows the entire system configurations.	√

3.3.5 System Commands > Log and Event Commands

Command	Description	ASR-5300I
!	Runs a previously executed command.	√
Delete Event	Clears the entire event log.	√
Delete History	Deletes the record of previously executed commands.	√
Set History	Defines the size of the command history buffer.	√
Set Log	Enables or disables logging commands into a file.	√
Show Event	Shows the past events.	√
Show History	Shows past executed commands.	√
Show Statistics	Shows status and performance of hardware components.	√

3.3.6 Controller and Disk Commands > Controller Commands

Command	Description	ASR-5300I
Delete Schedule	Deletes a task schedule.	√
Mute	Mutes the controller's audible alarm.	√
Reset Controller	Resets the controller.	√
Set Cache	Configures the write operation (write-back or write-through).	√
Set Controller Date	Configures the controller's date, time, and time zone.	√
Set Controller Default	Restores the NVRAM of the controller to factory setting.	√
Set Controller Name	Specifies the controller's name.	√
Set Controller Parameter	Configures the controller parameters.	√
Set Controller Trigger	Configures the controller to trigger an action when an event occurs.	√
Set Controller Uid	Specifies the identifier of the controller.	√
Set Password	Specifies the controller password.	√
Set Task	Aborts tasks in progress.	√
Show Cache	Shows the cache write policy of the controller.	√
Show Controller	Shows the controller configurations.	√
Show Controller Date	Shows the time, date, and time zone of the controller.	√
Show Controller Parameter	Shows the controller parameters.	√
Show Controller Redundancy	Shows if the redundant controllers are working properly.	√
Show Controller Trigger	Shows the event trigger configuration of the controller.	√
Show Controller Uid	Shows the controller unique identifier.	√
Show Schedule	Lists scheduled tasks.	√
Show Shutdown Status	Shows the progress of shutdown operation.	√
Show Task	Shows all tasks in progress.	√
Shutdown Controller	Shuts the RAID controller down and stops I/O processing.	√

3.3.7 Controller and Disk Commands > Disk Commands

Command	Description	ASR-5300I
Set Disk Clear	Removes the reserved space of a disk.	√
Set Disk Clone	Clones a hard drive.	√
Set Disk Copy	Copies the content of a disk to another disk.	√
Set Disk Flash	Flashes a disk's LED to help identify it.	√
Set Disk Parameter	Configures disk parameters.	√
Set Disk Read-Write Test	Tests the read/write capability of a disk.	√
Set Disk Saving	Configures the power saving mode for disks.	√
Set Disk Scan	Scans the disks.	√
Set Disk SMART Test	Sets disk to perform SMART self-test.	√
Set Disk Spare	Configures spare disks.	√
Show Disk	Shows the list of disk drives.	√
Show Disk Parameter	Shows the disk parameters.	√
Show Disk Saving	Shows the power-saving mode status of disk drives.	√
Show Disk SMART	Shows the disk SMART information.	√
Show Disk Spare	Shows the list of spare disks.	√

3.3.8 Channel Commands

Command	Description	ASR-5300I
Set Channel	Configures a host or drive channel.	√
Show Channel	Shows the configurations of host and drive channels.	√

3.3.9 Logical Drive Commands

Command	Description	ASR-5300I
Create Logical Drive	Creates a logical drive.	√
Delete Logical Drive	Deletes a logical drive.	√
Set Logical Drive	Configures a logical drive.	√
Set Logical Drive Add	Adds disks to a logical drive.	√
Set Logical Drive Expand	Expands a logical drive.	√
Set Logical Drive Migrate	Migrates a logical drive to a different RAID level.	√
Set Logical Drive Parity	Configures the parity of a logical drive.	√
Set Logical Drive Rebuild	Rebuillogical-drives a logical drive.	√
Set Logical Drive Saving	Configures the power saving mode for a logical drive.	√
Set Logical Drive Scan	Scans a logical drive for bad blocks.	√
Set Logical Drive Shutdown	Shuts down a logical drive.	√
Set Logical Drive Undelete	Recovers (undeletes) a deleted logical drive.	√
Show Logical Drive	Shows the list of logical drives.	√
Show Logical Drive Deleted	Shows the list of deleted (but recoverable) logical drives.	√
Show Logical Drive Saving	Shows the power saving status of logical drives.	√
Show Stripe	Shows the stripe block size for a RAID level.	√

3.3.10 Logical Volume and Partition Commands > Logical Volume Commands

Command	Description	ASR-5300I
Create Logical Volume	Creates a logical volume.	√
Delete Logical Volume	Deletes a logical volume.	√
Set Logical Volume	Configures a logical volume.	√
Set Logical Volume Expand	Expands the capacity of a logical volume.	√
Set Logical Volume Threshold	Configures the space threshold of a logical volume.	√
Show Logical Volume	Shows the configurations of logical volumes.	√
Show Logical Volume Logical Drive	Shows the configurations of logical drives inside logical volumes.	√
Show Logical Volume Threshold	Shows the space thresholds of logical volumes.	√

3.3.11 Logical Volume and Partition Commands > Partition Commands

Command	Description	ASR-5300I
Create Partition	Creates a partition in a logical drive.	√
Delete Partition	Deletes a partition.	√
Set Partition	Configures a partition.	√
Set Partition Expand	Expands the capacity of a partition.	√
Set Partition Purge	Configures the purge rule of a partition.	√
Set Partition Reclaim	Reclaims the space for a partition.	√
Show Partition	Shows the configurations of partitions.	√
Show Partition Purge	Shows the purge rules of partitions.	√

3.3.12 Host Commands

Command	Description	ASR-5300I
Create IQN	Creates an IQN (iSCSI-Qualified Name).	√
Create Map	Maps a partition or snapshot image to a host computer.	√
Create WWN	Creates a WWN and associates it with a host.	√
Delete IQN	Deletes the configurations of an IQN.	√
Delete Map	Deletes (un-maps) a partition or a snapshot image.	√
Delete WWN	Deletes a WWN.	√
Set Host	Configures the host controller.	√
Set IQN	Configures an IQN (iSCSI initiator).	√
Show Host	Shows the host computer configurations.	√
Show IQN	Shows the configurations of iSCSI initiator IQNs.	√
Show Map	Shows host mappings of partitions or channels.	√
Show WWN	Shows the list of WWNs.	√

3.3.13 iSCSI Commands

Command	Description	ASR-5300I
Create iSNS	Creates an iSNS server.	√
Create Trunk	Creates an iSCSI trunk group.	√
Delete iSNS	Deletes an iSNS server.	√
Delete Trunk	Deletes a trunk group.	√
Show iSNS	Shows the configurations of iSNS servers.	√
Show Trunk	Shows the list of trunk groups.	√

3.3.14 Firmware Download Commands

Command	Description	ASR-5300I
Update Firmware	Updates the controller firmware.	√
Update Firmware and Boot Record	Updates the controller firmware and boot record.	√

3.3.15 Application Commands > Snapshot Commands

Command	Description	ASR-5300I
Create Snapshot Image	Takes a snapshot image.	√
Delete Snapshot Image	Deletes a snapshot image.	√
Set Snapshot Image	Configures a snapshot image.	√
Set Snapshot Image Rollback	Recovers (rolls back) a snapshot image.	√
Show License	Shows the license status of the system.	√
Show Snapshot Image	Shows configurations of snapshots.	√

3.3.16 Application Commands > Replication Commands

Command	Description	ASR-5300I
Create Replication	Creates a replication job.	√
Delete Replication	Deletes a replication job.	√
Set Replication	Configures a replication job.	√
Show Diagnostic	Shows the result of network diagnosis for remote replication pairs.	√
Show Replication	Shows the configurations of replication jobs.	√

3.3.17 Application Commands > Agent Function Commands

Command	Description	ASR-5300I
Create SNMPtrap	Creates an SNMP trap receiver.	√
Delete SNMPtrap	Deletes an SNMP trap receiver.	√
Set SNMPtrap	Configures the SNMP trap service.	√
Show SNMPtrap	Shows configurations of the SNMP trap service.	√

Chapter 4

Descriptions

This chapter describes each command: syntax, parameters, and options. For overview of the Command Line Interface and syntax rules, refer to the previous chapter.

4.1 Descriptions of Commands

Commands are listed in alphabetical order. The following section shows the summary of commands and options.

- Summary of Commands by Functionalities
- Summary of Commands in Alphabetical Order
- Summary of Options

4.1.1 !

Runs a previously executed command.

Applicable to	ASR-5300I
Syntax	! [index]
Parameters	index Specifies a previously executed command by its index. If not specified, the last executed command will be selected.

Note! You can view the index of previously executed commands by using *show history*.



4.1.2 ?

Provides a simple help for selected commands.

Applicable to	ASR-5300I
Syntax	? [command] / help [command]
Parameters	command Specifies the command. If no parameter is specified, basic usage information will be displayed.

Note! ■ Allows hierarchical help for complex commands such as *help show*, *help set*, etc.)



■ This command is the same as *Help*.

4.1.3 Connect

Connects the RAID controller to the host computer.

Applicable to	ASR-5300I
Syntax	<code>connect [[IP]:port hostname] [index={device-index} uid={ID}] [password={secret}]</code>
Parameters	<p><code>[IP]:port hostname</code> Specifies the host computer by its IP address or host name. If not specified, the local host and the default port will be selected. Supports IPv6 addresses. Example: <code>connect 192.168.1.1</code> <code>connect 192.168.1.1:12345</code> <code>connect 2001:f18::50</code> <code>connect [2001:f18::50]:12345</code></p> <hr/> <p><code>index={device-index}</code> Specifies the RAID controller by its array index. If not specified: <ul style="list-style-type: none"> ■ There is only one array: it will be selected automatically ■ More than one array exists: the list of array appears. Example: <code>connect 192.168.1.1 index=3</code></p> <hr/> <p><code>password={secret}</code> Enters the password. If not specified, a prompt will ask you to provide a password. Example: <code>connect 192.168.1.1 index=3 password=123</code> (Connects to the first in-band array of IP 192.168.1.1)</p> <hr/> <p><code>uid={ID}</code> Specifies the RAID controller by its ID. Example: <code>connect 192.168.1.1 uid=12345</code></p>

Note!  You can connect several controllers at the same time by executing this command repeatedly. One connection will create one session, and it also allows you to switch between multiple sessions to execute further commands.

4.1.4 Create IQN

Creates an IQN (iSCSI-Qualified Name).

Applicable to	ASR-5300I
Syntax	<pre>create iqn [IQN] [IQN-alias-name] [user={user-name}] [password={secret}] [target={name}] [target-password={secret}] [ip={ip-address}] [mask={netmask-ip}]</pre>
Parameters	<p><code>group={group-names}</code> Specifies the group for host ID grouping. Example: <pre>create iqn iqn.2006-05.com.Infortrend.storage:hba1 host1 group=G1,G2</pre></p> <p><code>ip={ip-address}</code> Specifies the IP address of the iSCSI initiator. IQN Specifies the IQN (iSCSI-Qualified Name). IQN-alias-name Specifies the IQN alias name. Example: <pre>create iqn iqn.2006-05.com.Infortrend.storage:hba1 host1</pre></p> <p><code>mask={netmask-ip}</code> Specifies the net mask of the iSCSI initiator. Example: <pre>create iqn iqn.2006-05.com.Infortrend.storage:hba1 host1 user=account password=password target=target_account target-password=password ip=192.168.1.1 mask=255.255.255.0</pre></p> <p><code>password={secret}</code> Enters the password for CHAP authentication. Entering this parameter means you have chosen CHAP as the method for iSCSI authentication. (If you want to disable CHAP authentication, enter an empty string.) Example: <pre>create iqn iqn.2006-05.com.Infortrend.storage:hba1 host1 user=account password=password</pre></p> <p><code>target={username}</code> Enters the target user name for CHAP authentication.</p> <p><code>target-password={secret}</code> Enters the target password for CHAP authentication. Entering this parameter means you have chosen CHAP as the method for iSCSI authentication.</p> <p><code>user={username}</code> Enters the user name for CHAP authentication.</p>

Note! You can view the index of previously executed commands by using *show history*.



4.1.5 Create iSNS

Creates an iSNS server.

Applicable to	ASR-5300I
Syntax	<code>create isns [IP-addresses] [-r] [-y]</code>
Parameters	<p>IP-addresses</p> <p>Specifies the IP addresses of the iSNS server(s). Multiple addresses should be separated by commas.</p> <p>Example:</p> <pre>create isns 192.168.1.1, 192.168.1.2</pre>
Options	<p><code>-r</code></p> <p>Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller.</p> <p>Example:</p> <pre>create isns 192.168.1.1, 192.168.1.2 -r</pre> <p><code>-y</code></p> <p>Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n.)</p>

Note! *This command is for iSCSI subsystems only.*



4.1.6 Create Logical Drive

Creates a logical drive.

Applicable to	ASR-5300I
Syntax	<pre>create logical-drive [RAID-level] [disk-list] [assign={assign-to}] [size={allocated-disk-capacity}] [stripe={stripe-size}] [mode={value}] [name={LD-alias-name}] [write={write-policy}] Short form: create ld</pre>
Parameters	<p>assign={assign-to} Specifies the RAID controller to which the logical drives are assigned. Value: slotA (default), slotB. If not specified, controller A will be chosen (firmware v3.47 or before) or a controller will be dynamically chosen (firmware v3.51 or later).</p> <hr/> <p>disk-list Specifies the disks used in the RAID set. Each item is separated by a comma.</p> <hr/> <p>mode={value} Specifies the initialization mode. Value: online (default), offline. Example: <pre>create ld r0 assign=slotA 0,1 size=10000 stripe=128 mode=online</pre> (Creates a logical drive of RAID level 0 with physical disk 0 and 1; online mode assigned to controller A with 10GB [10000MB] per disk allocated.)</p> <hr/> <p>name={LD-alias-name} Specifies the logical drive's name. The max length is 32 characters.</p> <hr/> <p>RAID-level Specifies the RAID level of the logical drive. Value: nr (Non-RAID), r0 (RAID 0), r1 (RAID 1), r3 (RAID 3), r5 (RAID 5), r6 (RAID 6, supported in firmware v3.47 or later) Example: <pre>create ld r5 0,1,2</pre> (Creates a logical drive of RAID level 5 with physical disk 0-2 assigned to controller A)</p> <hr/> <p>size={allocated-disk-capacity} Specifies the capacity allocated for each disk, for both RAID and JBOD. If not specified, the maximum size will be allocated. The size should be specified by numbers followed by MB or GB. Example: <pre>create ld r5 2,3,4 assign=slotB size=36GB</pre> (Creates a logical drive of RAID level 5 with physical disk 2, 3, 4 assigned to controller B with 36GB allocated per disk.)</p> <hr/> <p>stripe={stripe-size} Specifies the stripe block size in KB. Value: 4, 8, 16, 32, 64, 128, 256, 512, 1024. Some values may not be available; use show stripe to see the list of available sizes. If not specified, the default optimization value will be used.</p> <hr/> <p>write={write-policy} Specifies the cache write policy for the logical drive. Value: default (applies the system default policy), write-back, write-through. Example: <pre>create ld r1 2,3 size=100 name=Test-LD write=write-back</pre> (Creates a logical drive of RAID level 1 with physical disk 2 and 3 allocated 100MB per disk; specified the name and write policy)</p>

4.1.7 Create Logical Volume

Creates a logical volume.

Applicable to	ASR-5300I
Syntax	<pre>create logical-volume [LD-index-list] [name] [assign={assign-to}] [write={write-policy}] Short form: create lv</pre>
Parameters	<p><code>assign={assign-to}</code> Specifies the controller to which the logical volume belongs. Value: slotA (default), slotB.</p> <hr/> <p><code>LD-index-list</code> Specifies the logical drives by their indexes. Each item should be separated by a comma.</p> <hr/> <p><code>name</code> Specifies the name of the logical volume. Example: create lv 0 LV-1</p> <hr/> <p><code>raid={RAID-level}</code> Specifies the RAID level of the logical volume. Value: r0 (RAID 0, default), r1 Example: create lv 0,1 assign=slotB write=default raid=r0</p> <hr/> <p><code>write={write-policy}</code> Specifies the data writing policy. Value: default (applies the system policy), write-back, write-through. Example: create lv 0,1 LV-3 write=write-through assign=slotb</p>

4.1.8 Create Map

Maps a partition or snapshot image to a host computer.

Applicable to	ASR-5300I
Syntax	<pre>create map [part] [partition-ID] [Channel-ID] [Target-ID] [LUN-ID] [assign={assign-to}] (Extended LUN mapping) create map [si] [snapshot-image-ID] [Channel-ID] [Target-ID] [LUN-ID] (Advanced LUN mapping) create map [part] [partition-ID] [Channel-ID] [Target-ID] [LUN-number] [assign={assign-to}] [wwn={host-wwn} iqn={initiator-iqn} host={alias-name}] [mask={wwn-mask}] [type={fil- ter-type}] [mode={access-mode}] [name={filter- name}]</pre>
Parameters	<p><code>assign={assign-to}</code> Specifies the controller to which the mapping will be done. If not specified, the controller will be assigned automatically. Value: slotA, slotB</p> <p><code>bootable={switch}</code> Specifies the volume bootable option. Value: disable (default), enable. This parameter is for extended LUN functionality.</p> <p><code>Channel-ID</code> Specifies the host channel ID.</p> <p><code>group={group-name}</code> Specifies the LUN group name. Example: <pre>create map vv 0000000000010104 0 112 1 group=Host1</pre></p> <p><code>host={alias-name}</code> Specifies the host alias name.</p> <p><code>index</code> Specifies the index of the logical drive or logical volume.</p>

Parameters	<p><code>iqn={initiator-iqn}</code> Specifies the inspector IQN. This parameter is for iSCSI models only. Example: <code>create map lv 1 1 113 0 iqn=iqn.2006-05.com.Infortrend.storage:hba1 mode=read-only</code></p> <hr/> <p><code>ld lv</code> Specifies whether to show a map of logical drive or logical volume.</p> <hr/> <p><code>LUN-ID</code> Specifies a host channel LUN ID (It should be a LUN set ID; the actual LUN number will be assigned automatically). Example: <code>create map part 0000000000010103 1 113 2</code></p> <hr/> <p><code>LUN-number</code> Specifies a host channel LUN number.</p> <hr/> <p><code>mask={wwn-mask}</code> Specifies the WWN mask in hexadecimal string. The default is FFFFFFFFFFFFFFFF. (This option is not support for iSCSI models)</p> <hr/> <p><code>mode={access-mode}</code> Specifies the access mode of the mapped LUN. Value: read-write (default), read-only</p> <hr/> <p><code>name={filter-name}</code> Specifies the filter name.</p> <p><code>part={index}</code> Specifies the partition of the logical drive or logical volume by its index. Example: <code>create map ld 0 0 112 0 assign=ctlrB part=1</code></p> <hr/> <p><code>[part] [partition-ID]</code> Specifies a partition. Example: <code>create map part 0000000000010101</code></p> <hr/> <p><code>priority={level}</code> Specifies the host I/O priority. Value: low, normal (default), high. This parameter is for extended LUN functionality. Example: <code>create map vv 0000000000010102 0 112 1 wwn=210000E08B0AADE1 iqn=iqn.2006-05.com.Infortrend.storage:hba1 bootable=enable priority=high</code></p> <hr/> <p><code>[si] [snapshot-image-ID]</code> Specifies a snapshot image ID.</p> <hr/> <p><code>Target-ID</code> Specifies the host channel target ID. Value: 0 to 126.</p> <hr/> <p><code>type={filter-type}</code> Specifies the filter type. Value: include (default), exclude. Example: <code>create map lv 1 1 113 0 wwn=210000E08B0AADE1 type=include mode=read-only</code></p> <hr/> <p><code>[vv] [virtual-volume-ID]</code> Specifies the virtual volume.</p> <hr/> <p><code>wwn={host-wwn}</code> Specifies the host WWN in hex string format. This parameter is not supported in iSCSI models.</p>
------------	--

Note!  If you ignore the parameters (Channel-ID, Target-ID and LUN-ID), the command will map the volume with default mappings; Creates mapping on each channel and assigns a Target-ID & LUN-ID automatically.

4.1.9 Create Partition

Creates a partition in a logical volume.

Applicable to	ASR-5300I
Syntax	<pre>create partition [LV-ID] [name] [size={partition-size}] [min={minimal-reserve-size}] [init={switch}] [tier={tier-level-list}]</pre> <p>Short form: <code>create part</code></p>
Parameters	<p><code>tier={tier-level-list}</code> Specify the tier level list, the tier list must be the logical volume configured tier. Valid values: 0,1,2,3. If not specified, partition created would reside at all logical volume configured tiers. NOTE: This parameter is only valid when tiering function of the logical volume has been enabled and configured.</p> <hr/> <p><code>init={switch}</code> Initialize (pre-allocate) the partition after creation to support media editing. This parameter could only be applied when the partition is created in full provisioning. Value: enable (default), disable. Example: <code>create part 000000000000000002 P4 size=20GB init=disable</code></p> <hr/> <p><code>ld lv</code> Specifies the logical drive or logical volume.</p> <hr/> <p><code>LV-ID</code> Specifies the logical volume by its ID.</p> <hr/> <p><code>min={minimal-reserve-size}</code> Specifies the minimum size for the logical volume capacity reserve for the created thin-provisioning partition in MB (default). If not specified, the size will be equal to that of the partition (full provisioning). Example: <code>create part 000000000000000002 P3 size=20GB min=10GB</code></p> <hr/> <p><code>name</code> Specifies the partition's name. Example: <code>create part 000000000000000001 P1</code></p> <hr/> <p><code>name={Alias-name}</code> Specifies the name of the partition. Example: <code>create part ld 1 5GB part=2 name=Part#1</code></p> <hr/> <p><code>part={index}</code> Specifies the partition. If not specified, the new partition would be divided from the whole LD, LV or partition index 0.</p>

Parameters	<code>size</code> Specifies the partition size in MB. Example: <code>create part lv 0 36GB</code>
	<code>size={volume-size}</code> Specifies the partition's size in MB (default) or GB. If not specified, the maximum available capacity in the logical volume will be assigned. Example: <code>create part 000000000000000002 P2 size=20GB</code>

Note! *The maximum reserve size is the current logical volume size.*



4.1.10 Create Replication

Creates a replication job and then replicate the data from the source to the target.

For detailed procedure of creating a remote replication pair for ASR-5300I subsystems, see the Appendix section.

Applicable to	ASR-5300I
Syntax	<pre>create replica [name] [part si] [source-volume-ID] [part] [target-volume-ID] [type={replication-mode}] [priority={level}] [desc={description}] [incremental={switch}] [timeout={value}] [compression={switch}]</pre>
Parameters	<p><code>compression={switch}</code> Enables data compression. This parameter is a licensed feature and is supported in asynchronous remote mirroring only. Value: enable, disable (default). Example: <pre>create replica VM2 part 00000000000000005 part 11111111000000006 type=async incremental=enable compression=enable</pre></p> <p><code>desc={description}</code> Specifies the description of the replication job. Example: <pre>create replica "Volume Copy 2" si 00000000000000101 part 0000000000000003 type=copy priority=low desc="Snapshot Backup"</pre></p> <p><code>incremental={switch}</code> Enables incremental recovery of the volume. This parameter is only used for asynchronous volume mirror. Value: enable, disable (default).</p> <p><code>name</code> Specifies the replication job.</p> <p><code>[part si] [source-volume-ID]</code> Specifies a partition or snapshot image as the source volume for replication operation. Only volume-copies can use snapshot images as source volumes.</p> <p><code>[part] [target-volume-ID]</code> Specifies a partition as the target volume for replication operation. Example: <pre>create replica VC-1 part 0000000000000001 part 0000000000000002</pre></p> <p><code>priority={level}</code> Specifies the priority of replication. Value: low, normal (default), high.</p>

Parameters	<p><code>timeout={value}</code> Specifies the timeout period of adaptive split. This parameter is used only for synchronous volume mirror setting. Values (in minutes): 10, 30 (default), 60, 90, 120, max. Example: <pre>create replica VM-1 part 0000000000000003 part 0000000000000004 type=mirror timout=max</pre></p> <hr/> <p><code>type={replication-mode}</code> Specifies the type of replication jobs. Value: copy (volume-copy, default), mirror (synchronous volume-mirror), async (asynchronous volume-mirror). * See Note below.</p> <hr/> <p><code>[vv si] [source-volume-ID]</code> Specifies a virtual volume or snapshot image as the source volume for replication operation. Only volume-copies can use snapshot images as source volumes.</p> <hr/> <p><code>[vv] [target-volume-ID]</code> Specifies a virtual volume as the target volume for replication operation. Example: <pre>create replica VC-1 vv 0000000000000001 vv 0000000000000002</pre></p>
------------	--

Note! In the “type” parameter:



- The “copy” type is supported only when the Local Volume Copy license is available.
- The “mirror” type is supported only when the Local Volume Mirror and Synchronous Remote Mirror license are available.
- The “async” type is supported only when the Local Volume Mirror and Asynchronous Remote Mirror license are available.

4.1.11 Create Schedule

Schedules a task.

Applicable to	ASR-5300I
Syntax	<code>create schedule [schedule-policy] [command] [init={switch}]</code>
Parameters	<p><code>command</code> Specifies the command to be scheduled, including their parameters. Example: <code>set disk scan [parameters], set ld scan [parameters]</code></p> <hr/> <p><code>init={switch}</code> Executes the schedule on controller initialization. Value: disable (default), enable.</p> <hr/> <p><code>schedule-policy</code> Values are:</p> <ul style="list-style-type: none">■ <code>{once [yyyyMMdd] [hhmmss]}</code>: Runs the task once at a specific time.■ <code>{daily [hhmmss]}</code>: Run the task every day at a specific time.■ <code>{weekly [week-day] [hhmmss]}</code>: Runs the task on weekly basis at a specific date and time.■ <code>yyyyMMdd</code>: Specifies the date. <code>yyyy</code>: The year in 4 digits. <code>MM</code>: The month; Value: 1-12, <code>dd</code>: The day of the month; Value: 1-31.■ <code>hhmmss</code>: Specifies the time. <code>hh</code>: The hour; valid Value: 0–23. <code>mm</code>: The minute; Value: 0–59. <code>ss</code>: The seconds; Value: 0–59.■ <code>week-day</code>: Specify the day of week, Value: 1-7. <p>Example: <code>create schedule once 20050110 080000 set disk scan 0,1 mode=continues priority=normal</code> (Scans drive 0 and 1 in continues mode and normal priority at a specific time.)</p> <p>Example: <code>create schedule weekly 7 235900 set ld scan 2 priority=low</code> (Scans drive 2 in default one-pass mode and low priority every Sunday.)</p>

4.1.12 Create SED Keyfile

Creates a new key file with random password for Self Encrypting Drives (SED).

Applicable to	ASR-5300I
Syntax	<code>create sed keyfile [file-path-name]</code>
Parameters	<p><code>[file-path-name]</code> : Creates a new key file with random password and saves it with the specified name and to the designated path. Example: <code>create sed keyfile /home/new.a.key</code></p>

4.1.13 Create Snapshot Image

Takes a snapshot image.

Applicable to	ASR-5300I
Syntax	<code>create snapshot-image [part] [partition-ID]</code>
Parameters	<p>[part] [partition-ID] Specifies the partition. Example: <code>create si part 0000000000010101</code></p> <hr/> <p>[vv] [virtual-volume-ID] Specifies the virtual volume. Example: <code>create si vv 0000000000010101</code></p>

Note! *This command is supported only when the Snapshot license is available.*



4.1.14 Create SNMPtrap

Creates an SNMP trap receiver.

Applicable to	ASR-5300I
Syntax	<code>create snmptrap [IP-address] [severity={severity-type}]</code>
Parameters	<p>[IP-address] Specify the IP address of the new SNMP trap receiver. IPv4 and IPv6 addresses are both supported. The address must be a unique one.</p> <hr/> <p>[severity={severity-type}] Specifies the severity type that triggers the SNMP trap for this receiver. Valid values: notification (default), warning, critical. Note: "Notification" includes notification, warning, and critical events. "Warning" includes warning and critical events. "Critical" includes only critical events. Example: <code>create snmptrap 192.168.1.11 severity=warning</code></p>

4.1.15 Create Trunk

Creates an iSCSI trunk group.

Applicable to	ASR-5300I
Syntax	<code>create trunk [channel-ID-list] [-r] [-y]</code>
Parameters	<code>channel-ID-list</code> Specifies the host channels to which the trunk group is attached by the channel IDs. Each item should be separated by a comma.
Options	<code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. Example: <code>create trunk 0,1,2,3 -r</code> <code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n).

Note! *This command is for iSCSI subsystems only.*



4.1.16 Create WWN

Creates a WWN and associates it with a host.

Applicable to	ASR-5300I
Syntax	<code>create wwn [WWN] [name]</code>
Parameters	<code>group={group-name}</code> Specifies the group(s) for host ID grouping. Example: <code>create wwn 1234567890123456 host1-1 group=host-1,G2,G3</code> <code>name</code> Specifies an alias name for the host bus adapter. Names that contain special characters, such as space, must be enclosed in double quotation marks. Example: <code>create wwn 1234567890123456 host1-1</code> <code>WWN</code> Specifies the WWN.

4.1.17 Delete Event

Clears the entire event log.

Applicable to	ASR-5300I
Syntax	<code>delete event</code> Short form: <code>del event</code>
Parameters	N/A

4.1.18 Delete History

Deletes the record of previously executed commands.

Applicable to	ASR-5300I
Syntax	<code>delete history</code> Short form: <code>del history</code>
Parameters	N/A

4.1.19 Delete IQN

Deletes the configurations of an IQN.

Applicable to	ASR-5300I
Syntax	<code>delete iqn [name]</code> Short form: <code>del iqn</code>
Parameters	<code>group={group-name}</code> Specifies the group(s) for deleting entries. Example: <code>delete iqn Host1-1 group=G2</code> <code>name</code> Specify the alias name of the iSCSI initiator for deletion. Example: <code>del iqn Host1</code>

4.1.20 Delete iSNS

Deletes an iSNS server.

Applicable to	ASR-5300I
Syntax	<code>delete isns [index] [-r] [-y]</code> Short form: <code>del isns</code>
Parameters	<code>index</code> Specifies the iSNS by its index. You can view the list of iSNS servers with <code>show isns</code> .
Options	<code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. Example: <code>del isns 1 -r</code> <code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .)

Note! *This command is for iSCSI subsystems only.*



4.1.21 Delete Logical Drive

Deletes a logical drive.

Applicable to	ASR-5300I
Syntax	<code>delete logical-drive [index-list] [-y]</code> Short form: <code>del ld</code>
Parameters	<code>index-list</code> Specifies the logical drives by their indexes. Each item should be separated by a comma. Example: <code>del ld 0,1</code>
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .)

4.1.22 Delete Logical Volume

Deletes a logical volume.

Applicable to	ASR-5300I
Syntax	<code>delete logical-volume [LV-ID] [-y]</code> Short form: <code>del lv</code>
Parameters	<code>LV-index-list</code> Specifies the logical volumes to be deleted. <code>LV-ID</code> Specifies the logical volumes by their indexes. Each item should be separated by a comma.
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .) Example: <code>del lv 0000000000010101 -y</code>

Note! This command will not delete logical drives within the logical volume.



4.1.23 Delete Map

Deletes (un-maps) a partition or a snapshot image.

Applicable to	ASR-5300I
Syntax	<pre>delete map [part] [partition-ID] [Channel-ID] [Target-ID] [LUN-ID] [-y] delete map [si] [snapshot-image-ID] [Channel-ID] [Target-ID] [LUN-ID] [-y] Short form: del map</pre>
Parameters	<p>Channel-ID Specifies the host channel ID.</p> <hr/> <p>group={group-name} Specifies the LUN group. Example: delete map vv 0000000000010102 host=Host-1-1 group=G2</p> <hr/> <p>host={alias-name} Specifies the host alias name.</p> <hr/> <p>iqn={initiator-iqn} Specifies the IQN of the initiator for deleting maps. (This option is for iSCSI models only)</p> <hr/> <p>LUN-ID Specifies the LUN ID.</p> <hr/> <p>LUN-number Specifies the LUN number.</p> <hr/> <p>[part] [partition-ID] Specifies a partition of which the mapping will be deleted. If not specified, all existing mappings will be deleted. Example: del map part 0000000000010102</p> <hr/> <p>[si] [snapshot-image-ID] Specifies the snapshot image.</p> <hr/> <p>Target-ID Specifies the host channel target number (SCSI ID). If no parameter is specified, all mappings will be deleted.</p> <hr/> <p>[vv] [virtual-volume-ID] Specifies a virtual volume. Example: delete map vv 0000000000010102</p>
Parameters	<p>wwn={host-wwn} Specifies the host WWN in hex string, such as: 210000E08B0AADE1. (This option is not supported for iSCSI models) Example: delete map 0 0 3 wwn=1234567890123456</p>
Options	<p>-y Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <i>y</i> or <i>n</i>.) Example: del map part 0000000000010102 0 112 0 -y</p>

Note! *If Channel-ID, Target-ID, and LUN-ID are not specified, all mappings in the specified volume will be deleted.*



4.1.24 Delete Partition

Deletes a partition.

Applicable to	ASR-5300I
Syntax	<code>delete partition [partition-ID] [-y]</code> Short form: <code>del part</code>
Parameters	<code>index</code> Specifies the logical drive or volume index. Example: <code>del part ld 0</code> <code>ld lv</code> Specifies the element: logical drive or logical volume. <code>part={index}</code> Specifies the partition by index. Example: <code>del part lv 0 part=1</code> <code>partition-ID</code> Specifies the partition.
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .) Example: <code>del part 0000000000010101 -y</code>

Note! *This command will not delete logical drives within the logical volume.*



4.1.25 Delete Replication

Deletes a replication job.

Applicable to	ASR-5300I
Syntax	<code>delete replica [volume-pair-ID] [-y]</code> Short form: <code>del replica</code>
Parameters	<code>volume-pair-ID</code> Specifies the replication job by the volume pair ID.
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .)

Note! *All subsystems should be connected prior to running this command to avoid the target volume being unassigned while deleting replications.*



4.1.26 Delete Schedule

Deletes a task schedule.

Applicable to	ASR-5300I
Syntax	delete schedule [job-ID] Short form: del schedule
Parameters	job-ID Specifies the task ID. Example: del schedule 3

4.1.27 Delete Snapshot Image

Deletes a snapshot image.

Applicable to	ASR-5300I
Syntax	delete snapshot-image [snapshot-image-ID] [-y] Short form: delete si
Parameters	snapshot-image-ID Specifies the snapshot by its ID.
Options	-y Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <i>y</i> or <i>n</i> .) Example: del si 00000000000010101 -y

4.1.28 Delete SNMPtrap

Deletes an SNMP trap receiver.

Applicable to	ASR-5300I
Syntax	delete snmptrap {receiver-index}
Parameters	receiver-index Specifies the index of the SNMP trap receiver. Users can find out the index via the command "show snmptrap".

4.1.29 Delete Trunk

Deletes a trunk group.

Applicable to	ASR-5300I
Syntax	<code>delete trunk [index] [-r] [-y]</code> Short form: <code>del trunk</code>
Parameters	<code>index</code> Specifies the trunk groups by their indexes. You can view the list of trunk index with <code>show trunk</code> . Each item should be separated by a comma.
Options	<code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. Example: <code>del trunk 1 -r</code> <code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .)

Note! This command is applicable to iSCSI subsystems only.



4.1.30 Delete WWN

Deletes a WWN.

Applicable to	ASR-5300I
Syntax	<code>delete wwn [name]</code> Short form: <code>del wwn</code>
Parameters	<code>group={group-name}</code> Specifies the group name(s) for deleting entries. Example: <code>delete wwn host-1-1 group=G2,G3</code> <code>name</code> Specifies the Host ID/WWN. Example: <code>delete wwn host-1-1</code>

4.1.31 Disconnect

Closes a CLI session.

Applicable to	ASR-5300I
Syntax	<code>disconnect [device-index]</code>
Parameters	If no parameter is specified, all connections will be disconnected. <code>device-index</code> Specifies the devices for terminating the session by their indexes. Each item should be separated by a comma.

4.1.32 Exit

Exits the CLI.

Applicable to	ASR-5300I
Syntax	<code>exit</code>
Parameters	N/A

4.1.33 Export Configuration

Exports the system configuration data to a local file.

Applicable to	ASR-5300I
Syntax	<code>export configuration [filename] [-f -l]</code> Short form: <code>export config</code>
Parameters	<code>filename</code> Specifies the local file name in XML format. If not specified, <code>config.xml</code> will be used.
Options	<code>-f</code> Saves the configuration data, including event, in plain text (*.txt). If the file name is not specified, <code>config.txt</code> will be used. Example: <code>export config -f config.txt</code>
	<code>-l</code> Exports only LUN configuration data. If the file name is not specified, <code>lun.xml</code> will be used. Example: <code>export config -l</code>

Note! *The destination folder/directory must exist prior to exporting the configuration file.*



4.1.34 Export NVRAM

Exports the NVRAM data in the controller to a local file.

Applicable to	ASR-5300I
Syntax	<code>export nvram [filename]</code>
Parameters	<code>filename</code> Specifies the file name. The data will be saved to the host as a binary file. If the file name is not specified, the NVRAM data will be saved to the disk reserved space. Example: <code>export nvram nvram.bin</code>

4.1.35 Export Support

Exports the support information file of the connected subsystems.

Applicable to	ASR-5300I
Syntax	<code>export support [filename]</code>
Parameters	<code>filename</code> Specifies the file name. If not specified, the default file name <code>support.zip</code> will be used. Example: <code>export support support.zip</code>

4.1.36 Help

Provides a simple help for selected commands.

Applicable to	ASR-5300I
Syntax	? [command] / help [command]
Parameters	If no parameter is specified, basic usage information will be displayed. command Specifies the command.

Note! Allows hierarchical help for complex commands such as help show, help set, etc.)



This command is the same as ?.

4.1.37 Import NVRAM

Imports the NVRAM data to the controller from a local file.

Applicable to	ASR-5300I
Syntax	import nvram [filename] [-n] [-y] [-r]
Parameters	filename Specifies the imported file name. If the file name is not specified, by default the import NVRAM data in the reserved space will be imported.
Options	-n Restores the NVRAM data without the password. Example: import nvram -n -y -r Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. -y Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n.) Example: import nvram nvram.bin -y -r

4.1.38 Man

Provides manuals for selected commands.

Applicable to	ASR-5300I
Syntax	man [command]
Parameters	If no command is specified, basic usage information will be displayed. command

Note! Allows hierarchical help for complex commands such as man show, man set, etc.)



4.1.39 Mute

Mutes the controller's audible alarm.

Applicable to	ASR-5300I
Syntax	mute
Parameters	N/A

Note! *The alarm will become audible again in the next fault condition.*



4.1.40 Reset Controller

Resets the controller.

Applicable to	ASR-5300I
Syntax	reset controller [flush={switch}] [-y] Short form: reset ctrl
Parameters	flush={switch} Flushes the cache to disk before reset. Value: enable (default), disable.
Options	-y Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <i>y</i> or <i>n</i> .)

Note! *This command shuts the controller down, flushes the cache to disk, and restarts the controller.*



4.1.41 Runscript

Runs a command script batch file.

Applicable to	ASR-5300I
Syntax	runscript [filename] [-i]
Parameters	filename Specifies the name of the batch file. If no file name is specified, the default script file name script.sc will be used.
Options	-i Interrupts executing the script file if any command inside the script returns error.

4.1.42 Scan Array

Discovers all drive arrays with in-band and out-of-band connection.

Applicable to	ASR-5300I
Syntax	<code>scan array [ip={ip-address}] [mask={netmask-ip}] [-b]</code>
Parameters	<p>If no parameter is specified, all in-band connected arrays of the local host will be discovered.</p> <p><code>ip={ip-address}</code> Specifies the IP domain for scanning. For in-band connected arrays, CLI will enumerate all in-band connected arrays of a specific IP address. CLI will also scan arrays by IP address through out-of-band connection. An array could be connected with the extended connect command.</p> <p>Example: <code>scan array ip=192.168.1.1 mask=255.255.255.255</code> (Scans arrays connected to 192.168.1.1 or find the array with the IP address 192.168.1.1)</p> <p><code>mask={netmask-ip}</code> Specifies the net-mask for scanning. If not specified, the default net-mask is 255.255.255.0.</p> <p>Example: <code>scan array ip=192.168.1.1 mask=255.255.255.255</code> (Scans arrays connected to 192.168.1.1 or find the array with the IP address 192.168.1.1)</p> <p>Example: <code>scan array ip=192.168.1.1 mask=255.255.0.0</code> (Class B for scanning 65535 nodes.)</p>
Options	<p><code>-b</code> Asks the array discovery job to run in background mode. The list of available arrays will be updated dynamically and displayed with the command <code>show array</code> any time.</p> <p>Example: <code>scan array ip=192.168.1.1 -b</code> (Class C for scanning 255 nodes in background.)</p>

Note!  *The result of discovering arrays by `scan array` will be kept by the CLI and you can later see the results for further usage. When you run `scan array` again, the buffered results will be replaced by the new results.*

4.1.43 Select

Selects a device.

Applicable to	ASR-5300I
Syntax	<code>select [index={device-index} uid={ID}] [password={secret}]</code>
Parameters	<p><code>index={device-index}</code> Specifies the devices by their index numbers. Each item should be separated by a comma. If there is just one device, the select command is automatically executed after connecting with the host. If no device index is specified, and more than one device exists, a list of choice will be displayed.</p> <hr/> <p><code>password={secret}</code> Specifies the password. If this parameter is not specified, A prompt will appear, asking you to provide the password after selecting the device.</p> <hr/> <p><code>uid={ID}</code> Specifies the unique controller ID after connecting with the host.</p>

4.1.44 Set Cache

Configures the write operation (write-back or write-through).

Applicable to	ASR-5300I
Syntax	<code>set cache [write={write-policy}] [sync-period={value}] [-r] [-y]</code>
Parameters	<p><code>sync-period={value}</code> Specifies the periodic cache synchronization value in seconds for write-through policy. Value: 0 (continuous syncing), 30, 60, 120, 300, 600, disable (default value) Example: <code>set cache write=write-back sync-period=30</code></p> <hr/> <p><code>write={write-policy}</code> Specifies the write policy. Value: write-back, write-through. Example: <code>set cache write=write-through -r</code></p>
Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller.</p> <hr/> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code>.)</p>

4.1.45 Set Channel

Configures a host or drive channel.

Applicable to	ASR-5300I
Syntax	<pre>set channel [channel-ID] [mode={value}] [aid={id-list}] [bid={id-list}] [maxrate={value}] [mcs={MCS-ID}] [-r] [-y]</pre> <p>Short form: <code>set ch</code></p>
Parameters	<p><code>aid={id-list}</code> Specifies the ID for controller A on the specified channel. Value: delete (no ID configured), 0–15 (for SCSI devices), 0–125 (for FC and SATA devices). Example: <code>set channel 1 aid=delete</code> (Deletes all indexes for controller A on channel 1.)</p> <hr/> <p><code>bid={id-list}</code> Specifies the ID for controller B on the specified channel. Value: delete (no ID configured), 0–15 (for SCSI devices), 0–125 (for FC and SATA devices). Example: <code>set channel 0 aid=1 bid=100,101,102</code></p> <hr/> <p><code>channel-ID</code> Specifies the drive channel.</p> <hr/> <p><code>maxrate={value}</code> Sets the maximum data transfer rate. The values are different among host interfaces.</p> <ul style="list-style-type: none">■ PATA/IDE drive channels: auto (default), 33MB, 44MB, 66MB, 100MB, and 133MB.■ SATA/SAS host or drive channels: auto, 330MHz, 440MHz, 660MHz, 1GHz, 1.33GHz, 1.5GHz, 3GHz and 6GHz.■ FC host or drive channels: auto, 1GHz, 2GHz, 4GHz and 8GHz.■ SCSI host or drive channels: 2.5MHz, 2.8MHz, 3.3MHz, 4MHz, 5MHz, 5.8MHz, 6.7MHz, 8MHz, 10MHz, 160MHz, 160MHz, 13.8MHz, 16.6MHz, 20MHz, 33MHz, 40MHz, 80MHz, 160MHz, 320MHz. <p>Example: <code>set channel 2 maxrate=4GHz</code> (Sets the maximum data transfer rate for FC channels)</p> <hr/> <p><code>mcs={MCS-ID}</code> Aggregates the channel to a MCS (Multi-Connection Session) group. (This parameter is only for iSCSI model host channels) Example: <code>set channel 3 mcs=0</code></p> <hr/> <p><code>mode={value}</code> Specifies whether the channel is a host or drive channel. For host channels, multiple IDs can be applied. For drive channels, only one ID can be applied. Value: host, disk.</p>
Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. Example: <code>set ch 1 mode=host -r</code> (Sets the channel as host and resets the controller immediately.)</p> <hr/> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code>.)</p>

4.1.46 Set Controller Date

Configures the controller's date, time, and time zone.

Applicable to	ASR-5300I
Syntax	<pre>set controller date [yyyyMMdd] [hhmmss] [gmt={value}]</pre> <p>Short form: <code>set ctrlr date</code></p>
Parameters	<p><code>gmt={value}</code> Specifies the time zone based on Greenwich Mean Time (GMT) followed by a plus (+) or minus (-) sign and the number of hours earlier or later than GMT. If not specified, the time zone will be synchronized with the setting in the RAID firmware. The time zone setting will not affect the date and time settings. Example: <pre>set ctrlr date 20050101 180000 gmt=+8</pre> (The date and time of the controller will be changed to 2005/01/01 18:00:00, GMT=+8)</p> <hr/> <p><code>hhmmss</code> Specifies the controller time.</p> <ul style="list-style-type: none"> ■ <code>hh</code>: The hour, Value: 0–23. ■ <code>mm</code>: The minute, Value: 1–59. ■ <code>ss</code>: The second, Value: 1–59. <hr/> <p><code>yyyyMMdd</code> Specifies the controller date.</p> <ul style="list-style-type: none"> ■ <code>yyyy</code>: The year in 4 digits. ■ <code>MM</code>: The month, Value: 1-12. ■ <code>dd</code>: The day of the month, Value: 1-31. <p>Example: <pre>set ctrlr date 083030</pre></p>

4.1.47 Set Controller Default

Restores the NVRAM of the controller to factory setting.

Applicable to	ASR-5300I
Syntax	<pre>set controller default [-y] [-r]</pre> <p>Short form: <code>set ctrlr default</code></p>
Parameters	N/A
Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller.</p> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n.)</p>

4.1.48 Set Controller Name

Specifies a name for the controller.

Applicable to	ASR-5300I
Syntax	<code>set controller name [name]</code> Short form: <code>set ctlr name</code>
Parameters	<code>name</code> Specifies the new controller name. If not specified, the controller name will become empty.

Note! *The maximum length of the name is 31 characters.*



4.1.49 Set Controller Parameter

Configures the controller parameters.

Applicable to	ASR-5300I
Syntax	<code>set controller parm [normal-verify={switch}] [init-verify={switch}] [rebuild-verify={switch}] [priority={level}] [max-response={timeout}] [av-optimization={category}] [snmp={community-string}] [snmp={SNTP-Server-IPs}] [snmp-poll={period}]</code> Short form: <code>set ctlr parm</code>
Parameters	<code>av-optimization = {category}</code> During data streaming, improves frame-drop rate and smoothes the performance. Once enabled, the max-response value will be fixed. Valid modes: <code>disable</code> (default), <code>fewer</code> (for fewer streaming), <code>multiple</code> (for multiple streaming). Example: <code>set ctlr parm av-optimization=multiple</code> <code>init-verify={switch}</code> Performs verification after write transaction while initializing logical drives. Value: <code>enable</code> , <code>disable</code> . <code>max-response={timeout}</code> Specifies the maximum response time on write wait for hard drives to ensure media error delays do not cause host I/O timeouts. Value: <code>0</code> (<code>disable</code> , default), <code>160</code> , <code>320</code> , <code>960</code> (in milliseconds) <code>normal-verify={switch}</code> Performs verification after write transaction during normal I/O requests. Value: <code>enable</code> , <code>disable</code> . <code>priority={level}</code> Specifies the priority of the logical drive rebuild-logical-drive process. Value: <code>low</code> , <code>normal</code> , <code>high</code> . Example: <code>set ctlr parm normal-verify=enable priority=normal</code> <code>rebuild-verify={switch}</code> Performs verification after write transaction during the rebuild-logical-drive process. Value: <code>enable</code> , <code>disable</code> . Example: <code>set ctlr parm init-verify=disable rebuild-verify=enable priority=high</code>

Parameters	<pre>snmp={community-string}</pre> <p>Uses the SNMP community string of the controller for SNMP discovery. Example: <code>set ctlr parm snmp=public</code></p> <hr/> <p>Specifies one or more SNTP server IP addresses for using network time protocol.</p> <hr/> <pre>sntp-poll={period}</pre> <p>Specifies the SNTP polling period in hours. The default is 0 (disabled). Example: <code>set ctlr parm sntp=192.43.244.18,207.46.197.32 sntp-poll=8</code></p>
------------	--

Note! *The `normal-verify={switch}` parameter affects write performance during normal use.*



4.1.50 Set Controller Trigger

Configures the controller to trigger an action when an event occurs.

Applicable to	ASR-5300I
Syntax	<pre>set controller trigger [ctlr-fail={switch}] [battery-fail={switch}] [power-loss={switch}] [power-fail={switch}] [fan-fail={switch}] [temp-exceed-delay={value}]</pre> <p>Short form: <code>set ctlr trigger</code></p>
Parameters	<pre>battery-fail={switch}</pre> <p>When a battery failure occurs, the cache setting switches from write-back to write-through. Value: enable, disable.</p> <hr/> <pre>ctlr-fail={switch}</pre> <p>When a controller failure occurs, the cache setting switches from write-back to write-through. Value: enable, disable.</p> <hr/> <pre>fan-fail={switch}</pre> <p>When a cooling fan failure occurs, the cache setting switches from write-back to write-through. Value: enable, disable.</p> <hr/> <pre>power-loss={switch}</pre> <p>When a power loss occurs, the cache setting switches from write-back to write-through. Value: enable, disable.</p> <hr/> <pre>power-fail={switch}</pre> <p>When a power failure occurs, the cache setting switches from write-back to write-through. Value: enable, disable. Example: <code>set ctlr trigger ctlr-fail=enable power-fail=enable</code></p> <hr/> <pre>temp-exceed-delay={value}</pre> <p>When the temperature exceeds the system threshold, the controller shuts down. You can set the time between temperature detection and shutdown. Values (in minutes): 0 (shutdown disabled), 2, 5, 10, 20, 30, 45, 60. Example: <code>set ctlr trigger fan-fail=enable temp-exceed-delay=10</code></p>

4.1.51 Set Controller Uid

Specifies the identifier of the controller.

Applicable to	ASR-5300I
Syntax	<code>set controller uid [ID] [-y] [-r]</code> Short form: <code>set ctlr uid</code>
Parameters	ID The identifier is a five-digit hexadecimal string from 00000 to fffff.
Options	<code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. <code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .)

Note! *The ID is originally created from the chassis serial number and should not be changed unless the chassis is replaced.*



4.1.52 Set Device Flash

Toggles the service LED of the controller.

Applicable to	ASR-5300I
Syntax	<code>set device flash [device-index-list]</code> <code>[mode={value}]</code>
Parameters	<code>device-index-list</code> Specifies the controllers by their indexes. Each item should be separated by a comma. Example: <code>set device flash 0</code> <code>mode={value}</code> Toggles the service LED. Values are on (default) or off. Example: <code>set device flash 0,1 mode=off</code>

4.1.53 Set Disk Clear

Removes the reserved space of a disk.

Applicable to	ASR-5300I
Syntax	<code>set disk clear [disk-index-list]</code>
Parameters	<code>disk-index-list</code> Specifies the drives by their indexes. Each item should be separated by a comma. Example: <code>set disk clear 4,5</code>

Note! *You can specify only unused (unassigned) disk drives.*



4.1.54 Set Disk Clone

Clones a hard drive.

Applicable to	ASR-5300I
Syntax	<pre>set disk clone [source-disk] [-s] set disk clone [destination-disk] [-a] set disk clone -l</pre>
Parameters	<p>destination-disk Specifies the destination disk.</p> <hr/> <p>source-disk Specifies the source disk. The spare disk will be cloned in perpetual mode.</p>
Options	<p>-a Aborts cloning. The source and destination disks return to the status before cloning. Example: <code>set disk clone 2 -a</code></p> <hr/> <p>-l Lists all cloning tasks in process. Example: <code>set disk clone -l</code></p> <hr/> <p>-s Replaces the disk when cloning completes or stops the disk in perpetual mode and replaces the source disk with the cloned one. Example: <code>set disk clone 1 -s</code></p>

Note! *A spare disk is required for the clone destination. This command is useful for cloning a suspected failing drive before it stops working.*



4.1.55 Set Disk Copy

Copies the content of a disk to another disk and then replaces the original disk.

Applicable to	ASR-5300I
Syntax	<pre>set disk copy [source-disk] [destination-disk] [priority={level}] set disk copy [destination-disk] [-a]</pre>
Parameters	<p>destination-disk Specifies the destination disk. You cannot specify a spare disk as the destination disk.</p> <hr/> <p>priority={level} Specifies the priority of the disk replacement. Value: low, normal, improved, high. Example: <code>set disk copy 0 1 priority=low</code></p> <hr/> <p>source-disk Specifies the source disk.</p>
Options	<p>-a Aborts copying the disk. Example: <code>set disk copy 1 -a</code></p>

4.1.56 Set Disk Flash

Flashes a disk's LED to help identify it.

Applicable to	ASR-5300I
Syntax	<code>set disk flash [disk-index]</code>
Parameters	<code>disk-index</code> Specifies the disks by their indexes. If not specified, all disks will flash (including those in JBODs). Example: <code>set disk flash 2</code>

4.1.57 Set Disk Parameter

Configures disk parameters.

Applicable to	ASR-5300I
Syntax	<code>set disk parm [spin={switch}] [smart={value}] [autospare={switch}] [delay={time}] [tag={value}] [io={timeout}] [check={period}] [poll={period}] [swap={period}] [cache={switch}]</code>
Parameters	<code>autospare={switch}</code> Assigns a drive as the global spare drive. Value: enable, disable. <code>cache={switch}</code> Enables write cache for SATA drives.. Value: enable, disable (default). Example: <code>set disk parm cache=enable</code> <code>check={period}</code> Sets the period of drive-side SCSI drive check in seconds. Value: 0 (disable), 0.5 (500ms), 1, 2, 5, 10, 30. <code>delay={time}</code> Sets a delay time before the first disk access in seconds. Value: 0 (No delay), 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60, 65, 70, 75. <code>io={timeout}</code> Sets the drive-side SCSI I/O timeout in seconds. Value: 0 (default), 0.5, 1, 2, 4, 6, 8, 10, 15, 20, 30. <code>poll={period}</code> Sets the period of SAF-TE and SES polling in seconds. Value: 0 (disabled), 0.05 (50ms), 0.1 (100ms), 0.2 (200ms), 0.5 (500ms), 1, 2, 5, 10, 20, 30, 60. Example: <code>set disk parm spin=enable smart=detect-perpetual-clone poll=5</code> <code>spin={switch}</code> Spins the motor up. Value: enable, disable. <code>swap={period}</code> Checks if failed drives have been swapped. Values (in seconds): 0 (disable), 5, 10, 15, 30, 60. Example: <code>set disk parm io=0.5 check=0.5 swap=10</code> <code>smart={value}</code> Activates the SMART (drive failure prediction) mode. Value: disable, detect-only, detect-perpetual-clone, detect-clone-replace, fail-drive.

Parameters	<pre>tag={value}</pre> <p>Sets the maximum drive-side SCSI tags per drive. Value: 0 (Tagged queuing disabled), 1, 2, 4, 8, 16, 32, 64, 128.</p> <p>Example:</p> <pre>set disk parm autospare=disable delay=0 tag=8</pre>
------------	--

4.1.58 Set Disk Read-Write Test

Tests the read/write capability of a disk.

Applicable to	ASR-5300I
Syntax	<pre>set disk rwtest [disk-index-list] [mode={value}] [error={value}] [recovery={value}] [-a]</pre>
Parameters	<p>disk-index-list Specifies the drives by their indexes. Each item should be separated by a comma. Maximum up to 30 disks can be set for read-write tests.</p> <hr/> <p>error={value} Specifies what to do if an error occurs during the test. Value: none (no action, default), abort (abort on any errors) and critical (abort only on critical errors)</p> <p>Example:</p> <pre>set disk rwtest 3 mode=force error=abort</pre> <hr/> <p>mode={value} Specifies the testing mode. Value: read-write (default), read-only, reset (resets the previous read-write test error status), force (resets and then runs the read-write test)</p> <p>Example:</p> <pre>set disk rwtest 2 mode=reset</pre> <hr/> <p>recovery={value} Specifies the recovery operation if bad blocks are found during testing. Value: none (no action, default), mark (marks the bad block), auto (automatically assigns bad blocks as reserved), attempt (tries to reassign bad blocks)</p> <p>Example:</p> <pre>set disk rwtest 1,2 mode=read-only recovery=auto</pre> <hr/> <p>-k Specifies that the result output will only show once the read / write tests have completed.</p> <p>Example:</p> <pre>set disk rwtest 1,2 -k mode=read-write</pre>
Options	<p>-a Aborts the test.</p> <p>Example:</p> <pre>set disk rwtest 2 -a</pre>

Note! *Select only new or unused drives which haven't been assigned to logical drives.*



You cannot run the read-write test if an error has ever occurred. Use `show disk` to view the error status and reset the system using `set disk rwtest [disk-index] mode=reset`. You may also use `mode=force` to force start the read-write testing.

4.1.59 Set Disk Saving

Configures the power saving mode for disks.

Applicable to	ASR-5300I
Syntax	<pre>set disk saving [mode] [level1={time}] [level2={time}]</pre>
Parameters	<p>level1={time} Specifies the no host I/O period for triggering power saving level 1 in minutes. If not specified, the default value will be applied. Value: 1, 5 (default), 10, 30, 60.</p> <p>level2={time} Specifies the no host I/O period for triggering power saving level 2 in minutes. If not specified, the default value will be applied. Value: 1, 5 (default), 10, 30, 60.</p> <p>Example: <pre>set disk saving 1 level1=10 level2=30</pre></p> <p>mode Specifies the power saving mode. Values are 0, 1, 2, 3.</p> <ul style="list-style-type: none">■ 0: Disables the power saving function for all disks (factory default).■ 1: When there is no host I/O, spare and unused disks automatically change to power saving level 1, then to power saving level 2.■ 2: When there is no host I/O, spare and unused disks automatically change to power saving level 1.■ 3: When there is no host I/O, spare and unused disks automatically change to power saving level 2. <p>Example: <pre>set disk saving 0</pre></p>

4.1.60 Set Disk Scan

Scans the disks.

Applicable to	ASR-5300I
Syntax	<pre>set disk scan [disk-index-list] [mode={value}] [priority={level}] set disk scan [index-list] [-a]</pre>
Parameters	<p>disk-index-list Specifies the disks by their indexes. Each item should be separated by a comma.</p> <p>mode={value} Specifies the scan modes. Value: continues, one-pass (default). If not specified, the one-pass mode will be used.</p> <p>priority={level}] Sets the priority of the scan. Value: low, normal, improved, high.</p> <p>Example: <pre>set disk scan 0,1 mode=continues priority=normal</pre></p>
Options	<p>-a Aborts scanning.</p> <p>Example: <pre>set disk scan 3 -a</pre></p>

Note! This command can only be applied to "global spare disk."



4.1.61 Set Disk SMART Test

Sets disk to perform SMART self-test.

Applicable to	ASR-5300I
Syntax	<code>show disk smtest [disk-index] [mode={value}]</code>
Parameters	<p><code>disk-index</code>: Specify the specific disk drive to apply SMART self test.</p> <p><code>mode={value}</code>: Specify the mode of SMART self test. Valid values: offline-short (default), offline-extended, captive-short, captive-extended</p> <p>Example:</p> <pre>set disk smtest 0</pre> <p>Example:</p> <pre>set disk smtest 1 mode= offline-extended</pre>

4.1.62 Set Disk Spare

Configures spare disks.

Applicable to	ASR-5300I
Syntax	<code>set disk spare [disk-index] [type={spare-type}] [LD={LD-ID}]</code> <code>set disk spare [disk-index] [-d]</code>
Parameters	<p><code>disk-index</code> Specifies the disk drives by their indexes. Each item should be separated by a comma. Example: <code>set disk spare 1</code></p> <p><code>LD={LD-ID}</code> Specifies the logical drive ID. This parameter is required only for local spare drive setting. Example: <code>set disk spare 3 type=local ld=4040665</code></p> <p><code>type={spare-type}</code> Specifies the type of spare drive. Value: global (default), local, enclosure. If you choose "local," the logical drive ID parameter is also required. Example: <code>set disk spare 2 type=enclosure</code></p>
Options	<p><code>-d</code> Un-assigns a spare disk. Example: <code>set disk spare 1 -d</code></p>

4.1.63 Set History

Defines the size of the command history buffer.

Applicable to	ASR-5300I
Syntax	<code>set history [size]</code>
Parameters	<p><code>size</code> The amount of previously executed commands kept in buffer: 0-255. '0' means to disable logging the command history.</p>

4.1.64 Set Host

Configures the host controller.

Applicable to	ASR-5300I
Syntax	<pre>set host [queue-depth={value}] [max-lun={value}] [conn-mode={value}] [concurrent={value}] [num- tag={value}] [dev-type={value}] [dev- qual={value}] [remove-media={switch}] [lun- app={value}] [chs={value-index}] [CHAP={switch}] [jumbo-frame={switch}] [-r] [-y]</pre>
Parameters	<p>CHAP={switch}] (For iSCSI interface only) Specifies the CHAP authentication support between array and initiators. Value: enable, disable.</p> <hr/> <p>chs={value-index} Specifies the CHS (Cylinder / Head / Sector). You may use show host chs to view the list of CHS.</p> <hr/> <p>conn-mode={value} Specifies the connection mode. Value: loop, point-to-point. Example: set host queue-depth=0 max-lun=16 conn-mode=loop</p> <hr/> <p>concurrent={value} Specifies the maximum number of concurrent host-LUN connections. Value: 1, 2, 4(default), 8, 16, 32, 64, 128, 256, 512, 1024.</p> <hr/> <p>dev-type={value} Specifies the type of the peripheral device. Value: no-dev, dir-acc, seq-acc, processor, cdrom, scanner, mo, storage, enclosure, unknown.</p> <hr/> <p>dev-qual={value} Specifies the status of the peripheral device. Value: connected, supported.</p> <hr/> <p>jumbo-frame={switch} Toggle the support of jumbo frame for iSCSI initiators. Valid Value: enable, disable. (For iSCSI only)</p> <hr/> <p>lun-app={value} Specifies the LUN applicability. Valid Value: all-lun, lun-0.</p> <hr/> <p>max-lun={value} Specifies the maximum number of LUNs that can be assigned to a host ID (target address). Each time a host channel ID is added, it uses the number of LUNs in this setting. Value: 1, 2, 4, 8, 16, 32 (default).</p> <hr/> <p>num-tag={value} Sets the number of tags reserved for each host-LUN connection. Valid Value: 1, 2, 4, 8, 16, 32(default), 64, 128 and 256.</p> <hr/> <p>queue-depth={value} Specifies the maximum number of I/O operations that can be queued simultaneously for a logical drive. Value: 0 (auto), 1, 2, 4, 8, 16, 32, 64, 128, 256, 512, 1024 (default). Example: set host queue-depth=1024</p> <hr/> <p>remove-media={switch} Specifies if the device supports removable media. Value: disable, enable.</p>

Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. Example: <code>set host CHAP=enable jumbo-frame=enable -r</code></p> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code>.)</p>
---------	--

Note! *The default CHAP password is the same with the array system password.*



4.1.65 Set IQN

Configures an IQN (iSCSI initiator).

Applicable to	ASR-5300I
Syntax	<pre>set iqn [name] [name={IQN-alias-name}] [user={username}] [password={secret}] [tar- get={name}] [target-password={secret}] [ip={ip- address}] [mask={netmask-ip}]</pre>
Parameters	<p><code>group={group-names}</code> Specifies the group for host ID grouping. Example: <code>set iqn Host1 group=Group1,G2</code></p> <p><code>ip={ip-address}</code> Specifies the IP address of the IQN.</p> <p><code>mask={netmask-ip}</code> Specifies the net mask of the IQN. Example: <code>set iqn Host1 target=target_account target-pass- word=password ip=192.168.1.1 mask=255.255.255.0</code></p> <p><code>name</code> Specifies the name of the IQN.</p> <p><code>name={IQN-alias-name}</code> Specify the user-defined alias name of the IQN.</p> <p><code>password={secret}</code> Specifies the password (secret string) for CHAP. Example: <code>set iqn Host1 name=Host2 user=user password=pass- word</code></p> <p><code>target={username}</code> Specifies the target user name for mutual CHAP authentication.</p> <p><code>target-password={secret}</code> Specifies the target password for mutual CHAP authentication.</p> <p><code>user={username}</code> Specifies the user name for CHAP authentication.</p>

4.1.66 Set Log

Enables or disables logging commands into a file.

Applicable to	ASR-5300I
Syntax	<code>set log [option] [filename] [-t]</code>
Parameters	<code>filename</code> Specifies the log file name; the default is <code>output.log</code> . <code>option</code> Enables logging and specifies optional actions: <ul style="list-style-type: none">■ <code>enable</code> Enables logging■ <code>append</code> Logs in appending mode (the default is overwriting mode)■ <code>disable</code> Disables logging Example: <code>set log append</code>
Option	<code>-t</code> Toggles the execution date and time.

4.1.67 Set Logical Drive

Configures a logical drive.

Applicable to	ASR-5300I
Syntax	<code>set logical-drive [LD-index] [assign={assign-to}] [name={LD-alias-name}] [write={write-policy}]</code> Short form: <code>set ld</code>
Parameters	<code>assign={assign-to}</code> Specifies the controller to which the logical drive belongs. Value: <code>slotA</code> , <code>slotB</code> . <code>LD-index</code> Specifies the logical drive. <code>name={LD-alias-name}</code> Specifies the logical drive's name. The maximum length is 32 characters. <code>write={write-policy}</code> Specifies the cache write policy for the logical drive. Value: <code>default</code> (applies the system default policy), <code>write-back</code> , <code>write-through</code> . Example: <code>set ld 0 assign=slotB name="" write=default</code>

4.1.68 Set Logical Drive Add

Adds disks to a logical drive.

Applicable to	ASR-5300I
Syntax	<code>set logical-drive add [ld-index] [disk-list]</code> Short form: <code>set ld add</code>
Parameters	<code>disk-list</code> Specifies the disk drives by their indexes. Each item should be separated by a comma. Example: <code>set ld add 0 3,4</code> (Adds disk 3 and 4 to the logical drive [logical-drive0].) <code>ld-index</code> Specifies the logical drive.

4.1.69 Set Logical Drive Expand

Expands a logical drive.

Applicable to	ASR-5300I
Syntax	<pre>set logical-drive expand [index-list] [size={expand-size}] [mode={value}]</pre> <p>Short form: <code>set ld expand</code></p>
Parameters	<p><code>index-list</code> Specifies the logical drives.</p> <hr/> <p><code>mode={value}</code> Specifies the initialization mode. Value: online (default), offline. Example: <pre>set ld expand 0 size=36GB mode=offline</pre> (Expands logical drive 0's each physical disk to 36GB in offline mode)</p> <hr/> <p><code>size={expand-size}</code> Specifies the expanded size followed by MB or GB. If not specified, the maximum available size will be used.</p>

4.1.70 Set Logical Drive Migrate

Migrates a logical drive to a different RAID level.

Applicable to	ASR-5300I
Syntax	<pre>set logical-drive migrate [index] [RAID-level] [append={disk-list}]</pre> <p>Short form: <code>set ld migrate</code></p>
Parameters	<p><code>append={disk-list}</code> Appends more disks if the RAID level to which you want to migrate needs more disks (such as migrating RAID-5 to RAID-6). Example: <pre>set ld migrate 1 r6 append=5</pre> (Migrates the logical drive 1 from RAID5 to RAID6 and appends a physical disk with index 5 for additional parity) Example: <pre>set ld migrate 2 r5</pre> (Migrates the logical drive 2 from RAID6 to RAID5 and removes an additional member disk from the logical drive)</p> <hr/> <p><code>index</code> Specifies the logical drive.</p> <hr/> <p><code>RAID-level</code> Specifies the RAID level for migration. Valid Value: r5 (RAID 5), r6 (RAID 6).</p>

Note!  Migration is allowed only between RAID 5 and RAID6 to restrict choosing disk drives arbitrarily. In firmware v 3.48, migration is limited to add (RAID5->RIAD6) or remove (RAID6->RAID5) only and changing the capacity or stripe size of the migrated logical drive is prohibited. For migrating RAID6 to RAID5, the removed disks will be chosen by the firmware automatically (the default is the last member disks).

4.1.71 Set Logical Drive Parity

Configures the parity of a logical drive.

Applicable to	ASR-5300I
Syntax	<pre>set logical-drive parity [LD-index-list] [mode={value}] set logical-drive parity [LD-index-list] [-a] Short form: set ld parity</pre>
Parameters	<p>LD-index-list Specifies the logical drives by their indexes. Each item should be separated by a comma. Example: <pre>set ld parity 0</pre> (Performs parity check on logical drive 0 [logical-drive0].)</p> <hr/> <p>mode={value} Specifies the parity check mode. If not specified, check-only mode will be used. Valid Value: check-only (default), regenerate Example: <pre>set ld parity 1 mode=regenerate.</pre></p>
Options	<p>-a Aborts the parity check Example: <pre>set ld parity 1 -a</pre></p>

4.1.72 Set Logical Drive Rebuild

Rebuilds a logical drive.

Applicable to	ASR-5300I
Syntax	<pre>set logical-drive rebuild [LD-index] [-y] [-a] Short form: set ld rebuild</pre>
Parameters	<p>LD-index Specifies the logical drive.</p>
Options	<p>-a Aborts the rebuild. Example: <pre>set ld rebuild 0 -a</pre></p> <hr/> <p>-y Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <i>y</i> or <i>n</i>.) Example: <pre>set ld rebuild 0 -y</pre></p>

4.1.73 Set Logical Drive Saving

Configures the power saving mode for a logical drive.

Applicable to	ASR-5300I
Syntax	<pre>set logical-drive saving [index] [mode] [level1={time}] [level2={time}]</pre> <p>Short form: <code>set ld saving</code></p>
Parameters	<p>index Specifies the index of the logical drive.</p> <hr/> <p>level1={time} Specifies the no-host I/O period for power saving level 1 in minutes. If not specified, the default value will be applied. Valid Value: 1, 5 (default), 10, 30, 60.</p> <hr/> <p>level2={time} Specifies the no-host I/O period for power saving level 2 in minutes. If not specified, the default value will be applied. Valid Value: 1, 5 (default), 10, 30, 60.</p> <p>Example: <code>set ld saving 0 1 level1=10 level2=30</code></p> <hr/> <p>mode Specifies the power saving mode for the logical drive. You need to configure the power saving mode for the logical drive prior to configuring individual disks (the logical drive would leverage the disk settings). Value: 0, 1, 2, 3</p> <ul style="list-style-type: none"> ■ 0: Disables the power saving function. ■ 1: Sets the power saving level to 1 if no host I/O occurs for a period of time, and to level 2 for another period. ■ 2: Sets the power saving level to 1 if no host I/O occurs for a period of time. ■ 3: Sets the power saving level to 2 if no host I/O occurs for a period of time. <p>Example: <code>set ld saving 0 0</code></p>

4.1.74 Set Logical Drive Scan

Scans a logical drive for bad blocks.

Applicable to	ASR-5300I
Syntax	<pre>set logical-drive scan [index-list] [mode={value}] [priority={level}] set logical-drive scan [index-list] [-a] Short form: set ld scan</pre>
Parameters	<p><code>index-list</code> Specifies the logical drives by their indexes. Each item should be separated by a comma.</p> <p><code>mode={value}</code> Specifies the scan mode. If not specified, one-pass mode will be used. Value: continues, one-pass (default).</p> <p><code>priority={level}</code> Sets the priority of the scan. Value: low, normal, improved, high. Example: <code>set ld scan 0,1 mode=continues priority=normal</code> (Ask logical drive 0 and 1 to media-scan with continues mode and normal priority.)</p>
Options	<p><code>-a</code> Aborts the scan. Example: <code>set ld scan 3 -a</code> (Aborts scanning logical drive 3.)</p>

4.1.75 Set Logical Drive SED Disable

Disables SED function for a specific logical drive.

Applicable to	ASR-5300I
Syntax	<pre>set ld sed disable [ld-index-list] [pass- word={password} keyfile={keyfile}]</pre>
Parameters	<p><code>{ld-index-list}</code>: Specify one or several logical drives to disable the SED function.</p> <p><code>password={password}</code>: Specify the local A-key to disable logical drive SED function.</p> <p><code>keyfile={keyfile}</code>: Specify the local A-key file name and path to disable logical drive SED function. Example: <code>set ld sed disable 0,1 password=AbCd</code> Example: <code>set ld sed disable 0,1 keyfile=/home/ ld.key</code></p>

4.1.76 Set Logical Drive SED Enable

Enables SED function for a specific logical drive.

Applicable to	ASR-5300I
Syntax	<code>set ld sed enable [ld-index-list] [password={password} keyfile={keyfile}]</code>
Parameters	<p><code>ld-index-list</code>: Specify one or several logical drives to enable logical drive SED function. NOTE: All member disks of logical drives should support SED to be enabled.</p> <hr/> <p><code>password={password}</code>: Specify the local A-key to enable logical drive SED function. NOTE: If global A-key exists, this parameter can not be configured.</p> <hr/> <p><code>keyfile={keyfile}</code>: Specify the local A-key file name and path to enable SED function. NOTE: If global A-key exists, this parameter can not be configured.</p> <p>Example: <code>set ld sed enable 0,1</code></p> <p>Example: <code>set ld sed enable 0,1 password=AbCd</code></p> <p>Example: <code>set ld sed enable 0,1 keyfile=/home/ld.key</code></p>

4.1.77 Set Logical Drive SED Unlock

Unlock specified logical drive(s) lock status.

Applicable to	ASR-5300I
Syntax	<code>set ld sed unlock [ld-index-list] [password={password} keyfile={keyfile}]</code>
Parameters	<p><code>{ld-index-list}</code>: Specify one or several logical drives to be unlocked.</p> <hr/> <p><code>password={password}</code>: Specify the local A-key to unlock logical drive.</p> <hr/> <p><code>keyfile={keyfile}</code>: Specify the local A-key file name and path to unlock logical drive.</p> <p>Example: <code>set ld sed unlock 0,1 password=AbCd</code></p> <p>Example: <code>set ld sed unlock 0,1 keyfile=/home/ ld.key</code></p>

4.1.78 Set Logical Drive Shutdown

Shuts down a logical drive.

Applicable to	ASR-5300I
Syntax	<code>set logical-drive shutdown [index] [-y]</code> Short form: <code>set ld shutdown</code>
Parameters	<code>index</code> Specifies the logical drive.
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .) Example: <code>set ld shutdown 0 -y</code>

4.1.79 Set Logical Drive Undelete

Recovers (undeletes) a deleted logical drive.

Applicable to	ASR-5300I
Syntax	<code>set logical-drive undelete [index] [-y]</code> Short form: <code>set ld undelete</code>
Parameters	<code>index</code> Specifies the logical drive.
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .) Example: <code>set ld undelete 0 -y</code>

4.1.80 Set Logical Volume

Configures a logical volume.

Applicable to	ASR-5300I
Syntax	<code>set logical-volume [LV-ID] [name={LV-name}]</code> <code>[assign={assign-to}] [write={write-policy}]</code> Short form: <code>set lv</code>
Parameters	<code>assign={assign-to}</code> Specifies the controller to which the logical volume belongs. Value: <code>slotA</code> , <code>slotB</code> . Example: <code>set lv 0000000000010101 name=LV-2 assign=slotb</code>
	<code>LV-index</code> Specifies the logical volume.
	<code>LV-ID</code> Specifies the logical volume.
	<code>name={LV-name}</code> Change the name of the logical volume.
	<code>write={write-policy}</code> Specifies the cache write policy for the logical volume. Value: <code>default</code> (applies the system policy), <code>write-back</code> , <code>write-through</code> .

4.1.81 Set Logical Volume Expand

Expands the capacity of a logical volume.

Applicable to	ASR-5300I
Syntax	<pre>set logical-volume expand [LV-ID] [size={expand-size}]</pre> <p>Short form: <code>set lv expand</code></p>
Parameters	<p>LV-index Specifies the logical volume. Example: <code>set lv expand 0</code></p> <hr/> <p>LV-ID Specifies the logical volume. Example: <code>set lv expand 123456789012345</code></p> <hr/> <p>size={expand-size} Specifies the expanded size in MB (default) or GB. If not specified, the maximum size will be used. Example: <code>set lv expand 123456789012345 size=10GB</code></p> <p>Example: <code>set lv expand 123456789012345 size=10240</code></p>

4.1.82 Set Logical Volume Threshold

Configures the space threshold of a logical volume.

Applicable to	ASR-5300I
Syntax	<pre>set logical-volume threshold [LV-ID] [rule]</pre> <pre>set logical-volume threshold [LV-ID] [-d]</pre> <p>Short form: <code>set lv threshold</code></p>
Parameters	<p>LV-ID Specifies the logical volume.</p> <hr/> <p>rule Specifies the threshold (rule). Value: [ratio] [policy-code] ratio: Specifies the threshold as percentage of the total amount of logical volume in %. policy-code: Specifies the policy code that will be applied when the threshold is violated. Value: 1, 2, 3, 4, 5. 1: Post Notification Event Only 2: Post Warning Event Only 3: Post Critical Event Only 4: Post Critical Event and Execute Snapshot Image Purge 5: Post Critical Event and Make Association Snapshot Image Invalid Example: <code>set lv threshold 0000000000000001 70% 2</code></p>
Options	<p>-d Deletes all threshold configurations of a logical volume. Example: <code>set lv threshold 0000000000000001 -d</code></p>

4.1.83 Set Logical Volume Tier-Enable

Enables the teiring function of a logical volume.

Applicable to	ASR-5300I
Syntax	<code>set lv tier-enable [LV-ID] [tier-level] [-y]</code>
Parameters	<code>LV-ID</code> Specifies the logical volume. <code>Tier-level</code> Specifies the level of tiers to enable. Values: 0, 1, 2, 3 Example: <code>set lv tier-enable 0000000000010101 2</code>
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n). No prompt message will appear if the FW need not to be reset. Example: <code>set lv tier-enable 0000000000010101 -y</code>

4.1.84 Set Logical Volume Multi-Tier

Enables the multiple teiring function of a logical volume or changes the tiering function of a specific logical volume.

Applicable to	ASR-5300I
Syntax	<code>set lv multi-tier [LV-ID] {LD-index-list} {tier-level-list}</code>
Parameters	<code>{LV-ID}</code> Specifies a non-tiering logical volume to enable tiering function. <code>{LD-index-list}</code> The list must contain all of the logical drives included for the specified logical volume. <code>{Tier-level-list}</code> Specifies the level of tiers to enable. Values: 0, 1, 2, 3 Example: <code>set lv multi-tier 0000000000010101 2,3 0,1</code>

4.1.85 Set Logical Volume Tier-Migrate

Execute tiering migration of logical volume.

Applicable to	ASR-5300I
Syntax	<code>set lv tier-migrate [LV-ID] [part={partition-IDs}] [dataservice={switch}]</code>
Parameters	<p><code>lv={LV-IDs}</code> Specifies the logical volumes by their indexes. Each item should be separated by a comma. If not specified, all logical volumes teiring migration function will be enabled.</p> <p><code>part={partition-IDs}</code> Specify one or several specific partitions for tier migration. If not specified, it will migrate all partition data of the whole logical volume.</p> <p><code>dataservice={switch}</code> Specify if the data service related data (snapshot, replication meta-data) should be migrated during the tier migration operation. Valid values: enable (default), disable.</p> <p><code>priority={priority}</code> Specify the migrating priority with IO. Valid values: high, normal (default value), low.</p> <p>Example: <code>set lv tier-migrate 0000000000010101</code> <code>set lv tier-migrate 0000000000010101</code> <code>part=0000111122223333 dataservice=disable</code> <code>set lv tier-migrate 0000000000010101 dataser-</code> <code>vice=disable priority=low</code></p>

4.1.86 Set Logical Volume Tier-Disable

Disables the teiring function of a logical volume.

Applicable to	ASR-5300I
Syntax	<code>set lv tier-disable [LV-ID]</code>
Parameters	<p><code>LV-ID</code> Specifies the logical volume to disable the tiering function.</p>

4.1.87 Set Net

Configures the system network interface for out-of-band management or iSCSI data channels.

Applicable to	ASR-5300I
Syntax	<pre>set net [ID] [ip={IP-Addresses}] [mask={Netmask-IPs}] [gw={Gateway-IPs}] [v6ip={IPv6-Addresses}] [prefix={prefix-lengths}] [route={route-addresses}] [-r] [-y]</pre>
Parameters	<p><code>gw={Gateway-IPs}</code> Specifies the IP address of network gateway. Example: <pre>set net 2 ip=192.168.1.3,192.168.1.4 mask=255.255.255.0,255.255.255.0 gw=192.168.1.254,192.168.1.254</pre>(For dual-controller RAID models only.) Example: <pre>set net 2 ip=,192.168.1.4 mask=,255.255.255.0 gw=,192.168.1.254</pre>(For dual-controller RAID models only, but changes the setting for <code>ctrl_B</code>)</p> <p>For iSCSI dual-controller RAID models, you have to specify parameters for both controllers except for ID.</p> <p>ID Specifies the channel ID of the network interface.</p> <p><code>ip={IP-Addresses}</code> Specifies the IP address of the network interface. If you specify the address using the reserved word "dhcp" (dynamic addressing via existing DHCP server), this value can be empty. Example: <pre>set net 0 ip=dhcp</pre></p> <p><code>mask={Netmask-IPs}</code> Specifies the subnet net mask for the IP address. Example: <pre>set net 1 ip=192.168.1.1 mask=255.255.255.0 gw=192.168.1.254</pre></p> <p><code>prefix={prefix-lengths}</code> Specifies the prefix length for the subnet of n IPv6 address. Example: <pre>set net 3 v6ip=2001:f18::50 prefix=32 route=2001:f18::80</pre></p> <p><code>route={route-addresses}</code> Specifies the route address as the default gateway for IPv6. Example: <pre>set net 3 v6ip=2001:f18::50 prefix=32 route=2001:f18::80</pre></p> <p><code>v6ip={IPv6-addresses}</code> Specifies the IPv6 address. If you specify the address using the reserved word "dhcp" (dynamic addressing via existing DHCP server), or if there is no value, IPv6 will be disabled.</p>

Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller. Example: <code>set net 3 v6ip="" -r -y</code></p> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n.) Example: <code>set net 3 v6ip="" -r -y</code></p>
---------	---

4.1.88 Set Partition

Configures a partition.

Applicable to	ASR-5300I
Syntax	<pre>set partition [partition-ID] [name={partition-name}] [min={minimal-reserve-size}]</pre> <p>Short form: <code>set part</code></p>
Parameters	<p><code>index</code> Specifies the logical drive or volume index.</p> <hr/> <p><code>ld lv</code> Specifies the logical drive or logical volume.</p> <hr/> <p><code>min={minimal-reserve-size}</code> Specifies the minimum logical volume capacity reserve for the partition in MB (default) or GB. Example: <code>set part 00000000000000001 name=P2 min=20GB</code></p> <hr/> <p><code>name={Alias-name}</code> Specifies the name of the partition. Example: <code>set part ld 1 1 name=Part#1</code></p> <hr/> <p><code>name={partition-name}</code> Specifies the new name for the partition. Example: <code>set part 00000000000000001 name=Part-1</code></p> <hr/> <p><code>part={index}</code> Specifies the partition. If not specified, the new partition would be divided from the whole LD, LV or partition index 0.</p> <hr/> <p><code>partition-ID</code> Specifies the partition by its ID.</p>

Note! *The minimal reserve size can be applied only to thin-provisioning and cannot be smaller than the size in use.*



4.1.89 Set Partition Expand

Expands the capacity of a partition.

Applicable to	ASR-5300I
Syntax	<pre>set partition expand [partition-ID] [size={expand-size}] Short form: set part expand</pre>
Parameters	<pre>partition-ID Specifies the partition by its ID. size={expand-size} Specify the expand size followed by MB or GB (default in MB) for partition expansion. If the parameter is not specified, the maximum available size will be used. Example: set part expand 0000000000010101 size=10GB</pre>

4.1.90 Set Partition Purge

Configures the purge rule of a partition.

Applicable to	ASR-5300I
Syntax	<pre>set partition purge [partition-ID] [number] [rule-type] Short form: set part purge</pre>
Parameters	<pre>number Specifies the number of purge rule triggers. partition-ID Specifies the partition by its ID. rule-type Specifies the purge rule type. Value: count (number of images), hour (time before image expiration), day, week. Example: set part purge 0000000000010101 128 count Example: set part purge 0000000000010101 7 day</pre>

4.1.91 Set Partition Reclaim

Reclaims the space for a partition.

Applicable to	ASR-5300I
Syntax	<pre>set partition reclaim [partition-ID] Short form: set part reclaim</pre>
Parameters	<pre>partition-ID Specifies the partition by its ID. Example: set part reclaim 0000000000010101</pre>

4.1.92 Set Password

Specifies the controller password.

Applicable to	ASR-5300I
Syntax	<code>set password [password={secret},{new-password}]</code>
Parameters	<p><code>password={secret},{new-password}</code> Specifies the new password. You need to enter the existing password followed by the new password. To remove the existing password, enter a zero-length string or a pair of single/double quote characters. If no parameter is specified, a prompt will ask you to enter the new password twice (for confirmation). Example: <code>set password password=,new</code> <code>set password password="",new</code> (Sets a password for a subsystem without password) Example: <code>set password password=logical-drive,</code> <code>set password password=logical-drive,''</code> (Replaces the password with the original subsystem password)</p>

4.1.93 Set Replication

Configures a replication job.

Applicable to	ASR-5300I
Syntax	<pre>set replica [volume-pair-ID] [op={operation}] [priority={level}] [name={replication-job-name}] [desc={description}] [timeout={value}]</pre>
Parameters	<p>desc={description} Changes the description of the replication job. Example: <pre>set replica 00000000000000001 name=VM-2 desc="Vol- ume Mirror for production"</pre></p> <p>name={replication-job-name} Changes the name of the replication job.</p> <p>op={operation} Specifies the operation of the replication job. Value: pause, resume, sync, async, split, switch. You can only use pause and resume for replications jobs of volume-copies.</p> <ul style="list-style-type: none">■ Pause / Resume: While copy or sync operation is in progress, you can pause or resume the operation.■ Example: <pre>set replica 00000000000000001 op=pause</pre>■ Sync: You can sync the source volume to the target volume when they are in the split state. After being synced, the volume mirror pair will return to the mirrored state.■ Async: You can sync the source volume at a specific time to the target volume. After being asynced, volume pair will return to the split state, and the target will become the full backup of the source volume at the specified time. (Async acts like Sync then Split Immediately)■ Split: You can split a mirrored volume pair, and allow mapping the target volume.■ Switch: Switches the roles in volume pair. The target will become source volume and the source will become the volume-mirror target. <p>priority={level} Specifies the priority of existing replication job. Value: low, normal and high. Example: <pre>set replica 00000000000000001 op=async prior- ity=low</pre></p> <p>timeout={value} Specifies the timeout period of adaptive split in minutes. The parameter is only used for synchronous volume mirror setting, Values (in minutes): 10, 30 (default), 60, 90, 120, max. Example: <pre>set replica 00000000000000001 timeout=120</pre></p> <p>Volume-Pair-ID Specifies the replication job by its ID.</p>

4.1.94 Set RS232

Configures the RS-232 interface.

Applicable to	ASR-5300I
Syntax	<code>set rs232 [port] [baud={value}] [term={switch}]</code>
Parameters	<p><code>baud={value}</code> Specifies the RS232 baud rate: 2400, 4800, 9600, 19200, 38400. Example: <code>set rs232 com1 baud=38400</code></p> <hr/> <p><code>port</code> Specifies the RS-232 port number: com1, com2.</p> <hr/> <p><code>term={switch}</code> Enables or disables the terminal emulation: enable, disable. Example: <code>set rs232 com2 term=enable</code></p>

4.1.95 Set SED Erase

Set to quick erase the specified SED disk.

Applicable to	ASR-5300I
Syntax	<code>set sed erase [disk-index]</code>
Parameters	<p><code>disk-index:</code> Specify the dedicated physical disk drive to configure. Example: <code>set sed erase 1</code></p>

4.1.96 Set SED Password

Set or change the SED password (A-Key).

Applicable to	ASR-5300I
Syntax	<code>set sed password [[password={password},{new-password}] [keyfile={keyfile},{new-keyfile}]</code>
Parameters	<p>If no parameter is specified, a prompt will appear asking the user to enter the new password and confirm (will be asked twice to confirm).</p> <p>To remove an existing password, specify a zero-length string, or with a pair of single/double quote characters. <code>password={password},{new-password}:</code> Specify the original and new changed password string for setting. Provide new password without prompt and double confirm.</p> <p><code>keyfile={keyfile},{new-keyfile}:</code> Specify the original and new changed key file name and path for setting.</p>

Note! *The maximum length of SED password is 32.*



Ex. set sed password

Ex. set sed password password=AbCd,XyZ

Ex. set sed password keyfile=/home/old-a.key,/home/new-a.key

4.1.97 Set Session

Switches the current operation environment to another session.

Applicable to	ASR-5300I
Syntax	<code>set session [device-index]</code>
Parameters	<code>device-index</code> Specifies the device index for the operational session switching.

4.1.98 Set Snapshot Image

Configures a snapshot image.

Applicable to	ASR-5300I
Syntax	<code>set snapshot-image [snapshot-image-ID]</code> <code>[name={snapshot-image-name} [desc={description}]</code> Short form: <code>set si</code>
Parameters	<code>desc={description}</code> Changes the description of the snapshot image. Example: <code>set si 00000000000010101 desc="The snapshot was token for bare-metal restore"</code> <code>name={snapshot-image-name}</code> Specifies the name of the snapshot image. <code>snapshot-image-ID</code> Specifies a snapshot image by its ID.

4.1.99 Set Snapshot Image Rollback

Recovers (rolls back) a snapshot image.

Applicable to	ASR-5300I
Syntax	<code>set snapshot-image rollback [snapshot-image-ID]</code> <code>[-y]</code> Short form: <code>set si rollback</code>
Parameters	<code>snapshot-image-ID</code> Specifies the snapshot image.
Options	<code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with y or n.) Example: <code>set si rollback 00000000000010101 -y</code>

4.1.100 Set SNMPtrap

Configures the SNMP trap service.

Applicable to	ASR-5300I
Syntax	<code>set snmptrap [service={switch}] [severity={severity-type}] [testevent={switch}]</code>
Parameters	<p><code>service={switch}</code> Enables or disables the SNMP trap service. Valid values: enable (default), disable. Example: <code>set snmptrap service=disable</code></p> <hr/> <p><code>[severity={severity-type}]</code> Specifies the severity type that triggers the SNMP trap for this receiver. Valid values: notification (default), warning, critical. Note: "Notification" includes notification, warning, and critical events. "Warning" includes warning and critical events. "Critical" includes only critical events. <code>testevent={switch}</code> Posts a test event that triggers the SNMP service. Valid values: enable, disable (default). Example: <code>set snmptrap severity=critical testevent=enable</code></p>

4.1.101 Set SSD-Cache Add

Adds one or a list of SSDs to the SSD cache pool.

Applicable to	ASR-5300I
Syntax	<code>set ssd-cache add disk={disk-list}[-y]</code>
Parameters	<p><code>disk={disk-list}</code>: Add specific SSD disks with a comma-separated list. <code>-y</code>: Execute this command without prompt. If this parameter not specified, it would prompt a warning message and ask user to confirm. ('y' or 'n'). This command will be ignored if the firmware does not need to reset controller to take effect. Example: <code>set ssd-cache add disk=3,4 -y</code></p>

4.1.102 Set SSD-Cache Remove

Removes one or a list of SSDs from the SSD cache pool.

Applicable to	ASR-5300I
Syntax	<code>set ssd-cache remove disk={disk-list}</code>
Parameters	<p><code>disk={disk-list}</code>: Remove specific SSD disks with a comma-separated list. Example: <code>set ssd-cache remove disk=1,2</code></p>

4.1.103 Set SSD-Cache SED Disable

Disables the SED function on SSD cache pool

Applicable to	ASR-5300I
Syntax	<code>set ssd-cache sed disable [password={password} keyfile={keyfile}]</code>
Parameters	<p>password={password}: Specify the setted local A-key to disable SSD cache pool SED function.</p> <p>keyfile={keyfile}: Specify the setted local A-key file path and name to disable SSD cache pool SED function.</p> <p>Example: <code>set ssd-cache sed disable password=AbCd</code></p> <p>Example: <code>set ssd-cache sed disable keyfile=/home/ssd.key</code></p>

4.1.104 Set SSD-Cache SED Enable

Enables the SED function on SSD cache pool

Applicable to	ASR-5300I
Syntax	<code>set ssd-cache sed enable [password={password} keyfile={keyfile}]</code>
Parameters	<p>password={password}: Specify the local A-key to enable SSD cache pool SED function. NOTE: If global A-key exists, this parameter could not be setting.</p> <p>keyfile={keyfile}: Specify the local A-key file name and path to enable SSD cache pool SED function.</p>

Note! *If global A-key exists, this parameter can not be configured.*



Ex. set ssd-cache sed enable

Ex. set ssd-cache sed enable password=AbCd

Ex. set ssd-cache sed enable keyfile=/home/ssd.key

4.1.105 Set SSD-Cache SED Unlock

Unlocks the locked SED function on SSD cache pool.

Applicable to	ASR-5300I
Syntax	<code>set ssd-cache sed unlock [password={password} keyfile={keyfile}]</code>
Parameters	<p>password={password}: Specify the A-key to unlock SED function.</p> <p>keyfile={keyfile}: Specify the A-key file path and name to unlock SSD cache pool.</p> <p>Example: <code>set ssd-cache sed unlock password=AbCd</code></p> <p>Example: <code>set ssd-cache sed unlock keyfile=/home/ld.key</code></p>

4.1.106 Set SSD-Cache Service

Toggle SSD cache pool function

Applicable to	ASR-5300I
Syntax	<code>set ssd-cache service {switch}</code>
Parameters	<code>{switch}</code> : Toggle to enable or disable SSD cache pool function Enables or disables the <code>ssd-cache</code> service. Valid values: <code>enable</code> , <code>disable</code> . Example: <code>set ssd-cache service enable</code>

4.1.107 Set Task

Aborts tasks in progress.

Applicable to	ASR-5300I
Syntax	<code>set task [Task-IDs] [-a]</code>
Parameters	<code>Task-IDs</code> Specifies one or several tasks by its ID. You can view the task IDs with <code>show task</code> .
Options	<code>-a</code> Aborts the task. Example: <code>set task 2 -a</code>

4.1.108 Show Access Mode

Shows the management interface: FC/SCSI channels (in-band) or Ethernet (out-of-band).

Applicable to	ASR-5300I
Syntax	<code>show access-mode</code>
Parameters	N/A

4.1.109 Show Array

Shows the connected drive arrays.

Applicable to	ASR-5300I
Syntax	<code>show array</code>
Parameters	N/A

Note!  *The result of discovering arrays by `show array` will be kept by the CLI and you can later see the results for further usage. When you run `show array` again, the buffered results will be replaced by the new results.*

4.1.110 Show Cache

Shows the cache write policy of the controller.

Applicable to	ASR-5300I
Syntax	<code>show cache</code>
Parameters	N/A

4.1.111 Show Channel

Shows the configurations of host and drive channels.

Applicable to	ASR-5300I
Syntax	<code>show channel</code>
Short form	<code>show ch</code>
Parameters	N/A

4.1.112 Show CLI

Shows the CLI configurations (version, name, copyright, revision, build number)

Applicable to	ASR-5300I
Syntax	<code>show cli</code>
Parameters	N/A

4.1.113 Show Configuration

Shows the entire system configurations.

Applicable to	ASR-5300I																																													
Syntax	<code>show configuration</code> Short form: <code>show config</code>																																													
Parameters	N/A																																													
Note	This command returns the results of the following commands in sequential order. <table border="1"><tr><td></td><td></td><td><code>show cli</code></td></tr><tr><td><code>show device</code></td><td><code>show net</code></td><td><code>show rs232</code></td></tr><tr><td><code>show access-mode</code></td><td><code>show enclosure</code></td><td><code>show ctrl</code></td></tr><tr><td><code>show ctrl date</code></td><td><code>show ctrl parm</code></td><td><code>show ctrl redundancy</code></td></tr><tr><td><code>show ctrl trigger</code></td><td><code>show ctrl uid</code></td><td><code>show cache</code></td></tr><tr><td><code>show shutdown-status</code></td><td><code>show task</code></td><td><code>show schedule</code></td></tr><tr><td><code>show disk</code></td><td><code>show disk parm</code></td><td><code>show disk saving</code></td></tr><tr><td><code>show disk spare</code></td><td><code>show channel</code></td><td><code>show host</code></td></tr><tr><td><code>show wwn</code></td><td><code>show iqn</code></td><td><code>show isns</code></td></tr><tr><td><code>show trunk</code></td><td><code>show ld</code></td><td><code>show ld deleted</code></td></tr><tr><td><code>show ld saving</code></td><td><code>show stripe</code></td><td><code>show license</code></td></tr><tr><td><code>show lv</code></td><td><code>show lv ld</code></td><td><code>show lv threshold</code></td></tr><tr><td><code>show part</code></td><td><code>show purge</code></td><td><code>show vv</code></td></tr><tr><td><code>show map</code></td><td><code>show rd</code></td><td><code>show remote</code></td></tr><tr><td><code>show si</code></td><td><code>show replica</code></td><td><code>show event</code></td></tr></table>			<code>show cli</code>	<code>show device</code>	<code>show net</code>	<code>show rs232</code>	<code>show access-mode</code>	<code>show enclosure</code>	<code>show ctrl</code>	<code>show ctrl date</code>	<code>show ctrl parm</code>	<code>show ctrl redundancy</code>	<code>show ctrl trigger</code>	<code>show ctrl uid</code>	<code>show cache</code>	<code>show shutdown-status</code>	<code>show task</code>	<code>show schedule</code>	<code>show disk</code>	<code>show disk parm</code>	<code>show disk saving</code>	<code>show disk spare</code>	<code>show channel</code>	<code>show host</code>	<code>show wwn</code>	<code>show iqn</code>	<code>show isns</code>	<code>show trunk</code>	<code>show ld</code>	<code>show ld deleted</code>	<code>show ld saving</code>	<code>show stripe</code>	<code>show license</code>	<code>show lv</code>	<code>show lv ld</code>	<code>show lv threshold</code>	<code>show part</code>	<code>show purge</code>	<code>show vv</code>	<code>show map</code>	<code>show rd</code>	<code>show remote</code>	<code>show si</code>	<code>show replica</code>	<code>show event</code>
		<code>show cli</code>																																												
<code>show device</code>	<code>show net</code>	<code>show rs232</code>																																												
<code>show access-mode</code>	<code>show enclosure</code>	<code>show ctrl</code>																																												
<code>show ctrl date</code>	<code>show ctrl parm</code>	<code>show ctrl redundancy</code>																																												
<code>show ctrl trigger</code>	<code>show ctrl uid</code>	<code>show cache</code>																																												
<code>show shutdown-status</code>	<code>show task</code>	<code>show schedule</code>																																												
<code>show disk</code>	<code>show disk parm</code>	<code>show disk saving</code>																																												
<code>show disk spare</code>	<code>show channel</code>	<code>show host</code>																																												
<code>show wwn</code>	<code>show iqn</code>	<code>show isns</code>																																												
<code>show trunk</code>	<code>show ld</code>	<code>show ld deleted</code>																																												
<code>show ld saving</code>	<code>show stripe</code>	<code>show license</code>																																												
<code>show lv</code>	<code>show lv ld</code>	<code>show lv threshold</code>																																												
<code>show part</code>	<code>show purge</code>	<code>show vv</code>																																												
<code>show map</code>	<code>show rd</code>	<code>show remote</code>																																												
<code>show si</code>	<code>show replica</code>	<code>show event</code>																																												

4.1.114 Show Controller

Shows the controller configurations.

Applicable to	ASR-5300I
Syntax	<code>show controller</code> Short form: <code>show ctrlr</code>
Parameters	N/A

4.1.115 Show Controller Date

Shows the time, date, and time zone of the controller.

Applicable to	ASR-5300I
Syntax	show controller date Short form: show ctlr date
Parameters	N/A

4.1.116 Show Controller Parameter

Shows the controller parameters.

Applicable to	ASR-5300I
Syntax	show controller parm Short form: show ctlr parm
Parameters	N/A

4.1.117 Show Controller Redundancy

Shows if the redundant controllers are working properly.

Applicable to	ASR-5300I
Syntax	show controller redundancy Short form: show ctlr redundancy
Parameters	N/A

4.1.118 Show Controller Trigger

Shows the event trigger configuration of the controller.

Applicable to	ASR-5300I
Syntax	show controller trigger Short form: show ctlr trigger
Parameters	N/A

4.1.119 Show Controller Uid

Shows the controller unique identifier.

Applicable to	ASR-5300I
Syntax	show controller uid Short form: show ctlr uid
Parameters	N/A

Note! The identifier is by default the serial number of the enclosure.



4.1.120 Show Device

Shows the list of devices (RAID controllers and JBODs)

Applicable to	ASR-5300I
Syntax	<code>show device</code>
Parameters	N/A

Note! You can connect and select subsystems via `connect`.



4.1.121 Show Diagnostic

Shows the result of network diagnosis for remote replication pairs.

Applicable to	ASR-5300I
Syntax	<code>show diagnostic [device-index] [count={packet-amount}] [output={filename}] [-p] [-a]</code>
Parameters	<p><code>device-index</code> Specifies the device index of the remote replication target subsystem. The target subsystem had to be connected in advance. To acquire the device index, use the command “show device”. Example: <code>show diagnostic 2</code></p> <hr/> <p><code>count={packet-amount}</code> Specifies the amount of diagnostic data (64K per packet), Valid values: 1-10000, default is 1.</p> <hr/> <p><code>output={filename}</code> Specify the name of the file for the network diagnostic result. If the file name is not specified, the diagnostic result will only be displayed on screen. Example: <code>show diagnostic 2 output=log.txt</code></p> <hr/> <p><code>-a</code> Aborts running the command.</p> <hr/> <p><code>-p</code> Polls the diagnostic results for uncompleted processes.</p>

4.1.122 Show Disk

Shows the list of disk drives and displays their disk information.

Applicable to	ASR-5300I
Syntax	<code>show disk [disk-index-list ch={ch}]</code>
Parameters	<p>If no parameter is specified, all disk information will be shown.</p> <p><code>disk-index-list</code> Specifies the disks by their indexes. Each item should be separated by a comma. Example: <code>show disk 0,1,2</code></p> <hr/> <p><code>ch={ch}</code> Shows information of all disks on the specified channel. Example: <code>show disk ch=1</code></p>

4.1.123 Show Disk Parameter

Shows disk parameters.

Applicable to	ASR-5300I
Syntax	<code>show disk parm</code>
Parameters	N/A

4.1.124 Show Disk Saving

Shows the power-saving mode status of disk drives.

Applicable to	ASR-5300I
Syntax	<code>show disk saving</code>
Parameters	N/A

4.1.125 Show Disk SMART

Shows disk SMART information of disk drives.

Applicable to	ASR-5300I
Syntax	<code>show disk smart [disk-index-list]</code>
Parameters	Specifies the disks by their indexes. Each item should be separated by a comma. Example: <code>show disk smart 0,1,2</code>

4.1.126 Show Disk Spare

Shows the list of spare disks.

Applicable to	ASR-5300I
Syntax	<code>show disk spare</code>
Parameters	N/A

4.1.127 Show Enclosure

Shows the enclosure configuration.

Applicable to	ASR-5300I
Syntax	<code>show enclosure</code>
Parameters	N/A

Note!



The enclosure information is returned by the SAF-TE (SCSI Accessed Fault Tolerant Enclosures) device and SES (SCSI Enclosure Services) devices embedded in SCSI LVD RAID enclosures or JBODs, including battery status, fan, power supply, temperature sensor and drive slot status.

4.1.128 Show Event

Shows the past events.

Applicable to	ASR-5300I
Syntax	<code>show event [n]</code>
Parameters	<code>n</code> Specifies the number of events. If not specified, all events will be shown.

4.1.129 Show History

Shows past executed commands.

Applicable to	ASR-5300I
Syntax	<code>show history [command-filter]</code>
Parameters	<code>command-filter</code> Shows only the commands matching the filter. If not specified, all previously executed commands will appear. Example: <code>show history set</code> (Shows all commands with "set" in them)

4.1.130 Show Host

Shows the host computer configurations.

Applicable to	ASR-5300I
Syntax	<code>show host [chs]</code>
Parameters	<code>chs</code> Shows the CHS (Cylinder / Head / Sector) of the host-channel supported. If not specified, all configurations of the host will be shown.

4.1.131 Show IQN

Shows the configurations of iSCSI initiator IQNs.

Applicable to	ASR-5300I
Syntax	<code>show iqn</code>
Parameters	N/A

4.1.132 Show iSNS

Shows the configurations of iSNS servers.

Applicable to	ASR-5300I
Syntax	<code>show isns</code>
Parameters	N/A

4.1.133 Show License

Shows the license status of the system.

Applicable to	ASR-5300I
Syntax	<code>show license</code>
Parameters	N/A

4.1.134 Show Logical Drive

Shows the list of logical drives.

Applicable to	ASR-5300I
Syntax	<code>show logical-drive [index-list]</code> Short form: <code>show ld</code>
Parameters	<code>index-list</code> Specifies the logical drives by their indexes. Each item should be separated by a comma. If not specified, all the logical drive information will be shown.

4.1.135 Show Logical Drive Deleted

Shows the list of deleted (but recoverable) logical drives.

Applicable to	ASR-5300I
Syntax	<code>show logical-drive deleted</code> Short form: <code>show ld deleted</code>
Parameters	N/A

4.1.136 Show Logical Drive Saving

Shows the power saving status of logical drives.

Applicable to	ASR-5300I
Syntax	<code>show logical-drive saving</code> Short form: <code>show ld saving</code>
Parameters	N/A

4.1.137 Show Logical Volume

Shows the configurations of logical volumes.

Applicable to	ASR-5300I
Syntax	<code>show logical-volume [lv={LV-IDs}] [-1]</code> Short form: <code>show lv</code>
Parameters	<code>lv={LV-IDs}</code> Specifies the logical volumes. If not specified, the information of all logical volumes will be shown. Example: <code>show lv lv=0000000000010101,0000000000010102</code>
Options	<code>-1</code> Lists detailed information of the logical volume. Example: <code>show lv lv=0000000000010101 -1</code>

4.1.138 Show Logical Volume Logical Drive

Shows the configurations of logical drives inside logical volumes.

Applicable to	ASR-5300I
Syntax	<code>show logical-volume logical-drive [ld={LD-index-list} lv={LV-IDs}] [-1]</code> Short form: <code>show lv ld</code>
Parameters	<code>ld={LD-index-list} lv={LV-IDs}</code> Specifies the logical drives by their indexes. Each item should be separated by a comma. If not specified, information of all logical drives and logical volumes will be shown. Example: <code>show lv ld ld=0,1</code>
Options	<code>-1</code> Lists detailed information of each logical drive. Example: <code>show lv ld -1</code>

4.1.139 Show Logical Volume Threshold

Shows the space thresholds of logical volumes.

Applicable to	ASR-5300I
Syntax	<code>show logical-volume threshold [lv={LV-IDs}]</code> Short form: <code>show lv threshold</code>
Parameters	<code>lv={LV-IDs}</code> Specifies the logical volumes by their indexes. Each item should be separated by a comma. If not specified, tiering of all logical volumes will be shown.

4.1.140 Show Logical Volume Tier

Shows tiering information of logical volumes.

Applicable to	ASR-5300I
Syntax	<code>show logical-volume tier [lv={LV-IDs}]</code> Short form: <code>show lv tier</code>
Parameters	<code>lv={LV-IDs}</code> Specifies the logical volumes by their indexes. Each item should be separated by a comma.

4.1.141 Show Map

Shows host mappings of partitions or channels.

Applicable to	ASR-5300I
Syntax]	<pre>show map [part={partition-IDs} channel={channel-IDs}] [-1] show map [si={snapshot-image-IDs} channel={channel-IDs}]</pre>
Parameters	<p>If no parameter is specified, all host mapping information will be shown.</p> <p>channel={channel-IDs} Specifies the channels.</p> <hr/> <p>part={partition-IDs} Specifies the partitions of which the mappings will be shown by their IDs. Each item should be separated by a comma. Example: show map part=00000000000010101, 00000000000010102</p> <hr/> <p>si={snapshot-image-IDs} Specifies the snapshot image.</p> <hr/> <p>vv={virtual-volume-IDs} Specifies the virtual volumes. Example: show map vv=00000000000010101, 00000000000010102</p>
Options	<p>-1 List detailed information of each record. Example: show map channel=0 -1</p>

4.1.142 Show Net

Shows the configurations of a RAID interface.

Applicable to	ASR-5300I
Syntax	<pre>show net [id={channel-IDs}] [-1]</pre>
Parameters	<p>id={channel-IDs} Specifies the channels by their IDs. Each item should be separated by a comma. If not specified, all network interfaces will be displayed in a list view.</p>
Options	<p>-1 Ask to list detail information of each selected record. Example: show net id=1 -1</p>

4.1.143 Show Partition

Shows the configurations of partitions.

Applicable to	ASR-5300I
Syntax	<code>show partition [part={partition-IDs} lv={LV-IDs}] [-l]</code> Short form: <code>show part</code>
Parameters	<code>index-list</code> Specifies the logical drive / volume index. <code>ld lv</code> Specifies the partitions of the logical drive / logical volume. <code>part={partition-IDs} lv={LV-IDs}</code> Specifies the partitions by their IDs. Each item should be separated by a comma. If not specified, all partition information will be shown. Example: <code>show part part=00000000000000101, 00000000000000102</code>
Options	<code>-l</code> Ask to list detail information of each selected record. Example: <code>show part lv=00000000000000100 -l</code>

4.1.144 Show Partition Purge

Shows the purge rules of partitions.

Applicable to	ASR-5300I
Syntax	<code>show partition purge [lv={LV-IDs}]</code> Short form: <code>show part purge</code>
Parameters	<code>lv={LV-IDs}</code> Specifies the logical volumes of which purge rules will be shown. If not specified, all purge rules will be shown. Example: <code>show part purge lv=00000000000000100</code>

4.1.145 Show Replication

Shows the configurations of replication jobs.

For detailed procedure of creating a remote replication pair for ASR-5300I subsystems, see the Appendix section.

Applicable to	ASR-5300I
Syntax	<code>show replica [id={volume-pair-IDs}] [-l]</code>
Parameters	<p><code>id={volume-pair-IDs}</code> Specifies the replication jobs by their IDs. Each item should be separated by a comma. If not specified, all replication jobs will be shown. Example: <code>show replica id=0000000000010101,0000000000010102</code></p>
Options	<p><code>-l</code> Lists detailed information of each record. Example: <code>show replica -l</code></p>

4.1.146 Show RS232

Shows the configurations of the RS232 interface.

Applicable to	ASR-5300I
Syntax	<code>show rs232</code>
Parameters	N/A

4.1.147 Show Schedule

Lists scheduled tasks.

Applicable to	ASR-5300I
Syntax	<code>show schedule</code>
Parameters	N/A

4.1.148 Show Shutdown Status

Shows the progress of shutdown operation.

Applicable to	ASR-5300I
Syntax	<code>show shutdown status</code>
Parameters	N/A

4.1.149 Show Snapshot Image

Shows configurations of snapshots.

Applicable to	ASR-5300I
Syntax	<pre>show snapshot-image [si={snapshot-image-IDs} part={partition-IDs} lv={LV-IDs}] [-l] Short form: show si</pre>
Parameters	<pre>si={snapshot-image-IDs} part={partition-IDs} lv={LV-IDs}</pre> <p>Specifies the snapshot images by their IDs. Each item should be separated by a comma. If not specified, configurations of all snapshots will be shown.</p> <p>Example:</p> <pre>show si si=00000000000010101,00000000000010102</pre>
Options	<pre>-l</pre> <p>Ask to list detail information of each selected record.</p> <p>Example:</p> <pre>show si lv=000000000000000001 -l</pre>

4.1.150 Show SNMPtrap

Shows configurations of the SNMP trap service.

Applicable to	ASR-5300I
Syntax	<pre>show snmptrap</pre>

4.1.151 Show SSD-Cache

Shows the member disks of the SSD cache pool

Applicable to	ASR-5300I
Syntax	<pre>show ssd-cache</pre>
Parameters	NA

4.1.152 Show Statistics

Shows status and performance of hardware components.

Applicable to	ASR-5300I
Syntax	<code>show stat [object] [target={specified-objects}] [type={stat-type}] [poll={period}] [count={number}] [output={filename}]</code>
Parameters	<p><code>object</code> Specifies the type of the hardware component.</p> <p><code>target={specified-objects}</code> Specifies the hardware component.</p> <p><code>type={stat-type}</code> Specifies the display index for the statistics.</p> <p>Valid values for <code>object</code>, <code>target</code>, and <code>type</code> are as follows:</p> <ul style="list-style-type: none"> ■ Controller IOPS and throughput: Object: <code>ctrlcontroller (ctrl)</code>. Target: <code>slotA, slotB, all (default)</code>. Type: <code>io (read and write requests), data (read and write data in bytes), all (default)</code>. ■ Memory usage (percentage of dirty cache): Object: <code>mem</code>. Target: <code>all</code>. Type: <code>all</code>. ■ Disk usage: Object: <code>disk</code>. Target: <code>disk-IDs, all (default)</code>. Type: <code>io (read and write requests), data (read and write in bytes), all</code>. <p>Example: <code>show stat controller type=data count=60</code></p> <p>Example: <code>show stat mem</code></p> <p>Example: <code>show stat disk target=1,2,3,4 type=all count=60</code></p> <hr/> <p><code>poll={period}</code> Specifies the polling period between each command for retrieving statistic data. Values (sec): 1 (default), 5, 10, 20, 30, 60</p> <p>Example: <code>show stat ctrl target=slotA type=io poll=10 count=10 output=log.txt</code></p> <hr/> <p><code>count={number}</code> Specifies the number of polling commands. The default is 1.</p> <p>Example: <code>show stat controller type=data count=60</code></p> <hr/> <p><code>output={filename}</code> Specifies the name of the log file. If not specified, the log file will not be generated.</p> <p>Example: <code>show stat ctrl target=slotA type=io poll=10 count=10 output=log.txt</code></p>

4.1.153 Show Stripe

Shows the stripe block size for a RAID level.

Applicable to	ASR-5300I
Syntax	<code>show stripe [RAID-level]</code>
Parameters	RAID-level Specifies the RAID level. Value: r0 (RAID 0), r1 (RAID 1), r3 (RAID 3), r5 (RAID 5), r6 (RAID 6). If not specified, the information for all RAID levels will be shown.

4.1.154 Show Task

Shows all tasks in progress.

Applicable to	ASR-5300I
Syntax	<code>show task</code>
Parameters	N/A

4.1.155 Show Trunk

Shows the list of trunk groups.

Applicable to	ASR-5300I
Syntax	<code>show trunk</code>
Parameters	N/A

Note! This command is for iSCSI subsystems only.



4.1.156 Show WWN

Shows the list of WWNs.

Applicable to	ASR-5300I
Syntax	<code>show wwn</code>
Parameters	N/A

Note! This command is not supported in iSCSI interface models.



4.1.157 Shutdown Controller

Shuts the RAID controller down and stops I/O processing.

Applicable to	ASR-5300I
Syntax	<code>shutdown controller [-y]</code> Short form: <code>shutdown ctlr</code>
Parameters	N/A
Options	-y Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code> .)

4.1.158 Update Firmware

Updates the controller firmware.

Applicable to	ASR-5300I
Syntax	<code>update fw [filename] [-y] [-u -r]</code>
Parameters	<code>fw_filename</code> Specifies the new firmware file.
Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller.</p> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code>.)</p> <p><code>-u</code> Automatically applies the firmware upgrade to the redundant controller.</p>

4.1.159 Update Firmware and Boot Record

Updates the controller firmware and boot record.

Applicable to	ASR-5300I
Syntax	<code>update fwbr [fw_filename] [br_filename] [-y] [-u -r]</code>
Parameters	<p><code>fw_filename</code> Specifies the new firmware file.</p> <p><code>br_filename</code> Specifies the new boot record file.</p>
Options	<p><code>-r</code> Resets the controller after running the command. If not specified, a prompt will ask you to reset the controller.</p> <p><code>-y</code> Executes this command without a prompt. If not specified, a prompt will ask you to confirm. (Answer with <code>y</code> or <code>n</code>.)</p> <p><code>-u</code> Automatically applies the firmware upgrade to the redundant controller.</p>

4.2 Descriptions of Options

Refer to command descriptions for actual interpretations and examples.

Option	Description
-a	Aborts running the command.
-b	Runs the command in background.
-d	Deletes or clears item(s).
-f	Specifies a file name. (See the following note)
-i	Interrupts running the command if an error is encountered.
-l	Lists detailed information of each item returned by the command.
-n	Does not store the password.
-o	Specifies the output file name.
-p	Polls the diagnostic results for uncompleted processes.
-r	Resets the RAID controller after running the command.
-s	Starts/stops perpetual cloning process.
-t	Activates time-stamp.
-u	Activates automatic rolling firmware upgrade.
-y	Automatically replies the prompt with "Yes."

Appendix **A**

Creating a Remote Replication Pair Using CLI

(Multiple Session Example)

Note! *The procedure in this section is applicable only to ASR-5300I series.*



A.1 Handling Multiple Subsystems with CLI (Remote Replication)

Although basically CLI is designed to manage only one subsystem at a time through serial interface, it can still be used to control multiple subsystems. To do so, users need to switch between management targets, treating each target (subsystem) as a “session.”


One example of multiple session usage is remote replication, which is described in detail in this section. The overall procedure is as follows.

1. Preparing the Environment
2. Connecting the Subsystems
3. Assigning a Target Subsystem Partition as the Remote Disk
4. Confirming the Remote Disk in the Source Side
5. Pairing the Remote Disk with a Source Subsystem Partition

A.2 Preparing the Environment

Prepare the following environment before you start creating a remote replication pair.

Devices	<ul style="list-style-type: none"> ■ Source Subsystem ■ Target Subsystem ■ Management Computer with CLI terminal <p>Connect the management computer to both the source subsystem and the target subsystem through Command Line Interface through the Ethernet management cable.</p>
---------	--



(The IP addresses and IDs are only shown as examples)

License	<p>A remote replication license must be present for both the source and the target subsystem.</p> <p>To view the license information, you may:</p> <ul style="list-style-type: none"> ■ Use the Show License CLI command. OR ■ Go to the Help > License Information menu in SANWatch Commander.
Firmware	<p>The firmware version must be 3.86 or later for both the source and the target subsystem.</p> <p>To view the firmware version:</p> <ul style="list-style-type: none"> ■ Go to View System Information → Firmware Version on the terminal interface. OR ■ Open SANWatch and go the Storage Manager and select the Configuration List tab at the bottom.
Target Volume	<ul style="list-style-type: none"> ■ The target logical volume size must be as large as or larger than that of the source logical volume. ■ The target volume (partition) cannot be mapped. ■ The target volume (partition) cannot include snapshot images.
Source Volume Space	<p>When conducting asynchronous remote replication, special storage space considerations should be taken into account to avoid any data errors in the event of network interruptions between the source and target sites.</p> <p>In the unlikely event that data transmissions between source and target are interrupted, the source volume will take snapshots of incoming data to prepare for replication at a later point in time when network transmissions are resumed. The extra required space for these snapshots will have to be reserved in advance.</p> <p>To ensure successful remote replication in any scenario, users are advised to reserve extra space in the source logical volume equal to the size of the source partition. For example, if a source logical volume consists of one partition of 50GB, the source logical volume in which the partition resides needs to have a size of 100GB if the partition is needed for asynchronous remote replication.</p>

A.3 Connecting the Subsystems

-
- 1. Connect the Source Subsystem**

Enter the “connect” command, followed by the source subsystem’s IP address.

```
RAIDCmd:> connect 192.168.11.1
```

The source subsystem’s model name and ID will be returned.

```
CLI: Successful: Device(UID:2d687, Name:, Model: ASR-5300I-16A1E) selected. Return: 0x0000
```

Note down the ID of the source subsystem (2d687 in this case).

 - 2. Connect the Target Subsystem**

Enter the “connect” command, followed by the target subsystem’s IP address.

```
RAIDCmd:> connect 192.168.11.2
```

The target subsystem’s model name and ID will be returned.

```
CLI: Successful: Device(UID:9d9de, Name:, Model: ASR-5300I-16A1E) selected. Return: 0x0000
```

Note down the ID of the target subsystem (9d9de in this case).

 - 3. List the Connected Subsystems**

Enter the “show device” command.

```
RAIDCmd:> show device
```

The currently connected devices will be listed. The Index number “1*” shows the currently active session, which is the target subsystem (192.168.11.2) in this example. Note that the source subsystem’s session Index is “0.” (Will be used later)
-

Index	ID	Model	Name	Connected-IP	JBOD-ID	Capacity	Service-ID
0	2D687	ASR-5300I-16A1E	---	192.168.11.1	---	203.97 GB	1234567
1*	9D9DE	ASR-5300I-16A1E	---	192.168.11.2	---	203.97 GB	7985630

```
CLI: Successful: 2 device(s) found Return: 0x0000
```

A.4 Assigning a Target Subsystem Partition as the Remote Disk

- List Partitions in the Target Subsystem**

Enter the “show partition” command.
RAIDCmd:> show part
All available partitions in the currently connected subsystem (target subsystem in this case) will be listed. Select the partition to be paired and note down its ID (19F646C23C20C7B5 in this case).


ID	Name	LV-ID	Size	Used	Min-reserve

19F646C23C20C7B5	P0	2B7DA4A203508D38	66492	66492	66492

CLI: Successful: 1 partition(s) shown
Return: 0x0000

- Assign a Partition as the Remote Disk**

Enter the “set remote” command, followed by the partition ID (19F646C23C20C7B5 in this case) and the source subsystem ID (2d687 in this case).
RAIDCmd:> set remote part 19F646C23C20C7B5 2D687
The target subsystem’s partition has now been specified as the remote disk for the source subsystem.
CLI: Successful
Return: 0x0000



A.5 Confirming the Remote Disk in the Source Side

1. **Switch to the Source Subsystem** Enter the “set session” command, followed by the source subsystem session ID, 0.
RAIDCmd:> set session 0
The session will be switched to the source subsystem (2d687 in this case).
CLI: Successful: Device (UID:2d687, Name:, Model: ASR-5300I-16A1E)
Return: 0x0000

2. **Confirm the Remote Disk** Enter the “show remote-disk” command.
RAIDCmd:> show rd
The list of remote disks for the source subsystem will appear. Confirm that the target subsystem partition ID (19F646C23C20C7B5 in this case) is recognized as the remote disk.

Index	ID	Device	LD/PART	LD ID	Partition	Size
0	19F646C23C20C7B5	9D9DE	PART	3C20C7B5 0	66492MB	

CLI: Successful: 1 partition(s) shown
Return: 0x0000

A.6 Pairing the Remote Disk with a Source Subsystem Partition

1. **List Partitions in the Target Subsystem** Enter the “show partition” command.
RAIDCmd:> show part
All available partitions in the currently connected subsystem (source subsystem in this case) will be listed. Select the partition to be paired and note down its ID (752E5AEE52812E9 in this case).

ID	Name	LV-ID	Size	Used	Min-reserve

752E5AEE52812E96	p0	47AF09F47724375C	66492	66492	66492

CLI: Successful: 1 partition(s) shown
Return: 0x0000

2. **Pair the Source and the Target** Enter the “create replication” command. You need to specify the following parameters.
 - Source partition (752E5AEE52812E9 in this case)
 - Target partition (19F646C23C20C7B5 in this case)
 - Replication pair name (test in this case)
 - Mirror type (async (asynchronous) in this case)
 - Incremental recovery option (enabled in this case)
 RAIDCmd:> create replica test part
752E5AEE52812E96 part 19F646C23C20C7B5
type=async incremental=enable
If the remote replication pair has been created, the “successful” message should appear.
CLI: Successful
Return: 0x0000

3. **Confirm the Remote Replication Status** Enter the “show replication” command.
RAIDCmd:> show replica
The list of existing replication pairs will appear. Note down the ID of the remote replication pair (6F54FD043A842095 in this case).


Pair-ID	Name	Source	Target	Status

6F54FD043A842095	test	(PART) 752E5AEE52812E96	(PART) 19F646C23C20C7B5	Async

CLI: Successful: 1 replication job(s) shown
Return: 0x0000

Subsystem Source (ID:2D687)

IP: 192.168.11.1



ADVANTECH

Enabling an Intelligent Planet

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2015