



Allen-Bradley

PowerFlex®
Communications

BACnet MS/TP Adapter

**22-COMM-B
FRN 1.xxx**

User Manual

**Rockwell
Automation**

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. *Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls* (Publication SGI-1.1 available from your local Rockwell Automation sales office or online at <http://www.rockwellautomation.com/literature>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc. is prohibited.

Throughout this manual, when necessary we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

Important: Identifies information that is critical for successful application and understanding of the product.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid the hazard, and recognize the consequences.



Shock Hazard labels may be located on or inside the equipment (e.g., drive or motor) to alert people that dangerous voltage may be present.



Burn Hazard labels may be located on or inside the equipment (e.g., drive or motor) to alert people that surfaces may be at dangerous temperatures.

Allen-Bradley, PowerFlex, DriveExplorer, DriveExecutive, DriveTools SP, and ControlFLASH are either registered trademarks or trademarks of Rockwell Automation, Inc.

BACnet is a registered trademark of American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE). Windows and Microsoft are registered trademarks of Microsoft Corporation.

Summary of Changes

The information below summarizes the changes made to this manual since its last release (May 2006):

| Description of Changes | Page(s) |
|--|---------------------------|
| In the "Quick Start" section: <ul style="list-style-type: none">• In Step 4, removed connecting the adapter to the network.• In Step 5, added two new sub-steps (B and C).• Added a new Step 6 "Connect the adapter to the network."• Incremented old Steps 6 and 7 to Steps 7 to 8. | 1-6 |
| Reorganized Chapter 2: <ul style="list-style-type: none">• Moved the "Connecting the Adapter to the Drive" section after the "Commissioning the Adapter" section.• Moved the "Applying Power" section after the "Connecting the Adapter to the Drive" section.• In the "Applying Power" section, added three new subsections:<ul style="list-style-type: none">– "Start-Up Status Indications"– "Verifying/Setting Key Adapter Parameters"– "Configuring/Verifying Key Drive Parameters."• Moved the "Connecting the Drive/Adapter to the Network" section to the end of the chapter. | Chapter 2 |
| In Chapter 3, moved the "Setting the Device Instance Number" section after the "Using the PowerFlex 7-Class HIM" section. Included additional information to the "Setting the Device Instance Number" section. | 3-3 |
| Added new Appendix D "Routing Capability for Networked Drives." | D-1 |

Table of Contents

| | |
|------------------|--|
| Preface | About This Manual |
| | Related Documentation P-1 |
| | Rockwell Automation Support P-2 |
| | Conventions Used in this Manual P-2 |
| Chapter 1 | Getting Started |
| | Components 1-1 |
| | Features 1-2 |
| | Compatible Products 1-3 |
| | Required Equipment 1-3 |
| | Safety Precautions 1-4 |
| | Quick Start 1-6 |
| | Status Indicators 1-7 |
| Chapter 2 | Installing the Adapter |
| | Preparing for an Installation. 2-1 |
| | Commissioning the Adapter. 2-1 |
| | Connecting the Adapter to the Drive 2-6 |
| | Applying Power 2-9 |
| | Connecting the Drive/Adapter to the Network 2-11 |
| Chapter 3 | Configuring the Adapter |
| | Configuration Tools 3-1 |
| | Using the PowerFlex 4-Class HIM 3-2 |
| | Setting the Device Instance Number 3-3 |
| | Setting a Comm Loss Action 3-5 |
| | Setting the Comm Loss Time. 3-6 |
| | Setting the Baud Rate. 3-7 |
| | Resetting the Adapter. 3-7 |
| | Viewing the Adapter Configuration 3-8 |
| Chapter 4 | Using BACnet Objects |
| | Understanding BACnet Objects 4-1 |
| | Basic Drive Operation on the Network 4-2 |
| | Supported BACnet Objects 4-3 |

| | | |
|-------------------|--|-----|
| Chapter 5 | Troubleshooting | |
| | Understanding the Status Indicators | 5-1 |
| | PORT Status Indicator | 5-2 |
| | MOD Status Indicator | 5-3 |
| | NET A Status Indicator | 5-4 |
| | NET B Status Indicator | 5-4 |
| | Adapter Diagnostic Items. | 5-5 |
| | Viewing and Clearing Events. | 5-6 |
| | | |
| Appendix A | Specifications | |
| | Communications | A-1 |
| | Electrical | A-1 |
| | Mechanical. | A-1 |
| | Environmental | A-2 |
| | Regulatory Compliance | A-2 |
| | | |
| Appendix B | Adapter Parameters | |
| | About Parameter Numbers. | B-1 |
| | Parameter List | B-1 |
| | | |
| Appendix C | Protocol Implementation Conformance Statement (PICS) | |
| | Product Description | C-1 |
| | BACnet Standardized Device Profile (Annex L). | C-1 |
| | List all BACnet Interoperability Building Blocks Supported (Annex K) | C-1 |
| | Segmentation Capability | C-1 |
| | Standard Object Types Supported | C-2 |
| | Data Link Layer Options | C-3 |
| | Device Address Binding | C-3 |
| | Networking Options. | C-3 |
| | | |
| Appendix D | Routing Capability for Networked Drives | |
| | | |
| | Glossary | |
| | | |
| | Index | |

About This Manual

| Topic | Page |
|---|---------------------|
| Related Documentation | P-1 |
| Rockwell Automation Support | P-2 |
| Conventions Used in this Manual | P-2 |

Related Documentation

| For: | Refer to: | Publication |
|---|---|------------------------------|
| DriveExplorer™ | http://www.ab.com/drives/driveexplorer , and DriveExplorer online Help (installed with the software) | — |
| DriveTools™ SP (includes DriveExecutive™) | http://www.ab.com/drives/drivetools , and DriveTools SP online Help (installed with the software) | — |
| HIM | <i>HIM Quick Reference</i> | 22HIM-QR001... |
| PowerFlex® 4 Drive | <i>PowerFlex 4 User Manual</i> <i>PowerFlex 4 Quick Start</i> | 22A-UM001... 22A-QS001... |
| PowerFlex® 40 Drive | <i>PowerFlex 40 User Manual</i> <i>PowerFlex 40 Quick Start</i> | 22B-UM001... 22B-QS001... |
| PowerFlex® 400 Drive | <i>PowerFlex 400 User Manual</i> | 22C-UM001... |

Documentation can be obtained online at
<http://www.rockwellautomation.com/literature>.

Rockwell Automation Support

Rockwell Automation, Inc. offers support services worldwide, with over 75 sales/support offices, over 500 authorized distributors, and over 250 authorized systems integrators located throughout the United States alone. In addition, Rockwell Automation, Inc. representatives are in every major country in the world.

Local Product Support

Contact your local Rockwell Automation, Inc. representative for:

- Sales and order support
- Product technical training
- Warranty support
- Support service agreements

Technical Product Assistance

If you need to contact Rockwell Automation, Inc. for technical assistance, please review the information in [Chapter 5, Troubleshooting](#) first. If you still have problems, then access the Allen-Bradley Technical Support web site at www.ab.com/support/abdrives.

Conventions Used in this Manual

The following conventions are used throughout this manual:

- Parameter names are shown in the format **Parameter xx - [*]**. The xx represents the parameter number, and the * represents the parameter name — for example, **Parameter 01 - [Mode]**.
- Menu commands are shown in bold type face and follow the format **Menu > Command**. For example, if you read “Select **File > Open**,” you should click the **File** menu and then click the **Open** command.
- The firmware release is displayed as FRN X.xxx. The “FRN” signifies Firmware Release Number. The “X” is the major release number. The “xxx” is the minor update number.
- This manual provides information about the 22-COMM-B BACnet MS/TP adapter and using it with PowerFlex 4-Class drives. The adapter can be used with other products that support a DSI adapter, such as the DSI External Comms Kit (22-XCOMM-DC-BASE). Refer to the documentation for your product for specific information about how it works with the adapter.

Getting Started


The 22-COMM-B BACnet MS/TP adapter is a communication option intended for installation into a PowerFlex 40 or PowerFlex 400 drive. It can also be used with other Allen-Bradley products that support an internal DSI (Drive Serial Interface) adapter, such as the DSI External Comms Kit (22-XCOMM-DC-BASE). The DSI External Comms Kit enables PowerFlex 4 drives (which cannot support an internally-mounted adapter) to connect to a BACnet MS/TP network.

| Topic | Page |
|-------------------------------------|---------------------|
| Components | 1-1 |
| Features | 1-2 |
| Compatible Products | 1-3 |
| Required Equipment | 1-3 |

| Topic | Page |
|------------------------------------|---------------------|
| Safety Precautions | 1-4 |
| Quick Start | 1-6 |
| Status Indicators | 1-7 |

Components

Figure 1.1 Components of the Adapter



| Item | Component | Description |
|------|---------------------------------|--|
| ① | Status Indicators | Four LEDs that indicate the status of the network connection, DSI, and the adapter. Refer to Chapter 5, Troubleshooting . |
| ② | DSI Connector | A 20-pin, single-row shrouded male header. An Internal Interface cable connects to this connector and a connector on the drive. |
| ③ | Terminal Block | A 3-pin terminal block with mating 3-pin linear plug connects the adapter to the network. |
| ④ | TERM, -BIAS, and +BIAS Switches | Switches for turning on/off the adapter's internal termination resistor and bias resistors. See Setting the TERM, -BIAS, and +BIAS Switches on page 2-4 for details. |
| ⑤ | MAC Address Switches | Switches for setting the MAC address. See Setting the MAC Address on page 2-2 for details. |

Features

The 22-COMM-B BACnet MS/TP adapter features the following:

- The adapter is normally mounted in a PowerFlex 40 or PowerFlex 400 drive. It can also be installed in a DSI External Comms Kit (22-XCOMM-DC-BASE).
- Switches let you:
 - Set a MAC address before applying power to the drive.
 - Turn on/off the adapter's built-in termination resistor and bias resistors for optimizing operation on the network.
- A captive screw secures and grounds the adapter to the drive or, when mounted in a DSI External Comms Kit, to the kit's metal enclosure.
- A number of configuration tools can be used to configure the adapter and connected drive. The tools include an external PowerFlex 4-Class HIM (22-HIM-*) or drive-configuration software such as DriveExplorer (version 3.01 or higher) or DriveExecutive (version 3.01 or higher).
- Status indicators report the status of drive communications, the adapter, and network. They are visible on the adapter or through the drive cover.
- Read/write access to parameters is available. You can configure and monitor parameter values over the network.
- User-defined fault actions let you determine how the adapter and drive respond to communication disruptions on the network.

Compatible Products

The 22-COMM-B BACnet MS/TP adapter is compatible with Allen-Bradley PowerFlex 4-Class (Component-Class) drives and other products that support an internal DSI adapter. At the time of publication, compatible products include all the following types of:

- PowerFlex 4 drives with DSI External Comms Kit
- PowerFlex 40 drives
- PowerFlex 400 drives

Required Equipment

Equipment Shipped with the Adapter

When you unpack the adapter, verify that the package includes:

- ☐ One 22-COMM-B BACnet MS/TP adapter
- ☐ One 15.24 cm (6 in.) Internal Interface Cable
- ☐ One 3-pin linear plug (plugged into the adapter socket)
- ☐ This manual

User-Supplied Equipment

To install and configure the adapter, you must supply:

- ☐ A small flathead screwdriver
- ☐ A shielded, twisted wire pair to connect the adapter to the network
- ☐ A configuration tool, such as:
 - PowerFlex 4-Class HIM (22-HIM-*)
 - DriveExplorer (version 3.01 or higher)
 - DriveExecutive stand-alone software (version 3.01 or higher) or bundled with the DriveTools SP suite (version 1.01 or higher)
 - Third-party network configuration software

Safety Precautions

Please read the following safety precautions carefully.



ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove power from the PowerFlex drive, and then verify power has been discharged before installing or removing an adapter.



ATTENTION: Risk of injury or equipment damage exists. Only personnel familiar with drive and power products and the associated machinery should plan or implement the installation, start-up, configuration, and subsequent maintenance of the product using an adapter. Failure to comply may result in injury and/or equipment damage.



ATTENTION: Risk of equipment damage exists. The adapter contains ESD (Electrostatic Discharge) sensitive parts that can be damaged if you do not follow ESD control procedures. Static control precautions are required when handling the adapter. If you are unfamiliar with static control procedures, refer to *Guarding Against Electrostatic Damage*, Publication 8000-4.5.2.



ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting control I/O to the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting an adapter.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 02 - [Comm Loss Action]** lets you determine the action of the adapter and connected PowerFlex drive if communications are disrupted. By default, this parameter faults the PowerFlex drive. You can set this parameter so that the drive continues to run. Precautions should be taken to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).



ATTENTION: Risk of injury or equipment damage exists. When a system is configured for the first time, there may be unintended or incorrect machine motion. Disconnect the motor from the machine or process during initial system testing.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 03 - [Comm Loss Time]** lets you determine how long it will take the adapter to detect network communication losses. By default, this parameter sets the timeout to ten seconds. You can set it so that the duration is shorter, longer, or disabled. When set to disabled, this also disables adapter **Parameter 02 - [Comm Loss Action]**. Therefore, a communications fault action will be ignored. Take precautions to ensure that the setting does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).



ATTENTION: Risk of injury or equipment damage exists. The examples in this publication are intended solely for purposes of example. There are many variables and requirements with any application. Rockwell Automation, Inc. does not assume responsibility or liability (to include intellectual property liability) for actual use of the examples shown in this publication.

Quick Start


This section is provided to help experienced users quickly start using the adapter. If you are unsure how to complete a step, refer to the referenced chapter.

| Step | Action | Refer to ... |
|------|--|---|
| 1 | Review the safety precautions for the adapter. | Throughout this manual |
| 2 | Verify that the PowerFlex drive is properly installed. | Drive User Manual |
| 3 | Commission the adapter. Set a unique MAC address and, depending on where the PowerFlex drive nodes are located on the network, appropriately set the TERM, -BIAS, and +BIAS switches. | Chapter 2, Installing the Adapter |
| 4 | Install the adapter. Verify that the PowerFlex drive is not powered. Then, connect the adapter to the drive using the Internal Interface cable. Use the captive screw to secure and ground the adapter to the drive. When installing the adapter in a DSI External Comms Kit, refer to the <i>22-XCOMM-DC-BASE Installation Instructions</i> (Publication No. 22COMM-IN001...) supplied with the kit. | Chapter 2, Installing the Adapter |
| 5 | Apply power to the adapter and verify key settings. A. The adapter receives power from the drive. Verify that the adapter is installed correctly and then apply power to the drive. The PORT status indicator should be solid green. If it is red, there is a problem. Refer to Chapter 5, Troubleshooting . B. Verify/set key adapter parameters. C. Configure/verify key drive parameters. | Chapter 2, Installing the Adapter |
| 6 | Connect the adapter to the network. Verify that the PowerFlex drive is not powered. Then, connect the adapter to the network using a shielded, twisted wire pair. | Chapter 2, Installing the Adapter |
| 7 | Configure the adapter for your application. Set adapter parameters for the following functions as required by your application: <ul style="list-style-type: none"> Fault actions Baud rate | Chapter 3, Configuring the Adapter |
| 8 | Set up the controller to communicate with the adapter. Use the controller's programming software to program the controller. | Instruction manual for your controller's programming software |

Status Indicators

The adapter uses four status indicators to report its operating status. They can be viewed on the adapter or through the drive cover ([Figure 1.2](#)).

Figure 1.2 Status Indicators *(location on drive may vary)*



| Item | Adapter Status Indicator Name |
|------|-------------------------------|
| 1 | PORT |
| 2 | MOD |
| 3 | NET A |
| 4 | NET B |

After installing the adapter and applying power to the drive, refer to [Start-Up Status Indications on page 2-9](#) for possible start-up status indications and their descriptions.

Notes:

Installing the Adapter

Chapter 2 provides instructions for installing the adapter in a PowerFlex 40 or PowerFlex 400 drive. This adapter can also be installed in a DSI External Comms Kit. In this case, refer to the *22-XCOMM-DC-BASE Installation Instructions* (Publication No. 22COMM-IN001...) supplied with the kit.

| Topic | Page |
|---|----------------------|
| Preparing for an Installation | 2-1 |
| Commissioning the Adapter | 2-1 |
| Connecting the Adapter to the Drive | 2-6 |
| Applying Power | 2-9 |
| Connecting the Drive/Adapter to the Network | 2-11 |

Preparing for an Installation

Before installing the adapter, verify that you have all required equipment. Refer to [Required Equipment on page 1-3](#).

Commissioning the Adapter

To commission the adapter, you must set a unique MAC address and, depending on where the PowerFlex drive nodes are located on the network (starting and ending network nodes versus other node locations), appropriately set the TERM, -BIAS, and +BIAS switches.

Important: New settings are recognized only when power is applied to the adapter or it is reset. If you change a switch setting, cycle power or reset the adapter to invoke the change.




ATTENTION: Risk of equipment damage exists. The adapter contains ESD (Electrostatic Discharge) sensitive parts that can be damaged if you do not follow ESD control procedures. Static control precautions are required when handling the adapter. If you are unfamiliar with static control procedures, refer to *Guarding Against Electrostatic Damage*, Publication 8000-4.5.2.

Setting the MAC Address

Set the MAC address using the MAC Address switches (Figure 2.1). Refer to Table 2.A for specific MAC address switch settings.

Important: Each node on the network must have a unique MAC address. The MAC address must be set before power is applied because the adapter uses the MAC address it detects when it first receives power. To change a MAC address, you must set the new value. Then remove and reapply power to the adapter, or reset the adapter.

Figure 2.1 Setting the Adapter MAC Address Switches



| Switches | Description | Default |
|----------|--|---------|
| SW1 | Least Significant Bit (LSB) of MAC Address | 0 |
| SW2 | Bit 1 of MAC Address | 0 |
| SW3 | Bit 2 of MAC Address | 0 |
| SW4 | Bit 3 of MAC Address | 0 |
| SW5 | Bit 4 of MAC Address | 0 |
| SW6 | Bit 5 of MAC Address | 0 |
| SW7 | Most Significant Bit (MSB) of MAC Address | 0 |
| SW8 | Mode (reserved for future use) | — |

Node 0



TIP: The MAC address can be verified using a PowerFlex 4-Class HIM, DriveExplorer software, or DriveExecutive software to view **Parameter 08 - [MAC Address]** or Diagnostic Item number 12 (page 5-5).

Table 2.A MAC Address Switch Settings (UP = 1 = OPEN)

| MAC Address | Switch Setting | | | | | | | MAC Address | Switch Setting | | | | | | |
|-------------|----------------|-----|-----|-----|-----|-----|-----|-------------|----------------|-----|-----|-----|-----|-----|-----|
| | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 4 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| 1 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 5 | 1 | 0 | 1 | 0 | 0 | 0 | 0 |
| 2 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 6 | 0 | 1 | 1 | 0 | 0 | 0 | 0 |
| 3 | 1 | 1 | 0 | 0 | 0 | 0 | 0 | 7 | 1 | 1 | 1 | 0 | 0 | 0 | 0 |

Table 2.A MAC Address Switch Settings (UP = 1 = OPEN) (Continued)

| MAC Address | Switch Setting | | | | | | | MAC Address | Switch Setting | | | | | | |
|-------------|----------------|-----|-----|-----|-----|-----|-----|-------------|----------------|-----|-----|-----|-----|-----|-----|
| | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 |
| 8 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 56 | 0 | 0 | 0 | 1 | 1 | 1 | 0 |
| 9 | 1 | 0 | 0 | 1 | 0 | 0 | 0 | 57 | 1 | 0 | 0 | 1 | 1 | 1 | 0 |
| 10 | 0 | 1 | 0 | 1 | 0 | 0 | 0 | 58 | 0 | 1 | 0 | 1 | 1 | 1 | 0 |
| 11 | 1 | 1 | 0 | 1 | 0 | 0 | 0 | 59 | 1 | 1 | 0 | 1 | 1 | 1 | 0 |
| 12 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 60 | 0 | 0 | 1 | 1 | 1 | 1 | 0 |
| 13 | 1 | 0 | 1 | 1 | 0 | 0 | 0 | 61 | 1 | 0 | 1 | 1 | 1 | 1 | 0 |
| 14 | 0 | 1 | 1 | 1 | 0 | 0 | 0 | 62 | 0 | 1 | 1 | 1 | 1 | 1 | 0 |
| 15 | 1 | 1 | 1 | 1 | 0 | 0 | 0 | 63 | 1 | 1 | 1 | 1 | 1 | 1 | 0 |
| 16 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 64 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| 17 | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 65 | 1 | 0 | 0 | 0 | 0 | 0 | 1 |
| 18 | 0 | 1 | 0 | 0 | 1 | 0 | 0 | 66 | 0 | 1 | 0 | 0 | 0 | 0 | 1 |
| 19 | 1 | 1 | 0 | 0 | 1 | 0 | 0 | 67 | 1 | 1 | 0 | 0 | 0 | 0 | 1 |
| 20 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 68 | 0 | 0 | 1 | 0 | 0 | 0 | 1 |
| 21 | 1 | 0 | 1 | 0 | 1 | 0 | 0 | 69 | 1 | 0 | 1 | 0 | 0 | 0 | 1 |
| 22 | 0 | 1 | 1 | 0 | 1 | 0 | 0 | 70 | 0 | 1 | 1 | 0 | 0 | 0 | 1 |
| 23 | 1 | 1 | 1 | 0 | 1 | 0 | 0 | 71 | 1 | 1 | 1 | 0 | 0 | 0 | 1 |
| 24 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 72 | 0 | 0 | 0 | 1 | 0 | 0 | 1 |
| 25 | 1 | 0 | 0 | 1 | 1 | 0 | 0 | 73 | 1 | 0 | 0 | 1 | 0 | 0 | 1 |
| 26 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 74 | 0 | 1 | 0 | 1 | 0 | 0 | 1 |
| 27 | 1 | 1 | 0 | 1 | 1 | 0 | 0 | 75 | 1 | 1 | 0 | 1 | 0 | 0 | 1 |
| 28 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 76 | 0 | 0 | 1 | 1 | 0 | 0 | 1 |
| 29 | 1 | 0 | 1 | 1 | 1 | 0 | 0 | 77 | 1 | 0 | 1 | 1 | 0 | 0 | 1 |
| 30 | 0 | 1 | 1 | 1 | 1 | 0 | 0 | 78 | 0 | 1 | 1 | 1 | 0 | 0 | 1 |
| 31 | 1 | 1 | 1 | 1 | 1 | 0 | 0 | 79 | 1 | 1 | 1 | 1 | 0 | 0 | 1 |
| 32 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 80 | 0 | 0 | 0 | 0 | 1 | 0 | 1 |
| 33 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 81 | 1 | 0 | 0 | 0 | 1 | 0 | 1 |
| 34 | 0 | 1 | 0 | 0 | 0 | 1 | 0 | 82 | 0 | 1 | 0 | 0 | 1 | 0 | 1 |
| 35 | 1 | 1 | 0 | 0 | 0 | 1 | 0 | 83 | 1 | 1 | 0 | 0 | 1 | 0 | 1 |
| 36 | 0 | 0 | 1 | 0 | 0 | 1 | 0 | 84 | 0 | 0 | 1 | 0 | 1 | 0 | 1 |
| 37 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 85 | 1 | 0 | 1 | 0 | 1 | 0 | 1 |
| 38 | 0 | 1 | 1 | 0 | 0 | 1 | 0 | 86 | 0 | 1 | 1 | 0 | 1 | 0 | 1 |
| 39 | 1 | 1 | 1 | 0 | 0 | 1 | 0 | 87 | 1 | 1 | 1 | 0 | 1 | 0 | 1 |
| 40 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | 88 | 0 | 0 | 0 | 1 | 1 | 0 | 1 |
| 41 | 1 | 0 | 0 | 1 | 0 | 1 | 0 | 89 | 1 | 0 | 0 | 1 | 1 | 0 | 1 |
| 42 | 0 | 1 | 0 | 1 | 0 | 1 | 0 | 90 | 0 | 1 | 0 | 1 | 1 | 0 | 1 |
| 43 | 1 | 1 | 0 | 1 | 0 | 1 | 0 | 91 | 1 | 1 | 0 | 1 | 1 | 0 | 1 |
| 44 | 0 | 0 | 1 | 1 | 0 | 1 | 0 | 92 | 0 | 0 | 1 | 1 | 1 | 0 | 1 |
| 45 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 93 | 1 | 0 | 1 | 1 | 1 | 0 | 1 |
| 46 | 0 | 1 | 1 | 1 | 0 | 1 | 0 | 94 | 0 | 1 | 1 | 1 | 1 | 0 | 1 |
| 47 | 1 | 1 | 1 | 1 | 0 | 1 | 0 | 95 | 1 | 1 | 1 | 1 | 1 | 0 | 1 |
| 48 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | 96 | 0 | 0 | 0 | 0 | 0 | 1 | 1 |
| 49 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 97 | 1 | 0 | 0 | 0 | 0 | 1 | 1 |
| 50 | 0 | 1 | 0 | 0 | 1 | 1 | 0 | 98 | 0 | 1 | 0 | 0 | 0 | 1 | 1 |
| 51 | 1 | 1 | 0 | 0 | 1 | 1 | 0 | 99 | 1 | 1 | 0 | 0 | 0 | 1 | 1 |
| 52 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 100 | 0 | 0 | 1 | 0 | 0 | 1 | 1 |
| 53 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 101 | 1 | 0 | 1 | 0 | 0 | 1 | 1 |
| 54 | 0 | 1 | 1 | 0 | 1 | 1 | 0 | 102 | 0 | 1 | 1 | 0 | 0 | 1 | 1 |
| 55 | 1 | 1 | 1 | 0 | 1 | 1 | 0 | 103 | 1 | 1 | 1 | 0 | 0 | 1 | 1 |


Table 2.A MAC Address Switch Settings (UP = 1 = OPEN) (Continued)

| MAC Address | Switch Setting | | | | | | | MAC Address | Switch Setting | | | | | | |
|-------------|----------------|-----|-----|-----|-----|-----|-----|-------------|----------------|-----|-----|-----|-----|-----|-----|
| | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 |
| 104 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 116 | 0 | 0 | 1 | 0 | 1 | 1 | 1 |
| 105 | 1 | 0 | 0 | 1 | 0 | 1 | 1 | 117 | 1 | 0 | 1 | 0 | 1 | 1 | 1 |
| 106 | 0 | 1 | 0 | 1 | 0 | 1 | 1 | 118 | 0 | 1 | 1 | 0 | 1 | 1 | 1 |
| 107 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 119 | 1 | 1 | 1 | 0 | 1 | 1 | 1 |
| 108 | 0 | 0 | 1 | 1 | 0 | 1 | 1 | 120 | 0 | 0 | 0 | 1 | 1 | 1 | 1 |
| 109 | 1 | 0 | 1 | 1 | 0 | 1 | 1 | 121 | 1 | 0 | 0 | 1 | 1 | 1 | 1 |
| 110 | 0 | 1 | 1 | 1 | 0 | 1 | 1 | 122 | 0 | 1 | 0 | 1 | 1 | 1 | 1 |
| 111 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 123 | 1 | 1 | 0 | 1 | 1 | 1 | 1 |
| 112 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | 124 | 0 | 0 | 1 | 1 | 1 | 1 | 1 |
| 113 | 1 | 0 | 0 | 0 | 0 | 1 | 1 | 125 | 1 | 0 | 1 | 1 | 1 | 1 | 1 |
| 114 | 0 | 1 | 0 | 0 | 1 | 1 | 1 | 126 | 0 | 1 | 1 | 1 | 1 | 1 | 1 |
| 115 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 127 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

Setting the TERM, -BIAS, and +BIAS Switches

The adapter’s TERM, -BIAS, and +BIAS switches ([Figure 2.2](#)) are used to turn on/off its built-in termination resistor and bias resistors.

Figure 2.2 Setting the TERM, -BIAS, and +BIAS Switches




| Switches | Description | Default |
|----------|---------------------------------------|----------|
| SW1 | Turns on/off the termination resistor | Up (Off) |
| SW2 | Turns on/off the -bias resistor | Up (Off) |
| SW3 | Turns on/off the +bias resistor | Up (Off) |
| SW4 | Reserved (not used) | — |

Since nodes on a BACnet MS/TP network are typically a mix of Allen-Bradley PowerFlex drives and other brands of building automation products, the network node locations for the PowerFlex drives will determine how their adapter’s TERM, -BIAS, and +BIAS switches should be set.

Network with PowerFlex Drives at Starting and/or Ending Nodes

For a network with PowerFlex drives at the starting and/or ending nodes ([Figure 2.3](#)), set their 22-COMM-B adapter's TERM, -BIAS, and +BIAS switches to the “Down” (On) position. All other PowerFlex drive network nodes must have these switches set to the “Up” (Off) position.


Figure 2.3 Example Network with PowerFlex Drives at Starting and/or Ending Nodes



Network with PowerFlex Drives at Other Nodes

For a network with PowerFlex drives at other node locations — not starting and/or ending nodes ([Figure 2.4](#)), set the TERM, -BIAS, and +BIAS switches to the “Up” (Off) position. In this network scenario, other brands of building automation products at the starting and/or ending nodes require appropriate termination and bias resistors. Refer to their instruction documentation for details.

Figure 2.4 Example Network with PowerFlex Drives at Other Nodes



Connecting the Adapter to the Drive


PowerFlex 40 Frames B and C, and PowerFlex 400 Frame C

1. Remove power from the drive.
2. Use static control precautions.
3. Mount the adapter on the *required special* drive cover (ordered separately — see [Figure 2.6](#) for part numbers).
 - Frame C: Use the adapter screw to secure the adapter to the cover.
 - Frame B: Disregard the screw and snap the adapter in place.

Important: For Frame C drives, tighten the adapter's lower left screw to ground the adapter (see [Figure 2.6](#)). For Frame B drives, install the special drive cover onto the drive using both cover fasteners to ground the adapter.


4. Connect the Internal Interface cable to the DSI port on the drive and then to the mating DSI connector on the adapter.

Figure 2.5 Connecting DSI Ports with Internal Interface Cable



| Item | Description |
|------|--|
| 1 | DSI connector |
| 2 | 15.24 cm (6 in.) Internal Interface cable |
| 3 | Shielded, twisted wire pair network connection |

Figure 2.6 Mounting and Grounding the Adapter – PowerFlex 40 Frames B and C, and PowerFlex 400 Frame C




NOTE: For Frame B drives, the lower left adapter screw does not ground the adapter. To ground the adapter, install the special drive cover onto the drive using both cover fasteners.

PowerFlex 400 Frames D, E, and F

1. Remove power from the drive.
2. Use static control precautions.
3. Remove the drive cover.
4. With the adapter board right side up, remove its mounting screw from the lower left hole. Save the screw for mounting in Step 7.
5. Connect the Internal Interface cable to the DSI port on the drive (see [Figure 2.7](#)).
6. With the adapter board oriented bottom side up, route the Internal Interface cable under the adapter, and then to the mating DSI connector on the adapter.
7. Install the adapter, bottom side up, to the right side of the display board by snapping it into place. Then insert the adapter mounting screw into the lower left hole on the board.

Important: Tighten the mounting screw in the adapter's lower left hole to ground the adapter to the drive.

Figure 2.7 Mounting and Connecting the Adapter – PowerFlex 400 Frames D, E, and F



Applying Power



ATTENTION: Risk of equipment damage, injury, or death exists. Unpredictable operation may occur if you fail to verify that parameter settings and switch settings are compatible with your application. Verify that settings are compatible with your application before applying power to the drive.

Apply power to the drive. The adapter receives its power from the connected drive. When you apply power to the adapter for the first time, its topmost status indicator “PORT” should be solid green after an initialization. If it is red, there is a problem. Refer to [Chapter 5, Troubleshooting](#).

Start-Up Status Indications

Status indicators for the drive and communications adapter can be viewed on the front of the drive ([Figure 2.8](#)) after power has been applied. Possible start-up status indications are shown in [Table 2.B](#).

Figure 2.8 Drive and Adapter Status Indicators (location on drive may vary)




Table 2.B Drive and Adapter Start-Up Status Indications

| Item | Name | Color | State | Description |
|------------------------------|-------|-------|----------|---|
| Drive FAULT Status Indicator | | | | |
| ❶ | FAULT | Red | Off | Drive ready but not running, and no faults are present. |
| | | | Flashing | A fault has occurred. |
| Adapter Status Indicators | | | | |
| ❷ | PORT | Green | Flashing | Normal Operation. The adapter is establishing communications with the drive. It will turn solid green or red. |
| | | | Steady | Normal Operation. The adapter is properly connected and communicating with the drive |
| | MOD | Green | Flashing | Normal Operation. The adapter is operating but is not transferring I/O data. |
| | | | Steady | Normal Operation. The adapter is operating and transmitting I/O data. |
| | NET A | Green | Flashing | Normal Operation. The adapter is properly connected and communicating on the network. |
| | NET B | Green | Off | Normal Operation. The adapter is properly connected but is idle. |
| | | | Flashing | Normal Operation. The adapter is transmitting data. |

Verifying/Setting Key Adapter Parameters

To access adapter parameters when using a remote PowerFlex 4-Class HIM (22-HIM-*), navigate to the Device Select screen. Then select the BACnet communications adapter (22-COMM-B) and press the Enter function key.

1. Verify that adapter **Parameter 08 - [MAC Address]** is reporting the MAC address set in [Setting the MAC Address on page 2-2](#).
2. Set adapter **Parameters 11 - [Device Inst Hi]** and **12 - [Device Inst Lo]** to establish a unique number for representation to the Building Automation Controller. For more information, see [Setting the Device Instance Number on page 3-3](#).
3. Reset the adapter by setting adapter **Parameter 01 - [Reset Module]** to “1” (Reset Module) so that the new Device Instance Number takes effect.

Configuring/Verifying Key Drive Parameters

The PowerFlex 4-Class drive can be separately configured for the control and reference functions in various combinations. For example, you could set the drive to have its control come from a peripheral or terminal block with the reference coming from the BACnet MS/TP network. Or you could set the drive to have its control come from the BACnet MS/TP network with the reference coming from another peripheral or terminal block. Or you could set the drive to have both its control and reference come from the BACnet MS/TP network.

The following steps in this section assume that the drive will receive the Logic Command and Reference from the BACnet MS/TP network.

1. Using drive **Parameter P038 - [Speed Reference]**, set the drive speed Reference to “5” (Comm Port).
2. Verify that drive **Parameter P036 - [Start Source]** is reporting that the source of the Reference to the drive is “5” (Comm Port). This ensures that any Reference commanded from the network can be monitored by using drive **Parameter d002 - [Commanded Freq]**. If a problem occurs, this verification step provides the diagnostic capability to determine whether the drive/adapter or the network is the cause.


Connecting the Drive/Adapter to the Network



ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove power from the drive, and then verify power has been discharged before installing or removing an adapter.

1. Remove power from the drive.
2. Use static control precautions, and remove the drive cover.
3. Connect a shielded, twisted wire pair to the network, and route it through the bottom of the drive (see [Figure 2.5](#)).
4. Connect the twisted wire pair and its shield to the 3-pin linear plug (provided with the adapter). See [Figure 2.9](#) for terminal designations and typical terminal connections.

Figure 2.9 Typical Network Terminal Connections



5. Insert the 3-pin linear plug into the mating adapter socket.
6. Install the drive cover.
7. Apply power to the drive.
8. Verify that adapter **Parameter 07 - [Baud Rate Act]** is reporting the actual network baud rate. If not, use **Parameter 06 - [Baud Rate Cfg]** to set the adapter to a fixed baud rate that matches the network baud rate.



TIP: After the drive is connected and communicating on the BACnet MS/TP network, it may be necessary to set additional adapter parameters to meet your application requirements. For example:

- **Parameter 02 - [Comm Loss Action]**
- **Parameter 03 - [Comm Loss Time]**

To access adapter parameters when using a PowerFlex 4-Class HIM, navigate to the Device Select screen. Then select the BACnet adapter (22-COMM-B) and press the Enter function key.

For adapter parameter configuration details, please refer to [Chapter 3](#).

Configuring the Adapter

Chapter 3 provides instructions and information for setting the parameters in the adapter.

| Topic | Page |
|--|---------------------|
| Configuration Tools | 3-1 |
| Using the PowerFlex 4-Class HIM | 3-2 |
| Setting the Device Instance Number | 3-3 |
| Setting a Comm Loss Action | 3-5 |
| Setting the Comm Loss Time | 3-6 |
| Setting the Baud Rate | 3-7 |
| Resetting the Adapter | 3-7 |
| Viewing the Adapter Configuration | 3-8 |

For a list of parameters, refer to [Appendix B, Adapter Parameters](#). For definitions of terms in this chapter, refer to the [Glossary](#).

Configuration Tools






The adapter stores parameters and other information in its own Non-Volatile Storage (NVS) memory. You must, therefore, access the adapter to view and edit its parameters. The following tools can be used to access the adapter parameters:

| Tool | Refer to... |
|--|---|
| PowerFlex 4-Class HIM (22-HIM-*) | Page 3-2 |
| DriveExplorer Software (version 3.01 or higher) | http://www.ab.com/drives/driveexplorer , and DriveExplorer online help (installed with the software) |
| DriveExecutive Software (version 3.01 or higher) | http://www.ab.com/drives/drivetools , and DriveExecutive online help (installed with the software) |

Using the PowerFlex 4-Class HIM

The PowerFlex 4-Class HIM (Human Interface Module) can be used to access parameters in the adapter. It is recommended that you read through the basic steps shown below before performing the sequence. For additional HIM information, refer to the HIM Quick Reference card.

Using the HIM


| Step | Key(s) | Example Screens |
|---|---|--|
| 1. Power up the drive. Then plug the HIM into the drive. The Parameters menu for the <u>drive</u> will be displayed. | | <div>Parameters</div> <div>Groups</div> <div>Linear List</div> <div>Changed Params</div> <div>DIAGPARAMDSELMEMSEL▶</div> |
| 2. Press Sel key once to display the Device Select menu. |  | <div>Device Select</div> <div>DSI Devices</div> <div></div> <div>DIAGPARAMDSELMEMSEL▶</div> |
| 3. Press Enter to display the DSI Devices menu. Press Down Arrow to scroll to 22-COMM-B. |  and  | <div>DSI Devices</div> <div>PowerFlex 40</div> <div>22-COMM-B</div> <div></div> |
| 4. Press Enter to select the BACnet MS/TP adapter. The Parameters menu for the <u>adapter</u> will be displayed. |  | <div>Parameters</div> <div>Linear List</div> <div>Changed Params</div> <div>DIAGPARAMDSELMEMSEL▶</div> |
| 5. Press Enter to access the parameters. Edit the adapter parameters using the same techniques that you use to edit drive parameters. |  | <div>Reset Module</div> <div>Parameter: # 001</div> <div>Ready 0</div> <div>VALUELIMITSSEL▶</div> |

Setting the Device Instance Number

While there are many ways to implement Device Instance and network strategies, the example shown in [Figure 3.1](#) illustrates one logical approach.

In this example, two individual Floor Level Networks are connected to the Building Level Network through a router which allows devices on each network to share the same MAC address. However, each device on the network must have a unique Device Instance which, in this case, consists of 4 digits. The first digit (in bold) represents the Building or Floor number. The last 3 digits represent the device's set MAC address.

Figure 3.1 Building Automation Network Example




The Device Instance Number can be a number from 1 to 4,194,302.

When the Device Instance Number is three digits or less, set **Parameter 11 - [Device Inst Hi]** to "0" (zero) and use **Parameter 12 - [Device Inst Lo]** to directly enter the number. When the Device Instance Number is four or more digits, use **Parameter 11 - [Device Inst Hi]** to enter the

high portion (most significant digits) of the number and **Parameter 12 - [Device Inst Lo]** to enter the low portion (always the three least significant digits) of the number. [Figure 3.2](#) illustrates how to apportion the Device Instance Number for entry into the 22-COMM-B adapter.

Figure 3.2 Apportioning the Device Instance Number for Entry



1. Enter the Device Instance Number using **Parameter 11 - [Device Inst Hi]** and **Parameter 12 - [Device Inst Lo]**.

Figure 3.3 Device Inst Hi/Lo Screens on PowerFlex 4-Class HIM (22-HIM-*)

| Device Inst Hi | Device Inst Lo |
|--------------------|--------------------|
| Parameter: # 011 | Parameter: # 012 |
| 160 | 0 |
| VALUE LIMITS SEL ▶ | VALUE LIMITS SEL ▶ |

These Device Instance Number examples illustrate the values needed to be entered by each parameter.

| Examples of Device Instance Numbers | Parameter 11 - [Device Inst Hi] Entry | Parameter 12 - [Device Inst Lo] Entry |
|-------------------------------------|---------------------------------------|---------------------------------------|
| 14 | 0 | 14 |
| 328 | 0 | 328 |
| 2369 | 2 | 369 |
| 160000 (default) | 160 | 0 |
| 4150732 | 4150 | 732 |

2. Reset the adapter (see [Resetting the Adapter on page 3-7](#)) so that the new Device Instance Number takes effect.

Setting a Comm Loss Action

By default, when communications are disrupted (for example, a cable is disconnected), the drive responds by faulting if it is using I/O from the network. You can configure a different response to communication disruptions using **Parameter 02 - [Comm Loss Action]**.



ATTENTION: Risk of injury or equipment damage exists.

Parameter 02 - [Comm Loss Action] lets you determine the action of the adapter and connected drive if communications are disrupted. By default, this parameter faults the drive. You can set this parameter so that the drive continues to run. Take precautions to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).

To change the Comm loss action

Set the value of **Parameter 02 - [Comm Loss Action]** to the desired response action:

| Value | Action | Description |
|-------|--------------|--|
| 0 | Fault | The drive is faulted and stopped. (Default) |
| 1 | Stop | The drive is stopped, but not faulted. |
| 2 | Zero Data | The drive is sent 0 for output data. This does not command a stop. |
| 3 | Hold Last | The drive continues in its present state. |
| 4 | Send Flt Cfg | The drive is sent the data that you set in the fault configuration parameters (Parameter 04 - [Flt Cfg Logic] and Parameter 05 - [Flt Cfg Ref]). |

Figure 3.4 Comm Loss Action Screen on PowerFlex 4-Class HIM (22-HIM-*)

| Comm Loss Action | | |
|------------------|--------|-------|
| Parameter: | # | 002 |
| | Fault | 0 |
| VALUE | LIMITS | SEL ► |

Changes to this parameter takes effect immediately. A reset is not required.

To set the fault configuration parameters

If you set **Parameter 02 - [Comm Loss Action]** to “Send Flt Cfg,” the values in the following parameters are sent to the drive after a communications fault occurs. You must set these parameters to values required by your application.

| Parameter | Name | Description |
|-----------|---------------|--|
| 04 | Flt Cfg Logic | A 16-bit value sent to the drive for Logic Command. |
| 05 | Flt Cfg Ref | A 16-bit value (0 – 65535) sent to the drive as a Reference. |

Changes to these parameters take effect immediately. A reset is not required.


Setting the Comm Loss Time

Set **Parameter 03 - [Comm Loss Time]** to a communication loss timeout period suitable for your application. By default, the timeout is set to ten (10) seconds. You can increase or decrease this value. Alternatively, you can set the value to zero (0) to disable this timeout feature so that the adapter does not detect communication losses.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 03 - [Comm Loss Time]** lets you determine how long it will take the adapter to detect network communication losses. By default, this parameter sets the timeout to ten (10) seconds. You can set it so that the duration is shorter, longer, or disabled. When set to disabled, this also disables adapter **Parameter 02 - [Comm Loss Action]**. Therefore, a communications fault action will be ignored. Take precautions to ensure that the setting does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).

Figure 3.5 Comm Loss Time Screen on PowerFlex 4-Class HIM (22-HIM-*)



Changes to this parameter take effect immediately. A reset is not required.

Setting the Baud Rate

The value of **Parameter 06 - [Baud Rate Cfg]** determines the baud rate used by the adapter. The Autobaud setting will detect the baud rate used on the network if another device is setting the baud rate. Your application may require a different setting.

1. Set the value of **Parameter 06 - [Baud Rate Cfg]** to the baud rate at which your network is operating.

Figure 3.6 Baud Rate Screen on PowerFlex 4-Class HIM (22-HIM-*)

| Baud Rate Cfg | | | Value | Description |
|---------------|----------|-------|-------|--------------------|
| Parameter: | # | 006 | 0 | Autobaud (Default) |
| | Autobaud | 0 | 1 | 9600 |
| | | | 2 | 19200 |
| | | | 3 | 38400 |
| | | | 4 | 76800 |
| VALUE | LIMITS | SEL ▶ | | |

2. Reset the adapter (see [Resetting the Adapter](#)) so that the new baud rate takes effect.

Resetting the Adapter

Changes to switch settings and some adapter parameters require that you reset the adapter before the new settings take effect. You can reset the adapter by cycling power to the drive or by using **Parameter 01 - [Reset Module]**.



ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting control I/O to the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting a connected adapter.

Set **Parameter 01 - [Reset Module]** to **Reset Module**.

Figure 3.7 Reset Screen on PowerFlex 4-Class HIM (22-HIM-*)

| Reset Module | | | Value | Description |
|--------------|--------------|-------|-------|-----------------|
| Parameter: | # | 001 | 0 | Ready (Default) |
| | Reset Module | 1 | 1 | Reset Module |
| | | | 2 | Set Defaults |
| VALUE | LIMITS | SEL ▶ | | |

When you enter **1 = Reset Module**, the adapter will be immediately reset. When you enter **2 = Set Defaults**, the adapter will set all adapter parameters to their factory-default settings. After performing a Set Defaults, enter **1 = Reset Module** so that the new values take effect. The value of this parameter will be restored to **0 = Ready** after the adapter is reset.

Viewing the Adapter Configuration

The following read-only parameters provide information about how the adapter is configured. You can view these parameters at any time.

| Number | Name | Description |
|--------|---------------|--|
| 07 | Baud Rate Act | <p>The baud rate used by the adapter. This will be one of the following values:</p> <ul style="list-style-type: none"> • The value of Parameter 06 - [Baud Rate Cfg]. • An old baud rate if Parameter 06 - [Baud Rate Cfg] has been changed and the adapter has not been reset. • The value "0" (Unknown) if Parameter 06 - [Baud Rate Cfg] is set to "0" (Autobaud) and the adapter has not yet detected the baud rate. |
| 08 | MAC Address | <p>The MAC address used by the adapter that was set by the MAC Address Switches SW1-SW7 (Figure 2.1).</p> |

Using BACnet Objects

Chapter 4 provides information about controlling a compatible PowerFlex 4-Class drive using BACnet objects.

| Topic | Page |
|--|---------------------|
| Understanding BACnet Objects | 4-1 |
| Basic Drive Operation on the Network | 4-2 |
| Supported BACnet Objects | 4-3 |

Understanding BACnet Objects

BACnet nodes are controlled and monitored by the use of several types of objects. The BACnet controller performs read and write commands to these objects, and the adapter transfers/translated the data between these objects and the drive.

When a read or write command occurs to a specific object, data in the object is refreshed from or transferred to the drive.

The BACnet object types that are supported by the adapter are:

- Analog Input (AI)
- Analog Output (AO)
- Analog Value (AV)
- Binary Input (BI)
- Binary Output (BO)
- Binary Value (BV)

Basic Drive Operation on the Network

This section describes how to operate a drive on the network using a combination of BACnet object types for basic control.



ATTENTION: Control information written to the adapter by a BACnet controller is volatile. That is, it will not survive an adapter reset or power cycle. For example, if a BACnet controller writes to a Binary Output (BO) object to energize an output relay on the drive and then that drive is reset or power cycled, the drive will return the relay to its default (de-energized) state. The adapter will not attempt to restore the relay to the energized state unless a BACnet controller writes to it again.

Basic Drive Control (Start/Stop)

1. Write a speed reference value (in %) to the Reference 1 Analog Value object (AV0) Present Value property.
2. To start the drive, write a value of “1” to the Run/Stop Binary Value object (BV10) Present Value property.
3. To stop the drive, write a value of “0” (zero) to the Run/Stop Binary Value object (BV10) Present Value property.

Using an Alternate Speed Reference

To assign an alternate speed reference to the drive:

1. Write a speed reference value (in %) to the Reference 2 Analog Value object (AV1) Present Value property.
2. Write a value of “1” to the Ref2/Ref1 Binary Value object (BV12) Present Value property.

Changing Motor Rotation Direction

To command a reverse direction of motor rotation when the drive is running, write a value of “1” to the Rev/Fwd Binary Value object (BV11) Present Value property. To command a forward direction when the drive is running, write a value of “0” (zero) to the Rev/Fwd Binary Value object (BV11) Present Value property.

Clearing a Drive Fault

To clear a drive fault, write a value of “1” to the Clear Faults Binary Value object (BV13) Present Value property.

Supported BACnet Objects

The type of drive used on the network determines the specific BACnet objects that are supported. Refer to [Table 4.A](#) for descriptions of the BACnet objects and the drives supporting those objects.

Table 4.A BACnet Object Descriptions and Supported Drives

| Object | Name | Use This Object to... | Compatible PowerFlex Drives | | | |
|----------------------------|-----------------------|--|-----------------------------|----|-----|---|
| | | | 4 | 40 | 400 | |
| Analog Input (AI) Objects | | | | | | |
| AI0 | Analog Input 1 (%) | Read the value of Analog Input 1 (voltage or current) on the drive's I/O terminal block. | ✓ | ✓ | ✓ | ✓ |
| AI1 | Analog Input 2 (%) | Read the value of Analog Input 2 (voltage or current) on the drive's I/O terminal block. | ✓ | ✓ | ✓ | ✓ |
| Analog Output (AO) Objects | | | | | | |
| AO0 | Analog Output 1 (%) | Read/write the value of Analog Output (PowerFlex 40) or Analog Output 1 (Powerflex 400) on the drive's I/O terminal block. The drive must be configured to accept the value of this output from the network. This is done by setting the following drive parameter: <ul style="list-style-type: none">PowerFlex 40: A065 - [Analog Out Sel] to the value "18" (Setpnt 0-10), "19" (Setpnt 0-20) or "20" (Setpnt 4-20)PowerFlex 400: T082 - [Analog Out1 Sel] to the value "5" (Setpnt 0-10), "12" (Setpnt 0-20) or "19" (Setpnt 4-20) | — | ✓ | | ✓ |
| AO1 | Analog Output 2 (%) | Read/write the value of Analog Output 2 on the drive's I/O terminal block. The drive must be configured to accept the value of this output from the network. This is done by setting drive parameter T085 - [Analog Out2 Sel] to the value "5" (Setpnt 0-10), "12" (Setpnt 0-20) or "19" (Setpnt 4-20). | — | — | | ✓ |
| Analog Value (AV) Objects | | | | | | |
| AV0 | Reference 1 (%) | Read/write the Reference 1 and Reference 2 values. The drive must be configured to accept its speed reference from the network. This is typically done by setting drive parameter P038 - [Speed Reference] to the value "5" (Comm Port). | ✓ | ✓ | | ✓ |
| AV1 | Reference 2 (%) | | ✓ | ✓ | | ✓ |
| AV2 | Output Frequency (Hz) | Read the drive's output frequency. | ✓ | ✓ | | ✓ |

Table 4.A BACnet Object Descriptions and Supported Drives (Continued)

| Object | Name | Use This Object to... | Compatible PowerFlex Drives | | |
|---------------------------|-----------------------|--|-----------------------------|----|-----|
| | | | 4 | 40 | 400 |
| AV3 | Output Current (Amps) | Read the drive's output current. | ✓ | ✓ | ✓ |
| AV4 | Output Voltage (VAC) | Read the drive's output voltage. | ✓ | ✓ | ✓ |
| AV5 | Output Power (kW) | Read the drive's output power. | — | ✓ | ✓ |
| AV6 | Output Energy (kWh) | Read/write the drive's accumulated output energy. Note: When writing, this object accepts only a value of "0" (zero). | — | — | ✓ |
| AV7 | DC Bus Voltage (VDC) | Read the drive's DC bus voltage. | ✓ | ✓ | ✓ |
| AV8 | Drive Temp (°C) | Read the drive's temperature. | ✓ | ✓ | ✓ |
| AV9 | Reserved | — | — | — | — |
| AV10 | Reserved | — | — | — | — |
| AV11 | Run Time (Hours) | <ul style="list-style-type: none"> PowerFlex 4/40: Read the drive's accumulated run time. PowerFlex 400: Read/write the drive's accumulated run time. Note: When writing, this object accepts only a value of "0" (zero). | ✓ | ✓ | ✓ |
| AV12 | Fault 1 | Read the code for the drive's most recent fault. | ✓ | ✓ | ✓ |
| AV13 | Fault 2 | Read the code for the drive's second most recent fault. | ✓ | ✓ | ✓ |
| AV14 | Fault 3 | Read the code for the drive's third most recent fault. | ✓ | ✓ | ✓ |
| AV15 | Accel Time 1 (Sec) | Read/write the drive's Accel Time 1 setting. | ✓ | ✓ | ✓ |
| AV16 | Decel Time 1 (Sec) | Read/write the drive's Decel Time 1 setting. | ✓ | ✓ | ✓ |
| AV17 | Mailbox Param | Read/write any drive parameter. To read a drive parameter, write the number for the desired parameter to the Mailbox Param object, and then read the Mailbox Value object. To write a drive parameter, write the number for the desired parameter to the Mailbox Param object, and then write the desired value to the Mailbox Value object. | ✓ | ✓ | ✓ |
| AV18 | Mailbox Value | | ✓ | ✓ | ✓ |
| Binary Input (BI) Objects | | | | | |
| BI0 | Stop Input | Read the state of the Stop Input on the drive's I/O terminal block. | ✓ | ✓ | ✓ |

Table 4.A BACnet Object Descriptions and Supported Drives (Continued)

| Object | Name | Use This Object to... | Compatible PowerFlex Drives | | | |
|----------------------------|----------------------|--|-----------------------------|----|-----|---|
| | | | 4 | 40 | 400 | |
| B11 | Start Input | Read the state of the Start Input on the drive's I/O terminal block. | ✓ | ✓ | ✓ | ✓ |
| B12 | Dir Input | Read the state of the Dir (Direction) Input on the drive's I/O terminal block. | ✓ | ✓ | ✓ | ✓ |
| B13 | Digital Input 1 | Read the state of Digital Input 1 on the drive's I/O terminal block. | ✓ | ✓ | ✓ | ✓ |
| B14 | Digital Input 2 | Read the state of Digital Input 2 on the drive's I/O terminal block. | ✓ | ✓ | ✓ | ✓ |
| B15 | Digital Input 3 | Read the state of Digital Input 3 on the drive's I/O terminal block. | — | ✓ | ✓ | ✓ |
| B16 | Digital Input 4 | Read the state of Digital Input 4 on the drive's I/O terminal block. | — | ✓ | ✓ | ✓ |
| Binary Output (BO) Objects | | | | | | |
| B00 | Digital Output Cmd 1 | Read/write the state of Digital Output 1 on the drive's I/O terminal block. The drive must be configured to accept the value of this output from the network. This is done by setting the following drive parameter: <ul style="list-style-type: none"> PowerFlex 4/40: P055 - [Relay Out Sel] to the value "20" (ParamControl) PowerFlex 400: T055 - [Relay Out1 Sel] to the value "12" (ParamControl) | ✓ | ✓ | | ✓ |
| B01 | Digital Output Cmd 2 | Read/write the state of Digital Output 2 on the drive's I/O terminal block. The drive must be configured to accept the value of this output from the network. This is done by setting the following drive parameter: <ul style="list-style-type: none"> PowerFlex 40: P058 - [Opto Out1 Sel] to the value "20" (ParamControl) PowerFlex 400: T060 - [Relay Out2 Sel] to the value "12" (ParamControl) | — | ✓ | | ✓ |
| B02 | Digital Output Cmd 3 | Read/write the state of Digital Output 3 on the drive's I/O terminal block. The drive must be configured to accept the value of this output from the network. This is done by setting the following drive parameter: <ul style="list-style-type: none"> PowerFlex 40: P061 - [Opto Out2 Sel] to the value "20" (ParamControl) PowerFlex 400: T065 - [Opto Out Sel] to the value "12" (ParamControl) | — | ✓ | | ✓ |

Table 4.A BACnet Object Descriptions and Supported Drives (Continued)

| Object | Name | Use This Object to... | Binary Value (BV) Objects | | | |
|--------|-----------------|---|-----------------------------|----|-----|---|
| | | | Compatible PowerFlex Drives | | | |
| | | | 4 | 40 | 400 | |
| BV0 | Ready | Read the drive's Ready status, which is active if the drive is ready to accept a run command. | ✓ | ✓ | | ✓ |
| BV1 | Running | Read the drive's Running status, which is active if the drive is running. | ✓ | ✓ | | ✓ |
| BV2 | Running Reverse | Read the drive's Running Reverse status, which is active if the drive is running in the reverse direction. | ✓ | ✓ | | ✓ |
| BV3 | Fault | Read the drive's Fault status, which is active if the drive is faulted. | ✓ | ✓ | | ✓ |
| BV4 | Alarm | Read the drive's Alarm status, which is active if the drive has an alarm. | ✓ | ✓ | | ✓ |
| BV5 | At Reference | Read the drive's At Reference status, which is active if the drive is running at the specified speed reference. | ✓ | ✓ | | ✓ |
| BV10 | Run/Stop | Read/write the adapter's Run/Stop command. Turn on this object to start the drive. Turn off this object to stop the drive. | ✓ | ✓ | | ✓ |
| BV11 | Rev/Fwd | Read/write the adapter's Rev/Fwd command. Turn on this object to command the reverse direction when the drive is running. Turn off this object to command Forward. | ✓ | ✓ | | ✓ |
| BV12 | Ref2/Ref1 | Read/write the adapter's Ref2/Ref1 command. Turn on this object to select the Reference 2 instance of the AV object as the drive's speed reference. Turn off this object to select Reference 1. The drive must be configured to accept its speed reference from the network. This is typically done by setting drive parameter P038 - [Speed Reference] to the value "5" (Comm Port). | ✓ | ✓ | | ✓ |
| BV13 | Clear Faults | Read/write the adapter's Clear Faults command. Turn on this object to clear the drive fault. Turning off this object does nothing. | ✓ | ✓ | | ✓ |

Troubleshooting


Chapter 5 provides information for diagnosing and troubleshooting potential problems with the adapter and network.

| Topic | Page |
|---|---------------------|
| Understanding the Status Indicators | 5-1 |
| PORT Status Indicator | 5-2 |
| MOD Status Indicator | 5-3 |
| NET A Status Indicator | 5-4 |
| NET B Status Indicator | 5-4 |
| Adapter Diagnostic Items | 5-5 |
| Viewing and Clearing Events | 5-6 |

Understanding the Status Indicators

The adapter has four status indicators. They can be viewed on the adapter or through the drive cover. See [Figure 5.1](#).

Figure 5.1 Status Indicators (*location on drive may vary*)



| Item | Status Indicator | Description | Page |
|------|------------------|-------------------------------------|---------------------|
| ❶ | PORT | DSI Connection Status | 5-2 |
| ❷ | MOD | Adapter Status | 5-3 |
| ❸ | NET A | Serial Communication Status | 5-4 |
| ❹ | NET B | Serial Communication Traffic Status | 5-4 |

PORT Status Indicator

| State | Cause | Corrective Actions |
|----------------|---|---|
| Off | The adapter is not powered or is not properly connected to the drive. | <ul style="list-style-type: none">Securely connect the adapter to the drive using the Internal Interface (ribbon) cable.Apply power to the drive (or adapter if mounted in a DSI External Comms Kit). |
| Flashing Red | The adapter is not receiving communication from the drive. | <ul style="list-style-type: none">Verify that cables are securely connected and not damaged. Replace cables if necessary.Cycle power to the drive (or adapter if mounted in a DSI External Comms Kit). |
| Orange | The adapter is connected to a product that does not support Rockwell Automation DSI communications. | Connect the adapter to a product that supports Allen-Bradley DSI communications (for example, PowerFlex 4-Class drives). |
| Flashing Green | The adapter is establishing communications with the drive. | No action required. This status indicator will turn solid green or flashing red. |
| Solid Green | The adapter is properly connected and is communicating with the drive. | No action required. |

MOD Status Indicator

| State | Cause | Corrective Actions |
|----------------|---|--|
| Off | The adapter is not powered or is not properly connected to the drive. | <ul style="list-style-type: none">Securely connect the adapter to the drive using the Internal Interface (ribbon) cable.Apply power to the drive (or adapter if mounted in a DSI External Comms Kit). |
| Flashing Red | The adapter has failed the firmware test. | <ul style="list-style-type: none">Cycle power to the drive (or adapter if mounted in a DSI External Comms Kit).If cycling power does not correct the problem, the adapter parameter settings may have been corrupted. Reset defaults and reconfigure the adapter.If resetting defaults does not correct the problem, flash the adapter with the latest firmware release. |
| Flashing Green | The adapter is operational, but is not transferring I/O data. | Enable the network device that is providing control to the adapter. |
| Solid Green | The adapter is operational and transferring I/O data. | No action required. |

NET A Status Indicator

| State | Cause | Corrective Actions |
|----------------|---|--|
| Off | The adapter is not powered or is not properly connected to the network. | <ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable. Correctly connect the network cable to the adapter's network connector. Apply power to the drive (or adapter if mounted in a DSI External Comms Kit) and network. |
| Flashing Red | A network connection has timed out. | <ul style="list-style-type: none"> Enable the network device that is providing control to the adapter. Check the amount of traffic on the network. |
| Flashing Green | The adapter is properly connected and communicating on the network. | No action required. The LED will flash green each time the token is passed to the adapter by another BACnet device. |

NET B Status Indicator

| State | Cause | Corrective Actions |
|----------------|---|---|
| Off | Adapter is not powered or is not transmitting on the network. | <p>If NET A indicator is off:</p> <ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable, and to the network using the appropriate network cable. Correctly connect the network cable to the adapter's network connector. <p>Normal condition if the adapter is idle.</p> |
| Flashing Green | The adapter is transmitting on the network. | No action required. |

Adapter Diagnostic Items


If you encounter unexpected communications problems, diagnostic items can help you or Rockwell Automation personnel troubleshoot the problem. The following diagnostic items can be accessed using a PowerFlex 4-Class HIM, DriveExplorer (version 3.01 or higher), or DriveExecutive (version 3.01 or higher).

| No. | Name | Description |
|-----|------------------|--|
| 1 | Reserved | — |
| 2 | Logic Cmd | The present value of the Logic Command being transmitted to the drive by the adapter. |
| 3 | Reference | The present value of the Reference being transmitted to the drive by the adapter. |
| 4 | Reserved | — |
| 5 | Logic Sts | The present value of the Logic Status being received from the drive by the adapter. |
| 6 | Feedback | The present value of the Feedback being received from the drive by the adapter. |
| 7 | DSI Overrun Errs | The number of DSI receive overrun errors. |
| 8 | DSI Framing Errs | The number of DSI receive framing errors. |
| 9 | DSI CRC Errs | The number of DSI receive CRC errors. |
| 10 | Boot Flash Count | The number of times the boot firmware in this adapter has been flash updated. |
| 11 | App Flash Count | The number of times the application firmware in this adapter has been flash updated. |
| 12 | MAC Addr SW | The MAC address selected by the DIP switches (SW1-SW7) on the adapter. This value is not latched when the adapter powers up, and will update as the switch settings are changed. |
| 13 | BN Rx Packets | The number of BACnet packets received by the adapter. |
| 14 | BN Tx Packets | The number of BACnet packets transmitted by the adapter. |
| 15 | BN Overrun Errs | A count of the number of BACnet receive overrun errors. |
| 16 | BN Framing Errs | A count of the number of BACnet receive framing errors. |
| 17 | BN CRC Errs | A count of the number of BACnet receive CRC errors. |

Viewing and Clearing Events

The adapter maintains an event queue that reports the history of its actions. You can view the event queue using a PowerFlex 4-Class HIM, DriveExplorer (version 3.01 or higher), or DriveExecutive (version 3.01 or higher).

Figure 5.2 DriveExplorer Event View/Clear Screen



Events

Many events in the event queue occur under normal operation. If you encounter unexpected communications problems, the events may help you or Allen-Bradley personnel troubleshoot the problem. The following events may appear in the event queue:

| Code | Event | Description |
|-----------------------|------------------|--|
| Adapter Events | | |
| 0 | No Event | Text displayed in an empty event queue entry. |
| 1 | Normal Startup | Power is applied to the adapter. |
| 2 | Manual Reset | The adapter was reset from the "Reset Module" parameter. |
| 3 | Watchdog T/O Flt | The software watchdog detected a failure and reset the adapter. |
| 4 | App Updated | The application firmware has been flash updated. |
| 5 | Boot Updated | The boot firmware has been flash updated. |
| 6 | EEPROM Sum Flt | The EEPROM checksum/CRC is incorrect. The functionality of the adapter will be limited. Default parameter values must be loaded to clear this condition. |
| 7-9 | Reserved | — |
| DSI Events | | |
| 10 | Slave Detected | The adapter detected that the slave has been connected. |
| 11 | Slave Removed | The adapter detected that the slave has been disconnected. |
| 12 | Slave Logon | The adapter has established communications with the slave. |
| 13 | Slave Timeout | The adapter has lost communications with the slave. |
| 14 | Slave Brand Flt | The slave brand is different than the adapter. |

| Code | Event | Description |
|-----------------------|------------------|--|
| 15 | Host 0 Logon | The adapter has established communications with the drive. |
| 16-19 | Reserved | — |
| 20 | Host 0 Timeout | The adapter has lost communications with the drive. |
| 21-24 | Reserved | — |
| 25 | Host 0 Brand Flt | The drive is not an Allen-Bradley brand drive. |
| 26-39 | Reserved | — |
| Network Events | | |
| 40 | Net Link Up | The network link is established. |
| 41 | Net Link Down | The network link is lost. |
| 42 | Dup Net Addr | The adapter detected that another device is using its network address. In this case, the adapter will not participate in any network activity. |
| 43 | Net Open | An I/O connection from the network to the adapter was opened. |
| 44 | Net Close | An I/O connection from the network to the adapter was closed. |
| 45 | Net Timeout | An I/O connection from the network to the adapter has timed out. |
| 46 | Net Comm Flt | The adapter has performed the “Comm Flt” action specified by the user. |
| 47 | Net Idle Flt | The adapter has performed the “Idle Flt” action specified by the user. |
| 48 | PCCC IO Open | The adapter has begun receiving PCCC Control messages (the PCCC Control Timeout was previously set to a non-zero value). |
| 49 | PCCC IO Close | The device sending PCCC Control messages to the adapter has set the PCCC Control Timeout to a value of zero. |
| 50 | PCCC IO Time Flt | The adapter has not received a PCCC Control message for longer than the PCCC Control Timeout. |
| 51 | Net Sent Reset | The adapter received a reset from the network. |
| 52 | Msg Ctrl Open | The adapter has begun receiving Client-Server Control messages (the Client-Server Control Timeout was previously set to a non-zero value). |
| 53 | Msg Ctrl Close | The device sending Client-Server Control messages to the adapter has set the Client-Server Control Timeout to a value of zero. |
| 54 | Msg Ctrl Timeout | The adapter has not received a Client-Server Control message for longer than the established timeout period. |

Notes:

Specifications

Appendix A presents the specifications for the adapter.

| Topic | Page |
|---------------------------------------|---------------------|
| Communications | A-1 |
| Electrical | A-1 |
| Mechanical | A-1 |
| Environmental | A-2 |
| Regulatory Compliance | A-2 |

Communications

| | |
|------------|----------------------------------|
| Network | |
| Protocol | BACnet MS/TP |
| Data Rates | 9600, 19200, 38400 or 76800 baud |
| Drive | |
| Protocol | DSI |
| Data Rate | 19.2 kbps |

Electrical

| | |
|-------------|--|
| Consumption | |
| Drive | 275 mA at 5 VDC, supplied through the drive or DSI |
| | External Comms Kit |
| Network | None |

Mechanical

| | |
|------------|-----------------------|
| Dimensions | |
| Height | 19 mm (0.75 inches) |
| Length | 86 mm (3.39 inches) |
| Width | 78.5 mm (3.09 inches) |
| Weight | 85g (3 oz.) |

Environmental

| | |
|-------------------|---|
| Temperature | |
| Operating | -10 to 50°C (14 to 122°F) |
| Storage | -40 to 85°C (-40 to 185°F) |
| Relative Humidity | 5 to 95% non-condensing |
| Atmosphere | Important: Adapter must not be installed in an area where the ambient atmosphere contains volatile or corrosive gas, vapors or dust. If the adapter is not going to be installed for a period of time, it must be stored in an area where it will not be exposed to a corrosive atmosphere. |

Regulatory Compliance

| Certification | Specification |
|---------------|--|
| BACnet | BTL (BACnet Testing Laboratories) approval pending |
| UL | UL508C |
| cUL | CAN / CSA C22.2 No. 14-M91 |
| CE | EN50178 and EN61800-3 |
| CTick | EN61800-3 |

NOTE: The addition of a ferrite core (Fair-Rite P/N 0431167281 or equivalent) to the BACnet cable might be required on applications which must meet IEC 61800-3.

NOTE: This is a product of category C2 according to IEC 61800-3. In a domestic environment this product may cause radio interference in which case supplementary mitigation measures may be required.

Adapter Parameters

Appendix B provides information about the BACnet MS/TP adapter parameters.


| Topic | Page |
|---|---------------------|
| About Parameter Numbers | B-1 |
| Parameter List | B-1 |



About Parameter Numbers

The parameters in the adapter are numbered consecutively. However, depending on which configuration tool you use, they may have different numbers.

| Configuration Tool | Numbering Scheme |
|--|--|
| <ul style="list-style-type: none"> • DriveExplorer • DriveExecutive • HIM | The adapter parameters begin with parameter 1. For example, Parameter 01 - [Reset Module] is parameter 1 as indicated by this manual. |

Parameter List

| Parameter | | |
|--|--|--|
| No. | Name and Description | Details |
| 01 | [Reset Module] No action if set to "Ready." Resets the adapter if set to "Reset Module." Restores the adapter to its factory default settings if set to "Set Defaults." This parameter is a command. It will be reset to "0 = Ready" after the command has been performed. | Default: 0 = Ready Values 0 = Ready 1 = Reset Module 2 = Set Defaults Type: Read/Write Reset Required: No |
|  ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting I/O that controls the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting a connected adapter. | | |

| Parameter | | | |
|-----------|--|---|--|
| No. | Name and Description | Details | |
| 02 | <p>[Comm Loss Action] Sets the action that the adapter and drive will take if the adapter detects that network communications have been disrupted. This setting is effective only if I/O that controls the drive is transmitted through the adapter.</p> | <p>Default: 0 = Fault Values: 0 = Fault 1 = Stop 2 = Zero Data 3 = Hold Last 4 = Send Flt Cfg Type: Read/Write Reset Required: No</p> | |
| | <p> ATTENTION: Risk of injury or equipment damage exists. Parameter 02 - [Comm Loss Action] lets you determine the action of the adapter and connected drive if communications are disrupted. By default, this parameter faults the drive. You can set this parameter so that the drive continues to run. Precautions should be taken to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected drive).</p> | | |
| 03 | <p>[Comm Loss Time] Sets the communication loss timeout period in seconds. The value zero disables this feature.</p> | <p>Default: 10 seconds Minimum: 0 seconds Maximum: 180 seconds Type: Read/Write Reset Required: No</p> | |
| | <p> ATTENTION: Risk of injury or equipment damage exists. Parameter 03 - [Comm Loss Time] lets you determine how long it will take the adapter to detect network communication losses. By default, this parameter sets the timeout to ten (10) seconds. You can set it so that the duration is shorter, longer, or disabled. When set to disabled, this also disables adapter Parameter 02 - [Comm Loss Action]. Therefore, a communications fault action will be ignored. Take precautions to ensure that the setting does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).</p> | | |
| 04 | <p>[Flt Cfg Logic] Sets the Logic Command data that is sent to the drive if Parameter 02 - [Comm Loss Action] is set to "Send Flt Cfg" and network communications are disrupted. The bit definitions will depend on the product to which the adapter is connected. See the documentation for the drive being used.</p> | <p>Default: 0000 0000 0000 0000 Minimum: 0000 0000 0000 0000 Maximum: 1111 1111 1111 1111 Type: Read/Write Reset Required: No</p> | |
| 05 | <p>[Flt Cfg Ref] Sets the Reference data that is sent to the drive if Parameter 02 - [Comm Loss Action] is set to "Send Flt Cfg" and communications are disrupted.</p> | <p>Default: 0 Minimum: 0 Maximum: 65535 Type: Read/Write Reset Required: No</p> | |
| 06 | <p>[Baud Rate Cfg] Sets the baud rate (kilobits per second) at which the adapter communicates. (Updates Parameter 07 - [Baud Rate Act] after a reset.)</p> | <p>Default: 0 = Autobaud Values: 0 = Autobaud 1 = 9600 kbps 2 = 19200 kbps 3 = 38400 kbps 4 = 76800 kbps Type: Read/Write Reset Required: Yes</p> | |

| Parameter | | | |
|-----------|---|--|--|
| No. | Name and Description | Details | |
| 07 | [Baud Rate Act] Displays the baud rate (kilobits per second) actually used by the adapter. | Default: Values: Type: | 0 = Unknown 0 = Unknown 1 = 9600 kbps 2 = 19200 kbps 3 = 38400 kbps 4 = 76800 kbps Read Only |
| 08 | [MAC Address] Displays the actual address selected by the MAC Address Switches SW1-SW7 (Figure 2.1) on the adapter. This value is latched when the adapter powers up. | Default: Minimum: Maximum: Type: | 0 0 127 Read Only |
| 09 | [Max Master] Sets the maximum MAC Address for any device in the BACnet MS/TP token ring. | Default: Minimum: Maximum: Type: Reset Required: | 127 0 127 Read/Write Yes |
| 10 | [Max Info Frames] Sets the maximum number of messages that the adapter can transmit while it owns the token. | Default: Minimum: Maximum: Type: Reset Required: | 1 1 255 Read/Write Yes |
| 11 | [Device Inst Hi] Sets the high-order portion of the Device Instance Number. The Device Instance Number used by the adapter is the value of this parameter times 1000 plus the value of Parameter 12 - [Device Inst Lo] . | Default: Minimum: Maximum: Type: Reset Required: | 160 0 4194 Read/Write Yes |
| 12 | [Device Inst Lo] Sets the low-order portion of the Device Instance Number. The Device Instance Number used by the adapter is the value of Parameter 11 - [Device Inst Hi] times 1000 plus the value of this parameter. | Default: Minimum: Maximum: Type: Reset Required: | 0 0 999 Read/Write Yes |

Notes:

Protocol Implementation Conformance Statement (PICS)

Date: March 27, 2006

Vendor Name: Rockwell Automation

Product Name: 22-COMM-B

Product Model Number: 22-COMM-B

Applications Software Version: 3.003

Firmware Revision: 1.001

BACnet Protocol Revision: 2

Product Description

DSI to BACnet MS/TP communication adapter for PowerFlex 4-Class drives

BACnet Standardized Device Profile (Annex L)

- ☐ BACnet Operator Workstation (B-OWS)
- ☐ BACnet Building Controller (B-BC)
- ☐ BACnet Advanced Application Controller (B-AAC)
- ☒ BACnet Application Specific Controller (B-ASC)
- ☐ BACnet Smart Sensor (B-SS)
- ☐ BACnet Smart Actuator (B-SA)

List all BACnet Interoperability Building Blocks Supported (Annex K)

DS-RP-B, DS-RPM-B,
DS-WP-B, DS-WPM-B,
DM-DDB-B, DM-DOB-B,
DM-DCC-B,
DM-PT-A, DM-PT-B,
DM-RD-B

Segmentation Capability

- ☐ Segmented requests supported Window size _____
- ☐ Segmented responses supported Window size _____

Standard Object Types Supported

The table below lists the object types supported by the 22-COMM-B. Dynamic object creation and deletion is not supported. The property access rules use the following key:

R = Read Only: the property is supported for this object type

W = Read/Write: the property is supported for this object type

C = Commandable: the property is supported for this object type

| Property | Analog Input | Analog Output | Analog Value | Binary Input | Binary Output | Binary Value | Device |
|---------------------------------|--------------|---------------|------------------|--------------|---------------|------------------|------------------|
| APDU Timeout | | | | | | | R |
| Application Software Version | | | | | | | R |
| Database Revision | | | | | | | R |
| Description | R | R | R | R | R | R | W ⁽¹⁾ |
| Device Address Binding | | | | | | | R |
| Event State | R | R | R | R | R | R | |
| Firmware Revision | | | | | | | R |
| Location | | | | | | | W ⁽²⁾ |
| Max APDU Length Accepted | | | | | | | R |
| Max Info Frames | | | | | | | W ⁽³⁾ |
| Max Master | | | | | | | W ⁽⁴⁾ |
| Model Name | | | | | | | R |
| Number of APDU Retries | | | | | | | R |
| Object Identifier | R | R | R | R | R | R | R |
| Object List | | | | | | | R |
| Object Name | R | R | R | R | R | R | R |
| Object Type | R | R | R | R | R | R | R |
| Out of Service | R | R | R | R | R | R | |
| Polarity | | | | R | R | | |
| Present Value | R | C | C ⁽⁵⁾ | R | C | C ⁽⁵⁾ | |
| Priority Array | | R | R ⁽⁶⁾ | | R | R ⁽⁶⁾ | |
| Protocol Object Types Supported | | | | | | | R |
| Protocol Revision | | | | | | | R |
| Protocol Services Supported | | | | | | | R |
| Protocol Version | | | | | | | R |
| Relinquish Default | | R | R ⁽⁶⁾ | | R | R ⁽⁶⁾ | |
| Segmentation Supported | | | | | | | R |
| Status Flags | R | R | R | R | R | R | |
| System Status | | | | | | | R |
| Units | R | R | R | | | | |
| Vendor Identifier | | | | | | | R |
| Vendor Name | | | | | | | R |

⁽¹⁾ This property will accept a maximum of 16 characters when written.

⁽²⁾ This property will accept a maximum of 32 characters when written.

⁽³⁾ This property will accept a value between 1 and 255 inclusive when written.

⁽⁴⁾ This property will accept a value between 0 and 127 inclusive when written.

⁽⁵⁾ This property is commandable for some instances of this object. Otherwise it is read/write.

⁽⁶⁾ This property is supported only for instances of this object where the Present Value property is commandable.

Data Link Layer Options

- ☐ BACnet IP, (Annex J)
- ☐ BACnet IP, (Annex J), Foreign Device
- ☐ ISO 8802-3, Ethernet (Clause 7)
- ☐ ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8)
- ☐ ANSI/ATA 878.1, RS-485 ARCNET (Clause 8), baud rate(s)
- ☒ MS/TP master (Clause 9), baud rate(s): 9600, 19200, 38400, 76800
- ☐ MS/TP slave (Clause 9), baud rate(s):
- ☐ Point-To-Point, EIA 232 (Clause 10), baud rate(s):
- ☐ Point-To-Point, modem (Clause 10), baud rate(s):
- ☐ LonTalk, (Clause 11), medium:
- ☐ Other:

Device Address Binding

Is static device binding supported? (This is currently necessary for two-way communication with MS/TP slaves and certain other devices.)

- ☐ Yes ☒ No

Networking Options

Not applicable.


Notes:

Routing Capability for Networked Drives

Appendix D provides information about the unique routing capability for up to 127 PowerFlex 4-Class drives on a BACnet MS/TP network when using the DriveExplorer (Full version only) drive software tool.

First, configure the 22-COMM-B adapter in each networked drive using the procedures described in [Chapter 2](#). Then use a 1203-USB or 22-SCM-232 converter to connect the first networked drive to a laptop or desktop PC with DriveExplorer Full. Thereafter, you can use DriveExplorer Full to route to any drive on the BACnet MS/TP network to configure or monitor the drive or any of its connected peripherals.

Figure D.1 BACnet MS/TP Network Routing Capability



Notes:

A Adapter

Devices such as drives, controllers, and computers usually require an adapter to provide a communication interface between them and a network such as BACnet MS/TP. An adapter reads data on the network and transmits it to the connected device. It also reads data in the device and transmits it to the network.

The 22-COMM-B adapter connects PowerFlex 4-Class drives to a BACnet MS/TP network. Adapters are sometimes also called “cards,” “embedded communication options,” “gateways,” “modules,” and “peripherals.”

B BACnet MS/TP

BACnet is a data communication protocol for building automation and control networks. BACnet MS/TP (master-slave/token-passing) is a specific type of BACnet network designed to run at speeds of 1 Mbps or less over twisted pair wiring.

Baud Rate

The speed at which data is transferred on the network. Each device on a network must be set for the same baud rate.

C ControlFLASH

ControlFLASH is an Allen-Bradley software tool that lets users electronically update firmware on printed circuit boards. The tool takes advantage of the growing use of flash memory (electronic erasable chips) across industrial control products.

D DSI (Drive Serial Interface)

DSI is based on the Modbus RTU serial communication protocol and is used by PowerFlex 4-Class drives.

DSI Peripheral

A device that provides an interface between DSI and a network or user. Peripheral devices are also referred to as “adapters” and “modules.” The 22-COMM-B, 22-SCM-232 serial converter, and PowerFlex 4-Class HIMs (22-HIM-xxx) are examples of DSI peripherals.

DSI Product

A device that uses the DSI communications interface to communicate with one or more peripheral devices. For example, a motor drive such as

a PowerFlex 4-Class drive is a DSI product. In this manual, a DSI product is also referred to as “drive” or “host.”

DriveExplorer Software

DriveExplorer software is a tool for monitoring and configuring Allen-Bradley products and adapters. It can be run on computers running various Microsoft Windows operating systems. DriveExplorer (version 3.xx or higher) can be used to configure this adapter and PowerFlex drives. Information about DriveExplorer software and a free lite version can be accessed at <http://www.ab.com/drives/driveexplorer>.

DriveTools SP Software

A software suite designed for running on various Microsoft Windows operating systems. This software suite provides a family of tools, including DriveExecutive (version 3.01 or higher), that you can use to program, monitor, control, troubleshoot, and maintain Allen Bradley products. DriveTools SP (version 1.01 or higher) can be used with PowerFlex drives. Information about DriveTools SP can be accessed at <http://www.ab.com/drives/drivetools>.

E EDS (Electronic Data Sheet) Files

EDS files are simple text files that are used by network configuration tools to describe products so that you can easily commission them on a network. EDS files describe a product device type, revision, and configurable parameters. EDS files for many Allen-Bradley products can be found at <http://www.ab.com/networks/eds>.

F Fault Action

A fault action determines how the adapter and connected drive act when a communications fault (for example, a cable is disconnected) occurs.

Fault Configuration

When communication is disrupted (for example, a cable is disconnected), the adapter and PowerFlex drive can respond with a user-defined fault configuration. The user sets the data that is sent to the drive using specific fault configuration parameters in the adapter. When a fault action parameter is set to use the fault configuration data and a fault occurs, the data from these parameters is sent as the Logic Command and Reference.

Flash Update

The process of updating firmware in a device. The adapter can be flash updated using the Allen-Bradley software tool ControlFLASH, the built-in flash capability of DriveExplorer (version 4.01 or higher), or when the adapter is installed in a DSI External Comms Kit, the

X-Modem protocol and a 22-SCM-232 serial converter (version 3.xx or higher firmware).

H HIM (Human Interface Module)

A device that can be used to configure and control a PowerFlex 4-Class drive. PowerFlex 4-Class HIMs (22-HIM-xxx) can be used to configure connected peripherals.

Hold Last

When communications are disrupted (for example, a cable is disconnected), the adapter and PowerFlex drive can respond by holding last. Hold last results in the drive receiving the last data received via the network connection before the disruption. If the drive was running and using the Reference from the adapter, it will continue to run at the same Reference.

I I/O Data

I/O data, sometimes called “implicit messages” or “input/output,” transmit time-critical data such as a Logic Command and Reference. The terms “input” and “output” are defined from the controller’s point of view. Output is produced by the controller and consumed by the adapter. Input is produced by the adapter and consumed by the controller.

L Logic Command/Logic Status

The Logic Command is used to control the PowerFlex drive (e.g., start, stop, direction). It consists of one 16-bit word of output to the adapter from the network. The definitions of the bits in this word depend on the drive.

The Logic Status is used to monitor the PowerFlex drive (for example, operating state, motor direction). It consists of one 16-bit word of input from the adapter to the network. The definitions of the bits in this word depend on the drive.

M MAC Address

Each device on a network must have a unique MAC address to identify it. On BACnet MS/TP networks, devices can have MAC addresses between 0 and 127 if the network is set up to accommodate that number of devices.

N NVS (Non-Volatile Storage)

NVS is the permanent memory of a device. Devices such as the adapter and drive store parameters and other information in NVS so that they are

not lost when the device loses power. NVS is sometimes called “EEPROM.”

P PCCC (Programmable Controller Communications Commands)

PCCC is the protocol used by some controllers to communicate with devices on a network. Some software products (for example, DriveExplorer and DriveExecutive) also use PCCC to communicate.

PowerFlex 4-Class (Component-Class) Drives

The Allen-Bradley PowerFlex Component-Class family of drives include the PowerFlex 4, PowerFlex 40, and PowerFlex 400. These drives can be used for applications ranging from 0.2 kW (0.25 HP) to 7.5 kW (10 HP).

R Reference/Feedback

The Reference is used to send a setpoint (for example, speed, frequency, torque) to the drive. It consists of one 16-bit word of output to the adapter from the network.

Feedback is used to monitor the speed of the drive. It consists of one 16-bit word of input from the adapter to the network.

S Status Indicators

Status indicators are LEDs that are used to report the status of the adapter, network, and drive. They are on the adapter and can be viewed on the front cover of the drive when the drive is powered.

Z Zero Data

When communications are disrupted (for example, a cable is disconnected), the adapter and drive can respond with zero data. Zero data results in the drive receiving zero as values for Logic Command and Reference data. If the drive was running and using the Reference from the adapter, it will stay running but at zero Reference.

Numerics

3-pin linear plug, **2-12**

A

adapter

- applying power, **2-9**
- commissioning, **2-1**
- compatible products, **1-3**
- components, **1-1**
- connecting to a drive, **2-6**
- connecting to the network, **2-11**
- definition, **G-1**
- features, **1-2**
- grounding, **2-6**
- installation, **2-1 to 2-12**
- mounting on a drive, **2-6 to 2-8**
- parameters, **B-1 to B-3**
- resetting, **3-7**
- setting the baud rate, **3-7**
- setting the MAC address, **2-2**
- specifications, **A-1**
- viewing its configuration, **3-8**

applying power to the adapter, **2-9**

attentions, **1-4**

B

BACnet MS/TP network, **G-1**

BACnet objects

- for basic drive control, **4-2**
- supported by the adapter, **4-3**
- types, **4-1**

baud rate

- definition, **G-1**
- setting, **3-7**

Baud Rate Act parameter, **B-3**

Baud Rate Cfg parameter, **B-2**

C

cables

- DSI Internal Interface, **2-6**
- network, **2-12**

Comm Loss Action parameter, **B-2**

Comm Loss Time parameter, **B-2**

commissioning the adapter, **2-1**

compatible products, **1-3**

components of the adapter, **1-1**

configuration tools, **3-1**

configuring parameters, **B-1 to B-3**

connecting

- adapter to the drive, **2-6**
- adapter to the network, **2-11**

ControlFLASH, **G-1**

D

Device Inst Hi parameter, **B-3**

Device Inst Lo parameter, **B-3**

diagnostic items list, **5-5**

dimensions, **A-1**

drive, *see* **DSI products**

DriveExecutive software

- accessing parameters with, **3-1**
- definition, **G-2**
- web site, **G-2**

DriveExplorer software

- accessing parameters with, **3-1**
- definition, **G-2**
- free lite version, **G-2**
- web site, **G-2**

DriveTools SP software, **G-2**

DSI

- definition, **G-1**
- peripheral, **G-1**
- ports on adapter and drive, **2-6**
- products, **1-3, G-1**

E

- EDS (Electronic Data Sheet) files
 - definition, **G-2**
 - web site, **G-2**
- EEPROM, *see Non-Volatile Storage (NVS)*
- electrical specifications, **A-1**
- environmental specifications, **A-2**
- equipment required, **1-3**
- events
 - list of, **5-6**
 - viewing and clearing, **5-6**

F

- factory-default settings, **3-7**
- fault action
 - configuring the adapter for, **3-5**
 - definition, **G-2**
- fault configuration
 - configuring the adapter for, **3-6**
 - definition, **G-2**
- features of the adapter, **1-2**
- firmware release, **P-2**
- flash update, **G-2**
- Flt Cfg Logic parameter, **B-2**
- Flt Cfg Ref parameter, **B-2**

G

- grounding the adapter, **2-6**

H

- HIM (Human Interface Module)
 - definition, **G-3**
 - using to access parameters, **3-2**
- hold last
 - configuring the adapter for, **3-5**
 - definition, **G-3**

I

- I/O data, **G-3**
- installation
 - applying power to the adapter, **2-9**
 - connecting to the drive, **2-6**
 - connecting to the network, **2-11**
 - preparing for, **2-1**
- Internal Interface cable
 - connecting to adapter and drive, **2-6**
 - shipped with adapter, **1-3**

L

- LEDs, *see status indicators*
- Logic Command/Status, **G-3**

M

- MAC address
 - definition, **G-3**
 - setting with switches, **2-2**
- MAC Address parameter, **B-3**
- manual
 - conventions, **P-2**
 - related documentation, **P-1**
- Max Info Frames parameter, **B-3**
- Max Master parameter, **B-3**
- mechanical dimensions, **A-1**
- MOD status indicator
 - locating, **1-7**
 - troubleshooting with, **5-3**
- mounting the adapter, **2-6 to 2-8**

N

- NET A status indicator
 - locating, **1-7**
 - troubleshooting with, **5-4**
- NET B status indicator
 - locating, **1-7**
 - troubleshooting with, **5-4**

network cable - connecting to 3-pin plug, **2-12**

Non-Volatile Storage (NVS)
accessing parameters in, **3-1**
definition, **G-3**

P

parameters
accessing, **3-1**
configuring, **3-1 to 3-8**
list of, **B-1 to B-3**
numbering scheme, **B-1**
restoring to factory-default settings, **3-8**

PCCC (Programmable Controller Communication Commands), **G-4**

plug for network cable, **2-12**

PORT status indicator
locating, **1-7**
troubleshooting with, **5-2**

power consumption, **A-1**

PowerFlex drives compatible with adapter, **1-3**

preparing for installation, **2-1**

Q

quick start, **1-6**

R

Reference/Feedback, **G-4**

regulatory compliance, **A-2**

related documentation, **P-1**

required equipment, **1-3**

Reset Module parameter, **B-1**

resetting the adapter, **3-7**

ribbon cable, *see Internal Interface cable*

routing capability for networked drives, **D-1**

S

safety precautions, **1-4**

specifications for the adapter, **A-1**

status indicators
definition, **G-4**
locating, **1-7**
MOD, **1-7, 5-3**
NET A, **1-7, 5-4**
NET B, **1-7, 5-4**
normal operation, **2-9**
PORT, **1-7, 5-2**
troubleshooting with, **5-2 to 5-4**
understanding, **5-1**

switches
MAC address, **2-2**
TERM, -BIAS, and +BIAS, **2-4**

T

technical support, **P-2**

three-pin linear plug, **2-12**

tools required, **1-3**

troubleshooting, **5-1 to 5-7**

U

update, *see flash update*

V

viewing adapter configuration, **3-8**

W

web site
DriveExecutive software, **G-2**
DriveExplorer software, **G-2**
DriveTools SP software, **G-2**
EDS files, **G-2**
PowerFlex manuals, **P-1**

Z

zero data

configuring the adapter for, **3-5**

definition, **G-4**

U.S. Allen-Bradley Drives Technical Support

Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives

www.rockwellautomation.com



Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846