

Leica GS09

Technical Reference Manual



Version 1.0
English

- when it has to be **right**

Leica
Geosystems

Introduction

Purchase

Congratulations on the purchase of a Leica GS09 system.



To use the product in a permitted manner, please refer to the detailed safety directions in the User Manual.

Product identification

The type and the serial number of your product are indicated on the type plate. Enter the type and serial number in your manual and always refer to this information when you need to contact your agency or Leica Geosystems authorised service workshop.

Type: _____

Serial No.: _____

Symbols

The symbols used in this manual have the following meanings:

Type	Description
	Important paragraphs which must be adhered to in practice as they enable the product to be used in a technically correct and efficient manner.

Trademarks

- Windows is a registered trademark of Microsoft Corporation in the United States and other countries
- CompactFlash and CF are trademarks of SanDisk Corporation
- Bluetooth is a registered trademark of Bluetooth SIG, Inc.

All other trademarks are the property of their respective owners.

Table of Contents

In this manual

Chapter		Page
PART 1 - The System		
1	Managing, Creating, Editing Jobs	12
1.1	Accessing Job Management	12
1.2	Creating a New Job	14
1.3	Editing an Existing Job	15
2	Managing, Creating, Editing Points/Data, Lines, Areas	17
2.1	Accessing Data Management	17
2.2	Creating a New Point	21
2.3	Editing an Existing Point	24
2.4	Creating a New Line/Area	28
2.5	Editing a Line/Area	31
2.6	Viewing the Data Log	34
2.7	Point Sorting and Filters	36
2.8	Terminology	38
3	Managing, Creating, Editing Codes/Codelists	47
3.1	Overview of Codelists	47
3.2	Accessing Codelist Management	49
3.3	Creating/Editing a Codelist	50
3.4	Accessing Code Management	51
3.5	Creating/Editing a Code	53

3.6	Managing Job Codes	55
3.7	Terminology	57
4	Managing, Creating, Editing Coord Systems	63
4.1	Overview of Coordinate Systems	63
4.2	Accessing Coordinate System Management	66
4.3	Creating/Editing a Coordinate System	68
4.4	Transformations	70
4.4.1	Accessing Transformation Management	70
4.4.2	Creating/Editing a Transformation	72
4.5	Ellipsoids	74
4.5.1	Accessing Ellipsoid Management	74
4.5.2	Creating/Editing an Ellipsoid	76
4.6	Projections	77
4.6.1	Accessing Projection Management	77
4.6.2	Creating/Editing a Projection	81
4.7	Geoid Models	83
4.7.1	Overview of Geoid Models	83
4.7.2	Accessing Geoid Model Management	84
4.7.3	Creating a Geoid Model from the CF Card	86
4.8	CSCS Models	87
4.9	Terminology	88
5	Converting Data - Copy, Export, Import	91
5.1	Copying Points Between Jobs	91
5.2	Exporting Data from a Job	93
5.3	Importing Data to a Job	100
6	Configuring the Antenna	106

7	Configuring the Codes and their Attributes	108
8	Configuring the Coordinate Quality Control	110
9	Configuring the Display Mask	112
10	Configuring the HOT Keys and the USER Menu	115
11	Configuring the Instrument Identification	117
12	Configuring the Language	118
13	Configuring the Local Time Zone	120
14	Configuring the Point Occupation Settings	121
15	Configuring the Radio Channel	123
16	Configuring the Interfaces	125
16.1	Overview of Interfaces	125
16.2	Configuring of a Rover Real-Time Interface	126
16.3	Configuring of GGA Message Sending for Reference Network Applications 139	
16.4	Configuring of the Internet Interface	142
17	Configuring NTRIP via Internet	145
17.1	Overview	145
17.2	Configuring a Real-Time Rover for Using NTRIP Service	148
17.2.1	Configuring an Access to the Internet	148
17.2.2	Configuring to Connect to a Server	150
17.2.3	Using the NTRIP Service with a Real-Time Rover	152

18	Configuring the Satellite Settings	155
19	Configuring the Screen Display	157
20	Configuring the Units and Formats	161
21	Using the Tools - Activating Licence Keys	168
22	Using the Tools - Calculating with Calculator	171
22.1	Overview of Calculator	171
22.2	Using the Calculator in RPN Mode	172
22.3	Using the Calculator in Standard Mode	174
22.4	Description of Softkeys	176
22.5	Configuring the Calculator	180
23	Using the Tools - Formatting Objects	182
24	Using the Tools - Transferring Objects	183
25	Using the Tools - Field to Office	186
26	Using the Tools - Uploading Software	191
27	Using the Tools - Viewing Data	194
28	Understanding MapView	197
28.1	Overview of MapView	197
28.2	Configuring MapView	199
28.3	MapView Components - The Softkeys	203
28.4	MapView Components - The Screen Area	204
28.5	MapView Components - The Toolbar	205

28.6	MapView Components - The Point Symbols	206
29	Understanding HOT Keys, USER key, STATUS Key	207
29.1	The HOT Keys	207
29.2	The USER Key	208
29.3	The STATUS Key	209
29.3.1	The Status Menu	209
29.3.2	Status Satellite Information	210
29.3.3	Status Real-Time Data Input	213
29.3.4	Status Current Antenna Position	217
29.3.5	Status Battery Level and Memory Usage	219
29.3.6	Status System Information	221
29.3.7	Status Radio Information	222

PART 2 - The Applications


30	Working with COGO	224
30.1	An Overview of the Program	224
30.2	Starting the Program	225
30.3	Calculating with Inverse	228
30.4	Calculating with Intersections	230
30.5	Calculating with Lines	235
30.6	Calculating with Arcs	238
30.7	Configuring the Program	242
31	Working with Determine Coord System	243
31.1	An Overview of the Program	243
31.2	Starting the Program	248

31.3	Determining a New Coord System using the Normal Method	250
31.4	Updating an Existing Coord System using the Normal Method	258
31.5	Determining a New Coord System using the One Pt. Local. Method	259
31.6	Configuring the Program	267
32	Working with GPS Resection	268
32.1	An Overview of the Program	268
32.2	Starting the Program	269
32.3	Using the Program	270
33	Working with Reference Line	274
33.1	An Overview of the Program	274
33.2	Starting the Program	276
33.3	Measuring to a Reference Line/Arc	280
33.4	Staking to a Reference Line/Arc	285
33.5	Staking to a Polyline	291
33.6	Configuring the Program	302
34	Working with Setup Reference	307
34.1	An Overview of the Program	307
34.2	Starting the Program	308
34.3	Using the Program	310
35	Working with Stakeout	314
35.1	An Overview of the Program	314
35.2	Starting the Program	316
35.3	Staking the Points	319
35.4	Staking the Digital Terrain Model (DTM)	323
35.5	Understanding the Stakeout Icons in MapView	326
35.6	Configuring the Program	328

36	Working with Survey	332
36.1	Starting the Program	332
36.2	Surveying the Points	334
36.3	Surveying the Auto Points	337
36.4	Configuring the Program - SmartCodes	339
36.5	Configuring the Program - Setting the Logging Method	341
36.6	Configuring the Program - Setting the Display Mask	343
37	Working with Survey - Hidden points	345
37.1	Overview	345
37.2	Starting the Program	348
37.3	Measuring Hidden Points	349
37.4	Computing an Azimuth	356
	37.4.1 Using the Sun	356
	37.4.2 Using Auxiliary Point	358
37.5	Computing Horizontal Distances from Slope Distances	360
37.6	Configuring the Program	363
Appendix A	Menu Tree	365
Appendix B	Memory Types	369
Appendix C	Directory Structure of the Memory Device	370
Appendix D	Pin Assignments and Sockets	372
D.1	CS09	372
D.2	GS09	373

Appendix E	Cables	375
<hr/>		
Index		377
<hr/>		

PART 1 - The System



1

Managing, Creating, Editing Jobs

1.1

Accessing Job Management


Access



Managing jobs

Listed are all jobs stored on the CF card. Jobs:

- structure surveying projects.
- contain all points, lines, areas and codes that are recorded and stored.
- can be downloaded to LGO for viewing or for data transfer to a further program.
- can be uploaded from LGO, for example, for real-time stake out operations.
- are stored on the CF card.



CONT (F1)

To select a job and continue.

NEW (F2)

To create a job.

EDIT (F3)

To edit the highlighted job.

DEL (F4)

To delete the highlighted job.

DATA (F5)

To view, edit and delete points, lines and areas stored with the job. Points, lines and areas are shown on separate pages.

The default job

A job called Default is available on CS09 after formatting the CF card or deleting all jobs from MANAGE Jobs.

The active job


The active job is the one data is stored to. One job is always considered the active job. After formatting the CF card, the job Default is used until a user-defined job is created and selected.

When a job becomes active, then the sort and filter settings of this job are saved in the System RAM. If the CompactFlash card is formatted then these last used sort and filter settings are used for the job Default.

1.2

Creating a New Job


Creating a new job step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job. The settings of this job are applied to the new job.
3.	NEW (F2) to access MANAGE New Job.
4.	MANAGE New Job, General page Name. A unique name for the new job. The name may be up to 16 characters long and may include spaces. Input required. Creator. The person's name who is creating the new job. Input optional.
5.	PAGE (F6) changes to the Codelist page.
6.	MANAGE New Job, Codelist page Codelist. Choosing a codelist copies the codes to the job.
7.	PAGE (F6) changes to the Coord System page.
8.	MANAGE New Job, Coord System page Coord System. Choosing a coordinate system attaches it to the job. If it is not known which coordinate system to use, select Coord System: WGS 1984. All other fields on this screen are output fields. They depend on the transformation type of the selected coordinate system.
9.	STORE (F1) creates the new job and returns to MANAGE Jobs.

1.3

Editing an Existing Job

Editing an existing job step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job to be edited.
3.	EDIT (F3)
4.	MANAGE Edit Job: Job Name, General page Name. Rename the job. The remaining functionality on this page is identical with the creation of a new job.
	DATA (F5) accesses MANAGE Data: Job Name. To view, edit and delete points, lines and areas stored with the job. Points, lines and areas are shown on separate pages. Selected sort and filter settings apply.
	SHIFT LOG (F5) accesses MANAGE Data Log: Job Name. To view, edit and delete points, lines and areas stored with the job. Points, lines and areas are sorted by time in one list.
5.	PAGE (F6) changes to the Codelist page.
6.	Are codes stored in the job? <ul style="list-style-type: none">• If no, continue with step 7.• If yes, continue with step 9.
7.	No codes are stored in the job. MANAGE Edit Job: Job Name, Codelist page

Step	Description
	Codelist: None This default setting can be changed. Choosing a codelist copies the codes to the job.
8.	PAGE (F6) changes to the Coord System page. Continue with step 11.
9.	Codes are stored in the job. MANAGE Edit Job: Job Name, Codelist page Codelist. If codes had been copied from a System RAM codelist, the name of the codelist is displayed. If codes have been typed in, then the name of the active job is displayed.
	CODES (F4) views codes currently stored in the job.
10.	PAGE (F6) changes to the Coord System page.
11.	MANAGE Edit Job: Job Name, Coord System page The functionality on this page is identical with the creation of a new job.
12.	STORE (F1) stores the changes and returns to the screen from where MANAGE Edit Job: Job Name was accessed.


2

2.1

Managing, Creating, Editing Points/Data, Lines, Areas

Accessing Data Management

Access step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name.

Description

- The points, lines and areas listed on the pages belong to the currently active job. The order of the points, lines and areas depend on the active sort settings.
- Data is a generic term for points, lines and areas.
- Data management is the administration of data stored in the active job. This includes
 - viewing data with their related information.
 - editing data.
 - creating new data.
 - deleting existing data.
 - sorting existing data.

Managing points

Point	3D CQ	Class
0001	0.0073	MEAS
0002	0.0075	MEAS
0003	0.0076	MEAS
0004	0.0072	MEAS
0005	0.0075	MEAS
reference	5.0000	REF

Softkey menu: CONT NEW EDIT DEL MORE PAGE

CONT (F1)

To accept the screen entries and continue.

NEW (F2)

To create a point.

EDIT (F3)

To edit the highlighted point.

DEL (F4)

To delete the highlighted point.

MORE (F5)

To display information about the codes if stored with any point, the time and the date of when the point was stored, the 3D coordinate quality, the class and the flag for Linework.

PAGE (F6)

To change to another page on the screen.

SHIFT LOG (F4)


To view points, lines, areas and free codes stored with the job sorted by time.

SHIFT FILT (F5)

To define sort settings.

Managing lines and areas

The explanations for the softkeys given below are valid for both pages.
The number in brackets next to the name of the page indicate the number of open lines/areas. Example: Lines (2)/Areas (2) means that two lines/areas are open.



CONT (F1)

To accept the screen entries and continue.

NEW (F2)

To create a line/area. After storing the new line, all existing lines and areas which are open are closed.

EDIT (F3)

To edit the highlighted line/area.

CLOSE (F4) and OPEN (F4)

To change between the options in the Open column of the highlighted line/area.

MORE (F5)

To display information about the codes if stored with any line/area, the start time, the end time of when the last point was added to the line/area, the length of the line, the perimeter and the area of the area.

PAGE (F6)

To change to another page on the screen.

SHIFT DEL (F4)

To delete the highlighted line/area.

SHIFT FILT (F5)

To define sort settings.


Column	Description of column
Line or Area	The listed lines/areas already stored in the active job.

Column	Description of column
Open	<p>The status of a line/area.</p> <ul style="list-style-type: none"><li data-bbox="695 172 1501 258">• Yes The line/area is open. Measured points are assigned to the line/area.<li data-bbox="695 273 1501 359">• No The line/area is closed. Measured points are not assigned to the line/area. <p>CLOSE (F4) and OPEN (F4) change between the options.</p>

2.2

Creating a New Point

Access step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name.

Creating a new point step-by-step

Step	Description
1.	MANAGE Data: Job Name, Points page.
2.	NEW (F2) to access MANAGE New Point.
3.	MANAGE New Point, Coords page. Enter a point ID and the coordinates.
	COORD (F2) to view other coordinate types.
	Negative geodetic coordinates are interpreted as being of the opposite hemisphere or other side of the central meridian. For example, entering -25 °N will be stored as 25 °S, entering -33 °E will be stored as 33 °W.
	NORTH (F3) or SOUTH (F3) . Available for local geodetic or WGS 1984 geodetic coordinates when Local Lat or WGS 1984 Lat is highlighted. Changes between North and South latitude.
	EAST (F3) or WEST (F3) . Available for local geodetic or WGS 1984 geodetic coordinates when Local Long or WGS 1984 Long is highlighted. Changes between East and West longitude.


Step	Description
	SHIFT ELL H (F2) or SHIFT ORTH (F2) . Available for local coordinates. Changes between the ellipsoidal and the orthometric height.
4.	PAGE (F6) changes to the Code page.
5.	<p>MANAGE New Point, Code page</p> <p>The setting for Thematc Codes in CONFIGURE Coding determines the availability of the subsequent fields and softkeys.</p> <ul style="list-style-type: none"> • For Thematc Codes: With Codelist: The codes from the job codelist are used. Point Code. All point codes of the job codelist can be selected. The description of the code is shown as an output field. The attributes are shown as output, input or choicelist fields depending on their definition. • For Thematc Codes: Without Codelist: Codes for points can be typed in but not selected from a codelist. Code. The code to be stored with the point. A check is performed to see if a point code of this name already exists in the job. If so, the according attributes are shown. Attribute n. Up to four attribute values are available.
6.	<p>Is Thematc Codes: With Codelist?</p> <ul style="list-style-type: none"> • If yes, continue with the next row. • If no, continue with step 7.
	NEW-A (F2) allows additional attributes to be created for this point code.

Step	Description
	<p>NAME (F3) or VALUE (F3) Available for attributes for which an attribute name can be typed in. To highlight Attribute n or the field for the attribute value. The name of Attribute n can be edited and an attribute value can be typed in.</p>
7.	<p>STORE (F1) stores the new point entered and all associated information and returns to <i>MANAGE Data: Job Name, Points</i> page.</p>
	<p>It may happen that a point with the same point ID exists in the job. In that case, a new point ID has to be typed in.</p>

2.3

Editing an Existing Point

Access step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name.

Editing an existing point step-by-step

Step	Description
1.	In MANAGE Data: Job Name, Points page highlight a point to be edited.
2.	EDIT (F3) to access MANAGE Edit Point: Point ID.  The visible pages on this screen depend on the properties of the point being edited.
3.	MANAGE Edit Point: Point ID, Coords page It is possible to edit the point ID and for points of Class: CTRL and Class: EST also the coordinates. Other point related data is shown in output fields.  Points of Class: REF cannot be renamed.  Changing the point ID for a point of any class applies this new point ID to all other points with the same original name, regardless of class.
	MORE (F5) displays information about class, sub class, 3D coordinate quality, time and date of when point was stored, the instrument source and the source.
	COORD (F2) to view other coordinate types.

Step	Description
	SHIFT ELL H (F2) or SHIFT ORTH (F2) . Available for local coordinates. Change between the option to enter an ellipsoidal or an orthometric height. Changing the height type does not edit the point.
4.	Is Class: MEAS? <ul style="list-style-type: none"> • If yes, continue with step 5. • If no, continue with step 7.
5.	The edited point is Class: MEAS. PAGE (F6) changes to the Obs page.
6.	MANAGE Edit Point: Point ID, Obs page For GPS points The name of the real-time reference station from where the GPS point was measured, the name of antenna used to measure the point and the baseline values are shown in output fields. For TPS points The name of the station from where the point was measured is shown in an output field.
	MORE (F5) Available for TPS points. Displays the horizontal angle or the azimuth from the point to the instrument.
7.	PAGE (F6) changes to the Code page.
8.	MANAGE Edit Point: Point ID, Code page The point code can be edited. All point codes in the job can be selected. The description of the code is shown as an output field.

Step	Description
	The attributes are shown as output, input or choicelist fields depending on their definition.
	NEW-A (F2) allows additional attributes to be created for this point code.
	NAME (F3) or VALUE (F3) Available for attributes for which an attribute name can be typed in. To highlight Attribute n: or the field for the attribute value. The name of Attribute n can be edited and an attribute value can be typed in.
9.	Is Class: MEAS and no offset point or Class: NAV? <ul style="list-style-type: none"> • If yes, continue with step 11. • If no, continue with step 10.
10.	Is Class: AVGE? <ul style="list-style-type: none"> • If yes, continue with step 13. • If no, continue with step 15.
11.	The edited point is Class: MEAS and no offset point or Class: NAV. PAGE (F6) changes to the Annots page.
12.	MANAGE Edit Point: Point ID, Annots page The comments to be stored with the point can be edited. Continue with step 15.
13.	The edited point is Class: AVGE. PAGE (F6) changes to the Mean page.
14.	MANAGE Edit Point: Point ID, Mean page

Step	Description
	All points of Class: MEAS of the same point ID are listed sorted by time. The settings in the Use column can be edited.
15.	<p data-bbox="539 199 1406 227">STORE (F1) stores the changes and returns to MANAGE Data: Job Name.</p> <p data-bbox="539 241 1222 269"> An edited point retains the creation value for Time.</p> <p data-bbox="539 284 1493 370"> Changing coordinates of a point which has been previously used in other application programs, for example COGO, does not update the application results.</p>
	It may happen that a point with the same point ID exists in the job. In that case, a new point ID has to be typed in.

2.4

Creating a New Line/Area

Description

A line/area consists of points and can be created/edited in MANAGE Data: Job Name. The individual points are measured within any application program. Points can be simultaneously assigned to one or more lines and/or areas.

A line/area can have

- a style for display in MapView.
- a code independent of the point code of the points comprising the line/area.




Points are assigned to a line/area when the line/area is open. Refer to "2.1 Accessing Data Management" for information on how to open a line/area.



The functionality of all screens and fields are similar for the creation of both lines and areas. The step-by-step instructions for creating a new line can be applied for areas.

Access step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name.

Creating a new line step-by-step

Step	Description
1.	MANAGE Data: Job Name, Lines page.
2.	NEW (F2) to access MANAGE New Line.

Step	Description
3.	<p>MANAGE New Line, General page</p> <p>Type in a number for the line, select the points to be stored with the line and select a line style if necessary.</p> <p>Pts to Store. The type of points which are used to form the line during a survey. Select between all points, measured points, auto points and offset points of type 1 or 2.</p> <p>Line Style. This is the line style in which lines/areas are represented in MapView and LGO. For Line Code: <None > on the Code page a line style can be selected from a choicelist. Otherwise the line style as defined for the selected line code is shown.</p>
4.	<p>PAGE (F6) changes to the Code page.</p>
5.	<p>MANAGE New Line, Code page</p> <p>The setting for Thematc Codes: in CONFIGURE Coding & Linework determines the availability of the subsequent fields and softkeys.</p> <ul style="list-style-type: none"> • For Thematc Codes: With Codelist: The codes from the job codelist are used. Line Code. All line codes of the job codelist can be selected. The description of the code is shown as an output field. The line style is shown as defined for the selected line code. It is the style in which lines/areas are represented in MapView and LGO. For Line Code: <None >, it can be changed. The attributes are shown as output, input or choicelist fields depending on their definition.

Step	Description
	<ul style="list-style-type: none"> For Thematc Codes: Without Codelist: Codes for lines can be typed in but not selected from a codelist. Line Code. The line code to be stored with the point. A check is performed to see if a line code of this name already exists in the job. If so, the according attributes are displayed. Attribute n. Up to eight attribute values are available.
6.	<p>Is Thematc Codes: With Codelist?</p> <ul style="list-style-type: none"> If yes, continue with the next row. If no, continue with step 7.
	NEW-A (F2) allows additional attributes to be created for this line code.
	<p>NAME (F3) or VALUE (F3) Available for attributes for which an attribute name can be typed in. To highlight Attribute n: or the field for the attribute value. The name of Attribute n can be edited and an attribute value can be typed in.</p>
7.	<p>STORE (F1) stores the new line entered and all associated information and returns to MANAGE Data: Job Name, Lines page. The value for Start Time: with which the line is stored is the time when STORE (F1) was pressed. The same value is assigned to the value for End Time: until a point is added to the line.</p> <p> Any existing lines and areas which are open are closed.</p>


2.5

Editing a Line/Area



The functionality of all screens and fields are similar for the editing of both lines and areas. The step-by-step instructions for editing a new line can be applied for areas.

Access step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name.

Editing an existing line/area step-by-step

Step	Description
1.	In MANAGE Data: Job Name, Lines page highlight a line to be edited.
2.	EDIT (F3) to access MANAGE Edit Line: Line ID.
3.	MANAGE Edit Line: Line ID, General page The line ID and the type of points which are used to form the line during a survey can be edited. Other line related data is shown in output fields. No. of Pts. The number of points contained within the line. Length. The sum of the distances between the points in the sequential order in which they are stored for the line. This can be a horizontal grid distance or a geodetic distance on the WGS 1984 ellipsoid. Start Time and Start Date. The time/date when the line was created.  A line cannot be renamed to an already existing line ID.

Step	Description
	MORE (F5) displays End Time: and End Date:. This is the time/date when the last point was added to the line. This can be different to the time the point was created. The values do not change after deleting the last added point or after editing unless an additional point is added to the line.
4.	PAGE (F6) changes to the Points page.
5.	MANAGE Edit Line: Line ID, Points page All points belonging to the line are listed. The point that was added last to the line is at the top of the list.
	ADD (F2) Accesses MANAGE Select Point with the Points and Map page. To add an existing point from the active job to the line. A new point is added above the point which was highlighted when ADD (F2) was pressed.
	EDIT (F3) edits the highlighted point.
	REMOV (F4) removes the highlighted point from the line. The point itself is not deleted.
	MORE (F5) displays information about the point codes if stored with the line, the time and the date of when the line was stored, the 3D coordinate quality, the class and the flag for Linework.
6.	PAGE (F6) changes to the Code page.
7.	MANAGE Edit Line: Line ID, Code page The line code can be edited. All line codes can be selected. For Line Code: <None >, the line style can be changed. The description of the code is shown as an output field.

Step	Description
	The attributes are shown as output, input or choicelist fields depending on their definition.
	NEW-A (F2) allows additional attributes to be created for this line code.
	NAME (F3) or VALUE (F3) Available for attributes for which an attribute name can be typed in. To highlight Attribute n: or the field for the attribute value. The name of Attribute n: can be edited and an attribute value can be typed in.
8.	STORE (F1) stores the changes and returns to <i>MANAGE Data: Job Name, Lines</i> page.
	An edited line retains the creation value for Start Time:. The value for End Time: changes when a point was added to the line.


2.6

Viewing the Data Log

Description

A list of all objects and free codes in the active job is displayed in order of time.

Access step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name, Points page.
4.	SHIFT LOG (F4) to access MANAGE Data Log: Job Name.

Viewing the data log



Data Record	Record Type
LINE13	Line
PT49	Point
PT48	Point
PT47	Point
PT46	Point
LINE12	Line
PT45	Point
PT44	Point

In the column Data Record, all points, lines and areas as well as free codes stored within the active job are displayed. They are always sorted by time with the most recent record at the top. For lines and areas, the value for Start Time: is relevant.

CONT (F1)

To accept the screen entries and continue.

NEW (F2)

To insert a free code below, this means timewise before, the currently highlighted object or record. The functionality of inserting a free code is identical to the functionality of entering a free code during a survey.

EDIT (F3)

To edit the highlighted point or free code. The functionality of editing a free code is identical to the functionality of entering a free code during a survey.

DEL (F4)

To delete the highlighted point or free code.

MORE (F5)

To display information about the type of data recorded, the time and the date of when it was stored and the codes if stored with any object.

2.7

Point Sorting and Filters

Description

The sort settings define the order of the objects in the active job. The filter settings define the objects to be viewed. The stakeout filter settings define a filter for the Stakeout application program, for example to show points which are already staked or points that are still to be staked.




The sort setting is stored in the job. It is remembered after turning off the instrument. When a job becomes active, then the sort and filter settings of this job are saved in the SystemRAM. If the CompactFlash card is formatted then these last used sort and filter settings are used for the job Default.



Changing the active job does influence the sort setting for the objects.

Accessing Manage Sorts & Filters, step-by-step


Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name.
4.	SHIFT FILT (F5) on the Points, Lines or Areas page to access MANAGE Sorts & Filters.

Managing point sorting

Field	Description of Field
Sort	<ul style="list-style-type: none">Ascend Point ID, Descend Point ID, Forward Time or Backward Time. Always available. The method objects are sorted by.

Field	Description of Field
Filter	<ul style="list-style-type: none"> Always available. The method the objects are filtered by. CODES (F4): Available on the lines and Areas pages. Available for Filter: Code/Code Group. To select the line codes to be used.  An active filter for an object is indicated in MANAGE Data: Job Name by ¶ located on the right hand side of the page name.

Accessing Manage Stakeout Filter, step-by-step

Step	Description
1.	
2.	In MANAGE Jobs highlight a job.
3.	DATA (F5) to access MANAGE Data: Job Name, Points page.
4.	SHIFT FILT (F5) to access MANAGE Sorts & Filters.
5.	STAKE (F5) to access MANAGE Stakeout Filter.

Managing stakeout filters

Field	Description of Field
View	<ul style="list-style-type: none"> All. Shows all points. Pts to Stakeout. Shows points not yet staked out. Staked Points. Shows points which are already staked out.
	<ul style="list-style-type: none"> RESET (F4) to reset the staked flag for all points of the currently active job.

2.8

Terminology

Description

- This chapter describes technical terms related to data management.
- Some characteristics only become relevant when a GPS1200, TPS1200+ or LGO job is used on GS09.

Coordinate triplet

- A measured point consists of three coordinate components - two horizontal components and one vertical component. The generic term for the three coordinate components is coordinate triplet. Depending on the class, a point ID can contain more than one coordinate triplet of the same and/or of different classes.

The class

- The class describes the type of coordinate triplet.
- The following table shows the classes in descending hierarchical order.

Class	Characteristic	Description
CTRL	Type	<ul style="list-style-type: none">• Control points. Automatically assigned to entered points.• GPS, TPS or LGO
	Instrument source	
ADJ	Type	<ul style="list-style-type: none">• Adjusted points using the adjustment program.• LGO
	Instrument source	
REF	Type	<ul style="list-style-type: none">• Reference point received by a real-time rover• GPS, TPS or LGO
	Instrument source	
AVGE	Type	<ul style="list-style-type: none">• Averaged point calculated when more than one coordinate triplet of class MEAS exist for the same point ID unless <Averaging Mode: Off>.

Class	Characteristic	Description
	Instrument source	<ul style="list-style-type: none"> • GPS or TPS
MEAS	Type	<ul style="list-style-type: none"> • Measured points differentially corrected using real-time phase or real-time code. • Calculated from some application programs.
	Instrument source	<ul style="list-style-type: none"> • GPS, TPS or LGO
NAV	Type	<ul style="list-style-type: none"> • Navigated points using uncorrected code solutions of a single epoch.
	Instrument source	<ul style="list-style-type: none"> • GPS
EST	Type	<ul style="list-style-type: none"> • Estimated points from LGO.
	Instrument source	<ul style="list-style-type: none"> • LGO.

The sub class

The sub class describes certain classes in detail. It indicates the status of the position when a coordinate triplet was measured and how the coordinates were determined.

Sub class	Description	Instrument source
COGO	Indirect coordinate determination with application program COGO.	GPS or TPS
NONE	Direction is available but no coordinates. Height is available but no position coordinates.	TPS Level
TPS	Measured with distances and angles.	TPS
Fixed (Height)	Manually entered and fixed in height.	GPS or TPS
Fixed (Position)	Manually entered and fixed in position.	GPS or TPS

Sub class	Description	Instrument source
Fixed (Pos & Ht)	Manually entered and fixed in position and height.	GPS or TPS
GPS Code Only	Direct coordinate determination with code solution.	GPS
GPS Fixed	Direct coordinate determination with phase fixed solution.	GPS
GPS Float	Direct coordinate determination with autonomous solution coming from LGO.	GPS
Hidden Point	Indirect coordinate determination with hidden point measurements.	GPS or TPS
Additional sub classes for GLONASS sensors:		
GNSS Code Only	Direct coordinate determination with code solution.	GPS
GNSS Fixed	Direct coordinate determination with phase fixed solution.	GPS
GNSS Float	Direct coordinate determination with autonomous solution coming from LGO.	GPS

The source

The source describes the application program or functionality that generated a coordinate triplet and the method with which it was created.

Source	Originated from application program/functionality	Instrument source
ASCII File	Convert Data, Import ASCII/GSI Data to Job	GPS or TPS

Source	Originated from application program/functionality	Instrument source
Arc Base Pt	COGO, Arc Calculation - Base Point	GPS or TPS
Arc Centre Pt	COGO, Arc Calculation - Centre Point	GPS or TPS
Arc Offset Pt	COGO, Arc Calculation - Offset Point	GPS or TPS
Arc Segmt Pt	COGO, Arc Calculation - Segmentation	GPS or TPS
Backward Brg-Dist	Hidden point measurements, Backward Bearing and Distance	GPS
Bearing-Distance	Hidden point measurements, Bearing and Distance	GPS
Chainage-Offset	Hidden point measurements, Chainage and Offset	GPS
COGO Area Divsn.	COGO Area Division	GPS or TPS
COGO Shift/Rtn	COGO, Shift, Rotate & Scale (Manual) COGO, Shift, Rotate & Scale (Match Pts)	GPS or TPS
COGO Traverse	COGO, Traverse	GPS or TPS
Copied Point	Convert Data, Copy points between jobs	GPS or TPS
Cross Section	Survey Cross Section on System1200.	GPS or TPS
Double Bearing	Hidden point measurements, Double Bearing	GPS
Double Distance	Hidden point measurements, Double Distance	GPS
GSI File	Convert Data, Import ASCII/GSI Data to Job	GPS or TPS
Hidden Point	Hidden Point, auxiliary points	TPS
Intsct (Brg Brg)	COGO, Intersection - Bearing - Bearing	GPS or TPS
Intsct (Brg Dst)	COGO, Intersection - Bearing - Distance	GPS or TPS

Source	Originated from application program/functionality	Instrument source
Intsct (Dst Dst)	COGO, Intersection - Distance - Distance	GPS or TPS
Intsct (4 Pts)	COGO, Intersection - By points	GPS or TPS
LandXML	Design to Field in LGO converting data from LandXML software to be used in the field	LGO
Line Base Pt	COGO, Line Calculation - Base Point	GPS or TPS
Line Offset Pt	COGO, Line Calculation - Offset Point	GPS or TPS
Line Segmt Pt	COGO, Line Calculation - Segmentation	GPS or TPS
None	No information on the source is available	GPS or TPS
RefLine (Grid)	Reference Line, staked out in a defined grid	GPS or TPS
RefLine (Meas)	Reference Line, measured	GPS or TPS
RefLine (Poly)	Reference Line, staked out relative to a polyline	GPS or TPS
RefLine (Stake)	Reference Line, staked out	GPS or TPS
Ref Plane (Meas)	Reference Plane, measured	GPS or TPS
Ref Plane (Scan)	Reference Plane, scan	TPS
Road Runner	Road Runner	GPS or TPS
Sets of Angles	Sets of Angles	TPS
Setup (Known BS)	Setup, Known Backsight Point	TPS
Setup (Loc Rsct)	Setup, Local Resection	TPS
Setup (Ori&Ht)	Setup, Orientation and Height Transfer	TPS
Setup (Resect)	Setup, Resection	TPS

Source	Originated from application program/functionality	Instrument source
Setup (Resect H)	Setup, Resection Helmert	TPS
Setup (Set Az)	Setup, Set Azimuth	TPS
Srvy Auto Offset	Survey Auto Points, automatically recorded with offsets	GPS or TPS
Stakeout	Stakeout	GPS or TPS
Survey	Survey, measured	TPS
Survey (Auto)	Survey Auto Points, automatically recorded	TPS
Survey (Event)	Survey, Event input	GPS
Survey (Instant)	Survey, measured with Pt Occupation: Instantaneous in CONFIGURE Point Occupation Settings	GPS
Survey (Rem Pt)	Survey, Remote Point	TPS
Survey (Static)	Survey, measured with Pt Occupation: Normal in CONFIGURE Point Occupation Settings	GPS
Traverse	Traverse	TPS
Unknown	-	GPS or TPS
User Application	Customised application programs	GPS or TPS
User Entered	Manually entered point	GPS or TPS

The instrument source

The instrument source describes where the coordinate triplet was measured or entered. The options are **GPS**, **TPS** or **LGO**.

The coordinate quality

Description

The Coordinate Quality is:

- computed on the rover for code solutions and phase fixed solutions.
- an indicator for the quality of the observations.
- an indicator for the current satellite constellation.
- an indicator for different environmental conditions.
- derived such that there is at least a two third probability that the computed position deviates from the true position by less than the CQ value.
- different from the standard deviation.

CQ versus standard deviation

The standard deviation as CQ would often be too optimistic. This is why the computation of the CQ in GS09 is not simply based on the basic standard deviation algorithms.


For the standard deviation, there is, statistically, a 39.3% probability in 2D that the computed position deviates from the true position by less than the standard deviation. This is not enough for a reliable quality indicator.

This is particularly true for low redundancy situations such as a constellation of four satellites. In such a case the RMS converges to zero and the standard deviation would show an unrealistically small value.

Computation

GPS measurements





Range

For a phase fixed solution:


Centimetre level

For a code solution:


From 0.4 to 5 m.

Position CQ versus height CQ

All GPS computed positions are almost twice as accurate in plan than in height. For the position determination, satellites can appear in all four quadrants. For the height determination, satellites can appear in two quadrants. This weakens the height position compared to the plan position.



Position determination with satellites appearing in all four quadrants.



Height determination with satellites appearing in two quadrants.


3 Managing, Creating, Editing Codes/Codelists

3.1 Overview of Codelists



It is recommended to create a codelist in LGO. A codelist can be transferred from LGO to the System RAM of the CS09 or from the PC via ActiveSync to the CF card of the CS09.

Steps from creating to using a codelist



The creating, editing and managing of codelists is explained in this chapter.


In order to use a codelist on the CS09, it must be transferred from the CF card to the System RAM. Refer to "24 Using the Tools - Transferring Objects".

3.2 Accessing Codelist Management

Access



Managing codelists



Listed are all codelists stored in the System RAM.

CONT (F1)

To select a codelist and continue. If this screen was accessed from a choicelist, the codes from the highlighted codelist are copied to the active job.

NEW (F2)

To create a codelist.

EDIT (F3)

To edit the highlighted codelist.

DEL (F4)

To delete the highlighted codelist.

MORE (F5)

To display information about the creator and the date of when the codelist was created.

3.3

Creating/Editing a Codelist

Creating/editing a codelist step-by-step

Step	Description
1.	
2.	MANAGE Codelists NEW (F2) or EDIT (F3)
3.	MANAGE New Codelist or MANAGE Edit Codelist Name. A unique name for the codelist. The name may be up to 16 characters long and may include spaces. Input required. Creator. The person's name who is creating the new codelist. Input optional.
	CODES (F4) accesses MANAGE Codes where codes can be created, edited or deleted.
4.	STORE (F1) stores the codelist and returns to MANAGE Codelists.

3.4


Accessing Code Management

Description


Managing codes includes:

- creating new codes,
- viewing codes with their related information,
- editing codes,
- deleting existing codes.

Access step-by-step

Step	Description
1.	
2.	In MANAGE Codelists highlight the codelist of which codes are to be managed.
3.	EDIT (F3) to access MANAGE Edit Codelist.
4.	CODES (F4) to access MANAGE Codes. This screen is described below.

Managing codes



The **att** indicates codes which have attributes attached.

CONT (F1)

To accept the screen entries and continue.

NEW (F2)

To create a new code.

EDIT (F3)

To edit the highlighted code.

DEL (F4)

To delete the highlighted code.

3.5

Creating/Editing a Code

Creating/editing a code step-by-step

Step	Description
1.	Refer to "3.4 Accessing Code Management" to access MANAGE Codes.
2.	NEW (F2) or EDIT (F3)
3.	<p>MANAGE New Code or MANAGE Edit Code</p> <p>Code. A unique name for the new code. The name may be up to 16 characters long and may include spaces. Input required.</p> <p>Code Desc. A detailed description of the code. This can be for example the full designation if Code is an abbreviation. Input optional.</p> <p>Code Type. The use of the code. On CS09, point codes can be created. Line and area code types can be displayed when editing a code from a System1200 codelist.</p> <p>Linework. Available for point codes. Allows a new line/area to be opened whenever the point code is newly selected. This functionality is also available when creating codelists with the LGO codelist Management.</p> <p>Line Style. Available for point codes or when editing a code from a System1200 codelist. The style in which lines/areas are represented in MapView and LGO.</p>
4.	NEW-A (F2) adds Attribute 1 as new input field for an attribute of attribute type normal and of value type text.
	NAME (F3) or VALUE (F3) Available for attributes for which an attribute name can be typed in. To highlight Attribute 1 or the field for the attribute value. The name of Attribute 1 can be edited and the attribute value to be used as the default attribute value can be typed in.

Step	Description
	Attributes of attribute type mandatory or fixed and of value type real or integer must be created in LGO.
	Up to four attributes can be created.
	Attribute names that have already been typed in cannot be edited in a job codelist.
5.	<p>Is another attribute to be created?</p> <ul style="list-style-type: none"> • If yes, repeat step 4. • If no, continue with step 6.
6.	STORE (F1) adds the new code and any associated attributes or stores the changes to the System RAM codelist and returns to the screen from where this screen was accessed.
	A new code can also be created within an application program. In this case, the new code is added to the job codelist.

3.6


Managing Job Codes

Description


To view and edit all codes currently stored in the job. The functionality of this screen is mainly the same as for MANAGE Codes. For simplicity, the functionality which is different from MANAGE Codes is explained here.

Access step-by-step

Available for jobs which have a codelist attached.

Step	Description
1.	
2.	In MANAGE Jobs highlight a job to be edited.
3.	EDIT (F3) to access MANAGE Edit Job: Job Name.
4.	In MANAGE Edit Job: Job Name, PAGE (F6) until the Codelist page is active.
5.	CODES (F4) to access MANAGE Job Codes.

Managing job codes



CONT (F1)

To accept the screen entries and continue.


NEW (F2)

To create a new code.

EDIT (F3)

To edit the highlighted code. Accesses MANAGE Edit Code where new attributes can be added to a code and line styles can be changed.

Editing a job code



STORE (F1)

To store the code including any newly created attributes and to return to the screen from where MANAGE Edit Code was accessed.

NEW-A (F2)

To add a new attribute to a code.

NAME (F3) or VALUE (F3)

Available for attributes for which an attribute name can be typed in. To highlight Attribute n or the field for the attribute value. The name of Attribute n can be edited and an attribute value can be typed in.

3.7

Terminology

Description



This chapter describes technical terms related to codes and codelists.


The values for codes and attributes are case sensitive. For example the code Tree is not the same as the code TREE.

Code

Description

A code is a description which can be stored with an point or alone.

Structure of codes



Code types

The code type defines how a code can be used. It is possible to create a code of the same name but of different code types in LGO. Example: The code Oak can exist with code type point code and with code type free code.

Point code: To record a code directly with a point. This is thematical point coding.
Point codes can be created on CS09.


Free code: To record a code based on time in between points.

Attribute

Description

The use of attributes allows additional information to be stored with the code. Up to twenty attributes can be related to one code. Attributes are not compulsory.

Structure of attributes



Attribute types

The attribute type defines the input requirements for the attribute.

- Normal: An input for the attribute is optional. The attribute value can be typed in the field. New attributes with this attribute type can be created in LGO or on the CS09.
- Mandatory: An input for the attribute is compulsory. The attribute value must be typed in the field. New attributes with this attribute type can be created in LGO.
- Fixed: The attribute value is a predefined default which is displayed but cannot be changed in the field. This attribute value is automatically attached to the code. New attributes with this attribute type can be created in LGO.

Attribute value types

The attribute value type defines which values are accepted as input.

- Text: Any input for the attribute is interpreted as text. New attributes with this attribute value type can be created in LGO or on the CS09.
- Real: An input for the attribute must be a real number, for example 1.23. New attributes with this attribute value type can be created in LGO.
- Integer: An input for the attribute must be an integer number, for example 5. New attributes with this attribute value type can be created in LGO.

Attribute value regions

The attribute value region defines if the attribute values must be selected from a predefined list.

- None: An input for the attribute must be typed in. New attributes with this attribute value region can be created in LGO or on the CS09.
- Range: An input for the attribute must fall within a predefined range. New attributes with this attribute value region can be created in LGO.

Chocelist: An input for the attribute is selected from a predefined list. New attributes with this attribute value region can be created in LGO.

Example

Code	Attributes	Attribute value type	Attribute value region	Example for the attribute value region
Birch	Height	Real	Range	0.5-3.0
	Condition	Text	Chocelist	Good, Dead, Damaged
	Remark	Text	None	-

Codelist

Description

A codelist is a collection of codes that can be used to describe surveyed points in the field.

Elements of a codelist

- Code
- Attributes

Structure of a codelist

Structure	Example
<pre>Codelist -- Code 1 -- Attribute 1.1.1 -- Attribute ... -- Attribute 1.1.20 -- Code 2 -- Attribute 1.2.1 -- Attribute ... -- Code ...</pre>	<pre>Codelist -- Birch -- Height -- Condition -- Remark -- Road -- Material -- ... -- ...</pre>

Codelist types

System RAM codelist:

A codelist stored in the System RAM of the CS09.

Job codelist:

The collection of codes contained within the currently active job.

4 Managing, Creating, Editing Coord Systems

4.1 Overview of Coordinate Systems

Description

A coordinate system:

- consists of up to five elements.
- allows the conversion from WGS 1984 geodetic or cartesian coordinates to, local cartesian, geodetic or grid coordinates and back.
- can be attached to jobs.
- can be manually defined.
- can be computed in the field.
- can be directly received from a reference network.
- can be downloaded to LGO.
- can be uploaded from LGO.



All GPS surveyed points are always stored as WGS 1984 geodetic coordinates regardless of the coordinate system being used. Using a different coordinate system converts the coordinates displayed on the screen, but does not convert and restore the coordinate values in the database DB-X.




One coordinate system can be attached to a job at one time. This coordinate system remains attached to the job unless it is changed.

Elements of a coordinate system

The five elements which define a coordinate system are:

- a transformation
- a projection
- an ellipsoid
- a geoid model
- a Country Specific Coordinate System model



GS09_TR_016

- a) WGS 1984 cartesian: X, Y, Z
- b) WGS 1984 ellipsoid
- c) WGS 1984 geodetic: Latitude, longitude, ellipsoidal height
- d) 7 parameter transformation: dX , dY , dZ , rx , ry , rz , scale
- e) Local cartesian: X, Y, Z
- f) Local ellipsoid
- g) Local geodetic: Latitude, longitude, ellipsoidal height
- h) Local projection
- i) Local grid: Easting, Northing, orthometric height

All these elements can be specified when creating a coordinate system.

The default coordinate system

The default coordinate system is WGS 1984. It cannot be deleted. Additional default coordinate systems may be available for certain countries.

The WGS 1984 coordinate system

WGS 1984 is the global geocentric datum to which all GPS positioning information is referred to. WGS 1984 is the default coordinate system on a CS09. It is not possible to manually create a coordinate system called WGS 1984.

The active coordinate system

The active coordinate system is the one attached to the job currently being used. One coordinate system is always considered as the active coordinate system.

The RTCM coordinate system

For Use Auto CrdSys=Yes configured in **CONFIGURE Additional Rover Settings** the coordinate system is directly received from a reference network. It is not possible to delete this coordinate system when it is active. Refer to "The active coordinate system".

4.2


Accessing Coordinate System Management

Access



For Use Auto CrdSys=Yes configured in **CONFIGURE Additional Rover Settings** the coordinate system management can only be accessed by selecting **Main Menu:**   .

Managing coordinate systems



Listed are all coordinate systems stored in the database DB-X. Any unavailable information is shown as -----.

CONT (F1)

To select a coordinate system and continue. The selected coordinate system will be attached to the active job.

NEW (F2)

To create a coordinate system manually.

EDIT (F3)

To edit the highlighted coordinate system.

DEL (F4)

To delete the highlighted coordinate system. This is not possible when the highlighted coordinate system is active and its source is RTCM.

MORE (F5)

To display information about the type of transformation used, the type of heights computed, the number of control points used for the determination and the date of when the coordinate system was created.

SHIFT SET-D (F4)

Available unless a default coordinate system is highlighted. To turn the highlighted coordinate system into a user defined default coordinate system stored in the CS09.

SHIFT DEFLT (F5)

To recall the deleted default coordinate systems.

4.3

Creating/Editing a Coordinate System



Coordinate systems can be defined by manual creation or determined by calculation. In this chapter, the manual creation of coordinate systems is explained. Refer to "31 Working with Determine Coord System" for information on the determination by calculation.



Coordinate systems with a Classic 3D transformation can be defined by manual creation.

Creating/Editing a coordinate system step-by-step

Step	Description
1.	
2.	In MANAGE Coordinate Systems highlight a coordinate system. When creating a new coordinate system, a copy of this coordinate system is taken for further configurations.
3.	NEW (F2) or EDIT (F3)
4.	MANAGE New Coordinate System or MANAGE Edit Coordinate System Name. A unique name for the new coordinate system. The name may be up to 16 characters long and may include spaces. Residuals. Available for transformations with control points. Manually entered transformations do not have control points. The method by which residuals are distributed throughout the transformation area. The transformation results become more realistic and any strain is dispersed in the transformation.

Step	Description
	<p>Residuals: $1/\text{Distance}$, $1/\text{Distance}^2$ and $1/\text{Distance}^{3/2}$ distribute the residuals of the control points according to the distance between each control point and the newly transformed point.</p> <p>Residuals: Multiquadratic distributes the residuals using a multiquadratic interpolation approach.</p> <p>Transform. The type of transformation. The transformation type determines the availability and the options of the subsequent fields.</p> <p>Pre Transform. Available for Twostep transformations from System1200. The name of a preliminary 3D transformation which is used together with the selected projection to obtain preliminary grid coordinates to be used for a final 2D transformation.</p> <p>Ellipsoid. Available unless projection Type: Customised. The local coordinates are based on this ellipsoid.</p> <p>Projection. The map projection.</p> <p>Geoid Model. The geoid model.</p> <p>For coordinate systems to be edited with source RTCM only the geoid model in use can be changed. Refer to "The RTCM coordinate system".</p> <p>CSCS Model. The Country Specific Coordinate System model.</p> <p>Make the required changes.</p>
5.	STORE (F1) stores the coordinate system and returns to MANAGE Coordinate Systems.

4.4

4.4.1




Access step-by-step


Transformations

Accessing Transformation Management

MANAGE Coordinate Systems cannot be accessed for coordinate systems with source RTCM. Refer to "The RTCM coordinate system".

Step	Description
1.	 A screenshot of the software interface. The top status bar shows the time 10:21, the coordinate system ID CS09, and some technical data like 13, 6=7, and sigma=11. A menu is open with 'Main Menu' highlighted in blue. There are also two icons on the right: a document icon and a globe icon.
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3)
4.	In MANAGE Edit Coordinate System highlight Transform.
5.	ENTER to access MANAGE Transformations.

Managing transformations



Listed are all Classic 3D transformations stored in the database DB-X. Any unavailable information is shown as -----.

CONT (F1)

To select a transformation and continue.

NEW (F2)

To create a new transformation.

EDIT (F3)

To edit the highlighted transformation.

DEL (F4)

To delete the highlighted transformation.

MORE (F5)

To display information about the type of heights computed and the number of control points used for the determination of the transformation.


SHIFT SET-D (F4)

To turn the highlighted transformation into a user defined default transformation stored in the CS09.

4.4.2

Creating/Editing a Transformation

Access step-by-step

Step	Description
	Transformations with source RTCM cannot be edited. Refer to "The RTCM coordinate system".
1.	
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3)
4.	In MANAGE Edit Coordinate System highlight Transform.
5.	ENTER to access MANAGE Transformations.

Creating/Editing a transformation step-by-step

Step	Description
1.	In MANAGE Transformations highlight a transformation. When creating a new transformation, a copy of this transformation is taken for further configurations.
2.	NEW (F2) or EDIT (F3)
3.	MANAGE New Transformation, General page or MANAGE Edit Transformation, General page Name. A unique name for the new transformation. The name may be up to 16 characters long and may include spaces. Type. Output field. No other transformations than Classic 3D can be created. Enter a name.

Step	Description
4.	PAGE (F6) changes to the Parameters page.
5.	MANAGE New Transformation, Parameters page or MANAGE Edit Transformation, Parameters page Enter the known values or change the existing values of the transformation parameters.
6.	PAGE (F6) changes to the More page.
7.	MANAGE New Transformation, More page Height Mode. The type of heights to be computed or used. Transf Model. The transformation model to be used. For Transf Model: Molodensky-Bad, additional input fields are available.
	CLEAR (F5) Available for Transf Model: Molodensky-Bad. To set the additional input fields to 0.
8.	STORE (F1) stores the transformation and returns to MANAGE Transformations.

4.5

4.5.1




Access step-by-step

Ellipsoids

Accessing Ellipsoid Management

MANAGE Ellipsoids cannot be accessed for coordinate systems with source RTCM. Refer to "The RTCM coordinate system".

Step	Description
1.	 A screenshot of the MANAGE software interface. The top status bar shows the time 10:21, the coordinate system CS09, and other parameters like Σ=11 and G=7. A menu bar is visible with 'Main Menu' highlighted in blue. There are also some icons on the right side of the interface.
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3) to access MANAGE Edit Coordinate System.
4.	In MANAGE Edit Coordinate System highlight Ellipsoid.
5.	ENTER to access MANAGE Ellipsoids.

Managing ellipsoids



Listed are all ellipsoids stored in the database DB-X.

CONT (F1)

To select an ellipsoid and continue.

NEW (F2)

To create a new ellipsoid.

EDIT (F3)

To edit the highlighted ellipsoid.

DEL (F4)

To delete the highlighted ellipsoid.

SHIFT SET-D (F4)

To turn the highlighted ellipsoid into a user defined default ellipsoid stored in the CS09.


SHIFT DEFLT (F5)

To recall the deleted default ellipsoids.

4.5.2

Creating/Editing a Ellipsoid

Access step-by-step

Step	Description
1.	 A screenshot of the software interface. The top status bar shows the time 10:21, the user ID CS09, and various system icons including a cursor, a printer, and a globe. The 'Main Menu' option is highlighted in blue.
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3) to access MANAGE Edit Coordinate System.
4.	In MANAGE Edit Coordinate System highlight Ellipsoid.
5.	ENTER to access MANAGE Ellipsoids.

Creating/Editing an ellipsoid step-by-step

Step	Description
1.	In MANAGE Ellipsoids highlight an ellipsoid. When creating a new ellipsoid, a copy of this ellipsoid is taken for further configurations.
2.	NEW (F2) or EDIT (F3)
3.	MANAGE New Ellipsoid or MANAGE Edit Ellipsoid Name. A unique name for the new ellipsoid. A name is mandatory and may be up to 16 characters long and may include spaces. Axis a. The semi-major axis a. 1/f. The reciprocal value of flattening f. Enter a name.
4.	STORE (F1) stores the ellipsoid and returns to MANAGE Ellipsoids.

4.6

4.6.1




Access step-by-step


Projections

Accessing Projection Management

MANAGE Projections cannot be accessed for coordinate systems with source RTCM. Refer to "The RTCM coordinate system".

Step	Description
1.	 A screenshot of a software interface. The top left shows the time '10:21' and the coordinate system 'CS09'. To the right are several icons, including a crosshair, a document, and a globe. A blue bar at the bottom of the screenshot contains the text 'Main Menu'.
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3) to access MANAGE Edit Coordinate System.
4.	In MANAGE Edit Coordinate System highlight Projection.
5.	ENTER to access MANAGE Projections.

Managing projections



Listed are all projections stored in the database DB-X. Any unavailable information is shown as -----.

CONT (F1)

To select a projection and continue.

NEW (F2)

To create a new projection.

EDIT (F3)

To edit the highlighted projection.

DEL (F4)

To delete the highlighted projection.

SHIFT SET-D (F4)

Available unless a default projection is highlighted. To turn the highlighted projection into a user defined default projection stored in the CS09.

SHIFT DEFLT (F5)

To recall the deleted default projections.

Column	Option	Description of Column
Type	Customised	The projection type. Refer to standard surveying literature for details on projections. Customised projection. Certain fixed projections which cannot be defined by any of the following options.


Column	Option	Description of Column
	Trans Mercator	Transverse Mercator. Conformal projection onto a cylinder with its axis lying on the equatorial plane. The cylinder is tangential to a meridian.
	UTM	Universal Transverse Mercator. Transverse Mercator projection with fixed zone-defining constants. The central meridian is selected automatically according to the selected zone number.
	Oblq Mercator	Oblique Mercator. Oblique Mercator Conformal projection onto a cylinder. The cylinder is tangent to any circle other than the equator or a meridian.
	Mercator	Mercator. Conformal projection onto a cylinder with its axis lying on a meridian plane. The cylinder is tangent to the sphere along the equator.
	Lambert 1 Para	Lambert 1 Parallel. Conformal projection onto a cone, with its axis coinciding with the z-axis of the ellipsoid.
	Lambert 2 Para	Lambert 2 Parallel. Conformal projection onto a cone, with its axis coinciding with the z-axis of the ellipsoid. The cone is secant to the sphere.
	Cassini-Soldn	Soldner Cassini. Projection onto a cylinder. It is neither equal area nor conformal. The scale is true along the central meridian and along lines perpendicular to central meridian.

Column	Option	Description of Column
	Polar Stereo	Polar Stereographic. Conformal azimuthal projection onto a plane. The point of projection is on the surface of the ellipsoid diametrically opposite of the origin which is the centre of the projection.
	Double Stereo	Double Stereographic. Conformal azimuthal projection onto a plane. The point of projection is on the surface of the sphere diametrically opposite of the centre of the projection.
	RSO	Rectified Skewed Orthomorphic. This is a special type of Oblique Mercator projection.

4.6.2

Creating/Editing a Projection

Access step-by-step

Step	Description
	Transformations with source RTCM cannot be edited. Refer to "The RTCM coordinate system".
1.	
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3) to access MANAGE Edit Coordinate System.
4.	In MANAGE Edit Coordinate System highlight Projection.
5.	ENTER to access MANAGE Projections.

Creating/Editing a projection step-by-step

Step	Description
1.	In MANAGE Projections highlight a projection. When creating a new projection, a copy of this projection is taken for further configurations.
2.	NEW (F2) or EDIT (F3)
3.	MANAGE New Projection or MANAGE Edit Projection Name. A unique name for the new projection. A name is mandatory and may be up to 16 characters long and may include spaces. Type. The projection type. The setting for Type determines the availability of the subsequent fields for the parameters of the projection. Enter a name.

Step	Description
4.	STORE (F1) stores the projection and returns to MANAGE Projections.

4.7

4.7.1

Geoid Models

Overview of Geoid Models

Use in the field

For use on the CS09 in the field, geoid field files are created from the geoid model.

Geoid field file

The geoid separations in a geoid field file may be used in the field to change between ellipsoidal and orthometric heights.


Creation: In LGO with export to the CF card of the CS09.

Extension: *.gem

Creating a geoid model on CS09


Geoid models can be created on the CS09 in one of two ways:

1.



Here the geoid field file is stored on the CF card of the CS09. It is recommended for large geoid field files. This method is explained in this chapter.

2.




Here the geoid field file is transferred to the System RAM and can be used at any time. The total size of all files in the System RAM is restricted to 1 MB. Refer to "24 Using the Tools - Transferring Objects" for information on how to transfer geoid field files to the System RAM of the CS09.


4.7.2

Accessing Geoid Model Management

Access step-by-step

Step	Description
1.	
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3) to access MANAGE Edit Coordinate System.
4.	In MANAGE Edit Coordinate System highlight Geoid Model.
5.	ENTER to access MANAGE Geoid Models.

Managing geoid models



Listed are all geoid models stored in the database. Any unavailable information is shown as -----, for example if the geoid field file which was associated to the geoid model is not available on the CF card.

CONT (F1)

To select a geoid model and continue.

EDIT (F3)

To view the highlighted geoid model. None of the fields can be edited. The geoid field file from which the geoid model was created must be stored in the System RAM or in the \DATA\GPS\GEOID directory of the CF card.

DEL (F4)

To delete the highlighted geoid model. The geoid field file which was associated with this geoid model is then also deleted.

4.7.3

Creating a Geoid Model from the CF Card

Requirement

At least one geoid field file with the extension *.gem is in the \DATA\GPS\GEOID directory of the CF card. Refer to "24 Using the Tools - Transferring Objects" for information on how to transfer geoid field files to the System RAM on the CS09.

Creating a geoid model step-by-step

Step	Description
1.	 A screenshot of the CS09 Main Menu screen. The top left shows the time 10:21 and the date CS09. The top right shows a compass icon, a checkmark, and the text Σ=11 and G=7. The bottom left shows a blue bar with the text "Main Menu". The bottom right shows two icons: a blue folder icon and a globe icon.
2.	In MANAGE Coordinate Systems highlight a coordinate system to be edited.
3.	EDIT (F3) to access MANAGE Edit Coordinate System.
4.	In MANAGE Edit Coordinate System highlight Geoid Model.
5.	ENTER to access MANAGE Geoid Models.
6.	INTL (F6) to scan the \DATA\GPS\GEOID directory of the CF card.
7.	For each geoid field file on the CF card, one geoid model is automatically created. The names given to the geoid models are those which were entered in LGO.  Existing geoid models are automatically overwritten by new models with the same name.
8.	The creation of a geoid model is finished.

4.8

CSCS Models

Use in the field

For use on the CS09 in the field, CSCS field files are created from the CSCS model.

CSCS field file

CSCS field files may be used in the field to directly convert coordinates from WGS 1984 to local grid without the need of transformation parameters.

Creation: In LGO with export to the CF card of the CS09.

Extension: *.csc



The creation of CSCS models on the CS09 and the functionality of all screens and fields are similar to those for geoid models.

The directory on the CF card for CSCS field files with the extension *.csc is \DATA\GPS\CSCS.

4.9

Terminology

Description

This chapter describes technical terms related to coordinate system management.

Transformation


Refer to "4.1 Overview of Coordinate Systems" for information on transformations.

Geoid model

Description

GPS operates on the WGS 1984 ellipsoid and all heights obtained by measuring baselines are ellipsoidal heights. Existing heights are usually orthometric heights, also called height above the geoid, height above mean sea level or levelled height. The mean sea level corresponds to a surface known as the geoid. The relation between ellipsoidal height and orthometric height is

Orthometric Height = Ellipsoidal Height - Geoid Separation N



GS09_TR_015

N value and geoid model

The geoid separation (N value) is the distance between the geoid and the reference ellipsoid. It may refer to the WGS 1984 or to the local ellipsoid. It is not a constant except over maybe small flat areas such as 5 km x 5 km. Therefore it is necessary to model the N value in order to obtain accurate orthometric heights. The modelled N values form a geoid model for an area. With a geoid model attached to a coordinate system, N values for the measured points can be determined. Ellipsoidal heights can be converted to orthometric heights and back.

Refer to the online help of LGO for more information on geoid models.



Geoid models are an approximation of the N value. In terms of accuracy, they may vary considerably and global models in particular should be used with caution. If the accuracy of the geoid model is not known it might be safer to use local control points with orthometric heights and apply a transformation to approximate the local geoid.

Geoid field file

Geoid field files may be used in the field to calculate orthometric heights out of ellipsoidal heights and vice versa.

CSCS model

Description

Country Specific Coordinate System models

- are tables of correction values to directly convert coordinates from WGS 1984 to local grid without the need of transformation parameters.
- take the distortions of the mapping system into account.
- are an addition to an already defined coordinate system.

Types of CSCS models

The correction values of a CSCS model can be applied at different stages in the coordinate conversion process. Depending on this stage, a CSCS model works differently. Three types of CSCS models are supported by GS09. Their conversion process is as explained in the

following table. Any suitable geoid model can be combined with a geodetic CSCS model. Refer to the online help of LGO for more information on CSCS models.

Type	Description
Grid	<ol style="list-style-type: none"> 1. Determination of preliminary grid coordinates by applying the specified transformation, ellipsoid and map projection. 2. Determination of the final local grid coordinates by applying a shift in Easting and Northing interpolated in the grid file of the CSCS model.
Cartesian	<ol style="list-style-type: none"> 1. Performing the specified transformation. 2. Determination of local cartesian coordinates by applying a 3D shift interpolated in the grid file of the CSCS model. 3. Determination of the final local grid coordinates by applying the specified local ellipsoid and map projection.
Geodetic	<ol style="list-style-type: none"> 1. Determination of local geodetic coordinates by applying a correction in latitude and longitude interpolated from the file of the CSCS model. 2. Determination of the final local grid coordinates by applying the local map projection. <p> Using a geodetic CSCS model excludes the use of a transformation in a coordinate system.</p>

CSCS field file

CSCS field files may be used in the field. They are extracted from the main CSCS model, which may be too big to fit on the instrument.

5 Converting Data - Copy, Export, Import

5.1 Copying Points Between Jobs

Description



This chapter explains the process of copying points from one job to another.


Important features:

- Points selected for copying may be viewed in a points listing. The point sort settings define the order of the points in the listing.
- When points are copied from one job to another:
 - their point codes and attached attributes are also copied.
 - their Class is retained.
 - their Sub Class is retained.
 - their Source is changed to Copied Point.
 - their Point Coordinate Quality is retained.
 - their Instrument Flag is retained.
 - their Date and Time Stamp is retained.

Access



Copying points between jobs



CONT (F1)

To accept the screen entries and continue.

DATA (F5)

To view, edit and delete points stored with the job. Selected sort settings apply.

CSYS (F6)

To select a different coordinate system.



Field	Description of Field
From Job	Describes where the points are to be copied from.
Coord System	The coordinate system which is currently attached to the job From Job.
To Job	Describes where the points are to be copied to.

5.2

Exporting Data from a Job

Description

- This screen lists all the exporters loaded.
- Data will be exported to a file on the CF card.

Export formats

Format	Characteristic	Description
Custom ASCII	Export variables	Refer to the online help of LGO.
	Format definition	Composed individually as format file using LGO. Refer to the online help of LGO for information on creating format files.
	Units	Defined within the format file.
	Coordinate conversion	All coordinate types are supported.
	Height	All height types are supported. If the desired height cannot be computed, the default value for the missing variable is output.
	Specialities:	
	Points in file outside of CSCS model	The default value for missing variable is output.
	Points in file outside of geoid model	The default value for missing variable is output, also if a geoid separation is available.
DXF	Coordinate conversion	All points are converted to local grid position using the coordinate system.
	Height	Orthometric height and ellipsoidal height are supported.

Format	Characteristic	Description
	Specialities: Points in file outside of CSCS model Points in file outside of geoid model	Points outside of CSCS model are not exported. The ellipsoidal height is exported.
LandXML	Coordinate conversion Height Specialities: Points in file outside of CSCS model Points in file outside of geoid model	All points are converted to local grid position using the coordinate system. Orthometric height and ellipsoidal height are supported. Local grid position of the points outside of CSCS model is not exported. The ellipsoidal height is exported.

Requirements

At least one format file was created using LGO and has been transferred to the System RAM.

Export ASCII Data from Job


- The settings on this screen define the data that is converted and exported and what format is used.
- Data is exported from the selected job. Currently active sort settings are applied. The points that are exported are those that are visible in MANAGE Data: Job Name.

Export data job to a custom ASCII format step-by-step


Step	Description
1.	
2.	Export ASCII
3.	<p>EXPORT Export ASCII Data from Job</p> <p>Export To: CF Card. Data can be exported to the CF card. Directory The data can be exported to the \Data, the \GSI or the root directory.</p> <p>Job. All jobs from Main Menu:   can be selected.</p> <p>Coord System. The coordinate system currently attached to the selected Job. Format File. The format files currently available in the System RAM. File Name. The name of the file to which the data should be exported. Select the job to be exported and enter a file name.</p>
4.	Highlight Format File and ENTER .
5.	<p>EXPORT Format Files</p> <p>All format files available in the System RAM are listed. Select the format file to be used.</p>
	DEL (F4) deletes the highlighted format file from the System RAM.
6.	CONT (F1) selects the highlighted format file and leads back to EXPORT Export Data from Job.
	CSYS (F6) accesses EXPORT Coordinate Systems. To update the coordinate system in which the coordinates are exported.
7.	CONT (F1) exports the data.

Step	Description
8.	Information message: Are more data to be exported? <ul style="list-style-type: none"> If yes, continue with step 9. If no, continue with step 10.
9.	YES (F4) . Repeat steps 2. to 8.
10.	NO (F6) returns to the GS09 Main Menu.

Export data job to DXF format step-by-step

Step	Description
1.	
2.	Export DXF
3.	<p>EXPORT Export DXF from Job</p> <p>Job. All jobs from Main Menu:   can be selected.</p> <p>Coord System. The coordinate system currently attached to the selected Job.</p> <p>File name. The name of the file to which the data should be exported. The name is automatically suggested based on the job name to be exported and the extension dxf.</p>
	<p>CONF (F2) accesses Configuration, Export page.</p> <p>Points. Defines if points are exported.</p> <p>Lines. Defines if lines are exported.</p> <p>Areas. Defines if areas are exported.</p>

Export data job to LandXML format step-by-step

Step	Description
1.	
2.	<p>Export LandXML</p>
3.	<p>EXPORT Export LandXML from Job</p> <p>Job. All jobs from Main Menu:   can be selected.</p> <p>Coord System. The coordinate system currently attached to the selected Job.</p> <p>File name. The name of the file to which the data should be exported. The name is automatically suggested based on the job name to be exported and the extension dxf.</p>
	<p>CONF (F2) accesses Configuration, Export page.</p> <p>Points. Defines if points are exported.</p> <p>Lines. Defines if lines are exported.</p> <p>Areas. Defines if areas are exported.</p> <p>TPS measurements. Defines if TPS observations are exported.</p> <p>GPS measurements. Defines if GPS observations are exported.</p> <p>Codes. Defines if point codes, line codes and area codes are exported.</p> <p>Free Codes. Defines if the free code, the free code description, the free code group and the free code attributes are exported to the LandXML file associated to each exported point.</p>
4.	<p>FILT (F4) to set the sort and filter settings for export. Accesses EXPORT Sorts & Filters.</p>

Step	Description
5.	<p>EXPORT Sorts & Filters, Points page.</p> <p>Sort. The order in which points, lines and areas are exported.</p> <p>Filter. Defines which points are exported.</p>
	<p>PAGE (F6) changes to the Lines or Areas page. The setting for Filter on these pages defines which lines or areas are exported.</p>
6.	<p>CONT (F1) leads back to EXPORT Configuration, Export page.</p>
	<p>PAGE (F6) changes to the LandXML page.</p> <p>Dimensions. Defines the dimension (2D, 3D) or the exported entities.</p> <p>LandXML version. Defines the LandXML version of the exported file. Supported LandXML versions: 1.0/1.1.</p>
7.	<p>CONT (F1) leads back to EXPORT Export LandXML from Job.</p>
8.	<p>CONT (F1) exports the data.</p>
	<p>Message: Do not remove CF Card!</p>
9.	<p>Information message: Are more data to be exported?</p> <p>If yes, continue with step 10.</p> <p>If no, continue with step 11.</p>
10.	<p>YES (F6). Repeat steps 2. to 8.</p>
11.	<p>NO (F4) returns to the GS09 Main Menu.</p>

5.3

Importing Data to a Job

Description

- This screen lists all the importers loaded. The data to import must be stored on the CF card.
- Data can be imported to a job on the CF card.

Import formats

Format	Characteristic	Description
ASCII	Import variables	Point ID, grid coordinates, thematic codes. No free codes, no attributes.
	Format definition	Free format. Use and order of variables and delimiter can be defined during import.
	Units	As currently configured on the CS09.
	Height	Orthometric or ellipsoidal
	Local heights but no coordinates in file	Points are imported without coordinates but with local height and code if available.
	Coordinates but no heights in file	Points are imported without height but with coordinates and code if available.
	Neither coordinates nor heights in file	No import
No point ID's in file	No import	
GSI8 GSI16	Import variables	Point ID (WI 11), local coordinates (WI 81, WI 82, WI 83), thematic codes (WI 71). No free codes, no attributes. Example for GSI8: 110014+00001448 81..01+00001363 82..01-00007748 83..01-00000000 71....+000sheep


Format	Characteristic	Description
	Format definition Units Heights Local heights but no coordinates in file Coordinates but no heights in file Neither coordinates nor heights in file No point ID's in file	Fixed format. Easting and Northing can be switched during import. As defined in the GSI file Orthometric or ellipsoidal Points are imported without coordinates but with local height and code if available. Points are imported without height but with coordinates and code if available. No import No import
DXF	Import variables Format definition Units Heights Neither coordinates nor heights in file	Block, point, line, arc, polyline. Local coordinates. No free codes, no attributes. Fixed format (X/Y/Z). Not predefined. Z value imported as orthometric. No import

Checks

Points are always imported with the class CTRL and a coordinate quality of -----.

While importing points to a job, checks are performed against point ID, class and coding of points already existing in the job.

Import data in ASCII format step-by-step

Step	Description
 1.	At least one ASCII file with any file extension is stored in the \DATA directory of the CF card. 
2.	Import ASCII/GSI Data
3.	IMPORT Import ASCII/GSI Data to Job Import: ASCII Data From File. All files in the \DATA directory of the CF card can be selected. To Job. Choosing a job as destination for import makes this job the active job. Header. This option allows up to ten header lines which may exist in an ASCII file to be skipped. Select the number of header lines.
4.	CONF (F2) defines the format of the data to be imported.
5.	IMPORT Define ASCII Import Delimiter. The separator between the import variables. Multi Spaces. Available for Delimiter: Space. Multi Spaces: No for space delimited data having one space between the variables. Multi Spaces: Yes for space delimited data having multi spaces between the variables. No. Lines/Pt. Available for Delimiter: Line Feed. The number of lines used to describe each point. Select the delimiter and the positions of the particular variables.
	DEFLT (F5) recalls the default ASCII import settings.
6.	CONT (F1) leads back to IMPORT Import ASCII/GSI Data to Job

Step	Description
7.	CONT (F1) imports the data.
8.	Information message: Are more data to be imported? <ul style="list-style-type: none"> • If yes, continue with step 9. • If no, continue with step 10.
9.	YES (F6) . Repeat steps 3. to 8.
10.	NO (F4) returns to the GS09 Main Menu.

Import data in GSI format step-by-step

Step	Description
 1.	At least one ASCII file in GSI format with the file extension *.gsi is stored in the \GSI directory of the CF card. 
2.	Import ASCII/GSI Data
3.	IMPORT Import ASCII/GSI Data to Job Import: GSI Data From File. All files with extension *.gsi in the \GSI directory of the CF card can be selected. To Job. Choosing a job as destination for import makes this job the active job.
	CONF (F2) accesses IMPORT Define GSI Import. For Switch WI81/WI82: Yes all WI 81 data, normally Easting, is imported as Northing and all WI 82 data, normally Northing, is imported as Easting. This coordinate switch is necessary for "left handed" coordinate systems.

Step	Description
4.	CONT (F1) imports the data.
5.	Information message: Are more data to be imported? <ul style="list-style-type: none"> • If yes, continue with step 6. • If no, continue with step 7.
6.	YES (F6) . Repeat steps 3. to 5.
7.	NO (F4) returns to the GS09 Main Menu.

Import DXF data step-by-step

Step	Description
 1.	At least one file in DXF format with the file extension *.dxf has to be stored in the \DATA directory of the CF card. 
2.	DXF Import
3.	DXF IMPORT Import DXF Data to Job From File. All files with extension *.dxf in the \DATA directory of the CF card can be selected. To Job. Choosing a job as destination for import makes this job the active job.
 	CONF (F2) accesses Configuration. Block Prefix. Optional prefix to imported blocks. Point Prefix. Optional prefix to imported points. Line Prefix. Optional prefix to imported lines.

Step	Description
	<p>File Units. Choosing the unit for the DXF data to be imported.</p> <p>Create Vertex Points. Option if points will be created at vertices of the imported line/arc/polyline elements. These points will be imported with class EST.</p> <p>Convrt White Elements. Option if white colored elements will be converted to black elements.</p> <p>Exclude Height. Height value inside the DXF file is considered invalid and will not be converted.</p> <p>CONT (F1) leads back to DXF IMPORT Import DXF Data to Job.</p>
4.	CONT (F1) imports the data.
5.	<p>Information message: Are more data to be imported?</p> <ul style="list-style-type: none"> • If yes, continue with step 6. • If no, continue with step 7.
6.	YES (F6) . Repeat steps 3. to 5.
7.	NO (F4) returns to the GS09 Main Menu.


6

Configuring the Antenna

Description

The settings on this screen define the antenna and the default height for the antenna.

Access



Configuring



Antenna : GS09 Pole
Default Ht : 2.000 m
Vert Offset : 0.000 m
Comm : Bluetooth
ID Address : 01d1d1e1

CONT (F1)

To accept the screen entries and continue.

SRCH (F4)

To search for all available Bluetooth devices. If more than one Bluetooth device is found a list of available devices is provided. The user can then select from this list.



Field	Description of Field
Antenna	<ul style="list-style-type: none">The antenna in the CS09 System RAM.
Default Ht	<ul style="list-style-type: none">The default antenna height during the use of the programs. The antenna height can still be changed during a survey.
Vert Offset	<ul style="list-style-type: none">The vertical antenna offset for the selected antenna.
Comm	<ul style="list-style-type: none">The communication medium between CS09 and GS09.

Field	Description of Field
	<ul style="list-style-type: none"><li data-bbox="699 132 1492 188">• Bluetooth. Use this setting if CS09 will be connected to GS09 via Bluetooth.<li data-bbox="699 199 1492 255">• USB Cable. Use this setting if CS09 will be connected to GS09 via Cable.
ID Address	<ul style="list-style-type: none"><li data-bbox="699 277 1149 296">• The ID address of GS09 to be used.

7 Configuring the Codes and their Attributes


Description

The settings on this screen define the method of coding. Refer to "3 Managing, Creating, Editing Codes/Codelists" for a complete description of coding.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Attributes	<ul style="list-style-type: none"> Determines the attribute values displayed under certain circumstances. This is applicable to both the storing and displaying of attribute values. Default Values. When available, the default attribute values, as stored in the job, are displayed and stored.


Field	Description of Field
	<ul style="list-style-type: none">• Last Used. When available, the last used attribute values as stored in the job are displayed and stored.
Thematc Codes	<ul style="list-style-type: none">• Sets the coding method.• With Codelist. Codes stored within the job codelist can be selected to code points.• Without Codelist. Codes stored within the job codelist cannot be selected to code points. Each code must be entered manually.

8 Configuring the Coordinate Quality Control


Description

The settings on this screen define the limits for coordinate quality and DOP values accepted for point occupations.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
CQ Control	<ul style="list-style-type: none"> The type of coordinate quality to be checked before storing a point. If activated, the limit defined in Maximum CQ is checked before storing a point. A warning signal is given when the limit is exceeded. None. No checking is made on the point.

Field	Description of Field
	<ul style="list-style-type: none"><li data-bbox="695 128 1214 157">• Pos Only. The point position is checked.<li data-bbox="695 169 1230 198">• Height Only. The point height is checked.<li data-bbox="695 209 1493 238">• Pos & Height. The point position and point height are checked.
Maximum CQ	<ul style="list-style-type: none"><li data-bbox="695 255 1500 312">• Available unless CQ Control=None. The maximum acceptable coordinate quality.

9

Configuring the Display Mask


Description

Display settings define the parameters shown on the main page of the Survey program. The settings on this screen define the layout of the display mask.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

CLEAR (F4)

To clear all the fields except the first field.

DEFLT (F5)

To recall the default settings.

Field	Description of Field
Name	<ul style="list-style-type: none"> Input field for the page name.
Visible	<ul style="list-style-type: none"> This is set to Yes. The display mask is always shown.
Fixed Lines	<ul style="list-style-type: none"> From 0 to 5. Defines how many lines do not scroll in the screen.
1st Line to 16th Line	<ul style="list-style-type: none"> For each line one of the following options can be selected.

Field	Description of Field
	<ul style="list-style-type: none"> • Antenna Ht. Input field for antenna height for static observations. • Attrib (free) 01-04. Output field for attributes for free codes. • Attrib 01-04. Input field for attributes for codes. • Code. Input field for codes. • Code (free). Input field for free codes. • Code Desc. Output field for description of codes. • Code Desc (free). Output field for description of free codes. • Code Type. Output field for the type of code. • GDOP. Output field for current GDOP of the computed position. • HDOP. Output field for current HDOP of the computed position. • Line Space Full. Insert full line space. • Line Space Half. Insert half line space. • Moving Ant Ht. Input field for antenna height for moving observations. • PDOP. Output field for current PDOP of the computed position. • Point ID. Input field for point number. • Quality 1D. Output field for current height coordinate quality of computed position. • Quality 2D. Output field for current 2D coordinate quality of computed position.


Field	Description of Field
	<ul style="list-style-type: none"><li data-bbox="691 126 1505 188">• Quality 3D. Output field for current 3D coordinate quality of computed position.<li data-bbox="691 193 1505 288">• RTK Positions. Output field for number of positions recorded over the period of point occupation. Appears in the display mask of real-time rover configurations.<li data-bbox="691 294 1505 389">• Time at Point. Output field for time from when the point is occupied until point occupation is stopped. Appears in the display mask during the point occupation.<li data-bbox="691 395 1505 435">• VDOP. Output field for current VDOP of the computed position.

10 Configuring the HOT Keys and the USER Menu

Description

The settings on this screen assign a particular function, screen or application program to each of the hot keys and to the **USER** key. Refer to "29 Understanding HOT Keys, USER key, STATUS Key" for more information on hot keys and the **USER** key.

Access



Configuring the Hot Keys




F7 : FUNC Select Free Code
 F8 : MGMT Data
 F9 : STAT Satellite Status
 F10: STAT Current Position
 F11: STAT Battery & Memory
 F12: FUNC Touch Screen On/Off



- CONT (F1)**
To accept the screen entries and continue.
- DEFLT (F5)**
To recall the default settings.
- PAGE (F6)**
To change to the next page on the screen.

Field	Description of Field
F7 to F12	All functions, screens or application programs which can be assigned to the particular key.

Configuring the User Menu



CONT (F1)

To accept the screen entries and continue.

DEFLT (F5)

To recall the default settings.

PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
1 to 9	All functions, screens or application programs which can be assigned to the individual lines in the user defined menu.

11

Configuring the Instrument Identification

Description

The settings on this screen define the instrument identification number. This number is used for the generation of the file names. Using format files, the instrument ID can be output together with data from the instrument. By doing so, it can be identified which instrument was used for certain measurements.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

DEFLT (F5)

To recall the default settings.



Field	Description of Field
Instrument ID	Sets a four digit number as instrument identification number. By default the last four numbers of the serial number are used.

12

Configuring the Language


Description

The setting on this screen defines the language used on the instrument. Three languages can be stored on the CS09 at one time - English and two others. English cannot be deleted. Refer to "26 Using the Tools - Uploading Software" for information on uploading languages.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

DEL (F4)

To delete the highlighted language.



Field	Description of Field
Language	The languages available on CS09. The selected language is used for the system software. If a language is not available for the system software, the English language is used instead. Application programs run in the language they were loaded.

13

Configuring the Local Time Zone


Description

The settings on this screen help CS09 to quickly locate and track satellites.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Time Zone	<ul style="list-style-type: none"> From -13:00 to +13:00. The time zone for the current location and local date.
Local Time	<ul style="list-style-type: none"> Setting the local time supports a very fast satellite acquisition.
Local Date	<ul style="list-style-type: none"> Setting the local date supports a very fast satellite acquisition.

14

Configuring the Point Occupation Settings


Description

The settings on this screen define the way in which points are occupied and recorded.

Access



Configuring pt occupation settings



Auto STOP : Yes
Auto STORE : No

CONT (F1)

To accept the screen entries and continue.

PARAM (F3)

To configure the time interval after which a point occupation can be stopped automatically.



Field	Description of Field
Auto STOP	<ul style="list-style-type: none">• Yes or No. Stops the measurements automatically when the parameter defined reaches 100 %.
Auto STORE	<ul style="list-style-type: none">• Yes or No. Stores points automatically after stopping the point occupation.

Configuring auto stop parameters



Auto STOP/%Indicator based on

Pos Quality < : 0.050 m
Ht Quality < : 0.070 m

For a min number of positions

Positions : 5
Position Update : 0.20 s



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Pos Quality	Sets the maximum position qualities for each point occupation. Calculating the qualities starts when OCUPY (F1) is pressed. The CS09 stops measuring when the position and height qualities are both less than the configured values.
Ht Quality	Sets the maximum height qualities for each point occupation. Calculating the qualities starts when OCUPY (F1) is pressed. The CS09 stops measuring when the position and height qualities are both less than the configured values.
Positions	Raw data is recorded for a minimum number of positions even when the Pos Quality and Ht Quality is already less than the specified maximum.
Position Update	The time interval after which a new position is calculated.

15

Configuring the Radio Channel


Description

The settings on this screen allow parameters related to radio to be configured.

Access



Configuring



Radio Type : Satellite 3AS
Channel : ██████████ 11
Actual Freq : 433.8000 MHz



CONT (F1)

To accept the screen entries and continue.

SCAN (F5)

Provides information such as the station ID, latency and the data format of incoming signals from reference stations broadcasting on the same radio channel. This information can be used to select appropriate reference stations to dial. The data format of the selected reference station is automatically used on the rover. Leica data format is standard in GS09.

Field	Description of Field
Radio Type	<ul style="list-style-type: none"> • The type of radio. Depending on the radio attached to the CS09, the Radio type will be switched automatically between: <ul style="list-style-type: none"> • IFR-300L • IFR300 • Intuicom 1200 DL • PacificCrest PDL (receive only) • Satelline 3AS • TFR300
Channel	<ul style="list-style-type: none"> • The radio channel. The channel used must be within minimum and maximum allowed input values. The minimum and maximum allowed input values for a radio depend on the number of channels supported by the radio and the spacing between the channels. Type in the radio channel.
Actual Freq	<ul style="list-style-type: none"> • The actual frequency of the radio. Only available for the Satelline 3AS radio.

16

Configuring the Interfaces

16.1

Overview of Interfaces



The configuration of the Interfaces requires the purchase of the RTK network access option. Refer to "21 Using the Tools - Activating Licence Keys".


Description

The real-time interface allows real-time related parameters to be configured.

Access



Configuring Interfaces



CONT (F1)

To accept the screen entries and continue.

EDIT (F3)

To configure the parameters related to the highlighted interface. Refer to the sections on each individual interface below.

CTRL (F4)

To configure additional parameters, for example changing channels of radios.


16.2

Configuring of a Rover Real-Time Interface

Access



Step 1 Configuring Real-Time Mode



CONT (F1)

To accept the screen entries and continue.

ROVER (F2)

To configure additional settings relevant to rover operations. Refer to "Step 2 Configuring Additional Rover Options, General Page".

DEVCE (F5)

To create, select, edit or delete a device. Available unless an SBAS data format has been selected for R-Time Data:. Refer to " " for information on SBAS.

SHIFT PARA (F3)

To activate and deactivate the prediction of real-time observations between the data rate of the reference. Refer to paragraph "Prediction" for information on prediction. Available unless R-Time Data=RTCM 1,2 v2 or R-Time Data=RTCM 9,2 v2. Define if GLONASS observations are fixed or not in an RTK solution or whether the sensor automatically decides.

SHIFT FILT (F4)

To activate and deactivate the height filter for height smoothing. Refer to paragraph "Height smoothing" for information on height smoothing.


Field	Description of Field
R-Time Mode	<ul style="list-style-type: none">• None or Rover. R-Time Data=Rover activates a rover real-time interface.
R-Time Data	<ul style="list-style-type: none">• Leica. The proprietary Leica real-time GPS data format. This is recommended when working exclusively with Leica receivers.• Leica 4G. The proprietary Leica real-time GNSS data format. This is recommended when working exclusively with Leica GNSS receivers.• CMR/CMR+. CMR and CMR+ are compacted formats used to broadcast data for third-party receivers.• RTCM v3.1. Use RTCM when rover units from a different manufacturer are to be used. Message according to RTCM version 3. A new standard format for transmission of Global Navigation Satellite System correction information. Higher efficiency than RTCM v2.x. Supports real-time services with significantly reduced bandwidth. Message types for real-time GNSS operation:<ul style="list-style-type: none">• 1001: L1-only GPS real-time observables• 1002: Extended L1-only GPS real-time observables• 1003: L1 & L2 GPS real-time observables• 1004: Extended L1 & L2 GPS real-time observables

Field	Description of Field
	<ul style="list-style-type: none"> • 1005: Stationary real-time reference station Antenna Reference Point • 1006: Stationary real-time reference station ARP with antenna height • 1007: Antenna descriptor • 1008: Antenna descriptor and serial number • 1009: L1-only GLONASS real-time observables • 1010: Extended L1-only GLONASS real-time observables • 1011: L1 & L2 GLONASS real-time observables • 1012: Extended L1 & L2 GLONASS real-time observables <p>Network RTK Messages according to Master-Auxiliary Concept:</p> <ul style="list-style-type: none"> • 1014: Network Auxiliary Station Data message. This message contains details of the reference stations in the network, for example the master station and its coordinates, and the coordinate differences between the master and its auxiliaries. • 1015: Ionospheric Correction Differences message • 1016: Geometric Correction Differences message • 1029: Unicode Text String message <p>Pseudorange and phase range values for L1 and L2. Depending on the type of receiver, the data for L1-only or for L1 and L2 are sent out.</p> <p>Accuracy at the rover:</p> <ul style="list-style-type: none"> • For L1-only: 0.25 - 1 m rms.

Field	Description of Field
	<ul style="list-style-type: none"> • For L1 and L2: 1 - 5 cm rms after a successful ambiguity resolution. • RTCM 1,2 v2. Message according to RTCM version 2.x. Differential and delta differential GPS corrections. Message 3 is also generated. Use for DGPS applications. Accuracy at the rover: 0.25 - 1 m rms. • RTCM 9,2 v2. Message according to RTCM version 2.x. GPS partial correction set and delta differential GPS corrections. Message 3 is also generated. Use for DGPS applications with a slow data link in the presence of interference. Accuracy at the rover: 0.25 - 1 m rms. • RTCM 18,19 v2. Message according to RTCM version 2.x. Uncorrected carrier phase and pseudorange. Message 3 is also generated. Use for real-time operations where the ambiguities will be resolved at the rover. Accuracy at the rover: 1 - 5 cm rms after a successful ambiguity resolution. • RTCM 20,21 v2. Message according to RTCM version 2.x. Real-time carrier phase corrections and high-accuracy pseudorange corrections. Message 3 is also generated. Use for real-time operations. Accuracy at the rover: 1 - 5 cm rms after a successful ambiguity resolution. • RTCM 1,2,18,19 v2. Message according to RTCM version 2.x. Combination of RTCM 1,2 v2 and RTCM 18,19 v2. • RTCM 1,2,20,21 v2. Message according to RTCM version 2.x. Combination of RTCM 1,2 v2 and RTCM 20,21 v2.
Port	<ul style="list-style-type: none"> • Bluetooth x. The Bluetooth port which will be used for the interface functionality. Requires the purchase of the Bluetooth functionality option.

Field	Description of Field
	<ul style="list-style-type: none"> • Clip-on. The clip-on-contacts. It is used for CS09 with GHT56 when a device is attached to the GHT56. • NETx. Available for an activated Internet interface. If these ports are not assigned to a specific interface, then these ports are additional remote ports.
Device	<ul style="list-style-type: none"> • Clip-on. Default device for the physical LEMO port on the GHT56. It is displayed for CS09 with GHT56 when Port=Clip-on is selected.
Ref Sensor	<ul style="list-style-type: none"> • Choicelist. The receiver type used at the reference. If the real-time data format does not contain the information of the receiver type certain corrections based on the information of the receiver type are applied in order to provide correct results. The real-time data formats Leica, CMR and CMR+ contain this information. This is mainly important when a System300 receiver is used as reference.
Ref Antenna	<ul style="list-style-type: none"> • Choicelist. The antenna used at the reference. If the real-time data format does not contain the information of the antenna certain corrections based on the information of the antenna are applied in order to provide correct results. The real-time data formats Leica, RTCM v2.3, CMR and CMR+ contain this information. <p> If the reference data is corrected by absolute antenna calibration values and a Leica standard antenna is being used on the rover, select ADVNULLANTENNA as reference antenna.</p>

Step 2
Configuring Additional
Rover Options, General
Page



CONT (F1)

To accept the screen entries and continue.

GGA (F4)

To activate the sending of a GGA message for reference network applications.

PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
Accept Ref	<ul style="list-style-type: none"> The reference station of which real-time data is to be accepted. <ul style="list-style-type: none"> User Defined. Incoming real-time data is accepted from the reference station defined in Ref Stn ID. First Received. Incoming real-time data from the first recognised reference station is accepted. Any Received. Incoming real-time data from any reference station is accepted.
Ref Stn ID	<ul style="list-style-type: none"> User input. Available for Accept Ref=User Defined. The special ID of the reference station from which real-time data is to be received. The allowed minimum and maximum values vary. <ul style="list-style-type: none"> From 0 to 31. For R-Time Data=Leica and R-Time Data=CMR/CMR+. From 0 to 1023. For RTCM Version=1.x and RTCM Version=2.x.

Field	Description of Field
	<ul style="list-style-type: none"> From 0 to 4095. For R-Time Data=RTCM v3.1.
Ref Network	<ul style="list-style-type: none"> Defines the type of reference network to be used. Refer to Leica GNSS Spider documentation for more detailed descriptions. None. For R-Time Data=Leica and R-Time Data=CMR/CMR+. Nearest. For R-Time Data=Leica and R-Time Data=CMR/CMR+. If this option is selected, a NMEA GGA message can be activated using GGA (F4). i-MAX. individualised Master-AuXiliary corrections. The rover sends its position via NMEA GGA message to Leica GNSS Spider where the Master-Auxiliary corrections are calculated. The corrections are also individualised by Leica GNSS Spider, which means it determines the best suitable corrections for that rover. The corrections are sent in Leica, RTCM v2.3 or RTCM v3.1 with message types 1015/1016. If this option is selected, a NMEA GGA message can be activated using GGA (F4). MAX. Master-AuXiliary corrections. The rover typically does not send its position to Leica GNSS Spider. Leica GNSS Spider calculates and sends Master-Auxiliary corrections to the rover. The rover individualises the corrections for its position, which means it determines the best suitable corrections. The corrections are sent in RTCM v3.1 with message types 1015/1016. If this option is selected, a NMEA GGA message can be activated using GGA (F4).

Field	Description of Field
	<ul style="list-style-type: none"> • VRS. Virtual Reference Station. If this option is selected, a NMEA GGA message must be activated using GGA (F4). • FKP. Area correction parameters. Derived from German: FlächenKorrektur Parameter.
Send User ID	<ul style="list-style-type: none"> • Yes or No. Activates the sending of a Leica proprietary NMEA message defining the user.
User ID 1 and User ID 2	<ul style="list-style-type: none"> • User input. Available for Send User ID=Yes. The specific user ID's to be sent as part of the Leica proprietary NMEA message. By default the serial number of the instrument is displayed.
RTCM Version	<ul style="list-style-type: none"> • 1.x, 2.1, 2.2 or 2.3. Available for R-Time Data=RTCM XX v2 in CONFIGURE Real-Time Mode. The same version must be used at the reference and the rover.
Bits / Byte	<ul style="list-style-type: none"> • 6 or 8. Defines the number of bits/byte in the RTCM message being received.

Step 3 Configuring Additional Rover Options, NTRIP Page

17:16
CONFIGURE
Additional Rover Options
General | NTRIP | RTCM Options
Use NTRIP: Yes
User ID : 1234512535
(cont) : ----
Password: ***
Mountpnt: Mountpnt5
a ↑
CONT SRCE PAGE

CONT (F1)

To accept the screen entries and continue.

SRCE (F5)

To download the NTRIP source table if **Mountpnt** is unknown. To do this, the GPRS Internet interface must already be configured. Refer to "17.2.3 Using the NTRIP Service with a Real-Time Rover".


PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
Use NTRIP	<ul style="list-style-type: none"> Yes or No. Activates NTRIP.
User ID	<ul style="list-style-type: none"> User input. A user ID is required to receive data from the NTRIP Caster. Contact the NTRIP administrator for information.
(cont)	<ul style="list-style-type: none"> User input. Allows the User ID string to continue onto a new line.
Password	<ul style="list-style-type: none"> User input. A password is required to receive data from the NTRIP Caster. Contact the NTRIP administrator for information.
Mountpnt	<ul style="list-style-type: none"> User input. The NTRIP Source from where real-time data is required.

Step 4
Configuring Additional
Rover Options, RTCM
Options Page

This page is only available for R-Time Data=RTCM v3.1 in **CONFIGURE Real-Time Mode**.



Use Auto CrdSys : **Yes**

RTCM Info Msg : **Log**

CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to the next page on the screen.



Field	Description of Field
Use Auto CrdSys	<ul style="list-style-type: none"> Yes or No. To set a RTCM coordinate system received by a reference network as active coordinate system. <p> Is marked grey and set to No for Ref Network=None in CONFIGURE Additional Rover Options, General page.</p>
RTCM Info Msg	<p>Defines to show and/or log an info message (RTCM message 1029) given by the receiver which is received by a reference network.</p> <ul style="list-style-type: none"> No. The info message will not be shown by the receiver. Show. The info message will only be shown by the receiver. Log. The info message will only be logged to a text file.

Field	Description of Field
	<ul style="list-style-type: none"> • Show and Log. The info message will be shown by the receiver and logged to a text file.

Prediction

The following provides additional information on the prediction of real-time positions between the data rate of the reference. This can be activated for a real-time rover interface unless R-Time Data=RTCM 1,2 v2 or R-Time Data=RTCM 9,2 v2.

Access

SHIFT PRED (F3) in **CONFIGURE Real-Time Mode**.

Description

Prediction is the interpolation of real-time corrections between those regularly transmitted by a reference at a defined data rate.

Advantages in using prediction

Computation of real-time positions on the rover is independent from the transmission rate of the data from the reference station.
Positions computed with prediction have a reduced latency of around 20 ms.

Recommended settings for using prediction

The slower the data rate the more important it is to activate prediction.

Height smoothing

The following provides additional information on the height filter for height smoothing.

Access


SHIFT FILT (F4) in **CONFIGURE Real-Time Mode**.

Description

Height smoothing is a filter applied to all heights measured in the WGS 1984 or a local coordinate system or output via NMEA. The filter defaults are best suited for high dynamic variations in height up to 1 m/s as carried out by graders.


Height Smoothing with high dynamic GPS operations

All GPS computed positions are almost twice as accurate in plan than in height. For the position determination, satellites can appear in all four quadrants. For the height determination, satellites can appear in two quadrants. This weakens the height position compared to the plan position.




GS09_TR_010

Position determination with satellites appearing in all four quadrants.



Height determination with satellites appearing in two quadrants.

In high dynamic GPS operations, this fact results in height variations of a few centimetres as shown in the blue curve in the diagram below. Some GPS monitoring applications require a stabilised height. By applying the filter, the height variations are smoothed and most of the noise in the height component is eliminated.



16.3

Configuring of GGA Message Sending for Reference Network Applications


Description

Most reference networks require an approximate position of the rover. For reference network applications, a rover dials into the reference network and submits its approximate position in form of a NMEA GGA message.

By default, the receiver sends GGA messages with updated current positions automatically when a reference network is selected.

Surveying regulations in some countries require that one certain position can be selected. This position is then sent to the reference network as GGA message through the real-time interface every five seconds.

Configuring Send GGA NMEA



Easting : 2764398.557 m
Northing : 1253086.862 m
Local Ell Ht : 421.161 m



CONT (F1)

To accept the screen entries and continue.

COORD (F2)

Available for GGA Position=From Job and GGA Position=LAST/HERE Posn. To view other coordinate types. Local coordinates are available when a local coordinate system is active.

LAST (F3)

Available for GGA Position=LAST/HERE Posn. To use the same coordinates in the GGA message as when the receiver was last used in a reference network application. This is possible when position coordinates from a previous reference network application are still stored in the System RAM.

HERE (F4)

Available for GGA Position=LAST/HERE Posn. To use the coordinates of the current navigation position in the GGA message.

SHIFT ELL H (F2) and SHIFT ORTH (F2)

To change between the ellipsoidal and the orthometric height. Available for local coordinates.

Field	Description of Field
GGA Position	<ul style="list-style-type: none"> • Automatic. The current rover position is sent to the reference network. The position is updated and sent every five seconds. • From Job. A point from the active job can be selected in Point ID. The position of this point is sent to the reference network every five seconds. • LAST/HERE Posn. The position last used in a reference network application or the current navigation position can be selected using LAST (F3) or HERE (F4). The selected position is sent every five seconds. • None. No GGA message is sent to the reference network.

Field	Description of Field
Point ID	<ul style="list-style-type: none"><li data-bbox="647 132 1493 219">• Choicelist. Available for GGA Position=From Job. The coordinates of this point are sent out in the GGA message. Opening the choicelist opens MANAGE Data: Job Name.

16.4


Configuring of the Internet Interface

Description


The Internet interface allows accessing the Internet using a GS09 receiver plus normally a GPRS device. can be used together with the Real-Time interface to receive real-time data from a NTRIP Caster via Internet communication. Refer to "17.1 Overview" for information about NTRIP.

The settings on this screen define the port and parameters required for accessing the Internet.

Access



Configuring the Internet Interface



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Internet	<ul style="list-style-type: none"> • Yes or No. Activates the Internet interface.
Port	<ul style="list-style-type: none"> • Bluetooth x. The Bluetooth port. It is used when connecting to a mobile phone using the Bluetooth port. Requires the purchase of the Bluetooth functionality option. • Clip-on. The clip-on-contacts. It is used for CS09 with GHT56 when a device is attached to the GHT56.
IP Address	<ul style="list-style-type: none"> • Chocelist. In order to get access to the Internet, an IP address is required. This IP address identifies the receiver in the Internet. • Dynamic. The IP address to get access to the Internet is provided by the network provider dynamically. Each time a GS09 receiver wants to access the Internet via the device a new IP address is assigned to the receiver. When using GPRS to connect to the Internet then the network provider always dynamically assigns the IP address. • Static. The IP address to get access to the Internet is provided by the network provider permanently. Each time GS09 wants to access the Internet via the device the same IP address identifies the receiver. This is important if GS09 is used as a TCP/IP server. This option should only be selected if a static IP address is available for the receiver.
Set IP Adr	<ul style="list-style-type: none"> • User input. Available for IP Address=Static. To set the IP address.
User ID	<ul style="list-style-type: none"> • User input. Some providers ask for a user ID to allow connecting to the Internet via GPRS. Contact your provider if a user ID needs to be used.
(cont)	<ul style="list-style-type: none"> • User input. Allows the User ID string to continue onto a new line.
Password	<ul style="list-style-type: none"> • User input. Some providers ask for a password to allow connecting to the Internet via GPRS. Contact your provider if a password is required.

17

17.1

Configuring NTRIP via Internet

Overview

Description


Networked Transport of RTCM via Internet Protocol


- is a protocol streaming real-time corrections over the Internet.
- is a generic protocol based on the Hypertext Transfer Protocol HTTP/1.1.
- is used to send differential correction data or other kinds of streaming data to stationary or mobile users over the Internet, allowing simultaneous PC, laptop, PDA, or receiver connections to a broadcasting host.
- supports wireless Internet access through mobile IP networks like digital cellular phones or modems.

System components

NTRIP consists of three system components:

- NTRIP Clients
- NTRIP Servers
- NTRIP Caster





NTRIP Client

The NTRIP Client receives data streams. This could be, for example a real-time rover receiving real-time corrections.

In order to receive real-time corrections, the NTRIP Client must first send

- a user ID
- a password
- an identification name, the so-called MountPoint, from which real-time corrections are to be received to the NTRIP Caster.

NTRIP Server

The NTRIP Server transfers data streams.

In order to send real-time corrections, the NTRIP Server must first send

- a password
 - an identification name, the so-called MountPoint, where the real-time corrections come from
- to the NTRIP Caster.

Before sending real-time corrections to the NTRIP Caster for the first time, a registration form must be completed. This is available from the NTRIP Caster administration centre. Refer to the Internet.

NTRIP Source

The NTRIP Source generates data streams.


NTRIP Caster

The NTRIP Caster

- is an Internet server handling various data streams to and from the NTRIP Servers and NTRIP Clients.
- checks the requests from NTRIP Clients and NTRIP Servers to see if they are registered to receive or provide real-time corrections.

decides whether there is streaming data to be sent or to be received.

Graphic



NTRIP and it's role in the Internet

17.2

17.2.1

Requirements



Configuring access to internet

Configuring a Real-Time Rover for Using NTRIP Service

Configuring an Access to the Internet

- Firmware v7.60 or higher must be loaded on the CS09.

To access to the Internet with a GS09 receiver, **General Packed Radio System** devices will normally be used. GPRS is a telecommunication standard for transmitting data packages using the Internet Protocol (IP).

A GPRS device can be connected in a clip-on-housing.

Step	Description
1.	 CONT (F1).
2.	Highlight Internet and EDIT (F3) to access CONFIGURE Internet Interface.
3.	CONFIGURE Internet Interface Internet=Yes IP Address=Dynamic User ID. Some providers ask for a user ID to allow connecting to the Internet via GPRS. Contact your provider if a user ID needs to be used. Password. Some providers ask for a password to allow connecting to the Internet via GPRS. Contact your provider if a password needs to be used.
4.	CONT (F1) to return to CONFIGURE Interfaces.
5.	CTRL (F4) to access CONFIGURE GPRS/Internet Connection.
6.	CONFIGURE GPRS/Internet Connection

Step	Description
	<p>APN. Available for some devices. The Access Point Name of a server from the network provider, which allows access to data services. Contact your provider to get the correct APN. Mandatory for using GPRS.</p>
	<p>CODES (F3). Available for digital cellular phones of GSM technology. To enter the Personal Identification Number of the SIM card. If the PIN is locked for any reason, for example the wrong PIN was entered, input the Personal UnblockKing code for access to the PIN.</p>
7.	<p>CONT (F1) to return to GS09 Main Menu.</p> <p>APN. Available for some devices. The Access Point Name of a server from the network provider, which allows access to data services. Contact your provider to get the correct APN. Mandatory for using GPRS.</p>

17.2.2

Configuring to Connect to a Server

Requirements

The configurations from the previous chapter must have been completed. Refer to "17.2.1 Configuring an Access to the Internet".

Configuring connect to a server

Step	Description
1.	 CONT (F1).
2.	Highlight Real-Time and EDIT (F3) to access CONFIGURE Real-Time Mode.
3.	CONFIGURE Real-Time Mode R-Time Mode=Rover R-Time Data. Select the type of data to be received from the Internet. Port=NETx.
4.	CONT (F1) to return to CONFIGURE Interfaces.
5.	Highlight Real-Time.
6.	CTRL (F4) to access CONFIGURE Set NET Port.
7.	CONFIGURE Set NET Port User=Client Server. The server to be accessed in the Internet. Opening the choicelist accesses CONFIGURE Server to Connect where new servers can be created and existing servers can be selected or edited. IP Address. The stored IP address of the selected Server to be accessed in the Internet.

Step	Description
	<p>Host. The host name of the selected Server as configured in CONFIGURE Server to Connect.</p> <p>TCP/IP Port. The stored port of the selected Internet Server through which the data is provided. Each server has several ports for various services.</p> <p>Auto CONEC=Yes. Allows for automatic connection between the rover and the Internet when a point is occupied during a survey. Ending the point occupation also ends the Internet connection.</p>
8.	CONT (F1) to return to CONFIGURE Interfaces.
	Once the receiver is connected to the server a message is displayed in the message line.
9.	CONT (F1) to return to GS09 Main Menu.

17.2.3

Using the NTRIP Service with a Real-Time Rover

Requirements

The configurations from the previous chapter must have been completed. Refer to "17.2.2 Configuring to Connect to a Server".

Using NTRIP service

Step	Description
1.	 CONT (F1).
2.	Highlight Real-Time and EDIT (F3) to access CONFIGURE Real-Time Mode.
3.	CONFIGURE Real-Time Mode Port=NETx must be selected.
4.	ROVER (F2) to access CONFIGURE Additional Rover Options.
5.	PAGE (F6) to access CONFIGURE Additional Rover Options, NTRIP page.
6.	CONFIGURE Additional Rover Options, NTRIP page Use NTRIP=Yes User ID. A user ID is required to receive data from to the NTRIP Caster. Contact the NTRIP administrator for information. Password. A password is required to receive data from the NTRIP Caster. Contact the NTRIP administrator for information.
7.	SRCE (F5) to access CONFIGURE NTRIP Source-Table.
8.	CONFIGURE NTRIP Source-Table All MountPoints are listed. MountPoints are the NTRIP servers sending out real-time data. This screen consists of two columns:

Step	Description
	<ul style="list-style-type: none"> • First column MountPoint: The abbreviations for the MountPoints. • Second column Identifier: The city where the MountPoint is located. <p>Highlight a MountPoint about which more information is required. This information helps to configure the receiver to use the selected MountPoint as a reference.</p>
9.	INFO (F3) to access CONFIGURE MountPoint: XX .
10.	<p>CONFIGURE MountPoint: XX, General page</p> <p>Format. The real-time data format sent out by the MountPoint.</p> <p>FormatDet. Details about Format, for example the RTCM message types including update rates in seconds displayed in brackets.</p> <p>Authentic. The type of password protection required for the authorisation to the NTRIP Server. Authentic=None if no password is required. Authentic=Basic if the password need not be encrypted. Authentic=Digest if the password must be encrypted.</p> <p>NMEA. Indicates if the MountPoint must receive GGA NMEA data from the rover in order to compute VRS information.</p> <p>Charges. Indicates if charges are currently made for the connection.</p> <p>Carrier. The type of carrier message sent out.</p> <p>System. The type of satellite system supported by the MountPoint.</p>
11.	PAGE (F6) to access CONFIGURE MountPoint: XX, Location page.
12.	CONFIGURE MountPoint: XX, Location page

Step	Description
	Detailed information about the location of the MountPoint is displayed.
13.	PAGE (F6) to access CONFIGURE MountPoint: XX, Miscell page.
14.	CONFIGURE MountPoint: XX, Miscell page Generator. The hard- or software generating the data stream. Compress. The name of the compression / encryption algorithm. Info. Miscellaneous information if available.
	PREV (F2) to display information about the previous MountPoint in the list.
	NEXT (F3) to display information about the next MountPoint in the list.
15.	CONT (F1) to return to CONFIGURE NTRIP Source-Table .
16.	CONT (F1) to return to CONFIGURE Additional Rover Options .
	SHIFT CONEC (F3) and SHIFT DISCO (F3) are now available in all applications to connect to and disconnect from the NTRIP Server.

18

Configuring the Satellite Settings


Description

The settings on this screen define which satellites and satellite signals will be used by CS09.

Access



Configuring



CONT (F1)

To accept the screen entries and continue.

SHIFT INIT (F4)

Force the receiver to delete the current GPS and GLONASS almanac stored and to download new almanacs.



Field	Description of Field
GLONASS	<p>Defines if GLONASS satellite signals are accepted by the receiver when tracking satellites.</p> <p>No. Only GPS satellites are tracked.</p> <p>Yes. GPS and GLONASS satellites are tracked.</p>

Field	Description of Field
GPS L2C	Automatic or Always Track . Defines if the L2C signal will be tracked. The recommended setting is Automatic .
Cut Off Angle	Sets the elevation in degrees below which satellite signals are not used and are not shown to be tracked. Recommended setting for real-time: 10°.


19

Configuring the Screen Display


Description

The settings on this screen allow the screen appearance to be configured, turn the notification beeps on and off and define the behaviour of the keys. The settings are stored on the CS09 itself. If CS09's are exchanged, the settings stored on the new CS09 apply.

Access



Configuring the display



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)


To change to the next page on the screen.



Field	Description of Field
Screen Illum	<ul style="list-style-type: none"> Controls the screen illumination to be on, off or on for the specified time after the last key was pressed, or touch screen event. Off.

Field	Description of Field
	<ul style="list-style-type: none"> • Always On. • On for 1 min, 2 min, 5 min.
Key Illum	<ul style="list-style-type: none"> • Controls the keyboard illumination. • Off. • Same as Screen. • Always On.
Contrast	<ul style="list-style-type: none"> • From 0% to 100%. Adjust the contrast level for the display with the right and left arrow key when the field is highlighted or using the supplied stylus on the slider.
Heating	<ul style="list-style-type: none"> • Automatic. The screen heating comes on automatically at 5°C and shuts off again at 7°C. • Off. The screen heating never comes on.

Configuring the beeps



CONT (F1)

To accept the screen entries and continue.


PAGE (F6)

To change to the next page on the screen.



Field	Description of Field
Warning Beeps	<ul style="list-style-type: none">• Off, Soft, Loud. Controls the beeps for acoustic warning signals.
Key Beeps	<ul style="list-style-type: none">• Off, Soft, Loud. Controls the beeps upon key presses on CS09.

Configuring the text



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to the next page on the screen.



Field	Description of Field
Deflt aNum	Sets the set of extra characters available through ?NUM or F1-F6 whenever an entry is made. The choices available depend on the character sets loaded on the instrument and the language configured to be used on the instrument.

Description


The settings on this screen define:

- the units for all types of measurement data displayed.
- information related to some types of measurement data.
- the order in which coordinates are displayed.

Access



Configuring the units



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)


To change to the next page on the screen.

Field	Description of Field
Distance Unit	<ul style="list-style-type: none"> • The units shown for all distance and coordinate related fields. • Metre (m). Metres [m]

Field	Description of Field
	<ul style="list-style-type: none"> • Int Ft (fi). International feet [fi], storage in US feet • Int Ft/Inch (fi). International feet [fi], inches and 1/8 inches (0' 00 0/8 fi), storage in US feet • US Ft (ft). US feet [ft] • US Ft/Inch (ft). US feet, inches and 1/8 inches (0' 00 0/8 fi) [ft] • Kilometres (km). Kilometres [km] • US Miles (mi). US miles [mi]
Distance Dec	<ul style="list-style-type: none"> • From 0 Decimals to 4 Decimals. The number of decimal places shown for all distance and coordinate related fields. This is for data display and does not apply to data export or storage. The available options depend on the selected Distance Unit.
Angle Unit	<ul style="list-style-type: none"> • 400 gon, 360 ° ' ", 360° dec or 6400 mil. The units shown for all angular and coordinate related fields. More angle settings can be defined on the Angle page.
Angle Dec	<ul style="list-style-type: none"> • The number of decimal places shown for all angular and coordinate related fields. This is for data display and does not apply to data export or storage. • From 1 Decimal to 3 Decimals. Available for Angle Unit: 6400 mil. • From 2 Decimals to 4 Decimals. Available for Angle Unit: 400 gon and Angle Unit: 360° dec. • 1", 5", 10", 60". Available for Angle Unit: 360 ° ' "".
Grade Unit	<ul style="list-style-type: none"> • The input and output format for grades. • h:v. Horizontal by vertical distance.

Field	Description of Field
	<ul style="list-style-type: none"> • v:h. Vertical by horizontal distance. • % (v/h * 100). Percentage of vertical by horizontal distance. • Elev Angle. Elevation angle.
Velocity Unit	<ul style="list-style-type: none"> • Km/h (kmh), Mph (mph) or Knots (kn). The units shown for all velocity related fields.
Area Unit	<ul style="list-style-type: none"> • m², Int Acres (Ai), US Acres (A), Hectares (ha), fi² or ft². The units shown for all area related fields.
Volume Unit	<ul style="list-style-type: none"> • m³, fi³, ft³ or yd³. The units shown for all volume related fields.
Temp Unit	<ul style="list-style-type: none"> • Celsius (°C) or Fahrenheit (°F). The units shown for all temperature related fields.
Press Unit	<ul style="list-style-type: none"> • mbar, mmHg, Inch Hg (inHg), hPa or psi. The units shown for all pressure related fields. PSI = pounds per square inch.

Configuring the angle



CONT (F1)

To accept the screen entries and continue.




PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
Direc Ref	<ul style="list-style-type: none"> North Azimuth, South Azimuth, North Anticlock or Bearing. Sets the reference direction as well as the direction from where and how azimuths are computed. For Direc Ref: Bearing, the azimuth/bearing fields in other screens are called Bearing. NE, SW, SE and NW indicate the quadrant of the bearing.

Field	Description of Field
	<div data-bbox="858 140 1216 501" data-label="Diagram"> </div> <p data-bbox="863 508 927 519">GS09_TR.017</p> <ul data-bbox="694 549 1497 602" style="list-style-type: none"> • For all other options, the azimuth/bearing fields in other screens are called Azimuth.
Dirac Base	<ul data-bbox="694 622 1257 647" style="list-style-type: none"> • True or Magnetic. Sets the North direction.
Mag Declin	<ul data-bbox="694 661 1497 745" style="list-style-type: none"> • Available for Dirac Base=Magnetic. The value for the magnetic declination. It is considered when computing or using any azimuth values.

Configuring the time



CONT (F1)

To accept the screen entries and continue.




PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
Time Format	<ul style="list-style-type: none"> 24 hour or 12 hour (am/pm). How the time is shown in all time related fields.
Date Format	<ul style="list-style-type: none"> Day.Month.Year, Month/Day/Year or Year/Month/Day. How the date is shown in all date related fields.

Configuring the format



CONT (F1)

To accept the screen entries and continue.



PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
Grid Format	<ul style="list-style-type: none"> East,North or North,East. The order in which grid coordinates are shown in all screens. The order in display masks depends on the user settings.
Geodetic Format	<ul style="list-style-type: none"> Lat,Long or Long,Lat. The order in which geodetic coordinates are shown in all screens. The order in display masks depends on the user settings.

21

Using the Tools - Activating Licence Keys

Description

A licence key can be used to activate protected programs and protected receiver options and can be used to define the expiry date of the software maintenance.

Access



Protected programs

A licence key is required for the following protected programs:

Protected programs
<ul style="list-style-type: none">• DTM Stakeout• Reference Line• RoadRunner• Volume Calculations

Protected option

A licence key is required for the following protected receiver option:

Protected receiver options
<ul style="list-style-type: none">• 5 Hz update rate• 5 km RTK range• Unlimited RTK range• Extended OWI messages• GLONASS tracking• RTK network access• Bluetooth functionality

Protected receiver options

- Raw data logging
- RTCM/CMR data input

Entering/Loading a licence key

- A licence key file can be uploaded to CS09. To upload a licence key file the file should be located on the \SYSTEM directory of the CF card. Licence key files use the naming convention L_123456.key, where 123456 is the instrument serial number.
- Licence keys can also be typed in manually.



Method : Manual Entry of Key
Key : ABCDEF123456

CONT (F1)

To accept the screen entries and continue.

SHIFT DEL (F4)

To delete all licence keys on CS09.



Field	Description of Field
Method	<ul style="list-style-type: none">• The method used to input the licence key to activate the program or the protected options or the software maintenance.

Field	Description of Field
	<ul style="list-style-type: none"> • Upload Key File. The licence key file is uploaded from the CF card. The licence key file must be stored in the \SYSTEM directory on the CF card. • Manual Entry of Key. Allows the licence key to be typed in manually.
Key	<ul style="list-style-type: none"> • Available for Method=Manual Entry of Key. The licence key required to activate a program. Entry is not case sensitive.

The next step

IF a licence key is to be	THEN
uploaded	select the method to input the licence key and press CONT (F1) .
deleted	press SHIFT DEL (F4) .

22

Using the Tools - Calculating with Calculator

22.1

Overview of Calculator

Description

The calculator can be used to perform the following arithmetic operations:

- addition, subtraction, multiplication and division,
- statistics,
- trigonometry, hyperbolic trigonometry and calculations with Pi,
- polar, rectangular and angle conversions,
- powers, logs, roots and exponential functions.

Access



Operating modes


- The calculator has two operating modes - RPN mode and Standard mode.
- The arithmetic operations available are identical, the difference lies in the way information is entered, stored and displayed on the screen.

Type	Description
RPN	<ul style="list-style-type: none">• Reverse Polish Notation• This operating mode was developed as a way of writing mathematical expressions without using parenthesis and brackets. Many scientific calculators, for example Hewlett Packard calculators, are implemented with this operating mode. Values are entered and kept in a working stack.
Standard	<ul style="list-style-type: none">• This operating mode is based on the principles of conventional pocket calculators. There is no stacking of values.

22.2

Using the Calculator in RPN Mode

Calculator in RPN mode



The function keys **F1-F6** are allocated seven times. Using \blacktriangle or \blacktriangledown the various allocations can be accessed.

Field	Description of Field
First field on the screen	<ul style="list-style-type: none"> The unit used for trigonometric functions in the calculator as configured in TOOLS Calculator Configuration. DEG. Degrees RAD. Radians GRAD. Gon
ΣY	<ul style="list-style-type: none"> The result of the sum or difference of values in Y using ?+ (F1) and ?- (F2).
ΣX	<ul style="list-style-type: none"> The result of the sum or difference of values in X using ?+ (F1) and ?- (F2).
T	<ul style="list-style-type: none"> Third stack. After an operation, the value from Z is written here.

Field	Description of Field
Z	<ul style="list-style-type: none">• Second stack. After an operation, the value from Y is written here.
Y	<ul style="list-style-type: none">• First stack. After an operation, the value from X is written here.
X	<ul style="list-style-type: none">• The value for the next operation.


The next step

Press **SHIFT DONE (F4)** to return to the Main Menu screen.

22.3

Using the Calculator in Standard Mode

Calculator in Standard mode



The function keys **F1-F6** are allocated seven times. Using \blacktriangle or \blacktriangledown the various allocations can be accessed.

Field	Description of Field
First field on the screen	<ul style="list-style-type: none"> The unit used for trigonometric functions in the calculator as configured in TOOLS Calculator Configuration. DEG. Degrees RAD. Radians GRAD. Gon
Σ	<ul style="list-style-type: none"> The result of the sum or difference of values in the last field on the screen using ?+ (F1) and ?- (F2).
Third to sixth field on the screen	<ul style="list-style-type: none"> Previously entered value or latest operation including result. # indicates that the value is cut after the third decimal.

Field	Description of Field
Last field on the screen	<ul style="list-style-type: none"><li data-bbox="695 132 1445 157">• The value for next operation or result from latest operation.

The next step

Press **SHIFT DONE (F4)** to return to the Main Menu screen.

22.4

Description of Softkeys

Description of softkeys

Softkey	Description of Softkey
Level 1 (press  to access the next level).	
	(F1): To add X and Y .
	(F2): To subtract X from Y .
	(F3): To multiply X by Y .
	(F4): To divide Y by X .
	(F5): To change between positive and negative algebraic sign for X .
	(F6): To clear X .
Level 2 (press  to access the next level).	
	(F1): To add X to ΣX and Y to ΣY .
	(F2): To subtract X from ΣX and Y from ΣY .
	(F3): To calculate the mean ΣX .
	(F4): To calculate the standard deviation for ΣX .
	(F5): This softkey is blank.
	(F6): To clear ΣX and ΣZ .
Level 3 (press  to access the next level).	
	(F1): To calculate sine of X .

Softkey	Description of Softkey
COS	(F2) : To calculate cosine of X .
TAN	(F3) : To calculate tangent of X .
ASIN	(F4) : To calculate arcsine of X .
ACOS	(F5) : To calculate arccosine of X .
ATAN	(F6) : To calculate arctangent of X .
Level 4 (press  to access the next level).	
°DMS	(F1) : To convert decimal degrees into dd.mm.ss.
°DEC	(F2) : To convert dd.mm.ss into decimal degrees.
PI	(F3) : To insert X: 3.1415926536 . The number of decimals depends on the selection for Display Dec in TOOLS Calculator Configuration .
	(F4) : This softkey is blank.
D->R	(F5) : To convert degrees into radians.
R->D	(F6) : To convert radians into degrees.
Level 5 (press  to access the next level).	
POLAR	(F1) : Conversion of rectangular coordinates into polar coordinates. The y coordinate must be visible in Y and the x coordinate in X when pressing this key. The angle is displayed in Y and the distance in X .
RECT	(F2) : Conversion of polar coordinates into rectangular coordinates. The angle must be visible in Y and the distance in X when pressing this key. The y coordinate is displayed in Y , the x coordinate in X .

Softkey	Description of Softkey
SQRT	(F3) : To calculate \sqrt{X} .
X^2	(F4) : To calculate $(X)^2$.
1/X	(F5) : To calculate inverse X .
Y^X	(F6) : To calculate $(Y)^X$.
Level 6 (press  to access the next level).	
LOG	(F1) : To calculate the $\log_{10}(X)$.
10^X	(F2) : To calculate $10^{(X)}$.
LN	(F3) : To calculate the $\log_e(X)$.
e^X	(F4) : To calculate $e^{(X)}$.
	(F5) : This softkey is blank.
Y^X	(F6) : To calculate $(Y)^{(X)}$.
Level 7 (press  to access the first level).	
STO	(F1) : To store X to the memory. Up to ten values can be stored.
RCL	(F2) : To recall a value for X from the memory. Up to ten values can be recalled.
X<>Y	(F3) : To swap the values for X and Y .
LASTX	(F4) : To recall the last X before recent calculation.
	(F5) : This softkey is blank.

Softkey	Description of Softkey
CLEAR	(F6) : To delete everything.

Press **SHIFT** at any level, to access the second level of function keys.

Softkey	Description of Softkey
CONF	(F2) : To configure the calculator.
DONE	(F4) : To return to the Main Menu screen.


22.5

Configuring the Calculator

Access step-by-step

Step	Description
1.	Select Main Menu :   .
2.	SHIFT CONF (F2) to access TOOLS Calculator Configuration.

Configuring



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Operatng Mode	<ul style="list-style-type: none"> RPN. The principle of, for example, Hewlett Packard calculators. Standard. The principle of conventional pocket calculators.
Angle Unit	<ul style="list-style-type: none"> The unit used for trigonometric functions in the calculator. The selection here is independent from the angle setting in CONFIGURE Units & Formats.

Field	Description of Field
	<ul style="list-style-type: none"><li data-bbox="695 128 895 156">• DEG. Degrees<li data-bbox="695 168 895 196">• RAD. Radians<li data-bbox="695 207 868 235">• GRAD. Gon
Display Dec	<ul style="list-style-type: none"><li data-bbox="695 255 1493 308">• From 0 Decimals to 10 Decimals. The number of decimal places shown in TOOLS Calculator.

23

Using the Tools - Formatting Objects

Description

Allows the CF card, the System RAM and the application programs memory to be formatted. All data will be erased.

Access



Formatting



Memory Device: CF Card

CONT (F1)

To format a memory device.

PROGS (F4)

To format the programs memory.

SYSTEM (F5)

To format System RAM memory. If the System RAM is formatted all system data such as almanac, user-defined antennas, codelists, geoid field files and CSCS field files will be lost.



Field	Description of Field
Memory Device	The type of memory to be formatted. Data will be fully deleted.

Description


This chapter describes the basic procedure for transferring objects between the Compact-Flash card and the System RAM. Refer to "Appendix C Directory Structure of the Memory Device" for information about file types and locations of files on the CF card.

Access**Transfer Objects Menu**

CONT (F1)

To select an object for transfer.

Transferring



CONT (F1)

To accept the screen entries and continue.

ALL (F3)

Available for some transfer object options.
To transfer all objects.



Field	Description of Field
From	<ul style="list-style-type: none"> Memory device to transfer object from. CF Card. Transfer from CompactFlash card. System RAM. Transfer from System RAM.
To	<ul style="list-style-type: none"> Memory device to transfer object to.
Codelist	<ul style="list-style-type: none"> To select the codelist to be transferred.
Coord Sys	<ul style="list-style-type: none"> To select the coordinate system to be transferred.

Field	Description of Field
File	<ul style="list-style-type: none"> • To select the geoid field file, the CSCS field file, the entire contents of the System RAM or the PZ90 transformation to be transferred, depending on the transfer option chosen. <p> Each new GS09 firmware will include the latest PZ-90 transformation, so that is normally not necessary to transfer a PZ-90 transformation to or from a sensor.</p> <p>PZ90 is the GLONASS reference frame. For a combined processing (GPS & GLONASS) a 7-parameter Helmert transformation is necessary to transform PZ90 into WGS84. The values for this transformation are hard-coded, but can be changed by importing the file "PZ90trafo.dat" that is provided by LGO.</p>
Format File	<ul style="list-style-type: none"> • To select the format files to be transferred.
Antenna	<ul style="list-style-type: none"> • To select the antenna records to be transferred.



This tool requires the purchase of the RTK network access option. Refer to "21 Using the Tools - Activating Licence Keys".


Description

This is to transfer jobs, codelists and other GS09 related files on the CompactFlash Card with a standard and simple FTP server.

FTP protocol is used to transfer between GS09, which runs GS09 software and has an internet device connected, and the ftp server. The zip/unzip functionality is included.

Licence keys can also be typed in manually in Main Menu: Tools...\Licence Keys or the first time the application program is started.

Access



Supported files

The following list shows the supported file extensions that will automatically move to the corresponding directory after downloading.

Supported file	File extension	Directory
Almanac file	Almanac.sys	DATA/GPS
Antenna file from GS09	List.ant	GPS
Application program files	*.a*	SYSTEM
ASCII files for import/export to/from job	*.txt	DATA
Coordinate system file from GS09	Trfset.dat	DBX
CSCS field files	*.csc	DATA/GPS/CSCS
DXF files for import/export to/from job	*.dxf	DATA
Firmware files	*.fw	SYSTEM

Supported file	File extension	Directory
Format files	*.frt	CONVERT
Geoid field files	*.gem	DATA/GPS/GEOID
GSI files	*.gsi	GSI
GSM/Modem station list from GS09	*.fil	GPS
Language files	*.s*	SYSTEM
Licence file	*.key	SYSTEM
Logfiles created from application programs	*.log	DATA
TPS configuration files	*.xfg	CONFIG
System files	System.ram	SYSTEM
Custom ASCII file (LEICA Geo Office Export)	*.cst	DATA
Comma separated variables, text file format (ASCII)	*.csv	DATA



Internet interface should be configured and connected prior to using this function.

TOOLS

Field to Office -> Config

Field	Description of Field
Host	<ul style="list-style-type: none"> User input. In order to get access to the Internet, a host name is required. This host name identifies the receiver in the Internet.
TCP/IP Port	<ul style="list-style-type: none"> User input. Port to be used. Any number between 0 and 65535 is valid.
User ID	<ul style="list-style-type: none"> User input. The User ID allows connection to the ftp site. If no value is typed in, then the instrument logs into the FTP server anonymously.

Field	Description of Field
Password	<ul style="list-style-type: none"> User input. The password to get access to the ftp site.


The next step

IF the task is	THEN
to connect to the FTP server entered	CONEC (F1) . Once the connection to the FTP server is established, TOOLS Field to Office: Transfer, Field page is displayed. Refer to "TOOLS Field to Office: Transfer, Field page".
to exit the screen	SHIFT QUIT (F6) .

TOOLS Field to Office: Transfer, Field page

The files and folders on the CompactFlash Card of the instrument are displayed including their size.

To get into the folders, highlight the folder and **ENTER**.



UPLD (F1)

To copy the file or folder to its corresponding directory on the ftp server. Files or folders bigger than 100 KB are zipped before sending.

UNZIP (F2)

To unzip a file in the download directory. Available if a zip file is highlighted.

TOOLS
Field to Office:
Transfer,
Office page

The next step

PAGE (F6) changes to the **FTP** page.

The files located on the FTP server are displayed.

Whenever switching to this page, a refresh action is done or it reconnects to the server if the connection to the server was disconnected.

The most important keys are explained.

IMPRT (F3)

To move a file from the \Download folder to the appropriate directory folder based on its file extension type.

Available in the \Download folder when a file is highlighted. Unavailable for unrecognised files in the \Download folder. These must stay in the \Download folder.

SHIFT QUIT (F6)

To return to **GS09 Main Menu** and disconnect automatically from the FTP server.



DWNLD (F1)

To download the highlighted file or folder list on the FTP server to the local download folder.

Downloaded files are moved automatically to the corresponding directories if recognised by the system. If not, they are stored in the download folder. Zipped files are unzipped before storing in the download folder.

SHIFT RFRSH (F5)

To refresh the FTP directory.

The next step

SHIFT QUIT (F6) returns to the **GS09** Main Menu.

26

Using the Tools - Uploading Software

Description

Application programs, system languages and firmware can be uploaded. These files to be uploaded are stored in the \SYSTEM directory of the memory device.

Type	Upload		File extension
	From	To	
Programs	CF card	Programs memory	filename.a*
Instrument firmware		<ul style="list-style-type: none">• GS09• CS09	filename.fw
System languages		CS09	Individual to each language

Access




Uploading options



CONT (F1)

To select files for upload.

Uploading



CONT (F1)

To accept the screen entries and continue.


Field	Description of Field
From	Upload from CF card.
To	Upload to application programs memory, CS09 or GS09.
Firmware	List of firmware files stored on the CF card.  GS09 must always be connected to CS09 when uploading GS09 firmware. Connect GS09 and CS09 via cable. Uploading the GS09 firmware takes some time.
Language	List of language files stored on the CF card.  It is not possible to have more than three language files stored on the instrument. English is always available as the default language and cannot be deleted.
Program	List of program files stored on the CF card.
Version	Version of the program file, firmware file or language file.

Description

Allows ASCII files on the CF card to be viewed. The ASCII file can have a size of up to 500 KB. Refer to "Appendix C Directory Structure of the Memory Device" for more information on the contents of folders on the memory device.

**Access**

The \DBX directory cannot be accessed to view files.

**Viewing the directory****CONT (F1)**

To access a directory or to view a file.

DIR (F2)

Available for a directory or .. being highlighted. To access the highlighted directory or to move up one directory.

VIEW (F3)

Available for a file being highlighted. To view the highlighted file. Accesses TOOLS View File: File Name.

DEL (F4)

Available for a file being highlighted. To delete the highlighted file.

MORE (F5)


To display information about the size of a directory or file.

Column	Description OF Column
File Name	<ul style="list-style-type: none">• Directories and files are displayed if available. The file extension is shown for files.• \ at the beginning of a line indicates a directory.• .. is displayed at the top of the list if a directory has been accessed.
Data Time	<ul style="list-style-type: none">• Date and Time of the directory or file.
Size	<ul style="list-style-type: none">• Size.

The next step

WHEN	THEN
quitting the screen	press ESC to return to the Main Menu screen.
accessing a directory	highlight the directory and press DIR (F2) .
viewing a file	highlight the file and press VIEW (F3) .

Viewing the file



09:32
TOOLS

View File: local.txt

309	549282.26	5248890.18	413.07
315	548314.88	5247659.36	419.72
402	550691.54	5247142.54	418.67



CONT (F1)

To continue.

Keys	Function of Keys
▲	Moves up.
▼	Moves down.
▶	Moves right.
◀	Moves left.

28

28.1

Understanding MapView

Overview of MapView

Description

- MapView is an interactive display feature embedded in the firmware but used by all application programs as well as MANAGE Data. MapView provides a graphical display of the survey elements which allows for a better overall understanding of how the data being used and measured relates to each other.
 - Depending on the application program and where in the application program MapView is accessed from, different modes, and their associated functionality, are available.
 - The displayed data in all modes of MapView can be shifted by using both the arrow keys and the touchscreen.
-

MapView modes

MapView is available in three modes:

Map mode:

- Available as the Map page in data management and some application programs.
- Is also available within some application programs, for example, the Reference Line application program.
- Can be used to view, select and edit points, lines and areas.

Plot mode:

- Available as the Plot page in some application programs.
- Is available to view results in various application programs. For example, COGO application program.

Survey mode:

- Available as the Map page in Survey, Stakeout and some other application programs.
 - Same as Map mode but also shows the positions of the reference stations and the rover.
 - Provides special functionality when staking out points.
 - Can be used to select lines and areas.
-

Displayable data

The data displayed in MapView is defined by the application program through which it was accessed and the selections made in a MapView Configuration screen.

Accessing MapView

The MapView interactive display feature is accessed through the application program itself. Depending on the application program and from where in the application program MapView is accessed, different MapView modes are available.


28.2

Configuring MapView


Description

- Allows options to be set which are used as default options within MapView. These settings are stored within the configuration set and apply to all Map and Plot pages.
- Any changes made in a MapView Configuration screen affect the appearance of MapView in all application programs, not just the active application program.

Accessing step-by-step

Step	Description
1.	
2.	Highlight a job from the list of jobs and press DATA (F5) .
3.	Move to the Map page and press SHIFT CONF (F2) .

Configuring the Points page



Display with Point Symbol

Point ID : Yes

CONT (F1)

To accept the screen entries and continue.

SYMBL (F3)

To view all point symbols and their descriptions.


PAGE (F6)

To change to the next page on the screen.



Field	Description of Field
Show Points	<ul style="list-style-type: none"> • Yes or No. Determines if points are displayed in MapView.
Point ID	<ul style="list-style-type: none"> • Yes or No. Available for Show Points=Yes. Determines if the ID of a point is displayed.

Configuring the Lines&Areas page



Show Areas : Yes

CONT (F1)

To accept the screen entries and continue.


PAGE (F6)

To change to another page on the screen.



Field	Description of Field
Show Lines	<ul style="list-style-type: none"> • Yes or No. Determines if lines are displayed in MapView.
Show Areas	<ul style="list-style-type: none"> • Yes or No. Determines if areas are displayed in MapView.

Configuring the Display page



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to the next page on the screen.

Field	Description of Field
Show Pt Info	<ul style="list-style-type: none"> When < 200 Pts. Point information is not shown when more than 200 points are displayed. As Configured. Point information is shown regardless of the number of points being displayed.
Datum View	<ul style="list-style-type: none"> WGS 1984 or Local. Determines the datum in which the points are viewed.
Rotate 180°	<ul style="list-style-type: none"> Yes or No. Available for Datum View=Local. To rotate the map by 180°. The north arrow is not rotated and still orientated towards the top of the screen.
Toolbar	<ul style="list-style-type: none"> On or Off. Determines if the toolbar of touch icons are displayed.

Field	Description of Field
Curr Pos Info	<ul style="list-style-type: none"> • Determines if certain information related to the current position are displayed on the lower left corner of the survey mode of MapView (only visible in survey mode). <ul style="list-style-type: none"> • None. No information is displayed in the map. • Point ID. Point ID of the current position. • Code. Code of the current position. • Attrib 01. User-defined attribute. • Attrib 02. User-defined attribute. • Attrib 03. User-defined attribute. • Attrib 04. User-defined attribute. • Attrib 05. User-defined attribute. • Quality 3D. Current 3D coordinate quality of the computed position.
Show Path	<ul style="list-style-type: none"> • Yes or No. Displays the path of the rover as a dashed line.

28.3

MapView Components - The Softkeys

The softkeys

Softkey	Description of Softkey
DONE (F2)	To deactivate the focus tool. Available in Map mode.
EDIT (F3)	To edit the highlighted point's parameters. Available in Map mode in MANAGE Data: Job Name, Map page.
FOCUS (F2)	To activate the focus tool and select a point without using the touch screen. Available in Map mode.
PAGE (F6)	To change to another page on this screen.
ZOOM+ (F4)	To zoom into the map.  Pressing ESC stops the zooming process. All keys become active again.
ZOOM- (F5)	To zoom out of the map.  Pressing ESC stops the zooming process. All keys become active again.
SHIFT CENTR (F4)	To centre the screen around the point with the current focus, or the focus tool if DONE (F2) is visible.
SHIFT CONF (F2)	To configure MapView. Accesses MapView Configuration.
SHIFT FILTR (F5)	To change the filter settings for Stakeout. Available in Map mode for FOCUS (F2) .
SHIFT FIT (F3)	To fit all displayable data into the screen area.
SHIFT FIT R (F4)	To fit the results in the screen area. Available in Plot mode.
SHIFT RFRSH (F5)	To refresh the screen. Available in Plot and Survey mode.

28.4

MapView Components - The Screen Area

The Scale bar

Symbol	Description of Symbol
	Scale of the current screen. The minimum is 0.5 m. There is no maximum for the zoom but the scale cannot display values greater than 99000 m. In this case the value displayed will be >99000 m.

The North arrow

Symbol	Description of Symbol
	North arrow. North is always orientated towards the top of the screen.

The Toolbar

Symbol	Description of Symbol
	Touch icon toolbar.

The Point with focus

Symbol	Description of Symbol
	The point that has the focus.

The Rover

Symbol	Description of Symbol
	Available in survey mode. Position of the rover.  The rover path is shown as dashed line.

28.5

MapView Components - The Toolbar

Description

Touch icons are available in a toolbar, if Toolbar: On in MapView Configuration, Display page. The toolbar is always located on the left-hand side of the screen. Some of the functions performed by the touch icons can also be replicated using a softkey in the same mode as when the touch icon appears. The softkey equivalent to each touch icon, if one exists, are indicated below.

Touch icons

Touch icon	Softkey	Description
	SHIFT FIT (F3)	Available as a touch icon in map mode. The fit touch icon fits all displayable data into the screen area, using the largest possible scale.
	-	The windowing touch icon zooms to a specified area window. An area window can be drawn by tapping on the top left and the bottom right corner of the area. This causes the screen to zoom to the selected area.

28.6

MapView Components - The Point Symbols

Points

When Show Points: Yes in MapView Configuration, points are displayed, in all modes, according to their class.

Symbol	Description
	3D control point is a point of class CTRL with full coordinate triplet.
	2D control point is a position only point of class CTRL.
	Adjusted point is a point of class ADJ.
	Reference point is a point of class REF.
	Average point is a point of class AVGE.
	Measured point is a point of class MEAS.
	Single Point Position uploaded from LGO.
	Navigated point is a point of class NAV.
	Estimated point is a point of class EST.
	Calculated COGO point is a point of class MEAS or CTRL depending on the COGO calculation method.



Points of class NONE or points of class CTRL/MEAS with a height only component cannot be displayed in MapView.



A list of the point types available, and their description, is available by pressing **SYMBL (F3)** in MapView Configuration, Points page.

29

29.1

Understanding HOT Keys, USER key, STATUS Key

The HOT Keys

Description


- Hot keys provide a shortcut for quickly and directly carrying out functions or starting programs. Assigning functions and programs to hot keys is user configurable.

Access

- The hot keys are accessed by pressing F7, F8, ..., F12 directly.
- Hot keys can be pressed at any time. It is possible that a function or application program assigned to a hot key cannot be executed in certain situations.

Defining a hot key step-by-step

- This example shows how to assign the STATUS Satellites screen to the F7 key.

Step	Description
1.	
2.	Using the choicelist assign STAT Satellite Status to the F7 key. 
3.	Press CONT (F1) to return to the Main Menu screen.
4.	Press F7 to access the STATUS Satellites screen.

29.2

The USER Key

Description


- The **USER** key opens the User Menu screen which can be configured to contain the most used functions or programs.

Access

- The **USER** key opens the User Menu screen. Selecting an option in the User Menu screen carries out the assigned function or starts the assigned program.
- The User Menu screen cannot be accessed while in a CONFIGURE screen.

Defining the USER key step-by-step

- This example shows how to assign the STATUS Satellites screen to the 1 key.

Step	Description
1.	 A screenshot of the Main Menu screen. The top bar shows the time 10:21, signal strength, and battery level. Below the bar, there are several icons: a gear, a blue 'G' icon, and a red 'USER' key icon. The text 'Main Menu' is displayed at the bottom.
2.	Using the choicelist assign STAT Satellite Status to the first line of the user menu.  A screenshot of the 'Hot Keys & User Menu' configuration screen. The title bar is blue with a close button. Below the title bar, there are two tabs: 'Hot Keys' and 'User Menu'. The 'User Menu' tab is selected. The screen shows a list of three items: '1: STAT Satellite Status', '2: MGMT Data', and '3: PROG Survey'. Each item has a left arrow and a right arrow next to it.
3.	Press CONT (F1) to return to the Main Menu screen.
4.	Press USER to access the user menu.
5.	Press 1 to access the STATUS Satellites screen.

29.3

29.3.1

The STATUS Key

The Status Menu


Description

The STATUS functions help using the receiver by showing the state of many receiver functions. All fields are output fields. Unavailable information is indicated by -----.

Access step-by-step

Step	Description
1.	Press USER .
2.	Press STAT (F3) from the User Menu screen.

The Status Menu



To select a status option and continue.

29.3.2

Status Satellite Information

Description

This screen shows information related to the satellites with the highest elevation angle.

The Rover, GPS page

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
ROV/REF (F3)	To change between the signal to noise ratio values of rover and reference. Available when R-Time Mode: Rover is configured in CONFIGURE Satellite Settings.
HELTH (F4)	To view the PRN numbers (GPS) or the Slot numbers (GLONASS) of satellites categorised in good, bad and unavailable.
PAGE (F6)	To change to another page on the screen.

Column	Description of Column
Sat	The Pseudo Random Noise number (GPS) or the Slot number (GLONASS) of the satellites.
Elev	The elevation angle in degrees. The arrows indicate if the satellite is rising or falling.
Azmth	The azimuth of the satellite.
S/N 1 and S/N 2	The signal to noise ratio on L1 and L2. The number is shown in brackets if the signal is currently not being used in the position calculations.

The Reference, GPS page

The information about the satellites at the reference shown on this page is identical with the information shown on STATUS Satellites, Rover page.


The Rover, GLO page

Available for GS09 when **GLONASS: Yes** is configured in CONFIGURE Satellite Settings. The information about the GLONASS satellites shown on this page is identical with the information shown on STATUS Satellites: Rover, GPS page.

The Skyplot page

The skyplot shows satellite information in a graphical way. The part of the skyplot between the 0° elevation and the cut-off angle is marked grey.

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
GPS X/GPS ü (F2)	To hide or show the GPS satellites (shown by the prefix G). Available for GS09 when GLONASS: Yes is configured in CONFIGURE Satellite Settings.
GLO X/GLO ü (F3)	To hide or show the GLONASS satellites (shown by the prefix R). Available for GS09 when GLONASS: Yes is configured in CONFIGURE Satellite Settings.
PAGE (F6)	To change to another page on the screen.

Symbol	Description of Symbol
	Satellites above the Cut Off Angle configured in CONFIGURE Satellite Settings.
	Satellites below the Cut Off Angle configured in CONFIGURE Satellite Settings.

The Almanac page

The almanac page shows the date of the used almanacs, the number of satellites tracked as shown on the skyplot and the number of all satellites available above the cut off elevation mask as shown on the skyplot.

Softkey	Description of Softkey
CONT (F1)	To exit STATUS Satellites: Rover.
PAGE (F6)	To change to another page on the screen.

29.3.3

Status Real-Time Data Input

Description

This screen shows information related to real-time data, for example the data link.

The General page

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
DATA (F4)	To view the data being received.
PAGE (F6)	To change to another page on the screen.

Field	Description of Field
R-Time Data	The received real-time data format message type.
GPS Used L1/L2	The number of satellites on L1 and L2 being used in the current position solution.
GLO Used L1/L2	Available for GS09 when GLONASS: Yes is configured in CONFIGURE Satellite Settings. The number of satellites on L1 and L2 being used in the current position solution.
Last Received	Seconds since the last message from the reference was received.
In Last Minute	The percentage of real-time data received from the reference compared with the data received from the GPS antenna within the last minute. This indicates how well the data link is working.
Ref Network	The type of reference network in use.

The Device Page

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
PAGE (F6)	To change to another page on the screen.

Field	Description of Field
Name	The name of the radio.
Type	The type of radio.
Port	The port to which the radio is connected.
Firmware	The software version of the attached radio.
Channel	The radio channel.
Actual Freq	The actual set frequency of the radio.

The Reference page

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
COORD (F2)	To view other coordinate types.
PAGE (F6)	To change to another page on the screen.

Field	Description of Field
Point ID	<ul style="list-style-type: none"> The point identification.
Ref Stn ID	<ul style="list-style-type: none"> An identification for a reference station. The ID can be converted into a compact format to be send out with real-time data in all real-time data formats. It is different from the point ID of the reference station.

Field	Description of Field
Antenna Ht	<ul style="list-style-type: none"> For data format Leica or RTCM v3.1: The antenna height at the reference from the marker to the MRP. For data format RTCM v2.3: ----- is displayed because the data format does not include information about the antenna height. For data format CMR/CMR+: The antenna height at the reference from the marker to the phase center.
Coords of	<ul style="list-style-type: none"> The coordinates for the reference station which are transferred depend on the active real-time data format. For real-time messages which include antenna height and antenna type: Marker.
	<ul style="list-style-type: none"> For real-time messages which do not include antenna Information: Phase Centre of L1.
Ref Antenna	<ul style="list-style-type: none"> The antenna used at the reference.
Ref Sensor	<ul style="list-style-type: none"> The receiver type used at the reference.

Real-Time Input Data

The following provides additional information on the satellite data received via real-time message. Information of those satellites is displayed, which are used on both reference and rover.

Access - press DATA (F4) on STATUS Real-Time, General page.

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
SAT- (F2)	To display information about the satellite with the next smaller PRN.

Softkey	Description of Softkey
SAT+ (F3)	To display information about the satellite with the next larger PRN.

The data being received from the satellites and the layout of the screen depend on the active real-time data format.

Field	Description of Field
Sat PRN	The PRN number (GPS) or the slot number (GLONASS) of the satellites shown with the prefix G (GPS) or R (GLONASS).
Sat Time	The GPS time of the satellite.
Phase L1, Phase L2	The number of phase cycles from the antenna to the satellite on L1 and L2.
Code L1, Code L2	The pseudorange between the antenna to the satellite for L1 and L2.

29.3.4

Status Current Antenna Position

Description

This screen shows information related to the current antenna position and the speed of the antenna. The baseline vector is also shown. MapView shows the current position in a graphical format.

The Position page

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
COORD (F2)	To view other coordinate types.
PAGE (F6)	To change to another page on the screen.

Field	Description of Field
Local Time	The local time.
Pos Latency	The latency of the computed position. Latency is mainly due to time required for data transfer and computation of position. Depends on the use of the prediction mode.
Pos Quality and Ht Quality	Available for phase fixed and code only solutions. The 2D coordinate and height quality of the computed position. Refer to "2.8 Terminology" for information on coordinate quality.
HDOP and VDOP	Available for navigated solutions.

The Baseline page

Information on the baseline vector is displayed.

The Speed page

Field	Description of Field
Horizontal	The speed over ground in the horizontal direction.

Field	Description of Field
On Bearing	Available for local coordinate systems. The bearing for the horizontal direction related to the North direction of the active coordinate system.
Vertical	The vertical component of the actual velocity.

29.3.5

Status Battery Level and Memory Usage

The Battery page

Softkey	Description of Softkey
CONT (F1)	To exit STATUS Satellites.
REF (F5)	To view the battery status of the reference.
PAGE (F6)	To change to another page on the screen.

Field	Description of Field
Any field	The percentage of remaining power capacity for all batteries are displayed numerically. Batteries not in use are shown in grey.

The Memory page

If no information for a field is available, then ----- is displayed.

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.
REF (F5)	To view battery and memory information for the reference.
PAGE (F6)	To change to another page on the screen.

Field	Description of Field
Device Used	The memory device in use.
Mem CF Card	The total/free memory for data storage on the CompactFlash card.
Mem Programs	The total/free system memory used for application programs.
Mem System	The total/free system memory. The system memory stores: <ul style="list-style-type: none">• CS09 related files such as system settings.• survey related files such as codelists.

29.3.6

Status System Information

The Instrument page

Shows the type of CS09, the serial number, the equipment number, the ID of the receiver, the currently active system language, the serial number of the measurement engine, the availability of additional instrument hardware options such as event input, position rate, RTK range, L2C, Multipath Mitigation, GLONASS ready, GLONASS permanent and if the protected OWI commands have been activated by a licence key.

The Firmware page

Shows the versions of all system firmware.

Field	Description of Field
Firmware	The version number of the firmware.
Build	The build number of the firmware.
Maintenance End	The expiry date of the software maintenance is shown.
Meas Engine	The firmware version for the measurement engine.
Meas Eng Boot	The firmware version of the boot software for the measurement engine.
Boot	The firmware version boot software.
LB2/OWI	The version of the LB2/OWI commands.
Navigation	The navigation firmware version with the algorithms for the signal processing.
API	The firmware version for the application program interface.
EF Interface	The firmware version for the electric front interface.

The Application page

Shows the versions of all uploaded application programs.

29.3.7

Status Radio Information

Description


This screen shows information related to the radio used to transfer real-time data.

Real-Time Input

Softkey	Description of Softkey
CONT (F1)	To return to the Main Menu screen.

Field	Description of Field
Name	The name of the radio.
Type	The type of radio.
Port	The port to which the radio is connected.
Firmware	The version number of the firmware.
Channel	The radio channel.
Actual Freq	The actual set frequency of the radio.
Signal	Indication of strength of received radio signal.

PART 2 - The Applications



30

30.1

Description



Working with COGO

An Overview of the Program


COGO is a program to perform COordinate GeOMetry calculations. This program calculates point coordinates, bearings between points and distances between points. It is a program for calculating rather than for measuring.

Changing the coordinates of a point which has been previously used in a COGO calculation, does not result in a previously calculated point being re-computed.


30.2

Starting the Program

Access



A) starting the program



CONT (F1)

To accept the screen entries and continue.

CONF (F2)

To configure the program.

DATA (F5)

To view, edit and delete points stored with the job.

CSYS (F6)

To select a different coordinate system.
Not available for Use Auto CrdSys=Yes
configured in **CONFIGURE Additional
Rover Settings**.



Field	Description of Field
Job	<ul style="list-style-type: none">The active job.
Coord System	<ul style="list-style-type: none">The coordinate system currently attached to the selected Job.
Codelist	<ul style="list-style-type: none">This field is a choicelist when codes are not stored in the selected Job.

Field	Description of Field
	<ul style="list-style-type: none"> This is field is an output when codes have already been stored in the selected Job. If codes had been copied from a System RAM codelist, then the name of the codelist is displayed. If codes have not been copied from a System RAM codelist but typed in manually, then the name of the active job is displayed.

B) selecting an option



CONT (F1)

To select an option and continue.



SHIFT CONF (F2)

To configure the program.

Menu option	Description of menu option
Inverse	To calculate the direction, the distance and the 3D coordinate differences between two known points. Points with full coordinate triplets, position only points and height only points can be used.
Intersections	To calculate the position of an intersection point using: <ul style="list-style-type: none"> Brng-Brng, bearings from two known points.

Menu option	Description of menu option
	<ul style="list-style-type: none"> • Brng-Dist, a bearing and a distance from two known points. • Dist-Dist, distances from two known points. • By Points, four points.
Line Calculations	<p>To calculate the base point of the line using:</p> <ul style="list-style-type: none"> • Calc Base Point, two known points and an offset point. <p>To calculate the offset point of the line using:</p> <ul style="list-style-type: none"> • Calc Offset Point, two known points that define the line, a distance along the line and an offset.
Arc Calculations	<p>To calculate:</p> <ul style="list-style-type: none"> • Calc Arc Center, the arc centre. • Calc Base Point, the base point of the arc. • Calc Offset Point, the offset point of the arc. <p>The arc can be defined using:</p> <ul style="list-style-type: none"> • three points. <p>Known must be also, depending on the arc calculation method:</p> <ul style="list-style-type: none"> • an offset point.


30.3

Calculating with Inverse

Starting

Refer to section "30.2 Starting the Program" to select the Inverse menu option.

Diagram



Known

P0 First known point

P1 Second known point

Unknown

α Direction from P0 to P1

d1 Slope distance between P0 and P1

d2 Horizontal distance between P0 and P1

d3 Height difference between P0 and P1

Calculating with Inverse

17:22	Σ=9	6=9	Bluetooth	Map
COGO	9	6=9		
Inverse				
Inverse Map				
From	:		PT1	↔
To	:		PT2	↔
Azimuth	:	200.0000	g	▲
HDist-Grid	:	5.400	m	
Δ Height	:	0.000	m	
Slope Dist	:	5.400	m	
Grade	:	1:0	hv	▼
				a ↑
STORE				PAGE

STORE (F1)

To store the result.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure the program.

Field	Description of Field
From	The point ID of the first known point. To type in coordinates for a known point open the choicelist. Press NEW (F2) to create a new point.
To	The point ID of the second known point. To type in coordinates for a known point open the choicelist. Press NEW (F2) to create a new point.
Azimuth	The direction from the first known point to the second known point.
HDist-Grid	The horizontal distance between the two known points.
Δ Height	The height difference between the two known points.
Slope Dist	The slope distance between the two known points.
Grade	The grade between the two known points.
Δ Easting	The difference in Easting between the two known points.
Δ Northing	The difference in Northing between the two known points.


30.4

Calculating with Intersections

Starting

Refer to section "30.2 Starting the Program" to select the Intersections menu option.

Diagram of intersection method 1, Bearing-Bearing



GS09_TR_012

Known

P0 First known point

P1 Second known point

$\alpha 1$ Direction from P0 to P2

$\alpha 2$ Direction from P1 to P2

Unknown

P2 COGO point (intersection point)

Calculating with Bearing-Bearing

Step 1 - inputting the data

17:42	+	7	Σ=7	7	6=7	+	+	+	+	+
COGO										
Intersection Input										
Input	Map									
Method	:	Brng - Brng								
1st Point	:	PT1								
Azimuth	:	105.0000 g								
2nd Point	:	PT2								
Azimuth	:	195.0000 g								

CALC					a ↑	PAGE
------	--	--	--	--	-----	------

Step 2 - storing/staking the results


17:48	+	7	Σ=7	7	6=7	+	+	+	+	+
COGO										
Brng - Brng Results										
Result	Code	Plot								
Point ID	:	3								
Easting	:	208.5425 m								
Northing	:	91.4575 m								
Ortho Ht	:	100.0000 m								

STORE	COORD					STAKE	a ↑	PAGE
-------	-------	--	--	--	--	-------	-----	------

Starting

Refer to section "30.2 Starting the Program" to select the Intersections menu option.

Diagram of intersection method 2, Bearing-Distance



Known

P0 First known point

P1 Second known point

α Direction from P0 to P2

r Radius, as defined by the distance P1 to P2

Unknown

P2 First COGO point (intersection point)

P3 Second COGO point (intersection point)

Calculating with Bearing-Distance

Step 1 - inputting the data

17:42	+	7	Σ=7	7	6=7	7	7	7	7
COGO									
Intersection Input									
Input Map									
Method	:	Brng - Dist							
1st Point	:	PT1							
Azimuth	:	105.0000 g							
2nd Point	:	PT2							
HDist-Grid	:	150.000 m							

								a ↑
CALC								PAGE


Step 2 - storing/staking the results

17:53	+	7	Σ=7	7	6=7	7	7	7	7
COGO									
Brng - Dist Results									
Result Code Plot									
Point ID	:	3							
Easting	:	295.8140 m							
Northing	:	84.5891 m							
Ortho Ht	:	100.0000 m							

								a ↑
STORE	COORD					STAKE		PAGE

Starting

Diagram of intersection method 3, Distance-Distance



GS09_TR_014

Refer to section "30.2 Starting the Program" to select the Intersections menu option.

Known

P0 First known point

P1 Second known point

r1 Radius, as defined by the distance P0 to P2

r2 Radius, as defined by the distance P1 to P2

Unknown

P2 First COGO point (intersection point)

P3 Second COGO point (intersection point)

Calculating with Distance-Distance

Step 1 - inputting the data

17:43	+	7	Σ=7	7	G=7	+	+	+	+	+
COGO										
Intersection Input										
Input Map										
Method	:	Dist - Dist								
1st Point	:	PT1								
HDist-Grid	:	150.000 m								
2nd Point	:	PT2								
HDist-Grid	:	150.000 m								

					a ↑
CALC					PAGE

Step 2 - storing/staking the results


17:54	+	7	Σ=7	7	G=7	+	+	+	+	+
COGO										
Dist - Dist Results										
Result1 Code Plot										
Point ID	:	3								
Easting	:	243.5414 m								
Northing	:	56.4586 m								
Ortho Ht	:	100.0000 m								

					a ↑
STORE	COORD	RSLT2		STAKE	PAGE

Starting

Refer to section "30.2 Starting the Program" to select the Intersections menu option.

Diagram of intersection method 4, By Points



GS09_TR_018

Known

P0 First known point

P1 Second known point

P2 Third known point

P3 Fourth known point

a Line from P0 to P1

b Line from P2 to P3

Unknown

P4 COGO point (intersection point)

Calculating with By Points

Step 1 - inputting the data

17:43	COGO	Σ=7	6=7
Intersection Input			
Input	Map		
Method	:	By Points	
1st Point	:	PT1	
2nd Point	:	PT2	
3rd Point	:	PT4	
4th Point	:	PT5	

CALC					a ↑
					PAGE

Step 2 - storing/staking the results

17:55	COGO	Σ=7	6=7
By Points Results			
Result	Code	Plot	
Point ID	:	3	
Easting	:	148.7179 m	
Northing	:	148.7179 m	
Ortho Ht	:	100.0000 m	

STORE	COORD				a ↑
					PAGE

Description of all softkeys

Softkey	Description of Softkey
CALC (F1)	To calculate the result.
COORD (F2)	To view other coordinate types.
PAGE (F6)	To change to another page on the screen.
RSLT1/RSLT2 (F3)	To view the first and second result.
STAKE (F5)	To access the Stakeout program and stake the calculated point.
STORE (F1)	To store the result.
SHIFT CONF (F2)	To configure the program.
SHIFT ELL H (F2) SHIFT ORTH (F2)	To change between the ellipsoidal and orthometric height.

Description of all input fields

Field	Description of Field
Method	The method for calculating the COGO point.
1st Point	The point ID of the first known point for the COGO calculation.
2nd Point	The point ID of the second known point for the COGO calculation.
3rd Point	The point ID of the third known point for the COGO calculation.
4th Point	The point ID of the fourth known point for the COGO calculation.
Azimuth	The direction from the known point to the calculated COGO point.
HDist-Grid	The grid distance from the known point to the calculated COGO point.


30.5

Calculating with Lines

Starting

Refer to section "30.2 Starting the Program" to select the Line Calculations menu option.

Diagram of line calculations method 1, Calc Base Point



Known

P0 Start Point

P1 End Point

P2 Offset Point

Unknown

P3 COGO point (base point)

d1 Offset Point

d2 Δ Line-Grid

Calculating with Calc Base Point

Step 1 - inputting the data

17:44 COGO $\Sigma=7$ $G=7$

Line Calculations Input

Input Map

Task : **Calc Base Point**

Start Point : PT1

End Point : PT2

Offset Point : PT4

CALC PAGE

Step 2 - storing/staking the results

17:55 COGO $\Sigma=7$ $G=7$

Base Point Results

Result	Code	Plot
Point ID		3
Easting		147.5000 m
Northing		147.5000 m
Ortho Ht		100.0000 m
Offset Point		4
Δ Line-Grid		67.1751 m
Δ Offset-Grid		-67.1751 m

STORE COORD STAKE PAGE

**Description
of all softkeys**

Softkey	Description of Softkey
CALC (F1)	To calculate the result.
COORD (F2)	To view other coordinate types.
PAGE (F6)	To change to another page on the screen.
RSLT1/RSLT2 (F3)	To view the first and second result.
STAKE (F5)	To access the Stakeout program and stake the calculated point.
STORE (F1)	To store the result.
SHIFT CONF (F2)	To configure the program.
SHIFT ELL H (F2) SHIFT ORTH (F2)	To change between the ellipsoidal and orthometric height.

**Description
of all input fields**

Field	Description of Field
Task	The task for calculating the COGO point.
Start Point	The point ID of the start point of the known line.
End Point	The point ID of the end point of the known line.
Offset Point	The point ID of the offset point to the known line.
ΔLine-Grid	The horizontal distance from the start point to the base point.
Offset-Grid	The offset distance from the base point to the offset point.


30.6

Calculating with Arcs

Starting

Refer to section "30.2 Starting the Program" to select the Arc Calculations menu option.

Diagram of arc calculations method 1, Calc Arc Center



GS09_TR_023

Known

P1 Start Point

P2 Second Point

P3 End Point

Unknown

P4 COGO point (arc center)

Calculating with Calc Arc Center

Step 1 - inputting the data

17:40	COGO	+	7	Σ=7	G=7	Bluetooth	GPS	Map	
Arc Calculations Input									
Input	Map								
Task	:	Calc Arc Center	↔						
Start Point	:	PT3	↔						
Second Point	:	PT2	↔						
End Point	:	PT1	↔						

CALC					a ↑	PAGE
------	--	--	--	--	-----	------

Step 2 - storing/staking the results


18:10	COGO	+	7	Σ=7	G=7	Bluetooth	GPS	Map	
Center of Arc Results									
Result	Code	Plot							
Point ID	:	4							
Easting	:	150.0000	m						
Northing	:	150.0000	m						
Ortho Ht	:	100.0000	m						
Arc Radius	:	70.7107	m						
Arc Length	:	333.2162	m						

STORE	COORD				STAKE	PAGE	a ↑
-------	-------	--	--	--	-------	------	-----

Starting

Refer to section "30.2 Starting the Program" to select the Arc Calculations menu option.

Diagram of arc calculations method 2, Calc Offset Point



Known

P1 Start Point

P2 Second Point

P3 End Point

d1 Δ ArcDist-Grid

d2 Δ Offset-Grid

Unknown

P4 COGO point (offset point)

Calculating with Calc Offset Point

Step 1 - inputting the data

17:41	COGO	Σ=7	G=7
Arc Calculations Input			
Input	Map		
Task	:	Calc Offset Point	
Start Point	:	PT3	↕
Second Point	:	PT2	↕
End Point	:	PT1	↕
Δ ArcDist-Grid:		50.000	m
Δ Offset-Grid :		5.000	m
			a ↑
CALC			PAGE


Step 2 - storing/staking the results

17:57	COGO	Σ=7	G=7
Offset Point Results			
Result	Code	Plot	
Point ID	:	4	
Easting	:	144.8607	m
Northing	:	215.5094	m
Ortho Ht	:	100.0000	m
Arc Radius	:	70.7107	m
Arc Length	:	333.2162	m
Offs Pt Brng	:	195.0158	g
			a ↑
STORE	COORD		STAKE PAGE

Starting

Refer to section "30.2 Starting the Program" to select the Arc Calculations menu option.

Diagram of arc calculations method 3, Calc Base Point



GS09_TR_022

Calculating with Calc Base Point

Step 1 - inputting the data

17:41	COGO	7	6=7	Σ=7	7
Arc Calculations Input					
Input	Map				
Task :	Calc Base Point				
Start Point :	PT3				
Second Point :	PT2				
End Point :	PT1				
Offset Point :	PT5				
					a ↑
CALC					PAGE

Step 2 - storing/staking the results

17:56	COGO	7	6=7	Σ=7	7
Base Point Results					
Result	Code	Plot			
Point ID :			4		
Easting :			200.0000	m	
Northing :			100.0000	m	
Ortho Ht :			100.0000	m	
Offset Point :			5		
ΔArcDist-Grid :			222.1441	m	
ΔOffset-Grid :			0.0000	m	
					a ↑
STORE	COORD			STAKE	PAGE

**Description
of all softkeys**

Softkey	Description of Softkey
CALC (F1)	To calculate the result.
COORD (F2)	To view other coordinate types.
PAGE (F6)	To change to another page on the screen.
RSLT1/RSLT2 (F3)	To view the first and second result.
STAKE (F5)	To access the Stakeout program and stake the calculated point.
STORE (F1)	To store the result.
SHIFT CONF (F2)	To configure the program.
SHIFT ELL H (F2) SHIFT ORTH (F2)	To change between the ellipsoidal and orthometric height.

**Description
of all input fields**

Field	Description of Field
Task	The task for calculating the COGO point.
Start Point	The point ID of the start point of the known arc.
Second point	The point ID of the second point of the known arc.
End Point	The point ID of the end point of the known arc.
Offset Point	The point ID of the offset point to the known arc.
ΔArcDist-Grid	The horizontal distance from the start point to the base point.
ΔOffset-Grid	The offset distance from the base point to the offset point.

30.7

Configuring the Program

Configuring

17:39
COGO
Configuration
Parameters
Est Pos Qlty : 0.300 m
Est Ht Qlty : 0.300 m
TPS Obs-TPS Obs Intersection
Compute Ht : Using Average

					a ↑
CONT					

Field	Description of Field
Est Pos Qlty	The estimated value for the position quality assigned to all calculated COGO points which is used for the averaging calculation.
Est Ht Qlty	The estimated value for the height quality assigned to all calculated heights which is used for the averaging calculation.

CONT (F1)

To accept the screen entries and continue.

SHIFT ABOUT (F5)

To display information about the program name, the version number, the date of the version, the copyright and the article number.

31

Working with Determine Coord System

31.1

An Overview of the Program

Description

- GPS measured points are always stored based on the global geocentric datum known as WGS 1984. Most surveys require coordinates in a local grid system, for example, based on a country's official mapping datum or an arbitrary grid system used in a particular area such as a construction site. To convert the WGS 1984 coordinates into local coordinates a coordinate system needs to be created. Part of the coordinate system is the transformation used to convert coordinates from the WGS 1984 datum to the local datum.
 - The Determine Coordinate System application program allows:
 - the parameters of a new transformation to be determined.
 - the parameters of an existing transformation to be recomputed.
-

Transformations

A transformation is the process of converting coords from one geodetic datum to another.

Transformation requirements

- Transformation parameters.
- In some cases a local ellipsoid.
- In some cases a map projection.
- In some cases a geoid model.

Transformation parameters

A transformation consists of a number of shifts, rotations and scale factors, depending on the type of transformation used. Not all of these parameters are always required. These parameters may already be known, or may need to be computed.

Description of transformations

A Onestep transformation is provided on CS09.

Characteristic	Description
Principle	<p>Transforms coordinates directly from WGS 1984 to local grid and vice versa without knowledge about the local ellipsoid or the map projection. Procedure:</p> <ol style="list-style-type: none"> 1. The WGS 1984 coordinates are projected onto a temporary Transverse Mercator projection. The central meridian of this projection passes through the centre of gravity of the common control points. 2. The results of 1. are preliminary grid coordinates for the WGS 1984 points. 3. These preliminary grid coordinates are matched with the local grid control points in order to compute the Easting and Northing shifts, the rotation and the scale factor between these two sets of points. This is known as a classic 2D transformation. 4. The height transformation is a single dimension height approximation.
Positions and heights	The position and height transformations are separated.
Use	<p>When measurements are to be forced to tie in with local existing control. For example:</p> <p>A site where the coordinates of the control points are based on a purely local grid. The coordinate values within this grid are totally arbitrary and are in no way connected with any ellipsoid or map projection. Obviously a Classic 3D transformation cannot be used here, as cartesian coordinates cannot be calculated from such a grid.</p>

Characteristic	Description
Requirements	<ul style="list-style-type: none"> • The position is known in WGS 1984 and in the local system for at least one point. Three or more points are recommended in order to obtain redundancy. • Additional height information for one point enables the transformation of heights. • Parameters of the local geoid model. This is not compulsory. • No parameters of the local ellipsoid. • No parameters of the local map projection.
Area	<ul style="list-style-type: none"> • Limited to about 10 x 10 km because no projection scale factor is applied and a standard Transverse Mercator projection is used to compute the preliminary WGS 1984 grid coordinates. • For areas without large height differences.
Points and transformation parameters	<p>The transformation parameters determined depend on the number of available points with position information.</p> <ul style="list-style-type: none"> • One point: Classic 2D with shift in X and Y. • Two points: Classic 2D with shift in X and Y, rotation about Z and scale. • More than two points: Classic 2D with shift in X and Y, rotation about Z, scale and residuals.
Points and height transformation	<p>The type of height transformation performed depends on the number of available points with height information.</p> <ul style="list-style-type: none"> • No point: No height transformation.

Characteristic	Description
	<ul style="list-style-type: none"> • One point: Heights are shifted to fit to the height control point. • Two points: Average height shift between the two height control points. • Three points: Tilted plane through the three height control points to approximate the local heights. • More than three points: Best fitting average plane.
Advantage	<ul style="list-style-type: none"> • Errors in height do not propagate into errors in position since the height and position transformations are separated. • If local heights have low accuracy or do not exist, a transformation of position can still be calculated and vice versa. • The height points and position points do not have to be the same points. • No parameters of the local ellipsoid and map projection is required. • Parameters may be computed with a minimum of points. Care should be taken when computing parameters using just one or two local points as the parameters calculated are valid in the vicinity of the points used for the transformation.
Disadvantage	<ul style="list-style-type: none"> • Restriction in the area over which the transformation can be applied. This is mainly due to the fact that there is no provision for scale factor in the projection. • The accuracy in height depends on the undulation of the geoid. The bigger the geoid variations the less accurate the results are.

Requirements to determine a transformation

- To determine a transformation it is necessary to have common control points whose positions are known in both WGS 1984 coordinates and local coordinates.
 - The more points that are common between datums the more accurately the transformation parameters can be calculated. Depending on the type of transformation used, details about the map projection, the local ellipsoid and a local geoidal model may also be needed.
-

Requirements for control points

- The control points used for the transformation should surround the area for which the transformation is to be applied. It is not good practice to survey or convert coordinates outside of the area covered by the control points as extrapolation errors may be introduced.
 - When a geoid field file is used in the determination of a coordinate system, the control points for the calculation must fall within the areas of the field files.
-


31.2

Starting the Program

Access



A) starting the program



Name : **new coord system**

WGS84 Pts Job: WGS84 job

Local Pts Job: Local job

Method : Normal



CONT (F1)

To accept the screen entries and continue.

CONF (F2)

To configure the program.

CSYS (F6)

To choose a coordinate system to edit.

Only available for Method=Normal.

Field	Description of Field
Name	<ul style="list-style-type: none"> A unique name for the coordinate system. The name may be up to 16 characters in length and may include spaces. Entering the name of a coordinate system will allow that existing system to be updated.
WGS84 Pts Job	<ul style="list-style-type: none"> The job from which the points with WGS84 coordinates will be taken.
Local Pts Job	<ul style="list-style-type: none"> The job from which the points with local coordinates will be taken.
Method	<ul style="list-style-type: none"> Method used to determine the coordinate system.

Field	Description of Field
	<ul style="list-style-type: none"> • Normal. One or more control points for both the WGS 1984 and the local datum.
	<ul style="list-style-type: none"> • One Pt Localistn. One control point for both the WGS 1984 and the local datum.

B) selecting method

IF the method is	THEN
Normal	<ul style="list-style-type: none"> • to determine a new coordinate system: <ul style="list-style-type: none"> • enter the name of the new coordinate system, • select the appropriate jobs, • select Method=Normal and continue with sec 31.3. • to update an existing coordinate system: <ul style="list-style-type: none"> • enter the name of the existing coordinate system or press CSYS (F6) to select the existing coordinate system, • select the appropriate jobs, • select Method=Normal and continue with sec 31.4.
One Pt Localistn	<ul style="list-style-type: none"> • to determine a new coordinate system: <ul style="list-style-type: none"> • enter the name of the new coordinate system, • select the appropriate jobs, • select Method=One Pt Localistn and continue with sec 31.5.


31.3

Determining a New Coord System using the Normal Method

Starting

Refer to section "31.2 Starting the Program" to select the Normal method.

Step 1) choosing height type



Transfm Name: **new coord system**
Transfm Type: **Onestep** |<|>
Height Mode : **Ellipsoidal** |<|>




CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Transfm Name	<ul style="list-style-type: none">A unique name for the transformation. The name may be up to 16 characters in length and may include spaces. If a coordinate system is being updated then its name is displayed.
Transfm Type	<ul style="list-style-type: none">The type of transformation to be used when determining a coordinate system.
Height Mode	<ul style="list-style-type: none">The height mode to be used in the determination of a coordinate system.Orthometric or Ellipsoidal. Available when determining a new coordinate system.

Step 2)
choosing geoid model



Geoid Mode1 :




CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Geoid Model	The geoid model to be used in the transformation.

Step 3)
matching the points



CALC (F1)

To confirm the selections, compute the transformation and continue with the next screen.

NEW (F2)

To match a new pair of points. This pair is added to the list.

EDIT (F3)

To edit the highlighted pair of matched points.

DEL (F4)

To delete the highlighted pair of matched points.

MATCH (F5)

To change the type of match for a highlighted pair of matched points.

AUTO (F6)

To scan both jobs for points that have the same point ID. Points with matching point ID's are added to the list.

SHIFT PARAM (F5)

To configure Classic 3D transformation parameters for Transform Type=Classic 3D or 2D & Height transformation parameters for Transform Type=Onestep and Transform Type=Twostep.

Column	Description of Column
WGS84 Pts	The point ID of the points chosen from WGS84 Pts Job.

Column	Description of Column
Local Pts	The point ID of the points chosen from Local Pts Job.
Match	The type of match to be made between the points. This information is used in the transformation calculation. Position & Height, Position only, Height only or None. None removes matched common points from the transformation calculation but does not delete them from the list. This can be used to help improve residuals.

This screen provides a list of points chosen from WGS84 Pts Job and Local Pts Job. The number of control points matched between both jobs is indicated in the title. Unless there is no pair of matching points in the list all softkeys are available.

Step 4) checking the residuals

WGS84 Pts	East [m]	North [m]
W100	-0.050	0.066
W200	0.002	-0.066
W300	0.048	-0.000

CONT RESULT MORE

CONT (F1)

To accept the screen entries and continue.

RESULT (F3)

To view results of the transformation.

MORE (F5)

To display information about height residuals.

Column	Description of Column
WGS84 Pts	The point ID of the points chosen from WGS84 Pts Job.
East	The Easting residual. If positions were not used in the transformation calculation then ----- will be displayed.
North	The Northing residual. If positions were not used in the transformation calculation then ----- will be displayed.
Height	The Height residual. If heights were not used in the transformation calculation then ----- will be displayed.
!	Indicates residuals that exceed the residual limit defined in DET C SYS Configuration, Residuals page.
!	Indicates the largest residual in East, North and Height.

The next step

IF	THEN
the residuals are unacceptable	press ESC to return to step 3. Matched points can be edited, deleted or temporarily removed from the list and the transformation recalculated.
the transformation results are to be checked	press RESLT (F3) to display the transformation results. Results of the transformation between the WGS 1984 datum and the local datum are shown for each of the transformation parameters.
the residuals are acceptable	press CONT (F1) to continue to step 5.

Transformation Results

17:33
DET C SYS

Transformation Results

Position | Height

Shift dX : 251694.1695 m
Shift dY : 756810.6695 m

Rotation : 0.00000 °
Scale : -74.3342 ppm

Rot Orig X : 4.2762 m
Rot Orig Y : 5.8048 m

CONT SCALE RMS PAGE a ↑

CONT (F1)

To return to step 4.

SCALE (F4) or PPM (F4)

Available on the Position page. To switch between Scale displaying the true scale and displaying the ppm.

RMS (F5) or PARAM (F5)

To switch between the root mean square values of the parameters and the actual parameter values.

PAGE (F6)


To change to another page on the screen.

Field	Description of Fields for the Position page
Shift dX	Shift in X direction.
Shift dY	Shift in Y direction.
Rotation	Rotation of transformation.
Scale	Scale factor used in transformation. Either true scale or ppm.
Rot Orig X	Position in the X direction of the origin of rotation.
Rot Orig Y	Position in the Y direction of the origin of rotation.

Field	Description of Fields for the Height page
Slope in X	Tilt of the transformation in the X direction.

Field	Description of Fields for the Height page
Slope in Y	Tilt of the transformation in the Y direction.
Height Shift	Shift in height between WGS 1984 datum and local datum.

Step 5)
storing the results



STORE (F1)

To store the coordinate system. Stores the coordinate system to the DB-X and attaches it to the WGS84 Pts Job selected at the beginning, replacing any coordinate system attached to this job. WGS84 Pts job becomes the active job.

PAGE (F6)

To store the coordinate system.

Field	Description of Fields for the Summary page
Name	The name of the coordinate system can be changed. The name may be up to 16 characters in length and may include spaces.
Transfrm Type	The type of transformation used.
Matched Pts	Number of matched points, as defined in step 3.
Easting, Northing or Height	Largest Easting/Northing/Height residual from the transformation calculation.

Field	Description of Fields for the Coord System page
Residuals	<ul style="list-style-type: none">• None, 1/Distance^{XX} or Multiquadratic.The method by which the residuals of the control points will be distributed throughout the transformation area.
Geoid Model	<ul style="list-style-type: none">• Name of geoid model used, as defined in step 2.

31.4

Updating an Existing Coord System using the Normal Method

Starting

Refer to section "31.2 Starting the Program" to select the Normal method.

Selecting the existing coordinate system

Refer to section "31.2 Starting the Program" to enter or select the existing coordinate system.

Updating the existing coordinate system

The steps to follow are identical to those when determining a new coordinate system using the Normal method. Refer to "31.3 Determining a New Coord System using the Normal Method", from step 3 onwards.


31.5

Determining a New Coord System using the One Pt. Local. Method

Starting

Refer to section "31.2 Starting the Program" to select the One Point Localisation method.

Step 1) choosing height type



Transform Name: **new coord system**
Transform Type: **Onestep**
Height Mode : **Ellipsoidal**




CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Transform Name	<ul style="list-style-type: none">A unique name for the transformation. The name may be up to 16 characters in length and may include spaces.
Transform Type	<ul style="list-style-type: none">The type of transformation to be used when determining a coordinate system.
Height Mode	<ul style="list-style-type: none">The height mode to be used in the determination of a coordinate system.
	<ul style="list-style-type: none">Orthometric or Ellipsoidal. Available when determining a new coordinate system.

Step 2)
choosing geoid model



Geoid Model :



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Geoid Model	The geoid model to be used in the transformation.

Step 3)
choosing common pt

17:29
DET C SYS

Step 3: Choose Common Point

Match Type : Pos Only

WGS84 Point : W100
Known Point : L100

Match Height : Yes


WGS84 Point : W200
Known Point : L200

CONT a ↑ CONT (F1)
To accept the screen entries and continue.

Field	Description of Field
Match Type	<ul style="list-style-type: none"> How the horizontal and vertical shifts of the transformation should be computed. Pos & Height. Position and height are taken from the same pair of matching points. Pos Only. Position is taken from one pair of matching points. The height can be taken from another pair of matching points.
WGS84 Point	<ul style="list-style-type: none"> Choicelist. The point ID of the horizontal and/or vertical control point chosen from WGS84 Pts Job. All WGS 1984 points can be selected.
Known Point	<ul style="list-style-type: none"> Choicelist. The point ID of the horizontal and/or vertical control point chosen from Local Pts Job. All local points can be selected.

Field	Description of Field
Match Height	<ul style="list-style-type: none"> Yes or No. Available for Match Type=Pos Only. Activates the determination of the vertical shift from a separate pair of matching points.

Step 4)
determining rotation



Rotation : 0.0000 g




CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Method	<ul style="list-style-type: none"> Use WGS84 North, User Entered, Convergence Angle or Two WGS84 Points. Method by which the rotation angle for the transformation is determined.
When Method=Use WGS84 North, the following fields apply:	
Rotation	<ul style="list-style-type: none"> Output. Transformation will be rotated to North as defined by the WGS 1984 datum. North is 0.00000°.
When Method=User Entered, the following fields apply:	

Field	Description of Field
Rotation	<ul style="list-style-type: none"> User Input. Allows the orientation of the transformation to be manually typed in.
When Method=Convergence Angle, the following fields apply:	
Coord System	<ul style="list-style-type: none"> Choicelist. Coordinate system to provide the direction of grid North in the area where the control point used for determining the local coordinate system, is located.
WGS84 Point	<ul style="list-style-type: none"> Choicelist. WGS 1984 point of which the convergence angle will be calculated.
Rotation	<ul style="list-style-type: none"> Output. The rotation of the transformation calculated as 0.00000° minus the computed convergence angle.
When Method=Two WGS84 Points, the following fields apply:	
Point 1	<ul style="list-style-type: none"> Choicelist. First WGS 1984 point to use for computation of Azimuth.
Point 2	<ul style="list-style-type: none"> Choicelist. Second WGS 1984 point to use for computation of Azimuth.
Azimuth	<ul style="list-style-type: none"> Output. Computed azimuth between Point 1 and Point 2.
Reqd Azimuth	<ul style="list-style-type: none"> User input. The required grid azimuth, computed between two local points.
Rotation	<ul style="list-style-type: none"> Output. The rotation of the transformation calculated as Reqd Azimuth minus Azimuth.

Step 5)
determining scale



CONT (F1)


To accept the screen entries and continue.
SCALE (F4) or PPM (F4)

To switch between Scale displaying the true scale and displaying the ppm. The scale is calculated using the formula $(r + h)/r$ where r is the distance from the centre of the ellipsoid to the WGS 1984 point selected in step 3 and h is the height of this point above the WGS 1984 ellipsoid.

Field	Description of Field
Method	<ul style="list-style-type: none"> Known WGS84 Pt, Known WGS84 Ht or User Entered. Method of determining the scale factor of the transformation.
When Method=Known WGS84 Pt, the following fields apply:	
WGS84 Point	<ul style="list-style-type: none"> Choicelist. WGS 1984 point from which the scale factor will be calculated. The scale factor is calculated using the height of the known WGS 1984 point.
Scale	<ul style="list-style-type: none"> Output. The calculated scale factor.
When Method=Known WGS84 Ht, the following fields apply:	
Known Height	<ul style="list-style-type: none"> User input. The WGS 1984 height of a point can be typed in. The scale factor is calculated using this height.
Scale	<ul style="list-style-type: none"> Output. The calculated scale factor.

Field	Description of Field
When Method=User Entered, the following fields apply:	
Scale	<ul style="list-style-type: none"> User Input. Allows the scale factor to be typed in manually.

Step 6)
storing the results



STORE (F1)

To store the coordinate system to the DB-X, attach the system to WGS84 Pts Job that was selected at the beginning and return to **GS09** Main Menu.

SCALE (F4) or PPM (F4)

To switch between Scale displaying the true scale and displaying the ppm.


Field	Description of Field
Name	A unique name for the coordinate system. The name may be up to 16 characters in length and may include spaces.
Shift dX	Shift in X direction.
Shift dY	Shift in Y direction.
Rotation	Rotation of transformation.
Scale	Scale factor of transformation.
Rot Orig X	Position in the X direction of the origin of rotation.

Field	Description of Field
Rot Orig Y	Position in the Y direction of the origin of rotation.

31.6

Configuring the Program

Configuring



Field	Description of Field
Easting, Northing or Height	<ul style="list-style-type: none"> The limit above which Easting/Northing/Height residuals will be flagged as possible outliers.
Residual Distbtn	<ul style="list-style-type: none"> The method by which the residuals of the control points will be distributed throughout the transformation area. None. No distribution is made. Residuals remain with their associated points. 1/Distance^{xx}. Distributes the residuals according to the distance between each control point and the newly transformed point. Multiquadratic. Distributes the residuals using a multiquadratic interpolation approach.

32

32.1

Description

Working with GPS Resection

An Overview of the Program

GPS Resection is a program which is:

- used to create and apply a onestep coordinate system to the active job.
- designed to provide an orientation to a GPS job in a similar method to a TPS resection.


This program is specifically aimed at those users who are:

- new to real-time GPS surveying.
 - unfamiliar with the concepts of coordinate systems and geoids.
 - familiar with the knowledge of TPS surveying and the ideas of setup and orientation.
-

32.2

Starting the Program

Access



Starting the program



Name : **GPS Resection**
Job : My 1st job



CONT (F1)

To accept the screen entries and continue.

Field	Description of Field
Name	A unique name for the coordinate system. The name may be up to 16 characters in length and may include spaces.
Job	The job from which the points with local coordinates and with WGS84 coordinates will be taken.

32.3

Using the Program

Step 1)
measuring
the local points using
WGS84 coordinates

13:29
GPS RESEC
Σ=13
G=9
Step 1: Measure Control Pt
Point ID : local_001
Antenna Ht : 2.0000 m
Easting : 500.0000 m
Northing : 500.0000 m
Ortho Ht : 100.0000 m
Match Type : Pos & Height
3D CQ : 0.0091 m
OCUPY H PNT a

OCUPY (F1)

To start measuring the WGS84 point. The position mode icon changes to the static icon. (F1) changes to **STOP**.

STOP (F1)

To end measuring the WGS84 point. When Auto STOP: Yes in CONFIGURE Point Occupation Settings, the measurement ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. (F1) changes to **STORE**.

STORE (F1)

To store the measured point. When Auto STORE: Yes in CONFIGURE Point Occupation Settings, the measured point is stored automatically. (F1) changes to **OCUPY**.

COORD (F2)

To view other coordinate types.


SHIFT ELL H (F2) or SHIFT ORTH (F2)

To change between the ellipsoidal and the orthometric height.

Field	Description of Field
Point ID	<ul style="list-style-type: none">The point ID of the known local point.
Antenna Ht	<ul style="list-style-type: none">The antenna height.

Field	Description of Field
Easting, Northing, Ortho Height or Local Ell Ht	<ul style="list-style-type: none"> The coordinates of the known local point.
Match Type	<ul style="list-style-type: none"> How the horizontal and vertical shifts should be computed. Pos & Height. Position and height are used for the calculation. Pos Only. The position is used for the calculation. Height Only. The height is used for the calculation.
3D CQ	<ul style="list-style-type: none"> The current 3D coordinate quality of the computed position.

Step 2)
matching
the local points to
WGS84 coordinates for
position and/or height



CALC (F1)

To confirm the selections, compute the transformation and continue with the subsequent screen.

ADD (F2)

To survey another WGS84 point. This point is added to the list. Accesses step 1.

DEL (F4)

To delete the highlighted point from the list.

MATCH (F5)

To change the type of match for a highlighted point.

Column	Description of Column
Points	The point ID of the points chosen for the calculation.

Column	Description of Column
Match	The type of match to be made between the WGS84 and the known local point. This information is used in the transformation calculation. Position & Height, Position Only, Height Only. None removes the highlighted point from the transformation calculation but does not delete it from the list. This can be used to help improve residuals.

Step 3)
checking
the calculated residuals

The screenshot shows a GPS device screen with the following elements:

- Top status bar: 13:29, GPS RESEC, 15, G=9, and various icons.
- Title bar: Step 3: Check Residuals
- Table of residuals:

Points	East [m]	North [m]
1oca1_001	-0.007	-0.007
1oca1_002	-0.015?	0.012
1oca1_003	0.012	0.023?
1oca1_004	-0.008	-0.015

At the bottom of the screen, there are control buttons: STORE, MORE, and a cursor icon.

STORE (F1)

To accept the screen entries and continue.

MORE (F5)

To display information about height residuals.

Column	Description of Column
Points	The point ID of the points used in the calculation.
East	The Easting residual. If positions were not used in the transformation calculation then ----- will be displayed.

Column	Description of Column
North	The Northing residual. If positions were not used in the transformation calculation then ----- will be displayed.
Height	The Height residual. If heights were not used in the transformation calculation then ----- will be displayed.
?	Indicates residuals that exceed the residual limit.
!	Indicates the largest residual in East, North and Height.

The next step

IF the residuals are	THEN
unacceptable	press ESC to return to step 2. The points can be edited, deleted or temporarily removed from the list and the transformation recalculated.
acceptable	press STORE (F1) to store the coordinate system and attach it to the active job.

Step 4) storing the calculated results

Press **STORE (F1)** to store the coordinate system and attach it to the active job.

33

Working with Reference Line

33.1

An Overview of the Program

Description

Reference Line is a program which can be used for the following tasks:

- Measuring to a line/arc where the coordinates of a target point can be calculated from its position relative to the defined reference line/arc.
- Staking to a line/arc where the position of a target point is known and instructions to locate the point are given relative to the reference line/arc.
- Staking to a polyline where the position of a target point is known and instructions to locate the point are given relative to the polyline.

Point types

Reference lines/arcs can be created from points stored as:

- WGS 1984 geodetic
- Local grid

Points must have full coordinate triplets. Heights and positions are always considered.

Terms

Term	Description of Term
Reference point	The term reference point is used in this chapter to refer to the point from which the perpendicular offset from the reference line/arc, to the target point, is measured.
Target point	The design point. <ul style="list-style-type: none">• For measuring to a reference line, this is the point with the coordinates of the current position and the designed or calculated height.• For staking to a reference line, this is the point to be staked.
Measured point	The current position.

Defining a reference line/arc



Coordinate systems


Direction of values

A reference line is defined by two known points.
A reference arc is defined by three known points.
Polylines can be imported from a DXF job and selected from a list or on the Map page.

It is possible to define an arc that has an opening angle of more than 180° .

It is possible to use a valid coordinate system but have the line or part of the line lying outside of the projection. In these cases the output fields of all prompts relating to the difference in coordinates between the point being staked and the current position are shown as -----.


The following diagram shows the direction of positive and negative values for distance and height differences between the target point and the reference point for reference lines.




33.2

Starting the Program

Access



A) starting the program



CONT (F1)

To accept the screen entries and continue.

CONF (F2)

To configure the program.

DATA (F4)

To view, edit and delete points stored with the job.

CSYS (F6)


To select a different coordinate system.
Not available for Use Auto CrdSys=Yes configured in **CONFIGURE Additional Rover Settings**.



Field	Description of Field
Control Job	The original points to be staked are stored in this job. Points to define reference lines/arcs are also taken from this job.
Job	The active job. Polylines are stored in this job. Points which are occupied after staking out are stored in this job. The original points to be staked are not copied to this job.
Coord System	The coordinate system currently attached to the selected Job. Cannot be edited for Use Auto CrdSys=Yes configured in CONFIGURE Additional Rover Settings .

Field	Description of Field
Codelist	<p>Chocelist. No codes are stored in the selected Job.</p> <p>Output. Codes have already been stored in the selected Job. If codes had been copied from a System RAM codelist, then the name of the codelist is displayed. If codes have not been copied from a System RAM codelist but typed in manually, then the name of the active job is displayed.</p>

B) selecting an option




CONT (F1)

To accept the screen entries and continue.

Menu option	Description of menu option
Measure to Line	Calculates the coordinates of a point from its position relative to the reference line.
Stake to Line	Allows points to be staked relative to the reference line.

Menu option	Description of menu option
Measure to Arc	Calculates the coordinates of a point from its position relative to the reference arc.
Stake to Arc	Allows points to be staked relative to the reference arc.
Stake to Polyline	Allows points to be staked relative to a polyline.

C) choosing the reference line



CONT (F1)

To accept the screen entries and continue.

SLOPE (F3)

To define the slope.

PAGE (F6)

To change to another page on the screen.



Field	Description of Field
Start Point	<ul style="list-style-type: none"> The start point of the reference line/arc.
Second Point	<ul style="list-style-type: none"> The second point of the reference arc.
End Point	<ul style="list-style-type: none"> The end point of the reference line/arc.
Line Length	<ul style="list-style-type: none"> The horizontal grid distance between Start Point and End Point of the line.

Field	Description of Field
	<ul style="list-style-type: none">• ----- is displayed if the distance cannot be calculated.
Arc Dist	<ul style="list-style-type: none">• The horizontal grid distance along the arc between Start Point and End Point of the arc.• ----- is displayed if the distance cannot be calculated.


33.3

Measuring to a Reference Line/Arc

Description


The horizontal and vertical position and the chainage of a manually occupied point can be calculated relative to the defined reference line/arc.

Diagram 1 measuring to a line, horizontally



- P0 Start point
- P1 End point
- P2 Measured point
- P3 Reference point
- d1 Δ Offset
- d2 Δ Line


Diagram 2 measuring to a line, vertically



- P0 Start point
- P1 End point
- P2 Measured point
- P3 Reference point with Design Ht
- d1 Δ Ht-Design

Diagram 3 measuring to an arc, horizontally


Target point inside arc



GS09_TR_003

- P0 Start point
- P1 End point
- P2 Measured point
- P3 Reference point
- d1 Δ Offset
- d2 Δ Arc


Target point outside arc



GS09_TR_004

- P0 Start point
- P1 End point
- P2 Measured point
- P3 Reference point
- d1 Δ Offset
- d2 Δ Arc

**Diagram 4
measuring to an arc,
vertically**



- P0 Start point
- P1 End point
- P2 Measured point
- P3 Reference point with Design Ht
- d1 Δ Ht-Design

Measuring the points

17:27	
REFLINE	
Measure Points	
Ref Line	Map
Point ID	: 0003
Antenna Ht	: 2.000 m
Δ Offset	: 62.500 m
Δ Line	: 87.517 m
Δ Ht-Design	: 30.338 m
Design Ht	: 58.671 m
Δ Perp Dist	: 96.346 m
a ↑	
OCUPY	PAGE

OCUPY (F1)

To start measuring the point. The position mode icon changes to the static icon. **(F1)** changes to **STOP**. The difference between the current position and the point being staked is still displayed.

STOP (F1)

To end measuring the point. When Auto STOP: Yes in CONFIGURE Point Occupation Settings, the measurement ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. **(F1)** changes to **STORE**.

STORE (F1)

To store the measured point. When Auto STORE: Yes in CONFIGURE Point Occupation Settings, the measured point is stored automatically. (F1) changes to **OCUPY**.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure the reference line/arc. Available for **OCUPY (F1)** being displayed.

SHIFT QUIT (F6)

To exit Reference Line application program.

Field	Description of Field
Point ID	The point ID of the point to be measured.
Antenna Ht	The height of the antenna that is being used. The changed antenna height is used until the application program is exited.
ΔOffset	Perpendicular offset from the reference line/arc measured from the reference point to the measured point. For reference arcs, the smallest ΔOffset possible is calculated. To ensure this the arc will be extended if necessary. Refer to paragraph "Diagram 3 measuring to an arc, horizontally".
ΔLine	Horizontal distance along the reference line from the start point to the reference point.
ΔArc	Horizontal distance along the reference arc from the start point to the reference point.

Field	Description of Field
ΔHt-Design	Height difference between the Design Ht and the height of the measured point.
Design Ht	Allows input of the design height of the target point.


33.4

Staking to a Reference Line/Arc

Description


Allows for the position of a point to be defined relative to a reference line/arc and then staked.

Diagram 1 staking to a line, horizontally




- P0 Start point
- P1 End point
- P2 Target point
- P3 Reference point
- d1 Stake Offset
- d2 Along Line

Diagram 2 staking to a line, vertically




- P0 Start point
- P1 End point
- P2 Target point
- P3 Reference point with Design Ht

Diagram 3
staking to an arc,
horizontally



- P0 Start point
- P1 End point
- P2 Target point
- P3 Reference point
- d1 Stake Offset
- d2 Along Arc

Diagram 4
staking to an arc,
vertically



- P0 Start point
- P1 End point
- P2 Target point
- P3 Reference point with Design Ht

Step 1)
Entering the offsets

17:25
 REFLINE
 Enter Stake Offset Values
 Point ID : 0003
 Along Line : 10.000 m
 Stake Offset : 20.000 m
 Design Ht : 424.777 m

CONT (F1)

To accept the screen entries and continue.


SHIFT CONF (F2)

To configure the reference line/arc.

CONT [] [] [] [] []

Field	Description of Field
Point ID	The point ID of the target point to be staked.
Stake Offset	The offset from the reference point to the target point.
Along Line	Available for Task=Stake to Line. Horizontal distance from the start point to the reference point along the reference line.
Along Arc	Available for Task=Stake to Arc. Horizontal distance from the start point to the reference point along the reference arc.
Design Ht	Allows input of the design height of the target point.

Step 2) Staking the points



OCUPY (F1)

To start measuring the point being staked. The position mode icon changes to the static icon. **(F1)** changes to **STOP**. The difference between the current position and the point being staked is still displayed.

STOP (F1)

To end measuring the point being staked. When Auto STOP: Yes in CONFIGURE Point Occupation Settings, the measurement ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. **(F1)** changes to **STORE**.

STORE (F1)

To store the measured point. When Auto STORE: Yes in CONFIGURE Point Occupation Settings, the measured point is stored automatically. **(F1)** changes to **OCUPY**.

REVRS (F3)

To reverse the graphical display top to bottom. A reversed graphical display can be used when the point to be staked lies behind the current position.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure the reference line/arc. Available for **OCUPY (F1)** being displayed.

SHIFT QUIT (F6)

To exit Reference Line application program.

Field	Description of Field
First field on the screen	The point ID of the point to be staked.
hA	The default antenna height. The changed antenna height is used until the application program is exited.
FORW	The horizontal distance from the current position to the point to be staked in the direction of the orientation.
BACK	The horizontal distance from the current position to the point to be staked in the reverse direction of the orientation.
RGHT	Horizontal distance from the current position to the point to be staked orthogonal to the right of the orientation direction.
LEFT	Horizontal distance from the current position to the point to be staked orthogonal to the left of the orientation direction.
CUT	The negative height difference from the height of the current position to the height of the point to be staked. To move down.
FILL	The positive height difference from the height of the current position to the height of the point to be staked. To move up.
D Ht	The design height, which is the orthometric height of the point to be staked, is displayed. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed. Changing the value for D Ht changes the values displayed for CUT and FILL.
3DCQ	Available for code and phase fixed solutions. The current 3D coordinate quality of the computed position.

Field	Description of Field
PDOP	Available for autonomous solutions. The current PDOP of the autonomous solution.

33.5

Staking to a Polyline

Description

The reference line task **Staking to Polyline** allows points to be staked relative to a polyline. This option makes use of line and area data from CAD as simple as possible.

Preparing the data

Line data can be created by one of the following methods:

Method	Description
Data from CAD	Selecting the polylines in the drawing that you want to stake in the field and saving them into a DXF file.
Measuring lines in the field	It is also possible to create the lines to be staked by measuring points in the field. Lines can be made using the linework commands in the Survey page. Also, taking measurements with line objects open or line codes can create lines.
Using Design to Field	Using the Design to Field tool of LEICA Geo Office, the user has the ability to bring in lines from multitudes of formats including XML, DXF, Microstation XML and many more. Refer to LGO Online Help for information on Design to Field.
Using Alignment Tool Kit	Using the ATK application, a simple centerline alignment can be created and be imported in Staking to Polyline .  Only straight and curve elements are supported. The alignment created with the ATK application has to be converted to a RoadRunner Job.
Creating Lines in LGO	It is possible as well to create the necessary lines in LGO. Refer to LGO Online Help.

Options to convert the DXF file to a job

To facilitate the electronic transfer of lines from the plans to the surveying instrument, different tools have been created to read DXF format into a System1200 job.


DXF Import: Copy the DXF files to the \data directory on the CompactFlash card of the CS09 controller. Once the card is back in the controller the DXF import program can be used to bring the lines into the job. Refer to "Importing Data to a Job".

Design to Field: This module is included in LEICA Geo Office and allows the conversion of DXF files into a System1200 job. This method makes the task of transferring several lines into a single job quick and efficient.



Refer to "Appendix C Directory Structure of the Memory Device" for the placements of the data files on the CompactFlash card.

Diagram
Basic rules for polyline
stakeout




- P1 BOP - Beginning of project
- P2 PC - Beginning of curve
- P3 RP - Radius point
- P4 PT - End of curve
- P5 PI - Point of intersection
- P6 AP - Angle point
- P7 EOP - End of project
- P1' BOP - Beginning of project
- P2' PC - Beginning of curve
- P3' PI - Point of intersection
- P4' PT - End of curve
- P5' AP-B - Angle point, back tangent
- P6' BP - Bisected point
- P7' AP-F - Angle point, forward tangent
- P8' EOP - End of project

General terms:

- Curve - Curve segment
- Extension - Line extension
- MCP - Mid curve point
- Straight - Straight segment

Step 1) Choosing the Polyline

The **Lines/Areas** page allows for a tabular selection of a polyline. Lines can be either 2D or 3D depending on the input data and are shown as such.



CONT (F1)

To select the highlighted polyline and to continue with the subsequent screen.

EDIT (F2)

To change the start or end chainage value of the selected line. If Strt Chainage is edited then the End Chainage is computed from the new input plus the length.

IMPRT (F5)


To import lines or Road objects from another job as long as the coordinate systems are compatible.

PAGE (F6)

To change to another page on this screen.

**Step 2)
Defining operating
parameters**

Operating parameters are defined on this page. This screen contains the **Parameters** page, the **Coords** page and the **Map** page. The explanations for the softkeys are valid for all three pages. Refer to "28 Understanding MapView" for information on the functionality and softkeys available.



CONT (F1)

To accept the parameters and to continue with the subsequent screen.

PREV (F4)

To decrease the chainage value, down chainage, by the defined chainage interval Chainage Inc..

NEXT (F5)

To increase the chainage value, up chainage, by the defined chainage interval Chainage Inc..

PAGE (F6)

To change to another page on this screen.

SHIFT BOP (F4)

To return the chainage value to the beginning of the project.

SHIFT EOP (F5)


To send the chainage value to the end of project.

Field	Description of Field
Line Name	Output. The name of the selected polyline.

Field	Description of Field
Strt Chainage	Output. The beginning chainage of the line.  The start chainage can be edited from REFLINE Choose Poly-line with EDIT (F2) .
Length	Output. The length of the line.
End Chainage	Output. The chainage of the end of the line.
Chainage	User input. The chainage to be staked initially. Any chainage can be entered.
Offset	User input. The distance to stake off the line. Any value between -2000 m and 2000 m can be entered.
Vert. Shift	User input. To shift the line vertically. The best example of the use of this feature is a situation where all grades of the line are finish grade but the stakes are set referenced to sub-grade.
Chainage Inc.	User input. The interval at which chainages will be staked. Incrementing begins from Chainage set above.

Step 3) Staking the points, Stake page

The explanations for the softkeys given below are valid for all pages.



OCUPY (F1)

To start measuring the point being staked. The position mode icon changes to the static icon. **(F1)** changes to **STOP**.

STOP (F1)

To end measuring the point being staked. When Auto STOP=Yes in **CONFIGURE Point Occupation Settings**, recording of positions ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. **(F1)** changes to **STORE**.

STORE (F1)

To store the measured point. When Auto STORE=Yes in **CONFIGURE Point Occupation Settings**, the measured point is stored automatically. **(F1)** changes to **OCUPY**.

3DCQ (F2) / ELEV (F2)

To change between the current 3D coordinate quality of the computed position or the current PDOP of the autonomous solution and the design height.

REVRS (F3)

To reverse the graphical display top to bottom. A reversed graphical display can be used when the point to be staked lies behind the current position.

PREV (F4)

To decrease the chainage value, down chainage, by the defined chainage interval Chainage Inc..

NEXT (F5)

To increase the chainage value, up chainage, by the defined chainage interval Chainage Inc..

PAGE (F6)

To change to another page on this screen.

SHIFT CONF (F2)

To configure reference line. Refer to "33.6 Configuring the Program".

Field	Description of Field
First line on screen	User input. The point ID of the point to be staked. Editable.
hA	User input. The default antenna height as defined in the active configuration set is suggested.
Third line on screen	User input. The current chainage to be staked. Editable.
FORW	Output. The horizontal distance from the current position to the point to be staked in the direction of the orientation. ↓ or ↑ to move towards the chainage depending on the selection for Visual Guides in REFLINE Configuration, General page.
BACK	Output. The horizontal distance from the current position to the point to be staked in the reverse direction of the orientation. ↑ or ↓ to move away from the chainage depending on the selection for Visual Guides in REFLINE Configuration, General page.

Field	Description of Field
RGHT	Output. Horizontal distance from the current position to the point to be staked orthogonal to the right of the orientation direction. → to move to the right of the line defined in Visual Guides , ← to move to the left of the line defined in Visual Guides .
LEFT	Output. Horizontal distance from the current position to the point to be staked orthogonal to the left of the orientation direction. ← to move to the left of the line defined in Visual Guides , → to move to the right of the line defined in Visual Guides .
CUT	Output. The negative height difference from the height of the current position to the height of the point to be staked. Move down.
FILL	Output. The positive height difference from the height of the current position to the height of the point to be staked. Move up.
ΔHt	Output. Displays the difference between the height of the current position and the height to be staked.
Ht	The orthometric height of the current position is displayed. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed.


Step 4)
Staking the points,
Details page

This page shows a live version of more information regarding the staked point.

Field	Description of Field
Design Sta	User input. Current chainage to be staked. Editable.
Design Offset	User input. Current offset being staked. Editable.

Field	Description of Field
Design Ht	User input. The design height, which is the orthometric height of the point to be staked, is displayed. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed.

**Step 5)
Results**



CONT (F1)

To return to **REFLINE Stakeout**.

+ELEV (F3)

To add a vertical offset to the design height and to display the new height.

PAGE (F6)

To change to another page on this screen.




Field	Description of Field
Point ID	Output. The point ID of the point staked.

Field	Description of Field
Code	<p>User input.</p> <p>With codelist: Select a code from the choicelist. Only point codes are available for selection. <None> to store a point without code or to perform Linework without coding.</p> <p>Without codelist: Type in a code. ----- to store a point without code or to perform Linework without coding.</p>
Meas Chainage	Output. The chainage measured at the staked point.
Meas Offset	Output. The offset from the polyline measured at the staked point.
Design Ht	Output. Allows input of the design height of the target point. The suggested value for the Design Ht is as configured in the Heights field in REFLINE Configuration, Heights page.
Meas Ht	Output. The height measured at the staked point.

33.6

Configuring the Program

Configuring orientation



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to another page on the screen.

SHIFT ABOUT (F5)


To display information about the application program name, the version number, the date of the version, the copyright and the article number.



Field	Description of Field
Orientate	<ul style="list-style-type: none">• The reference direction to be used to stakeout points. The stakeout elements and the graphical display shown in the Reference Line application program are based on this selection.• To North. The North direction shown in the graphical display based on the active coordinate system.• To Sun. The position of the sun calculated from the current position, the time and the date.• To Last Point. Time wise the last recorded point. If no points are yet staked, Orientate: To North is used for the first point to be staked.

Field	Description of Field
	<ul style="list-style-type: none"> • To Point(Stake). A point from Control Job selected in REFLINE Reference Line/Arc Begin. • To Point(Store). A point from Job selected in REFLINE Reference Line/Arc Begin. • To Line/Arc. The direction of the orientation is parallel to the reference line or the reference arc. • To Arrow. The direction of the orientation is from the current position to the point to be staked. The graphical display shows an arrow pointing in the direction of the point to be staked.
To	<ul style="list-style-type: none"> • To select the point to be used for orientation. Available for Orientate=To Point(Stake) and Orientate=To Point(Store).

Configuring the checks



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)


To change to another page on the screen.

SHIFT ABOUT (F5)

To display information about the application program name, the version number, the date of the version, the copyright and the article number.

Field	Description of Field
Pos Check	<ul style="list-style-type: none"> • Yes or No. Allows a check to be made on the horizontal coordinate difference between the manually occupied staked point and the point to be staked. If the defined Pos Limit is exceeded, the stakeout can be repeated, skipped or stored.
Pos Limit	<ul style="list-style-type: none"> • User input. Available for Pos Check=Yes. Sets the maximum horizontal coordinate difference which is accepted in the position check.
Height Check	<ul style="list-style-type: none"> • Yes or No. Allows a check to be made on the vertical difference between the manually occupied staked point and the point to be staked. If the defined Height Limit is exceeded, the stakeout can be repeated, skipped or stored.
Height Limit	<ul style="list-style-type: none"> • User input. Available for Height Check=Yes. Sets the maximum vertical difference accepted in the height check.
Beep near Pt	<ul style="list-style-type: none"> • Yes or No. The CS09 beeps when the horizontal radial distance from the current position to the point to be staked is equal to or less than defined in Dist from Pt.
Dist from Pt	<ul style="list-style-type: none"> • User input. Available for Beep near Pt=Yes. The horizontal radial distance from the current position to the point to be staked when a beep should be heard.

Configuring polyline



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to another page on the screen.

SHIFT ABOUT (F5)

To display information about the application program name, the version number, the date of the version, the copyright and the article number.



Field	Description of Field
Stake Points	<ul style="list-style-type: none"> • Choicelist. Sets the type of horizontal points to be staked. Refer to "33.5 Staking to a Polyline" for a graphic and an explanation of the abbreviations. • PC, PT, AP. Only these horizontal key points are calculated for staking, skipping the radius and midpoints of arcs and the angle bisector point on lines. • PC, PT, AP, BP. Only these horizontal key points are calculated for staking, skipping the radius point and midpoint of all arcs. • PC, PT, AP, RP, MCP. Only these horizontal key points are calculated for staking, skipping the angle bisector point. • All. All horizontal key points are available for stakeout. Refer to "33.5 Staking to a Polyline" for a list of all keypoints.

Field	Description of Field
Auto Increment	<ul style="list-style-type: none"> • Sets behaviour of the chainage after a point is stored. • <None>. Does not change the chainage after a point is stored. • Previous. Proceeds to the next key point down chainage after each stored staked point. • Next. Proceeds to the next key point up chainage after each stored staked point.
Ref. Tangent	<ul style="list-style-type: none"> • Back or Forward. Sets the tangent to be used when staking items in void areas.
Show Results	<ul style="list-style-type: none"> • Yes or No. To show or hide the results.

34

Working with Setup Reference

34.1

An Overview of the Program


Description

Setup Reference is a program to configure GS09 as a reference station. After completing the program, the reference station is operating and CS09 switches to rover mode and can be used for all rover applications.

34.2

Starting the Program

Access



Starting the program



CONT (F1)

To accept the screen entries and continue.

DATA (F5)

To view, edit and delete points stored with the job.

CSYS (F6)

To select a different coordinate system.
Not available for Use Auto CrdSys=Yes configured in **CONFIGURE Additional Rover Settings**.



Field	Description of Field
Job	The active job.
Coord System	The coordinate system currently attached to the selected Job. Cannot be edited for Use Auto CrdSys=Yes configured in CONFIGURE Additional Rover Settings .
Codelist	Chocelist. No codes are stored in the selected Job. Output. Codes have already been stored in the selected Job. If codes had been copied from a System RAM codelist, then the name of the codelist is displayed. If codes have not been copied from a System RAM codelist but typed in manually, then the name of the active job is displayed.

34.3

Using the Program

Step 1)
selecting the antenna



```
Antenna      : GS09 Tripod
ID Address   :      12f307dc36
Device       :      #164005 GS09
```

CONT (F1)

To accept the screen entries and continue.

SRCH (F4)

To search for all available Bluetooth devices. If more than one Bluetooth device is found a list of available devices is provided.



Field	Description of Field
Antenna	Antennas in the CS09 System RAM.
ID Address	The type of antenna to be used. This is fixed.
Device	The ID address of the GS09 to be used. This is fixed.

Step 2)
setting the
radio channel



Radio Type : Satelline 3AS
 Channel : 11
 Actual Freq : 433.8000 MHz

CONT (F1)

To accept the screen entries and continue.

SCAN (F5)

To scan for the radio at the reference.



Field	Description of Field
Radio Type	<ul style="list-style-type: none"> The type of radio. Depending on the radio attached to the CS09, the Radio type will be switched automatically: <ul style="list-style-type: none"> • IFR-300L • IFR300 • Intuicom 1200 DL • PacificCrest PDL • Satelline 3AS • TFR300
Channel	<ul style="list-style-type: none"> The radio channel. The channel used must be within minimum and maximum allowed input values. The minimum and maximum allowed input values for a radio depend on the number of channels supported by the radio and the spacing between the channels. Type in the radio channel.

Step 3)
selecting the
reference point

Field	Description of Field
Actual Freq	<ul style="list-style-type: none"> The actual frequency of the radio.

CONT (F1)

To accept the screen entries and continue.

COORD (F2)

To view other coordinate types.

LAST (F3)

To use the same coordinates as when the receiver was last used as a reference.

HERE (F4)

To use the coordinates of the current navigated position.

Field	Description of Field
Point ID	The point ID for the reference point. When setting the reference point for the setup, the selected point must be able to be viewed as WGS84 coordinates.
Antenna Ht	The antenna height at the reference point.

Step 4)
completing the setup



Point ID : 0001

Antenna Ht : 1.58 m

Time at Point: 00:00:07



FNSH (F1)

To continue.

Field	Description of Field
Point ID	The point ID for the reference point.
Antenna Ht	The antenna height at the reference point.
Time at Point	The time from when the point is occupied until point occupation is stopped.
GDOP	The current GDOP of the computed position.

Press **FNSH (F1)** to stop occupation and store the reference point.

35

Working with Stakeout

35.1

An Overview of the Program


Description

Stakeout is a program used to place marks in the field at predetermined points. These predetermined points are the points to be staked. The points to be staked must exist in a job on the CF card. The points may:

- already exist in a job on CS09.
- have been uploaded to a job on CS09 using LGO.
- have been uploaded from an ASCII file to a job on CS09.

A staked point can be manually occupied as a check.

Diagram



- P0 Current position
- P1 Point to be staked
- d1 Stake out distance
- d2 Height difference between current position and point to be staked
- α Stake out direction

Stakeout mode

Points are staked in orthogonal mode.

Coordinate system

Points cannot be staked if the active coordinate system is different to that in which the points to be staked are stored. For example, the points to be staked are stored with local coordinates and the active coordinate system is WGS 1984.

Point types

It is possible to stake:

- Position only points.
 - Height only points.
 - Points with full sets of coordinates.
-

Height source

Heights can be taken into account from:

- the vertical component of a coordinate triplet.
 - a Digital Terrain Model.
-


35.2

Starting the Program

Access



A) starting the program



CONT (F1)

To accept the screen entries and continue.

CONF (F2)

To configure the program.

DATA (F5)

To view, edit and delete points stored with the job.

CSYS (F6)

To select a different coordinate system.
Not available for Use Auto CrdSys=Yes configured in **CONFIGURE Additional Rover Settings**.



Field	Description of Field
Stakeout Job	The job containing the points to be staked.
Job	The active job. Points which are occupied after staking out are stored in this job. The original points to be staked are not copied to this job.
Coord System	The coordinate system currently attached to the selected Job. Cannot be edited for Use Auto CrdSys=Yes configured in CONFIGURE Additional Rover Settings .
Codelist	No codes are stored in the selected Job.

Field	Description of Field
	Codes have already been stored in the selected Job. If codes had been copied from a System RAM codelist, then the name of the codelist is displayed. If codes have not been copied from a System RAM codelist but typed in manually, then the name of the active job is displayed.

B) selecting the task



CONT (F1)

To accept the screen entries and continue.

SHIFT CONF (F2)

To configure the program.



Field	Description Of Field
Stakeout Task	<ul style="list-style-type: none"> • Points Only. The positions and heights of points in the selected Stakeout Job are staked out. No DTM file is used. • Points & DTM. The positions of points in the selected Stakeout Job are staked out. Heights to be staked are taken from DTM Job.

Field	Description Of Field
	<ul style="list-style-type: none"> • DTM only. Activates the stakeout of heights without positions. Heights relative to the selected DTM Job are staked out.
DTM Job	<ul style="list-style-type: none"> • Available for Stakeout Task=Points & DTM and Stakeout Task=DTM only. To select a DTM to be staked and to select the active DTM layer to be used. Heights are then staked out relative to the selected DTM.

The next step

IF the stakeout is	THEN
to stake points	select Stakeout Task=Points Only and press CONT (F1) .
to stake a DTM	select Stakeout Task=DTM Only, select a DTM Job, press CONT (F1) .

35.3


Staking the Points

Description

The stakeout elements are a horizontal distance forwards/backwards, a horizontal distance right/left and a cut/fill. The values are calculated from the current position to the point to be staked.


Diagram

The diagram shows an example for stake out in orthogonal mode with Orientate: To North.



- P0 Current position
- P1 Point to be staked
- d1 FORW or BACK
- d2 RGHT or LEFT
- d3 FILL or CUT

Staking the points



OCUPY (F1)

To start measuring the point being staked. The position mode icon changes to the static icon. **(F1)** changes to **STOP**. The difference between the current position and the point being staked is still displayed.

STOP (F1)

To end measuring the point being staked. When Auto STOP: Yes in CONFIGURE Point Occupation Settings, the measurement ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. **(F1)** changes to **STORE**. After ending the measurements, the differences between the measured point and the point to be staked are displayed.

STORE (F1)

To store the measured point. When Auto STORE: Yes in CONFIGURE Point Occupation Settings, the measured point is stored automatically. **(F1)** changes to **OCUPY**.

NEAR (F2)

To search Stakeout Job for the point nearest to the current position when the key is pressed. The point is selected as the point to be staked and is displayed in the first field on the screen. After staking and storing the nearest point, the next point suggested for staking out is the one which was suggested before the key was pressed. Available when **OCUPY (F1)** is displayed.

REVRS (F3)

To reverse the graphical display top to bottom. A reversed graphical display can be used when the point to be staked lies behind the current position.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure the Stakeout application program. Available for **OCUPY (F1)** being displayed.

SHIFT QUIT (F6)

To exit Stakeout application program. Available for **OCUPY (F1)** being displayed.

Field	Description of Field
First field on the screen	The point ID of the point to be staked. Accesses STAKEOUT Data: Job Name where points are shown according to sort and filter settings and staked points are indicated by the staked out symbol  .
hA	The default antenna height is suggested. The changed antenna height is used until the application program is exited.
FORW	The horizontal distance from the current position to the point to be staked in the direction of the orientation.
BACK	The horizontal distance from the current position to the point to be staked in the reverse direction of the orientation.
RGHT	Horizontal distance from the current position to the point to be staked orthogonal to the right of the orientation direction.

Field	Description of Field
LEFT	Horizontal distance from the current position to the point to be staked orthogonal to the left of the orientation direction.
CUT	The negative height difference from the height of the current position to the height of the point to be staked. To move down.
FILL	The positive height difference from the height of the current position to the height of the point to be staked. To move up.
D Ht	The design height, which is the orthometric height of the point to be staked, is displayed. If the orthometric height cannot be displayed, the local ellipsoidal height is displayed. If it is not possible to display the local ellipsoidal height, the WGS 1984 height is displayed. Changing the value for D Ht changes the values displayed for CUT and FILL.
3DCQ	Available for code and phase fixed solutions. The current 3D coordinate quality of the computed position.
PDOP	Available for autonomous solutions or if no solution is available. The current PDOP of the autonomous solution.


35.4

Staking the Digital Terrain Model (DTM)


Description

- With the Stakeout program a Digital Terrain Model can be staked. The heights of the current positions are compared against those of a selected DTM job. The height differences are calculated and displayed.
- Staking a DTM may be used for:
 - staking out where the DTM represents the surface to be staked.
 - quality control purposes where the DTM represents the final project surface.
- DTM jobs are created in LGO. DTM jobs are stored in the \DBX directory of the CF card.

Diagram



Staking the digital terrain model



OCUPY (F1)

To start measuring the height. The position mode icon changes to the static icon. (F1) changes to **STOP**.

STOP (F1)

To end measuring the height. When Auto STOP: Yes in CONFIGURE Point Occupation Settings, the measurement ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. (F1) changes to **STORE**.

STORE (F1)

To store the measured point. When Auto STORE: Yes in CONFIGURE Point Occupation Settings, the measured point is stored automatically. (F1) changes to **OCUPY**.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure the Stakeout application program. Available for **OCUPY (F1)** being displayed.

SHIFT QUIT (F6)

To exit Stakeout application program. Available for **OCUPY (F1)** being displayed.

Field	Description of Field
First field on the screen	The point ID of the point to be staked.
hA	The default antenna height is suggested. The changed antenna height is used until the application program is exited.
CUT	The negative height differences from the current position to the equivalent point in the selected DTM job is calculated and displayed. To move down.
FILL	The positive height differences from the current position to the equivalent point in the selected DTM job is calculated and displayed. To move up.
D Ht	The design height, which is the height of the DTM is displayed. Changing the value for D Ht changes the values displayed for CUT and FILL.
3DCQ	Available for code and phase fixed solutions. The current 3D coordinate quality of the computed position.
PDOP	Available for autonomous solutions or if no solution is available. The current PDOP of the autonomous solution.


35.5

Understanding the Stakeout Icons in MapView

Description

A graphical display provides a guide to find the point to be staked out. The elements of the graphical display used within the Stakeout application program screens are explained in this chapter. Some of the elements depend on the selection for Orientate in STAKEOUT Configuration, General page. Other elements are commonly displayed. The Map page provides an interactive display of the data.

Elements of the graphical display




Graphical display


If the antenna is too far away and the scale is >1000 m, the antenna is not shown and the point to be staked circle is grey.

For orthogonal stakeout


Standard graphical display



For scale 0.5 m




Reversed graphical display




For DTM stakeout

Standard graphical display




For scale 0.5 m



35.6

Configuring the Program

Configuring orientation



CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to another page on the screen.

SHIFT ABOUT (F5)

To display information about the application program name, the version number, the date of the version, the copyright and the article number.



Field	Description of Field
Orientate	<ul style="list-style-type: none">• The reference direction to be used to stakeout points. The stakeout elements and the graphical display shown in the Stakeout application program are based on this selection.• To North. The North direction shown in the graphical display based on the active coordinate system.• To Sun. The position of the sun calculated from the current position, the time and the date.• To Last Point. Time wise the last recorded point. If no points are yet staked, Orientate=To North is used for the first point to be staked.

Field	Description of Field
	<ul style="list-style-type: none"> • To Point(Stake). A point from Stakeout Job selected in STAKEOUT Stakeout Begin. • To Point(Store). A point from Job selected in STAKEOUT Stakeout Begin. • To Arrow. The direction of the orientation is from the current position to the point to be staked. The graphical display shows an arrow pointing in the direction of the point to be staked.
To	<ul style="list-style-type: none"> • To select the point to be used for orientation. Available for Orientate=To Point(Stake) and Orientate=To Point(Store).
Closest Point	<ul style="list-style-type: none"> • The order of the points suggested for staking out. • Yes. After staking and storing a point, the next point suggested for staking out is the point closest to the point which was staked. If there are many points in Stakeout Job, the search may take a few seconds. • No. After staking and storing one point, the next point suggested for staking out is the subsequent one in Stakeout Job.

Configuring the checks

17:39 STAKEOUT

Configuration

General Checks

Pos Check : Yes

Pos Limit : 0.020 m

Height Check : Yes

Height Limit : 0.020 m

Beep near Pt : Yes

Dist from Pt : 0.500 m

CONT PAGE

CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to another page on the screen.

SHIFT ABOUT (F5)

To display information about the application program name, the version number, the date of the version, the copyright and the article number.

Field	Description of Field
Pos Check	<ul style="list-style-type: none"> Yes or No. Allows a check to be made on the horizontal coordinate difference between the manually occupied staked point and the point to be staked. If the defined Pos Limit is exceeded, the stakeout can be repeated, skipped or stored.
Pos Limit	<ul style="list-style-type: none"> User input. Available for Pos Check=Yes. Sets the maximum horizontal coordinate difference which is accepted in the position check.
Height Check	<ul style="list-style-type: none"> Yes or No. Allows a check to be made on the vertical difference between the manually occupied staked point and the point to be staked. If the defined Height Limit is exceeded, the stakeout can be repeated, skipped or stored.
Height Limit	<ul style="list-style-type: none"> User input. Available for Height Check=Yes. Sets the maximum vertical difference accepted in the height check.

Field	Description of Field
Beep near Pt	<ul style="list-style-type: none">• Yes or No. The CS09 beeps when the horizontal radial distance from the current position to the point to be staked is equal to or less than defined in Dist from Pt.
Dist from Pt	<ul style="list-style-type: none">• User input. Available for Beep near Pt=Yes. The horizontal radial distance from the current position to the point to be staked when a beep should be heard.

36

Working with Survey


36.1

Starting the Program

Access



Starting the program



CONT (F1)

To accept the screen entries and continue.

CONF (F2)

To configure SmartCodes and auto points measurements.

DATA (F5)

To view, edit and delete points stored with the job.

CSYS (F6)

To select a different coordinate system. Not available for Use Auto CrdSys=Yes configured in **CONFIGURE Additional Rover Settings**.



Field	Description of Field
Job	The active job.
Coord System	The coordinate system currently attached to the selected Job. Cannot be edited for Use Auto CrdSys=Yes configured in CONFIGURE Additional Rover Settings .
Codelist	Choicelist. No codes are stored in the selected Job.

Field	Description of Field
	Output. Codes have already been stored in the selected Job. If codes had been copied from a System RAM codelist, then the name of the codelist is displayed. If codes have not been copied from a System RAM codelist but typed in manually, then the name of the active job is displayed.

The next step

IF the survey is	THEN
to survey points	press CONT (F1) and proceed to the Survey page.
to survey auto points	press CONT (F1) and proceed to the Auto page.



The arrow at the real-time device and real-time status icon flashes when real-time messages are being received.



Fixing ambiguity begins. The current position status is indicated by the position status icon. When working with code only corrections, an ambiguity solution is not attempted.



The position mode icon is the moving icon. This indicates that the antenna can be moved around and that no static observations are being recorded.

36.2

Surveying the Points

Surveying points

10:23
SURVEY
Survey: My 1st job
Survey Auto Map
Point ID : 0001
Antenna Ht : 2.00 m
Code : <None>
3D CQ : 0.01 m
OCUPY H PNT PAGE

OCUPY (F1)

To start measuring a point. The position mode icon changes to the static icon. (F1) changes to **STOP**.

STOP (F1)

To end measuring a point when enough data is collected. When Auto STOP: Yes in CONFIGURE Point Occupation Settings, the measurement ends automatically as defined by the stop criteria. The position mode icon changes to the moving icon. (F1) changes to **STORE**.

STORE (F1)

To store the point information. When Auto STORE: Yes in CONFIGURE Point Occupation Settings, the measured point is stored automatically. (F1) changes to **OCUPY**.

PAGE (F6)

To change to another page on the screen.


SHIFT CONF (F2)

To configure SmartCodes and auto points measurements.

Field	Description of Field
Point ID	The identifier for occupied points.
Antenna Ht	The antenna height

Field	Description of Field
3D CQ	The current 3D coordinate quality of the computed position.

Surveying points using SmartCodes



OCUPY (F1)

To start measuring a point. For **Measure Point: Yes** in SURVEY Survey: Job name, SCode page, tapping the code box with the supplied stylus automatically starts measuring the point. The highlighted code is stored with the point.

STOP (F1)

To end measuring a point when enough data is collected.

STORE (F1)

To store the point information.

CODES (F3)

To select a code from MANAGE Select Code panel and to assign it to the highlighted code box.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure SmartCodes and auto points measurements.

**Measuring lines/ares
using Code Blocks step-
by-step**

Field	Description of Field
Code Block	List of up to nine code boxes with assigned codes.

Step	Description
1.	Activate Show Info: Linework in SURVEY Configuration, SCode page.
2.	Go to SURVEY Survey: Job Name, SCode page.
3.	CODES (F3) to create a code block for lines/areas. Return to SURVEY Survey: Job Name, SCode page.
	The line/area is opened and closed using the SmartCode.
4.	To start an arc/spline move the focus on Linework:, the last line of the page, and select the linework flag to be stored with the point.
5.	Move the focus on the line/area code box.
6.	ALL (F1) to measure and store the point with the highlighted line/area code.

36.3

Surveying the Auto Points

Description

Auto points is used to automatically log points at a specific rate. Auto points are used in real-time moving applications to document the track which was walked or driven along. Auto points are logged between starting and stopping logging of auto points form one chain. A new chain is formed each time logging of auto points is started. Auto points can be collected in the Survey program.

Surveying auto points

17:29
SURVEY
Survey: Active job
Survey Auto Map
Auto Pt ID : Auto0009
Code (Auto) : Tree
Code Desc : single tree
Msd Auto Pts : 6
3D CQ : 0.010 m
STOP PAGE

Before logging of auto points has started, the default page appears as shown:

START (F1)

To start logging of auto points and offset points if configured or, for Log By: User Decides, to start the chain to which the auto points should be assigned. The first auto point is stored.

STOP (F1)

To end recording of auto points and offset points if configured or, for Log By: User Decides, to end the chain to which the auto points are assigned.

OCCUPY (F3)

Available for **STOP (F1)**. To store an auto point at any time.

PAGE (F6)

To change to another page on the screen.

SHIFT CONF (F2)

To configure auto points.

SHIFT QUIT (F6)

To exit the Survey application program.

Field	Description of Field
Auto Pt ID	The identifier for auto points. The ID can be changed. To start a new sequence of point ID's typeover the point ID.
Code (Auto)	<p>The thematical code for the auto point.</p> <p>Choicelist. Available for Thematc Codes: With Codelist. The attributes are shown as output, input or choicelist fields depending on their definition.</p> <p>User input. Available for Thematc Codes: Without Codelist. Codes can be typed in but not selected from a codelist. A check is performed to see if a code of this name already exists in the job. If so, the according attributes are shown.</p>
Code Desc	The description of the code.
Msd Auto Pts	Available after pressing START (F1) . The number of auto points logged since START (F1) has been pressed.
3D CQ	The current 3D coordinate quality of the computed position.

36.4

Configuring the Program - SmartCodes

Configuring Smart-Codes

17:26 SURVEY

Configuration

SCode Auto Points

Use SCodes : Yes

Show Info : Not used

Measure Point: Yes

String Attrib: 1

Method : Zig-Zag

Direction : Forward

No. Elements : 9

a ↑

CONT PAGE

CONT (F1)

To accept the screen entries and continue.

PAGE (F6)

To change to another page on the screen.


Field	Description of Field
Use SCodes	<ul style="list-style-type: none"> Yes. Activates using of SmartCodes. All other fields on the screen are active and can be edited. No. Deactivates using of SmartCodes and all fields on this screen.
Show Info	<ul style="list-style-type: none"> Information shown in line 8 of SURVEY Survey: Job name, SCode page. Not used. No display mask element is shown. Point ID, 3D CQ, 2D CQ, 1D CQ, Antenna Ht or Linework. Display mask element that is shown in line 8 of SURVEY Survey: Job name, SCode page.

Field	Description of Field
Measure Point	<ul style="list-style-type: none"> • Yes or No. If one of the code boxes is tapped in SURVEY Survey: Job name, SCode page then that code is selected and the point is measured for Measure Point: Yes.
String Attrib	<ul style="list-style-type: none"> • Choicelist. Available for Show Codes: All Codes. When this field is active, surveyed points that have the same code attached are strung to one line.
Method	<ul style="list-style-type: none"> • Method by which subsequent code box is selected after a point is stored. • Not used. Direction and No. Elements are invisible and the number of codes boxes shown in SURVEY Survey: Job name, SCode page is nine. • Zig-Zag. Each new code block is selected at the same end as where the previous code block finished. • Same direction. Each new code block is selected at the same end as where the previous code block started.
Direction	<ul style="list-style-type: none"> • The way of using the code boxes. This influences in which order the code boxes will be applied. • Forward. The code boxes are used in the same way as defined in SURVEY Survey: Job name, SCode page. • Backward. The code boxes are used in the reverse way as defined in SURVEY Survey: Job name, SCode page.
No. Elements	<ul style="list-style-type: none"> • 1, 2, 3, 4, 5, 6, 7, 8 or 9. Number of code boxes shown in SURVEY Survey: Job name, SCode page.

36.5

Configuring the Program - Setting the Logging Method

Setting
the logging method



CONT (F1)

To accept the screen entries and continue.

DMASK (F3)

To configure what is viewed in the Auto page in the Survey application program.




Field	Description of Field
Log By	<ul style="list-style-type: none">• Time. Auto points are logged according to a time interval. The time interval is independent from the update interval for the position on the screen.• Distance. The difference in distance from the last stored auto point, which must be reached before the next auto point is logged. The auto point is logged with the next available computed position.• Stop & Go. An auto point is stored when the position of the antenna does not move more than the distance configured in Stop Position within the Stop Time.

Field	Description of Field
	<ul style="list-style-type: none"> Once a point has been stored, the position from the point just stored must change more than the distance configured in Stop Position before the routine starts again.
Log Every	<ul style="list-style-type: none"> User input. For Log By=Distance. The difference in distance before the next auto point is logged. For Log By=Time from 1.0s to 60.0s. The time interval before the next auto point is logged.
Stop Position	<ul style="list-style-type: none"> Available for Log By=Stop & Go. The maximum distance within which the position is considered stationary.
Stop Time	<ul style="list-style-type: none"> Available for Log By=Stop & Go. The time while the position must be stationary until an auto point is stored.

36.6

Configuring the Program - Setting the Display Mask

Setting
the display mask



CONT (F1)

To accept the screen entries and continue.

CLEAR (F4)

To clear all the fields except the first field.

DEFLT (F5)

To recall the default settings.

Field	Description of Field
Fixed Lines	<ul style="list-style-type: none"> From 0 to 5. Defines how many lines do not scroll in the screen.
1st Line to 16th Line	<ul style="list-style-type: none"> For each line one of the following options can be selected. <ul style="list-style-type: none"> Attrib (free) 01-04. Output field for attributes for free codes. Attrib 01-03. Input field for attributes for codes. Code (auto). Choicelist or input field for codes. Code (free). Output field for free codes. Code Desc. Output field for description of codes. Code Desc (free). Output field for description of free codes. Code Type. Output field for the type of code.

Field	Description of Field
	<ul style="list-style-type: none"> • GDOP. Output field for current GDOP of the computed position. • HDOP. Output field for current HDOP of the computed position. • Line Space Full. Insert full line space. • Line Space Half. Insert half line space. • Moving Ant Ht. Input field for antenna height for moving observations. • Msd Auto Points. Output field for the number of auto points logged after pressing START (F1). Counting starts again from 0 when START (F1) pressed again. • PDOP. Output field for current PDOP of the computed position. • Quality 1D. Output field for current height coordinate quality of computed position. • Quality 2D. Output field for current 2D coordinate quality of computed position. • Quality 3D. Output field for current 3D coordinate quality of computed position. • VDOP. Output field for current VDOP of the computed position.

37

37.1

Description

Working with Survey - Hidden points

Overview

Hidden points cannot be measured directly by GPS. This is because they can not be physically reached or because satellites are obstructed, for example by trees or tall buildings.

- A hidden point can be calculated by measuring distances and/or azimuths to the hidden point.
- Additional auxiliary points may be manually occupied.
- Bearings may be computed from previously occupied points.

In contrast to the COGO application program, hidden point measurements is more of a measuring application program than a calculation application program.

Example

Application:

Completing a survey of telegraph poles for a telecommunication company.

Aim:

The telegraph poles must be surveyed to 0.3 m accuracy in plan but height is not of concern.

Use of hidden point measurements:

For poles surrounded by heavy undergrowth where it is not possible to directly measure the pole without taking a lot of time to cut a path through the undergrowth.



Changing coordinates of a point which has been previously used in hidden point measurements does not result in the hidden point being recomputed.



Hidden point measurements are possible for R-Time Mode=Rover and R-Time Mode=None. For R-Time Mode=None the hidden point can be calculated in LGO.

Hidden point measurement methods

A hidden point can be measured by

- Bearing and distance
 - Double bearing
 - Double distance
 - Chainage and offset
 - Backwards bearing and distance
 -
-

Magnetic declination

Any magnetic declination configured for Mag Declin in CONFIGURE Units & Formats, Angle page is applied when the hidden points are computed. The azimuth must be entered manually or it must be measured with a hidden point measurements device.

Heights

Heights are taken into account if configured. Refer to "37.6 Configuring the Program" for information on configuring height offsets.

Coding of hidden points

- Thematical coding: Available in HIDDEN PT Hidden Point Result after the calculation of a hidden point. Thematical coding of hidden points is identical to coding of manually occupied points. Refer to "3 Managing, Creating, Editing Codes/Codelists" for information on coding.
 - Free coding: Can be started while in HIDDEN PT Hidden Point Measurement. The code and attributes of the last entered free code in the active job is displayed. It cannot be changed.
 - Quick coding: Not available.
-

Averaging of hidden points

An average is calculated for hidden points if a point of class **MEAS** already exists with the same point ID.



Azimuth is used throughout this chapter. This should always be considered to also mean Bearing.

Auxiliary points

Auxiliary points are used to compute azimuths required for the calculation of hidden point coordinates. Auxiliary points can be points existing in the job or they can be manually occupied.

37.2

Starting the Program



Hidden point measurements are possible from the Survey application program and when the Survey application program screen is called from another application program, for example from Stakeout.

Access




37.3

Measuring Hidden Points

Starting

Refer to "37.2 Starting the Program" to access **HIDDEN PT Hidden Point Measurement**.

Diagram of hidden points measurement method 1, Brng & Distance



Known

P0 Known point, Point

To be measured

d Distance from P0 to P2

α Bearing from P0 to P2

P1 Auxiliary point, optional

Unknown

P2 Hidden point

Measuring a hidden point with Bearing & Distance





Diagram of hidden points measurement method 2, Double Bearing



Known

P0 First known point, Point A:

P3 Second known point, Point B:

To be measured

α_1 Bearing from P0 to P2

α_2 Bearing from P3 to P2

P1 First auxiliary point, optional

P4 Second auxiliary point, optional


Unknown

P2 Hidden point

Measuring a hidden point with Double Bearing

17:27	+	7	6=7	Σ=7	Bluetooth	GPS	Windows
HIDDEN PT							
Hidden Point Measurement							
Method	:	Double Bearing					
Point A	:	PT20					
Azimuth	:	15.0000 g					
ΔHeight	:	1.250 m					
Point B	:	PT21					
Azimuth	:	35.1234 g					
ΔHeight	:	0.750 m					
CALC							a ↑

Diagram of hidden points measurement method 3, Double Distance



GS09_TR_026

Known

P0 First known point, Point A:

P2 Second known point, Point B:

d3 Line from P0 to P2

a Right of d3

b Left of d3

To be measured

d1 Distance from P0 to P1

d2 Distance from P2 to P1


Unknown

P1 Hidden point

Measuring a hidden point with Double Distance

17:28	Σ= 7	7	6= 7	Bluetooth	GPS
HIDDEN PT					
Hidden Point Measurement					
Method	:	Double Distance			
Point A	:	PT20			
Horiz Dist	:	5.000 m			
ΔHeight	:	1.250 m			
Point B	:	PT21			
Horiz Dist	:	8.000 m			
ΔHeight	:	0.750 m			
Location	:	Right of Line AB			
					a ↑
CALC					

Diagram of hidden points measurement method 4, Chainage & Offset



GS09_TR_027

Known

P0 First known point, Point A:

P1 Second known point, Point B:

To be measured

d1 Chainage

d2 Offset


Unknown

P2 Hidden point

Measuring a hidden point with Chainage & Offset

17:28	+	7	Σ=7	7	G=7	Bluetooth	GPS
HIDDEN PT							
Hidden Point Measurement							
Method	:	Chainage & Offset					
Point A	:	PT20					
ΔHeight	:	1.250 m					
Point B	:	PT21					
ΔHeight	:	0.750 m					
Chainage	:	0.000 m					
Offset	:	0.000 m					
Location	:	Right of Line AB					
Chainage From:	:	Point A					
							a ↑
CALC			POS?				

Diagram of hidden points measurement method 5, Back Brng & Dist



- Known
- P0 Known point, Point
- To be measured
- d Distance from P0 to P2
- α Bearing from P0 to P2
- P1 Auxiliary point, optional
- Unknown
- P2 Hidden point

Measuring a hidden point with Back Brng & Distance

17:25
 HIDDEN PT Σ= 7
G= 7

Hidden Point Measurement

Method	:	Back Brng & Dist
Point	:	PT20
Azimuth	:	15.0000 g
Horiz Dist	:	1.200 m
ΔHeight	:	1.250 m

CALC a ↑

Description of all softkeys

Softkey	Description of Softkey
CALC (F1)	To calculate the hidden point and to display the results.
SUN (F3)	When Azimuth is highlighted. The azimuth from the direction of the sun to Point is computed.
SLOPE (F5)	When Horiz Dist is highlighted. To measure a slope distance and an elevation angle or percentage grade. The values are used to compute the horizontal distance.
SURVY (F5)	To manually occupy the known point for the calculation of the hidden point.
AZMTH (F4)	When Azimuth is highlighted. To select or manually occupy an auxiliary point and to compute the azimuth.
SHIFT CONF (F2)	To configure hidden point measurements.
SHIFT QUIT (F6)	To not store the hidden point and to return to the screen from where HIDDEN PT Hidden Point Measurement was accessed.

Description of all input fields

Field	Description of Field
Method	Choicelist. The hidden point measurement method. Refer to "37.6 Configuring the Program".
Point	The point ID of the current position. This is the known point for the calculation of the hidden point.
Point A	The point ID of the current position. This is the first known point for the calculation of the hidden point.
Point B	The point ID of the current position. This is the second known point for the calculation of the hidden point.

Field	Description of Field
Azimuth	The azimuth from Point to the hidden point.
Horiz Dist	The horizontal distance from Point to the hidden point.
ΔHeight	The positive or negative height difference between the centre of the hidden point measurement device and the target point. For hidden point measurement methods using two known points, Δ Height must be determined from each known point. Δ Height can also be computed using SLOPE (F5) .
Chainage	The chainage from one known point along the line between the two known points. Looking from the point selected in Chainage From, a positive chainage is towards the second known point. A negative chainage is into the opposite direction of the second known point.
Offset	The offset of the hidden point to the line between the two known points.
Location	The location of the hidden point relative to the line from Point A to Point B.
Chainage from	The point from where the chainage has been measured.

37.4

37.4.1

Computing an Azimuth

Using the Sun


Starting

Refer to "37.2 Starting the Program" to access HIDDEN PT Hidden Point Measurement. For Method=Brng & Distance, Method=Double Bearing or Method=Back Brng & Dist highlight Azimuth.


Description

The azimuth for a hidden point measurement can be computed using a known point and the sun. The known point can be manually occupied. The location of the hidden point can be away from the sun or in the direction towards the sun. Ensure the shadow of the pole falls in the direction of the point.

Diagram



Computing an azimuth using the sun



Description of softkeys

Softkey	Description of Softkey
CALC (F1)	To calculate the hidden point and to display the results.
SUN (F3)	When Azimuth is highlighted. The azimuth from the direction of the sun to Point is computed.
AZMTH (F4)	When Azimuth is highlighted. To select or manually occupy an auxiliary point and to compute the azimuth.
TOWRD (F4)	Available after pressing SUN (F3) . To be pressed when the hidden point is in the direction towards the sun.
AWAY (F6)	Available after pressing SUN (F3) . Is the hidden point in the direction towards the sun.

37.4.2

Using Auxiliary Point

Starting

Refer to "37.2 Starting the Program" to access HIDDEN PT Hidden Point Measurement. For Method=Brng & Distance, Method=Double Bearing or Method=Back Brng & Dist press **AZMTH (F4)** when Azimuth is highlighted to access **HIDDEN PT Choose Azimuth Point**.


Description

The azimuth for a hidden point measurement can be computed using an auxiliary point. The auxiliary point

- may already exist in the job.
- may be manually occupied during the hidden point measurements.
- may be manually typed in.

The location of the auxiliary point can be in the direction towards the hidden point or away from the hidden point.


Diagram



P0 Known point
 P1 Auxiliary point, Azimuth Pt
 P2 Hidden point
 α Bearing from P2 to P0

P0 Known point
 P1 Auxiliary point, Azimuth Pt
 P2 Hidden point
 α Bearing from P0 to P2

Choosing Azimuth Point



CONT (F1)

To accept changes and return to the screen from where this screen was accessed. The azimuth is computed and displayed in Azimuth in **HIDDEN PT Hidden Point Measurement**.

SURVY (F5)

Available for Azimuth Pt being highlighted. To manually occupy the auxiliary point for the calculation of the azimuth.



Field	Description of Field
Azimuth Pt	Choicelist. The auxiliary point for the calculation of the azimuth. All points from MANAGE Data: Job Name can be selected.
Direction	Choicelist. The location of the auxiliary point relative to the hidden point.


37.5

Computing Horizontal Distances from Slope Distances


Description

The horizontal distance for a hidden point measurement can be computed using a slope distance, and an elevation angle or percentage grade. The slope distance and the elevation angle can either be typed in or measured with a hidden point measurement device.

Diagram



Computing horizontal distances from slope distances



CONT (F1)

To access **HIDDEN PT Hidden Point Measurement**.



Computing horizontal distances from slope distances step-by-step

Field	Description of Field
Slope Distance	User input. Type in a distance from the known point to the hidden point.
Elev Angle	User input. Type in the elevation angle from the known point to the hidden point.
Grade (%)	The grade from the known point to the hidden point is automatically computed from the slope distance and the elevation angle. The value for Grade (%) can be typed in instead of the value for Elev Angle. Then Elev Angle is computed automatically.
Horiz Dist	The horizontal distance from the known point to the hidden point is automatically computed from the slope distance and the elevation angle.
ΔHeight	Available if using heights is configured. The height difference between the known point and the hidden point is automatically computed from the slope distance and the elevation angle.

37.6

Configuring the Program

Configuring

17:22
HIDDEN PT

Configuration

Deflt Method : **Brng & Distance**

Est Pos Qty : 0.300 m

Compute Ht : Yes

Est Ht Qty : 0.300 m

CONT (F1)

To accept the screen entries and continue.

SHIFT ABOUT (F5)

To display information about the program name, the version number, the date of the version, the copyright and the article number.

CONT [] [] [] [] a ↑

Field	Description of Field
Deflt Method	<p>Choicelist. The hidden point measurement method.</p> <p>Brng & Distance. The distance and the bearing from the known point to the hidden point are to be determined. An auxiliary point helps compute the bearing which might not be known. The auxiliary point may be measured in the direction from the known point to the hidden point.</p> <p>Double Bearing. The bearings from the known points to the hidden point are to be determined. Auxiliary points help compute the bearings which might not be known. Auxiliary points may be measured in the direction from the known point to the hidden point.</p>


Field	Description of Field
	<p>Double Distance. The distances from the known points to the hidden point are to be determined. The location of the hidden point relative to the line between the two known points is to be defined.</p> <p>Chainage & Offset. The chainage from one known point along the line between the two known points must be determined. The offset of the hidden point to the line between the two known points must be determined.</p> <p>Back Brng & Dist. The distance and the bearing from the hidden point to the known point are to be determined. An auxiliary point helps compute the bearing which might not be known. An auxiliary point may be measured in the direction from the hidden point to the known point.</p>
Est Pos Qlty	User input. The estimated value for the position quality assigned to all calculated points which is used for the averaging calculation.
Compute Ht	Yes or No. To include the height in hidden point measurements.
Est Ht Qlty	User input. The estimated value for the height quality assigned to all calculated heights which is used for the averaging calculation.


Appendix A

Menu Tree

Menu tree

MAIN MENU





|-- TOOLS...

- FORMAT
- TRANSFER...
 - CODELISTS
 - CONFIGURATION SETS
 - COORDINATE SYSTEMS
 - GEOID FIELD FILES
 - CSCS FIELD FILES
 - FORMAT FILES
 - SYSTEM RAM CONTENTS
 - MODEM/GSM STATIONS
 - IP HOSTS
 - ANTENNA RECORDS
 - PZ-90-TRANSFORMATION
 - FIELD TO OFFICE
- SYSTEM...
 - APPLICATION PROGRAMS
 - SYSTEM LANGUAGES
 - INSTRUMENT FIRMWARE
- CALC

- VIEW
 - LICENCE
-

Appendix B

Memory Types

Types of memory available

CF card:

- Jobs
 - Points
 - Codes
- Coordinate systems
- ASCII output files
- Logfiles
- ASCII files to be imported
- CSCS field files
- Geoid field files

The information is managed in the job database DB-X and in the measurement database.

Application programs memory, 8 MB

- System language
- Font files
- Application programs
 - Language files
 - Font files

System RAM, 1 MB

- Codelists
- Coordinate systems
- Antenna files
- Format files
- CSCS models/CSCS field files
- Geoid models/Geoid field files
- Almanac

Appendix C

Directory Structure of the Memory Device

Description

On the CF card, files are stored in certain directories.

Directory structure

---	CODE	<ul style="list-style-type: none">• Codelists, various files		
---	CONFIG	<ul style="list-style-type: none">• Configuration files (filename.xfg)		
---	CONVERT	<ul style="list-style-type: none">• Format files (filename.frt)		
---	DATA	<ul style="list-style-type: none">• ASCII files for import/export to/from job (filename.*)• DXF files for import/export to/from job (filename.dxf)• Logfiles created from application programs		
	---	GPS	<ul style="list-style-type: none">• Almanac file (Almanac.sys)	
		---	CSCS	<ul style="list-style-type: none">• CSCS field files (filename.csc)
		---	GEOID	<ul style="list-style-type: none">• Geoid field files (filename.gem)
---	DBX	<ul style="list-style-type: none">• Job files, various files• GNSS raw observation files• Coordinate system file (Trfset.dat)		
---	Download	<ul style="list-style-type: none">• Various files, downloaded by Field to Office application (*.*)		

-- GPS	<ul style="list-style-type: none">• Antenna file (List.ant)
-- GSI	<ul style="list-style-type: none">• GSI files (filename.gsi)• ASCII files for export from job (filename.*)
-- SYSTEM	<ul style="list-style-type: none">• Application program files (filename.a*)• Firmware files (filename.fw)• Language files (filename.s*)• Licence file (filename.key)• System files (System.ram)

Appendix D

Pin Assignments and Sockets

D.1

CS09

Description

Some applications require knowledge of the pin assignments for the CS09 port. In this chapter, the pin assignments and socket for the port of the CS09 are explained.

Pin assignments for 8 pin LEMO-1

Pin	Name	Description	Direction
1	USB_D+	USB data line	In or out
2	USB_D-	USB data line	In or out
3	GND	Signal ground	-
4	RxD	RS232, receive data	In
5	TxD	RS232, transmit data	Out
6	ID	Identification pin	In or out
7	PWR	Power input, 5 -28 V	In
8	GPI	RS232, general purpose signal	In

Sockets

8 pin LEMO-1: LEMO-1, 8 pin, LEMO HMI.1B.308.CLNP


D.2

GS09

Description

Some applications require knowledge of the pin assignments for the GS09 port. In this chapter, the pin assignments and socket for the port of the GS09 are explained.

Port at the GS09



GS09_TR_007

a) 8 pin LEMO-1 to connect cable to CS09

Pin assignments for 8 pin LEMO-1

Pin	Name	Description	Direction
1	USB_D+	USB data line	In or out
2	USB_D-	USB data line	In or out
3	GND	Signal ground	-
4	RxD	RS232, receive data	In
5	TxD	RS232, transmit data	Out
6	ID	Identification pin	In or out
7	PWR	Power input, 5 -28 V	In
8	ATX_ON	ATX on control signal, RS232 levels	In

Sockets

8 pin LEMO-1:

LEMO-1, 8 pin, LEMO HMI.1B.308.CLNP

Appendix E

Cables

Description

Some applications require the connection of instruments, devices or accessories to the CS09. In this chapter, the required cables and their use are listed.

Cables connecting instruments, devices or accessories

The table shows in alphabetical order which instruments, devices or accessories can be connected using cables. Refer to paragraph "Cables and product names" for a full description of these cables.

From	To	Cables
GEB171	CS09	• GEV97
	GS09	• GEV215
	GS09 and GFU	• GEV205
Power supply for GS09, 12 V DC	GS09 and CS09	• GEV215
RS232 9 pin on PC	CS09	• GEV162
CS09	GS09	• GEV237
USB on PC	CS09	• GEV234

Cables and product names

The product names of the cables in the above table are explained in detail below in ascending order.

Name	Description
GEV97	Cable 1.8 m, GX power cable
GEV162	Cable 2.8 m, data transfer GX RX to RS232
GEV205	Y-cable 1.8 m, GS09 to GEB171 and GFU, for GS09 reference station
GEV215	Y-cable, GS09 to CS09 and GEB171

Name	Description
GEV234	Cable 1.65 m, data transfer CS09 to USB
GEV237	Cable 1.65 m, GS09 to CS09

Index

A

Add point to line	32
ADJ, class	38
Almanac file, directory	370
Almanac.sys	370
Angle, display format	162
Antenna	
Set default height	106
Antenna file, directory	371
Application program file, directory	371
Application programs memory	369
Application programs memory, formatting	182
Arc, reference	274
Area	
Create	28
Delete	19
Edit	31
Filters	36
Sorting	36
Arrow, orientate to	
Reference Line	303
ASCII	
Export format	93
Import format	100
ASCII file	
Directory for import/export to/from job	370
ASCII files, directory	371

Attribute

Description	59
Type in new	53
Attribute type	60
Attribute value region	60
Attribute value type	60
Auxiliary points	
Azimuth computation	358
Hidden point measurements	347
Averaging	
Hidden points	346
AVGE, class	38
Azimuth, compute	
Hidden point measurements	356
Azimuth/bearing fields	164

B

Battery, status	219
Bearing/azimuth fields	164

C

Cables	375
Cassini projection	79
Class	38
Classification of points, hierarchy	38
Code	
Create	53
Description	57

Edit	53	Default	65
Free	57, 58	Edit	248
Point	58	Recall deleted system	67
SmartCodes	335, 339	RTCM	65
Thematical	57	Turn into user defined default	67
Code type	53, 58	Coordinate system file, directory	370
Codelist		Coordinate system management, access	66
Description	61	Coordinate triplet	38
Directory	370	Country Specific Coordinate System models	89
Elements	61	CQ	44
Job	62	Create	
System RAM	62	Area	28
Codes		Code	53
Manage	51	Codelist	50
Manage job codes	55	Coordinate system	68
Coding		CSCS models	87
Hidden points	346	Ellipsoid	76
COGO		Geoid model	86
Arc Calculations	227	Line	28
Intersections	226	Point	21
Inverse	226	Projection	81
Line Calculations	227	Transformation	72
Configuration file, directory	370	CS09	
Contrast, screen	158	Control key beep	159
Control points	247	Exchange	157
Coordinate quality	44	csc file	87
Coordinate system		CSCS field file	87
Active	65	Directory	370
Create	68	CSCS model	87

Create	87
Description	89
Types	89
CTRL, class	38
Current position, status	217
Cut off angle	156
D	
Data	17
Preparing for staking polylines	291
Data export	
Directory	95
Data format, Leica, RTCM, CMR/CMR+	123, 215
Data format, real-time	127
Data management	
Access	17
Database	369
DB-X	369
Default, recall	
Auto points, display mask settings	343
Coordinate system	67
Display mask settings	112
Ellipsoid	75
Projection	78
Delete	
Code	52
Codelist	49
Coordinate system	66
Ellipsoid	75
Format file	

Data export	95
From Data Log	35
Geoid model	85
Job	12
Matched points	252
Point	18, 19
Projection	78
Transformation	71
Delete point from Resection	271
Directory structure of memory device	370
Distribution	
Residuals throughout transformation area	267
DMASK	339, 341
Double Stereographic projection	80
DTM layer, select	318
DXF	101
Export format	93
DXF file	
Directory for import/export to/from job	370
E	
Edit	
Area	31
Codelist	50
Coordinate system	248
Job	15
Line	31
Point	24
Elevation mask	156
Ellipsoid	

Create	76
Delete	75
Edit	76
Recall deleted default	75
Ellipsoid management, access	74
Ellipsoidal height	88
Ellipsoids	74
End date	32
End time	32
EST, class	39
Exceeded limit	
Coordinate quality	110
Height	
Reference Line	304, 330
Position	
Reference Line	304, 330
Expiry date, software maintenance	221
Export format	93
F	
Field file	
CSCS	87
Geoid	83
FILT	18, 19
Filter	36
Filter symbol	37
Firmware file, directory	371
Firmware, version	221
Format	
Export	93

Import	100
Format file	
Directory	370
Export ASCII	93
Free code	57, 58
Delete	35

G

gem file	83
Geoid field file	83
Directory	370
Geoid model	83
Create from CF card	86
Delete	85
Description	88
Management, access	84
View	85
Geoid separation	88
Geoid, height above	88
GNSS raw observation files, directory	370
Graph, showing satellites	211
GS09 firmware, upload	191
GSI file, directory	371
GS16	100
GS18	100

H

Heating, screen	158
Height	
Ellipsoidal	88

Geoid	88	Job codelist	62
Levelled	88	Job file, directory	370
Mean sea level	88	K	
Orthometric	88	Keyboard, illumination	158
Height filter	127	L	
Height mode	73	Lambert 1 Parallel projection	79
Hidden points	345	Lambert 2 Parallel projection	79
Averaging	346	LandXML	
Coding	346	Export format	94
Measure	349	Language file, directory	371
Hot keys		Last point, orientate to	
Description	207	Reference Line	302
I		Layer, DTM, select	318
Identification number	117	Leica data format	123
Illumination		Levelled height	88
Keyboard	158	LGO	
Screen	157	Creation	
Import, format	100	Attributes	60
Increasing NE, SE, SW, NW	164	Codes	58
Instrument source	43	CSCS field files	87
Interface, Configure	125	DTM jobs	323
Internet, Interface	142	Geoid field files	83
J		Download	
Job		Coordinate systems	63
Active	13	Jobs	12
Create	14	Upload	
Default	12	Codelist to CS09	47
Edit	15	Coordinate systems	63

Jobs	12	Scale bar	204
Licence file, directory	371	Screen area	204
Line		Softkeys	203
Create	28	Symbol rover	204
Delete	19	Toolbar	205
Edit	31	Symbol	204
Filters	36	MATCH	252, 271
Length	31	Match points	
Orientate to, Reference Line	303	Determine Coordinate System	252
Reference	274	MAX	132
Sorting	36	Mean sea level, height	88
Line style		MEAS, class	39
New line	29	Memory	
Line style, coding	53	Directory structure	370
Linework	53	Format	182
Local		Status	219
Date	120	Memory types	369
Time	120	Menu tree	365
Logfile		Mercator projection	79
Directory	370	Mode, Calculator	171
M		Molodensky-Badekas	73
MapView		MountPoint	153
Access	198	N	
Configure	199	NAV, class	39
Mode	197	Next available point ID	334
North arrow	204	North, orientate to	
Overview	197	Reference Line	302
Point symbols	206	NTRIP	145
Point with focus, symbol	204	Number of satellites, used in solution	213

O	
Oblique Mercator projection	79
Onestep transformation	243
Orientate	
Reference Line	302
Orthometric height	88
OWI commands, status	221
P	
Pin assignment	372
Point	
Add to line	32
Auto	337
Auxiliary	347
Azimuth computation	358
Create	21
Delete	18, 35
Delete from line	32
Edit	24
Filters	36
Orientate to	
Reference Line	303
Sorting	36
Point code	58
Point ID, next available	334
Point symbols, MapView	206
Polar Stereographic projection	80
Polyline	
Preparing data	291
ppm, transformation results	255
Prediction	
Advantages	136
Recommended settings	136
PREV	154
PRN	210
PROGS	182
Projection	
Cassini	79
Create	81
Delete	78
Double Stereographic	80
Edit	81
Lambert 1 Parallel	79
Lambert 2 Parallel	79
Mercator	79
Oblique Mercator	79
Polar Stereographic	80
Recall deleted default	78
RSO	80
Transverse Mercator	79
UTM	79
Projection management, access	77
Projections	77
Properties	
Hidden points	346
Protected option	
5 Hz update rate	168
5 km RTK range	168
Bluetooth functionality	168

Extended OWI messages	168
GLONASS	168
Raw data logging	169
RTCM/CMR data input	169
RTK network access	168
Unlimited RTK range	168
Protected program	
DTM Stakeout	168
Reference Line	168
RoadRunner	168
Volume Calculations	168
PZ90	185
Q	
Quadrant	164
R	
Real-time, status	213
Recall	
ASCII import settings	102
Default	
Auto points, display mask settings	343
Display mask settings	112
Deleted default	
Coordinate system	67
Ellipsoid	75
Projection	78
Rectified Skewed Orthomorphic projection	80
REF, class	38
Residual	

Distribution throughout transformation area	267
RMS	45
Root Mean Square	45
Rotate, MapView	201
RPN mode	171
RSO projection	80
S	
S/N	210
Satellite Settings	
GPS & GLONASS	155
GPS L2C	156
GPS only	155
Satellites	
Number used in solution	213
Settings	155
Status	210
Scale, transformation results	255
Screen	
Contrast	158
Heating	158
Illumination	157
Select DTM layer	318
Serial number	221
SET-D	
Coordinate system	67
Ellipsoid	75
Projection	78
Transformation	71
Signal to noise ratio	210

Single Point Position	206	Survey	
Skyplot	211	Hidden points	345
Slope		Symbols, for points in MapView	206
Distance		System file, directory	371
Hidden point measurements	360	System information, status	221
Slot number	210	System language	
SmartCodes	339	Upload	191
Configuring	339	System RAM	369
Surveying points	335	Codelist	62
Smoothing heights	127	SYSTEM	182
Socket	372	T	
Soldner Cassini projection	79	Text	160
Sort settings, define	18, 19	Thematical code	57
Sorting	36	Transformation	
Source	40	Create	72
SPP	206	Delete	71
SRCE	134	Description	243
Standard deviation	44	Edit	72
Standard mode	171	Requirements	243, 247
Start date	31	Transformation management, access	70
Start time	31	Transformation model	73
STAT	209	Transformation parameters	243
Status		Transformations	70
OWI commands	221	Transverse Mercator projection	79
Sub class	39	Triplet	38
Sun		Type in new attribute	53
Azimuth computation	356	U	
Sun, orientate to		Universal Transverse Mercator projection	79
Reference Line	302		

Update coordinate system	248
UTM projection	79

V

Various files

Directory for Field to Office application	370
Versions of system firmware	221

View

Geoid model	85
Points and free codes stored in job	18

W

WGS 1984	65
----------------	----

Z

Zoom	203
Softkey	203
Window	205
αNUM	160

Total Quality Management - Our commitment to total customer satisfaction.



Leica Geosystems AG, Heerbrugg, Switzerland, has been certified as being equipped with a quality system which meets the International Standards of Quality Management and Quality Systems (ISO standard 9001) and Environmental Management Systems (ISO standard 14001).

Ask your local Leica Geosystems dealer for more information about our TQM program.

Leica Geosystems AG
Heinrich-Wild-Strasse
CH-9435 Heerbrugg
Switzerland
Phone +41 71 727 31 31
www.leica-geosystems.com

- when it has to be **right**

Leica
Geosystems

773078-1.0.0en
Original text
Printed in Switzerland
© 2009 Leica Geosystems AG, Heerbrugg, Switzerland