



EMG-1560IN



Mixer Grinder



www.elektaindia.com

Please read the guidelines provided in this User Manual on Important Instructions, Appliance Usage & Warranty before using the product.

Contents

Introduction	2
General description and technical specifications	2
Important instructions	3 - 4
Using the product How to fit the blades How to fit jar to base unit	4 - 5
Operation Before the first use Preparation for use	5
Cleaning and maintenance	6
Overload protection	6
Maximum jar capacities	6
Trouble shooting	7 - 8
Recommended blades	9
Warranty and service	10
Warranty card	10


Introduction

ELEKTA brings to you a range of mixer grinder with high quality steel jars. Please note accessories for your model. EMG-1560IN - wet, dry and chutney jar.

General description

- 1. Base unit:** the motor, speed switch, mains cord and overload protector switch.
- 2. Speed selector knob:** for different speed adjustment.
- 3. Overload Protection Switch:** *
- 4. Anti slip rubber feet**
- 5. 1.5 litre Wet grinding jar:** for liquidizing and blending.
- 6. 1.0 litre Dry grinding jar:** for dry grinding.
- 7. 0.4 litre Chutney grinding jar:** for small quantity grinding such as chutney, pepper, dry masala.
- 8. Wet grinding blade:** detachable.
- 9. Dry grinding blade:** detachable.
- 10. Chutney grinding blade:** detachable.
- 11. Spatula:** to clean sides of jars from inside and use as a spanner for blades.

Technical specifications
Model No. : EMG-1560IN
Voltage: 220-240V~50/60Hz
Wattage: 600W max.




* red coloured switch located below the base of the unit


Important instructions

We recommend that you read the following instructions carefully before using the appliance.


1. Check if the voltage indicated on the base of the appliance, corresponds to the local electrical mains voltage before connecting the appliance.



2. Do not use the appliance when the mains cord, the plug or other components are damaged. Only the company or a service centre authorized by ELEKTA must replace it.




3. Always unplug the appliance after use.




4. Never immerse the motor unit in water.




5. Always unplug the appliance before reaching into the jar with your fingers or an object e.g. spatula.



6. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.




7. Always ensure that speed selector knob is at 'Off' before fixing accessories.




8. Do not operate the mixer without the lid in place or with an empty jar.




9. Handle the blades carefully wash them under running water and do not rub by hand.



10. Do not use mixer on wet surface.



11. KEEP mixer away from hot gas burner, electric hot plate or similar appliances.



12. This appliance is strictly for household use.

13. Do not drop the main unit or jars.

14. Never use accessories or parts not recommended by ELEKTA or those made by other manufacturers, else the warranty will become invalid.


15. Do not use the jars as storage containers.

16. Do not leave unit unattended while in operation.


17. It is not advisable to run the mixer continuously for more than 30 minutes.

Using the product.


1. How to fit the blades Hold the coupler on the underside of the jar and with the spanner; tighten by rotating in anti-clockwise direction till the blade is securely locked. Repeat procedure for the other jars.



2. How to fit jar to base unit,
After fitting the blades, carefully insert jar on top of the base unit. Ensure that lock of the jar fits the slot of the base unit. Rotate the jar clockwise until it locks.




Check speed selector knob is at 'Off'
Connect mains plug to wall socket after fixing jar. Switch on main supply Turn speed selector to required position and speed. After operation, turn selector knob to 'Off ' and check. Repeat till desired results are obtained.



Operation

1. Before the first use thoroughly clean parts that come in contact with food.


2. Preparation for use Cool the hot ingredients before putting in jar.



Cut large ingredients into small pieces of approx 2cm before processing.




For blending /liquidizing/pureeing, use 'pulse' on speed knob. This will activate the whipping till you release the button.




Cleaning and maintenance

1. Remove main plug from wall socket. Do not immerse base unit in water.
2. Wipe base unit with a damp cloth and non-abrasive liquid cleaner.
3. Disassemble other parts after use. Wash them in soapy water, rinse with clean water and dry thoroughly. Do not wash in a dishwasher. Cleaning is easiest done immediately after use.
4. Take soapy water in jar and assemble it on base unit. Pulse 5-6 times and wash the jar.
5. Store mixer grinder standing on its heel in a safe and dry place.



Overload protection



Mixer is fitted with an automatic power shut off mechanism to avoid motor burning due to overloading. If mixer stops due to overloading, the red knob at the bottom will come out. Switch off the mixer. Remove excess load from jar wait for 2-3 minutes. Press red button and start mixer again.



Maximum jar capacities

No.	Type of jar	capacity	Wet capacity (rated) Max.	Dry capacity (rated) Max.
1	Wet grinding jar	1.5L	0.5L	0.7L
2	Dry grinding jar	1.0L	0.4L	0.5L
3	Chutney grinding jar	0.4L	0.2L	0.3L

Trouble shooting

No.	Problem	Cause	Solution
1	Appliance does not work.	No electricity supply 	Ensure that the plug is plugged well.
2	Appliance suddenly stops working while in use.	The appliance is equipped with an 'Over Load Protector'(OLP) switch. If appliance overheats, it automatically cuts off power supply.	Unplug appliance and let it cool for 2-3 minutes. Remove jar from base unit. At the bottom of base unit there is a red coloured switch (OLP). Reset OLP by pressing it Put plug back into wall socket and switch on appliance again (see heading 'Overload Protection').
3	Blade unit is blocked. 	The quantity being processed is probably too large.	Switch off appliance. Remove ingredients that are blocking the blade unit. Refer table on page 6 for the maximum capacity of jars.
4	Base unit gives an unpleasant smell during first few times of use.	This is normal for the first few times.	If appliance continues to smell after using a few times. Ensure that jars are clean and there are no ingredients stuck inside it. Ensure that appliance has been assembled correctly.

No.	Problem	Cause	Solution
5	Appliance makes a lot of noise.	Jar lid has not been properly placed. Jars have not been properly locked. Blade is loose.	Make sure lid has been properly and tightly locked. Make sure jar has been properly and tightly locked. Remove ingredient from jar and tighten the blade in anti-clockwise direction with spatula.
6	There are fumes from the appliance.	Appliance may have been used for too long.	Switch off appliance and let it cool for 60 minutes.
7	Unsatisfactory grinding/blending/mixing performance.	Incorrect jar selection. Ingredients overloading in jar. Large size of Ingredients. Chutney not grinding well	Use correct jar as per the application. Refer table on page 6 for the maximum capacity of jars. Cut ingredients into appropriate size. Inch 5-7 times to powder ingredients. Add water as required and grind on speed 3
8	Leakage from jar lid	Gasket has not been fit properly	Unplug appliance. Remove jar from base unit. Remove lid to check if gasket has been assembled correctly.

In case these measures do not work, contact the nearest Elekta Service Center or call at Toll free Number 18002702929.


Recommended blades

Stainless steel wet grinding blade




Best for wet grinding applications likes:
Tomato onion paste
Vegetable/ fruit puree
Rice and dal batter

Stainless steel dry grinding blade



Best for dry grinding applications likes:
Dry masalas, Rice and dal powder

Stainless steel chutney grinding blade (non-removable)



Best for making:
Chutneys and Pastas in small quantities-
Lesser quantities of masalas

For maximum jar capacity turn to page 6

Warranty and service

For any information or problem, contact your local ELEKTA dealer or authorized service center: For a list of authorized ELEKTA service centers visit: www.elektaindia.com or contact our Toll Free Number 18002702929 or mail us to customercareindia@elektagf.com

Warranty card

This apparatus is covered under warranty against any defect due to defective material or workmanship or TWO YEARS from the date of purchase. Should a defect develop during the period of warranty, ELEKTA undertakes to repair the apparatus FREE OF CHARGE through the dealer from whom it has been purchased or at any of the ELEKTA authorized Service Centres.

The warranty is not valid in case:

1. Apparatus is not used according to user manual.
2. Defects caused by improper or reckless use.
3. Repairs done by persons other than ELEKTA Authorized service centre.
4. Modifications of any nature made in the apparatus.
5. Tampered serial number.
6. Incomplete warranty card after purchase.
7. Product if used for commercial purpose (i.e. other than domestic use).
8. Usage of parts not recommended by ELEKTA or those made by other manufacturers.

All consumables and parts susceptible to normal wear and tear are not covered under warranty

Week/S.No.: _____

Date of purchase: _____

Dealer's name: _____

Dealer's stamp: _____

Customer's name and address: _____

Model No.: _____

Dealer's signature: _____