

# CubeSuite Ver.1.40

Integrated Development Environment

User's Manual: 78K0R Design

Target Device

78K0R Microcontroller

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

## Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
  - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

# How to Use This Manual

This manual describes the role of the CubeSuite integrated development environment for developing applications and systems for 78K0R microcontrollers, and provides an outline of its features.

CubeSuite is an integrated development environment (IDE) for 78K0R microcontrollers, integrating the necessary tools for the development phase of software (e.g. design, implementation, and debugging) into a single platform.

By providing an integrated environment, it is possible to perform all development using just this product, without the need to use many different tools separately.

**Readers** This manual is intended for users who wish to understand the functions of the CubeSuite and design software and hardware application systems.

**Purpose** This manual is intended to give users an understanding of the functions of the Cubesuite to use for reference in developing the hardware or software of systems using these devices.

**Organization** This manual can be broadly divided into the following units.

**CHAPTER 1 GENERAL**  
**CHAPTER 2 FUNCTIONS (Pin Configurator)**  
**CHAPTER 3 FUNCTIONS (Code Generator)**  
**APPENDIX A WINDOW REFERENCE**  
**APPENDIX B OUTPUT FILES**  
**APPENDIX C API FUNCTIONS**  
**APPENDIX D INDEX**

**How to Read This Manual** It is assumed that the readers of this manual have general knowledge of electricity, logic circuits, and microcontrollers.

**Conventions**

Data significance:	Higher digits on the left and lower digits on the right
Active low representation:	<u>XXX</u> (overscore over pin or signal name)
Note:	Footnote for item marked with Note in the text
Caution:	Information requiring particular attention
Remark:	Supplementary information
Numeric representation:	Decimal ... XXXX
	Hexadecimal ... 0xXXXX

**Related Documents**

The related documents indicated in this publication may include preliminary versions. However, preliminary versions are not marked as such.

Document Name		Document No.
CubeSuite	Start	R20UT0256E
Integrated Development Environment	Analysis	R20UT0265E
User's Manual	Programming	R20UT0266E
	Message	R20UT0267E
	Coding for CX compiler	R20UT0259E
	Build for CX compiler	R20UT0261E
	78K0 Coding	R20UT0004E
	78K0 Build	R20UT0005E
	78K0 Debug	R20UT0262E
	78K0 Design	R20UT0006E
	78K0R Coding	U19382E
	78K0R Build	U19385E
	78K0R Debug	R20UT0263E
	78K0R Design	This manual
	V850 Coding	U19383E
	V850 Build	U19386E
	V850 Debug	R20UT0264E
	V850 Design	R20UT0257E

**Caution** The related documents listed above are subject to change without notice. Be sure to use the latest edition of each document when designing.

All trademarks or registered trademarks in this document are the property of their respective owners.

[MEMO]

[MEMO]

[MEMO]

# TABLE OF CONTENTS

## CHAPTER 1 GENERAL ... 10

- 1.1 Overview ... 10
- 1.2 Features ... 10

## CHAPTER 2 FUNCTIONS (Pin Configurator) ... 11

- 2.1 Overview ... 11
- 2.2 Open Device Pin List Panel ... 13
  - 2.2.1 Select item ... 14
  - 2.2.2 Change display order ... 15
  - 2.2.3 Add column ... 16
  - 2.2.4 Delete column ... 17
- 2.3 Open Device Top View Panel ... 18
  - 2.3.1 Select shape of microcontroller ... 19
  - 2.3.2 Select color ... 20
  - 2.3.3 Select popup information ... 21
  - 2.3.4 Select additional information ... 22
- 2.4 Enter Information ... 23
- 2.5 Output Report Files ... 24
  - 2.5.1 Output device pin list ... 24
  - 2.5.2 Output device top view ... 25

## CHAPTER 3 FUNCTIONS (Code Generator) ... 26

- 3.1 Overview ... 26
- 3.2 Open Code Generator Panel ... 27
- 3.3 Enter Information ... 28
  - 3.3.1 Input rule ... 28
  - 3.3.2 Icon indicating incorrect entry ... 29
  - 3.3.3 Icon indicating pin conflict ... 30
- 3.4 Confirm Source Code ... 31
- 3.5 Output Source Code ... 32
  - 3.5.1 Setting that determines whether or not to generate source code ... 33
  - 3.5.2 Change file name ... 34
  - 3.5.3 Change API function name ... 35
  - 3.5.4 Change output mode ... 36
  - 3.5.5 Change output destination folder ... 37
- 3.6 Output Report Files ... 38
  - 3.6.1 Change output format ... 40
  - 3.6.2 Change output destination ... 41



## **APPENDIX A WINDOW REFERENCE ... 42**

**A.1 Description ... 42**

## **APPENDIX B OUTPUT FILES ... 108**

**B.1 Overview ... 108**

**B.2 Output File ... 108**

## **APPENDIX C API FUNCTIONS ... 114**

**C.1 Overview ... 114**

**C.2 Output Function ... 114**

**C.3 Function Reference ... 122**

**C.3.1 System ... 124**

**C.3.2 External Bus ... 135**

**C.3.3 Port ... 139**

**C.3.4 INT ... 146**

**C.3.5 Serial ... 157**

**C.3.6 Operational Amplifier ... 241**

**C.3.7 Comparator/PGA ... 246**

**C.3.8 A/D ... 254**

**C.3.9 D/A ... 267**

**C.3.10 Timer ... 276**

**C.3.11 Watchdog Timer ... 290**

**C.3.12 RTC ... 294**

**C.3.13 Clock Output ... 328**

**C.3.14 Clock Output/Buzzer Output ... 334**

**C.3.15 LCD Controller/Driver ... 341**

**C.3.16 DMA ... 348**

**C.3.17 LVI ... 358**

## **APPENDIX D INDEX ... 365**

## CHAPTER 1 GENERAL

CubeSuite is an integrated development environment used to carry out tasks such as design, coding, build and debug for developing application systems.

This chapter gives an overview of the design tool (Pin Configurator/Code Generator).

### 1.1 Overview

The design tool, which is one of the components provided by CubeSuite, enables you to output the pin assignment of the microcontroller (device pin list and device top view), and the source code (device driver programs, C source files and header files) necessary to control the peripheral functions provided by the microcontroller (clock generator, port functions, etc.) by configuring various information using the GUI.

### 1.2 Features

The design tool (Pin Configurator/Code Generator) has the following features.

- Code generating function

The Code Generator can output not only device driver programs in accordance with the information configured using the GUI, but also a build environment such as sample programs containing main functions and link directive files.

Source code output by Code Generator conforms to the MISRA-C (Guidelines for the Use of the C Language in Vehicle Based Software) coding convention.

- Reporting function

You can output configured information using Pin Configurator/Code Generator as files in various formats for use as design documents.

- Renaming function

The user can change default names assigned to the files output by Code Generator and the API functions contained in the source code.

---

**CHAPTER 2 FUNCTIONS (Pin Configurator)**

This chapter describes the key functions provided by the design tool (Pin Configurator) along with operation procedures.

**2.1 Overview**

The Pin Configurator is used to output report files such as a device pin list and a device top view by entering pin assignment information of the microcontroller.

The following sections describe the operation procedures for Pin Configurator.

**(1) Start CubeSuite**

Launch CubeSuite from the [Start] menu of Windows.

**Remark** See "CubeSuite Start User's Manual" for details on "Start CubeSuite".

**(2) Create/Open project**

Create a new project (that defines a kind of project, microcontroller to be used, build tools to be used, etc.) or load an existing project.

**Remark** See "CubeSuite Start User's Manual" for details on "Create/Open project".

**(3) Open Device Pin List Panel**

Open the [Device Pin List panel](#), where you enter information on the pins of the microcontroller.

**(a) Select item**

Allows you to select items displayed in the device pin list.

**(b) Change display order**

Allows you to change the order in which items are displayed in the device pin list.

**(c) Add column**

Allows you to add columns to the device pin list.

**(d) Delete column**

Allows you to delete columns from the device pin list.

**(4) Open Device Top View Panel**

Open the [Device Top View panel](#), where you can confirm the information entered for the pins.

**(a) Select shape of microcontroller**

Allows you to select the shape of the microcontroller displayed in the [Device Top View panel](#).

**(b) Select color**

Allows you to select colors used to distinguish the type of pins (power pins, special pins, used pins, etc.) whose information is displayed in the [Device Top View panel](#).

**(c) Select popup information**

Allows you to select the type of information that pops up when you move the mouse cursor over each pin in the [Device Top View panel](#).

**(d) Select additional information**

Select the type of information to display in Pin area of the [Device Top View panel](#).

**(5) Enter Information**

Enter information on the pins of the microcontroller in the [Device Pin List panel](#).

**(6) Output Report Files**

Output report files (files containing configured information using Pin Configurator: device pin list and device top view) to the specified folder.

**(a) Output device pin list**

Output a device pin list.

**(b) Output device top view**

Output a device top view.

**(7) Save project**

Save a project.


**Remark** See "CubeSuite Start User's Manual" for details on "Save project".

## 2.2 Open Device Pin List Panel

Open the [Device Pin List panel](#), where you enter information on the pins of the microcontroller.


To open the [Device Pin List panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List] in the [Project Tree panel](#).

Figure 2-1. Open Device Pin List Panel



- Remarks 1.** If an unsupported microcontroller is defined in the project for Pin Configurator, then "[Pin Configurator (Design Tool)] node" will hide under [*Project name* (Project)] in the [Project Tree panel](#).
- 2.** The [Device Pin List panel](#) consists of three tabs. Selecting one of the tabs changes the order in which "information on each pin of the microcontroller" is displayed.
- [\[Pin Number\] tab](#)  
Information on each pin of the microcontroller is displayed in the order of pin number.
  - [\[Macro\] tab](#)  
Information on each pin of the microcontroller is displayed in the order it was grouped into peripheral functions.
  - [\[External Peripheral\] tab](#)  
Information about the pins connected to external peripherals is displayed in order grouped at the external-peripheral component level.

2.2.1 Select item

The Pin Configurator is used to select items to be displayed in the device pin list using the  button in the upper left corner of the device pin list.



To select the item to be displayed, use the [Column Chooser dialog box](#) that opens by pressing the  button in the upper left corner of the device pin list.

Figure 2-2. Select Item



**Remark** To select the item to be displayed, check the check box that corresponds to the item.


Table 2-1. Select Item


Checked	Displays the selected item in the device pin list.
Not checked	Hides the selected item in the device pin list.

2.2.2 Change display order

In Pin Configurator, you can change the display order of columns in the device pin list (move columns) by dragging and dropping columns.

Figure 2-3. Change Display Order




**Remark** To change the display order, click the  button in the upper left of the device pin list. The [Column Chooser dialog box](#) opens. Drag an item displayed in the dialog's select Items to display area, and drop it to the desired destination in the device pin list. This will change the display order.

### 2.2.3 Add column

The Pin Configurator is used to add the "user's own column" to the device pin list using the [New Column] button in the [Column Chooser dialog box](#) that opens by pressing the  button in the upper left corner of the device pin list.

To add a column, use the [New Column dialog box](#) that opens by pressing the [New Column] button in the [Column Chooser dialog box](#).


Figure 2-4. Add Column



**Remark** On the device pin list, adding columns to the first level of [\[Macro\] tab](#), [\[External Peripheral\] tab](#) is restricted.




2.2.4 Delete column

The Pin Configurator is used to delete the "user's own column" from the device pin list using the [Delete Column] button in the [Column Chooser dialog box](#) that opens by pressing the  button in the upper left corner of the device pin list.

To delete a column, select the column you want to delete in the displayed item selection area of the [Column Chooser dialog box](#), and press the [Delete Column] button.

Figure 2-5. Delete Column




**Remark** You can only delete the column which you added using the [New Column dialog box](#).

2.3 Open Device Top View Panel

Open the [Device Top View panel](#), where you can confirm the information entered for the pins of the microcontroller.

To open the [Device Top View panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Top View] in the [Project Tree panel](#).

Figure 2-6. Open Device Top View Panel




**Remark** In the [Property panel](#), on the [[Pin Configurator Settings](#)] tab, if "BGA" is selected for the Package type, then [Device Top View panel](#) cannot be opened.

2.3.1 Select shape of microcontroller

Select the shape of the microcontroller displayed in the [Device Top View panel](#) which is opened as described in "2.3 Open Device Top View Panel".

To select the shape of the microcontroller, click [\[Pin Configurator Settings\] tab](#) >> [Package type] in the [Property panel](#) and select the desired shape.

Figure 2-7. Select Shape of Microcontroller




**Remark** Selection of the shape of the microcontroller is made using the order name (such as GC and GF).

2.3.2 Select color

Select the colors used to distinguish the type of pins (power pins, special pins, unused pins, etc.) whose information is displayed in the [Device Top View panel](#) which is opened as described in "2.3 Open Device Top View Panel".

To select the color to be displayed, select the desired color in the color palette that opens by clicking [[Device Top View Settings](#)] tab >> [Color] in the [Property panel](#).

Figure 2-8. Select Color



**Remark** Select the colors to be displayed for the following eight types of items.

Table 2-2. Select Color

Item	Outline
Power pins	Selects the display color for power pins (pins whose use is limited to power).
Special pins	Selects the display color for special pins (pins with specified uses).
Unused pins	Selects the display color for unused pins (dual-use pins with no use set in the <a href="#">Device Pin List panel</a> ).
Used pins	Selects the display color for used pins (dual-use pins with a use set in the <a href="#">Device Pin List panel</a> ).
Device	Selects the display color of the microcontroller.
Highlight	Selects the background color of a pin selected in the <a href="#">Device Pin List panel</a> , on the [ <a href="#">Pin Number</a> ] tab.
Macro highlight	Selects the background color of pins selected in the <a href="#">Device Pin List panel</a> , on the [ <a href="#">Macro</a> ] tab.


Item	Outline
External peripheral highlight	Selects the background color of pins selected in the <a href="#">Device Pin List panel</a> , on the <a href="#">[External Peripheral] tab</a> .

**2.3.3 Select popup information**

Select the type of information that pops up when you move the mouse cursor over each pin in the [Device Top View panel](#) which is opened as described in "2.3 [Open Device Top View Panel](#)".

To select the popup information, click [\[Device Top View Settings\] tab](#) >> [\[Tool tip\]](#) in the [Property panel](#) and select the desired type of information.

**Figure 2-9. Select Popup Information**



**Remark** Popup information is selected from the following four types.

**Table 2-3. Select Popup Information**


Popup Information	Outline
Display all	Displays the "Description", "Recommend Connection For Unused", and "Attention" strings for the device pin list.
Description / recommended connection for unused pin only	Displays the "Description", and "Recommend Connection For Unused" string for the device pin list.
Attention only	Displays the "Attention" string for the device pin list.
Not display	Hides tooltips when the mouse cursor hovers over a pin.

2.3.4 Select additional information

Select the type of information to display in Pin area, in the [Device Top View panel](#) opened in "2.3 Open Device Top View Panel".

Note that additional information is selected from the [Property panel](#), on the [[Device Top View Settings](#)] tab, by selecting the corresponding information under [Pin Name Display].

Figure 2-10. Select Additional Information



**Remarks 1.** Select one of the following two types for Define name (whether to display the "Define Name" string of the Device Pin List in appended format).

Display	Displays the "Define Name" string of the device pin list in appended format.
Not display	Hides the "Define Name" string of the device pin list.

**2.** Select one of the following two types for Pin function (whether to display it whether or not a function is selected for "Function" on the Device Pin List).


Display all	Displays functions selected via the device pin list's "Function" feature in parentheses.
Selected function only	Only display functions selected via the device pin list's "Function" feature in the device top view.

## 2.4 Enter Information

Enter information on the pins of the microcontroller in the [Device Pin List panel](#) which is opened as described in "2.2 [Open Device Pin List Panel](#)".

- Remarks 1.** You cannot add information in the "Pin Number" column, "Pin Name" column, "Description" column, "Recommend Connection For Unused" column and "Attention" column because they contain fixed information.
- 2.** If the "Free" in the "Function" column is changed to a specific pin name, color of the corresponding pin in the [Device Top View panel](#) changes from the "color representing the unused pins" to the "color representing the used pins" selected by clicking [[Device Top View Settings](#)] tab >> [Color] in the [Property panel](#).

Figure 2-11. Change in Displayed Color



## 2.5 Output Report Files


Output report files (files containing information configured using Pin Configurator: device pin list and device top view) to the specified folder.

### 2.5.1 Output device pin list

Select [File] menu >> [Save Pin List As...] to output a report file (a file containing information configured using Pin Configurator: device pin list).

The destination folder for the device pin list is specified in the [Save As dialog box](#) which opens by selecting [File] menu >> [Save Pin List As ...].

Figure 2-12. Output Device Pin List



- Remarks 1.** If a device pin list has been already output, that list will be overwritten by selecting [File] menu >> [Save Pin List].
- 2.** The output format for the device pin list is limited to Microsoft Office Excel Book.




### 2.5.2 Output device top view

Select [File] menu >> [Save Top View As...] to output a report file (a file containing information configured using Pin Configurator: device top view).

The destination folder for the device top view is specified in the [Save As dialog box](#) which opens by selecting [File] menu >> [Save Top View As ...].

Figure 2-13. Output Device Top View



**Remark** If a device top view has been already output, that view will be overwritten by selecting [File] menu >> [Save Top View].

---

**CHAPTER 3 FUNCTIONS (Code Generator)**

This chapter describes the key functions provided by the design tool (Code Generator) along with operation procedures.

**3.1 Overview**

The Code Generator outputs source code (device driver programs) based on information selected/entered on CubeSuite panels that is needed to control peripheral functions provided by the microcontroller (clock generator, port functions, etc.).

The following sections describe the operation procedures for Code Generator.

**(1) Start CubeSuite**

Launch CubeSuite from the [Start] menu of Windows.

**Remark** See "CubeSuite Start User's Manual" for details on "Start CubeSuite".

**(2) Create/Open project**

Create a new project (that defines a kind of project, microcontroller to be used, build tools to be used, etc.) or load an existing project.

**Remark** See "CubeSuite Start User's Manual" for details on "Create/Open project".

**(3) Open Code Generator Panel**

Open the [Code Generator panel](#) used to configure the information necessary to control the peripheral functions (clock generator, port functions, etc.).

**(4) Enter Information**

Configure the information necessary to control the peripheral functions in the [Code Generator panel](#).

**(5) Confirm Source Code**

Confirm the source code (device driver program) that reflects the information configured in the [Code Generator panel](#).

**(6) Output Source Code**

Output the source code (device driver program) to the specified folder.

**(7) Output Report Files**

Output report files (a file containing information configured using Code Generator and a file containing information regarding the source code) to the specified folder.

**(8) Save project**

Save a project.


**Remark** See "CubeSuite Start User's Manual" for details on "Save project".

### 3.2 Open Code Generator Panel

Open the [Code Generator panel](#) to configure the information necessary to control the peripheral functions (clock generator, port functions, etc.).

To open the [Code Generator panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[System], [Port], etc." in the [Project Tree panel](#).

Figure 3-1. Open Code Generator Panel



**Remark** If an unsupported microcontroller is defined in the project for Code Generator, then "[Code Generator (Design Tool)] node" will hide under [*Project name* (Project)] in the [Project Tree panel](#).

### 3.3 Enter Information

Configure the information necessary to control the peripheral functions in the information setting area of the [Code Generator panel](#) which is opened as described in "3.2 [Open Code Generator Panel](#)".

**Remark** When controlling multiple peripheral functions, repeat the procedures described in "3.2 [Open Code Generator Panel](#)" through "3.3 [Enter Information](#)".

#### 3.3.1 Input rule

Following is the rules for input to the [Code Generator panel](#).

##### (1) Character set

Character sets that are allowed to input are as follows.

**Table 3-1. List of Character Set**

Character Set	Outline
ASCII	1-byte alphabet, number, symbol
Shift-JIS	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji and 1-byte Katakana
EUC-JP	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji and 1-byte Katakana
UTF-8	2-byte alphabet, number, symbol, Hiragana, Katakana, Kanji (include Chinese character) and 1-byte Katakana


##### (2) Number

Notations allowed when entering numbers are as follows.

**Table 3-2. List of Notation**

Notation	Outline
Decimal number	A numeric value that starts with a number between 1 and 9 and followed by numbers between 0 and 9, and the numeric value 0
Hex number	A numeric value that starts with 0x and followed by a combination of numbers from 0 to 9 and characters from A to F (characters are not case sensitive)

3.3.2 Icon indicating incorrect entry

When performing code generation, if you enter an invalid string in the [Code Generator panel](#), or a required input is missing, then a  icon displays next to the incorrect input, and the text is displayed in red to warn that there is a problem with the input.




**Remark** If the mouse cursor is moved over the  icon, information regarding the string that should be entered (tips for correcting the entry) pops up.

Figure 3-2. Icon Indicating Incorrect Entry



3.3.3 Icon indicating pin conflict

If a conflict occurs between the pins while setting various peripheral functions in the [Code Generator panel](#), the  icon is displayed at the location where the conflict occurs to warn the user of a conflict between the pins.



**Remark** If the mouse cursor is moved over the  icon, information regarding the conflict between the pins (tips for avoiding the conflict) pops up.

Figure 3-3. Icon Indicating Pin Conflict




3.4 Confirm Source Code

Confirm the source code (device driver program) that reflects the information configured as described in "3.3 Enter Information".

To confirm the source code, use the [Code Generator Preview](#) panel that opens by selecting [View] menu >> [Code Generator Preview].


Figure 3-4. Confirm Source Code



- Remarks 1. You can change the source code to be displayed by selecting the source file name or API function name in the [Code Generator Preview](#) panel.
- 2. The following table displays the meaning of the color of the source code text displayed in the [Code Generator Preview](#) panel.


Table 3-3. Color of Source Code

Color	Outline
Green	Comment
Blue	Reserved word for C compiler
Red	Numeric value
Black	Code section
Gray	File name

- 3. You cannot edit the source code within the [Code Generator Preview](#) panel.
- 4. For some of the API functions (such as API functions for serial array units), values such as the SFR register value are calculated and finalized when the source code is generated (when the  [Generate Code](#) button on the [Code Generator](#) panel is pressed). For this reason, the source


code displayed in the [Code Generator Preview](#) panel may not be the same as that would actually be generated.

### 3.5 Output Source Code

Output the source code (device driver program) by pressing the  button on the [Code Generator](#) panel.

The destination folder for the source code is specified by clicking [\[Generation\]](#) tab >> [\[Output folder\]](#) in the [Property](#) panel.

Figure 3-5. Output Source Code





**Remark** In order to both output source files and add them to the project (display the corresponding source file names in the [Project Tree](#) panel) when you click the  button, you must open the [Property](#) panel, and under [\[Generation\]](#) tab >> [\[Register files\]](#), specify "Output files to project".

Figure 3-6. Configure Whether to Register






3.5.1 Setting that determines whether or not to generate source code

You can set whether or not to generate the corresponding source code on a per-API function basis by selecting [Generate code/Not generate code] from the context menu displayed by right clicking the API function name in the [Code Generator Preview panel](#).

Figure 3-7. Setting That Determines Whether or Not to Generate Source Code



**Remark** You can confirm the current setting for the generation of source code by checking the type of icon in the [Code Generator Preview panel](#).


Table 3-4. Setting That Determines Whether or Not to Generate Source Code

Type of Icon	Outline
	Source code for the currently selected API function is generated. If this icon is displayed next to the API function, the corresponding source code must be generated (it is impossible to change the icon to ).
	Source code for the currently selected API function is generated.
	Source code for the currently selected API function is not generated.

3.5.2 Change file name

The Code Generator is used to change the file name by selecting [Rename] from the context menu displayed by right clicking the file name in the [Code Generator Preview](#) panel.

Figure 3-8. Change File Name




**Remark** To restore the default file name defined by Code Generator, select [Default] from the context menu.

3.5.3 Change API function name

The Code Generator is used to change the name of the API function by selecting [Rename] from the context menu displayed by right clicking the API function name in the [Code Generator Preview panel](#).

Figure 3-9. Change API Function Name




**Remark** To restore the default name of the API function defined by Code Generator, select [Default] from the context menu.

3.5.4 Change output mode

The Code Generator is used to change the output mode (Overwrite file, Merge file, Do nothing if file exists) for the source code by selecting [Generation] tab >> [Generate file] in the Property panel.

Figure 3-10. Change Output Mode



**Remark** The output mode is selected from the following three types.

Table 3-5. Output Mode of Source Code

Output Mode	Outline
Overwrite file	If a file with the same name exists, the existing file is overwritten by a new file.
Merge file	If a file with the same name exists, a new file is merged with the existing file. Only the section between <code>/* Start user code ...</code> . Do not edit comment generated here <code>*/</code> and <code>/* End user code.</code> Do not edit comment generated here <code>*/</code> will be merged.
Do nothin if file exists	If a file with the same name exists, a new file will not be output.

### 3.5.5 Change output destination folder

The Code Generator is used to change the output destination folder for the source code by selecting [\[Generation\] tab](#) >> [\[Output folder\]](#) in the [Property panel](#).

To change the output destination, use the [Browse For Folder dialog box](#) which opens by pressing the [\[...\]](#) button in the [\[Output folder\]](#).

Figure 3-11. Change Output Destination Folder



3.6 Output Report Files

Output report files (a file containing information configured using Code Generator and a file containing information regarding the source code) by first activating the [Code Generator panel](#) or [Code Generator Preview panel](#), then selecting [File] menu >> [Save Code Generator Report].

The destination folder for the report file is specified by clicking [[Generation](#)] tab >> [Output folder] in the [Property panel](#).

**Remarks 1.** You can only use "macro" or "function" as a name of the report file.

**Table 3-6. Output Report Files**

File Name	Outline
macro	A file that contains the information configured using Code Generator
function	A file that contains the information regarding the source code

- The output mode for the report file is fixed to "Overwrite file".

**Figure 3-12. Output Example of Report File "macro"**




Figure 3-13. Output Example of Report File "function"


MCU name: NEG78K0RK3  
Chip name: uPD78F1166\_A0

Module	File	Macro	Function	Default	Status
<b>Common</b>					
	CG_main.c			CG_main.c	use
			void main(void)	main	not use
	CG_systeminit.c			CG_systeminit.c	use
			void systeminit(void)	systeminit	use
			void hdwinit(void)	hdwinit	use
	CG_macrodriver.h			CG_macrodriver.h	use
	CG_userdefine.h			CG_userdefine.h	use
	CG_ik.dr			CG_ik.dr	use
<b>System</b>					
	CG_system.c			CG_system.c	use
			void Clock_Init(void)	Clock_Init	use
	CG_system.h			CG_system.h	use
<b>External Bus</b>					
	CG_bus.c			CG_bus.c	not use
			void BUS_Init(void)	BUS_Init	not use
			void BUS_PowerOff(void)	BUS_PowerOff	not use
	CG_bus.h			CG_bus.h	not use
<b>Port</b>					
	CG_port.c			CG_port.c	use
			void PORT_Init(void)	PORT_Init	use
	CG_port.h			CG_port.h	use
<b>INT</b>					
	CG_int.c			CG_int.c	not use
			void INTP_Init(void)	INTP_Init	not use
			void KEY_Init(void)	KEY_Init	not use

3.6.1 Change output format

The Code Generator is used to change the output format (HTML file or CSV file) of the report file by selecting [Generation] tab >> [Report type] in the Property panel.

Figure 3-14. Change Output Format



**Remark** Output format is selected from the following two types.

Table 3-7. Output Mode of Source Code

Report Type	Outline
HTML file	Outputs a report file in HTML format.
CSV file	Outputs a report file in CSV format.




### 3.6.2 Change output destination

The Code Generator is used to change the output destination folder for the report file by selecting [\[Generation\] tab >> \[Output folder\]](#) in the [Property panel](#).

To change the output destination, use the [Browse For Folder dialog box](#) which opens by pressing the [...] button in the [Output folder].

Figure 3-15. Change Output Destination




## APPENDIX A WINDOW REFERENCE

This appendix explains in detail the functions of the windows, panels and dialog boxes of the design tool.

### A.1 Description

The design tool has the following windows, panels and dialog boxes.


**Table A-1. Window/Panel/Dialog Box List**

Window/Panel/Dialog Box Name	Function
<a href="#">Main window</a>	This is the first window to open when CubeSuite is launched. This window is used to operate various components (design tool, build tool, etc.) provided by CubeSuite.
<a href="#">Project Tree panel</a>	This panel displays the components of the project (microcontroller, design tool, build tool, etc.) in a tree structure.
<a href="#">Property panel</a>	This panel allows you to view the information and change the setting for the node selected in the <a href="#">Project Tree panel</a> , the peripheral function button pressed in the <a href="#">Code Generator panel</a> or the file selected in the <a href="#">Code Generator Preview panel</a> .
<a href="#">Device Pin List panel</a>	This panel allows you to enter information on each pin of the microcontroller.
<a href="#">Device Top View panel</a>	This panel displays the information entered in the <a href="#">Device Pin List panel</a> .
<a href="#">Code Generator panel</a>	This panel allows you to configure the information necessary to control the peripheral functions provided by the microcontroller.
<a href="#">Code Generator Preview panel</a>	This panel allows you to confirm or configure on a per-API function basis the setting that determines whether or not the source code (device driver program) is generated when the  button is pressed in the <a href="#">Code Generator panel</a> . It also allows you to confirm the source code that reflects the information configured in the <a href="#">Code Generator panel</a> .
<a href="#">Output panel</a>	This panel displays operation logs for various components (design tool, build tool, etc.) provided by CubeSuite.
<a href="#">Column Chooser dialog box</a>	This dialog box allows you to choose whether or not to display the item listed in this dialog box in the device pin list, and add columns to or delete columns from the device pin list.
<a href="#">New Column dialog box</a>	This dialog box allows you to add your own column to the device pin list.
<a href="#">Browse For Folder dialog box</a>	This dialog box allows you to specify the output destination for files (source code, report file, etc.).
<a href="#">Save As dialog box</a>	This dialog box allows you to name and save a file (such as a report file).

**Main window**

This is the first window to open when CubeSuite is launched. This window is used to operate various components (design tool, build tool, etc.) provided by CubeSuite.

Figure A-1. Main Window



The following items are explained here.

- [How to open]
- [Description of each area]

**[How to open]**

- From the [start] menu, select [All Programs] >> [NEC Electronics CubeSuite] >>[CubeSuite].

**[Description of each area]**

**(1) Menu bar**

This area consists of the following menu items.

## (a) [File] menu

Save Pin List	<p><a href="#">Device Pin List panel</a>-dedicated item</p> <p>Saves a report file (a file containing information configured using Pin Configurator: device pin list) overwriting the existing file.</p>
Save Pin List As...	<p><a href="#">Device Pin List panel</a>-dedicated item</p> <p>Opens the <a href="#">Save As dialog box</a> for naming and saving a report file (a file containing information configured using Pin Configurator: device pin list).</p>
Save Top View	<p><a href="#">Device Top View panel</a>-dedicated item</p> <p>Saves a report file (a file containing information configured using Pin Configurator: device top view) overwriting the existing file.</p>
Save Top View As...	<p><a href="#">Device Top View panel</a>-dedicated item</p> <p>Opens the <a href="#">Save As dialog box</a> for naming and saving a report file (a file containing information configured using Pin Configurator: device top view).</p>
Save Code Generator Report	<p><a href="#">Code Generator panel</a>/<a href="#">Code Generator Preview panel</a>-dedicated item</p> <p>Outputs report files (a file containing information configured using Code Generator and a file containing information regarding the source code).</p> <ul style="list-style-type: none"> <li>- The output format for the report file (either HTML or CSV) is selected by clicking <a href="#">[Generation] tab</a> &gt;&gt; <a href="#">[Report type]</a> in the <a href="#">Property panel</a>.</li> <li>- The destination folder for the report file is specified by clicking <a href="#">[Generation] tab</a> &gt;&gt; <a href="#">[Output folder]</a> in the <a href="#">Property panel</a>.</li> </ul>
Save Output- <i>Tab Name</i>	<p><a href="#">Output panel</a>-dedicated item</p> <p>Saves the message corresponding to the specified tab overwriting the existing file.</p>
Save Output- <i>Tab Name</i> As...	<p><a href="#">Output panel</a>-dedicated item</p> <p>Opens the <a href="#">Save As dialog box</a> for naming and saving the message corresponding to the specified tab.</p>

## (b) [Edit] menu

Undo	<p><a href="#">Property panel</a>-dedicated item</p> <p>Cancels the effect of an edit operation to restore the previous state.</p>
Cut	<p><a href="#">Property panel</a>-dedicated item</p> <p>Sends the character string or lines selected with range selection to the clipboard and deletes them.</p>
Copy	<p><a href="#">Property panel</a>/<a href="#">Output panel</a>-dedicated item</p> <p>Sends the character string or lines selected with range selection to the clipboard.</p>
Paste	<p><a href="#">Property panel</a>-dedicated item</p> <p>Inserts the contents of the clipboard at the caret position.</p>
Delete	<p><a href="#">Property panel</a>-dedicated item</p> <p>Deletes the character string or the lines selected with the range selection.</p>
Select All	<p><a href="#">Property panel</a>/<a href="#">Output panel</a>-dedicated item</p> <p>Selects all the strings displayed in the item being edited or all the strings displayed in the <a href="#">Message area</a>.</p>

Search...	<a href="#">Device Pin List panel</a> / <a href="#">Code Generator Preview panel</a> / <a href="#">Output panel</a> -dedicated item Opens the Search and Replace dialog box for searching strings with the [Quick Search] tab selected.
Replace...	<a href="#">Output panel</a> -dedicated item Opens the Search and Replace dialog box for replacing strings with the [Whole Replace] tab selected.

**(c) [Help] menu**

Open Help for Project Tree Panel	<a href="#">Project Tree panel</a> -dedicated item Displays the help of <a href="#">Project Tree panel</a> .
Open Help for Property Panel	<a href="#">Property panel</a> -dedicated item Displays the help of <a href="#">Property panel</a> .
Open Help for Device Pin List Panel	<a href="#">Device Pin List panel</a> -dedicated item Displays the help of <a href="#">Device Pin List panel</a> .
Open Help for Device Top View Panel	<a href="#">Device Top View panel</a> -dedicated item Displays the help of <a href="#">Device Top View panel</a> .
Open Help for Code Generator Panel	<a href="#">Code Generator panel</a> -dedicated item Displays the help of <a href="#">Code Generator panel</a> .
Open Help for Code Generator Preview Panel	<a href="#">Code Generator Preview panel</a> -dedicated item Displays the help of <a href="#">Code Generator Preview panel</a> .
Open Help for Output Panel	<a href="#">Output panel</a> -dedicated item Displays the help of <a href="#">Output panel</a> .

**(2) Panel display area**

This area consists of multiple panels, each dedicated to a different purpose.


See the following sections for details on this area.

- [Project Tree panel](#)
- [Property panel](#)
- [Device Pin List panel](#)
- [Device Top View panel](#)
- [Code Generator panel](#)
- [Code Generator Preview panel](#)
- [Output panel](#)

**Project Tree panel**

This panel displays components of the project (microcontroller, design tool, build tool, etc.) in a tree structure.

**Figure A-2. Project Tree Panel [Fx3]**



The following items are explained here.

- [How to open]
- [Description of each area]
- [[Help] menu (Project Tree panel-dedicated items)]
- [Context menu]

**[How to open]**

- From the [View] menu, select [Project Tree].

**[Description of each area]**

**(1) Project tree area**

This area displays components of the project (microcontroller, design tool, build tool, etc.) in a tree structure.

**(a) Pin Configurator (Design Tool)**

This node consists of the following pin nodes.

Device Pin List	Opens the <a href="#">Device Pin List panel</a> for entering information on the pins of the microcontroller.
-----------------	--

Device Top View	Opens the <a href="#">Device Top View panel</a> that displays the information entered in the <a href="#">Device Pin List panel</a> .
-----------------	--

**(b) Code Generator (Design Tool)**

This node consists of the following peripheral function nodes.




When there is peripheral function target microcontroller is not supporting, peripheral function button is not displayed.

System	Opens the <a href="#">[System]</a> for configuring the information necessary to control the functions of clock generator, on-chip debug function and etc. provided by the microcontroller.
External Bus	Opens the <a href="#">[External Bus]</a> for configuring the information necessary to control the functions of external bus interface (functions to connect an external bus to the area other than the built-in ROM, RAM or SFR) provided by the microcontroller.
Port	Opens the <a href="#">[Port]</a> for configuring the information necessary to control the port functions provided by the microcontroller.
INT	Opens the <a href="#">[INT]</a> for configuring the information necessary to control the interrupt functions and the key interrupt function provided by the microcontroller.
Serial	Opens the <a href="#">[Serial]</a> for configuring the information necessary to control the functions of serial array unit and functions of serial interface provided by the microcontroller.
Operational Amplifier	Opens the <a href="#">[Operational Amplifier]</a> for configuring the information necessary to control the functions of operational amplifier provided by the microcontroller.
Comparator/PGA	Opens the <a href="#">[Comparator/PGA]</a> for configuring the information necessary to control the functions of comparator/programmable gain amplifier provided by the microcontroller.
A/D	Opens the <a href="#">[A/D]</a> for configuring the information necessary to control the function of A/D converter provided by the microcontroller.
D/A	Opens the <a href="#">[D/A]</a> for configuring the information necessary to control the function of D/A converter provided by the microcontroller.
Timer	Opens the <a href="#">[Timer]</a> for configuring the information necessary to control the functions of timer array unit provided by the microcontroller.
Watchdog Timer	Opens the <a href="#">[Watchdog Timer]</a> for configuring the information necessary to control the functions of watchdog timer provided by the microcontroller.
RTC	Opens the <a href="#">[RTC]</a> for configuring the information necessary to control the functions of real-time counter provided by the microcontroller.
Clock Output	Opens the <a href="#">[Clock Output]</a> for configuring the information necessary to control the functions of clock output controller provided by the microcontroller.
Clock Output/Buzzer Output	Opens the <a href="#">[Clock Output/Buzzer Output]</a> for configuring the information necessary to control the functions of clock output/buzzer output controller provided by the microcontroller.
LCD Controller/Driver	Opens the <a href="#">[LCD Controller/Driver]</a> for configuring the information necessary to control the function of LCD controller/driver provided by the microcontroller.
DMA	Opens the <a href="#">[DMA]</a> for configuring the information necessary to control the functions of DMA (Direct Memory Access) controller provided by the microcontroller.

LVI	Opens the <a href="#">[LVI]</a> for configuring the information necessary to control the functions of low-voltage detector provided by the microcontroller.
-----	---

**(c) Icons**

The table below displays the meaning of the icon displayed to the left of the string representing the peripheral function node.

	Operation in the corresponding <a href="#">Code Generator panel</a> has been carried out.
	Operation in the corresponding <a href="#">Code Generator panel</a> has not been carried out.
	The problem occurs on the settings became the manipulation to the other peripheral function node influences.

**[[Help] menu (Project Tree panel-dedicated items)]**

Open Help for Project Tree Panel	Displays the help of this panel.
----------------------------------	----------------------------------

**[Context menu]**

The following context menu items are displayed by right clicking the mouse.


Return to Reset Value	Restores the information for the selected peripheral function node to its default state.
Property	Opens the <a href="#">Property panel</a> containing the information for the selected node ([Pin Configurator (Design Tool)] or [Code Generator (Design Tool)]).



## Property panel

This panel allows you to view the information on and change the setting for the node selected in the [Project Tree panel](#), the peripheral function button pressed in the [Code Generator panel](#) or the file selected in the [Code Generator Preview panel](#).

Figure A-3. Property Panel (Selected [Pin Configurator (Design Tool)])





The following items are explained here.



- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[\[Edit\] menu \(Property panel-dedicated items\)\]](#)
- [\[\[Help\] menu \(Property panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

### [How to open]

- On the [Project Tree panel](#), select a node ([Pin Configurator (Design Tool)], [Device Pin List], [Device Top View], [Code Generator (Design Tool)], peripheral function node "[System], [Port], etc."), and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select a node ([Pin Configurator (Design Tool)], [Device Pin List], [Device Top View], [Code Generator (Design Tool)], peripheral function node "[System], [Port], etc."), and then select [Property] from the context menu.
- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the [View] menu.
- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the context menu.



- Remarks 1.** If this panel is already open, selecting a different node ([Pin Configurator (Design Tool)], [Device Pin List], [Device Top View], [Code Generator (Design Tool)] or peripheral function node "[System], [Port], etc.") in the [Project Tree panel](#) changes the content displayed in the [Detail information display/change area](#) and [Explanation area](#) accordingly.
2. If this panel is already open, pressing a different peripheral function button " ,  , etc." in the [Code Generator panel](#) changes the content displayed in the [Detail information display/change area](#) and [Explanation area](#) accordingly.
  3. If this panel is already open, selecting a different file in the [Code Generator Preview panel](#) changes the content displayed in the [Detail information display/change area](#) and [Explanation area](#) accordingly.

**[Description of each area]****(1) Detail information display/change area**



This area allows you to view the information on and change the setting for the node ([Pin Configurator (Design Tool)], [Device Pin List], [Device Top View], [Code Generator (Design Tool)] or peripheral function node "[System], [Port], etc.") selected in the [Project Tree panel](#), the peripheral function button " ,  , etc." pressed in the [Code Generator panel](#), or the file selected in the [Code Generator Preview panel](#).

The content displayed in this area differs depending on the node selected in the [Project Tree panel](#), the peripheral function button pressed in the [Code Generator panel](#) or the file selected in the [Code Generator Preview panel](#).

The following table displays the meaning of  and  displayed to the left of each category.

	Indicates that the items within the category are displayed as a "collapsed view".
	Indicates that the items within the category are displayed as an "expanded view".

**Remarks 1.** See the sections "[\[Pin Configurator Settings\] tab](#)", "[\[Pin Configurator Information\] tab](#)", "[\[Device Top View Settings\] tab](#)", "[\[Generation\] tab](#)", "[\[Macro Setting\] tab](#)" and "[\[File Setting\] tab](#)" for details on the content displayed in this area.

2. To switch between  and  , click this mark or double-click the category name.

**(2) Explanation area**

This area displays a "brief description" of the category or item selected in the [Detail information display/change area](#).

**[[Edit] menu (Property panel-dedicated items)]**

Undo	Cancels the effect of an edit operation to restore the previous state.
Cut	Sends the character string or lines selected with range selection to the clipboard and deletes them.
Copy	Sends the character string or lines selected with range selection to the clipboard.
Paste	Inserts the contents of the clipboard at the caret position.
Delete	Deletes the character string or the lines selected with the range selection.
Select All	Selects all strings displayed in the item being edited.

**[[Help] menu (Property panel-dedicated items)]**

Open Help for Property Panel	Displays the help of this panel.
------------------------------	----------------------------------

**[Context menu]**

The following context menu items are displayed by right clicking the mouse.

**(1) While the item is being edited**

Undo	Cancels the effect of an edit operation to restore the previous state.
Cut	Sends the character string or lines selected with range selection to the clipboard and deletes them.

Copy	Sends the character string or lines selected with range selection to the clipboard.
Paste	Inserts the contents of the clipboard at the caret position.
Delete	Deletes the character string or the lines selected with the range selection.
Select All	Selects all strings displayed in the item being edited.


**(2) While the item is not being edited**

Property Reset to Default	Restores the selected item to its default state.
Property Reset All to Default	Restores all items to their default state.

**[Pin Configurator Settings] tab**

This tab displays information (Product Information, Use of Pin Configurator Panels and Package) on the [Pin Configurator (Design Tool)] selected in the [Project Tree panel](#).

**Figure A-4. [Pin Configurator Settings] Tab**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)], and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)], and then select [Property] from the context menu.

**Remark** If this panel is already open, selecting a different [Pin Configurator (Design Tool)] in the [Project Tree panel](#) changes the content displayed accordingly.

**[Description of each area]**

**(1) [Product Information] category**

This area displays product information (Version and Release date) on Pin Configurator.

Version	Displays the version of Pin Configurator.
Release date	Displays the release date of Pin Configurator.

**(2) [Use of Pin Configurator Panels] category**

Select whether to show the [Device Pin List panel](#) and [Device Top View panel](#).

Use pin configurator panels	Selects whether to display the <a href="#">Device Pin List panel</a> and <a href="#">Device Top View panel</a> in the <a href="#">Main window</a> the next time this project is opened.	
	Yes	Displays the <a href="#">Device Pin List panel</a> and <a href="#">Device Top View panel</a> .
	No	Hides the <a href="#">Device Pin List panel</a> and <a href="#">Device Top View panel</a> .

**(3) [Package] category**


Change the shape (package type) and settings of the microcontroller to display as the device top view in the [Device Top View panel](#).

Package type	Selects the shape of the microcontroller displayed in the device top view.
--------------	--

**[Pin Configurator Information] tab**

This tab displays information (Product information) on the [Device Pin List] selected in the [Project Tree panel](#).

**Figure A-5. [Pin Configurator Information] Tab**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List], and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List], and then select [Property] from the context menu.

**Remark** If this panel is already open, selecting a different [Device Pin List] in the [Project Tree panel](#) changes the content displayed accordingly.

**[Description of each area]**

**(1) [Product Information] category**


This area displays product information (Version and Release date) on Pin Configurator.

Version	Displays the version of Pin Configurator.
Release date	Displays the release date of Pin Configurator.

**[Device Top View Settings] tab**

This tab allows you to view the information (Color, Tool Tip and Pin Name Display) on and change the setting for the [Device Top View] selected in the [Project Tree panel](#).

Figure A-6. [Device Top View Settings] Tab



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Top View], and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Top View], and then select [Property] from the context menu.

**Remark** If this panel is already open, selecting a different [Device Top View] in the [Project Tree panel](#) changes the content displayed accordingly.

**[Description of each area]**

**(1) [Color] category**


Select the display colors to differentiate the pin groups (power pins, special pins, unused pins, etc.) in the device top view.

Power pins	Selects the display color for power pins (pins whose use is limited to power).
------------	--

Special pins	Selects the display color for special pins (pins with specified uses).
Unused pins	Selects the display color for unused pins (dual-use pins with no use set in the <a href="#">Device Pin List panel</a> ).
Used pins	Selects the display color for used pins (dual-use pins with a use set in the <a href="#">Device Pin List panel</a> ).
Device	Selects the display color of the microcontroller.
Highlight	Selects the background color of a pin selected in the <a href="#">Device Pin List panel</a> , on the <a href="#">[Pin Number] tab</a> .
Macro highlight	Selects the background color of pins selected in the <a href="#">Device Pin List panel</a> , on the <a href="#">[Macro] tab</a> .
External peripheral highlight	Selects the background color of pins selected in the <a href="#">Device Pin List panel</a> , on the <a href="#">[External Peripheral] tab</a> .

**Remark** To change the setting of the color, use the following color palette which opens by making a selection from the dropdown list in this area.

**Figure A-7. Color Palette**



**(2) [Tool Tip] category**

Select whether to display a tooltip with information about a pin when the mouse cursor is moved over the pin in the device top view.

Tool tip	Selects whether to display a tooltip with information about a pin when the mouse cursor is moved over the pin in the device top view panel.	
	Display all	Displays the "Description", "Recommend Connection For Unused", and "Attention" strings for the device pin list.
	Description / recommended connection for unused pin only	Displays the "Description", and "Recommend Connection For Unused" string for the device pin list.
	Attention only	Displays the "Attention" string for the device pin list.
	Not display	Hides tooltips when the mouse cursor hovers over a pin.



(3) [Pin Name Display] category


Select whether to display additional information about the pin in the device top view.

Define name	Selects whether to display the "Define Name" string of the device pin list appended to the pin in the device top view.	
	Display	Displays the "Define Name" string of the device pin list in appended format.
	Not display	Hides the "Define Name" string of the device pin list.
Pin function	Selects whether to also display unselected functions in the device top view when a function has been selected from the device pin list's "Function" feature.	
	Display all	Displays functions selected via the device pin list's "Function" feature in parentheses.
	Selected function only	Only display functions selected via the device pin list's "Function" feature in the device top view.

**[Generation] tab**

This tab allows you to view the information (Product Information, Generate File Mode) on and change the setting for the [Code Generator (Design Tool)] selected in the [Project Tree panel](#).

Figure A-8. [Generation] Tab



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)], and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)], and then select [Property] from the context menu.

**Remark** If this panel is already open, selecting a different [Code Generator (Design Tool)] in the [Project Tree panel](#) changes the content displayed accordingly.

**[Description of each area]**




**(1) [Product Information] category**

This area displays product information (Version and Release date) on Code Generator.

Version	Displays the version of Code Generator.
Release date	Displays the release date of Code Generator.

(2) [Generate File Mode] category


This area allows you to view and change the setting for the file generation mode (Generate file, Output folder, Report type and Register files) of Code Generator.

Generate file	Views or selects the operation mode applied when the  button is pressed. Operation mode applied when you select [File] menu >> [Save Code Generator Report] is fixed to "Overwrite file".	
	Overwrite file	If a file with the same name exists, the existing file is overwritten by a new file.
	Merge file	If a file with the same name exists, a new file is merged with the existing file. Only the section between "/* Start user code ... . Do not edit comment generated here */" and "/* End user code. Do not edit comment generated here */" will be merged.
	Do nothing if file exists	If a file with the same name exists, a new file will not be output.
Output folder	Views or selects the destination folder for various files (source code and report files) which are output when the  button is pressed or when [File] menu >> [Save Code Generator Report] is selected.	
Report type	Views or selects the format of the report files (a file containing information configured using Code Generator and a file containing information regarding the source code) which are output when [File] menu >> [Save Code Generator Report] is selected.	
	HTML file	Outputs a report file in HTML format.
	CSV file	Outputs a report file in CSV format.
Register files	Selects whether source code generated by pressing the  button should be added to the project.	
	Output files to project	Adds output source code to the project. The source code will be added to the <a href="#">Project Tree panel</a> , under the [File] - [Code Generator] node.
	Not output files to project	Does not add output source code to the project.

**Remark** To change the output destination, use the [Browse For Folder dialog box](#) which opens by pressing the [...] button in this area.

(3) [Pin Configurator Reflect Mode] category

Configure the information linking (mode) between Code Generator and Pin Configurator.

Mode	Selects whether to reflect the settings made in the <a href="#">Code Generator panel</a> in the <a href="#">Device Pin List panel</a> when the  button is pressed.	
	Reflected	Reflects <a href="#">Code Generator panel</a> settings in the <a href="#">Device Pin List panel</a> .
	Not reflected	Does not reflect <a href="#">Code Generator panel</a> settings in the <a href="#">Device Pin List panel</a> .

**Remark** If "Not reflected" is selected, then the  button will be grayed out (deselected).

**[Macro Setting] tab**




This tab allows you to view the information (Macro Information) on and change the setting for the peripheral function node "[System], [Port], etc." selected in the [Project Tree panel](#), or the peripheral function button " ,  , etc." pressed in the [Code Generator panel](#).

Figure A-9. [Macro Setting] Tab





The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[System], [Port], etc.", and then select [Property] from the [View] menu.
- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[System], [Port], etc.", and then select [Property] from the context menu.

- Remarks 1.** If this panel is already open, selecting a different peripheral function node "[System], [Port], etc." in the [Project Tree panel](#) changes the content displayed accordingly.
- 2.** If this panel is already open, pressing a different type of peripheral function button " ,  , etc." in the [Code Generator panel](#) changes the content displayed accordingly.

**[Description of each area]**

**(1) [Macro Information] category**


This area allows you to view the information (Macro name) on and change the setting for the peripheral function node "[System], [Port], etc." selected in the [Project Tree panel](#), or the peripheral function button pressed in the [Code Generator panel](#).

Macro name	Displays the type of peripheral function node selected in the <a href="#">Project Tree panel</a> or the type of peripheral function button pressed in the <a href="#">Code Generator panel</a> .
------------	--

**[File Setting] tab**

This tab allows you to view the information (File Information) on and change the setting for the file selected in the [Code Generator Preview panel](#).

Figure A-10. [File Setting] Tab



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the [View] menu.
- On the [Code Generator Preview panel](#), select a file, and then select [Property] from the context menu.

**Remark** If this panel is already open, selecting a different file in the [Code Generator Preview panel](#) changes the content displayed accordingly.

**[Description of each area]**

**(1) [File Information] category**


This area allows you to view the information (Default, File name) on and change the setting for the file selected in the [Code Generator Preview panel](#).

Default name	Views or selects the setting that determines whether the name of the file selected in the <a href="#">Code Generator Preview panel</a> is a default name or not.	
	Yes	The file name is a default name. Changing this area from "No" to "Yes" changes the name of the file to its default name.
	No	The file name is not a default name.
File name	Displays or change the name of the file selected on the <a href="#">Code Generator Preview panel</a> .	

**Device Pin List panel**

This panel allows you to enter information on each pin of the microcontroller.

**Figure A-11. Device Pin List Panel**



The following items are explained here.

- [How to open]
- [Description of each area]
- [[File] menu (Device Pin List panel-dedicated items)]
- [[Help] menu (Device Pin List panel-dedicated items)]

**[How to open]**



- On the **Project Tree panel**, select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List].
- From the [View] menu, select [Pin Configurator] >> [Device Pin List].

**[Description of each area]**

**(1) Toolbar**

This area consists of the following buttons.

	Displays the information in the <a href="#">Device pin list area</a> in an expanded view.
	Displays the information in the <a href="#">Device pin list area</a> in a folded view only.
	Clicks this button to automatically process the configuration information in the selected function, I/O, N-ch, and other fields after selecting one of the peripheral functions displayed in the first level on the <a href="#">[Macro] tab</a> .
	Clicks this button to initialize the selected function, I/O, N-ch, and other fields after selecting one of the peripheral functions displayed in the first level on the <a href="#">[Macro] tab</a> .
	Clicks this button to create an external peripheral controller from the external peripheral controller information on the <a href="#">[External Peripheral] tab</a> , and display it in the <a href="#">Device Top View panel</a> .
	Clicks this button to delete the information for the external peripheral controller displayed on the <a href="#">[External Peripheral] tab</a> , on the first layer.

- Remarks 1.** Click the  button to add the information in question as a choice in the "External Parts" column of the [\[Macro\] tab](#) and the [\[Pin Number\] tab](#).
- 2.** Click the  button to remove the external peripheral component in question from the [Device top view area](#) if the [Device Top View panel](#).

**(2) Device pin list area**

This area displays the "device pin list" for entering information on the pins of the microcontroller.

**(3) Tab selection area**

Selecting the tab changes the order in which "information on each pin of the microcontroller" is displayed.

This panel has the following tabs:

- [\[Pin Number\] tab](#)

This tab displays information on each pin of the microcontroller in the order of pin number.

- [\[Macro\] tab](#)

This tab displays information on each pin of the microcontroller in the order it was grouped into peripheral functions.

- [\[External Peripheral\] tab](#)

This tab displays information about the pins connected to external peripherals in order grouped at the external-peripheral component level.

**[[File] menu (Device Pin List panel-dedicated items)]**

Save Pin List	Saves a report file (a file containing information configured using Pin Configurator: device pin list) overwriting the existing file.
Save Pin List As...	Opens the <a href="#">Save As dialog box</a> for naming and saving a report file (a file containing information configured using Pin Configurator: device pin list).


**[[Help] menu (Device Pin List panel-dedicated items)]**

Open Help for Device Pin List Panel	Displays the help of this panel.
-------------------------------------	----------------------------------

**[Pin Number] tab**

This tab displays information on each pin of the microcontroller in the order of pin number.

**Figure A-12. [Pin Number] Tab**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List].
- From the [View] menu, select [Pin Configurator] >> [Device Pin List].

**[Description of each area]**


**(1) Device pin list area**

This area displays the "device pin list" for entering information on the pins of the microcontroller. The device pin list in this area is organized in the order of pin number. The following are the columns comprising the device pin list.

Column Heading	Outline
Pin Number	Displays the pin number of the pin.
Pin Name	This area allows you to select "which function to use" when the pin has more than one functions.
Function	This area allows you to select "which function to use" when the pin has more than one functions.
I/O	This area allows you to select the I/O mode of the pin.
N-ch	This area allows you to select "which output mode to apply" when using the pin in the output mode.
Define Name	This area allows you to assign a "user-defined pin name" to the pin.
Description	Displays the summary of function of the pin.




Column Heading	Outline
Recommend Connection For Unused	Displays instructions on how to handle the pin when it is not used. This column displays information only when the "Free" is selected in the "Function" column.
Attention	Displays the precaution on using the pin.
External Parts	This area is for selecting which external peripheral controller to connect the pin to.

- Remarks 1.** You cannot add information in the "Pin Number" column, "Pin Name" column, "Description" column, "Recommend Connection For Unused" column and "Attention" column because they contain fixed information.
2. If the "Free" in the "Function" column is changed to a specific pin name, color of the corresponding pin in the [Device Top View panel](#) changes from the "color representing the unused pins" to the "color representing the used pins" selected by clicking [\[Device Top View Settings\] tab](#) >> [Color] in the [Property panel](#).
  3. To move columns (change the display order) in the device pin list, drag and drop the desired column to the desired location.
  4. To add the "user's own column", use the [New Column dialog box](#) which opens by pressing the [New Column] button in the [Column Chooser dialog box](#) which opens by pressing the  button in the upper left corner of the device pin list.

**[Macro] tab**

This tab displays information on each pin of the microcontroller in the order it was grouped into peripheral functions.

**Figure A-13. [Macro] Tab**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List].
- From the [View] menu, select [Pin Configurator] >> [Device Pin List].

**[Description of each area]**

**(1) Device pin list area**

This area displays the "device pin list" for entering information on the pins of the microcontroller. The device pin list in this area is organized in the order the pins were grouped into peripheral functions.


**(a) First layer**

The following are the columns comprising the device pin list.

Column Heading	Outline
Macro Name	Displays the name of the peripheral function.
Total	Displays the total number of pins assigned to the peripheral function.
Used	Displays the total number of pins for which the purpose has been set.
Used in Other Macro	Displays the total number of pins for which the purpose has been set by other peripheral functions.

## (b) Second layer


Column Heading	Outline
Pin Number	Displays the pin number of the pin.
Pin Name	Displays the pin name of the pin.
Function	This area allows you to select "which function to use" when the pin has more than one functions.
I/O	This area allows you to select the I/O mode of the pin.
N-ch	This area allows you to select "which output mode to apply" when using the pin in the output mode.
Define Name	This area allows you to assign a "user-defined pin name" to the pin.
Description	Displays the summary of function of the pin.
Recommend Connection For Unused	Displays instructions on how to handle the pin when it is not used. This column displays information only when the "Free" is selected in the "Function" column.
Attention	Displays the precaution on using the pin.
External Parts	This area is for selecting which external peripheral controller to connect the pin to.

- Remarks 1.** You cannot add information in the "Macro Name", "Total", "Used", "Used by other function", "Pin Number", "Pin Name", "Description", "Recommend Connection For Unused" and "Attention" columns because they contain fixed information.
- If the "Free" in the "Function" column is changed to a specific pin name, color of the corresponding pin in the [Device Top View panel](#) changes from the "color representing the unused pins" to the "color representing the used pins" selected by clicking [\[Device Top View Settings\] tab](#) >> [\[Color\]](#) in the [Property panel](#).
  - To move columns (change the display order) in the device pin list, drag and drop the desired column to the desired location.
  - To add the "user's own column", use the [New Column dialog box](#) which opens by pressing the [\[New Column\]](#) button in the [Column Chooser dialog box](#) which opens by pressing the  button in the upper left corner of the device pin list.

**[External Peripheral] tab**

This tab displays information about the pins connected to external peripherals in order grouped at the external-peripheral component level.

Figure A-14. [External Peripheral] Tab



The following items are explained here.

- [How to open]
- [Description of each area]

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Pin Configurator (Design Tool)] >> [Device Pin List].
- From the [View] menu, select [Pin Configurator] >> [Device Pin List].

**[Description of each area]**

**(1) Device pin list area**

This area displays the “device pin list” for entering information on the pins connected to external peripheral parts. Note that items in this area’s device pin list are sorted by groups at the external peripheral controller level.

**(a) First layer**


The following are the columns comprising the device pin list.

Column Heading	Outline
External Peripheral	Displays the name of the external peripheral controller. To change the name, select this field and then press the [F2] key.
Total	Displays the total number of pins allocated for connection with the microcontroller.

**(b) Second layer**

Column Heading	Outline
Pin Number	Displays the pin number of the pin.
Pin Name	Displays the pin name of the pin.


Column Heading	Outline
Function	This area allows you to select "which function to use" when the pin has more than one functions.
I/O	This area allows you to select the I/O mode of the pin.
N-ch	This area allows you to select "which output mode to apply" when using the pin in the output mode.
Define Name	This area allows you to assign a "user-defined pin name" to the pin.
Description	Displays the summary of function of the pin.
Recommend Connection For Unused	Displays instructions on how to handle the pin when it is not used. This column displays information only when the "Free" is selected in the "Function" column.
Attention	Displays the precaution on using the pin.

- Remarks 1.** You cannot add information in the "External Peripheral Name", "Connected Pins", "Pin Number", "Pin Name", "Description", "Recommend Connection For Unused" and "Attention" columns because they contain fixed information.
2. If the "Free" in the "Function" column is changed to a specific pin name, color of the corresponding pin in the [Device Top View panel](#) changes from the "color representing the unused pins" to the "color representing the used pins" selected by clicking [\[Device Top View Settings\] tab](#) >> [Color] in the [Property panel](#).
  3. To move columns (change the display order) in the device pin list, drag and drop the desired column to the desired location.
  4. To add the "user's own column", use the [New Column dialog box](#) which opens by pressing the [New Column] button in the [Column Chooser dialog box](#) which opens by pressing the  button in the upper left corner of the device pin list.

Device Top View panel

This panel displays the information entered in the [Device Pin List panel](#).

Figure A-15. Device Top View Panel



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[\[File\] menu \(Device Top View panel-dedicated items\)\]](#)
- [\[\[Help\] menu \(Device Top View panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

**[How to open]**







- On the [Project Tree panel](#), select [*Project name* (Project)] >> [*Pin Configurator* (Design Tool)] >> [*Device Top View*].
- From the [View] menu, select [*Pin Configurator*] >> [*Device Top View*].

**Remark** In the [Property panel](#), on the [\[Pin Configurator Settings\] tab](#), if "BGA" is selected for the Package type, then this panel cannot be opened.


[Description of each area]

(1) **Toolbar**

This area consists of the following buttons.

	Clicks this button to enable changing of the display in the <a href="#">Device top view area</a> by drag and drop. By pressing this button, the shape of the mouse cursor in the <a href="#">Device top view area</a> changes from the arrow to the hand.
	Clicks this button to enable moving external peripheral components in the <a href="#">Device top view area</a> to arbitrary locations, and select pins. By pressing this button, the shape of the mouse cursor which has changed into the hand by pressing the  button reverts back to the arrow.
	Rotates the content in the <a href="#">Device top view area</a> 90 degrees counter-clockwise.
	Rotates the content in the <a href="#">Device top view area</a> 90 degrees clockwise.
	Expands or reduces the content in the <a href="#">Device top view area</a> .

(2) **[User Define] area**

Drag and drop the  button from this area to the [Device top view area](#) to creat and display an external peripheral controller.

(3) **Device top view area**

This area displays the pin assignment of the microcontroller.

Settings of the pin assignment are displayed using the colors specified by selecting [\[Device Top View Settings\] tab](#) >> [Color] in the [Property panel](#).

**Remark** If the pin name in the diagram is double-clicked, the [Device Pin List panel](#) opens and the focus moves to the clicked pin in the list.

**[[File] menu (Device Top View panel-dedicated items)]**

Save Top View	Saves a report file (a file containing information configured using Pin Configurator: device top view) overwriting the existing file.
Save Top View As...	Opens the <a href="#">Save As dialog box</a> for naming and saving a report file (a file containing information configured using Pin Configurator: device top view).

**[[Help] menu (Device Top View panel-dedicated items)]**

Open Help for Device Top View Panel	Displays the help of this panel.
-------------------------------------	----------------------------------

**[Context menu]**

When you right click on a pin or external peripheral controller in the [Device top view area](#), the following context menu displays.

**(1) When a pin is right clicked**

Use as	If the pin has multiple functions, select which function to use.
Connect to External Peripheral	Selects which external peripheral controller to connect the pin to.

**(2) When an external peripheral controller is right clicked**


Disconnect Pin	Disconnects from the pin.
Delete External Peripheral	Removes the external peripheral controller.



### Code Generator panel

This panel allows you to configure the information necessary to control the peripheral functions provided by the micro-controller.

Figure A-16. Code Generator Panel: [System]





The following items are explained here.

- [How to open]
- [Description of each area]
- [[File] menu (Code Generator panel-dedicated items)]
- [[Help] menu (Code Generator panel-dedicated items)]

#### [How to open]

- On the **Project Tree panel**, select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> Peripheral function node "[System], [Port], etc.".










**Remark** If this panel is already open, pressing a different peripheral function button " ,  , etc." changes the content displayed in the **Information setting area** accordingly.






## [Description of each area]

## (1) Toolbar

This area consists of the following "peripheral function buttons".

When there is peripheral function target microcontroller is not supporting, peripheral function button is not displayed.

 Reflect in Pin	Reflects settings made on this panel in the <a href="#">Device Pin List panel</a> . This button will be grayed out (disabled) if "Not reflected" is selected in the [PinPart Combination Mode] category of the <a href="#">[Generation] tab</a> .
 Generate Code	Outputs the source code (device driver program) to the folder specified by selecting <a href="#">[Generation] tab</a> >> [Output folder] in the <a href="#">Property panel</a> .
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[System]" for configuring the information necessary to control the functions of clock generator, on-chip debug function and etc. provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[External Bus]" for configuring the information necessary to control the functions of external bus interface (functions to connect an external bus to the area other than the built-in ROM, RAM or SFR) provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Port]" for configuring the information necessary to control the port functions provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[INT]" for configuring the information necessary to control the interrupt functions and the key interrupt function provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Serial]" for configuring the information necessary to control the functions of serial array unit and functions of serial interface provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Operational Amplifier]" for configuring the information necessary to control the functions of operational amplifier provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Comparator/PGA]" for configuring the information necessary to control the functions of comparator/programmable gain amplifier provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[A/D]" for configuring the information necessary to control the function of A/D converter provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[D/A]" for configuring the information necessary to control the function of D/A converter provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Timer]" for configuring the information necessary to control the functions of timer array unit provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Watchdog Timer]" for configuring the information necessary to control the functions of watchdog timer provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[RTC]" for configuring the information necessary to control the functions of real-time counter provided by the microcontroller".

	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Clock Output] for configuring the information necessary to control the functions of clock output controller provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[Clock Output/Buzzer Output] for configuring the information necessary to control the functions of clock output/buzzer output controller provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[LCD Controller/Driver] for configuring the information necessary to control the function of LCD controller/driver provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[DMA] for configuring the information necessary to control the functions of DMA (Direct Memory Access) controller provided by the microcontroller".
	Changes the content displayed in the <a href="#">Information setting area</a> to the "[LVI] for configuring the information necessary to control the functions of low-voltage detector provided by the microcontroller".

**(2) Information setting area**

The content displayed in this area differs depending on the "peripheral function node" or "peripheral function button" selected or pressed when opening this panel.

See the following sections for details on this area.

- [\[System\]](#)
- [\[External Bus\]](#)
- [\[Port\]](#)
- [\[INT\]](#)
- [\[Serial\]](#)
- [\[Operational Amplifier\]](#)
- [\[Comparator/PGA\]](#)
- [\[A/D\]](#)
- [\[D/A\]](#)
- [\[Timer\]](#)
- [\[Watchdog Timer\]](#)
- [\[RTC\]](#)
- [\[Clock Output\]](#)
- [\[Clock Output/Buzzer Output\]](#)
- [\[LCD Controller/Driver\]](#)
- [\[DMA\]](#)
- [\[LVI\]](#)

**Remark** See User's Manual for Microcontroller for details on the items to be set.

**[[File] menu (Code Generator panel-dedicated items)]**

Save Code Generator Report	Outputs report files (a file containing information configured using Code Generator and a file containing information regarding the source code).
----------------------------	---

- Remarks 1.** The output format for the report file (either HTML or CSV) is selected by clicking [\[Generation\] tab](#) >> [\[Report type\]](#) in the [Property panel](#).
- 2.** The destination folder for the report file is specified by clicking [\[Generation\] tab](#) >> [\[Output folder\]](#) in the [Property panel](#).

[[Help] menu (Code Generator panel-dedicated items)]

Open Help for Code Generator Panel	Displays the help of this panel.
------------------------------------	----------------------------------

**[System]**


This panel allows you to configure the information necessary to control the functions of clock generator, on-chip debug function and etc. provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-17. Example of [System]**

**[How to open]**

- On the [Project Tree](#) panel, select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [System].

**Remark** If the [Code Generator](#) panel is already open, pressing the  button changes the content displayed accordingly.

**[External Bus]**

This panel allows you to configure the information necessary to control the functions of external bus interface (functions to connect an external bus to the area other than the built-in ROM, RAM or SFR) provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.


**Figure A-18. Example of [External Bus]**

The screenshot shows the [External Bus] configuration panel with the following settings:

- Operation setting:**  Unused,  Used
- Mode setting:**  Multiplexed bus mode,  Separate bus mode
- Width setting:**  8 bits,  16 bits
- External memory area setting:**
  - 256-byte extension mode (8 address bus pins are used)
  - 4 KB extension mode (12 address bus pins are used)
  - 64 KB extension mode (16 address bus pins are used)
  - Full address mode (20 address bus pins are used)
- CLKOUT output clock setting:**
  - Clock value: 4 (fCLK) (MHz)
- Wait function setting:**  External wait pin enable

**[How to open]**


- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [External Bus].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[Port]**


This panel allows you to configure the information necessary to control port functions provided by the microcontroller. Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-19. Example of [Port]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Port].


**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[INT]**

This panel allows you to configure the information necessary to control the interrupt functions and the key interrupt function provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-20. Example of [INT]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [INT].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.



**[Serial]**

This panel allows you to configure the information necessary to control the functions of serial array unit and functions of serial interface provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-21. Example of [Serial]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Serial].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[Operational Amplifier]**

This panel allows you to configure the information necessary to control the functions of operational amplifier provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-22. Example of [Operatioal Amplifier]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Operational Amplifier].


**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[Comparator/PGA]**


This panel allows you to configure the information necessary to control the functions of comparator/programmable gain amplifier provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-23. Example of [Comparator/PGA]**

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Comparator/PGA].


**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

[A/D]

This panel allows you to configure the information necessary to control the function of A/D converter provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

Figure A-24. Example of [A/D]



[How to open]

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [A/D].


**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[D/A]**

This panel allows you to configure the information necessary to control the function of D/A converter provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-25. Example of [D/A]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [D/A].


**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

[Timer]

This panel allows you to configure the information necessary to control the function of timer array unit provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

Figure A-26. Example of [Timer]



[How to open]

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Timer].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[Watchdog Timer]**

This panel allows you to configure the information necessary to control the function of watchdog timer provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-27. Example of [Watchdog Timer]**

- Watchdog timer operation setting  
 Unused  Used

- Operation in HALT/STOP mode setting  
 Enabled  Stopped


- Overflow time setting  
Overflow time 4369 (2<sup>20</sup>/fIL) (ms)

- Window open period setting  
Window open period 100 (%)

- Interrupt setting  
 Enable interval interrupt when 75% of overflow time (INTWDTI)  
Priority Low

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Watchdog Timer].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

[RTC]


This panel allows you to configure the information necessary to control the function of real-time counter provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

Figure A-28. Example of [RTC]

[How to open]

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [RTC].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.




**[Clock Output]**

This panel allows you to configure the information necessary to control the functions of clock output controller provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-29. Example of [Clock Output]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Clock Output].


**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[Clock Output/Buzzer Output]**

This panel allows you to configure the information necessary to control the functions of clock output/buzzer output controller provided by the microcontroller.


Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-30. Example of [Clock Output/Buzzer Output]**



**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [Clock Output/Buzzer Output].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[LCD Controller/Driver]**

This panel allows you to configure the information necessary to control the functions of LCD controller/driver provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.

**Figure A-31. Example of [LCD Controller/Driver]**


The screenshot shows the following configuration details:

- LCD operation setting:**  Unused,  Used
- Drive voltage generator setting:**  External resistance division method,  Internal voltage boosting method,  Capacitor split method
- Display mode setting:**  Static,  Number of time slices: 4 (1/3 bias mode)
- Reference voltage setting:** VLC0 voltage: 3.00 (V)
- Display data area setting:**  Displaying an A-pattern area data (lower four bits of LCD display data memory),  Displaying a B-pattern area data (higher four bits of LCD display data memory),  Alternately displaying A-pattern and B-pattern area data (blinking display corresponding to the INTRTC interrupt timing of the real-time counter)
- Segment output pin setting:**

<input checked="" type="checkbox"/> SEG0	<input checked="" type="checkbox"/> SEG1	<input checked="" type="checkbox"/> SEG2	<input checked="" type="checkbox"/> SEG3	<input checked="" type="checkbox"/> SEG4
<input checked="" type="checkbox"/> SEG5	<input checked="" type="checkbox"/> SEG6	<input checked="" type="checkbox"/> SEG7	<input checked="" type="checkbox"/> SEG8-11	<input checked="" type="checkbox"/> SEG12-14
<input checked="" type="checkbox"/> SEG15	<input checked="" type="checkbox"/> SEG16-19	<input checked="" type="checkbox"/> SEG20-23	<input checked="" type="checkbox"/> SEG24-27	<input checked="" type="checkbox"/> SEG28-31
<input checked="" type="checkbox"/> SEG32-35	<input checked="" type="checkbox"/> SEG36-39			
- Clock setting:** Source clock (fLCD) selection: 625 (fCLK/2<sup>6</sup>) (kHz), Clock (LCDCL) selection: 488.3 (fLCD/2<sup>7</sup>) (Hz). (Current frame frequency is 122.1Hz)

**[How to open]**

- On the **Project Tree panel**, select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [LCD Controller/Driver].

**Remark** If the **Code Generator panel** is already open, pressing the  button changes the content displayed accordingly.

**[DMA]**

This panel allows you to configure the information necessary to control the functions of DMA (Direct Memory Access) controller provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.


**Figure A-32. Example of [DMA]**

The screenshot shows the DMA configuration window for DMA0. It includes the following settings:

- DMA operation setting:**  Used
- Transfer direction setting:**  SFR to internal RAM
- Transfer data size setting:**  8 bits
- Transfer address and count setting:**
  - SFR address: PO - 0x000fff00
  - RAM address: 0xfc00
  - Transfer byte count: 1024
- Start source setting:** Software trigger
- Interrupt setting:**
  - DMA0 transfer end interrupt (INTDMA0)
  - Priority: Low

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [DMA].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**[LVI]**

This panel allows you to configure the information necessary to control the functions of low-voltage detector provided by the microcontroller.

Screen Structure may be different, depending on the kinds of target microcontrollers. See user's manual for details on target microcontrollers.


**Figure A-33. Example of [LVI]**

The screenshot shows the LVI configuration panel with the following settings:

- Low voltage detector operation setting**
  - Unused
  - Used
  - LVI is ON by default on power application (Option Byte)
- Voltage detection setting**
  - Power voltage detection (VDD)  (V)
  - External voltage detection (EXLVI)  (V)
- Operation mode setting**
  - Generate interrupt signal (INTLVI)
    - Priority:
  - Generate internal reset signal

**[How to open]**

- On the [Project Tree panel](#), select [*Project name* (Project)] >> [Code Generator (Design Tool)] >> [LVI].

**Remark** If the [Code Generator panel](#) is already open, pressing the  button changes the content displayed accordingly.

**Code Generator Preview panel**



This panel allows you to confirm or configure on a per-API function basis the setting that determines whether or not the source code (device driver program) is generated when the  button is pressed in the [Code Generator panel](#). It also allows you to confirm the source code that reflects the information configured in the [Code Generator panel](#).

Figure A-34. Code Generator Preview Panel [Kx3]



The following items are explained here.


- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[File\] menu \(Code Generator Preview panel-dedicated items\)](#)
- [\[\[Help\] menu \(Code Generator Preview panel-dedicated items\)\]](#)
- [\[Context menu\]](#)

**[How to open]**

- From the [\[View\]](#) menu, select [\[Code Generator Preview\]](#).





[Description of each area]

(1) Preview tree

This area allows you to confirm or configure on a per-API function basis the setting that determines whether or not the source code (device driver program) is generated when the  **Generate Code** button is pressed in the [Code Generator panel](#).

- Remarks 1.** You can change the source code to be displayed by selecting the source file name or API function name in this tree.
2. To select whether or not to generate the source code, use the context menu (Generate code/Not generate code) which is displayed by right-clicking the mouse while the mouse cursor is on the desired icon in the tree.
  3. You can confirm the current setting that determines whether or not to generate the source code by checking the type of icon.

**Table A-2. Setting That Determines Whether or Not to Generate the Source Code**

Type of Icon	Outline
	Source code for the currently selected API function is generated. If this icon is displayed next to the API function, the corresponding source code must be generated (it is impossible to change the icon to  ).
	Source code for the currently selected API function is generated.
	Source code for the currently selected API function is not generated.


(2) Source code display area

This area allows you to confirm the source code (device driver program) that reflects the information configured in the [Code Generator panel](#).

The following table displays the meaning of the color of the source code text displayed in this area.

**Table A-3. Color of Source Code**

Color	Outline
Green	Comment
Blue	Reserved word for C compiler
Red	Numeric value
Black	Code section
Gray	File name

- Remarks 1.** You cannot edit the source code within this panel.
2. For some of the API functions (such as API functions for serial array units), values such as the SFR register value are calculated and finalized when the source code is generated (when the  **Generate Code** button on the [Code Generator panel](#) is pressed). For this reason, the source code displayed in this panel may not be the same as that would actually be generated.

3. You can change the source code to be displayed by selecting the source file name or API function name in the preview tree.

**[File] menu (Code Generator Preview panel-dedicated items)**

Save Code Generator Report	Outputs report files (a file containing information configured using Code Generator and a file containing information regarding the source code).
----------------------------	---






- Remarks 1.** The output format for the report file (either HTML or CSV) is selected by clicking [\[Generation\] tab >> \[Report type\]](#) in the [Property panel](#).
- 2.** The destination folder for the report file is specified by clicking [\[Generation\] tab >> \[Output folder\]](#) in the [Property panel](#).

**[[Help] menu (Code Generator Preview panel-dedicated items)**

Open Help for Code Generator Preview Panel	Displays the help of this panel.
--	----------------------------------

**[Context menu]**

The following context menu items are displayed by right clicking the mouse.

Generate code	Makes a setting so that the source code of the currently selected API function is generated to the folder specified by selecting <a href="#">[Generation] tab &gt;&gt; [Output folder]</a> in the <a href="#">Property panel</a> . Selecting this context menu item changes the icon of the currently selected API function from  to  .
Not generate code	Makes a setting so that the source code of the currently selected API function is not generated when the  button is pressed in the <a href="#">Code Generator panel</a> . Selecting this context menu item changes the icon of the currently selected API function from  to  .
Rename	Selecting this menu item changes the name portion of the currently selected file or API function into an edit box for editing the name. You can change the name of the file or API function by editing its name in the edit box.
Default	Reverts the file name or API function name to its original name before it was edited.
Property	Opens the <a href="#">Property panel</a> that contains the information for the currently selected file.



**Output panel**

This panel displays operation logs for various components (design tool, build tool, etc.) provided by CubeSuite.

**Figure A-35. Output Panel**



The following items are explained here.

- [How to open]
- [Description of each area]
- [[File] menu (Output panel-dedicated items)]
- [[Edit] menu (Output panel-dedicated items)]
- [[Help] menu (Output panel-dedicated items)]
- [Context menu]

**[How to open]**

- From the [View] menu, select [Output].

**[Description of each area]**

**(1) Message area**

This area displays operation logs for various components (design tool, build tool, etc.) provided by CubeSuite. The following table displays the meaning of the color of the message text displayed in this area.

**Table A-4. Color of Message Text/Background**

Message Text/Background	Description
Block/White	Information message Displayed with information notices.
Blue/Standard color	Warning message Displayed with warnings about operations.
Red/LightGray	Fatal error message Displayed when there is a fatal error, or when execution is not possible due to a operational mistake.

**Remark** See the sections "[All Output Messages] tab" and "[Code Generator] tab" for details on the content displayed in this area.

**(2) Tab selection area**

Select the source of message.

**Remark** When the new message is output, "\*" mark is displayed to the left of the tab name.

**[[File] menu (Output panel-dedicated items)]**

Save Output- <i>Tab Name</i>	Saves the message corresponding to the specified tab overwriting the existing file.
Save Output- <i>Tab Name</i> As...	Opens the <a href="#">Save As dialog box</a> for naming and saving the message corresponding to the specified tab.

**[[Edit] menu (Output panel-dedicated items)]**

Copy	Sends the character string or lines selected with range selection to the clipboard.
Select All	Selects all the messages displayed on the <a href="#">Message area</a> .
Search...	Opens the Search and Replace dialog box for searching strings with the [Quick Search] tab selected.
Replace...	Opens the Search and Replace dialog box for replacing strings with the [Whole Replace] tab selected.

**[[Help] menu (Output panel-dedicated items)]**

Open Help for Output Panel	Displays the help of this panel.
----------------------------	----------------------------------

**[Context menu]**

The following context menu items are displayed by right clicking the mouse.

Copy	Sends the character string or lines selected with range selection to the clipboard.
Select All	Selects all the messages displayed on the <a href="#">Message area</a> .
Clear	Deletes all the messages displayed on the <a href="#">Message area</a> .
Stop Searching	<p>Cancels the search currently being executed.</p> <p>This is invalid when a search is not being executed.</p>
Open Help for Message	<p>Displays help for the message on the current caret location.</p> <p>This only applies to warning messages and error messages.</p>

**[All Output Messages] tab**

This tab displays operation logs for all components (design tool, build tool, etc.) provided by CubeSuite.

**Figure A-36. [All Output Messages] Tab**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)

**[How to open]**

- From the [View] menu, select [Output].

**[Description of each area]**

**(1) Message area**

This area displays operation logs for all components (design tool, build tool, etc.) provided by CubeSuite. The following table displays the meaning of the color of the message text displayed in this area.

**Table A-5. Color of Message Text/Background**

Message Text/Background	Description
Black/White	Information message Displayed with information notices.
Blue/Standard Color	Warning message Displayed with warnings about operations.
Red/LightGray	Fatal error message Displayed when there is a fatal error, or when execution is not possible due to a operational mistake.

**[Code Generator] tab**

This tab displays only operation logs for Code Generator out of those for various components (design tool, build tool, etc.) provided by CubeSuite.

**Figure A-37. [Code Generator] Tab**



The following items are explained here.

- [How to open]
- [Description of each area]

**[How to open]**

- From the [View] menu, select [Output].

**[Description of each area]**

**(1) Message area**

This area displays only operation logs for Code Generator out of those for various components (design tool, build tool, etc.) provided by CubeSuite.

The following table displays the meaning of the color of the message text displayed in this area.


**Table A-6. Color of Message Text/Background**

Message Text/Background	Outline
Black/White	Information message Displayed with information notices.
Blue/Standard Color	Warning message Displayed with warnings about operations.
Red/LightGray	Fatal error message Displayed when there is a fatal error, or when execution is not possible due to a operational mistake.

**Column Chooser dialog box**

This dialog box allows you to choose whether or not to display the item listed in this dialog box in the device pin list, and add columns to or delete columns from the device pin list.




**Figure A-38. Column Chooser Dialog Box**



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

**[How to open]**

- In the [Pin Number] tab of the Device Pin List panel, click the  button.
- In the [Macro] tab of the Device Pin List panel, click the  button.
- In the [External Peripheral] tab of the Device Pin List panel, click the  button.

**[Description of each area]**

**(1) Operational object selection area**

This area allows you to select the device pin list to be configured in this dialog box.

Pin Number	Configures the device pin list corresponding to the [Pin Number] tab.
Macro	Configures the device pin list belonging to the first layer of the [Macro] tab.
Macro - Pin	Configures the device pin list belonging to the second layer of the [Macro] tab.
External Peripheral	Configures the device pin list belonging to the first layer of the [External Peripheral] tab.
External Peripheral - Pin	Configures the device pin list belonging to the second layer of the [External Peripheral] tab.

Figure A-39. Operational Object ([Pin Number] Tab)




Figure A-40. Operational Object ([Macro] Tab: First Layer)




Figure A-41. Operational Object ([Macro] Tab: Second Layer)




Figure A-42. Operational Object ([External Peripheral] Tab: First Layer)





Figure A-43. Operational Object ([External Peripheral] Tab: Second Layer)



(2) Displayed item selection area

Select whether or not to display the item selected in the [Operational object selection area](#) in the device pin list.

Checked	Displays the selected item in the device pin list.
Not checked	Hides the selected item in the device pin list.


[Function buttons]

Button	Function
New Column	Opens the <a href="#">New Column dialog box</a> for adding columns to the device pin list.
Delete Column	Deletes the selected columns from the device pin list. You can only delete the column which you added using the <a href="#">New Column dialog box</a> .
Default	Restores the column order to the default settings.
Close	Closes this dialog box.

**New Column dialog box**

This dialog box allows you to add your own column to the device pin list.

**Figure A-44. New Column Dialog Box**



The following items are explained here.

- [\[How to open\]](#)
- [\[Description of each area\]](#)
- [\[Function buttons\]](#)

**[How to open]**

- Click the [\[New Column\]](#) button in the [Column Chooser dialog box](#).

**[Description of each area]**

**(1) [Name]**

This area allows you to enter column headings of the columns added to the device pin list.

**(2) [Type]**

Select the input format of the column to add to the device pin list.

Text	Only character strings can be entered in the column.
Check box	Adds a column of check boxes.
Whole number	Only integers can be entered in the column.
Real number	Only real numbers can be entered in the column.
Date	Only dates in YYYYMMDD format can be entered in the column.

**[Function buttons]**


Button	Function
OK	Adds a column that has the column heading specified in the <a href="#">[Name]</a> to the right end of the device pin list.
Cancel	Ignores the setting and closes this dialog box.



**Browse For Folder dialog box**

This dialog box allows you to specify the output destination for files (source code, report file, etc.).

**Figure A-45. Browse For Folder Dialog Box**



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

**[How to open]**

- In the [Generation] tab of the Property panel, click the [...] button in [Output folder].

**[Description of each area]**

**(1) Folder location**

Select the folder to which the files (source code, report file, etc.) are output.


**[Function buttons]**

Button	Function
Make New Folder	Creates a "New Folder" below the folder selected in the Folder location.
OK	Specifies the folder selected in the Folder location as the destination for the files.
Cancel	Ignores the setting and closes this dialog box.

**Save As dialog box**

This dialog box allows you to name and save a file (such as a report file).

**Figure A-46. Save As Dialog Box**



The following items are explained here.

- [How to open]
- [Description of each area]
- [Function buttons]

**[How to open]**

- From the [File] menu, select [Save <object> As...].

**[Description of each area]**

**(1) [Save in]**

Select the folder to which the files (report files, etc.) are output.

**(2) List of files**

This area displays a list of files matching the conditions selected in [Save in] and [Save as type].

**(3) [File name]**

Specify the name of the file to be output.

**(4) [Save as type]**

Select the type of the file to be output.

Microsoft Office Excel Book (*.xls)	Microsoft Office Excel Book format
Bitmap (*.bmp)	Bitmap format
PNG (*.png)	PNG format
JPEG (*.jpg)	JPEG format
EMF (*.emf)	EMF format

**[Function buttons]**

Button	Function
Save	Outputs a file having the name specified in the <a href="#">[File name]</a> and <a href="#">[Save as type]</a> to the folder specified in the <a href="#">[Save in]</a> .
Cancel	Ignores the setting and closes this dialog box.

## APPENDIX B OUTPUT FILES

This appendix describes the files output by Code Generator.

### B.1 Overview

Below is a list of files output by Code Generator.

**Table B-1. File List**

Unit of Output	File Name	Description
Peripheral function	CG_ <i>PeripheralFunctionName</i> .c	Initial function, API function
	CG_ <i>PeripheralFunctionName</i> _user.c	Interrupt function, callback function
	CG_ <i>PeripheralFunctionName</i> .h	Defines macros for assigning values to registers
Project	CG_option.asm	Option bytes, secures ROM for MINICUBE2
	CG_systeminit.c	Call initial function of peripheral function Call <a href="#">CG_ReadResetSource</a>
	CG_main.c	main function
	CG_macrodriver.h	Defines common macros used by all source files
	CG_user_define.h	Empty file (for user definitions)
	CG_lk.dir	Link directive

### B.2 Output File

Below are the files (peripheral function) output by Code Generator.

**Table B-2. File List (Peripheral Function)**

Peripheral Function	Source File Name	Names of API Functions Included
System	CG_system.c	<a href="#">CLOCK_Init</a> <a href="#">CG_ChangeClockMode</a> <a href="#">CG_ChangeFrequency</a> <a href="#">CG_SelectPowerSaveMode</a> <a href="#">CG_SelectStabTime</a>
	CG_system_user.c	<a href="#">CLOCK_UserInit</a> <a href="#">CG_ReadResetSource</a>
	CG_system.h	-
External Bus	CG_bus.c	<a href="#">BUS_Init</a> <a href="#">BUS_PowerOff</a>
	CG_bus_user.c	<a href="#">BUS_UserInit</a>
	CG_bus.h	-
Port	CG_port.c	<a href="#">PORT_Init</a> <a href="#">PORT_ChangePmnInput</a> <a href="#">PORT_ChangePmnOutput</a>
	CG_port_user.c	<a href="#">PORT_UserInit</a>
	CG_port.h	-

Peripheral Function	Source File Name	Names of API Functions Included
INT	CG_int.c	INTP_Init KEY_Init INT_MaskableInterruptEnable INTPn_Disable INTPn_Enable KEY_Disable KEY_Enable
	CG_int_user.c	MD_INTPn MD_INTKR INTP_UserInit KEY_UserInit
	CG_int.h	-
Serial	CG_serial.c	SAUm_Init SAUm_PowerOff UARTn_Init UARTn_Start UARTn_Stop UARTn_SendData UARTn_ReceiveData CSImn_Init CSImn_Start CSImn_Stop CSImn_SendData CSImn_ReceiveData CSImn_SendReceiveData IICmn_Init IICmn_Stop IICmn_MasterSendStart IICmn_MasterReceiveStart IICmn_StartCondition IICmn_StopCondition UARTFn_Init UARTFn_PowerOff UARTFn_Start UARTFn_Stop UARTFn_SendData UARTFn_ReceiveData UARTFn_SetComparisonData UARTFn_DataComparisonEnable UARTFn_DataComparisonDisable IICA_Init IICA_PowerOff IICA_Stop IICA_MasterSendStart IICA_MasterReceiveStart IICA_StopCondition IICA_SlaveSendStart

Peripheral Function	Source File Name	Names of API Functions Included
Serial	CG_serial.c	IICA_SlaveReceiveStart IICn_Init IICn_Stop IICn_MasterSendStart IICn_MasterReceiveStart IICn_SlaveSendStart IICn_SlaveReceiveStart
	CG_serial_user.c	MD_INTSRn MD_INTSREn MD_INTSTn MD_INTCSImn MD_INTIICmn MD_INTLTn MD_INTLRn MD_INTLSn MD_INTIICn MD_INTIICA SAUm_UserInit UARTn_SendEndCallback UARTn_ReceiveEndCallback UARTn_SoftOverRunCallback UARTn_ErrorCallback CSImn_SendEndCallback CSImn_ReceiveEndCallback CSImn_ErrorCallback IICmn_MasterSendEndCallback IICmn_MasterReceiveEndCallback IICmn_MasterErrorCallback UARTFn_SendEndCallback UARTFn_ReceiveEndCallback UARTFn_SoftOverRunCallback UARTFn_ExpBitCetectCallback UARTFn_IDMatchCallback UARTFn_ErrorCallback IICA_UserInit IICA_MasterSendEndCallback IICA_MasterReceiveEndCallback IICA_MasterErrorCallback IICA_SlaveSendEndCallback IICA_SlaveReceiveEndCallback IICA_SlaveErrorCallback IICA_GetStopConditionCallback IICn_UserInit IICn_MasterSendEndCallback IICn_MasterReceiveEndCallback IICn_MasterErrorCallback IICn_SlaveSendEndCallback

Peripheral Function	Source File Name	Names of API Functions Included
Serial	CG_serial_user.c	IICn_SlaveReceiveEndCallback IICn_SlaveErrorCallback IICn_GetStopConditionCallback
	CG_serial.h	-
Operational Amplifier	CG_opamp.c	OPAMP_Init AMPn_Start AMPn_Stop
	CG_opamp_user.c	OPAMP_UserInit
	CG_opamp.h	-
Comparator/PGA	CG_cmppga.c	CMPPGA_Init CMPPGA_PowerOff CMPPGA_Start CMPPGA_Stop CMPPGA_ChangeCMPnRefVoltage CMPPGA_ChangePGAFactor
	CG_cmppga_user.c	MD_INTCMPn CMPPGA_UserInit
	CG_cmppga.h	-
A/D	CG_ad.c	AD_Init AD_PowerOff AD_ComparatorOn AD_ComparatorOff AD_Start AD_Stop AD_SelectADChannel AD_Read AD_ReadByte
	CG_ad_user.c	MD_INTAD AD_UserInit
	CG_ad.h	-
D/A	CG_da.c	DA_Init DA_PowerOff DAn_Start DAn_Stop DAn_SetValue DAn_Set8BitsValue DAn_Set12BitsValue
	CG_da_user.c	DA_UserInit
	CG_da.h	-
Timer	CG_timer.c	TAUm_Init TAUm_PowerOff TAUm_Channeln_Start TAUm_Channeln_Stop TAUm_Channeln_ChangeCondition

Peripheral Function	Source File Name	Names of API Functions Included
Timer	CG_timer.c	TAUm_Channeln_ChangeTimerCondition TAUm_Channeln_GetPulseWidth TAUm_Channeln_ChangeDuty TAUm_Channeln_SoftWareTriggerOn
	CG_timer_user.c	MD_INTTMmn TAUm_UserInit
	CG_timer.h	-
Watchdog Timer	CG_wdt.c	WDT_Init WDT_Restart
	CG_wdt_user.c	MD_INTWDTI WDT_UserInit
	CG_wdt.h	-
RTC	CG_rtc.c	RTC_Init RTC_PowerOff RTC_CounterEnable RTC_CounterDisable RTC_SetHourSystem RTC_CounterSet RTC_CounterGet RTC_ConstPeriodInterruptEnable RTC_ConstPeriodInterruptDisable RTC_AlarmEnable RTC_AlarmDisable RTC_AlarmSet RTC_AlarmGet RTC_IntervalStart RTC_IntervalStop RTC_IntervallInterruptEnable RTC_IntervallInterruptDisable RTC_RTC1HZ_OutputEnable RTC_RTC1HZ_OutputDisable RTC_RTCCL_OutputEnable RTC_RTCCL_OutputDisable RTC_RTCDIV_OutputEnable RTC_RTCDIV_OutputDisable RTC_ChangeCorrectionValue
	CG_rtc_user.c	MD_INTRTC MD_INTRTCI RTC_UserInit RTC_ConstPeriodInterruptCallback RTC_AlarmInterruptCallback
	CG_rtc.h	-
Clock Output	CG_pcl.c	PCL_Init PCL_Start PCL_Stop



Peripheral Function	Source File Name	Names of API Functions Included
Clock Output	CG_pcl.c	PCL_ChangeFreq
	CG_pcl_user.c	PCL_UserInit
	CG_pcl.h	-
Clock Output/Buzzer Output	CG_pclbuz.c	PCLBUZn_Init PCLBUZn_Start PCLBUZn_Stop PCLBUZn_ChangeFreq
	CG_pclbuz_user.c	PCLBUZn_UserInit
	CG_pclbuz.h	-
LCD Controller/Driver	CG_lcd.c	LCD_Init LCD_DisplayOn LCD_DisplayOff LCD_VoltageOn LCD_VoltageOff
	CG_lcd_user.c	LCD_UserInit
	CG_lcd.h	-
DMA	CG_dma.c	DMAAn_Init DMAAn_Enable DMAAn_Disable DMAAn_Hold DMAAn_Restart DMAAn_CheckStatus DMAAn_SetData DMAAn_SoftwareTriggerOn
	CG_dma_user.c	MD_INTDMA <i>n</i> DMAAn_UserInit
	CG_dma.h	-
LVI	CG_lvi.c	LVI_Init LVI_InterruptModeStart LVI_ResetModeStart LVI_Stop LVI_SetLVILevel
	CG_lvi_user.c	MD_INTLVI LVI_UserInit
	CG_lvi.h	-

## APPENDIX C API FUNCTIONS

This appendix describes the API functions output by Code Generator.

### C.1 Overview

Below are the naming conventions for API functions output by Code Generator.

- Macro names are in ALL CAPS.
- The number in front of the macro name is a hexadecimal value; this is the same value as the macro value.
- Local variable names are in all lower case.
- Global variable names start with a "g" and use Camel Case.
- Names of pointers to local variables start with a "p" and are in all lower case.
- Names of pointers to global variables start with a "gp" and use Camel Case.
- Names of elements in enum statements are in ALL CAPS.

### C.2 Output Function

Below is a list of API functions output by Code Generator.

**Table C-1. API Function List**

Peripheral Function	API Function Name	Function
System	CLOCK_Init	Performs initialization required to control the clock generator, on-chip debug, and etc. .
	CLOCK_UserInit	Performs user-defined initialization relating to the clock generator, on-chip debug, and etc. .
	CG_ReadResetSource	Performs processing in response to RESET signal.
	CG_ChangeClockMode	Changes the CPU clock/peripheral hardware clock.
	CG_ChangeFrequency	Changes the division ratio of the CPU clock/peripheral hardware clock.
	CG_SelectPowerSaveMode	Configures the CPU's standby function.
	CG_SelectStabTime	Configures the oscillation stabilization time of the X1 clock.
External Bus	BUS_Init	Performs initialization necessary to control external bus interface functions (functions to connect an external bus to areas other than onboard ROM, ROM and RAM).
	BUS_UserInit	Performs user-defined initialization relating to the external bus interface.
	BUS_PowerOff	Halts the clock supplied to the external bus interface.
Port	PORT_Init	Performs initialization necessary to control port functions.
	PORT_UserInit	Performs user-defined initialization relating to the port.
	PORT_ChangePmnInput	Switches the pin's I/O mode from output mode to input mode.
	PORT_ChangePmnOutput	Switches the pin's I/O mode from input mode to output mode.
INT	INTP_Init	Performs initialization necessary to control the external interrupt INTP <sub>n</sub> functions.

Peripheral Function	API Function Name	Function
INT	INTP_UserInit	Performs user-defined initialization relating to the external interrupt INTP $n$ functions.
	KEY_Init	Performs initialization necessary to control the key interrupt INTKR functions.
	KEY_UserInit	Performs user-defined initialization relating to the key interrupt INTKR functions.
	INT_MaskableInterruptEnable	Disables/enables the acceptance of the maskable interrupts.
	INTPn_Disable	Disables the acceptance of the maskable interrupts INTP $n$ (external interrupt requests).
	INTPn_Enable	Enables the acceptance of the maskable interrupts INTP $n$ (external interrupt requests).
	KEY_Disable	Disables the acceptance of the key interrupts INTKR.
	KEY_Enable	Enables the acceptance of the key interrupts INTKR.
Serial	SAUm_Init	Performs initialization necessary to control the serial array unit and serial interface functions.
	SAUm_UserInit	Performs user-defined initialization related to the serial array unit and serial interface functions.
	SAUm_PowerOff	Halts the clock supplied to the serial array unit.
	UARTn_Init	Performs initialization of the serial interface (UART) channel.
	UARTn_Start	Sets UART communication to standby mode.
	UARTn_Stop	Ends UART communication.
	UARTn_SendData	Starts UART data transmission.
	UARTn_ReceiveData	Starts UART data reception.
	UARTn_SendEndCallback	Performs processing in response to the UART transmission complete interrupt INTST $n$ .
	UARTn_ReceiveEndCallback	Performs processing in response to the UART reception complete interrupt INTSR $n$ .
	UARTn_SoftOverRunCallback	Performs processing in response to the UART reception complete interrupt INTSR $n$ .
	UARTn_ErrorCallback	Performs processing in response to the UART communication error interrupt INTSRE $n$ .
	CSImn_Init	Performs initialization of the serial interface (CSI) channel.
	CSImn_Start	Sets CSI communication to standby mode.
	CSImn_Stop	Ends CSI communication.
	CSImn_SendData	Starts CSI data transmission.
	CSImn_ReceiveData	Starts CSI data reception.
	CSImn_SendReceiveData	Starts CSI data transmission/reception.
CSImn_SendEndCallback	Performs processing in response to the CSI communication complete interrupt INTCSImn.	

Peripheral Function	API Function Name	Function
Serial	CSImn_ReceiveEndCallback	Performs processing in response to the CSI communication complete interrupt INTCSImn.
	CSImn_ErrorCallback	Performs processing in response to the CSI communication error interrupt INTSREn.
	IICmn_Init	Performs initialization of the serial interface (simple IIC) channel.
	IICmn_Stop	Ends simple IIC communication.
	IICmn_MasterSendStart	Starts simple IIC master transmission.
	IICmn_MasterReceiveStart	Starts simple IIC master reception.
	IICmn_StartCondition	Generates start conditions.
	IICmn_StopCondition	Generates stop conditions.
	IICmn_MasterSendEndCallback	Performs processing in response to the IICmn communication complete interrupt INTIICmn.
	IICmn_MasterReceiveEndCallback	Performs processing in response to the IICmn communication complete interrupt INTIICmn.
	IICmn_MasterErrorCallback	Performs processing in response to detection of parity error (ACK error) in simple IIC communication.
	UARTFn_Init	Performs initialization of the serial interface (UARTFn).
	UARTFn_PowerOff	Halts the clock supplied to the serial interface (UARTFn).
	UARTFn_Start	Sets UARTF communication to standby mode.
	UARTFn_Stop	Ends UARTF communication.
	UARTFn_SendData	Starts UARTF data transmission.
	UARTFn_ReceiveData	Starts UARTF data reception.
	UARTFn_SetComparisonData	Sets the data to compare to the received data.
	UARTFn_DataComparisonEnable	Starts the data comparison.
	UARTFn_DataComparisonDisable	Ends the data comparison.
	UARTFn_SendEndCallback	Performs processing in response to the transmission interrupt INTLTn.
	UARTFn_ReceiveEndCallback	Performs processing in response to the reception complete interrupt INTLRn.
	UARTFn_SoftOverRunCallback	Performs processing in response to the reception complete interrupt INTLRn.
	UARTFn_ExpBitCetectCallback	Performs processing in response to the status interrupt INTLSn.
	UARTFn_IDMatchCallback	Performs processing in response to the status interrupt INTLSn.
	UARTFn_ErrorCallback	Performs processing in response to the status interrupt INTLSn.
	IICA_Init	Performs initialization of the serial interface (IICA).
	IICA_UserInit	Performs user-defined initialization of the serial interface (IICA).

Peripheral Function	API Function Name	Function
Serial	IICA_PowerOff	Halts the clock supplied to the serial interface (IICA).
	IICA_Stop	Ends IICA communication.
	IICA_MasterSendStart	Starts IICA master transmission.
	IICA_MasterReceiveStart	Starts IICA master reception.
	IICA_StopCondition	Generates stop conditions.
	IICA_MasterSendEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
	IICA_MasterReceiveEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
	IICA_MasterErrorCallback	Performs processing in response to detection of error in IICA master communication.
	IICA_SlaveSendStart	Starts IICA slave transmission.
	IICA_SlaveReceiveStart	Starts IICA slave reception.
	IICA_SlaveSendEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
	IICA_SlaveReceiveEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
	IICA_SlaveErrorCallback	Performs processing in response to detection of error in IICA slave communication.
	IICA_GetStopConditionCallback	Performs processing in response to detection of stop condition in IICA slave communication.
	IICn_Init	Performs initialization of the serial interface (IICn).
	IICn_UserInit	Performs user-defined initialization of the serial interface (IICn).
	IICn_Stop	Ends IICn communication.
	IICn_MasterSendStart	Starts IICn master transmission.
	IICn_MasterReceiveStart	Starts IICn master reception.
	IICn_MasterSendEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
	IICn_MasterReceiveEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
	IICn_MasterErrorCallback	Performs processing in response to detection of error in IICn master communication.
	IICn_SlaveSendStart	Starts IICn slave transmission.
	IICn_SlaveReceiveStart	Starts IICn slave reception.
	IICn_SlaveSendEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
	IICn_SlaveReceiveEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
	IICn_SlaveErrorCallback	Performs processing in response to detection of error in IICn slave communication.

Peripheral Function	API Function Name	Function
Serial	IICn_GetStopConditionCallback	Performs processing in response to detection of stop condition in IICn slave communication.
Operational Amplifier	OPAMP_Init	Performs initialization necessary to control operational amplifier functions.
	OPAMP_UserInit	Performs user-defined initialization relating to the operational amplifier.
	AMPn_Start	Starts the operation of operational amplifier <i>n</i> (single AMP mode).
	AMPn_Stop	Ends the operation of operational amplifier <i>n</i> (single AMP mode).
Comparator/PGA	CMPPGA_Init	Performs initialization necessary to control comparator/programmable gain amplifiers functions.
	CMPPGA_UserInit	Performs user-defined initialization relating to the comparator/programmable gain amplifiers.
	CMPPGA_PowerOff	Halts the clock supplied to the comparator/programmable gain amplifiers.
	CMPPGA_Start	Starts the operation of comparator/programmable gain amplifier.
	CMPPGA_Stop	Ends the operation of comparator/programmable gain amplifier.
	CMPPGA_ChangeCMPnRefVoltage	Sets comparator <i>n</i> internal reference voltage.
	CMPPGA_ChangePGAFactor	Sets the input voltage amplification factor of a programmable gain amplifier.
A/D	AD_Init	Performs initialization necessary to control A/D converter functions.
	AD_UserInit	Performs user-defined initialization relating to the A/D converter.
	AD_PowerOff	Halts the clock supplied to the A/D converter.
	AD_ComparatorOn	Enables operation of voltage converter.
	AD_ComparatorOff	Disables operation of voltage converter.
	AD_Start	Starts A/D conversion.
	AD_Stop	Ends A/D conversion.
	AD_SelectADChannel	Configures the analog voltage input pin for A/D conversion.
	AD_Read	Reads the results of A/D conversion.
	AD_ReadByte	Reads the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution).
D/A	DA_Init	Performs initialization necessary to control D/A converter functions.
	DA_UserInit	Performs user-defined initialization relating to the D/A converter.
	DA_PowerOff	Halts the clock supplied to the D/A converter.
	DAn_Start	Starts D/A conversion.

Peripheral Function	API Function Name	Function
D/A	DAn_Stop	Ends D/A conversion.
	DAn_SetValue	Sets the initial analog voltage output to the ANOn pin.
	DAn_Set8BitsValue	Sets the initial analog voltage (8 bits) output to the ANOn pin.
	DAn_Set12BitsValue	Sets the initial analog voltage (12 bits) output to the ANOn pin.
Timer	TAUm_Init	Performs initialization necessary to control timer array unit functions.
	TAUm_UserInit	Performs user-defined initialization relating to the timer array unit.
	TAUm_PowerOff	Halts the clock supplied to the timer array unit.
	TAUm_Channeln_Start	Starts the count for channel <i>n</i> .
	TAUm_Channeln_Stop	Ends the count for channel <i>n</i> .
	TAUm_Channeln_ChangeCondition	Changes the counter value.
	TAUm_Channeln_ChangeTimerCondition	Changes the counter value.
	TAUm_Channeln_GetPulseWidth	Captures the high/low-level width measured between pulses of the signal (pulses) input to the TImn pin.
	TAUm_Channeln_ChangeDuty	Changes the duty ratio of the PWM signal output to the TOmn pin.
	TAUm_Channeln_SoftWareTriggerOn	Generates the trigger (software trigger) for one-shot pulse output.
Watchdog Timer	WDT_Init	Performs initialization necessary to control watchdog timer functions.
	WDT_UserInit	Performs user-defined initialization relating to the watchdog timer.
	WDT_Restart	Clears the watchdog timer counter and resumes counting.
RTC	RTC_Init	Performs initialization necessary to control real-time counter functions.
	RTC_UserInit	Performs user-defined initialization relating to the real-time counter.
	RTC_PowerOff	Halts the clock supplied to the real-time counter.
	RTC_CounterEnable	Starts the count of the real-time counter (year, month, weekday, day, hour, minute, second).
	RTC_CounterDisable	Ends the count of the real-time counter (year, month, weekday, day, hour, minute, second).
	RTC_SetHourSystem	Sets the clock type (12-hour or 24-hour clock) of the real-time counter.
	RTC_CounterSet	Sets the counter value (year, month, weekday, day, hour, minute, second) of the real-time counter.
	RTC_CounterGet	Reads the counter value (year, month, weekday, day, hour, minute, second) of the real-time counter.

Peripheral Function	API Function Name	Function
RTC	<a href="#">RTC_ConstPeriodInterruptEnable</a>	Sets the cycle of the interrupts INTRTC, then starts the cyclic interrupt function.
	<a href="#">RTC_ConstPeriodInterruptDisable</a>	Ends the cyclic interrupt function.
	<a href="#">RTC_ConstPeriodInterruptCallback</a>	Performs processing in response to the cyclic interrupt INTRTC.
	<a href="#">RTC_AlarmEnable</a>	Starts the alarm interrupt function.
	<a href="#">RTC_AlarmDisable</a>	Ends the alarm interrupt function.
	<a href="#">RTC_AlarmSet</a>	Sets the alarm conditions (weekday, hour, minute).
	<a href="#">RTC_AlarmGet</a>	Reads the alarm conditions (weekday, hour, minute).
	<a href="#">RTC_AlarmInterruptCallback</a>	Performs processing in response to the alarm interrupt INTRTC.
	<a href="#">RTC_IntervalStart</a>	Starts the interval interrupt function.
	<a href="#">RTC_IntervalStop</a>	Ends the interval interrupt function.
	<a href="#">RTC_IntervalInterruptEnable</a>	Sets the cycle of the interrupts INTRTCI, then starts the interval interrupt function.
	<a href="#">RTC_IntervalInterruptDisable</a>	Ends the interval interrupt function.
	<a href="#">RTC_RTC1HZ_OutputEnable</a>	Enables output of the real-time counter correction clock (1 Hz) to the RTC1HZ pin.
	<a href="#">RTC_RTC1HZ_OutputDisable</a>	Disables output of the real-time counter correction clock (1 Hz) to the RTC1HZ pin.
	<a href="#">RTC_RTCCL_OutputEnable</a>	Enables output of the real-time counter clock (32 kHz source) to the RTCCL pin.
	<a href="#">RTC_RTCCL_OutputDisable</a>	Disables output of the real-time counter clock (32 kHz source) to the RTCCL pin.
	<a href="#">RTC_RTCDIV_OutputEnable</a>	Enables output of the real-time counter clock (32 kHz cycle) to the RTCDIV pin.
	<a href="#">RTC_RTCDIV_OutputDisable</a>	Disables output of the real-time counter clock (32 kHz cycle) to the RTCDIV pin.
<a href="#">RTC_ChangeCorrectionValue</a>	Changes the timing and correction value for correcting clock errors.	
Clock Output	<a href="#">PCL_Init</a>	Performs initialization necessary to control clock output control circuit functions.
	<a href="#">PCL_UserInit</a>	Performs user-defined initialization relating to the clock output control circuits.
	<a href="#">PCL_Start</a>	Starts clock output.
	<a href="#">PCL_Stop</a>	Ends clock output.
	<a href="#">PCL_ChangeFreq</a>	Changes the output clock to the PCL pin.
Clock Output/Buzzer Output	<a href="#">PCLBUZn_Init</a>	Performs initialization necessary to control clock/buzzer output control circuit functions.
	<a href="#">PCLBUZn_UserInit</a>	Performs user-defined initialization relating to the clock/buzzer output control circuits.
	<a href="#">PCLBUZn_Start</a>	Starts clock/buzzer output.




Peripheral Function	API Function Name	Function
Clock Output/Buzzer Output	PCLBUZn_Stop	Ends clock/buzzer output.
	PCLBUZn_ChangeFreq	Changes the output clock to the PCLBUZn pin.
LCD Controller/Driver	LCD_Init	Performs initialization necessary to control LCD controller/driver functions.
	LCD_UserInit	Performs user-defined initialization relating to the LCD controller/driver.
	LCD_DisplayOn	Sets the LCD controller/driver to "display on" status.
	LCD_DisplayOff	Sets the LCD controller/driver to "display off" status.
	LCD_VoltageOn	Enables operation of the LCD controller/driver's voltage boost circuit and capacitor split circuit, then outputs the deselect signal from the segment pin.
	LCD_VoltageOff	Halts operation of the LCD controller/driver's voltage boost circuit and capacitor split circuit, then outputs the groundlevel signal from the segment/common pin.
DMA	DMA <sub>n</sub> _Init	Performs initialization necessary to control DMA controller functions.
	DMA <sub>n</sub> _UserInit	Performs user-defined initialization relating to the DMA controller.
	DMA <sub>n</sub> _Enable	Enables operation of channel <i>n</i> .
	DMA <sub>n</sub> _Disable	Disables operation of channel <i>n</i> .
	DMA <sub>n</sub> _Hold	Holds a DMA start request.
	DMA <sub>n</sub> _Restart	Releases hold on a DMA start request.
	DMA <sub>n</sub> _CheckStatus	Reads the transfer status (transfer complete/transfer ongoing).
	DMA <sub>n</sub> _SetData	Sets the RAM address of the transfer source/destination, and the number of times the data has been transferred.
	DMA <sub>n</sub> _SoftwareTriggerOn	Starts DMA transfer when DMA operation is enabled.
LVI	LVI_Init	Performs initialization necessary to control low-voltage detector functions.
	LVI_UserInit	Performs user-defined initialization relating to the low-voltage detector.
	LVI_InterruptModeStart	Starts low-voltage detection (when in interrupt generation mode).
	LVI_ResetModeStart	Starts low-voltage detection (when in internal reset mode).
	LVI_Stop	Stops low-voltage detection.
	LVI_SetLVILevel	Sets the low-voltage detection level.

C.3 Function Reference

This section describes the API functions output by Code Generator, using the following notation format.

Figure C-1. Notation Format of API Functions



(1) **Name**

Indicates the name of the API function.

(2) **Outline**

Outlines the functions of the API function.

(3) **[Classification]**

Indicates the name of the C source file to which the API function is output.

(4) **[Syntax]**

Indicates the format to be used when describing an API function to be called in C language.

**(5) [Argument(s)]**

API function arguments are explained in the following format.

I/O	Argument	Description
(a)	(b)	(c)

**(a) I/O**

Argument classification

I ... Input argument

O ... Output argument

**(b) Argument**

Argument data type

**(c) Description**

Description of argument

**(6) [Return value]**

API function return value is explained in the following format.

Macro	Description
(a)	(b)

**(a) Macro**

Macro of return value

**(b) Description**

Description of return value

**(7) [Example]**

Shows an example of the API function in use.

C.3.1 System

Below is a list of API functions output by Code Generator for system use.

**Table C-2. API Functions: [System]**

API Function Name	Function
CLOCK_Init	Performs initialization required to control the clock generator, on-chip debug, and etc. .
CLOCK_UserInit	Performs user-defined initialization relating to the clock generator, on-chip debug, and etc. .
CG_ReadResetSource	Performs processing in response to RESET signal.
CG_ChangeClockMode	Changes the CPU clock/peripheral hardware clock.
CG_ChangeFrequency	Changes the division ratio of the CPU clock/peripheral hardware clock.
CG_SelectPowerSaveMode	Configures the CPU's standby function.
CG_SelectStabTime	Configures the oscillation stabilization time of the X1 clock.

**CLOCK\_Init**

Performs initialization required to control the clock generator, on-chip debug and etc. .

**[Classification]**

CG\_system.c

**[Syntax]**

```
void    CLOCK_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**CLOCK\_UserInit**

Performs user-defined initialization relating to the clock generator, on-chip debug, and etc. .

**Remark** This API function is called as the [CLOCK\\_Init](#) callback routine.

**[Classification]**

CG\_system\_user.c

**[Syntax]**

```
void    CLOCK_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**CG\_ReadResetSource**

Performs processing in response to RESET signal.

**[Classification]**

CG\_system\_user.c

**[Syntax]**

```
void CG_ReadResetSource ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**[Example]**

Below are examples of the different processes executing depending on the RESET signal trigger.

[CG\_Systeminit.c]

```
void systeminit ( void ) {
    CG_ReadResetSource ();      /* Processes executed by RESET signal trigger */
    .....
}
```

[CG\_system\_user.c]

```
#include "CG_macrodriver.h"
void CG_ReadResetSource ( void ) {
    UCHAR flag = RESF;          /* Reset control flag register: Obtain RESF contents */
    if ( flag & 0x1 ) {         /* Trigger identification: Check LVIRF flag */
        ..... /* Internal reset request by low-voltage detector */
    } else if ( flag & 0x10 ) { /* Trigger identification: Check WDRF flag */
        ..... /* Internal reset request by watchdog timer */
    } else if ( flag & 0x80 ) { /* Trigger identification: Check TRAP flag */
        ..... /* Internal reset request by execution of illegal instruction */
    }
    .....
}
```

**CG\_ChangeClockMode**

Changes the CPU clock/peripheral hardware clock.

**[Classification]**

CG\_system.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_system.h"
MD_STATUS CG_ChangeClockMode ( enum ClockMode mode );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum ClockMode mode;	<p>Clock generator type</p> <p>[Fx3]</p> <p>HIOCLK: Internal high-speed oscillation clock</p> <p>SYSX1CLK: X1 clock</p> <p>SYSEXTCLK: External main system clock</p> <p>FILCLK: Internal low-speed oscillation clock</p> <p>[lx3]</p> <p>HIOCLK: Internal high-speed oscillation clock</p> <p>HIO40CLK: 40 MHz internal high-speed oscillation clock</p> <p>SYSX1CLK: X1 clock</p> <p>SYSEXTCLK: External main system clock</p> <p>SUBCLK: Subsystem clock</p> <p>[Kx3]</p> <p>HIOCLK: Internal high-speed oscillation clock</p> <p>SYSX1CLK: X1 clock</p> <p>SYSEXTCLK: External main system clock</p> <p>SUBCLK: Subsystem clock</p> <p>[Kx3-A] [Kx3-L] [Lx3]</p> <p>HIOCLK: Internal high-speed oscillation clock</p> <p>HIO20CLK: 20 MHz internal high-speed oscillation clock</p> <p>SYSX1CLK: X1 clock</p> <p>SYSEXTCLK: External main system clock</p> <p>SUBCLK: Subsystem clock</p>

**[Return value]**

Macro	Description
MD_OK	Normal completion



Macro	Description
MD_ERROR1	Exit with error (abend) [Fx3] [Kx3] - Cannot change to the X1 clock. Exit with error (abend) [Ix3] - Cannot change to the 40 MHz internal high-speed oscillation clock. Exit with error (abend) [Kx3-A] [Kx3-L] [Lx3] - Cannot change to the 20 MHz internal high-speed oscillation clock.
MD_ERROR2	Exit with error (abend) [Fx3] [Kx3] - Cannot change to the external main system clock. Exit with error (abend) [Ix3] [Kx3-A] [Kx3-L] [Lx3] - Cannot change to the X1 clock.
MD_ERROR3	Exit with error (abend) [Fx3] - Cannot change to the internal low-speed oscillation clock. Exit with error (abend) [Ix3] [Kx3-A] [Kx3-L] [Lx3] - Cannot change to the external main system clock. Exit with error (abend) [Kx3] - Cannot change to the subsystem clock because the XT1 and XT2 pins are in input mode.
MD_ERROR4	Exit with error (abend) [Ix3] [Kx3-A] [Kx3-L] [Lx3] - Cannot change to the subsystem clock.
MD_ARGERROR	Invalid argument specification

**CG\_ChangeFrequency**

Changes the division ratio of the CPU clock/peripheral hardware clock.

**[Classification]**

CG\_system.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_system.h"
MD_STATUS CG_ChangeFrequency ( enum CPUClock clock );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum CPUClock <i>clock</i> ;	Division ratio type [Fx3] SYSTEMCLOCK: fPLL SYSONEHALF: fPLL/2 SYSONEFOURTH: fPLL/4 SYSONEIGHTH: fPLL/8 SYSONESIXTEENTH: fPLL/16 SYSONETHIRTYSECOND: fPLL/32 [Ix3] [Kx3] [Kx3-L] SYSTEMCLOCK: fMAIN SYSONEHALF: fMAIN/2 SYSONEFOURTH: fMAIN/4 SYSONEIGHTH: fMAIN/8 SYSONESIXTEENTH: fMAIN/16 SYSONETHIRTYSECOND: fMAIN/32 [Kx3-A] [Lx3] SYSTEMCLOCK: fMAIN SYSONEHALF: fMAIN/2 SYSONEFOURTH: fMAIN/4 SYSONEIGHTH: fMAIN/8 SYSONESIXTEENTH: fMAIN/16 SYSONETHIRTYSECOND: fMAIN/32 SUB: fSUB SUBONEHALF: fSUB/2

**Remark** "fPLL" signifies the frequency of the PLL clock, "fMAIN" signifies the frequency of the main system clock, and "fSUB" signifies the frequency of the subsystem clock.

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**CG\_SelectPowerSaveMode**

Configures the CPU's standby function.

**[Classification]**

CG\_system.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_system.h"
MD_STATUS CG_SelectPowerSaveMode ( enum PSLevel level );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum PSLevel level;	Standby function type PSSTOP: STOP mode PSHALT: HALT mode

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR	Exit with error (abend) - If the CPU is operating by a subsystem clock (XT1 oscillator), then STOP mode cannot be specified.
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of changing the standby function to "STOP mode".

[CG\_main.c]

```
#include "CG_macrodriver.h"
#include "CG_system.h"
void main ( void ) {
    MD_STATUS ret;
    .....
    TAU0_PowerOff (); /* Stop clock supply */
    ret = CG_SelectPowerSaveMode ( PSSTOP ); /* Change to STOP mode */
    if ( ret != MD_OK ) {
        while ( 1 );
    }
    TAU0_Init (); /* Initialize timer array unit */
```

```
TAU0_Channel0_Start ();           /* Starts the channel 0 count */  
.....  
}
```

**CG\_SelectStabTime**

Configures the oscillation stabilization time of the X1 clock.

**[Classification]**

CG\_system.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_system.h"
MD_STATUS CG_SelectStabTime ( enum StabTime waittime );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum StabTime <i>waittime</i> ;	Oscillation stabilization time type STLEVEL0: 2 <sup>8</sup> /fx STLEVEL1: 2 <sup>9</sup> /fx STLEVEL2: 2 <sup>10</sup> /fx STLEVEL3: 2 <sup>11</sup> /fx STLEVEL4: 2 <sup>13</sup> /fx STLEVEL5: 2 <sup>15</sup> /fx STLEVEL6: 2 <sup>17</sup> /fx STLEVEL7: 2 <sup>18</sup> /fx

**Remark** "fx" signifies the frequency of the X1 clock.

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**C.3.2 External Bus**

Below is a list of API functions output by Code Generator for external bus interface use.

**Table C-3. API Functions: [External Bus]**

API Function Name	Function
<a href="#">BUS_Init</a>	Performs initialization necessary to control external bus interface functions (functions to connect an external bus to areas other than onboard ROM, ROM and RAM).
<a href="#">BUS_UserInit</a>	Performs user-defined initialization relating to the external bus interface.
<a href="#">BUS_PowerOff</a>	Halts the clock supplied to the external bus interface.

**BUS\_Init**

Performs initialization necessary to control external bus interface functions (functions to connect an external bus to areas other than onboard ROM, ROM and RAM).

**[Classification]**

CG\_bus.c

**[Syntax]**

```
void    BUS_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**BUS\_UserInit**

Performs user-defined initialization relating to the external bus interface.

**Remark** This API function is called as the [BUS\\_Init](#) callback routine.

**[Classification]**

CG\_bus\_user.c

**[Syntax]**

```
void    BUS_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**BUS\_PowerOff**

Halts the clock supplied to the external bus interface.

**Remark** Calling this API function changes the external bus interface to reset status. For this reason, writes to the control registers (memory extension mode control register: MEM) after this API function is called are ignored.

**[Classification]**

CG\_bus.c

**[Syntax]**

```
void BUS_PowerOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**C.3.3 Port**

Below is a list of API functions output by Code Generator for port use.

**Table C-4. API Functions: [Port]**

API Function Name	Function
<a href="#">PORT_Init</a>	Performs initialization necessary to control port functions.
<a href="#">PORT_UserInit</a>	Performs user-defined initialization relating to the port.
<a href="#">PORT_ChangePmnInput</a>	Switches the pin's I/O mode from output mode to input mode.
<a href="#">PORT_ChangePmnOutput</a>	Switches the pin's I/O mode from input mode to output mode.

**PORT\_Init**

Performs initialization necessary to control port functions.

**[Classification]**

CG\_port.c

**[Syntax]**

```
void PORT_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**PORT\_UserInit**

Performs user-defined initialization relating to the port.

**Remark** This API function is called as the [PORT\\_Init](#) callback routine.

**[Classification]**

CG\_port\_user.c

**[Syntax]**

```
void PORT_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**PORT\_ChangePmnInput**

Switches the pin's I/O mode from output mode to input mode.

**[Classification]**

CG\_port.c

**[Syntax]**

The format for specifying this API function differs according to whether the target pin has built-in pull-up resistance/a TLL input buffer.

- Built-in pull-up resistance: none; TLL input buffer: none

```
void PORT_ChangePmnInput ( void );
```

- Built-in pull-up resistance: yes; TLL input buffer: none

```
#include "CG_macrodriver.h"
void PORT_ChangePmnInput ( BOOL enablepu );
```

- Built-in pull-up resistance: yes; TLL input buffer: yes

```
#include "CG_macrodriver.h"
void PORT_ChangePmnInput ( BOOL enablepu, BOOL enablettl );
```

**Remark** *mn* is the port number.

**[Argument(s)]**

I/O	Argument	Description
I	BOOL <i>enablepu</i> ;	Built-in pull-up resistance used MD_TRUE: Yes MD_FALSE: No
I	BOOL <i>enablettl</i> ;	Input buffer type MD_TRUE: TTL input buffer MD_FALSE: Normal input buffer

**[Return value]**

None.

**[Example 1]**

Below is shown an example where pin P00 (built-in pull-up resistance: yes; TLL input buffer: none) is changed as follows:

I/O mode type:                      Input mode  
Built-in pull-up resistance used:    Yes

[CG\_main.c]

```

#include    "CG_macrodriver.h"
void main ( void ) {
    .....
    PORT_ChangeP00Input ( MD_TRUE );    /* Switch I/O mode */
    .....
}

```

**[Example 2]**

Below is shown an example where pin P00 (built-in pull-up resistance: yes; TLL input buffer: none) is changed as follows:

I/O mode type:	Input mode
Built-in pull-up resistance used:	No

[CG\_main.c]

```

#include    "CG_macrodriver.h"
void main ( void ) {
    .....
    PORT_ChangeP00Input ( MD_FALSE );    /* Switch I/O mode */
    .....
}

```

**[Example 3]**

Below is shown an example where pin P04 (built-in pull-up resistance: yes; TLL input buffer: yes) is changed as follows:

I/O mode type:	Input mode
Built-in pull-up resistance used:	No
Input buffer type:	TTL input buffer

[CG\_main.c]

```

#include    "CG_macrodriver.h"
void main ( void ) {
    .....
    PORT_ChangeP04Input ( MD_FALSE, MD_TRUE );    /* Switch I/O mode */
    .....
}

```

**PORT\_ChangePmnOutput**

Switches the pin's I/O mode from input mode to output mode.

**[Classification]**

CG\_port.c

**[Syntax]**

If the target device is a 78K0R/Fx3, then the format for specifying this API function differs depending on whether N-ch open-drain output is being performed via the target pin, and whether slow mode is specified.

- N-ch open drain output: none; Slow mode: none [Fx3]

```
#include    "CG_macrodriver.h"
void    PORT_ChangePmnOutput ( BOOL initialvalue );
```

- N-ch open drain output: yes; Slow mode: none [Fx3]

```
#include    "CG_macrodriver.h"
void    PORT_ChangePmnOutput ( BOOL enablench, BOOL initialvalue );
```

- N-ch open drain output: none; Slow mode: yes [Fx3]

```
#include    "CG_macrodriver.h"
void    PORT_ChangePmnOutput ( BOOL enableslow, BOOL initialvalue );
```

- N-ch open drain output: yes; Slow mode: yes [Fx3]

```
#include    "CG_macrodriver.h"
void    PORT_ChangePmnOutput ( BOOL enablench, BOOL enableslow, BOOL initialvalue );
```

If the target device is 78K0R/lx3, 78K0R/Kx3, 78K0R/Kx3-A, 78K0R/Kx3-L or 78K0R/Lx3, then the format for specifying this API function differs according to whether the target pin conducts N-ch open drain output.

- N-ch open drain output: none [lx3] [Kx3] [Kx3-A] [Kx3-L] [Lx3]

```
#include    "CG_macrodriver.h"
void    PORT_ChangePmnOutput ( BOOL initialvalue );
```

- N-ch open drain output: yes [lx3] [Kx3] [Kx3-A] [Kx3-L] [Lx3]

```
#include    "CG_macrodriver.h"
void    PORT_ChangePmnOutput ( BOOL enablench, BOOL initialvalue );
```

**Remark** *nm* is the port number.



**[Argument(s)]**

I/O	Argument	Description
I	BOOL <i>enablench;</i>	Output mode type MD_TRUE: N-ch open drain output (VDD withstand voltage) mode MD_FALSE: Normal output mode
I	BOOL <i>enableslow;</i>	Output mode type MD_TRUE: Slow mode MD_FALSE: Normal mode
I	BOOL <i>initialvalue;</i>	Initial output value MD_SET: Output HIGH level "1" MD_CLEAR: Output LOW level "0"

**[Return value]**

None.

**[Example 1]**

Below is shown an example where pin P00 (N-ch open drain output: none) is changed as follows:

I/O mode type: Output mode  
Initial output value: Output HIGH level "1"

[CG\_main.c]

```
#include "CG_macrodriver.h"
void main ( void ) {
    .....
    PORT_ChangeP00Output ( MD_SET ); /* Switch I/O mode */
    .....
}
```

**[Example 2]**

Below is shown an example where pin P04 (N-ch open drain output: yes) is changed as follows:

I/O mode type: Output mode  
Output mode type: N-ch open drain output (VDD withstand voltage) mode  
Initial output value: Output LOW level "0"

[CG\_main.c]

```
#include "CG_macrodriver.h"
void main ( void ) {
    .....
    PORT_ChangeP04Output ( MD_TRUE, MD_CLEAR ); /* Switch I/O mode */
    .....
}
```

## C.3.4 INT

Below is a list of API functions output by Code Generator for interrupt and key interrupt use.

**Table C-5. API Functions: [INT]**

API Function Name	Function
INTP_Init	Performs initialization necessary to control the external interrupt INTP $n$ functions.
INTP_UserInit	Performs user-defined initialization relating to the external interrupt INTP $n$ functions.
KEY_Init	Performs initialization necessary to control the key interrupt INTKR functions.
KEY_UserInit	Performs user-defined initialization relating to the key interrupt INTKR functions.
INT_MaskableInterruptEnable	Disables/enables the acceptance of the maskable interrupts.
INTPn_Disable	Disables the acceptance of the maskable interrupts INTP $n$ (external interrupt requests).
INTPn_Enable	Enables the acceptance of the maskable interrupts INTP $n$ (external interrupt requests).
KEY_Disable	Disables the acceptance of the key interrupts INTKR.
KEY_Enable	Enables the acceptance of the key interrupts INTKR.

**INTP\_Init**

Performs initialization necessary to control the external interrupt INTP $n$  functions.

**[Classification]**

CG\_int.c

**[Syntax]**

```
void    INTP_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**INTP\_UserInit**

Performs user-defined initialization relating to the external interrupt INTP $n$  functions.

**Remark** This API function is called as the [INTP\\_Init](#) callback routine.

**[Classification]**

CG\_int\_user.c

**[Syntax]**

```
void    INTP_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**KEY\_Init**

Performs initialization necessary to control the key interrupt INTKR functions.

**[Classification]**

CG\_int.c

**[Syntax]**

```
void KEY_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**KEY\_UserInit**

Performs user-defined initialization relating to the key interrupt INTKR functions.

**Remark** This API function is called as the [KEY\\_Init](#) callback routine.

**[Classification]**

CG\_int\_user.c

**[Syntax]**

```
void KEY_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**INT\_MaskableInterruptEnable**

Disables/enables the acceptance of the maskable interrupts.

**[Classification]**

CG\_int.c

**[Syntax]**

- [Fx3] [Ix3] [Kx3-A] [Kx3-L] [Lx3]

```
#include "CG_macrodriver.h"
#include "CG_int.h"
MD_STATUS INT_MaskableInterruptEnable ( enum MaskableSource name, BOOL enableflag );
```

- [Kx3]

```
#include "CG_macrodriver.h"
#include "CG_int.h"
void INT_MaskableInterruptEnable ( enum MaskableSource name, BOOL enableflag );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum MaskableSource name;	Maskable interrupt type INT_xxx: Maskable interrupt
I	BOOL enableflag;	Acceptance enabled/disabled MD_TRUE: Acceptance enabled MD_FALSE: Acceptance disabled

**Remark** See the header file CG\_int.h for details about the maskable interrupt type INT\_xxx.

**[Return value]**

- [Fx3] [Ix3] [Kx3-A] [Kx3-L] [Lx3]

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

- [Kx3]

None.

**[Example 1]**

Below is an example of disabling acceptance of the maskable interrupt INTP0.

[CG\_main.c]

```
#include "CG_macrodriver.h"
#include "CG_int.h"
void main ( void ) {
    .....
    INT_MaskableInterruptEnable ( INT_INTP0, MD_FALSE ); /* Disable acceptance of maskable
interrupt INTP0 */
    .....
}
```

**[Example 2]**

Below is an example of enabling acceptance of the maskable interrupt INTP0.

[CG\_main.c]

```
#include "CG_macrodriver.h"
#include "CG_int.h"
void main ( void ) {
    .....
    INT_MaskableInterruptEnable ( INT_INTP0, MD_TRUE ); /* Enable acceptance of maskable
interrupt INTP0 */
    .....
}
```



**INTP $n$ \_Disable**

Disables the acceptance of the maskable interrupts INTP $n$  (external interrupt requests).

**[Classification]**

CG\_int.c

**[Syntax]**

```
void    INTP $n$ _Disable ( void );
```

**Remark**  $n$  is the interrupt factor number.

**[Argument(s)]**

None.

**[Return value]**

None.

**INTP $n$ \_Enable**

Enables the acceptance of the maskable interrupts INTP $n$  (external interrupt requests).

**[Classification]**

CG\_int.c

**[Syntax]**

```
void    INTP $n$ _Enable ( void );
```

**Remark**  $n$  is the interrupt factor number.

**[Argument(s)]**

None.

**[Return value]**

None.

**KEY\_Disable**

Disables the acceptance of the key interrupts INTKR.

**[Classification]**

CG\_int.c

**[Syntax]**

```
void KEY_Disable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**KEY\_Enable**

Enables the acceptance of the key interrupts INTKR.

**[Classification]**

CG\_int.c

**[Syntax]**

```
void KEY_Enable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

## C.3.5 Serial

Below is a list of API functions output by Code Generator for serial array unit and serial interface use.

Table C-6. API Functions: [Serial]

API Function Name	Function
SAUm_Init	Performs initialization necessary to control the serial array unit and serial interface functions.
SAUm_UserInit	Performs user-defined initialization related to the serial array unit and serial interface functions.
SAUm_PowerOff	Halts the clock supplied to the serial array unit.
UARTn_Init	Performs initialization of the serial interface (UART) channel.
UARTn_Start	Sets UART communication to standby mode.
UARTn_Stop	Ends UART communication.
UARTn_SendData	Starts UART data transmission.
UARTn_ReceiveData	Starts UART data reception.
UARTn_SendEndCallback	Performs processing in response to the UART transmission complete interrupt INTST <i>n</i> .
UARTn_ReceiveEndCallback	Performs processing in response to the UART reception complete interrupt INTSR <i>n</i> .
UARTn_SoftOverRunCallback	Performs processing in response to the serial transfer end interrupt INTSR <i>n</i> .
UARTn_ErrorCallback	Performs processing in response to the UART communication error interrupt INTSRE <i>n</i> .
CSImn_Init	Performs initialization of the serial interface (CSI) channel.
CSImn_Start	Sets CSI communication to standby mode.
CSImn_Stop	Ends CSI communication.
CSImn_SendData	Starts CSI data transmission.
CSImn_ReceiveData	Starts CSI data reception.
CSImn_SendReceiveData	Starts CSI data transmission/reception.
CSImn_SendEndCallback	Performs processing in response to the CSI communication complete interrupt INTCSImn.
CSImn_ReceiveEndCallback	Performs processing in response to the CSI communication complete interrupt INTCSImn.
CSImn_ErrorCallback	Performs processing in response to the CSI communication error interrupt INTSRE <i>n</i> .
IICmn_Init	Performs initialization of the serial interface (simple IIC) channel.
IICmn_Stop	Ends simple IIC communication.
IICmn_MasterSendStart	Starts simple IIC master transmission.
IICmn_MasterReceiveStart	Starts simple IIC master reception.
IICmn_StartCondition	Generates start conditions.
IICmn_StopCondition	Generates stop conditions.
IICmn_MasterSendEndCallback	Performs processing in response to the simple IIC <i>mn</i> communication complete interrupt INTIICmn.
IICmn_MasterReceiveEndCallback	Performs processing in response to the simple IIC <i>mn</i> communication complete interrupt INTIICmn.

API Function Name	Function
IICmn_MasterErrorCallback	Performs processing in response to detection of parity error (ACK error) in simple IIC communication.
UARTFn_Init	Performs initialization of the serial interface (UARTFn).
UARTFn_PowerOff	Halts the clock supplied to the serial interface (UARTFn).
UARTFn_Start	Sets UARTF communication to standby mode.
UARTFn_Stop	Ends UARTF communication.
UARTFn_SendData	Starts UARTF data transmission.
UARTFn_ReceiveData	Starts UARTF data reception.
UARTFn_SetComparisonData	Sets the data to compare to the received data.
UARTFn_DataComparisonEnable	Starts the data comparison.
UARTFn_DataComparisonDisable	Ends the data comparison.
UARTFn_SendEndCallback	Performs processing in response to the transmission interrupt INTLTn.
UARTFn_ReceiveEndCallback	Performs processing in response to the reception complete interrupt INTLRn.
UARTFn_SoftOverRunCallback	Performs processing in response to the reception complete interrupt INTLRn.
UARTFn_ExpBitCetectCallback	Performs processing in response to the status interrupt INTLSn.
UARTFn_IDMatchCallback	Performs processing in response to the status interrupt INTLSn.
UARTFn_ErrorCallback	Performs processing in response to the status interrupt INTLSn.
IICA_Init	Performs initialization of the serial interface (IICA).
IICA_UserInit	Performs user-defined initialization of the serial interface (IICA).
IICA_PowerOff	Halts the clock supplied to the serial interface (IICA).
IICA_Stop	Ends IICA communication.
IICA_MasterSendStart	Starts IICA master transmission.
IICA_MasterReceiveStart	Starts IICA master reception.
IICA_StopCondition	Generates stop conditions.
IICA_MasterSendEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
IICA_MasterReceiveEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
IICA_MasterErrorCallback	Performs processing in response to detection of error in IICA master communication.
IICA_SlaveSendStart	Starts IICA slave transmission.
IICA_SlaveReceiveStart	Starts IICA slave reception.
IICA_SlaveSendEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
IICA_SlaveReceiveEndCallback	Performs processing in response to the IICA communication complete interrupt INTIICA.
IICA_SlaveErrorCallback	Performs processing in response to detection of error in IICA slave communication.
IICA_GetStopConditionCallback	Performs processing in response to detection of stop condition in IICA slave communication.
IICn_Init	Performs initialization of the serial interface (IICn).

API Function Name	Function
IICn_UserInit	Performs user-defined initialization of the serial interface (IICn).
IICn_Stop	Ends IICn communication.
IICn_MasterSendStart	Starts IICn master transmission.
IICn_MasterReceiveStart	Starts IICn master reception.
IICn_MasterSendEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
IICn_MasterReceiveEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
IICn_MasterErrorCallback	Performs processing in response to detection of error in IICn master communication.
IICn_SlaveSendStart	Starts IICn slave transmission.
IICn_SlaveReceiveStart	Starts IICn slave reception.
IICn_SlaveSendEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
IICn_SlaveReceiveEndCallback	Performs processing in response to the IICn communication complete interrupt INTIICn.
IICn_SlaveErrorCallback	Performs processing in response to detection of error in IICn slave communication.
IICn_GetStopConditionCallback	Performs processing in response to detection of stop condition in IICn slave communication.

**SAUm\_Init**

Performs initialization necessary to control the serial array unit and serial interface functions.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void SAUm_Init ( void );
```

**Remark** *m* is the unit number.

**[Argument(s)]**

None.

**[Return value]**

None.



**SAUm\_UserInit**

Performs user-defined initialization related to the serial array unit and serial interface functions.

**Remark** This API function is called as the [SAUm\\_Init](#) callback routine.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void SAUm_UserInit ( void );
```

**Remark** *m* is the unit number.

**[Argument(s)]**

None.

**[Return value]**

None.

**SAUm\_PowerOff**

Halts the clock supplied to the serial array unit.

**Remark** Calling this API function changes the serial array unit to reset status. For this reason, writes to the control registers (e.g. serial clock select register  $n$ : SPS $n$ ) after this API function is called are ignored.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void SAUm_PowerOff ( void );
```

**Remark**  $m$  is the unit number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UART $n$ \_Init**

Performs initialization of the serial interface (UART) channel.

**Remark** This API function is used as an internal function of [SAUm\\_Init](#). For this reason, there is normally no need to call it from a user program.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void    UARTn_Init ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UART $n$ \_Start**

Sets UART communication to standby mode.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void UARTn_Start ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UART $n$ \_Stop**

Ends UART communication.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void    UARTn_Stop ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UART<sub>n</sub>\_SendData**

Starts UART data transmission.

- Remarks 1.** This API function repeats the byte-level UART transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** When performing a UART transmission, [UART<sub>n</sub>\\_Start](#) must be called before this API function is called.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS UARTn_SendData ( UCHAR *txbuf, USHORT txnum );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of sending a UART transmission of four bytes of fixed-length data from channel 0 one time.

[CG\_main.c]

```
#include "CG_macrodriver.h"
BOOL gFlag; /* Transmission complete flag */
void main ( void ) {
    UCHAR txbuf[] = "ABCD";
    USHORT txnum = 4;
    gFlag = 1; /* Initialize transmission complete flag */
    .....
    UART0_Start (); /* Start UART communication*/
    UART0_SendData ( &txbuf, txnum ); /* Start UART data transmission */
    while ( gFlag ); /* Wait for txnum transmissions */
```

```
.....  
}
```

[CG\_serial\_user.c]

```
#include "CG_macrodriver.h"  
extern BOOL gFlag; /* Transmission complete flag */  
__interrupt void MD_INTST0 ( void ) { /* Interrupt processing for INTST0 */  
    if ( gUart0TxCnt > 0 ) {  
        .....  
    } else {  
        UART0_SendEndCallback (); /* Call callback routine */  
    }  
}  
  
void UART0_SendEndCallback ( void ) { /* Callback routine for INTST0 */  
    gFlag = 0; /* Set transmission complete flag */  
}
```

**UART $n$ \_ReceiveData**

Starts UART data reception.

- Remarks 1.** This API function performs byte-level UART reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 2.** Actual UART reception starts after this API function is called, and [UART \$n\$ \\_Start](#) is then called.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS UARTn_ReceiveData ( UCHAR *rxbuf, USHORT rxnum );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of UART reception of four bytes of fixed-length data from channel 0 one time.

[CG\_main.c]

```
#include "CG_macrodriver.h"
BOOL gFlag; /* Reception complete flag */
void main ( void ) {
    UCHAR rxbuf[10];
    USHORT rxnum = 4;
    gFlag = 1; /* Initialize reception complete flag */
    .....
    UART0_ReceiveData ( &rxbuf, rxnum ); /* Start UART data reception */
    UART0_Start (); /* Start UART communication */
    while ( gFlag ); /* Wait for rxnum receptions */
```



```
.....  
}
```

[CG\_serial\_user.c]

```
#include "CG_macrodriver.h"  
extern BOOL gFlag; /* Reception complete flag */  
__interrupt void MD_INTSR0 ( void ) { /* Interrupt processing for INTSR0 */  
    .....  
    if ( gUart0RxLen > gUart0RxCnt ) {  
        .....  
        if ( gUart0RxLen == gUart0RxCnt ) {  
            UART0_ReceiveEndCallback (); /* Call callback routine */  
        }  
    }  
}  
  
void UART0_ReceiveEndCallback ( void ) { /* Callback routine for INTSR0 */  
    gFlag = 0; /* Set reception complete flag */  
}
```

**UART $n$ \_SendEndCallback**

Performs processing in response to the UART transmission complete interrupt INTST $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTST $n$  corresponding to the UART transmission complete interrupt INTST $n$  (performed when number of transmission data specified by [UART \$n\$ \\_SendData](#) parameter *txnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTn_SendEndCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UART $n$ \_ReceiveEndCallback**

Performs processing in response to the UART reception complete interrupt INTSR $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTSR $n$  corresponding to the UART reception complete interrupt INTSR $n$  (performed when number of received data specified by [UART \$n\$ \\_ReceiveData](#) parameter *rxnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTn_ReceiveEndCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UART $n$ \_SoftOverRunCallback**

Performs processing in response to the UART reception complete interrupt INTSR $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTSR $n$  corresponding to the UART reception complete interrupt INTSR $n$  (process performed when the amount of data received is greater than the parameter *rxnum* specified for [UART \$n\$ \\_ReceiveData](#)).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

- [Fx3]

```
void    UARTn_SoftOverRunCallback ( void );
```

- [Ix3] [Kx3] [Kx3-A] [Kx3-L] [Lx3]

```
#include    "CG_macrodriver.h"
void    UARTn_SoftOverRunCallback ( UCHAR rx_data );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

- [Fx3]

None.

- [Ix3] [Kx3] [Kx3-A] [Kx3-L] [Lx3]

I/O	Argument	Description
O	UCHAR <i>rx_data</i> ;	Receive data (greater than the parameter <i>rxnum</i> specified for <a href="#">UART<math>n</math>_ReceiveData</a> )

**[Return value]**

None.

**UART $n$ \_ErrorCallback**

Performs processing in response to the UART communication error interrupt INTSRE $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTSRE $n$  corresponding to the UART communication error interrupt INTSRE $n$ .

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void UARTn_ErrorCallback ( UCHAR err_type );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR <i>err_type</i> ;	Trigger for error interrupt 00000xx1B: Overrun error 00000x1xB: Parity error 000001xxB: Framing error

**[Return value]**

None.

**[Example]**

Below are examples of callback processing by the trigger for the UART communication error interrupt.

[CG\_serial\_user.c]

```
#include "CG_macrodriver.h"
__interrupt void MD_INTSRE0 ( void ) { /* Interrupt processing for INTSRE0 */
    UCHAR err_type;
    .....
    UART0_ErrorCallback ( err_type ); /* Call callback routine */
}

void UART0_ErrorCallback ( UCHAR err_type ) { /* Callback routine for INTSRE0 */
    if ( err_type & 0x1 ) { /* Determine trigger */
        ..... /* Callback processing in response to overrun error */
    } else if ( err_type & 0x2 ) { /* Determine trigger */
        ..... /* Callback processing in response to parity error */
    } else if ( err_type & 0x4 ) { /* Determine trigger */
```

```
..... /* Callback processing in response to framing error */  
}  
}
```

**CSImn\_Init**

Performs initialization of the serial interface (CSI) channel.

**Remark** This API function is used as an internal function of [SAUm\\_Init](#). For this reason, there is normally no need to call it from a user program.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void CSImn_Init ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**CSImn\_Start**

Sets CSI communication to standby mode.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void CSImn_Start ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**CSImm\_Stop**

Ends CSI communication.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void CSImm_Stop ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**CSImn\_SendData**

Starts CSI data transmission.

- Remarks 1.** This API function repeats the byte-level CSI transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** When performing a CSI transmission, [CSImn\\_Start](#) must be called before this API function is called.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS CSImn_SendData ( UCHAR *txbuf, USHORT txnum );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of sending a CSI transmission of four bytes of fixed-length data from channel 00 one time.

[CG\_main.c]

```
#include "CG_macrodriver.h"
BOOL gFlag; /* Transmission complete flag */
void main ( void ) {
    UCHAR txbuf[] = "ABCD";
    USHORT txnum = 4;
    gFlag = 1; /* Initialize transmission complete flag */
    .....
    CSI00_Start (); /* Start CSI communication */
    CSI00_SendData ( &txbuf, txnum ); /* Start CSI transmission */
    while ( gFlag ); /* Wait for txnum transmissions */
```

```
.....  
}
```

[CG\_serial\_user.c]

```
#include "CG_macrodriver.h"  
extern BOOL gFlag; /* Transmission complete flag */  
__interrupt void MD_INTCSI00 ( void ) { /* Interrupt processing for INTCSI00 */  
    if ( gCsi00TxCnt > 0 ) {  
        .....  
    } else {  
        CSI00_SendEndCallback (); /* Call callback routine */  
    }  
}  
  
void CSI00_SendEndCallback ( void ) { /* Callback routine for INTCSI00 */  
    gFlag = 0; /* Set transmission complete flag */  
}
```

**CSImn\_ReceiveData**

Starts CSI data reception.

- Remarks 1.** This API function performs byte-level CSI reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 2.** When performing a CSI reception, [CSImn\\_Start](#) must be called before this API function is called.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS CSImn_ReceiveData ( UCHAR *rxbuf, USHORT rxnum );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of receiving a CSI transmission of four bytes of fixed-length data from channel 00 one time.

[CG\_main.c]

```
#include "CG_macrodriver.h"
BOOL gFlag; /* Reception complete flag */
void main ( void ) {
    UCHAR rxbuf[10];
    USHORT rxnum = 4;
    gFlag = 1; /* Initialize reception complete flag */
    .....
    CSI00_Start (); /* Start CSI communication */
    CSI00_ReceiveData ( &rxbuf, rxnum ); /* Start CSI reception */
    while ( gFlag ); /* Wait for rxnum receptions */
```

```
.....  
}
```

[CG\_serial\_user.c]

```
#include "CG_macrodriver.h"  
extern BOOL gFlag; /* Reception complete flag */  
__interrupt void MD_INTCSI00 ( void ) { /* Interrupt processing for INTCSI00 */  
    if ( gCsi00RxCnt < gCsi00RxLen ) {  
        .....  
        if ( gCsi00RxCnt == gCsi00RxLen ) {  
            CSI00_ReceiveEndCallback (); /* Call callback routine */  
        } else {  
            .....  
        }  
    }  
}  
  
void CSI00_ReceiveEndCallback ( void ) { /* Callback routine for INTCSI00 */  
    gFlag = 0; /* Set reception complete flag */  
}
```

**CSImn\_SendReceiveData**

Starts CSI data transmission/reception.

- Remarks 1.** This API function repeats the byte-level CSI transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** This API function performs byte-level CSI reception the number of times specified by the parameter *txnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 3.** When performing a CSI reception, [CSImn\\_Start](#) must be called before this API function is called.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS CSImn_SendReceiveData ( UCHAR *txbuf, USHORT txnum, UCHAR *rxbuf );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send/receive
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of sending and receiving a CSI transmission of four bytes of fixed-length data from channel 00 one time.

[CG\_main.c]

```
#include "CG_macrodriver.h"
BOOL gSflag; /* Transmission complete flag */
void main ( void ) {
    UCHAR txbuf[] = "0123";
    USHORT txnum = 4;
    UCHAR rxbuf[10];
```

```

    gSflag = 1;                                /* Initialize flag */
    .....
    CSI00_Start ();                            /* Start CSI communication */
    CSI00_SendReceiveData ( &txbuf, txnum, &rxbuf ); /* Start CSI send/receive */
    while ( gSflag );                          /* Wait for txnum transmissions/receptions
*/
    .....
}

```

[CG\_serial\_user.c]

```

#include "CG_macrodriver.h"
extern BOOL gSflag; /* Transmission complete flag */
__interrupt void MD_INTCSI00 ( void ) { /* Interrupt processing for INTCSI00 */
    if ( gCsi00TxCnt > 0 ) {
        .....
    } else {
        .....
        CSI00_SendEndCallback (); /* Call callback routine */
    }
    .....
}

void CSI00_SendEndCallback ( void ) { /* Callback routine for INTCSI00 */
    gSflag = 0; /* Set transmission complete flag */
}

```

**CSImn\_SendEndCallback**

Performs processing in response to the CSI communication complete interrupt INTCSImn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTCSImn corresponding to the CSI communication complete interrupt INTCSImn (performed when number of transmission data specified by [CSImn\\_SendData](#) parameter *txnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void CSImn_SendEndCallback ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**CSImn\_ReceiveEndCallback**

Performs processing in response to the CSI communication complete interrupt INTCSImn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTCSImn corresponding to the CSI communication complete interrupt INTCSImn (performed when number of received data specified by [CSImn\\_ReceiveData](#) parameter *rxnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void CSImn_ReceiveEndCallback ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**CSImn\_ErrorCallback**

Performs processing in response to the CSI communication error interrupt INTSRE $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTSRE $n$  corresponding to the UART communication error interrupt INTSRE $n$ .

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include    "CG_macrodriver.h"
void    CSImn_ErrorCallback ( UCHAR err_type );
```

**Remark**  $m$  is the unit number, and  $n$  is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR <i>err_type</i> ;	Trigger for error interrupt 0000xx1B: Overrun error

**[Return value]**

None.

**[Example]**

Below are examples of callback processing by the trigger for the CSI communication error interrupt.

[CG\_serial\_user.c]

```
#include    "CG_macrodriver.h"
__interrupt void MD_INTSRE0 ( void ) {          /* Interrupt processing for INTSRE0 */
    UCHAR    err_type;
    .....
    CSI00_ErrorCallback ( err_type );          /* Call callback routine */
}

void CSI00_ErrorCallback ( UCHAR err_type ) {   /* Callback routine for INTSRE0 */
    if ( err_type & 0x1 ) {                    /* Determine trigger */
        ..... /* Callback processing in response to overrun error */
    }
}
```

**IICmn\_Init**

Performs initialization of the serial interface (simple IIC) channel.

**Remark** This API function is used as an internal function of [SAUm\\_Init](#). For this reason, there is normally no need to call it from a user program.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICmn_Init ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICmn\_Stop**

Ends simple IIC communication.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICmn_Stop ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICmn\_MasterSendStart**

Starts simple IIC master transmission.

**Remark** This API function repeats the byte-level simple IIC master transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

**[Classification]**

CG\_serial.c

**[Syntax]**


```
#include "CG_macrodriver.h"
void IICmn_MasterSendStart ( UCHAR adr, UCHAR *txbuf, USHORT txnum );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>adr</i> ;	Device address
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send

**Remark** Below is shown the format for specifying device address *adr*.



**[Return value]**

None.

**IICmn\_MasterReceiveStart**

Starts simple IIC master reception.

**Remark** This API function performs byte-level simple IIC master reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

**[Classification]**

CG\_serial.c

**[Syntax]**


```
#include "CG_macrodriver.h"
void IICmn_MasterReceiveStart ( UCHAR adr, UCHAR *rxbuf, USHORT rxnum );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>adr</i> ;	Device address
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive

**Remark** Below is shown the format for specifying device address *adr*.



**[Return value]**

None.

**IICmn\_StartCondition**

Generates start conditions.

**Remark** This API function is used as an internal function of [IICmn\\_MasterSendStart](#) and [IICmn\\_MasterReceiveStart](#). For this reason, there is normally no need to call it from a user program.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICmn_StartCondition ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICmn\_StopCondition**

Generates stop conditions.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICmn_StopCondition ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**IICmn\_MasterSendEndCallback**

Performs processing in response to the simple IICmn communication complete interrupt INTIICmn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICmn corresponding to the simple IICmn communication complete interrupt INTIICmn (performed when number of transmission data specified by IICmn\_MasterSendStart parameter *txnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICmn_MasterSendEndCallback ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICmn\_MasterReceiveEndCallback**

Performs processing in response to the simple IICmn communication complete interrupt INTIICmn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICmn corresponding to the simple IICmn communication complete interrupt INTIICmn (performed when number of received data specified by IICmn\_MasterReceiveStart parameter *rxnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICmn_MasterReceiveEndCallback ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICmn\_MasterErrorCallback**

Performs processing in response to detection of parity error (ACK error) in simple IIC communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICmn_MasterErrorCallback ( MD_STATUS flag );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	MD_STATUS <i>flag</i> ;	Cause of communication error MD_NACK: Acknowledge not detected

**[Return value]**

None.

**UARTFn\_Init**

Performs initialization of the serial interface (UARTFn).

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void    UARTFn_Init ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_PowerOff**

Halts the clock supplied to the serial interface (UARTFn).

**Remark** Calling this API function changes the serial interface (UARTFn) to reset status. For this reason, writes to the control registers (e.g. LIN-UARTn status register: UF $n$ STR) after this API function is called are ignored.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void UARTFn_PowerOff ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_Start**

Sets UARTF communication to standby mode.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void UARTFn_Start ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTF $n$ \_Stop**

Ends UARTF communication.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void UARTF $n$ _Stop ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_SendData**

Starts UARTF data transmission.

- Remarks 1.** This API function repeats the byte-level UARTF transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.
- 2.** When performing a UARTF transmission, [UARTFn\\_Start](#) must be called before this API function is called.
- 3.** If the serial interface (UARTF*n*) is used in expansion bit mode, then store the data to send in the buffer specified by parameter *txbuf*, in the following format.  
"8-bit data", "Expansion bit", "8-bit data", "Expansion bit", ...

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS UARTFn_SendData ( UCHAR *txbuf, USHORT txnum );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification
MD_DATAEXISTS	Executing transmission process



**UARTFn\_ReceiveData**

Starts UARTF data reception.

- Remarks 1.** This API function performs byte-level UARTF reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.
- 2.** Actual UARTF reception starts after this API function is called, and [UARTFn\\_Start](#) is then called.
- 3.** If the serial interface (UARTFn) is used in expansion bit mode, then the received data is stored in the buffer specified by parameter *rxbuf*, in the following format.  
"8-bit data", "Expansion bit", "8-bit data", "Expansion bit", ...

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS UARTFn_ReceiveData ( UCHAR *rxbuf, USHORT rxnum );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**UARTFn\_SetComparisonData**

Sets the data to compare to the received data.

**Remark** The value specified in parameter *comdata* is set to LIN-UART*n* ID setting register (UF*n*ID).

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void UARTFn_SetComparisonData ( UCHAR comdata );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>comdata</i> ;	Data to compare

**[Return value]**

None.

**UARTFn\_DataComparisonEnable**

Starts the data comparison.

**Remark** Calling this API function switches the serial interface (UARTFn) to expansion bit mode (with data comparison).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTFn_DataComparisonEnable ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_DataComparisonDisable**

Ends the data comparison.

**Remark** Calling this API function switches the serial interface (UARTFn) to expansion bit mode (no data comparison).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTFn_DataComparisonDisable ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_SendEndCallback**

Performs processing in response to the transmission interrupt INTLT $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTLT $n$  corresponding to the transmission interrupt INTLT $n$  (performed when number of transmission data specified by [UARTFn\\_SendData](#) parameter *txnum* has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTFn_SendEndCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_ReceiveEndCallback**

Performs processing in response to the reception complete interrupt INTLR $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTLR $n$  corresponding to the reception complete interrupt INTLR $n$  (performed when number of received data specified by [UARTFn\\_ReceiveData](#) parameter  $rxnum$  has been completed).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTFn_ReceiveEndCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_SoftOverRunCallback**

Performs processing in response to the reception complete interrupt INTLR $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTLR $n$  corresponding to the reception complete interrupt INTLR $n$  (process performed when the amount of data received is greater than the parameter *rxnum* specified for [UARTFn\\_ReceiveData](#)).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTFn_SoftOverRunCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_ExpBitCetectCallback**

Performs processing in response to the status interrupt INTLS $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTLS $n$  corresponding to the status interrupt INTLS $n$  (processing when the expansion bit is received).

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void UARTFn_ExpBitCetectCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**UARTFn\_IDMatchCallback**

Performs processing in response to the status interrupt INTLS $n$ .

**Remark** This API function is called as the callback routine of interrupt process MD\_INTLS $n$  corresponding to the status interrupt INTLS $n$ .

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void    UARTFn_IDMatchCallback ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**UARTFn\_ErrorCallback**

Performs processing in response to the status interrupt INTLSn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTLSn corresponding to the status interrupt INTLSn.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void UARTFn_ErrorCallback ( UCHAR err_type );
```

**Remark** n is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR <i>err_type</i> ;	Trigger for status interrupt 00000xx1B: Overrun error 00000x1xB: Framing error 000001xxB: Parity error

**[Return value]**

None.

**IICA\_Init**

Performs initialization of the serial interface (IICA).

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICA_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_UserInit**

Performs user-defined initialization of the serial interface (IICA).

**Remark** This API function is called as the [IICA\\_Init](#) callback routine.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICA_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_PowerOff**

Halts the clock supplied to the serial interface (IICA).

**Remark** Calling this API function changes the serial interface (IICA) to reset status. For this reason, writes to the control registers (e.g. IICA control register  $n$ : IICCTL $n$ ) after this API function is called are ignored.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICA_PowerOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_Stop**

Ends IICA communication.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICA_Stop ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_MasterSendStart**

Starts IICA master transmission.

**Remark** This API function repeats the byte-level IICA master transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS IICA_MasterSendStart ( UCHAR adr, UCHAR *txbuf, USHORT txnum, UCHAR wait );
```

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>adr</i> ;	Slave address
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send
I	UCHAR <i>wait</i> ;	Setup time of start conditions

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR1	Bus communication status
MD_ERROR2	Bus not released status

**IICA\_MasterReceiveStart**

Starts IICA master reception.

**Remark** This API function performs byte-level IICA master reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS IICA_MasterReceiveStart ( UCHAR adr, UCHAR *rxbuf, USHORT rxnum, UCHAR wait );
```

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>adr</i> ;	Slave address
O	UCHAR <i>*rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive
I	UCHAR <i>wait</i> ;	Setup time of start conditions

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR1	Bus communication status
MD_ERROR2	Bus not released status



**IICA\_StopCondition**

Generates stop conditions.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICA_StopCondition ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_MasterSendEndCallback**

Performs processing in response to the IICA communication complete interrupt INTIICA.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICA corresponding to the IICA communication complete interrupt INTIICA.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICA_MasterSendEndCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_MasterReceiveEndCallback**

Performs processing in response to the IICA communication complete interrupt INTIICA.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICA corresponding to the IICA communication complete interrupt INTIICA.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICA_MasterReceiveEndCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_MasterErrorCallback**

Performs processing in response to detection of error in IICA master communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICA_MasterErrorCallback ( MD_STATUS flag );
```

**[Argument(s)]**

I/O	Argument	Description
I	MD_STATUS <i>flag</i> ;	Cause of communication error MD_SPT: Stop condition detected MD_NACK: Acknowledge not detected

**[Return value]**

None.

**IICA\_SlaveSendStart**

Starts IICA slave transmission.

**Remark** This API function repeats the byte-level IICA slave transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICA_SlaveSendStart ( UCHAR *txbuf, USHORT txnum );
```

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send

**[Return value]**

None.

**IICA\_SlaveReceiveStart**

Starts IICA slave reception.

**Remark** This API function performs byte-level IICA slave reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICA_SlaveReceiveStart ( UCHAR *rxbuf, USHORT rxnum );
```

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive

**[Return value]**

None.

**IICA\_SlaveSendEndCallback**

Performs processing in response to the IICA communication complete interrupt INTIICA.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICA corresponding to the IICA communication complete interrupt INTIICA.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICA_SlaveSendEndCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICA\_SlaveReceiveEndCallback**

Performs processing in response to the IICA communication complete interrupt INTIICA.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICA corresponding to the IICA communication complete interrupt INTIICA.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICA_SlaveReceiveEndCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**IICA\_SlaveErrorCallback**

Performs processing in response to detection of error in IICA slave communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICA_SlaveErrorCallback ( MD_STATUS flag );
```

**[Argument(s)]**

I/O	Argument	Description
I	MD_STATUS <i>flag</i> ;	Cause of communication error MD_ERROR: Address mismatch detected MD_NACK: Acknowledge not detected

**[Return value]**

None.

**IICA\_GetStopConditionCallback**

Performs processing in response to detection of stop condition in IICA slave communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICA_GetStopConditionCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_Init**

Performs initialization of the serial interface (IICn).

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICn_Init ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_UserInit**

Performs user-defined initialization of the serial interface (IICn).

**Remark** This API function is called as the [IICn\\_Init](#) callback routine.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICn_UserInit ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_Stop**

Ends IICn communication.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
void IICn_Stop ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_MasterSendStart**

Starts IICn master transmission.

**Remark** This API function repeats the byte-level IICn master transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS IICn_MasterSendStart ( UCHAR adr, UCHAR *txbuf, USHORT txnum, UCHAR wait );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>adr</i> ;	Slave address
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send
I	UCHAR <i>wait</i> ;	Setup time of start conditions

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR	Exit with error (abend)

**IICn\_MasterReceiveStart**

Starts IICn master reception.

**Remark** This API function performs byte-level IICn master reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS IICn_MasterReceiveStart ( UCHAR adr, UCHAR *rxbuf, USHORT rxnum, UCHAR wait );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>adr</i> ;	Slave address
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive
I	UCHAR <i>wait</i> ;	Setup time of start conditions

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR	Exit with error (abend)

**IICn\_MasterSendEndCallback**

Performs processing in response to the IICn communication complete interrupt INTIICn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICn corresponding to the IICn communication complete interrupt INTIICn.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICn_MasterSendEndCallback ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**IICn\_MasterReceiveEndCallback**

Performs processing in response to the IICn communication complete interrupt INTIICn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICn corresponding to the IICn communication complete interrupt INTIICn.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICn_MasterReceiveEndCallback ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_MasterErrorCallback**

Performs processing in response to detection of error in IICn master communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICn_MasterErrorCallback ( MD_STATUS flag );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	MD_STATUS <i>flag</i> ;	Cause of communication error MD_SPT: Stop condition detected MD_NACK: Acknowledge not detected

**[Return value]**

None.

**IICn\_SlaveSendStart**

Starts IICn slave transmission.

**Remark** This API function repeats the byte-level IICn slave transmission from the buffer specified in parameter *txbuf* the number of times specified in parameter *txnum*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICn_SlaveSendStart ( UCHAR *txbuf, USHORT txnum );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR * <i>txbuf</i> ;	Pointer to a buffer storing the transmission data
I	USHORT <i>txnum</i> ;	Total amount of data to send

**[Return value]**

None.

**IICn\_SlaveReceiveStart**

Starts IICn slave reception.

**Remark** This API function performs byte-level IICn slave reception the number of times specified by the parameter *rxnum*, and stores the data in the buffer specified by the parameter *rxbuf*.

**[Classification]**

CG\_serial.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICn_SlaveReceiveStart ( UCHAR *rxbuf, USHORT rxnum );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR * <i>rxbuf</i> ;	Pointer to a buffer to store the received data
I	USHORT <i>rxnum</i> ;	Total amount of data to receive

**[Return value]**

None.

**IICn\_SlaveSendEndCallback**

Performs processing in response to the IICn communication complete interrupt INTIICn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICn corresponding to the IICn communication complete interrupt INTIICn.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICn_SlaveSendEndCallback ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_SlaveReceiveEndCallback**

Performs processing in response to the IICn communication complete interrupt INTIICn.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTIICn corresponding to the IICn communication complete interrupt INTIICn.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICn_SlaveReceiveEndCallback ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**IICn\_SlaveErrorCallback**

Performs processing in response to detection of error in IICn slave communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void IICn_SlaveErrorCallback ( MD_STATUS flag );
```

**Remark** n is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	MD_STATUS flag;	Cause of communication error MD_ERROR: Address mismatch detected MD_NACK: Acknowledge not detected

**[Return value]**

None.

**IICn\_GetStopConditionCallback**

Performs processing in response to detection of stop condition in IICn slave communication.

**[Classification]**

CG\_serial\_user.c

**[Syntax]**

```
void IICn_GetStopConditionCallback ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**C.3.6 Operational Amplifier**

Below is a list of API functions output by Code Generator for operational amplifiers use.

**Table C-7. API Functions: [Operational Amplifier]**

API Function Name	Function
OPAMP_Init	Performs initialization necessary to control operational amplifier functions.
OPAMP_UserInit	Performs user-defined initialization relating to the operational amplifier.
AMPn_Start	Starts the operation of operational amplifier <i>n</i> (single AMP mode).
AMPn_Stop	Ends the operation of operational amplifier <i>n</i> (single AMP mode).

**OPAMP\_Init**

Performs initialization necessary to control operational amplifier functions.

**[Classification]**

CG\_opamp.c

**[Syntax]**

```
void OPAMP_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**OPAMP\_UserInit**

Performs user-defined initialization relating to the operational amplifier.

**Remark** This API function is called as the [OPAMP\\_Init](#) callback routine.

**[Classification]**

CG\_opamp\_user.c

**[Syntax]**

```
void OPAMP_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**AMP $n$ \_Start**

Starts the operation of operational amplifier  $n$  (single AMP mode).

**[Classification]**

CG\_opamp.c

**[Syntax]**

```
void AMPn_Start ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**AMP $n$ \_Stop**

Ends the operation of operational amplifier  $n$  (single AMP mode).

**[Classification]**

CG\_opamp.c

**[Syntax]**

```
void AMPn_Stop ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**C.3.7 Comparator/PGA**

Below is a list of API functions output by Code Generator for comparator/programmable gain amplifiers use.

**Table C-8. API Functions: [Comparator/PGA]**

API Function Name	Function
<a href="#">CMPPGA_Init</a>	Performs initialization necessary to control comparator/programmable gain amplifiers functions.
<a href="#">CMPPGA_UserInit</a>	Performs user-defined initialization relating to the comparator/programmable gain amplifiers.
<a href="#">CMPPGA_PowerOff</a>	Halts the clock supplied to the comparator/programmable gain amplifiers.
<a href="#">CMPPGA_Start</a>	Starts the operation of comparator/programmable gain amplifier.
<a href="#">CMPPGA_Stop</a>	Ends the operation of comparator/programmable gain amplifier.
<a href="#">CMPPGA_ChangeCMPnRefVoltage</a>	Sets comparator <i>n</i> internal reference voltage.
<a href="#">CMPPGA_ChangePGAFactor</a>	Sets the input voltage amplification factor of a programmable gain amplifier.

**CMPPGA\_Init**

Performs initialization necessary to control comparator/programmable gain amplifiers functions.

**[Classification]**

CG\_cmppga.c

**[Syntax]**

```
void    CMPPGA_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**CMPPGA\_UserInit**

Performs user-defined initialization relating to the comparator/programmable gain amplifiers.

**Remark** This API function is called as the [CMPPGA\\_Init](#) callback routine.

**[Classification]**

CG\_cmppga\_user.c

**[Syntax]**

```
void    CMPPGA_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**CMPPGA\_PowerOff**

Halts the clock supplied to the comparator/programmable gain amplifiers.

**Remark** Calling this API function changes the comparator/programmable gain amplifiers to reset status. For this reason, writes to the control registers (e.g. programmable gain amplifier control register: OAM) after this API function is called are ignored.

**[Classification]**

CG\_cmppga.c

**[Syntax]**

```
void CMPPGA_PowerOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**CMPPGA\_Start**

Starts the operation of comparator/programmable gain amplifier.

**[Classification]**

CG\_cmppga.c

**[Syntax]**

```
void CMPPGA_Start ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**CMPPGA\_Stop**

Ends the operation of comparator/programmable gain amplifier.

**[Classification]**

CG\_cmppga.c

**[Syntax]**

```
void    CMPPGA_Stop ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**CMPPGA\_ChangeCMPnRefVoltage**

Sets comparator *n* internal reference voltage.

**Remark** The value specified in parameter *voltage* is set to comparator *n* internal reference voltage setting register (CnRVM).

**[Classification]**

CG\_cmppga.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_cmppga.h"
MD_STATUS CMPPGA_ChangeCMPnRefVoltage ( enum CMPRefVoltage voltage );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	enum CMPRefVoltage <i>voltage</i> ;	Comparator <i>n</i> internal reference voltage [ <i>n</i> = 0: In the case of the channel 0] CMPREFVOL0: 2AV <sub>REF</sub> /16 CMPREFVOL1: 4AV <sub>REF</sub> /16 CMPREFVOL2: 6AV <sub>REF</sub> /16 CMPREFVOL3: 8AV <sub>REF</sub> /16 CMPREFVOL4: 10AV <sub>REF</sub> /16 CMPREFVOL5: 12AV <sub>REF</sub> /16 [ <i>n</i> = 1: In the case of the channel 1] CMPREFVOL0: 3AV <sub>REF</sub> /16 CMPREFVOL1: 5AV <sub>REF</sub> /16 CMPREFVOL2: 7AV <sub>REF</sub> /16 CMPREFVOL3: 9AV <sub>REF</sub> /16 CMPREFVOL4: 11AV <sub>REF</sub> /16 CMPREFVOL5: 13AV <sub>REF</sub> /16

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**CMPPGA\_ChangePGAFactor**

Sets the input voltage amplification factor of a programmable gain amplifier.

**Remark** The value specified in parameter *voltage* is set to programmable gain amplifier control register (OAM).

**[Classification]**

CG\_cmppga.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_cmppga.h"
MD_STATUS CMPPGA_ChangePGAFactor ( enum PGAFactor factor );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum PGAFactor <i>factor</i> ;	Input voltage amplification factor PGAFACTOR0: x4 PGAFACTOR1: x6 PGAFACTOR2: x8 PGAFACTOR3: x10 PGAFACTOR4: x12

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

## C.3.8 A/D

Below is a list of API functions output by Code Generator for A/D converter use.

**Table C-9. API Functions: [A/D]**

API Function Name	Function
AD_Init	Performs initialization necessary to control A/D converter functions.
AD_UserInit	Performs user-defined initialization relating to the A/D converter.
AD_PowerOff	Halts the clock supplied to the A/D converter.
AD_ComparatorOn	Enables operation of voltage converter.
AD_ComparatorOff	Disables operation of voltage converter.
AD_Start	Starts A/D conversion.
AD_Stop	Ends A/D conversion.
AD_SelectADChannel	Configures the analog voltage input pin for A/D conversion.
AD_Read	Reads the results of A/D conversion.
AD_ReadByte	Reads the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution).

**AD\_Init**

Performs initialization necessary to control A/D converter functions.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
void AD_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**AD\_UserInit**

Performs user-defined initialization relating to the A/D converter.

**Remark** This API function is called as the [AD\\_Init](#) callback routine.

**[Classification]**

CG\_ad\_user.c

**[Syntax]**

```
void AD_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**AD\_PowerOff**

Halts the clock supplied to the A/D converter.

**Remark** Calling this API function changes the A/D converter to reset status. For this reason, writes to the control registers (e.g. A/D converter mode register: ADCM) after this API function is called are ignored.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
void AD_PowerOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**AD\_ComparatorOn**

Enables operation of voltage converter.

- Remarks 1.** About 1 microsecond of stabilization time is required when changing the voltage converter from operation stopped to operation enabled status.  
Consequently, about 1 micro second must be left free between the call to this API function and the call to [AD\\_Start](#).
- 2.** On the [Code Generator panel \(\[A/D\]\)](#), in the [Comparator operation setting] area, if "Operation" is selected, then the voltage converter will be switched to "always on". There is thus no need to call this API function in this case.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
void AD_ComparatorOn ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**AD\_ComparatorOff**

Disables operation of voltage converter.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
void AD_ComparatorOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**AD\_Start**

Starts A/D conversion.

**Remark** About 1 micro second of stabilization time is required when changing the voltage converter from operation stopped to operation enabled status.  
Consequently, about 1 micro second must be left free between the call to [AD\\_ComparatorOn](#) and the call to this API function.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
void AD_Start ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**[Example 1]**

Below is an example of starting analog voltage via the conversion start pin selected in the [Code Generator panel \(\[A/D\]\)](#), then converting the analog voltage from the ANI1 input pin to digital. In the example, "Stop" is selected in the [Comparator operation setting] area of the [Code Generator panel \(\[A/D\]\)](#) (when performing the call to [AD\\_ComparatorOn](#)).

[CG\_main.c]

```
#include "CG_macrodriver.h"
#include "CG_ad.h"
BOOL gFlag; /* A/D conversion complete flag */
void main ( void ) {
    USHORT buffer = 0;
    int wait = 100;
    gFlag = 1; /* Initialize A/D conversion complete flag */
    .....
    AD_ComparatorOn (); /* Move to operation enabled status */
    while ( wait ); /* Ensure stabilization time (at least 1 micro second) */
    AD_Start (); /* Start A/D conversion */
    while ( gFlag ); /* Wait for INTAD */
    AD_Read ( &buffer ); /* Read results of A/D conversion */
    AD_SelectADChannel ( ADCHANNEL1 ); /* Switch input pins */
    gFlag = 1; /* Initialize A/D conversion complete flag */
    while ( gFlag ); /* Wait for INTAD */
    AD_Read ( &buffer ); /* Read results of A/D conversion */
}
```

```

AD_SelectADChannel ( ADCHANNEL1 ); /* Switch input pins */
gFlag = 1; /* Initialize A/D conversion complete flag */
while ( gFlag ); /* Wait for INTAD */
AD_Read ( &buffer ); /* Read results of A/D conversion */
AD_Stop (); /* End A/D conversion */
AD_ComparatorOff (); /* Move to operation disabled status */
.....
}

```

[CG\_ad\_user.c]

```

#include "CG_macrodriver.h"
extern BOOL gFlag; /* A/D conversion complete flag */
__interrupt void MD_INTAD ( void ) { /* Interrupt processing for INTAD */
    gFlag = 0; /* Set A/D conversion complete flag */
}

```

**[Example 2]**

Below is an example of starting analog voltage via the conversion start pin selected in the [Code Generator panel \(\[A/D\]\)](#), then converting the analog voltage from the ANI1 input pin to digital. In the example, "Operation" is selected in the [\[Comparator operation setting\] area of the Code Generator panel \(\[A/D\]\)](#) (when not performing the call to [AD\\_ComparatorOn](#)).

[CG\_main.c]

```

#include "CG_macrodriver.h"
#include "CG_ad.h"
BOOL gFlag; /* A/D conversion complete flag */
void main ( void ) {
    USHORT buffer = 0;
    gFlag = 1; /* Initialize A/D conversion complete flag */
    .....
    AD_Start (); /* Start A/D conversion */
    while ( gFlag ); /* Wait for INTAD */
    AD_Read ( &buffer ); /* Read results of A/D conversion */
    AD_SelectADChannel ( ADCHANNEL1 ); /* Switch input pins */
    gFlag = 1; /* Initialize A/D conversion complete flag */
    while ( gFlag ); /* Wait for INTAD */
    AD_Read ( &buffer ); /* Read results of A/D conversion */
    AD_Stop (); /* End A/D conversion */
    .....
}

```

[CG\_ad\_user.c]

```

#include "CG_macrodriver.h"

```

```
extern  BOOL    gFlag;                /* A/D conversion complete flag */
__interrupt void MD_INTAD ( void ) { /* Interrupt processing for INTAD */
    gFlag = 0;                        /* Set A/D conversion complete flag */
}
```

**AD\_Stop**

Ends A/D conversion.

**Remark** The voltage converter continues to operate after the process of this API function completes. Consequently, to stop the operation of the voltage converter, you must call [AD\\_ComparatorOff](#) after the process of this API function completes.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
void AD_Stop ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**AD\_SelectADChannel**

Configures the analog voltage input pin for A/D conversion.

**Remark** The value specified in parameter *channel* is set to analog input channel specification register (ADS).

**[Classification]**

CG\_ad.c

**[Syntax]**

- [Fx3] [Ix3] [Kx3-A] [Kx3-L] [Lx3]

```
#include    "CG_ad.h"
MD_STATUS  AD_SelectADChannel ( enum ADChannel channel );
```

- [Kx3]

```
#include    "CG_ad.h"
void       AD_SelectADChannel ( enum ADChannel channel );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum ADChannel <i>channel</i> ;	Analog voltage input pin ADCHANNEL <i>n</i> : Input pin

**Remark** See the header file CG\_ad.h for details about the analog voltage input pin ADCHANNEL*n*.

**[Return value]**

- [Fx3] [Ix3] [Kx3-A] [Kx3-L] [Lx3]

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

- [Kx3]

None.



**AD\_Read**

Reads the results of A/D conversion.

**Remark** If the target device is 78K0R/Fx3, 78K0R/Kx3, 78K0R/Kx3-L, then the results of A/D conversion will be 10 bits. If the target device is 78K0R/Kx3-A, 78K0R/Lx3, then the results of A/D conversion will be 12 bits.

**[Classification]**

CG\_ad.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void AD_Read ( USHORT *buffer );
```

**[Argument(s)]**

I/O	Argument	Description
O	USHORT *buffer;	Pointer to area in which to store read results of A/D conversion

**[Return value]**

None.

**AD\_ReadByte**

Reads the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution).

**[Classification]**

CG\_ad.c

**[Syntax]**


```
#include "CG_macrodriver.h"
void AD_ReadByte ( UCHAR *buffer );
```

**[Argument(s)]**

I/O	Argument	Description
O	UCHAR *buffer;	Pointer to area in which to store the results of A/D conversion (8 bits; most significant 8 bits of 10-bit resolution)

**Remark** Below is an example of the results of A/D conversion to be stored in *buffer*.

- [Fx3] [Ix3] [Kx3] [Kx3-L]



- [Kx3-A] [Lx3]



**[Return value]**

None.

## C.3.9 D/A

Below is a list of API functions output by Code Generator for D/A converter use.

**Table C-10. API Functions: [D/A]**

API Function Name	Function
DA_Init	Performs initialization necessary to control D/A converter functions.
DA_UserInit	Performs user-defined initialization relating to the D/A converter.
DA_PowerOff	Halts the clock supplied to the D/A converter.
DAn_Start	Starts D/A conversion.
DAn_Stop	Ends D/A conversion.
DAn_SetValue	Sets the initial analog voltage output to the ANOn pin.
DAn_Set8BitsValue	Sets the initial analog voltage (8 bits) output to the ANOn pin.
DAn_Set12BitsValue	Sets the initial analog voltage (12 bits) output to the ANOn pin.

**DA\_Init**

Performs initialization necessary to control D/A converter functions.

**[Classification]**

CG\_da.c

**[Syntax]**

```
void DA_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**DA\_UserInit**

Performs user-defined initialization relating to the D/A converter.

**Remark** This API function is called as the [DA\\_Init](#) callback routine.

**[Classification]**

CG\_da\_user.c

**[Syntax]**

```
void DA_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**DA\_PowerOff**

Halts the clock supplied to the D/A converter.

**Remark** Calling this API function changes the D/A converter to reset status. For this reason, writes to the control registers (e.g. D/A converter mode register: DAM) after this API function is called are ignored.

**[Classification]**

CG\_da.c

**[Syntax]**

```
void DA_PowerOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**DAn\_Start**

Starts D/A conversion.

**[Classification]**

CG\_da.c

**[Syntax]**

```
void DAn_Start ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**DAn\_Stop**

Ends D/A conversion.

**[Classification]**

CG\_da.c

**[Syntax]**

```
void DAn_Stop ( void );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**DAn\_SetValue**

Sets the analog voltage output to the ANOn pin.

**[Classification]**

CG\_da.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void DAn_SetValue ( UCHAR value );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>value</i> ;	Analog voltage (0x0 to 0xff)

**[Return value]**

None.

**[Example]**

Below is an example of setting "analog voltage" to channels 0 and 1.

[CG\_main.c]

```
void main ( void ) {
    .....
    DA0_Start ();          /* Start D/A conversion */
    DA1_Start ();          /* Start D/A conversion */
    .....
    DA0_SetValue ( 0x7f ); /* Set analog voltage */
    .....
}
```

[CG\_timer\_user.c]

```
#include "CG_macrodriver.h"
UCHAR gValue = 0;
__interrupt void MD_INTTM05 ( void ) { /* Interrupt processing for INTTM05 */
    DA1_SetValue ( gValue++ ); /* Set analog voltage */
}
```

**DAn\_Set8BitsValue**

Sets the analog voltage (8 bits) output to the ANOn pin.

**[Classification]**

CG\_da.c

**[Syntax]**

```
#include    "CG_macrodriver.h"
void      DAn_Set8BitsValue ( UCHAR value );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>value</i> ;	Analog voltage (0x0 to 0x1f)

**[Return value]**

None.

**[Example]**

Below is an example of setting "analog voltage" to channels 0 and 1.

[CG\_main.c]

```
void main ( void ) {
    .....
    DA0_Start ();          /* Start D/A conversion */
    DA1_Start ();          /* Start D/A conversion */
    .....
    DA0_Set8BitsValue ( 0x7f ); /* Set analog voltage */
    .....
}
```

[CG\_timer\_user.c]

```
#include    "CG_macrodriver.h"
UCHAR      gValue = 0;
__interrupt void MD_INTTM05 ( void ) { /* Interrupt processing for INTTM05 */
    DA1_Set8BitsValue ( gValue++ ); /* Set analog voltage */
}
```

**DAn\_Set12BitsValue**

Sets the analog voltage (12 bits) output to the ANOn pin.

**[Classification]**

CG\_da.c

**[Syntax]**

```
#include    "CG_macrodriver.h"
void      DAn_Set12BitsValue ( UCHAR value );
```

**Remark** *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>value</i> ;	Analog voltage (0x0 to 0xff)

**[Return value]**

None.

**[Example]**

Below is an example of setting "analog voltage" to channels 0 and 1.

[CG\_main.c]

```
void main ( void ) {
    .....
    DA0_Start ();                /* Start D/A conversion */
    DA1_Start ();                /* Start D/A conversion */
    .....
    DA0_Set12BitsValue ( 0x1ff ); /* Set analog voltage */
    .....
}
```

[CG\_timer\_user.c]

```
#include    "CG_macrodriver.h"
UCHAR      gValue = 0;
__interrupt void MD_INTTM05 ( void ) { /* Interrupt processing for INTTM05 */
    DA1_Set12BitsValue ( gValue++ ); /* Set analog voltage */
}
```

## C.3.10 Timer

Below is a list of API functions output by Code Generator for timer array unit use.

Table C-11. API Functions: [Timer]

API Function Name	Function
TAUm_Init	Performs initialization necessary to control timer array unit functions.
TAUm_UserInit	Performs user-defined initialization relating to the timer array unit.
TAUm_PowerOff	Halts the clock supplied to the timer array unit.
TAUm_Channeln_Start	Starts the count for channel <i>n</i> .
TAUm_Channeln_Stop	Ends the count for channel <i>n</i> .
TAUm_Channeln_ChangeCondition	Changes the counter value.
TAUm_Channeln_ChangeTimerCondition	Changes the counter value.
TAUm_Channeln_GetPulseWidth	Captures the high/low-level width measured between pulses of the signal (pulses) input to the <i>TImn</i> pin.
TAUm_Channeln_ChangeDuty	Changes the duty ratio of the PWM signal output to the <i>TOmn</i> pin.
TAUm_Channeln_SoftWareTriggerOn	Generates the trigger (software trigger) for one-shot pulse output.

**TAUm\_Init**

Performs initialization necessary to control timer array unit functions.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
void    TAUm_Init ( void );
```

**Remark** *m* is the unit number.

**[Argument(s)]**

None.

**[Return value]**

None.

**TAUm\_UserInit**

Performs user-defined initialization relating to the timer array unit.

**Remark** This API function is called as the [TAUm\\_Init](#) callback routine.

**[Classification]**

CG\_timer\_user.c

**[Syntax]**

```
void    TAUm_UserInit ( void );
```

**Remark** *m* is the unit number.

**[Argument(s)]**

None.

**[Return value]**

None.

**TAUm\_PowerOff**

Halts the clock supplied to the timer array unit.

**Remark** Calling this API function changes the timer array unit to reset status. For this reason, writes to the control registers (e.g. timer clock select register 0: TPS0) after this API function is called are ignored.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
void    TAUm_PowerOff ( void );
```

**Remark** *m* is the unit number.

**[Argument(s)]**

None.

**[Return value]**

None.

**TAUm\_Channeln\_Start**

Starts the count for channel  $n$ .

**Remark** The time from the call to this API function to the start of counting depends on the type of the function in question (e.g. interval timer, square-wave output, or external event counter).

**[Classification]**

CG\_timer.c

**[Syntax]**

```
void    TAUm_Channeln_Start ( void );
```

**Remark**  $m$  is the unit number, and  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.



**TAUm\_Channeln\_Stop**

Ends the count for channel *n*.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
void    TAUm_Channeln_Stop ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**TAUm\_Channeln\_ChangeCondition**

Changes the counter value.

- Remarks 1.** The value specified in parameter *regvalue* is set to timer data register *mn* (TDR*mn*).
- 2.** The timing for calling these API functions differs as follows, depending on the type of function (e.g. interval timer, square wave output, or external event counter).

Function Type	Timing for Calling
Interval timer	Can call at user discretion.
Square wave output	Can call at user discretion.
Divider function	Can call at user discretion.
External event counter	Can call at user discretion.
Input pulse interval measurement	Cannot be called.
Input pulse high-/low-level width measurement	Cannot be called.
PWM output	Cannot be called.
One-shot pulse output	Cannot be called during operation.
Multiple PWM output	Cannot be called.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void TAUm_Channeln_ChangeCondition ( USHORT regvalue );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	USHORT <i>regvalue</i> ;	Counter value (0x0 to 0xffff)

**[Return value]**

None.

**[Example]**

The example below shows changing the interval time to one half.  
In this example, channel 0 has been selected for the interval timer.

[CG\_main.c]

```
#include "CG_macrodriver.h"
```

```
void main ( void ) {  
    USHORT value = TAU_TDR00_VALUE >> 1;      /* TAU_TDR00_VALUE: Current interval time */  
    .....  
    TAU0_Channel0_Start ();                    /* Start count */  
    .....  
    TAU0_Channel0_ChangeCondition ( value );  /* Change counter value */  
    .....  
}
```

**TAUm\_Channeln\_ChangeTimerCondition**

Changes the counter value.

- Remarks 1.** The value specified in parameter *regvalue* is set to timer data register *mn* (TDR*mn*).
- 2.** The timing for calling these API functions differs as follows, depending on the type of function (e.g. interval timer, square wave output, or external event counter).

Function Type	Timing for Calling
Interval timer	Can call at user discretion.
Square wave output	Can call at user discretion.
Divider function	Can call at user discretion.
External event counter	Can call at user discretion.
Input pulse interval measurement	Cannot be called.
Input pulse high-/low-level width measurement	Cannot be called.
PWM output	Cannot be called.
One-shot pulse output	Cannot be called during operation.
Multiple PWM output	Cannot be called.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void TAUm_Channeln_ChangeTimerCondition ( USHORT regvalue );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	USHORT <i>regvalue</i> ;	Counter value (0x0 to 0xffff)

**[Return value]**

None.

**[Example]**

The example below shows changing the interval time to one half.  
In this example, channel 0 has been selected for the interval timer.

[CG\_main.c]

```
#include "CG_macrodriver.h"
```

```
void main ( void ) {  
    USHORT value = TAU_TDR00_VALUE >> 1;      /* TAU_TDR00_VALUE: Current interval time */  
    .....  
    TAU0_Channel0_Start ();                    /* Start count */  
    .....  
    TAU0_Channel0_ChangeTimerCondition ( value ); /* Change counter value */  
    .....  
}
```

**TAUm\_Channeln\_GetPulseWidth**

Captures the high/low-level width measured between pulses of the signal (pulses) input to the TImn pin.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void TAUm_Channeln_GetPulseWidth ( ULONG *width );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

I/O	Argument	Description
O	ULONG *width;	Pointer to an area to store the measurement width (0x0 to 0x1ffff)

**[Return value]**

None.

**TAUm\_Channeln\_ChangeDuty**

Changes the duty ratio of the PWM signal output to the TOn pin.

**Remark** The timing for calling these API functions differs as follows, depending on the type of function (e.g. interval timer, square wave output, or external event counter).

Function Type	Timing for Calling
Interval timer	Cannot be called.
Square wave output	Cannot be called.
Divider function	Cannot be called.
External event counter	Cannot be called.
Input pulse interval measurement	Cannot be called.
Input pulse high-/low-level width measurement	Cannot be called.
PWM output	After INTT $m$ n master channel interrupt.
One-shot pulse output	Cannot be called.
Multiple PWM output	After INTT $m$ n master channel interrupt.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
#include "CG_macrodriver.h"
void TAUm_Channeln_ChangeDuty ( UCHAR ratio );
```

**Remark**  $m$  is the unit number, and  $n$  is the slave-side channel number.

**[Argument(s)]**

I/O	Argument	Description
I	UCHAR <i>ratio</i> ;	Duty ratio (0 to 100, unit: %)

**Remark** The value set to duty ratio *ratio* must be in base 10 notation.

**[Return value]**

None.

**[Example]**

The example below shows changing the duty ratio to 25%.  
 In this example, channels 0 and 1 have been selected for PWM output or multiplex PWM output.

[CG\_main.c]

```
#include "CG_macrodriver.h"
void main ( void ) {
    UCHAR ratio = 25;
    .....
    TAU0_Channel0_Start ();          /* Start count */
    .....
    TAU0_Channel1_ChangeDuty ( ratio ); /* Change duty ratio */
    .....
}
```



**TAUm\_Channeln\_SoftWareTriggerOn**

Generates the trigger (software trigger) for one-shot pulse output.

**[Classification]**

CG\_timer.c

**[Syntax]**

```
void    TAUm_Channeln_SoftWareTriggerOn ( void );
```

**Remark** *m* is the unit number, and *n* is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**C.3.11 Watchdog Timer**

Below is a list of API functions output by Code Generator for watchdog timer use.

**Table C-12. API Functions: [Watchdog Timer]**

API Function Name	Function
WDT_Init	Performs initialization necessary to control watchdog timer functions.
WDT_UserInit	Performs user-defined initialization relating to the watchdog timer.
WDT_Restart	Clears the watchdog timer counter and resumes counting.

**WDT\_Init**

Performs initialization necessary to control watchdog timer functions.

**[Classification]**

CG\_wdt.c

**[Syntax]**

```
void WDT_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**WDT\_UserInit**

Performs user-defined initialization relating to the watchdog timer.

**Remark** This API function is called as the [WDT\\_Init](#) callback routine.

**[Classification]**

CG\_wdt\_user.c

**[Syntax]**

```
void WDT_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**WDT\_Restart**

Clears the watchdog timer counter and resumes counting.

**[Classification]**

CG\_wdt.c

**[Syntax]**

```
void WDT_Restart ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

## C.3.12 RTC

Below is a list of API functions output by Code Generator for real-time counter use.

Table C-13. API Functions: [RTC]

API Function Name	Function
RTC_Init	Performs initialization necessary to control real-time counter functions.
RTC_UserInit	Performs user-defined initialization relating to the real-time counter.
RTC_PowerOff	Halts the clock supplied to the real-time counter.
RTC_CounterEnable	Starts the count of the real-time counter (year, month, weekday, day, hour, minute, second).
RTC_CounterDisable	Ends the count of the real-time counter (year, month, weekday, day, hour, minute, second).
RTC_SetHourSystem	Sets the clock type (12-hour or 24-hour clock) of the real-time counter.
RTC_CounterSet	Sets the counter value (year, month, weekday, day, hour, minute, second) of the real-time counter.
RTC_CounterGet	Reads the counter value (year, month, weekday, day, hour, minute, second) of the real-time counter.
RTC_ConstPeriodInterruptEnable	Sets the cycle of the interrupts INTRTC, then starts the cyclic interrupt function.
RTC_ConstPeriodInterruptDisable	Ends the cyclic interrupt function.
RTC_ConstPeriodInterruptCallback	Performs processing in response to the cyclic interrupt INTRTC.
RTC_AlarmEnable	Starts the alarm interrupt function.
RTC_AlarmDisable	Ends the alarm interrupt function.
RTC_AlarmSet	Sets the alarm conditions (weekday, hour, minute).
RTC_AlarmGet	Reads the alarm conditions (weekday, hour, minute).
RTC_AlarmInterruptCallback	Performs processing in response to the alarm interrupt INTRTC.
RTC_IntervalStart	Starts the interval interrupt function.
RTC_IntervalStop	Ends the interval interrupt function.
RTC_IntervalInterruptEnable	Sets the cycle of the interrupts INTRTCI, then starts the interval interrupt function.
RTC_IntervalInterruptDisable	Ends the interval interrupt function.
RTC_RTC1HZ_OutputEnable	Enables output of the real-time counter correction clock (1 Hz) to the RTC1HZ pin.
RTC_RTC1HZ_OutputDisable	Disables output of the real-time counter correction clock (1 Hz) to the RTC1HZ pin.
RTC_RTCCL_OutputEnable	Enables output of the real-time counter clock (32 kHz source) to the RTCCL pin.
RTC_RTCCL_OutputDisable	Disables output of the real-time counter clock (32 kHz source) to the RTCCL pin.
RTC_RTCDIV_OutputEnable	Enables output of the real-time counter clock (32 kHz cycle) to the RTCDIV pin.
RTC_RTCDIV_OutputDisable	Disables output of the real-time counter clock (32 kHz cycle) to the RTCDIV pin.
RTC_ChangeCorrectionValue	Changes the timing and correction value for correcting clock errors.

**RTC\_Init**

Performs initialization necessary to control real-time counter functions.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_UserInit**

Performs user-defined initialization relating to the real-time counter.

**Remark** This API function is called as the [RTC\\_Init](#) callback routine.

**[Classification]**

CG\_rtc\_user.c

**[Syntax]**

```
void    RTC_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**RTC\_PowerOff**

Halts the clock supplied to the real-time counter.

**Remark** Calling this API function changes the real-time counter to reset status. For this reason, writes to the control registers (e.g. real-time counter control register 0: RTCC0) after this API function is called are ignored.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void RTC_PowerOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_CounterEnable**

Starts the count of the real-time counter (year, month, weekday, day, hour, minute, second).

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_CounterEnable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_CounterDisable**

Ends the count of the real-time counter (year, month, weekday, day, hour, minute, second).

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_CounterDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_SetHourSystem**

Sets the clock type (12-hour or 24-hour clock) of the real-time counter.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_rtc.h"
MD_STATUS RTC_SetHourSystem ( enum RTCHourSystem hoursystem );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum RTCHourSystem <i>hoursystem</i> ;	Clock type HOUR12: 12-hour clock HOUR24: 24-hour clock

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_BUSY1	Executing count process (before change to setting)
MD_BUSY2	Stopping count process (after change to setting)
MD_ARGERROR	Invalid argument specification

**Remark** If MD\_BUSY1 or MD\_BUSY2 is returned, it may be because the counter-operation is stopped, or the counter operation start wait time is too short, so make the value of the RTC\_WAITTIME macro defined in the header file "CG\_rtc.h" larger.

**[Example]**

Below is an example of setting the clock type to the 24-hour clock.

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    .....
    RTC_CounterEnable (); /* Start count */
    .....
    RTC_SetHourSystem ( HOUR24 ); /* Set clock type */
    .....
}
```

```
}  
}
```

**RTC\_CounterSet**

Sets the counter value (year, month, weekday, day, hour, minute, second) of the real-time counter.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_rtc.h"
MD_STATUS RTC_CounterSet ( struct RTCCounterValue counterwriteval );
```

**[Argument(s)]**

I/O	Argument	Description
I	struct RTCCounterValue counterwriteval;	Counter value

**Remark** Below is an example of the structure RTCCounterValue (counter value) for the real-time counter.

```
struct RTCCounterValue {
    UCHAR  Sec;    /* second */
    UCHAR  Min;    /* Minute */
    UCHAR  Hour;   /* Hour */
    UCHAR  Day;    /* Day */
    UCHAR  Week;   /* Weekday (0: Sunday, 6: Saturday) */
    UCHAR  Month;  /* Month */
    UCHAR  Year;   /* Year */
};
```

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_BUSY1	Executing count process (before change to setting)
MD_BUSY2	Stopping count process (after change to setting)

**Remark** If MD\_BUSY1 or MD\_BUSY2 is returned, it may be because the counter-operation is stopped, or the counter operation start wait time is too short, so make the value of the RTC\_WAITTIME macro defined in the header file "CG\_rtc.h" larger.

**[Example]**

The example below shows the counter value of the real-time counter being set to "2008/12/25 (Thu.) 17:30:00".

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( main ) {
    struct RTCCounterValue counterwriteval;
    .....
    RTC_CounterEnable ();          /* Start count */
    .....
    counterwriteval.Year = 0x08;
    counterwriteval.Month = 0x12;
    counterwriteval.Day = 0x25;
    counterwriteval.Week = 0x05;
    counterwriteval.Hour = 0x17;
    counterwriteval.Min = 0x30;
    counterwriteval.Sec = 0;
    RTC_SetHourSystem ( HOUR24 );  /* Set clock type */
    RTC_CounterSet ( counterwriteval ); /* Set counter value */
    .....
}
```

**RTC\_CounterGet**

Reads the counter value (year, month, weekday, day, hour, minute, second) of the real-time counter.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_rtc.h"
MD_STATUS RTC_CounterGet ( struct RTCCounterValue *counterreadval );
```

**[Argument(s)]**

I/O	Argument	Description
O	struct RTCCounterValue *counterreadval;	Pointer to structure in which to store the counter value being read

**Remark** See [RTC\\_CounterSet](#) for details about the RTCCounterValue counter value.

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_BUSY1	Executing count process (before reading)
MD_BUSY2	Stopping count process (after reading)

**Remark** If MD\_BUSY1 or MD\_BUSY2 is returned, it may be because the counter-operation is stopped, or the counter operation start wait time is too short, so make the value of the RTC\_WAITTIME macro defined in the header file "CG\_rtc.h" larger.

**[Example]**

Below is an example of reading the counter value of the real-time counter.

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    struct RTCCounterValue counterreadval;
    .....
    RTC_CounterEnable (); /* Start count */
    .....
    RTC_CounterGet ( &counterreadval ); /* Read count value */
    .....
}
```



```
}  
}
```

**RTC\_ConstPeriodInterruptEnable**

Sets the cycle of the interrupts INTRTC, then starts the cyclic interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_rtc.h"
MD_STATUS RTC_ConstPeriodInterruptEnable ( enum RTCINTPeriod period );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum RTCINTPeriod <i>period</i> ;	Interrupt INTRTC cycle HALFSEC: 0.5 seconds ONESEC: 1 second ONEMIN: 1 minute ONEHOUR: 1 hour ONEDAY: 1 day ONEMONTH: 1 month

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of setting the cycle of the interrupts INTRTC, then starting the cyclic interrupt function.

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    .....
    RTC_ConstPeriodInterruptDisable (); /* End of cyclic interrupt function */
    .....
    RTC_ConstPeriodInterruptEnable ( HALFSEC ); /* Start of cyclic interrupt function */
    .....
}
```

**RTC\_ConstPeriodInterruptDisable**

Ends the cyclic interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_ConstPeriodInterruptDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_ConstPeriodInterruptCallback**

Performs processing in response to the cyclic interrupt INTRTC.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTRTC corresponding to the cyclic interrupt INTRTC.

**[Classification]**

CG\_rtc\_user.c

**[Syntax]**

```
void RTC_ConstPeriodInterruptCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_AlarmEnable**

Starts the alarm interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_AlarmEnable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_AlarmDisable**

Ends the alarm interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_AlarmDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_AlarmSet**

Sets the alarm conditions (weekday, hour, minute).

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_rtc.h"
void RTC_AlarmSet ( struct RTCArmValue alarmval );
```

**[Argument(s)]**


I/O	Argument	Description
I	struct RTCArmValue alarmval;	Alarm conditions (weekday, hour, minute)

**Remark** Below is shown the structure RTCArmValue (alarm conditions).

```
struct RTCArmValue {
    UCHAR Alarmwm; /* Minute */
    UCHAR Alarmwh; /* Hour */
    UCHAR Alarmmw; /* Weekday */
};
```

- Alarmwm (Minute)


Below are shown the meanings of each bit of the structure member Alarmwm.



- Alarmwh (Hour)


Below are shown the meanings of each bit of the structure member Alarmwh. If the real-time counter is set to the 12-hour clock, then bit 5 has the following meaning.

- 0: AM
- 1: PM



- Alarmww (Weekday)

Below are shown the meanings of each bit of the structure member Alarmww.



[Return value]

None.

[Example 1]

The example below shows the alarm conditions being set to "Monday/Tuesday/Wednesday at 17:30".

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    struct RTCAlarmValue alarmval;
    .....
    RTC_AlarmEnable ();          /* Start alarm interrupt function */
    RTC_CounterEnable ();       /* Start count */
    .....
    RTC_SetHourSystem ( HOUR24 ); /* Set clock type */
    alarmval.Alarmww = 0xe;
    alarmval.Alarmwh = 0x17;
    alarmval.Alarmwm = 0x30;
    RTC_AlarmSet ( alarmval );  /* Set conditions */
    .....
}
```



**[Example 2]**

The example below shows the alarm conditions being set to "Saturday/Sunday (time left unchanged)".

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    struct RTCArmValue  alarmval;
    .....
    RTC_AlarmEnable ();          /* Start alarm interrupt function */
    .....
    alarmval.Alarmww = 0x41;
    RTC_AlarmSet ( alarmval );  /* Change conditions */
    .....
}
```

**RTC\_AlarmGet**

Reads the alarm conditions (weekday, hour, minute).

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_rtc.h"
void RTC_AlarmGet ( struct RTCArmValue *alarmval );
```

**Remark** See [RTC\\_AlarmSet](#) for details about RTCArmValue (alarm conditions).

**[Argument(s)]**

I/O	Argument	Description
O	struct RTCArmValue *alarmval;	Pointer to structure in which to store the conditions being read

**[Return value]**

None.

**[Example]**

The example below shows the alarm conditions being read.

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    struct RTCArmValue alarmval;
    .....
    RTC_AlarmEnable (); /* Start alarm interrupt function */
    .....
    RTC_AlarmGet ( &alarmval ); /* Read conditions */
    .....
}
```

**RTC\_AlarmInterruptCallback**

Performs processing in response to the alarm interrupt INTRTC.

**Remark** This API function is called as the callback routine of interrupt process MD\_INTRTC corresponding to the alarm interrupt INTRTC.

**[Classification]**

CG\_rtc\_user.c

**[Syntax]**

```
void    RTC_AlarmInterruptCallback ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_IntervalStart**

Starts the interval interrupt function.

**Remark** After setting the cycle of the interrupts INTRTCI, call [RTC\\_IntervalInterruptEnable](#) to start the interval interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void RTC_IntervalStart ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_IntervalStop**

Ends the interval interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void RTC_IntervalStop ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_IntervalInterruptEnable**

Sets the cycle of the interrupts INTRTCI, then starts the interval interrupt function.

**Remark** Call [RTC\\_IntervalStart](#) to start the interval interrupt function without setting the cycle of the interrupts INTRTCI.

**[Classification]**

CG\_rtc.c

**[Syntax]**

- [Ix3 (excluding IB3)] [Kx3-A] [Kx3-L] [Lx3]

```
#include "CG_rtc.h"
MD_STATUS RTC_IntervalInterruptEnable ( enum RTCINTInterval interval );
```

- [Kx3]

```
#include "CG_rtc.h"
void RTC_IntervalInterruptEnable ( enum RTCINTInterval interval );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum RTCINTInterval interval;	Interrupt INTRTCI cycle INTERVAL0: 2 <sup>6</sup> /fXT INTERVAL1: 2 <sup>7</sup> /fXT INTERVAL2: 2 <sup>8</sup> /fXT INTERVAL3: 2 <sup>9</sup> /fXT INTERVAL4: 2 <sup>10</sup> /fXT INTERVAL5: 2 <sup>11</sup> /fXT INTERVAL6: 2 <sup>12</sup> /fXT

**Remark** fXT is the frequency of the subsystem clock.

**[Return value]**

- [Ix3 (excluding IB3)] [Kx3-A] [Kx3-L] [Lx3]

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

- [Kx3]  
None.

**[Example]**

Below is an example of changing the interval, the restarting the interval interrupt function.

[CG\_main.c]

```
#include "CG_rtc.h"
void main ( void ) {
    .....
    RTC_IntervalStart ();          /* Start interval interrupt function */
    .....
    RTC_IntervalStop ();          /* End interval interrupt function */
    .....
    RTC_IntervalInterruptEnable ( INTERVAL6 ); /* Start interval interrupt function */
    .....
}
```

**RTC\_IntervalInterruptDisable**

Ends the interval interrupt function.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_IntervalInterruptDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**RTC\_RTC1HZ\_OutputEnable**

Enables output of the real-time counter correction clock (1 Hz) to the RTC1HZ pin.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_RTC1HZ_OutputEnable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_RTC1HZ\_OutputDisable**

Disables output of the real-time counter correction clock (1 Hz) to the RTC1HZ pin.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_RTC1HZ_OutputDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_RTCCCL\_OutputEnable**

Enables output of the real-time counter clock (32 kHz source) to the RTCCL pin.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_RTCCCL_OutputEnable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_RTCCCL\_OutputDisable**

Disables output of the real-time counter clock (32 kHz source) to the RTCCCL pin.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_RTCCCL_OutputDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_RTCDIV\_OutputEnable**

Enables output of the real-time counter clock (32 kHz cycle) to the RTCDIV pin.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_RTCDIV_OutputEnable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_RTCDIV\_OutputDisable**

Disables output of the real-time counter clock (32 kHz cycle) to the RTCDIV pin.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
void    RTC_RTCDIV_OutputDisable ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**RTC\_ChangeCorrectionValue**

Changes the timing and correction value for correcting clock errors.

**[Classification]**

CG\_rtc.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_rtc.h"
MD_STATUS RTC_ChangeCorrectionValue ( enum RTCCorectionTiming timing, UCHAR corectVal );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum RTCCorectionTiming <i>timing</i> ;	When clock errors are corrected EVERY20S: When the seconds digits are 00, 20 or 40 EVERY60S: When the seconds digits are 00
I	UCHAR <i>corectVal</i> ;	Clock error correction value

**Remark** This API function does not correct clock errors if correction value *corectVal* is set to 0x0, 0x1, 0x40 or 0x41.

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**C.3.13 Clock Output**

Below is a list of API functions output by Code Generator for clock output use.

**Table C-14. API Functions: [Clock Output]**

API Function Name	Function
PCL_Init	Performs initialization necessary to control clock output control circuit functions.
PCL_UserInit	Performs user-defined initialization relating to the clock output control circuits.
PCL_Start	Starts clock output.
PCL_Stop	Ends clock output.
PCL_ChangeFreq	Changes the output clock to the PCL pin.



**PCL\_Init**

Performs initialization necessary to control clock output control circuit functions.

**[Classification]**

CG\_pcl.c

**[Syntax]**

```
void PCL_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**PCL\_UserInit**

Performs user-defined initialization relating to the clock output control circuits.

**Remark** This API function is called as the [PCL\\_Init](#) callback routine.

**[Classification]**

CG\_pcl\_user.c

**[Syntax]**

```
void PCL_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**PCL\_Start**

Starts clock output.

**[Classification]**

CG\_pcl.c

**[Syntax]**

```
void PCL_Start ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**PCL\_Stop**

Ends clock output.

**[Classification]**

CG\_pcl.c

**[Syntax]**

```
void PCL_Stop ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**PCL\_ChangeFreq**

Changes the output clock to the PCL pin.

**Remark** The value specified in parameter *clock* is set to clock output select register (CKS).

**[Classification]**

CG\_pcl.c

**[Syntax]**

```
#include "CG_pclbuz.h"
void PCL_ChangeFreq ( enum PCLclock clock );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum PCLclock <i>clock</i> ;	Output clock type MAINCLOCK: fMAIN MAIN2: fMAIN/2 MAIN4: fMAIN/4 MAIN8: fMAIN/8 MAIN16: fMAIN/16 MAIN2048: fMAIN/2048 MAIN4096: fMAIN/4096 MAIN8192: fMAIN/8192 PLLCLOCK: fPLL PLL2: fPLL/2 PLL4: fPLL/4 PLL8: fPLL/8 PLL16: fPLL/16 PLL2048: fPLL/2048 PLL4096: fPLL/4096 PLL8192: fPLL/8192 ILCLOCK: fIL SUBCLOCK: fSUB

**Remark** fMAIN is the main system clock frequency; fPLL is the PLL clock frequency; fIL is the internal low-speed oscillation clock frequency; fSUB is the subsystem clock frequency.

**[Return value]**

None.

**C.3.14 Clock Output/Buzzer Output**

Below is a list of API functions output by Code Generator for clock output/buzzer output use.

**Table C-15. API Functions: [Clock Output/Buzzer Output]**

API Function Name	Function
PCLBUZn_Init	Performs initialization necessary to control clock/buzzer output control circuit functions.
PCLBUZn_UserInit	Performs user-defined initialization relating to the clock/buzzer output control circuits.
PCLBUZn_Start	Starts clock/buzzer output.
PCLBUZn_Stop	Ends clock/buzzer output.
PCLBUZn_ChangeFreq	Changes the output clock to the PCLBUZn pin.

**PCLBUZ $n$ \_Init**

Performs initialization necessary to control clock/buzzer output control circuit functions.

**[Classification]**

CG\_pclbuz.c

**[Syntax]**

```
void PCLBUZn_Init ( void );
```

**Remark**  $n$  is the output pin.

**[Argument(s)]**

None.

**[Return value]**

None.

**PCLBUZ $n$ \_UserInit**

Performs user-defined initialization relating to the clock/buzzer output control circuits.

**Remark** This API function is called as the [PCLBUZ \$n\$ \\_Init](#) callback routine.

**[Classification]**

CG\_pclbuz\_user.c

**[Syntax]**

```
void PCLBUZ $n$ _UserInit ( void );
```

**Remark**  $n$  is the output pin.

**[Argument(s)]**

None.

**[Return value]**

None.



**PCLBUZ $n$ \_Start**

Starts clock/buzzer output.

**[Classification]**

CG\_pclbuz.c

**[Syntax]**

```
void PCLBUZn_Start ( void );
```

**Remark**  $n$  is the output pin.

**[Argument(s)]**

None.

**[Return value]**

None.

**PCLBUZ $n$ \_Stop**

Ends clock/buzzer output.

**[Classification]**

CG\_pclbuz.c

**[Syntax]**

```
void PCLBUZn_Stop ( void );
```

**Remark**  $n$  is the output pin.

**[Argument(s)]**

None.

**[Return value]**

None.

**PCLBUZn\_ChangeFreq**

Changes the output clock to the PCLBUZn pin.

**Remark** The value specified in parameter *clock* is set to clock output select register *n* (CKSn).

**[Classification]**

CG\_pclbuz.c

**[Syntax]**

```
#include "CG_pclbuz.h"
MD_STATUS PCLBUZn_ChangeFreq ( enum PCLBUZclock clock );
```

**Remark** *n* is the output pin.

**[Argument(s)]**

I/O	Argument	Description
I	enum PCLBUZclock <i>clock</i> ;	Output clock type MAINCLOCK: fMAIN MAIN2: fMAIN/2 MAIN4: fMAIN/4 MAIN8: fMAIN/8 MAIN16: fMAIN/16 MAIN2048: fMAIN/2048 MAIN4096: fMAIN/4096 MAIN8192: fMAIN/8192 SUBCLOCK: fSUB SUB2: fSUB/2 SUB4: fSUB/4 SUB8: fSUB/8 SUB16: fSUB/16 SUB32: fSUB/32 SUB64: fSUB/64 SUB128: fSUB/128

**Remark** fMAIN is the main system clock frequency; fSUB is the subsystem clock frequency.

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**[Example]**

Below is an example of changing the output clock of pin PCLBUZ0 each time an externally connected button is pressed, in a system that generates the interrupt INTPO each time the button is pressed.

[CG\_main.c]

```
#include "CG_macrodriver.h"
#include "CG_pclbuz.h"
BOOL gFlag; /* Button pressed flag */
#define PCLBUZ_FREQUENCY 8 /* Total number of output clock types */
const enum PCLBUZclock gClock[PCLBUZ_FREQUENCY] = { /* Output clock type */
    PCLBUZ_OUTCLK_fSUB0, PCLBUZ_OUTCLK_fSUB1, PCLBUZ_OUTCLK_fSUB2,
    PCLBUZ_OUTCLK_fSUB3, PCLBUZ_OUTCLK_fSUB4, PCLBUZ_OUTCLK_fSUB5,
    PCLBUZ_OUTCLK_fSUB6, PCLBUZ_OUTCLK_fSUB7
};
void main ( void ) {
    int index = 0;
    gFlag = 0; /* Initialize button pressed flag */
    .....
    PCLBUZ0_Start (); /* Start clock/buzzer output */
    while ( 1 ) {
        if ( gFlag ) { /* Wait for INTPO */
            PCLBUZ_ChangeFreq ( gClock[index++] ); /* Change output clock */
            if ( index >= PCLBUZ_FREQUENCY ) {
                index = 0;
            }
            gFlag = 0; /* Clear button pressed flag */
        }
    }
}
```

[CG\_int\_user.c]

```
#include "CG_macrodriver.h"
extern BOOL gFlag; /* Button pressed flag */
__interrupt void MD_INTPO ( void ) { /* Interrupt processing for INTPO */
    gFlag = 1; /* Set button pressed flag */
}
```

**C.3.15 LCD Controller/Driver**

Below is a list of API functions output by Code Generator for LCD controller/driver use.

**Table C-16. API Functions: [LCD Controller/Driver]**

API Function Name	Function
<a href="#">LCD_Init</a>	Performs initialization necessary to control LCD controller/driver functions.
<a href="#">LCD_UserInit</a>	Performs user-defined initialization relating to the LCD controller/driver.
<a href="#">LCD_DisplayOn</a>	Sets the LCD controller/driver to "display on" status.
<a href="#">LCD_DisplayOff</a>	Sets the LCD controller/driver to "display off" status.
<a href="#">LCD_VoltageOn</a>	Enables operation of the LCD controller/driver's voltage boost circuit and capacitor split circuit, then outputs the deselect signal from the segment pin.
<a href="#">LCD_VoltageOff</a>	Halts operation of the LCD controller/driver's voltage boost circuit and capacitor split circuit, then outputs the groundlevel signal from the segment/common pin.

**LCD\_Init**

Performs initialization necessary to control LCD controller/driver functions.

**[Classification]**

CG\_lcd.c

**[Syntax]**

```
void LCD_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**LCD\_UserInit**

Performs user-defined initialization relating to the LCD controller/driver.

**Remark** This API function is called as the [LCD\\_Init](#) callback routine.

**[Classification]**

CG\_lcd\_user.c

**[Syntax]**

```
void LCD_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**LCD\_DisplayOn**

Sets the LCD controller/driver to "display on" status.

**[Classification]**

CG\_lcd.c

**[Syntax]**

```
void LCD_DisplayOn ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**LCD\_DisplayOff**

Sets the LCD controller/driver to "display off" status.

**[Classification]**

CG\_lcd.c

**[Syntax]**

```
void LCD_DisplayOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**LCD\_VoltageOn**

Enables operation of the LCD controller/driver's voltage boost circuit and capacitor split circuit, then outputs the deselect signal from the segment pin.

**[Classification]**

CG\_lcd.c

**[Syntax]**

```
void LCD_VoltageOn ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**LCD\_VoltageOff**

Halts operation of the LCD controller/driver's voltage boost circuit and capacitor split circuit, then outputs the ground-level signal from the segment/common pin.

**[Classification]**

CG\_lcd.c

**[Syntax]**

```
void LCD_VoltageOff ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

## C.3.16 DMA

Below is a list of API functions output by Code Generator for DMA (Direct Memory Access) controller use.

Table C-17. API Functions: [DMA]

API Function Name	Function
<a href="#">DMAAn_Init</a>	Performs initialization necessary to control DMA controller functions.
<a href="#">DMAAn_UserInit</a>	Performs user-defined initialization relating to the DMA controller.
<a href="#">DMAAn_Enable</a>	Enables operation of channel <i>n</i> .
<a href="#">DMAAn_Disable</a>	Disables operation of channel <i>n</i> .
<a href="#">DMAAn_Hold</a>	Holds a DMA start request.
<a href="#">DMAAn_Restart</a>	Releases hold on a DMA start request.
<a href="#">DMAAn_CheckStatus</a>	Reads the transfer status (transfer complete/transfer ongoing).
<a href="#">DMAAn_SetData</a>	Sets the RAM address of the transfer source/destination, and the number of times the data has been transferred.
<a href="#">DMAAn_SoftwareTriggerOn</a>	Starts DMA transfer when DMA operation is enabled.

**DMA $n$ \_Init**

Performs initialization necessary to control DMA controller functions.

**[Classification]**

CG\_dma.c

**[Syntax]**

```
void DMA $n$ _Init ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**DMA $n$ \_UserInit**

Performs user-defined initialization relating to the DMA controller.

**Remark** This API function is called as the [DMA \$n\$ \\_Init](#) callback routine.

**[Classification]**

CG\_dma\_user.c

**[Syntax]**

```
void DMA $n$ _UserInit ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**DMA $n$ \_Enable**

Enables operation of channel  $n$ .

**[Classification]**

CG\_dma.c

**[Syntax]**

```
void DMA $n$ _Enable ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**DMA $n$ \_Disable**

Disables operation of channel  $n$ .

- Remarks**
1. This API function does not forcibly terminate DMA transfer.
  2. Before using this API function, you must confirm that transmission has ended via [DMA \$n\$ \\_CheckStatus](#).

**[Classification]**

CG\_dma.c

**[Syntax]**

```
void DMA $n$ _Disable ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**[Example]**

The example below shows setting the operation mode of channel 0 to "disabled".

[CG\_main.c]

```
#include "CG_macrodriver.h"
void main ( void ) {
    .....
    while ( MD_COMPLETED == DMA0_CheckStatus () ); /* Check transfer status */
    DMA0_Disable (); /* Change to operation disabled status */
    .....
}
```



**DMA $n$ \_Hold**

Holds a DMA start request.

**Remark** Call [DMA \$n\$ \\_Restart](#) to release the hold on DMA start requests.

**[Classification]**

CG\_dma.c

**[Syntax]**

```
void DMA $n$ _Hold ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**DMA $n$ \_Restart**

Releases hold on a DMA start request.

**[Classification]**

CG\_dma.c

**[Syntax]**

```
void DMA $n$ _Restart ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**DMA $n$ \_CheckStatus**

Reads the transfer status (transfer complete/transfer ongoing).

**[Classification]**

CG\_dma.c

**[Syntax]**

```
#include "CG_macrodriver.h"
MD_STATUS DMA $n$ _CheckStatus ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

Macro	Description
MD_UNDEREXEC	Transfer ongoing
MD_COMPLETED	Transfer complete

**DMA $n$ \_SetData**

Sets the RAM address of the transfer source/destination, and the number of times the data has been transferred.

**Remark** Calling this API function while a transfer is ongoing will end the transfer.

**[Classification]**

CG\_dma.c

**[Syntax]**

- [Fx3] [Ix3] [Kx3-A] [Kx3-L] [Lx3]

```
#include "CG_macrodriver.h"
MD_STATUS DMA $n$ _SetData ( USHORT sfraddr, USHORT ramaddr, USHORT count );
```

- [Kx3]

```
#include "CG_macrodriver.h"
MD_STATUS DMA $n$ _SetData ( USHORT ramaddr, USHORT count );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

I/O	Argument	Description
I	USHORT <i>sfraddr</i> ;	SFR address of source/destination
I	USHORT <i>ramaddr</i> ;	RAM address of source/destination
I	USHORT <i>count</i> ;	Number of data transmissions (1 to 1024)

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ARGERROR	Invalid argument specification

**DMA $n$ \_SoftwareTriggerOn**

Starts DMA transfer when DMA operation is enabled.

**[Classification]**

CG\_dma.c

**[Syntax]**

```
void DMA $n$ _SoftwareTriggerOn ( void );
```

**Remark**  $n$  is the channel number.

**[Argument(s)]**

None.

**[Return value]**

None.

**[Example]**

Below is an example of software trigger as a DMA transfer start trigger.

[CG\_main.c]

```
void main ( void ) {  
    .....  
    DMA0_Enable ();          /* Change to operation enabled status */  
    DMA0_SoftwareTriggerOn (); /* Start DMA transfer */  
    .....  
}
```

## C.3.17 LVI

Below is a list of API functions output by Code Generator for low-voltage detector use.

**Table C-18. API Functions: [LVI]**

API Function Name	Function
<a href="#">LVI_Init</a>	Performs initialization necessary to control low-voltage detector functions.
<a href="#">LVI_UserInit</a>	Performs user-defined initialization relating to the low-voltage detector.
<a href="#">LVI_InterruptModeStart</a>	Starts low-voltage detection (when in interrupt generation mode).
<a href="#">LVI_ResetModeStart</a>	Starts low-voltage detection (when in internal reset mode).
<a href="#">LVI_Stop</a>	Stops low-voltage detection.
<a href="#">LVI_SetLVILevel</a>	Sets the low-voltage detection level.

**LVI\_Init**

Performs initialization necessary to control low-voltage detector functions.

**[Classification]**

CG\_lvi.c

**[Syntax]**

```
void LVI_Init ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**LVI\_UserInit**

Performs user-defined initialization relating to the low-voltage detector.

**Remark** This API function is called as the [LVI\\_Init](#) callback routine.

**[Classification]**

CG\_lvi\_user.c

**[Syntax]**

```
void LVI_UserInit ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.



**LVI\_InterruptModeStart**

Starts low-voltage detection (when in interrupt generation mode).

**[Classification]**

CG\_lvi.c

**[Syntax]**

```
void LVI_InterruptModeStart ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**[Example]**

The example below shows the detection of low voltage when the operation mode is interrupt generation mode (generate the interrupt INTLVI).

[CG\_main.c]

```
void main ( void ) {
    .....
    LVI_InterruptModeStart ( );          /* Start low-voltage detection */
    .....
}
```

[CG\_lvi\_user.c]

```
__interrupt void MD_INTLVI ( void ) { /* Interrupt processing for INTLVI */
    if ( LVIF == 1 ) {                /* Trigger identification: Check LVIF flag */
        ..... /* Handle case when "power voltage (VDD) < detected voltage (VLVI)" detected */
    } else {
        ..... /* Handle case when "power voltage (VDD) >= detected voltage (VLVI)" detected */
    }
}
```

**LVI\_ResetModeStart**

Starts low-voltage detection (when in internal reset mode).

**[Classification]**

CG\_lvi.c

**[Syntax]**

```
MD_STATUS LVI_ResetModeStart ( void );
```

**[Argument(s)]**

None.

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR	Exit with error (abend) <ul style="list-style-type: none"> <li>- The program is configured to not use the low-voltage detector function.</li> <li>- The object of low voltage detection is external voltage (VDD), and power voltage (VDD) &lt;= detected voltage (VLVI).</li> <li>- The object of low voltage detection is external input voltage (EXLVI), and external input voltage (EXLVI) &lt;= detected voltage (VEXLVI).</li> </ul>

**LVI\_Stop**

Stops low-voltage detection.

**[Classification]**

CG\_lvi.c

**[Syntax]**

```
void LVI_Stop ( void );
```

**[Argument(s)]**

None.

**[Return value]**

None.

**LVI\_SetLVILevel**

Sets the low-voltage detection level.

- Remarks 1.** To change the low-voltage detection level, you must call [LVI\\_Stop](#) before calling this API function.  
**2.** The value specified in parameter *level* is set to low-voltage detection level select register (LVIS).

**[Classification]**

CG\_lvi.c

**[Syntax]**

```
#include "CG_macrodriver.h"
#include "CG_lvi.h"
MD_STATUS LVI_SetLVILevel ( enum LVILevel level );
```

**[Argument(s)]**

I/O	Argument	Description
I	enum LVILevel <i>level</i> ;	Voltage level to detect as low voltage LVILEVEL0: 4.22 V ± 0.1 V LVILEVEL1: 4.07 V ± 0.1 V LVILEVEL2: 3.92 V ± 0.1 V LVILEVEL3: 3.76 V ± 0.1 V LVILEVEL4: 3.61 V ± 0.1 V LVILEVEL5: 3.45 V ± 0.1 V LVILEVEL6: 3.30 V ± 0.1 V LVILEVEL7: 3.15 V ± 0.1 V LVILEVEL8: 2.99 V ± 0.1 V LVILEVEL9: 2.84 V ± 0.1 V LVILEVEL10: 2.68 V ± 0.1 V LVILEVEL11: 2.53 V ± 0.1 V LVILEVEL12: 2.38 V ± 0.1 V LVILEVEL13: 2.22 V ± 0.1 V LVILEVEL14: 2.07 V ± 0.1 V LVILEVEL15: 1.91 V ± 0.1 V

**Remark** If the target device is 78K0R/Fx3 or 78K0R/lx3, then keyword that can be specified for *level* is limited to "LVILEVEL0" to "LVILEVEL9".

**[Return value]**

Macro	Description
MD_OK	Normal completion
MD_ERROR	Exit with error (abend)
MD_ARGERROR	Invalid argument specification

## APPENDIX D INDEX

**A**

[A/D] ... 84

A/D ... 254

AD\_ComparatorOff ... 259

AD\_ComparatorOn ... 258

AD\_Init ... 255

AD\_PowerOff ... 257

AD\_Read ... 265

AD\_ReadByte ... 266

AD\_SelectADChannel ... 264

AD\_Start ... 260

AD\_Stop ... 263

AD\_UserInit ... 256

AD\_ComparatorOff ... 259

AD\_ComparatorOn ... 258

AD\_Init ... 255

AD\_PowerOff ... 257

AD\_Read ... 265

AD\_ReadByte ... 266

AD\_SelectADChannel ... 264

AD\_Start ... 260

AD\_Stop ... 263

AD\_UserInit ... 256

[All Output Messages] tab ... 99

AMPn\_Start ... 244

AMPn\_Stop ... 245

API functions ... 114

A/D ... 254

Clock Output ... 328

Clock Output/Buzzer Output ... 334

Comparator/PGA ... 246

D/A ... 267

DMA ... 348

External Bus ... 135

INT ... 146

LVI ... 358

Operational Amplifier ... 241

Port ... 139

RTC ... 294

Serial ... 157

System ... 124

Timer ... 276

Watchdog Timer ... 290

**B**

Browse For Folder dialog box ... 105

BUS\_Init ... 136

BUS\_PowerOff ... 138

BUS\_UserInit ... 137

**C**

CG\_ChangeClockMode ... 128

CG\_ChangeFrequency ... 130

CG\_ReadResetSource ... 127

CG\_SelectPowerSaveMode ... 132

CG\_SelectStabTime ... 134

CLOCK\_Init ... 125

[Clock Output] ... 89

Clock Output ... 328

PCL\_ChangeFreq ... 333

PCL\_Init ... 329

PCL\_Start ... 331

PCL\_Stop ... 332

PCL\_UserInit ... 330

[Clock Output/Buzzer Output] ... 90

Clock Output/Buzzer Output ... 334

PCLBUZn\_ChangeFreq ... 339

PCLBUZn\_Init ... 335

PCLBUZn\_Start ... 337

PCLBUZn\_Stop ... 338

PCLBUZn\_UserInit ... 336

CLOCK\_UserInit ... 126

CMPPGA\_ChangeCMPnRefVoltage ... 252

CMPPGA\_ChangePGAFACTOR ... 253

CMPPGA\_Init ... 247

CMPPGA\_PowerOff ... 249

- CMPPGA\_Start ... 250
- CMPPGA\_Stop ... 251
- CMPPGA\_UserInit ... 248
- Code Generator panel ... 73
  - [A/D] ... 84
  - [Clock Output] ... 89
  - [Clock Output/Buzzer Output] ... 90
  - [Comparator/PGA] ... 83
  - [D/A] ... 85
  - [DMA] ... 92
  - [External Bus] ... 78
  - [INT] ... 80
  - [LCD Controller/Driver] ... 91
  - [LVI] ... 93
  - [Operational Amplifier] ... 82
  - [Port] ... 79
  - [RTC] ... 88
  - [Serial] ... 81
  - [System] ... 77
  - [Timer] ... 86
  - [Watchdog Timer] ... 87
- Code Generator Preview panel ... 94
- [Code Generator] tab ... 100
- Column Chooser dialog box ... 101
- [Comparator/PGA] ... 83
- Comparator/PGA ... 246
  - CMPPGA\_ChangeCMPnRefVoltage ... 252
  - CMPPGA\_ChangePGAFactor ... 253
  - CMPPGA\_Init ... 247
  - CMPPGA\_PowerOff ... 249
  - CMPPGA\_Start ... 250
  - CMPPGA\_Stop ... 251
  - CMPPGA\_UserInit ... 248
- CSImn\_ErrorCallback ... 186
- CSImn\_Init ... 175
- CSImn\_ReceiveData ... 180
- CSImn\_ReceiveEndCallback ... 185
- CSImn\_SendData ... 178
- CSImn\_SendEndCallback ... 184
- CSImn\_SendReceiveData ... 182
- CSImn\_Start ... 176
- CSImn\_Stop ... 177
- D**
- [D/A] ... 85
- D/A ... 267
  - DA\_Init ... 268
  - DAn\_Set12BitsValue ... 275
  - DAn\_Set8BitsValue ... 274
  - DAn\_SetValue ... 273
  - DAn\_Start ... 271
  - DAn\_Stop ... 272
  - DA\_PowerOff ... 270
  - DA\_UserInit ... 269
- DA\_Init ... 268
- DAn\_Set12BitsValue ... 275
- DAn\_Set8BitsValue ... 274
- DAn\_SetValue ... 273
- DAn\_Start ... 271
- DAn\_Stop ... 272
- DA\_PowerOff ... 270
- DA\_UserInit ... 269
- Device Pin List panel ... 62
  - [External Peripheral] tab ... 68
  - [Macro] tab ... 66
  - [Pin Number] tab ... 64
- Device Top View panel ... 70
- [Device Top View Settings] tab ... 55
- [DMA] ... 92
- DMA ... 348
  - DMAAn\_CheckStatus ... 355
  - DMAAn\_Disable ... 352
  - DMAAn\_Enable ... 351
  - DMAAn\_Hold ... 353
  - DMAAn\_Init ... 349
  - DMAAn\_Restart ... 354
  - DMAAn\_SetData ... 356
  - DMAAn\_SoftwareTriggerOn ... 357
  - DMAAn\_UserInit ... 350
- DMAAn\_CheckStatus ... 355
- DMAAn\_Disable ... 352
- DMAAn\_Enable ... 351

- DMA<sub>n</sub>\_Hold ... 353  
 DMA<sub>n</sub>\_Init ... 349  
 DMA<sub>n</sub>\_Restart ... 354  
 DMA<sub>n</sub>\_SetData ... 356  
 DMA<sub>n</sub>\_SoftwareTriggerOn ... 357  
 DMA<sub>n</sub>\_UserInit ... 350
- E**
- [External Bus] ... 78  
 External Bus ... 135  
     BUS\_Init ... 136  
     BUS\_PowerOff ... 138  
     BUS\_UserInit ... 137  
 [External Peripheral] tab ... 68
- F**
- [File Setting] tab ... 61  
 Functions ... 11, 26  
     Code Generator ... 26  
     Pin Configurator ... 11
- G**
- [Generation] tab ... 58
- I**
- IICA\_GetStopConditionCallback ... 226  
 IICA\_Init ... 211  
 IICA\_MasterErrorCallback ... 220  
 IICA\_MasterReceiveEndCallback ... 219  
 IICA\_MasterReceiveStart ... 216  
 IICA\_MasterSendEndCallback ... 218  
 IICA\_MasterSendStart ... 215  
 IICA\_PowerOff ... 213  
 IICA\_SlaveErrorCallback ... 225  
 IICA\_SlaveReceiveEndCallback ... 224  
 IICA\_SlaveReceiveStart ... 222  
 IICA\_SlaveSendEndCallback ... 223  
 IICA\_SlaveSendStart ... 221  
 IICA\_Stop ... 214  
 IICA\_StopCondition ... 217  
 IICA\_UserInit ... 212  
 IICmn\_Init ... 187  
 IICmn\_MasterErrorCallback ... 195  
 IICmn\_MasterReceiveEndCallback ... 194  
 IICmn\_MasterReceiveStart ... 190  
 IICmn\_MasterSendEndCallback ... 193  
 IICmn\_MasterSendStart ... 189  
 IICmn\_StartCondition ... 191  
 IICmn\_Stop ... 188  
 IICmn\_StopCondition ... 192  
 IICn\_GetStopConditionCallback ... 240  
 IICn\_Init ... 227  
 IICn\_MasterErrorCallback ... 234  
 IICn\_MasterReceiveEndCallback ... 233  
 IICn\_MasterReceiveStart ... 231  
 IICn\_MasterSendEndCallback ... 232  
 IICn\_MasterSendStart ... 230  
 IICn\_SlaveErrorCallback ... 239  
 IICn\_SlaveReceiveEndCallback ... 238  
 IICn\_SlaveReceiveStart ... 236  
 IICn\_SlaveSendEndCallback ... 237  
 IICn\_SlaveSendStart ... 235  
 IICn\_Stop ... 229  
 IICn\_UserInit ... 228  
 [INT] ... 80  
 INT ... 146  
     INT\_MaskableInterruptEnable ... 151  
     INTP\_Init ... 147  
     INTPn\_Disable ... 153  
     INTPn\_Enable ... 154  
     INTP\_UserInit ... 148  
     KEY\_Disable ... 155  
     KEY\_Enable ... 156  
     KEY\_Init ... 149  
     KEY\_UserInit ... 150  
 INT\_MaskableInterruptEnable ... 151  
 INTP\_Init ... 147  
 INTPn\_Disable ... 153  
 INTPn\_Enable ... 154  
 INTP\_UserInit ... 148
- K**
- KEY\_Disable ... 155

KEY\_Enable ... 156  
 KEY\_Init ... 149  
 KEY\_UserInit ... 150

**L**

[LCD Controller/Driver] ... 91  
 LCD Controller/Driver  
   LCD\_DisplayOff ... 345  
   LCD\_DisplayOn ... 344  
   LCD\_Init ... 342  
   LCD\_UserInit ... 343  
   LCD\_VoltageOff ... 347  
   LCD\_VoltageOn ... 346  
 LCD\_DisplayOff ... 345  
 LCD\_DisplayOn ... 344  
 LCD\_Init ... 342  
 LCD\_UserInit ... 343  
 LCD\_VoltageOff ... 347  
 LCD\_VoltageOn ... 346  
 [LVI] ... 93  
 LVI ... 358  
   LVI\_Init ... 359  
   LVI\_InterruptModeStart ... 361  
   LVI\_ResetModeStart ... 362  
   LVI\_SetLVILevel ... 364  
   LVI\_Stop ... 363  
   LVI\_UserInit ... 360  
 LVI\_Init ... 359  
 LVI\_InterruptModeStart ... 361  
 LVI\_ResetModeStart ... 362  
 LVI\_SetLVILevel ... 364  
 LVI\_Stop ... 363  
 LVI\_UserInit ... 360

**M**

[Macro Setting] tab ... 60  
 [Macro] tab ... 66  
 Main window ... 43

**N**

New Column dialog box ... 104

**O**

OPAMP\_Init ... 242  
 OPAMP\_UserInit ... 243  
 [Operational Amplifier] ... 82  
 Operational Amplifier ... 241  
   AMPn\_Start ... 244  
   AMPn\_Stop ... 245  
   OPAMP\_Init ... 242  
   OPAMP\_UserInit ... 243  
 Output panel ... 97  
   [All Output Messages] tab ... 99  
   [Code Generator] tab ... 100

**P**

PCLBUZn\_ChangeFreq ... 339  
 PCLBUZn\_Init ... 335  
 PCLBUZn\_Start ... 337  
 PCLBUZn\_Stop ... 338  
 PCLBUZn\_UserInit ... 336  
 PCL\_ChangeFreq ... 333  
 PCL\_Init ... 329  
 PCL\_Start ... 331  
 PCL\_Stop ... 332  
 PCL\_UserInit ... 330  
 [Pin Configurator Information] tab ... 54  
 [Pin Configurator Settings] tab ... 52  
 [Pin Number] tab ... 64  
 [Port] ... 79  
 Port ... 139  
   PORT\_ChangePmnInput ... 142  
   PORT\_ChangePmnOutput ... 144  
   PORT\_Init ... 140  
   PORT\_UserInit ... 141  
 PORT\_ChangePmnInput ... 142  
 PORT\_ChangePmnOutput ... 144  
 PORT\_Init ... 140  
 PORT\_UserInit ... 141  
 Project Tree panel ... 46  
 Property panel ... 49  
   [Device Top View Settings] tab ... 55  
   [File Setting] tab ... 61



[Generation] tab ... 58  
 [Macro Setting] tab ... 60  
 [Pin Configurator Information] tab ... 54  
 [Pin Configurator Settings] tab ... 52

**R**

[RTC] ... 88

RTC ... 294

RTC\_AlarmDisable ... 310  
 RTC\_AlarmEnable ... 309  
 RTC\_AlarmGet ... 314  
 RTC\_AlarmInterruptCallback ... 315  
 RTC\_AlarmSet ... 311  
 RTC\_ChangeCorrectionValue ... 327  
 RTC\_ConstPeriodInterruptCallback ... 308  
 RTC\_ConstPeriodInterruptDisable ... 307  
 RTC\_ConstPeriodInterruptEnable ... 306  
 RTC\_CounterDisable ... 299  
 RTC\_CounterEnable ... 298  
 RTC\_CounterGet ... 304  
 RTC\_CounterSet ... 302  
 RTC\_Init ... 295  
 RTC\_IntervallInterruptDisable ... 320  
 RTC\_IntervallInterruptEnable ... 318  
 RTC\_IntervalStart ... 316  
 RTC\_IntervalStop ... 317  
 RTC\_PowerOff ... 297  
 RTC\_RTC1HZ\_OutputDisable ... 322  
 RTC\_RTC1HZ\_OutputEnable ... 321  
 RTC\_RTCCL\_OutputDisable ... 324  
 RTC\_RTCCL\_OutputEnable ... 323  
 RTC\_RTCDIV\_OutputDisable ... 326  
 RTC\_RTCDIV\_OutputEnable ... 325  
 RTC\_SetHourSystem ... 300  
 RTC\_UserInit ... 296  
 RTC\_AlarmDisable ... 310  
 RTC\_AlarmEnable ... 309  
 RTC\_AlarmGet ... 314  
 RTC\_AlarmInterruptCallback ... 315  
 RTC\_AlarmSet ... 311  
 RTC\_ChangeCorrectionValue ... 327

RTC\_ConstPeriodInterruptCallback ... 308  
 RTC\_ConstPeriodInterruptDisable ... 307  
 RTC\_ConstPeriodInterruptEnable ... 306  
 RTC\_CounterDisable ... 299  
 RTC\_CounterEnable ... 298  
 RTC\_CounterGet ... 304  
 RTC\_CounterSet ... 302  
 RTC\_Init ... 295  
 RTC\_IntervallInterruptDisable ... 320  
 RTC\_IntervallInterruptEnable ... 318  
 RTC\_IntervalStart ... 316  
 RTC\_IntervalStop ... 317  
 RTC\_PowerOff ... 297  
 RTC\_RTC1HZ\_OutputDisable ... 322  
 RTC\_RTC1HZ\_OutputEnable ... 321  
 RTC\_RTCCL\_OutputDisable ... 324  
 RTC\_RTCCL\_OutputEnable ... 323  
 RTC\_RTCDIV\_OutputDisable ... 326  
 RTC\_RTCDIV\_OutputEnable ... 325  
 RTC\_SetHourSystem ... 300  
 RTC\_UserInit ... 296

**S**

SAUm\_Init ... 160  
 SAUm\_PowerOff ... 162  
 SAUm\_UserInit ... 161  
 Save As dialog box ... 106  
 [Serial] ... 81  
 Serial ... 157  
 CSImn\_ErrorCallback ... 186  
 CSImn\_Init ... 175  
 CSImn\_ReceiveData ... 180  
 CSImn\_ReceiveEndCallback ... 185  
 CSImn\_SendData ... 178  
 CSImn\_SendEndCallback ... 184  
 CSImn\_SendReceiveData ... 182  
 CSImn\_Start ... 176  
 CSImn\_Stop ... 177  
 IICA\_GetStopConditionCallback ... 226  
 IICA\_Init ... 211  
 IICA\_MasterErrorCallback ... 220

IICA_MasterReceiveEndCallback ...	219
IICA_MasterReceiveStart ...	216
IICA_MasterSendEndCallback ...	218
IICA_MasterSendStart ...	215
IICA_PowerOff ...	213
IICA_SlaveErrorCallback ...	225
IICA_SlaveReceiveEndCallback ...	224
IICA_SlaveReceiveStart ...	222
IICA_SlaveSendEndCallback ...	223
IICA_SlaveSendStart ...	221
IICA_Stop ...	214
IICA_StopCondition ...	217
IICA_UserInit ...	212
IICmn_Init ...	187
IICmn_MasterErrorCallback ...	195
IICmn_MasterReceiveEndCallback ...	194
IICmn_MasterReceiveStart ...	190
IICmn_MasterSendEndCallback ...	193
IICmn_MasterSendStart ...	189
IICmn_StartCondition ...	191
IICmn_Stop ...	188
IICmn_StopCondition ...	192
IICn_GetStopConditionCallback ...	240
IICn_Init ...	227
IICn_MasterErrorCallback ...	234
IICn_MasterReceiveEndCallback ...	233
IICn_MasterReceiveStart ...	231
IICn_MasterSendEndCallback ...	232
IICn_MasterSendStart ...	230
IICn_SlaveErrorCallback ...	239
IICn_SlaveReceiveEndCallback ...	238
IICn_SlaveReceiveStart ...	236
IICn_SlaveSendEndCallback ...	237
IICn_SlaveSendStart ...	235
IICn_Stop ...	229
IICn_UserInit ...	228
SAUm_Init ...	160
SAUm_PowerOff ...	162
SAUm_UserInit ...	161
UARTFn_DataComparisonDisable ...	204
UARTFn_DataComparisonEnable ...	203
UARTFn_ErrorCallback ...	210
UARTFn_ExpBitCetectCallback ...	208
UARTFn_IDMatchCallback ...	209
UARTFn_Init ...	196
UARTFn_PowerOff ...	197
UARTFn_ReceiveData ...	201
UARTFn_ReceiveEndCallback ...	206
UARTFn_SendData ...	200
UARTFn_SendEndCallback ...	205
UARTFn_SetComparisonData ...	202
UARTFn_SoftOverRunCallback ...	207
UARTFn_Start ...	198
UARTFn_Stop ...	199
UARTn_ErrorCallback ...	173
UARTn_Init ...	163
UARTn_ReceiveData ...	168
UARTn_ReceiveEndCallback ...	171
UARTn_SendData ...	166
UARTn_SendEndCallback ...	170
UARTn_SoftOverRunCallback ...	172
UARTn_Start ...	164
UARTn_Stop ...	165
[System] ...	77
System ...	124
CG_ChangeClockMode ...	128
CG_ChangeFrequency ...	130
CG_ReadResetSource ...	127
CG_SelectPowerSaveMode ...	132
CG_SelectStabTime ...	134
CLOCK_Init ...	125
CLOCK_UserInit ...	126
<b>T</b>	
TAUm_Channeln_ChangeCondition ...	282
TAUm_Channeln_ChangeDuty ...	287
TAUm_Channeln_ChangeTimerCondition ...	284
TAUm_Channeln_GetPulseWidth ...	286
TAUm_Channeln_SoftWareTriggerOn ...	289
TAUm_Channeln_Start ...	280
TAUm_Channeln_Stop ...	281
TAUm_Init ...	277

TAUm\_PowerOff ... 279  
 TAUm\_UserInit ... 278  
 [Timer] ... 86  
 Timer ... 276  
     TAUm\_Channeln\_ChangeCondition ... 282  
     TAUm\_Channeln\_ChangeDuty ... 287  
     TAUm\_Channeln\_ChangeTimerCondition ... 284  
     TAUm\_Channeln\_GetPulseWidth ... 286  
     TAUm\_Channeln\_SoftWareTriggerOn ... 289  
     TAUm\_Channeln\_Start ... 280  
     TAUm\_Channeln\_Stop ... 281  
     TAUm\_Init ... 277  
     TAUm\_PowerOff ... 279  
     TAUm\_UserInit ... 278

**U**

UARTFn\_DataComparisonDisable ... 204  
 UARTFn\_DataComparisonEnable ... 203  
 UARTFn\_ErrorCallback ... 210  
 UARTFn\_ExpBitCetectCallback ... 208  
 UARTFn\_IDMatchCallback ... 209  
 UARTFn\_Init ... 196  
 UARTFn\_PowerOff ... 197  
 UARTFn\_ReceiveData ... 201  
 UARTFn\_ReceiveEndCallback ... 206  
 UARTFn\_SendData ... 200  
 UARTFn\_SendEndCallback ... 205  
 UARTFn\_SetComparisonData ... 202  
 UARTFn\_SoftOverRunCallback ... 207  
 UARTFn\_Start ... 198  
 UARTFn\_Stop ... 199  
 UARTn\_ErrorCallback ... 173  
 UARTn\_Init ... 163  
 UARTn\_ReceiveData ... 168  
 UARTn\_ReceiveEndCallback ... 171  
 UARTn\_SendData ... 166  
 UARTn\_SendEndCallback ... 170  
 UARTn\_SoftOverRunCallback ... 172  
 UARTn\_Start ... 164  
 UARTn\_Stop ... 165

**W**

[Watchdog Timer] ... 87  
 Watchdog Timer ... 290  
     WDT\_Init ... 291  
     WDT\_Restart ... 293  
     WDT\_UserInit ... 292  
 WDT\_Init ... 291  
 WDT\_Restart ... 293  
 WDT\_UserInit ... 292  
 Window reference ... 42

Revision Record

Rev.	Date	Description	
		Page	Summary
1.00	Sep 01, 2010	-	First Edition issued

---

CubeSuite Ver.1.40 User's Manual: 78K0R Design

Publication Date: Rev.1.00 Sep 1, 2010

Published by: Renesas Electronics Corporation

---

**SALES OFFICES****Renesas Electronics Corporation**<http://www.renesas.com>Refer to "<http://www.renesas.com/>" for the latest and detailed information.**Renesas Electronics America Inc.**2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.  
Tel: +1-408-588-6000, Fax: +1-408-588-6130**Renesas Electronics Canada Limited**1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada  
Tel: +1-905-898-5441, Fax: +1-905-898-3220**Renesas Electronics Europe Limited**Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.  
Tel: +44-1628-585-100, Fax: +44-1628-585-900**Renesas Electronics Europe GmbH**Arcadiastrasse 10, 40472 Düsseldorf, Germany  
Tel: +49-211-65030, Fax: +49-211-6503-1327**Renesas Electronics (China) Co., Ltd.**7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China  
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679**Renesas Electronics (Shanghai) Co., Ltd.**Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China  
Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898**Renesas Electronics Hong Kong Limited**Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong  
Tel: +852-2886-9318, Fax: +852 2886-9022/9044**Renesas Electronics Taiwan Co., Ltd.**7F, No. 363 Fu Shing North Road Taipei, Taiwan  
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670**Renesas Electronics Singapore Pte. Ltd.**1 HarbourFront Avenue, #06-10, Keppel Bay Tower, Singapore 098632  
Tel: +65-6213-0200, Fax: +65-6278-8001**Renesas Electronics Malaysia Sdn.Bhd.**Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia  
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510**Renesas Electronics Korea Co., Ltd.**11F., Samik Lavied' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea  
Tel: +82-2-558-3737, Fax: +82-2-558-5141

CubeSuite Ver.1.40



Renesas Electronics Corporation

R20UT0007EJ0100