


User Manual
RS 232 Firmware

Milan drive
advanced

Servo motor with
integral controls



GFC

Preface

Thoroughly read the present manual and all safety instructions and warnings in particular before installation and commissioning of the servo drive. Observe all warning plates attached to the device. Please make sure that all warning plates are legible and that missing or damaged signs are replaced.

For more detailed information refer to:

Website

For technical and general information, customers may refer to the following address:

<http://www.milan-drive.de>

Contact

In case you have any questions or problems when reading these operating instructions, please contact one of the addresses mentioned at the end of these instructions or the sales agent responsible for your area.

Possibly other functions may be available which are not described in this document. However, the manufacturer shall not be obliged to provide these functions with a new drive or when performing maintenance work. The contents of this document were checked for compliance with the described hardware and software. Deviations may nevertheless occur; we assume no liability for full compliance with all data. The information contained in these documents is subject to regular revision and any required modification will be included in the next issue.

We reserve the right to alter the present document without prior notification.

Issue	Note
1.05	First issue
1.06	General update
1.07	Update due to functional extension with firmware APP 02.00
1.09	Update due to: - Consolidation of user manual "RS232 Firmware" and "RS232 Firmware (ATEX II 3D)" - Functional extension with Firmware APP 02.04 and MDAwin 02.04 - Correction of operation instructions (overview of electrical connection, page 22)

Table of contents

1	Safety instructions	7
1.1	Designated use	7
1.2	General notes.....	7
1.3	Warnings and notes	7
1.3.1	Used danger signs	8
1.3.2	Used mandatory signs	8
1.3.3	Further symbols	8
2	Assembly and commissioning	9
2.1	Assembly.....	9
2.2	Installation (electrical connection)	10
2.3	Commissioning.....	12
2.3.1	Connection with Ex cable gland (optional).....	13
2.3.2	M12 connector with fixing bush (Optional).....	15
2.4	Commissioning for a linear axis	16
3	Operation	20
3.1	Ambient conditions during operation	20
3.2	Device identification	21
3.2.1	Additional name plate for version according to ATEX (optional)	21
3.3	Technical data.....	21
3.4	Applications in Ex zone 22 (option)	22
4	Electrical connection	23
4.1	Overview	23
4.2	Wiring assignment.....	23
4.2.1	Plug X1: Power supply for drive, external ballast resistor	24
4.2.2	Plug X2: Auxiliary voltage for electronics and holding brake.....	25
4.2.3	Plug X3: Programming interface RS232.....	25
4.2.4	Plugs X4/X5: Fieldbus.....	26
4.2.5	Plug X7: Inputs.....	27
4.2.6	Plug X8: Outputs	27
4.3	Plug alignments.....	28
5	Detailed information on the drive	29
5.1	Position indicator.....	29
5.1.1	Resolver	29
5.1.2	Absolute encoder (option).....	29
5.2	DC link charging circuit for input current limitation.....	30
5.3	Auxiliary voltages	30
5.3.1	Electronics.....	30
5.3.2	Holding brake/Fan.....	30
5.4	Ballast resistor.....	30
5.4.1	Internal	30
5.4.2	External (option).....	30

5.5	Inputs/ outputs.....	31
5.5.1	Digital inputs.....	31
5.5.2	Digital outputs (relay)	31
5.5.3	Digital outputs (transistor outputs)	31
5.5.4	Analogue input	32
5.6	Fieldbus (option)	32
5.6.1	PROFIBUS DP.....	32
5.6.2	CANopen.....	32
5.7	Holding brake (optional)	33
6	Operating software MDAwin	34
6.1	System requirements	34
6.1.1	Software installation	34
6.2	Introduction	34
6.3	User interface.....	35
6.3.1	Title bar	35
6.3.2	Menu bar	36
6.3.3	Tool bar	40
6.3.4	Status bar	41
6.3.5	Parameter tree	42
6.4	Actual values window.....	43
6.5	Drive information window.....	44
6.5.1	Info Status group.....	44
6.5.2	Info drive group	45
6.5.3	Info collective warning group	45
6.5.4	Info collective fault group	45
6.5.5	Status digital inputs group.....	45
6.5.6	Status digital outputs group	45
6.6	Drive fault window	46
6.7	Drive warning window	47
6.8	Operational data window.....	48
6.9	Fieldbus monitoring window.....	49
6.10	Event buffer window.....	50
6.10.1	Event logging group box	50
6.10.2	View group box	51
6.11	Manual operation window	52
6.12	DDR editor window	53
6.12.1	Controller type.....	53
6.12.2	Maximum values group box	55
6.12.3	Features group box	55
6.13	Name plate window.....	56
6.14	Hardware window.....	57
6.14.1	Motor data group box	57
6.14.2	Motor transmitter group box	58
6.14.3	Holding brake / fan group box.....	58
6.14.4	Global settings group box	58

6.15	Control loop window.....	59
6.16	Speed position controller window	60
6.17	System window	61
6.18	I/O drive window.....	63
6.18.1	Digital Input group box	63
6.18.2	Digital Output group box	65
6.18.3	Analogue input group box	66
6.19	Fieldbus window.....	68
6.20	Reference operation window	69
6.20.1	Configuration group box.....	69
6.20.2	Limits group box.....	74
6.20.3	Set reference position group box	74
6.21	Technological function window	75
6.21.1	Flying referencing.....	75
6.21.1.1	Flying measuring	76
6.21.1.2	Flying referencing	76
6.21.2	Electric shaft.....	77
6.21.2.1	Functional description	78
6.21.2.2	Commissioning	78
6.22	Online monitoring	79
6.22.1	Software installation.....	79
6.22.2	Functional description	79
7	Multi-turn absolute encoder	82
7.1	Basic settings	82
7.2	Absolute encoder range	82
7.3	Monitoring	83
7.4	Adjustment	83
7.5	Reference operation	83
8	Transport and storage	84
9	Maintenance	85
9.1	Maintenance on drives in standard version	85
9.2	Maintenance of the version according to ATEX.....	85
10	Disposal and recycling	86
11	Declaration of conformity and declaration of Incorporation	87
11.1	Konformitätserklärung für Antriebe in Ausführung nach ATEX (Option)	89
12	Literature	90
12.1	Milan user manuals	90
13	Appendix	91
13.1	Trouble shooting	91
13.2	Faults and warnings.....	93
13.2.1	Drive fault window	93
13.2.2	Drive warning window	95
13.3	Event buffer assignment list.....	96

13.3.1	Class 1: Faults	96
13.3.2	Class 2: Warnings	97
13.3.3	Class 4: Info	97
13.3.4	Class 8: Parameters.....	98
13.3.5	Class 16: Command.....	98
13.3.6	Class 32: System	98
13.4	Parameter lists	99
13.4.1	Summary of system units which can be selected and combined	99
13.4.2	Actual values window	100
13.4.3	Drive information window	101
13.4.4	Manual operation window	102
13.4.5	DDR editor window	103
13.4.6	Hardware window.....	104
13.4.7	Control loop window	105
13.4.8	Speed position controller window	105
13.4.9	System window	106
13.4.10	I/O drive window.....	107
13.4.11	Reference operation window	109

1 Safety instructions

1.1 Designated use

Milan Drive Advanced servo drives, also called MDA in the following, are designed as equipment for the use in industrial environments. As standard, the servo drives are designed for installation in industrial robots, pick and place units, and many other equipment and devices. For other applications, please consult us. The manufacturer is not liable for any damage resulting from use in other than the designated applications. Such risk lies entirely with the user. Observance of these operation instructions is considered as part of the servo drive's designated use.

Please read these instructions thoroughly as they are intended for your personal safety and also help enhancing the lifetime of your servo drive.

1.2 General notes

- During operation, parts move or rotate within this unit. Important dangers can arise from rotating shaft couplings with keyway and inserted parallel key. Remove inserted parallel keys or protect them against loosening by taking suitable measures.
- During operation, surfaces of the drive unit may heat up according to its enclosure protection. The surface temperature can rise up to above 100 °C. Before touching the unit, measure the temperature for safety reasons; if required, wait until it has cooled down to 40 °C.

1.3 Warnings and notes

Failure to observe of the warnings and notes may lead to serious injuries or damage. Qualified personnel must be thoroughly familiar with all warnings and notes in these operation instructions.

In order to highlight safety-relevant procedures in these operation instructions, the following safety instructions apply:

DANGER indicates an imminently hazardous situation, which – if the warnings and notes are not observed – could result in **death** or **serious damage to health** or **considerable material damage**. This note is only used in case of **danger to life** and a high level of hazard.

Danger sign on the type of danger and/ or pictograph on consequences, measures, or prohibitions	 DANGER
	Type of hazard and its source
	Possible consequence(s) on non-observance → Measure(s) to avoid the hazard.

WARNING indicates a potentially hazardous situation, which – if the warnings and notes are not observed – could result in **death** or **serious damage to health** or **considerable material damage**.

Danger sign on the type of danger and/ or pictograph on consequences, measures, or prohibitions	 WARNING
	Type of hazard and its source
	Possible consequence(s) on non-observance → Measure(s) to avoid the hazard.

CAUTION indicates a potentially hazardous situation, which – if the warnings and notes are not observed – could result in **minor injuries** or **material damage**.

Danger sign on the type of danger and/ or pictograph on consequences, measures, or prohibitions	 CAUTION
	Type of hazard and its source
	Possible consequence(s) on non-observance → Measure(s) to avoid the hazard.

NOTE contains important information on the product or highlights a section of the documentation to which special attention should be paid.

Pictograph on consequences or measures	NOTE
	Type of hazard and its source Possible consequence(s) on non-observance → Measure(s) to avoid the hazard.

1.3.1 Used danger signs

Danger signs warn about a danger source.
Layout: yellow triangle and symbol.



General danger zone in combination with personal injuries!

Please heed all measures marked with the danger sign to prevent injuries or damage.



Hazardous electrical voltage!

Danger due to electric shock.



Hot surfaces

Danger of burns.

1.3.2 Used mandatory signs

Mandatory signs call on the user to do something to prevent a danger.
Layout: blue circle and symbol.



General mandatory sign

Heed instruction.



Caution

Disconnect plug before opening.

1.3.3 Further symbols



Information

Contains important tips and information. In case of non-observance, no damage is to be expected.

2 Assembly and commissioning

2.1 Assembly

Check servo drive for (transport) damage before assembly. Possible damage has to be assessed and eliminated, if required. Make sure that the means of transport, ropes or hooks have appropriate supporting strength and stability.

Proper installation or assembly of the servo drives lies within the responsibility of the customer. Respecting and observing the instructions of the present section is the prerequisite for specified product characteristics and for meeting possible warranty claims.

Inappropriate assembly may cause damage and functional failures of the servo drive. Assembly and commissioning may **only** be performed by suitably trained personnel.

	 DANGER
	Assembly work may only be performed → if the servo drive is at standstill, not live and protected against accidental switching on.

Mounting the flange: The servo drive is mounted using four screws at the A end shield. Screw diameter and minimum reach of screw at the flange connection surface of the machine have to be selected according to the dimensions of the fixing holes. The fastening screws are not included in the delivery.

For data and dimensions of the flanges, please refer to the dimension sheet and the technical data sheet.

The flange mounting surface on the machine has to be level and torsion resistant. A deviation of more than 0.03 mm from the perpendicular position to the shaft axis is not permitted. Furthermore, the output shaft and the gear or drive shaft have to be in perfect alignment to prevent deformation of the bearing shaft.

The A end shield may be damaged during assembly if exposed to excessive radial load or if the screws are fastened applying excessive torque.

When mounting hollow shaft gearboxes or other shaft fittings (pinions, pulleys, etc.), no axial forces (e.g. due to hammering) may be transmitted to the servo drive. This might damage bearings, housing, shaft and holding brake. In principle, all axial forces acting upon the output shaft should be reduced to a minimum.

Any mounting position is possible; ideal heat elimination is achieved in the horizontal mounting position.

	 CAUTION
	Hot surfaces. During operation, the surface temperature of the drive unit may rise up to 100°C according to its enclosure protection. → Do not touch unless measuring the temperature; if necessary, wait until the temperature has cooled down to 40°C. → For the version according to ATEX category II 3D, the drive must be cleaned from dust collections at a regular basis to prevent an accumulation of ignitable dust layer from accumulating on the drive. For this reason, we recommend horizontal installation.

2.2 Installation (electrical connection)

In the standard version, the electrical connections are established via standardised signal (M12) and power plug/socket connectors (M23). For connection, the drive does not have to be opened.

When establishing the electrical connections, the following points have to be observed:

- Switch off voltage before connection
- Operate drive system only with an earthed supply.
- Lay power, control, and bus cables separately.

	 DANGER
	Lethal voltages at electrical connections Electric shock risk → Work on the electrical system or equipment must only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with the applicable electrical engineering rules

Before commissioning and test run observe the following points:

	 WARNING
	In case of excessive voltage or wrong polarity at the connections, the servo system may be destroyed. → For electrical installation refer to the order-related wiring diagram.

For the version according to **ATEX category II 3D**, the drive is equipped with a cable gland instead of the M23 connector and therefore has to be opened when connecting the 230V mains supply.

**WARNING**

For work carried out in hazardous areas, special regulations (Standard EN 60079-14 and EN 60079-17) must be observed.

Work at the open actuator under voltage must only be performed if it is assured that for the duration of the work there is no danger of explosion.

Pay attention to additional national regulations.

Only remove electrical connections when disconnected from the mains.

Wait at least two minutes after disconnecting the voltage supply and unplugging the plug/socket connectors before opening the drive.


2.3 Commissioning

Before commissioning and test run observe the following points:

- Ensure that all electrical connections are correctly wired (see chapter electrical connection).
- Ensure that the permissible supply voltage levels at the connections of the power and signal plugs are not exceeded:
 - 230 VAC power supply
 - 24 VDC auxiliary voltage for electronics (option)
 - 24 VDC auxiliary voltage for holding brake/ fan (option)
- Ensure correct polarity of DC voltage supply.

	 DANGER
	During electrical operation, certain parts inevitably carry lethal voltages. Electric shock risk → Work on the electrical system or equipment must only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such an electrician and in accordance with the applicable electrical engineering rules.

The general and regional installation and safety regulations for work on power installations with hazardous voltages (e.g. EN 50178) as well as the regulations on the expert use of tools and the use of personal protective equipment have to be observed.

	NOTE
	Power, intermediate circuit, and motor terminals may carry hazardous voltages, even if the MDA is not in operation. → After switching off the device, always allow 2 minutes for discharging before starting any work on the MDA.

If measurements and tests have to be performed on the live device, the provisions according to VBG 4.0 have to be observed, in particular those of § 8, "Permissible deviations when working on live parts".

The device must not be used as 'Emergency shutdown device' (refer to EN 60204, 9.2.5.4).

	WARNING
When installing the MDA, deviations from the safety regulations are not permitted!	

	WARNING
The MDA is not equipped with an integral power switch and will therefore be live as soon as the mains connection has been established.	

	NOTE
	The MDA contains electronic parts. → Cables connected to the MDA must never be subject to an insulation test with a high voltage level.

2.3.1 Connection with Ex cable gland (optional)



WARNING

For work carried out in hazardous areas, special regulations (Standard EN 60079-14 and EN 60079-17) must be observed.

Work at the open actuator under voltage must only be performed if it is assured that for the duration of the work there is no danger of explosion.

Pay attention to additional national regulations.

Only remove electrical connections when disconnected from the mains.

Wait at least two minutes after disconnecting the voltage supply and unplugging the plug/socket connectors before opening the drive.

For the version according to **ATEX category II 3D**, the drive has to be opened when connecting the 230V mains supply (refer to figure 2.3.1). For this, loosen the 4 screws at the cover with an Allen key and carefully lift the cover. The internal brake resistor is fitted within the cover (refer to figure 2.3.2).

Attention: The screws in the cover are not secured against falling out. When opening the cover, ensure that no screws are lost!

Use cable glands with „EEx e“-approval and of size suitable for connecting cables only. The enclosure protection stated on the name plate is only ensured if suitable cable glands are used and fitted correctly.

As standard, cable glands with an M20x1.5 thread for a cable diameter of 8.5 mm to 13 mm are mounted.

Seal cable entries which are not used with suitable plugs.

- Check whether type of current, supply voltage and frequency correspond to motor data (refer to name plate at motor).
- Loosen screws and carefully lift the cover (refer to figures 2.3.1 and 2.3.2, cover may not be removed completely since the internal brake resistor and potential compensation remain connected).
- Strip cable at a length of 130 mm and slip the enclosed glass fibre hoses over the wires. The screen must be cut to a length of 30 mm in accordance with the cable glands used.
- Insert cable through cable glands and fit the screen in compliance with the requirements.
- Strip wires at a length of 15mm respective 10 mm (PE); for stranded wires use end-sleeves according to DIN 46228. One wire for each connection is permitted only.
- The PE of mains supply has to be fixed to the PE-terminal block (refer to figure 2.3.5).




Figure 2.3.1: Lifting the cover




Figure 2.3.2: MDA opened




figure2.3.3: wiring diagram

- Connect cables according to order-related wiring diagram. The wires of the voltage supply are directly wired to the terminal block of the power board (refer to figure 2.3.4)
- Close the cover and tighten the screws with a torque of 1.3 Nm.

Figure 2.3.4 is the enlarged section (white circle) of figure 2.3.2




Figure 2.3.4: terminal block of the MDA

The PE of mains supply has to be fixed to the terminal supply (refer to figure 2.3.5).




Figure 2.3.5: connecting PE of mains

For the version according to **ATEX category II 3D** the MDA is equipped with an external PE. To this terminal block a PE cable with 4 mm² minimum has to be connected (refer to figure 2.3.6).




Figure 2.3.6: external PE

2.3.2 M12 connector with fixing bush (Optional)



WARNING

For work carried out in hazardous areas, special regulations (Standard EN 60079-14 and EN 60079-17) must be observed.

Work at the open actuator under voltage must only be performed if it is assured that for the duration of the work there is no danger of explosion.

Pay attention to additional national regulations.

Only remove electrical connections when disconnected from the mains.

Wait at least two minutes after disconnecting the voltage supply and unplugging the plug/socket connectors before opening the drive.

The connections X2 to X8 are made with M12 connectors. The enclosure protection indicated on the name plate is only ensured, if connectors are connected to all sockets or temporary covers are fitted and fastened with the specific torque and if the enclosed fixing bushes have been mounted properly.

- Check whether type of current, supply voltage and frequency correspond to motor data (refer to name plate at motor).
- Loosen screws and remove fixing bush (refer to figure 2.3.7)




Figure 2.3.7: fixing bush for M12

Attention: The screws in the cover are not secured against falling out. When opening the cover, ensure that no screws are lost!

- Slip fixing bush onto the cable (refer to figure 2.3.8). The diameter of the M12 connector must be 16mm maximum.
- Fit M12 connector and fasten it tightly.
- Set the fixing bush in position and tighten it with screws (refer to figure 2.3.9).



Figure 2.3.8: slipping the fixing bush

Attention: Set the fixing bush with the three screw holes showing to the outer side of the MDA (refer to figure 2.3.9).

- Connect cables according to the order-related wiring diagram.

The actuator must only be set under voltage, if connectors are connected to all sockets or temporary covers are fitted and fastened with the specific torque and if the enclosed fixing bushes have been mounted properly.





Figure 2.3.9: tightening fixing bush

2.4 Commissioning for a linear axis

The settings for software commissioning depend on the selected use and are determined by the used positioning system. In this section, the commissioning is performed for a linear axis with limit switches and a servo drive with a resolver.



For drives with absolute encoder, some other points have to be observed. They are described in detail in the "Multi-turn absolute encoder" section.



Our example contains the following components:

- Servo drive **MDA 35.1**
- Planetary gear with a multiplication of $i = 10$ (with inversion of direction of rotation)
- Linear axis with a slope of $s = 60 \text{ mm/turn}$
- 2 hardware limit switches with NC contact

The following steps are required for commissioning:


- Start up of the user interface and establishment of a connection
- Definition of the system
- Definition of the inputs/ outputs
- Definition of the reference operation
- Perform reference operation
- Definition of driving data records

Step 1: Start of MDA win user interface and setting up of a connection


- Installation (refer to section software installation)
- Start of MDWin.exe
- Select appropriate interface (**Menu options**, refer to section Tool bar)
- Click the **Connect**  button to set up a connection to the drive.
- Change to Online level 4 (Default password: 0000) via the **Menu mode**
- Read parameters from the drive: **READ** button

Step 2: Definition of the system

- To open the **System** window, click on **System** in the parameter tree.



- Determine system type
System type = Linear
- Observe planetary gear: Enter gear multiplication in the fields
Gear factor input = 10
Gear factor output = 1
Activate **Inversion of direction gear**
- Enter the slope of the linear axis




Select the unit Gear rotation to take the gear into consideration.

- No software limit switch: deactivate the **Software limit switch** field
- Select display units for system view (linear):
Display unit Time = minute
Position = mm and
Temperature = °Celsius:
- Click the **Write** button to save changed settings

Step 3: Definition of the inputs/ outputs

- Open **I/O drive** window.



- Configuration of the digital inputs

Digital input	1	2	3	4
high active	☒	☒	☐	☐
DDR dependent	☒	☒	☐	☐
Function	Start/ stop	Start/ stop	Limit switch negative	Limit switch positive
DDR no.	1	2	0	0


- Configuration of the digital outputs

Digital input	1	2	3	4
high active	☒	☒	☒	☐
DDR dependent	☐	☒	☒	☐
Function	Error	DDR active	DDR active	Setpoint reached
DDR no.	0	1	2	0

- Click the **Write** button to save changed settings

Step 4: Definition of the reference operation

- Open **Reference operation** window.



- Configure reference operation:
 - Type** = Limit switch minus
 - Start** = Manual
 - Reference offset** = value < 0
 - Behaviour after reference** = Approach position
 - Position after ref operation** = 0
- Determine limit values:
 - Acceleration ramp** = Linear
 - Acceleration** = 1000
 - Brake ramp** = Linear
 - Delay** = 1000
 - Output speed** = 500
 - Force** = 500
- Click the **Write** button to save changed settings

Step 5: Performance of reference operation

- Click **Start reference operation** button

**WARNING**


The functions *Run*, *Start DDR*, and *Stop DDR* CANNOT be executed in real-time and do NOT meet the requirements of an emergency stop.

- The load is operated in direction of the limit switch minus (ESM/ESL). When releasing the limit switch, the reference point is set. Since **Reference offset** < 0 was entered, the zero point of the axis is within the travel range of the axis. After **Behaviour after reference** was defined, the axis moves to the absolute position 0.
- To ensure that a reference operation is performed during further operation, the Start parameter may be set to *Powerup* or *First start*.

Step 6: Definition of driving data records DDR

- Click the **Start reference operation** button in the DDR editor window

3 Operation

	NOTE The MDA servo drive is designed for continuous operation S1. Excessive switching on and off may damage the DC link circuit. For information on the switching cycles, please refer to the technical data sheet.
 	WARNING Lethal voltages at the connection terminals of the intermediate circuit (up to two minutes after disconnecting the voltage supply) when plugging in or removing the connections. Danger of burns and electric shocks due to electric arcs. → Only remove electrical connections when disconnected from the mains. → Wait at least two minutes after disconnecting the voltage supply and unplugging the plug/ socket connectors before touching live connections or sections of the equipment.
	CAUTION Hot surfaces. During operation, the surface temperature of the drive unit may rise up to 100 °C according to its enclosure protection. Risk of burns. → Do not touch unless measuring the temperature; if necessary, wait until the temperature has cooled down to 40 °C. → For the version according to ATEX category II 3D, the drive must be cleaned from dust collections at a regular basis to prevent an accumulation of ignitable dust layer from accumulating on the drive. For this reason, we recommend horizontal installation.

3.1 Ambient conditions during operation

Operation temperature

For version with resolver: – 10 °C to +50 °C
 For version with absolute encoder: – 5 °C to +50 °C

Combustible dust hazard protection for use in the zone 22 (optional)

II 3D IP6X T 150 °C X ¹⁾
 II 3D c T150 °C

¹⁾ X: reduced rates on the tests for resistance to impact according to EN 50014 chapter 23.4.3.1

On and off cycles

Refer to the technical data sheet.

Air humidity during operation

Relative humidity 85 %

Installation height

Up to 1,000 m above sea level without performance reduction
 Between 1,000 and 2,000 m above sea level a performance reduction of 1 % per 100 m.

Ventilation and mounting position

The MDA is equipped with convection cooling. The cooling system may be mounted in any position. Optimum cooling is achieved for a horizontal mounting position.
 (Reduction in performance at rising ambient temperature, refer to technical data sheet)

Thrusts and vibrations

Refer to the technical data sheet.

3.2 Device identification

The name plate is attached to the drive (motor) and contains the following information:

Manufacturer	Type designation	
	Commission number	
	Works number	
	Wiring diagram number	
	Rated torque	Rated output speed
	Power supply	CE-symbol
	Current consumption	Enclosure protection

The MDA has an electronic name plate. Some of the data on the name plate can be called via a bus connection (refer to Name plate window section)

3.2.1 Additional name plate for version according to ATEX (optional)

For the version according to **ATEX category II 3D** an additional name plate is attached to the drive (motor) and contains the following information:

GFC	GFC	Ex-symbol	CE-symbol
	AntriebsSysteme GmbH		
	D – 01640 Coswig		
	II 3D IP5X T 150 °C	X	
	II 3D c T 150 °C		
	-10 °C ≤ Ta ≤ 50 °C		

Furtheron there are some more warning and information plates according to ATEX attached to the device. Please make sure that all warning and information plates according to ATEX are legible and that missing or damaged signs are replaced.

3.3 Technical data

For the technical data and information on dimensions and weights please refer to the **Technical data sheet** and the **Dimension sheet**. These data sheets can be downloaded via the Internet at www.milan-drive.de.

3.4 Applications in Ex zone 22 (option)

Milan Drive Advanced servo drives in the version according to **ATEX category II 3D** basically meet the requirements for applications in dust hazardous locations of zone 22 in accordance with ATEX directive 94/9/EC.

The servo drives are designed to meet enclosure protection IP 64 and fulfil the requirements of EN 50281-1-1:1998 section 6 – Electrical apparatus for use in presence of combustible dust, requirements for category 3 electrical equipment – protected by enclosures.

To comply with all requirements of EN 50281-1-1: 1998, the following points must imperatively be observed:

- In compliance with the ATEX directive 94/9/EC, the servo drives must be equipped with an additional identification – II3D IP6X T150 °C.
- The maximum surface temperature of the servo drives, based on an ambient temperature of + 40 °C in accordance with EN 50281-1-1 section 10.4, is 150 °C. In accordance with section 10.4, an increased dust deposit on the equipment was not considered for the determination of the maximum surface temperature.
- The correct connection of the thermo switches or the PTC thermistors as well as fulfilling the requirements of the duty type and the technical data are prerequisites for compliance with the maximum surface temperature of servo drives.
- The connection plug may only be plugged in or pulled out when device is disconnected from the mains.
- The cable glands used also have to meet the requirements of category II3 D and must at least comply with enclosure protection IP 67.
- The servo drives must be connected by means of an external ground connection to the potential compensation.
- As a general rule, the requirements of EN 50281-1-1 must be respected in dust hazardous locations. During commissioning, service, and maintenance, respective special care as well as qualified and trained personnel is required for the safe operation of servo drives



WARNING

For work carried out in hazardous areas, special regulations (Standard EN 60079-14 and EN 60079-17) must be observed.

Work at the open actuator under voltage must only be performed if it is assured that for the duration of the work there is no danger of explosion.

Pay attention to additional national regulations.

Only remove electrical connections when disconnected from the mains.

Wait at least two minutes after disconnecting the voltage supply and unplugging the plug/socket connectors before opening the drive.

4 Electrical connection

4.1 Overview

The following table shows the function and the type of plug at the drive. A detailed description is contained in the following chapter.



For the version and the plug wiring of your MDA, please refer to the included order-specific wiring diagram.


The order-specific wiring diagram can be downloaded from the Internet.

Name	Function	Size/ no. of poles	Note
X1	Power External ballast resistor (optional)	M23 / 6	Pin
X2	Auxiliary voltage electronics, Brake (optional), Fan (optional)	M12 / 5	Pin
X3	RS232	M12 / 5	Jack
X4	Fieldbus (optional) PROFIBUS CANopen	M12 / 5	Jack, B-coded (inverted) Pin
X5	Fieldbus (optional) PROFIBUS CANopen	M12 / 5	Pin, B-coded (inverted) Jack
X6	Local CAN (not implemented)	M12 / 3	Pin
X7	Input	M12 / 8	Jack
X8	Output	M12 / 8	Pin

4.2 Wiring assignment

The numbering of pins and sockets of the device plugs corresponds to the usual standard and is shown in the following.

M12 standard assignment for device plug / cable plug (pin-side)



M12 standard assignment for mounting jack / cable jack (pin-side)

DANGER

Lethal voltages at the control and power connections even if the drive is at a standstill.

Electric shock risk

- Disconnect all wires of the connected control and power cables – also those which are not required – at the respective terminals in the control cabinet and protect them against direct contact.
- It is not permitted by any means to just to cut the connecting cables at the unassembled end.

WARNING

For work carried out in hazardous areas, special regulations (Standard EN 60079-14 and EN 60079-17) must be observed.

Work at the open actuator under voltage must only be performed if it is assured that for the duration of the work there is no danger of explosion.

Pay attention to additional national regulations.

Only remove electrical connections when disconnected from the mains.

Wait at least two minutes after disconnecting the voltage supply and unplugging the plug/socket connectors before opening the drive.

The following tables list the standard assignment only. The connection of the respective drive may therefore deviate.

Ready-made cables are available for the MDA. For more detailed information, please refer to the accessories catalogue.

4.2.1 Plug X1: Power supply for drive, external ballast resistor

Pin	Signal	Description	Note
PE	PE	Protective earth	
1	230VAC / N	Mains	
2	230VAC / L1	Mains	
4	RBal-	Ballast resistor -	Optional
5	RBal+	Intermediate circuit +, Ballast resistor +	Optional
6	reserved		
Thread		Screen	



The M23 plug is not available in the version according to **ATEX category II 3D**. Version and plug assignments for your MDA are listed on the order-related wiring diagram supplied.

4.2.2 Plug X2: Auxiliary voltage for electronics and holding brake

Pin	Signal	Description	Note
1	+24V	Power supply for electronics +24VDC	approx. 250mA
2	GND	Power supply for electronics GND	
3	BRAKE24V	Power supply for brake +24VDC	max. 2A (holding brake, fan per 1A)
4	BRAKEGND	Power supply for brake GND	
5	BRAKEON	Release of brake	Holding brake is released by connecting to BRAKEGND
Thread		Screen	

4.2.3 Plug X3: Programming interface RS232

Pin	Signal	Description	Note
1		Not connected	
2	RxD	Receive	PC: TxD, SUB-D 9pin Pin 2
3	TxD	Transmit	PC: RxD, SUB-D 9pin Pin 3
4		Not connected	
5	GND	Power supply for electronics GND	PC: GND, SUB-D 9inl Pin 5
Thread		Screen	

4.2.4 Plugs X4/X5: Fieldbus



WARNING

Vcc Bus+ and Vcc Bus– are used to supply the bus termination resistor. Power supply via Vcc Bus+ and Vcc Bus– causes the destruction of the bus interface.

PROFIBUS			
Pin	Signal	Description	Note
1	Vcc Bus+	Power supply for bus+	5V supply for termination resistor
2	RS485-	Profibus (A cable)	SUB-D 9pin: Pin 8 green
3	Vcc Bus-	Power supply for bus -	5V supply for termination resistor
4	RS485+	Profibus (B cable)	SUB-D 9pin: Pin 3: red
5		Screen	

CANopen			
Pin	Signal	Description	Note
1		Screen	
2	Vcc Bus+	Power supply for bus	5V supply for termination resistor
3	Vcc Bus-	Power supply for bus	5V supply for termination resistor
4	CAN_H	CAN High	
5	CAN_L	CAN Low	

4.2.5 Plug X7: Inputs

Pin	Signal	Description	Note
1	DIN1	Digital input 1	
2	DIN2	Digital input 2	
3	DIN3	Digital input 3	
4	DIN4	Digital input 4	
5	24VOUT	Power supply 24VDC	Output, max. 100 mA, galvanically isolated
6	AIN1	Analogue input 1	Standard: –10V to +10V
7	GND	Power supply GND	Common reference point for digital inputs DIN1 to DIN4 and power supply 24VOUT
8	AGND	GND analogue input	Internally connected to GND of the auxiliary voltage for electronics
Thread		Screen	

4.2.6 Plug X8: Outputs

	NOTE
	Digital outputs 2 through 4 are opto-decoupled transistor outputs. Wrong connections can lead to damage. → Please refer to chapter “Digital outputs (transistor outputs)” for Information regarding correct connections.

Pin	Signal	Description	Note
1	DOUT1	white	Digital output 1 (relais)
2	DOUT1COM	brown	Digital output 1 common (relais)
3	DOUT2	green	Digital output 2
4	DOUT2COM	yellow	Digital output 2 common
5	DOUT3	grey	Digital output 3
6	DOUT3COM	pink	Digital output 3 common
7	DOUT4	blue	Digital output 4
8	DOUT4COM	red	Digital output 4 common
Thread		Screen	




The digital outputs are only supplied according to *ATEX category II 3D* if no fieldbus interface is used. Version and plug assignments for your MDA are listed on the order-related wiring diagram supplied.


4.3 Plug alignments

The alignment of the plugs (X1 to X8) is indicated on the DAC wiring diagram included in the scope of supply. The wiring diagram may also be downloaded from the Internet www.milan-drive.de. The following two figures are extracts of the DAC standard wiring diagram for the sizes **MDA 35.1** or **MDA 56.1** and **63.1**.

MDA 35.1



MDA 56.1 und 63.1



5 Detailed information on the drive

For the **Milan Drive Advanced** servo drive, the motor and the controls are firmly connected as a unit. In the standard version, the electrical connections are established via standardised signal (M12) and power plug/socket connectors (M23).

Motor:

The MES servo motors are three-phase synchronous motors with special permanent magnets. Permanent ambient temperatures up to 155 °C (insulation class F) are permitted. The motor temperature is monitored by a sensor integrated in the motor winding. As an option, the motor is also available with integral holding brake, the shaft end is optionally available with parallel key groove.

Electronics:

The DAC servo controls combine all components necessary for independent electronic controls in one housing. These are:

- a self-commutated intermediate circuit including a mains filter for direct connection to the mains,
- 4 quadrant operation (integral brake resistor)
- integral voltage supply for electronics
- sequence control and motor control
- fieldbus interfaces Profibus DP, CANopen (option)
- digital galvanically isolated inputs and outputs
- analogue input (option)
- RS232 interface for the operation and programming via **MDAwin** programming tool for computers with Windows operating system.

Therefore, the MDA may be operated independently for many drive solutions or may also be integrated in automation systems.

5.1 Position indicator

5.1.1 Resolver

As standard, the drive is equipped with a resolver. The resolver has a resolution of 4096 increments per rotation.

5.1.2 Absolute encoder (option)

As an option, the drive may also be equipped with a multi-turn absolute encoder. The encoder has a resolution of 4096 increments per rotation and a multi-turn range of 4096 rotations.

When using an absolute encoder, a reference operation (for commissioning only) is not required after switching on the power supply.



Using an absolute encoder within the MDA requires a special procedure during commissioning. For information on the commissioning of drives with absolute encoder, please refer to the “Multi-turn absolute encoder” section.

5.2 DC link charging circuit for input current limitation

The integral DC link charging circuit limits the switch-on peak within the switch-on torque to values < 20A. A premature tripping of safety equipment is therefore avoided. After the limitation period (set to 2 seconds) has expired, the drive is ready for operation.

	NOTE
	Time and number of starts have an impact on the lifetime of the DC link charging circuit.
	→ For information on the switch-on and switch-off cycles, please refer to the technical data sheet.

5.3 Auxiliary voltages

5.3.1 Electronics

To ensure that the signals remain active or the bus communication established even if the power supply of the drive is disconnected, a separate auxiliary voltage 24 VDC may be connected to the plug X2. If the power supply of the drive is available, the external 24 VDC supply is disconnected via an internal relay.

The power supply unit should supply a current of 0.5 A.

5.3.2 Holding brake/Fan

The auxiliary voltage for holding brake/ fan is only required if the drive is equipped with a holding brake/ fan. The GND of the auxiliary voltages for electronics and holding brake/ fan is internally connected. Both auxiliary voltages may be supplied from a single power supply unit. The required current depends on the version (refer to technical data sheet MDA).

5.4 Ballast resistor

The ballast resistor has a maximum continuous power of 3 kW for all sizes.

	NOTE
	The ballast resistor is electronically protected against thermal overload when taking in braking energy. Optimum protection is only guaranteed if the I²t monitoring is correctly set.
	→ Please refer to the chapter “Hardware window” for information about I ² t monitoring.

5.4.1 Internal

As standard, the drive is equipped with an internal ballast resistor. The resistor is designed for a high impulse load occurring for a short time as it is the case during deceleration.

5.4.2 External (option)

For the consumption of braking power with more than 50 watts permanent power or in case of increased ambient temperature, an external ballast resistor is required or recommended. This option has to be indicated when placing an order.

The external ballast resistor is connected to pins 4 and 5 of the X1 plug. For this version, no internal ballast resistor is installed in the servo controls in the factory, therefore the external brake resistor must always be connected to the motor electronics. The resistance value of the external braking resistor may not fall below 50 Ohms. An external fuse (10 A) is recommended for protecting the regen circuit.

Conversion from internal to external ballast resistor may only be performed by GFC AntriebsSysteme.

5.5 Inputs/ outputs

For the wiring of the inputs and outputs, refer to the enclosed wiring diagram and the electrical connection section.

	NOTE The digital inputs and outputs are not supplied via the internal 24 V supply. → If the signals should be maintained even for switched off power supply, the inputs and outputs have to be supplied separately.
---	--

5.5.1 Digital inputs

The digital inputs are potential-free. All digital inputs have a common reference point (plug X7 pin 7). This reference point is internally connected to the 24 V OUT supply.
 The logic levels are PLC compatible; i.e. nominal voltage high = 24 V
 High level of +13V....30V, low level of 0...5 V
 Internal resistance: 10 kOhm

5.5.2 Digital outputs (relay)


Digital output 1 of the interface is a relay output. Digital outputs equipped with a relay are potential-free. The NO contact may be loaded with a max. of 30 VDC/ 1A.

5.5.3 Digital outputs (transistor outputs)

The digital outputs 2, 3, and 4 are potential-free via an opto-isolator. The outputs are not interconnected, i.e. both connections of the transistor output are wired to the plug. The transistor output may be loaded with a max. of **30 VDC/ 10 mA** and is not short-circuit proof.

The digital outputs can be operated as

open collector or common collectors




Open collector enables simple logic links by connecting the outputs in parallel while using a common collector resistor. The signal voltage is compatible to most common PLC voltages. The connection to a PLC is mostly operated as common collectors.

	NOTE If the optional fan is integrated, output 3 is internally used for controlling the fan. If the optional holding brake is integrated, output 4 is internally used for controlling the holding brake. → These digital outputs cannot be used for other functions.
---	---

5.5.4 Analogue input

The analogue input has an input range of -10 V to $+10\text{ V}$. The resolution is 10 bit. The analogue input is not potential-free. The input range may be limited by the software; the resolution will, however, be reduced accordingly.



5.6 Fieldbus (option)

As an option, the drive may also be equipped with a fieldbus interface. By means of the Fieldbus In and Out plugs, the drive may easily be integrated into a segment. The last bus device must be terminated using an external bus termination (refer to accessories). Subsequent installation or modification of a fieldbus interface may be performed by the service of GFC AntriebsSysteme.

5.6.1 PROFIBUS DP

Profibus DP enables a baud rate of up to 12 MBaud. The drive supports Profidrive V2.0. For further information refer to the "Interface description Profibus DP" user manual.

5.6.2 CANopen

For CANopen, a baud rate of up to 1MBaud is possible. The drive supports the CiA DSP 4.02 CANopen profile. For further information, refer to the "Interface description CANopen" user manual.

5.7 Holding brake (optional)

The drive is optionally available with an integral holding brake which has to be specified when placing the order. This holding brake blocks the motor shaft if there is no voltage supply available (primary 230 VAC). The brake management (control of the holding brake while taking the apply and release time into account) is performed by the controls. Separate power supply is required for the holding brake (24 VDC/1.0 A). The power supply is connected to plug X2.

To check the function of the holding brake - if there is no power supply available at the drive -, the brake may be released by connecting the BRAKEON signal (X2 pin 5) with BRAKEGND (X2 pin 4).



WARNING

By releasing the holding brake, the drive loses the stop torque and a load will no longer be decelerated

→ Before releasing the holding brake, an appropriate safety device, which may take on this holding function, has to be activated

The required basic configuration in the **Hardware** window is made in the factory. When programming driving data records (**DDR** window), it can be defined whether the brake is to be activated after a stop command (**Stop with brake features** activated). The behaviour of the brake after a reference operation is determined in the **Reference operation** window via the *Brake after ref operation* drop down list.



NOTE

The holding brake is not designed for braking the drive.

→ If the holding brake is used for braking, the braking effect may decrease or lack completely: The lifetime of the friction lining depends on the peak temperature during braking. The latter depends on output speed, delay time and current braking torque.

Subsequent installation of a holding brake may be performed by the service of GFC AntriebsSysteme by exchanging the motor and adapting the controls.

6 Operating software MDAwin

For the tables containing the parameters and the fault numbers quoted in the following chapters, please refer to the appendix.

6.1 System requirements

An operating system Windows NT 4.0, Windows 2000, or Windows XP and a free serial interface (115 kBit) are required for operation. When using interface adapters (e.g. USB – RS232 or Ethernet – RS232), no comprehensive functional warranty for the MDAwin operating software may be granted. Service cable Z036.657 (SUB-D 9 pin to M12/5 pin) is required to connect the servo drive (X3) to the PC. If there is no service cable available, you may pre-assemble a cable yourself (for the pin assignment refer to the DAC wiring diagram and the electrical connection section, Plug X3: Programming interface).

6.1.1 Software installation

To be able to run the operating software MDA Win, operating system Windows NT 4.0, Windows 2000, or Windows XP is required.



You can find the MDAwin operating software on the included CD-ROM in the “B-MDAwin operating software” folder or can be download the software via Internet at www.milan-drive.de.

The operating software consists of the **MDAwin.exe** and **LgEnglish.dll** files. The files may be copied to a directory on the hard disk of the PC. The program may be started from this directory. An installation is not necessary. The library file LgEnglish.dll is required if MDAwin is to be viewed in English language.



To be able to use the online monitoring functions, available for MDAwin version 02.00 and higher, further software packages are required. For more detailed information refer to the Online Monitoring section.



Further files are required to allow using the online help for MDAwin as from version 02.04. For further information, please refer to chapter “Menu bar”.

6.2 Introduction

Using the MDA Win operating software, the servo drive may be conveniently configured, programmed and operated:

- special functions for easy commissioning
- operation of the servo drive
- programming of the driving data records
- simple fault diagnosis



WARNING


The functions **Start DDR** and **Stop DDR** CANNOT be executed in real-time and do NOT meet the requirements of an emergency stop.

The configuration/ programming may be saved at any time on the hard drive or any other storage medium.

6.3 User interface

The program runs in a window which has been optimised for a resolution of 1024x768. The window may be changed in size, i.e. minimized and maximized. The user interface consists of the following elements:

- Title bar
- Menu bar
- Tool bar
- Tree view for navigation
- Dialog box
- Status bar



6.3.1 Title bar

The title bar shows whether there is a connection to the servo drive. The status of the connection can also be seen in the status bar.

DAC Application

A connection to the drive is available, i.e. the drive is online

Communication Error

There is no connection, to the drive, i.e. the drive is offline.

Bootloader Application

The drive runs in the bootloader mode

Unknown Application

The operating software cannot recognise the firmware of the drive

In case the configuration was changed and not yet saved, there will be an asterisk * behind the "MDA windows interface module – DAC application" text.

6.3.2 Menu bar

Standard and special functions may be executed and settings be performed via the menu bar:

- File**
- Use the **New** command to start a new configuration using default values.
 Use the **Open** command to load a configuration from a file. All settings in the operating software are overwritten.
 Use the **Save** command to save the current configuration to a file. The file name where the configuration is saved may be entered or selected in a dialog box. All parameters are written. Apart from the parameters, the current actual values and status signals are saved. Before overwriting, this action has to be confirmed in a popup window.
 Use the **Printer setup** menu to select the printer.
 Click the **Exit** command to close the operating software. If there is still an online connection to the drive, the connection is first correctly shut down and then the operating software is closed.
 The **Compare**, **Print**, **Print Preview**, **Last file** commands currently have no function.
 As from version MDAwin 02.04, the **Print** menu item allows to export the set drive parameters into an XML file.
- Mode**
- In the **Offline** mode, there is no connection to the drive. In this mode, all parameters within the limit values may be changed and saved (to a file). To change to an online level, a connection to the drive has to be established (go online).
 For operating software MDAwin 02.00 and higher, reading is automatically started when establishing a connection to the drive. In addition, a progress bar is implemented which indicates that reading or writing is in progress.
 In **Online Level 1** (Observer, lowest level), there is a connection to the drive. The settings may be viewed, but not modified.
 For **Online Level 2** (Operator), **Online Level 3** (Maintenance), and **Online Level 4** (Planning), a password is required (default 0000). Independent of the function of the user, parameters may be changed and the drive be started and stopped within this level.
Online Level 5 is reserved for the service technicians of GFC AntriebsSysteme.
Online Level 6 is reserved for the administrators of GFC AntriebsSysteme or for the configuration in the factory.
- Extra**
- Use the **Download Firmware Application** command to download the firmware of the application to the drive.
 The **Download Bootloader Application** command updates both the application and the bootloader. Bootloader is an auxiliary software for download. This function only has to be used if you receive an update file whose use has expressly been stipulated. This is the case for major version changes.
 For operating software version MDAwin 02.00 and higher, a popup window indicates if the bootloader has to be used.
 Use the **Download Firmware Motorcontrol** command to download the firmware for motor control.
 The present functions are only available from Online Level 4.

	NOTE
	When downloading the firmware Application (DAC-APP) and Motorcontrol (DAC-MC), the compatibility versions Pxx, Dxx and Exx behind the version identification have to match. → In case of different compatibility versions, the proper function is not ensured or the values are indicated incorrectly.

From time to time, updates with enhanced functions or bug fixes are released. In this instance, GFC will send you the files called



oder *Firmware-DAC-**MC-02-02**-D02.elf.S*
*Firmware-Dac-**App-01-04**_P02-D02-E07.bin*

The parts marked in bold indicate type of firmware and current version.

To ensure safe update performance, the following steps must be observed. To ensure a suitable combination of motor control and application on the drive, the parameter designations must be identical, i.e. in the *Name plate* of the operating software MDAwin, the fields *Firmware Application* and *Firmware MotorControl* must show identical parameter designations after the update procedure. The numerical sequence following the *D* must be identical, e.g. . *D02*.

Firmware Update Procedure

Open the MDAwin operating software and go online. Updates can be executed in online level 4. First of all, the current drive configuration should be displayed and saved via menu item *File > Save*, to ensure that data recovery is possible in case of a fault or data loss.

Update Firmware Motor Control

The update of the MotorControl firmware can be downloaded to the drive via menu item *Extras > Download Firmware MotorControl*.

The firmware transfer is displayed in the operating software via a progress bar. Upon termination of the update, the drive performs an automatic reset; this can be noticed when the operating software returns into online level 1.

Now return to online level 4 to display the drive data and to check in the *Firmware MotorControl* field of the *Name plate* window, whether the correct version is displayed, e.g. *02.02-D02*.

Update firmware application

Prior to a firmware application update it must be checked whether the update parameter version is different from the current version at the drive. For this, the *Parameter version* field in the *name plate* window of the MDAwin operating software must be compared with the update file name for the numerical sequence after the *E*, e.g. *E07*.

If the parameter version is different:

Download the update of the firmware application to the drive via menu item *Extras > Download Bootloader Application*.

If the parameter version is identical:

Download the update of the firmware application to the drive via menu item *Extras > Download Firmware Application*.

If an update is performed via this menu item in spite of a parameter version difference, the drive changes to bootloader mode after the download. This is shown in the title bar (refer to the chapter "tile bar" in this manual). In this case, the update can be performed again using the correct menu item.

The firmware transfer is displayed in the operating software MDAwin via a progress bar. Upon termination of the update, the drive performs an automatic reset; this can be noticed when the operating software returns into online level 1.

Now return to online level 4 to display the actuator data and to check in the *Firmware MotorControl* field of the *Name plate* window, whether the correct version is displayed, e.g. *01.04-P02.D02.E07*.

Should any difficulties occur during update, please contact your competent service engineer.

With the **Set defaults parameter** command, the default settings may be restored. This function is only available in Online Levels 5 and 6.

	NOTE
	All parameters are reset to their default settings. → The function may only be used after consultation with GFC, for the motor parameters, which cannot be changed by the user, are also reset to the default settings.

If **default parameters** are to be restored at a drive, this can generally be made in level 4. Proceed as follows:

- Start the operating software; when starting the operating software, the default values are automatically indicated.
- Select the **Save** command to save the default settings to a file with the extension **.dac**. Generally speaking, all default values are stored; a write procedure will only overwrite those values which are enabled in the set user level.
- Set up an online connection at the drive, click the **Read** button to read the drive data and change to Online Level 4.
- Open the stored file with the default settings and click **Write** to load them to the drive.

Use the **Calculate UZK factor** command to determine a correction factor for the calculation of the DC link circuit. After entering the current mains voltage, the firmware calculates the UZK correction factor. This function is only available in Online Levels 5 and 6.

	NOTE
	The Uzk factor is preset in the factory. → A subsequent change of the Uzk factor may cause faults or even the failure of the drive.

Use the **Change password** command to change the passwords for Online Levels 2 to 5. The current password of the level is required to change a password. The new password has to be entered twice. The password has to have at least 4 characters and must not be longer than 7 characters. All ASCII standard characters (no special characters) may be used for the password. The password is case-sensitive (upper case/ lower case).

Select the **Activate technology function** command to activate customer-specific special functions of the drives. This function has not yet been implemented.

MDA

Use the **Read** command to read the configuration from the drive. The current settings in the operating software will be overwritten.

Via the **Write** command, all parameters which may be accessed in the current level are written to the drive.

Via the **Write changes** command, all changed parameters which may be accessed in the current level are written to the drive.

For operating software MDAwin 02.00 and higher, reading is automatically started when establishing a connection to the drive. In addition, a progress bar is implemented which indicates that reading or writing is in progress.

The **Start** and **Stop** commands match the Start DDR and Stop DRR buttons of the tool bar and are described in the chapter Toolbar

Via the **Acknowledge fault** command, a fault signal may be reset if the cause of the fault has been eliminated.

Options	Use the RS232 command to select the serial interface used for the communication with the drive. Use the Language or Sprache command to either view the user interface of the operating software in German or in English. A language button in the tool bar is available for operating software version MDAwin 02.01 and higher.
View	Via the View menu, the elements (toolbar, status bar, parameter tree, command bar, and single step bar) of the user interface may be opened or closed.
Window	The Window menu contains Windows standard functions for handling windows and a list of the open dialog boxes. An * shows that parameters have been changed in this dialog box. As from version MDAwin 02.04, a further menu command Close all windows has been integrated allowing to close all open windows at once.
?	Menu item ? contains information about MDAwin and allows displaying help topics. The help topics are from the online user manual supported by the MDAwin as from version 02.04. They are separate MdaWin_DE.chm and MdaWin_EN.chm files and must be saved into the same directory as MDAwin.

6.3.3 Tool bar

Important functions may be directly performed via the tool bar. Some buttons are only activated in the online mode (level 1 to 6).



These icons corresponds to the functions **New**, **Open** and **Save** in the File menu.



Connect

By means of this button, a connection to the drive is established and a change-over to the Online Level 1 mode performed. To reach a higher level, the desired level has to be selected in the Mode menu and the respective password to be entered. The current status of the connection is indicated in the status bar and the title bar.

For operating software MDAwin 02.00 and higher, reading is automatically started when establishing a connection to the drive. The online data is directly available in the windows after establishing the connection to the drive. For previous versions of the operating software, click the Read button to start reading before change parameters can be transferred to the drive. In addition, a progress bar is implemented which indicates that reading or writing is in progress.



Disconnect connection

This button is used to disconnect an existing connection and to change-over to the offline mode. For MDAwin 02.00 operating software and higher, the online connection has to be actively disconnected, before the operating software can be terminated using the Close window windows button (X). As long as a connection is established, the button is deactivated.



Motor / System

Use these buttons to change over between **Motor view** (M) and **System view** (S) display. Nominal, actual and limit values are displayed in the units relevant to this view. The system view is converted in the MDAwin operating software. The drive only supplies data relevant to the motor which correspond to the motor view. When using fieldbus connections, only motor-specific data is available via fieldbus. The conversion of the values indicated in system view has to be performed by the corresponding superordinate control system.



Language

Use the **Language buttons** to either view the user interface of the operating software in German or in English.

Start DDR and DDR no.

Use the **Start** button to start the driving data record entered in the **DDR no.** field. This function cannot be executed in real time!

Stop DDR

Use this button to stop an active driving data record, i.e. the drive is stopped with the specified brake ramp. This function cannot be executed in real time!



WARNING

The functions **Start DDR** and **Stop DDR** CANNOT be executed in real-time and do NOT meet the requirements of an emergency stop.

Read

Use this button to read the configuration from the drive. The current settings in the operating software will be overwritten.

For operating software MDAwin 02.00 and higher, reading is automatically started when establishing a connection to the drive. In addition, a progress bar is implemented which indicates that reading or writing is in progress.

Write	Activate the Write button to write the (complete) current configuration to the drive. Only those parameters will be accepted for which the required access rights (level) are available. The Write button is only active after reading the configuration from the drive (Read button or Read MDA active). For operating software MDAwin 02.00 and higher, reading is automatically started when establishing a connection to the drive. The online data is directly available in the windows after establishing the connection to the drive. For previous versions of the operating software, click the Read button to start reading before changed parameters can be transferred to the drive. In addition, a progress bar is implemented which indicates that reading or writing is in progress.
Write changes	The Write changes button only transfers the changed parameters to the drive. Only those parameters will be accepted for which the required access rights (level) are available. The Write changes button is only active after reading the configuration from the drive (Read button or Read MDA active). For operating software MDAwin 02.00 and higher, reading is automatically started when establishing a connection to the drive. The online data is directly available in the windows after establishing the connection to the drive. For previous versions of the operating software, click the Read button to start reading before changed parameters can be transferred to the drive. In addition, a progress bar is implemented which indicates that reading or writing is in progress.
Single step	Click the Single step button to activate the single step mode of driving data records (DDR) without end-to-end connection, the next driving data record without end-to-end connection is only started when clicking the Next DDR button. The Next DDR button is only active if the single step mode has been activated.



In the single step mode, DDR with end-to-end connection are considered as a single DDR. DDR with end to end connection (DDR groups) are processed without interruption (according to linking type and holding time)!

Next DDR	Click Next DDR to start the next driving data record for active single step mode. Condition: processing of the previous driving data record has to be completed.
-----------------	--

6.3.4 Status bar

The status bar provides a quick overview over important states and current values.

Status of the connection	The current status of the connection (online/ offline) and the current access level is shown by means of an option button. The used interface (e.g. COM1) is shown in the next option field. The indication of the online connection always has to be considered in combination with the title bar. If the user changes to online level 1 and has no connection to the indicator, Online Level 1 is displayed, but Communication error is indicated in the title bar.
Drive status	An option button each shows whether a warning or an error is active.
Actual values	In the right section of the status bar, the active driving data record and the current view (motor view: torque [mNm], output speed [rpm] and position [inc], system view: independent of the system and the display units). The system view is converted in the MDAwin operating software. The drive only supplies data relevant to the motor which correspond to the motor view. In case a reference operation is performed, or none of the driving data records is active, MDAwin indicates DDR 0.


Leading priority,

Parameter change rights Two priorities are administered for the MDA servo drives: The parameter change rights and the leading priority. These two priorities can be individually assigned to different users.

To recognise priority assignment, they are displayed in the status bar as PH (parameter change rights) and FH (leading priority) as from operating software MDAwin 02.01.


If another user (fieldbus master) already possesses the priority rights, he must abandon his priority first.

To enable access to an MDA via the operating software MDAwin, the respective priority must be available. If applicable, the priority must be abandoned by the bus master first. If a user program cannot obtain a priority, it will signal each missing priority by opening an information window.



6.3.5 Parameter tree


The parameter tree can be used to call up the dialog boxes for programming, status indication and operation. The contents of the parameter tree depend on the operating software version and the support of some of the functions. These dialog boxes are described in the following chapters.



6.4 Actual values window

In the Actual values window, the current values of the drive are shown depending on the selected view (motor and system view). These values are automatically updated.

The system view is converted in the MDAwin operating software. The setting of the desired display units is made via the System window. The drive only supplies data relevant to the motor which correspond to the motor view.



Active DDR

The active DDR is indicated here. In case a reference operation is performed, or none of the driving data records is active, DDR 0 is indicated. The DDR 0 is displayed even if drives equipped with CANopen interface are operated in a CANopen standardised operation mode (refer to interface description CANopen for further information about the CANopen interface).

Torque/ Force

In the motor view, the current torque is indicated in mNm. In the system view, the Force (linear system) or the Torque (round shaft system) is indicated in the selected display unit (Linear or round shaft, refer to section) depending on the selected system (linear or round shaft).

Speed / Output speed

In the motor view (M), the current output speed is indicated in rpm. In the system view (S), the speed (linear system) or the output speed (round shaft system) is indicated in the selected display unit depending on the selected system (linear or round shaft).

Position

In the motor view, the current position is indicated in increments. In the system view, the position is indicated in the selected display unit, depending on the selected system (linear or round shaft).

Contouring Error

When executing positioning driving data records (absolute, relative, modulo) and contouring error driving data records, the current error is displayed. The indication depends on the system (motor, linear or round shaft) and the selected display unit.

Temperatures

The current temperatures in motor, electronics, and switch gear are indicated in the selected unit (°C or F).

Pt


In this field, the current load of the ballast resistor is indicated in %.

Voltages

Apart from the **DC link circuit** (UZK) and the internal voltage supply **24V internal**, the current measured values of the auxiliary voltage, the current measured values of the auxiliary voltage **24V external** and the **Brake voltage** are indicated.

6.5 Drive information window

In the **Drive information** window, statuses, signals and commands are indicated using option buttons.



6.5.1 Info Status group

The option buttons of the Info status group box provide information on the status of the application. They include the following signals:

Warning	Active in case a warning is present. A warning will not cause the drive being switched off. Detailed information on the warning is contained in the Info collective warning group box or in the Drive warning dialog box
Error	Active in case an error is present. An error will not cause a switching off of the drive. Detailed information on the fault is contained in the Info collective fault group box or in the Drive fault dialog box
DDR active	A driving data record is being processed.
Setpoint	The setpoint specified in the DDR has been reached
Reference operation active	The reference operation is being executed
Fieldbus active	A connection to the master via fieldbus is available
Intermediate stop	A DDR was interrupted by the Intermediate stop command
Single step	The single step mode is activated
Single step pause	A DDR was terminated in the single step mode. The drive is waiting for a new start command
Reference set	The reference point was set. This enables absolute positioning
Cmd RF0	The controller release RF0 was eliminated. A DDR is terminated with maximum ramp, the drive then maintains the position at maximum torque
Cmd Stop	The Stop command is active (via operating software, fieldbus, or digital input), an active DDR is terminated using the specified brake ramp
Cmd Qstop	The quick stop command is active (via fieldbus or digital input). A DDR is terminated at max. brake ramp, then the motor is disconnected from the mains. The command causes a fault

Synchronous running

This function is available for firmware APP 02.00 in combination with the MDAwin 02.00 operating software and indicates the status of the "Electric shaft" technological function.

Ack Stop, Ack Qstop, Ack Rf0

Acknowledges that either the Stop, quick stop or RF0 command was executed

6.5.2 Info drive group

The option buttons of the Info drive group box contain information on the current status of the servo drive:

Limit switch plus The limit switch plus is activated

Limit switch minus The limit switch minus is activated

Drive without power The motor is not supplied with power. The position may change if there is no holding brake available

Drive at standstill The motor shaft does not move. The monitoring is always active if the servo controller is supplied with power or auxiliary voltage. Therefore, it is also indicated if the motor shaft is moving due to external influences.

Brake active The holding brake is not supplied with power and blocks the motor shaft

Fan active The fan is activated (optional).

Info Analogue In1 In this field, the current measured value (10 bit) of the analogue input is indicated



Within firmware version APP 02.01 and operating software version MDAwin 02.01, the current functional value is displayed without unit indication. Calculating the functional value is made by using the analogue input settings in the I/O drive window.

6.5.3 Info collective warning group

The collective warning group box contains the cause(s) for a collective fault. For further details, refer to the Drive warning dialog box.

6.5.4 Info collective fault group

The group box contains the causes for a collective fault. For further details, refer to the Drive fault dialog box.

6.5.5 Status digital inputs group


This group box is used to indicate the current logic status of the digital inputs, i.e. option button active if input is high-active = high (24 V) or if input is low-active = low (0 V).

6.5.6 Status digital outputs group

This group box is used to indicate the current logic status of the digital outputs, i.e. option button active if output is high-active = controlled or if output is low-active = not controlled (0 V).


6.6 Drive fault window

The **Drive fault** window shows detailed information on the cause of a fault.



A fault code is indicated in the drop down list. Click on the drop down list to view the active fault cause(s). After remedying the cause of fault, the fault has to be acknowledged via the **DAC fault window** or via the **MDA Acknowledge fault** window.

For the table with the fault numbers, please refer to the appendix.




The popup window indicates that a fault has occurred. Click the **Info** button to directly open the Drive fault window. Click the **Acknowledge fault** button to acknowledge the fault if the cause of the fault is no longer present. The language of the popup window depends on the settings of your Microsoft Windows.



A fault may only be acknowledged if the cause is no longer active. If a fault is reset via acknowledge Fault, the fault number is also deleted from the fault register. Click the Info button first to have the fault displayed.

6.7 Drive warning window


The **Drive warning** window contains detailed information on the causes of a warning.



A warning number is indicated in the drop down list. Click on the drop down list to view the active warning cause(s). After remedying the cause of warning, the warning is automatically reset. For the table with the warning numbers, please refer to the appendix.

6.8 Operational data window

The **Operational data** window shows recorded operating data such as operation time, motor running time, and various faults.



Operation time Total on-time of the electronics in days, hours, minutes, and seconds.

Motor running time Total period during which the motor was supplied with power in days, hours, minutes, and seconds.

Faults In the **Fault Temp. PE**, **Fault Temp. Electr.**, **Fault Temp. Motor**, **Fault excess current**, **Fault DC link circuit**,

Fault Temp. PE Temperature of the power amplifier

Fault Temp. Electr. Temperature of the electronics

Fault Temp. Motor Temperature of the motor

Fault excess current exceeded current (of the motor)

Fault DC link circuit DC link circuit

Fault Bus Fieldbus

fields, the number of the respective faults causing a fault signal are recorded and indicated.

Restarts The number of power-on procedure of the voltage supply is shown in this field.



In the drive, the operational data is updated every second within the RAM and is saved to the EEPROM every 100s. The drive has to be supplied with power for at least 100s to enable a remanent update of the operational data.




The indication of the operational data in MDAwin is not automatically updated but has to be read out by the user themselves (refer to Tool bar, Read).

6.9 Fieldbus monitoring window



This function is available from firmware version APP 02.04 and operating software version MDAwin 02.04 and higher.




This window displays the control word and status word of a drive equipped with fieldbus interface. For this, there must be an active connection to the drive. The update is carried out at the same frequency as the update of other displays, like speed or position. No indication can be made on transient procedures via the fieldbus monitor. This window is used to commission a drive with fieldbus interface.

6.10 Event buffer window



This function is available from firmware version APP 02.04 and operating software version MDAwin 02.04 and higher.



The event buffer is a ring buffer with a maximum buffer capacity of 100 event entries. Events of up to 6 different signal types may be recorded. When reaching the maximum buffer capacity, the oldest entry is overwritten.

6.10.1 Event logging group box

A filter can be set for entries into the event buffer. The recording to the events can be restricted to obtain more buffer capacity for certain events. In the Event logging group, the event types to be recorded can be selected. The following event types can be recorded independently of each other

Faults	Fault signals (Drive fault)
Warnings	Warning signals (Drive warning)
Info	Status signals (Drive info)
Parameters	Parameter changes (via MDAwin or fieldbus)
Command	Internal drive commands
System	Internal system signals

Online level 4 is required for selection and transmission to the drive.



In the drive, the operational data is updated every second within the RAM and is saved to the EEPROM every 100s. The drive has to be supplied with power for at least 100s to enable a remanent update of the operational data.

The servo drive is equipped with an internal real-time clock without buffer (the time is not updated while the drive is switched off). Therefore, all signals are marked with a time stamp, starting with 06.01.2005 as the date and 0:00 as the time if the clock was not set via MDAwin or if the drive was completely disconnected from the mains. Click the **Set date/time** button to mark the signals with a time stamp.

6.10.2 View group box

The View group filters those event types which are read from the event buffer and shown in the indication field. Since these event types can already be filtered when saving to the event buffer, the maximum which can be shown in the indication field is the contents of the event buffer reduced by the event types filtered for indication.

Click **Update** or **Read** to update the event indication in Online Level 4.




If too many event types are selected for logging, important signals and warnings are immediately overwritten.

If the motor is disconnected from the mains, the time stamp is lost and has to be reset.

For an overview of all signals, refer to the tables in the appendix.

6.11 Manual operation window

The **Manual operation** window contains two driving data records with the most important parameters for quick commissioning of the drive. The parameters are described in the chapter on the **DDR editor** window. For simple handling, the most important commands are available on the buttons.



Run The drive runs with the settings in the manual operation as long as the **Run** button is pressed down. **This function cannot be executed in real time!**

Start Use the **Start** button to start a DDR with the settings in the **Manual operation** window. The DDR is terminated when reaching the limit condition (time or position) or by means of a stop command. **This function cannot be executed in real time!**



Click the button to transfer the manual operation DDR input to the drive and to start the DDR. Loading the changed data via the Write or Write changes command is not required.

Stop The active DDR (manual operation or normal operation) is terminated. **This function cannot be executed in real time!**




WARNING

The functions *Run*, *Start DDR* and *Stop DDR* CANNOT be executed in real-time and do NOT meet the requirements of an emergency stop.

6.12 DDR editor window

In the **DDR editor** window, the driving data records are programmed or may be checked.



Driving data record Use this field to select a DDR (1 to 99). The DDR 0 is reserved as buffer of operation commands by the CANopen and cannot be used as regular DDR.

Program identification This field is provided for the identification of programs stored in the drive.

6.12.1 Controller type

The controller type for the DDR is determined in this field. The controller type can only be changed in level 4 or higher.

No DDR is not defined

Torque / Force During the *Target time*, the drive controls to the *nominal torque* or the *nominal force*. A *target time* of 0 means infinite, without time limit.
Via *Max. speed / Max. output speed*, the maximum output speed or speed may be limited.

Output speed/ Speed During the *Target time*, the drive runs at *Nominal output speed* or at *Nominal speed*. A *target time* of 0 means infinite, without time limit.
By entering a value for *Max. torque / max. force*, the maximum torque or the maximum force is limited.

Absolute Position The absolute position *Nominal position* is approached at *Nominal output speed* or *Nominal speed*. Absolute positioning is only possible if the *Reference* is set.
By entering a value for *Max. torque/ max. force*, the maximum torque or the maximum force is limited.
The output speed/ speed for compensating the contouring error may be limited by activating the *with speed limitation* feature and entering a *Max. output speed/ Max. speed*.

Relative Position The drive is operated at *Nominal output speed* or *Nominal speed* by the relative *Nominal position*.
By entering a value for *Max. torque/ max. force*, the maximum torque or the maximum force is limited.
The output speed/ speed for compensating the contouring error may be limited by activating the *with speed limitation* feature and entering a *Max. output speed/ Max. speed*.

**Modulo
Position**

Only round shaft system.

The drive positions within a (system) rotation on the shortest way possible, for specifications > 360°; the integral multiple is ignored. During positioning, the gear reduction ratio (*Gear factor input*, *Gear factor output*) and the *System conversion* are observed.

The output speed/ speed for compensating the contouring error may be limited by activating the *with speed limitation* feature and entering a *Max. output speed/ Max. speed*.

**NOTE**

The max. possible distance for a position-controlled driving data record amounts to approx. 536 million increments.

→ To be able to use the full range of the position controller or to cover longer distances, the distance has to be divided into several driving data records running one after the other.

Contouring error During the *Target time*, the drive runs at *Nominal output speed* or at the *Nominal speed*. An existing contouring error will be compensated. The output speed/ speed for compensating the contouring error may be limited by activating the *with speed limitation* feature and entering a *Max. output speed/ Max. speed*.

Depending on the controller type, the fields in this window will be shown/ hidden and the identification adapted. These dependencies are shown in the following table for round shaft system or motor:

Controller type	None	Torque	Output speed	Position	Contouring error
from level:					
3	Nominal value	Nominal torque	Nominal output speed	Nominal position	Nominal output speed
3	Nominal output speed	--	--	Nominal output speed	--
3	Target time	Target time	Target time	--	Target time
3	Max. torque	--	Max. torque	Max. torque	Max. torque
3	Max output speed	Max output speed	--	Max output speed ¹⁾	Max output speed ¹⁾

¹⁾ if **with speed limitation** feature is activated

**Controller parameter
record**

For each DDR, a controller parameter record may be selected. The controller parameter records are defined in the Speed position controller window.

**Driving data record
linking**

The **Driving data record linking** defines the behaviour between two driving data records. In case a linking was selected, a holding time and the next DDR must be defined. The following linking types are available:

- None** There is no change-over to another DDR, the drive stops after processing the DDR (behaviour is defined via *Features*).
- Overhung** Change-over to the next DDR without any stop (end-to-end connection). The change over to the next DDR is made using the settings for acceleration value and acceleration ramp of the next DDR.



**For end-to-end linking, the position reached signal is rather short.
In the single step mode, DDR with end-to-end connection are considered as a single DDR.**

Maintain position	The current position is actively maintained for the <i>Holding time</i> at the <i>Max. torque</i> (DDR or global) inbetween the DDRs.
Brake	Same as <i>Maintain position</i> if the holding time exceeds the apply and release time, the current position is maintained via the holding brake
Without power	The drive is not supplied with power during the <i>Holding time</i> . The position may change.
Holding time	This field defines the holding time between the DDRs in case a linking was defined between the DDRs. The time is entered in ms.
Next DDR	The next DDR, which is to be started in case of a linking and after the holding time has elapsed, is entered here.

6.12.2 Maximum values group box

The limit values for the DDR are defined in this group box. Depending on the controller type, the **Max. torque** and **Max. output speed** limit values are shown/ masked out. The designations and units depend on the system type, the motor/ system view and the selected display units. The slope and the type of the acceleration and deceleration are defined using the **Acceleration value**, **Deceleration value**, **Acceleration ramp** and **Deceleration ramp** fields. The sinesquare ramp type limits the jolt.

6.12.3 Features group box

The following features may be activated within the Features group box. These features only affect the selected DDRs.

Synchronisation	The DDR will only be started after a synchronisation impulse has been received (via digital input or bus)
Nominal value externally allowed	Not the nominal value entered in the DDR is used, but the nominal value specified by the fieldbus or the analogue input.
Stop with position dwell time	In case the DDR is stopped (via the Stop command or DDR end without linking), the position will be actively maintained during the <i>position dwell time</i> .
Stop with brake	If the DDR is stopped (via Stop command or DDR end without linking), the holding brake is activated.
Intermediate stop without current	In case the DDR was interrupted by an intermediate stop, the position is not maintained actively during the intermediate stop.
with speed limitation	For the controller types Absolute position, Relative position, Modulo position and Contouring error, the output speed/ speed is limited with regards to the contouring error compensation.

6.13 Name plate window

The **Name plate** window is the electronic name plate of the drive. It contains information on the order and the drive. The information may not be changed (except for the customer designation1 and 2)

The screenshot shows a software window titled "Name plate" with a tree view on the left and a data grid on the right. The tree view includes categories like Status, Manual operation, DDR programming, Parameters, and Drive. Under the Drive category, "Name plate" is selected. The data grid contains the following fields:

Commission number	15100663	Application firmware	02.01 T 06.11.27
Works number	4604NU00740	Motor control firmware	02.03-D02
Serial no motor	0705ND00897	Logic variant	Z035.265/01
Serial no electr	0705NT00001	Interface variant	Z035.266/01
Customer designation 1	GFC	Bus module variant	Z039.675/01 PBD
Customer designation 2	AntriebsSysteme	Power supply unit variant	01.00
Date of final test	14.03.2005	Power board variant	01.00
Wiring diagram DAC	1110-A14P0-000	Parameter version	E08.00
Terminal plan MES	3010-K10X0-000		

Commission number	This field indicates the order number of GFC AntriebsSysteme.
Works number	This field contains the definite works number of the drive.
Serial no	The Serial no motor and serial no electr fields contain the definite serial number of the motor and the controls.
Customer designation	The Customer designation 1 and Customer designation 2 fields contain information specified by the customer (max. 20 characters each). These entries may also be changed in <i>Online Level 4</i> .
Date of final test	The date of the final test is entered in this field.
Wiring diagram DAC	The Wiring diagram DAC field contains the number of the wiring diagram for the controls. The diagram shows the position of the plug and the wiring assignment. The name plate also bears this number. A copy of this wiring diagram is included in the scope of delivery of the drive. The wiring diagram may also be downloaded or printed out from the Internet.
Terminal plan MES	This field contains the number of the terminal plan between motor and controls.
Firmware application	This field contains the version of the application firmware as well as version indications for the compatibility to operating software (Pxx), parameter structure (Exx) and motorcontrol firmware (Dxx).
Motor control firmware	This field contains the motor control firmware and the version number of the application firmware (Dxx)
Logic variant	Article no. and variant of the logic board.
Interface variant	Article no. and variant of the interface board
Bus module variant	Article no. and variant of the bus module
Power supply unit variant	Article no. and variant of the power supply unit
Power board variant	Article no. and variant of the power board
Parameter version	Version indication for parameter structure

6.14 Hardware window

The **Hardware** window contains the basic configurations of the servo drive. Some of them are programmed in the factory and may therefore not be changed.

UZK correction factor

The UZK correction factor field contains a correction factor for adapting the hardware. This value is set in the factory and may not be modified.

	NOTE
	Modifications of the UZK correction factor may cause major faults or even a complete failure of the drive. → The values may only be changed by the service of GFC AntriebsSysteme.

I²t monitoring

Use this field to set the type of the connected ballast resistor. For the type "none", there is no I²T monitoring.

Due to this monitoring, an overload of the brake resistance is detected and an alarm is emitted.

As from Firmware APP 02.01 and MDAwin 02.01, the I²t monitoring is set in the factory to the load resistance used and can only be changed by GFC AntriebsSysteme.

6.14.1 Motor data group box

This group box contains parameters for adapting the controls to the motor. The *Max. motor torque* and *Max. motor speed* fields contain the max. values of the motor which may not be exceeded. These fields may not be modified.

	NOTE
	Modifications of the motor data, the motor offset and the UZK correction factor may cause major faults or even a complete failure of the drive. → The values may only be changed by the service of GFC AntriebsSysteme.

6.14.2 Motor transmitter group box

This group box contains parameters for adapting the controls to the motor transmitter. The **Position indicator** and the **Pos. ind. resolution** depend on the motor used and are programmed in the factory.

The **Speed limit** contains the output speed limit. If the measured actual output speed exceeds this speed limit, the drive is switched off (without power) and changes to the fault mode. This value may be change in level 4 (Planning).

After a motor change, the motor offset has to be entered in the Motor offset field (value –1 means "not defined" and will issue a warning or fault signal). If this value is not known, it may be determined via the **Start motor adjustment** button. The motor adjustment is adapted via the **Motor adjustment** and **Motor adjustment time** values. These fields may only be modified by the service of GFC AntriebsSysteme.

6.14.3 Holding brake / fan group box

Via the commands in this group box, the controls are adapted to the optional holding brake within the motor. The brake requires an **apply time** for engaging and a **release time** for releasing. During these times, the full holding torque is applied by the controls so that the position may be maintained during engaging or releasing the holding brake. The motor is only started at the end of the release time. This prevents the motor from working against the still engaged brake. Use the **Fan** field to define the control of an optionally mounted fan.

6.14.4 Global settings group box

The **Global settings** group box is used to define the global maximum values, both positive and negative, for **Torque** and **Output speed**. These values have priority over those values which were defined in the DDR; however they may not exceed the values in the Motor data group box. By means of the **Position holding time** field, the time after the expiry of a DDR is determined, during which the position is actively maintained by the drive. For the setting 0 ms, the position will be infinitely maintained.



The duration of the position holding time also determines how long the setpoint reached signal is displayed. When operating the MDA with a bus system, it may be required to increase the position holding time to ensure that the signal is displayed for an appropriate period via the bus.

As from firmware version APP 02.01 and operating software version MDWin 02.01, the quick stop ramp can be set within the drive. The parameters **Quick stop ramp** and **Quick stop deceleration** are used to set the ramp form as well as the deceleration value.

For example, the quick stop ramp is used in the event of faults to bring the drive to an orderly standstill.



WARNING

The setting of deceleration values of the quick stop ramp influences the time needed for the drive to come to a standstill triggered by the quick stop function.

If the value 0 is recorded, the drive does not introduce a deceleration!

→ The deceleration value must be set to the highest possible value, at least superior to 0 to ensure the standstill of the drive.




DANGER

If the deceleration value 0 is recorded, the drive does not introduce a deceleration!

→ The deceleration value must be set to a value superior to 0, in order to ensure the standstill of the drive.

6.15 Control loop window

The parameters of the control loop are set in the **Control loop** window. These parameters are adapted to the mounted motor in the factory and may not be changed.




NOTE

Modifications of the parameters of the control loop may cause major faults or even a complete failure of the drive.

→ The values may only be changed by the service of GFC AntriebsSysteme.

6.16 Speed position controller window

In the **Speed position controller** window, the parameter of the speed controller, the parameters of the position controller, and further settings for the position control have been made. 4 parameter records may be defined for the speed position controller. For each DDR, the parameter record to be used may be selected.



Speed

position controller

The number of the controller parameter record can be set in this field. Four controller parameter records are available

Output speed P-amplification

The amplification factor K_p for the speed controller is entered in this field. The factor changes the P-part of the PI controller. The default value is 5.8. If the P-part is too high, the drive does not run smoothly and tends to vibrate if the P-part is too low, the drive is soft and slow.

Output speed I-reset time

The reset time T_n is determined for the speed controller in this field. The factor changes the I-part of the PI controller. The default value is 1310 μs . The value may be changed within a range from 0 to 655350 μs with a resolution of 10 μs . The value 0 μs deactivates the I-part.

If the I-part is too high, the drive is too soft; if it is too low, the drive does not run smoothly. Large foreign moments of inertia usually require higher reset times.

Position P-amplification

Use this field to determine the K_p amplification. Within the range 0.01 to 250, the K_p amplification may be changed with a resolution of 0.01. The default value is 6.50. The higher the value, the faster will a position difference be compensated.

Position pilot control

This value is used to determine the amplification of the pilot control, i.e. that part of the nominal output speed which is directly supplied to the speed controller. The part may be modified within the range from 0 (=deactivated) to 1. The default value is 1.0. For position pilot control = 1, a contouring error is almost compensated, however the drive runs at fluctuating output speed specification (e.g. noise via analogue input) with a lot of vibration and quite noisily.

Positioning window


Reaching the target position is checked for the controller types Absolute position, Relative position and Modulo position. The size of the positioning window (+/-window) determines as from which distance onwards from the nominal position the signal "Target reached" is to be issued. The "Setpoint reached" signal (in the Drive info window) is reset after the position holding time (Hardware window) has expired.

Contouring error window

There is always a difference between the nominal position value and the actual position value if the drive is running. For the controller types absolute position, relative position, modulo position, and contouring error, the Contouring error warning will be activated if this value has been exceeded, this means that the occurring contouring error may not be compensated by the position controller since e.g. the torque is not sufficient.

6.17 System window

In the **System** window, the adaptations to the existing system are determined. This adaptation requires Level 4 (except for the display units time, position, and temperature).



System type
Linear

Use this field to select the existing system:
The servo drive is mounted to a linear axis or in a system with translatory movements.

Round shaft /
Modulo

The servo drive is mounted to a round shaft or in a system with rotary movements. The modulo function is used for a circulating system where positions are to be approached via the shortest distance (within motor or system rotation).



The system view displayed in the upper part of the window changes its appearance depending on the system type, the gear and system inversion

The system view can be used to check whether the settings made match the mechanic system which is to be used in the drive.

Software
limit switch

Independent of the hardware limit switches (ESL/ESM and ESR/ESP) additional software limit switches may be determined by activating the **Software limit switch** check box. The value for the **Limit switch Minus** must be lower than the value for the **Limit switch Plus**.

Before starting a DDR with the controller type absolute position or relative position, it is checked whether the nominal position (target position) is within the software limit switches. If the nominal position is not within the software limit switches, the DDR is not started and a fault is signalled.

**NOTE**

For the controller types Torque, Output speed, Modulo position, and Contouring error, the software limit switches will not be evaluated.

→ When using DDRs with the above mentioned controller types for a linear system, hardware limit switches should be available to avoid damage/destruction of the linear axis.

Inversion of direction

By activating the **Inversion of direction gear** checkbox, it is determined that the directions of the gear input and gear output differ. The inversion of direction system checkbox adapts the direction of movement between motor or gear and linear axis.

Conversion

These fields are used to define the conversion factor of primary movement (motor view) to secondary movement (system view). The values of the user interface are converted by this factor between motor and system view (refer to section 6.3.3). To facilitate the input, the unit *Gear rotation* should be selected on the left. Any available gear (*Gear input* and *Gear output* fields) is taken into consideration. For the *Motor turn* and *Increments* units, the gear reduction included in the specified conversion factor.

Conversion	1	Gear rotation	=	60	mm
------------	--------------------------------	--	---	---------------------------------	---------------------------------

Depending on the selected *System type*, you may chose on the right side between rotary units (round shaft: turns, degree, seconds) or translatory units (linear: m, dm, cm, mm, μ m).

Display unit Time

This setting allows the change of the time unit for some of the parameters. Apart from time indications, output speed, or speed, values will also be affected. The indication of values in the motor view will, however, not be changed.

Display unit Position

This setting allows the change of the position unit for some of the parameters. The selection depends on the *System type* chosen: rotary units (turns, degree, seconds) for round shaft or translatory units (m, dm, cm, mm, μ m) for linear axis. The indication of values in the motor view will however not be changed.

Display unit Temperature

This setting allows the selection of the temperature units between °C and F for some of the parameters.

Gear factor


The reduction of the gear optionally mounted at the motor is included in the **Gear factor input** and **Gear factor output** fields.



The changes will not be applicable unless the drive is at standstill. Terminate driving data records before writing system changes.

6.18 I/O drive window

The digital and analogue inputs and outputs of the drive are configured in the **I/O drive** window. The number and the type of the inputs/ outputs depends on the *Interface variant*. Level 4 (Planning) is required for changing the parameters.



6.18.1 Digital Input group box

The number of the input (1 to 4) is selected in the input field on the upper right. The **Module address** and **Input number** fields are definitely assigned and may not be changed.

The **high active** checkbox defines the logic state of the input:

- ☐ Input low active, i.e. for low level, the input is logically active
- ☒ Input high active, i.e. for high level, the input is logically active

If the **DDR dependent** checkbox is activated, the selected input function is only applied to the DDR entered in the **DDR no.** field. For all functions described in the following there is a note indicating the influence of the activated checkbox on the function or whether the checkbox may not be selected.

The function of the input is determined by the **Function** drop down list.

None Input has no function or is not used

Synchronisation Starts the next DDR if is waiting for a synchronisation impulse (refer to DDR editor, Feature). The **DDR dependent** function may not be selected.



In the single step mode, DDR with end-to-end connection are considered as a single DDR.

Go to DDR(x) ☐ **DDR dependent:** end-to-end change-over to DDR 99
☒ **DDR dependent:** end-to-end change-over to the specified driving data record

Intermediate stop The current DDR is interrupted (refer to DDR editor, Feature). The **DDR dependent** function may not be selected.

Single step mode The single step mode is activated: Press Start to acknowledge each DDR change-over. DDRs with end-to-end linking (DDR groups) are considered as a single DDR and are processed without interruption.

Reference	The reference switch is connected to the input. The reference switch is required for the <i>Marker</i> and <i>Flank</i> reference types (refer to Reference operation window section).
Reference start	This signal is used to start the reference operation. The DDR dependent function may not be selected.
Start / Stop	☐ DDR dependent: The drive may only be started if the signal is on logically high. Global release signal (Cmd Stop). If a DDR is terminated using this signal, the drive stops with the deceleration ramp of the active DDR). ☒ DDR dependent: The indicated DDR is executed as long as the input is logically high. If the input becomes logically low, the DDR is stopped.
Limit switch positive	The limit switch positive is connected to the input. Drive stops when the signal is deactivated or activated (Cmd QStop). The DDR dependent function may not be selected.
Limit switch negative	The limit switch negative is connected to the input. Drive stops when the signal is deactivated or activated (Cmd QStop). The DDR dependent function may not be selected.
Controller enable RF0	Drive stops when the signal is deactivated or activated (Cmd RF0). The drive is stopped at maximum torque and remains connected to the mains (during standstill). No fault signal is issued. The DDR dependent function may not be selected.
Quick stop	Drive stops when the signal is deactivated or activated (Cmd QStop). The drive is stopped at maximum torque. Afterwards, a fault is signalled. For standstill of the motor, the motor is disconnected from the mains. The DDR dependent function may not be selected.
Power amplifier off	Power amplifier is deactivated, motor is without power and slows down. The DDR dependent function may not be selected.
Start	☐ DDR dependent: If the single step mode is active, the next DDR is started via a logic LH flank (low to high). Otherwise the signal has no function. ☒ DDR dependent: Starts the indicated DDR.
Stop	Stops the current DDR. Drive stops when the signal is deactivated or activated (Cmd Stop). If a DDR is terminated using this signal, the drive stops with the deceleration ramp of the active DDR).

**CAUTION**

If a DDR is active and in *Maintain position*, operating the Stop switch disconnects the motor from the mains.

If the Stop switch is operated twice for an active DDR with the *Maintain position* feature, the drive is disconnected from the mains.

→ The *Stop with brake* feature can be additionally used to lock the motor shaft if the drive is equipped with an internal holding brake.

Teach In	☐ DDR dependent: The input saves the current actual position value in the active DDR ☒ DDR dependent: The input saves the current actual position value in the determined DDR
Acknowledge fault	Use the input to acknowledge a fault. The DDR dependent function may not be selected.

Set reference manual

The function is available for firmware APP 02.00 and operating software 02.00 and higher. This function can be used to determine one position as reference without having to perform a reference operation. This is suitable for programming the reference operation directly to the reference memory (refer to Reference operation window and Multi-turn absolute encoder section). The **DDR dependent** function may not be selected.

Limit switch negative warning

This function is available from firmware version APP 02.01 and operating software version MDAwin 02.01. The limit switch negative is connected to this input. The drive stops once the signal is removed or applied. (Cmd QStop).

Limit switch positive warning

This function is available from firmware version APP 02.01 and operating software version MDAwin 02.01. The limit switch negative is connected to this input. The drive stops once the signal is removed or applied. (Cmd QStop).

6.18.2 Digital Output group box

The number of the output (1 to 4) is selected in the input field on the upper right. The **Module address** and **Output number** fields are definitely assigned and may not be changed.

The **high active** checkbox defines the logic state of the output:

- ☐ Output low active, i.e. output active for logically not active
example: relay controlled if signal not active
- ☒ Output high active, i.e. output active for logically not active
example: relay controlled if signal is active

If the **DDR dependent** checkbox is activated, the selected output function is only applied to the DDR entered in the **DDR no.** field. For all functions described in the following there is a note indicating the influence of the activated checkbox on the function or whether the checkbox may not be selected.

The function of the output is determined by the **Function** drop down list.

None Output has no function, is not used

Collective warning A warning is present. The **DDR dependent** function may not be selected.

Collective fault A fault is available (a DDR was interrupted). The **DDR dependent** function may not be selected.

DDR active ☐ **DDR dependent:** a DDR or
☒ **DDR dependent:** the indicated DDR is being processed.

Setpoint reached ☐ **DDR dependent:** the setpoint (generally) or
☒ **DDR dependent:** the setpoint specified in the DDR has been reached.

Reference operation The reference operation is being executed. The **DDR dependent** function may not be selected.

Fieldbus active Connection to the master established or fieldbus communication is available. The **DDR dependent** function may not be selected.

Contouring error ☐ **DDR dependent:** The error (generally) or
☒ **DDR dependent:** the error in the mentioned DDR exceeds the value that is defined in the contouring error window

Intermediate stop The drive has interrupted a DDR and is in the intermediate stop function. The **DDR dependent** function may not be selected.

Single step mode The single step mode is active. The **DDR dependent** function may not be selected.

Single step pause	A DDR has been completely processed, the drive is waiting in the single step mode for a new start command. The DDR dependent function may not be selected.
Reference set	The reference position was set (manually or by means of a reference operation). The DDR dependent function may not be selected.
Limit switch positive	The limit switch positive is activated. The DDR dependent function may not be selected.
Limit switch negative	The limit switch negative is activated. The DDR dependent function may not be selected.
Drive without power	The motor is not supplied with power, no DDR active. The DDR dependent function may not be selected.
Drive at standstill	The motor does not turn (output speed = 0). The DDR dependent function may not be selected.
Acknowledge Quick stop	Quick stop command (Cmd QStop) successfully acknowledged. The DDR dependent function may not be selected.
Acknowledge Stop	Stop command (Cmd Stop) successfully acknowledged. The DDR dependent function may not be selected.
Acknowledge RF0-stop	RF0 command (Cmd RF0) successfully acknowledged. The DDR dependent function may not be selected.
PB-I/O extension	For firmware APP 02.00 and operating software MDAwin 02.00: Output can be used as local peripheral device of a Profibus master. The DDR dependent function may not be selected.

6.18.3 Analogue input group box

The **Module address** and **Input number** fields are definitely assigned and may not be changed.

The **Characteristics** determine the direction of action of the analogue input:

Normal	The minimum input value is assigned to the minimum function value.
Inverse	The minimum input value is assigned to the maximum function value.
Fault range	Not yet implemented. The minimum input value is assigned to the minimum function value. If the input value is not within the determined range, the drive will be stopped and a fault signal be issued.

The **Function** defines the function of the analogue input:

None	Input has no function, is not used
Output speed setpoint	The nominal output speed or the nominal speed are specified via the analogue input if the <i>Nominal value externally allowed</i> feature is activated.
Torque setpoint	The nominal torque or the nominal force are specified via the analogue input if the <i>Nominal value externally allowed</i> feature is activated.

- Max output speed** The maximum output speed or speed are limited via the analogue input. The function corresponds to the **Max. speed positive / negative** field in the Global settings group in the **Hardware** window and has global influence on all driving data records.
- Max. torque** The maximum torque or force are limited via the analogue input. The function corresponds to the **Max. torque positive / negative** field in the Global settings group in the **Hardware** window and has global influence on all driving data records.
- Nominal position value** For firmware APP 01.06 and higher in combination with the operating software MDAwin 01.04, a position can be specified via the analogue input. The position is limited to a value range of 16 bit.

The range of the selected **Function** is defined via the **Function value min.** and **Function value max.** fields. The unit depends on the selected function.

Output speed Setpoint	rpm at motor
Torque setpoint	mNm at motor
Max output speed	rpm at motor
Max. torque	mNm at motor
Nominal position value	Increments at motor


The input range of the analogue signal is determined via the **Interface value min.** and **Interface value max.** fields. The **Input type** is – 10V to + 10V with 10 bit depth for the standard interface. If the input range is to be changed within the limits specified by the standard interface, this can be done in the Value min. and Value max. fields.

- filter adjustment** The response behaviour of the analogue input can be set via filter adjustment. For small values, the analogue input quickly responds to signal fluctuations; for higher values, the fluctuations are increasingly filtered.
- Dead zone value** The functional value 0 margin is set via the dead zone value to ensure that a stable functional value (setpoint value 0) can be generated even in the event of input signal fluctuations.

Example: The output speed is to be adjusted within a range between 0 to 1000 rpm via an external potentiometer (0 to 5 V). The following settings have to be made.

6.19 Fieldbus window

In the Fieldbus window, the parameters for the fieldbus may be set.



- Type** The bus module included within the drive is automatically detected and viewed if there is a connection to the drive available (online).
- Slave Address** The address of the slave (0...127) is entered in this field. An address may be assigned only once within a segment.
- Baud rate** For CANopen, the baud rate must be set in this field. It must comply with to the baud rate of the master.
For Profibus DP, the baud rate of the master is automatically detected and adapted. For Profibus DP, this field is not displayed.
- Diagnosis** For firmware APP 02.00 in combination with operating software MDAwin 02.00, the fault diagnosis can be switched off for Profibus DP. For more detailed information, please refer to the fieldbus-specific interface description.


The **Operation mode**, **Disable fieldbus access** and **Rights** fields, still do not have any function and are reserved for subsequent enhancements.



After having modified the slave address, the actuator must be switched off. After renewed switching on, the actuator can be accessed using the new address. For more detailed information on the fieldbus interface, please refer to the fieldbus-specific interface description.

6.20 Reference operation window

In the **Reference operation** window, the parameters for the reference operation are configured.



6.20.1 Configuration group box

The procedure for determining the reference point is selected in the **Type** drop down list:

- | | |
|------------------------------|---|
| None | No reference operation is being executed. The actual position depends on the motor transmitter and the reference is set in this position. |
| Marker | The reference point is set when reaching a reference marker. Hardware limit switches are required for this configuration type. If the reference marker is passed, a signal pulse will be issued; for setting the functions of the digital inputs, please refer to the I/O drive window section. |
| Flank | The reference point is set when detecting the flank of the reference switch. For operation in positive direction, the reference switch only generates a flank from low to high within the entire travel range. A sensor is required for this type; for setting the functions of the digital inputs, please refer to the I/O drive window section. |
| Limit switch positive | The reference point is set when releasing the limit switch positive. Hardware limit switches are required for this type; for setting the functions of the digital inputs, please refer to the I/O drive window section. |
| Limit switch negative | The reference point is set when releasing the limit switch negative. Hardware limit switches are required for this type; for setting the functions of the digital inputs, please refer to the I/O drive window section. |
| Block Plus | The reference point is set for operation in positive direction when reaching the force specified in the <i>Force</i> field. |
| Block Minus | The reference point is set for operation in negative direction when reaching the force specified in the <i>Force</i> field. |
| Reference memory | <p>Motor with absolute encoder:</p> <p>When switching off the power supply, the status of the reference bit is stored in the EEPROM. The reference bit is restored during a restart, the current position is directly read out from the absolute encoder.</p> |



Please refer to the chapter „Multi-turn absolute encoder” in this manual.

Motor with **resolver**:

When switching off the power supply, the current actual position is stored in the EEPROM. This position is used when rebooting.

**CAUTION**

The position is only correct if the drive is not operated when not supplied with power.

- Use mounted brakes or other suitable means to ensure that the position of the drive cannot be changed when the drive is switched off. If this cannot be ensured, a reference operation has to be performed after each restart.

The required direction of rotation of the motor for setting the reference point is defined in the **Reference operation** field. This field is only effective for the reference types marker and flank. For more detailed information on the reference operations, please refer to the following charts.

The following charts show the sequence of the reference types depending the start position and the direction of operation. The abbreviations stand for the following:

ESM	Limit switch minus (negative)
ESP	Limit switch plus (positive)
SP	Start position
RP	Reference position
RM	Marker
REF	Flank
v	Speed (including direction positive or negative)
x	Position

**WARNING**

The reference operation is used for setting the machine or the system.


- Check the safety of the installation before performing a reference operation.

**NOTE**


For firmware version APP 02.00 and higher, the reference behaviour of the (reference) marker has changed.

If the drive has already reached the (reference) marker, the reference is set directly when leaving the marker (see illustrations below).


Type: marker, reference traverse: positive




type: marker, reference traverse: negative



type: flank, reference traverse: positive




type: flank, reference traverse: negative




When using the limit switches as reference switches, the setting of the reference traverse is without function.

Type: limit switch positive




type: limit switch negative



In the **Start** field, the start of the reference operation is defined:

Powerup	After switching on the voltage supply, a reference operation will automatically be started.
First Start	When starting, the reference operation is performed before the first DDR.
Manual	The reference operation must either be started via the Start reference operation button or via the <i>Reference start</i> via fieldbus. The reference operation may be restarted at any time. For servo drives with absolute encoder or resolver with reference memory, this parameter must be set to Powerup once the reference operation has been completed.
Input	The reference operation is started via a Reference start (via digital input). After the reference point is set, the reference operation may not be repeated.

In the **Reference offset** field, the position offset is entered between zero point and reference point. If the reference offset = 0, both the reference point and the zero point are identical.



NP: zero point RP: reference point x: position

If the value -1 is entered in the **Absolute resolver position** field, the reference point is set when detecting the required flank of the reference switch (marker, flank, or limit switch). For values between 0 and 4095, the reference point is set with regards to the position of the position indicator: This means: when detecting the required flank, the flank is converted to the indicated motor increment. Therefore, the reference point is independent of the switching behaviour of the reference switch. The motor offset must be considered when entering the data since otherwise, the reference point may differ by one motor turn.

If *Start Manual* has been selected, the reference operation may be started via the **Start reference operation** button.

In the **Behaviour after reference** field, the behaviour after setting the reference point is defined:

No operation	The drive stops in the current position after the reference operation.
---------------------	--

 **WARNING**

If a behaviour after reference is selected for the type "None" and the start "Powerup", the drive performs an operation to the position entered in the "Position after ref operation" or the limit switches after switching on.

Approach limit switch positive	After the reference operation, the limit switch plus is approached. If <i>Software limit switch</i> is activated, the <i>Software limit switch plus</i> is approached.
Approach limit switch negative	After the reference operation, the limit switch minus is approached. If <i>Software limit switch</i> is activated, the <i>Software limit switch minus</i> is approached.
Approach position	After the reference operation, the position is approached in the <i>Position after ref operation</i> field.
Next DDR	After the reference operation, the DDR of which the number is entered within the field "Next DDR" will be executed.

In the **Position after ref operation** field, the position is entered which is approached after a reference operation if *Behaviour after ref operation Approach position* is selected.

The **Brake after ref operation** field indicates whether the holding brake is to be activated after the reference operation.

A driving data number is entered into the **Next DDR** field; the actuator is supposed to execute this number after completion of the reference operation.

The **Timeout** field is provided for time setting after which the drive stops with a fault signal if no reference signal could be detected.

6.20.2 Limits group box

The limit values for the reference operation are defined in this group box. The units depend on the motor/ system view and the selected display units.

The slope and the type of the acceleration and deceleration are defined using the **Acceleration value**, **Deceleration value**, **Acceleration ramp**, and **Deceleration ramp** fields. The sinesquare ramp type limits the jolt.

6.20.3 Set reference position group box

In this section, the current position can be set to a certain position value at any time. The new position is entered in the **Reference position** field. Click the **Set reference position** button to immediately accept this data from the drive.

	NOTE When repeating the start of a reference operation, the reference bit is reset. If the reference operation is aborted, the reference bit remains reset.
---	---

6.21 Technological function window

The Technological function node lists the optional technological functions supported by the operating software. The parameters required for the selected technological function may be set in the respective window.

Technological functions have to be activated separately. The activation key can be ordered from GFC AntriebsSysteme.

Enter the activation key in the **Activate technological function** command in the **Tools** menu.



Activation ID

If the Flying referencing technological function has been activated by entering the activation key, this is indicated in the Activation ID field. If the function is not activated, *disabled* is displayed in the indication field

6.21.1 Flying referencing



This function is available for firmware version APP02.00 and operating software version MDAwin 02.00 and higher. Furthermore, a more recent hardware generation of the DAC servo controller is required.



Reference type

Use this field to select the desired reference type.

Flying measuring

If the reference switch is operated, the current actual value of the position controller is provided for further processing by a control system. The control system can determine a possibly existing slack and send new actual values for correction to the drive.

Flying referencing

The Flying measuring and the subsequent correction of the slack is automatically performed by the drive. If the reference switch is operated, the current actual value of the position controller is overwritten by the setpoint of the reference switch.

Active position

In this field, the actual value of the position controller at the time of activation of the reference switch is displayed in increments.

Nominal position

In this field, the position the position controller should have at the time of activation of the reference switch, i.e. the correct position of the reference switch within the system.



The position value can only be entered as increments, i.e. as motor view. The positions are not converted into the system view.

A reference switch has to be connected to **digital input 1** of the MDA to be able to use the Flying referencing technological function (also called Flying measuring). The input is assigned with an interrupt required for this technological function. This input has to be assigned the "Reference" function. Due to the hardware requirements, only MDA for a special hardware version and higher (interrupt capacity of digital input 1) can be used.



Only one reference switch within the system can be evaluated. The reference switch will only be evaluated again after completing the driving data record.

Flying referencing can be applied to the three operation modes: speed, torque, and position control. For speed and torque the actual value is immediately corrected, for position control only if the drive is at a standstill.

6.21.1.1 Flying measuring

Flying measuring can be activated by selecting the reference type. To be able to perform the function correctly, flying measuring has to be active or activated before starting a driving data record.

If the reference switch is passed when processing the driving data record, the actual position determined by the position controller of the motor (resolver or absolute encoder) is displayed. *MDAwin* will only be updated when reading is triggered, i.e. by clicking the Read button.

From the determined actual position and correct position determined for the reference switch within the system, the superordinate control system may calculate the slack and define a new nominal position. To this end, the value has to be entered as nominal position in the driving data record and the driving data record has to be restarted to apply the new nominal position.

6.21.1.2 Flying referencing

During commissioning, the nominal position has to be determined in increments, i.e. the correct position of the reference switch in the system has to be determined. The position can be approached via the manual operation driving data records in push-to-run operation; the read out position can be entered in the nominal position field.

Flying referencing is activated by selecting the reference type. Flying referencing has to be started while the drive is disconnected from the mains and before starting a driving data record to ensure the function is correctly performed. The drive may not remain in position or be processing a driving data record. During flying referencing, driving data records with end-to-end connection cannot be executed.


If the reference switch is passed while processing a driving data record, the actual position determined by the position controller of the motor (resolver or absolute encoder) is indicated. *MDAwin* will only be updated when reading is triggered, i.e. by clicking the Read button. For speed and torque driving data records, this position is directly replaced by the predetermined nominal position.

For positioning driving data records, the nominal position is corrected in the driving data record and the corrected position is approached. The corrected position value (actual value of the position controller) is only applied after terminating the driving data record.

6.21.2 Electric shaft



This function is available for firmware version APP02.00 and operating software version MDAwin 02.00 and higher. In addition, two MDAs with CANopen interface are required.



Operation mode The desired operation mode is set in this field.
Master The drive in this operation mode specifies nominal values.
Slave The drive in this operation mode receives its nominal values from the master

The **Gear factor input** and **Gear factor output** fields are used to set the output speed or the positioning ratio of the master to the slave and are only evaluated in the slave operation mode. In the master operation mode, no entries can be made in these fields.

CAN-ID master The CAN-ID master has to be selected within a range between 265 and 271. The ID is required for the communication between master and slave.

CAN-ID slave The CAN-ID slave has to be selected within a range between 257 and 264. The ID is required for the communication between master and slave.

The setting of the CAN-ID master and the CAN-ID slave have to match both with regards to the master and the slave. Set the baud rate in the "Fieldbus" window to at least 500 kBit/s for both drives to be able to use the technological function. Due to the high baud rates, both drives have to be equipped with a termination resistor.

Timeout This input field is used for setting the bus monitoring.
 The unit to be entered is cycles whereas 1 cycle corresponds to 1 ms.

Sync mode This drop-down box is used to set the behaviour of the slave. The sync mode is only evaluated in the slave operation mode.

Speed The slave synchronises to the speed of the master while observing the selected transmission ratio.

Position The slave synchronises to the position of the master while observing the selected transmission ratio.

Behaviour on error This input field currently has no function.

After programming the drive has been completed, the connection of the *MDAwin* to the drive has to be reset correctly to Online Level 1, since the control change rights have to be transferred to the master when starting the synchronisation.

6.21.2.1 Functional description

The Electric shaft technological function is a synchronous control of two drives. Apart from the synchronous operation of two drives, reduction ratios and therefore mechanic gears can be simulated.

The drives are linked via CAN bus; the communication between the drives is established without any external master. This function is only available for two drives without CANopen interface. Since no CANopen specific operation mode is used, the CANopen mode is no longer available for the two interfaces. Additional CANopen devices can however still be integrated in the network. The bus communication can be considerably impaired due to the high bus load of the electric shaft.

The two drives do not exchange any programming telegrams. The necessary programming has to be performed separately on both drives and has to be synchronised.

A fault within the drive is signalled to the master and leads to a quick stop of the master (and therefore also of the slave). A fault which occurs at the slave has to be acknowledged directly at the slave.

6.21.2.2 Commissioning

The settings described above have to be performed to be able to use the technological function. A start command at the master activates the synchronisation; after successful synchronisation the **Synchronous running** signal is displayed in the **Drive information** window.

After successful synchronisation, a driving data record can be started by means of another, i.e. second start command at the master, and the slave follows the movements of the master in the set Sync mode. All drive tasks performed by the master (individual DDR, end-to-end driving program or manual operation) are synchronously performed by the master.

When using the gear factors ensure that the slave is not operated beyond its physical limits. The gear transmission ratio therefore has to be selected as to ensure that the output speed for the slave does not exceed the set maximum output speed.

6.22 Online monitoring



This function is available for firmware version **APP02.00** and operating software version **MDAwin 02.00** and higher.

Online monitoring is used for recording and graphic representation of nominal and actual values of the servo drives.

Data management and graphic editing is performed using a LabView application. Thereby the read out data is also made available to experienced LabView users and for other LabView functions.

6.22.1 Software installation

If no LabView software packages have been installed on your computer so far, install the LabView- Runtime **LVRunTime.exe** included on the CD. The **MDA_Monitoring.ini** and **MDA_Monitoring.exe** files have to be stored in the same directory as the MDAwin file.

To install LabView- Runtime, you need administrator rights.

6.22.2 Functional description

Use the **Start Monitor** or **Stop Monitor** commands to activate or quit the online monitoring function. If a connection between MDAwin and the drive already exists and if the online monitoring program is then started, monitoring is directly started within the operating software MDAwin even without command selection.



Activation of the online monitoring starts the transmission of status telegrams between drive and MDAwin. Since the telegram sequence is very high due to the required accuracy of the monitoring, the processing of programming or control commands is delayed. This has to be specially observed when using the start and stop functions via MDAwin, since the control of the drive can be considerably delayed.




WARNING

Due to the monitoring function, the transmission of commands via RS232 is delayed. The reaction time of the drive to start and stop commands via MDAwin / RS232 is considerably increased.

→ While using the monitoring the drive should not be controlled via MDAwin.


After activating the monitoring via MDA win, the MDA_Monitoring.exe file has to be started separately. The monitoring program allows to display different nominal and actual values can either be displayed as a line chart or an oscilloscope diagram. The position in increments, the speed in rpm at the motor, the torque in Nm at the motor can be displayed as actual values. The indicated nominal value depends on the controller type set in the active DDR.

Line chart view:



The elements are operating elements of the monitoring program:

Start/ stop	Starts or stops the recording
Commu State	communication status of the connection between MDAwin and the monitoring program
Erfassungszähler	counter of valid and computed telegrams exchanged by MDAwin and the monitoring program
Datenstatus	lights up, when receiving valid telegramms
Triggerauswahl	The trigger selection can only be performed if the recording has been stopped via the start/stop button. Functions of the digital output are available as trigger.
Messkurven löschen	deletes the line chart recorder contents

Oscilloscope view:

Two data lines are shown within the window of the oscilloscope diagram. They can both be selected via channel selection.

The save and load functions are used to save and reopen files with the oscilloscope diagram data view.

7 Multi-turn absolute encoder

This chapter contains important information and special characteristics regarding commissioning and reference operation for drives with multi-turn absolute encoders.

7.1 Basic settings


The following values have to be entered in the Motor transmitter group box in the Hardware window:

Parameter	Value	Note
Position indicator	Absolute encoder	
Pos.ind. resolution	4096	number of inc./turn

7.2 Absolute encoder range

Since the position ranges of the absolute encoder (24bit) and position controller (32bit) differ, you have to ensure before commissioning that the position of the absolute encoder has no zero point/overflow. Refer to Adjustment section.


If the working range of the system is within the multi-turn range of the absolute encoder and the encoder shows no overrun, the position is definite:



Bereich Absolutwertgeber: maximum value range of the absolute encoder

Arbeitsbereich: application values

If the working range includes one or several zero points/overruns of the absolute encoder, the indicated position after a restart of the system may differ from the actual position after a restart of the system.




The zero point is set to position x_1 . The working range (yellow) lies between x_1 and x_3 , within the working range, there is an overrun of the absolute encoder at x_0 . If the drive is switched off and on at position x_2 ; with reference to the absolute encoder, the drive is still at $x_2 = x_2^*$. But the position corresponds absolutely to a working range (orange) between x_1^* and x_3^* .

If the position is changed beyond the working range of the absolute encoder while the voltage is disconnected and if the supply voltage is connected again, a position offset of 2^{24} bit occurs. The user has to ensure that the position of the drive has returned to the working range before switching on the supply voltage again to avoid incorrect positioning.

7.3 Monitoring

When leaving the working range of the absolute encoder, the "AEN range" bit is set. The bit is set in the "Driving data manger" register of the "Drive warning" window as numerical value "16". If the drive is run back to the working range of the absolute encoder, the "AEN" bit is reset.



If a reference bit is set by a reference operation, the "AEN" range bit will be reset and remains reset until the range of the absolute encoder is left again.

The status of the "AEN range" bit is saved to the EEPROM when switching off. If the bit was reset when switching off, the status of the reference bit is always restored when switching on.

If the "AEN bit" is set when switching on, a fault signal (numerical value "256" is set in the driving data manager register of the Drive fault window) is issued since the drive was outside the working range of the absolute encoder when switching off. The reference bit is also reset and a new reference operation has to be performed.

7.4 Adjustment

Before performing the mechanic installation of the servo drive into the application environment, the absolute encoder has to be adjusted. The drive has to be run to the outer (positive or negative) limit of the absolute encoder range:

Run drive with positive (negative) speed control until the "AEN range" bit is set. Then run drive with negative (positive) speed control in the opposite direction, until the "AEN range" bit has just been reset.

On the basis of the set reference position, the AEN working range amounts to less than 4096 motor turns in negative rotation direction if the rotation direction was negative or to less than 4096 motor turns in positive direction if the opposite direction was positive.

Afterwards, the drive can be mechanically installed in the application environment.

7.5 Reference operation

The actual reference operation is performed after the adjustment. For details on the reference operation, please refer to the Reference operation section.

Option: Enter the desired **Reference position** in the Reference position group box and click the **Set reference** button.

The reference position has to be within the multi-turn range of the absolute encoder as determined above.

After the reference bit is active and the absolute position has been adapted to the system, the parameters in the Reference operation window have to be set to the following values:

Type: Reference memory
Start: Powerup

With this setting, the status of the reference bit before switching off the controls is saved to the EEPROM. Each time the drive is restarted, this status is read in again, and the absolute position is taken over from the absolute encoder unless the multi-turn range was left before switching off.

8 Transport and storage

Correct transport, proper storage, mounting and installation, as well as careful commissioning and maintenance are essential to ensure a trouble-free and safe operation.

Do not cover the housing with another layer of paint since the thermal behaviour of the drive would be changed.

- Transport to place of installation in sturdy packing.
- Store in well-ventilated, dry room.
- Protect against floor dampness by storage on a shelf or on a wooden pallet.
- Cover to protect against dust and dirt (plugs must be sealed with protective caps).
- Apply suitable corrosion protection agent to uncoated surfaces.

9 Maintenance

9.1 Maintenance on drives in standard version

The standard version of the Milan Drive Advanced is maintenance-free.

Milan Drive Advanced servo drives are filled with grease for life. Grease change and relubrication are not required.

For an increased ambient temperature and high radial and/or axial force of the bearings, the bearings should be checked at regular intervals and be exchanged in due course, if required.

9.2 Maintenance of the version according to ATEX

	HINWEIS
	Regular inspection and maintenance performed by qualified and trained personnel according to the European standard EN 60079-17 „Inspection and maintenance of electrical installations in hazardous areas“ is required.

Check actuator visually. Ensure that no outside damage or changes are visible. The electric connecting cables must be without damage and wired correctly.

Do a thorough touch-up of possible damage to paint finish to prevent corrosion.

Cable entries, cable glands, plugs, etc. have to be checked for correct tightness and sealing. Observe torques according to manufacturer's details. If required, replace the components. Only use components which have a test certificate.

Check, whether Ex-connections are fastened correctly.

Take care of possible discoloration of the terminals and wires. This would indicate an increased temperature.

For Ex-housings, take care especially of a possible collection of water. This may originate from "breathing" due to severe temperature variations (e.g. change of night and day), from damaged seals etc. Remove any water immediately.

Ensure that all housing covers are handled carefully and that the seals are checked.

All cable and motor protection components have to be checked.

If defects which affect the safety are detected during maintenance, repair measures have to be initiated without delay.

When exchanging parts, seals etc. only original spare parts shall be used.

The motor bearings have to be replaced after 90 % of the standard lifetime. Refer to the technical data sheet. For an increased ambient temperature and high radial and/or axial force of the bearings, the bearings should be checked at regular intervals and be exchanged in due course, if required.

	WARNING
For work carried out in hazardous areas, special regulations (Standard EN 60079-14 and EN 60079-17) must be observed. Work at the open actuator under voltage must only be performed if it is assured that for the duration of the work there is no danger of explosion. Pay attention to additional national regulations.	

10 Disposal and recycling

Servo drives by GFC AntriebsSysteme have an extremely long lifetime. However, they have to be replaced at one point in time.

The drives have a modular design and may therefore easily be disassembled, separated, and sorted according to materials, i.e. electronic scrap, metals, plastics, greases, and oils.

The following generally applies:

Collect greases and oils during disassembly. As a rule, these substances are hazardous to water and must not be released into the environment.

See disassembled material to a sound disposal or to separate recycling according to materials.

Observe the national regulations for waste disposal.

11 Declaration of conformity and declaration of Incorporation



EG-Konformitätserklärung gemäß der Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliederstaaten über die elektromagnetische Verträglichkeit (89/336/EWG) und der Niederspannungsrichtlinie (73/23/EWG)

GFC-Servosysteme „Milan-Drive-Advanced“ der Baureihen:

MDA 35.1
MDA 56.1
MDA 63.1

in serienmäßiger Ausführung sind zum Anbau- bzw. Einbau in Handlinggeräten, Zufuhrsysteme und andere Geräte und Maschinen bestimmt.

Die GFC-AntriebsSysteme GmbH als Inverkehrbringer erklärt hiermit, dass oben genannten Servoantriebssysteme den Anforderungen folgender Richtlinien entsprechen:

- Elektromagnetische Verträglichkeit (EMV) (89/336/EWG)
- Niederspannungsrichtlinie (73/23/EWG)

Zur Beurteilung der Geräte wurden folgende Normen herangezogen:

- a) hinsichtlich elektromagnetischer Verträglichkeit

EN 61800-3:2002

- b) hinsichtlich der Niederspannungsrichtlinie

EN 61800-5-1:2003
EN 60204-1: 1997
EN 50178-1: 1997

GFC AntriebsSysteme GmbH

Grenzstraße 5
01610 Coswig

Telefon: 03523 / 9460
Telefax: 03523 / 74 142
www.gfc-antriebs.de

Coswig 2005-04-26

Jürgen Riester GL

Diese Erklärung beinhaltet keine Zusicherung von Eigenschaften.
Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten.



**Erklärung des Herstellers
gemäß EG – Maschinenrichtlinien 98/37/EG
Artikel 4, Absatz 2 bzw. Anhang II B**

GFC-Servosysteme „Milan-Drive-Advanced“ der Baureihen:

**MDA 35.1
MDA 58.1
MDA 63.1**

in serienmäßiger Ausführung sind zum Anbau - bzw. Einbau in Handlinggeräten, Zufuhrsysteme und andere Geräte und Maschinen bestimmt.

Die GFC-Antriebssysteme als Inverkehrbringer erklärt hiermit, dass bei der Konstruktion der oben genannten Servoantriebssysteme folgende einschlägigen Bestimmungen angewandt wurden:

**EN ISO 12100-1:2004
EN ISO 12100-2:2004
EN 60 204-1:2002**


Die Inbetriebnahme ist solange untersagt, bis sichergestellt wurde, dass die gesamte Maschine, in die MDA-Servoantriebssysteme eingebaut sind, den Bestimmungen der EG-Richtlinie 98/37/EG entspricht.

GFC AntriebsSysteme GmbH

Grenzstraße 5
01610 Coswig

Telefon: 03523 / 9460
Telefax: 03523 / 74 142
www.gfc-antriebe.de

Coswig 2005-04-26


Jürgen Riester GL

11.1 Konformitätserklärung für Antriebe in Ausführung nach ATEX (Option)

EG-Konformitätserklärung gemäß der Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliederstaaten über Explosionsschutzrichtlinie (94/9/EG) die elektromagnetische Verträglichkeit (89/336/EWG) und der Niederspannungsrichtlinie (73/23/EWG)

GFC-Servosysteme „Milan Drive Advanced“ der Baureihen:

MDA 35.1

MDA 56.1

MDA 63.1

In serienmäßiger Ausführung sind zum Anbau bzw. Einbau in Handlinggeräten, Zuführsysteme und andere Geräte und Maschinen bestimmt.

Die GFC-AntriebsSysteme GmbH als Inverkehrbringer erklärt hiermit, dass die oben genannten Servoantriebssysteme den Anforderungen folgender Richtlinien entsprechen:

- Geräte und Schutzsysteme zur bestimmungsgemäßen Verwendung in explosionsgefährdeten Bereichen (94/9/EG) Kategorie II 3D
- Elektromagnetische Verträglichkeit (EMV) (89/336/EWG)
- Niederspannungsrichtlinie (73/23/EWG)

Zur Beurteilung der Geräte wurden folgende Normen herangezogen:


- a) hinsichtlich der Explosionsschutzrichtlinie
 - EN 50281-1-1: 10/1999
 - EN 1127-1: 10/1997
 - EN 13463-1:04/2002
- b) hinsichtlich elektromagnetischer Verträglichkeit
 - EN 61800-3: 2002
- c) hinsichtlich der Niederspannungsrichtlinie
 - EN 61800-5-1: 2003
 - EN 60204-1: 1997
 - EN 50178-1: 1997

GFC AntriebsSysteme GmbH

Grenzstrasse 5
01610 Coswig

Telefon: 03523 / 9460
Telefax: 03523 / 74142
www.gfc-antriebe.de

Coswig 2005-10-21


J. Riester
Geschäftsleitung

Diese Erklärung beinhaltet keine Zusicherung von Eigenschaften.
Die Sicherheitshinweise der mitgelieferten Produktdokumentation sind zu beachten.

12 Literature

12.1 Milan user manuals

1. Short instructions
Order no.: Y004.135
2. User manual RS232 Firmware
Order no.: Y003.804
3. Dimension sheet
Order no.: Y003.805
(2D and 3D-CAD data of the MDA for common CAD systems can be ordered from GFC AntriebsSysteme)
4. Technical data
Order no.: Y003.806
5. Interface description PROFIBUS DP
Order no.: Y004.011
6. Interface description CANopen
Order no.: Y004.013
7. Functional block description S7 functional blocks for Profibus DP
Order no.: Y004.012
8. Functional block description PLC function blocks for CANopen
Order no.: Y004.014
9. Operation instructions Operation box PV 1608
Order no.: Y004.010

13 Appendix

13.1 Trouble shooting

In the following, some fault descriptions and the possible cause of fault is listed.

Faults	Possible cause of fault	Remedy cause of fault as follows
No connection to the drive over RS232 possible	Cable incorrect or defective Cable at motor or PC incorrectly connected Incorrect interface selected No power at the drive	Check cable for correct pin assignment and function Connect cable to X3 at the motor or correct interface at the PC Select the correct interface in the operating software Check power supply and auxiliary voltage
Motor without current	Controller release is missing Stop command is present Mains voltage is missing	Issue RF0 release Deactivate stop command at digital inputs and fieldbus Check DC link circuit in the Actual value window, check voltage supply if required
Motor does not turn	Setpoint is missing Brake does not release Drive is mechanically locked Limit values are incorrect Reference bit is not set (Drive info window)	Specify setpoint in the DDR or externally Check holding brake supply Check drive Check global limit values and limit values in the DDR Check setting in the Reference operation window Check settings in the reference operation window
Motor turns incorrectly	System incorrectly configured GND for analogue input is missing	Check setting in the System window Connect GND
Drive vibrates in the output speed mode	Amplification Kp (P-part) too high Analogue GND missing	Reduce amplification Kp Connect analogue GND
Drive is too soft in the output speed mode	Reset time Tn (I-part) too high Amplification Kp too low	Reduce reset time Tn Increase amplification Kp
Drive oscillates in the output speed mode	Reset time Tn too low Amplification Kp too high	Increase reset time Tn Reduce amplification Kp

Some fault signals and possible fault causes are listed hereafter.

Fault	Possible fault cause	Remedy fault cause
Drive data manager No. 2 “DDR parameter wrong”	Drive generates a fault when starting a DDR: Drive is in end position Software end switch set and calculated target point outside software end switch range. Start of a DDR in wrong Profibus type of duty Start of FDS 0 via Profibus or MDAwin When linking, DDR 0 selected as next DDR	Operation in opposite direction Correct software end switch or target position Set correct type of duty Starting a DDR 1 – 99 Linking a DDR 1 – 99
Drive data manager No. 32 „Drive does not stop after stop command“	Drive does not stop within 2.5 s after stop command Positioning window too small Control parameter setting too limited Ramps and speeds very high for small maximum torque, i.e. high contouring error	Enlarge positioning window Control parameter setting too limited Check operating profile
Motor No. 512 „Fault Power electronics“	Absence of mains voltage Control parameter setting too limited Drive overload	Zwischenkreisspannung im Fenster Istwerte und Sicherung bzw. Versorgungsspannung überprüfen Regelparameter weniger hart einstellen Antriebsauslegung überprüfen
Motor No. 8192 „Output speed fault“	Drive generates a fault when starting a DDR: Speed limit setting too low	Correctly set speed limit in hardware window

13.2 Faults and warnings

13.2.1 Drive fault window

Register	Description
1	Faults Voltage
2	Faults Temperature
3	Faults Motor
4	Faults LocalCAN
5	Faults Fieldbus
6	Faults Driving data record
7	Faults Parameters
8	Faults Logic hardware
9 – 16	Fault registers 09 to 16

Register 1 (voltages)

Bit	Decimal	Description
0	1	Voltage monitoring DC-circuit link UZK < 180V
1	2	Voltage monitoring DC-circuit link UZK < 400V
2	4	Voltage monitoring Brake
3 – 15	> 8	reserved

Register 2 (temperatures)

0	1	Temperature monitoring Motor
1	2	Temperature monitoring Electronics
2	4	Temperature monitoring Power electronics
3	8	Temperature monitoring Ballast resistor
4 – 15	> 16	reserved

Register 3 (motor)

0	1	Resolver signal
1	2	Resolver index
2	4	Encoder signal
3	8	Encoder index
4	16	Loss of Spi synchronisation
5	32	reserved
6	64	reserved
7	128	reserved
8	256	reserved
9	512	Fault Power electronics
10	1024	Motor blocked (during resolver adjustment)
11	2048	Number of pole pairs incorrect
12	4096	Motor incorrectly connected
13	8192	Output speed fault
14	16284	Hardware fault
15	32768	Firmware fault

Register 4 (LocalCAN)

0	1	Connection CAN XC-DSP
1	2	Connection CAN XC-I/OBox
2 – 15	> 4	reserved

Register 5 (fieldbus)

0	1	Connection monitoring via bus
1	2	Fault in the slave drive (for Technological function Electric shaft)
2 – 15	> 4	reserved

Register 6 (driving data manager)

0	1	Reference operation fault
1	2	Process driving data record
2	4	Quickstop is performed
3	8	Drive blocked during driving data record
4	16	Switch-on limit active
5	32	Drive does not stop after stop command
6	64	Positioning commands without set reference
7	128	Analogue value outside the valid range
8	256	Overflow of absolute encoder
9 – 15	> 512	reserved

Register 7 (parameters)

Bit	Decimal	Description
0	1	Fault Motor parameters
1	2	Fault System parameters
2 – 15	> 4	reserved

Register 8 (Logic hardware)

0	1	Fault in the EEPROM
1	2	Fault in the Flash-CRC
2	4	Fault during system start
3 – 15	> 8	reserved

13.2.2 Drive warning window

Register	Description
1	Warnings Voltage
2	Warnings Temperature
3	Warnings Motor
4	Warnings LocalCAN
5	Warnings Fieldbus
6	Warnings Driving data manager
7	Warnings Parameters
8	Warnings Logic hardware
9 – 16	Warning registers 09 to 16

Register 1 (voltages)

Bit	Decimal	Description
0	1	Voltage monitoring DC-circuit link UZK
1	2	Voltage monitoring Brake
2 – 15	> 4	reserved

Register 2 (temperatures)

0	1	Temperature monitoring Motor
1	2	Temperature monitoring Electronics
2	4	Temperature monitoring Power electronics
3	8	Temperature monitoring Ballast resistor
4 – 15	> 16	reserved

Register 3 (motor)

0 – 15	> 1	reserved
--------	-----	----------

Register 4 (LocalCAN)

0	1	Connection CAN XC-DSP
1	2	Connection CAN XC-I/OBox
2 – 15	> 4	reserved

Register 5 (fieldbus)

0	1	Connection monitoring via bus
1 – 15	> 2	reserved

Register 6 (driving data manager)

The alarm signal “limit switch reached” is available from firmware version APP 02.01 and operating software version MDAwin 02.01 and higher.

0	1	Contouring error available
1	2	Global speed limit reached
2	4	Global torque limit reached
3	8	Switch-on limit active
4	16	Overflow of absolute encoder
5	32	Limit switch (positive or negative) reached
6 – 15	> 64	reserved

Register 7 (parameters)

0	1	Warning Motor parameters
1	2	Warning System parameters
2 – 15	> 4	reserved

Register 8 (Logic hardware)

0 – 15	> 1	reserved
--------	-----	----------

13.3 Event buffer assignment list

13.3.1 Class 1: Faults

Number	Register	Designation
337	Voltage	Voltage monitoring DC-circuit link UZK < 180V
338		Voltage monitoring DC-circuit link UZK < 400V
339		Voltage monitoring Brake
353	Temperature	Temperature monitoring Motor
354		Temperature monitoring Electronics
355		Temperature monitoring Power electronics
356		Temperature monitoring Ballast resistor
369	Motor	Motor faults
385	LocalCAN	Connection CAN XC-DSP
386		Connection CAN XC-I/OBox
401	Fieldbus	Connection monitoring via bus
402		Fault in the slave drive (for Technological function Electric shaft)
417	Driving data manager	Reference operation fault
418		Process driving data record
419		Quickstop is performed
420		Drive blocked during driving data record
421		Switch-on limit active
422		Drive does not stop after stop command
423		Positioning commands without set reference
424		Analogue value outside the valid range
425		Overflow of absolute encoder
433	Parameters	Fault Motor parameters
434		Fault System parameters
449	Logic hardware	Fault in the EEPROM
450		Fault in the Flash-CRC
451		Fault during system start

13.3.2 Class 2: Warnings

Number	Register	Designation
65	Voltage	Voltage monitoring DC-circuit link UZK
66		Voltage monitoring Brake
81	Temperature	Temperature monitoring Motor
82		Temperature monitoring Electronics
83		Temperature monitoring Power electronics
84		Temperature monitoring Ballast resistor
85		Derating
97	Motor	
113	Fieldbus	Connection CAN XC-DSP
114		Connection CAN XC-I/OBox
129		Connection monitoring via bus
145	Driving data manager	Contouring error available
146		Global speed limit reached
147		Global torque limit reached
148		Switch-on limit active
149		Overflow of absolute encoder
161	Parameters	Warning Motor parameters
162		Warning System parameters
177	Logic hardware	Fault in the EEPROM
178		Fault in the Flash-CRC
179		Fault during system start

13.3.3 Class 4: Info

Number	Register	Designation
1	Info	Collective warning
2		Collective fault
3		Diving data record active
4		Setpoint reached (type of setpoint depends on the driving data record type)
5		Reference operation active
6		Fieldbus active
7		Control error
8		Intermediate stop during driving data record processing
9		Single step mode active
10		Single step pause active
11		Reference set
17		Command Stop is active
18		Command RF0 is active
19		Command Quick stop is active
20		Synchronous mode active (for technological function Electric Shaft)
33		Limit switch right
34		Limit switch left
35		Drive without power
36		Drive at standstill
37		Brake active
38		Fan active

13.3.4 Class 8: Parameters

Currently, there are no entries for this class.

13.3.5 Class 16: Command

Number	Register	Designation
0		Start reference operation
1		Synchronisation signal active
2		Switch single step mode on/off
3		Execute single step operation
4		Limit switch positive
5		Limit switch negative
6		Switch off motor current
7		Quickstop
8		Enable / disable controller
9		Intermediate stop
10		Start DDR
11		Stop DDR
12		Go to FDS x
13		New nominal speed
14		New nominal torque
15		New nominal position
16		Start reference operation manually
17		Set reference
18		Execute resolver adjustment
19		Reference mark
20		New limit speed (maximum speed)
21		New limit torque (maximum torque)
22		Stop ramp-function generator (freeze output speed)
23		Drive runs at DDR inching 1
24		Drive runs at DDR inching 2
25		Transfer nominal value to DDR
26		Stop signal active/passive
27		Start DDR, no linking
28		Quickstop (without fault signal)
29		Override, set function
30		Override, set value
31		Connect motor to power

13.3.6 Class 32: System

Number	Register	Designation
0		None
1		System start

13.4 Parameter lists

13.4.1 Summary of system units which can be selected and combined

	Unit	
	Round shaft/Modulo	Linear
Temperature		°C
		F
Target time		ms
Torque/force	mNm	N
Position & error		Inc
	U	
	°	
	∠min	
	∠sec	
		m
		dm
		cm
		mm
		µm
Output speed/speed	rpm	
	rps	
	%s	
	%min	
	∠min/min	
	∠min/s	
	∠sec/min	
	∠sec/s	
		m/min
		m/s
		dm/min
		dm/s
		cm/min
		cm/s
		mm/min
		mm/s
Acceleration ramp Deceleration ramp	rpm*s	
	rps*s	
	%min*s	
	%s*s	
	∠min/min*s	
	∠min/s*s	
	∠sec/min*s	
	∠sec/s*s	
		m/min*s
		m/s*s
		dm/min*s
		dm/s*s
		cm/min*s
		cm/s*s
		mm/min*s
		mm/s*s
		µm/min*s
		µm/min*s

13.4.2 Actual values window

Parameters	Unit	Min	Max
Active DDR		0	99
Torque/Force	depending on system type, system conversion, display units, controller type		
Output speed/speed	depending on system type, system conversion, display units, controller type		
Position	depending on system type, system conversion, display units, controller type		
Error	depending on system type, system conversion, display units, controller type		
DC link circuit	V	Display values	
Brake voltage	V		
24 V intern	V		
24 V extern	V		
Temp. Motor	°C / F		
Temp. Electr.	°C / F		
Temp. Power electronics	°C / F		
I ² _t	%	0	100

13.4.3 Drive information window

Group	Parameters
Status	Warning
	Error
	DDR active
	Setpoint
	Ref traverse active
	Fieldbus active
	Intermediate stop
	Single step
	Single step pause
	Ref set
	Cmd Stop
	Cmd QStop
	Cmd RF0
	Ack Stop
	Ack Qstop
	Ack RF0
Collective warning	Voltage
	Temperature
	Motor
	Local CAN
	Fieldbus
	DDR
	Parameters
Collective fault	Voltage
	Temperature
	Motor
	Local CAN
	Fieldbus
	DDR
	Parameters
	Logic hardware
Drive	Limit switch plus
	Limit switch minus
	Drive without power
	Drive at standstill
	Brake active
	Fan active
	Info analogue in1
Status digital inputs	E1
	E2
	E3
	E4
Status digital outputs	A1
	A2
	A3
	A4

13.4.4 Manual operation window

Maximum values group box

Designation/field	Parameters	Unit	Parameters	
			Min	Max
Controller type	None			
	Torque			
	Output speed			
	Absolute position			
	Relative position			
	Modulo position			
	Contouring error			
	Nominal output speed or target position	depending on system type, system conversion, display units, controller type		
	Nominal output speed or nominal speed	depending on system type, system conversion, display units, controller type		
	not activated or target time	ms	depending on system type, system conversion, display units	
	Controller parameter record		1	4
	Max. torque / max. force	mNm / N	0	system-dependent
	Acceleration value	system-dependent	100	$2^{16}-1$
	Deceleration value	system-dependent	100	$2^{16}-1$
Acceleration ramp	Linear			
	Sinesquare			
Deceleration ramp	Linear			
	Sinesquare			
Synchronisation				
Nominal value externally allowed				
Stop with position dwell time				
Stop with brake				
Intermediate stop without current				
with speed limitation				

Features group box

Synchronisation			
Nominal value externally allowed			
Stop with position dwell time			
Stop with brake			
Intermediate stop without current			
with speed limitation			

13.4.5 DDR editor window

Maximum values group box

Designation/field	Parameters	Unit	Parameters	
			Min	Max
Driving data record	DDR no.		1	99
Program identification	Program number		1	99
Controller type	None			
	Torque			
	Output speed			
	Absolute position			
	Relative position			
	Modulo position			
	Contouring error			
	Nominal output speed or nominal position	depending on system type, system conversion, display units, controller type		
	Nominal output speed or nominal speed	depending on system type, system conversion, display units, controller type		
	not activated or target time	ms	depending on system type, system conversion, display units	
	Controller parameter record		1	4
Driving data record linking	None			
	Overhung			
	Maintain position			
	Brake			
	Without power			
	Holding time	ms	0	1000000
	Next DDR		0	99
	Max. torque / max. force	mNm / N	0	system-dependent
	Acceleration value	system-dependent	100	2 ¹⁶ -1
	Deceleration value	system-dependent	100	2 ¹⁶ -1
Acceleration ramp	Linear			
	Sinesquare			
Deceleration ramp	Linear			
	Sinesquare			

Features group box

Synchronisation			activated / not activated
Nominal value externally allowed			activated / not activated
Stop with position dwell time			activated / not activated
Stop with brake			activated / not activated
Intermediate stop without current			activated / not activated
with speed limitation			activated / not activated

13.4.6 Hardware window

Motor data group box

Designation/field	Parameters	Unit	Parameters	
			Min	Max
Motor type			not initialised	
			MES 35-3000	
			MES 56-3000	
			MES 63-3000	
	Max. motor torque	mNm	0	10,000
	Max. motor speed	rpm	0	8,000
Motor pole pairs			not initialised	
			3	
			4	
			5	
			6	
	Current factor		1,000	10,000

Motor transmitter group box

Position indicator			Resolver	
			Absolute encoder	
	Pos.ind. resolution	inc/turn	1	$2^{16}-1$
	Speed limit	1/min	0	8 000
	Motor offset	Inc	-1	$2^{12}-1$
	Motor adjustment field		0	$2^{16}-1$
	Motor adjustment time	ms	0	$2^{16}-1$

Holding brake / Fan group box

Brake			available	not available
	Brake apply time	ms	0	5,000
	Brake release time	ms	0	5,000
Fan			available	not available

Global settings group box

	Max. torque positive	mNm	0	10,000
	Max. torque negative	mNm	0	10,000
	Max. speed positive	rpm	0	8,000
	Max. speed negative	rpm	0	8,000
	Position holding time	ms	0	8,000
I ² t monitoring			None	
			Internal	
			External 100 W	
			External 200 W	
			External 400 W	
Ballast warning			0	$2^{16}-1$
Ballast fault			0	$2^{16}-1$
UZK correction factor			0	1,000

13.4.7 Control loop window

Parameters	Unit	Parameters		Default
		Min	Max	
Field P-amplification		0.001	32	
Field-I reset time	μs	0	$2^{16}-1$	
Torque P-amplification		0.001	$2^{16}-1$	
Torque-I reset time	μs	0	$2^{16}-1$	

13.4.8 Speed position controller window

Parameters	Unit	Parameters		Default
		Min	Max	
Parameter record		1	4	
Output speed P-amplification		0.001	32	
Output speed I-reset time	μs	0	$2^{16}-1$	
Position P-amplification	1/s	0.01	250	
Position pilot control		0	1	
Positioning window	depending on system type, system conversion, display units			
Contouring error window				

13.4.9 System window

Designation/field	Parameters	Unit	Parameters	
			Min	Max
System type	Linear	-	activated / not activated	
	Round shaft/Modulo	-	not activated / activated	

Motor primary gear group box

	Inversion of direction gear	-	activated	not activated
--	-----------------------------	---	-----------	---------------

Gear factor group box

	Gear factor input	-	0.01	100
	Gear factor output	-	0.01	100
	Display box i	-	0.0001 ... 10000	

Software limit switches group box

Software limit switch	Negative	-	depending on system type, system conversion, display units	
-----------------------	----------	---	--	--

System conversion group box

Inversion of direction system		-	activated	not activated
Conversion factor	Primary movement	-	1	65,000
	Secondary movement	-	1	65,000
Primary conversion parameters	Motor turn	turns		
	Gear rotation	turns		
	Increments	inc		
Secondary conversion parameters (System type Round shaft/modulo)	Turn	turns		
	°C	∠°C		
	Minute	∠Min		
	Second	∠Sec		
Secondary conversion parameters (System type Linear)	m	m		
	dm	dm		
	cm	cm		
	mm	mm		
	µm	µm		

Display units group box

Time	Second	sec		
	Min	min		
Temperature	°Celsius	°C		
	Fahrenheit	°F		
Position (System type Round shaft/Modulo)	Turn	1		
	°C	∠		
	Minute	∠		
	Second	∠		
Position (System type Linear)	m	m		
	dm	dm		
	cm	cm		
	mm	mm		
	µm	µm		

13.4.10 I/O drive window

Digital input group box

Designation/field	Parameters	Parameters	
		Min	Max
	Input number	1	4
Module address		fixed	
Input number		fixed	
high active		activated / not activated	
DDR dependent		activated / not activated	
Function	None		
	Synchronisation		
	Go to DDR(x)		
	Intermediate stop		
	Single step mode		
	Reference		
	Reference start		
	Start/ stop		
	Limit switch negative		
	Limit switch positive		
	Controller enable RF0		
	Quickstop		
	Power amplifier off		
	Start		
	Stop		
	Teach in		
	Ack fault		
	Reference set manually		
	DDR no.	1	99

Digital output group box

	Output number	1	4
Module address		fixed	
Output number		fixed	
high active		activated / not activated	
DDR dependent		activated / not activated	
Function	None		
	Collective warning		
	Collective fault		
	DDR active		
	Setpoint reached		
	Reference operation		
	Fieldbus active		
	Control error		
	Intermediate stop		
	Single step mode		
	Single step pause		
	Reference set		
	Limit switch positive		
	Limit switch negative		
	Drive without power		
	Drive at standstill		
	Ack Quick stop		
	Ack Stop		
	Ack RF0 stop		

Analogue input group box

Designation/field	Parameters	Unit	Parameters	
			Min	Max
Module address			Interface	
Input number			1	
Inverse			activated / not activated	
Fault range			activated / not activated	
Function	None			
	Output speed setpoint			
	Torque setpoint			
	Max output speed			
	Max. torque			
	Nominal position value			
Function value min.		depending on the selected function: rpm / mNm	-2 ¹⁵	2 ¹⁵ -1
Function value max.			-2 ¹⁵	2 ¹⁵ -1
Interface value min.		V	-10	10
Interface value max.		V	-10	10
Input type			-10V ... +10V	

13.4.11 Reference operation window

Configuration group box




Designation/field	Parameters	Unit	Parameters	
			Min	Max
Type	None			
	Marker			
	Flank			
	Limit switch positive			
	Limit switch negative			
	Block plus			
	Block minus			
	Reference memory			
Start	Power up			
	First start			
	Manual			
	Input			
Reference traverse	Positive			
	Negative			
	Reference offset	system-dependent	-2^{31}	$2^{31}-1$
	Absolute resolver position	inc	-1	$2^{12}-1$
Behaviour after reference	No operation			
	Approach limit switch positive			
	Approach limit switch negative			
	Approach position			
Position after ref operation		system-dependent	-2^{31}	$2^{31}-1$
Brake after ref operation	No			
	Yes			
Acceleration ramp	Linear			
	Sinesquare			
	Acceleration	system-dependent	100	$2^{16}-1$
Deceleration ramp	Linear			
	Sinesquare			
	Deceleration	system-dependent	100	$2^{16}-1$
	Output speed/speed	system-dependent	system-dependent	
	Torque/Force	system-dependent	system-dependent	
	Reference position	system-dependent	-2^{31}	$2^{31}-1$

Maximum values group box

Acceleration ramp	Linear			
	Sinesquare			
	Acceleration	system-dependent	100	$2^{16}-1$
Deceleration ramp	Linear			
	Sinesquare			
	Deceleration	system-dependent	100	$2^{16}-1$
	Output speed/speed	system-dependent	system-dependent	
	Torque/Force	system-dependent	system-dependent	

Set reference position group box

	Reference position	system-dependent	-2^{31}	$2^{31}-1$
--	--------------------	------------------	-----------	------------



GFC

Grenzstrasse 5
01640 Coswig
Tel +49 (0) 3523 94-60
Fax +49 (0) 3523 74142
gfc-antriebe@gfc-antriebe.de

Daimlerstrasse 9
73760 Ostfildern
Tel +49 (0) 711 34803 0
Fax +49 (0) 711 34803 3034
riester@wof.auma.com