

UNDERWATER FISHING CAMERA

USER MANUAL



Read this manual carefully before operating
Please recharge the battery before your first time use

Contents

Warning and Precaution-----	2
Introduction -----	2
Connection -----	6
Installation of Float and Fishhook -----	7
Accessories -----	8
Specification -----	9

Warning and Precaution

Warning


Please use the adaptor together with the product only! We are not responsible for the problem caused by any other adaptor

Precaution

1. A good image is not available when camera just opposite to the sun, also for safety do not put the camera under the blazing sunshine for quite a long time ;
2. Put the camera at a appropriate position for a good image;
3. To keep it well-preserved, please wash the camera and cable by soap or warm water after using;
4. Warranty is not available if the unit being opened;

Introduction

The model without sun-visor



① V1/V2 ②  ③ MENU ④ - ⑤ + ⑥ 

V1/V2: To change the mode between 16:9 and 4:3 on screen display;

↻ : To change the direction of the image shows on the LCD screen, totally there are 4 directions, to have the correct display on it;

MENU: To access the settings menu of Bright, Contrast, Color, Mode, TCON, Language, and Reset;

- & + : To decrease or increase the numerical value of the settings;

⏻ : To power on & off the LCD screen;

DVR OPERATION

(this operation only available when the unit with DVR function)

Before the operation of the DVR function, make sure the unit already has the SD card in it. Press the button on the left side of the monitor to check the SD card, see picture as below:

Press this button to
release the monitor

Insert the SD card here



Monitor with DVR function



- ① REC/-
- ② PLAY/+
- ③ MENU/EXIT
- ④ >
- ⑤ <
- ⑥ ⏻

Operation of DVR

1. Settings: Press MENU button to access the settings, and press it again to change the different menu of settings. Press the > & < buttons to change the items under the each menu, and press PLAY to enter into the settings of the each item. The REC/- & PLAY/+ buttons are to decrease & increase the numerical value of settings. In settings of Time & Date, press PLAY to enter into the settings, then press the > & < buttons to change the value of the time & date;
2. Video Recording: Press REC to record the video, and press it again to finish the recording;
3. Play the Video: Press button of PLAY to play the recorded video continuously, and press it pause. Press > & < buttons to display the next and previous recorded video;

4. Take & Play the Picture: Press > button to take the picture. Press < button to display the pictures taken by the camera, and press > & < buttons to display the next and previous pictures;

NOTES:

1. After insert a new SD card or when the SD card has problem, press the button of REC, the unit will check and display whether formatting the SD card, press the button of > & < to select Yes or No, then press MENU to confirm the selection;
2. Time and date will display at the bottom right corner all the time when the monitor is power on;
3. The button of MENU is also to exit in any other mode

The model with Sun-visor(this model don't support DVR function)



1. Mirror: To change the direction of the image shows on the LCD screen, total 4 directions, to have the correct display on it;
2. To change the mode between 16:9 and 4:3 on screen display;
3. Menu: To access the settings menu(Bright, Contrast, Color, Mode, TCON, Language, and Reset);
4. V-: Decrease the numerical value of settings;
5. V+: Increase the numerical value of settings;
6. POWER: Power on & off the monitor LCD screen

Connection


Firstly connect the battery to the power input cable from the monitor, then connect the power output cable & Video input connectors from the monitor with the camera. See picture as below.



Installation of the Float, and Fishhook


Float

Firstly use a fishing line to fasten the float across the hole on top of it, the length of the fishing line is according to your own choice. And then select an appropriate place on the wire of the camera to fasten the float. See picture as below



Fishhook

1. Connection in series: Normally fix 2pcs or at most 3pcs fishhook on the fishing line in a line, and each at 5cm distance, which can make sure all are clear when show on screen. The distance of the Lead can be a litter longer than the last fish hook on the line. See picture as below



2. Connection in parallel: normally fix 2pcs fishhook just under the camera, the length of the fishing line is according to the clarity of the water. Make sure to fix one fishhook on the loop to avoid the mixing with another one. See picture as below



Notice: DO NOT fix the fishing line of the fishhook on the wire of the camera, which can destroy it. Make sure to fix the fishing line on the groove part at the end of the camera body. See picture at side



Accessories

Camera with wire and reel -----	1pcs
Lithium Battery pack -----	1pcs
Charger -----	1pcs
Float -----	1pcs
User manual -----	1pcs
Metal clip -----	8pcs(2 sets)

Specification

Monitor

Screen size: 7" Digital TFT Screen

TFT Resolution: 800*480

Language: English

Power supply: DC 12V

Battery: 4500 mAh Lithium Battery pack

Battery working time: 9-12 hours

Working Temp.: -20 ~ 60°C

Storage Temp.: -30 ~ 70°C

Camera

Lens: COLOR CMOS / CCD, HD 800 TV lines

Focus: 3.6 or 4.0mm

Visible distance (clear water): 1- 3 m

Working Temp.: -20 ~ 60°C

Storage Temp.: -30 ~ 70°C