




User manual

ADMA

Version 2x.6.1.4

Hardware V. 2.x / Firmware v.2x.6.0 and higher



**GeneSys Elektronik GmbH
Offenburg**

Date: March 2009



Note

GENESYS ELEKTRONIK strives to maximize the accuracy of all its data and specifications, but cannot rule out the possibility of errors and reserves the right to future modifications without any prior notice.

GENESYS ELEKTRONIK is not obliged to maintain secrecy over any received material or other information in the absence of any corresponding agreements made with GENESYS prior to submission of such information.

GENESYS will gladly respond to enquiries and provide product details.

Copyright

Copyright © 2006 GENESYS ELEKTRONIK GmbH. All rights reserved.

This entire user manual, or excerpts thereof, must not be reproduced, stored or transmitted in any manner – electronically, mechanically or otherwise – without the prior approval of GENESYS ELEKTRONIK GmbH.

Windows is a registered trademark of Microsoft Corporation.

DIAdem is a registered trademark of National Instruments.

Revision

Document revision 2x.6.1.4

Date: March 2009

Contact

GeneSys Elektronik GmbH

In der Spöck 10

D-77656 Offenburg

Phone: 0049-781-969279-30

Fax: 0049-781-969279-11

www.genesys-offenburg.de



Table of contents

1.	Introduction	5
2.	Scope of delivery	5
2.1.	ADMA only	5
2.2.	ADMA with internal / external GPS receiver	6
2.3.	ADMA with a GPS receiver and GPS base station	7
3.	ADMA laboratory bench testing	9
3.1.	General information.....	9
3.2.	Setup and cabling.....	9
3.3.	Modifying the ADMA's configuration.....	10
3.3.1.	Handling of the ADMA System Software (Help).....	10
3.3.2.	Loading configuration from the ADMA	11
3.3.3.	Configuring measurement data transmission via the COM interface	12
3.3.4.	Selection of data packets to be transmitted	13
3.3.5.	Auxiliary systems.....	14
3.3.6.	Parameter	15
3.3.7.	Transmitting modified settings to ADMA	16
3.4.	Starting a measurement.....	17
3.4.1.	Data recording – principle of operation	20
3.4.2.	Standard recording.....	21
3.4.3.	Sequential recording.....	21
3.5.	Static test.....	22
3.5.1.	Transient condition of the <i>Kalman filter</i>	22
3.5.2.	Checking the system status.....	22
3.5.3.	Checking displayed orientation.....	23
3.5.4.	Checking displayed rotational speeds.....	24
3.5.5.	Checking the displayed accelerations.....	25
3.5.6.	Stopping a measurement	25
3.6.	Dynamic test.....	26
3.6.1.	Test procedure and data display	26
3.6.2.	Checking the rotational speeds.....	26
3.6.3.	Checking accelerations	27
4.	Installation and cabling inside the vehicle	28
4.1.	Operational configurations	28
4.2.	Point of installation.....	29
4.2.1.	ADMA.....	29
4.2.2.	External speed measuring system	29
4.2.3.	GPS antenna	29
4.2.4.	Modem and modem antenna	29
4.3.	Cabling	30
4.3.1.	ADMA in stand-alone mode (minimal configuration)	30
4.3.2.	ADMA in stand-alone mode - optional connections	30
4.3.3.	ADMA and external speed measurement.....	30
4.3.4.	ADMA and GPS.....	31
4.3.5.	ADMA and DGPS with a separate base station	32
5.	Setting up the ADMA in the vehicle	33
5.1.	Configuration of the external velocity.....	33
5.2.	Satellite based GPS correction data.....	34
5.3.	Modify threshold for AutoInit function and GPS-course	35
5.4.	Modify threshold for standstill detection	36
5.4.1.	Max. turn rate at standstill.....	37
5.4.2.	Max. velocity at standstill	37
5.5.	Modify thresholds for quality.....	38



5.5.1.	Threshold for position quality.....	39
5.5.2.	Threshold for Tilt quality.....	39
5.5.3.	Enter geo. latitude and geo. longitude.....	39
5.6.	Compensating an ADMA misalignment.....	40
5.6.1.	ADMA misalignment.....	40
5.6.2.	Sequence of ADMA misalignment angle compensation.....	40
5.6.3.	Horizontal compensation of a ADMA misalignment.....	40
5.6.4.	Compensation of ADMA's vertical axis misalignment.....	41
5.6.5.	Compensation of vertical-axis misalignment of a 2-axis speed sensor.....	41
5.7.	Compensating the installation position.....	42
5.7.1.	Virtual measuring point (point of interest).....	44
5.7.2.	External speed measuring system.....	44
5.7.3.	GPS antenna.....	44
6.	Configuring ADMA's measurement mode.....	45
6.1.	System settings.....	45
6.2.	Starting a measurement.....	45
6.2.1.	<i>Start measurement</i> in the ADMA System Software.....	45
6.2.2.	<i>Remote Start</i> in the ADMA System Software.....	45
6.2.3.	Autostart mode.....	46
6.2.4.	Start a measurement via a user specific tool.....	46
6.2.5.	Start course.....	46
6.2.6.	Autolnit function (yaw angle init).....	46
6.2.7.	Pre-alignment.....	47
6.2.8.	Transient phase of the Kalman filter.....	47
7.	ABD Steering Robot (HW 2.2 and higher).....	48
7.1.	ADMA-configuration for ABD-steering robot.....	48
7.2.	Measurement.....	49
8.	ADMA – firmware download.....	50
8.1.	General.....	50
8.2.	Firmware / System Software – Compatibility.....	50
8.3.	Handling Ini-files created by older System Software versions.....	50
8.4.	Download ADMA firmware.....	51



1. Introduction

This user manual serves as an aid in commissioning the ADMA gyro system. The first part of the manual describes a routine for testing whether the ADMA gyro system's inertial sensors are operating without error. This function test is also a good way to become familiar with ADMA and to gain experience in setting up the ADMA. The second part of the manual describes a typical configuration of a test vehicle, including auxiliary sensors such as an external speed measurement system or a GPS.

2. Scope of delivery

2.1. ADMA only

- The ADMA module
- A supply cable designated ADMA-Power, colour code red
- A communication cable designated ADMA-COM, colour code blue
- A communication cable designated ADMA-CAN, colour code green
- ADMA Download – cable, colour code white
- The configuration tool designated ADMA System Software
- Documentation (User manual, Technical Documentation and ADMA System Software)
- Transport case

Optional items:

HW 2.2 and higher versions

- Signal-In-cable, colour code orange
- Signal-Out-cable, colour code yellow
- ADMA-Speed-cable, colour code grey
- Rescue case with replacement cable and download-software

HW 2.1

- Event-In 1 - cable, colour code orange
- Event-In 2 - cable, colour code orange
- Sync Out - cable, colour code yellow
- Error Out – cable, colour code black
- Aux-Out – cable, colour code black
- ADMA Speed – cable, colour code grey
- Rescue case with replacement cable and download-software



2.2. ADMA with internal / external GPS receiver

- The ADMA or ADMA-G module
- A supply cable designated ADMA-DC In, colour code red
- A communication cable designated ADMA-COM, colour code blue
- A communication cable designated ADMA-CAN, colour code green
- A ADMA Download – cable designated *Prog*, colour code white with programming adapter
- The configuration tool designated ADMA System Software
- Documentation (User manual, Technical Documentation and ADMA System Software)
- Transport case for ADMA or ADMA-G
- GPS receiver (only by ADMA with external GPS-Receiver)
- GPS supply cable (only by ADMA with external GPS-Receiver)
- GPS communication cable (only by ADMA with external GPS-Receiver), colour code brown
- GPS rover antenna with cable (in case ADMA-G with, in case ADMA without, colour code brown)
- Magnetic base for GPS rover antenna
- Documentation (GPS receiver)
- Transport case for GPS-Rover

Optional items:

HW 2.2 and higher versions

- Signal-In-cable, colour code orange
- Signal-Out-cable, colour code yellow
- ADMA-Speed-cable, colour code grey
- Radio modem or GSM modem
- Radio/ GSM modem antenna with magnetic base and antenna cable
- ADMA-G modem connection cable, colour code brown (only with ADMA-G with internal GPS)
- GPS modem connection cable (only with ADMA with external GPS Receiver)
- Receiver enabling for WAAS
- Rescue case with replacement cable and download-software

HW 2.1

- Event-In 1 - cable, colour code orange
- Event-In 2 - cable, colour code orange
- Sync Out - cable, colour code yellow
- Error Out – cable, colour code black
- Aux-Out – cable, colour code black
- ADMA Speed – cable, colour code grey
- Radio / GSM modem
- Radio / GSM modem antenna with magnetic base and antenna cable
- ADMA-G modem connection cable, colour code brown (only with ADMA-G with internal GPS)
- GPS modem connection cable (only with ADMA with external GPS)
- Receiver enabling for WAAS
- Rescue case with replacement cable and download-software



2.3. ADMA with a GPS receiver and GPS base station

In the base station the GPS receiver, wireless / GSM modem and associated cables are integrated into a housing. The antenna, communication and supply cables need simply to be plugged into the external connectors provided for this purpose.

- The ADMA or ADMA-G module
- A supply cable designated *ADMA-DC In*, colour code red
- A communication cable designated *ADMA-COM*, colour code blue
- A communication cable designated *ADMA-CAN*, colour code green
- The configuration tool designated *ADMA System Software*
- ADMA Download – cable designated *ProgSys I*, colour code white with programming adapter
- Documentation (User manual, Technical Documentation and ADMA System Software)
- Transport case for ADMA or ADMA-G
- GPS receiver (only with ADMA with external GPS-Receiver)
- GPS supply cable (only with ADMA with external GPS-Receiver)
- GPS communication cable (only with ADMA with external GPS-Receiver), colour code brown
- GPS rover antenna with cable (in case ADMA-G with, in case ADMA without, colour code brown)
- Magnetic base for GPS rover antenna with assembly adapter
- Documentation (GPS receiver)
- Transport case for GPS-Rover
- GPS base receiver integrated into a housing
- GPS base supply cable
- GPS base communication cable
- GPS base antenna and cable
- Wireless / GSM modem integrated into a housing
- Wireless / GSM modem antenna and antenna cable
- Connection cable from GPS base to Wireless/GSM modem
- Wireless/GSM modem power supply unit 220V
- Tripods for GPS base antenna and Wireless/GSM modem antenna
- Mounting structure for GPS base antenna and Wireless/GSM modem antenna
- Documentation (on the GPS receiver and GPS control terminal)
- Transport case for GPS base



Optional items:

HW 2.2 and higher versions

- Event-In 1 cable, colour code orange
- Event-In 2 cable, colour code yellow
- ADMA Speed – cable, colour code grey
- Radio / GSM modem
- Radio / GSM modem
- ADMA-G modem connection cable, colour code brown (only with ADMA with internal GPS)
- GPS modem connection cable (only with ADMA with external GPS)
- Long-wave receiver for DGPS correction data
- Power regeneration box 7...34 V
- Rescue case with replacement cable and download software

HW 2.1

- Event-In 1 - cable, colour code orange
- Event-In 2 - cable, colour code orange
- Sync Out - cable, colour code yellow
- Error Out – cable, colour code black
- Aux-Out – cable, colour code black
- ADMA Speed – cable, colour code grey
- Wireless / GSM modem
- Wireless / GSM modem antenna with magnetic base and antenna cable
- ADMA-G modem connection cable, colour code brown (only with ADMA-G with internal GPS)
- GPS modem connection cable (only with ADMA with external GPS)
- Power regeneration box 7 .. 34 Volt
- Rescue case with replacement cable and download-software



3. ADMA laboratory bench testing

3.1. General information

The routine described below is intended to test the functionality of the gyro system's inertial sensors, i.e. the accelerometers and gyroscopes. This function test is also a good way to become familiar with the ADMA and to gain experience in setting up the ADMA.

3.2. Setup and cabling

The following components should be prepared for the function test:

- ADMA
- *ADMA-Power* supply cable
- *ADMA-COM* communication cable
- A PC / laptop with the *ADMA System Software*

Connect the *ADMA-Power* cable's red-coded Lemo-plug to the *DC In* ADMA socket and turn on the power supply. Depending on system design, the nominal supply is 12, 24 or 42 VDC. The *DC In* LED should come on as a result.

Afterward, connect the *ADMA-COM* communication cable's blue-coded Lemo-plug to the *COM* ADMA-socket and the other end of the cable to the *COM* interface of your measurement data acquisition device (usually a PC or laptop). These connections are also depicted in the diagram below.




Figure 1 Setup an cabling



3.3. Modifying the ADMA's configuration

3.3.1. Handling of the ADMA System Software (Help)

For a better usability of the ADMA System Software, an interactive help has been implemented. With each parameter available in the configuration mode a hint will be displayed, and, if applicable, an image, to assure that the most important information are available for the user.

To have the parameter hint displayed, set the focus to the appropriate control element. In case of pure keyboard editing, you can tab (shift+tab) through the control elements. In case of option control elements simply use the arrow keys.

If you prefer working with a mouse or touchpad, the focus can be set with a right button click. This only displays the hint of an option control element or a checkbox, thus having focus, but not changing its state. To activate or deactivate these control elements please use the left mouse button.

If the displayed information isn't sufficient, you can obtain further information by clicking on the *Help*-button on the very bottom of the window to open the *Technical documentation*. Please note, that a PDF-reader has to be installed.

To make fast and efficient working with ADMA System Software possible, the most important functions are available via *Hotkeys*. An overview listing all preset hotkeys is given at the main menu's item *Hotkeys*. Please note, that the Hotkeys are not available all the time.



3.3.2. Loading configuration from the ADMA

Certain settings need to be enabled in order to conduct the function test. For this purpose, it is necessary to check and possibly modify the configuration saved in the ADMA system. To view and change these configuration parameters, start the *ADMA System Software* and select the menu option *Configuration*.




Figure 2 Menu of the ADMA System Software

The following dialog will open, where you can choose the source to load the configuration data from.

For function testing the settings should be loaded from the ADMA. Please choose the option *Load settings from ADMA* and confirm with the button *Load / Generate settings*.




Figure 3 Dialog: Load configuration

The ADMA system software then starts to read out the ADMA's configuration data. Once this process is complete, the loaded data is displayed.



3.3.3. Configuring measurement data transmission via the COM interface

The dialog Data Link appears. For testing, please click on the COM option.

This sets up the ADMA to transmit the data via the COM port. The ADMA System Software is capable of receiving the data via the COM port, where the data will be displayed, and if required, stored.




Figure 4 Dialog: Data Link



3.3.4. Selection of data packets to be transmitted

The Data dialog is used to individually select the data packets to be transmitted by the ADMA. Data packets which are not required can be deactivated in order to reduce the transmission data volume.

The following data packets need to be selected for the function test:

- Rates (Body)
- Rates (Horizontal)
- Acceleration (Body)
- Acceleration (Horizontal)
- Tilt / Heading




Figure 5 Dialog: Data

With this dialog other settings can be changed such as the *Data coordinate output format*, the *Update frequency* and the *Autostart* mode.

The following settings are needed for the function test:

- Deactivate the *DIN 70000* option in the field labelled *Data coordinate output system*
- Set the *Update frequency* to 50 Hz (upper limit for most PCs with COM data transfer)
- Please deactivate the *Autostart* option



3.3.5. Auxiliary systems

This dialog is used to specify parameters related to auxiliary systems such as speed measurement systems and GPS receivers.

For the function test, it is necessary to deactivate all auxiliary systems as described below:

- Select the *No GPS* option from the *GPS Model* drop-down menu in the field labelled *GPS*
- Deactivate the *x-Signal active* option in the field labelled *Velocity*




Figure 6 Dialog: Auxiliary Systems



3.3.6. Parameter

The dialog *Parameter* is used to specify the system behaviour. For the function test only the parameter *Prealignment* is important. Please enable prealignment and specify a duration of 10 seconds.




Figure 7 Dialog: Parameters



3.3.7. Transmitting modified settings to ADMA

The altered settings now need to be transmitted to the ADMA. For this purpose, click in the left frame the *Save / Exit configuration* button.

The following dialog *Save configuration* will open with different options to save the altered settings.

Please note, that exiting the configuration modus without saving is possible too. Please select the option *Save settings in ADMA* and confirm with the *Save / Exit configuration mode –* button.

This commences data transmission.




Figure 8 Dialog: Save / Exit configuration

If you want to save changed settings to the ADMA, a password has to be entered. Default password is *adma*. To change the password, use menu *File -> change password*.

The modified configuration can be saved for further tests on the hard disk. For this purpose, choose the option *Save settings in ini-file*.

If you want to save the altered configuration both in the ADMA and in ini-file please select the option *Save settings in ADMA and in ini-file*.

After choosing an option and confirming with the button *Save / Exit configuration* the configuration mode will be closed and the program will return to the main menu.



3.4. Starting a measurement

To start a measurement, select *Data Acquisition – Start Measurement* from the ADMA System Software's main menu.



Figure 9 Start Measurement item in main menu

This invokes the window shown below:




Figure 10 Dialog: ADMA Measurement data

There are two data acquisition modes for saving data available:

- Single data set saving
- Sequential data set saving

Sequential data saving can be enabled/disabled by using the checkbox in the lower left corner of the window. For first tests we recommend disabling sequential data saving.



After clicking the ADMA-Start button, the following dialog is displayed. You can enter:

- Start course [deg] and
- Pre-alignment [sec]

Start parameter COM

Start Course: [deg] 0

Prealignment: [sec] 10

OK

Abbrechen

Figure 11 Dialog: Start parameter for Measurement

On requirement these two parameters can be changed. After confirming the entries with *OK* the measurement starts.

Because prealignment has been activated, the initial display consists of the status and selected, reset data packets. Prealignment is indicated in the system status field by a corresponding flag, together with the *Count* variable which indicates the time remaining to the end of the pre-alignment process.

Important --- do not move ADMA while prealignment is in progress!



Pre-alignment in progress is indicated as shown below.

The screenshot shows the 'ADMA Measurement data' dialog box. At the top, there are two hex data tables. The first table shows 'Status' with values 0A, 00, 30, 01. The second table shows 'Error' with values 00, 00, 00, 00. A red circle highlights the number '10' in the 'Size per step' field. Another red circle highlights the 'Tilt-Course' table, which contains the following data:

Tilt-Course	Roll [deg]	Pitch [deg]	Yaw [deg]	COG [deg]
Roll [deg]	0.00			
Pitch [deg]		0.00		
Yaw [deg]			0.00	
COG [deg]				0.00

Other data tables visible include Rates, Acceleration, External velocity, Miscellaneous, Triggers, System data, GPS-Position, GPS-Velocity, GPS-Errors, Height, Tilt-Course, GPS Aux, Inertial pos., Inertial vel., and Inertial Errors. At the bottom, there are control buttons for 'ADMA' (Start, Stop, ...running) and 'Record' (Start, Pause, Stop, ...recording), along with 'Help' and 'Close' buttons.

Figure 12 Dialog: Measurement in prealignment mode

Once pre-alignment is complete, the ADMA switches automatically to the measurement mode and starts to transmit current measurement data.

Important --- The Kalman filter will need some time to settle.



3.4.1. Data recording – principle of operation

The control buttons for starting/stopping data acquisition is separated into two groups:

- ADMA
- Recording

▪ Group ADMA

With the two buttons *Start* and *Stop* the ADMA can be put into or set back from data acquisition operation.

This is also visualised by the status led to the right of the two buttons.

- green -> running (data acquisition active, data is transferred)
- red -> stopped (data acquisition stopped, no data transfer)

Please note, that stopping the data acquisition will set the ADMA back to initial condition, and the settled state of the Kalman filter will be lost.

▪ Group Record

The buttons of this group control the start of data recording, pausing and stopping, and are equivalent to an audio recorder. Pressing the button *Start* will start saving data to the hard disk, while *Pause* will temporarily halt recording, until *Pause* is pressed again. In this case the ADMA System Software will continue to save data in the same data file.

Pressing *Stop* will end recording, leaving you with two choices, which are saving the data file to a location and with a file name to your choice or discard the recorded data.




Figure 13 Dialog: Record Stop

A new recording can now be started by pressing the *Start* button again.

We have also implemented a status visualisation with a led for the group *Recording* to the right of the control buttons.

- green -> running (received data is saved)
- red -> stopped (no data being saved)



3.4.2. Standard recording

If the checkbox *Sequential data saving* is disabled, data recording is in standard mode and handling is like described above.

Please note that if the data record is to be saved, this data will be converted to ASCII first, and is then saved in a separate file.

3.4.3. Sequential recording

Checking *Sequential data saving* will allow you to save several, individual data records with less handling afford. At start you will be asked to enter directory and filename for the sequential data records, and then proceed recording as usual. With each single data recording you will have the choice to either save or discard the data.

Saved recordings will not be converted immediately, priority is to save the recording sequence, where each filename will have a sequence number amended, like :

- Filename_001.bin
- Filename_002.bin
-
- Filename_XXX.bin

If sequential recording is ended, all records will be converted to ASCII and saved in separate *.prn files




Figure 14 Sequential measurement mode: Continue / Terminate serial



3.5. Static test

3.5.1. Transient condition of the Kalman filter

The Kalman filter of the ADMA can be active without auxiliary systems like an external velocity or a (D)GPS (in standstill). It is possible to experience transient effects in the first few minutes (<120 seconds). After this transient phase stable values are shown. This transient phenomenon in the beginning of a initiated measurement is inherent with the Kalman filter's design and can only be temporal compressed, however not eliminated.

3.5.2. Checking the system status

The system status indicates the system's states as well as elementary errors. During correct measurement, this status should indicate AHRS mode* (status byte 1, bit 5 = 0x20).

Furthermore, the Count status variable is incremented by one each time a new data record is transmitted (status byte 3). Once the maximum displayable figure of 255 has been reached, the transmission count is resumed from 0.

The screenshot shows the 'ADMA Measurement data' dialog box. At the top, there are two tables: 'Status' and 'Error', both circled in red. The 'Status' table has columns for Byte 3, Byte 2, Byte 1, and Byte 0, with values DB, 00, 20, and 11 respectively. The 'Error' table has columns for Byte 3, Byte 2, Byte 1, and Byte 0, with values 00, 00, 00, and 00 respectively. The dialog contains numerous other data panels such as Rates, Acceleration, GPS-Position, GPS-Velocity, GPS-Errors, Inertial pos., Inertial vel., Inertial Errors, Height, Tilt-Course, GPS Aux..., Triggers, and System data. At the bottom, there are control buttons for 'Start', 'Stop', 'Pause', and 'Record', along with a 'Help' button and a 'Close' button.

Figure 15 Dialog: Measurement - Check of system status



If an error bit is set (error bytes 0 and 1), measurements are no longer valid. In this case, please contact our service department.

*

- AHRS = Attitude and Heading Reference System
- AHRS-mode = Only solid angles are indicated (no position or speed)

3.5.3. Checking displayed orientation

When the system is at rest and nearly horizontal, the following *Tilt/Heading* data should be indicated:

- Roll $\approx 0^\circ$
- Pitch $\approx 0^\circ$
- Course $\approx 0^\circ$ or 360°

The screenshot shows the 'ADMA Measurement data' dialog box with the following data tables:

Status	Byte 3	Byte 2	Byte 1	Byte 0
(hex)	DB	00	20	11

221

Error	Byte 3	Byte 2	Byte 1	Byte 0
(hex)	00	00	00	00

Rates

	X	Y	Z
Body [deg/s]	-0.02	-0.02	-0.01
Levelled [deg/s]	-0.03	-0.02	0.00
Frame [deg/s]			

Acceleration

	X	Y	Z
Body [g]	-0.0044	0.0016	-0.9990
Levelled [g]	0.0007	0.0003	-0.9990
Frame [g]			

External velocity

	X	Y
Vel. analog [m/s]		
Vel. corrected [m/s]		

External velocity digital

	X	Y
Vel. digital [m/s]		
Pulse [#]		

Miscellaneous

Inv. path radius [1/m]	
Side slip angle [deg]	
Distance [m]	

Triggers

SynchIn [ms]	
Event0 [ms]	
Event1 [ms]	
GPS [ms]	

System data

Ta [ms]	19.984
Temp [°C]	38.4
Time St [s]	4.0
DSP [%]	10.1

GPS-Position

	Latitude	Longitude
absolute [deg]		
relative [m]		

GPS-Velocity

	X	Y	Z
frame [m/s]			
Latency [s]			

GPS-Errors

	X	Y	Z
EPE [m]			
EVE [m/s]			

Height

GPS [m]	
Inertial [m]	

Tilt-Course (circled in red)

Roll [deg]	-0.08
Pitch [deg]	-0.29
Yaw [deg]	0.00
COG [deg]	0.00

GPS Aux ...

No. sat. [#]	
Log delay [T.a]	
Data age [s]	

Inertial pos.

	Lat	Long
absolute [deg]		
relative [m]		

Inertial vel.

	VXH	VYH	VZH
levelled [m/s]			
frame [m/s]			

Inertial Errors

	X	Y	Z
EVE [m/s]			
ETE (R/P/Y)[deg]			
EPE [m]			

Time

	Milliseconds	Week
ADMA-Time		
GPS-Time		

Size per step: 10 ADMA: Start Stop ...running Help

Sequential data saving Record: Start Pause Stop ...recording Close

Figure 16 Dialog: Measurement - Check of displayed orientation



3.5.4. Checking displayed rotational speeds

In a static state, the following rotational speeds should be indicated:

- X-axis $\approx 0^\circ/s$
- Y-axis $\approx 0^\circ/s$
- Z-axis $\approx 0^\circ/s$

ADMA Measurement data

Status	Byte 3	Byte 2	Byte 1	Byte 0
[hex]	DB	00	20	11

221

Error	Byte 3	Byte 2	Byte 1	Byte 0
[hex]	00	00	00	00

Rates	X	Y	Z
Body [deg/s]	-0.02	-0.02	-0.01
Levelled [deg/s]	-0.03	-0.02	0.00
Frame [deg/s]			

GPS-Position	Latitude	Longitude
absolute [deg]		
relative [m]		

Inertial pos.	Lat	Long
absolute [deg]		
relative [m]		

Acceleration	X	Y	Z
Body [g]	-0.0044	0.0016	-0.9990
Levelled [g]	0.0007	0.0003	-0.9990
Frame [g]			

GPS-Velocity	X	Y	Z
frame [m/s]			
Latency [s]			

Inertial vel.	VXH	VYH	VZH
levelled [m/s]			
frame [m/s]			

External velocity	X	Y
Vel. analog [m/s]		
Vel. corrected [m/s]		

GPS-Errors	X	Y	Z
EPE [m]			
EVE [m/s]			

Inertial Errors	X	Y	Z
EVE [m/s]			
ETE [R/P/Y] [deg]			
EPE [m]			

External velocity digital	X	Y
Vel. digital [m/s]		
Pulse [#]		

Height
GPS [m]
Inertial [m]

Miscellaneous
Inv. path radius [1/m]
Side slip angle [deg]
Distance [m]

Tilt-Course	
Roll [deg]	-0.08
Pitch [deg]	-0.29
Yaw [deg]	0.00
COG [deg]	0.00

GPS Aux. ...
No. sat. [#]
Log delay [T/s]
Data age [s]

Triggers
SyncIn [ms]
Event0 [ms]
Event1 [ms]
GPS [ms]

System data	
Ta [ms]	19.984
Temp. [°C]	38.4
Time Si [s]	4.0
DSP [%]	10.1

Time	Milliseconds	Week
ADMA-Time		
GPS-Time		

Size per step: 10 ADMA: Start Stop ...running Help

Sequential data saving Record: Start Pause Stop ...recording Close

Figure 17 Dialog: Measurement - Check of displayed rates



3.5.5. Checking the displayed accelerations

The ADMA should be positioned on a laboratory bench or similar facility, thus being placed on a close to horizontal surface. The following body-fixed accelerations should then be indicated:

- X-axis ≈ 0 g
- Y-axis ≈ 0 g
- Z-axis ≈ -1 g




Figure 18 Dialog: Measurement - Check of displayed accels

3.5.6. Stopping a measurement

Click on the *Stop* and *Close* buttons in succession.



3.6. Dynamic test

3.6.1. Test procedure and data display

As part of the dynamic test, the ADMA undergoes defined linear and rotary motion, i.e. along or about the systems sensor axis. The rotational speeds are checked first, beginning with the X-axis (roll), followed by the Y and Z axes, and followed by the acceleration check in the same sequence of axes.

For easier analysis, the data can be saved and processed with an appropriate software tool. If you want to save the data explicitly, click on the *Save measurement data* option in the measurement mode window. When starting a measurement with the *Save measurement data* activated, a dialog will open asking a file name.

While a measurement is in progress, the acquired data is saved in binary format. On completion of the measurement with the *Stop* button, the measurement data to be evaluated will be converted automatically to ASCII format.

Overall 3 files are created:

- Filename.dat Data in binary format
- Filename.prn Data in ASCII format
- Filename_PrnList.txt Description of the individual columns of the file *filename.prn*

3.6.2. Checking the rotational speeds

Start a measurement with the storage option activated as described above. After prealignment, the system is rotated about the individual measurement axes in the sequence X, Y and Z. The plotted data could look like this:




Diagram 1 Plot - rates



This data plot shows that ADMA detects negative as well as positive rotational speeds about all three measurement axes.

3.6.3. Checking accelerations

Start another measurement with the storage option activated as described above. After pre-alignment, the system is moved linearly along the individual axes in the sequence X, Y and Z. The plotted data could appear as follows:




Diagram 2 Plot - Accelerations

This data plot shows that ADMA detects negative as well as positive accelerations along the three measurement axes.



4. Installation and cabling inside the vehicle

4.1. Operational configurations

Any of three operational configurations is available in accordance with the involved vehicle test and required accuracy of data: Stand-alone, ADMA with external speed signal and ADMA with (D)GPS. The diagram below depicts these three configurations.




Figure 19 Configuration facilities: ADMA-G with internal GPS-Rover




Figure 20 Configuration facilities: ADMA-G with external GPS-Rover

Note that although the operational configuration involving ADMA with a (D)GPS does not necessarily require an external speed signal, such a signal proves especially useful in situations susceptible to GPS failure.



4.2. Point of installation

4.2.1. ADMA

The ideal installation point for a gyro system inside a vehicle is at the theoretical centre of motion, with the system's measuring axes parallel to those of the vehicle.

If installation at the centre of motion is not possible, the ADMA system needs to be positioned at a point inside the vehicle more conducive to installation. In this case, the selected point should preferably lie on one of the axes or on a plane formed by two axes and containing the centre of motion (for example, in the boot, on the vehicle's longitudinal axis passing through the centre of motion).

The ADMA's ideal position of installation in a vehicle is one in which the ADMA's measurement axes align with those of the vehicle, i.e. where the X measurement axis is parallel to the vehicle's longitudinal axis. It is difficult to actually achieve this ideal situation, so that the resulting discrepancy in alignment needs to be compensated. Section 5.6 cont. describes how to compensate discrepancies in the ADMA's installation position and alignment.

4.2.2. External speed measuring system

Usually, the external speed measuring system is attached to one side of the vehicle. For slalom tests involving a higher risk of damage to the sensor, a point at the front / rear of the vehicle can be used.

4.2.3. GPS antenna

If the ADMA is operated together with a GPS receiver, the GPS antenna must be mounted on the vehicle's roof to ensure a clear line of sight to GPS satellites. The ideal position for the antenna is one offering a clear view of the entire sky, from the zenith to the horizon. If the installation point on the vehicle's roof can be freely selected, it is advisable to select a point directly above the ADMA. This is where the vector to the ADMA's installation point is at its shortest and the effects of pitching and rolling at a minimum. Compensation of the GPS antenna's installation point is described in Section 5.7.3.

4.2.4. Modem and modem antenna

If the ADMA is operated together with a GPS receiver in the RTK-DGPS mode (also termed local-area DGPS), it is also necessary to employ a wireless / GSM modem for receiving correction data from the base station.

In most cases, the modem's IPxx protection type is not sufficient for external mounting on the vehicle, so that the modem unit needs to be mounted inside the vehicle, while only the modem's antenna is fastened on the roof.

Please note:

Wireless modems which usually transmit over a 433 / 868-MHz band need a direct line of sight to the base station's radio antenna in almost all cases, and therefore should be installed as high as possible on the vehicle's roof.

This does not apply to GSM modems, which are capable of maintaining contact with the base station even under adverse conditions without a direct line of sight.



4.3. Cabling

After mounting in/on the vehicle is complete, it is necessary to lay the ADMA cables required for operation. Based on the minimal configuration, the available operational variants are described below. Additional information on connection possibilities and the ADMA sockets is provided in the technical description.

4.3.1. ADMA in stand-alone mode (minimal configuration)

Connect the *ADMA-Power* cable's red-coded Lemo-plug to the *DC In* ADMA socket and turn on the power supply. Depending on system design, the nominal supply is 12, 24 or 42 VDC. The *DC In* LED should come on as a result.

Afterward, connect the *ADMA-COM* communication cable's blue-coded Lemo-plug to the *COM* ADMA-socket and the other end of the cable to the *COM* interface of your measurement data acquisition device.

If you want to perform measurements via the *CAN* bus, connect the *ADMA-CAN* communication cable's green-coded Lemo-plug to the *CAN* ADMA socket and the other end of the cable to the *CAN* interface of your measurement data recorder (made by Vector or Softing, for instance).

4.3.2. ADMA in stand-alone mode - optional connections

The minimal configuration for operating ADMA is supplemented by additional terminals which might prove useful for some other measurements. These include the *SyncOut* output as well as the *Event 1* and *Event 2* inputs which are extremely suitable for establishing chronological references during a measurement. Such references can comprise, for example, a lap index, lane entrance or circular travel index. A detailed description of the signals and associated cables is provided in the technical documentation.

4.3.3. ADMA and external speed measurement

ADMA can read in analogue speed signals - including 2-axis signals - via the *Speed* terminal. For this purpose, connect ADMA to the speed sensor via the appropriate *ADMA-Speed* cable.

Please do not forget the power supply for the speed sensor.



4.3.4. ADMA and GPS

If the ADMA is to be operated with a GPS, all the cables for the GPS receiver should be connected first. ADMA-G with internal GPS receiver and ADMA with external GPS receiver are connected differently.

In case of ADMA-G with internal GPS-receiver the GPS antenna has to be connected with the ADMA via a coaxial cable. As a rule the GPS antenna is mounted on the roof with a magnetic base.

To use the DGPS-mode of the GPS-receiver a modem is required to receive correction data. This can be either a wireless- or a GSM-modem. Connect the ADMA modem output with the modem and the modem with its modem antenna. Please note, that the ADMA supplies the modem with voltage.




Figure 21 ADMA-G with internal GPS receiver

In case of ADMA with external GPS-receiver the GPS receiver has to be connected with the GPS antenna via a coaxial cable. As a rule the GPS antenna is mounted on the roof with a magnetic base.

To use the DGPS-mode of the GPS-receiver a modem is required to receive correction data. This can be either a wireless- or a GSM-modem. Connect the receiver with the modem and the modem with its modem antenna. Please note, that both the GPS-receiver and the optional modem need to be supplied.




Figure 22 ADMA with external GPS receiver



4.3.5. ADMA and DGPS with a separate base station

The separate base station is set up similar to the installation of an external GPS receiver in the vehicle, except that in the case of a mobile station, a PC or laptop communicates with the base. There are two different GPS base models available. Besides a standard GPS base GeneSys also offers an all-weather housing for accommodating all the essential components of a base station. In this case just simply connect the housing's integrated sockets to the GPS antenna, modem antenna, communication cable for setup, and power supply cable.

The standard base setup is displayed below.




Figure 23 GPS base station: Pin assignment of the basic design



5. Setting up the ADMA in the vehicle

5.1. Configuration of the external velocity

In the dialogue *Auxiliary Systems* you can setup an external velocity signal for additional support for the Kalman filter. In this dialog you can configure your analogue or digital speed sensor. Depending on the velocity source, you can set the X- and Y-axis scale factors for that sensor.




Figure 24: Dialog: Aux. Systems - Configuration of the external velocity

There is also the possibility to have the ADMA estimate the X scale factor of the external velocity sensor automatically. For this, we have implemented a External-Velocity-Kalman filter, which has 3 Modes available:

- Off Ext-Vel-Kalman filter is deactivated
- Once Activation for one measurement
- On Ext-Vel-Kalman filter is permanently activated

The determined scale factor is saved for further measurements. The scale factor estimation of the external velocity sensor is signalled by 2 status bits (see Technical documentation).



5.2. Satellite based GPS correction data

With satellite based correction data the GPS data accuracy can be improved. As the satellites used to transmit the correction data are geostationary, the signal coverage will be available for fixed regions, which are:

- EGNOS Europe
- WAAS America
- MSAS Asia/Japan

Please see *Satellite based Augmentation* at the Auxiliary Systems dialog for activation of this service.



5.3. Modify threshold for AutoInit function and GPS-course

The Autoinit function of the ADMA is used to automatically set the ADMA inertial states after system start-up, including the yaw angle. This is only possible with an adequate vehicle velocity, since the yaw angle will be overwritten with the GPS course over ground value, and therefore a certain speed is essential.

The “Min. velocity for AutoInit (m/s)” – threshold is used to allow the user to set this threshold to his application requirements. For instance Dozers and other slow moving vehicles have difficulties to reach velocities of let’s say 5 m/s.

Please note, that depending on GPS reception the accuracy of the GPS course over ground can vary quite a lot at low speeds. We recommend using a 3 m/s threshold only with good GPS reception. In case of bad GPS reception 5 m/s, under some conditions even 7 m/s, are advisable.

The “Min. velocity for GPS-Course (m/s)” – threshold is used to switch of GPS course over ground calculation, if the vehicle speed drops below this threshold.




Figure 25 Dialog: Parameter - Threshold for AutoInit and GPS-course



5.4. Modify threshold for standstill detection

The following describes standstill detection thresholds and their correct entry, which will increase the data integrity. The parameters for the *Standstill detection* (Max. rate at standstill, Max. velocity at standstill) are very important parameters, as standstill allows a special form of augmentation for use with the *Kalman filter*, the so called *Zero-Velocity-Update*. This variant of the *Kalman filter* update increases the stability of the measurement mode in case of standstill.




Figure 26 Dialog: Parameters - Standstill detection



5.4.1. Max. turn rate at standstill

The measured ADMA turn rates allow a good detection of vehicle standstill, as the measured rates of the vehicle are smaller in standstill compared to those in dynamic operation. However the thresholds have to be checked and adapted, depending on the type of vehicle. This can best be done with a test measurement followed by a data analysis.

The special mode of the *Kalman filter* update via *Zero-Velocity-Update* is available in all operation modes, however in solo-operation (no external velocity / no (D)GPS) only the turn rates are used for standstill detection.

5.4.2. Max. velocity at standstill

If the ADMA is operated in a non-solo mode, then an additional check, against the (inertial) velocity, is performed for standstill detection. In that case both criteria (rate and velocity) need to be valid for the ADMA to indicate standstill detection.



5.5. Modify thresholds for quality

The position- and the tilt-status are implemented to have an easy way to display the ADMA system performance. The position- and tilt-status are based on the Kalman filter internal estimation of the state variable's quality (standard deviation). With 2 adjustable thresholds for each status it's possible to give a statement about the measurement's quality, which can be displayed in form of a traffic light design. The threshold *green-yellow* separates small from tolerable measurement errors, the threshold *yellow-red* tolerable from non-acceptable errors. Thus, GPS outage situations, where system performance degrades over time, are easily detected and appropriate actions can be taken while being out on the test track, etc.

Values for pos- and tilt-quality:

- 0 = Red
- 1 = Yellow
- 2 = Green

This functionality is also advantageous while in the transient phase of the *Kalman filter* at the beginning of a measurement. After a set time the status is switched active, changing from "red" to whatever the actual state is, normally to "yellow" or "green" state. This indication can be used to start data recording.




Figure 27 Dialog: Parameters – Quality (Pos and Tilt)



5.5.1. Threshold for position quality

The position quality is particularly of interest when (D)GPS is used. If the ADMA is operating with (D)GPS, the position error is expected to be within an error band, depending on the quality of the actual GPS position and the available GPS mode. If GPS data isn't available for a certain amount of time (e.g. due to GPS outage), then the ADMA position quality decreases due to the gyro system's own error dynamic, following a square function.

With decreasing quality the standard deviation of the signals will increase. In case the threshold is reached, this is shown accordingly (yellow, resp. red). Acceptable errors and thus their thresholds may vary with the application, and can be within a possible error range of 0.1, 1, 5, 10 or even 20m. As an example, in case of crosswind influence tests the position measurement needs to be very exact and accordingly the limits must be set closely.

With the GPS re-entering after a GPS outage the position quality will increase again. This leads to smaller standard deviations of the ADMA position and thus affecting the position standard deviation.

Please note:

The position error can be reduced to a linear error behaviour by using an external velocity signal. Associated with this is a better expected position quality over the time.

5.5.2. Threshold for Tilt quality

In contrary to the position quality the tilt quality is of interest to most operation modes. It is advantageous that the tilt error only increases linear over the time. In cases of a (D)GPS outage a better error behaviour can be expected compared to those of the position.

5.5.3. Enter geo. latitude and geo. longitude

To operate the ADMA without (D)GPS the actual position can be defined in the configuration. With the correct entry of the geo. latitude the earth rate and the earth gravitational vector length can be calculated correctly.

If the ADMA is using (D)GPS the entered position can be used as the origin for the relative position grid (local tangent plane). To allow this option activate the checkbox *Accept position as origin* (for further information see the *Technical documentation*). The relative position data output from the ADMA is referenced to this point. This is very suitable for repetitive tests, where recorded data sets have to be compared (path following tests or steering influence tests).

Please note:

Some test setups with DGPS might take more than a day or test campaigns might have to be run over a longer period of time, but the users could find themselves in the situation to remove the base station at the end of the day. In case of measurements in RTK-DGPS mode (up to 2cm) the exact position of the base station antenna needs to be saved and marked to meet the requirements of comparability.

Additionally, at the first day of a measuring campaign the exact position of the base station antenna should be determined, if no known position is available (also see GPS base documentation for saving measured GPS base positions).



5.6. Compensating an ADMA misalignment

5.6.1. ADMA misalignment

As described earlier, an exact alignment of the ADMA's measurement axes with the vehicle's axes is rarely achieved. However, it is possible to mathematically compensate for such alignment errors. Compensation values can be entered in the *Offsets* dialog in the ADMA System Software.

Please note:

As reference orientation, a horizontal defined plane of the vehicle is used, which aligns with the axis of the DIN70000 coordinate system. This plane then defines zero for the Roll and Pitch angles. It's also very important to state the lever arm vectors within this coordinate system, to obtain correctly compensated data.

5.6.2. Sequence of ADMA misalignment angle compensation

The sequence of misalignment angle compensation is mathematically defined by which rotary matrices are applied (X, Y, Z = Roll, Pitch, Yaw).

With the setup routine given by ADMA System Software the first two axes can be compensated. Once executed, only the misalignment in Yaw (Z) remains, which can be entered using the configuration menu of the ADMA System Software.

To avoid errors in compensating, all three misalignments saved in the ADMA configuration are set to zero prior to execution of the setup routine, compensating Roll and Pitch misalignment. This approach will assure that the setup routine will be executed upon the body fixed (non-compensated) coordinate system of the ADMA. Finally the compensation of the Yaw misalignment has to be entered.

After successful compensation of the misalignment angles all axes are mathematically rotated correctly, thus the measurement data will correspond to a horizontal and in driving direction mounted ADMA. Further transformations (e.g. lever arms), which follow the misalignment compensation in code, are not affected.

5.6.3. Horizontal compensation of a ADMA misalignment

Please bring the vehicle into the desired reference orientation and start the setup routine for the roll and pitch angle from the ADMA System Software menu. The setup routine will give you an estimate of the two angles within 1 min, and saves those in the ADMA internal setup configuration after finishing the routine. While the routine is running, the estimated offset angles are displayed.

Please note:

If the ADMA is operated only with an external velocity signal, then the position calculation is made via dead reckoning methods. The dead reckoning calculates the position with integrated velocity and the course angle. The height can be calculated accordingly, but in this case using the pitch angle instead of the course angle. However the pitch angle misalignment must be compensated for the height measurement to be acceptable.



5.6.4. Compensation of ADMA's vertical axis misalignment

The ADMA's Z-axis misalignment with respect to its longitudinal axis cannot be ascertained as easily as the horizontal angles.

One alternative is to perform a setup test involving longitudinal acceleration produced in stop & go travel. The ADMA's z-axis misalignment about its vertical axis causes the levelled acceleration acting along the X-axis to produce a component along the Y-axis as well. This relationship can be used to compute an angle of misalignment on the basis of the measured data. Similar to the horizontal angles, the obtained value is entered in the Z field of the section labelled *Mounting offset angles*. If not executed carefully, this method can give rise to errors.

5.6.5. Compensation of vertical-axis misalignment of a 2-axis speed sensor

If a 2-axis speed sensor - for instance, one made by Corrsys - is employed, its mounting can be rotated. The corresponding misalignment can only be determined during a straight-ahead run. Similar to the misalignment in the case of the ADMA, a misalignment causes the vehicle's X-axis speed to produce a component along the sensor's Y-axis. This data can be used to calculate the angle of misalignment. The obtained value is entered in the field *Ext. velocity* in the section labelled *Mounting offset angles*.



5.7. Compensating the installation position

Normally the ADMA, the GPS antenna and external speed sensor can't be mounted at the same spot - as we would like to - but at different positions in or outside the vehicle. The GPS antenna is usually mounted on the roof, the ADMA in the vicinity of the centre console or in the boot, and the speed sensor on the vehicle's side, front or rear. Radar sensors are sometimes also mounted underneath the vehicle. The distance between the individual components is termed "lever arm".

As a consequence, the position measured by the GPS antenna does not correspond to the *virtual measuring point* (reference point: **Point Of Interest**). An uncompensated lever arm also causes roll, pitch and course changes to be registered as errors in the form of position discrepancies.

Furthermore, the speed measured at the installation position of the external speed sensor is not equal to the speed at the *virtual measuring point*. While the vehicle is travelling through a corner or in a circle, the speed measured by a sensor mounted on the vehicle's outer side is higher than the speed measured in the middle of the vehicle or on the inside of the vehicle.

Installation positions are compensated by specifying the position vectors ADMA relative to GPS antenna and ADMA relative to external speed sensor. With these lever arms the GPS sensor data and the sensor data of the external speed sensor are factored into the calculation of the ADMA's position such ensuring the correct transformation of ADMA related data to the POI. The position vectors are entered and edited in the ADMA System Software's *Offsets* dialog. For determination of the installation position a folding rule or reference tape is completely adequate.



Please note:

The vector is based on the coordinate system defined by DIN 70000. Additional details are provided in ADMA's technical description.




Figure 28 Dialog: Offsets



5.7.1. Virtual measuring point (point of interest)

If the ADMA isn't mounted in the *virtual measurement point* (Point Of Interest), then a lever arm exists between the reference point and the installation position of the ADMA. This lever arm can be compensated by entering the lever arms of the *virtual measurement point*.

The entry should be made correspondent to the coordinate system DIN70000 in [cm]:

- X (positive in travel direction)
- Y (positive leftward with respect to direction of travel)
- Z (positive upward)

Please note:

This compensation is only valid, if the assumption is met that the car turns around a virtually fixed axes and the movement of this axes in the horizontal plane is insignificant relative to the vehicle. However this compensation is incorrect, if the axis doesn't fulfil the above mentioned condition. For example, this could happen in driving situations like spinning or drifting i.e. the axis moves obviously.

5.7.2. External speed measuring system

The position vector for compensating speed data refers to the *virtual measuring point* and consists only of the components:

- X (positive in travel direction)
- Y (positive leftward with respect to direction of travel)

The Z-component is not of significance to compensation.

The compensation of the external connected velocity to the reference point effects the calculation of the inverse path radius and the side slip angle, if no GPS is connected.

5.7.3. GPS antenna

The position vector for the GPS antenna consists of all three components and refers to the ADMA.



6. Configuring ADMA's measurement mode

6.1. System settings

Use the ADMA system software to configure the system as required for your tests. The following items are parameterised here:

- Data interface and (in the case of CAN) advanced options
- Sampling frequency, prealignment time, autostart, etc.
- Additional digital inputs / outputs
- Existent auxiliary systems such as external speed measurement modules or GPS

For further information about this settings, use the interactive help described in chapter 3.3.1. In addition to these settings, it is necessary to account for data volumes and resultant memory loading occurring during prolonged measurement runs. Once all these steps have been taken, measurements can be properly started.

6.2. Starting a measurement

Basically there are 4 possibilities to start a measurement:

- Start a measurement via the main menu's item *Start measurement* in ADMA System Software
- Start a measurement via the main menu's item *Remote Start* in ADMA System Software
- Start a measurement via the *Autostart* mode
- Start a measurement via a user specific tool

6.2.1. *Start measurement* in the ADMA System Software

In this case the ADMA measuring mode is started with the System software via the COM port. Before starting a measurement please enter the *start course* and the *pre-alignment* in the displayed dialog. The measurement will start directly after this. For further information about these 2 parameters have a look at the following chapters 6.2.5 and 6.2.7.

The dialog *ADMA measurement data* appears and the parameters are displayed.

6.2.2. *Remote Start* in the ADMA System Software

Remote Start starts a measurement, in which the data is output via the CAN port. For this purpose select *CAN* port in dialog *Parameter* in configuration mode. Before starting a measurement please enter the *start course* and *pre-alignment* in the displayed dialog. For further information about these 2 parameters have a look at the following chapters 6.2.5 and 6.2.7. The dialog *ADMA measurement data* appears and the data are displayed.



6.2.3. Autostart mode

The setting *Autostart* can be enabled in configurations dialog Data. If *Autostart* is activated, the ADMA automatically starts data acquisition after power on. Whether the data is transmitted via CAN- or COM-interface, depends on your choice in configurations dialog "Interface". In this case, the 2 parameters *start course* and *pre-alignment* can't be modified. The saved values of the configuration settings are used.

Please note that the ADMA in Autostart mode takes a minimum of 15 seconds to switch to pre-alignment or measuring mode. During this time the internal GPS-Receiver is booting up and therefore configuration is not possible.

6.2.4. Start a measurement via a user specific tool

Data acquisition can also be started via a user specific tool. The interface protocol for the COM- and CAN-interface is available on request, please contact us. Please refer in this case to the contact address on page 2.

6.2.5. Start course

If the ADMA is operated without GPS, this entry will assure that earth rate is compensated correctly, which otherwise will lead to calculation errors. If the ADMA is operating with (D)GPS, the transient duration of the Kalman filter can be reduced by entering a correct start course, but it's an option.

6.2.6. Autolnit function (yaw angle init)

If the ADMA is operated with (D)GPS, you might omit entering a start course, as this will be automatically set by the ADMA's Autolnit function.

After pre-alignment a first estimation for roll and pitch is found and set as starting values, but only with a true start course set the yaw angle will be correct.

The ADMA Autolnit function will overwrite the yaw angle with the GPS course after exceeding a velocity threshold, which will help Kalman filter settling, and eliminates the need to have the user enter a start course. Please note, that the Autolnit function will only be executed once with each measurement started.

Important for a successful yaw init with the GPS course is a minimum of vehicle speed, as the GPS course is calculated from the GPS velocity. The rule of thumb is: higher vehicle speeds reduce the GPS course error introduced by GPS velocity noise. Please keep this also in mind when you are expecting poorer GPS reception.

When analysing data, the successful execution of the Autolnit routine can be detected in the data when the vehicle reaches the configured velocity threshold first time (unless the initial yaw angle was already true). Yaw angle and GPS course should then be similar, but only if the classic coordinate system is chosen (please see configuration options of the ADMA). Please note, that the coordinate system as stated in DIN 70000 is rotated about the roll angle by 180°, hence pitch and yaw angles will have an inverted sign compared to the classic coordinate system. The GPS course will be output according to the classic coordinate system.

DIN 70000	90° (west)	270° (east)	counter clockwise
Classic	90° (east)	270° (west)	clockwise



6.2.7. Pre-alignment

During pre-alignment the roll- and pitch angles are calculated from accelerometer data, while the vehicle is in standstill. The duration of the pre-alignment determines the expected precision of the angle estimation. Typical time periods are in the range of 5 – 30 seconds.

6.2.8. Transient phase of the Kalman filter

The transient phase of the *Kalman filter* can't be bypassed, as described above in chapter 3.5.1, and takes ca. 120 seconds. However the Transient condition can be supported by the user of the ADMA. After pre-alignment, the *Kalman filter* converges faster, if the vehicle is moved in circles of 8, or is zigzagged down a straight.

Important are driving conditions with accelerations. The vehicle can be driven *brisk* in this case, however spinning states should be avoided.



7. ABD Steering Robot (HW 2.2 and higher)

7.1. ADMA-configuration for ABD-steering robot

You can activate the data output by checking the *ABD - steering robot* in the configuration dialog *Data*:




Figure 29: ABD - steering robot

If this checkbox is active, the *Update Frequency* is set to 100Hz which is specified for the ABD-steering robot. In addition, all needed configuration for the Ethernet interface is set automatically for the communication to the robot:

	ADMA	ABD Steering Robot
IP Address	195.0.0.132	195.0.0.100
Port	1025	1025
Protokoll	UDP	UDP

Use *Save Settings in ADMA* in the *Save / Exit configuration* dialog to transfer the configuration to the ADMA.



7.2. Measurement

If you activate the steering robot and download the configuration to the ADMA or power cycle the previous configured ADMA and no Ethernet cable is connected, the Ethernet interface LED on the front of the ADMA should blink with about 1Hz. Then the ADMA tries to reach the robot with the IP address 195.0.0.100.

If you now connect the ADMA to the Robot via Ethernet cable, the LED should stop to blink after less than 10 seconds, only then you can start the data acquisition. The Ethernet interface LED should blink fast (100 Hz), if data is send to the robot.



8. ADMA – firmware download

8.1. General

The ADMA System Software and the ADMA USB download cable allow an easy download of new firmware (FW) versions onto the ADMA. With this feature the customer himself can upgrade his ADMA at his facilities.

8.2. Firmware / System Software – Compatibility

Beginning with SW and FW version 21.5.0 the ADMA System Software will check before exchanging settings, if SW and FW are compatible. This procedure was introduced to minimise possible handling errors based on usage of older versions of either the SW or the FW. Current versions can be downloaded or sent by email.

Please note, that versions of SW and FW are compatible, if the first three numbers match, e.g. 21.5.0 and 21.5.0.1, etc.

In case a version mismatch is detected on configuration readout or while starting data acquisition, the System Software will give notice, and ask you to download the current version of FW and SW. The SW will not continue to communicate with the ADMA until version match has been incorporated.

8.3. Handling Ini-files created by older System Software versions

Ini-files that have been created with older versions of the SW can now be read with versions 21.5.0 and newer. If the SW detects a missing entry in the older Ini-file, it will give notice, that a parameter was not found, and set it to its default. For later analysis, all given messages will be saved in a text file named Protocol.txt in the working directory of the SW. The updated copy of the configuration parameters can now be downloaded to the ADMA, and/or be saved in a new Ini-file.

New with SW-Version 21.5.0 is that the Ini-file will now be saved with a header containing basic system information. It will be located at the beginning of the file, and it will show this information:

- ADMA serial number
- ADMA hardware version
- ADMA firmware version
- ADMA System Software version (with which the Ini-file was made)

Please note, that the header is only added, if an ADMA has been read and the configuration was saved to an ini-file.

Important:

Please don not change the ini-file manually



8.4. Download ADMA firmware

Please apply correct supply voltage to the ADMA and connect the USB-Download cable to the ADMA and the USB-Port of or PC/laptop. Then start the ADMA System Software and choose from the menu *Firmware - JTAG-Download*.



Figure 30 Menu Firmware download

The following dialog will appear, where you can search for the ADMA firmware file using the *Load BIN file* button. Following loading of the binary firmware file, download could be started, although we recommend checking download verification.




Figure 31 Dialog: FW - download

The *Start download* button will initiate a sequence of actions; the first step will clear the flash chip, followed by reprogramming and finally verifying the download process, if enabled.

After step 2 and 3 you will be informed, if either of the both steps were successfully executed. After a successful download, please remove the supply voltage for a couple of seconds, to then find the ADMA ready for operation.

Please note, that the new firmware might need a compatible System Software



Table of figures

Figure 1 Setup an cabling	9
Figure 2 Menu of the ADMA System Software	11
Figure 3 Dialog: Load configuration	11
Figure 4 Dialog: Data Link	12
Figure 5 Dialog: Data.....	13
Figure 6 Dialog: Auxiliary Systems	14
Figure 7 Dialog: Parameters.....	15
Figure 8 Dialog: Save / Exit configuration	16
Figure 9 Start Measurement item in main menu	17
Figure 10 Dialog: ADMA Measurement data	17
Figure 11 Dialog: Start parameter for Measurement	18
Figure 12 Dialog: Measurement in prealignment mode.....	19
Figure 13 Dialog: Record Stop	20
Figure 14 Sequential measurement mode: Continue / Terminate serial	21
Figure 15 Dialog: Measurement - Check of system status.....	22
Figure 16 Dialog: Measurement - Check of displayed orientation.....	23
Figure 17 Dialog: Measurement - Check of displayed rates	24
Figure 18 Dialog: Measurement - Check of displayed accels.....	25
Figure 19 Configuration facilities: ADMA-G with internal GPS-Rover.....	28
Figure 20 Configuration facilities: ADMA-G with external GPS-Rover	28
Figure 24: Dialog: Aux. Systems - Configuration of the external velocity	33
Figure 25 Dialog: Parameter - Threshold for AutoInIt and GPS-course.....	35
Figure 26 Dialog: Parameters - Standstill detection	36
Figure 27 Dialog: Parameters – Quality (Pos and Tilt)	38
Figure 28 Dialog: Offsets	43
Figure 29: ABD - steering robot	48
Figure 30 Menu Firmware download.....	51
Figure 31 Dialog: FW - download	51

Table of diagrams

Diagram 1 Plot - rates.....	26
Diagram 2 Plot - Accelerations.....	27