


SofTec[®]
MICROSYSTEMS
*Development Tools
for the EmbeddedWorld*



BRUSHLESS MOTOR CONTROL



User's Manual

AK-ST7FMC

Starter Kit for STMicroelectronics ST7FMC Motor Control Device

User's Manual

Revision 2.0



Copyright © 2005 SofTec Microsystems®

DC00915

We want your feedback!

SofTec Microsystems is always on the look-out for new ways to improve its Products and Services. For this reason feedback, comments, suggestions or criticisms, however small, are always welcome.

SofTec Microsystems

E-mail (general information): info@softecmicro.com

E-mail (marketing department): marketing@softecmicro.com

E-mail (technical support): support@softecmicro.com

Web: <http://www.softecmicro.com>

Important

SofTec Microsystems reserves the right to make improvements to the AK-ST7FMC Starter Kit, its documentation and software routines, without notice. Information in this manual is intended to be accurate and reliable. However, SofTec Microsystems assumes no responsibility for its use; nor for any infringements of rights of third parties which may result from its use.

SOFTEC MICROSYSTEMS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.

Trademarks

STMicroelectronics is a registered trademark of STMicroelectronics, Inc.

Metrowerks and CodeWarrior are trademarks or registered trademarks of Metrowerks Corp.

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation.

PC is a registered trademark of International Business Machines Corporation.

Other products and company names listed are trademarks or trade names of their respective companies.

Contents

0 Before Starting 11

- 0.1 Safety Warnings 11
 - 0.1.1 General 11*
 - 0.1.2 Intended Use 11*
 - 0.1.3 Operation 11*
 - 0.1.4 Important Notice to Users 12*
- 0.2 Required Skills 12
- 0.3 Credits 12

1 Overview 15

- 1.1 What is the AK-ST7FMC Starter Kit? 15
- 1.2 ST7FMC Family Overview 16
- 1.3 The Brushless AC (BLAC) or DC (BLDC) Motor 16
- 1.4 The Brushless AC (PM Sinusoidal) Motor 17
- 1.5 The Three-Phase AC Induction Motor 18
- 1.6 The Single-/Bi-Phase AC Induction Motor 18
- 1.7 Recommended Reading 19
- 1.8 Software Upgrades 19
- 1.9 Troubleshooting 20
- 1.10 Getting Technical Support 20

2 AK-ST7FMC Components 21

- 2.1 Package Checklist 21
- 2.2 The Motor Control Board 22
- 2.3 The BLDC Motor 24
- 2.4 The In-Circuit Debugger/Programmer (inDART-STX) 24
- 2.5 The Optoisolation board 24
- 2.6 The “Alternate Z Sampling” Daughter Board 25

3 Getting Started for Three-Phase BLAC/BLDC Motors 27

- 3.1 Introduction 27
- 3.2 Step-by-Step Tutorial 27

- 3.2.1 *Tools Required* 27
- 3.2.2 *Installing the Software* 28
- 3.2.3 *Installing the Hardware* 28
- 3.2.4 *Tutorial Steps* 29

4 Getting Started for PMAC Motors 33

- 4.1 Introduction 33
- 4.2 Step-by-Step Tutorial 34
 - 4.2.1 *Tools Required* 34
 - 4.2.2 *Installing the Software* 34
 - 4.2.3 *Installing the Hardware* 34
 - 4.2.4 *Tutorial Steps* 36

5 Getting Started for Three-Phase AC Motors 39

- 5.1 Introduction 39
- 5.2 Step-by-Step Tutorial 40
 - 5.2.1 *Tools Required* 40
 - 5.2.2 *Installing the Software* 40
 - 5.2.3 *Installing the Hardware* 41
 - 5.2.4 *Tutorial Steps* 42

6 Getting Started for Single- and Bi-Phase AC Motors 45

- 6.1 Introduction 45
- 6.2 Step-by-Step Tutorial 46
 - 6.2.1 *Tools Required* 46
 - 6.2.2 *Installing the Software* 47
 - 6.2.3 *Installing the Hardware* 48
 - 6.2.4 *Tutorial Steps (for a Single-Phase Motor)* 49
 - 6.2.5 *Tutorial Steps (for a Bi-Phase Motor)* 51

7 Connectors and Functions 55

- 7.1 Power Supply 55
 - 7.1.1 *Introduction* 55
 - 7.1.2 *Optoisolation Board Supply* 56
 - 7.1.3 *Power Supply Connectors Summary* 56
- 7.2 Push-Buttons and Potentiometers (Standalone Mode) 57
 - 7.2.1 *Introduction* 57
 - 7.2.2 *Preparing for Standalone Mode: General Notes* 57
 - 7.2.3 *Preparing for Standalone Mode: BLAC/BLDC Motors* 58
 - 7.2.4 *Preparing for Standalone Mode: PMAC Motors* 63
 - 7.2.5 *Preparing for Standalone Mode: Three-Phase AC Motors* 67
 - 7.2.6 *Preparing for Standalone Mode: Single- and Bi-Phase Motors* 71

- 7.2.7 *Push-Buttons* 75
- 7.2.8 *Potentiometers* 76
- 7.2.9 *Standalone Mode: Driving a BLAC/BLDC Motor* 77
- 7.2.10 *Standalone Mode: Driving a PMAC Motor* 78
- 7.2.11 *Standalone Mode: Driving a Three-Phase AC Motor* 78
- 7.2.12 *Standalone Mode: Driving an Single-Phase Motor* 79
- 7.2.13 *Standalone Mode: Driving a Bi-Phase Motor* 80
- 7.3 **BLAC/BLDC Motor Outputs and Feedback** 81
 - 7.3.1 *Introduction* 81
 - 7.3.2 *Sensorless Mode (STMicroelectronics Method)* 82
 - 7.3.3 *Sensorless Mode (Standard Method)* 83
 - 7.3.4 *Sensor Mode* 83
- 7.4 **PMAC Motor Outputs and Feedback** 83
- 7.5 **Three-Phase AC Motor Outputs and Feedback** 83
 - 7.5.1 *Open Loop* 84
 - 7.5.2 *Closed Loop* 84
- 7.6 **Single- and Bi-Phase AC Motor Outputs and Feedback** 84
 - 7.6.1 *Open Loop* 84
 - 7.6.2 *Closed Loop* 84
- 7.7 **ICC Connector** 85
- 7.8 **External Power Stage Connectors** 85
- 7.9 **RS-232 Connector** 86
- 7.10 **Summary of Jumper and Connector Settings** 87
 - 7.10.1 *Jumpers Summary* 87
 - 7.10.2 *Connectors Summary/Pinout* 90
 - 7.10.3 *Jumper Settings for a BLAC/BLDC Motor (Default)* 94
 - 7.10.4 *Jumper Settings for a PMAC Motor* 95
 - 7.10.5 *Jumper Settings for an AC Motor (Single-, Bi- or Three-Phase)* 96

8 AK-ST7FMC Control Panel Features 97

- 8.1 **Introduction** 97
 - 8.1.1 *Suggested BLAC/BLDC Motor Learning Steps* 97
 - 8.1.2 *Suggested PMAC Motor Learning Steps* 98
 - 8.1.3 *Suggested Single-, Bi- and Three-Phase AC Motor Learning Steps* 98
- 8.2 **Motor Type Choice** 99
- 8.3 **BLAC/BLDC Motor Parameters** 100
 - 8.3.1 *Main Motor Settings* 102
 - 8.3.2 *Start-Up Settings* 104
 - 8.3.3 *Real-Time Settings* 108
 - 8.3.4 *Advanced Settings* 109

	8.3.5	<i>Power Board Settings</i>	119
8.4		PMAC Motor Parameters	121
	8.4.1	<i>Main Motor Settings</i>	123
	8.4.2	<i>Voltage Limitation</i>	124
	8.4.3	<i>Start-Up Settings</i>	124
	8.4.4	<i>Real-Time Settings</i>	125
	8.4.5	<i>Advanced Settings</i>	126
	8.4.6	<i>Ph/F Curve Settings</i>	128
8.5		Three-Phase AC Motor Parameters	128
	8.5.1	<i>Main Motor Settings</i>	130
	8.5.2	<i>V/F Curve Settings</i>	131
	8.5.3	<i>Start-Up Settings</i>	131
	8.5.4	<i>Real-Time Settings</i>	132
	8.5.5	<i>Advanced Settings</i>	133
8.6		Single- and Bi-Phase AC Motor Parameters	136
	8.6.1	<i>Main Motor Settings</i>	137
	8.6.2	<i>V/F Curve Settings</i>	138
	8.6.3	<i>Start-Up Settings</i>	138
	8.6.4	<i>Real-Time Settings</i>	139
	8.6.5	<i>Advanced Settings</i>	141
9		Electrical Specifications	143

Index of Figures

Figure 2.1: AK-ST7FMC Hardware Components	22
Figure 2.2: Motor Control Board	23
Figure 3.1: Motor Type Choice Dialog Box	30
Figure 3.2: AK-ST7FMC Control Panel Main Window for BLAC/BLDC Motors	31
Figure 4.1: AK-ST7FMC Control Panel Main Window for PMAC Motors	37
Figure 4.2: AK-ST7FMC Control Panel Main Window for Three-Phase AC Motors	43
Figure 6.1: Typical Single-Phase AC Motor Connection	46
Figure 6.2: Typical Bi-Phase AC Motor Connection	47
Figure 6.3: AK-ST7FMC Control Panel Main Window for Single-Phase AC Motors	50
Figure 6.4: AK-ST7FMC Control Panel Main Window for Bi-Phase AC Motors	52
Figure 7.1: Power Supply Connectors	56
Figure 7.2: BLAC/BLDC Motor Closed Loop Parameters Collecting	59
Figure 7.3: Program Dialog Box	63
Figure 7.4: PMAC Motor Closed Loop Parameters Collecting: Ki, Kp	64
Figure 7.5: PMAC Motor Closed Loop Parameters Collecting: Phase Shift	65
Figure 7.6: Three-Phase AC Motor Closed Loop Parameters Collecting: Ki, Kp	68
Figure 7.7: Three-Phase AC Motor Closed Loop Parameters Collecting: Slip Frequency	69
Figure 7.8: SBAC Motor Closed Loop Parameters Collecting: Ki, Kp	72
Figure 7.9: SBAC Motor Closed Loop Parameters Collecting: Slip Frequency	73
Figure 7.10: Push Buttons	76
Figure 7.11: Potentiometers	76
Figure 7.12: Motor Outputs and Feedback	82
Figure 7.13: Power Stage Connectors	85
Figure 8.1: Motor Type Choice Dialog Box	100
Figure 8.2: AK-ST7FMC Control Panel Main Window for BLAC/BLDC Motors	101
Figure 8.3: BLAC/BLDC Motor Advanced Settings Dialog Box	110
Figure 8.4: BLDC Motor: BEMF Sampling Methods	118
Figure 8.5: Power Board Settings Dialog Box	119
Figure 8.6: AK-ST7FMC Control Panel Main Window for PMAC Motors	122
Figure 8.7: PMAC Motor Advanced Settings Dialog Box	126
Figure 8.8: AK-ST7FMC Control Panel Main Window for Three-Phase AC Motors	129
Figure 8.9: Three-Phase AC Motor Advanced Settings Dialog Box	134
Figure 8.10: AK-ST7FMC Control Panel Main Window for Single- and Bi-Phase AC Motors	136
Figure 8.11: Single- and Bi-Phase AC Motor Advanced Settings Dialog Box	141

Index of Tables

Table 7.1: BLAC/BLDC Motor Closed Loop Standalone Firmware Defines	61
Table 7.2: Option Bytes Settings for ST7FMC Programming	62
Table 7.3: PMAC Motor Closed Loop Standalone Firmware Defines	66
Table 7.4: Three-Phase AC Motor Closed Loop Standalone Firmware Defines	70
Table 7.5: SBAC Motor Closed Loop Standalone Firmware Defines	74
Table 7.6: Open and Closed Loop Standalone Controls for a BLAC/BLDC Motor	77
Table 7.7: Open and Closed Loop Standalone Controls for a PMAC Motor	78
Table 7.8: Open and Closed Loop Standalone Controls for a Three-Phase AC Motor	79
Table 7.9: Open and Closed Loop Standalone Controls for a Single-Phase AC Motor	80
Table 7.10: Open and Closed Loop Standalone Controls for a Bi-Phase AC Motor	81
Table 7.11: Jumpers Summary	87
Table 7.12: Connectors Summary/Pinout	90
Table 7.13: Jumper Settings Example for a BLAC/BLDC Motor	94
Table 7.14: Jumper Settings Example for a PMAC Motor	95
Table 7.15: Jumper Settings Example for a Single-, Bi- or Three-Phase AC Motor	96
Table 8.1: AK-ST7FMC Control Panel: Motor Type Choice	100
Table 8.2: AK-ST7FMC Control Panel: BLAC/BLDC Trapezoidal Motor Main Settings	102
Table 8.3: AK-ST7FMC Control Panel: BLAC/BLDC Motor Start-Up Settings	106
Table 8.4: AK-ST7FMC Control Panel: BLAC/BLDC Motor Real-Time Settings	108
Table 8.5: AK-ST7FMC Control Panel: BLAC/BLDC Motor Advanced Settings	111
Table 8.6: AK-ST7FMC Control Panel: Power Board Settings	120
Table 8.7: AK-ST7FMC Control Panel: PMAC Motor Main Settings	123
Table 8.8: AK-ST7FMC Control Panel: PMAC Motor Voltage Limitation Settings	124
Table 8.9: AK-ST7FMC Control Panel: PMAC Motor Start-Up Settings	124
Table 8.10: AK-ST7FMC Control Panel: PMAC Motor Real-Time Settings	125
Table 8.11: AK-ST7FMC Control Panel: PMAC Motor Advanced Settings	127
Table 8.12: AK-ST7FMC Control Panel: PMAC Motor Ph/F Curve Settings	128
Table 8.13: AK-ST7FMC Control Panel: Three-Phase AC Motor Main Settings	130
Table 8.14: AK-ST7FMC Control Panel: Three-Phase AC Motor V/F Curve Settings	131
Table 8.15: AK-ST7FMC Control Panel: Three-Phase AC Motor Start-Up Settings	131
Table 8.16: AK-ST7FMC Control Panel: Three-Phase AC Motor Real-Time Settings	132
Table 8.17: AK-ST7FMC Control Panel: Three-Phase AC Motor Advanced Settings	135
Table 8.18: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor Main Settings	137
Table 8.19: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor V/F Curve Settings	138

Contents

Table 8.20: AK-ST7FMC Control Panel: Single- and Bi-Phase AC motor Start-Up Settings	138
Table 8.21: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor Real-Time Settings	139
Table 8.22: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor Advanced Settings	142
Table 9.1: Motor Control Board Electrical Specifications	143
Table 9.2: Optoisolation Board Electrical Specifications	143

0 Before Starting

0.1 Safety Warnings

0.1.1 General

In operation, the AK-ST7FMC Starter Kit has uninsulated wires, moving or rotating parts (when connected to a motor), as well as hot surfaces. In case of improper use, wrong installation or maloperation, there is danger of serious personal injury and damage to property. All operations, installation and maintenance are to be carried out by skilled technical personnel (national accident prevention rules must be observed).

When the Motor Control board is supplied with voltages greater than 30 V AC/DC, all of the board and components must be considered “hot”, and any contact with the board must be avoided. The operator should stay away from the board as well (risk of projection of material in case of components destruction, especially when powering the board with high voltages). The rotating parts of motors are also a source of danger.

The AK-ST7FMC Starter Kit contains electrostatic sensitive components which may be damaged through improper use.

0.1.2 Intended Use

The AK-ST7FMC Starter Kit is made of components designed for demonstration purposes and must not be included in electrical installations or machinery. Instructions about the setup and use of the AK-ST7FMC Starter Kit must be strictly observed.

0.1.3 Operation

After disconnecting the board from the voltage supply, several parts and power terminals must not be touched immediately because of possible energized capacitors or hot surfaces.

0.1.4 Important Notice to Users

While every effort has been made to ensure the accuracy of all information in this document, SofTec Microsystems assumes no liability to any party for any loss or damage caused by errors or omissions or by statements of any kind in this document, its updates, supplements, or special editions, whether such errors are omissions or statements resulting from negligence, accident, or any other cause.

0.2 Required Skills

In order to profitably use the AK-ST7FMC Starter Kit, you should be acquainted with several skills, ranging from hardware design to software design. In particular, you should possess the following knowledge:

- Electrical motor knowledge;
- Programming knowledge (Assembly and C);
- Microcontroller systems;
- ST7 architecture knowledge.

0.3 Credits

The AK-ST7FMC Start Kit has been developed by SofTec Microsystems together with STMicroelectronics. In particular, the Motor Control board has been developed by STMicroelectronics. A special thanks goes to the following people for contributing to this project and manual with ideas, technical information, diagrams.

Mr. Matteo Borini (SofTec Microsystems)
Mr. Federico Ceolin (SofTec Microsystems)
Mr. Jean-Marie Charreton (STMicroelectronics)
Mr. Gianluigi Forte (STMicroelectronics)
Mr. Arnaud Julienne (STMicroelectronics)
Mr. Vincent Onde (STMicroelectronics)
Mr. Loris Pacquola (SofTec Microsystems)

Mr. Eric Payet (STMicroelectronics)
Ms. Luisa Polesel (SofTec Microsystems)
Mr. Piero Poletto (SofTec Microsystems)
Mr. Gaetano Rasconà (STMicroelectronics)
Mr. Jawhar Turki (STMicroelectronics)
Mr. Thomas Vicenzotto (SofTec Microsystems)
Mr. Abdelkader Yeddes (STMicroelectronics)

This manual has been edited by Paolo Xausa (SofTec Microsystems).

1 Overview

1

1.1 What is the AK-ST7FMC Starter Kit?

The AK-ST7FMC Starter Kit is an integrated system designed to provide the user with a complete, ready-to-use motor control application. The Starter Kit is built around the STMicroelectronics ST7FMC microcontroller, which has a built-in, dedicated motor control peripheral. This peripheral is particularly suited to drive brushless motors (either induction or permanent magnet types). The Starter Kit demonstrates how effectively the ST7FMC family of microcontrollers can be used in real-world motor control applications.

The Starter Kit is composed of a Motor Control board, a three-phase, permanent-magnet, brushless DC (BLDC) motor, plus an in-circuit debugger board and an Optoisolation board.

The Motor Control board has a built-in power stage and is capable of directly driving both AC and DC motors.

The Starter Kit can be used in two ways:

1. **For demonstration purposes.** Connect your own motor and drive it. A graphical user interface (AK-ST7FMC Control Panel) is provided, which allows you to change all of the driving parameters.
2. **For user application development.** A complete, integrated development environment is provided, which allows you to write your own software, download it to the ST7FMC microcontroller and debug it.



Caution: *The AK-ST7FMC Starter Kit should only be used by engineers and technicians who are experienced in power electronics.*

1

1.2 ST7FMC Family Overview

The ST7FMC microcontroller family is designed for mid-range applications with a Motor Control dedicated peripheral. All devices are based on a common industry-standard 8-bit core, featuring an enhanced instruction set and are available with FLASH memory.

The ST7 Motor Controller peripheral (MTC) can be seen as a three-phase, pulse-width modulator multiplexed on six output channels and a Back Electromotive Force (BEMF) zero-crossing detector for sensorless control of Permanent Magnet Brushless Direct Current (BLDC) motors or Permanent Magnet Brushless Alternating Current (BLAC) motors driven by rectangular voltage strokes.

The MTC is particularly suited to driving brushless motors (either induction or permanent magnet types) and supports operating modes like:

- Commutation step control with motor voltage regulation and current limitation.
- Commutation step control with motor current regulation, i.e. direct torque control.
- Position sensor or sensorless motor phase commutation control (six-step mode).
- BEMF zero-crossing detection with high sensitivity. The integrated phase voltage comparator is directly referred to the full BEMF voltage without any attenuation. A BEMF voltage down to 200 mV can be detected, providing high noise immunity and self-commutated operation in a large speed range.
- Real-time motor winding demagnetization detection for fine-tuning the phase voltage masking time to be applied before BEMF monitoring.
- Automatic and programmable delay between BEMF zero-crossing detection and motor phase commutation.
- PWM generation for three-phase sinewave or three-channel independent PWM signals.

1.3 The Brushless AC (BLAC) or DC (BLDC) Motor

A brushless AC (BLAC) or DC (BLDC) motor is a rotating electric machine where the stator is a classic three-phase stator like that of an induction motor

and the rotor has surface-mounted permanent magnets. In this respect, the BLAC/BLDC motor is equivalent to a reversed AC or DC commutator motor, in which the magnet rotates while the conductors remain stationary. In the AC and DC commutator motors, the current polarity is altered by the commutator and brushes. On the contrary, in brushless AC and DC motors, the polarity reversal is performed by power transistors switching in synchronization with the rotor position. Therefore, BLAC/BLDC motors often incorporate either internal or external position sensors to sense the actual rotor position or the position can be detected without sensors.

The BLAC/BLDC motor is driven by rectangular voltage strokes coupled with the given rotor position. The generated stator flux interacts with the rotor flux, (which is generated by a rotor magnet) and defines the torque and thus speed of the motor. The voltage strokes must be properly applied to the two phases of the three-phase winding system so that the angle between the stator flux and the rotor flux is kept close to 90° to get the maximum generated torque. Due to this fact, the motor requires electronic control for proper operation.

1.4 The Brushless AC (PM Sinusoidal) Motor

The PMAC (Permanent Magnet Alternate Current) motors are very similar to BLDC motors. The stator is composed by three winding at 120° (like the AC induction motor), the rotor has surface-mounted permanent magnets, and the motor is specifically designed to be excited with a sinusoidal current waveform. The stator windings of the sinusoidal PMAC motor are typically distributed over multiple slots in order to approximate a sinusoidal distribution. The resulting BEMF waveforms generated by the sinusoidal PMAC motor are, in fact, sinusoidally shaped.

A PMAC motor can be excited with two driving methods: trapezoidal or sinusoidal. The main difference between the two types of driving is the acoustic noise generated. The abrupt variation of the trapezoidal phase current generally introduces a great amount of acoustic and electronic noise in comparison to the sinusoidal phase current. Usually, the reduction of noise when a PMAC motor is driven by a sinusoidal current is audibly noticeable, and the efficiency loss caused by the sinusoidal excitation is negligible.

Driving a PMAC motor requires that at least one rotor position sensor is used. The elimination of the position sensor in sinusoidal PMAC machines is more challenging since all three phases are continuously excited. This differs

in the 6-step BLDC method where one of the three phases is unexcited during each 60° electrical interval, making it possible to get information about BEMF zero crossing.

1.5 The Three-Phase AC Induction Motor

The AC induction motor is a rotating electric machine designed to operate from a three-phase source of alternating voltage. The stator is a classic three phase stator with the winding displaced by 120° . The most common type of induction motor has a squirrel cage rotor in which aluminum conductors or bars are shorted together at both ends of the rotor by cast aluminum end rings. When three currents flow through the three symmetrically placed windings, a sinusoidally distributed air gap flux generating the rotor current is produced. The interaction of the sinusoidally distributed air gap flux and induced rotor currents produces a torque on the rotor. The mechanical angular velocity of the rotor is lower than the angular velocity of the flux wave by so called slip velocity.

In adjustable speed applications, AC motors are powered by inverters. The inverter converts DC power to AC power at the required frequency and amplitude. The inverter consists of three half-bridge units where the upper and lower switches are controlled complementarily. As the power device's turn-off time is longer than its turn-on time, some dead-time must be inserted between the turn-off of one transistor of the half-bridge and turn-on of its complementary device. The output voltage is mostly created by a pulse width modulation (PWM) technique. The three-phase voltage waves are shifted 120° to each other and thus a three-phase motor can be supplied.

1.6 The Single-/Bi-Phase AC Induction Motor

The rotors in the single- and bi-phase AC induction motors are of the squirrel cage type.

The single phase (mono phase) AC induction motor usually is provided with an auxiliary winding (used for starting the motor) which (thanks to a capacitor) is driven with a current in quadrature with respect to that of the main phase. In this way, a starting torque is delivered during the starting phase of the motor. The capacitor can be excluded when a certain rotor speed is reached (in this case the motor behaves like a properly named

single phase motor) or kept permanently (in this case the motor works as a bi-phase motor).

In the bi-phase AC induction motor, the two permanent phases (a main winding and a secondary or auxiliary winding) are driven by two voltages with a phase difference of 90°.

1.7 Recommended Reading

This documentation describes how to use the AK-ST7FMC Starter Kit and how to set up basic debugging sessions with STMicroelectronics Visual Debug IDE together with the inDART-STX in-circuit debugger/programmer. Additional information can be found in the following documents:

- **ST7FMC Datasheets;**
- **STMicroelectronics Motor Control Application Notes;**
- **AK-ST7FMC Schematic;**
- **Visual Debug Additional Documentation;**
- **inDART-STX for ST7 User's Manual and User's Manual Addendum.**

All of the above documents (and many more) are present on the AK-ST7FMC “**System Software**” CD-ROM.

*Additionally, on the AK-ST7FMC “**System Software**” CD-ROM, an interactive tutorial on electric motors is present.*

1.8 Software Upgrades

The latest version of the AK-ST7FMC system software is always available free of charge from our website: <http://www.softecmicro.com>.

When installing the AK-ST7FMC system software you have the option to electronically register the product. If you register the product, you will be automatically notified by e-mail every time a new version of the AK-ST7FMC system software is available.

1.9 Troubleshooting

A troubleshooting guide is available online at <http://mcu.st.com/faq.html>.

1.10 Getting Technical Support

Technical assistance is provided free to all customers. For technical assistance, documentation and information about products and services, please refer to your local SofTec Microsystems partner.

SofTec Microsystems offers its customers a free technical support service at **support@softecmicro.com**. Before getting in contact with us, we advise you to check that you are working with the latest version of the AK-ST7FMC system software (upgrades are available free of charge at <http://www.softecmicro.com>).

Additional online support is available on the STMicroelectronics MCU Support Site (<http://mcu.st.com>).

For ST7FMC product information (datasheets, tools, application notes, etc.), please go to <http://mcu.st.com/devicedocs-ST7MC2N6-15.html>.

Knowledge base (FAQ) is available at <http://mcu.st.com/faq.html>.

To subscribe to automatic Motor Control updates please go to <http://mcu.st.com/modules.php?name=Subscription>.

STMicroelectronics also hosts a Motor Control forum at <http://mcu.st.com/forums.html>.

2 AK-ST7FMC Components

2.1 Package Checklist

The AK-ST7FMC package includes the following items:

- The Motor Control board (1).
- A BLDC motor (a 24 V DC AMETEK blower) (2).
- An in-circuit debugger/programmer (inDART-STX) (3).
- An Optoisolation board (code 237-00156) (4).
- An “Alternate Z Sampling” daughter board, to use (optionally) with BLAC/BLDC motors (code 237-00158) (5).
- Cables: motor cable (6), Optoisolation board’s power supply cable (7), USB Cable (8), ISP Cables (also called ICP cables in STMicroelectronics terminology) (9).
- The SofTec Microsystems AK-ST7FMC “System Software” CD-ROM.
- A “QuickStart Tutorial” color poster.
- The inDART-STX for ST7 user’s manual.
- This user’s manual.




Figure 2.1: AK-ST7FMC Hardware Components

2.2 The Motor Control Board

The following figure illustrates the main connectors and functions of the Motor Control board.




Figure 2.2: Motor Control Board

1. Motor and board input power stage, auxiliary power supply, and voltage rectification.
2. Prototype area.
3. RS-232 connector.
4. Push buttons and trimmers for standalone operation.
5. Hall sensors input.
6. Tachometer input for closed-loop controlled AC motors.
7. Three-phases outputs to motor.
8. ICC connector to isolation board, or directly to inDART-STX.

9. 10 A inverter and level shifter.

2.3 The BLDC Motor

2

The motor included in the AK-ST7FMC Starter Kit is an AMETEK 5" BLDC Low-Voltage (24 V DC) Blower.

For electrical specifications and mechanical dimensions please refer to the AMETEK datasheets present in the SofTec Microsystems AK-ST7FMC “**System Software**” CD-ROM.

2.4 The In-Circuit Debugger/Programmer (inDART-STX)

inDART-STX is a powerful entry-level tool for STMicroelectronics ST7-based systems. inDART-STX takes advantage of the STMicroelectronics STVD7 (STMicroelectronics Visual Debug) Integrated Development Environment and the ISP (In-System Programming) feature to program the FLASH memory of the microcontrollers belonging to the ST72F family. Together with STVD7, inDART-STX provides you with everything you need to write, compile, download, in-circuit emulate and debug user code. Full-speed program execution allows you to perform hardware and software testing in real time. inDART-STX is connected to the host PC through a USB port, while the 10-pin probe of the product fits into the target's standard ISP connector. A standalone, full-featured programming utility (DataBlaze) is also provided with inDART-STX.

inDART-STX is required to program and in-circuit debug (in real-time) the ST7FMC microcontroller present in the Motor Control board.

For more information on inDART-STX, please refer to the inDART-STX for ST7 User's Manual.

2.5 The Optoisolation board

The Optoisolation board's purpose is to provide galvanic isolation between the inDART-STX in-circuit debugger/programmer board and the Motor Control board. The inDART-STX ISP cable (also called ICP cable in

STMicroelectronics terminology) plugs into the Optoisolation board, while another ISP cable goes from the Optoisolation board to the Motor Control board's ICC connector. The Optoisolation board helps to prevent damage to the PC in the event of a catastrophic failure on the Motor Control board. This isolation barrier also solves the problem caused by the PC, inDART-STX and the Motor Control board being at different ground potentials.

2

2.6 The “Alternate Z Sampling” Daughter Board

When using a BLAC/BLDC motor the Motor Control board uses, by default, STMicroelectronics patented three-resistor method for BEMF detection. This method has the advantage of being implemented with few components, but has the drawback of limiting the maximum duty cycle of the PWM signal applied to the power switches.

If a specific application requires a 100% PWM duty cycle, the “classical” BEMF detection method must be implemented.

The “Alternate Z Sampling” daughter board allows to drive a BLAC/BLDC motor using the classical BEMF detection circuit. The daughter board plugs into the J11 connector and into the W14, W15 and W16 jumpers of the Motor Control board.

Of course, motor-specific resistors and capacitors must be mounted on the daughter board.

For detailed information, please refer to STMicroelectronics' AN1946 Application Note.

3 Getting Started for Three-Phase BLAC/BLDC Motors

3.1 Introduction

The Motor Control board is interfaced to a host PC via the inDART-STX in-circuit debugger/programmer. A control panel application is provided which allows you to change (in real time) all of the motor's electrical parameters. In this way it is possible to learn all of the possibilities offered by the ST7FMC integrated motor control peripheral.

3



Caution: *before supplying the board, double check proper connections, make sure that there are no metal parts on, below or around the PCB and that there are no undesired earth/ground loops due to measuring equipment such as oscilloscope.*

3.2 Step-by-Step Tutorial

3.2.1 Tools Required

For this tutorial, you need:

- The Motor Control board together with the provided BLDC motor;
- The inDART-STX in-circuit debugger/programmer;
- The Optoisolation board;
- A 24 V DC, 4 A power supply (not provided with the Starter Kit).

3.2.2 Installing the Software

Note: *before to connect the inDART-STX board to the PC, it is recommended that you install the AK-ST7FMC Control Panel application first (see below), so that the inDART-STX USB driver will be automatically found by Windows when you connect the board.*

3

To install the AK-ST7FMC Control Panel, insert the SofTec Microsystems “**System Software**” CD-ROM into your computer’s CD-ROM drive. A startup window will automatically appear. Choose “**Install Instrument Software**” from the main menu. A list of available software will appear. Click on the “**AK-ST7FMC Control Panel**” option. Follow the on-screen instructions.

Note: *if you are installing the AK-ST7FMC Control Panel on Windows 2000 or Windows XP you must have logged in as Administrator.*

3.2.3 Installing the Hardware

Connection steps are listed below in the recommended flow order:

1. Verify that all of the Motor Control board jumpers are in their default position (as detailed in “Table 7.13: Jumper Settings Example for a BLAC/BLDC Motor” on page 94).
2. The Motor Control board and the provided BLDC motor come assembled together over a metal support. Verify that the motor cable is correctly connected between the Motor Control board’s “MOTOR” connector (J12) and the motor terminal connector.
3. The Motor Control board and the Optoisolation board come already connected through an ISP cable. Moreover, the Optoisolation board’s power connector is also already connected to the Motor Control board’s J2 connector. In this way, the Motor Control board automatically supplies the Optoisolation board. Verify that both the power cable and the ISP cable are connected as stated above.

4. Connect inDART-STX to the Optoisolation board with the other ISP cable provided (from inDART-STX's "ISP" connector to the Optoisolation board's "ICC IN" connector).
5. Connect inDART-STX to the host PC with the USB cable provided. The green "POWER" LED on the instrument will turn on. Windows will automatically recognize the instrument and will load the appropriate USB driver.
6. Power up the Motor Control board by connecting the output terminals of your DC power supply to the "MAINS" connector. The provided voltage must be 24 V DC and your power supply must be able to provide a minimum current of 4 A.

Note: *both Windows 2000 and Windows XP may issue a warning the first time inDART-STX is connected to the PC. This warning is related to the fact that the USB driver used by inDART-STX is not digitally signed by Microsoft, and Windows considers it to be potentially malfunctioning or dangerous for the system. However, you can safely ignore the warning, since every kind of compatibility/security test has been carried out by SofTec Microsystems.*

3

3.2.4 Tutorial Steps

1. Start the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**. The AK-ST7FMC Control Panel application will open.
2. You will be asked what motor type you are working with. Select the **"3 Phase BLAC/BLDC Motor (Trapezoidal)"** option and click the **"OK"** button.




Figure 3.1: Motor Type Choice Dialog Box

3

3. A dialog box will appear asking you to check for proper jumpers configuration. Click the **“OK”** button.
4. The AK-ST7FMC Control Panel main window will open.




Figure 3.2: AK-ST7FMC Control Panel Main Window for BLAC/BLDC Motors

5. Change the “**Speed Regulation**” parameter to “**Closed Loop**” and click the “**START**” button. A firmware will be automatically created based on all of the AK-ST7FMC Control Panel's parameter and downloaded to the ST7FMC microcontroller in the Motor Control board. At the end of the download phase the motor will start to run.
6. Change the “**Target Mechanical Speed**” parameter to **5000** by typing in the new value and pressing the Enter key. The new parameter will be downloaded to the ST7FMC microcontroller in real time and the motor will accelerate.
7. Click the “**STOP**” button to stop the motor.

Congratulations! You have successfully completed this tutorial! You can now continue to experiment with the AK-ST7FMC Control Panel on your own.

Additionally, you can develop and debug your own application by installing the “inDART-STX for ST7” software (which includes a complete development toolchain) present on the SofTec Microsystems “**System Software**” CD-ROM.

4 Getting Started for PMAC Motors

4.1 Introduction

The Motor Control board is interfaced to a host PC via the inDART-STX in-circuit debugger/programmer. A control panel application is provided which allows you to change (in real time) all of the motor's electrical parameters. In this way it is possible to learn all of the possibilities offered by the ST7FMC integrated motor control peripheral.



Caution: *before supplying the board, double check proper connections, make sure that there are no metal parts on, below or around the PCB and that there are no undesired earth/ground loops due to measuring equipment such as oscilloscope.*



Caution: *when the Motor Control board is supplied with voltages greater than 30 V AC/DC, all of the board and components must be considered "hot", and any contact with the board must be avoided. The operator should stay away from the board as well (risk of projection of material in case of components destruction, especially when powering the board with high voltages). The rotating parts of motors are also a source of danger.*

4.2 Step-by-Step Tutorial

4.2.1 Tools Required

For this tutorial, you need:

- The Motor Control board together with the provided BLDC motor (used as a PMAC motor);
- The inDART-STX in-circuit debugger/programmer;
- The Optoisolation board.

4

4.2.2 Installing the Software

Note: *before to connect the inDART-STX board to the PC, it is recommended that you install the AK-ST7FMC Control Panel application (see below), so that the inDART-STX USB driver will be automatically found by Windows when you connect the board.*

To install the AK-ST7FMC Control Panel, insert the SofTec Microsystems “**System Software**” CD-ROM into your computer’s CD-ROM drive. A startup window will automatically appear. Choose “**Install Instrument Software**” from the main menu. A list of available software will appear. Click on the “**AK-ST7FMC Control Panel**” option. Follow the on-screen instructions.

Note: *if you are installing the AK-ST7FMC Control Panel on Windows 2000 or Windows XP you must have logged in as Administrator.*

4.2.3 Installing the Hardware

Connection steps are listed below in the recommended flow order:

1. Verify that all of the Motor Control board jumpers are set up to use with an PMAC motor (as explained in “Table 7.14: Jumper Settings Example for a PMAC Motor” on page 95).
2. The Motor Control board and the provided BLDC motor (in this case used as PMAC) come assembled together over a metal support. Verify that the motor cable is correctly connected between the Motor Control board’s “MOTOR” connector (J12) and the motor terminal connector and the “HALL SENSOR” connector (J19) with the Hall sensor cable provided with the motor.
3. The Motor Control board and the Optoisolation board come already connected through an ISP cable. Moreover, the Optoisolation board’s power connector is also already connected to the Motor Control board’s J2 connector. In this way, the Motor Control board automatically supplies the Optoisolation board. Verify that both the power cable and the ISP cable are connected as stated above.
4. Connect inDART-STX to the Optoisolation board with the other ISP cable provided (from inDART-STX’s “ISP” connector to the Optoisolation board’s “ICC IN” connector).
5. Connect inDART-STX to the host PC with the USB cable provided. The green “POWER” LED on the instrument will turn on. Windows will automatically recognize the instrument and will load the appropriate USB driver.
6. Make sure that the “S1” jumper selects the “<35V ONLY” position, then power up the Motor Control board by connecting the output terminals of your DC power supply to the “MAINS” connector. The provided voltage must be 30 V DC and your power supply must be able to provide a minimum current of 3 A.

Note: *both Windows 2000 and Windows XP may issue a warning the first time inDART-STX is connected to the PC. This warning is related to the fact that the USB driver used by inDART-STX is not digitally signed by Microsoft, and Windows considers it to be potentially malfunctioning or dangerous for the system. However, you can safely ignore the warning, since every kind of compatibility/security test has been carried out by SofTec Microsystems.*

4.2.4 Tutorial Steps

4

1. Start the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**. The AK-ST7FMC Control Panel application will open.
2. You will be asked what motor type you are working with. Select the **“3 Phase PMAC Motor (Sinewave)”** option and click the **“OK”** button.
3. A dialog box will appear asking you to check for proper jumpers configuration. Click the **“OK”** button.
4. The AK-ST7FMC Control Panel main window will open.




Figure 4.1: AK-ST7FMC Control Panel Main Window for PMAC Motors

5. Click the **“START”** button. A firmware will be automatically created based on all of the AK-ST7FMC Control Panel's parameter and downloaded to the ST7FMC microcontroller in the Motor Control board. At the end of the download phase the motor will start to run.
6. Change the **“Stator Voltage”** parameter to **150** by typing in the new value and pressing the Enter key. The new parameter will be downloaded to the ST7FMC microcontroller in real time and the motor will accelerate.
7. Click the **“STOP”** button to stop the motor.

Congratulations! You have successfully completed this tutorial! You can now continue to experiment with the AK-ST7FMC Control Panel on your own.

Additionally, you can develop and debug your own application by installing the “inDART-STX for ST7” software (which includes a complete development toolchain) present on the SofTec Microsystems “**System Software**” CD-ROM.

5 Getting Started for Three-Phase AC Motors

5.1 Introduction

The Motor Control board is interfaced to a host PC via the inDART-STX in-circuit debugger/programmer. A control panel application is provided which allows you to change (in real time) all of the motor's electrical parameters. In this way it is possible to learn all of the possibilities offered by the ST7FMC integrated motor control peripheral.



Caution: *before supplying the board, double check proper connections, make sure that there are no metal parts on, below or around the PCB and that there are no undesired earth/ground loops due to measuring equipment such as oscilloscope.*

5

Caution: *when the Motor Control board is supplied with voltages greater than 30 V AC/DC, all of the board and components must be considered “hot”, and any contact with the board must be avoided. The operator should stay away from the board as well (risk of projection of material in case of components destruction, especially when powering the board with high voltages). The rotating parts of motors are also a source of danger.*

5.2 Step-by-Step Tutorial

5.2.1 Tools Required

For this tutorial, you need:

- The Motor Control board;
- The three-phase, SELNI AC motor (available as an accessory—SofTec Microsystems order code 237-00157);
- The inDART-STX in-circuit debugger/programmer;
- The Optoisolation board.

5.2.2 Installing the Software

5

Note: *before to connect the inDART-STX board to the PC, it is recommended that you install the AK-ST7FMC Control Panel application (see below), so that the inDART-STX USB driver will be automatically found by Windows when you connect the board.*

To install the AK-ST7FMC Control Panel, insert the SofTec Microsystems “**System Software**” CD-ROM into your computer’s CD-ROM drive. A startup window will automatically appear. Choose “**Install Instrument Software**” from the main menu. A list of available software will appear. Click on the “**AK-ST7FMC Control Panel**” option. Follow the on-screen instructions.

Note: *if you are installing the AK-ST7FMC Control Panel on Windows 2000 or Windows XP you must have logged in as Administrator.*

5.2.3 Installing the Hardware

Connection steps are listed below in the recommended flow order:

1. Verify that all of the Motor Control board jumpers are set up to use with an AC motor (as explained in “Table 7.15: Jumper Settings Example for a Single-, Bi- or Three-Phase AC Motor” on page 96).
2. The Motor Control board and the provided BLDC motor come assembled together over a metal support. To use the AC motor you must first disconnect the BLDC motor cable from the “MOTOR” connector (J12) and from the “HALL SENSOR” connector (J19).
3. Connect the AC motor phases to the Motor Control board’s “MOTOR” connector (J12) with the motor cable provided with the AC motor.
4. Connect the AC motor tachometer sensor to the Motor Control board’s “TACHOMETER” connector (J16) with the tachometer cable provided with the AC motor.
5. The Motor Control board and the Optoisolation board come already connected through an ISP cable. Moreover, the Optoisolation board’s power connector is also already connected to the Motor Control board’s J2 connector. In this way, the Motor Control board automatically supplies the Optoisolation board. Verify that both the power cable and the ISP cable are connected as stated above.
6. Connect inDART-STX to the Optoisolation board with the other ISP cable provided (from inDART-STX’s “ISP” connector to the Optoisolation board’s “ICC IN” connector).
7. Connect inDART-STX to the host PC with the USB cable provided. The green “POWER” LED on the instrument will turn on. Windows will automatically recognize the instrument and will load the appropriate USB driver.
8. Make sure that the “S1” jumper selects the “<35V ONLY” position, then power up the Motor Control board by connecting the output terminals of your DC power supply to the “MAINS” connector. The provided voltage must be 30 V DC and your power supply must be able to provide a minimum current of 4 A.

Note: *both Windows 2000 and Windows XP may issue a warning the first time inDART-STX is connected to the PC. This warning is related to the fact that the USB driver used by inDART-STX is not digitally signed by Microsoft, and Windows considers it to be potentially malfunctioning or dangerous for the system. However, you can safely ignore the warning, since every kind of compatibility/security test has been carried out by SofTec Microsystems.*

5.2.4 Tutorial Steps

1. Start the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**. The AK-ST7FMC Control Panel application will open.
2. You will be asked what motor type you are working with. Select the “**3 Phase AC Induction Motor (Sinewave)**” option and click the “**OK**” button.
3. A dialog box will appear asking you to check for proper jumpers configuration. Click the “**OK**” button.
4. The AK-ST7FMC Control Panel main window will open.




Figure 4.2: AK-ST7FMC Control Panel Main Window for Three-Phase AC Motors

5. Click the **“START”** button. A firmware will be automatically created based on all of the AK-ST7FMC Control Panel's parameter and downloaded to the ST7FMC microcontroller in the Motor Control board. At the end of the download phase the motor will start to run.
6. Change the **“Target Rotational Frequency”** parameter to **40** by typing in the new value and pressing the Enter key. The new parameter will be downloaded to the ST7FMC microcontroller in real time and the motor will accelerate.
7. Click the **“STOP”** button to stop the motor.

Congratulations! You have successfully completed this tutorial! You can now continue to experiment with the AK-ST7FMC Control Panel on your own.

Additionally, you can develop and debug your own application by installing the “inDART-STX for ST7” software (which includes a complete development toolchain) present on the SofTec Microsystems “**System Software**” CD-ROM.

6 Getting Started for Single- and Bi-Phase AC Motors

6.1 Introduction

The Motor Control board is interfaced to a host PC via the inDART-STX in-circuit debugger/programmer. A control panel application is provided which allows you to change (in real time) all of the motor's electrical parameters. In this way it is possible to learn all of the possibilities offered by the ST7FMC integrated motor control peripheral.



Caution: *before supplying the board, double check proper connections, make sure that there are no metal parts on, below or around the PCB and that there are no undesired earth/ground loops due to measuring equipment such as oscilloscope.*



Caution: *when the Motor Control board is supplied with voltages greater than 30 V AC/DC, all of the board and components must be considered “hot”, and any contact with the board must be avoided. The operator should stay away from the board as well (risk of projection of material in case of components destruction, especially when powering the board with high voltages). The rotating parts of motors are also a source of danger.*

6.2 Step-by-Step Tutorial

6.2.1 Tools Required

For this tutorial, you need:

- The Motor Control board;
- A single-phase or a bi-phase motor (not included in the Starter Kit);
- The inDART-STX in-circuit debugger/programmer;
- The Optoisolation board.

Note: you can use either a single-phase motor or a bi-phase motor. Be aware on the internal/external electrical motor characteristics (including the wirings and the eventual external capacitor for single-phase motors). A typical single-phase motor (including a split capacitor) has only two wires that should be connected opportunely to the Motor Control board connector. Similarly, a bi-phase motor has three available wires: one representing the 'common' between the two phases, a main winding and a secondary (or auxiliary) one. Also in this case, the wires have to be connected to the Motor Control Board in the proper way. See below for details on how to connect these motors to the board.




Figure 6.1: Typical Single-Phase AC Motor Connection




Figure 6.2: Typical Bi-Phase AC Motor Connection

Note: for practicing purposes, the SELNI motor, not included in the Starter Kit, can be used as a single-phase or bi-phase motor as well, with some limitations and restrictions:

- In single-phase configuration, a 4 μF , high voltage capacitor (400 V) must be connected between two of the three phase wires available from the motor. One of these two wires, together with the third one (not connected to the capacitor) has to be inserted into connector J12 at pin 2 and pin 3 (phase A and B, respectively).
- In bi-phase configuration, connect the SELNI motor to Starter Kit as a three-phase motor.

This allows you to practice with single- or bi-phase motor driving, even though the solutions outlined above are not efficient ways of driving those motors.

6

6.2.2 Installing the Software

Note: before to connect the inDART-STX board to the PC, it is recommended that you install the AK-ST7FMC Control Panel application (see below), so that the inDART-STX USB driver will be automatically found by Windows when you connect the board.

To install the AK-ST7FMC Control Panel, insert the SofTec Microsystems **“System Software”** CD-ROM into your computer's CD-ROM drive. A startup window will automatically appear. Choose **“Install Instrument Software”** from the main menu. A list of available software will appear. Click on the **“AK-ST7FMC Control Panel”** option. Follow the on-screen instructions.

Note: *if you are installing the AK-ST7FMC Control Panel on Windows 2000 or Windows XP you must have logged in as Administrator.*

6.2.3 Installing the Hardware

Connection steps are listed below in the recommended flow order:

1. Verify that all of the Motor Control board jumpers are set up to use with a three-phase AC motor (as explained in “Table 7.15: Jumper Settings Example for a Single-, Bi- or Three-Phase AC Motor” on page 96).
2. The Motor Control board and the provided BLDC motor come assembled together over a metal support. To use the single/two-phase AC motor you must first disconnect the BLDC motor cable from the “MOTOR” connector (J12) and from the “HALL SENSOR” connector (J19).
3. For a single-phase motor, connect the two available motor wires (in no particular order) to the pins 2 (phase A) and 3 (phase B) of the Motor Control board's “MOTOR” connector (J12).
4. For a bi-phase motor, connect the common wire to pin 3 (B phase) of the Motor Control board's “MOTOR” connector (J12), the main winding to pin 2 (A phase) and the secondary winding to pin 1 (C phase).
5. Connect the AC motor tachometer sensor to the Motor Control board's “TACHOMETER” connector (J16) with the tachometer cable provided with the AC motor.
6. The Motor Control board and the Optoisolation board come already connected through an ISP cable. Moreover, the Optoisolation board's power connector is also already connected to the Motor Control board's J2 connector. In this way, the Motor Control board automatically

- supplies the Optoisolation board. Verify that both the power cable and the ISP cable are connected as stated above.
7. Connect inDART-STX to the Optoisolation board with the other ISP cable provided (from inDART-STX's "ISP" connector to the Optoisolation board's "ICC IN" connector).
 8. Connect inDART-STX to the host PC with the USB cable provided. The green "POWER" LED on the instrument will turn on. Windows will automatically recognize the instrument and will load the appropriate USB driver.
 9. Make sure that the "S1" jumper selects the "<35V ONLY" position, then power up the Motor Control board by connecting the output terminals of your DC power supply to the "MAINS" connector. The provided voltage must be 30 V DC and your power supply must be able to provide a current of 4 A.

Note: *both Windows 2000 and Windows XP may issue a warning the first time inDART-STX is connected to the PC. This warning is related to the fact that the USB driver used by inDART-STX is not digitally signed by Microsoft, and Windows considers it to be potentially malfunctioning or dangerous for the system. However, you can safely ignore the warning, since every kind of compatibility/security test has been carried out by SofTec Microsystems.*

6.2.4 Tutorial Steps (for a Single-Phase Motor)

1. Start the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**. The AK-ST7FMC Control Panel application will open.
2. You will be asked what motor type you are working with. Select the **"Single and Bi-Phase AC Induction Motor (Sinewave)"** option and click the **"OK"** button.
3. A dialog box will appear asking you to check for proper jumpers configuration. Click the **"OK"** button.
4. Make sure that the **"Single-Phase"** option is selected in the **"Motor Type"** settings.
5. The AK-ST7FMC Control Panel main window will open.




Figure 6.3: AK-ST7FMC Control Panel Main Window for Single-Phase AC Motors

6. Click the **“START”** button. A firmware will be automatically created based on all of the AK-ST7FMC Control Panel's parameter and downloaded to the ST7FMC microcontroller in the Motor Control board. At the end of the download phase the motor will start to run.
7. Change the **“Main Voltage”** parameter to **40** by typing in the new value and pressing the Enter key. The new parameter will be downloaded to the ST7FMC microcontroller in real time and the motor will accelerate.
8. Click the **“STOP”** button to stop the motor.

Note: the SELNI motor configured as single-phase motor (see note on paragraph 6.2.1) is not able to self-starting at 30 V when the “**START**” button is pressed. In this case, it is better to provide a manual start-up by rotating the motor shaft with the hand as soon as the “**START**” button has been pressed.

Note: the default parameters in the AK-ST7FMC Control Panel are suitable for driving the optional SELNI motor. The V/f curve and/or voltage level may therefore not be suited for your own single-phase motor. Several trials with increasing voltage levels will then be needed to start-up and run your motor.

6.2.5 Tutorial Steps (for a Bi-Phase Motor)

1. Start the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**. The AK-ST7FMC Control Panel application will open.
2. You will be asked what motor type you are working with. Select the “**Single and Bi-Phase AC Induction Motor (Sinewave)**” option and click the “**OK**” button.
3. A dialog box will appear asking you to check for proper jumpers configuration. Click the “**OK**” button.
4. The AK-ST7FMC Control Panel main window will open.
5. Make sure that the “**Bi-Phase**” option is selected in the “**Motor Type**” settings.




Figure 6.4: AK-ST7FMC Control Panel Main Window for Bi-Phase AC Motors

6. Click the **“START”** button. A firmware will be automatically created based on all of the AK-ST7FMC Control Panel’s parameter and downloaded to the ST7FMC microcontroller in the Motor Control board. At the end of the download phase the motor will start to run.
7. Change the **“Main Voltage”** parameter to **40** by typing in the new value and pressing the Enter key. The new parameter will be downloaded to the ST7FMC microcontroller in real time and the motor will accelerate.
8. Click the **“STOP”** button to stop the motor.

Note: *the default parameters in the AK-ST7FMC Control Panel are suitable for driving the optional SELNI motor. The V/f curve and/or voltage level may therefore not be suited for your own single-phase motor. Several trials with increasing voltage levels will then be needed to start-up and run your motor.*

Congratulations! You have successfully completed this tutorial! You can now continue to experiment with the AK-ST7FMC Control Panel on your own.

Additionally, you can develop and debug your own application by installing the “inDART-STX for ST7” software (which includes a complete development toolchain) present on the SofTec Microsystems “**System Software**” CD-ROM.

7 Connectors and Functions

7.1 Power Supply

7.1.1 Introduction

The Motor Control board can be supplied in two ways:

- **Single power supply (for motors requiring a voltage greater than 18 V).**

Power is supplied to the J3 connector. Power supply voltage must not be higher than 42 V DC or 30 Veff AC. This power supplies both the motor and the Motor Control board. A 15 V DC voltage is automatically generated for the Motor Control board logic. However, depending on the voltage supplied to the J3 connector, two cases are possible:

1. If the supplied voltage is greater than 35 V DC, the S1 jumper must select the “HIGH VOLTAGE” position;
2. If the supplied voltage is between 18 V and 35 V DC, the S1 jumper must select the “<35V ONLY” position.

- **Dual power supply (for motors requiring a voltage less than 18 V).**

Power for the motor is supplied to the J3 connector, while a separate power for the Motor Control board logic must be supplied to the J1 connector (15 V DC, 0.5 A). **The S1 jumper must be removed.**

Note: on the J3 connector, polarity of DC or AC input is not important.

7.1.2 Optoisolation Board Supply

The Optoisolation board requires a 15 V DC power supply. This power is conveniently provided by the Motor Control board's J2 connector.

Note: J1 and J2 connectors are internally connected to the same 15 V DC power bus.

7.1.3 Power Supply Connectors Summary

The following figure illustrates the location of the Motor Control board power supply connectors.




Figure 7.1: Power Supply Connectors

1. J1 connector. 15 V DC, 0.5 A power supply input (used for dual power supply mode).
2. J2 connector. 15 V DC output to Optoisolation board.
3. J3 connector. Motor power supply (for dual power supply mode) or motor plus Motor Control board power supply (for single power supply mode). Up to 42 V DC or 30 Veff AC.

4. S1 jumper. In single power supply mode, selects the motor voltage. In dual power supply mode, it must be removed.

7.2 Push-Buttons and Potentiometers (Standalone Mode)

7.2.1 Introduction

Four potentiometers and two push-buttons are available on the Motor Control board for standalone operation (no PC connection required). To operate the Motor Control board in standalone mode, several steps must be completed to ensure compatibility between the ST7FMC firmware and the push-buttons and potentiometers.

7.2.2 Preparing for Standalone Mode: General Notes

The steps below must be followed to generate the correct firmware to use the Motor Control board in standalone mode. Please note that the firmware is motor-specific. After generating (and downloading to the ST7FMC microcontroller) the appropriate firmware for the type of motor and the type of control you want to use, the push-buttons and potentiometers are available for use in standalone mode, as explained later.

Note: the following steps require that the *inDART-STX for ST7 System Software* be installed.

To install the *inDART-STX for ST7 System Software*, insert the SofTec Microsystems “**System Software**” CD-ROM into your computer’s CD-ROM drive. A startup window will automatically appear. Choose “**Install Instrument Software**” from the main menu. A list of available software will appear. Click on the “**inDART-STX for ST7**” option. Follow the on-screen instructions.

Note: most of the configurations of the STMicroelectronics Motor Control library can be compiled using the free, 4 KB version of the Cosmic or Metrowerks compilers. Alternatively, It is also possible to download the 16 KB free version or to contact Cosmic or Metrowerks via email to get a full-featured, time-limited evaluation version of the ST7 C compiler:

- For Cosmic: sales@cosmic.fr
- For Metrowerks: license@metrowerks.com

Note: it is recommended to read carefully the release notes of the motor control library that will be used for your project, and ensure that you have the latest library version (available for free at <http://mcu.st.com>, in the software/microcontroller section).

7.2.3 Preparing for Standalone Mode: BLAC/BLDC Motors

1. Set up the Motor Control board as explained in the “Installing the Hardware” section in the “Getting Started for BLDC Motors” chapter.
2. Get the latest release of the AK-ST7FMC Control Panel system software from SofTec Microsystems website (<http://www.softecmicro.com>), uninstall the previous version and install the new one.
3. In the “**Program Files\SofTec Microsystems\AK-ST7FMC\Library**” directory there are various subdirectories, each specific for a motor/control type (e.g. “BLAC/BLDC Sensorless”). Each subdirectory contains a pre-made project specific for that motor/control type. Copy the appropriate subdirectory (the subdirectory that corresponds to your motor and control type) into another location. The copied subdirectory will become your working directory. The folder “**BLDC_3PH_SL_2.0**” is relative to Sensorless driving mode, whereas the folder “**BLDC_3PH_SR_2.0**” is relative to Sensor driving mode.
4. Run the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**.

5. You will be asked what motor type you are working with. Select the “**3 Phase BLAC/BLDC Motor (Trapezoidal)**” option and click the “**OK**” button. The main AK-ST7FMC Control Panel window will open.
6. To run a BLAC/BLDC motor in standalone mode (Closed Loop), you must choose an optimum sampling time and collect, for each of four critical speeds, a set of real-time parameters (rising BEMF delay, falling BEMF delay, Ki and Kp). These parameters must be fine tuned for the minimum and maximum motor speed (the same speeds specified in the “**Advanced Settings**” dialog box) plus two other intermediate speeds of your choice. During operation, the ST7FMC firmware will make a linear extrapolation of real-time parameters in between the four specified speeds to ensure smooth operation (for more information about parameter collecting, refer to the STMicroelectronics’ Application Note AN1905).




Figure 7.2: BLAC/BLDC Motor Closed Loop Parameters Collecting

7. To run a BLAC/BLDC motor in standalone mode (Open Loop), it is not necessary to collect any real-time settings, since all real-time parameters are controlled through the potentiometers.
8. Click the “**Generate Source Files...**” button. Browse for your working directory and select the “**\source**” subdirectory. Click the “**OK**” button. The appropriate header files will be generated and saved in the “**\source**” subdirectory as *.h files. All parameters set in the AK-ST7FMC Control Panel (other than the real-time parameters listed in point 6) are saved automatically in the *.h files.

9. Run the STVD7 IDE by selecting **Start > Programs > SofTec Microsystems > inDART-STX > ST7 > STVD7 for inDART-STX**.
10. From the main menu, choose **File > Open Workspace**. Select the “**BLDC_3PH_SR.stw**” workspace file for Sensor mode (or “**BLDC_3PH_SL.stw**” for Sensorless mode) that is located under your working directory. Click “**Open**”.
11. Only in the case of Closed Loop control, some defines in the “**mtc.h**” file must be edited according to the collected parameters. The defines to be edited are listed in the following table.

Table 7.1: BLAC/BLDC Motor Closed Loop Standalone Firmware Defines

BLAC/BLDC Motor-Specific Defines to Be Edited
#define SAMPLING_TIME
#define Rising_Fmin
#define Falling_Fmin
#define Ki_Fmin
#define Kp_Fmin
#define F_1
#define Rising_F_1
#define Falling_F_1
#define Ki_F_1
#define Kp_F_1
#define F_2
#define Rising_F_2
#define Falling_F_2
#define Ki_F_2
#define Kp_F_2
#define Rising_Fmax
#define Falling_Fmax
#define Ki_Fmax
#define Kp_Fmax

12. From the main menu, choose **Build > Configurations** for selecting the active project, according to the compiler being used:
 - When using the Cosmic compiler, “**ac_3ph_sr_csmc**” (or “**ac_3ph_sl_csmc**” for Sensorless mode) has to be selected;
 - When using the Metrowerks 1.1 compiler, “**ac_3ph_sr_mwks**” (or “**ac_3ph_sl_mwks**” for Sensorless mode) has to be selected.

Then choose “**Release**” in the **Configuration** list box. Afterward, by pressing the “**Set Active**” button, the selected project will become the active one. Press the “**Close**” button to close the “**Project Configurations**” dialog box.

Note: *if the 4 KB limited version of the Cosmic compiler is used, the “**Release**” configuration is the only choice that allows to compile the project. In this case it is not possible to proceed with any debugging session.*

13. Select the “**Build**” command from the “**Build**” menu. The project will be compiled and built, and an executable file will be generated in the “**\Release**” folder with an “**.s19**” extension.
14. You can now program the ST7FMC microcontroller with the generated executable. In the main menu select **Debug > Start Debugging** and then press the “**OK**” button in the “**Target Selection**” dialog box (“**STX-Indart**” is the only choice).
15. In the “**MCU Configuration**” dialog box select “**inDART-STX**” as the “**Hw Model**” and specify “**ST7FMC2N6**” as “**Device Code**”. Then, select the proper values for the **Option Bytes** as detailed in the table below.

Table 7.2: Option Bytes Settings for ST7FMC Programming

Option Bits	Setting
[FMP_R] - Read-Out Protection	Read-Out Protection Disabled
[DIV2] - Divider by 2	DIV2 divider enabled
[RSTC] - RESET Clock Cycle Selection	Reset phase with 4096 CPU cycles
[VD] - Voltage Detection Selection	LVD and AVD On
[CKSEL] - Clock Source Selection	PLL clock selected
[WDG_SW] - Watchdog Activation	Software
[WDG_HALT] - Watchdog and Halt Mode	Reset in HALT
[MCO] - Motor Control Output Options	Low
[PKG] - Package Selection	SDIP56

16. From the main menu choose **Debug Instrument > Program** and set all the parameters according to the screen shot reported below:




Figure 7.3: Program Dialog Box

17. By pressing the **“Start”** button the firmware is downloaded to the microcontroller. If the programming phase is completed correctly, the message **“Device successfully programmed”** will be displayed.
18. Now the microcontroller is programmed. You can unplug the ISP cable from the Motor Control board and operate the Motor Control board in standalone mode.
19. To start running the microcontroller, press the **“RESET”** push-button. For details about how to control the motor with the Motor Control board's push-buttons and potentiometers, please refer to the “Push-Buttons”, “Potentiometers” and “Standalone Mode: Driving a BLDC Motor” sections later in this chapter.

7.2.4 Preparing for Standalone Mode: PMAC Motors

1. Set up the Motor Control board as explained in the “Installing the Hardware” section in the “Getting Started for PMAC Motors” chapter.
2. Get the latest release of the AK-ST7FMC Control Panel system software from SofTec Microsystems website (<http://www.softecmicro.com>), uninstall the previous version and install the new one.
3. In the **“\Program Files\SofTec Microsystems\AK-ST7FMC\Library”** directory there are various subdirectories, each specific for a motor/control type. Each subdirectory contains a pre-made project

specific for that motor/control type. Copy the appropriate subdirectory (the subdirectory that corresponds to your motor and control type) into another location. The copied subdirectory will become your working directory.

4. Run the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**.
5. You will be asked what motor type you are working with. Select the “**3 Phase PMAC Motor (Sinewave)**” option and click the “**OK**” button. The main AK-ST7FMC Control Panel window will open.
6. To run a PMAC motor in standalone mode (Closed Loop), you must choose an optimum sampling time and then characterize two curves, a K_i , K_p versus stator frequency curve and a phase shift versus stator frequency curve. Both curves must have two points, as illustrated below.




Figure 7.4: PMAC Motor Closed Loop Parameters Collecting: K_i , K_p




Figure 7.5: PMAC Motor Closed Loop Parameters Collecting: Phase Shift

7. To run an PMAC motor in standalone mode (Open Loop), it is not necessary to collect any real-time settings, since all real-time parameters are controlled through the potentiometers.
8. Click the **“Generate Source Files...”** button. Browse for your working directory and select the **“\source”** subdirectory. Click the **“OK”** button. The appropriate header files will be generated.
9. Run the STVD7 IDE by selecting **Start > Programs > SofTec Microsystems > inDART-STX > ST7 > STVD7 for inDART-STX**.
10. From the main menu, choose **File > Open Workspace**. Select the **“PMAC_3PH_SR.stw”** workspace file that is located under your working directory. Click **“Open”**.
11. Only in the case of Closed Loop control, some defines in the **“PMACParam.h”** file must be edited according to the collected parameters. The defines to be edited are listed in the following table.

Table 7.3: PMAC Motor Closed Loop Standalone Firmware Defines

PMAC Motor-Specific Defines to Be Edited
#define PI_PROP_LOWSPD
#define PI_PROP_HIGHSPD
#define PI_INT_LOWSPD
#define PI_INT_HIGHSPD
#define PI_LOWFREQ_LIMIT
#define PI_HIGHFREQ_LIMIT
#define PHI_MIN
#define PHI_MAX
#define PHI_LOWFREQ
#define PHI_HIGHFREQ

12. From the main menu, choose **Build > Configurations** for selecting the active project, according to the compiler being used:

- When using the Cosmic compiler, “**pmac_3ph_sr_csmc**” has to be selected;
- When using the Metrowerks 1.1 compiler, “**pmac_3ph_sr_mwks**” has to be selected.

Then choose “**Release**” in the “**Configuration**” list box. Afterward, by pressing the “**Set Active**” button, the selected project will become the active one. Press the “**Close**” button to close the “**Project Configurations**” dialog box.

Note: *if the 4 KB limited version of the Cosmic compiler is used, the “**Release**” configuration is the only choice that allows to compile the project. In this case it is not possible to proceed with any debugging session.*

13. Select the **“Build”** command from the **“Build”** menu. The project will be compiled and built, and an executable file will be generated in the **“\Release”** folder with an **“.s19”** extension.
14. You can now program the ST7FMC microcontroller with the generated executable. In the main menu select **Debug > Start Debugging** and then press the **“OK”** button in the **“Target Selection”** dialog box (**“STX-Indart”** is the only choice).
15. In the **“MCU Configuration”** dialog box select **“inDART-STX”** as the **“Hw Model”** and specify **“ST7FMC2N6”** as **“Device Code”**. Then, select the proper values for the **Option Bytes** as detailed in “Table 7.2: Option Bytes Settings for ST7FMC Programming” on page 62.
16. From the main menu choose **Debug instrument > Program** and set all the parameters according to “Figure 7.3: Program Dialog Box” on page 63.
17. By pressing the **“Start”** button the firmware is downloaded to the microcontroller. If the programming phase is completed correctly, the message **“Device successfully programmed”** will be displayed.
18. Now the microcontroller is programmed. You can unplug the ISP cable from the Motor Control board and operate the Motor Control board in standalone mode.
19. To start running the microcontroller, press the **“RESET”** push-button. For details about how to control the motor with the Motor Control board's push-buttons and potentiometers, please refer to the “Push-Buttons”, “Potentiometers” and “Standalone Mode: Driving a PMAC Motor” sections later in this chapter.

7.2.5 Preparing for Standalone Mode: Three-Phase AC Motors

1. Set up the Motor Control board as explained in the “Installing the Hardware” section in the “Getting Started for Three Phase AC Motors” chapter.
2. Get the latest release of the AK-ST7FMC Control Panel system software from SofTec Microsystems website (<http://www.softecmicro.com>), uninstall the previous version and install the new one.
3. In the **“\Program Files\SofTec Microsystems\AK-ST7FMC\Library”** directory there are various subdirectories, each specific for a motor/control type. Each subdirectory contains a pre-made project

specific for that motor/control type. Copy the appropriate subdirectory (the subdirectory that corresponds to your motor and control type) into another location. The copied subdirectory will become your working directory.

4. Run the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**.
5. You will be asked what motor type you are working with. Select the “**3 Phase AC Induction Motor (Sinewave)**” option and click the “**OK**” button. The main AK-ST7FMC Control Panel window will open.
6. To run a three-phase AC motor in standalone mode (Closed Loop), you must choose an optimum sampling time and then characterize two curves, a K_i , K_p versus stator frequency curve and a slip frequency versus stator frequency curve. Both curves must have two points, as illustrated below.




Figure 7.6: Three-Phase AC Motor Closed Loop Parameters Collecting: K_i , K_p




Figure 7.7: Three-Phase AC Motor Closed Loop Parameters Collecting: Slip Frequency

7. To run a three-phase AC motor in standalone mode (Open Loop), it is not necessary to collect any real-time settings, since all real-time parameters are controlled through the potentiometers.
8. Click the **“Generate Source Files...”** button. Browse for your working directory and select the **“\source”** subdirectory. Click the **“OK”** button. The appropriate header files will be generated.
9. Run the STVD7 IDE by selecting **Start > Programs > SofTec Microsystems > inDART-STX > ST7 > STVD7 for inDART-STX**.
10. From the main menu, choose **File > Open Workspace**. Select the **“AC_3PH_SR.stw”** workspace file that is located under your working directory. Click **“Open”**.
11. Only in the case of Closed Loop control, some defines in the **“ACMPParam.h”** file must be edited according to the collected parameters. The defines to be edited are listed in the following table.

Table 7.4: Three-Phase AC Motor Closed Loop Standalone Firmware Defines

Three-Phase AC Motor-Specific Defines to Be Edited
#define SAMPLING_TIME
#define PI_PROP_LOWSPD
#define PI_PROP_HIGHSPD
#define PI_INT_LOWSPD
#define PI_INT_HIGHSPD
#define PI_LOWFREQ_LIMIT
#define PI_HIGHFREQ_LIMIT
#define OPT_SLIP_LOWFREQ_LIMIT
#define OPT_SLIP_HIGHFREQ_LIMIT
#define OPT_SLIP_LOWFREQ
#define OPT_SLIP_HIGHFREQ

12. From the main menu, choose **Build > Configurations** for selecting the active project, according to the compiler being used:
- When using the Cosmic compiler, “**ac_3ph_sr_csmc**” has to be selected;
 - When using the Metrowerks 1.1 compiler, “**ac_3ph_sr_mwks**” has to be selected.

Then choose “**Release**” in the **Configuration** list box. Afterward, by pressing the “**Set Active**” button, the selected project will become the active one. Press the “**Close**” button to close the “**Project Configurations**” dialog box.

Note: if the 4 KB limited version of the Cosmic compiler is used, the “**Release**” configuration is the only choice that allows to compile the project. In this case it is not possible to proceed with any debugging session.

13. Select the **“Build”** command from the **“Build”** menu. The project will be compiled and built, and an executable file will be generated in the **“\Release”** folder with an **“.s19”** extension.
14. You can now program the ST7FMC microcontroller with the generated executable. In the main menu select **Debug > Start Debugging** and then press the **“OK”** button in the **“Target Selection”** dialog box (**“STX-Indart”** is the only choice).
15. In the **“MCU Configuration”** dialog box select **“inDART-STX”** as the **“Hw Model”** and specify **“ST7FMC2N6”** as **“Device Code”**. Then, select the proper values for the **Option Bytes** as detailed in “Table 7.2: Option Bytes Settings for ST7FMC Programming” on page 62.
16. From the main menu choose **Debug instrument > Program** and set all the parameters according to “Figure 7.3: Program Dialog Box” on page 63.
17. By pressing the **“Start”** button the firmware is downloaded to the microcontroller. If the programming phase is completed correctly, the message **“Device successfully programmed”** will be displayed.
18. Now the microcontroller is programmed. You can unplug the ISP cable from the Motor Control board and operate the Motor Control board in standalone mode.
19. To start running the microcontroller, press the **“RESET”** push-button. For details about how to control the motor with the Motor Control board’s push-buttons and potentiometers, please refer to the “Push-Buttons”, “Potentiometers” and “Standalone Mode: Driving an AC Motor” sections later in this chapter.

7.2.6 Preparing for Standalone Mode: Single- and Bi-Phase Motors

Unless specified expressly, the following steps refer to single-phase and bi-phase motors indifferently (generically indicated as SBAC motor).

1. Set up the Motor Control board as explained in the “Installing the Hardware” section in the “Getting Started for Single- and Bi-Phase AC Motors” chapter.
2. Get the latest release of the AK-ST7FMC Control Panel system software from SofTec Microsystems website (<http://www.softecmicro.com>), uninstall the previous version and install the new one.

3. In the “**Program Files\SofTec Microsystems\AK-ST7FMC\Library**” directory there are various subdirectories, each specific for a motor/control type. Each subdirectory contains a pre-made project specific for that motor/control type. Copy the appropriate subdirectory (the subdirectory that corresponds to your motor and control type) into another location. The copied subdirectory will become your working directory.
4. Run the AK-ST7FMC Control Panel by selecting **Start > Programs > SofTec Microsystems > AK-ST7FMC > AK-ST7FMC Control Panel**.
5. You will be asked what motor type you are working with. Select the “**Single and Bi-Phase AC Induction Motor (Sinewave)**” option and click the “**OK**” button. The main AK-ST7FMC Control Panel window will open.
6. To run a SBAC motor in standalone mode (Closed Loop), you must choose an optimum sampling time and then characterize two curves, a K_i , K_p versus stator frequency curve and a slip frequency versus stator frequency curve. Both curves must have two points, as illustrated below.




Figure 7.8: SBAC Motor Closed Loop Parameters Collecting: K_i , K_p




Figure 7.9: SBAC Motor Closed Loop Parameters Collecting: Slip Frequency

7. To run an SBAC motor in standalone mode (Open Loop), it is not necessary to collect any real-time settings, since all real-time parameters are controlled through the potentiometers.
8. Click the **“Generate Source Files...”** button. Browse for your working directory and select the **“\source”** subdirectory. Click the **“OK”** button. The appropriate header files will be generated.
9. Run the STVD7 IDE by selecting **Start > Programs > SofTec Microsystems > inDART-STX > ST7 > STVD7 for inDART-STX**.
10. From the main menu, choose **File > Open Workspace**. Select the **“AC_1PH_SR.stw”** (or **“AC_2PH_SR.stw”** for a bi-phase motor) workspace file that is located under your working directory. Click **“Open”**.
11. Only in the case of Closed Loop control, some defines in the **“ACMPParam_1PH.h”** file, for a single-phase motor (**“ACMPParam_2PH.h”** for a bi-phase motor) must be edited according to the collected parameters. The defines to be edited are listed in the following table.

Table 7.5: SBAC Motor Closed Loop Standalone Firmware Defines

SBAC Motor-Specific Defines to Be Edited
#define SAMPLING_TIME
#define PI_PROP_LOWSPD
#define PI_PROP_HIGHSPD
#define PI_INT_LOWSPD
#define PI_INT_HIGHSPD
#define PI_LOWFREQ_LIMIT
#define PI_HIGHFREQ_LIMIT
#define OPT_SLIP_LOWFREQ_LIMIT
#define OPT_SLIP_HIGHFREQ_LIMIT
#define OPT_SLIP_LOWFREQ
#define OPT_SLIP_HIGHFREQ

12. From the main menu, choose **Build > Configurations** for selecting the active project, according to the compiler being used:
- When using the Cosmic compiler, “**ac_1ph_sr_csmc**” (or “**ac_2ph_sr_csmc**” for a bi-phase motor) has to be selected;
 - When using the Metrowerks 1.1 compiler, “**ac_1ph_sr_mwks**” (or “**ac_2ph_sr_mwks**” for a bi-phase motor) has to be selected.

Then choose “**Release**” in the “**Configuration**” list box. Afterward, by pressing the “**Set Active**” button, the selected project will become the active one. Press the “**Close**” button to close the “**Project Configurations**” dialog box.

Note: if the 4 KB limited version of the Cosmic compiler is used, the “**Release**” configuration is the only choice that allows to compile the project. In this case it is not possible to proceed with any debugging session.

13. Select the **“Build”** command from the **“Build”** menu. The project will be compiled and built, and an executable file will be generated in the **“\Release”** folder with an **“.s19”** extension.
14. You can now program the ST7FMC microcontroller with the generated executable. In the main menu select **Debug > Start Debugging** and then press the **“OK”** button in the **“Target Selection”** dialog box (**“STX-Indart”** is the only choice).
15. In the **“MCU Configuration”** dialog box select **“inDART-STX”** as the **“Hw Model”** and specify **“ST7FMC2N6”** as **“Device Code”**. Then, select the proper values for the **Option Bytes** as detailed in “Table 7.2: Option Bytes Settings for ST7FMC Programming” on page 62.
16. From the main menu choose **Debug instrument > Program** and set all the parameters according to “Figure 7.3: Program Dialog Box” on page 63.
17. By pressing the **“Start”** button the firmware is downloaded to the microcontroller. If the programming phase is completed correctly, the message **“Device successfully programmed”** will be displayed.
18. Now the microcontroller is programmed. You can unplug the ISP cable from the Motor Control board and operate the Motor Control board in standalone mode.
19. To start running the microcontroller, press the **“RESET”** push-button. For details about how to control the motor with the Motor Control board’s push-buttons and potentiometers, please refer to the “Push-Buttons”, “Potentiometers” and “Standalone Mode: Driving a Bi-Phase Motor” sections later in this chapter.

7.2.7 Push-Buttons

The following figure shows the location of the two push-buttons available in the Motor Control board.




Figure 7.10: Push Buttons

1. “ON/OFF”: starts or stops the motor.
2. “RESET”: resets the ST7FMC microcontroller.

7.2.8 Potentiometers

The following figure shows the location of the four potentiometers available in the Motor Control board.




Figure 7.11: Potentiometers

1. “POT1”: current reference setting (for BLAC/BLDC motor only).

2. “RV1”, “RV2”, “RV3”: Open Loop and Closed Loop settings.

7.2.9 Standalone Mode: Driving a BLAC/BLDC Motor

A BLAC/BLDC motor can be driven in Current mode or Voltage mode. Depending on the driving mode, you must set the W12 jumper accordingly. Furthermore, in either mode, you can drive the motor in Open Loop mode or Closed Loop mode.

The W12 jumper must be set as follows.

- If the W12 jumper selects the “VARIABLE” position, the current reference comes from a PWM-generated, RC-filtered signal generated by the ST7FMC microcontroller. The “VARIABLE” position may be selected either in Current mode or Voltage mode. Note: In Voltage mode, the maximum current is set in the AK-ST7FMC Control Panel before generating the .h files.
- If the W12 jumper select the “FIXED” position, the current reference comes from the “POT1” potentiometer. **The “FIXED” position can be selected only in Voltage mode.**

The following table summarizes how the potentiometers can be used in Open Loop mode or Closed Loop mode for a BLDC motor.

Table 7.6: Open and Closed Loop Standalone Controls for a BLAC/BLDC Motor

Potentiometer	Open Loop	Closed Loop
RV1	Sets the duty cycle (Voltage mode) or the current reference (Current mode)	Sets the target speed (frequency)
RV2	Sets the coefficient to calculate the delay for a rising BEMF	Not used
RV3	Sets the coefficient to calculate the delay for a falling BEMF	Not used
POT1	Sets the maximum current allowed in the motor (Voltage mode only)	Sets the maximum current allowed in the motor (Voltage mode only)

Note: in Current mode, the W12 jumper must always select the “VARIABLE” position to allow dynamic current control by the ST7FMC microcontroller. In Current mode, the “POT1” potentiometer is inactive.

7.2.10 Standalone Mode: Driving a PMAC Motor

The following table summarizes how the potentiometers can be used in Open Loop mode or Closed Loop mode for a PMAC motor.

Table 7.7: Open and Closed Loop Standalone Controls for a PMAC Motor

Potentiometer	Open Loop	Closed Loop	Closed Loop with PI Tuning
RV1	Sets the stator voltage (from 0 V to the limit set by the V/F curve)	Set the target speed (from 10 Hz to 266 Hz)	Set the target speed (from 10 Hz to 266 Hz)
RV2	Not used	Not used	Sets the Ki integral coefficient (from 0 to 255)
RV3	Sets the phase shift value (from 0 degree to 360 degree)	Not used	Sets the Kp proportional coefficient (from 0 to 255)
POT1	Not used	Not used	Not used

7.2.11 Standalone Mode: Driving a Three-Phase AC Motor

The following table summarizes how the potentiometers can be used in Open Loop mode or Closed Loop mode for a three-phase AC motor.

Table 7.8: Open and Closed Loop Standalone Controls for a Three-Phase AC Motor

Potentiometer	Open Loop	Closed Loop	Closed Loop with PI Tuning
RV1	Sets the stator frequency	Set the target speed	Set the target speed
	Frequency/speed can vary from minimum to maximum frequency/speed boundaries defined in the Main Motor settings		
RV2	Sets the stator voltage (from 0 V to the limit set by the V/F curve)	Not used	Sets the Ki integral coefficient (from 0 to 255)
RV3	Sets the braking torque (from a 0 to 40% PWM duty cycle if the PWM frequency is 12.5 KHz and from 0 to 50% for other PWM frequencies)	Not used	Sets the Kp proportional coefficient (from 0 to 255)
POT1	Not used	Not used	Not used

7.2.12 Standalone Mode: Driving an Single-Phase Motor

The following table summarizes how the potentiometers can be used in Open Loop mode or Closed Loop mode for a single-phase AC motor.

Table 7.9: Open and Closed Loop Standalone Controls for a Single-Phase AC Motor

Potentiometer	Open Loop	Closed Loop	Closed Loop with PI Tuning
RV1	Sets the stator frequency (from 1 Hz to 256 Hz)	Set the target speed (from 10 Hz to 266 Hz)	Set the target speed (from 10 Hz to 266 Hz)
RV2	Sets the stator voltage (from 0 V to the limit set by the V/F curve)	Not used	Sets the Ki integral coefficient (from 0 to 255)
RV3	Sets the braking torque (from a 0 to 40% PWM duty cycle if the PWM frequency is 12.5 KHz and from 0 to 50% for other PWM frequencies)	Not used	Sets the Kp proportional coefficient (from 0 to 255)
POT1	Not used	Not used	Not used

7.2.13 Standalone Mode: Driving a Bi-Phase Motor

The following table summarizes how the potentiometers can be used in Open Loop mode or Closed Loop mode for a bi-phase AC motor.

Table 7.10: Open and Closed Loop Standalone Controls for a Bi-Phase AC Motor

Potentiometer	Open Loop	Closed Loop	Closed Loop with PI Tuning
RV1	Sets the stator frequency (from 1 Hz to 256 Hz)	Set the target speed (from 10 Hz to 266 Hz)	Set the target speed (from 10 Hz to 266 Hz)
RV2	Sets the stator voltage for both the two motor windings ⁽¹⁾ or just for the primary winding ⁽²⁾ (from 0 V to the limit set by the V/F curve)	Not used	Sets the Ki integral coefficient (from 0 to 255)
RV3	Not used or sets the stator voltage only for the secondary winding ⁽²⁾ (from 0 V to the limit set by the V/F curve)	Not used	Sets the Kp proportional coefficient (from 0 to 255)
POT1	Not used	Not used	Not used

⁽¹⁾ when a relationship is set between the two winding voltages (see chapter 8 for details)

⁽²⁾ when the two winding voltages can be set independently (see chapter 8 for details)

7.3 BLAC/BLDC Motor Outputs and Feedback

7.3.1 Introduction

The Motor Control board can be configured to drive a BLAC/BLDC motor in Sensor/Sensorless mode and Open/Closed Loop mode. The following figure illustrates where the input (sensor) connectors, the output connector (motor phases) and related jumper settings selectors are located.




Figure 7.12: Motor Outputs and Feedback

1. J8: filtering capacitors jumper selection.
2. W14, W15, W16: Sensor/Sensorless mode jumper selection.
3. W13: tachometer jumper selection (AC motors only).
4. J19: Hall sensors input connector.
5. J12: motor phases output connector.
6. J16: tachometer input connector.

7

A BLAC/BLDC motor can be controlled in Sensorless mode (using STMicroelectronics patented three-resistor method), in Sensorless mode (using classic method) and in Sensor mode, as detailed below.

7.3.2 Sensorless Mode (STMicroelectronics Method)

To drive a BLAC/BLDC motor in Sensorless mode, using STMicroelectronics patented three-resistor method, the W14, W15 and W16 jumpers should select the upper position (default factory setting). The W13 jumper and all of the J8 jumpers should be removed.

Additionally, the **“Z Event Sampling Method”** parameter, in the AK-ST7FMC Control Panel (in the **“Advanced Settings”** dialog box) should be set to **“At the end of the PWM low state”**.

7.3.3 Sensorless Mode (Standard Method)

To drive a BLAC/BLDC motor in Sensorless mode using classic method (dividers and filters on each of the three phases and reconstruction of the motor virtual neutral), the “Alternate Z Sampling” daughter board supplied with the kit should be plugged in on the pins of the W14, W15 and W16 jumpers and on the pins of the J11 connector. The W13 jumper must be removed. The J8 jumpers can be kept if the provided 2.2 nF filtering capacitors are compatible with the filter needed.

Of course, motor-specific resistors and capacitors must be mounted on the daughter board (see STMicroelectronics application note AN1946)

Additionally, the “**Z Event Sampling Method**” parameter, in the AK-ST7FMC Control Panel (in the “**Advanced Settings**” dialog box) should be set to “**At PWM on, with delay, once**”, to “**At PWM on, with delay, at f_{SCF} frequency**” or to “**At f_{SCF} frequency**”.

7.3.4 Sensor Mode

To drive a BLAC/BLDC motor in Sensor mode, the W14, W15 and W16 jumpers should select the lower position. The W13 jumper must be removed. The J8 jumpers can be kept to filter the sensor signal.

7.4 PMAC Motor Outputs and Feedback

A PMAC motor can be controlled either in open and closed loop.

To drive a PMAC motor, connect from one to three Hall sensor signals to the H1, H2, and H3 pins of the J19 connector, and put the W15, W15 and W16 jumpers, respectively, in the lower position. The W13 jumper must be removed.

In case of a noisy system, Hall sensor filtering can be implemented by inserting all of the jumpers in the J8 connector.

7.5 Three-Phase AC Motor Outputs and Feedback

A three-phase AC motor can be controlled in open or closed loop, as detailed below.

7.5.1 Open Loop

To drive a three-phase AC motor in open loop, the W14, W15 and W16 jumpers must select the lower position.

7.5.2 Closed Loop

To drive a three-phase AC motor in closed loop, the W14 and W15 jumpers must select the lower position, and the W16 jumper must be removed. Additionally, the W13 jumper must be present, to feed the tachometer signal to the microcontroller's MCIC input. This signals needs to be filtered by placing a jumper between pins 7 and 8 in the J8 connector.

7.6 Single- and Bi-Phase AC Motor Outputs and Feedback

Single- and bi-phase AC motors (SBAC) can be controlled in open or closed loop, as detailed below.

7.6.1 Open Loop

To drive a SBAC motor in open loop, the W14 and W15 jumpers must select the lower position, the W16 jumper must be removed, and all of the J8 jumpers must be present.

7.6.2 Closed Loop

To drive a SBAC motor in closed loop, the W14 and W15 jumpers must select the lower position, and the W16 jumper must be removed. Additionally, the W13 jumper must be present, to feed the tachometer signal to the microcontroller's MCIC input. This signals needs to be filtered by placing a jumper between pins 7 and 8 in the J8 connector.

7.7 ICC Connector

The ST7FMC microcontroller can be in-circuit programmed via the “ICC” connector, using the inDART-STX in-circuit debugger/programmer.

7.8 External Power Stage Connectors

Two connectors allow you to override the internal power inverter.




Figure 7.13: Power Stage Connectors

1. J4: AC motor power connector.
2. J6: BLAC/BLDC motor power connector.
3. W3: onboard power inverter current sensor.
4. W4: onboard power inverter diagnostic/enable.
5. W5: onboard power inverter thermal sensor.

The W3 and W4 jumpers should be removed when using an external power inverter. The W5 jumper should be present if no thermal monitoring is available on the external power inverter, otherwise the thermal sensor must be connected to pin 1 of the W5 jumper.

Note: *when using an external power stage and controlling the motor with the Control Panel, it is necessary to add external pull-up/down resistors to avoid floating port configuration on the MCOx inputs driving the power switches. For this purpose, a resistive network can be connected to the J4 connector while using the J6 connector and vice-versa. Refer to chapter **8.3.5** (Power Board Settings) for further details and configuration through the AK-ST7FMC Control Panel interface.*

7.9 RS-232 Connector

An optoisolated RS-232 connector allows the Motor Control board to be connected to a PC for displaying information about using a terminal utility like HyperTerminal. By default, single and bi-phase AC motor real-time values such as speed, voltage, stator frequency, etc. are sent to the PC (see STMicroelectronics Application Note AN2039). For the other motors, RS-232 communication can easily be enabled when working in standalone mode, through a conditional compilation key (see related Application Notes).

7.10 Summary of Jumper and Connector Settings

7.10.1 Jumpers Summary

Table 7.11: Jumpers Summary

Name	Selection	Description
S1	"HIGH VOLTAGE"	Motor supply is greater than 35 V DC or 25 Veff AC.
	"<35V ONLY"	Motor supply is less than 35 V DC or 25 Veff AC.
	Not present	Motor supply is separated from Motor Control board. The Motor Control board must be supplied with 15 V DC (0.5 A) on J1.
W3	Present	Connects the R21 shunt resistor to external Operational OpAmp circuitry and to the ST7FMC internal OpAmp.
	Not present	Disconnects the R21 shunt resistor from the external Operational OpAmp circuitry and to the ST7FMC internal OpAmp, when using an external power stage through J4 or J6.
W4	Present	Connects the diagnostic output of the L6386 driver to the MCES pin of the ST7FMC and enables the onboard inverter power stage.
	Not present	Disables the onboard inverter, when using an external inverter power stage on J4 or J6.
W5	Present	Connects the heatsink thermal sensor (NTC2, located on the bottom side of the PCB) to the AIN0 pin of the ST7FMC.
	Not present	Heatsink thermal sensor not connected to the AIN0 pin of the ST7FMC.
W6	Not present	ST7FMC internal OpAmp is used to amplify current sensed by the R21 shunt resistor.
	Upper position	ST7FMC internal OpAmp not used. External OpAmp not used. The ST7FMC MCCFI0 pin (comparator input) is directly connected to the R21 shunt resistor to sense current.
	Lower position	ST7FMC internal OpAmp not used. External OpAmp used to amplify the current sensed by the R21 shunt resistor. The ST7FMC MCCFI0 pin (comparator input) is connected to the external OpAmp output.
W7	"15V" (left position)	A voltage of 15 V DC is applied on pin 9 of J4 (to supply the external inverter and driver).





Name	Selection	Description
	"5V" (right position)	A voltage of 5 V DC is applied on pin 9 of J4 (to supply the external inverter and driver).
W8	"5V" (left position)	A voltage of 5 V DC is applied on pin 8 of J4.
	Right position	The pin 8 of J4 is redirected to the MCES input of the ST7FMC.
W9	"INT" (lower position)	Internal voltage is applied to the WUP pin of the L9638 LIN transceiver. LIN transceiver supplied with the onboard 15 V DC, mainly for debugging purposes.
	"EXT" (upper position)	External voltage is applied to the WUP pin of the L9638 LIN transceiver. LIN transceiver supplied with external voltage, typically the battery bus in automotive applications.
W10	Upper position	The TDO output of the ST7FMC is directed to the L9638 LIN transceiver.
	Lower position	The TDO output of the ST7FMC is directed to ST232 UART transceiver.
W11	Upper position	The RDI input of the ST7FMC comes from the L9638 LIN transceiver.
	Lower position	The RDI input of the ST7FMC comes from the ST232 UART transceiver.
W12	"VARIABLE"	The current reference comes from a PWM-generated, RC-filtered signal generated by the ST7FMC microcontroller (Current mode or Voltage mode).
	"FIXED"	The current reference comes from the "POT1" potentiometer (Voltage mode only).
W13	Not present	BLAC/BLDC motor: sensorless input on the MCIA, MCIB, MCIC pins of the ST7FMC (rotor position information comes from motor's three phases).
W14	Upper position	
W15	Upper position	
W16	Upper position	BLAC/BLDC motor: sensor input on the MCIA, MCIB, MCIC pins of the ST7FMC (rotor position information comes from J19).
W13	Not present	
W14	Lower position	
W15	Lower position	
W16	Lower position	AC motor (single-, bi- and three-phase) with no tachometer sensor. PMAC motor with Hall sensors H1, H2 and H3 connected to the MCIA, MCIB and MCIC inputs, respectively (rotor position information comes from J19).
W13	Not present	
W14	Lower position	
W15	Lower position	
W16	Lower position	



Name	Selection	Description
W13	Present	AC motor (single-, bi- and three-phase) with tachometer sensor (the tachometer signal is connected to the MCIC input of the ST7FMC).
W14	Lower position	
W15	Lower position	
W16	No Jumper	
J8	All jumpers present	AC motor (single-, bi- and three-phase): tachometer signal is filtered with capacitors. BLAC/BLDC motor, Sensorless mode (standard method): the four analog inputs MCIA, MCIB, MCIC and MCVREF are filtered with capacitors (providing their values follow the calculations described in AN1946). BLAC/BLDC motor, Sensor mode: Hall sensors signals are filtered with capacitors. PMAC motor: Hall sensors signals are filtered with capacitors.
	No jumper present	The four analog inputs MCIA, MCIB, MCIC and MCVREF are not filtered.
J9	All jumpers present	Connects the bus voltage to the AIN1 pin of the microcontroller, and the temperature monitoring signal to the AIN0 pin of the microcontroller.
	No jumper present	No monitoring of bus voltage or temperature (not recommended). The AK-ST7FMC Control Panel and the Motor Control library might not work properly if these jumpers are removed (real-time monitoring of bus voltage and heatsink temperature might read values leading to motor stop).
J10	All jumpers present	May be used for wire-wrapping purposes on ST7FMC Port E[3:0] I/O pins.
J15	All jumpers present	Always connected.





7.10.2 Connectors Summary/Pinout






The following table details the pinout of each of the Motor Control board's connector.

Table 7.12: Connectors Summary/Pinout

Name	Reference	Description/Pinout
J1		Optional 15 V DC, 0.5 A input connector to supply the Motor Control board logic separately from the motor power stage. <ol style="list-style-type: none">15 V DC Power SupplyVSS Power
J2		15 V DC output connector to supply the Optoisolation board. <ol style="list-style-type: none">15 V DC Power SupplyVSS Power
J3		Up to 42 V DC or 30 Veff AC power supply input connector. <ol style="list-style-type: none">EarthPower Input (AC/DC)Power Input (AC/DC)
J4		AC motor power connector (when overriding internal power inverter). <ol style="list-style-type: none">MCO0 – Motor Control Output 0MCO2 – Motor Control Output 2MCO4 – Motor Control Output 4MCO1 – Motor Control Output 1MCO3 – Motor Control Output 3MCO5 – Motor Control Output 5MCES – Motor Control Emergency StopSelectable between 5 V and MCES (see W8 Jumper)Selectable between 5 V and 15 V (see W7 Jumper)VSS Board

Name	Reference	Description/Pinout
J5		LIN output connector. 1. BAT – LIN Transceiver External Supply Voltage 2. LIN – Bidirectional I/O 3. VSS Board
J6		BLDC motor power connector (when overriding internal power inverter). 1. MCES – Motor Control Emergency Stop 2. VSS Board 3. MCO1 – Motor Control Output 1 4. VSS Board 5. MCO0 – Motor Control Output 0 6. VSS Board 7. MCO3 – Motor Control Output 3 8. VSS Board 9. MCO2 – Motor Control Output 2 10. VSS Board 11. MCO5 – Motor Control Output 5 12. VSS Board 13. MCO4 – Motor Control Output 4 14. VSS Board 15. 15 V DC Power Supply 16. VSS Board 17. MCIA – Motor Control Input A 18. VSS Board 19. MCIB – Motor Control Input B 20. VSS Board 21. MCIC – Motor Control Input C 22. VSS Board 23. OAP – Operational Amplifier Input 24. VSS Board 25. 5 V DC Power Supply 26. VSS Board

Name	Reference	Description/Pinout
J7		<p>LIN control connector.</p> <ol style="list-style-type: none"> 1. WUP – LIN Wake-Up Input 2. INH – LIN Inhibit Output 3. EN – LIN Enable Input 4. 2.2 KOhm Pull-Up Resistor to 5 V (enables the LIN transceiver when adding a jumper between pin 3 and pin 4)
J11		<p>Motor phases and additional monitor signals. Also used to connect the “Alternate Z Sampling” daughter board (for classic sensorless control method).</p> <ol style="list-style-type: none"> 1. Motor Phase C 2. VSS Board 3. Motor Phase B 4. VSS Board 5. Motor Phase A 6. VSS Board 7. MCVREF – Motor Control Voltage Reference
J12		<p>Motor three phases output.</p> <ol style="list-style-type: none"> 1. Motor Phase C 2. Motor Phase A 3. Motor Phase B 4. DC Bus Middle Point (may be used for bi-phase motors) 5. Earth
J13		<p>ICC connector, to be used with inDART-STX to download/debug code.</p> <ol style="list-style-type: none"> 1. VSS Board 2. ICCDATA 3. VSS Board 4. ICCCLK 5. VSS Board 6. RESET# 7. 5 V DC Power Supply 8. VPP 9. N.C. 10. VSS Board

Name	Reference	Description/Pinout
J16		<p>Tachometer input connector for AC motor speed loop control.</p> <ol style="list-style-type: none"> 1. Tachometer Bias (0.6 V) 2. Tachometer Input
J17		<p>External analog input connected to the AIN9 pin of the ST7FMC (available to the user).</p> <ol style="list-style-type: none"> 1. Analog Input (filtered with a 1 KOhm/10 nF RC network) 2. VSS Board
J18		<p>External digital I/O connected to the PF3 pin of the ST7FMC (available to the user).</p> <ol style="list-style-type: none"> 1. Digital Input (47 KOhm pull-up resistor to 5 V and 10 nF debouncing capacitor: allows to directly connect a push-button or switch). 2. VSS Board
J19		<p>Hall sensors input connector.</p> <ol style="list-style-type: none"> 1. Hall Sensor Input 1 2. Hall Sensor Input 2 3. Hall Sensor Input 3 4. 5 V DC Power Supply 5. VSS Board
P1		<p>RS-232 connector.</p> <ol style="list-style-type: none"> 1. N.C. 2. RX 3. TX 4. Tied to Pin 6 5. 0 V 6. Tied to Pin 4 7. Tied to Pin 8 8. Tied to Pin 7 9. N.C.

7.10.3 Jumper Settings for a BLAC/BLDC Motor (Default)

Table 7.13: Jumper Settings Example for a BLAC/BLDC Motor

Jumper	Settings for the Default AMETEK 24 V BLDC Motor	Settings for a Generic High-Voltage BLAC/BLDC Motor
S1	"<35V ONLY"	"<35V ONLY" or "HIGH VOLTAGE"
W3	Present	
W4	Present	
W5	Present	
W6	Not present	
W7	Not present	
W8	Not present	
W9	Not present	
W10	Lower position	
W11	Lower position	
W12	"VARIABLE"	
W13	Not present	
W14	Sensorless mode (default): all jumpers in upper position Sensor mode: all jumpers in lower position	
W15		
W16		
J8	No jumper present	
J9	All jumpers present	
J10	No jumper present	
J15	All jumpers present	

7.10.4 Jumper Settings for a PMAC Motor

Table 7.14: Jumper Settings Example for a PMAC Motor

Jumper	Settings for a Generic PMAC Motor, Onboard Inverter Power Stage, Hall sensors Feedback
S1	"<35V ONLY" or "HIGH VOLTAGE"
W3	Present
W4	Present
W5	Present
W6	Not present
W7	Not present
W8	Not present
W9	Not present
W10	Lower position
W11	Lower position
W12	"VARIABLE"
W13	Not Present
W14	Lower position
W15	Lower position
W16	Lower position
J8	All jumpers present
J9	All jumpers present
J10	No jumper present
J15	All jumpers present

7.10.5 Jumper Settings for an AC Motor (Single-, Bi- or Three-Phase)

Table 7.15: Jumper Settings Example for a Single-, Bi- or Three-Phase AC Motor

Jumper	Settings for a Generic AC Motor, Onboard Inverter Power Stage, Tachometer Feedback
S1	"<35V ONLY" or "HIGH VOLTAGE"
W3	Present
W4	Present
W5	Present
W6	Not present
W7	Not present
W8	Not present
W9	Not present
W10	Lower position
W11	Lower position
W12	"VARIABLE"
W13	Present
W14	Lower position
W15	Lower position
W16	Not present
J8	All jumpers present
J9	All jumpers present
J10	No jumper present
J15	All jumpers present

8 AK-ST7FMC Control Panel Features

8.1 Introduction

Note: *the AK-ST7FMC Control Panel doesn't reflect the full capabilities of the ST7FMC microcontroller and uses only partially its built-in resources. To take full advantage of the ST7FMC capabilities, it may be necessary to bypass the AK-ST7FMC Control Panel and edit directly the ST7FMC firmware.*

It can be the case that for a specific motor (e.g. BLDC compressor with load condition) the AK-ST7FMC Control Panel doesn't provide enough flexibility to be used for motor driving (start-up and/or run). In this case, separate fine tuning of the ST7FMC firmware is needed for optimum start-up algorithm and maximum speed.

8.1.1 Suggested BLAC/BLDC Motor Learning Steps

1. Run the provided AMETEK motor and use the AK-ST7FMC Control Panel default settings to understand the interdependence of the various parameters.
2. Then, run your own motor in Sensorless, Open Loop mode in order to find the correct start-up sequence setting. Preferably, select Voltage mode: this allows the motor to take as much current as needed (within the maximum current limit acceptable by the motor) and ensures a successful start-up.
3. Set the correct alignment parameters and acceleration phase parameters. In the Real-Time Settings parameter group, set a duty cycle at least equal to the acceleration phase's. Click the **"START"** button and, in case the motor fails to start, adjust start-up settings and/or advanced settings. When the motor starts, adjust the delay

coefficients for a given duty cycle (speed) to get the best motor efficiency.

4. After the Open Loop mode start-up parameters and advanced settings have been fine tuned, the motor can then be run in Closed Loop mode based on these parameters.
5. In Closed Loop mode, start-up parameters must be set again to comply with the closed loop operation.
6. It is then possible to run the motor in standalone mode by collecting real-time data and generating the appropriate header files to be used with the provided Motor Control library, in order to generate a firmware to be programmed into the microcontroller. This is explained in detail in the “Preparing for Standalone Mode: BLAC/BLDC Motors” section on page 58.

8.1.2 Suggested PMAC Motor Learning Steps

1. Run the provided AMETEK motor and use the AK-ST7FMC Control Panel default settings to understand the interdependence of the various parameters.
2. Then, run your own motor in Open Loop mode in order to characterize the motor and/or to verify that the motor is suitable for the intended load.
3. After the V/F curve, the start-up parameters and the advanced settings have been fine tuned, the motor can then be run in Closed Loop mode.
4. In Closed Loop mode, start-up parameters must be set again to comply with the closed loop operation.
5. It is then possible to run the motor in standalone mode by collecting real-time data and generating the appropriate header files to be used with the provided Motor Control library, in order to generate a firmware to be programmed into the microcontroller. This is explained in detail in the “Preparing for Standalone Mode: PMAC Motors” section on page 63.

8

8.1.3 Suggested Single-, Bi- and Three-Phase AC Motor Learning Steps

1. We suggest you to order the optional SELNI motor (available as an accessory) and experiment with the AK-ST7FMC Control Panel's

default settings for this motor, to understand the interdependence of the various parameters.

2. Then, run your own motor in Open Loop mode with a speed sensor (this will allow to monitor the speed and ensure that the stator frequency doesn't go below the rotor frequency—otherwise reactive current will be generated by the motor, causing overvoltage on bulk capacitors and possibly destruction of the board) in order to characterize the motor and/or to verify that the motor is suitable for the intended load.
3. After the V/F curve, the start-up parameters and the advanced settings have been fine tuned, the motor can then be run in Closed Loop mode.
4. In Closed Loop mode, start-up parameters must be set again to comply with the closed loop operation.
5. It is then possible to run the motor in standalone mode by collecting real-time data and generating the appropriate header files to be used with the provided Motor Control library, in order to generate a firmware to be programmed into the microcontroller. This is explained in detail in the “Preparing for Standalone Mode: Three-Phase AC Motors” section on page 67 and in the “Preparing for Standalone Mode: Single- and Bi-Phase Motors” section on page 71.

Note: *please note that the SELNI motor is a three-phase induction motor. Therefore, good performances will be achieved when it is driven as a three-phase motor. It can be used as a single- or bi-phase motor only for training purposes, but in these conditions the overall driving performances will be very poor.*

8.2 Motor Type Choice

When starting the AK-ST7FMC Control Panel, you must choose which motor type you are working with.




Figure 8.1: Motor Type Choice Dialog Box

Table 8.1: AK-ST7FMC Control Panel: Motor Type Choice

Parameter Name	Parameter Values/Description	
Motor Type Choice	3 Phase BLAC/BLDC Motor (Trapezoidal)	Controls the BLDC blower included in the AK-ST7FMC Starter Kit or any other BLAC/BLDC motor/compressor, including PMAC wound motors in six-step mode. MDTG write-once register, bit PCN at 0.
	3 Phase Brushless Permanent Magnet AC Motor (Sinewave)	Controls the BLDC blower included in the AK-ST7FMC Starter Kit or any other PMAC motor/compressor, with at least one hall sensor. MDTG write-once register, bit PCN at 1.
	3 Phase AC Induction Motor (Sinewave)	Controls the SELNI three-phase induction motor (not included in the AK-ST7FMC Starter Kit) or any other three-phase induction motor/compressor in sinewave mode. MDTG write-once register, bit PCN at 1.
	Single/bi-phase AC Induction Motor (Sinewave)	Controls the SELNI three-phase induction motor (used as a single- or bi-phase motor) (not included in the AK-ST7FMC Starter Kit) or any other single- or bi-phase induction motor/compressor in sinewave mode. MDTG write-once register, bit PCN at 1.

8.3 BLAC/BLDC Motor Parameters

This set of parameters allows you to control the AMETEK BLDC blower included the kit or any other BLAC/BLDC motor/compressor, including PMAC wound motors in six step mode. Please ensure that the correct jumper settings have been set on the board.




Figure 8.2: AK-ST7FMC Control Panel Main Window for BLAC/BLDC Motors

Note: in the following tables, the name of the ST7FMC registers corresponding to the AK-ST7FMC Control Panel settings is reported in bold when applicable. This is in order to help you establish an easy link between the AK-ST7FMC Control Panel and the information available in the microcontroller datasheet.

8.3.1 Main Motor Settings

Table 8.2: AK-ST7FMC Control Panel: BLAC/BLDC Trapezoidal Motor Main Settings

Parameter Name	Parameter Values/Description	
Motor Type	AMETEK Motor	An AMETEK 24 V BLDC blower is the default motor included in the AK-ST7FMC Starter Kit. This motor features 3 Hall sensors but is controlled in Sensorless mode by default. It can also be controlled in Sensor mode (see below). The “ Default Settings ” button restores the best performance settings for this motor.
	Other BLPMDC Motor	Any other BLAC/BLDC motor (including compressor) with or without sensors can be controlled by the AK-ST7FMC Starter Kit. Motors (including compressors) wound to use sinewave mode (so called PMAC motors) can also be controlled with optimum results in trapezoidal mode. Note that all basic and advanced parameters are by default those chosen for the AMETEK motor. It is unlikely that these settings will suit your motor. The AK-ST7FMC Control Panel can help you find these parameters.
Poles Pair	Number of pair poles of the motor connected to the Starter Kit. Motors with up to 18 pairs of poles can be used.	
Detection Mode	Sensorless	The default sensorless control method is the STMicroelectronics patented three-resistor method. Other standard sensorless methods can be implemented by modifying the Motor Control board hardware (or by using the “Alternate Z Sampling” daughter board supplied with the kit) and by selecting the appropriate BEMF sampling method. All sensorless methods implemented in this Starter Kit use a six-step signal driving topology. MCRA register, bit SR at 0.
	Sensor 120°	To run the motor in Sensor mode you need to properly set jumpers W14, W15, W16. You need to connect sensors and respect sensor wiring. MCRA register, bit SR at 1.

Parameter Name	Parameter Values/Description	
	Sensor 60°	To run the motor in Sensor mode you need to properly set jumpers W14, W15, W16. For the AMETEK motor the wiring of sensors provided is compatible with the firmware to control the motor in Sensor mode. For other motors you need to connect sensors and respect sensor wiring (and modify jumper settings accordingly). MCRA register, bit SR at 1.
Driving Mode	Current	In this mode, a current reference is set either by the user (in Open Loop mode) or by the PI (Proportional Integral regulator) to reach or maintain target speed (in Closed Loop mode). The ST7FMC motor control peripheral automatically adapts the PWM duty cycle to maintain the current in the motor at the level of the current reference. MCRA register, bit V0C1 at 1.
	Voltage	Voltage mode is preferred in applications requiring high torque at start-up and applications with significant load variations. In this mode, a PWM duty cycle is set by the user (in Open Loop mode) or by the PI (Proportional Integral regulator) to reach or maintain target speed (in Closed Loop mode). MCRA register, bit V0C1 at 0.
Current Limitation	When using Voltage mode, a programmable current limitation can be set. The AK-ST7FMC Control Panel doesn't allow to set this value in real time (the motor needs to be stopped each time). However, in the actual application, the maximum current value can be programmed and modified by software in real time (by varying the 8-bit ARTimer or 12-bit PWM duty cycle and connecting the 8-bit ARTimer or 12-bit PWM output to the proper RC circuit, this RC circuit being connected to the current comparator input). MCPVH and MCPVL compare registers.	
Speed Regulation	Open Loop	No speed regulation (no Proportional Integral regulation) is available. The motor is controlled directly by the user through duty cycle (voltage mode) or current reference (current mode). Useful to fine tune the start-up parameters and the BEMF rising and falling edge coefficients.

Parameter Name	Parameter Values/Description	
	Closed Loop	Proportional Integral regulation is available (this is done by software in the MCU). The user sets a desired speed: based on the PI values for this speed, the MCU defines a duty cycle (voltage mode) or a current reference (current mode). Closed Loop mode is used to implement a fine speed response and regulation.
Stator Frequency	Minimum	Available in Closed Loop only. Speed below which you do not want the motor to run. This can be useful in Sensorless mode, to avoid going below a speed that doesn't generate enough BEMF. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
	Maximum	Available in Closed Loop only. This is a safety value. Speed above which you do not want the motor to run. Example: for a motor with a specification of 20,000 RPM absolute maximum, set this value as maximum stator frequency. If this speed is exceeded, the rotor may explode or ball bearings may get damaged, and in turn this may cause major injuries (the rotor may be blocked instantaneously, causing the whole motor chassis to turn as a reaction). Always fix securely the motor on a mechanical bench. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).

8

8.3.2 Start-Up Settings

A successful motor start-up is a start-up that occurs 100% of the times and in a very short time. To achieve a successful start-up, two phases are required: the alignment phase and the acceleration phase. The start-up method implemented in AK-ST7FMC Control Panel is only one among many different start-up methods. For some motors it may be necessary to implement a start-up strategy different than the one proposed in the AK-ST7FMC Control Panel. This will require the ST7FMC firmware to be edited directly without using the AK-ST7FMC Control Panel.

The alignment phase consist in rotating the motor in a know position and to stabilize the rotor before starting. To achieve this, a voltage or current ramp

is supplied to the motor (increasing current or increasing duty cycle depending on Current or Voltage mode). During the alignment phase, the motor is polarized with a fixed step configuration T1-T4-T6 (no rotating statoric field).

The acceleration phase is a phase during which synchronous rotation is forced on the motor with a fixed acceleration rate in order to get BEMF information and switch as soon as possible from Forced mode to Autoswitched mode (for more information about Forced mode and Autoswitched mode please refer to the ST7FMC microcontroller datasheet).

Table 8.3: AK-ST7FMC Control Panel: BLAC/BLDC Motor Start-Up Settings

Parameter Name	Parameter Description
Final Current	In Current mode, sets the final current at the end of the programmed alignment time. MCPVH and MCPVL compare registers.
Final Duty Cycle	In Voltage mode, sets the final duty cycle at the end of the programmed alignment time. MCPUH and MCPUL compare registers.
Alignment Duration	The alignment duration is the duration of the alignment phase. MCOMP (data) and MPRSR (clock) registers.
Mechanical Acceleration Rate	The acceleration phase is a phase during which synchronous rotation is forced on the motor with a fixed acceleration rate in order to get BEMF information and switch from the forced mode to the autoswitched mode as soon as possible. Forced mode: MCRA register, SWA bit at 0. Autoswitched mode: MCRA register, SWA bit at 1. To achieve mechanical acceleration, a 64-step acceleration ramp is built, based on this parameter. 64 steps are usually more than enough to safely reach Autoswitched mode. If Autoswitched mode cannot be reached by the end of the acceleration ramp, the motor will stop and the “Start-Up Fails” or “Motor Stalled” (if rotor blocked) red icon turns on. This value can be set in Hz/s or RPM/s (click the “Hz” or “RPM” button next to the edit box to switch between units).
Duty Cycle	Constant duty cycle applied during the acceleration phase. MCPUH and MCPUL compare registers.
Current	Constant current reference applied during the acceleration phase. MCPVH and MCPVL compare registers.
Number of Z Events Before Autoswitched Mode	Number of consecutive Z events that must be detected to switch to Autoswitched mode.
Step Number without Z detection	Number of first steps of the ramp which are blanked (no BEMF reading). During the very first steps of the acceleration, the BEMF may be too low to be detected. During these first steps, the BEMF detection should be inhibited.

Parameter Name	Parameter Description
Electrical Frequency	Theoretical projected mechanical speed based on the 64th step duration and acceleration rate. Based on the number of pairs of poles and acceleration rate, the AK-ST7FMC Control Panel will compute the length of all of the elementary 64 electrical steps of the acceleration ramp and therefore provide a projection of the mechanical frequency at the end of the 64 steps (this is a theoretical value, as it is unlikely that 64 steps are actually needed to start-up the motor—typically the motor control will be switched to Autoswitched mode within the first 10 steps). This value can be set in Hz or RPM (click the “ Hz ” or “ RPM ” button next to the edit box to switch between units).
Total Duration	Theoretical duration of the acceleration phase if all of the 64 steps are completed.

8.3.3 Real-Time Settings

Table 8.4: AK-ST7FMC Control Panel: BLAC/BLDC Motor Real-Time Settings

Parameter Name	Parameter Description
Target Electrical Frequency	<p>Closed Loop target speed. When running in Closed Loop this is a key parameter because, for a given speed, several other parameters in the AK-ST7FMC Control Panel main window (BEMF coefficients, PI control coefficients, sampling time) and in the “Advanced Settings” dialog box (software demagnetization, and possibly blanking windows/event counters) needs to be fine tuned.</p> <p>This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).</p> <p>Note: if the desired speed cannot be reached, it may be because of the minimum and maximum speed limits set in the “Advanced Settings” dialog box. Please also check that the “Switches PWM Minimum Off Time” parameter in the “Advanced Settings” dialog box is not too high (only when using the STMicroelectronics’ patented three-resistor BEMF sampling method).</p>
Duty Cycle	<p>This is an Open Loop, Voltage Mode parameter. It is used to manually control the speed of the motor.</p> <p>Note: if the desired duty cycle cannot be reached, it may be because of the maximum duty cycle set in the “Advanced Settings” dialog box. Please also check that the “Switches PWM Minimum Off Time” parameter in the “Advanced Settings” dialog box is not too high (only when using the STMicroelectronics’ patented three-resistor BEMF sampling method).</p> <p>MCPUH and MCPUL compare registers.</p>
Current Reference	<p>This is an Open Loop, Current Mode parameter. It is used to manually control the speed of the motor.</p> <p>MCPVH and MCPVL compare registers.</p>
Delay Coefficient	<p>Value between 0 and 255 used to compute the delay between the Zero Crossing event (Z) and the Next Commutation event (C).</p> <p>Formula: $\text{Delay} = (\text{Delay Coefficient} * \text{ZTime}) / 256$,</p> <p>where ZTime is the time between the current Zero Crossing event and the previous Zero Crossing event (or the previous two if this has been set in the “Delay Computation” parameter in the “Advanced Settings” dialog box). Rising and falling edge detection have been differentiated to compensate the small delay due to the imbalance in step time. Imbalance in step time comes from the fact that the Zero Crossing event is not exactly detected at zero but slightly before (falling BEMF) or after (rising BEMF). This is caused by threshold voltage and by the asymmetrical BEMF shape on some motors.</p>

Parameter Name	Parameter Description	
BEMF Rising Edge	Sets the coefficient used to compute the delay when the BEMF is rising. MWGH register.	
BEMF Falling Edge	Sets the coefficient used to compute the delay when the BEMF is falling. A check box allows you to apply the same value used for the BEMF Rising Edge parameter. MWGH register.	
Integral Coefficient (Ki)	Closed Loop parameter. For beginning with a new motor, it is recommended to start from 0. The higher the value, the shorter the time necessary to cancel the static error, but a value too high will render the system unstable.	
Proportional Coefficient (Kp)	Closed Loop parameter. The higher the value, the lower will be the static error, but a value too high will render the system unstable.	
Sampling Time	The time interval between two PI control samplings. The lower the sampling time the better will be the regulation bandwidth. However, a value too low will not increase the system dynamic response above a certain point, and will consume microcontroller resources.	
Motor Direction	Normal Mode	The motor runs in the selected direction: CCW Direction: motor runs in Counter Clock Wise Direction; CW Direction: motor runs in clock wise direction. Please note that the rotation direction depends on the physical connection of the motor phases to the Starter Kit.
	Toggle Mode	The motor direction changes each time the motor is started.
Electrical Frequency	Rotor speed reading. This value can be read in Hz or RPM (click the “Hz” or “RPM” button next to the value to switch between units).	
Reported Duty Cycle	Available in Closed Loop only. Displays the duty cycle computed by the PI control, which is directly applied on power switches (in Voltage mode), or used to modulate the current reference (in Current mode).	

8.3.4 Advanced Settings

BLAC/BLDC motor advanced settings are available by clicking the “**Advanced Settings**” button in the main AK-ST7FMC Control Panel window.

BLAC/DC Trapezoidal Advanced Settings

PWM Settings

Switches PWM Frequency: 18.1 KHz

Switches PWM Minimum Off Time: 2.5 μ s

Complementary PWM Signal: Disabled

Dead Times: 4 μ s

☐ PWM Distribution

Clock Wise Mode **Counter Clock Wise Mode**

After C D Z After C D Z

T1-T4	0	0	0
T1-T6	0	0	0
T3-T6	0	0	0
T3-T2	0	0	0
T5-T2	0	0	0
T5-T4	0	0	0

Current Loop

Current Blanking Window: 0.5 μ s

Current Event Counter Filter: 1

Maximum Allowed Current: 3 A

Maximum Allowed Duty Cycle: 95.5 %

Sampling Parameters

Sampling Clock (ISCF): 1000 KHz

Unused MCIX Input: Grounded

B-emf Sampling Method

Z Event Sampling Method: At end of the PWM Low state

Delay For Sampling: 25 μ s

Zero Crossing

After D Blanking Window: 5 μ s

Z Event Counter Filter: 1

Delay Computation: Previous Z

Z Event Protection: Disabled

Threshold Voltage: 0.2 V

Demagnetization

After C Blanking Window: 5 μ s

D Event Counter Filter: 1

☐ All Hardware

☒ Alternate Hardware/Software

☐ All Software

Demagnetization Time: 450 μ s

☐ Force Duty Cycle during demagnetization

Duty Cycle: 0.5 %

Stop Condition

☒ Free Wheeling

☐ DC Current Braking

Brake Level: 1 % of Max Duty Cycle

Brake Time: 1 ms

OK **Cancel**

Figure 8.3: BLAC/BLDC Motor Advanced Settings Dialog Box

Table 8.5: AK-ST7FMC Control Panel: BLAC/BLDC Motor Advanced Settings

Parameter Name	Parameter Values/Description
PWM Settings	
Switches PWM Frequency	<p>Inverter switches (IGBT/MOSFET) PWM output frequency.</p> <p>In the firmware, the frequency is set as follows: in Voltage mode, the 12-bit timer frequency is set to the desired PWM frequency (MCPOL, MCPOH and MPCR registers); in Current mode, the PWM frequency is selected in the MPRSR register, 4 bits from SA3 to SA0. The output polarity (MPOL register, 6 bits from OP5 to OP0) of the six PWM outputs is fixed for the STMicroelectronics drivers and cannot be changed. For sources using the opposite polarity, please contact STMicroelectronics.</p>
Switches PWM Minimum Off-Time	<p>When using the STMicroelectronics patented three-resistor method, this parameter is required to maintain a sufficient PWM OFF state on the high side of the switches to allow for BEMF reading. This parameter is enabled only when the “At end of PWM low state” Z Event sampling method is selected. The BEMF sampling is done during the PWM OFF state, but just before the ON state. The optimum OFF time should be carefully calculated depending on the PWM switching frequency and on motor behavior (mainly the motor stray capacitance).</p> <p>MPWME register, 4 bits from OT3 to OT0.</p>
Complementary PWM Signal	<p>Only when using MOSFETs (instead of the Motor Control board's onboard IGBTs), this feature can be enabled to perform synchronous rectification, allowing the free wheeling current to pass inside the MOSFETs instead of the body diode (reduced power losses). The “Dead Times” parameter (see below) must be set correctly.</p> <p>Compl. PWM disabled: MDTG write-once register, bit DTE at 0. Compl. PWM enabled: MDTG write-once register, bit DTE at 1.</p>
Dead Times	<p>Sets the deadtime between the switches' high and low side to avoid cross conduction. The inverter of the Motor Control board requires a minimum deadtime of 0.625 μs to avoid cross conduction problems. Values from 0.625 μs to 16 μs are available in the AK-ST7FMC Control Panel. However, values as low as 0.125 μs can be set when editing ST7FMC registers directly. This allows to modify the deadtime in case an external inverter power stage is connected to the board.</p> <p>MDTG write-once register, 6 bits from DTG5 to DTG0.</p>

Parameter Name	Parameter Values/Description
PWM Distribution	<p>Sets PWM signal distribution between the switches' high side and low side (respectively even and odd) after each C, D and Z event. Double click to toggle from 0 to 1 and vice versa.</p> <p>For each step it is possible to select on which active switch the PWM signal is applied after the 3 different events (C, D and Z). This is useful to accelerate demagnetization and to reduce the level of reactive current inside the winding.</p> <p>There is a table for each rotor direction.</p> <p>Example: on step T1-T4, T1 is the high side (even) and T4 is the low side (odd). Setting the corresponding "After C" value to 1 causes the PWM signal to be applied on the odd switch (T4) from the C event until the D event; setting the "After D" value to 0 causes the PWM signal to be applied on the even switch (T1) from the D event until the Z event; setting the "After Z" value to 1 causes the PWM signal to be applied on the odd switch (T4) from the Z event until the next C event.</p> <p>MCRB register, 3 bits from OS2 to OS0.</p>
Speed Range	
Minimum Mechanical Speed	<p>Available in Closed Loop only. Speed below which you do not want the motor to run. This can be useful in Sensorless mode, to avoid going below a speed that doesn't allow to generate enough BEMF.</p> <p>This value can be set in Hz or RPM (click the "Hz" or "RPM" button next to the edit box to switch between units).</p>
Maximum Mechanical Speed	<p>This is a safety value.</p> <p>Example: for a motor with a specification of 20,000 RPM absolute maximum, set this value; if this speed is exceeded, the rotor may be explode or ball bearings may get damaged, and in turn this may cause major injuries (the rotor may be blocked instantaneously, causing the whole motor chassis to turn as a reaction). Always fix securely the motor on a mechanical bench.</p> <p>This value can be set in Hz or RPM (click the "Hz" or "RPM" button next to the edit box to switch between units).</p>
Current Loop	
Current Blanking Window	<p>Used to prevent the Current Loop from stopping on a current spike after PWM ON. This spike is usually caused by the recovery current from the half-bridge free wheeling diode and can be further increased by the discharge of the motor winding stray capacitance. The blanking window starts after each PWM ON event and during this blanking window no reading of current is done. This blanking window can also be disabled.</p> <p>MCFR register, 3 bits from CFW2 to CFW0.</p>
Current Event Counter Filter	<p>Number of consecutive current comparator samples (at 1 MHz) required to switch the PWM signal to OFF.</p> <p>MCFR register, 3 bits from CFF2 to CFF0.</p>

Parameter Name	Parameter Values/Description	
Maximum Allowed Current	In Current mode, to avoid damaging the motor, the user can set a maximum current acceptable for the motor. This value cannot be exceeded by the PI control (in Closed Loop) and by the current reference real-time setting (in Open Loop). However, this value can be exceeded during the start-up phase (Alignment Phase and Acceleration Phase). The AK-ST7FMC Control Panel the maximum current value is clamped to 8.7 A to suit the starter kit hardware.	
Maximum Allowed Duty Cycle	In Voltage mode, the user can specify a maximum PWM duty cycle that the application can't exceed. This value cannot be exceeded by the PI control (in Closed Loop) and by the duty cycle real-time setting (in Open Loop). However, this value can be exceeded during the start-up phase (Alignment Phase and Acceleration Phase). When using the STMicroelectronics' patented three-resistor control method (“ Z Event Sampling Method ” parameter set to “ At the end of the PWM low state ”), the maximum PWM duty cycle is clamped to a value (calculated by the AK-ST7FMC Control Panel) which is based on the programmed PWM signal frequency and on the minimum off time. Clamping the maximum PWM signal duty cycle to this value allows for sufficient time for BEMF reading during the PWM OFF state.	
D and Z Sampling Parameters		
Sampling Clock (fSCF)	Sampling frequency used for detecting D events. The same sampling frequency is used for detecting Zero Crossing events, when the (“ Z Event Sampling Method ” parameter is set to “ At PWM On, with delay, at fSCF frequency ” or to “ At fSCF frequency ”. MSCR register, 2 bits from SCF1 to SCF0.	
Unused MC1x Input	Sets the state of the two phases that, at any given time, are not sampled (while the third phase is being sampled). When using STMicroelectronics' patented three-resistor sensorless method, unused MC1x input are grounded. MSCR register, DISS bit.	
BEMF Sampling Method		
Z Event Sampling Method	At end of the PWM low state	To be used with STMicroelectronics patented three-resistor control method. This method uses the default jumper setting of the Motor Control board.
	At PWM on, with delay, once	To be used with sensorless classic control method. The “Alternate Z Sampling” daughter board must be used, and jumpers in the Motor Control board must be set accordingly.
	At PWM on, with delay, at fSCF frequency	Classic automotive method. The “Alternate Z Sampling” daughter board must be used, and jumpers in the Motor Control board must be set accordingly.

Parameter Name	Parameter Values/Description	
	At fSCF frequency	Pulse Amplitude Modulation method. The Motor Control board needs to be significantly modified.
	The figure at the end of this table illustrates these four sampling methods. MCRC register, SPLG bit and MCONF register, 4 bits from DS3 to DS0.	
Delay for Sampling	The delay between the PWM signal rising edge and start of BEMF sampling. This feature is only applicable to “ At PWM on, with delay, once ” and “ At PWM on, with delay, at fSCF frequency ” Z sampling methods. MCONF register, 4 bits from DS3 to DS0.	
Zero Crossing		
After D Blanking Window	Protects against noise that may be wrongly interpreted as a Zero Crossing event. After commutation, there is a time window during which a Zero Crossing event cannot physically occur. During this time window there should not be Z sampling. MZFR register, 4 bits from ZWF3 to ZWF0.	
Z Event Counter Filter	Protects against Zero Crossing (Z) spurious information. It's possible to detect from 1 to 15 Zero Crossing events before validating the Z event. MZFR register, 4 bits from ZEF3 to ZEF0.	
Delay Computation	Formula: Delay = (Delay Coefficient * ZTime) / 256 When calculating the Delay value (see the “ Delay Coefficient ” parameter in the Real-Time Settings group), Ztime is the time between the current Zero Crossing event and the one before, or between the previous Zero Crossing event and the one preceding it. Usually, “ Current ” is used. “ Previous ” can be selected to compensate for asymmetrical step times. MCRA register, DCB bit.	
Z Event Protection	If enabled, the Motor Control board verifies that, when a Zero Crossing event is detected, the state of the BEMF signal was opposite at the previous sampling. This is needed to differentiate a BEMF Zero Crossing event from a End-of-Demagnetization event. This feature can be useful when using hardware End-of-Demagnetization event detection and running the motor at high speed. When this parameter is enabled, the “ Z Event Counter Filter ” parameter is disabled. MCRA register, PZ bit.	

Parameter Name	Parameter Values/Description	
Threshold Voltage	<p>When using the STMicroelectronics' patented sensorless BLDC method, this parameter sets the voltage of the second comparator input (the voltage to be compared to BEMF, first comparator input being the BEMF). A list of pre-set values is available.</p> <p>When using other BEMF sampling methods, requiring the reconstruction of the motor ground, the external threshold option ("Ext. Ref." value) should be selected, and the corresponding hardware should be implemented on the Motor Control board.</p> <p>MCRC register, 3 bits from VR2 to VR0.</p>	
After C Blanking Window	<p>Protect against noise that may be wrongly interpreted as an End-of-Demagnetization (D) event. After commutation, there is a time window during which an End-of-Demagnetization event cannot physically occur. During this time window there should not be D sampling.</p> <p>MDFR register, 4 bits from DWF3 to DWF0.</p>	
D Event Counter Filter	<p>Protects against End-of-Demagnetization (D) spurious information. It's possible to detect from 1 to 15 D events before validating the D event.</p> <p>MDFR register, 4 bits from DEF3 to DEF0.</p>	
Demagnetization	All Hardware	<p>The End-of-Demagnetization event is detected only by hardware.</p> <p>MCRB register, bit HDM at 1, bit SDM at 0.</p>

Parameter Name	Parameter Values/Description	
	Alternate Hardware/Software	<p>It is possible to get more reliable End-of-Demagnetization event detection by using hardware detection together with software detection. This consists in extending by software (after the hardware detection of D event) the total demagnetization time before validating the End-of-Demagnetization event. In both the AK-ST7FMC Control Panel and in the ST7FMC firmware, this is implemented by multiplying the detected hardware demagnetization time by 1.25, as in the following formula:</p> <p>Total demagnetization time = Hardware demagnetization time * Ked,</p> <p>where Ked = 1.25. However, when editing directly the ST7FMC firmware, it is possible to change the Ked value and it is also possible add a fixed time, i.e.:</p> <p>Total demagnetization time = Hardware demagnetization time * Ked + Ved,</p> <p>where Ved is a time set by the user and which depends on several parameters, including motor speed (see the “All Software” below).</p> <p>MCRB register, bit HDM at 1, bit SDM at 1.</p>

Parameter Name	Parameter Values/Description	
	All Software	<p>In some situations (e.g. when the “Hardware/Software” option is not safe enough) it may be necessary to set a demagnetization time. This demagnetization time must always be equal to or higher than the physical demagnetization time of the motor winding. In addition, since the rotor speed will affect directly the step time, it is important, for each speed (or duty cycle in Open Loop, Voltage mode or current reference in Open Loop, Current mode) to set a corresponding software demagnetization time (or duty cycle, or current reference). If the demagnetization time is too long, it will limit the speed that can be reached by the motor. What all of this means is that, when using software demagnetization, you should not significantly modify the target speed, duty cycle, or current reference in the real-time settings (when the motor is running), but you should instead stop the motor, change the software demagnetization time and start the motor again.</p> <p>MCRB register, bit HDM at 0, bit SDM at 1.</p>
Demagnetization Time	<p>Available when the “All Software” option above is selected. This time should be longer than the physical demagnetization time of the motor, but short enough not to delay the BEMF detection. For each target speed there should be a different software demagnetization time.</p> <p>MDREG register, 8 bits from DN7 to DN0.</p>	
Force Duty Cycle during Demagnetization	<p>During demagnetization, current circulating in windings where the polarization doesn't change may increase to a level which may damage the motor. To avoid this situation, a dedicated duty cycle can be applied during demagnetization. This feature is available in Sensorless, Voltage mode.</p>	
Duty Cycle	<p>Available when the “Force Duty Cycle during Demagnetization” option above is enabled.</p>	
Stop Condition	Free Wheeling	After stop, the motor will continue to spin freely.
	DC Current Braking	To slow down the motor quickly, this feature allows to apply active braking.
Brake Level	<p>Available when the “DC Current Braking” option above is selected. Two of the three bridge legs are grounded and a PWM signal with 50% duty cycle (maximum) is applied on the third leg's high side switch.</p> <p>In Voltage mode, the duty cycle is loaded in the MCPUH and MCPUL registers.</p> <p>In Current mode, the current reference is loaded in the MCPVH and MCPVL registers.</p>	

Parameter Name	Parameter Values/Description
Brake Time	Available when the “DC Current Braking” option above is selected. Time during which active braking is applied and after which the motor is free wheeling.

The following figures illustrates the options available for the “Z Event Sampling Method” parameter.




Figure 8.4: BLDC Motor: BEMF Sampling Methods

8.3.5 Power Board Settings

It is possible to select whether the power stage to use is the Starter Kit's on-board power stage or an external one, provided by the user. In the second case, you should use the J6 or J4 connector to connect your own power stage, taking care to add external pull-up/pull-down resistors in order to maintain a low impedance level on MCOx pins during Control Panel-based operations.

To open the “**Power Board Settings**” dialog box, select “**Hardware**” in the AK-ST7FMC Control Panel's menu bar.




Figure 8.5: Power Board Settings Dialog Box

Table 8.6: AK-ST7FMC Control Panel: Power Board Settings

Parameter Name	Parameter Description	
Power Board	Starter Kit Power Board	Default setting. When this option is active, all of the other items are not accessible by the user, and their values are suited for working with the power stage from Starter Kit.
	External Power Board	Allows you to specify the active level for the motor control output channels to be compliant with your own external power board.
External Power Board Settings	MCU Output Channels	Allows to set the active level (High or Low) for each Motor Controller Peripheral Output (MCOx lines). MPOL register, 6 bits OP0 to OP5.
	Reset State Polarity	According to the Active Output Channel polarity, indicates the Motor Controller Peripheral Outputs (MCOx lines) state during an hardware reset or when the MTC peripheral outputs are disabled (MOE bit equal to 0). This is set to HiZ and cannot be changed for safety reasons: read carefully the note below for details. Option Byte 1, bits OT1:0.



Caution: *due to the ICC-based communication protocol used by the AK-ST7FMC control panel, the polarity of the microcontroller's MCOx lines at the reset state cannot be set to either a low or high level. During the AK-ST7FMC Control Panel startup sequence, the MCU enters the ICC mode and the MCOx lines are set to high impedance regardless of the corresponding Option Bytes value. Consequently, when using the AK-ST7FMC Control Panel, your external power stage must guarantee a safe, non-floating level on the drivers' inputs of the power switches. This can be done by means of external pull-up/pull-down resistors (when using L6386 drivers, this is automatically done by the drivers' built-in pull-down resistors). When using the J6 connector, a resistive network can easily be connected thanks to the J4 connector and vice-versa. In standalone mode, instead, the Option Bytes are not by-passed, and therefore they must be properly programmed so that they specify the correct state of the MCOx lines at the microcontroller's reset state.*

If you need to enter the ICC mode (for example during a field upgrade), make sure that your power stage is either compatible with the high impedance state of the microcontroller's MCOx lines or not powered.

8.4 PMAC Motor Parameters

This set of parameters allows you to control the AMETEK blower included in the kit or any other PMAC motor/compressor in sinewave mode. Please ensure that the correct jumpers setting has been set on the board.




Figure 8.6: AK-ST7FMC Control Panel Main Window for PMAC Motors

8.4.1 Main Motor Settings

Table 8.7: AK-ST7FMC Control Panel: PMAC Motor Main Settings

Parameter Name	Parameter Values/Description	
Motor Type	AMETEK Motor	An AMETEK 24 V blower is the default motor included in the AK-ST7FMC Starter Kit. This motor features 3 Hall sensors. The “ Default Settings ” button restores the best performance settings for this motor.
	Other PMAC Motor	Any three-phase PMAC motor with at least one hall sensor.
Poles Pairs	Number of poles pairs of the motor connected to the Starter Kit. PMAC motors with up to 10 pairs of poles can be used. Setting the correct number of pairs of poles is important, as this defines the relationship between rotor speed and stator frequency.	
Speed Regulation	Open Loop	Open Loop can be selected for operating the motor with a predictable load. Open Loop can also be used to drive the motor over the full Voltage/Frequency range. When selecting Open Loop, no Proportional Integral (PI) control is available, but speed monitoring is possible. Open Loop is used for characterizing the efficiency versus the phase shift of the motor.
	Closed Loop	Closed Loop uses the PI control (see real-time settings below). PI values must be adjusted depending on load conditions. PI parameters not properly set may lead to unstable behavior, especially in case of no load condition.
Sensors Configuration	One Sensor	The motor has only one Hall sensor.
	Two Sensors	The motor has two Hall sensors mechanically placed at 90 degrees from each other.
	Three Sensors	The motor has three Hall sensors mechanically placed at either 60 or 120 degrees from each other.
Stator Frequency	Minimum	Speed below which you do not want the motor to run. This value can be set in Hz or RPM (click the “ Hz ” or “ RPM ” button next to the edit box to switch between units).

Parameter Name	Parameter Values/Description	
	Maximum	<p>This is a safety value. Speed above which you do not want the motor to run.</p> <p>Example: for a motor with a specification of 20,000 RPM absolute maximum, set this value as maximum stator frequency. If this speed is exceeded, the rotor may explode or ball bearings may get damaged, and in turn this may cause major injuries (the rotor may be blocked instantaneously, causing the whole motor chassis to turn as a reaction). Always fix securely the motor on a mechanical bench.</p> <p>This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).</p>

8.4.2 Voltage Limitation

Table 8.8: AK-ST7FMC Control Panel: PMAC Motor Voltage Limitation Settings

Parameter Name	Parameter Description
Knee-Point Voltage Index	Sets the maximum allowed voltage (255 corresponds to full bus voltage) for low frequencies.
Knee-Point Frequency	Frequency below which voltage cannot go higher than the minimum voltage specified by user.
Rated Frequency	Frequency above which voltage can go up to the full bus voltage (255/255).

8

8.4.3 Start-Up Settings

Table 8.9: AK-ST7FMC Control Panel: PMAC Motor Start-Up Settings

Parameter Name	Parameter Description
Voltage Slew Rate	Time interval between two voltage increments (1/255) of the Stator Voltage modulation index during start-up.
Start-Up Stator Frequency	<p>Inverter output frequency at start-up.</p> <p>This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).</p>

Parameter Name	Parameter Description
Maximum Duration	Closed Loop parameter only. Time after which the motor is considered as not started. It is expressed in milliseconds.
Minimum Rotor Frequency to Validate Closed Loop	This frequency, when reached by the rotor, will trigger true Closed Loop control by exiting the start-up phase and entering the Closed Loop routine (the start-up phase is controlled in Open Loop by default, as no speed information is available during this phase). This value is always smaller than the start-up frequency. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).

8.4.4 Real-Time Settings

Table 8.10: AK-ST7FMC Control Panel: PMAC Motor Real-Time Settings

Parameter Name	Parameter Description
Stator Voltage	Open Loop parameter only. This is the voltage applied to the stator windings (it can be any voltage below the V/F limit, in other words any voltage within the red area).
Set Phase Shift According to Ph/F Curve	When this option is checked the Phase Shift value is set according to the Ph/F curve (see Advanced Settings) and depends on the actual stator frequency.
Phase Shift	The angle between the H1 edge transition and the point at 90° of the sinusoidal phase on the A winding. This value must be set to get the synchronism between rotor and stator and to optimize the efficiency of the motor. This value can be different for different speed and/or load condition. See STMicroelectronics Application Note AN1947.
Target Rotor Frequency	Closed Loop parameter only. The target rotor speed (frequency) is the expected speed (frequency) of the rotor. The Proportional Integral (PI) control will adjust the stator voltage according to this target frequency. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
Integral Coefficient (Ki)	Closed Loop parameter. When beginning with a new motor, it is recommended to start from 0. The higher the value, the shorter the time necessary to cancel the static error, but a value too high will render the system unstable.
Proportional Coefficient (Kp)	Closed Loop parameter. The higher the value, the lower will be the static error, but a value too high will render the system unstable.
Sampling Time	The time interval between two PI control samplings. The lower the sampling time the better will be the regulation bandwidth. However, a value too low will not increase the system dynamic response above a certain point, and will consume microcontroller resources.

Parameter Name	Parameter Description	
Motor Direction	Normal Mode	The motor runs in the selected direction: CCW Direction: motor runs in Counter Clock Wise Direction; CW Direction: motor runs in clock wise direction. Please note that the rotation direction depends on the physical connection of the motor phases to the Starter Kit.
	Toggle Mode	The motor direction changes each time the motor is started.
Reported Frequency	This is the speed (frequency) of the rotor as read by the sensor. This value can be read in Hz or RPM (click the “Hz” or “RPM” button next to the value to switch between units).	
Reported Voltage	Voltage output of the PI controller (in units of the bus voltage, full bus voltage being 255/255).	

8.4.5 Advanced Settings

PMAC motor advanced settings are available by clicking the “**Advanced Settings**” button in the main AK-ST7FMC Control Panel window.

8




Figure 8.7: PMAC Motor Advanced Settings Dialog Box

Table 8.11: AK-ST7FMC Control Panel: PMAC Motor Advanced Settings

Parameter Name	Parameter Values/Description	
Switches PWM Frequency	Inverter switches (IGBT/MOSFET) PMW output frequency. In the firmware, the 12-bit timer frequency is set to the desired PWM frequency (MCPOL , MCPOH and MPCR registers).	
Dead Times Value	Sets the deadtime between the switches' high and low side to avoid cross conduction. The inverter of the Motor Control board requires a minimum deadtime of 0.625 μ s to avoid cross conduction problems. Values from 0.625 μ s to 16 μ s are available in the AK-ST7FMC Control Panel. However, values as low as 0.125 μ s can be set when editing ST7FMC registers directly. This allows the deadtime to be modified in case an external inverter power stage is connected to the board. MDTG write-once register, 6 bits from DTG5 to DTG0.	
Run Time	Voltage Slew Rate	After the start-up phase is over, the unit increment/decrement in the 8-bit value Target Voltage, representing the modulation index, is delayed by this amount in Open Loop. The unit increment/decrement (0.1 Hz) in the target speed is delayed by this amount in Closed Loop.
	Free Wheeling	After stop, the motor will continue to spin freely.
Stop Condition	Active Braking	To slow down the motor quickly, this feature allows to apply active braking.
	Brake Voltage	Available when the “ Active Braking ” option above is selected. A sinusoidal waveform is provided to the motor to generate a statoric field 90° in advance with respect to the rotoric field. The sinusoidal waveform supplied for the braking has a ramp of voltage modulation index that reaches a user defined value as Brake Voltage (expressed in 1/255 th of bus voltage). During the braking process, the self synchronization mechanism is maintained.
Brake Minimum Speed	Available when the “ Active Braking ” option above is selected. This braking is active until the motor slows down to this value. This value can be read in Hz or RPM (click the “ Hz ” or “ RPM ” button next to the value to switch between units).	

8.4.6 Ph/F Curve Settings

Table 8.12: AK-ST7FMC Control Panel: PMAC Motor Ph/F Curve Settings

Parameter Name	Parameter Description
Knee-Point Phase	Phase shift value for frequencies below the knee-point frequency.
Rated Knee-Point Phase	Phase shift value for frequency above the rated frequency.
Knee-Point Frequency	Low frequency corner of the curve.
Rated Frequency	High frequency corner of the curve. For frequencies between the low and high frequency of the knee-point, the phase shift is calculated as linear interpolation of this two points.

8.5 Three-Phase AC Motor Parameters

This set of parameters allows you to control the SELNI three-phase induction motor (to be ordered separately) or any other three-phase induction motors/compressors in sinewave mode. Please ensure that the correct jumper settings has been set on the board.




Figure 8.8: AK-ST7FMC Control Panel Main Window for Three-Phase AC Motors

8.5.1 Main Motor Settings

Table 8.13: AK-ST7FMC Control Panel: Three-Phase AC Motor Main Settings

Parameter Name	Parameter Values/Description	
Motor Type	SELNI Induction Motor	The SELNI motor is an 800 W, 190 V, three-phase induction motor. It features a tachometer generator for speed monitoring. Due to its size and weight it is not included in the AK-ST7FMC Starter Kit but can be ordered separately. Beginners to three-phase induction motor control are strongly recommended to first use the SELNI motor as a learning phase. The “ Default Settings ” button restores the best performance settings for driving this motor when the Motor Control board is supplied with an input voltage of 42 V DC.
	Other 3-Phase Induction Motor	Any three-phase induction motor with or without sensor (tachometer, encoder, Hall sensor).
Poles Pair	Number of pair of poles of the motor connected to the Starter Kit. Induction motors with up to 2 pairs of poles can be used. Setting the correct number of pairs of poles is important, as this defines the relationship between speed and stator frequency.	
Speed Regulation	Open Loop	Open Loop can be selected for operating the motor with no sensors and predictable load. Open Loop can also be used to drive the motor over the full Voltage/Frequency range. When selecting Open Loop, no Proportional Integer (PI) control is available, but speed monitoring is possible (with the speed sensor). When characterizing the efficiency versus the slip of the motor, the speed sensor must be used. Beware of motor breakdown and reactive current.
	Closed Loop	Closed Loop requires the use of the speed sensor (either a tachometer or an Hall sensor), and uses the PI control (see real-time settings below). PI values must be adjusted depending on load conditions. PI parameters not properly set may lead to unstable behavior, especially in case of no load condition.
Speed Sensor Feedback	Enable this feature if speed monitoring is required in Open Loop for efficiency versus slip characterization.	

Parameter Name	Parameter Values/Description
Tachometer Periods per Revolution	Available when the “ Speed Sensor Feedback ” option above is enabled, and specifies the number of poles pair of the tachometer generator (if the tachometer has 8 pairs of poles, then 8 pulses per revolution will be sent). For the SELNI motor, this value is fixed to 8.

8.5.2 V/F Curve Settings

Table 8.14: AK-ST7FMC Control Panel: Three-Phase AC Motor V/F Curve Settings

Parameter Name	Parameter Description
Min Voltage	Sets the maximum allowed voltage (255 corresponds to full bus voltage) for low frequencies. This to avoid stator winding saturation (and, in turn, stator overcurrent).
Low Frequency	Frequency below which voltage cannot go higher than the minimum voltage specified by user.
High Frequency	Frequency above which voltage can go up to the full bus voltage (255/255).

8.5.3 Start-Up Settings

Table 8.15: AK-ST7FMC Control Panel: Three-Phase AC Motor Start-Up Settings

Parameter Name	Parameter Description
Voltage Slew Rate	Open Loop parameter only. Time interval between two voltage increments (1/255).
Start-Up Stator Frequency	Closed Loop parameter only. Inverter output frequency at start-up. This value can be set in Hz or RPM (click the “ Hz ” or “ RPM ” button next to the edit box to switch between units).
Maximum Duration	Closed Loop parameter only. Time after which the motor is considered as not started if no speed information has been detected.
Minimum Rotor Frequency to Validate Closed Loop	This frequency, when reached by the rotor, will trigger true Closed Loop control by exiting the start-up phase and entering the Closed Loop routine (the start-up phase is controlled in Open Loop by default, as no speed information is available during this phase). This value is always smaller than start-up frequency. This value can be set in Hz or RPM (click the “ Hz ” or “ RPM ” button next to the edit box to switch between units).

8.5.4 Real-Time Settings

Table 8.16: AK-ST7FMC Control Panel: Three-Phase AC Motor Real-Time Settings

Parameter Name	Parameter Description
Stator Frequency	Open Loop parameter only. Defines the synchronous speed of the motor. Basically it is the inverter output frequency. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
Set Voltage According to V/F Curve	In Open Loop (and for predictable load systems), this option is useful to adjust the speed without taking care of the applied voltage (the V/F curve has been tuned to fit the load). If this option is disabled, then the voltage can be set in the “Voltage” parameter below.
Voltage	Open Loop parameter only. For a given stator frequency, this is the voltage applied to the stator windings (it can be any voltage below the V/F limit, in other words any voltage within the red area).
Target Rotor Frequency	Closed Loop parameter only. The target rotor speed (frequency) is the expected speed (frequency) of the rotor. The Proportional Integral (PI) control will adjust the stator voltage and frequency according to this target frequency, the slip frequency and the V/F curve. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
Target Slip Frequency	Closed Loop parameter only. The slip value to be entered here should be the slip giving optimum efficiency for the given target rotor frequency and motor characteristics. The PI control will adjust the stator voltage and frequency according to this slip frequency, the target frequency and the V/F curve. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
Integral Coefficient (Ki)	Closed Loop parameter. For beginning with a new motor, it is recommended to start from 0. The higher the value, the shorter the time necessary to cancel the static error, but a value too high will render the system unstable.
Proportional Coefficient (Kp)	Closed Loop parameter. The higher the value, the lower will be the static error, but a value too high will render the system unstable.
Sampling Time	The time interval between two PI control samplings. The lower the sampling time the better will be the regulation bandwidth. However, a value too low will not increase the system dynamic response above a certain point, and will consume microcontroller resources.

Parameter Name	Parameter Description	
Motor Direction	Normal Mode	<p>The motor runs in the selected direction:</p> <p>CCW Direction: motor runs in Counter Clock Wise Direction;</p> <p>CW Direction: motor runs in clock wise direction.</p> <p>Please note that the rotation direction depends on the physical connection of the motor phases to the Starter Kit.</p>
	Toggle Mode	The motor direction changes each time the motor is started.
Reported Frequency	<p>Only valid in Closed Loop or in Open Loop with speed sensor feedback. This is the speed (frequency) of the rotor as read by the speed sensor.</p> <p>This value can be read in Hz or RPM (click the “Hz” or “RPM” button next to the value to switch between units).</p>	
Slip Frequency	<p>The slip speed (frequency) is the stator speed (frequency) minus the rotor speed (frequency).</p> <p>This value can be read in Hz or RPM (click the “Hz” or “RPM” button next to the value to switch between units).</p>	
Reported Voltage	Voltage output of the PI controller (in units of the bus voltage, full bus voltage being 255/255).	

8.5.5 Advanced Settings

AC motor advanced settings are available by clicking the “**Advanced Settings**” button in the main AK-ST7FMC Control Panel window.




Figure 8.9: Three-Phase AC Motor Advanced Settings Dialog Box

Table 8.17: AK-ST7FMC Control Panel: Three-Phase AC Motor Advanced Settings

Parameter Name	Parameter Values/Description	
Switches PWM Frequency	Inverter switches (IGBT/MOSFET) PMW output frequency. In the firmware, the 12-bit timer frequency is set to the desired PWM frequency (MCPOL , MCPOH and MPCR registers). The output polarity (MPOL register, 6 bits from OP5 to OP0) of the six PWM outputs is fixed for the STMicroelectronics drivers and cannot be changed. For sources using the opposite polarity, please contact STMicroelectronics.	
Minimum Stator Frequency	Speed below which you do not want the motor to run. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).	
Maximum Stator Frequency	This is a safety value. Example: for a motor with a specification of 20,000 RPM absolute maximum, set the same value; if this speed is exceeded, the rotor may be explode or ball bearings may get damaged, and in turn this may cause major injuries (the rotor may be blocked instantaneously, causing the whole motor chassis to turn as a reaction). Always fix securely the motor on a mechanical bench. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).	
Dead Times Value	Sets the deadtime between the switches' high and low side to avoid cross conduction. The inverter of the Motor Control board requires a minimum deadtime of 0.625 μ s to avoid cross conduction problems. Values from 0.625 μ s to 16 μ s are available in the AK-ST7FMC Control Panel. However, values as low as 0.125 μ s can be set when editing ST7FMC registers directly. This allows the deadtime to be modified in case an external inverter power stage is connected to the board. MDTG write-once register, 6 bits from DTG5 to DTG0.	
Stop Condition	Free Wheeling	After stop, the motor will continue to spin freely.
	DC Current Braking	To slow down the motor quickly, this feature allows to apply active braking.
Brake Level	Available when the “ DC Current Braking ” option above is selected. Two of the three bridge legs are grounded and a complementary PWM with maximum 50% duty cycle is applied on the switches of the third leg. Duty cycle loaded in the MCPUH and MCPUL registers.	
Brake Time	Available when the “ DC Current Braking ” option above is selected. Time during which active braking is applied and after which the motor is free wheeling.	

8.6 Single- and Bi-Phase AC Motor Parameters

This set of parameters allows you to control a single- or bi-phase AC motor/compressor (or a SELNI motor in single-/bi-phase configuration) in sinewave mode. Please ensure that the correct jumper settings has been set on the board.




Figure 8.10: AK-ST7FMC Control Panel Main Window for Single- and Bi-Phase AC Motors

8.6.1 Main Motor Settings

Table 8.18: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor Main Settings

Parameter Name	Parameter Values/Description	
Motor Type	Single-Phase	A single-phase AC motor.
	Bi-Phase	Any bi-phase induction motor with or without sensors (tachometer, Hall sensor).
Poles Pairs	Number of pair of poles of the motor connected to the Starter Kit. Induction motors with up to 10 pairs of poles can be used. Setting the correct number of pairs of poles is important, as this defines the relationship between speed and stator frequency.	
Speed Regulation	Open Loop	Open Loop can be selected for operating the motor with no sensors and predictable load. Open Loop can also be used to drive the motor over the full Voltage/Frequency range. When selecting Open Loop, no Proportional Integral (PI) control is available, but speed monitoring is possible (with a speed sensor). When characterizing efficiency versus slip frequency, a speed sensor must be used. Beware of motor breakdown and reactive current.
	Closed Loop	Closed Loop requires the use of a speed sensor (either a tachometer or an Hall sensor), and uses the PI control (see real-time settings below). PI values must be adjusted depending on load conditions. PI parameters not properly set may lead to unstable behavior, especially in case of no load condition.
Speed Sensor Feedback	Enable this feature if speed monitoring is required in Open Loop for efficiency versus slip characterization.	
Tachometer Periods per Revolution	Available when the “ Speed Sensor Feedback ” option above is enabled. Specifies the number of poles pairs of the tachometer generator (if the tachometer has 8 pairs of poles, then 8 pulses per revolution will be sent).	
Stator Frequency	Minimum	Speed below which you do not want the motor to run. This value can be set in Hz or RPM (click the “ Hz ” or “ RPM ” button next to the edit box to switch between units).

Parameter Name	Parameter Values/Description	
	Maximum	<p>This is a safety value. Speed above which you do not want the motor to run.</p> <p>Example: for a motor with a specification of 20,000 RPM absolute maximum, set this value as maximum stator frequency. If this speed is exceeded, the rotor may explode or ball bearings may get damaged, and in turn this may cause major injuries (the rotor may be blocked instantaneously, causing the whole motor chassis to turn as a reaction). Always fix securely the motor on a mechanical bench.</p> <p>This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).</p>

8.6.2 V/F Curve Settings

Table 8.19: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor V/F Curve Settings

Parameter Name	Parameter Description
Knee-Point Voltage Index	Sets the maximum allowed voltage (255 corresponds to full bus voltage) for low frequencies. This to avoid stator winding saturation (and, in turn, stator overcurrent).
Knee-Point Frequency	Frequency below which voltage cannot go higher than the minimum voltage specified by user.
Rated Frequency	Frequency above which voltage can go up to the full bus voltage (255/255).
Boost Rate	A percentage of the “ Knee-Point Voltage Index ” parameter above that is added to the current applied voltage level during the “ Boost Duration ” time interval (see parameter below). During this time interval, the whole V/F curve is shifted up by this amount.
Boost Duration	A time interval, expressed in ms (max 65535), during which the applied voltage level (modulation index) is increased by a quantity depending on the “ Boost Rate ” parameter and the “ Knee-Point Voltage Index ” parameter.

8.6.3 Start-Up Settings

Table 8.20: AK-ST7FMC Control Panel: Single- and Bi-Phase AC motor Start-Up Settings

Parameter Name	Parameter Description
Voltage Slew Rate	Open Loop parameter only. Time interval between two voltage increments (1/255).
Start-Up Stator Frequency	Closed Loop parameter only. Inverter output frequency at start-up. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
Maximum Duration	Closed Loop parameter only. Time after which the motor is considered as not started if no speed information has been detected.
Minimum Rotor Frequency to Validate Closed Loop	This frequency, when reached by the rotor, will trigger true Closed Loop control by exiting the start-up phase and entering the Closed Loop routine (the start-up phase is controlled in Open Loop by default, as no speed information is available during this phase). This value is always smaller than start-up frequency. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).

8.6.4 Real-Time Settings

Table 8.21: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor Real-Time Settings

Parameter Name	Parameter Description
Stator Frequency	Open Loop parameter only. Defines the synchronous speed of the motor. Basically it is the inverter output frequency. This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).
Set Voltage According to V/F Curve	In Open Loop (and for predictable load systems), this option is useful to adjust the speed regardless of the applied voltage (the V/F curve has been tuned to fit the load). Otherwise, the voltage can be set in the “Main Voltage” parameter below.
Main Voltage	Open Loop parameter only. For a given stator frequency, this is the voltage applied to the stator winding (the primary one for bi-phase motors). This parameter can be any voltage below the V/F limit, in other words any voltage within the red area of the V/F curve.
Secondary Voltage (Bi-Phase Motors Only)	Open Loop parameter only. For a given stator frequency, this is the voltage applied to the secondary (auxiliary) winding (it can be any voltage below the V/F limit, in other words any voltage within the red area of the V/F curve). This parameter depends on the relationship between the two winding voltages (see advanced settings).

Parameter Name	Parameter Description	
Target Rotor Frequency	<p>Closed Loop parameter only. The target rotor speed (frequency) is the expected speed (frequency) of the rotor. The Proportional Integral (PI) control will adjust the stator voltage and frequency according to this target frequency, the slip frequency and the V/F curve.</p> <p>This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).</p>	
Target Slip Frequency	<p>Closed Loop parameter only. Slip frequency giving optimum efficiency for the given target rotor frequency and motor characteristics. The PI control will adjust the stator voltage and frequency according to this slip frequency, the target frequency and the V/F curve.</p> <p>This value can be set in Hz or RPM (click the “Hz” or “RPM” button next to the edit box to switch between units).</p>	
Integral Coefficient (Ki)	<p>Closed Loop parameter. When beginning with a new motor, it is recommended to start from 0. The higher the value, the shorter the time necessary to cancel the static error, but a value too high will render the system unstable.</p>	
Proportional Coefficient (Kp)	<p>Closed Loop parameter. The higher the value, the lower will be the static error, but a value too high will render the system unstable.</p>	
Sampling Time	<p>The time interval between two PI control samplings. The lower the sampling time the better will be the regulation bandwidth. However, a value too low will not increase the system dynamic response above a certain point, and will consume microcontroller resources.</p>	
Motor Direction (Bi-Phase Motors Only)	Normal Mode	<p>The motor runs in the selected direction:</p> <p>CCW Direction: motor runs in Counter Clock Wise Direction;</p> <p>CW Direction: motor runs in clock wise direction.</p> <p>Please note that the rotation direction depends on the physical connection of the motor phases to the Starter Kit.</p>
	Toggle Mode	<p>The motor direction changes each time the motor is started.</p>
Reported Frequency	<p>Only valid in Closed Loop or in Open Loop with speed sensor feedback. This is the speed (frequency) of the rotor as read by the speed sensor.</p> <p>This value can be read in Hz or RPM (click the “Hz” or “RPM” button next to the value to switch between units).</p>	
Slip Frequency	<p>The slip speed (frequency) is the stator speed (frequency) minus the rotor speed (frequency).</p> <p>This value can be read in Hz or RPM (click the “Hz” or “RPM” button next to the value to switch between units).</p>	

Parameter Name	Parameter Description
Reported Voltage (Single-Phase Motors)/Main Voltage (Bi-Phase Motors)	The voltage output of the PI controller (applied across the main winding for bi-phase motors) in units of the bus voltage, full bus voltage being 255/255).
Secondary Voltage (Bi-Phase Motors only)	The voltage output of the PI controller (applied across the secondary windings) in units of the bus voltage, full bus voltage being 255/255.

8.6.5 Advanced Settings

Single- and bi-phase AC motor advanced settings are available by clicking the “**Advanced Settings**” button in the main AK-ST7FMC Control Panel window.




Figure 8.11: Single- and Bi-Phase AC Motor Advanced Settings Dialog Box

AK-ST7FMC Control Panel Features

Table 8.22: AK-ST7FMC Control Panel: Single- and Bi-Phase AC Motor Advanced Settings

Parameter Name	Parameter Values/Description	
Switches PWM Frequency	Inverter switches (IGBT/MOSFET) PWM output frequency. In the firmware, the 12-bit timer frequency is set to the desired PWM frequency (MCPOL , MCPOH and MPCR registers). The output polarity (MPOL register, 6 bits from OP5 to OP0) of the six PWM outputs is fixed for the AK-ST7FMC Starter Kit drivers and can be changed when using an external power board.	
Voltage Slew Rate	This value affects the speed of change in the modulation index variable (one unit increment/decrement at a time) once motor start-up has been completed and the motor is running.	
Voltage Control (Bi-Phase Motors Only)	V1 = V2	The voltages applied to the primary and secondary windings are the same (both in Open and in Closed Loop).
	V2 as fraction of V1	The voltage applied to the secondary winding is a fraction of the voltage applied to the primary winding (both in Open and in Closed Loop).
	V1, V2 independent	The voltages applied to the primary and secondary windings can be set independently (only in Open Loop).
Dead Times Value	Sets the deadtime between the switches' high and low side to avoid cross conduction. The inverter of the Motor Control board requires a minimum deadtime of 0.625 μ s to avoid cross conduction problems. Values from 0.625 μ s to 16 μ s are available in the AK-ST7FMC Control Panel. However, values as low as 0.125 μ s can be set when editing ST7FMC registers directly. This allows the deadtime to be modified in case an external inverter power stage is connected to the board. MDTG write-once register, 6 bits from DTG5 to DTG0.	
Stop Condition	Free Wheeling	After stop, the motor will continue to spin freely.
	DC Current Braking	To slow down the motor quickly, this feature allows to apply active braking.
Brake Level	Available when the “ DC Current Braking ” option above is selected. For single-phase motors, the phase B is grounded and a complementary PWM with 50% duty cycle maximum is applied to the switches of the first leg (A phase). For bi-phase motors, two of the three bridge legs are grounded and a complementary PWM with 50% duty cycle maximum is applied to the switches of the third leg (A phase). Duty cycle loaded in the MCPUH and MCPUL registers.	
Brake Time	Available when the “ DC Current Braking ” option above is selected. Time during which active braking is applied and after which the motor is free wheeling.	

9 Electrical Specifications

Table 9.1: Motor Control Board Electrical Specifications

Parameter	Maximum Ratings
Motor Types	Three-Phase BLAC/BLDC, Three-Phase PMAC, Single-, Bi- and Three-Phase AC
Main Input Voltage (J3)	42 V DC or 30 Veff AC
Auxiliary Input Voltage (J1)	15 V DC, 0.5 A
Auxiliary Output Voltage (J2)	15 V DC, 0.5 A
Maximum Output Current on Motor Phases (J12)	10 A
Analog Input Voltage (J17)	5 V DC
Digital Input/Output Voltage (J18)	5 V DC

Table 9.2: Optoisolation Board Electrical Specifications

Parameter	Maximum Ratings
Input Voltage (J3)	15 V DC, 0.3 A
"ICC IN" Connector I/O Lines Voltage (J1)	5 V DC
"ICC OUT" Connector I/O Lines Voltage (J2)	5 V DC

