



**Sigma Electronic Industries**

[www.sigma-electronics.com](http://www.sigma-electronics.com)

**سيجما للصناعات الإلكترونية**

## **TURBO Series Servo Stabilizers**

**Single Phase Servo Stabilizers**

## **User's Manual**

---

**Micro Controlled  
Line Stabilizer**

**Index**

<b>Index-----</b>	<b>2</b>
<b>Micro Controlled Line Stabilizers -----</b>	<b>3</b>
<b>Technical Specifications-----</b>	<b>4</b>
<b>Electrical Wiring Diagram-----</b>	<b>5</b>
<b>Line Stabilizer User Instructions-----</b>	<b>6</b>
<b>Front Panel User Instructions-----</b>	<b>7</b>
<b>Maintenance Procedure-----</b>	<b>11</b>

## Micro Controlled Line Stabilizers

**TURBO Series of Single Phase Servo Stabilizers** provide un-paralleled performance and reliability in voltage correction systems, with their outstanding features and design. They are built ruggedly to work reliably in any environment and are so compact.

**TURBO Series of Single Phase Servo Stabilizers** provides state of the art display through a single LCD for easier user interface.

### **General Specifications:-**


- True RMS Input/Output Measurements.
- Micro Controlled System.
- 80v/Sec Dynamic Regulations Speed.
- 1% Static Regulation.
- Electronic Overload and Over/Under Voltage Protection.
- Load Level, Output Voltage, Input Voltage LCD Display.
- Programmable Low and High Level Voltage Protection.
- Wide Range Correction Operating Area 160 – 250 VAC
- Programmable Output Voltage.

## Technical Specifications

<b>Input Voltage Range</b>	: 160 – 250 VAC RMS
<b>Output Voltage</b>	: 220 VAC $\pm$ 1.5%
<b>Output Voltage Adjustment</b>	: $\pm$ 5 %
<b>Operating Frequency</b>	: 50 Hz $\pm$ 5%
<b>Overloading</b>	: 10 Sec, > 150% Load
<b>Regulation Speed</b>	: ~80VAC / Sec
<b>Efficiency</b>	: > 98%
<b>Operating Technique</b>	: PWM controlled DC motor by microcontroller
<b>User Interface</b>	: LCD Display + 3 Buttons + 3 LEDs
<b>Warnings</b>	: Input High/Low, Output outside $\pm$ 1% , Overload
<b>Alarms</b>	: Output O.V/U.V, Overload (after Timer)
<b>Measurement Values</b>	: Input/Output Voltage, Output Current
<b>Output Protection</b>	: Short Circuit, Overload, Over/Under Voltage
<b>Input Protection</b>	: Over Voltage, Over Current Thermal Protection
<b>Operating Temperature</b>	: -10°C to 50°C
<b>Humidity</b>	: 95%
<b>Operating Altitude</b>	: < 2000 mt.
<b>Noise Level</b>	: < 50 db at 1 mt.

Micro Controlled  
Line Stabilizer

Phase Electrical Block Diagram



---

# **Line Stabilizer User Instructions**

## **Instructions about Installation**


- 1- Input and Output Power Cable Connections must have correct Cross Section to carry the Full Load Current
- 2- For Air Circulation, there must be adequate empty space around the stabilizer for safety and heat flow.
- 3- Ground Line must be always connected to the case of the stabilizer for safety.
- 4- Read Carefully the Operating Procedure before the installation of the Line Stabilizer.




## **Make the Following Works in Row**

- 1- Connect the Input Power Cable to the Input of the Line Stabilizer
  - 2- Connect the Input Circuit Breaker
  - 3- Check if Phase Rotation exists; rewire Input Power Cable till correct sequence occurs.
  - 4- On the Front Panel, Select the Desired Output Level and configuration
  - 5- Disconnect the Input Circuit Breaker
  - 6- Connect the Output Power Cable to the Output of the Line Stabilizer
  - 7- Connect the Input Circuit Breaker
  - 8- Check Output Power Cable is connected in the correct sequence for correct load operation, else rewire Output Power Cable .
-

Micro Controlled  
Line Stabilizer

## Front Panel User Instructions




		Control / Monitor	Function
Control	SET	SET Button	Enter Setup Mode to adjust VoNominal & OV/UV Limits
	INC	INC Button	Increment Page in Display Mode Increment Value in Setup Mode
	DEC	DEC Button	Decrement Page in Display Mode Decrement Value in Setup Mode
Monitor		INPUT LED	Valid Input and stabilizer Ready
		OUTPUT LED	Appropriate O/P exists and Output Contactor is ON
		Alarm/Warn LED	Flashes with Warnings and solid illumination for Alarms

**Micro Controlled  
Line Stabilizer**

## **Display Mode**

Displays: Input Voltage, Output Voltage , Output Current , Warnings .

- Navigate through pages by INC & DEC Buttons.
- Press SET Button to enter Setup Mode.



## **Setup Mode**

Used to adjust the desired Output Voltage (VoNominal), and to adjust Over Voltage / Under Voltage Limits (OV/UV Limits) where the stabilizer would disconnect for protection.

### **VoNominal Setup:-**

**Nominal Vo : 220**  
**Set:Exit D+I:Sav**

- Use DEC & INC Buttons to loop from 210 to 230 VAC as desired
- Press DEC + INC (D+I) Buttons to save the desired value and exit Nominal Vo Setup
- Press SET Button to exit Vo Setup Page without save and enter OV/UV Limits Page

### **OV/UV Limits Setup:-**

**OV/UV Limits: 3%**  
**Set:Exit D+I:Sav**

- Use DEC & INC Buttons to loop from 3% to 5% as desired
- Press DEC + INC (D+I)Buttons to save the desired value and exit OV/UV Limits Setup
- Press SET Button to exit OV/UV Limits Setup Page without save and enter Display Mode



---

**Micro Controlled  
Line Stabilizer**

**Warnings :-**

On Warning situation, TURBO Stabilizer continues operation with a buzzer and Warning LED flashing, following are warnings issued from TURBO Stabilizer:-

**Vi Under Limit** : Vi Under Limit Warning, when Vi is below 160VAC

**Vi Over Limit** : Vi Over Limit Warning, when Vi is over 250VAC

**Vo Under Normal**: Vo Under Normal Warning, when Vo goes below of VoNominal - 1%

**Vo Over Normal** : Vo Over Normal Warning, when Vo goes above of VoNominal + 1%

**Io OverLoad** : Io Over Loading Warning, when Io goes above Full Load current

**Motor Error** : Motor Error Warning, when Motor or Motor driver circuit failure occurs

**Alarms :-**


On Alarm situations, TURBO Stabilizer disconnects O/P Contactor to protect the load from fault and abnormal conditions, following are alarms issued by TRBO Stabilizer:-

**Vo Over Limit** : Vo goes Over O/V limit ( $Vo_{Nominal} + O/V_{Limit}\%$ )

**Vo Under Limit** : Vo goes Under U/V limit ( $Vo_{Nominal} - U/V_{Limit}\%$ )

**Io Over Limit** : Io Overloading for a period beyond the programmed tripping curve  
(Tripping Table in Page10)

**Micro Controlled  
Line Stabilizer**



OverLoad Tripping Curve	
Percentage Overload	Time
100% - 110%	5Min , 15 Sec
110% - 120%	4 Min , 15 Sec
120% - 130%	3Min , 14Sec
130% - 140%	2 Min , 12 Sec
140% - 150%	1 Min , 11 Sec
above 150%	10 Sec

## Maintenance Procedure

- 1- Switch “OFF” Input Circuit Breaker.**
- 2- Disconnect input/output terminals.**
- 3- Open the covers of the line stabilizer and clean with air compressor the dust carefully.**
- 4- Clean the variable transformer “VARIAC” wheel brush carefully.**
- 5- Check the belt frame system, if there’s a mechanical loose, please tighten properly.**
- 6- Check the micro switches on the variable transformer “VARIAC”, if there’s a failure in their ON-OFF action, please replace.**
- 7- Check all mechanical cable connections and Ground-Case connections for safety.**
- 8- Check Power Supply Fuse, replace if blown**
- 9- Check the electronic Control PCB connections and tighten the connectors.**
- 10- Connect Input terminals and recheck the line stabilizer input/Output voltages and variable transformer brush movement.**
- 11- Reconnect Output Load terminals upon success.**

Note: Please only experienced maintenance technicians are allowed to follow this steps.