

Lubrication System QLS 301



4197a99



6093b03

U.S. Patent-No. 6,244,387, German Registration Design No. 29923765.6

Subject to modifications

810-55230-1

All rights reserved.
Any duplication of this User Manual, in its entirety or in part,
by whatever means is prohibited without the prior consent in
writing of Lincoln GmbH & CO. KG.
Subject to modifications without prior notification.



© 2005 by
LINCOLN GmbH & Co. KG
Postfach 1263
D-69183 Walldorf

Phone: +49 (6227) 33-0
Fax: +49 (6227) 33-259

Table of Contents

	Page		Page
Introduction	4	Operation	19
Explanation of Symbols Used	4	Pump	19
User's Responsibility	4	Pressure Relief Valve	19
Environmental Protection	4	Display of the Membrane Keypad	19
Service	4	Monitoring time/ malfunction	20
Glossary	4	Reservoir empty	21
Safety Instructions	5	Operator keys of the keypad	21
Appropriate Use	5	Additional operating cycle	21
Misuse	5	Setting the pause time.....	21
General Safety Instructions	5	Acknowledging receipt of a malfunction	22
Regulations for Prevention of Accidents	5	Display of information regarding the set pause time....	22
Operation, Maintenance and Repair	5	Changing to the different programming levels	22
Repair	5	Monitoring Relay	22
Operation/Maintenance	6	Setting and Operation	23
Operation with bayonet plug	6	Factory Settings	23
Disposal	6	Operator Keys	23
Exclusion of Liability	6	Display mode	24
Installation	6	Programming mode	25
Installation Instructions	7	Operating mode	30
Pump	7	Maintenance, Repair and Tests	
SSV-Lubricant Metering Device	7	Maintenance	33
Adjusting the output by Crossporting of outlets	7	To fill reservoir	33
Single Output	7	Repair	34
Double or Multiple Outputs	7	Functional Test	34
Closure plugs	7	Troubleshooting	
Check valves	7	Pump of the QLS 301 system	35
Returning of lubricant quantities	8	SSV Metering Device	37
Lubrication points	9	Technical Data	39
Installing Zerk-Locks onto Grease Fittings	9	QLS 301, General	39
Connection of Feed Lines	10	Electrical Data	39
Filling of Reservoir.....	10	Time Setting	39
Identification Code		Relay for Malfunction	39
VDC	11	Feed Lines	39
VAC	12	Tightening Torques	39
Electrical Connecting Diagrams	13	Accessory Kits	39
VAC	13	Dimensions	40
VDC	15	Pump	40
Description		SSV Divider Blocks	40
QLS 301 with back position of the SSV divider block	17	Service Parts	41
QLS 301 with bottom position of the SSV divider block ...	17	Version with bayonet plug	41
QLS 301 with external SSV divider block	18	QLS 301 with bottom mounted SSV divider block and square-type plug	42
		QLS 301 with back mounted SSV divider block and square-type plug	44
		Option for Metrical Fittings	46
		EC Declaration of Conformity	47

Introduction

Explanation of Symbols Used

The following description standards are used in this manual:

Safety Instructions

Structure of safety instructions:

- Pictogram
- Signal word
- Danger text
 - Danger note
 - How to avoid danger

The following pictograms are used in this manual and are combined with the corresponding signal words:

 1013A94	 4273a00	 6001a02
- ATTENTION - CAUTION - WARNING	- ATTENTION - CAUTION - WARNING	- NOTE - IMPORTANT

The signal words give the seriousness of danger if the following text is not observed:

ATTENTION	refers to faults or damages on machines.
CAUTION	refers to bad damages and possible injuries.
WARNING	refers to possible dangerous injuries.
NOTE	indicates improved operation of the device.
IMPORTANT	indicates special operating features of the device.

Example:



ATTENTION!

When making use of other than the tested spare parts, serious damage may affect your device.

Therefore, for the operation of your device always use original spare parts made by Lincoln GmbH & Co. KG.

Furthermore, you will find the following text symbols in this manual:

- Listing of applicable statements
 - Subpoint of applicable statements
- 1. Determination of the number or sequence of contents
- ➔ Procedural instruction

User's Responsibility

To ensure the safe operation of the unit, the user is responsible for the following:

1. The pump / system shall be operated only for the intended use (see next chapter "Safety Instructions") and its design shall neither be modified nor transformed.
2. The pump / system shall be operated only if it is in a proper functioning condition and if it is operated in accordance with the maintenance requirements.
3. The operating personnel must be familiar with this Owner Manual and the safety instructions mentioned within and observe these carefully.

The correct installation and connection of tubes and hoses, if not specified by Lincoln GmbH & Co. KG, is the user's responsibility. Lincoln GmbH & Co. KG will gladly assist you with any questions pertaining to the installation.

Environmental Protection

Waste (e.g. used oil, detergents, lubricants) must be disposed of in accordance with relevant environmental regulations.

Service

The personnel responsible for the handling of the pump / system must be suitably qualified. If required, Lincoln GmbH & Co. KG offers you full service in the form of advice, on-site installation assistance, training, etc. We will be pleased to inform you about our possibilities to support you purposefully. In the event of inquiries pertaining to maintenance, repairs and spare parts, we require model specific data to enable us to clearly identify the components of your pump / system. Therefore, always indicate the part, model and series number of your pump / system.

Glossary

Lubricating time	=	Operating time
Operating cycle	=	Lubrication cycle

Safety Instructions

Appropriate Use

The lubrication system QLS 301 has been designed for initial and retrofit installation. It has been designed for:

1. the automatic lubrication of machines and systems
2. the automatic lubrication of commercial vehicles and construction machines
3. the automatic lubrication of hydraulically driven units and devices.

The lubrication system QLS 301 is able to deliver greases up to NLGI grade 2 or fluid greases of NLGI grade 000 or 00.

- Use the QLS 301 exclusively to supply lubricants.
- The QLS 301 is adequate for intermittent operation only.
- The QLS 301 is adequate for feeding max. 18 lube points per operating cycle.
- Do not use QLS 301 with bottom-mounted SSV metering device for mobile applications. Do not install the system with machines exposed to shock.

Misuse

Any use of the QLS 301 that is not expressly mentioned in this User Manual will be regarded as misuse. If the QLS 301 is used or operated in a different manner other than specified, any claim for warranty or liability will be null and void.



6001a02

NOTE

If personal injury or material damage occurs as a result of inappropriate operation, e.g. if the safety instructions are ignored or resulting from an incorrect installation of the QLS 301, no claims or legal actions may be taken against Lincoln GmbH & Co. KG.

General Safety Instructions

- Lubrication systems QLS 301
 - are designed state-of-the-art.
 - can be assembled for safe operation.
 - must be regularly refilled with clean lubricant.
- Incorrect use may result in bearing damage caused by poor or over-lubrication.
- Do not over-pressurize reservoir when filling the pump. Refill QLS 301 pump with clean lubricant.
- Each outlet needed must be equipped with an appropriate check valve.



6001a02

IMPORTANT

Do not paint the pump. Before painting a machine or commercial vehicle, remove or cover the pump completely.

- Unauthorized modifications or changes to an installed system are not recommended and will void warranty. Any modifications must be subject to prior consultation with the manufacturer of the QLS 301.

Regulations for Prevention of Accidents

To prevent accidents, observe all city, state and federal safety regulation of the country in which the product will be used.

Operation, Repair and Maintenance



1013A94

ATTENTION!

*Malfunction because of dirt!
When executing any maintenance or repair works on the QLS 301, ensure absolute cleanliness.*



4273a00

CAUTION!

Switch off the power supply before beginning maintenance or repair work.

Repair

Repairs should only be performed by authorized personnel who are familiar with the instructions.

Safety Instructions, continuation

Operation, Repair and Maintenance, continuation

Operation/Maintenance

Lubrication systems QLS 301

- must operate with mounted pressure relief valve, only.
- must operate only with mounted or connected SSV divider blocks.
- must be regularly filled with clean and air-free lubricant.
- operates automatically. However, a regular check (approximately every 2 weeks) should be made to ensure that lubricant is being dispensed from all lubricant points.

Operation with bayonet plug



4273a00

CAUTION!

If the protective-conductor terminal is not connected or interrupted, dangerous touch voltages may occur on the equipment!

Protective measures to be applied for the appropriate operation with bayonet plugs:

"Functional extra-low voltage with safe isolation" /
"Protective Extra-Low Voltage" (PELV)

Standards: EN60204 Part1:1992 / IEC 204-1:1992, modified
DIN VDE 0100 Part 410 / IEC 364-4-41:1992
(see pages 15 to 19)

Disposal

Used or contaminated lubricants must be disposed of in accordance with local environmental regulations, see technical data sheets of lubricants.

Exclusion of Liability

The manufacturer of the centralized lubrication system will not accept any liability for:

- damage caused by insufficient lubricant and irregular refilling of pump
- damage due to the use of greases which are not or are only conditionally pumpable in centralized lubrication systems
- damage caused by the use of contaminated lubricants
- damage caused by inadequate disposal of used or contaminated lubricants
- damage caused by unauthorized modification of system components
- damage caused by the use of unapproved parts (voids the pump warranty)

Installation



6001a02

IMPORTANT

Do not remove, modify or alter any safety equipment already installed on the machine, the construction machine or the commercial vehicle.

- If necessary, these devices may be removed temporarily during the installation of the pump.
- The devices must be properly put back in place after the installation of the pump.
- Use only original spare parts or spare parts authorized by Lincoln.
- Keep pump QLS 301 away from sources of heat (see Operating Temperature Specification, Technical Data).
- Provide access to fill, clean and visually monitor the pump operation.



6001a02

IMPORTANT

Adhere to the installation instructions of the vehicle or machine manufacturer as regards all drilling and welding procedures. Observe the specified minimum distances between bores and upper/lower rim of the frame or between the bores.



4273a00

CAUTION!

The QLS 301 may only be installed by qualified personnel. The connection (N/L/PE) of the supply voltage must be made according to VDE 0100 and VDE 0160.

Install a protective and lockout device for isolating and disconnecting the QLS 301. Before beginning the installation work, disconnect the electrical supply.



4273a00

WARNING!

Failure to observe the safety instructions, e. g. touching electrically charged parts when the system is opened, or improper handling of the QLS 301 may cause serious injury or death.

If the values specified in the Technical Data are exceeded, the device may overheat. It may damage the QLS 301 and thus impair the electric safety.

Installation Instructions

Pump

Use drilling template to mark and drill mounting holes of the QLS 301. Drilling template and mounting bolts are included in the package.

SSV Metering Device




Fig. 1 Single double and triple lubricant output, on back-mounted metering devices

- 0x-3x Output (single, double, etc.)
- 1-6 Outlet numbers
- A Clamping ring of the check valve
- B Grease supply
- C Enclosed grease
- R Return to reservoir

Adjusting the output by cross-porting of outlets

Single Output

A single output is the lubricant quantity fed to the lube point by a piston per stroke and outlet port. **It amounts to approximately 0.2 cm³**, see outlet 6, fig. 1.

Double or Multiple Outputs

- Outputs can be increased by simply plugging the unused outlet ports with closure plugs (fig. 2, provided in the accessory kit).
- Lubricant from a plugged outlet is redirected to the next outlet on the same side of the SSV divider block in descending numerical order (see fig.1).
- Example, see fig. 1:
By closing
 - of outlet 4, outlet 2 receives the double quantity.
 - of outlets 5 and 3, outlet 1 receives the triple amount of lubricant. The connecting conduit from outlet line 1 to outlet line 2 and to the return line (R) is closed by clamping rings (A) of the check valve.
- Unused lubricant can be internally fed back to the reservoir, see paragraph "direct internal feed back feature".



6001a02

NOTE

Do not plug outlets number 1 or 2 (horizontally positioned outlets) on bottom-mounted lubricant metering devices SSV 8, 12 and 18.

Do not plug outlets number 1 or 2 on externally mounted metering devices.



Fig. 2 Closure plug, also provided in the accessory kits

Closure plugs

- Install a closure plug in each outlet port that is not required, see fig. 1 or 4.
- Closure plugs are used in fig. 1 and 4 as follows:
 - Fig. 1 outlets 3, 4 and 5
 - Fig. 4 (page 8) outlets 1, 2, 4 and 5

Check valves

- For feed lines (diameter 6x1.5 mm, 1/4" I.D., provided in the accessory kits) use check valves with standard collar and knurled flange.
- Install a check valve in each outlet port that is required, see fig. 1 or 4. Observe paragraph "Direct (internal) feed-back feature" (see page 8).
- Check valves are used in fig. 1 and 4 as follows:
 - Fig. 1 outlets 1, 2 and 6
 - Fig. 4 (page 8) outlets 3 and 6




Fig. 3 Check valve, push-in type
A Clamping ring (brass)

Subject to modifications

Installation Instructions, continuation




Fig. 4 Internal feedback of supplied lubricant, only on back-mounted SSV metering devices

- 0x-2x Output (single, double, etc.)
- 1-6 Outlet numbers
- A Clamping ring of the check valve
- B Grease supply
- C Enclosed grease
- R Return-line bore



6001a02

NOTE

Maximum internal combination of outlets:

SSV 6 = 3

SSV 12 = 6

SSV 18 = 9

Further combinations are possible outside the metering device by means of a tee-piece only.

Direct (internal) feedback feature

- All pumps with **back-mounted SSV metering device** have the capability to feed back unused lubricant internally from closed outlets directly to the reservoir (see pos. R fig. 1, 4).
- This procedure will start automatically, if **outlet port 2** is plugged with a closure plug. All pumps have capability to feed back the lubricant directly to the reservoir **from even and odd outlets** via the passage from outlet 1 to outlet 2.
- When feeding back, always start with plugging the outlets **with the smallest outlet numbers**, e.g. 2, 4, 6... or 1, 3, 5... **plus outlet 2**. In fig. 4 the outputs of outlets 1, 2 and 4 (3xR) are fed back to the reservoir.
- The remaining outlets are to be used for the connection to the lube point or for increasing the lubricant output (double or triple), see fig.1.



1013A94

CAUTION!

If **outlet 2** is connected to a lube point, then **never close outlet 1**, see clamping ring (A) in outlet 2, **fig. 1**.



6001a02

NOTE

To feed back unneeded lubricant quantities from **bottom-mounted metering devices** to the reservoir, connect unneeded outlet via the feed line to plug (pos. R, Fig 20, page 19) for external return line.

Installation Instructions, continuation

Lubrication Points

Installing Quicklinc fittings into lube points

Remove lubrication fitting from lube point and install appropriate Quicklinc fitting into the bore of the lube point.

Installing Zerk-Lock onto Lube Fitting




Fig. 5 Place the Zerk-Lock body over the filler fitting

Fig. 6 Installation of Zerk-Locks with staking tool

The Zerk-Lock fitting consists of the Zerk-Lock body, insert and a Quicklinc fitting.

- Place the Zerk-Lock body over the lube fitting and place the staking tool firmly against the Zerk-Lock insert. (Staking tool is included in the accessory kits).
- Strike the tool sharply with a hammer until the Zerk-Lock insert partially crimps onto the grease fitting.




Fig. 7 Screwing Quicklinc fitting into the Zerk-Lock body

- Screw the Quicklinc fitting into the Zerk-Lock body and tighten until parts resist further tightening (about 1-1/2 turns).



6001a02

NOTE

Quicklinc hex. is 12 mm. Zerk-Lock body hex is 1/2".

- Move the Zerk-Lock and tube fitting from side to side on the lubrication fitting to insure the Zerk-Lock is firmly seated.

Installation Instructions, continuation

Connection of Feed Lines




Fig. 8 Feed line installed in the Quicklinc fitting

- Measure, cut and route the feed lines included in the accessory kit.



6001a02

NOTE

Avoid sharp bends of the plastic tubing and the moving parts of the machine that could damage the lubrication lines. Minimum bending radius is 50 mm (2 in).

- Secure the lubrication lines to the machine using nylon ties, clamps or straps provided in the accessory kit.
- If the feed lines are not primed, prime all lubrication feed lines before connecting them to the lube point (by triggering additional lubrications or via the filler fitting, pos. 4, fig. 17 and 18, page 17).
- Connect the feed lines directly to the check valves of the metering device and to the Quicklinc fittings of the lube point.




Fig. 9 Feed line insert into the fitting up to the next white mark



6001a02

NOTE

Push the ends of the feed line firmly into the Quicklinc fitting until it is fully seated in the body of the fitting. The primed feed lines are marked with white lines (fig. 9, 10) to facilitate installation.

- Cut the pressure plastic tube off at one of the white lines before it is mounted.
- Then insert the plastic pressure tube into the fitting up to the next white mark. This will ensure a correct installation of the pressure plastic tube in the threaded tube fitting.

Filling of reservoir



Fig. 10 Vent hole on reservoir

- Fill the reservoir with suitable clean lubricant without air pockets.



1013A94

WARNING!

Risk of bursting if the reservoir is overfilled. When filling the reservoir by means of pumps with a large delivery volume do not exceed the max. filling mark.

CAUTION!

Avoid inclusions of air in the lubricant below the follower plate. When filling the reservoir, the follower plate sealing lip overlaps the vent hole (see fig. 10) to ensure that all air pockets can be vented.

Selection Guide VDC

		P301	6	2	4	1	0	1	5	3	
Pump models		P30100210113									
Examples of part numbers		P30162410153									
Pump 301 for grease	P301										
SSV Metering Device											
External, SSV 6, SSV 8 ¹⁾	0										
External, SSV 12, SSV 18 ¹⁾	1										
SSV 6 (back)	3										
SSV 8 (bottom)	4										
SSV 12	6										
SSV 18	9										
¹⁾ Note: For external metering device application only use specific SSV metering devices... KNQLS.											
SSV Metering Device Position, arrangement of the outlets											
Without / external metering device	0										
Back (vertical order of lines)	1										
Bottom ²⁾ (horizontal order of lines)	2										
²⁾ Note: Do not use QLS 301 with SSV metering device in bottom-mounting position for mobile applications. Do not install the pump in areas exposed to shock (see chapter "Safety Instruc-											
Operating Voltage											
12 VDC ³⁾	2										
24 VDC ³⁾	4										
³⁾ Note: Standard 12 and 24 VDC pump models for mobile applications can be supplied with 10-meter (30') electrical cable.											
Reservoir											
1 liter reservoir with low-level control	1										
Possible connections											
- 1A = 1 connector (square plug), left, power supply	0										
- 2A = 2 connectors (square plugs) 1 connector, left, power supply 1 connector, right, fault indication	1										
- 1A = 1 connector (bayonet plug), left, power supply; Fault indication	2										
Type of Plug Connector											
* Square-type plug, acc. to DIN 43650 type of construction A (industrial application)	1										
** Bayonet plug, DIN 72585-1, 4-core (mobile application, VDC)	5										
Electrical Connectors											
With socket without cable *	1										
With socket and 10 m cable *	5										
With socket and 10 m cable ADR *	6										
With socket and 10 m cable **	7										
With socket and 6 m cable, ADR **	8										
Control p. c. b.											
Terminal board without time control	0										
Control p.c.b. S3: NC contact or NO contact (programmable), monitored: - 1-5 cycles	3										

(Accessory kits see "Technical Data")

Selection Guide VAC

Pump models		P30100810113									
Examples of part numbers		P30162610113									
		<table border="0" style="margin-left: auto; margin-right: auto;"> <tr> <td style="text-align: center; width: 10%;">P301</td> <td style="text-align: center; width: 10%;">6</td> <td style="text-align: center; width: 10%;">2</td> <td style="text-align: center; width: 10%;">6</td> <td style="text-align: center; width: 10%;">1</td> <td style="text-align: center; width: 10%;">0</td> <td style="text-align: center; width: 10%;">1</td> <td style="text-align: center; width: 10%;">1</td> <td style="text-align: center; width: 10%;">3</td> </tr> </table>	P301	6	2	6	1	0	1	1	3
P301	6	2	6	1	0	1	1	3			
Pump 301 for grease	P301										
SSV Metering Device											
External, SSV 6, SSV 8 ¹⁾	0										
External, SSV 12, SSV 18 ¹⁾	1										
SSV 6 (back)	3										
SSV 8 (bottom)	4										
SSV 12	6										
SSV 18	9										
¹⁾ Note: For external metering device application, use the specific metering device SSV ... KNQLS.											
SSV Metering Device Position, arrangement of the outlets											
External metering device	0										
Back (vertical order of the lines)	1										
Bottom ²⁾ (horizontal order of the lines)	2										
²⁾ Note: Do not use QLS 301 with SSV metering device in bottom-mounting position for mobile applications. Do not install pump in areas exposed to shock (see "Safety Instructions").											
Operating Voltage											
120 VAC ³⁾ (only with control p.c.b.)	6										
230 VAC ³⁾ (only with control p.c.b.)	8										
³⁾ Note: Standard 120 and 230 VAC pump models for industry are supplied without electrical cable.											
Reservoir											
1 liter reservoir with low-level control	1										
Possibilities of connection											
- 1A = 1 connector (square plug), left, power supply	0										
- 2A = 2 connectors (square plug)											
1 connector, left, power supply											
1 connector, right, fault indication	1										
Type of Plug Connector											
* Square-type plug, acc. to DIN 43650 type of construction A	1										
Electrical Connectors											
With socket, without cable *	1										
Control p.c.b.											
Control p.c.b. S3:											
NC or NO contact (programmable), monitored											
- 1 cycle with SSV 12, SSV 18											
- 1 to 3 cycles with SSV 6, SSV 8	3										

(Accessory kits, see "Technical Data")

Electrical Connecting Diagrams

Electrical connection



4273a00

CAUTION!

Before starting, make sure that the electrical supply is off. The device may not be connected or disconnected when the power is on. The protective conductor must always be connected. Take care that this line section is undamaged and conforms to standards and the contacts are safe.



4273a00

ATTENTION!

Consider residual ripple of max. $\pm 5\%$ to connect pumps with direct current version (in relation to the operating voltage acc. to DIN 41755).



6001a02

NOTE

The protection IP6K9K is guaranteed when the socket (X1.; X2.; see fig. 6 ff) is tightened on housing cover with flat packing.

- Verify the connection and the type of construction of your QLS.
- Verify the configuration of your QLS 301:
 - Type of voltage (VDC / VAC)
 - Low-level control
 - Connection (square-type/ bayonet plug)
 - Metering device (internal/ external cycle switch)
- Connect the electrical wires according to the following electrical connecting diagrams (page 13 to 16).

Operation with bayonet plug



4273a00

ATTENTION!

If the protective-conductor terminal is not connected or interrupted, dangerous touch voltages may occur on the equipment!

Protective measures to be applied for the appropriate operation with bayonet plugs:

"Functional extra-low voltage with safe isolation" /
"Protective Extra-Low Voltage" (PELV)

Standards: EN60204 Part1:1992 / IEC 204-1:1992, modified
DIN VDE 0100 Part 410 / IEC 364-4-41:1992
(see pages 15 and 16)

Alternate current (AC)

with integrated control p.c.b. and **attached** metering device, alarm contact as normally open or normally closed contact (programmable):




Fig. 11 Electrical connecting diagram for alternate current VAC with square-type plug, alarm contact as normally closed contact

Subject to modifications

Electrical Connecting Diagrams, continuation

Alternate current (AC)

with integrated control p.c.b. and **external** metering device, alarm contact as normally open or normally closed contact (programmable):




Fig. 12 Electrical connecting diagram for alternate current VAC with square-type plug, alarm contact as normally closed contact

Electrical Connecting Diagrams, continuation

Direct current (DC), square-type plug

with integrated control p.c.b. and **attached** metering device, alarm contact as normally open or normally closed contact (programmable):




Fig. 13 Electrical connecting diagram for direct current VDC with square-type plug, alarm contact as normally closed contact

Direct current (DC), square-type plug

with integrated control p.c.b. and **external** metering device, alarm contact as normally open or normally closed contact (programmable):





Fig. 14 Electrical connecting diagram for direct current VDC with square-type plug, alarm contact as normally closed contact

Subject to modifications

Electrical Connecting Diagrams, continuation

Direct Current (DC), bayonet plug

with integrated control p.c.b. and **attached** metering device, alarm contact as normally open or normally closed contact (programmable):




6298a04

Fig. 15 Electrical connecting diagram for direct current VDC with bayonet plug, alarm contact as normally open contact

Direct Current (DC), bayonet plug

with integrated control p.c.b. and **external** metering device, alarm contact as normally open or normally closed contact (programmable):



6300a04

Fig. 16 Electrical connecting diagram for direct current VDC with bayonet plug, alarm contact as normally open contact

Subject to modifications

Description




Fig. 17 QLS 301 with back position of the SSV metering device

- 1 Proximity switch
- 2 Control pin
- 3 SSV metering device
- 4 Nipple for external manual lubrication (1/8")

- The QLS 301 is a complete compact lubrication system for a **maximum of 18 lubrication points per operating cycle**.
- The pump has three basic configurations:
 - SSV metering device back-mounted (see Fig. 19)
 - SSV metering device bottom-mounted (see Fig. 20)
 - Pump without SSV metering device attached respectively with external metering device KNQLS (see fig. 21)
- The pump with bottom-mounted SSV metering device has the capability of using steel tubing as lubrication lines if necessary.
- Standard lubrication lines are high-pressure plastic hoses included in the pump installation kit for pumps with attached SSV metering device.



6001a02

NOTE

The function of the pump is independent of the SSV metering device's mounting position.




Fig. 18 QLS 301 with bottom position of the SSV metering device

- A signal from the pump timer starts the electric motor and the pumping element starts pumping the lubricant to the SSV metering device.
- When all lubrication points have received lubricant, an internal proximity switch (pos. 1, fig. 19, initiator) turns the motor off, completing one operating cycle.



6001a02

NOTE

If the QLS 301 is not provided with an attached SSV metering device but with an external SSV KNQLS (see Fig. 19, page 18), the proximity switch (of the SSV KNQLS) switches the motor off.

- If the operating cycle is not completed **within the maximum permissible time**, the flashing fault indication "Er" appears on the display of the membrane keypad (see Fig. 24, page 20). The QLS 301 does not start automatically anymore.

Max. cycle time of the VDC-version 25 minutes
Max. cycle time of the VAC-version 15 minutes

- 1 Connecting block
- 2 Manifold
- 3 SSV metering device
- 4 Nipple for external manual lubrication (1/8")
- 5 Plug (1/8") for
- P external pressure line
- R external return line

Subject to modifications

Description, continuation




Fig. 19 QLS 301 without mounted SSV metering device with connection for external SSV metering device KN QLS

- 1 Connecting block
- 2 Closure plug
- 3 Nipple for emergency lubrication, R 1/8'
- 4 Connecting socket for SSV KN QLS
- P For feed line to external SSV KN QLS
- R Relief line connection

- An externally connected lubricant metering device SSV KN QLS is equipped with the same proximity switch as the normal QLS 301.
- The proximity switch is provided with a connecting cable of 2 m lengths and a connecting plug that must be connected to the socket of the QLS 301.
- The socket is integrated in the housing instead of the proximity switch and is connected to the control p.c.b.



6001a02

NOTE

The function of the QLS 301 is independent of the mounting position of the proximity switch.

There are available the following externally connectable metering devices SSV KN QLS:

- | | |
|-----------------|-------------|
| - SSV 6 KN QLS | 619-28945-1 |
| - SSV 8 KN QLS | 619-28946-1 |
| - SSV 10 KN QLS | 619-28949-1 |
| - SSV 12 KN QLS | 619-28950-1 |
| - SSV 14 KN QLS | 619-28951-1 |
| - SSV 16 KN QLS | 619-28952-1 |
| - SSV 18 KN QLS | 619-28953-1 |

Operation

Pump




Fig. 20 QLS 301, schematic

- The QLS 301 operates according to operating cycles (pause and lubricating times).
- The pause time begins the cycle, and then the lubricating time occurs.
- A division of the lube points (**option**) via sub-metering devices and one main metering device (SSV 6, SSV 8) is possible only up to **max. 18 points per operating cycle**. In this case, set the number of cycles of the main metering device according to the number of lube points or the lubricant need to 1, 2, 3 or max. 5 cycles; see P3 on page 27.

- 1 Low-level control
- 2 Proximity switch
- 3 Keypad with display
- 4 Control unit
- 5 Pump unit
- 6 SSV 6, 8, 12, 18

Pressure Relief Valve




Fig. 21 Pressure relief valve (cartridge) in housing

- The QLS 301 is protected with a pressure relief valve (cartridge).
- The pressure relief valve limits the pressure build-up in the QLS 301. It opens at an overpressure of 205 bar (3000 psi).
- If the pressure relief valve is actuated, this indicates that the system is malfunctioning. The lubricant flows back into the reservoir (hardly visible from outside).
- When the monitoring time of 15 minutes (VAC version) respectively 25 minutes (VDC version) has elapsed, the pump switches off. On the display of the membrane keypad appears the flashing fault indication * Er *, see display mode below Setting and Operation of the QLS.

Pump Display Window




Fig. 22 Green segment display, pause time

- When switching the pump on, the segment in the display window is lit (pause time starts).




Fig. 23 Green rotating display, lubricating time

- Pump "running" is indicated on the display by a rotating light movement of the green display (lubricating time).
- If the voltage supply is interrupted during the lubricating time, the times already expired are stored. When the power supply is switched on again, the lubricating time continues operating from the point where it had been interrupted.

Operation, continuation

Monitoring time/ malfunction




Fig. 24 Display of a fault indication




Fig. 25 Membrane keypad with fault indication and operator keys

- 1 Display window
- 2 Operator key
 - operating mode: trigger additional lubrication
 - programming mode: setting of times and metering device cycles – terminate programming
- 3 Operator key
 - display mode: acknowledge receipt of flashing functional fault
 - Operating mode: display of the set pause time and residual pause time
 - programming mode: change to the different programming levels

- If the proximity switch (pos. 1, fig. 17, page 17) does not give any feedback after the pause time has elapsed or after triggering additional operating cycles within **15 minutes** (AC monitoring time) or **25 minutes** (DC monitoring time), the pump switches off immediately. The flashing fault indication * Er * (Error) appears on the display.



6001a02

IMPORTANT

If a **malfunction** is present, the pump does **not switch on automatically** any longer.

- ➔ In this case, switch on the pump by pressing the button for additional operating cycle (pos. 2, fig. 31).
- ➔ The fault can be confirmed (see pos. 3, Fig. 25). However, this is not obligatory.



6001a02

IMPORTANT

When confirming a fault indication, the flashing light changes into a permanent light or a signal horn can be temporarily switched off.

- When a malfunction is present, it can be cancelled only by initiating an additional operating cycle and if a proper operating cycle has been executed afterward.
- If the fault is still present after an additional operating cycle has been initiated, the fault indication "Er" is displayed again.
- The monitoring time starts in parallel to the lubricating time. It is firmly adjusted and amounts to 15 respectively 25 minutes.
- If the voltage supply is interrupted during the monitoring time (lubricating time), the monitoring time starts from the beginning after the pump is switched on again.

Low-level indication

Low-level indication




Fig. 26 Announcement of a low-level indication

- In the **display mode** the flashing display * L8 *, * L7 *, * L6 *, ... * L1 * announces a **low-level indication**.
- Right at the end appears the flashing display * LL * to indicate an unconfirmed low-level indication (see page 21, Fig. 27).

Operation, continuation

Low-level indication, continuation




Fig. 27 Display of a low-level indication




Fig. 28 Parts of the low-level indication

- The follower plate (3) (Fig. 28) of the reservoir moves the pin (pos. 2) with the solenoid (pos. 1) ahead of the sensor on the printed circuit board and initiates the low-level signal.
- In this case, the pump is not switched off immediately. The current operating cycle is completed. Upon expiration of the pause time, the pump cannot be started again automatically. The flashing display "LL" appears, see Fig. 27.

➤ Fill reservoir.

- As soon as the lubricant reservoir is filled up, the "LL" display is cancelled. The operating cycle resumes.

- 1 Solenoid
- 2 Pin
- 3 Follower plate

Malfunction/low-level indication

- If both indications (fig. 24 and 27) occur at the same time, then both displays * Er * and * LL * will flash.

Operator keys of the keypad

Operator keys of the keypad in the operating mode




Fig. 29 Pushbutton for additional operating cycle

- **Additional operating cycle**

- is triggered via the button (Fig. 30). Press the button for 2 seconds.
- can be initiated at any time, provided that the power supply is applied.

If a fault signal (malfunction) is present, it will be cancelled as soon as the system is operating properly, again.



NOTE

An existing fault indication (flashing display) can be confirmed before triggering additional operating cycles. However, this is not obligatory (see Fig. 29).

Operator keys of the keypad in the programming mode




Fig. 30 Key for resetting the pause time

- **Reset of the pause time**

- Setting of the pause time by
 - single key activation for one hour/minute
 - permanent activation for quick run

- **Setting of the monitoring relay**


Setting of the metering device circulations:

- The monitoring relay signalizes a functional fault on an external lamp via the optional connection "X2" (see connecting diagrams).
In case of the standard setting "normally open contact" the fault is indicated by a lamp with permanent light.
In case of the setting "normally closed contact" the fault is indicated by a lamp gone out.

Operation, continuation

Operator keys of the keypad, continuation

Operator keys of the keypad in the programming mode, continuation



Continuation of fig. 30: Key for resetting the pause time and terminating the programming mode

- For VDC version 1 to 5 cycles
- For VAC version
- SSV 6 / SSV 8 1 to 3 cycles
- SSV 12 / SSV 18 1 cycle

- **Start settings**

- Set: SP (Start with pause time)
- SO (Start with lubricating time)

- Termination of the programming mode.

Operator keys of the keypad in the display mode




Fig. 31 Acknowledging receipt of a flashing fault indication

- **Acknowledging receipt of a malfunction**

- By pressing the key (fig. 31) the flashing *Er* changes into a permanent light.

- **Acknowledging receipt of the low-level indication**

- By pressing the key (fig. 31) the flashing *LL* changes into a permanent light.

Operator keys of the keypad in the operating mode




Fig. 32 Information regarding the set pause time and residual pause time

- **Display of information regarding the set pause time and residual pause time**

- Press key >2 seconds.

Operator keys of the keypad in the programming mode




Fig. 33 Changing to the different programming levels

- **Changing to the different programming levels**

- Press keys to access the programming mode.

- Set parameters.

- Setting:

hours	P1
minutes	P2
metering device cycles	P3
outlet potential-free contact	P4
external display for functional faults of (NO) or (NC) contacts	P5
start with pause time or lubricating time	P6
- termination of programming

Monitoring relay

- The monitoring relay signals a low-level indication or a malfunction (only in combination with optional connector X2, see electrical connection diagrams).
- In the first case the relay picks up (normally open contact).

- In the second case the relay releases (normally closed contact, broken-wire interlock).
- The signal is available via a potential-free contact.
- The monitoring relay is released upon acknowledgement of the fault.

Subject to modifications

Setting and Operation








6001a02

NOTE

The following technical description includes information on the centralized lubrication systems QLS 301 after upgrading them with the following control printed circuit boards:

- for 12/24 VDC ... 236-14212-7
- for 120 VAC 236-10298-6
- for 230 VAC 236-10298-1

Factory Settings

Programming steps	Factory setting	Description	Page
 min h 4215a99	6 h	6 hours Pause time	7
 min h 4217a99	0 min	0 minutes Pause time	7
 min h 4218a99	1 cycle	Operating cycles: 1 cycle (metering device cycle)	8
 min h 6252b04	no	Signal output of the fault relay: no (normally open) Signalizing during the failure, e. g. low-level indication	8
 min h 6255b04	--	Differentiation fault indication (ER) / low-Level control (LL): -- Permanent signal (no differentiation between ER and LL)	9
 min h 4299a00	SP	Start phase: SP Start with pause time	10

Tab. 1 Programming steps P1 to P6

Operator Keys

Key	Function
 4222a99	Key for modifying the parameters in the programming step

Fig. 34

Key	Function
 4214a99	Key for switching to the next programming step

Fig. 35


Subject to modifications

Setting and Operation, continuation

Three possible modes of operation and settings can be selected on the keypad.

- **Display mode**
- **Programming mode (page 26 ff)**
- **Operating mode (page 30 ff)**


Display Mode




4206a04

Display


press




4207a99




4227a99



6574b05



4208a04



4209a99

- **In the display mode** the user receives information on functions and malfunctions of the QLS 301.
- As soon as voltage is applied to the pump, the keypad is automatically in **display mode**. The **segment** is illuminated on the display.
- Normally, the display is dark. Only the functions (segment, rotating segment display) or malfunctions (* Er *, * LL *) are displayed.

- A test display is made when the voltage is applied, all segments and decimal points are illuminated for 2 seconds.



6001a02

NOTE

If ***EP*** is displayed after the display test, there is a malfunction of the operating keys (see page 20).

If ***EE*** is displayed, this indicates an electromagnetic interference. In this case, individually set times are set back to the factory setting and must be programmed newly

- **In the display mode** during the pause time there appears the right segment display (On). It is to display the readiness for operation (voltage supply). As soon as another message is displayed, the segment turns off.
- The lubricating time is displayed as a rotating segment.

Fig. 36 Display Mode (continuation next page)

Setting and Operation, continuation

Display Mode, continuation




Fig. 36 Display Mode

- * Er * is shown to indicate a malfunction.

- **In the display mode**, a low level is announced by an intermittent display of * L8 *, * L7 *, * L6 *, ... * L1 *.

- Finally appears the intermittent display * LL * for a low-level indication that had not been confirmed.

To acknowledge malfunctions

- The flashing display is changed into a continuous light by pressing the button (**acknowledging**). To **acknowledge**, press the button only briefly (< 2 sec.).
- Messages which have been acknowledged but have not yet been remedied flash again after the pump is switched off and on again.

Setting and Operation, continuation

Programming Mode




Fig. 37 Programming Mode (continuation next page)

Setting Pause Time P1 and P2

➤ To access the programming mode, **press both buttons** at the same time > **4 seconds**, so that "P1" appears in the display.

Programming options:	Pause time:
P1	0 - 59 hours
P2	0 - 59 minutes
Min. pause time DC	4 minutes
Min. pause time AC	20 minutes
Max. pause time DC/AC	59 hours 59 minutes

P1: Setting hours

When releasing the two buttons, the currently set value appears (here the factory-set value: 6 hours). The field "hour" is indicated by a **decimal point on the right-hand side**.

- Press button.
- Settings are made in one direction: 0, 1, 2, 3, ..., 59 h
- Button pressed once increases by 1 hour
- Button pressed continuously quick sequence

P2: Setting minutes

➤ Press button, so that "P2" appears in the display.

When releasing the button, the currently set value appears (here the factory-set value: 0 minutes). The field "minute" is indicated by a **decimal point on the left-hand side**.

- Press button.
- Settings are made in one direction: 0, 1, 2, 3, 4, ..., 59 min
- Button pressed once increases by 1 minute
- Button pressed continuously quick sequence



6001a02

NOTE



The minimum pause time is 4 respectively 20 minutes. For settings < 4 respectively < 20 minutes (without input of hours) there automatically appears ". 04" respectively ". 20" in the display provided the programming sequence has been carried out completely.

Setting and Operation, continuation

Programming Mode, continuation

P3: Setting number of cycles

If lube points are divided via sub-metering devices (SSV 6) and a main metering device (SSV 6, SSV 8), **never exceed a maximum of 18 (24) lube points.**



6001a02

IMPORTANT

Settings are only possible in connection with progressive metering device SSV 6 or SSV 8 KNQLS (connected as a main metering device) and a jumper attached at the p.c.b

➤ Press button, so that "P3" appears in the display.

Max. cycle time VDC 1 to 5
Max. cycle time VAC 1 to 3

When releasing the button, the currently set value appears (here the factory-set value: 1 cycle)



- Press button.
- Settings are made in one direction: 1, 2, 3, 4, 5



6001a02

NOTE

For the VDC version all metering device cycle numbers are possible with SSV 6, SSV 8, SSV 12 and SSV 18.
For the VAC version depending on the type of SSV metering device the following cycle numbers are possible:
- with SSV 6 and SSV 8 1 to 3
- with SSV 12 and SSV 18 1



P4: Programming of the output signal on the monitoring relay for external fault indication (external fault contact)

➤ Press button, so that "P4" appears in the display.


When releasing the button, the currently set value appears in the display (here the factory-set value "no", normally open contact).

- Press button.
The external fault contact is modified by programming it as an "nc" normally closed contact.

Fig. 37 Programming Mode (continuation next page)

Setting and Operation, continuation

Programming Mode, continuation



6255b04



4214a99

P5: Program external display for empty reservoir or fault indications

➔ Press button, so that "P5" appears in the display.



6256b04

factory setting


When releasing the button, the display symbol " - " for permanent signal appears in the display.



6001a02

NOTE

In this setting, a differentiation between low-level indication and fault indication is not possible.




6257b04




4222a99

The output signal on the monitoring relay for the external fault indication "P4" is set as a normally open contact (**no**) (see page 30).

➔ Press key to change the external signal into an intermittent signal.



Then low-level indications appear as intermittent signals and malfunctions as permanent signals (On).




6258b04



4222a99

The output signal on the monitoring relay for the external fault indication "P4" is set as a normally closed contact (**nc**) (see page 30).

➔ Press key to change the external signal into an intermittent signal.



Then low-level indications appear as intermittent signals and malfunctions as permanent signals (Off).

Fig. 37 Programming Mode (continuation next page)

Setting and Operation, continuation

Programming Mode, continuation




4299a00



4214a99



6259b04



6260b04



4222a99


P6: Program start phase

- Press button, so that "P6" appears in the display.

The pump is set as a standard with starting pause time **SP (Start Pause time)**.

- Press button.

The pump then starts after each switching on with the lubricating time **SO (Start Operation)**. After the first lubricating time the preset pause time is valid.



4221a99



4214a99



4222a99

Completing the programming

- Press button. „ P -“ is displayed.



6001a02

IMPORTANT

In order to avoid a wrong program, make sure to always carry out the programming order completely, i. e. setting of P1 (hours), P2 (minutes), P3 (number of cycles), P4 (external contact), P5 (external display), P6 (start phase) and P- (Programming end).

- Press this key (additional lubrication) to complete the programming and to save the entered parameters.




6001a02

NOTE

If the button "additional lubrication" is not pressed within 30 seconds, the changed parameters are not saved and the previous programming remains valid.

IMPORTANT

After completion of the programming, check the parameter settings in the operating mode once again (see pages 33 ff).



4208a99

Fig. 37 Programming Mode

Setting and Operation, continuation

Operating Mode

Display	press
<p>4208a04</p>	
<p>4209a99</p>	<p>4222a99</p> <p>> 2 sec.</p>
<p>4208a04</p>	
<p>4123a99</p>	<p>4214a99</p>
<p>4216a99</p>	after two sec.
<p>4220a99</p>	after two sec.
<p>4224a99</p>	after two sec.

Fig. 38 Operating Mode (continuation next page)



6001a02

IMPORTANT

The operating mode is accessible only during the pause time, and cannot be operated during the running time (pump lubricating time).

- Precondition: When the voltage supply is applied, the segment (On) is lit.

Operating option: Initiating an additional operating cycle

- Press the button (> 2 sec.). The elapsed pause time is reset. The lubricating time starts. A rotating segment is visible on the display during the whole lubricating time.

Operating option: Calling up of set parameters and data determined

- Press the button.

PP (set pause time)



6001a02

NOTE

The following display sequence is shown **once** and is cancelled after 40 seconds. The change of display occurs every two seconds. Example:

PP = 12h 30 min
rP = 5h 10 min

12 . (hours)

. 30 (minutes)

rP (remaining pause time)

Setting and Operation, continuation

Operating Mode, continuation

	after two sec.	5. (hours)
4225a99		
	after two sec.	.10 (minutes)
4226a99		
	after two sec.	AC number of the automatically triggered operating cycles, countable up to 9999 cycles. Then counting starts from the beginning again.
4277a00		Example 0625 cycles:
	after two sec.	06. Display for thousands and hundreds 06 as 600
4281a00		
	after two sec.	.25 Display for tens and ones
4280a00		
	after two sec.	UC Number of the manually triggered (by the user) additional operating cycles, countable up to 9999 cycles. Then counting starts from the beginning again.
4278a00		Example 0110 cycles:
	after two sec.	01. Display for thousands and hundreds 01 as 100
4297a00		
	after two sec.	.10 Display for tens and ones
4226a99		

Fig. 38 Operating Mode (continuation next page)

Setting and Operation, continuation

Operating Mode, continuation

	after two sec.	P3: <u>Number of metering device cycles</u>
4218a99		
	after two sec.	Display of the metering device cycles
4219a99		
	after two sec.	P4: <u>Programming of the output signal</u>
6252b04		
	after two sec.	Display of the output signal “normally closed” (nc) or “normally open” (no)
6253b04		
	after two sec.	P5: <u>Differentiation between low-level indication and fault indication</u> (only external indication)
6255b04		
	after two sec.	Differentiation inactive
6256b04		
	after two sec.	P6: <u>Programming of the start phase</u>
4299a00		
	after two sec.	Display of the start phase with “start lubricating time” (SO) or “start pause time” (SP)
6260b04		
	after approx. 40 sec.	Termination of the operating mode
4208a04		

Fig. 38 Operating Mode

Maintenance, Repair and Tests

Maintenance

- Maintenance is essentially limited to refilling the reservoir with clean lubricant as necessary. However, check regularly whether the lubricant is being dispensed to all the lubrication points.
- Also check the feed lines for damage and replace them, if necessary.



4273a00

CAUTION!

Turn off the voltage supply for pumps 120 VAC and 230 VAC before servicing the pump.



6001a02


NOTE

Whenever work is performed on the centralized lubrication system, special attention should be paid to cleanness. Dirt will cause failure of the system.

IMPORTANT

To clean the system use petroleum spirit or petroleum. Do not use Tri, Per or similar solvents or polar or organic solvents such as alcohol, methanol, acetone, etc.

To fill reservoir



4231a99

Fig. 39 Filling nipple for filling reservoir

- 1 Filling nipple
- 2 Vent hole
- 3 Follower plate

Filling of the empty reservoir

- Make sure that all air has been expelled from under the follower plate after refilling the empty reservoir.
- The follower plate seal should contact the hole located on the top of the reservoir. Small amount of grease should be refilled to ensure expelling of air from under the follower plate.

Fill the reservoir up to the "Max." mark via the filling nipple, see fig. 38.



6001a02

IMPORTANT

The grease must be free from impurities and must not be liable to change its consistency over the course of time.

NOTE

If the reservoir has been completely emptied, the pump may require priming and a longer running time to reach the full lubricant output. Therefore, trigger additional operating cycles manually.



1013A94

CAUTION!

**Risk of bursting if the reservoir is overfilled!
When filling the reservoir by means of pumps with a large delivery volume, do not exceed the max. filling mark.**

Maintenance, Repair and Tests, continuation

Repair

- For repair work on the QLS 301 use only original **Lincoln** spare parts.
- Using non-**Lincoln** parts voids the pump warranty.



4273a00

CAUTION!

Switch off the voltage supply for pumps 120 VAC and 230 VAC before servicing the pump.



1013A94

CAUTION!

*By operating the drive motor without the reservoir installed, there is a **risk of injury** by the eccentric gear. Never use the lubrication system QLS 301 without installing the reservoir!*

Functional Test



4222a99

- ➞ Press pushbutton > 2 sec. to trigger an operating cycle.

Fig. 40 Pushbutton for additional operating cycle

Troubleshooting

Pump of the QLS 301 system




Fig. 41 Green rotating segment, lubricating time

- The green rotating display indicates that the pump operates properly.

Fault: Pump motor doesn't run

Cause:

- Power supply interrupted. Green decimal point On/h on display is not lit.
- Power supply from printed circuit board to motor interrupted. Electric motor defective.
- Printed circuit board defective
- Keypad or button is defective. "EP" display at the keypad flashes.

Remedy:



4273a00

Warning!

Disconnect the power supply before starting any maintenance or repair works.

- Check the voltage supply to the pump/fuses. If necessary, eliminate the fault or replace the fuses.
- Check the feedline from the fuses to the plug of the pump and then to the printed circuit board.
- Trigger an additional operating cycle. Check voltage supply from the printed circuit board to the motor.
- Replace printed circuit board.
- Replace housing with keypad.

Fault: Pump does not deliver lubricant

Cause:

- Reservoir is almost empty. "LL" display at the keypad is flashing.
- Pump lost prime and "Er" display at the keypad is flashing.
- Air pockets in lubricant.
- Improper lubricant has been used.
- Suction hole of pump element clogged.
- Pump piston is worn.
- Check valve in pump element defective or clogged.

Remedy:

- Fill up the reservoir with clean grease. Let the pump run (initiate an additional operating cycle) until lubricant shows at all lube points.



6001a02

NOte

Dependent on the ambient temperature and/or sort of lubricant output. Therefore, trigger several additional operating cycles.

- Trigger an additional operating cycle. Lubricant must dispense without air bubbles.
- Change the lubricant.
- Remove pump element. Check suction hole for foreign particles. If there are any, remove them.
- Replace pump element.
- Replace pump element.

Troubleshooting, continuation

Fault: Pump either does not switch off at all or only after the monitoring time of 15 min.

Cause:

- Proximity switch is not dampened, i.e. the control pin does not move within the switching range of the initiator, or the distance between the control pin and the initiator surface is more than 0.5 mm (0.02 in.).

Remedy:

- Trigger additional lubrication. Check whether the control pin moves centrally over the switching surface of the initiator. In case the adjustments do not correspond to the indications, the fixing position of the metering device has to be corrected.
- Check the distance.
 - Between the control pin and the switching surface of the initiator (max. 0.5 mm; 0.02 in.)
 In case the adjustments do not correspond to the indications, the fixing position of the proximity switch has to be corrected.
 - Distances between the switching surface of the initiator and the upper edge of the fixing nut:
 - When the metering device is mounted at the back: 16+ / -0.2 mm (0.62+/-0.08 in.)
 - When the metering device is mounted at the bottom: 12.7 +/-0.1 mm (0.5 +/-0.004 in.).
- Tightening torque of the nut: 1.5 NM (1.10 ft-lb.).


Fault: Pump runs continuously

Cause:

- Programming of pause time in step P1 was set to "00". Programming of further steps P2, P3, P4, P5, P6 and P- was not carried out. Pump starts running immediately. The proximity switch switches off the cycle for two minutes. Then, pump runs continuously.

Remedy:

- Switch off pump (power supply) by removing left-hand side socket from plug.
- Press both buttons of keypad:



- Switch on pump (power supply) by replugging left-hand side socket.
- Release both pushbuttons after approx. 5 seconds.
- The factory-set pause time of 6 hours is automatically reset.
- Afterwards new setting of pause time is possible.

Fault: Fault indication * EE *

Cause:

- Electromagnetic interferences have modified the customer's time setting. All values have been set back to the factory setting.

Remedy:

- Eliminate electromagnetic interferences.
- Repeat individual programming (see as of page 26).

Troubleshooting, continuation

SSV metering device

Fault: Blockage in the downstream progressive system

Cause:

- Bearings, lines or metering device clogged
 - Mounting position of metering device: bottom
 - In the case of metering devices SSV 8,12 and 18, the outlets 1 and/or 2 are closed.
 - Mounting position of metering device: back
 - In the case of metering devices SSV 6, 12 and SSV 18, outlet 1 is closed and outlet 2 is connected to a lube point.
- The fault can be identified as follows:
- a) Fault indication "Er" flashing on the keypad display.
 - b) The indicator pin at the metering device piston does not move.

Remedy:

- Determine the cause of the blockage as described in the following example and eliminate it.
- Let the pump run (refer to "trigger additional operating cycles").
- Disconnect all feed lines (pos. D) of the metering device one after the other. If grease shows under pressure the blockage is located in the line of outlet 3 or in the connected bearing point.
- Pump through the blocked line or bearing point using a hand pump.



6001a02

NOTE

To check the individual outlets, leave all outlets disconnected for a while, since only one piston stroke is executed with each motor revolution. Several strokes are required for a full cycle of all metering devices.

- Check pressure relief valve (fig. 21, page 19). Replace it, if necessary.




Fig. 43 Example of a QLS 301

- A pressure relief valve
- B pump
- C SSV 12 metering device
- D feed lines
- R return line

Troubleshooting, continuation

Fault: Blockage in the downstream progressive system, continuation

Cause:

- Metering device is blocked

Remedy:

- Replace the metering device or clean it as follows:
 - Remove all threaded tube fittings.
 - Unscrew the piston closure plugs.
 - Remove the piston, if possible, with a soft mandrel (smaller than \varnothing 6 mm, 0.24 in).



6001a02

IMPORTANT

The pistons are individually fit in the bores of the metering device. After removing the pistons, mark them in order to reinstall them in the right direction and position. They may not be interchanged.

- Thoroughly clean the metering device body in a grease-dissolving detergent and dry it with compressed air.
- Clean through the material passages (\varnothing 1.5 mm, 0.59 in) at the thread ends of the piston bores using a pin.
- Clean the metering device once more and dry it thoroughly.
- Reassemble the metering device.

Fault: Differing lubricant amounts at the lubrication point

Cause:

- Lubricant metering not correct.
- Setting of the pause time incorrect.

Remedy:

- Check the lubricant metering acc. to the lubrication chart.
- Check time setting.

Technical Data

QLS 301, GENERAL

Operating temperature..... -25° C to 70° C (-10° F to 160° F)
 Maximum operating pressure of pump model without metering device..... 205 bar (3,000 psig)
 Number of outlets..... 6, 8, 12, 18
 Output per outlet and cycle approx. 0.2 cm²
 Reservoir capacity 1 l
 Lubricant up to NLGI 2 grease
 Weight (average) 5.7 kg. (12.5 lbs.)
 Protection..... IP6K 9K acc. to DIN 40050 T9
 Reverse polarity protection:
 The operating voltage inlets are protected against reverse polarity.

ELECTRICAL DATA AC (ALTERNATE CURRENT)

Operating voltage..... 120 VAC/60 Hz +/- 10 %
 Operating current..... 1,0 A
 Operating voltage..... 230 VAC; 50/60 Hz +/- 10 %
 Operating current..... 0.5 A

ELECTRICAL DATA DC (DIRECT CURRENT)

Operating voltage..... 12 V, - 20%/+ 30 %
 Operating current..... 2,0 A
 Operating voltage..... 24 V, - 20%/+ 30 %
 Operating current 1.0 A
 Residual ripple in relation to the operating voltage ± 5% acc. to DIN41755



6001a02

NOTE

The pump motor is suitable for intermittent operation only.

- In addition to the EMV directive, **DC systems** also comply with the following guidelines and standards:
 - vehicle guideline 95/245/EC
 - EMV regulation for on-road vehicles acc. EN 40839 parts 1, 3 and 4

TIME SETTING

Range of pause time increment 1 minute
 - VDC 4 minutes to 60 hours
 - VAC 20 minutes to 60 hours
 Factory setting
 Pause time 6 hours/cycle

Numbers of operating cycles
 - VDC 1 to 5 cycles
 - VAC SSV 6 / SSV 8 1 to 3 cycles
 SSV 12 / SSV 18 1 cycle

Timer memory..... indefinite over EEPROM

RELAY FOR MALFUNCTION AC (OPTION)

Potential-free outlet for malfunction/low-level option
 Switching voltage..... max. 230 VAC/ 125 VDC
 Switching current..... max. (resistive) 2 A
 Switching capacity max. 100 VA/80 W

RELAY FOR MALFUNCTION DC (OPTION)

Potential-free outlet for malfunction/low level option
 Switching voltage..... max. 48 VAC/ VDC
 Switching current..... max. (resistive) 2 A
 Switching capacity max. 100 VA/80 W



6001a02

NOTE

All data depends on operating voltage, ambient temperature and max. operating pressure.

LINES

Plastic tube (ø 6x1,5 mm; 1/4 in.)

Min. bending radius 50 cm (2 in.)
 Bursting pressure at 20° C (70°F) approx. 210 bar (3050 psi)
 Min. temperature -25° C (-10°F)

TIGHTENING TORQUES

Pump

Electric motor to housing..... 3 NM (2.5 lb.-ft)
 Pump element in housing..... 25 NM (19.0 lb.-ft)

Metering device, accessories

Closure plug (piston) in metering device 18 NM (13.5 lb.-ft)
 Closure plug (outlets) in metering device 15 NM (11.0 lb.-ft)
 Outlet fitting in metering device
 - screw-type 17 NM (12.5 lb.-ft)
 - push-in type 12 NM (9.0 lb.-ft)
 Compression nut onto outlet fitting, screw-type:
 - plastic tube 10 NM (7.5 lb.-ft)
 - steel tube 11 NM (8.0 lb.-ft)
 Indicator pin in metering device 18 NM (13.5 lb.-ft)
 Mounting of the metering device 10 NM (8.0 lb.-ft)

ACCESSORY KITS:

Inch-Size Kits:

SSV 6/8 part no. 550-36971-1
 SSV 12 part no. 550-36971-2
 SSV 18 part no. 550-36971-3

Metric Size Kits:

SSV 6/8 part no. 550-36970-1***
 SSV 12 part no. 550-36970-2***
 SSV 18 part no. 550-36970-3***

*** Lube fittings must be ordered separately

Service Parts

Version with bayonet plug

(VDC application only)




Fig. 47 QLS 301 housing with **bottom-mounted** SSV metering device and bayonet plug (replacement of pos. 11, Fig. 49)




Fig. 48 QLS 301 housing with **back-mounted** SSV metering device and bayonet plug (replacement of pos. 11, Fig. 50)


Parts list for bottom-mounted and back-mounted SSV lubricant metering devices with bayonet plug

Pos.	Description	Kit	Single Part	Qty	Part No.
11	Housing cover for VDC, plug 1A1	x		1	550-34179-3
11.1	Socket with 6 m cable for bayonet plug or Socket with 6 m cable for bayonet plug ADR	x		1	664-34045-1
		x		1	664-34045-3
11.2	Bayonet plug		x	1	664-34045-2
12	Proximity switch	x		1	550-36980-1

Tab. 2 Parts list, QLS 301 with bayonet plug to table 3 and 4 (instead of square-type plug, pages 43 and 45)

Service Parts, continuation

QLS 301 with bottom-mounted SSV metering device and square-type plug



4193b02

Fig. 49 QLS 301 with bottom-mounted SSV metering device and square-type plug

Subject to modifications

Service Parts, continuation

Parts list for bottom-mounted SSV metering device and square-type plug

Pos.	Description	Kit	Single part	Qty	Part No.
1	Reservoir	x		1	550-36979-2
2	Spring DA 28x1,6x106		x	1	218-14172-6
3	Follower plate	x		1	550-36979-3
4	Intermediate bottom	x		1	450-24749-1
5	Eccentric gear	x		1	550-36979-4
6	Shaft	x		1	550-36979-1
7	Pressure relief valve, cartridge		x	1	235-14343-1
8	Pump element, assy. ø 6 mm		x	1	650-28856-1
9	Sealing parts for pump element	x		1	550-36979-5
10	Housing with low level control	x		1	550-36981-3

With square-type plug (pos. 11, fig. 49, page 42):


11	Housing cover with low level control and VDC, plug 1A1	x		1	550-34179-3
	or VDC, plug 2A1	x		1	550-36984-2
	Housing cover with low level control and VAC, plug 1A1	x		1	550-36984-3
	or VAC, plug 2A1	x		1	550-36984-4
11.1	Socket 2 with 10 m cable, for remote control	x		1	664-36078-9
11.2	Socket, black GMD-3011		x	2	236-13277-9
11.3	Flat packing		x	2	236-13294-3
11.4	Appliance plug 2 , for remote control, VDC		x	1	664-36968-6
	Appliance plug 2 , for remote control, VAC		x	1	664-36968-5
11.5	Appliance plug 1, for power supply, VDC		x	1	664-36968-4
	Appliance plug 1, for power supply, VAC		x	1	664-36968-3
11.6	Socket 1 with 10 m cable, for power supply		x	1	664-36078-7
11.7	Screw with washer assy.		x	1	201-14434-1

Pos.	Description	Kit	Single part	Qty	Part No.
12	Proximity switch	x		1	550-36980-1
13	p.c.b. for 1-5 cycles 12/24 VDC	x		1	550-36983-7
	p.c.b. for 1 cycle 120 VAC	x		1	550-34199-1
	230 VAC	x		1	550-34199-3
	p.c.b. for 3 cycles 120 VAC	x		1	550-34199-2
	230 VAC	x		1	550-34199-4
14	Low-level control	x		1	550-36979-9
15	Motor, 12 VDC	x		1	550-36982-1
	Motor, 24 VDC	x		1	550-36982-2
	Motor, 120 VAC	x		1	550-36982-3
	Motor, 230 VAC	x		1	550-36982-4
15.1	Motor connection VDC		x	1	664-36968-2
15.2	Motor connection VAC		x	1	664-36968-1
16	Hydraulic lube fitting, ST AR 1/8		x	1	251-14040-1
17	Adapter M 22x1,5 (a) x G 1/8 in.(i)		x	1	304-19619-1
18	O-Ring ø 5 x1, 5 mm		x	3	219-12222-2
19	Banjo bold		x	1	226-13777-2
20	Sealing ring alumi- num		x	2	226-13780-1
21	Manifold	x		1	550-36979-6
22	Connecting block	x		1	550-36979-7
23	Hydraulic lube fitting, ST AR 1/8		x	1	251-14040-1
24	SSV metering device SSV 8 - K	x		1	619-37586-1
	SSV 12 - K	x		1	619-37587-1
	SSV 18 - K	x		1	619-37588-1
25	Piston plug with sealing for control pin		x	1	519-32123-1
	Sealing kit for QLS 301		x	1	550-36979-8

Subject to modifications

Service Parts, continuation

QLS 301 with back-mounted SSV metering device and square-type plug



4194b02

Fig. 50 QLS 301 with back-mounted SSV metering device and square-type plug

Subject to modifications

Service Parts, continuation

Parts List for back-mounted SSV metering device and square-type plug

Pos.	Description	Kit	Single Part	Qty	Part No.
1	Reservoir	x		1	550-36979-2
2	Spring DA 28x1,6x106		x	1	218-14172-6
3	Follower plate	x		1	550-36979-3
4	Intermediate bottom	x		1	450-24749-1
5	Eccentric gear	x		1	550-36979-4
6	Shaft	x		1	550-36979-1
7	Pressure relief valve, cartridge		x	1	235-14343-1
8	Pump element, assy. ø 6 mm		x	1	650-28856-1
9	Sealing parts for pump element	x		1	550-36979-5
10	Housing with low- level control	x		1	550-36981-3

With square-type plug (pos. 11, fig. 50, page 44):


11	Housing cover with low level control and VDC, plug 1A1 or VDC, plug 2A1	x		1	550-34179-3
	Housing cover with low level control and VAC, plug 1A1 or VAC, plug 2A1	x		1	550-36984-2
	Housing cover with low level control and VAC, plug 1A1 or VAC, plug 2A1	x		1	550-36984-3
	Housing cover with low level control and VAC, plug 1A1 or VAC, plug 2A1	x		1	550-36984-4
11.1	Socket 2 with 10 m cable, for remote control	x		1	664-36078-9
11.2	Socket, black GMD-3011		x	2	236-13277-9
11.3	Flat packing		x	2	236-13294-3
11.4	Appliance plug 2, for remote control, VDC		x	1	664-36968-6
	Appliance plug 2, for remote control, VAC		x	1	664-36968-5
11.5	Appliance plug 1, for power supply, VDC		x	1	664-36968-4
	Appliance plug 1, for power supply, VAC		x	1	664-36968-3

Pos.	Description	Kit	Single Part	Qty	Part No.
11.6	Socket 1 with 10 m cable, for power supply		x	1	664-36078-7
11.7	Screw with washer assy.		x	1	201-14434-1

12	Proximity switch	x		1	550-36980-1
13	p.c.b. for 1-5 cycles 12/24 VDC	x		1	550-36983-7
	p.c.b. for 1 cycle 120 VAC	x		1	550-34199-1
	230 VAC	x		1	550-34199-3
	p.c.b. for 3 cycles 120 VAC	x		1	550-34199-2
	230 VAC	x		1	550-34199-4
14	Low-level control	x		1	550-36979-9
15	Motor, 12 VDC	x		1	550-36982-1
	Motor, 24 VDC	x		1	550-36982-2
	Motor, 120 VAC	x		1	550-36982-3
	Motor, 230 VAC	x		1	550-36982-4
15.1	Motor connection VDC		x	1	664-36968-2
15.2	Motor connection VAC		x	1	664-36968-1
16	Hydraulic lube fitting, ST AR 1/8		x	1	251-14040-1
17	Adapter M 22x1,5 (a) x G 1/8 in.(i)		x	1	304-19619-1
18	O-Ring ø 5 x1, 5 mm		x	3	219-12222-2
19	SSV metering device				
	SSV 6 - K	x		1	619-37589-1
	SSV 12 - K	x		1	619-37590-1
	SSV 18 - K	x		1	619-37591-1
20	Hydraulic lube fitting, ST AR 1/8		x	1	251-14040-1
21	Piston plug with sealing for control pin		x	1	519-32123-1
	Sealing kit for QLS 301			1	550-36979-8

Option for metric fittings (not included in the accessory kits)


SSV Connecting tube fitting, screw-type and push-in type



- 1 Ferrule nut
- 2 Cutting ring
- 3 Valve body with sealing and ferrule

Fig. 51 Screw-type check valve

Connection of the pressure plastic tube or the high-pressure hose



- For high-pressure hose (\varnothing 4.1 x 2.3 mm) use check valve A, fig. 52, with reinforced collets 1a and smooth flange (part no. 226-14091-4)
- For pressure plastic tube (\varnothing 6 x 1.5 mm) use check valve B, fig. 52, with standard collets 2a and knurled flange (part no. 226-14091-2)

- A Check valve with reinforced collets
- B Check valve with standard collets
- 1a Smooth flange
- 2a Knurled flange

Fig. 52 Different types of check valves



Fig. 53 Check valve with reinforced collets and high-pressure hose



6001a02

NOTE

On construction machines or agricultural machines use high-pressure hoses as feed lines. In such cases, the check valves of the sub-metering devices must have a reinforced collets and a smooth flange.



6001a02

IMPORTANT

Connect only high-pressure hoses (\varnothing 4.1 x 2.3 mm) with threaded sleeve and hose stud to the check valves with reinforced collets.

Option for metric fittings (not included in the accessory kits), continuation

Mounting of the threaded sleeves and hose studs onto the high-pressure hose




Fig. 54 Pre-assembly of the threaded sleeves and hose studs onto the main line

- Screw threaded sleeve (1, fig. 54) counterclockwise onto the high-pressure hose (2) until the illustrated dimension of 11mm is reached. Then screw the hose stud (3) into the threaded sleeve (1).



IMPORTANT

Oil parts 1 and 3 well before screwing them together.

6001a02

- 1 Threaded sleeve
- 2 Main line
- 3 Hose stud

EC Declaration of Conformity as defined by Machinery Directive 98/37/EC, Annex II A

This is to declare that the design of the

QLS 301 lubrication system

in the version supplied by us, complies with the provisions of the directive 98/37/EC – including all modifications of this directive valid at the time of the declaration.

Applied harmonized standards in particular:

- EN 12100-1** Safety of machinery part 1
Basic terminology, methodology
- EN 12100-2** Safety of machinery part 2
Technical principles and specifications
- EN 809** Pumps and pump units for liquids
Safety requirements
- EN 60204-1** Safety of machinery
Electrical equipment of machines
Part 1: General requirements

EC Declaration of Conformity according EMC Directive 2004/108/EC

We declare that the model of the

QLS 301 lubrication system

in the version supplied by us, complies with the provisions of above-mentioned directive.

Applied harmonized standards in particular:

- EN 55011** Specifications, limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) radio-frequency equipment
- EN 50081-1** Electromagnetic compatibility
Generic emission standard
Part 1: residential, commercial and light industry
- EN 50082-2** Electromagnetic compatibility
Generic immunity standard
Part 2: industrial environment

Walldorf, 10.08.2004, Dr. Ing. Z. Paluncic

Walldorf, 10.08.2004, Dr. Ing. Z. Paluncic

Subject to modifications

U.S. Patent-No. 6,244,387, German Registration Design No. 29923765.6

America:	Europe/Africa:	Asia/Pacific:	
Lincoln Industrial One Lincoln Way St. Louis, MO 63120-1578 USA Phone: (+1) 314 679 4200 Fax: (+1) 800 424 5359	Lincoln GmbH & Co. KG Heinrich-Hertz Straße 2-8 69190 Walldorf, Germany Tel: (+49) 6227 33-0 Fax: (+49) 6227 33-259	Lincoln Industrial Corporation 51 Changi Business Park Central 2 # 09-06 The Signature Singapore 486066 Phone: (+65) 6588-0188 Fax: (+65) 6588-3438 Email: sales@lincolnindustrial.com.sg	© Copyright 2005 Printed in Germany Web site: www.lincolnindustrial.com

Subject to modifications