





## Contents and general safety instructions

Original ..... de

Version ..... en 1207c

Designation ..... P.BE-CPX-FB6-EN

Order no. .... 526434

© (Festo AG & Co. KG, D-73726 Esslingen, 2012)

Internet: <http://www.festo.com>

E-Mail: [service\\_international@festo.com](mailto:service_international@festo.com)

Reproduction, distribution or sale of this document or communication of its contents to others without express authorization is prohibited. Offenders will be liable for damages. All rights reserved in the event that a patent, utility model or design patent is registered.

INTERBUS<sup>®</sup>, TORX<sup>®</sup> and VDE<sup>®</sup> are registered trademarks of the respective trademark owners in certain countries.

## Table of contents

Intended use .....	III
Target group .....	IV
Service .....	IV
Important user information .....	V
Instructions on this description .....	VII
<b>1. Installation .....</b>	<b>1-1</b>
1.1 General installation instructions .....	1-3
1.2 Settings of the DIL switches on the bus node .....	1-7
1.3 Connecting the fieldbus .....	1-14
1.3.1 System structure on the remote bus .....	1-14
1.3.2 Pin allocation of the fieldbus interface .....	1-17
1.3.3 Connecting the fieldbus .....	1-18
1.3.4 Fieldbus baud rate and fieldbus length .....	1-21
1.4 Fibre-optic cable connection for Interbus .....	1-22
1.5 Selection of the power supply unit .....	1-23
1.6 Pin allocation of power supply .....	1-23
<b>2. Commissioning .....</b>	<b>2-1</b>
2.1 Configuration and addressing .....	2-4
2.1.1 Ascertaining the address range .....	2-4
2.1.2 Address assignment of the CPX terminal .....	2-14
2.1.3 Address assignment after extension/conversion .....	2-24
2.1.4 Bus configuration and addressing .....	2-27
2.1.5 Switching on the power supply .....	2-28
2.1.6 Bus configuration with the CMD software .....	2-29
2.1.7 Bus configuration without CMD software .....	2-38
2.1.8 Process data entry via the CMD software .....	2-39
2.1.9 Configuration in the remote controller operating mode .....	2-42
2.2 Parametrisation .....	2-43
2.2.1 Parametrisation concepts .....	2-45
2.2.2 Device parametrisation with the CMD software .....	2-49

2.2.3	Parametrisation with CMD user functions .....	2-50
2.2.4	Parametrisation with the PLC user program .....	2-53
2.3	Commissioning the CPX terminal on the Interbus .....	2-54
2.3.1	Fail safe .....	2-55
<b>3.</b>	<b>Diagnostics and error handling .....</b>	<b>3-1</b>
3.1	Summary of diagnostics options .....	3-4
3.2	Diagnostics via LEDs .....	3-6
3.2.1	Normal operating status .....	3-7
3.2.2	CPX-specific LEDs .....	3-8
3.2.3	Interbus-specific LEDs .....	3-11
3.3	Diagnostics via Interbus .....	3-13
3.3.1	Status bits .....	3-13
3.3.2	I/O diagnostics interface .....	3-15
3.3.3	Diagnostics via the PCP channel .....	3-16
3.3.4	Peripheral faults (PF) .....	3-18
3.4	Error handling .....	3-20
<b>A.</b>	<b>Technical appendix .....</b>	<b>A-1</b>
A.1	Technical data bus node type CPX-FB6 .....	A-3
A.2	Accessories .....	A-5
A.3	Access to parameters and data via the PCP channel .....	A-6
A.4	Parameters in the operating mode Remote I/O .....	A-8
A.4.1	System parameters .....	A-8
A.4.2	Module parameters .....	A-9
A.4.3	Diagnostic memory parameters .....	A-18
A.4.4	Diagnostic memory data .....	A-18
A.4.5	System diagnostics data .....	A-20
A.4.6	Module diagnostics data .....	A-21
A.4.7	System data .....	A-22
A.4.8	Module data .....	A-22
A.4.9	Length of the PCP data objects .....	A-24
<b>B.</b>	<b>Index .....</b>	<b>B-1</b>

## Intended use

The bus node documented in this description CPX-FB06 is exclusively for use as a participant in the Interbus.

The CPX terminal must only be used as follows:

- as intended in an industrial environment
- in original condition, without unauthorised modifications. Only the conversions or modifications described in the documentation supplied with the product are permitted.
- in excellent technical condition.

If standard ancillary components, such as sensors and actuators, are connected, the specified limits for pressures, temperatures, electrical data, torques, etc. must be complied with. Observe the standards specified in the respective chapters and comply with the regulations of the trade association and the German Technical Control Board (TÜV), the VDE specifications or relevant national regulations.



### Warning

- Only use PELV circuits in accordance with IEC/EN 60204-1 (protective extra-low voltage, PELV) for the electrical power supply.
- Observe also the general requirements for PELV power circuits in accordance with IEC/EN 60204-1.
- Only use voltage sources which guarantee reliable electrical isolation of the operating voltage in accordance with IEC/EN 60204-1.

Through the use of PELV circuits, protection against electric shock (protection against direct and indirect contact) is ensured in accordance with IEC/EN 60204-1.

## **Target group**

This description is intended exclusively for technicians trained in control and automation technology, who have experience in installing, commissioning, programming and diagnosing slaves on the Interbus.

## **Service**

Please consult your local Festo Service if you have any technical problems.



## Important user information

### Danger categories

This description includes instructions on the possible dangers which can occur if the product is used incorrectly. These instructions are marked with a signal word (Warning, Caution, etc.), printed on a shaded background and marked additionally with a pictogram. A distinction is made between the following danger warnings:



#### **Warning**

... means that failure to observe this instruction may result in serious personal injury or material damage.



#### **Caution**

... means that failure to observe this instruction may result in personal injury or material damage.



#### **Note**

... means that failure to observe this instruction may result in material damage.

In addition, the following pictogram marks passages in the text which describe activities with electrostatically sensitive devices:



Electrostatically sensitive devices: Incorrect handling may cause damage to devices.

## Marking special information

The following pictograms mark passages in the text which contain special information.

### Pictograms



**Information:**  
Recommendations, tips and references to other information sources.



**Accessories:**  
Specifications on necessary or useful accessories for the Festo product.




**Environment:**  
Information on the environmentally friendly use of Festo products.

### Text designations

- Bullet points indicate activities which may be carried out in any sequence.
- 1. Numerals identify activities which must be carried out in the sequence specified.
- Arrowheads indicate general lists.

## Instructions on this description

This description contains information about the following module:

CPX bus node	Type designation	Description	Connection technology
	<p>CPX-FB6</p>	<p>CPX bus node for Interbus</p> <p>Data transmission:</p> <ul style="list-style-type: none"> <li>– Interbus uses the closed loop protocol (user data are encapsulated by outline data).</li> <li>– Real-time-capable</li> </ul> <p>Standards and norms with reference to Interbus:</p> <ul style="list-style-type: none"> <li>– EN 50254</li> <li>– IEC 61158</li> <li>– IEC 61784</li> </ul>	<p>incoming: Sub-D (plug)</p> <p>continued: Sub-D (socket)</p>

Tab. 0/1: Overview, CPX bus node for Interbus



**Note**

This description refers to the following revision:

Revisions	Newly supported modules
as from software status 26 May 2003 <sup>1)</sup>	<ul style="list-style-type: none"> <li>– Support for the handheld, type CPX-MMI-1</li> <li>– MPA1 pneumatics (type 32)</li> </ul>
from Revision 22 <sup>2)</sup>	<ul style="list-style-type: none"> <li>– MPA1 pneumatics (type 33 and 34)</li> <li>– MPA2 pneumatics (type 32, 33 and 34)</li> <li>– CPX-FB6 as remote controller (e.g. with CPX-FEC)</li> <li>– CPX-CP interface</li> <li>– Pneumatic interface for VTSA- and /VTSA-F-Pneumatic (Type 44 and 45)</li> </ul>
<sup>1)</sup> Software status (SW) see name plate <sup>2)</sup> Revision identification, see name plate	

Fig. 0/1: New CPX-FB6 modules supported through the bus node

This description contains specific information on installing, commissioning, programming and diagnosing with the CPX bus node for Interbus.



Additional information about Interbus can be obtained in the internet:

- [www.interbusclub.com](http://www.interbusclub.com)
- [www.ibsclub.com](http://www.ibsclub.com)

General basic information about the mode of operation, mounting, installation and commissioning of CPX terminals can be found in the CPX system description.



Information about additional CPX modules can be found in the description for the respective module.

An overview of the structure of the CPX terminal user documentation is contained in the CPX system description.

Product-specific information about the control system (IPC, PLC or I/O controller) can be found in the manufacturer's product documentation accompanying the product.

The following product-specific terms and abbreviations are used in this manual.

<b>Term/abbreviation</b>	<b>Significance</b>
A0 <sub>H</sub>	Hexadecimal numbers are marked by a low-set “h”
Bus nodes	Create the connection to certain networks or fieldbuses, pass on control signals to the connected modules and monitor their functioning
CP	Compact Performance installation system, comprising a CP master with one or more CP strings. The system consists of CP or CPI modules (without or with extended functions).
CPA	Pneumatic modules/valve terminal type 12
CPX bus	Data bus via which the CPX modules communicate with each other and are supplied with the necessary operating voltage.
CPX modules	Collective term for the various modules which can be integrated into a CPX terminal.
CMD software	Parametrisation, commissioning and diagnostic software for stations on the Interbus (configuration, monitoring, diagnostics).
CPX terminal	Modular electric terminal type 50
DIL switch	Dual-in-line switches consist of several switch elements with which settings can be made.
FEC	Front End Controller, e.g. CPX-FEC, can be used as: <ul style="list-style-type: none"> <li>– stand-alone system controller (PLC, stand alone operating mode)</li> <li>– system controller (PLC, remote controller operating mode)</li> <li>– fieldbus slave (remote I/O operating mode)</li> </ul>
Handheld	Handheld terminal (handheld, CPX-MMI) for CPX modules for commissioning and service purposes (man-machine interface, MMI)
I	Digital input
ID code	By means of the Identification code (in brief: ident. code), the interface module ascertains the type and the process data length of all stations.
Interface module	The interface module is the central device for controlling the Interbus data ring. It exchanges the data transported serially in the data ring with the higher-order controller or computer system and the lower-order Interbus stations in both directions acyclically or cyclically.

<b>Term/abbreviation</b>	<b>Significance</b>
I/Os	Digital inputs and outputs
I/O diagnostic interface	The I/O diagnostic interface is a bus-independent diagnostic interface at I/O level, permitting access to internal data of the CPX terminal.
I/O modules	Common term for the CPX modules which provide digital inputs and outputs (CPX input modules and CPX output modules).
Midi/maxi	Pneumatic modules/valve terminal type 03
MPA	Pneumatic modules/valve terminal type 32
O	Digital output
Parameter data	Data for parametrisation, diagnostics and configuration which are transmitted acyclically in a multiplex procedure via the PCP channel.
PCP channel	Stations that can also process parameter data are also known as PCP stations. Communication between these stations and the interface module takes place via the Peripheral Communication Protocol (in brief: PCP or PCP channel). PCP is an integral part of the Interbus protocol.
Peripheral faults (PF)	Malfunctions in the peripherals of Interbus stations are shown by means of peripheral faults (dependent on station), e.g.: <ul style="list-style-type: none"> <li>– load voltage failure</li> <li>– short circuit at the outputs, etc.</li> </ul> The peripheral fault is a common error message and does not contain any module-specific information.
PLC/IPC	Programmable logic controller/industrial PC
Pneumatics interface	The pneumatics interface is the interface between the modular electrical peripherals and the pneumatics.
Process data	I/O data from the Interbus stations transmitted cyclically via the Interbus, e.g. for: <ul style="list-style-type: none"> <li>– light barriers, sensors</li> <li>– valves, contactors</li> <li>– diagnostic I/Os.</li> </ul>
Remote bus	The remote bus bridges long distances within an Interbus system (main string). With baud rates of 500 kBd and 2 MBd, it can be up to 12.8 km long (from the interface module to the last connected remote bus station). Individual segments can be up to 400 m long.

<b>Term/abbreviation</b>	<b>Significance</b>
Status bits	Internal inputs which supply coded common diagnostic messages.
VTSA	Pneumatic modules/valve terminal type 44

Tab. 0/2: CPX-specific or Interbus-specific terms and abbreviations



# Installation

## Chapter 1

# 1. Installation

## Table of contents

<b>1.</b>	<b>Installation</b> .....	<b>1-1</b>
1.1	General installation instructions .....	1-2
1.2	Settings of the DIL switches on the bus node .....	1-6
1.3	Connecting the fieldbus .....	1-13
1.3.1	System structure on the remote bus .....	1-13
1.3.2	Pin allocation of the fieldbus interface .....	1-16
1.3.3	Connecting the fieldbus .....	1-17
1.3.4	Fieldbus baud rate and fieldbus length .....	1-20
1.4	Fibre-optic cable connection for Interbus .....	1-21
1.5	Selection of the power supply unit .....	1-22
1.6	Pin allocation of power supply .....	1-22

## 1. Installation

### 1.1 General installation instructions



#### **Warning**

Before carrying out installation and maintenance work, switch off the following:

- compressed air supply
- operating voltage supply for the electronics/sensors
- load voltage supply for the outputs and valves.

In this way, you can avoid:

- uncontrolled movements of loose tubing lines,
- accidental movements of the connected actuators,
- undefined switching states of the electronics.



#### **Caution**

The CPX bus node includes electrostatically sensitive components for Interbus.

- Do not touch any contacts.
- Observe the handling specifications for electrostatically sensitive devices.

They will help you avoid damage to the electronics.

## 1. Installation

### Electrical connecting and display elements

The following connection and display components can be found on the CPX bus node for Interbus:

- 1 Bus-status-specific and CPX-specific LEDs
- 2 Fieldbus connection OUT (continued, 9-pin sub-D socket)
- 3 Fieldbus connection IN (incoming, 9-pin sub-D plug)
- 4 Service interface for handheld, etc.




Fig. 1/1: Connection and display components on the CPX bus node

## 1. Installation

### Dismantling and mounting

The CPX bus node is installed in an interlinking block of the CPX terminal (see Fig. 1/2).

#### Dismantling

Dismantle the bus node as follows:

1. Loosen the four screws of the bus node with a Torx screwdriver size T10.
2. Pull the bus node carefully and without tilting away from the contact rails of the interlinking block.

- 1 Bus node
- 2 Interlinking block
- 3 Contact rails
- 4 Screws




Fig. 1/2: Dismantling / mounting the bus node

## 1. Installation

### Mounting

Mount the bus node as follows:

1. Place the bus node in the interlinking block. Make sure that the corresponding grooves with the contacting terminals on the bottom of the bus node are above the contact rails. Then push the bus node carefully and without tilting into the interlinking block up to the stop.
2. Only tighten the screws by hand. Place the screws so that the self-cutting threads can be used. Tighten the screws with a Torx screwdriver size T10 with torque 0.9 ... 1.1 Nm.

## 1. Installation

### 1.2 Settings of the DIL switches on the bus node

There are 4 DIL switches for configuring the bus node. These are situated in the recesses in the housing over the sub-D connections.

- 1** DIL switch 1:  
Operating mode and activation of the PCP
- 2** DIL switch 2:  
Error mode and baud rate
- 3** DIL switch 3:  
reserved
- 4** DIL switch 4:  
Diagnostics mode (status bits and I/O diagnostics interface) or Interbus data width (dependent on the operating mode)




Fig. 1/3: DIL switches in the bus node  
(additional information on **1** ... **4** see following pages)



Procedure:

1. Switch off the power supply.
2. Remove either the mounted fieldbus plugs or the cover, as required.
3. Set the DIL switches as described on the following pages.
4. Mount the fieldbus plugs or the cover again, as required. Tighten the mounting screws at first by hand and then with 0.4 Nm.



**Setting the operating mode** 1

You can set the operating mode of the CPX terminal with switch element 1 of the dual DIL switch 1:

Operating mode	Setting DIL switch 1.1	
<p><b>Remote I/O operating mode</b> Standard remote bus station on the Interbus; all inputs and outputs are controlled by the PLC. A possible CPX-FEC or CPX-CEC integrated in the CPX terminal works as a passive function module.</p>		<p>1.1: OFF (default)</p>
<p><b>Operating mode Remote Controller</b> A CPX-FEC or CPX-CEC integrated into the CPX terminal takes over I/O control. This operating mode is only useful if an FEC/CEC is integrated into the CPX terminal.</p>		<p>1.1: ON</p>

Tab. 1/1: Setting the bus node operating mode



**Note**



The setting of the operating mode with the DIL switch has priority over all other settings.



## 1. Installation

### Activating the PCP channel 1

You activate the PCP channel with the switch element 2 of the dual DIL switch 1:

PCP channel	Setting DIL switch 1.2	
<b>Without PCP</b> (+ 0 I/O bits)		1.2: OFF (default)
<b>With PCP</b> (+ 16 I/O bits)		1.2: ON



Tab. 1/2: Activating the PCP channel

An additional 16 internal I/Os are assigned with the activated PCP channel. The PCP channel serves mainly for parametrisation and for reading system and diagnostic data out of the CPX terminal.

## 1. Installation

### Setting the peripheral fault mode 2

You set the error mode with switch element 1 of the dual DIL switch 2:

Peripheral fault mode	Setting DIL switch 2.1	
<b>Report all errors</b>		2.1: OFF (default)
<b>Filter error messages</b> Errors during the monitoring of the load voltage supply will be ignored		2.1: ON

Tab. 1/3: Setting the peripheral fault mode



With the setting “Filter error messages”, any voltage errors which occur will not be reported to the interface module as peripheral faults (see also section 3.3.4). In this way, you can, for example, suppress unnecessary error messages during the commissioning phase.

The setting of the DIL switch has precedence over the parametrisation of defined settings.

## 1. Installation

### Setting the baud rate 2

You can set the baud rate with switch element 2 of the dual DIL switch 2:

Baud rate	Setting DIL switch 2.2	
500 kBd		2.2: OFF (default)
2 MBd		2.2: ON


Tab. 1/4: Setting the baud rate

Recommendation:

Set 500 kBd. Not all devices support 2 MBd.

### Reserved DIL switch 3

The switch element 1 of the dual DIL switch 3 is reserved for future extensions.



Reserved DIL switch	Setting DIL switch 3	
Reserved		3.1: OFF (default)

Tab. 1/5: Reserved DIL switch

## 1. Installation

### Setting the diagnostic compatibility for MPA modules with diagnostic function D2 3

With switch element 2 of the dual DIL switch 3, you can determine whether the broken cable diagnostics (Open Load) is reported. The setting of this DIL switch can be overwritten via parameterisation.

Diagnostics	Setting DIL switch 3.2	
<b>Filter broken cable error message (Open Load)</b> Error in monitoring broken cable (Open Load) is ignored.		3.2: OFF (default)
<b>Report broken cable error message (Open Load)</b>		3.2: ON
Power OFF/ON is necessary after the DIL switch is changed during operation. Changes by means of parameterisation are immediately effective.		

Tab. 1/6: Diagnostic function

## 1. Installation

### Setting the diagnostics mode or the number of Interbus data words 4







#### Note

The function of the dual DIL switch 4 is dependent on the set operating mode: (DIL switch 1.1)

In the Remote I/O operating mode (DIL switch 1.1: OFF), you can set the diagnostics mode with dual element DIL switch 4. The individual diagnostics modes also occupy the specified I/O bits.

With the operating mode Remote Controller (DIL switch 1.1 ON), you can set the number of Interbus data words (logical I/Os) with the dual DIL switch 4.

In the “Remote Controller” operating mode, 8I/8O are established for communication with the CPX-FEC/CPX-CEC.

Remote I/O operating mode	Remote Controller operating mode	Setting DIL switch 4	
Diagnostics mode	Number of I/O bytes		
<b>System diagnostics switched off</b> (+ 0 I/O bits)	not permitted		4.1: OFF 4.2: OFF (factory setting)
<b>Status bits</b> (+ 8 input bits, beginning with the first free input byte)			4.1: OFF 4.2: ON
<b>I/O diagnostics interface</b> (+ 16 I/O bits, beginning with the first free process data word)			4.1: ON 4.2: OFF
<b>Reserved</b>			4.1: ON 4.2: ON

Tab. 1/7: Setting the diagnostics mode or the number of I/O bytes

## 1. Installation

### 1.3 Connecting the fieldbus

There are two connections on the bus node for connecting the Interbus. One connection is intended for the supply line, the other for the continuation of the fieldbus line.

Dependent on your application, different Interbus interfaces and therefore different connection and screening methods are used. Observe therefore the following listed differences on the remote bus.



#### **Note**

Faulty installation and high transmission rates may cause data transmission errors as a result of signal reflections and attenuations.

Transmission errors can be caused by:

- faulty screened connection
- transmission over distances that are too long
- inappropriate cables.

Observe the cable specifications! Obtain information about the cable type to be used from the manual for the interface module or the Interbus installation manual.

#### 1.3.1 System structure on the remote bus


The CPX terminal with bus node FB6 is a remote bus station on the Interbus. Dependent on the modules used, it behaves on the remote bus like a bus terminal with integrated I/Os and must be addressed correspondingly.

## 1. Installation



### Note

- Commissioning on the remote bus can only take place if all stations are completely connected or bridged by means of a software setting.
- The CPX terminal requires a 24 V DC power supply. Depending on the interlinking blocks used, the electric outputs and valves can be supplied with power and switched off separately.



- 1 Interbus master: PC or PLC with interface
- 2 CPX terminal: Only electric I/O modules
- 3 CPX terminal: CPA valves and electric I/O modules
- 4 Further Interbus stations

Fig. 1/4: Remote bus system structure with CPX terminals

## Remote bus floating

The bus node has been prepared for floating operation on the remote bus. Check with the standards and guidelines (e.g. VDE) valid for your application to ascertain whether your application is appropriate for floating operation.



Additional information on installing an Interbus system can be found in the Interbus user manual.

<b>Phoenix Contact</b>	
<b>Designation</b>	<b>Article no.</b>
IBS SYS PRO INST UM	27 43 79 2

Procurement source:  
Phoenix Contact GmbH & Co.  
Postfach 1341  
D-32819 Blomberg, Germany  
[www.phoenixcontact.com](http://www.phoenixcontact.com)


There is 9-pin sub-D plug (incoming remote bus) as well as a 9-pin sub-D socket (continued remote bus) on the bus node for connecting the CPX terminal to the fieldbus.

These connections are used for the supply line and the continuation of the fieldbus line.




## 1. Installation

### 1.3.2 Pin allocation of the fieldbus interface

<b>Bus connection incoming<sup>1)</sup></b>				
<b>Plug</b>	<b>Pin</b>	<b>Sub-D plug type FBS-SUB-9-BU-IB-B</b>	<b>Interbus</b>	<b>Designation</b>
	1	DO	DO1	Data out
	2	DI	DI1	Data in
	3	GND	GND	Reference conductor/ground
	4		n.c.	Not connected
	5		n.c.	Not connected
	6	/DO	/DO1	Data out inverse
	7	/DI	/DI1	Data in inverse
	8		n.c.	Not connected
	9		n.c.	Not connected
Housing	Clamp strap	Screening	Connection via R/C combination to FE of the CPX terminal	

<sup>1)</sup> The incoming interface is galvanically separated from the CPX peripherals. The plug housing is connected via an R/C combination to the FE of the CPX terminal.

<b>Bus connection continued</b>				
<b>Socket</b>	<b>Pin</b>	<b>Sub-D plug type FBS-SUB-9-GS-IB-B</b>	<b>Interbus</b>	<b>Designation</b>
	1	DO	DO2	Data out
	2	DI	DI2	Data in
	3	GND	GND	Reference conductor/ground
	4		n.c.	Not connected
	5		+ 5 V	Detect station <sup>1)</sup>
	6	/DO	/DO2	Data out inverse
	7	/DI	/DI2	Data in inverse
	8		n.c.	Not connected
	9		RBST	Detect station <sup>1)</sup>
Housing	Clamp strap	Screening	Connection to FE of the CPX terminal	

<sup>1)</sup> The CPX terminal contains the protocol chip SUP13-OPC. This ensures automatic detection of additional connected Interbus stations. There is therefore no need for a bridge between pin 5 and pin 9.

Tab. 1/8: Pin allocation of bus connection

## 1. Installation

### 1.3.3 Connecting the fieldbus



#### Note

Observe that only the plugs from Festo guarantee compliance with protection class IP 65/IP 67.

If the continued bus interface is not connected:

- Seal the continued bus interface with the supplied cover.

Connecting with sub-D plugs of other manufacturers:

- Replace the two flat screws with bolts (type UNC4-40/M3x8).
- Connect the cable screening to the plug housing.

Connecting with the fieldbus plugs from Festo

- Observe the assembly instructions for the fieldbus plugs.

You can conveniently connect the CPX terminal to the fieldbus with the fieldbus plugs from Festo.



Connection	Fieldbus plug type
Incoming bus interface	FBS-SUB-9-BU-IB-B
Continued bus interface	FBS-SUB-9-GS-IB-B

Fig. 1/5 shows the connection with the fieldbus plugs from Festo.

## 1. Installation

- 1 Folding cover with inspection window
- 2 Blanking plug
- 3 Clamp strap for screened connection
- 4 Terminal strip for incoming or continued fieldbus
- 5 CPX-FB6 (shown at reduced size)




Fig. 1/5: Fieldbus plug from Festo, type FBS-SUB-9-GS-IB-B and FBS-SUB-9-BU-IB-B



### Note

The clamp strap in the sub-D plugs is connected internally to the metal housing of the socket or plug.

- Clamp the screening of the fieldbus cable under the clamp strap of the fieldbus plug.



## 1. Installation

### Connection with M12 connection block (reverse key coded)

- Observe the assembly instructions for the M12 connection block.

With the M12 connection block type CPX-AB-2-M12-RK-IB, you can connect the CPX terminal to the Interbus using M12 plug connectors.

Connection to the fieldbus is made with a 5-pin M12 plugs with PG 9 fitting. The pin allocation meets the Interbus Club specification V1.0 for M12 plug connectors.

M12 connection block	Pin number
	1. DO 2. /DO 3. DI 4. /DI 5. GND Housing/thread: screening
	

Tab. 1/9: Pin allocation of the fieldbus interface with M12 connection block

## 1. Installation

### Fieldbus cable

If the IP 65/IP 67 plugs from Festo are used, a cable outer diameter of 7-10 mm is permissible. The following cable is appropriate for use corresponding to the remote bus specifications:

Cable selection	Order no. Phoenix
3 x 2 x 0.22 mm <sup>2</sup> IBS RBC METER-T (standard)	28 06 28 6
3 x 2 x 0.25 mm <sup>2</sup> IBS RBC METER / F-T (highly flexible)	27 23 12 3
3 x 2 x 0.22 mm <sup>2</sup> IBS RBC METER / E-T (can be laid underground)	27 23 14 9

Procurement source:  
Phoenix Contact GmbH & Co.  
Postfach 1341  
D-32819 Blomberg, Germany  
[www.phoenixcontact.com](http://www.phoenixcontact.com)

### Bus length

Specifications on the bus length can be found in the manuals for your interface module.



#### Note

If the valve terminal is mounted into a moving part of a machine, the fieldbus cable on the moving part must be provided with strain relief. Also observe the corresponding regulations in EN 60204 Part 1.

### 1.3.4 Fieldbus baud rate and fieldbus length

The maximum permissible fieldbus length is dependent on the baud rate used. With a baud rate of 500 kBd, the maximum fieldbus length must not exceed 12.8 km (400 m per segment).

### 1.4 Fibre-optic cable connection for Interbus

We recommend fibre-optic technology (FOC) for transmission in environments subjected to heavy interference as well as for extending the working range when high transmission rates are used.

This offers the following advantages:

- high EMC compatibility, high electromagnetic resistance to interference due to the optical transmission of the signals,
- protection against lightning,
- electrical isolation of the individual Interbus stations.

The Interbus interface of the bus node is appropriate for the Phoenix Contact Interbus/FOC converter Optosub Plus (protection class IP 20) and thus supports control of network components for fibre-optic cables.

### 1.5 Selection of the power supply unit



#### **Warning**

- Only use PELV circuits in accordance with IEC/EN 60204-1 (protective extra-low voltage, PELV) for the electrical power supply.
- Also take into account the general requirements for PELV circuits in accordance with IEC/EN 60204-1.
- Use only voltage sources that guarantee reliable electrical isolation of the operating voltage according to IEC/DIN EN 60204-1.

Through the use of PELV circuits, protection against electric shock (protection against direct and indirect contact) is ensured in accordance with IEC/EN 60204-1.

### 1.6 Pin allocation of power supply

The current consumption of a CPX terminal depends on the number and type of integrated modules and components.






Observe the information on power supply as well as on the earthing measures to be carried out in the CPX system description.

## 1. Installation

System power supply, additional power supply and valve power supply

Through the interlinking blocks with system, additional and valve power supply of type CPX-GE-EV-S..., CPX-GE-EV-Z... or CPX-GE-EV-V..., the CPX terminal is supplied with operating and load voltage.

Plug	Pin allocation of interlinking block with		
	system power supply type CPX-GE-EV-S...	additional power supply type CPX-GE-EV-Z...	valve power supply type CPX-GE-EV-V...
 <p><b>M18</b></p>	1: 24 V <sub>EL/SEN</sub> 2: 24 V <sub>VAL</sub> / 24 V <sub>OUT</sub> 3: 0 V <sub>EL/SEN</sub> / 0 V <sub>VAL</sub> / 0 V <sub>OUT</sub> 4: FE	1: Free (not connected) 2: 24 V <sub>OUT</sub> 3: 0 V <sub>OUT</sub> 4: FE	1: Free (not connected) 2: 24 V <sub>VAL</sub> 3: 0 V <sub>VAL</sub> 4: FE
 <p><b>7/8"-4POL</b></p>	A: 24 V <sub>EL/SEN</sub> B: 24 V <sub>VAL</sub> / 24 V <sub>OUT</sub> C: FE D: 0 V <sub>EL/SEN</sub> / 0 V <sub>VAL</sub> / 0 V <sub>OUT</sub>	A: free (not connected) B: 24 V <sub>OUT</sub> C: FE D: 0 V <sub>OUT</sub>	A: free (not connected) B: 24 V <sub>VAL</sub> C: FE D: 0 V <sub>VAL</sub>
 <p><b>7/8"-5PIN</b></p>	1: 0 V <sub>VAL</sub> / 0 V <sub>OUT</sub> 2: 0 V <sub>EL/SEN</sub> 3: FE 4: 24 V <sub>EL/SEN</sub> 5: 24 V <sub>VAL</sub> / 24 V <sub>OUT</sub>	1: 0 V <sub>OUT</sub> 2: Free (not connected) 3: FE 4: Free (not connected) 5: 24 V <sub>OUT</sub>	—
V <sub>EL/SEN</sub> : Operating voltage electronics/sensors V <sub>OUT</sub> : Load voltage of outputs V <sub>VAL</sub> : Load voltage of the valves FE: Functional earth A, B, C, D: <b>Note:</b> Coupling (plug socket NECU-G78G4-C2) is marked with "1, 2, 3, 4". Allocation: D=1, C=2, B=3, A=4. Other couplings can deviate from this.			

Tab. 1/10: Pin allocation for system power supply, additional power supply and valve power supply



# Commissioning

## Chapter 2

## Table of contents

<b>2.</b>	<b>Commissioning</b>	<b>2-1</b>
2.1	Configuration and addressing	2-4
2.1.1	Ascertaining the address range	2-4
2.1.2	Address assignment of the CPX terminal	2-14
2.1.3	Address assignment after extension/conversion	2-24
2.1.4	Bus configuration and addressing	2-27
2.1.5	Switching on the power supply	2-28
2.1.6	Bus configuration with the CMD software	2-29
2.1.7	Bus configuration without CMD software	2-38
2.1.8	Process data entry via the CMD software	2-39
2.1.9	Configuration in the remote controller operating mode	2-42
2.2	Parametrisation	2-43
2.2.1	Parametrisation concepts	2-45
2.2.2	Device parametrisation with the CMD software	2-49
2.2.3	Parametrisation with CMD user functions	2-50
2.2.4	Parametrisation with the PLC user program	2-53
2.3	Commissioning the CPX terminal on the Interbus	2-54
2.3.1	Fail safe	2-55

## 2. Commissioning

Contents of this chapter	<p>In this chapter you will find information on commissioning the CPX terminal on the Interbus.</p> <ul style="list-style-type: none"><li>– CPX terminal configuration and addressing</li><li>– Bus configuration and addressing on the Interbus: The bus configuration is explained using the example of CMD software Version 4.50.</li><li>– The behaviour of the CPX terminal can be adapted to the respective requirements through parametrisation. This permits e.g. the setting of debounce times, signal extensions or the behaviour in case of error.</li></ul>
Additional information	<p>Prior to commissioning, you must first install the CPX terminal correctly. Information on this can be found in chapter 1.</p> <p>General information on commissioning the CPX terminal as well as a detailed description of the individual parameters can be found in the CPX system description (P.BE-CPX-SYS-..).</p> <p>Information on commissioning the pneumatic interface, MPA pneumatic modules and I/O modules can be found in the description for the CPX I/O modules (P.BE-CPX-EA-..) or CPX-analogue I/O modules (P.BE-CPX-AX-..).</p> <p>Instructions on commissioning the pneumatic components can be found in the corresponding description of pneumatics.</p>

### 2.1 Configuration and addressing

#### 2.1.1 Ascertaining the address range

Before configuring, ascertain the exact number of available inputs/outputs. Dependent on what you have ordered, a CPX terminal comprises a different number of I/Os.



#### **Note**

- Observe that a CPX terminal provides status bits or an I/O diagnostic interface, depending on the setting.
- The status bits must be treated like inputs and occupy an additional 8 input addresses.
- The 16 bits of the I/O diagnostic interface must be treated like inputs and outputs. They occupy an additional 16 input addresses and 16 output addresses.
- If the PCP channel is configured, an additional 16 input addresses and 16 output addresses are occupied.
- The maximum possible extension of the CPX terminal is limited to 96 inputs and outputs.

The I/Os will be assigned automatically within the CPX terminal.

## 2. Commissioning

### Available inputs and outputs

The CPX terminal supports the following maximum number of inputs and outputs on the I/O modules and on the pneumatic interface, dependent on the DIL switch settings.

Settings			Maximum number of available inputs and outputs
Status bits (8 I)	I/O diagnostics interface (16 I/O)	PCP channel (16 I/O)	
No	No	No	96 inputs 96 outputs
Yes	No	No	88 inputs 96 outputs
No	Yes	No	80 inputs 80 outputs
No	No	Yes	80 inputs 80 outputs
Yes	No	Yes	72 inputs 80 outputs
No	Yes	Yes	64 inputs 64 outputs

Tab. 2/1: Number of available inputs and outputs

The I/Os will be assigned automatically within the CPX terminal.



The address assignment within the individual modules can be found in the corresponding description for the respective module.

## 2. Commissioning

On the basis of the module type, you can ascertain the number of inputs and outputs occupied by the module.

The individual modules are displayed with their indicator on the handheld. In the case of the I/O modules, the indicator is also shown in the LED inspection window.

Electric modules <sup>1)</sup>	Type	Module indicator <sup>2)</sup>	Assigned addresses	
			Inputs	Outputs
Bus node FB6, remote I/O, without system diagnostics <sup>3)</sup>	CPX-FB6	FB06-RIO	–	–
Bus node FB6, remote I/O, with status bits <sup>3)</sup>			8 I	–
Bus node FB6, remote I/O, with I/O diagnostics interface <sup>3)</sup>			16 I	16 O
Bus node FB6, remote controller, without system diagnostics	CPX-FB6	FB06-RC	–	–
Digital 4-off input module	CPX-4DE	4DI	4 I	–
Digital 8-off input module	CPX-8DE	8DI	8 I	–
Digital 8-off input module with channel diagnostics	CPX-8DE-D	8DI-D	8 I	–
Digital 8-off input module n-switching	CPX-8NDE	8NDI	8 I	–
Digital 16-off input module	CPX-16DE	16DI	16 I	–
Digital 16-off input module with channel diagnostics	CPX-16DE-D	16DI-D	16 I	–
Digital multi I/O module	CPX-8DE-8DA	8DI/8DO	8 I	8 O
<sup>1)</sup> Additional modules in preparation. <sup>2)</sup> Module indicators on the handheld; in the case of I/O modules these are shown in the inspection window. <sup>3)</sup> The status bits or the I/O diagnostics interface is activated by a DIL switch (see section 1.2).				

Tab. 2/2: Overview of indicators and addresses of electric modules (part 1)

## 2. Commissioning

Electric modules <sup>1)</sup>	Type	Module indicator <sup>2)</sup>	Assigned addresses	
			Inputs	Outputs
Digital 8-off output module, high-current variant	CPX-8DA-H	8DO-H	–	8 O
Analogue 2-input module	CPX-2AE-U-I	2AI	32 I	–
Digital 4-off output module	CPX-4DA	4DO	–	4 O
Digital 8-off output module	CPX-8DA	8DO	–	8 O
Analogue 4-off input module	CPX-4AE-I	4AI-I	64 I	–
Analogue 4-off input module (temperature module for RTD sensors)	CPX-4AE-T	4AI-T	32/64 I	–
Analogue 4-input module (temperature module for TC sensors)	CPX-4AE-TC	4AI-TC	64 I	–
Analogue dual output module	CPX-2AA-U-I	2AO	–	32 O
CP interface		CPI	32 I	32 O
Front end controller CPX-FEC		FEC controller	8 I	8 O
CoDeSys controller CPX-CEC		CEC controller	8 I	8 O
<sup>1)</sup> Additional modules in preparation. <sup>2)</sup> Module indicators on the handheld; in the case of I/O modules these are shown in the inspection window.				

Tab. 2/3: Overview of indicators and addresses of electric modules (part 2)

### Pneumatic modules and pneumatic interfaces

The valves are configured according to the pneumatic interface used:

- Valves of type 12 (CPA), type 03 (Midi/Maxi) or type 44 (VTSA, ISO):  
For expansion of the valve side, only **one** identifier is used for the pneumatics interface. In the pneumatics interface, the number of solenoid coils is set with a DIL switch (grid pattern 1 byte).
- Valves of type 32 (MPA pneumatic modules):  
From the technical point of view, the individual MPA pneumatic modules each represent an electric module with digital outputs for controlling the attached valves. For each pneumatic module of type **MPA1**, 8 outputs of type **MPA2**, 4 outputs assigned, independent of how many valves the pneumatic module is equipped with.



Additional information on MPA pneumatic modules can be found in the description for the CPX I/O modules (P.BE-CPX-EA-..) and the corresponding description of pneumatics.



## 2. Commissioning

Pneumatics interfaces <sup>1)</sup>	Type	Module indicator <sup>2)</sup>	Assigned addresses	
			Inputs	Outputs
Pneumatics interface for MPA-S valves (type 32)	VMPA-FB-EPL-...	–	–	–
Pneumatics interface for MPA-F valves (Type 33)	VMPAF-FB-EPL-...	–	–	–
Pneumatics interface for MPA-L valves (Type 34)	VMPAL-EPL-CPX	–	–	–
Pneumatics interface for CPA valves (type 12) with setting: <sup>3)</sup> – 1...8 solenoid coils – 1...16 solenoid coils – 1...24 solenoid coils (22 effective)	CPX-GP-CPA-10 CPX-GP-CPA-14	CPA10/14	–	8 0 16 0 24 0
Pneumatics interface for Midi/Maxi valves (type 03) with setting: <sup>2)</sup> – 1...8 solenoid coils – 1...16 solenoid coils – 1...24 solenoid coils – 1...32 solenoid coils (26 effective)	CPX-GP-03-4.0	TYPE3	–	8 0 16 0 24 0 32 0
Pneumatics interface for VTSA pneumatics (ISO, Type44) <sup>2)</sup> and VTSA-F pneumatics – 1...8 solenoid coils – 1...16 solenoid coils – 1...24 solenoid coils – 1...32 solenoid coils	VABA-10S6-x1	ISO plug-in or type 44 <sup>3)</sup>	–	8 0 16 0 24 0 32 0
<sup>1)</sup> Additional interfaces in preparation <sup>2)</sup> Module indicator in the Handheld <sup>3)</sup> Setting with DIL switches in the pneumatics interface (see description, CPX I/O modules).				

Tab. 2/4: Overview of pneumatics interfaces

## 2. Commissioning

Pneumatics modules <sup>1)</sup>	Type of electronics module	Module indicator <sup>2)</sup>	Assigned addresses	
			Inputs	Outputs
MPA1 pneumatics module (type 32, 33) without galvanic isolation	VMPA1-FB-EMS-8	MPA1S	–	8 0
MPA1 pneumatics module (type 32, 33) with galvanic isolation	VMPA1-FB-EMG-8	MPA1G	–	8 0
MPA2 pneumatics module (type 32, 33) without galvanic isolation	VMPA2-FB-EMS-4	MPA2S	–	4 0 <sup>3)</sup>
MPA2 pneumatics module (type 32, 33) with galvanic isolation	VMPA2-FB-EMG-4	MPA2G	–	4 0 <sup>3)</sup>
MPA1 pneumatics module (type 32, 33) without galvanic isolation with diagnostic function D2	VMPA1-FB-EMS-D2-8	MPA1S-D	–	8 0
MPA1 pneumatics module (type 32, 33) with galvanic isolation with diagnostic function D2	VMPA1-FB-EMG-D2-8	MPA1G-D	–	8 0
MPA2 pneumatics module (type 32, 33) without galvanic isolation with diagnostic function D2	VMPA2-FB-EMS-D2-4	MPA2S-D	–	4 0 <sup>3)</sup>
MPA2 pneumatics module (type 32, 33) with galvanic isolation with diagnostic function D2	VMPA2-FB-EMG-D2-4	MPA2G-D	–	4 0 <sup>3)</sup>
<sup>1)</sup> Additional modules in preparation <sup>2)</sup> Module indicator in the Handheld <sup>3)</sup> 8 bits are always assigned				

Tab. 2/5: Overview of pneumatics modules MPA-S and MPA-F

## 2. Commissioning



Information on compatibility when replacing MPA electronics modules can be found in the subsequent table (→ Tab. 2/6).

Detailed information on the MPA electronics modules without and with diagnostic function D2 can be found in the description for type P.BE-MPA-ELEKTRONIK-....

Replacement of MPA electronics modules	Compatibility
<p>VMPA <b>without</b> diagnostic function <b>D2</b> is replaced by: VMPA <b>with</b> diagnostic function <b>D2</b></p>	<p><b>You would like to remain compatible with the existing VMPA (without diagnostic function D2):</b></p> <ul style="list-style-type: none"> <li>– DIL switch 3.2 must be OFF</li> <li>– The extended diagnostic functions are parameterised inactive as standard.</li> </ul> <p>Only the standard diagnostics are reported<sup>1)</sup>:</p> <ul style="list-style-type: none"> <li>– Error: load voltage for valves (<math>U_{VAL}</math>)</li> </ul> <hr/> <p><b>You wish to use the extended diagnostic function D2:</b></p> <ul style="list-style-type: none"> <li>– You wish to activate the diagnostic functions by means of parameterisation (PCP) (see MPA electronics description).</li> <li>– The broken cable diagnostic function (Open Load) can also optionally be activated with the DIL switch 3.2 at ON. A diagnostic message is also issued if an unmounted solenoid coil is addressed.</li> </ul> <p>All errors are registered by the CPX terminal with CPX-FB6 as common error messages (“peripheral errors”) (see description for the CPX-FB6).</p>
<p>VMPA <b>with</b> diagnostic function <b>D2</b> is replaced by: VMPA <b>without</b> diagnostic function <b>D2</b></p>	<p>Only the standard diagnostics are reported<sup>1)</sup>:</p> <ul style="list-style-type: none"> <li>– Error: load voltage for valves (<math>U_{VAL}</math>)</li> </ul>
<p><sup>1)</sup> This diagnostic message can be deactivated or activated via parameterisation (PCP).</p>	

Tab. 2/6: Information on the replacement of MPA electronics modules

## 2. Commissioning

Pneumatics modules <sup>1)</sup>	Type of electrical interlinking	Module indicator <sup>2)</sup>	Assigned addresses	
			Inputs	Outputs
MPA-L pneumatics module (type 34) for one solenoid valve, one solenoid coil	VMPAL-EVAP-10-1	MPAL	–	1 0
MPA-L pneumatics module (type 34) for one solenoid valve, 2 solenoid coils	VMPAL-EVAP-10-2	MPAL	–	2 0
MPA-L pneumatics module (type 34) for 4 solenoid valves, 4 solenoid coils	VMPAL-EVAP-10-1-4	MPAL	–	4 0
MPA-L pneumatics module (type 34) for 4 solenoid valves, 8 solenoid coils	VMPAL-EVAP-10-2-4	MPAL	–	8 0
<sup>1)</sup> Additional modules in preparation <sup>2)</sup> Module indicator in the Handheld				

Tab. 2/7: Overview of pneumatics modules MPA-L

The complete address space including the I/Os for the diagnostics always includes an equal number of inputs and outputs.



**Tip:**  
Copy the following table for further calculations.

## 2. Commissioning

### Calculating the number of inputs/outputs

Use the following table for calculating the number of inputs and outputs on your CPX terminal.

Input/output modules and system diagnostics		Inputs	Outputs
1. I/O diagnostics interface, if set	+ 16 I/O	+ ____ I	+ ____ O
2. Number of input modules CPX-4DE	+ __ x 8I <sup>1)</sup>	+ ____ I	
3. Number of input modules CPX-8DE, -8NDE, 8DE-D	+ __ x 8 I	+ ____ I	
4. Number of input modules CPX-16DE	+ __ x 16I	+ ____ I	
5. Number of output modules CPX-4DA	+ __ x 8O <sup>1)</sup>		+ ____ O
6. Number of output modules CPX-8DA	+ __ x 8 O		+ ____ O
7. Number of Multi I/O modules CPX-8DE-8DA	+ __ x 8 I/O	+ ____ I	+ ____ O
8. Number of analogue input modules CPX-2AE-U-I	+ __ x 32 I	+ ____ I	
9. Number of analogue input modules CPX-4AE-I	+ __ x 64 I / x 32 I	+ ____ I	
10. Number of analogue input modules CPX-4AE-T	+ __ x 64 I	+ ____ I	
11. Number of analogue output modules CPX-2AA-U-I	+ __ x 32 O		+ ____ O
12. Number of inputs and outputs of other modules (e.g. CP interface)	+ __ I/O	+ ____ I	+ ____ O
13. Midi/Maxi, CPA or VTSA pneumatics interface: Number of configured valve solenoid coils (+8 O, 16 O, 24 O, 32 O) Configured at the factory is 32 O (Midi/Maxi, VTSA) or 24 O (CPA)!			+ ____ O
14. Number of MPA1 or MPA2 pneumatics modules	+ __ x 8 O <sup>1)</sup>		+ ____ O
<b>15. Sum total of inputs/outputs to be configured</b> Total of 1 to 14:		= $\Sigma$ ____ I	= $\Sigma$ ____ O
<sup>1)</sup> 8 bit addresses are always assigned (4 remain unused).			

Tab. 2/8: Ascertaining the number of inputs and outputs

## 2. Commissioning

### 2.1.2 Address assignment of the CPX terminal

#### Basic rules for addressing

##### Inputs and outputs

- The address assignment of the inputs is independent of the outputs.
- Counting mode does not depend on the position of the bus node (the bus node counts as a module with 0 inputs and 0 outputs)
- Counting is from left to right, in ascending order without gaps
- Sequence:
  - Input/output words of the analogue modules,
  - Input/output words of the technology modules (word-oriented),
  - Input/output bits of the electric inputs and outputs (including valves),
  - The 8 status bits follow the input bits as from the next byte,
  - The 16 bits of the I/O diagnostics interface follow the input/output bits as from the next word.



##### Note

If two addresses are assigned for one valve position, the assignment applies:

- less significant address: pilot solenoid coil 14
- higher-value address: pilot solenoid coil 12

### Address allocation on the Interbus

The address allocation (processing data assignment) of the inputs and outputs of a CPX terminal on the Interbus depends above all on the Interbus interface and on the control system used.



#### Caution

There are different address allocations on the Interbus. The cause of this is the arrangement of the process data within the Interbus interface module.

- When allocating the addresses, observe the position of the high and low bytes, as the position of these bytes may be swapped in combination with some control systems.

You can then avoid errors in addressing the inputs/outputs.



Further specifications on addressing can be found in the manuals for your controller and for the Interbus interface module.

The following examples provide basic information on the different address allocations and the positions of the low byte (n) and the high byte (n+1) with various controllers. There are two modes:

- In the **Siemens mode** the lower-value input or output byte (byte n) is mapped on inputs or outputs 0 ... 7, byte n+1 on the next inputs or outputs (8 ... 15) etc.
- In the **standard mode** the lower-value input or output byte (byte n) is mapped on inputs or outputs 8 ... 15, byte n+1 on the inputs or outputs 0 ... 7.

This assignment applies also for the bytes of the I/O diagnostics interface.

## 2. Commissioning

In section 2.1.8 you will find instructions on addressing with the CMD software (process data assignment) and on modifying the position of the low and high bytes (“byte swap”).

### Examples for the address assignment of the CPX terminal

The following examples show the assignment of the input and output bytes to the individual modules. In the examples the following applies:

- Configured input address: IB20  
configured output address: OB20
- The address allocation is represented both in the Siemens mode and in the Standard mode.



The address assignment within the individual I/O modules can be found in the description for the I/O modules. The address assignment within the pneumatics modules can be found in the description for the valve terminal pneumatics. The address assignment within the CP interface can be found in the description for the CPX-CP interface.



## 2. Commissioning

The modules and diagnostics I/Os are represented in the examples as follows:




Fig. 2/1: Identification of the modules in the examples

## 2. Commissioning

### Example 1

#### I/O modules and CPA pneumatics (setting 8 0)




Fig. 2/2: Example 1 – byte assignment in Siemens and Standard modes

## 2. Commissioning




Fig. 2/3: Example 1 – address assignment in Siemens and Standard modes

## 2. Commissioning

### Example 2

#### I/O modules and CPA pneumatics (setting 16 A)




Fig. 2/4: Example 2 – byte assignment in Siemens and Standard modes

## 2. Commissioning

### Example 3

#### I module and Midi/Maxi pneumatics (setting 32 0)




Fig. 2/5: Example 3 – byte assignment in Siemens and Standard modes


## 2. Commissioning

### Example 4

#### I/O modules and MPA pneumatics

Byte assignment  
of the input bytes

Siemens mode:	IB 20	IB 21	IB 22	IB 23	IB 24	IB 25	IB 26	IB 27
Standard mode:	IB 21	IB 20	IB 23	IB 22	IB 25	IB 24	IB 27	IB 26



IB = input byte; OB = output byte; status bits or I/O diagnostic interface optional

Fig. 2/6: Example 4 – byte assignment in Siemens and Standard modes


## 2. Commissioning

### Example 5

#### Digital and analogue I/O modules and MPA pneumatics

Byte assignment of the input bytes

Siemens mode:	IB 20	IB 21	IB 22	IB 23	IB 24	IB 25	IB 26	IB 27
Standard mode:	IB 21	IB 20	IB 23	IB 22	IB 25	IB 24	IB 27	IB 26



Byte assignment of the output bytes

Siemens mode:	OB 20	OB 21	OB 22	OB 23	OB 24	OB 25	OB 26	OB 27
Standard mode:	OB 21	OB 20	OB 23	OB 22	OB 25	OB 24	OB 27	OB 26

IB = input byte; OB = output byte; status bits or I/O diagnostic interface optional

Fig. 2/7: Example 5 – byte assignment in Siemens and Standard modes

## 2. Commissioning

### 2.1.3 Address assignment after extension/conversion

A special feature of the CPX terminal is its flexibility. If the requirements placed on the machine change, the equipment on the CPX terminal can also be modified.



#### **Caution**

If the CPX terminal is extended or converted at a later stage, the input/output addresses may be shifted. This applies in the following cases:

- Additional modules are inserted between existing modules.
- Existing modules are removed or replaced by other modules which have fewer or more input/output addresses.
- Interlinking blocks (CPA) or pneumatic connection blocks (Midi/Maxi) for monostable valves are replaced by interlinking blocks for bistable valves or vice versa (see pneumatics description).
- Additional interlinking blocks (CPA) or manifold blocks (Midi/Maxi) are inserted between existing ones.
- The configured addresses of the pneumatics interface are modified.



#### **Note**

If the configuration is modified, the addresses of the status bits as well as those of the I/O diagnostics interface will also be shifted!



## 2. Commissioning

The following diagram shows, as an example, what changes occur to the address assignment when the equipment from example 1 is modified. On the I/O module side, an 8-off input module has been replaced by a 4-off input module. On the valve side, a valve has been added and the pneumatic interface has been set to 16 O.




Fig. 2/8: Byte assignment of a CPX terminal after extension/conversion

## 2. Commissioning




Fig. 2/9: Address assignment of a CPX terminal after extension/conversion

## 2. Commissioning

### 2.1.4 Bus configuration and addressing

#### General commissioning instructions

Prior to commissioning or programming, create a configuration list of all connected fieldbus stations. On the basis of this list you can:

- carry out a comparison between NOMINAL and ACTUAL configurations in order to detect connection faults.
- access these specifications during the syntax check of a program, in order to avoid addressing faults

Configuration of the CPX terminal demands a very accurate procedure, as different configuration specifications are sometimes necessary for each station on the Interbus, due to the modular structure. Note here the specifications in the sections which follow.

## 2. Commissioning

### 2.1.5 Switching on the power supply



#### **Note**

Observe also the instructions in the manual for your controller with Interbus interface.

When the controller with Interbus module is switched on, it automatically carries out a comparison between the NOMINAL and ACTUAL configurations. It is important for this configuration run that:

- The configuration specifications are complete and correct.
- The fieldbus stations are supplied with voltage so they can be detected when the ACTUAL configuration is ascertained.

Therefore, switch on the power supply for all the fieldbus stations simultaneously, e.g. via a central switch. Or switch on the power supply in the following sequence:

1. First switch on the power supply for all fieldbus stations.
2. Then switch on the power supply for the controller.

## 2. Commissioning

### 2.1.6 Bus configuration with the CMD software

This section describes, as an example, the main steps within the CMD software for inserting a CPX terminal in your project. A general and comprehensive description can be found in the corresponding manual for the CMD software. In the following it is assumed that the user is familiar with the contents of the CMD manual.



#### **Note**

Observe that software packages are often updated, so modifications to the software may not yet be taken into account in this description.

The examples used here for the screen displays have been taken from CMD software version 4.50.

## 2. Commissioning

### Inserting with ident. code

Proceed as follows:

1. Click on the interface module with the right-hand mouse key.
2. Select the command “Einfügen mit ID-Code ...” (Insert with ident. code ...) in the context menu..




Fig. 2/10: Inserting bus stations with ident. code

## 2. Commissioning

The following dialogue window will then be displayed:

The dialog box titled "Teilnehmer einfügen" contains the following fields and options:

- ID-Code:** Input field with value "3". Radio buttons for "hex." and "dez." (selected).
- Prozessdatenkanal:** Input field with value "32". Label "Bit".
- Parameterkanal:** Dropdown menu.
- Teilnehmerart:** Radio buttons for:
  - Fernbusteilnehmer
  - Buskoppler mit Lokalbusabzweig
  - Buskoppler mit Fernbusabzweig
  - Lokalbusteilnehmer
- Buttons:** OK, Abbrechen, Hilfe.

Fig. 2/11: Dialogue window "Teilnehmer einfügen" (Insert station)

3. Enter the ident. code and the size of the process data channel. Information on this can be found on the following page.
4. Select the entry "Fernbusteilnehmer" (Fieldbus station) under "Teilnehmerart" (Station type) for the CPX terminal.
5. Accept these entries with OK.

## 2. Commissioning

Ident. code:

Enter the corresponding ident code in accordance with the table:

Layout	Ident code <sup>1)</sup>
Only digital outputs <sup>2)</sup> (no status bits or I/O diagnostics interface)	1 <sub>D</sub>
Only digital inputs (no I/O diagnostics interface)	2 <sub>D</sub>
Digital inputs and outputs <sup>2)</sup>	3 <sub>D</sub>
Digital inputs and outputs <sup>2)</sup> , with PCP channel (1 word)	243 <sub>D</sub>
<sup>1)</sup> Decimal <sup>2)</sup> Solenoid coils and/or electric outputs	

Tab. 2/9: Ident. code

Process data channel:

Enter the number of inputs and/or outputs on the CPX terminal ascertained as in the section 2.1.1 under “Calculating the number of inputs/outputs”. Observe the following:



### Note

- Round up the number of inputs and/or outputs to the next word limit (16, 32, 48, 64, 80 or 96).
- If the number of input bits differs from the number of output bits, the greater number is in each case decisive for entry of the process data channel bits.
- The 16 bits of the PCP channel do not count as process data channel bits.



## 2. Commissioning

If you have inserted the CPX terminal with PCP channel (ident. code 243 dec.), the dialogue window “Parameterkanal” (Parameter channel) will be displayed.




Fig. 2/12: Dialogue window “Parameterkanal” (Parameter channel)

6. Enter 128 bytes each for “Senden” (Send) and “Empfangen” (Receive) under “Telegrammlängen” (Telegram lengths).
7. Activate the check boxes “Read”, “Write” and “Get OD” (object dictionary) under “Unterstützte Parameterkanal-Dienste” (Support parameter channel services).

## 2. Commissioning

**Insert station description** In the following dialogue window, you can describe the station and enter specific information, e.g. station name and station picture.

The dialog box 'Teilnehmerbeschreibung einfügen' contains the following fields and controls:

- Teilnehmernummer:** 2.0
- Gruppennummer:** (empty)
- Stationsname:** (empty)
- Service-Info:** (empty)
- Teilnehmername:** (empty)
- Herstellername:** Festo
- Gerätetyp:** CPX-Terminal
- ID-Code:** 3 dez.
- Profilnummer:** 12 hex.
- Prozessdatenkanal:** 32 Bit
- Parameterkanal:** (dropdown menu)
- Buttons:** Schnittstellentyp ..., Darstellung ..., Parameterkanal ...
- Checkboxes:** Teilnehmer ausblenden, Box-Darstellung
- Bottom Buttons:** OK, Abbrechen, Hilfe

Fig. 2/13: Dialogue window “Teilnehmerbeschreibung einfügen” (Insert station description)

8. Profile number:  
The CPX terminal corresponds to the Interbus I/O profile 12<sub>H</sub>. Enter this value in the field “Profilnummer” (Profile number).
9. Interface type:  
Universal is preset. This setting can be accepted. Alternatively, with the button “Schnittstellentyp” (Interface type), you can open a dialogue window in which you can set the type “Fernbus” (remote bus).

## 2. Commissioning

10. If required, you can enter corresponding terms for identifying the CPX terminal under “Stationsname” (Position name), “Teilnehmername” (Station name), “Herstellername” (Manufacturer name) and “Gerätetyp” (Device type).

### 11. Representation:

You can individually adapt the representation of the CPX terminal in the CMD software. However, this is not absolutely necessary for commissioning.

With the button “Darstellung” (Representation), you can open a dialogue window in which you can set a specific icon for the CPX terminal.



The specific icons for CPX terminals can be found

- in the internet under [www.festo.com](http://www.festo.com) (Download Area – Fieldbus Utilities),
  - on the Utility CD from Festo (in preparation).
- Copy the files “CPX-01.ico” und “CPX-PCP.ico” into the CMD directory \PICTURE\.
  - Actuate the button “Auswählen ...” (Select ...) in the dialogue window “Darstellung...” (Representation...).
  - Select the entry “Icons (\*.ico)” under “File type”.




Fig. 2/14: Dialogue window “Ändern der Bildersammlung” (Modifying the picture collection)

## 2. Commissioning

- Select one of the files “CPX-01.ico” (CPX terminal without PCP channel) or “CPX-PCP.ico” (CPX terminal with PCP channel).




Fig. 2/15: Dialogue window “Darstellung” (Representation) for selecting an icon

- Accept your selection with OK.

## 2. Commissioning

When all entries have been made, the CPX terminal will be integrated into your bus structure as follows (example):




Fig. 2/16: Example – inserted CPX terminal

### 2.1.7 Bus configuration without CMD software

#### Logical addressing

In the case of the bus configuration without CMD software, the following specifications must be known or ascertained for each bus station. Configure the CPX terminal as follows:

- **ID code (Ident. code)**
  - CPX terminal only with **outputs** <sup>1)</sup>: ident. code 1<sub>D</sub>
  - CPX terminal only with **inputs**: ident. code 2<sub>D</sub>
  - CPX terminal with **inputs and outputs** <sup>1)</sup>: ident. code 3<sub>D</sub>
  - CPX terminal with **PCP channel**: ident. code 243<sub>D</sub>
- **Process data channel:**
  - Calculate the number of I/Os per valve terminal. The number of inputs and outputs must be rounded up to the next word limit. If the number of input bits differs from the number of output bits, the greater number is in each case decisive for entry of the process data channel bits.
  - Observe that the status bits occupy an additional 8 inputs.
  - Observe that the I/O diagnostics interface occupies an additional 16 inputs and outputs.
  - Observe that the maximum number of process data bits is reduced by 16 inputs and outputs when the PCP channel is activated.
  - Assign logical IN and OUT addresses to each station.

## 2. Commissioning

### 2.1.8 Process data entry via the CMD software

The CMD software offers from version 4 the possibility of assigning any input/output in the PLC/IPC bit-by-bit to each input/output of a CPX terminal within the configured address range. Proceed as follows:

1. Insert a CPX terminal into your bus structure (necessary steps see section 2.1.6 “Bus configuration with the CMD software”).
2. Select the command “Prozessdaten” (Process data) in the context menu of the CPX terminal.




Fig. 2/17: Open the dialogue window “Prozessdaten” (Process data)

## 2. Commissioning

You can define the I/O addresses in the following dialogue window. In this way you can adapt the I/Os of the CPX terminal to the PLC used. The following diagram shows the byte-by-byte assignment for a Siemens S7:




Fig. 2/18: Entering process data – example for “Siemens mode”



## 2. Commissioning

If necessary, interchange the high byte and the low byte (byte swap).



### Note

To correct the byte assignment in the Siemens and standard modes, it is enough to assign the corresponding I/O address to each byte.

Individual I/O assignment at bit level is only necessary in rare cases.

The following dialogue window shows the entries required for interchanging the assignment of the high byte and the low byte (example: byte swap for “standard mode”).




Fig. 2/19: Modification of the I/O assignment (byte swap) – example for “standard mode”

## 2. Commissioning

### 2.1.9 Configuration in the remote controller operating mode

If there is a CPX-FEC or CPX-CEC in your CPX terminal, you can operate the bus node in the remote controller operating mode. The bus node then occupies 8 input bytes and 8 output bytes. These are available to the control program in the CPX-FEC or CPX-CEC.

Configuration of the bus node remote controller operating mode

1. Ensure that DIL switch 1 of the bus node is in the remote controller position (see section 1.2, Tab. 1/1).
2. Set 8 I/O bytes with DIL switch 4 (see section 1.2, Tab. 1/7).

The bus node is thus configured as remote controller.

### 2.2 Parametrisation

You can set the behaviour of the CPX terminal as well as the behaviour of individual modules and channels through parametrisation. A distinction is made between the following parametrisation types:

- System parametrisation, e.g. deactivating error messages etc.
- Module parametrisation (module- and channel-specific), e.g.: monitoring, settings in case of error, settings for Forcing.

#### Parameters of the CPX terminal

An overview of the parameters available for the CPX terminal can be found in appendix A.3.



A description of the functions of the individual parameters can be found in the CPX system description.

Which module parameters are available for the various modules can be found in the description for the respective module (e.g. description for CPX I/O modules (P.BE-CPX-EA-..)).

### Requirements for parametrisation

You can influence the start characteristics with the system parameter “System start”. If possible, select the setting “Systemstart mit Default-Parametrierung und aktuellem CPX-Ausbau” (System start with default parametrisation and current CPX expansion). The desired parametrisation can then be carried out in the initialisation phase or user-controlled.



#### Note

Parametrisation of the CPX terminal is in principle only possible if the system parameter “System start” has the setting “Systemstart mit Default-Parametrierung und aktuellem CPX-Ausbau” (System start with default parametrisation and current CPX expansion).

If the M LED lights up permanently after the system start, then “Systemstart mit gespeicherter Parametrierung und gespeichertem CPX-Ausbau” (System start with saved parametrisation and saved CPX expansion) is set. In this case, no other parametrisation can be carried out.



#### Caution

In the case of CPX terminals on which the M LED lights up permanently, parametrisation will not be restored automatically by the higher-order system if the CPX terminal is replaced during servicing. In these cases, check before replacement to see which settings are required and carry out these settings.

## 2. Commissioning

### 2.2.1 Parametrisation concepts

You can parametrise a CPX terminal with the bus node CPX-FB6 using various methods. The following table provides an overview of the methods.



The PCP channel is required for all parametrisation methods except for parametrisation with the handheld.

#### Parametrisation via the PCP channel

A distinction is made between:

- device parametrisation via the CMD software, e.g. during commissioning
- boot-up parametrisation with power on, e.g. via user functions or via the PLC user program.



#### **Note**

Without the PCP channel, parametrisation is only possible with the handheld.



Further information on the PCP channel can be found in the appendix.

## 2. Commissioning

Method	Description	Advantages	Disadvantages
CMD device parametrisation	The relevant parametrisation is selected and carried out directly via the CMD software. It is possible to save the individual parametrisation within the CMD software.	<ul style="list-style-type: none"> <li>– Fast, simple parametrisation during commissioning for testing the parameters</li> </ul>	<ul style="list-style-type: none"> <li>– Parametrisation is saved locally in the CPX terminal and is lost after power off or if the terminal is replaced.</li> <li>– Access via remote maintenance is not possible.</li> </ul>
CMD user functions automatically after power on (“boot” active)	Macros with the desired parametrisation are created via the user functions. These macros are transmitted by the interface module after power on.	<ul style="list-style-type: none"> <li>– CMD-uniform parametrisation</li> <li>– Data are loaded automatically after power on and are therefore retained if the CPX terminal is replaced.</li> </ul>	<ul style="list-style-type: none"> <li>– Parametrisation is saved only in the interface module memory and not in the complete control project.</li> <li>– Access via remote maintenance is not possible</li> </ul>
CMD user functions accessed by user program	Values (parameters) can be transferred to the user functions via Interbus process data words. In this way, parametrisation can be undertaken flexibly via a PLC user program.	<ul style="list-style-type: none"> <li>– CMD-uniform parametrisation</li> <li>– Parametrisation data are saved in the user program. Remote maintenance is therefore possible</li> </ul>	<ul style="list-style-type: none"> <li>– Sequential parametrisation by means of a large number of user functions</li> </ul>

Tab. 2/1: Parametrisation concepts – part 1

## 2. Commissioning

Method	Description	Advantages	Disadvantages
PLC user program	Parametrisation is carried out within the user program in the PLC/IPC. Special function blocks for PCP communication are usually used here.	<ul style="list-style-type: none"> <li>– Parametrisation is saved in the PLC and backed up in the user program.</li> <li>– Modification by remote maintenance is possible</li> </ul>	<ul style="list-style-type: none"> <li>– Complex programming</li> </ul>
Handheld *)	Parametrisation is carried out via menu-guided entries with the handheld.	<ul style="list-style-type: none"> <li>– Very user-friendly parametrisation via menu-guiding (plain text).</li> </ul>	<ul style="list-style-type: none"> <li>– Parametrisation is saved locally in the CPX terminal and lost if the CPX terminal is replaced.</li> <li>– Access via remote maintenance is not possible.</li> </ul>
*) PCP channel not required			

Tab. 2/1: Parametrisation concepts – part 2

### Recommendation:

Use the parametrisation via the PLC user program. You will then achieve a high degree of reliability and flexibility.



Further instructions on the procedure for parametrisation can be found in the sections which follow.

### Sequence of parametrisation

After power on, parametrisation of the CPX terminal can take place in various ways, e.g.

- Bus master start-up (user functions with “boot” attribute)
- PLC user programs (user functions with parameter transfer or function blocks)
- CMD device parametrisation/handheld (optional), etc.



#### **Note**

The last parametrisation received in the CPX terminal is always valid.

Parametrisation of the CPX terminal is in principle only possible if the system parameter “System start” has the setting “Systemstart mit Default-Parametrierung und aktuellem CPX-Ausbau” (System start with default parametrisation and current CPX expansion).

In this case, the standard parameter settings are valid in the CPX terminal after power on.



#### **Note**

If the system parameter “System start” has the setting “Systemstart mit gespeicherter Parametrierung und gespeichertem CPX-Ausbau” (System start with saved parametrisation and saved CPX expansion), modified parameter settings in the CPX terminal will become valid immediately after power on.



## 2. Commissioning

### 2.2.2 Device parametrisation with the CMD software

With the device parametrisation via the CMD software, access can be made to the assigned parameter bytes (function numbers) via the PCP index.




Fig. 2/20: “Geräte-Parametrierung –Werte verändern” ( Device parametrisation – modifying values)

The parameter bytes can be modified according to the desired parametrisation, and the modified parametrisation can then be written into the CPX terminal.

The individual parametrisation undertaken can be saved within the CMD software.

If a parameter file (\*.dsc) with instructions is available, it can be loaded in the CMD software.

## 2. Commissioning

### 2.2.3 Parametrisation with CMD user functions

User functions can be created in the CMD software. A user function is a macro assigned with parameters.

The following options are available for parametrisation of the CPX terminal with the aid of the user functions:

- The boot attribute for the user function is set
- The user function is started by the user program

The boot attribute for the user function is set

The function is carried out when the module starts up.




Fig. 2/21: “Anwenderfunktion” (User function) – boot attribute is set

## 2. Commissioning




Fig. 2/22: “Anwenderfunktion – Parameter bearbeiten” (User function – process parameters)

## 2. Commissioning

The user function is started by the user program

You can start and monitor a user function from your user program. The parameter values are transferred to the user function, e.g. via Interbus process data words.




Fig. 2/23: User function – parameters are transferred via variables (e.g. process data words).

## 2. Commissioning

### 2.2.4 Parametrisation with the PLC user program

The CPX terminal can be parametrised directly by a user program with the aid of special function blocks for PCP communication.



Information on using the function blocks can be obtained from the manufacturer of the controller/interface module.

```
CALL FC      23
  IBDB       :=DB20           // IBDB - Interbus data module
  PCP_DB     :=DB21
  CR         :=2             // CR number of the PCP slave
  TOGGLE     :=M120.5        // Second bit
  ONLY_INITIATE:=TRUE        //
  RET        :=M120.2        // Result bit
  FC_BUSY    :=M120.3        // Activate function
  ACTIVATE_BITS:=MB103
  INITIALIZE :=M120.4
  STATUS     :=MW104
```

Fig. 2/24: Program example (SIEMENS STEP 7)

### 2.3 Commissioning the CPX terminal on the Interbus

In order to avoid errors (e.g. configuration and parametrisation errors) during commissioning:

- Please observe the general commissioning instructions in the CPX system description.
- Check the DIL switch settings before using and replacing CPX terminals.
- Observe the instructions on switching on the power supply in section 2.1.5.
- Check the configured address range (process data and assigned input and output bytes). If necessary, test the I/Os.
- Check the address assignment of the I/Os on the CPX terminal. In order to do this, you can, if necessary, force the I/Os (see CPX system description).
- Make sure that the desired parametrisation of the CPX terminal in the initialisation phase or after fieldbus interruptions is carried out by the interface module. This ensures that if the CPX terminal is replaced, the new terminal will also be operated with the desired parameter settings.
- Check the parametrisation on a random basis, e.g. with the function “CMD device parametrisation” or with the handheld.
- The M/TR LED signals communication via the PCP channel. You can then ascertain whether parametrisation via the PCP channel has taken place, e.g. in the start-up phase.

## 2. Commissioning

### 2.3.1 Fail safe

The CPX terminal supports special Fail Safe parametrisation. System-specific I/O states can therefore be defined in the event of an error.



Information on Fail Safe parametrisation can be found in the CPX system description.



#### **Note**

In order to maintain defined I/O statuses in the event of an error, the Sysfail evaluation of the Interbus master must be activated.

The Sysfail evaluation in the Interbus master ensures that if the PLC (CPU) stops or has an error, the exchange of process data between the CPU and the Interbus interface module will be synchronised.

This is to prevent 0-signals from being incorrectly transmitted via the Interbus. Otherwise, useful Fail Safe treatment or programming would not be possible.

## 2. Commissioning



# Diagnostics and error handling

## Chapter 3

## Table of contents

<b>3.</b>	<b>Diagnostics and error handling</b>	<b>3-1</b>
3.1	Summary of diagnostics options	3-4
3.2	Diagnostics via LEDs	3-6
3.2.1	Normal operating status	3-7
3.2.2	CPX-specific LEDs	3-8
3.2.3	Interbus-specific LEDs	3-11
3.3	Diagnostics via Interbus	3-13
3.3.1	Status bits	3-13
3.3.2	I/O diagnostics interface	3-15
3.3.3	Diagnostics via the PCP channel	3-16
3.3.4	Peripheral faults (PF)	3-18
3.4	Error handling	3-20

### 3. Diagnostics and error handling

Contents of this chapter	<p>The CPX terminal - offers extensive diagnostics options. In this chapter you will find an overview as well as detailed information on the diagnostics options:</p> <ul style="list-style-type: none"><li>– LEDs</li><li>– Status bits</li><li>– I/O diagnostic interface</li><li>– PCP channel</li><li>– Peripheral faults (PF)</li><li>– Handheld</li></ul>
Further information	<p>Information on the general diagnosis of the CPX terminal can be found in the CPX system manual (P.BE-CPX-SYS-..).</p> <p>Information on diagnosing the pneumatic interface and the I/O modules can be found in the manual for the CPX I/O modules (P.BE-CPX-EA-..)</p> <p>Instructions on diagnosing the pneumatics can be found in the relevant pneumatics description.</p>

### 3. Diagnostics and error handling

#### 3.1 Summary of diagnostics options

The CPX terminal provides comprehensive and user-friendly options for diagnostics and error handling. The following options are available, depending on the configuration:

<b>Diagnostics option</b>	<b>Brief description</b>	<b>Advantages</b>	<b>Detailed description</b>
LED display	The LEDs show directly configuration errors, hardware errors, bus errors, etc.	Fast “on-site” error detection	Section 3.2
Status bits	Internal inputs that supply coded common diagnostic messages. The 8 status bits are transmitted to the interface as “inputs” cyclically with the normal inputs.	Fast access to error messages, independent of the interface and master	Section 3.3.1 and CPX system description
I/O diagnostics interface	The I/O diagnostics interface is a bus-independent diagnostics interface at I/O level, which enables access to internal data of the CPX terminal (16 inputs and 16 outputs).	Detailed error detection: the diagnostic data (e.g. with peripheral errors) can be processed further, e.g. by a PLC user program	Section 3.3.2 and CPX system description
Diagnostics via the PCP channel	Transmission of diagnostics information via the Interbus	Detailed error detection: the diagnostic data (e.g. with peripheral errors) can be processed further, e.g. by a PLC user program	Section 3.3.3
Diagnostics via the handheld	Diagnostic information can be shown on the handheld in a convenient and menu-driven manner.	Fast “on-site” error detection	Description for the Handheld

Tab. 3/1: Diagnostics options

### 3. Diagnostics and error handling

#### Peripheral faults (PF)

If an error is recognized by the CPX terminal, a peripheral fault is triggered, transmitted to the interface and displayed there (see section 3.3.4).

**Note**

Observe that the diagnostic information shown can depend on the DIL switch settings on the bus node as well as on the parametrisation of the CPX terminal.

### 3. Diagnostics and error handling

## 3.2 Diagnostics via LEDs

LEDs for diagnostics of the CPX terminal are available on the bus node as well as on the individual modules.



The significance of the LEDs on the electric modules can be found in the description for the respective module.

### LEDs at the bus node CPX-FB6

The light emitting diodes on the cover indicate the operating status of the CPX bus node.

- 1 CPX-specific LEDs:
    - PS (green)
    - PL (green)
    - SF (red)
    - M (yellow) \*)
  - 2 Interbus-specific LEDs:
    - UL (green)
    - RC (green)
    - BA (green)
    - RD (yellow)
    - TR (yellow) \*)
- \*) The LED M/TR is assigned twice




Fig. 3/1: LEDs on the CPX bus node CPX-FB6











### 3. Diagnostics and error handling

The LEDs are shown in their various statuses as follows:

 lights up;  flashes;  off








#### 3.2.1 Normal operating status





In the standard operating status, all green LEDs light up. The red and yellow LEDs do not light up.

LED display	Operating status
 <p>UL  PS  RC  PE  BA  SF  RD  M  TR </p>	<p>All green LEDs light up:</p> <ul style="list-style-type: none"><li>- UL</li><li>- RC</li><li>- BA</li><li>- PS</li><li>- PL</li></ul> <p>Red and yellow LEDs do not light up:</p> <ul style="list-style-type: none"><li>- SF</li><li>- RD</li><li>- M/TR</li></ul>

### 3. Diagnostics and error handling









#### 3.2.2 CPX-specific LEDs

<b>PS (power system) – power sensor/logic supply</b>			
<b>LED (green)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED illuminated		No error. Operating voltage/sensor supply applied	–
 LED flashes		Operating voltage/sensor supply outside the tolerance range	Eliminate undervoltage
		Internal fuse for the operating voltage/sensor supply has responded	1. Eliminate short circuit/overload on module side 2. Dependent on the parametrisation of the module (module parameter): <ul style="list-style-type: none"> <li>• The sensor supply voltage will be switched on again <b>automatically</b> after the short circuit has been eliminated (default)</li> <li>• Power off/on is necessary</li> </ul>
 LED not illuminated		The operating voltage/sensor supply is not applied	Check the operating voltage connection of the electronics







<b>PL (power load) – power load voltage(outputs/valves)</b>			
<b>LED (green)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED illuminated		No error. Load voltage applied	None
 LED flashes		Load voltage at the system supply or additional power supply outside the tolerance range	Eliminate undervoltage



### 3. Diagnostics and error handling

<b>SF (system failure) – system error</b>			
<b>LED (red)</b>	<b>Sequence <sup>1)</sup></b>	<b>Status</b>	<b>Significance / error handling</b>
 LED not illuminated	ON  OFF	No error.	–
 LED flashes	ON  OFF	Simple error/information (error class 1)	See description of error numbers in the CPX system description
 LED flashes	ON  OFF	Error (error class 2)	
 LED flashes	ON  OFF	Serious error (error class 3)	
<sup>1)</sup> The System Failure LED flashes dependent on the applicable error class. Error class 1 (simple error): 1 * flashing, pause time Error class 2 (error): 2 * flashing, pause time Error class 3 (serious error): 3 * flashing, pause time			

### 3. Diagnostics and error handling





<b>M (modify) – parametrisation modified or force active</b>			
<b>LED (yellow)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED not illuminated		System start with default parametrisation (factory setting) and current CPX expansion set; external parametrisation is possible (presetting)	None
 LED illuminated		System start with saved parametrisation and saved CPX expansion has been set; Parameters and CPX expansion are saved remanently; external parametrisation is blocked <sup>1)</sup>	Caution when replacing CPX valve terminals with saved parametrisation. With these CPX valve terminals, parametrisation is not carried out automatically by the higher-order PLC/IPC when the terminal is replaced. In these cases, check which settings are required before the replacement and make these settings if necessary.
 LED flashes		Force is active <sup>1)</sup>	The Force function is enabled (see system parameter Force mode; function no. 4402).
<sup>1)</sup> The display of the Force function (LED flashes) has precedence over the display of the setting for System start (LED lights up).			





The LED M/TR is intended for several functions (see also under Interbus-specific LEDs). The status which is shown takes place in the following sequence:







1. Force active
2. Parameters saved remanently
3. PCP communication

### 3. Diagnostics and error handling





#### 3.2.3 Interbus-specific LEDs





<b>UL (U load) – logic supply for bus interface</b>			
<b>LED (green)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED illuminated		No error. Logic voltage applied	–
 LED not illuminated		Logic supply for bus interface not applied	Service required, if necessary replace bus node

<b>RC (remote bus check) – fieldbus connection</b>			
<b>LED (green)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED illuminated		Incoming remote bus connection OK	–
 LED not illuminated		Incoming remote bus connection faulty	Check incoming field bus connection.

<b>BA (bus active) – remote bus active</b>			
<b>LED (green)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED illuminated		Data transmission on Interbus active, Interbus to RUN	–
 LED flashes		No data transmission on the Interbus. Interface module initiates ID cycles.	<ul style="list-style-type: none"> <li>• Eliminate bus error.</li> <li>• Reset interface module.</li> <li>• Acknowledge error.</li> <li>• Start data transmission.</li> </ul>
 LED not illuminated		No data transmission on the Interbus.	Interface module not in “run” status.

### 3. Diagnostics and error handling

<b>RD (remote bus disable) – remote bus switched off</b>			
<b>LED (yellow)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED illuminated		– Continued interface switched off. – Data transmission on the Interbus interrupted.	<ul style="list-style-type: none"> <li>• Start data transmission.</li> <li>• Check stations on continued interface.</li> </ul>
 LED not illuminated		Normal operation.	–

<b>TR (transmit/receive) – PCP active</b>			
<b>LED (yellow)</b>	<b>Process</b>	<b>Status</b>	<b>Significance / error handling</b>
 LED flickers		CPX terminal sends/receives data	Parametrisation or diagnostics take place via the PCP channel. The LED lights up only briefly while data transmission takes place via the PCP channel.
 LED not illuminated		CPX terminal does not send/receive data	At present there is no communication via the PCP channel

The LED M/TR is intended for several functions (see also under CPX-specific LEDs).

## 3.3 Diagnostics via Interbus

The CPX terminal enables diagnostics via the Interbus. The following diagnostics options are supported here:

- status bits (system status)
- I/O diagnostics interface (system diagnostics)
- diagnostics via the PCP channel
- peripheral errors

### 3.3.1 Status bits

The status bits serve to display common diagnostic messages (global error message).



#### **Note**

To use the status bits, they must be activated via the DIL switch on the bus node.

These status bits are treated like inputs and are transmitted to the Interbus master with the other inputs. They can be queried there as “standard” inputs, linked and processed.

The status bits always occupy 8 addresses of the configured address range. If the inputs of the input addresses thereunder are not used, the CPX terminal will set them to “logical zero”. The addresses of the status bits in the address space depend, like all inputs/outputs, on the Interbus interface and on the control system used (see section 2.1.2).

### 3. Diagnostics and error handling

Bit	Diagnostic information with logic 1	Description
0	Error at valve	Module type in which an error has occurred
1	Error at output	
2	Error at input	
3	Error on analogue module/ function module	
4	Undervoltage	Fault type
5	Short circuit/overload	
6	Wire break	
7	Other error	

Tab. 3/2: Overview of status bits

If all status bits supply logic 0, no error will be reported.

If various errors occur simultaneously on different types of modules, these errors cannot be assigned via the status bits. If required, errors can be uniquely defined via the I/O diagnostics interface.

Further instructions on the function and content of the status bits can be found in the CPX system description.



### 3. Diagnostics and error handling

#### 3.3.2 I/O diagnostics interface

Detailed diagnostic information can be accessed via the I/O diagnostic interface. You can ascertain exactly, for example, on which module and on which channel an error has occurred. System diagnostics are retrieved by means of 16 input bits and 16 output bits, through which all diagnostics data can be read.



#### **Note**

To use the I/O diagnostics interface, it must be activated via DIL switches on the bus node.

The addresses of the inputs and outputs of the diagnostics interface, like all inputs/outputs, are dependent on the Interbus module and on the control system used (see section 2.1.2).



Instructions on diagnostics with the I/O diagnostics interface can be found in the CPX system description.

### 3. Diagnostics and error handling

#### 3.3.3 Diagnostics via the PCP channel

Via the PCP channel you have flexible access to the diagnostic information of the CPX terminal.



**Note**

To use the diagnostics via the PCP channel, they must be activated via DIL switches on the bus node.

For accessing the diagnostic information via the PCP channel, you can use the same methods as for parametrisation (see section 2.2).

Access to the diagnostic information via the PCP channel takes place via index numbers. An overview of the available diagnostic information, its function numbers as well as the assignment to the index numbers can be found in the appendix A.3.



Information on the available diagnostic information and its function numbers can be found in the CPX system manual.



### 3. Diagnostics and error handling

#### Overview of diagnostics data

<b>Diagnostics data</b>	<b>Contents / description</b>
Global diagnostics data	– General overview of errors
Module diagnostics data	– Detail diagnostics per module
Status of diagnostic memory	– Number of entries in the diagnostic memory – Operating mode
Diagnostic memory data	– Long-term memory (max. 40 entries) – Detail diagnostics + relative time stamp per error event

Tab. 3/3: Diagnostics data

### 3. Diagnostics and error handling

#### 3.3.4 Peripheral faults (PF)

If an error is detected by the valve terminal, a peripheral fault will be triggered as a common error message, transmitted to the module and displayed there. This common error message can be classified more accurately either with the status bits or the I/O diagnostics interface.

The causes of peripheral faults can be all the error messages of the CPX terminal, which have also been entered in the status bits e.g.:

- voltage of the valves and electric outputs below the tolerance.
- voltage of the valves and electric outputs switched off (e.g. with EMERGENCY STOP).
- short circuit in supply voltage to inputs/sensors.
- short circuit or overload at digital outputs.
- further specific error messages of the CPX terminal.

Additional information on error messages of the CPX terminal can be found in the CPX system description.



### 3. Diagnostics and error handling

#### Hiding voltage error messages

On delivery from the factory, a peripheral fault can be triggered by various causes. Voltage faults, however, can be suppressed with the DIL switch setting on the bus node.

**Note**

Independent of the setting of DIL switch 2.1, the errors are entered in the status bits.

The system is not stopped due to peripheral faults. You can define the reaction to peripheral faults in the user program. A peripheral fault is also acknowledged in the user program.

#### 3.4 Error handling

The behaviour of the CPX terminal with the following malfunctions is dependent on the configured behaviour of the master interface and the parametrised Fail Safe setting:

- telegram failure
- master stop
- interruption in the bus cable

Depending on the parametrisation, the outputs (valves and electric outputs) will be switched off (factory setting), switched on or retain their status (see CPX system description).



#### **Warning**

- Ensure that valves and outputs are put into a safe state if the stated malfunctions occur.

An incorrect status of the valves and outputs can lead to dangerous situations!



#### **Note**

Please observe the following if the outputs are reset in the event of a PLC stop or fieldbus interruption or malfunction:

- Single-solenoid valves move to the normal position
- Double-solenoid valves remain in the current position.
- Mid-position valves go into mid-position (pressurized, exhausted or closed, depending on valve type).

# Technical appendix

## Appendix A

## Table of contents

<b>A.</b>	<b>Technical appendix</b> .....	<b>A-1</b>
A.1	Technical data bus node type CPX-FB6 .....	A-3
A.2	Accessories .....	A-5
A.3	Access to parameters and data via the PCP channel .....	A-6
A.4	Parameters in the operating mode Remote I/O .....	A-8
A.4.1	System parameters .....	A-8
A.4.2	Module parameters .....	A-9
A.4.3	Diagnostic memory parameters .....	A-18
A.4.4	Diagnostic memory data .....	A-18
A.4.5	System diagnostics data .....	A-20
A.4.6	Module diagnostics data .....	A-21
A.4.7	System data .....	A-22
A.4.8	Module data .....	A-22
A.4.9	Length of the PCP data objects .....	A-24

## A.1 Technical data bus node type CPX-FB6

<b>General</b>	
<b>General technical data</b>	See CPX system description: – Description P.BE-CPX-SYS-...
<b>Protection class</b> according to EN 60 529, CPX-FB6 completely mounted, plug connector, like accessories, plugged in or equipped with protective cap	IP 65/IP 67
<b>Protection against electric shock</b> (protection against direct and indirect contact in accordance with IEC/DIN 60204-1)	By means of PELV power supply unit (Protected Extra Low Voltage)
<b>Current consumption bus node CPX-FB6</b> Internal current consumption at 24 V (internal electronics): – from operating voltage supply for electronics/sensors ( $U_{EL/SEN}$ )	typ. 50 mA
<b>Galvanic isolation</b> – Incoming interface – Continued interface	galvanically separated (optocoupler) non-floating with CPX peripherals
<b>Module code (CPX-specific)</b>  <b>Module identifier (e.g. on the handheld)</b>	Remote I/O: 203 Remote controller: 154 Remote I/O: FB06-RIO Remote controller: FB06-RC

<b>Fieldbus</b>	
<b>Version</b>	RS 422, floating
<b>Type of transmission</b>	Serial asynchronous, full-duplex
<b>Protocol</b>	Interbus
<b>Baud rate</b>	500 kBaud, 2 MBaud

## A. Technical appendix






<b>Fieldbus</b>	
<b>Cable type</b> – Remote bus without additional power supply, max. cable capacity	LI-ICY, 3 x 2 x 0.25 mm <sup>2</sup> , 120 pF/m
<b>Cable length at 500 kBd</b> – between two remote bus slaves – of the complete system	Max. 400 m up to 12.8 km



## A.2 Accessories



The following table provides an overview of necessary and useful accessories for the bus node CPX-FB6.

Accessories	Type	Designation	Description
	FBS-SUB-9-BU-IB-B	STECKER,SUB9-D	Socket for fieldbus connection incoming, 9-pin Sub-D, IP 65/IP 67
	FBS-SUB-9-GS-IB-B	STECKER,SUB9-D	Plug for fieldbus connection continued, 9-pin Sub-D, IP 65/IP 67
	CPX-AB-2-M12-RK-IB	CONNECTION BLOCK	Connection block M12, reverse key for Interbus IP 67/IP 67
	UNC 4-40/M3X6	SCREW LOCKING	Threaded bush. If plugs or sockets of other manufacturers are used for the fieldbus connection, the flat screws on the bus node must be replaced by threaded bushes.
	ISK-M12	PROTECTIVE CAP	Protective cap for sealing the service interface for the handheld or the connection "Out" on the connection block M12 reverse key, if this is not already used.
	AK-SUB-9/15-B	INSPECTION COVER	Cover for sealing the continued bus interface, if this is not already used (included in scope of delivery).



Further information on accessories for the CPX terminal can be found in the CPX system description or in the description for the CPX modules used.

### A.3 Access to parameters and data via the PCP channel

Via the PCP channel you can access all system data and system parameters which the CPX terminal provides.

The PCP channel is available if the bus node is configured with the following ident. code:

- 243<sub>D</sub>

An overview of the available data and parameters, their function numbers as well as the assignment to the index numbers can be found in the following sections.

The description and mode of operation of the individual parameters and data can be found in the CPX system description.



**Note**

Bytes and bits not listed are reserved for future extensions.

### Function of the PCP channel

In addition to I/O data, complex data records can also be transmitted via the Interbus. The transmission of the following information, for example, is therefore possible:

- parametrisation information,
- diagnostics information.

Communication is made via the “Peripheral Communication Protocol” (PCP or PCP channel). Fieldbus stations that support communication via the PCP channel are designated PCP stations.

The PCP channel possesses the following features:

- Parameters are transmitted sequentially
- Parameter data are transmitted word by word in 16-bit packages
- Per data cycle, 8 bits of parameter data and 8 bits of administrative data are transmitted
- “Breaking up” and “Putting together” the parameter data takes place via the Interbus protocol chip (SUPI).

## A.4 Parameters in the operating mode Remote I/O

### A.4.1 System parameters

System parameters	Function no.	PCP index
Reserved (Bit 0 ... 7)	4400	74F5 <sub>H</sub> – byte 0
Monitoring (active/inactive) (bit 0 ... 4) – Bit 0: short circuit/overload in sensor supply (SCS) – Bit 1: short circuit/overload at outputs (SCO) – Bit 2: undervoltage at outputs (U <sub>OUT</sub> ) – Bit 3: undervoltage at valves (U <sub>VAL</sub> ) – Bit 4: short circuit at valves (SCV)	4401	74F5 <sub>H</sub> – byte 1
Fail safe (behaviour with communication errors) (bit 0, 1)	4402	74F5 <sub>H</sub> – byte 2
Force mode (enable/block force) (bit 2, 3)	4402	74F5 <sub>H</sub> – byte 2
System start (bit 6)	4402	74F5 <sub>H</sub> – byte 2

### A.4.2 Module parameters

The following tables contain an overview of the typical parameters of the CPX modules.



Information on the module parameters can be found in the description for the relevant module, e.g. description CPX I/O modules (P.BE-CPX-EA-..) or CPX analogue I/O modules (P.BE-CPX-AX-..).

Module parameters	Module no.	Function no.	PCP index
Monitoring CPX module (bit 0 ... 7)	0	4828	7535 <sub>H</sub> – byte 0
– Bit 0: short circuit/overload in sensor supply (SCS)	1	4892	7545 <sub>H</sub> – byte 0
	2	4956	7555 <sub>H</sub> – byte 0
– Bit 1: short circuit/overload at outputs (SCO)	3	5020	7565 <sub>H</sub> – byte 0
	4	5084	7575 <sub>H</sub> – byte 0
– Bit 2: undervoltage at outputs/valves (U <sub>OUT/VAL</sub> )	5	5148	7585 <sub>H</sub> – byte 0
– Bit 3: short circuit at valves (SCV)	6	5212	7595 <sub>H</sub> – byte 0
– Bit 4: reserved	7	5276	75A5 <sub>H</sub> – byte 0
– Bit 5: reserved	8	5340	75B5 <sub>H</sub> – byte 0
– Bit 6: reserved	9	5404	75C5 <sub>H</sub> – byte 0
– Bit 7: monitoring parametrisation errors (internal errors)	10	5468	75D5 <sub>H</sub> – byte 0
	11	5532	75E5 <sub>H</sub> – byte 0
	12	5596	75F5 <sub>H</sub> – byte 0
	13	5660	7605 <sub>H</sub> – byte 0
	14	5724	7615 <sub>H</sub> – byte 0
	15	5788	7625 <sub>H</sub> – byte 0
	16	5852	7635 <sub>H</sub> – byte 0
	17	5916	7645 <sub>H</sub> – byte 0
	...	...	...

## A. Technical appendix

Module parameters	Module no.	Function no.	PCP index
Behaviour according to short circuit/overload (bit 0 ... 3) – Bit 0: short circuit/overload in sensor supply (SCS) – Bit 1: short circuit/overload at outputs (SCO) – Bit 2: reserved – Bit 3: short circuit/overload at analogue output Input bounce time (bit 4, 5) Signal extension time (bit 6, 7)	0	4829	7535 <sub>H</sub> – byte 1
	1	4893	7545 <sub>H</sub> – byte 1
	2	4957	7555 <sub>H</sub> – byte 1
	3	5021	7565 <sub>H</sub> – byte 1
	4	5085	7575 <sub>H</sub> – byte 1
	5	5149	7585 <sub>H</sub> – byte 1
	6	5213	7595 <sub>H</sub> – byte 1
	7	5277	75A5 <sub>H</sub> – byte 1
	8	5341	75B5 <sub>H</sub> – byte 1
	9	5405	75C5 <sub>H</sub> – byte 1
	10	5469	75D5 <sub>H</sub> – byte 1
	11	5533	75E5 <sub>H</sub> – byte 1
	12	5597	75F5 <sub>H</sub> – byte 1
	13	5661	7605 <sub>H</sub> – byte 1
	14	5725	7615 <sub>H</sub> – byte 1
	15	5789	7625 <sub>H</sub> – byte 1
	16	5853	7635 <sub>H</sub> – byte 1
17	5917	7645 <sub>H</sub> – byte 1	
...	...	...	
Data format for analogue value of inputs (bit 0, 1) Data format for analogue value of outputs (bit 4, 5)	0	4831	7535 <sub>H</sub> – byte 3
	1	4895	7545 <sub>H</sub> – byte 3
	2	4959	7555 <sub>H</sub> – byte 3
	3	5023	7565 <sub>H</sub> – byte 3
	4	5087	7575 <sub>H</sub> – byte 3
	5	5151	7585 <sub>H</sub> – byte 3
	6	5215	7595 <sub>H</sub> – byte 3
	7	5279	75A5 <sub>H</sub> – byte 3
	8	5343	75B5 <sub>H</sub> – byte 3
	9	5407	75C5 <sub>H</sub> – byte 3
	10	5471	75D5 <sub>H</sub> – byte 3
	11	5535	75E5 <sub>H</sub> – byte 3
	12	5599	75F5 <sub>H</sub> – byte 3
	13	5663	7605 <sub>H</sub> – byte 3
	14	5727	7615 <sub>H</sub> – byte 3
	15	5789	7625 <sub>H</sub> – byte 3
	16	5853	7635 <sub>H</sub> – byte 3
17	5917	7645 <sub>H</sub> – byte 3	
...	...	...	



**Note**

The function is assigned module-specifically from “byte 6” in the respective PCP object of the module parameters.

The following tables include an overview of the parameters for typical CPX modules.

Module parameters	Module no.	Function no.	PCP index
<b>Example for digital input modules:</b> Signal lengthening channel 0 ... 7 (bit 0 ... 7) (bit no. = channel no.)	0	4834	7535 <sub>H</sub> – byte 6
	1	4898	7545 <sub>H</sub> – byte 6
	2	4962	7555 <sub>H</sub> – byte 6
	3	5026	7565 <sub>H</sub> – byte 6
	4	5090	7575 <sub>H</sub> – byte 6
	5	5154	7585 <sub>H</sub> – byte 6
	6	5218	7595 <sub>H</sub> – byte 6
	7	5282	75A5 <sub>H</sub> – byte 6
	8	5346	75B5 <sub>H</sub> – byte 6
	9	5410	75C5 <sub>H</sub> – byte 6
	10	5474	75D5 <sub>H</sub> – byte 6
	11	5538	75E5 <sub>H</sub> – byte 6
	12	5602	75F5 <sub>H</sub> – byte 6
	13	5666	7605 <sub>H</sub> – byte 6
	14	5730	7615 <sub>H</sub> – byte 6
	15	5794	7625 <sub>H</sub> – byte 6
	16	5858	7635 <sub>H</sub> – byte 6
	17	5922	7645 <sub>H</sub> – byte 6
...	...	...	

## A. Technical appendix

Module parameters	Module no.	Function no.	PCP index
<b>Example for pneumatics interface:</b>	0	4834 ... 4837	7535 <sub>H</sub> – byte 6 ... 9
Monitoring wire break (bit 0 ... 7)	1	4898 ... 4901	7545 <sub>H</sub> – byte 6 ... 9
Channel 0 ... 7: byte 6	2	4962 ... 4965	7555 <sub>H</sub> – byte 6 ... 9
Channel 8 ... 15: byte 7	3	5026 ... 5029	7565 <sub>H</sub> – byte 6 ... 9
Channel 16 ... 23: byte 8	4	5090 ... 5093	7575 <sub>H</sub> – byte 6 ... 9
Channel 24 ... 31: byte 9	5	5154 ... 5157	7585 <sub>H</sub> – byte 6 ... 9
(bit no. + n * 8 = channel no. ; n = 0 ... 3)	6	5218 ... 5221	7595 <sub>H</sub> – byte 6 ... 9
	7	5282 ... 5285	75A5 <sub>H</sub> – byte 6 ... 9
	8	5346 ... 5349	75B5 <sub>H</sub> – byte 6 ... 9
	9	5410 ... 5413	75C5 <sub>H</sub> – byte 6 ... 9
	10	5474 ... 5477	75D5 <sub>H</sub> – byte 6 ... 9
	11	5538 ... 5541	75E5 <sub>H</sub> – byte 6 ... 9
	12	5602 ... 5605	75F5 <sub>H</sub> – byte 6 ... 9
	13	5666 ... 5669	7605 <sub>H</sub> – byte 6 ... 9
	14	5730 ... 5733	7615 <sub>H</sub> – byte 6 ... 9
	15	5794 ... 5797	7625 <sub>H</sub> – byte 6 ... 9
	16	5858 ... 5851	7635 <sub>H</sub> – byte 6 ... 9
	17	5922 ... 5925	7645 <sub>H</sub> – byte 6 ... 9
	...	...	...
<b>Example for analogue I/O modules:</b>	0	4834 ... 4835	7535 <sub>H</sub> – byte 6, 7
Monitoring channel x (bit 0 ... 7)	1	4898 ... 4899	7545 <sub>H</sub> – byte 6, 7
Channel 0: byte 6	2	4962 ... 4963	7555 <sub>H</sub> – byte 6, 7
Channel 1: byte 7	3	5026 ... 5027	7565 <sub>H</sub> – byte 6, 7
– Bit 0: lower limit value (or value falling below nominal range)	4	5090 ... 5091	7575 <sub>H</sub> – byte 6, 7
– Bit 1: upper limit value (or value exceeding nominal range)	5	5154 ... 5155	7585 <sub>H</sub> – byte 6, 7
– Bit 2: wire break (analogue inputs) or short circuit/overload (analogue outputs)	6	5218 ... 5219	7595 <sub>H</sub> – byte 6, 7
– Bit 3: wire break/idling (analogue outputs)	7	5282 ... 5283	75A5 <sub>H</sub> – byte 6, 7
– Bit 4 ... 6: reserved	8	5346 ... 5347	75B5 <sub>H</sub> – byte 6, 7
– Bit 7: Parametrisation errors	9	5410 ... 5411	75C5 <sub>H</sub> – byte 6, 7
	10	5474 ... 5475	75D5 <sub>H</sub> – byte 6, 7
	11	5538 ... 5539	75E5 <sub>H</sub> – byte 6, 7
	12	5602 ... 5603	75F5 <sub>H</sub> – byte 6, 7
	13	5666 ... 5667	7605 <sub>H</sub> – byte 6, 7
	14	5730 ... 5731	7615 <sub>H</sub> – byte 6, 7
	15	5794 ... 5795	7625 <sub>H</sub> – byte 6, 7
	16	5858 ... 5859	7635 <sub>H</sub> – byte 6, 7
	17	5922 ... 5923	7645 <sub>H</sub> – byte 6, 7
	...	...	...



## A. Technical appendix

Module parameters	Module no.	Function no.	PCP index
<b>Example for analogue I/O modules:</b>	0	4836	7535 <sub>H</sub> – byte 8
Signal range channel x (bit 0 ... 7)	1	4900	7545 <sub>H</sub> – byte 8
– Bit 0, 1: position of DIL switch 0 for channel 0 (read only)	2	4964	7555 <sub>H</sub> – byte 8
switch 0.1 = bit 0	3	5028	7565 <sub>H</sub> – byte 8
switch 0.2 = bit 1	4	5092	7575 <sub>H</sub> – byte 8
– Bit 2, 3: signal range channel 0 (AIO)	5	5156	7585 <sub>H</sub> – byte 8
– Bit 4, 5: position of DIL switch 1 for channel 1 (read only)	6	5220	7595 <sub>H</sub> – byte 8
switch 1.1 = bit 4	7	5284	75A5 <sub>H</sub> – byte 8
switch 1.2 = bit 5	8	5348	75B5 <sub>H</sub> – byte 8
– Bit 6, 7: signal range channel 1 (AI1)	9	5412	75C5 <sub>H</sub> – byte 8
	10	5476	75D5 <sub>H</sub> – byte 8
	11	5540	75E5 <sub>H</sub> – byte 8
	12	5604	75F5 <sub>H</sub> – byte 8
	13	5668	7605 <sub>H</sub> – byte 8
	14	5732	7615 <sub>H</sub> – byte 8
	15	5796	7625 <sub>H</sub> – byte 8
	16	5860	7635 <sub>H</sub> – byte 8
	17	5924	7645 <sub>H</sub> – byte 8
	...	...	...
<b>Example for analogue input modules:</b>	0	4837	7535 <sub>H</sub> – byte 9
Measured value smoothing channel x (bit 0 ... 7)	1	4901	7545 <sub>H</sub> – byte 9
– Bit 0, 1: measured value smoothing channel 0	2	4965	7555 <sub>H</sub> – byte 9
	3	5029	7565 <sub>H</sub> – byte 9
	4	5093	7575 <sub>H</sub> – byte 9
– Bit 2, 3: reserved (= 0)	5	5157	7585 <sub>H</sub> – byte 9
– Bit 4, 5: measured value smoothing channel 1	6	5221	7595 <sub>H</sub> – byte 9
– Bit 6, 7: reserved (= 0)	7	5285	75A5 <sub>H</sub> – byte 9
	8	5349	75B5 <sub>H</sub> – byte 9
	9	5413	75C5 <sub>H</sub> – byte 9
	10	5477	75D5 <sub>H</sub> – byte 9
	11	5541	75E5 <sub>H</sub> – byte 9
	12	5605	75F5 <sub>H</sub> – byte 9
	13	5669	7605 <sub>H</sub> – byte 9
	14	5733	7615 <sub>H</sub> – byte 9
	15	5797	7625 <sub>H</sub> – byte 9
	16	5861	7635 <sub>H</sub> – byte 9
	17	5925	7645 <sub>H</sub> – byte 9
	...	...	...

A. Technical appendix

Module parameters	Module no.	Function no.	PCP index
<b>Example for analogue output modules:</b>	0	4837 ... 4844	7535 <sub>H</sub> – byte 9 ... 16
Lower limit value channel x / (bit 0 ... 7)	1	4901 ... 4908	7545 <sub>H</sub> – byte 9 ... 16
Upper limit value channel x	2	4965 ... 4972	7555 <sub>H</sub> – byte 9 ... 16
	3	5029 ... 5036	7565 <sub>H</sub> – byte 9 ... 16
Lower limit values:	4	5093 ... 5100	7575 <sub>H</sub> – byte 9 ... 16
Channel 0, low byte: byte 9	5	5157 ... 5164	7585 <sub>H</sub> – byte 9 ... 16
Channel 0, high byte: byte 10	6	5221 ... 5228	7595 <sub>H</sub> – byte 9 ... 16
Channel 1, low byte: byte 11	7	5285 ... 5292	75A5 <sub>H</sub> – byte 9 ... 16
Channel 2, high byte: byte 12	8	5349 ... 5356	75B5 <sub>H</sub> – byte 9 ... 16
Upper limit values:	9	5413 ... 5420	75C5 <sub>H</sub> – byte 9 ... 16
Channel 0, low byte: byte 13	10	5477 ... 5484	75D5 <sub>H</sub> – byte 9 ... 16
Channel 0, high byte: byte 14	11	5541 ... 5548	75E5 <sub>H</sub> – byte 9 ... 16
Channel 1, low byte: byte 15	12	5605 ... 5612	75F5 <sub>H</sub> – byte 9 ... 16
Channel 2, high byte: byte 16	13	5669 ... 5676	7605 <sub>H</sub> – byte 9 ... 16
	14	5733 ... 5740	7615 <sub>H</sub> – byte 9 ... 16
	15	5797 ... 5804	7625 <sub>H</sub> – byte 9 ... 16
	16	5861 ... 5868	7635 <sub>H</sub> – byte 9 ... 16
	17	5925 ... 5932	7645 <sub>H</sub> – byte 9 ... 16
	...	...	...
<b>Example for analogue input modules:</b>	0	4838 ... 4845	7535 <sub>H</sub> – byte 10 ... 17
Lower limit value channel x / (bit 0 ... 7)	1	4902 ... 4909	7545 <sub>H</sub> – byte 10 ... 17
Upper limit value channel x	2	4966 ... 4973	7555 <sub>H</sub> – byte 10 ... 17
	3	5030 ... 5037	7565 <sub>H</sub> – byte 10 ... 17
Lower limit values:	4	5094 ... 5101	7575 <sub>H</sub> – byte 10 ... 17
Channel 0, low byte: byte 9	5	5158 ... 5165	7585 <sub>H</sub> – byte 10 ... 17
Channel 0, high byte: byte 10	6	5222 ... 5229	7595 <sub>H</sub> – byte 10 ... 17
Channel 1, low byte: byte 11	7	5286 ... 5293	75A5 <sub>H</sub> – byte 10 ... 17
Channel 2, high byte: byte 12	8	5350 ... 5357	75B5 <sub>H</sub> – byte 10 ... 17
Upper limit values:	9	5414 ... 5421	75C5 <sub>H</sub> – byte 10 ... 17
Channel 0, low byte: byte 13	10	5478 ... 5485	75D5 <sub>H</sub> – byte 10 ... 17
Channel 0, high byte: byte 14	11	5542 ... 5549	75E5 <sub>H</sub> – byte 10 ... 17
Channel 1, low byte: byte 15	12	5606 ... 5613	75F5 <sub>H</sub> – byte 10 ... 17
Channel 2, high byte: byte 16	13	5670 ... 5677	7605 <sub>H</sub> – byte 10 ... 17
	14	5734 ... 5741	7615 <sub>H</sub> – byte 10 ... 17
	15	5798 ... 5805	7625 <sub>H</sub> – byte 10 ... 17
	16	5862 ... 5869	7635 <sub>H</sub> – byte 10 ... 17
	17	5926 ... 5933	7645 <sub>H</sub> – byte 10 ... 17
	...	...	...

## A. Technical appendix

Module parameters	Module no.	Function no.	PCP index
Fail safe – fault mode (bit 0 ... 7) Channel 0 ... 7: byte 0 Channel 8 ... 15: byte 1 Channel 16 ... 23: byte 2 Channel 24 ... 31: byte 3 (bit no. + n * 8 = channel no. ; n = 0 ... 3)	0	–	7539 <sub>H</sub> – byte 0 ... 3
	1	–	7549 <sub>H</sub> – byte 0 ... 3
	2	–	7559 <sub>H</sub> – byte 0 ... 3
	3	–	7569 <sub>H</sub> – byte 0 ... 3
	4	–	7579 <sub>H</sub> – byte 0 ... 3
	5	–	7589 <sub>H</sub> – byte 0 ... 3
	6	–	7599 <sub>H</sub> – byte 0 ... 3
	7	–	75A9 <sub>H</sub> – byte 0 ... 3
	8	–	75B9 <sub>H</sub> – byte 0 ... 3
	9	–	75C9 <sub>H</sub> – byte 0 ... 3
	10	–	75D9 <sub>H</sub> – byte 0 ... 3
	11	–	75E9 <sub>H</sub> – byte 0 ... 3
	12	–	75F9 <sub>H</sub> – byte 0 ... 3
	13	–	7609 <sub>H</sub> – byte 0 ... 3
	14	–	7619 <sub>H</sub> – byte 0 ... 3
	15	–	7629 <sub>H</sub> – byte 0 ... 3
	16	–	7639 <sub>H</sub> – byte 0 ... 3
	17	–	7649 <sub>H</sub> – byte 0 ... 3
	...	...	...
Fail safe – fault state (bit 0 ... 7) Channel 0 ... 7: byte 0 Channel 8 ... 15: byte 1 Channel 16 ... 23: byte 2 Channel 24 ... 31: byte 3 (bit no. + n * 8 = channel no. ; n = 0 ... 3)	0	–	753A <sub>H</sub> – byte 0 ... 3
	1	–	754A <sub>H</sub> – byte 0 ... 3
	2	–	755A <sub>H</sub> – byte 0 ... 3
	3	–	756A <sub>H</sub> – byte 0 ... 3
	4	–	757A <sub>H</sub> – byte 0 ... 3
	5	–	758A <sub>H</sub> – byte 0 ... 3
	6	–	759A <sub>H</sub> – byte 0 ... 3
	7	–	75AA <sub>H</sub> – byte 0 ... 3
	8	–	75BA <sub>H</sub> – byte 0 ... 3
	9	–	75CA <sub>H</sub> – byte 0 ... 3
	10	–	75DA <sub>H</sub> – byte 0 ... 3
	11	–	75EA <sub>H</sub> – byte 0 ... 3
	12	–	75FA <sub>H</sub> – byte 0 ... 3
	13	–	760A <sub>H</sub> – byte 0 ... 3
	14	–	761A <sub>H</sub> – byte 0 ... 3
	15	–	762A <sub>H</sub> – byte 0 ... 3
	16	–	763A <sub>H</sub> – byte 0 ... 3
	17	–	764A <sub>H</sub> – byte 0 ... 3
	...	...	...

A. Technical appendix

Module parameters	Module no.	Function no.	PCP index
Force mode outputs (bit 0 ... 7)	0	–	753B <sub>H</sub> – byte 0 ... 3
Channel 0 ... 7: byte 0	1	–	754B <sub>H</sub> – byte 0 ... 3
Channel 8 ... 15: byte 1	2	–	755B <sub>H</sub> – byte 0 ... 3
Channel 16 ... 23: byte 2	3	–	756B <sub>H</sub> – byte 0 ... 3
Channel 24 ... 31: byte 3 (bit no. + n * 8 = channel no. ; n = 0 ... 3)	4	–	757B <sub>H</sub> – byte 0 ... 3
	5	–	758B <sub>H</sub> – byte 0 ... 3
	6	–	759B <sub>H</sub> – byte 0 ... 3
	7	–	75AB <sub>H</sub> – byte 0 ... 3
	8	–	75BB <sub>H</sub> – byte 0 ... 3
	9	–	75CB <sub>H</sub> – byte 0 ... 3
	10	–	75DB <sub>H</sub> – byte 0 ... 3
	11	–	75EB <sub>H</sub> – byte 0 ... 3
	12	–	75FB <sub>H</sub> – byte 0 ... 3
	13	–	760B <sub>H</sub> – byte 0 ... 3
	14	–	761B <sub>H</sub> – byte 0 ... 3
	15	–	762B <sub>H</sub> – byte 0 ... 3
	16	–	763B <sub>H</sub> – byte 0 ... 3
	17	–	764B <sub>H</sub> – byte 0 ... 3
	...	...	...
Force mode outputs (bit 0 ... 7)	0	–	753C <sub>H</sub> – byte 0 ... 3
Channel 0 ... 7: byte 0	1	–	754C <sub>H</sub> – byte 0 ... 3
Channel 8 ... 15: byte 1	2	–	755C <sub>H</sub> – byte 0 ... 3
Channel 16 ... 23: byte 2	3	–	756C <sub>H</sub> – byte 0 ... 3
Channel 24 ... 31: byte 3 (bit no. + n * 8 = channel no. ; n = 0 ... 3)	4	–	757C <sub>H</sub> – byte 0 ... 3
	5	–	758C <sub>H</sub> – byte 0 ... 3
	6	–	759C <sub>H</sub> – byte 0 ... 3
	7	–	75AC <sub>H</sub> – byte 0 ... 3
	8	–	75BC <sub>H</sub> – byte 0 ... 3
	9	–	75CC <sub>H</sub> – byte 0 ... 3
	10	–	75DC <sub>H</sub> – byte 0 ... 3
	11	–	75EC <sub>H</sub> – byte 0 ... 3
	12	–	75FC <sub>H</sub> – byte 0 ... 3
	13	–	760C <sub>H</sub> – byte 0 ... 3
	14	–	761C <sub>H</sub> – byte 0 ... 3
	15	–	762C <sub>H</sub> – byte 0 ... 3
	16	–	763C <sub>H</sub> – byte 0 ... 3
	17	–	764C <sub>H</sub> – byte 0 ... 3
	...	...	...

## A. Technical appendix

<b>Module parameters</b>	<b>Module no.</b>	<b>Function no.</b>	<b>PCP index</b>
Force mode inputs Channel 0 ... 7 (bit no. = channel no.)	0	–	753D <sub>H</sub> – byte 0
	1	–	754D <sub>H</sub> – byte 0
	2	–	755D <sub>H</sub> – byte 0
	3	–	756D <sub>H</sub> – byte 0
	4	–	757D <sub>H</sub> – byte 0
	5	–	758D <sub>H</sub> – byte 0
	6	–	759D <sub>H</sub> – byte 0
	7	–	75AD <sub>H</sub> – byte 0
	8	–	75BD <sub>H</sub> – byte 0
	9	–	75CD <sub>H</sub> – byte 0
	10	–	75DD <sub>H</sub> – byte 0
	11	–	75ED <sub>H</sub> – byte 0
	12	–	75FD <sub>H</sub> – byte 0
	13	–	760D <sub>H</sub> – byte 0
	14	–	761D <sub>H</sub> – byte 0
	15	–	762D <sub>H</sub> – byte 0
	16	–	763D <sub>H</sub> – byte 0
	17	–	764D <sub>H</sub> – byte 0
...	...	...	
Force state inputs Channel 0 ... 7 (bit no. = channel no.)	0	–	753E <sub>H</sub> – byte 0
	1	–	754E <sub>H</sub> – byte 0
	2	–	755E <sub>H</sub> – byte 0
	3	–	756E <sub>H</sub> – byte 0
	4	–	757E <sub>H</sub> – byte 0
	5	–	758E <sub>H</sub> – byte 0
	6	–	759E <sub>H</sub> – byte 0
	7	–	75AE <sub>H</sub> – byte 0
	8	–	75BE <sub>H</sub> – byte 0
	9	–	75CE <sub>H</sub> – byte 0
	10	–	75DE <sub>H</sub> – byte 0
	11	–	75EE <sub>H</sub> – byte 0
	12	–	75FE <sub>H</sub> – byte 0
	13	–	760E <sub>H</sub> – byte 0
	14	–	761E <sub>H</sub> – byte 0
	15	–	762D <sub>H</sub> – byte 0
	16	–	763D <sub>H</sub> – byte 0
	17	–	764D <sub>H</sub> – byte 0
...	...	...	

### A.4.3 Diagnostic memory parameters

<b>Diagnostic memory parameters</b>	<b>Function no.</b>	<b>PCP index</b>
Reset diagnostic memory By means of write access to PCP object 7525 <sub>H</sub> , the diagnostic memory can be deleted. Read access is not possible.	–	7525 <sub>H</sub> – byte 0
Entries remanent with Power ON Run/Stop filter 1 (Bit 0) (bit 1)	3480	74F8 <sub>H</sub> – byte 0
Run/Stop filter 2 (bit 0 ... 2) Error end filter (bit 3) Error number filter (bit 4, 5) Module/channel filter (bit 6, 7)	3484	74F8 <sub>H</sub> – byte 4
Module number (MN) (bit 0 ... 7)	3485	74F8 <sub>H</sub> – byte 5
Channel number (CN) (bit 0 ... 7)	3486	74F8 <sub>H</sub> – byte 6
Error number (FN) (bit 0 ... 7)	3487	74F8 <sub>H</sub> – byte 7

### A.4.4 Diagnostic memory data

<b>Diagnostic memory data</b>	<b>Function no.</b>	<b>PCP index</b>
Number of entries in diagnostic memory (bit 0 ... 7)	3482	74F8 <sub>H</sub> – byte 2
Overflow Status (bit 0) (bit 1)	3483	74F8 <sub>H</sub> – byte 3
Diagnostic memory data (10 bytes per diagnostic entry, max. 40 entries) (bit 0 ... 7)	3488 ... 3887	see following table

## A. Technical appendix

Diagnostic memory data			Diagnostic event	Function no.	PCP index
Days:	byte 0	(bit 0 ... 7)	0	3488 ... 3497	74F9 <sub>H</sub> – byte 0 ... 9
Hours:	byte 1		1	3498 ... 3507	74FA <sub>H</sub> – byte 0 ... 9
Minutes:	byte 2		2	3508 ... 3517	74FB <sub>H</sub> – byte 0 ... 9
Seconds:	byte 3		3	3518 ... 3527	74FC <sub>H</sub> – byte 0 ... 9
Milliseconds:	byte 4		4	3528 ... 3537	74FD <sub>H</sub> – byte 0 ... 9
Module code:	byte 5		5	3538 ... 3547	74FE <sub>H</sub> – byte 0 ... 9
Module position:	byte 6		6	3548 ... 3557	74FF <sub>H</sub> – byte 0 ... 9
Channel number:	byte 7		7	3558 ... 3567	7500 <sub>H</sub> – byte 0 ... 9
Error number:	byte 8		8	3568 ... 3577	7501 <sub>H</sub> – byte 0 ... 9
Subsequent channels:	byte 9	9	3578 ... 3587	7502 <sub>H</sub> – byte 0 ... 9	
			10	3588 ... 3597	7503 <sub>H</sub> – byte 0 ... 9
			11	3598 ... 3607	7504 <sub>H</sub> – byte 0 ... 9
			12	3608 ... 3617	7505 <sub>H</sub> – byte 0 ... 9
			13	3618 ... 3627	7506 <sub>H</sub> – byte 0 ... 9
			14	3628 ... 3637	7507 <sub>H</sub> – byte 0 ... 9
			15	3638 ... 3647	7508 <sub>H</sub> – byte 0 ... 9
			16	3648 ... 3657	7509 <sub>H</sub> – byte 0 ... 9
			17	3658 ... 3667	750A <sub>H</sub> – byte 0 ... 9
			18	3668 ... 3677	750B <sub>H</sub> – byte 0 ... 9
			19	3678 ... 3687	750C <sub>H</sub> – byte 0 ... 9
			20	3688 ... 3697	750D <sub>H</sub> – byte 0 ... 9
			21	3698 ... 3707	750E <sub>H</sub> – byte 0 ... 9
			22	3708 ... 3717	750F <sub>H</sub> – byte 0 ... 9
			23	3718 ... 3727	7510 <sub>H</sub> – byte 0 ... 9
			24	3728 ... 3737	7511 <sub>H</sub> – byte 0 ... 9
			25	3738 ... 3747	7512 <sub>H</sub> – byte 0 ... 9
			26	3748 ... 3757	7513 <sub>H</sub> – byte 0 ... 9
			27	3758 ... 3767	7514 <sub>H</sub> – byte 0 ... 9
			28	3768 ... 3777	7515 <sub>H</sub> – byte 0 ... 9
			29	3778 ... 3787	7516 <sub>H</sub> – byte 0 ... 9
			30	3788 ... 3797	7517 <sub>H</sub> – byte 0 ... 9
			31	3798 ... 3807	7518 <sub>H</sub> – byte 0 ... 9
			32	3808 ... 3817	7519 <sub>H</sub> – byte 0 ... 9
			33	3818 ... 3827	751A <sub>H</sub> – byte 0 ... 9
			34	3828 ... 3837	751B <sub>H</sub> – byte 0 ... 9
			35	3838 ... 3847	751C <sub>H</sub> – byte 0 ... 9
			36	3848 ... 3857	751D <sub>H</sub> – byte 0 ... 9
			37	3858 ... 3867	751E <sub>H</sub> – byte 0 ... 9
			38	3868 ... 3877	751F <sub>H</sub> – byte 0 ... 9
			39	3878 ... 3887	7520 <sub>H</sub> – byte 0 ... 9

## A. Technical appendix

### A.4.5 System diagnostics data

<b>System diagnostics data</b>		<b>Function no.</b>	<b>PCP index</b>
Status bits (error type and source of error) (bit 0 ... 7) Source of error: – Bit 0: valve – Bit 1: output – Bit 2: input – Bit 3: analogue/function module Type of error: – Bit 4: undervoltage – Bit 5: short circuit/overload – Bit 6: wire break – Bit 7: other error	(bit 0 ... 7)	1936	74F7 <sub>H</sub> – byte 0
Module number and diagnostic status	(bit 0 ... 6)	1937	74F7 <sub>H</sub> – byte 1
Error number	(bit 0 ... 7)	1938	74F7 <sub>H</sub> – byte 2



## A. Technical appendix

### A.4.6 Module diagnostics data

<b>Module diagnostics data</b>	<b>Module no.</b>	<b>Function no.</b>	<b>PCP index</b>
Number of the faulty channel: byte 0	0	2008 ... 2011	7532 <sub>H</sub> – byte 0 ... 3
Module error number: byte 1	1	2012 ... 2015	7542 <sub>H</sub> – byte 0 ... 3
Information 2 (reserved): byte 2	2	2016 ... 2019	7552 <sub>H</sub> – byte 0 ... 3
Information 3 (reserved): byte 3	3	2020 ... 2023	7562 <sub>H</sub> – byte 0 ... 3
	4	2024 ... 2027	7572 <sub>H</sub> – byte 0 ... 3
	5	2028 ... 2031	7582 <sub>H</sub> – byte 0 ... 3
	6	2032 ... 2035	7592 <sub>H</sub> – byte 0 ... 3
	7	2036 ... 2039	75A2 <sub>H</sub> – byte 0 ... 3
	8	2040 ... 2043	75B2 <sub>H</sub> – byte 0 ... 3
	9	2044 ... 2047	75C2 <sub>H</sub> – byte 0 ... 3
	10	2048 ... 2051	75D2 <sub>H</sub> – byte 0 ... 3
	11	2052 ... 2055	75E2 <sub>H</sub> – byte 0 ... 3
	12	2056 ... 2059	75F2 <sub>H</sub> – byte 0 ... 3
	13	2060 ... 2063	7602 <sub>H</sub> – byte 0 ... 3
	14	2064 ... 2067	7612 <sub>H</sub> – byte 0 ... 3
	15	2068 ... 2071	7622 <sub>H</sub> – byte 0 ... 3
	16	2072 ... 2075	7632 <sub>H</sub> – byte 0 ... 3
	17	2076 ... 2079	7642 <sub>H</sub> – byte 0 ... 3
	...	...	...

## A. Technical appendix

### A.4.7 System data

<b>System data</b>	<b>Function no.</b>	<b>PCP index</b>
CPX operating mode (bit 0 ... 3) CPX expansion (bit 4) Handheld (bit 5) Force mode (bit 6) System start (bit 7)	0	74F4 <sub>H</sub> – byte 0
Fail safe (bit 0, 1)	1	74F4 <sub>H</sub> – byte 1
Monitoring CPX terminal (bit 0 ... 7)	2	74F4 <sub>H</sub> – byte 2

### A.4.8 Module data

<b>Module data</b>	<b>Module no.</b>	<b>Function no.</b>	<b>PCP index</b>
Module code: byte 0 Revision code: byte 13	0	16, 29	7530 <sub>H</sub> – byte 0, 13
	1	32, 45	7540 <sub>H</sub> – byte 0, 13
	2	48, 61	7550 <sub>H</sub> – byte 0, 13
	3	64, 77	7560 <sub>H</sub> – byte 0, 13
	4	80, 93	7570 <sub>H</sub> – byte 0, 13
	5	96, 109	7580 <sub>H</sub> – byte 0, 13
	6	112, 125	7590 <sub>H</sub> – byte 0, 13
	7	128, 141	75A0 <sub>H</sub> – byte 0, 13
	8	144, 157	75B0 <sub>H</sub> – byte 0, 13
	9	160, 173	75C0 <sub>H</sub> – byte 0, 13
	10	176, 189	75D0 <sub>H</sub> – byte 0, 13
	11	192, 205	75E0 <sub>H</sub> – byte 0, 13
	12	208, 221	75F0 <sub>H</sub> – byte 0, 13
	13	224, 237	7600 <sub>H</sub> – byte 0, 13
	14	240, 253	7610 <sub>H</sub> – byte 0, 13
	15	256, 269	7620 <sub>H</sub> – byte 0, 13
	16	272, 285	7630 <sub>H</sub> – byte 0, 13
	17	288, 301	7640 <sub>H</sub> – byte 0, 13
...	...	...	

A. Technical appendix

<b>Module data</b>	<b>Module no.</b>	<b>Function no.</b>	<b>PCP index</b>
Serial number: byte 0 ... 3	0	784 ... 787	7531 <sub>H</sub> - byte 0 ... 3
	1	788 ... 791	7541 <sub>H</sub> - byte 0 ... 3
	2	792 ... 795	7551 <sub>H</sub> - byte 0 ... 3
	3	796 ... 799	7561 <sub>H</sub> - byte 0 ... 3
	4	800 ... 803	7571 <sub>H</sub> - byte 0 ... 3
	5	804 ... 807	7581 <sub>H</sub> - byte 0 ... 3
	6	808 ... 811	7591 <sub>H</sub> - byte 0 ... 3
	7	812 ... 815	75A1 <sub>H</sub> - byte 0 ... 3
	8	816 ... 819	75B1 <sub>H</sub> - byte 0 ... 3
	9	820 ... 823	75C1 <sub>H</sub> - byte 0 ... 3
	10	824 ... 827	75D1 <sub>H</sub> - byte 0 ... 3
	11	828 ... 831	75E1 <sub>H</sub> - byte 0 ... 3
	12	832 ... 835	75F1 <sub>H</sub> - byte 0 ... 3
	13	836 ... 839	7601 <sub>H</sub> - byte 0 ... 3
	14	840 ... 843	7611 <sub>H</sub> - byte 0 ... 3
	15	844 ... 847	7621 <sub>H</sub> - byte 0 ... 3
	16	848 ... 851	7631 <sub>H</sub> - byte 0 ... 3
	17	852 ... 855	7641 <sub>H</sub> - byte 0 ... 3
	...	...	...

### A.4.9 Length of the PCP data objects

PCP index	Name	PCP name <sup>1)</sup>	Length	Access <sup>2)</sup>	Function number
74F4 <sub>H</sub>	System data	g_sys_conf	16 bytes	r	0 ... 2
74F5 <sub>H</sub>	System parameters	g_sys_param	8 bytes	r/w	4400 ... 4402
74F7 <sub>H</sub>	System diagnostics data	g_sys_diag	8 bytes	r	1936 ... 1938
74F8 <sub>H</sub>	Diagnostic memory parameters and data	g_sys_sdt	8 bytes	r/w	3480 ... 3487
74F9 <sub>H</sub>	Diagnostic memory data, entry 0	diag_trc0	10 bytes	r	3488 ... 3497
74FA <sub>H</sub>	Diagnostic memory data, entry 1	diag_trc1	10 bytes	r	3498 ... 3507
...	...	...	...	...	...
7520 <sub>H</sub>	Diagnostic memory data, entry 39	diag_trc39	10 bytes	r	3878 ... 3887
7525 <sub>H</sub>	Delete diagnostics trace	del_dt	2 bytes	w	-
7530 <sub>H</sub> , 7540 <sub>H</sub> , ...	Module data, module n <sup>3)</sup>	m_conf_n <sup>3)</sup>	each 16 bytes	r	(16 + n*16), (29 + n*16) <sup>3)</sup>
7531 <sub>H</sub> , 7541 <sub>H</sub> , ...	Module data (serial number), module n <sup>3)</sup>	m_serno_n <sup>3)</sup>	each 4 bytes	r	(784 + n*4) ... (787 + n*4) <sup>3)</sup>
7532 <sub>H</sub> , 7542 <sub>H</sub> , ...	Module diagnostics data, module n <sup>3)</sup>	m_diag_n <sup>3)</sup>	each 4 bytes	r	(2008 + n*4) ... (2011 + n*4) <sup>3)</sup>
7535 <sub>H</sub> , 7545 <sub>H</sub> , ...	Module parameter, module n <sup>3)</sup>	m_paramw_n <sup>3)</sup>	each 64 bytes	r/w	(4828 + n*64) ... (4837 + n*64) <sup>3)</sup>

<sup>1)</sup> PCP name shown via the service "Get\_OD"

<sup>2)</sup> Access: r = read, w = write

<sup>3)</sup> n = module number

## A. Technical appendix

PCP index	Name	PCP name <sup>1)</sup>	Length	Access <sup>2)</sup>	Function number
7539 <sub>H</sub> , 7549 <sub>H</sub> , ...	Fault mode, module n <sup>3)</sup>	m_ftmo_n <sup>3)</sup>	each 64 bytes	r/w	-
753A <sub>H</sub> , 754A <sub>H</sub> , ...	Fault state, module n <sup>3)</sup>	m_ftst_n <sup>3)</sup>	each 64 bytes	r/w	-
753B <sub>H</sub> , 754B <sub>H</sub> , ...	Force mode outputs, module n <sup>3)</sup>	m_frcmoa_n <sup>3)</sup>	each 64 bytes	r/w	-
753C <sub>H</sub> , 754C <sub>H</sub> , ...	Force state outputs, module n <sup>3)</sup>	m_frcsta_n <sup>3)</sup>	each 64 bytes	r/w	-
753D <sub>H</sub> , 754D <sub>H</sub> , ...	Force mode inputs, module n <sup>3)</sup>	m_frcmoe_n <sup>3)</sup>	each 64 bytes	r/w	-
753E <sub>H</sub> , 754E <sub>H</sub> , ...	Force state inputs, module n <sup>3)</sup>	m_frcste_n <sup>3)</sup>	each 64 bytes	r/w	-
<p>1) PCP name shown via the service “Get_OD”                  2) Access: r = read, w = write                  3) n = module number</p>					

## A. Technical appendix

# Index

## Appendix B

B. Index

**B. Index ..... B-1**



## Index

### A

Abbreviations, Product-specific .....	XII
Accessories .....	A-5
Additional power supply .....	1-24
Address assignment .....	2-14
Addressing .....	2-27
Logical .....	2-38
Siemens mode .....	2-15
Standard mode .....	2-15

### B

Baud rate .....	1-11
Bus configuration .....	2-27

### C

Cable, Fieldbus .....	1-21
CEC .....	2-7, 2-42
CMD software .....	2-29, 2-39
Connecting	
Fieldbus .....	1-14, 1-18
Power supply .....	1-23
CP interface .....	2-7
CPA pneumatics .....	2-8
CPX-CEC .....	2-7, 2-42
CPX-FEC .....	2-7, 2-42

### D

Diagnostics mode .....	1-13
------------------------	------

DIL switch .....	1-7
Dismantling .....	1-5

## **E**

Electrical connection and display components .....	1-4
Error message, hide .....	3-19

## **F**

FEC .....	2-7, 2-42
Fibre-optic cable (FOC) connection .....	1-22
Fieldbus baud rate .....	1-21
Fieldbus cable .....	1-21
Fieldbus length .....	1-21
Fieldbus plug .....	1-18

## **I**

I/O diagnostics interface .....	3-15
Inputs, Calculating the number .....	2-13
Instructions on the description .....	IX
Intended use .....	V
Interbus	
Addressing .....	2-27
Bus configuration .....	2-27, 2-29, 2-38
Interbus data words .....	1-13
ISO pneumatics (VTSA) .....	2-8

## **L**

LEDs .....	3-6
------------	-----

## M

M12 connection block .....	1-20
Midi/Maxi pneumatics .....	2-8
Mounting .....	1-5

## O

Operating mode .....	1-8, 2-42
Outputs, Calculating the number .....	2-13

## P

PCP channel .....	1-9, A-7
PELV .....	1-23
Peripheral fault mode .....	1-10
Peripheral faults (PF) .....	3-18
Pictograms .....	VIII
Pin assignment, Fieldbus interface .....	1-17
Power supply .....	1-23
Switching on .....	2-28
Power supply unit .....	1-23

## R

Remote bus	
Connection .....	1-16
floating .....	1-16
System structure .....	1-14
Remote controller .....	1-8, 2-42
Remote I/O .....	1-8
Reverse Key .....	1-20

## S

Screened connection .....	1-19
Service .....	VI
Setting	
Baud rate .....	1-11
Diagnostics mode .....	1-13
Interbus data words .....	1-13
Operating mode .....	1-8
PCP channel .....	1-9
Peripheral fault mode .....	1-10
Status bits .....	3-13
Strain relief .....	1-21
System power supply .....	1-24

## T

Target group .....	VI
Technical data .....	A-3
Text designations .....	VIII

## U

User instructions .....	VII
-------------------------	-----

## V

Valve power supply .....	1-24
VTSA pneumatics (ISO) .....	2-8