


# **CMT56118 / IDAN-CMT56118**

## **CompactFlash Carrier**

### **utilityModules**

## **User's Manual**



RTD Embedded Technologies, Inc.

*"Accessing the Analog World"®*

BDM-610020063  
Rev. B

ISO9001 and AS9100 Certified



---

---

**CMT56118 / IDAN-CMT56118**  
**CompactFlash Carrier utilityModules**  
**User's Manual**

---

---



**RTD Embedded Technologies, Inc.**

103 Innovation Blvd.

State College, PA 16803-0906

Phone: +1-814-234-8087

FAX: +1-814-234-5218

E-mail

[sales@rtd.com](mailto:sales@rtd.com)

[techsupport@rtd.com](mailto:techsupport@rtd.com)

web site

[www.rtd.com](http://www.rtd.com)

## Revision History

Rev. A	New Manual
Rev. B	<p>Renamed manual to include "IDAN-CMT56118" in title.</p> <p>Correct drawings and designators to match PCB revisions 160002451BB (CMT56118).</p> <p>Removed references to 80-conductor cable; the board is designed to use only 40-conductor cables when cabling to off-board IDE devices.</p> <p>Noted that hot-swapping CompactFlash devices is not supported.</p> <p>Add a bullet to describe the purpose of the retention bracket.</p> <p>Add a chapter to describe the features of the IDAN-CMT56118.</p> <p>Describe CMT56118 and IDAN-CMT56118 configuration jumpers.</p> <p>Described the features provided by the Multifunction Connector (PC speaker, battery, ATX push button, system reset button, keyboard, and Bus Mouse)</p> <p>Reorganized chapters so the chapter on connecting is before the chapter on configuring.</p> <p>Add dimensional drawing for the IDAN-CMT56118HRS.</p>

Published by:

RTD Embedded Technologies, Inc.  
103 Innovation Blvd.  
State College, PA 16803-0906

Copyright 2007-2009 RTD Embedded Technologies, Inc.

All rights reserved

Printed in U.S.A.

The RTD Logo is a registered trademark of RTD Embedded Technologies. cpuModule and utilityModule are trademarks of RTD Embedded Technologies. MS-DOS, Windows, Windows 95, Windows 98 and Windows NT are trademarks of Microsoft Corp. PC/104 is a registered trademark of PC/104 Consortium. All other trademarks appearing in this document are the property of their respective owners.



# TABLE OF CONTENTS

<b>CHAPTER 1 INTRODUCTION.....</b>	<b>1</b>
CMT56118 COMPACTFLASH CARRIER UTILITYMODULE .....	1
FEATURES.....	2
CONNECTORS .....	2
RECOMMENDED CABLES .....	2
GENERAL SPECIFICATIONS.....	2
<b>CHAPTER 2 INSTALLING THE UTILITYMODULE.....</b>	<b>3</b>
RECOMMENDED PROCEDURE .....	3
<b>CHAPTER 3 CONNECTING THE UTILITYMODULE .....</b>	<b>4</b>
CONNECTOR AND JUMPER LOCATIONS .....	4
COMPACTFLASH CONNECTOR, CN3 (CN1 - IDAN-CMT56118 ONLY).....	5
EIDE STACK-THROUGH CONNECTOR, CN4.....	5
EIDE CABLE CONNECTOR, CN5 .....	6
KEYBOARD AND PUSH-BUTTON RESET, JP2.....	7
BUS MOUSE, JP3 .....	8
MULTIFUNCTION CONNECTOR, JP4 .....	8
ATX POWER BUTTON, JP5.....	9
BATTERY, BAT1 (FACTORY INSTALLED) .....	9
SOLDER JUMPER, B5 (TO BYPASS BATTERY PROTECTION DIODE).....	9
PC SPEAKER, SPK1 (FACTORY INSTALLED).....	9
<b>CHAPTER 4 CONFIGURING THE UTILITYMODULE .....</b>	<b>10</b>
CF VOLTAGE SELECT JUMPER, JP7 (JP9 – IDAN-CMT56118 ONLY) .....	10
MASTER/SLAVE SELECTION JUMPER, JP8.....	10
CONNECTING EXTERNAL IDE DEVICES .....	11
<b>CHAPTER 5 IDAN-CMT56118 .....</b>	<b>12</b>
CONNECTOR AND JUMPER LOCATIONS .....	12
<b>CHAPTER 6 IDAN-CMT56118HRS .....</b>	<b>14</b>
DIMENSIONAL DRAWING .....	15
<b>CHAPTER 7 GETTING TECHNICAL SUPPORT .....</b>	<b>16</b>
<b>LIMITED WARRANTY.....</b>	<b>17</b>

## Chapter 1 INTRODUCTION


This manual gives information on the CMT56118 CompactFlash Carrier utilityModule. This module attaches to the EIDE interface connector of RTD cpuModules, allowing a high speed CompactFlash drive interface.

### ***CMT56118 CompactFlash Carrier utilityModule***

The CMT56118 utilityModule was designed to provide a CompactFlash drive in a stack when used as a companion to RTD's family of cpuModules that have integrated EIDE controllers. It is very similar in function to the CMT56106.

**Note:** The CMT56118 is not an IDE controller - It is a drive carrier. The CMT56118 must be used with a cpuModule that has an on-board IDE controller.

**Warning:** Because the CompactFlash connector uses an ATA/IDE interface, hot-swapping is not supported.



**Figure 1.1 CMT56118 with Retention Bracket**

## **Features**

The following are major features of the CMT56118 utilityModule.

- Provides a drive interface up to UDMA Mode 2 (Ultra ATA/33) if supported by the cpuModule
- A standard +3.3V or +5V CompactFlash drive can be mounted directly onto the module
- An optional retention bracket provides a mechanism to prevent unwanted removal of the CompactFlash device
- A 0.1" 40-pin connector is provided to connect to a second drive, i.e. a CD-ROM drive.
- A stack-through connector is provided to allow for the combination of multiple boards from the CMT56118, CMT36106, and CMT56106 utilityModule families in one system.

## **Connectors**

Connectors provided are:

- CN3: CompactFlash drive connector
- CN4: EIDE stack-through connector
- CN5: EIDE cable connector

## **Recommended Cables**

A 40-conductor EIDE cable can be used to connect an external drive (hard drive or CD-ROM drive) to connector CN5 on the CMT56118.

## **General Specifications**

The following operating conditions do not apply to the CompactFlash drive and may be limited by the IDE controller of the cpuModule

- Operating temperature: -40 to +85°C
- Relative humidity: 0 - 95%, non-condensing
- Storage temperature: -55 to +125°C



## Chapter 2 INSTALLING THE UTILITYMODULE

---

Since the utilityModule uses an EIDE stack-through bus, it must be stacked directly above the cpuModule.

### ***Recommended Procedure***

We recommend you follow the procedure below to ensure that stacking of the modules does not damage connectors or electronics.

- Turn off power to the PC/104-*Plus* or PCI-104 system or stack.
- Select and install standoffs to properly position the utilityModule on the PC/104-*Plus* or PCI-104 stack.
- Touch a grounded metal part of the stack to discharge any buildup of static electricity.
- Remove the utilityModule from its anti-static bag.
- Verify the jumper settings of the utilityModule.
- Hold the utilityModule by its edges and orient it so the bus connector pins line up with the matching connector on the stack.
- Gently and evenly press the utilityModule onto the stack.

---

**CAUTION: Do not force the module onto the stack!** Wiggling the module or applying too much force may damage it. If the module does not readily press into place, remove it, check for bent pins or out-of-place keying pins, and try again.

---

## Chapter 3 CONNECTING THE UTILITYMODULE

The following sections describe the connectors and jumpers of the utilityModule.

### Connector and Jumper Locations

A white area silk-screened on the top side of the PC board indicates where pin 1 is located on the connectors. A square solder pad visible on the bottom of the PC board also shows where pin 1 is located. Make certain pin 1 is correctly identified before connecting to it. The connector locations of the CMT56118 are shown below.




Figure 3.1 CMT56118 Connector and Jumper Locations

<b>CMT56118</b>		
<b>Top Side Connectors and Jumpers</b>		
<b>Designator</b>	<b>Function</b>	<b>Size</b>
CN3	CompactFlash Connector	50 pin
CN4	EIDE Stack-through Connector	44 pin
CN5	EIDE Cable Connector	40 pin
JP2	Keyboard and Push-Button Reset	6 pin
JP3	Bus Mouse	4 pin
JP4	Multifunction Connector	10 pin
JP5	ATX Power Switch Connector	2 pin
JP7	CompactFlash voltage selection	3 pin
JP8	CompactFlash master/slave selection	3 pin
SPK1	PC Speaker (Factory Installed)	2 pin
BAT1	Battery (Factory Installed)	2 pin
<b>CMT56118</b>		
<b>Bottom Side Connectors and Jumpers</b>		
<b>Designator</b>	<b>Function</b>	<b>Size</b>
B5	Solder Jumper (to bypass battery protection diode)	2 pin

## ***CompactFlash Connector, CN3 (CN1 - IDAN-CMT56118 only)***

Connector CN3 supports +3.3V and +5V CompactFlash devices. For information on configuring the supply voltage and master/slave setting of a device installed in the connector, refer to Chapter 4 .

---

**Warning:** Because the CompactFlash connector uses an ATA/IDE interface, hot-swapping is not supported.

**Note:** In addition to CN3, the IDAN-CMT56118 (described in Chapter 5 ) has a second CompactFlash connector (CN1) which also supports +3.3V and +5V CompactFlash devices.

---

## ***EIDE Stack-through Connector, CN4***

The EIDE stack-through connector is a 44-pin 2mm DIL connector. The pin connections of this connector are shown below.

<b>EIDE Hard Drive Connector, CN3</b>			
<b>Pin</b>	<b>Signal</b>	<b>Function</b>	<b>in/out</b>
1	RESET*	Reset HD	out
2	GND	Ground signal	--
3	HD7	HD data 7	in/out
4	HD8	HD data 8	in/out
5	HD6	HD data 6	in/out
6	HD9	HD data 9	in/out

7	HD5	HD data 5	in/out
8	HD10	HD data 10	in/out
9	HD4	HD data 4	in/out
10	HD11	HD data 11	in/out
11	HD3	HD data 3	in/out
12	HD12	HD data 12	in/out
13	HD2	HD data 2	in/out
14	HD13	HD data 13	in/out
15	HD1	HD data 1	in/out
16	HD14	HD data 14	in/out
17	HD0	HD data 0	in/out
18	HD15	HD data 15	in/out
19	GND	Ground signal	--
20	n.c.		--
21	AEN	Address Enable	out
22	GND	Ground signal	--
23	IOW*	I/O Write	out
24	GND	Ground signal	--
25	IOR*	I/O Read	out
26	GND	Ground signal	--
27	IOCHRDY	I/O Channel Ready	in
28	BALE	Bus Address Latch Enable	out
29	n.c.		
30	GND	Ground signal	--
31	IRQ	Interrupt Request	in
32	IOCS16*	16 bit transfer	in
33	A1	Address 1	out
34	GND	Ground signal	--
35	A0	Address 0	out
36	A2	Address 2	out
37	HCS0*	HD Select 0	out
38	HCS1*	HD Select 1	out
39	LED	HDD activity LED (-)	in
40	GND	Ground signal	--
41	+5V	Logic Power	Pwr
42	+5V	Motor Power	Pwr
43	GND	Power Ground	--
44	n.c.		

## ***EIDE Cable Connector, CN5***

The EIDE cable connector is a 40-pin 0.1" DIL connector. The pin out of this connector is the same as pins 1-40 of CN3.

## Keyboard and Push-Button Reset, JP2

The Keyboard and Push-Button Reset connectors provide the following features which may be cabled to the cpuModule via the Multifunction Connector (JP4):

- AT keyboard
- System reset input

The following table gives the pinout of JP2.

Keyboard and Push-Button Reset, JP2			
Pin	Signal	Function	Input/Output
1	KBP_SPKR-	Keyboard Power (+5V)	Output
2	CPU_GND	CPU Ground	--
3	KBD	Keyboard Data	Input
4	KBC	Keyboard Clock	Output
5	RESET*	Manual push button reset	Input
6	CPU_GND	CPU Ground	--

### Keyboard

An AT compatible keyboard can be connected to JP2. Usually PC keyboards come with a cable ending with a 5-pin male PS/2 connector. The following table lists the relationship between the pins on JP2 and a standard PS/2 keyboard connector.

Keyboard Connector Pins on JP2			
JP2	Signal	Function	PS/2
1	KBP_SPKR-	Keyboard Power (+5 Volts)	4
2	CPU_GND	CPU Ground	3
3	KBD	Keyboard Data	1
4	KBC	Keyboard Clock	5

### System Reset

Pin 5 of JP2 allows connection of an external push-button to manually reset the system. The push-button should be normally open, and connect to ground when pushed.

## Bus Mouse, JP3

The Bus Mouse connector provides an input for connecting a mouse to the system. The Bus Mouse may be routed to the cpuModule by running a cable from the Multifunction Connector (JP4).

Facing the connector pins, the pinout of JP3 is:

Bus Mouse, JP3			
Pin	Signal	Function	Input/Output
1	KBP_SPKR-	Speaker output (+5V)	Output
2	CPU_GND	CPU Ground	--
3	MCLK	Mouse Clock	Output
4	MDATA	Mouse Data	Input/Output

## Multifunction Connector, JP4

The Multifunction Connector may be used to cable the following CMT56118 functions to the cpuModule:

- Speaker
- AT Keyboard
- Bus Mouse
- System Reset
- Battery
- ATX Power Button

---

**Note:** If a cable is not connected to the Multifunction Connector, the features listed above are unused by the system.

---

The following table gives the pinout of JP4.

Multifunction Connector, JP4			
Pin	Signal	Function	Input/Output
1	SPKR+	Speaker output (open collector)	Input
2	KBP_SPKR-	Speaker output (+5V)	Input
3	RESET*	Manual push button reset	Output
4	PWR_BUTTON	ATX Power Button	Output
5	KBD	Keyboard Data	Output
6	KBC	Keyboard Clock	Input
7	CPU_GND	CPU Ground	--
8	MCLK	Mouse Clock	Input
9	BAT+	Battery output	Output
10	MDATA	Mouse Data	Input/Output

## **ATX Power Button, JP5**

The ATX power button input may be routed to the cpuModule by running a cable from the Multifunction Connector (JP4). The push-button should be normally open, and connect to ground when pushed.

<b>Power Button, JP5</b>			
<b>Pin</b>	<b>Signal</b>	<b>Function</b>	<b>Input/Output</b>
1	GND	Ground	--
2	PWR_BUTTON	Soft Power Button	Input

## **Battery, BAT1 (Factory Installed)**

Connection BAT1 on the CMT56118 is the system connection for a backup battery (in the range 2.40 V to 4.15 V; typically 3.0 or 3.6 V). The battery may be routed to the cpuModule by running a cable from the Multifunction Connector (JP4). Consult the cpuModule's hardware manual for how it uses the battery.

<b>Battery, BAT1</b>			
<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
1	Battery +	2	Battery -

## **Solder Jumper, B5 (to bypass battery protection diode)**

To bypass the onboard battery protection diode, short pins one and two of solder jumper B5.

## **PC Speaker, SPK1 (Factory Installed)**

A speaker is available on pins 1 and 2 of SPK1. The speaker may be routed to the cpuModule by running a cable from the Multifunction Connector (JP4)

These outputs are controlled by a transistor to supply 0.1 watt of power to an external speaker. The factory installed speaker has an impedance of 8 ohms and is connected between pins 1 and 2.

<b>PC Speaker, SPK1</b>			
<b>Pin</b>	<b>Signal</b>	<b>Function</b>	<b>Input/Output</b>
1	SPKR+	Speaker Output (open collector)	Output
2	KBP_SPKR-	Speaker output (+5 volts)	Output

## Chapter 4 CONFIGURING THE UTILITYMODULE

---

The following sections contain information on configuring the utilityModule.

---

**Important:** The EIDE bus connection on the CMT56118 which provides the electrical connections to the CompactFlash connector (CN3) and the EIDE cable connector (CN5) connects to the CPU's IDE controller via the EIDE stack-through connector (CN4). While this IDE channel connection supports multiple boards, up to two storage devices (e.g., CompactFlash cards, 2.5" disk drives, IDE drives, CD-ROM drives, ATA/IDE Disk Chip) are permitted throughout this electrical bus.

To prevent a conflict with a device already on the bus, it is important to know the number of devices already residing on the bus, as well as their master/slave configuration.

---

### ***CF Voltage Select Jumper, JP7 (JP9 – IDAN-CMT56118 only)***

Jumper JP7 is a 3-pin jumper used to select the supply voltage for the CompactFlash device residing in connector CN3.

To configure the operating voltage for 3.3V, set JP7 to close pins 1-2. To configure the operating voltage for 5V, set JP7 to close pins 2-3.

---

**Note:** The IDAN-CMT56118 (described in Chapter 5 ) has a second jumper (JP9) to configure the CF supply voltage of a second CompactFlash connector (CN1). The jumper behaves the same as JP7, with the same pinout.

---

### ***Master/Slave Selection Jumper, JP8***

Jumper JP7 is a 3-pin jumper used to configure the CompactFlash device in connector CN3 such that it does not conflict with another device connected to the system's EIDE stack-through connector. The bus should have only one master and one slave device.

To set the CompactFlash card as the master, close pins 1-2 of JP8. To set the CompactFlash card as the slave, close pins 2-3.

---

**Note:** The IDAN-CMT56118 (described in Chapter 5 ) is designed such that when one of the CF sockets is configured as master, the other is configured as slave. JP8 may be set as follows:

Close pins 1-2: CN1 master, CN3 slave  
Close pins 2-3: CN3 master, CN1 slave

---



## ***Connecting External IDE Devices***

External EIDE drives such as additional hard drive or CD-ROM drive can be connected to CN5 of the CMT56118 with an IDE cable. Only 40-conductor IDE cables are supported, which permit transfer speeds of up to UDMA Mode 2 (Ultra ATA/33).

When connecting an external drive to the CMT56118, the device's master/slave jumper must be configured such that it does not conflict with the master/slave setting of any other device connected to the system's EIDE stack-through connector (for example, the CompactFlash connector, when a CF card is present in the socket).

## Chapter 5 IDAN-CMT56118

A variation of the CMT56118 called the IDAN-CMT56118 is also available which offers two CompactFlash connectors. Unlike the CMT56118, it does not include a multifunction connector, battery, or speaker.

### Connector and Jumper Locations

A white area silk-screened on the top side of the PC board indicates where pin 1 is located on the connectors. A square solder pad visible on the bottom of the PC board also shows where pin 1 is located. Make certain pin 1 is correctly identified before connecting to it. The connector locations of the IDAN-CMT56118 are shown below.




Figure 5.1 IDAN-CMT56118 Connector Locations

<b>IDAN-CMT56118HRS</b>			
<b>Top Side Connectors and Jumpers</b>			
<b>Designator</b>	<b>Function</b>	<b>Size</b>	<b>Reference Chapter</b>
CN1	CompactFlash Connector (Externally Removable)	50 pin	Chapter 3
CN3	CompactFlash Connector (Internal Socket with CF Retainer)	50 pin	Chapter 3
CN4	EIDE Stack-through Connector	44 pin	Chapter 3
CN5	EIDE Cable Connector	40 pin	Chapter 3
JP7	CompactFlash voltage selection for CN3	3 pin	Chapter 4
JP8	CompactFlash master/slave selection	3 pin	Chapter 4
JP9	CompactFlash voltage selection for CN1	3 pin	Chapter 4

## Chapter 6 IDAN-CMT56118HRS

---

To purchase the IDAN-CMT56118 in a single height IDAN frame as shown below, the ordering model number is IDAN-CMT56118HRS.



**Figure 6.1 IDAN-CMT56118HRS Top View**



**Figure 6.2 IDAN-CMT56118HRS Front View**

# Dimensional Drawing

The figure below shows the dimensional drawings of the IDAN-CMT56118HRS.




Figure 6.3 IDAN-CMT56118HRS Dimensional Drawing

## Chapter 7 GETTING TECHNICAL SUPPORT

---

For help with this product, or any other product made by RTD, you can contact RTD Embedded Technologies via the following methods:

- Phone: +1-814-234-8087
- E-Mail: techsupport@rtd.com

Be sure to check the RTD web site (<http://www.rtd.com>) frequently for product updates, including newer versions of the board manual and application software.

---

## LIMITED WARRANTY

---

RTD Embedded Technologies, Inc. warrants the hardware and software products it manufactures and produces to be free from defects in materials and workmanship for one year following the date of shipment from RTD Embedded Technologies, INC. This warranty is limited to the original purchaser of product and is not transferable.

During the one year warranty period, RTD Embedded Technologies will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to RTD Embedded Technologies. All replaced parts and products become the property of RTD Embedded Technologies. Before returning any product for repair, customers are required to contact the factory for an RMA number.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCTS WHICH HAVE BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE (such as: use of incorrect input voltages, improper or insufficient ventilation, failure to follow the operating instructions that are provided by RTD Embedded Technologies, "acts of God" or other contingencies beyond the control of RTD Embedded Technologies), OR AS A RESULT OF SERVICE OR MODIFICATION BY ANYONE OTHER THAN RTD Embedded Technologies. EXCEPT AS EXPRESSLY SET FORTH ABOVE, NO OTHER WARRANTIES ARE EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND RTD Embedded Technologies EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED HEREIN. ALL IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES FOR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS WARRANTY. IN THE EVENT THE PRODUCT IS NOT FREE FROM DEFECTS AS WARRANTED ABOVE, THE PURCHASER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. UNDER NO CIRCUMSTANCES WILL RTD Embedded Technologies BE LIABLE TO THE PURCHASER OR ANY USER FOR ANY DAMAGES, INCLUDING ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOST PROFITS, LOST SAVINGS, OR OTHER DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, AND SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

RTD Embedded Technologies, Inc.

103 Innovation Blvd.

State College PA 16803-0906

USA

Our website: [www.rtd.com](http://www.rtd.com)

Techsupport: [techsupport@rtd.com](mailto:techsupport@rtd.com)

(814) 234-4626