

# Keysight Technologies N5261A and N5262A

## User's and Service Guide

Notice: This document contains references to Agilent. Please note that Agilent's Test and Measurement business has become Keysight Technologies. For more information, go to [www.keysight.com](http://www.keysight.com).

Millimeter Head  
Controller

## Notices

© Keysight Technologies 2008-2014

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

### Manual Part Number

N5262-90001

### Print Date

September 2014

Supersede: December 2013

Published in USA

Keysight Technologies Inc.  
1400 Fountaingrove Parkway  
Santa Rosa, CA 95403

### Where to Find the Latest Information

Documentation is updated periodically. For the latest information about these products, including instrument software upgrades, application information, and product information, browse to the following URL, search for the name of your product:

<http://www.keysight.com/find>

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

### Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

## Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

## Safety Notices

### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

### WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

---

# Table of Contents

## 1. Installation & System Operation

Introduction	2
Network Analyzer Requirements	2
System Configurations	4
Compatible mm-wave Modules	7
Verifying Your Shipment	9
Option List Information	9
Specifications	15
General Characteristics	15
Cable Loss Between the Test Set and the Module	17
Front Panel Features	18
Rear Panel Features	20
Available Fuses	22
System Configuration and Operation	23
Site Preparation	23
System Setup	24
Rear Panel Connections	27
PNA and PNA-X Front Panel Connections	33
Millimeter-wave Module Cable Connections	34
Configuring the Network Analyzer Firmware	37
System Operation Verification	40
Banded System Check	40
System Level Troubleshooting	44

## 2. Service Information

Test Set Operation Check	2
Preparation	2
Test Set I/O Commands	3
Procedure	5
Theory of Operation	12
Functional Block and Assembly Information	12
Test Set Troubleshooting	15
Power Supply and Fans	15
No DC Power for Millimeter-wave Modules	17
Over Current LEDs are On (amber)	17
Front Panel Active and Port Status LED	17
RF OUT Failures	18
LO Out Failure	19
REF IF or Test IF Failure	19
Test Set Diagrams and Graphics	20
Part Replacement and Location Information	25
Replaceable Parts	25
Test and Adjustment Procedures	30
Gain Factors for the SRC RF Paths	31
Adjust ALC Levels	34
Safety and Information	36
Introduction	36
Safety Earth Ground	36
Declaration of Conformity	36
Statement of Compliance	36
Before Applying Power	37
Connector Care and Cleaning Precautions	38

Regulatory Information .....	39
Instrument Markings .....	39
Battery Collection .....	40
EMC Information .....	40
Acoustic Noise Emission .....	40
Safety .....	40
Electrostatic Discharge Protection .....	41
Agilent Support, Services, and Assistance .....	42
Service and Support Options .....	42
Contacting Agilent .....	42
Shipping Your Product to Agilent for Service or Repair .....	42

---

# **1** Installation & System Operation

## Introduction

This section of this document describes system installation and operation for a banded millimeter-wave system using an N5261A or N5262A Millimeter Head Controller. Banded millimeter-wave systems are made up of three types of major components: a PNA or PNA-X, a controller test set, and millimeter-wave heads. These components are generally purchased separately and assembled into a system at the customer's site. This section of the document focuses on receiving the controller with accessories and then on system installation and operation.

[Table 1-1 on page 4](#) and [Table 1-2 on page 5](#) lists compatible PNA and PNA-X models with required options. [Table 1-3 on page 8](#) and [Table 1-4 on page 8](#) list available millimeter-wave modules. Typical system configurations are pictured in [Figure 1-1 on page 3](#) and [Figure 1-1 on page 3](#).

The N5261A or N5262A Millimeter Head Controller may also be used as part of the N5251A broadband analyzer system. This application is not discussed in this manual. Refer to N5251-90001 for N5251A system information.

In this document the N5261A and N5262A will be referred to as the test set.

This manual should be used in conjunction with the following documents:

- PNA-X Series Network Analyzer On-line Help System
- Millimeter-wave Technical Overview 5989-7620EN
- OML Millimeter-wave modules (N5256-90001)
- VDI Millimeter-wave modules (N5256-90002)
- N5251A Installation and Service Guide (N5251-90001)

---

## Network Analyzer Requirements

The required options for PNA models are indicated in the “PNA Option(s)” column of [Table 1-1](#). The required options for PNA-X models are indicated in the “PNA Option(s)” column of [Table 1-2](#). Note that all models require Option 020.

The minimum firmware revision for PNA models is A.09.42.16. The minimum firmware revision for PNA-X models is A.09.33.09.

Figure 1-1 2-Port Banded Millimeter-wave Configuration (N5261A)



Figure 1-2 4-Port Banded Millimeter-wave Configuration (N5262A)



## System Configurations

Table 1-1 and Table 1-2 document all supported configurations for S-Parameter measurement capabilities for banded mm-wave systems using the N5261A and N5262A test sets.

**NOTE** Capabilities: [C1]=pulse, [C2]=power control/RCVR leveling, [C3]=SMC+phase, [C4]=SPM, [C5]=ITSMA

**Table 1-1 PNA Based Configurations**

PNA Model (s)	PNA Options <sup>a</sup>	Test Set	SRC Connects	Ck <sup>b</sup>	Cable Interface Kit	Cable Config. Diag(s) <sup>c</sup>	Capabilities and Notes
N5222A	200, 201 or 219	N5261A	front	n	N5261A-102	A Y	[C1,C2,C3,C4_]
		N5262A	front	n	N5262A-102	B V	[C1,C2_C4,_] <sup>d</sup>
	400, 401 or 419	N5261A	front	n	N5261A-104	A Z	[C1,C2,C3,C4_]
		N5262A	front	n	N5262A-104	B X	[C1,C2,C3,C4,C5]
N5224/5A	200, 201 or 219	N5261A	front	n	N5261A-112	A Y	[C1,C2,C3,C4_]
		N5262A	front	n	N5262A-112	B V	[C1,C2_C4,_] <sup>d</sup>
	400, 401 or 419	N5261A	front	n	N5261A-114	A Z	[C1,C2,C3,C4_]
		N5262A	front	n	N5262A-114	B X	[C1,C2,C3,C4,C5]
N5227A	200, 201 or 219	N5261A	front	n	N5261A-112	A Y	[C1,C2,C3,C4_]
			rear	y	N5261A-112	E	[C1,C2,C3,C4_]
		N5262A	front	n	N5262A-112	B V	[C1,C2_C4,_] <sup>d</sup>
			rear		xxxxxx	xxx	config not available
	400, 401 or 419	N5261A	front	n	N5261A-114	A Z	[C1,C2,C3,C4_]
			rear	y	N5261A-114	E	[C1,C2,C3,C4_]
		N5262A	front	n	N5262A-114	B X	[C1,C2,C3,C4,C5]
			rear	y	N5262A-114	F	[C1,C2,C3,C4,C5]

- All PNA's require Option 020. When an N5262A is used with a 2-Port PNA, Option 551 is required.
- Condition of the Route PNA RF to rear panel "RF OUT" check box. n = not checked, y = check. Refer to [step 9 on page 40](#).
- See [Figure 1-15](#) through [Figure 1-22](#) for the configuration diagrams.
- Can only drive output on one port at a time in this configuration.

**Table 1-2 PNA-X Based Configurations**

PNA-X Model (s)	PNA Option(s) <sup>a</sup>	Test Set	SRC Connects	C <sub>k</sub> <sup>b</sup>	Cable Interface Kit	Cable Config. Diag(s) <sup>c</sup>	Capabilities and Notes
N5242A	200	N5261A	front	n	N5261A-102	A Y	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-102	B V	[C1,C2,___C4,___] <sup>d</sup>
	200 & 224	N5261A	front	n	N5261A-102	A Y	[C1,C2,C3,C4,___]
			rear	y	N5261A-102	C	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-102	B W	[C1,C2,C3,C4,___]
			rear	y	N5262A-104	D	[C1,C2,C3,C4,___]
	400	N5261A	front	n	N5261A-104	A Z	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-104	B X	[C1,C2,C3,C4,C5]
	400 & 423	N5261A	front	n	N5261A-104	A Z	[C1,C2,C3,C4,___]
			rear	y	N5261A-104	C	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-104	B X	[C1,C2,C3,C4,C5]
			rear	y	N5262A-104	D	[C1,C2,C3,C4,C5]
N5244/5A	200	N5261A	front	n	N5261A-112	A Y	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-112	B V	[C1,C2,___C4,___] <sup>d</sup>
	200 & 224	N5261A	front	n	N5261A-112	A Y	[C1,C2,C3,C4,___]
			rear	y	N5261A-106	C	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-112	B W	[C1,C2,C3,C4,___]
			rear	y	N5262A-108	D	[C1,C2,C3,C4,___]
	400	N5261A	front	n	N5261A-114	A Z	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-114	B X	[C1,C2,C3,C4,C5]
	400 & 423	N5261A	front	n	N5261A-114	A Z	[C1,C2,C3,C4,___]
			rear	y	N5261A-108	C	[C1,C2,C3,C4,___]
		N5262A	front	n	N5262A-114	B X	[C1,C2,C3,C4,C5]
			rear	y	N5262A-108	D	[C1,C2,C3,C4,C5]

*Continued on Page 6*

Table 1-2 PNA-X Based Configurations

PNA-X Model (s)	PNA Option(s) <sup>a</sup>	Test Set	SRC Connects	CK <sup>b</sup>	Cable Interface Kit	Conn. Diag(s) <sup>c</sup>	Capabilities and Notes
N5247A	200	N5261A	front	n	N5261A-112	A Y	[C1,C2,C3,C4, ]
			rear	y	N5261A-102	E	[C1,C2,C3,C4, ] <sup>e</sup>
		N5262A	front	n	N5262A-112	B V	[C1,C2,C3,C4, ] <sup>d</sup>
			rear		xxxx	xxxx	config not available
	200 & 224	N5261A	front	n	N5261A-112	A Y	[C1,C2,C3,C4, ]
			rear	y	N5261A-102	E	[C1,C2,C3,C4, ] <sup>f</sup>
		N5262A	front	n	N5262A-112	B W	[C1,C2,C3,C4, ]
			rear	y	N5262A-104	F	[C1,C2,C3,C4, ]
	400	N5261A	front	n	N5261A-114	A Z	[C1,C2,C3,C4, ]
			rear	y	N5261A-102	E	[C1,C2,C3,C4, ] <sup>g</sup>
		N5262A	front	n	N5262A-114	B X	[C1,C2,C3,C4,C5]
			rear	y	N5262A-104	F	[C1,C2,C3,C4,C5]
	400 & 423	N5261A	front	n	N5261A-114	A Z	[C1,C2,C3,C4, ]
			rear	y	N5261A-104	E	[C1,C2,C3,C4, ] <sup>f</sup>
		N5262A	front	n	N5262A-114	B X	[C1,C2,C3,C4,C5]
			rear	y	N5262A-104	F	[C1,C2,C3,C4,C5] <sup>h</sup>

- a. All PNA-X's require Option 020. When an N5262A is used with a 2-Port PNA-X, Option 551 is required.
- b. Condition of the Route PNA RF to rear panel "RF OUT" check box. n = no, y = check, x = don't care. Refer to [step 9](#) on [page 40](#).
- c. See [Figure 1-15](#) through [Figure 1-22](#) for configuration diagrams.
- d. Can only drive output on one port at a time in this configuration.
- e. Must use RF OUT on the rear panel.
- f. Must use RF OUT or RF1 OUT on the rear panel. Options 224 and 423 do not provide rear panel connections for Port 1. Functionality is the same as PNA-X without Option 224/423.
- g. Must use RF1 OUT on the rear panel.
- h. Must use RF OUT or RF2 OUT on the rear panel. Functionality is the same as PNA-X without Option 224/423.

## Compatible mm-wave Modules


Keysight offers millimeter modules manufactured by Olsen Microwave Labs (OML) and Virginia Diodes Inc (VDI) for use with the N5261/62A for banded mm-wave network analyzer systems. Refer to [Table 1-3, “Available OML Modules,”](#) on page 8 and [Table 1-4, “Available VDI Modules,”](#) on page 8.

Transmission/Reflection millimeter-wave modules contain an RF source multiplier, dual directional coupler, reference downconverter and a test downconverter. The Transmission/Reflection millimeter-wave module is usually the primary module of a millimeter-wave VNA system. A single Transmission/Reflection module allows the measurement of S11 reflection coefficient only. Refer to [Figure 1-3](#).

“Receive only” millimeter-wave modules contain a test downconverter to receive the test signal from a Transmission/Reflection millimeter-wave module. The use of a Receiver module, as the second module, allows the system capability to measure S11 and S21 only.

The use of two Transmission/Reflection modules in the millimeter-wave VNA system allows for all four S-parameters to be measured. The test downconverters of Transmission/Reflection modules are the receivers for the signal from the modules sources. When the two modules waveguide are connected, S11 and S21 are measured in the forward direction, S22 and S12 are measured when the signal path is reversed. If a 4-Port system is configured with Transmission/Reflection modules, all 16 S-parameter measurements can be made on a 4-Port device.

Figure 1-3 Module Configurations



**Table 1-3 Available OML Modules<sup>a,b</sup>**

Banded Freq Ranges (GHz)	Port Type	Source	Receiver	Model #	Notes
33 to 500	Waveguide	√	√	N5256AWxx	T/R Module
33 to 500	Waveguide		√	N5257ARxx	Receiver
33 to 500	Waveguide		Dual	N5258ADxx	Receiver-Dual

a. The Interface cable set is not supplied, refer to [Table 1-6 on page 10](#).

b. Adjustable RF Attenuator, RF & LO internal amplifiers options are available. Refer to OML millimeter-wave modules documentation (N5256-90001).

**Table 1-4 Available VDI Modules<sup>a,b</sup>**

Banded Freq Ranges (GHz)	Port Type	Source	Receiver	Model #	Notes
750 to 1100	Waveguide	√	√	N5262AW01-TST	T/R Module
500 to 750	Waveguide	√	√	N5256AW01-TST	T/R Module
50 to 500	Waveguide	√	√	N5262AWxx-TST	T/R Module
750 to 1100	Waveguide		√	N5262AR01-TST	Receiver
500 to 750	Waveguide		√	N5256R01-TST	Receiver
50 to 500	Waveguide		√	N5262ARxx-TST	Receiver

a. The Interface cable set is supplied with each VDI module. Do not order cable Options 501, 502, 503 and 505.

b. These modules are compatible with the test set only. They are provided with their own power supply, do not connect to the test set DC power port. Refer to VDI millimeter-wave modules documentation (N5256-90002).

---

## Verifying Your Shipment

To verify the contents shipped with your product, refer to the “Box Content List” included with the shipment. For a list of option components, refer to [Table 1-6 on page 10](#).

Inspect the shipping container. If the container or packing material is damaged, it should be kept until the contents of the shipment have been checked mechanically and electrically. If there is physical damage refer to [“Contacting Keysight” on page 86](#). Keep the damaged shipping materials (if any) for inspection by the carrier and a Keysight Technologies representative.

---

**CAUTION** The N5261/62A Millimeter Head Controller and the millimeter-wave modules are sensitive to electrostatic discharge (ESD). Ground your work station before unpacking and installing the millimeter-wave modules. See [“Electrostatic Discharge Protection” on page 85](#).

---

## Option List Information

Use the tables below to verify that your specific option shipment is complete.

Table 1-5 N5261/62A Standard Content

√	Keysight Part Number	Ref Des	Description	Qty
	N5261A or N5262A		Millimeter Head Controller Test Set	1
	1810-0118 (N5261A)		Coax Termination, 50 Ohm, male (load)	1
	1810-0118 (N5262A)		Coax Termination, 50 Ohm, male (load)	2
	N4011-21002	W7	Multi-Cond Flex CA AY - DSub25 m/m, 520mm (20in), Rear Panel Connections	1
	9230-0333		Envelope (Calibration Certificate)	1
	9320-6636		Functional Certificate	1
	N5262-90001		User's and Service Guide	1
	N5256-90001		OML Module Product Note	1
	N5256-90002		VDI Module Product Note	1

**Table 1-6 N5261A Interface Kits**

√	Keysight Part Number	Ref Des	Description	Qty
N5261A Option 102 (Interface Kit for 2-Port PNA N5222/42A))				
	5061-9038	W5, W8-W12	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	6
	N5262-20016	W1	Coax Rigid CA-Assy, SMA (m/f), (SRC1 to 2-Port PNA)	1
	U3021-60002		Lock Link Kit, Test Set to PNA-X	1
N5261A Option 104 (Interface Kit 4-Port PNA N5222/42A)				
	5061-9038	W5, W8-W12	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	6
	N5262-20018	W1	Coax Rigid CA-Assy, SMA (m/f), (SRC1 to 4-Port PNA)	1
	U3021-60002		Lock Link Kit, Test Set to PNA	1
N5261A Option 106 (Interface Kit 2-Port PNA N5224/25/44/45A)				
	5061-9038	W5, W8-W12	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	6
	N5262-20023	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 2-Port PNA)	1
	N4903-61250		Coax Adapter (3.5 mm female to 2.4 mm male)	1
	U3021-60003		Lock Link Kit, Test Set to PNA	1
N5261A Option 108 (Interface Kit 4-Port PNA N5224/25/44/45A)				
	5061-9038	W5, W8-W12	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	6
	N5262-20026	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 4-Port PNA)	1
	N4903-61250		Coax Adapter (3.5 mm female to 2.4 mm male)	1
	U3021-60003		Lock Link Kit, Test Set to PNA	1
N5261A Option 112 (Interface Kit 2-Port N5227/47A)				
	5061-9038	W5, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	7
	N5262-20023	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 2-Port PNA)	1
	U3021-60003		Lock Link Kit, Test Set to PNA	1
N5261A Option 114 (Interface Kit 4-Port N5227/47A)				
	5061-9038	W5, W6, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	8
	N5262-20026	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 4-Port PNA)	1
	U3021-60003		Lock Link Kit, Test Set to PNA	1

**Table 1-7 N5262A Interface Sets**

√	Keysight Part Number	Ref Des	Description	Qty
N5262A Option 102 (Interface Kit 2-Port N5222/42A)				
	5061-9038	W5, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	7
	N5262-20016	W1	Coax Rigid CA-Assy, SMA male to female (SRC1 to 2-Port PNA)	1
	N5262-20017	W3	Coax Rigid CA-Assy, SMA male to female (SRC2 to 2-Port PNA)	1
	N5262-20020	W2	Coax Rigid CA-Assy, SMA male to female (SRC2 to 2-Port PNA)	1
	U3021-60002		Lock Link Kit, Test Set to PNA	1
N5262A Option 104 (Interface Kit 4-Port N5222/42A)				
	5061-9038	W5, W6, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	8
	N5262-20018	W1	Coax Rigid CA-Assy, SMA male to female (SRC1 to 4-Port PNA)	1
	N5262-20019	W2	Coax Rigid CA-Assy, SMA male to female (SRC2 to 4-Port PNA)	1
	U3021-60002		Lock Link Kit, Test Set to PNA	1
N5262A Option 106 (Interface Kit 2-Port N5224/25/44/45A)				
	5061-9038	W5, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	7
	N5262-20023	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 2-Port PNA)	1
	N5262-20024	W3	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC2 to 2-Port PNA)	1
	N5262-20025	W2	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC2 to 2-Port PNA)	1
	N4903-61250		Coax Adapter (3.5 mm female to 2.4 mm male)	2
	U3021-60003		Lock Link Kit, Test Set to PNA	1

*Continued on Page 12*

**Table 1-7 N5262A Interface Sets (Continued)**

N5262A Option 108 (Interface Kit 4-Port N5224/25/44/45A)				
5061-9038	W5, W6, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	8	
N5262-20026	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 4-Port PNA)	1	
N5262-20027	W2	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC2 to 4-Port PNA)	1	
N4903-61250		Coax Adapter (3.5 mm female to 2.4 mm male)	2	
U3021-60003		Lock Link Kit, Test Set to PNA	1	
N5262A Option 112 (Interface Kit 2-Port N5227/47A)				
5061-9038	W5, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	7	
N5262-20023	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 2-Port PNA)	1	
N5262-20024	W3	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC2 to 2-Port PNA)	1	
N5262-20025	W2	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC2 to 2-Port PNA)	1	
U3021-60003		Lock Link Kit, Test Set to PNA	1	
N5262A Option 114 (Interface Kit 4-Port N5227/47A)				
5061-9038	W5, W6, W8-W13	Coax Flex CA-Assy - SMA (m/m), 520 mm (20 in), rear panel connections	8	
N5262-20026	W1	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC1 to 4-Port PNA)	1	
N5262-20027	W2	Coax Rigid CA-Assy, SMA male to 2.4 mm female (SRC2 to 4-Port PNA)	1	
U3021-60003		Lock Link Kit, Test Set to PNA	1	

**Table 1-8 Test Set to the Module Cable Sets**

√	Keysight Part Number	Description	Qty
	Option 501 (1-Port Trans/Refl Cable Set (48 inches = 1.2 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	8121-1221	Coax flex CA-Assy, 3.5 mm male to male, 1.2 m (48 in) - RF & LO	2
	85105-60030	Multi-Cond Flex CA-Assy, Cir 7C, 1.2 m (48 in) - DC Power Bias	1
	85105-60048	Coax flex CA-Assy, right angle- SMA m/m 1.2 m (48 in) - Ref & Test IF	2
	N5261-60019	Cable Sleeve and Marker Kit, 1.2 m (48 in)	1
	Option 502 (1-Port Trans/Refl Cable Set (79 inches = 2 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	N5260-60023	Coax flex CA-Assy, 3.5 mm male to male, 2 m (79 in) - RF & LO	2
	N5260-60070	Coax flex CA-Assy, right angle SMA m/m, 2 m (79 in) - Ref & Test IF	2
	N5260-60025	Multi-Cond Flex CA-Assy, Cir 7C, 2 m (79 in) - DC Power Bias	1
	N5261-60020	Cable Sleeve and Marker Kit, 5 m (197 in)	1
	Option 503 (1-Port Trans/Refl Cable Set (118 inches = 3 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	N5260-60026	Coax flex CA-Assy, 3.5 mm male to male, 3 m (118 in) - RF & LO	2
	N5260-60027	Coax flex CA-Assy, right angle SMA m/m, 3 m (118 in) - Ref & Test IF	2
	N5260-60028	Multi-Cond Flex CA-Assy, Cir 7C, 3 m (118 in) - DC Power Bias	1
	N5261-60020	Cable Sleeve and Marker Kit, 5 m (197 in)	1
	Option 505 (1-Port Trans/Refl Cable Set (197 inches = 5 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	N5260-60029	Coax flex CA-Assy, 3.5 mm male to male, 5 m (179 in) - RF & LO	2
	N5260-60071	Coax flex CA-Assy, right angle SMA m/m, 5 m (179 in) - Ref & Test IF	2
	N5260-60072	Multi-Cond Flex CA-Assy, Cir 7C, 5 m (197 in) - DC Power Bias	1
	N5261-60020	Cable Sleeve and Marker Kit, 5 m (197 in)	1

Table 1-9 Rackmount Front Handle Kits

√	Keysight Part Number	Description	Qty
	Option 1CM (Rackmount Kit without Front Handles)		
	5063-9215	Rackmount Kit - 177.OH-without Handle	1
	Option 1CN (Front Handle Kit)		
	5063-9228	Front Handle Kit - 177.OH	1
	Option 1CP (Rackmount Kit with Front Handle Kit)		
	5063-9222	Rackmount Kit with handle- 177.OH	1

## Specifications

The following information is provided to confirm the operation of the N5261/62A.

### General Characteristics

Environmental:

Temperature	20 to 30 °C
Altitude	3,000 meters (9,842 ft)
EMC	Samples of this product Meets radiated and conducted emission requirements of IEC 60068-2 and levels are similar to MIL-PRF-28800F Class 3.

Power Requirements:

Nominal Frequency Range	50/60 Hz
Nominal Voltage Range	100/120/220/240 Vac
N5261A or N5262A Power	350 Watts

Weight and Dimensions:

Net Weight	N5261A 10 kg (22 lb) N5262A 11 kg (24.2 lb)
Dimensions	Height: 18 cm (7.1 in) Width: 42.5 cm (16.75 in) Depth: 42.5 cm (16.75 in)

---

**CAUTION** This product is designed for use in Installation Category II and Pollution Degree 2.

---

### Required Conditions for Accuracy Enhanced Measurement

Accuracy-enhanced (error-corrected) measurements require the ambient temperature of the N5261/62A to be maintained within  $\pm 1$  °C of the ambient temperature at calibration.

The instrument can safely operate in a relative humidity of 80% for temperatures to 31 degrees C, decreasing linearly to 50% relative humidity at 40 degrees C.

---

**CAUTION** Ventilation Requirements: When installing the instrument in a cabinet, the convection into and out of the instrument must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the instrument by 4 °C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, forced convection must be used.

---

Table 1-10 Characteristics and Specifications

Front/Rear Panel Connector <sup>a</sup>	Power Levels (dBm)			Gain	Frequency
	Min	Typ	Max <sup>b</sup>		
N5261A					
TEST or REF IF (Input) (characteristic)	-	-27	-10	-	7.6 MHz
TEST IF to A/B/C/D IF OUTPUT (specification) See <a href="#">Figure 2-4 on page 55</a> .	-	-	-	-1.5 dB (± 1)	7.6 MHz
REF IF to A/B/C/D IF OUTPUTS (specification) See <a href="#">Figure 2-4 on page 55</a> .	-	-	-	-1.5 dB (± 1)	7.6 MHz
REF IF to R IF OUTPUTS (specification) See <a href="#">Figure 2-4 on page 55</a> .	-	-	-	-1.5 dB (± 1)	7.6 MHz
LO IN (characteristic)	-10	-	2	-	8 to 19 GHz
LO OUT (specification) <sup>c</sup> See <a href="#">Figure 2-1 on page 50</a> .	10	11.5	14.5	>14.5 dB	8 to 19 GHz
SRC1 RF IN (characteristic)	0	-	15	-	8 to 19 GHz
RF OUT (specification) <sup>d</sup> See <a href="#">Figure 2-2 on page 52</a> .	10	11.5	14.5	>14.5 dB	8 to 19 GHz
N5262A					
TEST or REF IF (Input) (characteristic)	-	-27	-10	-	7.6 MHz
Test IF to A/B/C/D IF OUTPUTS (specification) See <a href="#">Figure 2-4 on page 55</a> .	-	-	-	-2 dB (± 1)	7.6 MHz
Ref IF to A/B/C/D IF OUTPUTS (specification) See <a href="#">Figure 2-5 on page 55</a> .	-	-	-	-4 dB (± 1.5)	7.6 MHz
Ref IF to R IF OUTPUTS (specification) See <a href="#">Figure 2-6 on page 55</a> .	-	-	-	-5 dB (± 1.5)	7.6 MHz
LO IN (characteristic)	-10	-	2	-	8 to 19 GHz
LO OUT (specification) <sup>c</sup> See <a href="#">Figure 2-1 on page 50</a> .	10	11.5	14.5	14.5 dB	8 to 19 GHz
SRC1 or SRC2 RF IN (characteristic)	0	-	15	-	8 to 19 GHz
RF OUT (specification) <sup>d</sup> See <a href="#">Figure 2-2 on page 52</a> .	10	11.5	14.5	14.5 dB	8 to 19 GHz

- a. All connectors are SMA female.
- b. Do not exceed the maximum level or damage may occur.
- c. With a -3 dBm Input, measure on the test set connector. See [Figure 2-1 on page 50](#).
- d. ALC on and with 0 dBm Input, measure on the test set connector. See [Figure 2-2 on page 52](#).

## Cable Loss Between the Test Set and the Module

If the cables between the test set and the millimeter-wave modules are longer than four feet, cable loss for the RF and LO paths may be excessive. Perform the analysis recommended below.

Determine the input power level requirements for the millimeter-wave module selected for use. Refer to the documentation included with your module. To determine the power available at the module, calculate the cable loss using [Figure 1-4](#) or [Table 1-11](#), then subtract the cable loss from the RF and LO Out characteristic power of 10 dBm. You may also use a power meter.


A separate DC supply is recommended for OML modules if they are greater than 5 meters from the controller. A DC bias power cable, with banana plug connectors, is available for use with a separate power supply such as E3615A for OML modules. VDI modules have a DC power supply included with the module.

If you are installing an external amplifier in the LO or RF path, ensure the amplifier's input is connected to the test set, and the output is connected to the mm-wave module's LO or RF Input. Modules with internal amplifiers are available.

Table 1-11 Typical Cable Insertion Loss

Cable Option	Cable Length	7 GHz	10 GHz	18 GHz
501	4 ft. (1.22 m)	1 dB	1.2 dB	1.6 dB
502	6.58 ft. (2 m)	1.65 dB	2 dB	2.65 dB
503	9.83 ft. (3 m)	2.5 dB	3 dB	4 dB
505	16.4 ft. (5 m)	4.1 dB	5 dB	6.6 dB

Figure 1-4 Typical RF Cable Loss (dB loss per foot)



---

## Front Panel Features

Figure 1-5 N5261A (2-Port) Front Panel Features





Figure 1-6 N5262A (4-Port) Front Panel Features



#### TEST IF

IF signal input connection from the millimeter module's Test or Measure IF Output.

#### REF IF

Reference IF signal input connection from the millimeter module's Reference IF Output.

#### RF OUT

Provides an amplified RF source signal to the millimeter-wave module's RF Input.

#### LO OUT

Provides amplified LO signal to the millimeter-wave module's LO Input.

#### SRC1 and SRC2

Connects to the analyzer's front panel Test Ports for RF Output power.

#### Port Status LEDs

The amber LEDs indicate which source port is active. The green LEDs indicate which receiver port is active. All receivers are active in normal operation.

#### DC Power (Bias)

This bias supplies the +12 Vdc and ground lines for OML millimeter-wave modules. Pins 1 and 3 are both +12 Vdc supplies. Pins 4 and 6 are the dc supply ground lines. Pins 2, 5, and 7 are unused. The DC power connections are intended for use with OML modules.

#### DC Power/Over Current LEDs

The green LEDs indicate that the DC power bias is on. The amber LEDs indicate an over current condition.

#### Standby Switch

The switch is only a Standby switch, not a AC line power switch.

#### Active LED

When the test set is connected and addressed by a analyzer, the LED is On (illuminated). The LED is Off (not illuminated) when the test set is in Standby, or not addressed by the analyzer.

---

#### NOTE

The SRC2 Input and Ports 3 and 4 features are not present on the N5261A. Refer to [Figure 1-1 on page 3](#).

## Rear Panel Features

Figure 1-7 N5261A Rear Panel Features





Figure 1-8 N5262A Rear Panel Features



### IF OUTPUTs – SMA (female)

- D (from the test set to the analyzer's IF D Input)
- C (from the test set to the analyzer's IF C Input)
- R (from the test set to the analyzer's IF R Input, not installed in the N5261A)
- A (from the test set to the analyzer's IF A Input)
- B (from the test set to the analyzer's IF B Input)

### LO IN

This input is from the LO drive of the analyzer. The signal is split and amplified and then output to the front panel of the N5261/62A.

### SRC 1 RF IN and SRC 1 RF OUT

Test set rear panel RF Input access for use with the analyzer's Option 224 or 423. SRC 1 provides the power input for RF OUT Ports 1 & 2.

### SRC 2 RF IN and SRC 2 RF OUT (Not installed in the N5261A)

Rear panel RF Input access for use with the analyzer's Option 224 or 423. SRC 2 provides the power input for RF OUT Ports 3 & 4.

### Chassis Ground

A threaded terminal post for connecting the test set to a conductive object, cabinet or structure to ensure a common potential and reduce leakage current in a system. Requires an English 1/4-20 thread nut (0140-0084) and lock washer (2190-0067).

### Pass Through Interface

Connection to another test set.

### Test Set I/O

The test set interface connector is used to send address and data to the test set from the analyzer.

### Line Module

This assembly houses the line cord connection, line fuse, and line voltage selector. Remove the line module cover to replace or change the fuse. Line voltage selection is automatic and no setting is required. Recommended fuse values are printed on the rear panel of the N5261/62A.

### Power Cords

A line power cord is supplied in one of several configurations, depending on the destination of the original shipment. Keysight can supply additional certified power cords to meet region electrical supply and receptacle configurations. Please refer to our website at: <http://www.keysight.com> for assistance in power cord selection.

## Available Fuses

- Fuse (F 5 A/250V, 2110-0709) UL listed and CSA certified.

---

**WARNING** For continued protection against fire hazard replace line fuse only with same type and rating. The use of other fuses or material is prohibited.

---

Figure 1-9 Line Fuse



---

**CAUTION** Verify that the premise electrical voltage supply is within the range specified on the instrument.

---

## System Configuration and Operation

### Site Preparation

Install the instrument so that the detachable power cord is readily identifiable and is easily reached by the operator. An externally installed switch or circuit breaker (which is readily identifiable and is easily reached by the operator) should be used as the disconnecting device. The detachable power cord can also be used to disconnect the mains circuits from the mains supply before other parts of the instrument. The front panel switch is only a standby switch and is not a LINE switch.

### Protect Against Electrostatic Discharge (ESD)

This is important. If not properly protected electrostatic discharge can seriously damage your analyzer, resulting in costly repair.

---

**CAUTION** To reduce the chance of electrostatic discharge, follow all of the recommendations outlined in **“Electrostatic Discharge Protection”** on page 85.

---

**Table 1-12 Power Requirements of a Standard Configuration**

Standard Equipment	
Instrument	Maximum Watt
N5222A, N5224A, N5225A or N5227A	450
N5242A, N5244A, N5245A or N5247A	450
N5261/62A Millimeter Head Controller	350
Millimeter-wave Module (OML)	(powered from controller)
Millimeter-wave Module (VDI)	175

## System Setup

It is recommended that you connect the cables to the rear panel of the test set before mounting the analyzer on top of the test set. When the analyzer is mounted on the test set, the back of the analyzer extends over the rear panel of the test set and may interfere with access to the rear panel connectors. The cables can then be connected to the analyzer after it is mounted on the test set. [Table 1-1 on page 4](#) or [Table 1-2 on page 5](#) indicates which connection diagrams to use for your configuration.

---


**WARNING** The network analyzer is heavy. It is recommended that two individuals, or a mechanical lift be used to lift or transport the instrument.

---

### Mounting a Network Analyzer on the Test Set


1. Refer to the following kits for your specific analyzer. In this procedure a N5242A 4-Port PNA-X is used with a N5262A. There are other kits available via the U3021M model. Refer to [“Keysight Support, Services, and Assistance” on page 86](#) for ordering information.
  - Locking Kit (U3021-60002) for the test set. Includes the Locking kit (5023-0132) and screws (0515-2317) to connect the test set to the N5222A PNA or N5242A PNA-X. The N5242-20138 is the right foot and N5242-20139 is the left.
  - Locking Kit (U3021-60003) for the test set. Includes the Locking kit (5023-0132) and screws (0515-2317) to connect the test set to the N5224/25/27/A PNA or N5244A/45/47A PNA-X. The N5242-20130 is the right foot and N5242-20131 is the left foot.
1. Remove the feet from the bottom of the analyzer.
2. Remove the 2 lower standoffs from the rear panel on the analyzer.

Figure 1-10 Rear Bottom Feet



3. Install the two rear locking feet from the (5023-0132) onto the analyzer, where the standoffs were removed.

Figure 1-11 Install Locking Feet on Network Analyzer




4. Remove the top two standoffs from the rear panel on the test set.
5. Install the two rear locking feet from the kit (U3021-60002) onto the test set using two screws (0515-2317), included in shipment. Looking at the rear panel, the N5242-20139 is the left foot and the N5242-20138 is the right foot.

Figure 1-12 Rear Locking Feet (N5222A or N5242A)



6. Place the analyzer on top of the test set and ensure that the front frame of the analyzer is positioned slightly forward of the locks that are attached to the test set. Slide the analyzer back so the locks engage the front frame of the analyzer.

Figure 1-13 Locking the Analyzer



7. Secure the analyzer's lower locking feet to the test set's upper locking feet using the spring-loaded screws on the locking feet. Refer to [Figure 1-14 on page 27](#). If the locking feet are not aligned with the screw holes in the test set's upper locking feet, loosen the screws securing the feet to the instrument slightly to align and tighten.

Figure 1-14 Locking Feet Screws



### Rear Panel Connections

Rear panel connections are documented in [Figure 1-15](#) through [Figure 1-20](#). Refer to [Table 1-1 on page 4](#) and [Table 1-2 on page 5](#) to determine which figure applies to your configuration.

Figure 1-15 N5261A Rear Panel Configuration A



From: PNA/PNA-X	D/R2	C/R1	Test Set I/O	LO OUT (J5)	B	A
To: N5261A Controller	D	C	Test Set I/O	LO IN	B	A

Figure 1-16 N5262A Rear Panel Configuration B



From: PNA/PNA-X	D/R2	C/R1	R	Test Set I/O	LO OUT (J5)	B	A
To: N5262A Controller	D	C	R	Test Set I/O	LO IN	B	A

Figure 1-17 N5261A Rear Panel Configuration C



From: PNA/PNA-X	D/R2	C/R1	Test Set I/O	LO OUT (J5)	B	A	SW SRC <sup>a</sup> OUT (J11)
To: N5261A Controller	D	C	Test Set I/O	LO IN	B	A	SRC 1 RF IN (Port1 SW SRC)

a. Install the adapter (N4903-61250) on the N5224/25A or N5244/45A SW SRC OUT (J11).

Figure 1-18 N5262A Rear Panel Configuration D



From: PNA/PNA-X	D/R2	C/R1	R	Test Set I/O	LO OUT (J5)	B	SW SRC <sup>a</sup> OUT (J8)	A	SW SRC <sup>a</sup> OUT (J11)
To: N5262A Controller	D	C	R	Test Set I/O	LO IN	B	SRC 2 RF IN (SRC 2 SW SRC)	A	SRC1 RF IN (Port 1 SW SRC)

a. Install the adapters (N4903-61250) on the N5224/25A or N5244/45A SW SRC OUT (J8 and J11).

Figure 1-19 N5261A Rear Panel Configuration E



From: PNA/PNA-X	D/R2	C/R1	Test Set I/O	LO OUT (J5)	B	A	RF 1 OUT (J6)
To: N5261A Controller	D	C	Test Set I/O	LO IN	B	A	SRC 1 RF IN (Port 1 SW SRC)

Figure 1-20 N5262A Rear Panel Configuration F



From: PNA/PNA-X	D/R2	C/R1	R	Test Set I/O	LO OUT (J5)	RF 2 OUT (J12)	B	RF 1 OUT (J6)	A
To: N5262A Controller	D	C	R	Test Set I/O	LO IN	SRC 2 RF IN (SRC 2 SW SRC)	B	SRC1 RF IN (Port 1 SW SRC)	A

## PNA and PNA-X Front Panel Connections

Some system configurations require SRC connections between the analyzer's ports and the front panel of the test set. Refer to [Table 1-1 on page 4](#) and [Table 1-2 on page 5](#) to determine if these connections are necessary for your configuration. [Figure 1-21](#) and [Figure 1-22](#) provide the connection diagrams.

Figure 1-21 N5261A Front Panel Configuration Y and Z



Figure 1-22 N5262A Front Panel Configuration V and X



## Millimeter-wave Module Cable Connections

Before connecting the millimeter-wave modules, verify that the test set and the power supplies (if used) are powered down.

There are four RF cables for each T/R module. Cables provided with the VDI modules are pre-labeled. The cables for use with the OML modules come in two types, two lighter and two heavier. Use the lighter cables for the IF signals and the heavier cables for the RF and LO signals.

Figure 1-23 Example; OML Module Connections





Figure 1-24 Example; VDI Module Connections



The following detailed instructions are for connecting an OML T/R module. These instructions assume a cable dress kit (black sleeving) is available. Modify the instructions appropriately for other types of modules.

1. Prepare the cable bundle comprised of five cables listed in [Table 1-13](#).
  - a. Complete Steps 1 through 5 of the Installation Guide from the Millimeter-wave Cable Dress Kit (document number N5260-90070 contained in kit part number N5261-60019). **DO NOT APPLY THE VELCRO ASSEMBLIES AT THIS TIME.**
2. Connect the five cables to the front panel of the controller in the following order. Use two right angle adapters (1260-2604).

Table 1-13 Controller Connections

Order	Test Set	Module (OML)
1	DC POWER	+12 V
2	TEST IF	Test I.F.
3	REF IF	Ref I.F.
4	RF OUT	R.F. In
5	LO OUT	L.O. In

Figure 1-25 Controller Front Panel Connections



3. Repeat [step 1](#) and [step 2](#) for each module in the system.

4. Select a Millimeter-wave module and place it on the work surface in front of the test set.
5. Connect the bundle of cables to the module in the following order.

Table 1-14 Millimeter Head Connections

Order	Module (OML)
1	+12 V
2	R.F In
3	L.O. In
4	Ref I.F.
5	Test I.F.

Figure 1-26 Test Head Module Connections



6. Repeat **step 4** and **step 5** for the remaining modules.
7. Apply Velcro assemblies to the ends of the cable sleeves.
  - a. Complete steps 6, 7 and 8 of the Installation Guide from the Millimeter-wave Cable Dress Kit (document number N5260-90070 contained in kit part number N5261-60019 and N5261-90020).
8. Position each test head in the approximate location where it will be used for measurement operations.
9. Torque all RF connections to 8 in-lb.

## Configuring the Network Analyzer Firmware

This section will describe how to set up and operate the N5261/62A Millimeter Head Controller with your network analyzer.

The N5261/62A Millimeter Head Controller is considered a “slave” instrument. A network analyzer must be used to control the test set.

---

**CAUTION** Before turning on this instrument, verify that the AC supply voltage is in the specified range.

---

### Typeface Key Conventions

The following key conventions are used throughout this document.

- [HARDKEYS] are labeled front panel keys.
- SOFTKEYS are indicated on the instrument display.

### Before Beginning this Section

Determine the multiplier factors to use for RF IN and LO IN. The factors for each head are indicated on the labels located on the top of each head (near the RF and LO connectors).

---

**NOTE** The maximum frequency of RF signals from the PNA-X rear panel is 19 GHz.

---


## Millimeter Mode

The Millimeter mode allows you to configure the system for the millimeter-wave module you are using. Refer to the analyzer's Help menu for more information.

The following instructions assume the system has not been configured for the desired heads.

1. Connect your system and turn on all of the equipment.
2. To access the millimeter application select [System] > Configure > Millimeter Module.
3. Select the test set you are using from the drop-down menu (N5261A or N5262A).
4. Click the New command button.
5. In the "Selected Configuration" dialog box enter a title, such as "WR15" to replace "Config 1".

Figure 1-27 Banded Configuration



6. Enter the Multiplier RF IN number. Example: (WR15 = 4). Refer to [Figure 1-28](#) and the documentation shipped with your module.
7. Enter the Multiplier LO IN number. Example: (WR15 = 5) Refer to [Figure 1-28](#) and the documentation shipped with your module.
8. In the Test Port Frequency dialog box enter the Start and Stop Frequency of the millimeter-wave module. Example: (WR15 = 50 GHz and 75 GHz)

9. Select or clear the “Route PNA RF to rear panel “RF OUT” check box as indicated in [Table 1-1 on page 4](#) or [Table 1-2 on page 5](#).


10. Set the ALC mode according to the following information:

For most applications the ALC mode should be on “Enable Test Set RF ALC” box checked. For this condition “Max Power Limit at Multiplier’s RF IN” is automatically set to 11 dBm. The hardware ALC’s in the test set provide a nominal 11 dBm power level at the RF inputs to the extender modules. This applies to both the RF and LO inputs. A nominal cable loss between the test set and extender modules is assumed.

If the ALC mode “Enable Test Set RF ALC” is off, the max power may be set by the user in the “Max Power Limit at Multiplier’s RF IN” dialog box. If the user adjusts the analyzer’s RF power, the RF power into the millimeter-wave modules will change, but will not exceed the specified max power in the dialog box. It is recommended that ALC “Enable Test Set RF ALC” be turned off in Pulse mode. Without ALC the power control is less accurate.

11. Select OK. The analyzer will preset for millimeter operation after you select OK in the next dialog window.

Figure 1-28 Millimeter System Selections



**NOTE** Select the “Standard PNA” configuration to return to normal PNA operation without the heads.

## System Operation Verification

- The **Banded System Check** verifies the configured system is operating correctly. It requires all system components.
- If a problem is suspected with the N5261A or N5262A test set, refer to **“Test Set Operation Check” on page 46** and **“Test Set Troubleshooting” on page 59**.

### Banded System Check

The Banded System operational verification procedure confirms that the system is operating correctly. There are no hard specifications for the system measurement performance, but guidelines are provided for evaluating the system operation results.

The purpose of the Operation Check is to detect significant degradations in the system that make the performance unacceptable. The calibration kit and test environment can affect the System Operation Check results. Refer to **“Site Preparation” on page 24**.

When any part of the operator’s check provides unsatisfactory results, refer to **“System Level Troubleshooting” on page 45** to determine the cause of the problem.

### Required Equipment

- Waveguide Short
- Data for your mm-wave modules receivers
- 3/32 Ball Driver (OML), or 5/64 Ball Driver (VDI)
- 5/16 Open end Torque Wrench, 8 in-lb.

## Preparing the Network Analyzer

1. Connect the analyzer, test set and the millimeter-wave band modules as described in [“System Configuration and Operation” on page 24](#).
2. Turn on the test set and the analyzer.
3. Configure the analyzer for operation with the millimeter-wave modules. Refer to [“Configuring the Network Analyzer Firmware” on page 38](#). Refer to the Help menu for further information.


## Procedure

This procedure assumes that you have a Transmission/Reflection module on each port. If not, the procedure will have to be modified appropriately.

The Operational Check procedure verifies that the banded system is connected correctly and the modules, test set and analyzer are operating properly.

1. Allow the system to warm up for at least 30 minutes.
2. Attach a waveguide extension section to each module’s waveguide flange port to protect the modules waveguide connector.
3. Verify that the analyzer is in Millimeter mode and that the frequency range is correct for the configured millimeter system.
4. To verify the port as a receiver, perform the following steps:
  - a. Connect a short to Port 1.
  - b. Display all receivers on the analyzer’s screen using the following menu selections: [System] > Service > Utilities > Receiver Display.
  - c. Compare the A,1 and R1,1 traces to the data for your modules Test and Reference receivers. The general shape should be similar, but not necessarily identical to the graphics in the module documentation. Depending on the PNA model used, there may be a level shift of up to 10 dB. If a waveguide short is not connected the Test Receiver level will appear to have low amplitude.
  - d. If you are using more than one Transmission/Reflection module move the short to Port 2. If you are only testing one port proceed to [step 6](#).
  - e. Compare the B,2 and R2, 2 traces to the data for your modules Test and Reference receivers for the millimeter-wave module on Port 2. The general level and shape should be similar.
  - f. Repeat [step d](#) and [step e](#) for Port 3 and compare trace 3 C,3 and R3, 3.
  - g. Repeat [step d](#) and [step e](#) for Port 4 and compare trace 4 D,4 and R4, 4.

Figure 1-29 Example; Banded Receiver Display




5. Measure a Thru Connection.

- a. Connect the Port 1 to Port 2 module, and Port 3 to Port 4 module (N5262A) to form thru connections.
- b. Delete the trace 1, S11. Select Trace/Chan > Trace > Delete Trace.
- c. Select [Preset] > Trace/Chan > Trace > New Trace. Select S12, S21, S34 and S43. This test confirms that the modules are sourcing and receiving. Refer to your millimeter-wave modules data from OML or VDI, included with the your module.


**NOTE** S12 requires a Transmission/Reflection module on Port 1.  
 S21 requires a Transmission/Reflection module on Port 2.  
 S34 requires a Transmission/Reflection module on Port 3.  
 S43 requires a Transmission/Reflection module on Port 4.

Figure 1-30 Uncalibrated S12 and S21



6. Measure the Dynamic Range of each Millimeter-wave module.
  - a. Measure S11 for a 1-Port system, or S12 and S21 for a 2-Port system, or S12, S21, S34 and S43 for a 4-Port system.
  - b. Select [Avg] > IF Band width [10] > [Enter].
  - c. Set the power level to the maximum for each band.
  - d. For a 1-Port system connect a short to the test port. For a 2-Port or 4-Port system connect the module ports together to form thru connections. Refer to **“Measure a Thru Connection.”** on page 43 for connections.
  - e. Normalize each trace. Select the trace and press [Memory] > Normalize.
  - f. For a 1-Port system remove the TEST IF cable from the test set or module. For a 2-Port or 4-Port system disconnect the module ports and connect a load or short to all module ports.
  - g. Select [Scale] > Reference Level > [-30] > [Enter]. Set the reference as needed to view each trace.
  - h. The S11, S12, S21, S34 or S43 traces show non-calibrated system dynamic range. The dynamic range will vary depending on the modules used, and the configuration of the system. Reference your modules document for performance information. See **Figure 1-31.**
  - i. Select [Memory] > Data Math > Off and review the traces for noise floor performance.

Figure 1-31 Dynamic Range Trace Example



## System Level Troubleshooting

If the **System Operation Verification** procedure fails, perform the following procedure to isolate the problem.

Refer to the Keysight PNA Series: firmware, Upgrades, and Support at: <http://na.support.keysight.com/pna> for further information.

To request service, please contact your local service center. In the US, call 800-829-4444. For a listing of service centers worldwide, please visit us at <http://www.keysight.com/find/service>.

1. Confirm that each piece of equipment is turned on, and all analyzer, and Module connections are correct.
2. Verify that the analyzer has the correct options for Millimeter mode operation. Refer to **“Network Analyzer Requirements” on page 2**.
3. Verify that the analyzer is in Millimeter mode for the waveguide band of the modules used.
4. If the receiver levels (A,B, C, D or R 1) fail the Banded System check refer to the Measure, Test and Reference graphs in the documentation included with the module. If the REF IF and Test IF levels are low connect the REF IF and TEST IF cables directly from the mm-wave module to the analyzer’s rear panel IF Inputs. If the levels are correct proceed to **step 7**. If the levels are low continue with **step 5**.
5. If one of more of the ports are working, substitute the mm-module with a known working module. If the port is still not working measure the RF Out and LO Out power from the test set’s RF Out and LO Out connectors at the end of the cables. Replace or substitute the cables if the loss is greater than the cable specification. If the cables are not the cause proceed to **step 7**.

---

**CAUTION** Turn off the test set before disconnecting or reconnecting the modules.

6. Confirm that the analyzer is working properly by disconnecting it from the test set and performing an Operation Verification (OP VER) in the Help menu.
7. If the analyzer is operating properly, verify the test set by performing the **“Test Set Operation Check” on page 46**. If the test fails continue to **“Test Set Troubleshooting” on page 59**.
8. If the analyzer, test set and Modules are functioning, but the system is not operating properly, contact **“Keysight Support, Services, and Assistance” on page 86**.

---

## **2** Service Information

## Test Set Operation Check

This chapter contains service information for a standalone N5261A and N5262A controller test sets.

The following procedure verifies the test set without system components.

The instructions below generally assume a 4-Port N5262A. If you are using a N5261A, omit Ports 3 and 4.

### Preparation

#### Required Equipment

- PNA, PNA-L, PNA-X capable of 20 GHz. (The required Test Set I/O interface is included with all models). The PNA, PNA-L or PNA-X will be referred to as the PNA throughout this procedure.
- Two RF flexible cables with 3.5 mm male connectors (5062-6696 or equivalent). One cable must be long enough to comfortably connect between the PNA and the rear panel of the test set.
- Three SMA or 3.5 mm adapters (female to female)
- Voltmeter
- Power sensor and compatible power meter. The power sensor must be capable of measuring from -10 dBm to +15 dBm at a frequency of 8 GHz. A E4413A power sensor may be used.

#### Power Sensor and Power meter Preparation

The power sensor and power meter must be prepared to make measurements at 8 GHz. This may include calibrating the power sensor with the meter and entering a calibration factor for 8 GHz.

#### PNA and Test Set Preparation

1. Connect the Test Set I/O cable from the PNA to the test set.
2. Turn on the PNA and the test set.
3. The PNA must be in “Standard PNA” mode. To check the mode, select **Utility > System > Configure > Millimeter Module Configuration**. The Millimeter Module Configuration window will be displayed. “Standard PNA” should be the Selected Configuration. If not, click on “Standard PNA” in the list of Available Configuration(s) then click OK.

## PNA Normalization Calibration

This procedure prepares the PNA to for path loss measurements.

1. Select [Preset] on PNA.
2. Set the Start and Stop frequencies.
3. Set the desired power output level.
4. Set to measure S12.
5. Connect an RF cable to PNA Port 1. Connect a second RF cable to PNA Port 2.
6. Connect the two RF cables together with an adapter.
7. Normalize the trace, Select [Memory] > Normalize or select [Data] > Normalize. You will see a flat line at 0 dB.
8. Remove the adapter between the RF cables.

## Test Set I/O Commands

The **Test Set Operation Check** requires the use of Test Set I/O commands. These commands are issued by the PNA.

### Controlling the Test Set using Test Set I/O Commands

A Test Set I/O command may be used when the PNA is connected to the Test Set via the Test Set I/O cable. Commands may control the test set or read data from the test set. The GPIB command processor utility, in the network analyzer software, is used to communicate over the Test Set I/O connector.

It is recommended to use a USB keyboard with a PNA when using the command processor.

### Using the GPIB command processor

- Select Utility > System > Configure > SICL/GPIB/SCPI, then GPIB Command Processor Console. In the dialog box type the command text and then Enter on the keyboard to execute the command.
- A write command is of the form: cont:ext:test:data n,m "n" is the address and "m" is the data to be written. Typically these values may be any number up to three digits in length.
- A read command is of the form: cont:ext:test:data? n "n" is the address. A read command returns a single numeric value.
- Pressing F3 on the keyboard will recall a previously sent command line for editing.
- As a check, send the command: cont:ext:test:data? 0 <enter>. A 61 or 62 should be returned, depending on the model number of the test set.
- An active command processor window may be minimized via the "\_" in the upper right hand corner of the window. To access a minimized command processor window, minimize the PNA window. Select File > Minimize Application.

## Test Set I/O Command List

The following commands are available for controlling/reading the test set. The step-by-step commands in the [Test Set Operation Check](#) procedure require the use of these commands. The user is required to select the appropriate command, depending on the port or function under test.

Read commands involve a single number, an address. Write commands involve two numbers, address and data.

Table 2-1 I/O Commands

0	address for reading two digits from model number of the test set
32,0	turns on ALC for both SRC1 (Port 1 and 2) and SRC2 (Port 3 and 4)
32,1	turns off ALC for SRC1 (Port 1 and 2)
32,2	turns off ALC for SRC2 (Port 3 and 4)
0,1	SRC1 IN to Port 1 RF OUT
0,2	SRC1 IN to Port 2 RF OUT
0,16	SRC2 IN to Port 3 RF OUT
0,32	SRC2 IN to Port 4 RF OUT
64,17	turns on Receiver and Source LED's for Port 1 (all other LEDs off)
64,34	turns on Receiver and Source LED's for Port 2 (all other LEDs off)
64,68	turns on Receiver and Source LED's for Port 3 (all other LEDs off)
64,136	turns on Receiver and Source LED's for Port 4 (all other LEDs off)

---

**NOTE** The amber Source LED's are controlled separately from the switches for the RF OUT paths.


---

The write commands for IF path control for the N5262A are listed in [Table 2-2 on page 54](#). The commands for reading and writing gain factors for are listed in [Table 2-5 on page 76](#).

## Procedure

### Verify DC Voltages and Front panel LED's

Verify DC voltage levels on each of the front panel DC power connectors.  
Pins 1 & 3 = +12 V ( $\pm 0.8$  V), Pins 4 & 6 = ground



Issue the Test Set I/O commands that apply to the Receiver and Source LED's for the test set model being tested. See the ["Preparation" on page 46](#) for a list of possible commands. Confirm that each command drives the LED's appropriately.

### Measure LO OUT (Gain and Power)


Prepare the PNA to measure S12 with a normalization calibration. Refer to **“PNA Normalization Calibration” on page 47**. Use a frequency range of 8 to 20 GHz and a power level of -10 dBm. The cable on PNA Port 2 must be long enough to reach the rear panel of the test set.

1. Connect the PNA Port 2 cable to the rear panel LO IN.
2. Connect PNA Port 1 to Port 1 LO OUT on the test set. Verify the LO Output gain is > 20 dB. The trace should be within 10 dB of “flat” and have no significant holes or discontinuities. Refer to **Figure 2-1 on page 50**.
3. Select [Sweep] > Sweep Type > CW Time. Set the sweep time to 5 seconds.
4. Select [Freq] > Start > [8 GHz].
5. Disconnect the cable from LO IN and measure the power at the end of the cable using a power sensor. The power should be in the -8 to -12 dBm range. Adjust the PNA power output level if needed.

Reconnect the cable to LO IN.

6. Measure the Port 1 LO OUT power using a power meter. The power should be +12 dBm ( $\pm 1.5$  dB). Measure LO OUT for the other ports on the test set.

Figure 2-1 LO Output Gain with -10 dB Input



### Measure the SRC1 & SRC2 RF Paths

The following procedure verifies SRC1 and SRC2 internal cables between the front and rear panels.

Prepare the PNA to measure S12 with a normalization calibration using a frequency range of 8 to 20 GHz and a power level of -8 dBm. See [“PNA Normalization Calibration” on page 47](#).

The cable on PNA Port 2 must be long enough to reach the rear panel of the test set.

1. Remove the SRC1 RF IN to SRC1 RF OUT rear panel jumper.
2. Connect the PNA RF Port 1 to SRC1 RF IN on the front panel.
3. Connect Port 2 to the rear panel SRC1 RF OUT.
4. The maximum loss should be < 2.5 dB.
5. Repeat the steps above with appropriate modification to measure the SRC2 path, the maximum loss should be < 2.5 dB.

### Measure RF OUT (Gain and Power)

The following procedure measures gain.

Prepare the PNA to measure S12 with a normalization calibration. Refer to [“PNA Normalization Calibration” on page 47](#). Use a frequency range of 8 to 20 GHz and a power level of 2 dBm.

1. Re-install the SRC1 RF IN to SRC1 RF OUT and the SRC2 RF IN to SRC2 RF OUT rear panel jumpers.
2. Connect PNA Port 2 to SRC1 RF IN on the front panel.
3. Connect the PNA Port 1 to the Test Set Port 1 RF OUT.
4. Issue the Test Set I/O commands 32,0 and 0,1 (enable ALC and output to Port 1). Verify that the gain is greater than 10 dB at all frequencies and there are no holes or significant discontinuities in the trace. Refer to [Figure 2-2 on page 52](#).
5. Issue the Test Set I/O command 32,1 (disable ALC on Port 1). Verify that the gain increases at all frequencies and that there are no holes in the trace. Refer to [Figure 2-3 on page 52](#).
6. Repeat the previous the previous four steps for each of the remaining test set ports using appropriate SRC1/2 connections and appropriate Test Set I/O commands.

The following procedure measures the power output level.

1. Select [Sweep] > Sweep Type > CW Time. Set the sweep time to 5 seconds.
2. Select [Freq] > Start > [8 GHz].
3. Set the PNA power output level to 2 dBm.
4. Connect the PNA Port 2 to SRC1 RF IN.
5. Issue the Test Set I/O commands 32,0 and 0,1 (enable ALC and output to Port 1).
6. Measure the Port 1 RF OUT power using the power sensor. Confirm that RF OUT is +12.5 dBm ( $\pm 1.5$  dB).
7. Repeat the previous three steps for each of the remaining test set ports using appropriate SRC1/2 connections and Test Set I/O commands.

Figure 2-2 RF Output Gain with +2 dBm ALC On





Figure 2-3 RF Output Gain with +2 dBm ALC Off



## Measuring Test IF and REF IF Path Loss on the N5261A

---

**NOTE** The IF paths for the N5261A are not switched, see [Figure 2-8 on page 64](#).

The cable connected to PNA Port 1 must be long enough to reach the rear panel of the test set.

1. Prepare the PNA to measure S12 with a normalization calibration. Select a frequency range of 10 to 20 MHz and a power level of -20 dBm. See [“PNA Normalization Calibration” on page 47](#).
2. Measure the signal paths listed below. Connect PNA Port 2 to the test set front panel. Maximum loss should be < 3 dB.
  - Port 1 TEST IF to A (rear panel)
  - Port 1 REF IF to C (rear panel)
  - Port 2 TEST IF to B (rear panel)
  - Port 2 REF IF to D (rear panel)

## Measuring Test IF and REF IF Path Loss on the N5262A

---

**NOTE** The IF paths for the N5262A are switched (i.e. multiplexed), see [Figure 2-9 on page 65](#).

The cable connected to PNA Port 1 must be long enough to reach the rear panel of the test set.

1. Prepare the PNA to measure S12 with a normalization calibration. See [“PNA Normalization Calibration” on page 47](#). Select a frequency range of 10 to 20 MHz and a power level of -20 dBm. See [“PNA Normalization Calibration” on page 47](#).
2. Measure each path listed in [Table 2-2 on page 54](#) for N5262A. Each path is defined by entries in the “From:” and “To: N5262” columns.
  - For a given IF path, issue the appropriate command then measure the gain (loss) and connect PNA Port 2 to the appropriate connection on the front panel of the test set.
  - The maximum path loss is listed for each path.
  - There should be no holes or significant discontinuities on the traces. [Figure 2-4](#), [Figure 2-5](#) and [Figure 2-6 on page 55](#) are examples of acceptable traces.

Table 2-2 IF Path Measurement

From: TEST IF Front Panel	To: N5261A Rear Panel IF OUT	To: N5262A Rear Panel IF OUT	Command <sup>1</sup>	Max Path Loss for N5262A (dB)
Port 1 TEST IF	A	A	16,8	3
Port 2 TEST IF	B	B	16,4	3
Port 3 TEST IF	n/a	C	16,2	3
Port 4 TEST IF	n/a	D	16,1	3
Port 1 REF IF	C	D	16,8	6.0
Port 1 REF IF	n/a	R	16,33	7.5
Port 2 REF IF	D	C	16,4	6.0
Port 2 REF IF	n/a	R	16,2	7.5
Port 3 REF IF	n/a	A	16,2	6.0
Port 3 REF IF	n/a	R	16,56	7.5
Port 4 REF IF	n/a	B	16,1	6.0
Port 4 REF IF	n/a	R	16,20	7.5

1. Commands are not required for the N5261A.

Figure 2-4 Test IF Path to A, B, C or D




Figure 2-5 Ref IF to A, B, C or D





Figure 2-6 Ref IF to R



## Theory of Operation

### Functional Block and Assembly Information

The N5261A/62A routes PNA-X LO and RF signals to a millimeter-wave module. This allows the PNA-X to up-convert for a millimeter-wave source and down-convert a received millimeter-wave frequency to an IF frequency 7.6 MHz. It also provides the DC power for the millimeter-wave module. The following components are used in the N5261/62A. Refer to the block diagrams, [Figure 2-10](#) through [Figure 2-13](#) beginning on [page 66](#).

#### Test Set Control Board (N5261-60006)

The Test Set Control board (N5261-60006) is a surface mount, printed circuit assembly (PCA) that provides a connection to the power supply and the PNA-X Test Set I/O. The PNA-X sends address and data commands which are read by the test set controller for selecting the switch paths of the SRC1 and SRC2 RF and IF switch paths. The test set controller board has a programmed FPGA and memory (NovRam) with model number and gain correction values for the Amplifiers and ALC circuits. Switch S1 is set to lock the memory after calibration is been loaded. The front panel “Active” and port LEDs are only on when the PNA-X has addressed the N5261/62A Millimeter Head Controller. The rear panel fan is on when the Controller board supplies are operational.

IF the Controller board is replaced, the gain data will need to be stored into the new board. Refer to [“Contacting Keysight” on page 86](#) for the replacement procedure.

#### Interface Board (N5261-60101)

The Interface board is installed on top of the test set controller board. It provides switch drive signals and voltage for the solid-state switches that select RF Inputs (SRC1 or SRC2) to one of the front panel RF Outputs ports. It provides switching from the front panel TEST IF and REF IF Inputs to the rear panel IF Outputs D/R2 C/R1, R, A, B. The board also provides DC voltage, ALC control of the Amplifiers and a FPGA programmed device that enables N5261/62A Millimeter Head Controller operation.

#### LED Board (N5261-60005)

Two LED board assemblies are mounted to the front panel. The top LED board indicates the Source Path (amber/yellow color), or Receiver Path (green colored) shown as “S” and “R” for each port. The bottom LED Board indicates the DC Power is on (green). If an over-current condition occurs on the millimeter-wave module the LED will be (amber/yellow), which could be a result of a shorted interface cable or damaged Millimeter-wave module. The LED board assemblies are connected to the test set controller board by ribbon cables.

#### DC Power Board (N5261-60102)

The DC Power board provides connection to the power supply and self recovering fuses for each millimeter-wave module supply (+12 volt) on the front panel. The fuses are reset when the N5261/62A is turned off.

### **Power Supply (0950-4729)**

The power supply (0950-4729) converts the AC line voltages to DC. This is an automatic line voltage selecting power supply. The AC line voltage (100 to 240 V @ 50/60 Hz) is provided from the line module located on the rear panel.

### **Isolators (0955-1595)**

Isolators are installed in the LO Output RF path for each port. These 10 watt isolators maximizes the LO power input to the millimeter-wave modules over a frequency range of 8 to 19 GHz.

### **LO Preamp (5087-7750)**

A preamplifier installed in the LO Input path provides a higher RF power level required for the LO Amp.

### **RF and LO ALC Amplifier (5087-7771)**

The Mod/Amp has adjustable gain that provides ALC leveling for the front panel RF and LO Output signals. Adjustments are made on each Mod/Amp to set the maximum output power to +12.0 or +12.5 dBm (R3). The output of each amplifier is connected to a coupler, and with a detector for ALC, the mod/amps provide RF and LO leveling. Each Mod Amp has a Bias board (N5261-60103) installed on top that provides the power supply connection and circuitry for setting the gain of the amplifier (R3) and an SMB Input to the modulator.

The ALC function for the LO is always enabled. The ALC function for the RF sections may be turned off. The test set controller board stores open loop gain values for the RF sections. These gain values are used by the PNA firmware to provide a power level of approximately 10 dBm to the mm-wave heads when the ALC function is off.

### **Attenuator, 7 dB (0955-0242)**

This attenuator is used at the LO Input port to provide a good match and set the LO Input level for the preamplifier.

### **Attenuator, 6 dB (0955-0243)**

The 6 dB attenuators are used to attenuate the RF and LO power to the ALC detector to set the RF level for linear operation.

### **Attenuator, 3 dB (0955-0246)**

The 3 dB attenuators are used in the SRC1 or SRC2 Mod/Amp Inputs to provide a good match and ensure it does not exceed +15 dBm.

### **Coupler (0955-0148)**

Directional couplers with 10 dB coupling factor are used for ALC feedback for RF and LO Output leveling.

### **Slope Attenuator Cable Assy (N5262-20033)**

A slope pad is installed on the leveling coupler of the RF Out path to compensate for the RF switch loss at higher frequencies.

### **Power Divider (N5262-80003)**

A four-way power divider provides each Port LO Output from the LO amplifier with approximately 7.2 dB attenuation for each LO Out. Two 50 ohm terminators are installed on the unused N5261A divider paths. If a system is configured with a unused port (a 1-Port reflection system for example) the front panel LO Output ports are to be terminated with a 50 ohm load (1810-0118). This keeps the power divider balanced and prevents an “open” reflective signal from entering the power divider and mixing with the RF signal.

### **RF Switch (5087-7733)**

A solid-state switch with internal 50 ohm termination is used for switching the RF Output path for Ports 1 and 2, or Ports 3 and 4. These switches are controlled by the test set controller and interface boards.

---

## Test Set Troubleshooting

For assistance refer to [“Keysight Support, Services, and Assistance” on page 86](#).

If the test set is not operating properly, use the following procedures to aid in isolating the problem. Refer to the [“Test Set Diagrams and Graphics” starting on page 64](#).


### Power Supply and Fans

1. Verify the front panel Standby switch is operational.
  - a. The rear panel fan and front panel DC Power LEDs should be on when the Standby switch is in the on position.
2. AC Line voltage checks.
  - a. Ensure the proper AC line voltage is present at the instrument line cord.
  - b. Remove the AC power cord from the instrument. Check the instrument AC line module 5 amp fuse, as shown in [Figure 1-9 on page 23](#).
  - c. Remove the instrument bottom cover. Near the rear panel are two fuse holders, remove the 8 amp fuses and verify that they are operational. See [Figure 2-18 on page 73](#).
3. Internal DC Power checks.
  - a. Set the Standby switch to the Standby position.
  - b. Remove the top cover and connect the AC power cord. No fans or DC power LEDs should be on.
  - c. Set the Power Switch to the on position. Both rear panel and internal power supply fans should be operational; the front panel DC Power LEDs should be on. If the DC Power LEDs are off, measure the +12 Vdc pins on the front panel connectors. Refer to [“Test Set I/O Commands” on page 47](#).
  - d. Ensure the Controller board DC Supply indicator LEDs are on. If not, suspect power supply (0950-4727) or front panel Standby switch. Using a DVM measure the power supply terminal connections. Refer to the label on the power supply for voltages on the terminals screws. [Figure 2-7 on page 60](#).
  - e. If the voltages on the power supply are correct, lift the Interface board. If the Controller board DC Supply LEDs are on, disconnect switches (J60 & J61) and amp cables (J10, 11, 12 and 14) to the Interface board and re-install the board. If the indicator LEDs are on, suspect the switch or amplifier. [Table 2-3 on page 60](#).
  - f. If the fan is not working and all Controller board DC Supply LEDs are on, replace fan.

Table 2-3 Interface Board DC Power Distribution Details

Ref Des	Load	DC Voltage	DC Source
J10	RF Amp1	2, -2, 9, 15, -15	Main PS U22 & U23
J11	RF Amp2	2, -2, 9, 15, -15	Main PS U22 & U23
J12	LO Pre Amp	15	Main PS
J14	LO Amp	2, -2, 9, 15, -15	Main PS U22 & U23
J60	RF Sw1	-10 & 13	U20 & U21
J61	RF Sw2	-10 & 13	U20 & U21

Figure 2-7 DC Power Check Locater



## No DC Power for Millimeter-wave Modules

1. Remove the top and bottom covers.
2. Inspect the DC Power board (N5261-60002) connections.
3. Measure the +12 Vdc (red wires) on the DC Power board. If the +12 Vdc is present, replace the DC power cable from the front panel (N5652-60001). If the +12 Vdc is not present go to [step 4](#).
4. Verify that the supply LED indicators on the Test Set Control Board (N5261-60006) are on. If they are, replace the DC Power Board (N5261-60002). Refer to [Figure 2-14 on page 70](#). If the LEDs not off, refer to [“Test Set Troubleshooting” on page 59](#).

## Over Current LEDs are On (amber)

1. Remove all millimeter module connections from the front panel. If the over current LEDs are off, suspect the millimeter module or the DC Power Bias cable. If the LEDs are on continue with [step 2](#).
2. Verify that the +12 Vdc on the front panel DC Power connectors is not shorted to ground. Refer to [“Test Set Operation Check” on page 46](#). If it is shorted to ground, replace the front panel DC Power cable (N5652-60001) or the DC Power Board (N5261-60002). If it is not shorted to ground continue to [step 3](#).
3. Move the DC Power board ribbon cable to the Source/Receiver Status LED board, if the over current LEDs are still on replace the DC Power Board (N5261-60002). If the LED's are off replace the DC Power LED Board (N5261-60005).

## Front Panel Active and Port Status LED

Front Panel R and S Indicator LED check. If the LED indicators are not operating, verify the ribbon cable connection and ensure the rear panel test set interface cable is connected securely. Proceed to the next section for further troubleshooting before replacing the front panel board.

1. Connect the Test Set I/O cable (N4011-21002) from the analyzer to the test set.
2. Using the I/O command values, confirm the correct address and data values are used, refer to [Table 2-2 on page 54](#).
3. Front Panel R and S indicator LED Check.
  - a. Verify that at least three of the Controller Status LEDs, are on. Refer to [Figure 2-7 on page 60](#).
  - b. If none are on remove the Switch Driver board and recheck, if still no indication, replace the Controller board.
  - c. If the Controller Status LEDs and the front panel Active LED is on, suspect the front panel LED board or the ribbon cable. Replace as needed. You can move the ribbon cable connection to the DC power board and verify if the problem is the Port Status LED board, or use the ribbon cable from the DC power board to verify if the problem is the ribbon cable.

## RF OUT Failures

If the test ports are not switching, or fail the Operational Check the following procedures can be used to verify the failure. The procedures assume power supplies, controller board and front panel LEDs are working. Suspect the switch Interface board, ribbon cable connection or RF switch. Refer to [Table 2-3 on page 60](#) and [Figure 2-7 on page 60](#).

1. Inspect the ribbon cable connections from the RF switches to the Switch Interface board (N5261-60001). Ensure the RF jumpers (E8356-20072) are installed on SRC1 IN/OUT and SRC2 IN/OUT on the rear panel.
2. Start by measuring the power at SRC1 or SRC2, continuing through the RF Amp, Directional Coupler and Solid State Switch. If you find incorrect power levels and suspect a component has failed verify the DC voltages referencing [Table 2-3 on page 60](#) and [Figure 2-7 on page 60](#). Replace the failed component.

If you suspect the RF Amp (5086-7771) substitute the LO Amp (5086-7771) to verify the failure. The RF Amp uses a leveling circuit with directional coupler and detector that also can be checked before replacing the RF Amp. You may also substitute the Directional Coupler and Detector from the LO Amp section. If the RF Amp is replaced a gain calibration must be preformed.

3. If you suspect the Solid State Switch (SW1 & SW2) confirm that one of its two LEDs toggle on/off when you send a Test Set I/O command. Refer to [“Measure RF OUT \(Gain and Power\)” on page 51](#) and [Table 2-2 on page 54](#).
4. Substitute a known good switch, or connect a known good wire-harness cable and retest. Replace if necessary.
5. If the problem is not the switch measure the switch drive voltage on the Interface board (J60 or J61, Pin 1) for a change in voltage (-10 V or +13.0 V), use I/O command in [Table 2-2 on page 54](#). Replace the Interface board.

## LO Out Failure

If the LO Out fails the Operation Verification test the following procedure can be used to verify the failure. The procedures assume power supplies, controller board and front panel LEDs are working. Suspect the switch Interface board, Bias cable, RF pre-amp or Power Divider.

1. If one or more of the LO ports are working, suspect the Power Divider.
2. If none of the port are working, start by measuring the power at LO IN, continuing through the pre-amplifier, LO Amp, Directional Coupler and Power Divider. If you find incorrect power levels and suspect a component has failed verify the DC voltages referencing [Table 2-3 on page 60](#) and [Figure 2-7 on page 60](#). Replace the failed component.

If you suspect the LO Amp (5086-7771) substitute the RF Amp (5086-7771) to verify the failure. The LO Amp uses a leveling circuit with directional coupler and detector that also can be checked before replacing the LO Amp. You may also substitute the Directional Coupler and Detector from the RF Amp section.

## REF IF or Test IF Failure

If the REF IF or Test IF fails the Operation Verification test the following procedure can be used to verify the failure. The procedures assume power supplies, controller board and front panel LEDs are working. Suspect the switch Interface board or coaxial cables. Refer to [Table 2-3 on page 60](#) and [Figure 2-7 on page 60](#).

1. N5261A - Verify that the front panel Port 1 & 2 REF and IF coax cables are properly connected to the rear panel (A, B, C and D) and insertion loss is not  $> -2.5$  dB. Replace the coax cable if defective. Refer to [Figure 2-8 on page 64](#).
2. N5262A - Verify that the front panel Port 1 & 4 REF and IF coax cables and rear panel coax cables (A, B, C, D and R) are properly connected to the Interface board. Verify that the insertion loss is not  $> -2.5$  dB. Replace the coax cable if defective.
3. If the coax cables are properly connected and the insertion loss is correct, replace the Interface board. Refer to [Figure 2-9 on page 65](#).

## Test Set Diagrams and Graphics

Figure 2-8 N5261A Test Set Diagram




Figure 2-9 N5262A Test Set Diagram






Figure 2-10 N5261A RF and LO Block Diagram<sup>1</sup>



1. Refer to Figure 2-8 on page 64 for IF paths.

Figure 2-11 N5262A RF and LO Block Diagram<sup>1</sup>



1. Refer to [Figure 2-9 on page 65](#) for IF paths.

Figure 2-12 Signal Routing 2-Port





Figure 2-13 Signal Routing 4-Port



## Part Replacement and Location Information

There are many other repair and calibration options available from the Keysight Technologies support organization. These options cover a range of service agreements with varying response times. Contact Keysight for additional information on available service agreements for this product.

### Replaceable Parts

Special options are built to order, so long lead times may be encountered when ordering replacement parts. For parts that are not listed in the following table refer to **“Keysight Support, Services, and Assistance”** on page 86.

Description	Keysight Part Number
Millimeter Head Interface Bd	N5261-60101
DC Power Bd	N5261-60102
RF/LO Bias/ALC Bd	N5261-60103
Preamplifier Bias Bd	N5261-60104
LED Bd, Front Panel	N5261-60005
Test Set Controller Bd	N5261-60006
RF 4-way Divider	N5262-80003
RF Detector	33330-80021
Coax Cable, Sloped Attenuator	N5262-20033
DC Power Supply	0950-4729
RF Isolator, 20 GHz	0955-1595
Preamplifier	5087-7750
RF/LO Amplifier	5087-7771
Coax Attenuator (3 dB)	0955-0246
Coax Attenuator (6 dB)	0955-0243
Coax Attenuator (7 dB)	0955-0242
RF Directional Coupler (2-20 GHz)	0955-0148
RF Switch, SPDT Solid State	5087-7733
Hex Nut	0140-0084
Lock Washer	2190-0067
Fuse 5 A/250V	2110-0709
Cable, IF MUX, front panel	8121-0150
Cable, IF MUX, rear panel	8120-8483

Figure 2-14 N5261A Top View




Figure 2-15 Slope Pad



Figure 2-16 N5261A Top Front View






Figure 2-17 N5262A Top View<sup>1</sup>



1. Refer to [Figure 2-9 on page 65](#) for IF cable routing between the Interface board and the front and rear panels.

Figure 2-18 N5262A Bottom View



## Test and Adjustment Procedures

The “**Test Set Operation Check**” on **page 46** should be performed whenever any active electronic part is replaced in the test set.

Additional procedures are required when certain components are replaced. **Table 2-4** indicates when additional procedures are required. The additional procedures depend on the location of the replaced component.

The additional procedures are indicated as A, B, C, D, F, Q, R, S and Z in **Table 2-4**.

**Table 2-4 Additional Required Procedures for Assemblies Replaced**

Description of the Replaced Component	Keysight Part Number	Location: Ports 1 & 2 RF Section <sup>1</sup>	Location: Ports 3 & 4 RF Section <sup>1</sup>	Location: LO Section	General Location
Millimeter Head Interface Bd	N5261-60101				Z
Test Set Controller Bd	N5261-60006				C <sup>2</sup> D
RF/LO Bias/ALC Bd	N5261-60103	Q	R	S	
Preamplifier Bias Bd	N5261-60104			S	
RF 4-way Divider	N5262-80003			S	
RF Detector	3333-80021	Q	R	S	
Coax Cable, Sloped Attenuator	N5262-20033	Q	R		
Preamplifier	5087-7750			S	
RF/LO Amplifier	5087-7771	Q A D	R B D	S	
RF Directional Coupler	0955-0148	Q A D	R B D	S	
RF Switch, SPDT Solid State	5087-7733	Q A D	R B D		

1. Refer to **Figure 2-9** thru **Figure 2-12** and **Figure 2-15** thru **Figure 2-18** to determine part location.
2. Procedure “C” must be done before removing the “old” board.

The procedures referenced above may be found on the following pages. Many of the steps require familiarity with the “**Preparation**” section beginning on **page 46**.

## Gain Factors for the SRC RF Paths

### Background

The controller board in the test set stores gain factors for the various SRC RF paths in non-volatile memory. These gain factors are used by the PNA firmware to ensure that the SRC RF power delivered to the mm-wave head is approximately 11 dBm when the ALC is off.

When a component in a SRC RF path is replaced it is necessary to measure the new gain factors and update the values stored on the controller board. Typically the gain factors must be updated whenever one or more of the components in an “RF Section” of [Figure 2-10, “N5261A RF and LO Block Diagram,”](#) or [Figure 2-11, “N5262A RF and LO Block Diagram.”](#) is replaced.

When a controller board is going to be replaced, if possible, the gain factors should be read from the old controller board before it is removed from the test set. After the new controller board is installed the gain factors must be written into the test set. If the gain factors cannot be read from the old board then the gain factors must be measured after the new controller board is installed.

Instructions for issuing Test Set I/O commands are contained in the “[Preparation](#)” section beginning on [page 46](#). [Table 2-4 on page 74](#) indicates which procedure(s) is required.

### Measure Gain Factors for Ports 1 and 2 (Procedure A)

1. Connect the SRC 1 jumper on the rear panel of the test set.
2. [Preset] the PNA. Set the measured frequency range from 7 GHz to 20 GHz.
3. Set the PNA power output level to -15 dBm. Set the PNA to measure S12.
4. Connect cables to PNA Ports 1 and 2. These two cables will allow connection to the front panel of the test set.
5. Connect the two cables together using an adapter and perform a normalization calibration. Refer to “[Test Set Operation Check](#)” on [page 46](#) for instructions.
6. Connect PNA Port 2 to SCR1 IN and PNA Port 1 to Test Set Port 1 RF OUT.  
Issue the Test Set I/O commands 32,1 and 0,1 (turn off SRC1 ALC and set path to Port 1).
7. Set markers for 7, 10, 15 and 20 GHz on the PNA trace.
8. Read the value for each marker and translate to tenths of a dB (round the raw number as required). Example: a reading of 25.34 dB would be translated to a value of 253.
9. Record the values for Port 1 in [Table 2-5 on page 76](#).
10. Issue the Test Set I/O command 0,2 to set the path to Port 2.
11. Move the PNA Port 1 cable to Test Set Port 2 RF OUT.
12. Record the values for Port 2 in [Table 2-5](#).

### Measure Gain Factors for Ports 3 and 4 (Procedure B)

Repeat the process above for Ports 3 and 4 with the following modifications:

- Connect the SRC2 jumper on the rear panel.
- Connect to SRC2 IN in place of SRC1 IN.
- The first set of Test Set I/O commands should be 32,2 and 0,16.  
 (turn off SRC2 ALC and set the path to Port 3)
- The Test Set I/O command to set the path to Port 4 is 0,32.

Table 2-5 Gain Factor Addresses and Values

Ports/Freq	Write Address	Read Address	Value
Port 1 - 7 GHz	144	16	
Port 1 - 10 GHz	148	20	
Port 1 - 15 GHz	152	24	
Port 1 - 20 GHz	156	28	
Port 2 - 7 GHz	160	32	
Port 2 - 10 GHz	164	36	
Port 2 - 15 GHz	168	40	
Port 2 - 20 GHz	172	44	
Port 3 - 7 GHz	176	48	
Port 3 - 10 GHz	180	52	
Port 3 - 15 GHz	184	56	
Port 3 - 20 GHz	188	60	
Port 4 - 7 GHz	192	64	
Port 4 - 10 GHz	196	68	
Port 4 - 15 GHz	200	72	
Port 4 - 20 GHz	204	76	

### Read Gain Factors from the Test Set (Procedure C)

Issue a separate Test Set I/O read command for each entry in [Table 2-5 on page 76](#). Record each value as it is read from the test set. As an example, to read the value for Port 2 at 10 GHz, issue the following command: 36. The command will return the value stored in the test set. The value is an integer representing tenths of a dB. Ignore the leading “+”.

### Write Gain Factors to the Test Set (Procedure D)

A slide switch must be accessed to enable writing of gain factors. The switch is located on the test set Control Board next to U5, close to the rear panel. (The test set control board is shown in [Figure 2-17 on page 72](#)) “NWE” and “NCLR” labels are silk-screened near the sides of the switch. To enable writing, slide both sections of the switch toward U5. To disable writing, slide both sections of the switch away from U5. The switch may be covered with soft, transparent plastic. A sharp, stiff tool may be required to manipulate the switch.

Enable writing via the slide switch.

Issue a separate Test Set I/O write command for each entry in [Table 2-5](#). As an example, to write a value of “253” for Port 1 at 7 GHz, issue the following command: 144,253.

It is only necessary to write “new” values. If only Procedure A has been performed and not Procedure B, then only values for Ports 1 and 2 need to be written. If a test set controller board has been replaced, then values for all four ports must be written for an N5262A.

Disable writing via the slide switch when this procedure is complete.

## Adjust ALC Levels

### Background

When a component is changed in an RF or LO signal path, it is often necessary to adjust the ALC level for the path. See [Table 2-4 on page 74](#) for required adjustments when a part is replaced.

### PNA and Power Sensor Preparation

A power sensor and power meter must be prepared to make measurements at 8 GHz. This may include calibrating the power sensor with the meter and entering a calibration factor for 8 GHz.

1. Set the PNA to measure S12.
2. Set for CW sweep at 8 GHz.
3. Set the sweep time to 5 seconds.
4. Set the power to -8 dBm.

### ALC level for Port 1 (Procedure Q)

1. Prepare the PNA and Power Sensor as described above.
2. Connect PNA Port 2 to SRC 1 IN.
3. Connect the power sensor to Port 1 RF OUT.
4. Issue the Test Set I/O commands: 32,0 and 0,1 (ALC on and Port 1 RF OUT).
5. Identify the "Port 1 & 2 ALC Amp", see [Figure 2-17 on page 72](#). Identify R7 and R3, see [Figure 2-19 on page 79](#).
6. Adjust R7: turn full CW (may require up to 30 turns) then 5 turns CCW.
7. Adjust R3: adjust for a reading on the power meter of 12.5 dB ( $\pm 0.1$  dBm).


### ALC level for Port 3 (Procedure R)

1. Prepare the PNA and Power Sensor as described above.
2. Connect PNA Port 2 to SRC 2 IN.
3. Connect the power sensor to Port 3 RF OUT.
4. Issue the Test Set I/O commands: 32,0 and 0,16 (ALC on and Port 3 RF OUT).
5. Identify the "Port 3 & 4 ALC Amp," R7 and R3, see [Figure 2-17](#) and [Figure 2-19](#).
6. Adjust R7: turn full CW (may require up to 30 turns) then 5 turns CCW.
7. Adjust R3: adjust for a reading on the power meter of 12.5 dB ( $\pm 0.1$  dBm).

### ALC level for LO (Procedure S)

1. Prepare the PNA and Power Sensor as described on [page 78](#).
2. Connect PNA Port 2 to LO IN on the rear panel of the test set.
3. Connect the power sensor to Port 1 LO OUT.
4. Identify the “LO ALC Amp,” R7 and R3, see [Figure 2-17](#) and [Figure 2-19](#).
5. Adjust R7: turn full CW (may require up to 30 turns) then 5 turns CCW.
6. Adjust R3: adjust for a reading on the power meter of 12 dB ( $\pm 0.1$  dBm).

Figure 2-19 Mod Amp Identifiers



## Safety and Information

### Introduction

Review this product and related documentation to familiarize yourself with safety markings and instructions before you operate the instrument.

This product has been designed and tested in accordance with accepted industry standards, and has been supplied in a safe condition. The documentation contains information and warnings that must be followed by the user to ensure safe operation and to maintain the product in a safe condition.

### Safety Earth Ground

---

**WARNING** This is a Safety Class I Product (provided with a protective earthing ground incorporated in the power cord). The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. Any interruption of the protective conductor inside or outside of the product is likely to make the product dangerous. Intentional interruption is prohibited.

---

**CAUTION** Always use the three prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage and the risk of electrical shock.

---

### Declaration of Conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Keysight Regulatory Website. Click on "Declarations of Conformity" and enter your product number to find the latest Declaration of Conformity statement.

<http://regulations.about.keysight.com>

### Statement of Compliance

This instrument has been designed and tested in accordance with CAN/CSA 22.2 No. 61010-1-04, UL Std No. 61010-1 (2nd Edition).

## Before Applying Power

Verify that the premises electrical supply is within the range of the instrument. The instrument has an autoranging power supply.

---

**WARNING** If this product is not used as specified, the protection provided by the equipment could be impaired. This product must be used in a normal condition (in which all means for protection are intact) only.

---

**CAUTION** The Mains wiring and connectors shall be compatible with the connector used in the premise electrical system. Failure, to ensure adequate earth grounding by not using the correct components may cause product damage, and serious injury.

---

**CAUTION** Always use the three prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage and the risk of electrical shock.

---

**CAUTION** This product is designed for use in Installation Category II and Pollution Degree.

---

**CAUTION** Before switching on this instrument, make sure the supply voltage is in the specified range.

---

**CAUTION** Verify that the premise electrical voltage supply is within the range specified on the instrument.

---

**CAUTION** Ventilation Requirements: When installing the instrument in a cabinet, the convection into and out of the instrument must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the instrument by 4 °C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, forced convection must be used.

---

---

**WARNING** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended. Discard used batteries according to manufacturer's instructions.

---

**WARNING** For continued protection against fire hazard replace line fuse only with same type and rating. The use of other fuses or material is prohibited.

---

**WARNING** These servicing instructions are for use by qualified personnel only. To avoid electrical shock, do not perform any servicing unless you are qualified to do so.

---

**WARNING** The opening of covers or removal of parts is likely to expose the user to dangerous voltages. Disconnect the instrument from all voltage sources before opening.

---

**WARNING** No operator serviceable parts inside. Refer servicing to qualified personnel. To prevent electrical shock, do not remove covers.

---

**WARNING** The detachable power cord is the instrument disconnecting device. It disconnects the mains circuits from the mains supply before other parts of the instrument. The front panel switch is only a standby switch and is not a LINE switch (disconnecting device).

---

## Connector Care and Cleaning Precautions

Remove the power cord to the instrument. To clean the connectors use alcohol in a well ventilated area. Allow all residual alcohol moisture to evaporate, and fumes to dissipate prior to energizing the instrument.

---

**WARNING** To prevent electrical shock, disconnect the Keysight N5261A or N5262A from mains electrical supply before cleaning. Use a dry cloth or one slightly dampened with water to clean the external case parts. Do not attempt to clean internally.

---

**WARNING** If flammable cleaning materials are used, the material shall not be stored, or left open in the area of the equipment. Adequate ventilation shall be assured to prevent the combustion of fumes, or vapors.

---

## Regulatory Information

This section contains information that is required by various government regulatory agencies.

### Instrument Markings



The instruction documentation symbol. The product is marked with this symbol when it is necessary for the user to refer to the instructions in the documentation.



The AC symbol indicates the required nature of the line module input power.



This symbol indicates separate collection for electrical and electronic equipment, mandated under EU law as of August 13, 2005. All electric and electronic equipment are required to be separated from normal waste for disposal (Reference WEEE Directive, 2002/96/EC).



This symbol indicates that the power line switch is ON.



This symbol indicates that the power line switch is in the STANDBY position.



This symbol indicates that the power line switch is in the OFF position.



This symbol is used to identify a terminal which is internally connected to the product frame or chassis.



The CE mark is a registered trademark of the European Community. (If accompanied by a year, it is when the design was proven.)



The CSA mark is a registered trademark of the CSA International.



This mark designates the product is an Industrial Scientific and Medical Group 1 Class A product (reference CISPR 11, Clause 5)



This is a marking to indicate product compliance with the Canadian Interference-Causing Equipment Standard (ICES-001).



Direct Current.

**IP 2 0**

The instrument has been designed to meet the requirements of IP 2 0 for ingress and operational environment.



The RCM mark is a registered trademark of the Australian Communications and Media Authority



Indicates the time period during which no hazardous or toxic substance elements are expected to leak or deteriorate during normal use. Forty years is the expected useful life of the product.



This symbol on all primary and secondary packaging indicates compliance to China standard GB 18455-2001.



South Korean Certification (KC) mark; includes the marking's identifier code which follows the format: MSIP-REM-YYY-ZZZZZZZZZZZZZZ.

## Battery Collection

Do not throw batteries away but collect as small chemical waste, or in accordance with your country's requirements. You may return the battery to Keysight Technologies for disposal. Refer to **“Contacting Keysight” on page 86** for assistance.

## Electrical Safety Compliance

### SAFETY

Complies with European Low Voltage Directive 2014/35/EU

- IEC/EN 61010-1:2010, 3<sup>rd</sup> Edition
- Canada: CSA C22.2 No. 61010-1-12
- USA: UL std no. 61010-1, 3<sup>rd</sup> Edition
- Acoustic statement (European Machinery Directive 2022/42/EC, 1.7.4.2U)  
Accoustical noise emission  
LpA < 70 dB  
Operator position  
Normal operation mode  
Per ISO 7779

## EMI and EMC Compliance

### EMC

Complies with European EMC Directive 2014/30/EU

- IIEC 61326-1:2012/EN 61326-1:2013
- CISPR Pub 11 Group 1, class A
- AS/NZS CISPR 11:2011
- ICES/NMB-001  
This ISM device complies with Canadian ICES-001.  
Cet appareil ISM est conforme a la norme NMB du Canada.
- South Korean Class A EMC declaration: This equipment is Class A suitable for professional use and is for use in electromagnetic environments outside of the home.

A ( ) (A )  
, 가 .

## Electrostatic Discharge Protection

Electrostatic discharge (ESD) can damage or destroy electronic components. The product is shipped in materials that prevent damage from static, and should only be removed from the packaging in an anti-static area ensuring that the correct anti-static precautions are taken.

Two types of ESD protection are listed below. Purchase acceptable ESD accessories from your local supplier.

- Conductive table-mat and wrist-strap combination
- Conductive floor-mat and heel-strap combination

Both types, when used together, provide a significant level of ESD protection. To ensure user safety, static-safe accessories must provide at least 1 M $\Omega$  of isolation from ground.

---

**WARNING**      These techniques for a static-safe work station should not be used when working on circuitry with a voltage potential greater than 500 volts.

## Keysight Support, Services, and Assistance

### Service and Support Options

There are many other repair and calibration options available from the Keysight Technologies support organization. These options cover a range of service agreements with varying response times. Contact Keysight for additional information on available service agreements for this product.

### Contacting Keysight

Assistance with test and measurement needs, and information on finding a local Keysight office are available on the Internet at:

<http://www.keysight.com/find/assist>

You can also purchase accessories or documentation items on the Internet at:

<http://www.keysight.com/find>

If you do not have access to the Internet, contact your field engineer.

---

**NOTE** In any correspondence or telephone conversation, refer to the Keysight product by its model number and full serial number. With this information, the Keysight representative can determine the warranty status of your unit.

---

### Shipping Your Product to Keysight for Service or Repair

---

**IMPORTANT** Keysight Technologies reserves the right to reformat or replace the internal hard disk drive in your analyzer as part of its repair. This will erase all user information stored on the hard disk. It is imperative, therefore, that you make a backup copy of your critical test data located on the analyzer's hard disk before shipping it to Keysight for repair.

---

If you wish to send your instrument to Keysight Technologies for service or repair:

- Include a complete description of the service requested or of the failure and a description of any failed test and any error message.
- Remove and retain the front handles and all rack mount hardware. The analyzer should be sent to Keysight in the same configuration as it was originally shipped.
- Remove and retain the front handles and all rack mount hardware. The analyzer should be sent to Keysight in the same configuration as it was originally shipped.
- Contact Keysight for instructions on where to ship your analyzer.