



LXL Series Hydraulic Slide Gate Operators

INSTALLATION MANUAL



Model No.: _____

Serial No.: _____

B&B ARMOR

Corporate Office & Tech Support:

2009 Chenault Drive Suite 114

Carrollton, TX 75006

Phone: (800) 367-0387

Fax: (972) 385-9887

E-mail: info@bb-armr.com

techsupport@bb-armr.com

www.bb-armr.com

MADE IN THE USA



Your safety is extremely important to us. If you have any questions or are in doubt about any aspect of the equipment, please contact us.

Introduction

Welcome!

Congratulations on your purchase of a B&B ARMR gate operator. In addition to providing detailed operating instructions, this manual describes how to install, maintain, and troubleshoot your operator. If you require additional assistance with any aspect of installation or operation, please contact us.

Safety



SYMBOL MEANING:



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of non insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instruction in the literature accompanying the product.

Important Safety Information

TO REDUCE THE RISK OF SERIOUS INJURY OR DEATH, READ AND FOLLOW ALL INSTRUCTIONS PROVIDED IN THIS MANUAL.

1. Hydraulic slide gate operators are intended for vehicular use only. Pedestrians should use a separate walkthrough entrance designed for on-foot traffic.
2. Keep children away from gate movement area and off the gate operator. Never let children operate or play with gate controls.
3. Install all warning signs provided with the gate operator so that they are clearly visible from both sides of the gate.
4. It is the responsibility of the specifier, designer, purchaser, installer and end-user to ensure the gate system is properly configured for its intended application.
5. Use the emergency manual release only when the gate is not in motion.
6. Test gate operator and all related safety devices monthly. The gate must reverse or stop when a safety device is tripped. The gate must stop upon sensing a second sequential safety violation before reaching a limit switch. If the gate utilizes a transmitting device on a safety edge, check the battery on a regular basis to ensure proper operation. Failure to adjust and re-test the gate operator properly can increase the risk of injury.
7. This gate operator utilizes a pumping system which contains hydraulic fluid. Consult local EPA (Environmental Protection Agency) regulations for damming requirements (if any) around the base of the gate operator.
8. Service and maintenance of the gate operator should be performed on a routine basis by a qualified technician. Attempts to service the gate equipment by non-qualified personnel could result in serious injury and will void all applicable warranties.

SAVE THESE INSTRUCTIONS.

THIS MANUAL SHOULD BE LEFT WITH A RESPONSIBLE INDIVIDUAL AT THE INSTALLATION SITE AND KEPT IN A DESIGNATED LOCATION FOR MAINTENANCE OR TROUBLESHOOTING OPERATIONS

How to Contact Us

If you have any questions or experience any problems with your vehicle barrier—or if we can help you with any other facility security issues—please contact us directly at:

Corporate/Tech Support:**B&B ARMR**

2009 Chenault Drive Suite 114

Carrollton, TX 75006 USA

Telephone: (972) 385-7899

Toll Free: (800) 367-0387

Fax: (972) 385-9887

E-mail: info@bb-armr.comtechsupport@bb-armr.com

System Installation Record

To assist in documenting the products installed in your system, please take a minute to record the following reference information. This information can be located on the blue B&B ARMR model number plate located on the product.

Additional columns are added for your convenience in documenting other components in the system.

Site:			
Job #:			
Date:			
Serial Number:			
Model Number:			
Voltage:			
Phase:			

Table of Contents

Introduction	2
Safety	2
How to Contact Us	4
System Installation Record.....	4
1. UL 325 And Gate Operators.....	7
1.1 What Is UL?	7
1.2 Development Of UL-325	7
1.3 Overview Of UL-325 And Gates	7
1.4 Gate Operator Classifications	8
2. Effect On Installation	10
2.1 Factors Related To Gate Construction And Installation.....	10
2.2 Device-Specific Installation Instructions	10
2.3 Statements In Manufacturer's Instructions Concerning Installation	11
2.4 Gate And Fence Dealer Documentation Suggestions	11
3. LXL Operator Models And Features	12
3.1 General Description.....	12
3.2 LXL Operator Features.....	12
3.3 Models Available.....	13
4. Installing and Programming the LXL Operator	14
4.1 Prepare Concrete Pad.....	14
4.2 Anchor Gate Operator To Pad.....	14
4.3 Mount Drive Rail.....	15
4.4 Install Limit Switch Trip Plates.....	15
4.5 Connect Primary Power.....	16
4.6 Install Limit Switches	16
4.7 Connect Primary / Battery Power D/C Units Only	17
4.8 Connect Converter To Operator	17
4.9 Install Vent Cap.....	17
4.10 Set Operator Handing (Inside Looking Out).....	18
4.10.1 HCMSGOFF Parameter	18
4.11 Setting The Date And Time (optional, not required)	19
4.12 Setting The Max Run Timer	19

4.13	Turning ON / OFF The Timer To Close	20
4.14	Setting The Timer To Close	20
4.15	Setting The Inherent Safety.....	21
4.16	Setting the Gate Locking Device	21
4.16.1	Self Latching Lock Parameter.....	21
4.16.2	Maglock Parameter	22
4.16.3	Maglock Delay Parameter.....	22
4.17	Maintain Input Parameters	22
4.17.1	MAINOPEN Parameter	23
6.	The LXL Interface Board.....	24
7.	Secondary Safety Devices.....	25
8.	Master Slave Connections	26
9.	Other Device Connections	27
10.	Appendix	28
2.1	General Parts Breakdown.....	29
2.2	Battery Backup Schematic.....	31
11.	Troubleshooting.....	39
2.3	Alarm Definitions	39
2.4	PLC Input/Output Definitions	39
2.5	Equipment Maintenance Log Form.....	42
12.	Warranty Information.....	43

1. UL 325 And Gate Operators

1.1 What Is UL?

Underwriters Laboratories, Inc., a non-profit organization established in 1894, is self-described as “the leading third-party certification organization in the United States and the largest in North America.” UL’s primary stated mission is “to evaluate products in the interest of public safety.” Note that while UL declares it is the “leading” third-party certification, it is not the only one. There are other testing laboratories and certification organizations in the United States.

1.2 Development Of UL-325

The first edition of UL-325 was released in 1973. That edition was primarily focused on the electric operation of garage doors and did not contain provisions for gates. After federal laws were enacted in the early 1990’s, citing the provisions of UL-325 as applicable to garage door operation, DASMA members of the gate operator industry initiated the inclusion of electric gate operator provisions in UL-325. Some government agencies and other interested groups have monitored the standard’s progress and have provided input on the final format of the provisions of the standard that relate to gate operators.

1.3 Overview Of UL-325 And Gates

Highlights of UL-325 include the following:

- A glossary which defines each type of operator
- Different “classes” of gate operators
- Entrapment¹ protection criteria for each “class” of operator
- Entrapment alarm criteria
- Requirements for gate construction and installation
- Instructional requirements placing increased responsibility on installers

A key part of the UL-325 standard is a table that summarizes the entrapment device options for different classes of operators of the various types of gates included in the standard. The table, labeled “Table 31.1”, is reproduced here from the 5th edition of the *Standard for Safety for Door, Drapery, Gate, Louver, and Window Operators and Systems, UL-325*. It is reprinted with the permission of Underwriters Laboratories, Inc. Refer to the table as you read about the provisions that are described in the following sections.

1. In this document, “entrapment” is defined as “the condition when an object is caught or held in a position that increases the risk of injury.”



PROTECTION AGAINST ENTRAPMENT				
VEHICULAR USAGE CLASS	GATE OPERATOR CATEGORY			
	Horizontal Slide VERTICAL LIFT VERTICAL PIVOT		SWING GATE VERTICAL BARRIER (ARM)	
	PRIMARY TYPE	SECONDARY TYPE	PRIMARY TYPE	SECONDARY TYPE
Class I & II	A	B1,B2 or D	A or C	A,B1,B2,C or D
Class III	A,B1 or B2	A,B1,B2,D or E	A,B1,B2 or C	A,B1,B2,C,D or E
Class IV	A,B1,B2 or D	A,B1,B2,D or E	A,B1,B2,C or D	A,B1,B2,C,D or E
<p>NOTE: The same type of device shall not be utilized for both the primary and secondary entrapment protection means. Use of a single device to cover both the openings and closing directions is in accordance with this requirement; however, a single device is not required to cover both directions. A combination of one Type B1 for one direction and one Type B2 for the other direction is the equivalent of one device for the purpose of complying with the requirements of either the primary or secondary entrapment protection means. Entrapment protection types:</p> <p>Type A - Inherent entrapment sensing system. See 31.1.5</p> <p>Type B1 - Provision for connection of, or supplied with, a non-contact sensor (photoelectric sensor or the equivalent). See 31.1.6-31.1.9.</p> <p>Type B2 - Provision for connection of, or supplied with, a contact sensor (edge device or equivalent). See 31.1.7 and 31.1.10 - 31.1.12.</p> <p>Type C - Inherent adjustable clutch or pressure relief device. See 31.1.13.</p> <p>Type D - Provision for connection of, or supplied with, an actuating device requiring continuous pressure to maintain opening or closing motion of the gate. See 31.1.14 and 31.1.15.</p> <p>Type E - An inherent audio alarm. See 31.1.16, 31.1.17 and 31.1.18.</p> <p><i>This table is re-created from the 5th edition of the Standard for Safety for door, drapery, gate, louver, and Window Operators and Systems, UL-325, and is reprinted with permission of Underwriters Laboratories, Inc.</i></p>				

1.4 Gate Operator Classifications

Four distinct types of classifications have been established:

- Class I: Residential usage, covering one to four single-family dwellings.
- Class II: Commercial usage where general public access is expected; a common application would be a public parking lot or gated community.
- Class III: Industrial usage where limited access is expected; one example is a warehouse property entrance not intended to serve the general public.
- Class IV: Restricted access; this includes applications such as a prison entrance that is monitored either in person or via closed circuit television.

Gate speed shall be no greater than 1 foot per second in Class I and II applications.

**Figure 1 Non-Contact Sensor Detail****Figure 2 Contact Sensor Detail**

2. Effect On Installation

These provisions will have several effects on gate and fence dealers:

- Gate and fence dealers should look for an indication of the Class of each operator, which will be specified by the gate operator manufacturer.
- Fence dealer sales personnel must match the site application with the Class of operator. The gate operator manufacturer should be contacted if there is any question about the site application.
- Both primary and secondary safety devices must be provided and matched to both the operator and site conditions. Although the gate operator manufacturer may provide or specify these devices, the gate/fence dealer should insure that they are installed and correctly matched. Any questions again should be directed to the gate operator manufacturer.
- Warning signs must be permanently affixed to the gate panel. UL-325 includes specific requirements on the format, content, and placement of these signs.

2.1 Factors Related To Gate Construction And Installation

- Vehicular gate operators should ONLY be used on vehicular gates and never pedestrian gates.
- A sliding gate should work smoothly with easy rolling/movement in both directions, with all exposed pinch points eliminated or guarded, prior to the installation of the operator.
- Controls should be as far away from the gate as possible to prevent “reach-through” occurrences.
- All openings of the horizontal slide gate must be guarded and screened from the bottom of the gate to a minimum of 4' above the ground to prevent a 2 1/4" diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.
- A minimum of 2 warning signs and placards must be installed and be visible in the area of the gate.
- All high and low voltage wire runs must comply with local electrical codes.

2.2 Device-Specific Installation Instructions

There are also specific installation requirements for certain types of entrapment protection devices. These specific requirements emphasize the care and attention that each device must be given prior to and during installation.

For gate operators utilizing non-contact sensor devices (Type B1), instructions should be consulted for placement for each application, care should be exercised to reduce the risk of nuisance tripping, and one or more of these devices must be installed where the risk of entrapment or obstruction exists.

For gate operators utilizing contact sensor devices (Type B2), several requirements are spelled out in UL-325. One or more contact sensors shall be located:

- at the leading edge, the trailing edge, and also post-mounted both inside and outside of, a vehicular horizontal slide gate;
- at the bottom edge of a vehicular vertical slide gate; and
- at the entrapment point of a vehicular vertical pivot gate.

A wired contact sensor shall be located, and its wiring arranged, so that communication between sensor and gate operator is not subjected to mechanical damage. A wireless contact sensor shall be located where the transmission of the signals is not obstructed or impeded by building structures, natural landscaping, or similar obstructions, and shall function under the intended end use conditions.

For operators utilizing continuous pressure activating device (type D), controls must be placed so that the user has full view of the gate area when the gate is moving. A placard must be placed adjacent to the controls and no other activation devices shall be connected. Most importantly, an automatic closing device shall not be employed.

2.3 Statements In Manufacturer's Instructions Concerning Installation

Gate and fence dealers can expect to see in gate operator instructions the following statements:

1. The operator must be appropriate for the construction of the gate and the usage class of the gate. The appropriate primary and secondary safety devices to be used are a major consideration to support this requirement.
2. All openings of a horizontal slide gate, and the portion of the fence where the slide gate passes, must be guarded or screened. These specific requirements in UL-325 that govern this provision were developed to address “reach-through” occurrences. For example, slide gates must have a protective cover 48 inches in height extending from the bottom of the gate/fence panel.
3. All exposed entrapment points must be eliminated or guarded. It is up to the individual gate and fence dealers to identify these points on a product-by-product basis, or on a job-by-job basis.
4. Guarding must be supplied for exposed rollers. Exposed rollers are regarded as potential pinch points.

2.4 Gate And Fence Dealer Documentation Suggestions

In dealing with the effects of the new provisions, here are some suggestions gate and fence dealers may consider to expand their documentation of gate projects. One possibility is to visually document, either via photography or videotape, the complete gate installation including applicable signs and labels, and the owner receiving the instruction manual from the installer. Other options could include the development and use of an installation checklist, a consumer sign-off form, and a service/preventative maintenance contract.

3. LXL Operator Models And Features

3.1 General Description

B&B ARMR's model LXL hydraulic sliding gate operator is designed to reliably operate many styles of sliding gates, including overhead track, ground track, and cantilever style gates. Our LXL series of operators are designed to operate in all four UL-325 classes of operators. The operator is unobtrusive in appearance, yet durable under heavy use. The design of the LXL Series incorporates numerous features intended to improve safety, maintain security, increase reliability and reduce maintenance.

The operator actuates the gate by two rotating wheels (the LXL uses an idler wheel and pinion gear). A drive rail bolted to the gate is drawn between the two drive wheels. The wheels are spring loaded against the drive rail to produce a positive friction feed in both directions. Spring loading the wheels also serves to correct for wheel wear. The drive wheels are rotated by series-connected hydraulic motors to minimize uneven rotation between the wheels.

Rotation direction is determined by the hydraulic valve system, not by the rotational direction of the electric motor. Independence from the electric motor rotation has the advantage that the direction of gate travel can be instantly reversed without the use of brakes. Also, the hydraulic valve, when not energized, rests in the neutral position. This effectively locks the hydraulic system, drive wheels, and the gate in the stopped position. Controls operate on safe and reliable 24VDC regulated voltage.

3.2 LXL Operator Features

The LXL hydraulic slide gate operator incorporates the following features and options:

- Designed to meet UL-325 Class I-IV.
- Inherent entrapment sensing on all units
- Simple user interface utilizes a 12x4 character LCD display
- User-Programmable right-hand to left-hand conversion; no hose swapping required
- Delay on reverse standard
- 24VAC and 24VDC auxiliary control power
- Low maintenance - No sprockets, chains, or pulleys to adjust
- Built-in, fully adjustable maximum run and auto close timers
- Soft start / soft stop (option)
- Plug-in loop detectors (option)
- Hand-operated, quick release drive system for manual operation
- Master/slave capability
- Interlocking capability
- Proximity limit switches eliminate false tripping due to misaligned drive rail

3.3 Models Available

NOTE: To order any of the LXL models, substitute the required input voltage for the "v" and the required input phase for "p".

Typical Available Models	Travel Speed	Gate Size	Pull Force	UL Class
LXL-15vp-SS Standard Speed	1.0 ft/s	2,000 lbs	400 lbs	I-IV
LXL-15vp-HS High Speed	2.0 ft/s	1,000 lbs	300 lbs	III & IV
LXL-20vp-HD Heavy Duty	1.0 ft/s	3,000 lbs	600 lbs	I-IV
LXLR-15vp-SS Rack & Pinion	1.0 ft/s	3,000 lbs	350 lbs	I-IV
LXLR-20vp-HD Rack & Pinion	1.0 ft/s	4,700 lbs	450 lbs	I-IV
LXLB-13vp-SS Battery Back-up	1.0 ft/s	2,000 lbs	350 lbs	I-IV
LXLB-13vp-HS Battery Back-up High Speed	1.0 ft/s	1,000 lbs	350 lbs	III & IV
LXLD-20vp-SS Extra Heavy Duty	0.8 ft/s	20,000 lbs	1,700 lbs	I-IV
LXLT-30vp-SS Extreme Heavy Duty	0.8ft/s	25,000 lbs	1,800 lbs	III-IV

a. Travel speed on all operators limited to 1 foot per second in Class I and II applications.


Other models for extra heavy-duty operation are available for extremely long and heavy gates. Contact your local distributor or the factory for more information.

4. Installing and Programming the LXL Operator


Installation and programming of the LXL series gate operators can be accomplished in a few easy steps. The following illustrations will guide you through the process of mounting the operator and drive rail, connecting power and programming the LXL controller functions.

NOTE: Installation of the gate operator requires connection of high voltage power, which should only be performed by a licensed electrician.


4.1 Prepare Concrete Pad

 <p>The diagram shows a side view of the concrete pad with the following dimensions and labels:</p> <ul style="list-style-type: none"> 27.125: Total width of the pad. 25.875 MTG. DIM.: Mounting dimension from the gate side to the center of the drive wheels. 3.00: Distance from the gate side to the center of the drive wheels. 4.00 x 6.00 CONDUIT ENTRANCE: Dimensions of the conduit entrance. .625 x 1.00 SLOTTED HOLES (4): Dimensions and quantity of the mounting holes. 5.50: Distance from the top of the pad to the center of the drive wheels. 15.000 MTG. DIM.: Mounting dimension from the bottom of the pad to the center of the drive wheels. 19.00: Total height of the pad. 	<ol style="list-style-type: none"> 1. Pour concrete pad 24"W x 36"L and at least 6" below frost line. 2. Conduit needs to be installed so that the conduit stubs up in the operators supplied conduit entrance. 3. Allow concrete to cure before attempting to anchor gate operator to the pad.
---	--

4.2 Anchor Gate Operator To Pad


 <p>The diagram shows the gate operator being anchored to the concrete pad with the following labels:</p> <ul style="list-style-type: none"> ANCHOR BOLTS(4): Four bolts used to secure the operator to the pad. CONCRETE PAD: The base for the operator. CONDUIT: The conduit used for power supply. 	<ol style="list-style-type: none"> 1. Double-check 3" measurement from face of gate to center of drive wheels and ensure operator is parallel with the gate panel. 2. Drill 4 anchor bolt holes (1/2"x6"). It is not necessary to move the operator. 3. Drive anchor bolts into holes, being careful not to damage bolt threads. 4. Tighten nuts.
--	---

4.3 Mount Drive Rail



1. Place gate operator on the pad and measure 3" from the face of a vertical gate member to center of the wheels.
2. With the drive wheels disengaged, slide the drive rail between the wheels, to the closed position.
3. Align the drive rail with a clearance of 12.375 inches from the base of the operator to the center of the drive rail. Attach drive rail to the vertical member closest to the operator. Slide gate open and repeat for each vertical member.
4. Close the gate. With the drive wheels disengaged, slide the drive rail between the open and closed limit and verify that the drive rail is level. Also verify that the drive rail is equidistant from the drive wheels.

4.4 Install Limit Switch Trip Plates




1. Slide the gate to the full open position.
2. On the top of the drive rail, place a trip plate so that the last 2" is in front of the proximity switch.
3. Mark and drill holes. Mount limit switch as shown under drive rail.
4. Repeat for the close position


Note: Maintain a distance of 1/4" between proximity switch and limit plate. Adjust switch away from operator if necessary.

4.5 Connect Primary Power


Connecting the Primary Power should be performed by a license electrician. The primary power must have a circuit breaker in-line from power source in accordance to NEC.

	<p>A/C UNITS ONLY FOR D/C UNITS, GO TO STEP 4.7-4.8</p> <ol style="list-style-type: none"> 1. Connect the primary power as shown in the illustration. 2. Earth ground the operator. THIS IS NOT AN OPTION! 3. Drive a solid copper rod at least 36" into the ground. 4. Using a #10 solid copper wire, connect ground wire from the rod to the ground lug located in the main power disconnect box.
---	---

4.6 Install Limit Switches


	<ol style="list-style-type: none"> 1. Insert the limit wired into the A limit on the board into the whole marked LIMIT A. 2. Adjust the limit so that it is approximately 1/4" away from the trip plate and leave a little room to adjust. 3. Disengage the drive wheels. Turn on the operator and move the gate trip plate in front of the limit and adjust the limit in or out until the limit senses the trip plate. 4. Tighten the limit in place. 5. Repeat for the B limit. 6. CONTINUE TO STEP 4.9 <p>Note: on the supplied limits, a red light will light up on the back of the limit when it senses the trip plate.</p>
---	---

4.7 Connect Primary / Battery Power D/C Units Only




1. Connect the primary power to switch S1B and the batteries to switch S1A in the converter enclosure.
2. Earth ground the enclosure.
THIS IS NOT AN OPTION!
3. Drive a solid copper rod at least 36" into the ground.
4. Using a #10 solid copper wire, connect ground wire from the rod to the ground lug located in the control cubicle.

4.8 Connect Converter To Operator



1. Connect the converter enclosure to switch S4 in the gate operator using #6 AWG wire.
2. Earth ground the operator. **THIS IS NOT AN OPTION!**
3. Drive a solid copper rod at least 36" into the ground.
4. Using a #10 solid copper wire, connect ground wire from the rod to the ground lug located in the operator.

4.9 Install Vent Cap



1. Locate the red plug on the hydraulic reservoir.
2. Remove the red plug and replace with the supplied vent cap.
3. Keep the red plug should removal of the vent cap be necessary.


4.10 Set Operator Handing (Inside Looking Out)

<p>3 BUTTON CONTROL STATION</p> <p>RIGHT HAND OPERATION</p> <p>OUTSIDE INSIDE</p> <p>OPERATOR</p> <p>LEFT HAND OPERATION</p> <p>OUTSIDE INSIDE</p> <p>OPERATOR</p> <p>The diagram shows a 3-button control station with buttons labeled OPEN, CLOSE, and STOP. Arrows indicate the sequence of button presses for setting the handing. For Right Hand Operation, the gate moves from INSIDE to OUTSIDE. For Left Hand Operation, the gate moves from OUTSIDE to INSIDE.</p>	<ol style="list-style-type: none"> 1. With power off, move the gate to the close position with the limit plate in front of the close limit switch. 2. While holding down STOP and CLOSE buttons on supplied 3 button station, turn operator power on. 3. Wait for the alarm to sound (date and time will flash on first power up), then release the STOP and CLOSE buttons. Handing is now set.
--	--


4.10.1 HCMSGOFF Parameter

<p>The screenshot shows a menu with the text 'HCMSGOFF' and 'Switch-Off'. Below the text is a diamond-shaped navigation pad with four arrows. At the bottom of the screen are two buttons labeled 'ESC' and 'OK'.</p>	<p>The LXL operator now has the ability to display a message if the Handing has been changed. To enable this setting;</p> <ol style="list-style-type: none"> 1. From the main menu, select 'Set Param'. 1. Press the UP grey arrow key and scroll through the options to HCMSGOFF 2. Press OK. 3. The S on Switch will start flashing 4. Use the arrow keys to Off to On 5. Press OK to save
---	--


Setting The Date And Time (optional, not required)

	<ol style="list-style-type: none"> 1. Turn power on. Date and time will be flashing. Press the ESC key. 2. This is the main menu. Use the UP and DOWN arrow keys to select 'Set Clock', and press the OK button. 3. Press OK again. A cursor flashes under the parameter to be changed. 4. Use the UP and DOWN arrow keys to change the value. Use the LEFT and RIGHT arrow keys to move between lines. 5. Press OK when finished. <p>NOTE: *Time format is military time only.</p>
--	--

4.11 Setting The Max Run Timer

 <p data-bbox="618 1549 878 1623">Bottom number shows elapsed time.</p>	<ol style="list-style-type: none"> 1. From the main menu, select 'Set Param'. 2. Use the UP arrow to scroll to the MAX RUN screen and press OK. 3. Press OK again to activate cursor. 4. Use the arrow keys to set the desired time. 5. Press OK to save <p>Note: Max run time = gate length ÷ gate speed * 2 + 5 seconds</p>
--	--

4.12 Turning ON / OFF The Timer To Close




With the unit powered down and the gate in the closed position, locate the supplied 3 button control station and do the following (in order):

1. Press and hold the STOP button
2. While holding the STOP button, press and hold the CLOSE button.
3. While holding the STOP and CLOSE buttons, press and release the OPEN button.
4. Release the CLOSE button, then the STOP button.
5. Trigger the open limit switch. If the timer is on, you will see the screen to the left.
6. Repeat step 1 to toggle the timer off

NOTE: The AutoClose screen will not be visible if the timer is turned off

There is a 3 minute window with which to turn the timer to close on or off each time the operator power is turned on.


4.13 Setting The Timer To Close



1. From the main menu, select 'Set Param'.
2. Use the UP arrow to scroll to the AUTO CLS screen and press OK.
3. Press OK again to activate cursor. Use the arrow keys to set the desired time.
4. Press OK to save


Note: s = seconds, m = minutes, h = hours

4.14 Setting The Inherent Safety


	<ol style="list-style-type: none"> 1. Press the ESC button to return to the main menu. 2. Engage the drive wheels on the drive rail. Open and Close the operator using the 3 button control station. The screen on the left will appear. 3. While the gate is running, pay attention to the SYSTEM PRESS value. This is the amount of pressure required to move the gate. 4. Stop the gate operator and press the ESC button to enter the main menu. 5. Select 'Set Param' and use the UP arrow key to scroll to SAFE PSI. 6. Press OK to activate the cursor. Enter the On value (SYSTEM PRESS+30), then the Off value (On-10). 7. Press OK to save and return to the main menu.
---	--

4.15 Setting the Gate Locking Device


4.15.1 Self Latching Lock Parameter

	<ol style="list-style-type: none"> 1. From the main menu, select 'Set Param'. 2. UNLOCK will be the first user parameter, press OK. 3. The S on Switch will start flashing 4. Use the UP grey arrow key to change Off to On 5. Press OK to save <p>Now you will need to wire in the self latching lock as shown on page 40</p>
---	---

4.15.2 Maglock Parameter

	<ol style="list-style-type: none"> 1. From the main menu, select 'Set Param'. 2. Press the UP grey arrow key and scroll through the options to MAGLOCK? 3. Press OK. 4. The S on Switch will start flashing 5. Use the arrow keys to Off to On 6. Press OK to save <p>Now you will need to wire in the maglock as shown on page 40</p>
---	--


4.15.3 Maglock Delay Parameter


	<p>When using a Maglock you have an option to change a delay from when the close limit is made and the voltage being applied to the maglock. Default is 1 second. To change this setting;</p> <ol style="list-style-type: none"> 1. From the main menu, select 'Set Param'. 1. Press the UP grey arrow key and scroll through the options to MAGDELAY 2. Press OK. 3. The 0 on the T line will start flashing 4. Use the UP grey arrow keys toggle value. 5. Use the RIGHT or LEFT grey arrow keys to move with the time frame 6. Once desired time is entered 7. Press OK to save <p>Note: s = seconds, m = minutes, h = hours</p>
--	---


4.16 Maintain Input Parameters

The inputs that cause the gate to open or close has a feature where you can enable or disable a maintain command. These inputs are Open, Close, Open/Close, and Int Open. Meaning that you can change the command from a pulsed input to a hold until complete command or set a time which has to be maintain before input is recognized as a valid input.


4.16.1 MAINOPEN Parameter

	<ol style="list-style-type: none"> 5. From the main menu, select 'Set Param'. 2. Press the UP grey arrow key and scroll through the options to MAINOPEN 3. Press OK. 4. The S on Switch will start flashing 5. Use the arrow keys to Off to On 6. Press OK to save 7. You can now set the maintain time <p>Changing the Switch to On enables the Maintain Open command</p>
---	---

	<ol style="list-style-type: none"> 1. From the main menu, select 'Set Param'. 8. Press the UP grey arrow key and scroll through the options to MANCLOSE 9. Press OK. 10. The S on Switch will start flashing 11. Use the arrow keys to Off to On 12. Press OK to save <p>Changing the Switch to On enables the Maintain Close command</p>
--	---

	<ol style="list-style-type: none"> 2. From the main menu, select 'Set Param'. 13. Press the UP grey arrow key and scroll through the options to MAINOPEN 14. Press OK. 15. The S on Switch will start flashing 16. Use the arrow keys to Off to On 17. Press OK to save <p>Changing the Switch to On enables the Maintain Open command</p>
---	--

6. The LXL Interface Board




- 1 24VAC/24VDC auxiliary power
- 2 Processor/Controller
- 3 Built-in 3 button station
- 4 Position indication and power loss relays
- 5 Secondary safety device connections
- 6 Control inputs (open devices, safety loops, etc.)
- 7 Input power for control board
- 8 Contactor output

- 9 1 amp fuse (processor protection)
- 10 Factory connections

7. Secondary Safety Devices

Connecting safety devices to the secondary safety connectors will stop the gate on the detection of the safety and proceed in the event of clearing the safety. To reverse the gate on the event of a safety, you must connect the safety device to the loopsafe terminal on connector 3.

INFRARED BEAMS




IMPORTANT NOTE:

UL 325 approved secondary safety devices **MUST** be used for the gate installation to comply with the requirements of UL 325.

Refer to the UL approved manufacturer's documentation for proper installation of secondary safety devices.

SAFETY EDGES



*Note: The ROAD and BACK connections are normally open connections

UL Approved Secondary Safety Devices:


Miller Edge - manufacturer of contact sensors for all types of gates (800-220-EDGE).

website: <http://www.milleredge.com>

EMX Industries - manufacturer of non-contact sensors for gates (800-426-9912).


website: [http:// www.emxinc.com](http://www.emxinc.com)

8. Master Slave Connections



- ☐ 10 conductors required for master / slave connection between operators (16-18 gauge wire), plus 4 for safety devices
- ☐ Each operator must be programmed separately
- ☐ Secondary safety devices must be connected to their respective operators for proper operation, and to ensure UL 325 compliance

9. Other Device Connections



10. Appendix

** Note: There are some changes in the drawing below. Standard speed setup is shown. For high speed and rack and pinion users please note that these item numbers are different:

Number 31 will be XHYD-103-1572 for standard and high speed units

Number 31 will be 0050-RS-1001010 for rack and pinion units


Number 9 will be XHYD-M406-0103 for high speed units

*Also, note for electrical components such as transformers or motors your voltage and phase may change the part number required




LXL electrical cubical


2.1 General Parts Breakdown



Typical Installation



2.2 Battery Backup Schematic



NOTES:

1. ONLY BATT B (-) TERMINAL IS TIED TO EARTH GROUND (NOT BATT A)
2. JUMPER BETWEEN 2-12V BATTERIES IS ON BATTERIES

Battery backup Parts List

ITEM	QTY	B&B ARMR #	DESCRIPTION
1	1	XTRAN-416-1181	3KVA TRANSFORMER
2	1	XSOL-124-114111	24VDC
3	1	XCHGR-CT500-3	SOLENOID 230V 3A BATTERY
4	1	XBRKR-Q0U260	CHARGER 60A CIRCUIT BREAKER
5	1	XBRKR-Q0U220 XBRKR-Q0U240	20A CIRCUIT BREAKER (FOR 240V) 40A CIRCUIT BREAKER (FOR 120V)
6	1	XCAP-34000/40	34000uF CAPACITOR
7	1	YR838-M50100SB	100A RECTIFIER
8	1	XLUG-LAM2A1/0	GROUND LUG
9	1	XRLY-2W929	24vac RELAY

DRAWING: ± 0.5 015	DRWN:	M. Heuer	Sept. 19 2006	B&B ARMR
	ENGR:			
	PART:	0054-2019		
	©COPYRIGHT 06-Jun-06 B&B ARMR ALL RIGHTS RESERVED			
	THIS DOCUMENT AND THE INFORMATION IT CONTAINS SHALL NOT BE COPIED IN WHOLE OR PART WITHOUT THE EXPRESSED WRITTEN CONSENT OF B&B ARMR.			
	SIZE	FSCM NO.	DWG NO:	REV.
	B		XLBBU-CT-MAN	B
	SCALE: _____		DO NOT SCALE PRINT	SHEET 1 OF 1

Battery Backup Input (1 ?)						
HP	Voltage Amps	Wire Gauge	mm ²	Single Operator	Dual Operators	
0.4	115 V	12	3.309	120	60	
	4.6 A.A.C	10	5.261	200	100	
0.4	22.04 A.D.C	8	8.366	320	160	
	208 V	6	13.302	520	260	
0.4	208 V	12	3.309	430	215	
	2.5 A.A.C	10	5.261	680	340	
0.4	21.67 A.D.C	8	8.366	1090	545	
	230 V	6	13.302	1730	865	
0.4	230 V	12	3.309	510	255	
	2.3 A.A.C	10	5.261	820	410	
0.4	22.04 A.D.C	8	8.366	1310	655	
	230 V	6	13.302	2090	1045	
0.75	115 V	12	3.309	90	45	
	6.9 A.A.C	10	5.261	140	70	
0.75	33.06 A.D.C	8	8.366	230	115	
	208 V	6	13.302	360	180	
0.75	208 V	12	3.309	290	145	
	3.8 A.A.C	10	5.261	470	235	
0.75	32.93 A.D.C	8	8.366	750	375	
	230 V	6	13.302	1200	600	
0.75	230 V	12	3.309	370	185	
	3.4 A.A.C	10	5.261	580	290	
0.75	32.58 A.D.C	8	8.366	930	465	
	230 V	6	13.302	1490	745	
1.3	115 V	12	3.309	50	25	
	13 A.A.C	10	5.261	80	40	
1.3	62.29 A.D.C	8	8.366	120	60	
	208 V	6	13.302	200	100	
1.3	208 V	12	3.309	160	80	
	7.2 A.A.C	10	5.261	260	130	
1.3	62.40 A.D.C	8	8.366	420	210	
	230 V	6	13.302	670	335	
1.3	230 V	12	3.309	190	95	
	6.7 A.A.C	10	5.261	310	155	
1.3	64.21 A.D.C	8	8.366	500	250	
	230 V	6	13.302	800	400	

AWG Stranded Wire Resistance			
Size	Diameter	mm	R @ 77°F
AWG	mm ²	mm	Ohms /100'
28	0.081	14.6	66.14
26	0.129	0.468	41.76
24	0.205	0.59	26.18
22	0.326	0.744	16.46
20	0.518	0.938	10.36
18	0.823	1.152	6.52
16	1.309	1.491	4.08
14	2.081	1.88	2.58
12	3.309	2.371	1.62
10	4.261	2.989	1.02
8	8.366	3.77	0.64
6	13.3	4.753	0.402


3 ? Power Wiring (Continued)						
HP	Voltage Amps	Wire Gauge	mm ²	Single Operator	Dual Operators	
3	208 V	12	3.309	150	75	
	7.8 A.A.C	10	5.261	240	120	
3	230 V	8	8.366	390	195	
	7.4 A.A.C	6	13.302	620	310	
3	230 V	12	3.309	180	90	
	7.4 A.A.C	10	5.261	280	140	
3	460 V	8	8.366	450	225	
	3.7 A.A.C	6	13.302	730	365	
5	208 V	12	3.309	90	45	
	15 A.A.C	10	5.261	140	70	
5	230 V	8	8.366	230	115	
	13.2 A.A.C	6	13.302	370	185	
5	230 V	12	3.309	110	55	
	13.2 A.A.C	10	5.261	180	90	
5	460 V	8	8.366	280	140	
	6.6 A.A.C	6	13.302	460	230	
5	230 V	12	3.309	150	75	
	6.6 A.A.C	10	5.261	230	115	
5	460 V	8	8.366	370	185	
	6.6 A.A.C	6	13.302	600	300	


Control Wiring			
Voltage	Wire Gauge	Max Distance (ft)	Drop
24 V	28	0.081	450
24 V	26	0.129	710
24 V	24	0.205	1140
24 V	20	0.518	2890
24 V	18	0.823	4600


Notes	
1	Maximum distance is measured from Power Source to Operator
2	Maximum distance for controls is measured from Operator to Pushbutton or other control device
3	If distance to power Source is greater than value shown use a higher voltage or three phase unit or contact utility company for a service feeder
4	If distance to Remote Control device is greater than 2000ft use a range extender device.
5	Power Tables are based on stranded copper wires and allows up to 2% voltage drop
6	Control Table is based on stranded copper wires and allows up to 25% Connect Power per local codes
7	Connect Power per local codes
8	Run Power and Control wiring separately
9	Ampere rating is motor full load; Startup up current may be higher
10	100 VA Allowed for Controls & Heater
11	Wires sizes and resistance is from Mogam
12	0.1 Amps for control current, these may well vary for different models


3 ? Power Wiring						
HP	Voltage Amps	Wire Gauge	mm ²	Single Operator	Dual Operators	
1/2	208 V	12	3.309	510	255	
	2 A.A.C	10	5.261	820	410	
1/2	230 V	8	8.366	1310	655	
	2 A.A.C	6	13.302	2080	1040	
1/2	230 V	12	3.309	580	290	
	2 A.A.C	10	5.261	920	460	
1/2	460 V	8	8.366	1470	735	
	1 A.A.C	6	13.302	2340	1170	
1	208 V	12	3.309	2330	1165	
	3.5 A.A.C	10	5.261	3700	1850	
1	230 V	8	8.366	5900	2950	
	3.2 A.A.C	6	13.302	9390	4695	
1	208 V	12	3.309	320	160	
	3.5 A.A.C	10	5.261	510	255	
1	230 V	8	8.366	810	405	
	3.2 A.A.C	6	13.302	1290	645	
1	230 V	12	3.309	390	195	
	3.2 A.A.C	10	5.261	620	310	
1	460 V	8	8.366	980	490	
	1.6 A.A.C	6	13.302	1570	785	
1	208 V	12	3.309	1560	780	
	1.6 A.A.C	10	5.261	2480	1240	
1	230 V	8	8.366	3950	1975	
	6.2 A.A.C	6	13.302	6290	3145	
1 1/2	208 V	12	3.309	190	95	
	6.2 A.A.C	10	5.261	300	150	
1 1/2	230 V	8	8.366	480	240	
	5.6 A.A.C	6	13.302	770	385	
1 1/2	230 V	12	3.309	230	115	
	5.6 A.A.C	10	5.261	370	185	
1 1/2	460 V	8	8.366	590	295	
	2.8 A.A.C	6	13.302	940	470	
1 1/2	208 V	12	3.309	940	470	
	2.8 A.A.C	10	5.261	1490	745	
2	208 V	12	3.309	2380	1190	
	6.2 A.A.C	10	5.261	3790	1895	
2	230 V	8	8.366	480	240	
	5.6 A.A.C	6	13.302	770	385	
2	230 V	12	3.309	110	55	
	5.6 A.A.C	10	5.261	180	90	
2	460 V	8	8.366	280	140	
	2.8 A.A.C	6	13.302	460	230	
3	208 V	12	3.309	150	75	
	18.7 A.A.C	10	5.261	230	115	
3	230 V	8	8.366	370	185	
	17 A.A.C	6	13.302	600	300	

1 ? Power Wiring						
HP	Voltage Amps	Wire Gauge	mm ²	Single Operator	Dual Operators	
1/2	115 V	12	3.309	80	40	
	7.5 A.A.C	10	5.261	130	65	
1/2	208 V	8	8.366	210	105	
	3.9 A.A.C	6	13.302	340	170	
1/2	230 V	12	3.309	290	145	
	3.9 A.A.C	10	5.261	460	230	
1/2	230 V	8	8.366	740	370	
	3.7 A.A.C	6	13.302	1180	590	
1	230 V	12	3.309	340	170	
	3.7 A.A.C	10	5.261	540	270	
1	230 V	8	8.366	860	430	
	12 A.A.C	6	13.302	1380	690	
1	115 V	12	3.309	50	25	
	12 A.A.C	10	5.261	80	40	
1	208 V	8	8.366	130	65	
	6.4 A.A.C	6	13.302	220	110	
1	230 V	12	3.309	180	90	
	6.4 A.A.C	10	5.261	290	145	
1	230 V	8	8.366	470	235	
	6 A.A.C	6	13.302	750	375	
1 1/2	115 V	12	3.309	220	110	
	15 A.A.C	10	5.261	350	175	
1 1/2	208 V	8	8.366	550	275	
	8.3 A.A.C	6	13.302	880	440	
1 1/2	230 V	12	3.309	140	70	
	8.3 A.A.C	10	5.261	230	115	
1 1/2	230 V	8	8.366	370	185	
	7.5 A.A.C	6	13.302	580	290	
1 1/2	230 V	12	3.309	170	85	
	7.5 A.A.C	10	5.261	280	140	
2	208 V	8	8.366	450	225	
	13.2 A.A.C	6	13.302	720	360	
2	230 V	12	3.309	90	45	
	12 A.A.C	10	5.261	140	70	
2	230 V	8	8.366	230	115	
	12 A.A.C	6	13.302	370	185	
3	208 V	12	3.309	110	55	
	18.7 A.A.C	10	5.261	180	90	
3	230 V	8	8.366	280	140	
	17 A.A.C	6	13.302	460	230	
3	230 V	12	3.309	60	30	
	17 A.A.C	10	5.261	100	50	
3	230 V	8	8.366	160	80	
	17 A.A.C	6	13.302	260	130	
3	230 V	12	3.309	80	40	
	17 A.A.C	10	5.261	120	60	
3	230 V	8	8.366	200	100	
	17 A.A.C	6	13.302	320	160	












FIGURE 2 – USE WITH SELF-LATCHING MECHANISM

FIGURE 1 – USE WITH MAGLOCK

11. Troubleshooting

The table below provides a general guidance on identifying and correcting any problems with your LXL Series gate operator. If you encounter problems that you cannot fix, contact B&B ARM and we will gladly work with you to correct them.

2.3 Alarm Definitions –

Continuous solid beep – Gate is moving or a Stop command is active

5sec On, 1sec Off – MaxRun Time Error

1sec On, 1sec Off – Forward and/or Reverse Safety

0.25sec On, 0.5sec Off – Inherent Safety Error

2.4 PLC Input/Output Definitions –

The screenshot shows a software window titled "Connector Names" with a close button (X) in the top right corner. The window is divided into two main sections: "Input Terminals:" on the left and "Output Terminals:" on the right. Each section contains a list of terminals with their corresponding names. The "Input Terminals" list has 13 items (I1 to I13), and the "Output Terminals" list has 14 items (Q1 to Q14). At the bottom of the window are three buttons: "OK", "Cancel", and "Help".

Input Terminals:		Output Terminals:	
I1	OPEN	Q1	VALVE 1
I2	CLOSE	Q2	VALVE 2
I3	LIMIT A	Q3	MOTOR
I4	LIMIT B	Q4	ALARM
I5	RDWY IR	Q5	UNLOCK (NEG LK)
I6	BACK IR	Q6	LOCK (POS LK)
I7	STP/RST	Q7	
I8	INHERENT SAFETY	Q8	HANDING CHANGED
I9	OPEN/CLS	Q9	
I10	INT OPEN/LOCKPIN UP	Q10	
I11	EMERGENCY OPEN	Q11	
I12	LOOP SAFE	Q12	
I13		Q13	
		Q14	

Symptom	Actions
Gate operator does not respond when commanded.	<ol style="list-style-type: none"> 1. Check CONN 9 for power when command is given. 2. Check overload protector 3. Check PLC output. 4. Check that safeties are clear, and that IR Beams are aligned. 5. Check PLC input. 6. Check the +24VDC at CONN3 pins 8 and 10
Gate operator drives the gate in the incorrect direction.	<ol style="list-style-type: none"> 1. Refer to step 4.10 of Installing and Programming the LXL Operator for setting the handing. 2. Refer to step 4.5 of Installing and Programming the LXL Operator to check for correct installation of the Limit Switch Plates.
Operator drives gate too slowly.	<ol style="list-style-type: none"> 1. Check for any binding of the gate. 2. Check for slippage of the drive wheels. 3. Check the fluid level in the reservoir. 4. Check the quality of the hydraulic fluid. Old fluid will become sludgy and clogging of internal filter is possible.
MAX Runtime Error	<ol style="list-style-type: none"> 1. Check for any binding of the gate. 2. Check for slippage of the drive wheels. 3. Check the fluid level in the reservoir. 4. Check the MAX RUN TIME setting in Parameters to insure sufficient time is set for the gate size. 5. REMEMBER – Gate only may only move 1 ft/sec
Date and time flash on the PLC.	<ol style="list-style-type: none"> 1. Refer to step 4.11 of Installing and Programming the LXL Operator for setting the date and time. (Optional, not required to be set)
Gate does not stop automatically when encountering an obstacle.	<ol style="list-style-type: none"> 1. Refer to step 4.15 of Installing and Programming the LXL Operator for setting the Inherent Safety. 2. Check for system pressure on Inherent Safety screen of the PLC, if no reading is evident while gate is running suspect a faulty pressure transducer. 3. Check the functionality of the safety devices. 4. Check safety device wiring, refer to sections 6 and/or 8
Operator drive wheels slip on gate and gate does not move.	<ol style="list-style-type: none"> 1. Check for binding by disengaging the drive wheels, and ensuring that the gate rides smoothly manually. 2. Check the tension of the drive wheels, adjust as needed. 3. Check for any water or precipitation on the drive rail.
Fuses are blowing.	<ol style="list-style-type: none"> 1. Check for incorrect incoming power to the LXL board. 2. Ensure all external devices are sending the correct voltage to the LXL board, and that there are no shorts.
PLC says Stop/Reset activated.	<ol style="list-style-type: none"> 1. If using an external push button, ensure that the stop button is a normally closed contact. 2. If not using an external push button, ensure there is a jumper wire between stop/reset and +24 stp/rst on CONN 3. 3. Check the connection of the wire between the J1Pin 9

Symptom	Actions
	<p>connector and I7 of the PLC.</p> <ol style="list-style-type: none"> Verify shunt is present on JP1 between pins 1 and 2. Check F3.
Electric Motor turns but gate does not move.	<ol style="list-style-type: none"> Check the fluid level in the reservoir. Check PLC outputs to see if Q1 turns on for an OPEN and/or Q2 turns on for a CLOSE. Disengage drive wheels and check to see if they move. If drive wheels move, check for binding in the gate. If drive wheels do not move, check for loose coupling between the electric motor and pump assembly. Check for voltage between COM and HYD VAL 1 and 2 on CONN 1 of LXL board, and ensure wires connections are tight. If voltage is correct, manually shift the detent in the center of the solenoid on either side of the hydraulic valve, if wheels move suspect hydraulic valve. If wheels do not move after manually shifting the detent, suspect pump assembly. If unit is a 3 phase unit and a new installation, reverse two of the incoming power leads.

2.5 Equipment Maintenance Log Form



Product Type: _____

Location: _____

	Date	Performed By	Checklist Complete	Anomalies	Notes
Jan			Yes No		
Feb			Yes No		
Mar			Yes No		
Apr			Yes No		
May			Yes No		
Jun			Yes No		
Jul			Yes No		
Aug			Yes No		
Sep			Yes No		
Oct			Yes No		
Nov			Yes No		
Year			Yes No		

	Date	Performed By	Checklist Complete	Anomalies	Notes
Jan			Yes No		
Feb			Yes No		
Mar			Yes No		
Apr			Yes No		
May			Yes No		
Jun			Yes No		
Jul			Yes No		
Aug			Yes No		
Sep			Yes No		
Oct			Yes No		
Nov			Yes No		
Year			Yes No		

12. Warranty Information

B&B-ARMR CORPORATION warrants for a period of five (5) years, after delivery F.O.B. plant, unless otherwise specified by Supplier, from failure of operation in ordinary use and against defects due to faulty material or workmanship. Any defective equipment in the Barrier shall be returned to the factory, at Supplier's option, for repair or replacement, and Supplier assumes no responsibility for service at any consumer site. Supplier is in no event responsible for any labor costs under the warranty. Subject to the above limitation, all service, parts, and replacements necessary to maintain the equipment as warranted shall be furnished by the end user. Supplier shall not have any liability under these specifications, other than for repair or replacement as described above for equipment malfunction or equipment failure of any kind, caused for any reason, including, but not limited to unauthorized repairs, improper installation, installation not performed by Supplier personnel, nor by Supplier authorized personnel, failure to perform manufacturer's suggested routine maintenance, modifications, misuse, accident, catastrophe, neglect, natural disaster, act of God or if at any time the power supplied to any part of the Security Barrier falls short or exceeds the rate of tolerance for the equipment.

Replacement parts shipped from B&B ARMR, are warranted for 90 days after shipment. Replacement parts are subject to the same warranty terms as stated above.

Drive wheels are considered normal wear parts and are not covered under this warranty except in cases of manufacturer defects.

The exclusive remedy for breach of any warranty by Supplier shall be the repair or replacement at supplier's option, of any defects in the equipment. IN NO EVENT SHALL THE SUPPLIER OF SECURITY BARRIER BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES OR ANY KIND OF DAMAGES TO ANYONE. Except as provided herein, Supplier makes no warranties or representations to consumer or to anyone else and consumer hereby waives all liability against Supplier as well as any other person for the design, manufacture, sale, installation, and/or servicing of the Security Barrier.

THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO OTHER WARRANTIES EXIST.

Any modification or alteration by anyone other than B&B-ARMR will render the warranty herein as null and void.