

# TwinLock 7220

# Manual



EN 1300  
M 105361 / M 102309  
G 105133 / G 102013  
G 106016 / G 106015

High Security Lock - Class 3  
IAS – ACE Switching Element- Class C  
IAS – ACE Locking Element - Class C

Copyright © May 09 INSYS MICROELECTRONICS GmbH

Any duplication of this manual is prohibited. All rights on this documentation and the devices are with INSYS MICROELECTRONICS GmbH Regensburg.

### Restrictions of guarantee

This handbook contains a concise description. The compilation of the text has been made with the utmost care. Despite all efforts, there may be deviations to the actual functions. No guarantee can therefore be given for the accuracy of the contents. We can neither assume legal responsibility nor any liability for incorrect information and their consequences. Suggestions for improvements and comments are always welcome.

### Trademarks and logos

The use of a trademark or logo not shown below does not indicate that it is freely available for use.

INSYS ® is a registered trademark of INSYS MICROELECTRONICS GmbH.

Windows™ is a registered trademark of Microsoft Corporation.

### Publisher:

INSYS MICROELECTRONICS GmbH  
Waffnergasse 8  
93047 Regensburg, Germany

Phone: +49 (0) 941/58692-22  
Fax: +49 (0) 941/563471  
Internet: <http://www.insys-security.de>

Carl Wittkopp GmbH & Co. KG  
Sternbergstr. 5  
42551 Velbert, Germany

Phone: +49 (0) 2051/9566-0  
Fax: +49 (0) 2051/9566-66  
Internet: <http://www.cawi.com>

Errors excepted. Subject to technical changes

Date: May 09

Version: 1.08A

... this document

The manual contains detailed information for the operation and the programming of the high-security lock **TwinLock 7220** and is mainly intended for the system MASTER responsible for the system configuration and administration.

For users, we recommend the Quick Reference Guide. The concise document contains all important information required for normal system operation in short form.

The document ASSEMBLY INSTRUCTIONS has been created to assist with the installation of the system. This contains all information for the implementation of the TwinLock system.



**Sections marked with this symbol contain important notes regarding the safe, damage-free operation of this product. Please read these sections carefully.**

## Contents


<b>1. SYSTEM DIAGRAM .....</b>	<b>6</b>
<b>2. SYSTEM DESCRIPTION.....</b>	<b>8</b>
2.1. INPUT UNIT: FLATCONTROL .....	8
2.2. LOCK: TWINLOCK.....	8
2.3. BUS DISTRIBUTOR: TWINCONNECT .....	8
2.4. EXTENSION UNIT: TWINXT.....	9
2.5. ARMING DEVICE: TWINALARM.....	9
2.6. CHIP CARDS (TWINCARD) .....	11
2.7. CONFIGURATION SET TWINCOMM .....	12
<b>3. FUNCTION DESCRIPTION.....</b>	<b>13</b>
3.1 CODE AND LOCKING FUNCTIONS .....	14
3.2. TIMER FUNCTIONS .....	18
3.3. SERVICE FUNCTIONS .....	20
3.4. ARMING DEVICE AND BAS CONNECTION .....	21
3.5. OPERATIONAL SAFETY.....	22
3.6. PREVENTION AGAINST SABOTAGE .....	24
3.7 OTHER FUNCTIONS.....	24
3.8. CERTIFICATIONS .....	24
3.9. PC SUPPORT WITH CONFIGURATION SET TWINCOMM .....	25
<b>4. OPERATION .....</b>	<b>26</b>
4.1 DISPLAY AND CONTROL ELEMENTS OF THE INPUT EQUIPMENT .....	26
4.2. MENU NAVIGATION .....	27
4.3 GENERAL OPERATING INSTRUCTIONS .....	28
<b>5. GENERAL OPERATION PROCESSES.....</b>	<b>30</b>
5.1. UNLOCKING A LOCK .....	31
5.2. LOCKING A LOCK .....	32
5.3. STATUS REQUEST OF A LOCK.....	33
5.4. RESPONSES.....	34
5.5. OPERATION WITH A BURGLARY ALARM SYSTEM (BAS) .....	36
5.5.1. <i>Arming the Burglary Alarm System.....</i>	<i>36</i>
5.5.2. <i>Disarming the Burglary Alarm System.....</i>	<i>38</i>
EMERGENCY SHUTDOWN OF THE BAS CONTROL .....	39
<b>6. PROGRAMMING THE SYSTEM WITH THE CONTROL UNIT .....</b>	<b>40</b>
6.1. REPROGRAMMING A MASTER / SYSTEM CODE.....	41
6.2. PROGRAMMING AND REPROGRAMMING OF A USER CODE.....	43
6.3. DELETE A USER CODE.....	44
6.4. DISPLAY THE PROGRAMMED USER CODES.....	45
6.5. CODE COMBINATION PROGRAMMING (FOUR-/SIX-EYE CODE) .....	46
6.6. SETTING THE DATE, TIME AND WEEKDAY .....	47
6.7. PROGRAM EXPRESS BLOCKINGS .....	48
6.8. PROGRAM THE ACTIVATION OF THE TWINXT LOCK I/O .....	49
6.9. OPENING DURESS (PROGRAM FORCED SEQUENCE) .....	50
6.10. PROGRAM UNLOCKING TIME DELAY .....	51
6.11. ACTIVATE ARMING DEVICE 'TWINALARM' .....	52
6.12. REGISTER ALARM USER.....	53
6.13. DISPLAY REGISTERED ALARM USERS .....	55
6.14. REMOVE BAS USER (DEREGISTER ALARM USER).....	56
6.15. PROGRAM SILENT ALARM.....	57
6.16. WRITE LOG AND CONFIGURATION TO CHIP CARD .....	58
6.17. READ CONFIGURATION FROM CHIP CARD .....	59
6.18. READ NEW SYSTEM LANGUAGE .....	60

6.19. INSTALL / CHANGE LOCKS IN THE SYSTEM .....	61
6.20. RESET THE INPUT UNIT TWIN CONTROL/FLAT CONTROL.....	63
6.21. QUERY OF THE CONTROL UNIT VERSION .....	65
6.22. VERSION QUERY OF THE LOCKS.....	66
6.23. RESET A LOCK.....	67
6.24. LOCK MOTOR SERVICE .....	68
6.25. RESET OF THE ARMING DEVICE TWINALARM.....	69
6.26. VERSION QUERY OF THE ARMING DEVICE TWINALARM .....	70
6.27. ACTIVATE PARALLEL CODE.....	71
6.28. INTERRUPT ACTIVE TIMER PROGRAMS .....	72
6.29. IGNORE BOLT SYSTEM POSITION SWITCH .....	73
6.30. AUTOMATIC LOCKING.....	74
<b>7. PROGRAMMING OF THE SYSTEM WITH THE PC SOFTWARE TWINCOMM.....</b>	<b>75</b>
7.1. GENERAL OPERATION .....	76
7.2. PROGRAM THE WEEKLY PROGRAM.....	78
7.3. PROGRAMMING OF SPECIAL DAYS .....	79
7.4. PROGRAMMING THE BLOCKING TIME .....	80
7.5. PROGRAMMING PARTIAL BLOCKING TIMES .....	81
7.6. PROGRAMMING OF GENERAL SETTINGS.....	82
7.7. PROGRAMMING THE UNLOCKING DELAY .....	85
7.8. DISPLAY EVENT LOG .....	86
7.9. MENU SIMULATOR AND MENU WIZARD .....	87
7.10. USER DATA MANAGEMENT .....	88
7.11. CUSTOMER DATA MANAGEMENT .....	89
<b>8. APPENDIX .....</b>	<b>90</b>
8.1. APPLICATIONS.....	90
8.1.2. <i>Remote release</i> .....	90
8.1.2. <i>Network Connection</i> .....	91
8.2. TECHNICAL DATA .....	92
8.3. NOTES.....	94


## Revision History

## 1. System Diagram


### TwinLock 7220 - Alarm



## TwinLock 7220 base system 2.1 FlatControl (2 lock system with XT)



## TwinLock 7220 base system 2.1 FlatControl (1 lock system with XT)



## 2. System Description

**TwinLock 7220 - Alarm** is an electronic high security lock system with integrated arming device for a burglary alarm system class 3/C. It is a modular system. Up to 14 locks and 2 control units can be connected.

The security-relevant system parts are designed fully redundant.

The system consists of the following components:

- 1...2 Control units = Terminals
- 1..3 Locks
  - 1 Arming device = BAS connection, distributor
  - 1 Bus distributor = Connector for the individual components (hub)
- 1...7 Extension units TwinXT

### 2.1. Input Unit: FlatControl

The input unit is mounted on the outside of the safe (see assembly of the input unit) and is used to control and operate the locking system (code input, programming, etc.), as well as to arm or disarm a burglary alarm system using a physical code (chip card).



### 2.2. Lock: TwinLock

The locks are mounted within the secured area of the safe (see assembly of locks). The mnemonic codes are stored and evaluated inside the locks.



### 2.3. Bus distributor: TwinConnect

The bus distributor TwinConnect enables the connection of the individual system components. The system is connected by means of a redundant bus system (BUS A and BUS B). This bus system allows the entire system to be upgraded to 3 locks



TwinConnect allows the connection of the input unit, the arming device, and up to 3 locks. There is also the possibility to cascade several bus distributors, i.e. to connect several TwinConnect units in series, to be able to connect several locks.

In addition, TwinConnect has a power supply unit (12 VDC), which can supply the TwinLock lock system. (When the arming device is connected, however, the system must be supplied through the BAS).

## 2.4. Extension Unit: *TwinXT*

The TwinLock system can very easily be extended by 4 inputs and 2 outputs by means of the extension unit **TwinXT**. Basically, a TwinXT can be connected to each lock in the system. Consequently, each lock can be specifically locked or released, and each lock can have a bolt system contact.



- 2 switching inputs (release/bolt system contact) for lock 1
- 2 switching inputs (release/bolt system contact) for lock 2
- 2 relay outputs (status/silent alarm) (30V/1A)
- Power supply 12 VDC
- Antitamper loop with tamper switch

## 2.5. Arming Device: *TwinAlarm*

The arming device TwinAlarm is mounted inside the safe and is used as a connecting link between the terminal TwinControl or FlatControl (input unit) and the locks and a burglary alarm system (BAS), as well as to connect a serial printer/PCs, and as a distributor for the burglary alarm system (bolt contacts, door contacts, resistance monitoring, etc.).



Soldering terminals for the mounting of resistors for resistance monitored lines are available. The inputs can be customized in various ways, using jumpers.

In **TwinAlarm**, the electronic keys (chip cards) as well as the input signals of the burglary alarm system are evaluated.

The TwinAlarm housing is protected against sabotage by the means of a tamper switch and protection on all sides, and it is secured with a sealing adhesive label.

### BAS Inputs:

<i>BAS READY</i>	Prevents the BAS from being armed (Customization by jumper and software).
<i>DISARM BLOCK</i>	Prevents the BAS from being disarmed (Customization by jumper and software).
<i>RELEASE</i>	Prevents the unlocking of the locks (customization by jumper and software).
<i>ACKNOWLEDGEMENT</i>	Evaluates the arming acknowledgement of the BAS (Customization by jumper and software).


### Other Inputs:

<i>NO TIMEOUT</i>	Enables the interruption of the timer programs (weekly programs, special days, blocking time), so that, for example, persons locked into the safe may be freed during an active timer program.
<i>CENTRAL CONTACT</i>	The central contact prevents the shutting of locks when the bolt system is open. -> <b>Bolt system contact</b>

### Outputs:

<i>ALARM</i>	The relay switches, when a 'silent alarm' was triggered during the code input at the TwinControl/FlatControl device. (last code digit +1). The relay is triggered for 2 seconds. All relay contacts are directed to the screw terminals. Resistors for resistance monitored lines may be employed.
<i>ARMED/DISARMED</i>	The Relay is used to arm or disarm the burglary alarm system. All relay contacts are directed to the screw terminals. Resistors for resistance monitored lines may be employed.
<i>STATUS</i>	The relay is used to indicate the status of all locks in the system. All relay contacts are directed to the screw terminals. Resistors for resistance monitored lines may be employed.


## 2.6. Chip Cards (TwinCard)



### **TwinCard code access**


Chip card as 'physical code' to disarm a BAS.

The code is changed continuously.



### **TwinCard configuration**

Chip card for the system configuration and the event log. In cooperation with PC software TwinComm, the configuration can be imported or exported and the log can be read out.




### **TwinCard language**

Chip card for the configuration of the system language. (German, English, Czech, Portuguese...)

### 2.7. Configuration Set TwinComm

The TwinLock system can be configured fast and conveniently using the program TwinComm in connection with the chip card reader of the configuration set and the chip card **TwinCard configuration**. All settings and the event log can be displayed, printed and saved.



## 3. Function Description

### Function Overview

#### Code and Locking Functions

- 1 Master code per lock
- 1 System code
- 35 User codes per lock
- Status indicator for programmed user codes
- Unlock & lock by entering the security code
- Forced Sequence
- Parallel code
- Lock & Code
- Automatic lock with door switch
- Code linking (Four-eye code/six-eye code)
- Silent alarm
- Code manipulation detection
- Quick unlocking code

#### Timer Functions

- Weekly program
- Special days
- Blocking time
- Partial blocking times
- Express blocking
- Timer program interruption
- Time delay
- Alarm/sabotage delays
- Automatic switching to daylight savings time

#### Service Functions

- Event log 768 events
- Import/export of the configuration via chip card
- System language can be configured using the chip card
- Reset of the individual system components
- Query of the system component version
- System components login/logout
- Step-by-step operation for motor test
- System line free configurable
- System status indicator
- Voltage monitoring

#### Arming Device and BAS Connection

- Activate arming/disarming
- Distributor
- BAS Inputs: BAS ready, block disarming, release, acknowledge, timeout, bolt system contact
- BAS Outputs: Silent alarm, armed/disarmed, state
- Connection facility for 2 more bolt system and door contacts each
- Antitamper loop with area sensor and cover contact
- Control points for resistance monitoring
- RS232-Port

## 3.1 Code and Locking Functions

### Master code

Each lock has a master code (user ID = 00 + 8-digit master code).

The master code has the authorization to program lock-specific procedures (e.g. time delay, user codes, etc.) or to unlock, respectively.

The master code can not be deleted or deactivated.

### ATTENTION:



The default code for the user 00 (= Master) of each lock is the pre-programmed code 1 2 3 4 5 6 7 8. The user codes no. 01...35 of the individual locks have been deactivated by the manufacturer.

For security reasons, the master codes of the individual codes must be changed **IMMEDIATELY!**

When programming the code you must see to the new unlocking code being checked repeatedly while the safe is open.

Do not use personal data when programming unlocking codes!

Loosing a master code can have very costly consequences!!!

### Enter system

The system code is identical to the master code of lock 01 (user ID = 00 + 8-digit system code).

In addition to having lock master privileges, the system master is also authorized for system programming. The system code can not be deleted or deactivated.

### User code

Each lock has 35 user codes (user ID 01 – 35 + 8-digit user code).

The user codes are programmed or deleted by the according master code. A user can reprogram his/her user code autonomously. Otherwise, the user only has an unlocking authorization.

A user code can be assigned the possibility for "Quick unlocking" (= quick unlocking code) without time delay expiration (see timer programs).

### Status indicator for programmed user codes

For each lock, the programmed user codes can be displayed. The programming status, i.e. OK or NOK is displayed. The display can only be activated by the according lock master.

## Unlocking & Locking

The unlocking is tied to at least one code entry. This always takes place via the menu keys (see prevention against sabotage). Unlocking can be prevented by several functions (timer programs...).

Locking is usually not tied to a code entry, and is either initiated by the menu item 'Lock' or by a switch which is connected to the lock.

## Forced Sequence

When a 'forced sequence' is activated, the locks can only be opened in a certain sequence (lock 01, 02, ...). When locking the system, the sequence is reversed.

The system is only unlocked and accessible for configuration and service after all locks have been opened.

## Lock & Code

When this function is activated, the locking process is tied to the entry of a valid code. This means that the system can only be locked by authorized persons. The user number is recorded in the log.

This function can only be configured via the PC software TwinComm.

## Automatic lock with door switch

The system can be locked automatically using a door switch or a bolt system contact, which is either connected to a TwinAlarm or TwinXT system, depending on the system variant.

This function can only be configured via the PC software TwinComm.

## Code linkage

For the entire system, the function 'Four-eye code' or 'Six-eye code' can be programmed. A lock can thus only be unlocked by entering 2 or 3 user codes respectively. Programming can only be performed by the system master. If a four-eye or six-eye code has already been programmed, the system master can perform the programming only in connection with other users of lock 01.

## Parallel code

For a **2 or 3 lock system**, the function 'parallel code' can be programmed.

This function can only be configured via the PC software TwinComm.

In this case, the unlocking codes apply to 2 or 3 locks, e.g. the user does no longer need to select a lock, and he is not bound to a specific lock. In all locks, however, the same codes must be programmed for the according users, e.g.

User 08:                   Code: Lock 1: 08080808  
                              Code: Lock 2: 08080808  
          Or                Code: Lock 3: 08080808

### Keyboard entry

A simplified code entry for programming processes can be defined to enter the code via the key pad. The code entry via the menu keys for an unlocking process, however, is maintained. The definition can only be performed by the system master. This function can only be configured via the PC software TwinComm.

### Silent alarm

During a threatening situation, a special alarm code may be entered when locks are opened and closed, to trigger a silent alarm.

The alarm code consists of the normal user access code where the last number is increased by **+1** (9 switches to 0!).

The system now acts exactly like for the normal opening procedure for the user (and the intimidator), but at the same time a silent alarm signal is sent to the BAS.

Furthermore, an individual opening time delay may be defined for the case of an alarm. The lock can only be opened after the set waiting period has expired (see also timer programs).

The defined release time of the “normal” time delay is used as release time.

Example:

Unlocking code: 1-2-3-4-5-6-7-8 >> Alarm code: 1-2-3-4-5-6-7-9


### Code Manipulation

When the code has been entered incorrectly for four times, a blocking period of 1 minute is activated. During this blocking time, no opening procedure may be performed. Each further incorrect code entry increases the blocking time by one minute. The maximum blocking period is 15 minutes.

(see also timer programs and prevention against sabotage)

wrong code blocking period
-------------------------------

## Code distribution in the TwinLock 7220 system



## 3.2. Timer Functions

### Weekly program

There are 2 definable opening periods for each weekday (Monday to Sunday). The system can only be unlocked within the set time window. The individual weekdays can also be completely locked (e.g. on weekends). The programming is performed using the system code.

### Special days

30 definable days, on which the system can not be unlocked (e.g. public holidays). The programming is performed using the system code.

### Blocking period

Period (up to three months) during which the system can not be unlocked. Programming of the start time (date / time) and the end time (date / time) is done using the system code (e.g. company holidays).

### Partl lock time

Two time periods for each of the seven days of the week are available, during which the system may be partially locked. The partial locking is only designed for two lock operation. Within the part lock time, only lock 2 is closed; lock 1 remains open. The part lock time may be combined with the function "automatic locking" via door switch.

### Express blocking

Period, during which a lock is blocked, i.e. can no longer be unlocked. The programming of the end time (date / time) is performed using the according lock master code. The express blocking starts with the programming time and must be performed individually for each lock.

### Timer program interruption

A person locked in the secured area can deactivate an active timer program (weekly program, special days, blocking period, part lock time) with a key to enable opening the system from the outside by entering an unlocking code. Afterwards, the timer program is resumed.

The key is connected to TwinAlarm. It can not be connected to TwinXT.

### Time delay

Unlocking delay, individually configurable for each lock (00 - 99 min.). A release time (00 - 99 min.) can be programmed for each unlocking delay. After the time delay expiration an unlocking code must be reentered.

The programming is performed using the according lock master code.

A user can be assigned a quick unlocking code function to bypass this program.

## **Alarm/sabotage delays**

When the unlocking code was entered incorrectly 4 times, a time delay of 1 minute starts. For each further attempt with a wrong code the waiting period is extended by 1 minute, up to a maximum of 15 minutes.

When a silent alarm is triggered, a waiting period with a set duration will start.

These special programs can not be bypassed or interrupted.

(see also code functions and prevention against sabotage)

## **Blocking time interruption**

A running timer program (weekly program, special days, blocking period, part lock time) can be interrupted by entering the quick unlocking code.

This code is entered in the system menu with the following sequence:

Press the key: F2 -> Press the key: 2

Now the quick unlocking code for lock 1 must be entered.

The timer program is now interrupted for one unlocking process.

The unlocking process can be performed.

The entering of the quick unlocking code and the blocking period interruption are logged.

The owner of the quick unlocking code also has the opportunity to trigger a "silent alarm".

## 3.3. Service Functions

### Event Log

The latest 768 events (programming processes, hardware errors, and certain status messages, manipulation and sabotage attempts) are logged in chronological order, including date and time (perhaps the user number).

The event log can be displayed online, i.e. each log entry is immediately transmitted to a printer/PC connected via TwinAlarm.

There is also the possibility to transfer the entire event memory to the TwinCard configuration. Display and printing of the event memory take place with the PC software TwinComm.

The clear text display of events in the set language is identical to the messages at the control unit TwinControl/FlatControl or with the messages in the PC software TwinComm.

### Configuration import/export

An entire configuration profile can be swapped out to the chip card Twin Card Configuration. This profile can then be edited with the PC software TwinComm and reimported or saved. The above-described event log is also written to the card and can be displayed, printed and saved using TwinComm.

### System language

The system language can be transferred using the chip card TwinCard language. This card is available in several languages and must be requested separately.

### More functions

- Reset of the individual system components
- Query of the system component version
- System components login/logout
- Step-by-step operation for motor test
- Operation of several control units

## 3.4. Arming Device and BAS Connection

### Activate arming/disarming

The main task of the arming device is to arm or disarm a connected BAS. Disarming is basically an unlocking process, which requires an additional physical code in form of a chip card. Up to 36 different card users can be logged on. The user management is performed by the system master. The current codes of the logged on cards are saved in TwinAlarm and change after each use. The BAS arming procedure can also be tied to a physical code to avoid arming by an unauthorized person.

### I/O distributor

**BAS Inputs:** BAS (EMA) ready, block disarming, release, acknowledge (BAS adjustment via configurable inputs)

**BAS Outputs:** Silent alarm, armed/disarmed

**Other Inputs:** Timeout, bolt system contact

**Other outputs:** Status

Connection facility for two more bolt systems and door contacts each

Antitamper loop with area sensor and cover contact

Control points for resistance monitoring


### RS232-Port

This port enables the connection of the system to a PC, a serial printer or a modem. The protocol or individual online log entries can be sent, for example.

Interface parameters: 1200 baud, data format 8N1, no handshake.

It is possible to release or block the system via modem/ISDN/GSM. This functionality is identical to the release signal function via an input contact.

For a remote release, the arming device must be configured accordingly (see assembly instructions).



### Release procedure:

Dialup and connection establishment to the TwinLock system

Identification requirement -> send from 'TwinAlarm'

Response:

Requirement: Release

Response: OK or NOK

Termination

As soon as the system reports OK, the release time starts to run. The system may now be unlocked. After 120 seconds, the system is locked again.

### 3.5. Operational Safety

#### Redundancy

A dual bus system and a dual electronic and mechanical locking system in the locks guarantee high system stability. The two identical system parts are completely independent from each other and can therefore function individually.

#### Voltage monitoring

When the power supply is applied or when the system recovers from energy saving mode, the state of the battery (system voltage) is checked. When the system falls below a set warning threshold, an entry is made in the log and a message is displayed. Press F2 to display the system voltage from the system menu.

```
*** TwinLock ***  
battery: 9.0V
```


```
*** TwinLock ***  
!!! Low Batt !!!
```

Every time the system is restarted (battery replacement) or when the system is activated, the battery voltage is measured and checked. If the battery voltage falls below the set warning limit, the message '!!! Low - Batt !!!' is displayed and also stored in the event memory.

## Power Failure

The FlatControl receives its power supply via each of the two bus cables. When a voltage failure occurs, an emergency current feed for the entire system is possible via a jack at the bottom of the keyboard.

For this, an adapter cable 7237-101-0 and a 9 volt block battery (alkaline type) is required. For the connection of the adapter cable, see figure.



## Real time clock

The date and the time are generated by a specially buffered real time clock and will survive even if the system receives no current for several days.

If a real time clock still happens to be deleted, the system will be in an undefined state.

## More functions

Protection against locking the locks while the bolt system is open.

Constant self-diagnosis of the bus lines and system components.

Log entry of all warning and error messages.

Validity check of entered times and dates.

### **3.6. Prevention Against Sabotage**

#### **Input unit FlatControl**

The input unit in the unsecured area is secured by different measures.

Opening the case (battery compartment) is immediately detected and displayed until an authorized user unlocks the system lock properly.

A person standing next to the authorized user cannot watch the entering of the code. A special film in the view window of the terminal prevents the reading of the display from a lateral position.

Besides that, the opening code is not entered via the keyboard, but via the arrow keys above a digit selection on the display. After each entry of a digit, the cursor will be displayed at a randomly selected new position.

#### **Arming device TwinAlarm**

The arming device case is protected against unnoticed intrusion by means of a tamper switch and protection on all sides.

All sabotage and control lines to the BAS can be equipped with a defined line resistance. Soldering spots for resistance-supported performance control are available.

#### **More functions**

All codes are saved and evaluated within the secured area.

Log entry of all security-relevant events.

Blocking times when a wrong code is entered repeatedly.

(see code programs, timer programs)

Configuration only possibly for unlocked systems after entering the system codes.

### **3.7 Other Functions**

Automatic switching to daylight savings time.

System line freely configurable. When the system is activated, the company name is displayed, for example.

System status indicator. The condition of the individual locks can be queried.

### **3.8. Certifications**

The TwinLock 7220 system is VdS approved for locks as BAS locking and arming devices, classes 3/C.

## 3.9. PC Support with Configuration Set TwinComm

Basically, the TwinLock 7220 system also works without PC support, but using the software simplifies the configuration and enables easy reading of the event log.

The exchange of data with the lock system takes place with the chip card **TwinCard configuration** and the service function **'Import/Export'** at the control unit.

Read-out configuration profiles can be saved, printed, or modified and reimported.

All timer programs and system settings can be programmed.


When the system settings are read out, the event log is also written to the chip card.

The protocol can be displayed and printed with TwinComm.


The menu manager enables the blocking of individual menu items of the terminal to disable the selected functions at the terminal.

## 4. Operation

### 4.1 Display and Control Elements of the Input Equipment



## 4.2. Menu Navigation



### 4.3 General Operating Instructions

#### System Activation

When idle, the TwinLock System is activated by operating a menu key at the control unit. After the activation, a system check is performed and the individual states of the connected locks, of the burglary alarm system (EMA or Einbruchmeldeanlage), and of the TwinLock system are displayed.


system check  
lock opened 01

system check  
BAS armed

system check  
system locked

#### Key Functions

##### Menu Keys:



- > Menu navigation to the right, i.e. next menu item
- < Menu navigation to the left, i.e. previous menu item
- enter Selection or confirmation
- clear Cancel, return to previous menu item  
(press 2 seconds = return to system menu)

##### Key Pad:




- 0...9 Numeric keys to enter timer programs, etc.
- F1 Arming a BAS (only possible in the system menu)
- F2 Display of the current battery voltage  
(only possible in the system menu)

#### Code input


Unlocking and locking codes may only be entered via the menu keys.

Using the arrow keys, the cursor is placed over the desired digit and selected with the enter key.

As an alternative, the code can also be entered in the configuration and service area using the keyboard. This function must be activated in the menu "Settings/System/General" (see manual).



TwinControl



FlatControl



Entering the code using the numeric keypad

Entering the code using the menu keys.  
Menu Navigation

## System Menu

The start page of the menu structure is called system menu

. The system menu consists of one editable line (line 1 = system line, which can contain individual text), and the current date/time display (line 2).

\*\*\* TwinLock \*\*\*  
Th 21.05.09 12:00




### *Programming the Code*


#### Important notes regarding the programming of the code

- \* **For security reasons, switch the system code or the master code of the individual codes immediately after installation. The default code 1 2 3 4 5 6 7 8 is pre-programmed for the user no. 00 (= master/system master). The user codes no. 01...35 of the individual locks have been deactivated by the manufacturer.**
- \* **When programming the code you must see to the new unlocking code being checked repeatedly while the safe is open!**
- \* **Do not use personal data when programming unlocking codes!**

### 5. General Operation Processes



## 5.1. Unlocking a Lock




Select the menu item '**Unlock**'.  
(see menu plan 4.2)


When several locks are available in the system, select one lock. When 'Forced Sequence' is selected, lock #01 is unlocked first.

Select the user number


Enter the unlock code



Enter a further unlock code, when the four-eye code is activated.




Enter a further unlock code, when the six-eye code is activated.



When time delay is activated  
Display of the remaining time delay


After the time delay has expired the release time starts. Within this time window a further unlocking code must be entered.



After the system lock has been unlocked, the system may be configured.

Automatic return after 3 seconds

## 5.2. Locking a Lock




Automatic return after 3 seconds

Select the menu item '**Lock**'  
(see menu plan 4.2)

When several locks are available in the system, select one lock. When 'Forced Sequence' is selected, all locks are automatically closed.

For 'Lock & Code':  
Select the user number


Enter the code



Lock locks

When the system lock (01) was locked,  
the system can no longer be re-configured.


## 5.3. Status Request of a Lock



Select the menu item '**Status**'  
(see menu plan 4.2)

Selektion lock if there are more  
Locks in the system.

The status of the selected  
component is displayed.



Automatic return after 3 seconds

## 5.4. Responses

### Unlocking Messages

<code>open time lock week</code>	No unlocking possible, because the current time is not within the time window defined in the weekly program.
<code>open time lock day</code>	No unlocking possible, because the current date coincides with the date of a defined special day.
<code>open blocking period</code>	No unlocking possible, because the blocking time program is active.
<code>open part lock time</code>	No unlocking possible, because the system is in part lock time mode.
<code>open system blocked</code>	No unlocking possible, because the input RELEASE at the arming device is not active.
<code>Open cancel Blocking time</code>	An active timer program is cancelled by activating the input TIMEOUT in the secured area.
<code>open terminal switch</code>	The control unit was switched or re-initialized.
<code>open ! manipulation !</code>	At the last code entry, a user entered a wrong code more than three times. ! Attention!
<code>restart or voltage drop</code>	The system was either restarted or there was no power supply, or the battery compartment was opened (only for TwinControl).

## Status messages

system check failure Bus A	Lock can no longer be addressed at bus A. <b>Please call customer service !</b>
system check failure Bus B	Lock can no longer be addressed at bus B. <b>Please call customer service !</b>
system check failure motor A	Final bolt position of the lock at bus A is not accessible. <b>Please call customer service !</b>
system check failure motor B	Final bolt position of the lock at bus B is not accessible. <b>Please call customer service !</b>
System check failure motor AB	Final bolt position of the lock is not accessible at bus A or bus B. <b>Please call customer service !</b>
Status DMS XX Error	General lock fault. <b>Please call customer service !</b>

## General Error Messages

. . . . . invalide code	Code entry incorrect. Please enter correct code!
. . . . . invalide input	Incorrect or invalid entry. Check entry and retry!
. . . . . failure BUS A	Addressed component at bus A does not respond. <b>Please call customer service !</b>
. . . . . failure BUS B	Addressed component at bus B does not respond. <b>Please call customer service !</b>
. . . . . failure motor AB	Error when unlocking/locking a lock. <b>Please call customer service !</b>
. . . . . COM - Error	Error during communication between control unit and lock. <b>Please call customer service !</b>
. . . . . Error Serial No.	Error during communication between control unit and lock. Control unit serial number does not match the lock. <b>Please call customer service !</b>

## 5.5. Operation with a Burglary Alarm System (BAS)

### 5.5.1. Arming the Burglary Alarm System

The system TwinLock 7220 can arm a connected BAS using the arming device TwinAlarm. The arming may only occur when,



1. The system lock is locked  
(usually lock #1, for the forced sequence for all locks)
2. At least one physical code (chip card) has been logged on.
3. The connected BAS is activated.

```
*** TwinLock ***  
04.05.09 21:06
```

```
BAS user  
user: 01<
```

```
user 01  
insert card
```

```
user 01  
remove card
```

```
User 01  
! BAS armed!
```

Arming using  
the key <F1> in the system menu



Select the BAS user number  
(chip card number)

When the function 'Arm & Card'  
has been activated, the chip card  
TwinCard code access is required  
for the arming procedure.



The BAS is now armed.  
(an acoustic signal is emitted)

Automatic return after 3 seconds

#### Note:



**We recommend to activate the function 'Arm & Card', as otherwise the BAS could be armed by a non-authorized person. The BAS user numbers are only linked to the logged-on chip cards and have nothing to do with the user numbers of the individual locks.**

## Error messages:

<pre>..... Error Armed !</pre>	Burglary alarm system could not be armed, because BAS was perhaps not acknowledged.
<pre>..... BAS not ready</pre>	The input "BAS ready" at the TwinAlarm is not set by the BAS, so arming is disabled.
<pre>..... Wrong card ID</pre>	The selected EMA user number is not identical to the user number of the code card.
<pre>..... Error code card</pre>	The code on the code card is wrong, i.e. the code card is invalid!
<pre>..... Disarm code ??</pre>	No code card was logged in yet, i.e. the BAS cannot be armed!

### 5.5.2. Disarming the Burglary Alarm System

The system TwinLock 7220 Alarm can disarm a connected BAS using the arming device TwinAlarm. The disarming procedure is linked to the unlocking procedure of the system lock (lock 01, for the forced sequence for all locks) and is enabled by entering the mnemonic code during the unlocking procedure, plus the additionally required physical code (TwinCard code access).

If an unlocking procedure is not possible due to an active timer program or the like, no disarming will take place.



BAS user  
User no.: 01<

user: 01  
insert card

Unlocking see  
unlocking a lock

disarm  
! BAS disarmed !

BAS user  
remove card

open  
please wait

open  
lock open 01

open  
system unlocked

Select the menu item '**Unlock**'.  
(see menu plan 4.2)

When several locks are available in the system, select one lock. When 'Forced Sequence' is selected, lock 01 is unlocked first.

Select the BAS user number (card number)

Insert card into the control unit with the chip facing downward.



Codelinkage,  
time delay for unlocking ...  
See also 'Unlocking a Lock'

The BAS is now disarmed  
(an acoustic signal is emitted)

Remove code card.



The lock is opened

After the system lock has been unlocked, the system may be configured.

## Attention:



The disarming procedure can only take place with the code card and the mnemonic code!

The BAS user numbers are only linked to the logged-on chip cards and have nothing to do with the user numbers of the individual locks.

The BAS is disarmed before the locks are unlocked.

Remove the code card only when the system asks the user to do so!

## Error messages:

```
.....
Disarm error !
```

The BAS could not be disarmed.

```
.....
Disarm block !
```

The input "Disarm Block" at the TwinAlarm is set by the BAS, so disarming is disabled.

```
.....
Wrong card ID
```

The selected EMA user number is not identical to the user number of the code card.

```
.....
Error code card
```

The code on the code card is wrong, i.e. the code card is invalid!

## Emergency shutdown of the BAS control

If it is no longer possible to disarm the BAS control via TwinLock, because the available code cards are faulty or other technical errors have occurred, the BAS control may, also for closed systems in this special case, be deactivated via the system code.



Please note that this procedure will trigger an alarm as soon as the locks are opened!

```
*** TwinLock ***
21.05.09 1200
```

In the system menu, first the key F2, then key 4 is pressed



Now enter the system code.

More see Chapter: „6.11. Activate Arming Device TwinAlarm

In this case, the arming device must be deactivated.

## 6. Programming the System with the Control Unit



The following functions and settings can be performed using the control unit:

- Reprogram master and system codes
- Program user codes
- Delete a user code
- Display a programmed User code
- Activate/deactivate code linkage
- Date/Time
- Program unlocking delay
- Program silent alarm
- Activate lock I/O, TwinXT
- Program forced sequence
- Program parallel code
- Write configuration and log to chip card
- Read configuration from chip card
- Import new system language

Some of these functions and all others can be implemented by means of the **Configuration Set TwinComm**.

## 6.1. Reprogramming a Master / System Code

### Menu Navigation:




System  
Master codes

Select the menu item '**Master Codes**'  
(see menu plan 4.2 / see above)


Master codes  
Lock 01

When several locks are available  
in the system, select one lock



Master code  
Code:\*\*\*\*\*

Enter the master code of the  
selected lock



Master code  
Please wait

Evaluate the entry



New M code  
Code:\*\*\*\*\*

Enter the new master code  
of the selected lock



Confirm code  
Code:\*\*\*\*\*

Reconfirm the new master  
code once more

New M code  
Please wait

Save the new code

New M code  
Saved

Action completed

Automatic return after 3 seconds

Besides the normal unlocking authorization, the master code is also authorized to configure the lock, for quick unlocking, and single unlocking with four-/six-eye code. The master code of lock 01 is at the same time the system code for system configuration and service functions.

When entering the code, the user = 00 is the master.

### **ATTENTION:**



The default code 1 2 3 4 5 6 7 8 is pre-programmed for the master of each lock. The user codes no. 01...35 of the individual locks have been deactivated by the manufacturer.

For security reasons, the master codes of the individual locks must be changed immediately.

When programming the code you must see to the new unlocking code being checked repeatedly while the safe is open.






Do not use personal data when programming unlocking codes!



Loosing a master code can have very costly consequences!!!

## 6.2. Programming and Reprogramming of a User Code

### Menu Navigation:

*** TwinLock *** 21.05.09 12:00	*** TwinLock *** Configuration	Configuration System	System User codes
system usercodes	Select the menu item 'User Codes' (see menu plan 4.2/ see above)		
usercodes programming	Select programming		
programming lock 01	Select the lock		
programming user no.: xx	Enter the user number.		
old M/U code code:*****	Enter the old unlocking code (user codes/user code) or master code		
programming user no.: xx	Enter the user number of the user code to be programmed		
new usercodes code:*****	Enter the new unlocking code		
confirm code code:*****	Re-enter the new unlocking code		
usercodes please wait	The new user code is saved		
usercode xx saved			

Automatic return after 3 seconds

### User codes

A user can reprogram his/her user code autonomously. Otherwise, the user only has an unlocking authorization.

**Attention:** When you program a user code for the first time, you must first enter the master code.



**When programming the code you must see to the new unlocking code being checked repeatedly while the safe is open. Do not use personal data when programming a code**

## 6.3. Delete a user code

### Menu Navigation:




System  
usercodes

Select the menu item '**User Codes**'  
(see menu plan 4.2/ see above)

usercodes  
delete

When several locks are available  
in the system, select one lock.

delete  
lock 01



Code entry  
user no.: 00

Enter the user number 00  
For the master code

old M/U code  
code:\*\*\*\*\*

Enter the master code of the  
selected lock




delete  
user no.: 01

Select the user (e.g. 01)  
to be deleted

delete  
please wait

The selected user is  
deleted



usercode 01  
deleted

Action completed


Automatic return after 3 seconds

Only the according owner of the master code can delete user codes. This action is saved in the event log.

The function itself can only be performed at the control unit.

## 6.4. Display the Programmed User Codes


### Menu Navigation:



### Display the Programmed User Codes

For each lock, the users can be displayed, which were entered in it. This means that not the codes themselves are displayed, but the status (programmed, not programmed).

The display of a programmed user code can only take place by entering the according master code of the lock.



## 6.5. Code combination Programming (Four-/Six-Eye Code)

When code linkage was selected (four-eye code/six-eye code), the lock can only be unlocked or programmed by entering 2 or 3 codes. The arrangement of the 2 or 3 codes is random.

The function applies to the entire system, i.e. each lock must be unlocked with 2 or 3 codes, when code linkage is activated.


The programming of this function can only be performed by the owner of the system code and is saved in the event log!

### Note:



The code combination / - linkage can only be programmed if 2 or 3 user codes are programmed.  
User codes can only be deleted when the code linkage was deactivated beforehand.

### Menu Navigation:



Automatic return after 3 seconds

### Code combination (code linkage)

*Comment:*

*Selection by means of arrow keys and ENTER*

1: Single code (normal)

2: Four-eye code (2 users)

3: Six-eye code (3 users)

This function can also be configured via the PC software TwinComm.

## 6.6. Setting the Date, Time and Weekday

### Menu Navigation:




system  
date/time

Select the menu item **'Date/Time'**  
(see menu plan 4.2)

system code  
code:\*\*\*\*\*

Enter system code




system code  
please wait

Evaluate the entry


time: 10:01 Mo  
date: 20.12.02

Select time-date/weekday  
Display current settings



time: 12:00 Mo  
date: 18.08.02

Reenter date,  
time or weekday



date/time  
saved

Action completed

### Date/Time

The date/time/weekday can only be changed by the owner of the system code. This action is saved in the event log.

### Attention:



**The correct setting of the date/time/weekday is the basis for all timer programs in the system or the event log to run properly.**


## 6.7. Program Express Blockings

### Menu Navigation:



lock  
express blocking

Select the menu item '**Express blocking**'  
(see menu plan 4.2/ see above)



express blocking  
Lock 01

When several locks are available  
in the system, select one lock.


Master code  
code:\*\*\*\*\*

Enter the master code of the  
selected lock



Master code  
please wait

Evaluate the entry



express blocking  
E:00:00 00.00.00

Display current settings  
Start the entry with ENTER.

express blocking  
E:21:06 04.05.09

Enter the new end time



express blocking  
saved

Action completed

Automatic return after 3 seconds

### Express blocking

Express blocking can be programmed for each lock. Express blocking is active from the time when it was programmed and stays active until the specified end time. During this period, the according lock can not be unlocked.


The express blocking programming can only be performed by the owner of the according master code of the respective lock and is saved in the event log.

Default express blockings: 00:00 00.00.00

This function can not be programmed via the PC software.

## 6.8. Program the Activation of the TwinXT Lock I/O

### Menu Navigation:



Automatic return after 3 seconds

### Lock I/O

The inputs or outputs of the locks can be programmed by means of the master code (system code) of lock 01. The following functionality is achieved:

Input functions:

- \* Locking feature (contact for external release/blocking of the lock)
- \* Locking after bolt contact query

Output functions:

- \* Silent alarm (relay contact for silent alarm messages)
- \* Display of the lock bolt position (relay contact)

This programming action is saved in the event log!

### Note:



The function "Automatic locking via door contact" can only be programmed via the PC software TwinComm. (see Chap. 6.30.)

The function of the inputs can also be re-configured:


- Active = contact closed, or
- Active = contact open

Factory setting:

TwinXT inactive

## 6.9. Opening duress (program forced sequence)

### Menu Navigation:



Automatic return after 3 seconds

### Forced Sequence

Programming the function 'Opening duress' determines the unlocking or locking sequence.

The system will only then be in an unlocked state when all locks are open. It will be in a locked state, when all locks are closed.

Opening sequence: lock 1, lock 2 ... lock n (system unblocked)

Locking sequence: Lock n, ... lock 2, lock 1 (system locked)

The programming of this function can only be performed by the owner of the system code and is saved in the event log!

Factory setting:

No opening duress (no forced sequence) = No.


## 6.10. Program Unlocking Time Delay

### Menu Navigation:



lock  
time delay

Select the menu item 'time delay'  
(see menu plan 4.2/ see above)



time delay  
lock 01

When several locks are available  
in the system, select one lock.

Master code  
Code:\*\*\*\*\*

Enter the master code of the  
selected lock




Master code  
Please wait

Evaluate the entry

time delay  
Time:00 Rel.:00

Display current settings  
Start the entry with ENTER.



time delay  
Time:04 Rel.:05

Enter the new end time

time delay  
saved

time delay  
deleted

Action completed

Automatic return after 3 seconds

### Time Delay for Unlocking:

This function delays the unlocking procedure when the code is entered correctly. The time is entered in minutes (00-99). A time delay can be entered for each lock.

#### Release time:

The release time is used to safeguard the time delay. If a release time was programmed (e.g. >00), a correct unlocking code must be entered after the time delay has expired, to finally open the lock.

The release time is set in minutes (00-99) and specifies the period, during which the user can re-enter the unlocking code after the time delay has expired. If no release was programmed (00), the lock will open without re-entering the code after the time delay has expired.

The programming of this function can only be performed by the owner of the system code and is saved in the event log!

Factory setting: Time: 00 Rel.: 00 (deactivated)


## 6.11. Activate Arming Device 'TwinAlarm'

### Menu Navigation:



Alarm  
TwinAlarm enable

Select the menu item '**TwinAlarm enable**'  
(see menu plan 4.2 / see above)




System code  
Code:\*\*\*\*\*

Enter system code


System code  
Please wait

Evaluate the entry



TwinAlarm enable  
\*= Yes \*=No

Display of the current setting  
and selection of the new condition



TwinAlarm active  
Please wait

Save setting

TwinAlarm active  
Saved

Action completed

Automatic return after 3 seconds

### TwinAlarm active:

The TwinLock system can be connected to a BAS center via the arming device TwinAlarm.

When the alarm function is activated, the functions of the BAS control, the inputs and outputs, and the RS232 port are available.

The activation/deactivation can only be performed by the owner of the system code and is saved in the event log!


### Possible message:

TwinAlarm enable  
No TwinAlarm

No arming device connected, or  
arming device cannot be addressed

## 6.12. Register alarm user

### Menu Navigation:




Alarm  
New user

Select the menu item **'New user'**  
(see menu plan 4.2/ see above)

System code  
Code:\*\*\*\*\*

Enter system code




System code  
Please wait

Evaluate the entry

New user  
User: 01

Select new user number  
(card number)



User: 01  
Insert card

Insert TwinCard code access

User: 01  
Please wait

Save setting



User: 01  
Remove card

Remove TwinCard code access

User: 01  
Saved

Action completed

Automatic return after 3 seconds


### Register alarm user

A mnemonic and a physical code are required to control the BAS. The 'mnemonic' code is realized via the unlocking code of the lock. The chip card is the 'physical' code carrier. The code is saved in the arming device and on the card. Every time the system is disarmed, the physical code is changed, i.e. a new code is stored in the card to achieve a high level of security.

Use the function Register alarm user to allocate a physical code to a specific user. The alarm function is only linked to lock 01 (= system lock).

Only the owner of the system code can create a new alarm user. This action is stored in the event log.


Error messages:



Inserted chip card is invalid  
or cannot be read.

## 6.13. Display Registered Alarm Users

### Menu Navigation:



### Display registered alarm user:

With this function, the system master can check which 'physical codes' (**TwinCard code access**) are currently registered.

This function can only be activated by the owner of the system code and is saved in the event log!

## 6.14. Remove BAS user (Deregister Alarm User)

### Menu Navigation:




Alarm  
remove BAS user

Select the menu item '**remove BAS user**'  
(see menu plan 4.2/ see above)

System code  
Code:\*\*\*\*\*

Enter system code




System code  
Please wait

Evaluate the entry

remove BAS user  
User: 01

Select according user  
(or card number)



remove BAS user  
Deleted

Action completed

Automatic return after 3 seconds

### Deregister alarm user:


The physical code of an alarm user is deleted in the arming device, which means that this user can no longer (arm) disarm the system.

The chip card is not required for deletion, as the code entry is removed from the arming device.

Only the owner of the system code can delete an alarm user. This action is stored in the event log.

## 6.15. Program silent alarm

### Menu Navigation:



Automatic return after 3 seconds

### Silent alarm

A silent alarm is indicated via the alarm output of the arming device (relay output). When the function is activated, a silent alarm is triggered by entering a valid unlocking code (last code digit +1, see example) and stored in the event log. A time delay can be set (00-99 min), which is only activated during the triggering of an alarm. The defined release time of the programmed „normal“ time delay is used as release time. The function 'Silent alarm' can only be performed by the owner of the system code and is saved in the event log.

Example:

User code: 1-2-3-4-5-6-7-8 >> Alarm code 1-2-3-4-5-6-7-9  
(9 becomes 0!)

## 6.16. Write Log and Configuration to Chip Card

### Menu Navigation:

```
*** TwinLock ***
21.05.09 12:00
```


```
*** TwinLock ***
Import / Export
```

```
*** TwinLock ***
Import / Export
```

Select the menu item **'Import / Export'**  
(see menu plan 4.2/ see above)


```
System code
Code:*****
```

Enter system  
code



```
System code
Please wait
```

Evaluate the entry



```
Import / Export
Data - Export
```

Select data export  
with the menu keys


```
Data export
Insert card
```

Insert the TwinCard configuration



```
Data export
Configuration
```

Select Export configuration



```
Write data
>>>>>>
```

Data are written to the  
chip card

```
Data export
Remove card
```



Remove card

The data can be read by means of the **Configuration set TwinComm** and can be processed further.

The data export procedure is stored in the event log.

## 6.17. Read configuration from chip card

### Menu Navigation:


*** TwinLock *** 21.05.09 12:00	*** TwinLock *** Import / Export		
*** TwinLock *** Import / Export	Select the menu item 'Import / Export' (see menu plan 4.2/ see above)		
System code Code:*****	Enter system code		
System code Please wait	Evaluate the entry		
Import / Export Data import	Select data import with the menu keys		
Data import Insert card	Insert the TwinCard configuration		
Data import Configuration	Select Export configuration		
Read data >>>>>>	Data is read from the chip card into the system		
Data import Remove card	Remove card		

The data import procedure is stored in the event log.


## 6.18. Read New System Language

To switch the language of your system, you need an according **TwinCard language**. The language cards can be ordered on request.



### Menu Navigation:





Select the menu item **'Import / Export'** (see menu plan 4.2)




Enter system code




Evaluate the entry





Select data import with the menu keys




Insert the TwinCard language



Select Export configuration



Data is read from the chip card into the system



Remove card

The data import procedure is stored in the event log. The new language is activated immediately after the card has been read.

## 6.19. Install / Change Locks in the System

### Menu Navigation:

*** TwinLock *** 21.05.09 12:00	*** TwinLock *** Service	Service System	System Install new lock
------------------------------------	-----------------------------	-------------------	----------------------------

System  
install new lock

Select the menu item 'install new lock'  
(see menu plan 4.2/ see above)

System code  
Code:\*\*\*\*\*

Enter system code



System code  
Please wait

Evaluate the entry


install new lock  
New lock

install new lock  
change lock

Selection: Re-register  
or change a lock

change lock  
Lock 01

Select the lock to  
be replaced



!!Bus cable on!!

Connect both bus cables of the according  
lock to TwinConnect  
and acknowledge with ENTER  
To allocate the serial number, the master code  
of the new lock must be entered.  
(1 2 3 4 5 6 7 8)

Master codes  
Code:\*\*\*\*\*

Serial number  
Please wait

The serial number is transferred to the lock

install new lock  
Lock 02 OK

Detect and initialize the lock  
Acknowledge the lock number

Automatic return after 3 seconds

### Re-registering/replacing of locks:

Only the owner of the system code can re-register or replace a lock. This action is stored in the event log.

#### **ATTENTION:**



The system code is only queried, if a lock is already registered in the system.

Only one individual lock can be re-registered or replaced. If there are more locks in the system this procedure must be repeated.. Each lock that is being re-registered receives the next highest lock number in the system.


## 6.20. Reset the Input Unit Twin Control/Flat Control

### Menu Navigation:



System  
Reset

Select the menu item '**System Reset**'  
(see menu plan 4.2/ see above)




System code  
Code:\*\*\*\*\*

Enter system code

System code  
Please wait

Evaluate the entry



Reset  
Saved

Action completed

Automatic return after 3 seconds

### System reset:


Only the owner of the system code can perform the system reset. The following settings are reset to factory defaults:

Weekly program	Inactive	Quick unlocking code	09
Special days	Inactive	TwinCard code access	Active
Blocking time	Inactive		
Unlocking delay	Inactive		
Partial blocking	Inactive		
System line	*** TwinLock ***		
Lock with code	Inactive		
Opening duress	Inactive		
Parallel code	Inactive		
Send log online	Inactive		
Arming device	Inactive		
Battery warning limit	7.0V		
Code linkage	1 user		
TwinXT	Inactive		

Only the control unit is reset. This means that all settings which are stored in the control unit are reset to factory defaults. The locks are not reset during this procedure and therefore maintain their allocations.

After a control unit has been reset, it is restarted. The system sends a prompt for re-registering.


```
System setup
New system
```



To re-integrate the existing locks into the system, the menu item "Terminal switch" must be activated using the arrow keys.


```
System setup
Terminal switch
```

Switch to "Terminal switch".  
Acknowledge with Enter




```
System Setup
No. DMS : 01<
```

Select the number of locks  
available in the system.  
Acknowledge with Enter.



```
System-Setup
Terminal No.: 01<
```



Select the number of the control unit.  
Acknowledge with Enter.  
(Usually always: 01)




After all data is entered, a system check is performed and the system is operational.

## 6.21. Query of the Control Unit Version


### Menu Navigation:



Select menu item '**System version query**'  
(see menu plan 4.2/ see above)



Version number is displayed



Automatic return after 5 seconds

### Version query:



Any user can perform the version query. The current FlatControl software version is displayed.




Please note the version lists!

## 6.22. Version Query of the Locks



### Menu Navigation:



Select menu item **'Lock version control'**  
(see menu plan 4.2)



When several locks are available  
in the system, select one lock.



Version number is displayed


Automatic return after 5 seconds

### Version query:



Any user can perform the version query. The current TwinLock software version is displayed.

## 6.23. Reset a Lock

### Menu Navigation:





Select the menu item '**Lock Reset**'  
(see menu plan 4.2/ see above)



When several locks are available  
in the system, select one lock.



Enter the master code of the  
selected lock



Evaluate the entry



Action completed

Automatic return after 3 seconds

### Lock reset:

The reset can only be performed by the owner of the system code and is saved in the event log.

The following settings are reset to factory defaults:


Master code: 12345678  
 User code 01 .. 35: Inactive  
 Input/Output Inactive

The lock addresses, i.e. the allocations, are not reset!



A hardware reset can only be performed by removing the seal. For this purpose, the according lock must be sent to your service partner.

## 6.24. Lock Motor Service


### Menu Navigation:




Select the menu item '**Motor service**'  
(see menu plan 4.2/ see above)




When several locks are available  
in the system, select one lock.




Enter the master code of the  
selected lock



Evaluate the entry



Open and close gradually  
Cancel with ENTER/CLEAR



Automatic return after 150 seconds

### Gradual opening and closing:



With this function, the lock can be opened and closed gradually for service purposes. This function can only be activated or performed by the owner of the according master code of the according lock. The user has 150 seconds to the next motor step. If no key is pressed, the function is cancelled.

The gradual opening or closing of the lock bolt is only meant for service purposes and can only be performed in an unlocked system state.



After this function is completed, it is stored in the event log.

## 6.25. Reset of the Arming Device TwinAlarm


### Menu Navigation:




Select the menu item '**Alarm Reset**'  
(see menu plan 4.2/ see above)



When several locks are available  
in the system, select one lock.



Enter system code



Evaluate the entry



Action completed

Automatic return after 3 seconds

### Alarm device reset:

The reset can only be performed by the owner of the system code and is saved in the event log.

The following settings are reset to factory defaults:

Physical Codes 00 ... 35: Inactive  
 Input level for BAS: low active  
 Relay outputs: Idle  
 State: Disarmed




### Notes:



**The code cards must be re-registered!**  
(see 6.12. Register alarm user)


## 6.26. Version query of the Arming Device TwinAlarm

### Menu Navigation:



Select menu item '**Alarm version query**'  
(see menu plan 4.2)

Version number is displayed



Automatic return after 5 seconds

### Version query:

Every user can perform the version query. The current TwinAlarm software version is displayed.

## 6.27. Activate Parallel Code

### Menu Navigation:



System  
Parallel code

System code  
Code:\*\*\*\*\*

System code  
Please wait

Parallel code  
\*= Yes \*=No



Parallel code  
Saved

Enter system code

Evaluate the entry

Display of the current setting  
and selection of the new condition

Save setting  
Action completed



### Notes:



**Only possible, if there are 2 or 3 locks in the system**

Unlocking procedure:

During the unlocking procedure, the status of lock 01 is queried first. If lock 01 is closed, an unlocking code must be entered without selecting lock 01 beforehand. If lock 01 is open, the condition of lock 02 is automatically queried. When lock 02 is closed, an unlocking code must be entered without selecting lock 02 beforehand. Lock 02 unlocks.

### Programming of the codes

In all locks, the same codes must be programmed for the according users, e.g.

User 08: Code: Lock 1: 08080808  
Code: Lock 2: 08080808  
or  
Code: Lock 3: 08080808

### Notes:

1. For this functionality, the explicit four-eye code (code combination) is deactivated.
2. This function is only approved for 2 or 3 lock operation.

## 6.28. Interrupt Active Timer Programs

### Menu Navigation:

```
*** TwinLock ***  
21.05.09 12:00
```

```
*** TwinLock ***  
21. 05.09 12:00
```


```
Timer Prog.Cancel  
Enter code
```

```
Enter code  
Code: *****
```

In the system menu, first the key F2, then key 2 is pressed

Confirm the entry with "Enter"

Enter the quick unlocking code (Lock 01)



Active timer programs are interrupted for an unlocking procedure

### Notes:



A running timer program (weekly program, special days, blocking time, express blocking) can be interrupted by entering the quick unlocking code.


The timer program is now interrupted for one unlocking process. The unlocking process can be performed.

The entering of the quick unlocking code and the blocking time interruption are logged.

The owner of the quick unlocking code also has the opportunity to trigger a "silent alarm".

## 6.29. Ignore Bolt System Position Switch

### Menu Navigation:



The bolt system position switch, which may be connected to TwinAlarm or TwinXT, is ignored for one locking procedure. This means that the system can still be locked properly even if the switch is damaged.

## 6.30. Automatic Locking

The TwinLock system can be automatically locked using a door switch or a bolt system position switch. The switch is connected to a TwinXT or TwinAlarm system, depending on the system variant.

In idle state (display off), the door or bolt system switch is queried periodically. Pressing the key will automatically lock the system.

### Connection to TwinXT

***The following connections and settings must be performed:***

- Connect the switch at the terminals of the bolt system position switch (see assembly instructions). For a two lock system, the terminals of the bolt system position switch must be bridged for lock 1 and 2.
- Activate TwinXT (via the menu or the PC software)
- Set the forced sequence (via the menu or the PC software TwinComm)
- Setting the switching status for the locking (via PC software TwinComm)
  - Active low => when the contact is closed -> System locks
  - Active high => when the contact is open -> System locks
- Setting: Automatic locking with door switch (via PC software TwinComm)
- Optional: Combination with partial blocking time (via PC software TwinComm)

### Connection to TwinAlarm

***The following connections and settings must be performed:***

- Connect the switch at the terminals of the bolt system position switch or the central contact (see assembly instructions).
- Activate TwinAlarm
- Set the forced sequence (via the menu or the PC software TwinComm)
- Setting: Automatic locking with door switch (via PC software TwinComm)
- Setting the switching state for locking is omitted.
  - => when the contact is closed -> System locks
- Optional: Combination with partial blocking time (via PC software TwinComm)

## 7. Programming of the System with the PC Software TwinComm



The following functions can be performed with the configuration software TwinComm.

### **General settings**

- Silent alarm, alarm delay
- TwinXT active
- Automatic switching to daylight savings time
- Quick unlocking code
- Four-/Six-eye principle
- Lock after bolt system contact query
- Quick unlocking code
- System line
- Battery warning limit
- Parallel code
- Forced Sequence

### **Timer Programs**

- Weekly program
- Special days
- Blocking time
- Time delay, release time
- Teilsperzeit

### **Managing functions**

- Customer data
- User data
- Menu simulator and menu wizard

### 7.1. General Operation

Installation guidelines for the software can be found on the program CD!

#### Start screen




Before the chip card reader is used, the serial interface to which the reader is connected must be activated.

The setting is done in the menu **“Chip card -> Configure“**. Or the user is prompted to select the interface when the PC software starts for the first time.




## License chip card

To activate the PC software you will need a license chip card, which is a part of the scope of delivery of the configuration set. After TwinComm is started, this card must be inserted into the chip card reader.




After the license chip card has been read, the according locking system can be selected. (-> **TwinLock**)

To read the data from the chip card "**TwinCard configuration**", it must be inserted into the chip card reader. Then push the button "**Read chip card**".



To save the data to the chip card "**TwinCard configuration**", it must be inserted into the chip card reader. Then push the button "**Write chip card**".

## 7.2. Program the Weekly Program



### Weekly program:

For the 7 weekdays, 2 periods each are available, during which the system can be unlocked. The weekly program is evaluated every time the unlocking procedure is performed. This means that the unlocking procedure is cancelled when the opening is performed during a time which is not within those two periods defined in the weekly program.

Green : 00:00-00:00      Unlocking can take place all day  
 Gray :                      Unlocking can only take place during the specified period  
 Red :                         No unlocking procedure can be performed on this day


Factory setting:  
 Mo ... Su.: 00:00-00:00      Weekly program deactivated  
                  00:00-00:00

### Attention:



**To ensure proper functioning of the weekly program, the correct setting of the date, time and weekday is required.**

## 7.3. Programming of Special Days



### Special days:

Special days are days where the system can not be unlocked all day.

30 special days are available. The special days are evaluated every time the unlocking procedure is performed. This means that the unlocking procedure is cancelled when the unlocking is performed on days which are defined as special days.

Setting the checkmark will set a special day as a “recurring special day”. This means that the system will be locked each year on this day and month.

The setting of special days can only be performed by the owner of the system code and is saved in the event log!

### Factory setting:


01.01.2006      Special days deactivated  
 Recurring special day deactivated.

### Attention:



**To ensure proper functioning of the special days, the correct setting of the date, time and weekday is required. The settings only apply once for the set date.**

### 7.4. Programming the Blocking Time



#### Blocking time:

It is possible to program a blocking time during which the system can not be unlocked. The blocking time can have a duration of 2 months max.

The programming of this function can only be performed by the owner of the system code and is saved in the event log!

#### Factory setting:


Blocking time deactivated

#### Attention:



To ensure proper functioning of the blocking time, the correct setting of the date, time and weekday is required.

## 7.5. Programming Partial Blocking Times



### Partial blocking time

Two time periods for each of the seven days of the week are available, during which the system may be partially blocked.

The partial blocking is only designed for two lock operation.

Both locks are opened by entering a code.

Within the partial blocking time, only lock 2 is closed; lock 1 remains open.

The evaluation of the partial blocking time takes place during each locking procedure.

If lock 01 must be quickly locked despite an active partial locking time, the ENTER key must be pressed during the locking procedure when "Locking lock 01" "Partially locked!" is displayed. This will skip the partial locking time and close lock 01.

The partial locking time can be combined with the function „automatic locking“ via door switch and will perform the locking after the configured total blocking time has started.

Factory setting:


Mo ... Su.: 00:00-00:00      Partial blocking time deactivated  
 00:00-00:00

### Attention:



**To ensure proper functioning of the weekly program, the correct setting of the date, time and weekday is required.**

## 7.6. Programming of General Settings



### Code linkage

Programming the four-eye code principle  
For unlocking and programming, 2 code entries each are required

### Parallel code

Only possible, if there are 2 or 3 locks in the system

#### Unlocking procedure:

During the unlocking procedure, the status of lock 01 is queried first. When lock 01 is closed, an unlocking code must be entered without selecting lock 01 beforehand.

When lock 01 is open, the condition of lock 02 is queried automatically. When lock 02 is closed, an unlocking code must be entered without selecting lock 02 beforehand. Lock 02 unlocks.

Programming of the codes  
In all locks, the same codes must be programmed for the according users, e.g.

User 08:                   Code: Lock 1: 08080808  
                              Code: Lock 2: 08080808  
                              or  
                              Code: Lock 3: 08080808

Notes:  
1. For this functionality, the explicit four-eye code (code linkage) is deactivated.  
2. This function is only approved for 2 or 3 lock operation.

## Activate TwinXT

Lock I/O. The inputs and outputs of the extension unit TwinXT are activated and queried.

## Quick unlocking code

A user code that skips the unlocking delay can be defined as quick unlocking code.  
Factory setting in the lock: User 09

## General

**Forced sequence** programmable, i.e. the unlocking and locking sequence.  
Unlocking: Lock 01 -> Lock 02  
Locking: Lock 02 -> Lock 01

## Battery warning limit:

With this function, the threshold of the battery warning can be set between 6.8 V and 9.3 V. Critical dropping of the supply voltage is automatically detected and the following message is displayed:

*** TwinLock *** !!! Low Batt !!!
--------------------------------------

## Switching to Daylight savings time:

The time is automatically switched at the last weekend in March and at the last weekend in October.

## Manual locking Code query

can only take place via a code entry.

### Automatic locking a door switch

Automatic locking with bolt system or door switch. For this action, the function **TwinXT active** must be programmed, or **TwinAlarm active**.

### Manual locking after bolt system query

Before the locking procedure, the position of the bolt system is queried using a switch. For this action, the functions **TwinXT active** or **TwinAlarm active** must be programmed.

### TwinAlarm active

Activate TwinAlarm. This function is required for the arming/disarming of a BAS.

### Silent alarm

Activate silent alarm, time delay  
01-99 minutes

### BAS level

BAS input and output level setting  
**Factory setting at the lock: "low active"**



#### Notes:

The levels must only be reprogrammed in special circumstances. The factory setting should be applicable to all conventional burglary alarm systems.

### Arming with code card

From version T08 (control unit), 2 different code cards can be inserted:

**Code card**  
**Code card II**

**Factory setting at the lock: Code card**

It is not possible to use both card types in one system.


### BAS user 1 BAS user 2

Allocating a BAS user number, which is used to not open the lock after it is entered, the code is queried and the BAS is disarmed. Two codes may be defined!

### System line:

The system line is displayed in the 1st. line of the main menu, on the display of the control unit. It can be changed and set as required anytime.


## 7.7. Programming the Unlocking Delay



For each lock, an unlocking delay of 01 – 99 minutes can be programmed. A release time of 01 – 15 minutes can be programmed as well, during which a code entry must take place after the unlocking delay has expired.

Unlocking delay = 00	No unlocking delay
Release time = 00	No code entry after unlocking delay
	The lock is immediately unlocked

### 7.8. Display Event Log




The following events are logged:

All unlocking and locking procedures and all code entries are logged. Furthermore, all configuration procedures and manipulation attempts are logged.


The log list can be printed on a connected printer or saved and archived in a file.

Use the button “Update user” to display the according user names after the log is being read, if the users were entered.

## 7.9. Menu Simulator and Menu Wizard




With the help of the **menu wizard**, individual menus in the user interface of the lock can be activated or deactivated. The structure can be simplified for the user, or individual menus, to which the user should have no access, can be selectively hidden.




With the help of the **menu simulator**, the new user interface can be simulated.

### 7.10. User Data Management




Each user of the lock can be allocated a name which is also saved in the event log.



The user overview can be printed or saved for administrative purposes.

## 7.11. Customer Data Management



Customer data can be saved and archived for each programming. This means that an individual configuration file can be created for each customer. This file can be read also at a later date.


## 8. Appendix

### 8.1. Applications

#### 8.1.2. Remote release


TwinLock - Remote release via remote data transmission

On request !



## 8.1.2. Network Connection

On request !



### Network Connection

- Online logging of all events at the safe
- The control center or head office records and stores events centrally
- Centralized timer programs for all connected safes and their users
- Central access control/release by the head office
- Alarm messages via the network to the control center or head office
- Easy-to-use management software with extensive analysis functions for the head office

## 8.2. Technical Data

### Input Unit: TwinControl

Power supply:	9 VDC (6 x Mignon Alkaline 1,5V) Alternatively, power supply unit 12 VDC via TwinConnect
Current consumption:	Stand-by condition: approx. 30 $\mu$ A Input condition (display active): approx. 55mA
Dimensions:	4.92 x 3.54 x 2.44 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

### Input Unit: FlatControl

Power supply:	9 VDC Alternatively, power supply unit 12 VDC via TwinConnect Alternatively emergency power supply via mini DC jack
Current consumption:	Stand-by condition: approx. 30 $\mu$ A Input condition (display active) approx. 55mA
Dimensions:	5.51 x 4.02 x 0.98 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

### Lock: TwinLock

Power supply:	9 VDC
Current consumption:	Idle state: approx. 40 $\mu$ A Motor operation (without bolt load): approx. 110 mA
Dimensions:	3.54 x 2.40 x 1.34 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

## Arming Device: TwinAlarm

Power supply:	12 VDC
Current consumption:	Idle state: approx. 10mA each active output relay: approx. 20mA
Dimensions:	3.94 x 5.91 x 1.38 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

### Connections.

2 RJ11 connectors for the connection of the system busses A and B  
Terminal connectors for the serial interface RS232 (RX, TC and GND, 1200 baud 8N1), power supply (12 VDC), distributor, inputs and outputs.

## Bus distributor: TwinConnect

Power Supply	12 VDC (optional)
Current consumption	For power supply operation 12 VDC: Approx. 9 mA Only as distributor: 0 mA
Dimensions:	3.94 x 2.36 x 0.98 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30

## Extension Unit: TwinXT

Power Supply	12 VDC (optional) Only for output relay operation
Current consumption	For power supply operation 12 VDC: Approx. 20 mA Per relay Only when the inputs are used: 0 mA
Dimensions:	3.94 x 2.36 x 0.98 inches (L x W x H)
Environment:	32°F - 122°F, 75% RH Environment class II according to VdS
Protection class:	IP 30





### Revision History

Version	Date	Modification	Name
1.00	31.07.01	First edition	MB
1.01	27.06.02	Complete revision	GM
1.02	20.10.03	Extension of the menu plan	MB
1.03	10.05.05	Review	MB
1.04	27.06.05	Supplements	MB
1.05	26.03.06	Supplements partial blocking time/recurring special days/locking with door switch	MB
	19.04.06	Layout adjustment	ES
1.06	30.10.06	New Layout TwinCards	ES
1.08A	14.05.09	Revision	MR

!!! Subject to correction !!!