


AlphaMax 82A

AlphaMax 82S



Alarm and Control Network Element

AlphaMax 82A and AlphaMax 82S

Version 2.2B

Alarm and Control Network Elements

Publication Number UM00A.26120

Date of issue: 10-26-00



"Your Partners In Telecom Management Networks"

4955 E. Yale Ave.

Fresno, CA 93727

Phone (559) 454-1600 / FAX (559) 454-1688 / Toll-free (800) 622-3314

e-mail - sales@dpstele.com

<http://www.dpstele.com>

Copyright 2000, DPS Telecom

Warranty

DPS Telecom products are warranted to be free from defects in material and workmanship at the time of sale. DPS Telecom's obligation under this warranty is limited to the replacement of any hardware proved to be defective within one year from the date of delivery and the replacement of any software for ninety days from the date of delivery. If the product malfunctions during the warranty period, DPS Telecom will repair it at its option at no charge to the purchaser other than the cost of shipping to and from DPS Telecom, which shall be the responsibility of the purchaser. Before using, the purchaser shall determine the suitability of the product for the intended use and user assumes all risk and liability whatsoever in connection therewith. This warranty is made in lieu of and excludes all other warranties, expressed or implied. The implied warranties of merchantability and fitness for a particular use are specifically excluded. Neither seller nor manufacturer shall be liable for any other injury, loss or damage, whether direct or consequential, arising out of the use of or the inability to use this product.

Purchaser shall fill out the requested information on the Product Warranty Card and mail it to DPS Telecom. This card provides information that helps DPS Telecom make product improvements as well as develop new products that better suit our customer's needs.

Extended Warranty

For an additional fee seller may make available to purchaser an extended warranty, providing an additional period of time for the applicability of the standard warranty provided with hardware and software. If the product malfunctions during the warranty period, DPS Telecom will repair it at its option at no charge to the purchaser other than the cost of shipping to and from DPS Telecom, which shall be the responsibility of the purchaser. An extended warranty, when purchased, is made in lieu of and excludes all other warranties, expressed or implied, other than the standard warranty. The implied warranties of merchantability and fitness for a particular use are specifically excluded. Neither seller nor manufacturer shall be liable for any other injury, loss or damage, whether direct or consequential, arising out of the use of or the inability to use this product.

In Case of Failure

If a product should fail while in service, contact DPS Telecom for technical support. Many problems are fixed with a simple phone call. Have available the invoice to determine if the product is under warranty. If the problem cannot be solved over the telephone and the product is in warranty, DPS Telecom will authorize the return of the product for service and will provide shipping information. If the product is out of warranty, repair charges will be quoted and repairs will be made after the charges are authorized by the customer. All non-warranty repairs receive an additional 90-day warranty.

Copyright Notice

All software and manuals are copyrighted by DPS Telecom. Said software and manuals may not be reproduced, copied, transmitted or used to make a derivative work, by either mechanical, electronic or any other means, in whole or in part, without prior written consent from DPS Telecom, except as required by United States Copyright laws. All rights reserved.

Trademark Acknowledgments

IBM is a registered trade mark of International Business Machines, Inc.

Windows, Windows 95, Windows 98, and Windows NT are registered trade marks of Microsoft Corp.

Notice

The information contained in this document is subject to change without notice. DPS Telecom assumes no responsibility for any errors that may appear in materials or programs.

Table of Contents

Chapter 1 - Overview	1
AlphaMax 82A and 82S	2
Chapter 2 - Hardware Setup	5
AlphaMax 82A (model 245)	6
AlphaMax 82A (model 246)	8
AlphaMax 82S (model 247)	10
AlphaMax 82A with optional single connector block	12
AlphaMax 82A with optional UPS connector block	14
AlphaMax 82A with panel mounted wire wrap block	16
Chapter 3 - Software Setup	19
T/AlphaW Software	20
Tconfig	20
Configuration Data (Fill In)	21
Install T/AlphaW	22
Start T/AlphaW	23
Define a New Device	24
Edit an Existing Device	25
Pagers	26
Alarms	27
Relays	28
Advanced - Site Definition	29
Advanced - Pagers	30
Advanced - Alarms	31
Advanced - Relays	32
Save your file	33
Select your computer's modem.	34
Write (Download) Configuration to AlphaMax	35
Ring Bypass Feature	36
Software Menu Chart	38

Table of Contents

Chapter 4 - Checkout - - - - -	39
Connect - - - - -	40
Test Alarms - - - - -	41
Test Controls - - - - -	42
Test Pager - - - - -	43
Pager Test Feature - - - - -	44
Chapter 5 - Operation - - - - -	45
AlphaNumeric Pager - - - - -	46
Numeric Pager - - - - -	47
ASCII Terminal - - - - -	48
DTMF Direct Dial In - - - - -	49
Advanced - Monitor Mode - - - - -	50
Advanced - LED Display Status - - - - -	51
Advanced - ASCII Through Port Access (82S) - - - - -	52
Advanced - Flow Chart - - - - -	53
Chapter 6 - Correcting a Malfunction - - - - -	55
How to Obtain Technical Support After Hours - - - - -	56
Checklist - - - - -	57
Chapter 7 - Frequently Asked Questions - - - - -	61
Chapter 8 - Specifications - - - - -	65
Features - - - - -	66
AlphaMax Description - - - - -	67
UPS Connector Block Description - - - - -	69
Technical Description - - - - -	70
AlphaMax Functional Schematic - - - - -	71
AlphaMax 82A Specifications - - - - -	72
AlphaMax 82S Specifications - - - - -	73
UPS Connector Block Specifications - - - - -	74
AlphaMax Part Numbers - - - - -	75
Accessory Part Numbers - - - - -	76
Index - - - - -	77

Chapter 1 - Overview

The following pages give a brief description of what the AlphaMax can do for you.

Chapter 1 - Overview

AlphaMax 82A and 82S - - - - - 2

Cautions

Observe electrostatic precautions when servicing this equipment.

Observe polarity when connecting power to this unit.

There are no user serviceable parts inside the enclosure.

For intra-building connections, all interfaces must be connected through a shielded cable that is grounded at both ends.

AlphaMax 82A and 82S

DPS' AlphaMax 82A or 82S, teamed with your local pager service, will let you know when you have an important event occurring at some isolated, unmanned location. The AlphaMax can be supplied with a "UPS" Connector Block with Battery Backup to simplify installation and provide continued operation during power outages.

The AlphaMax can detect any event that can be translated into an electrical signal, such as that coming from a micro switch or photo cell. Door openings and equipment failures are typical events that it can report on your pager. In addition, you can contact the AlphaMax from any tone dialing telephone and, by password identification, activate remote control devices like door locks or security lights. AlphaMax has broad applications in many areas, including:

Telecommunications - The AlphaMax is just right for cell sites, small offices and remote huts for monitoring tower lights and other critical equipment. In addition to its pager reporting, telecom locations may forward selected alarm points to a central monitoring system. AlphaMax reports with TRIP protocol or ASCII messages.

Transportation - AlphaMax is ideal for monitoring crossing gates and other safety devices and reporting problems via pager or cellular phone.

Refrigeration - AlphaMax monitors freezer doors, temperature, compressor operation and power lines, warning you of problems before they become losses.

Manufacturing - AlphaMax monitors processes and equipment status on-line, paging your maintenance and supervisory personnel throughout a facility, 24 hours a day.

Security - AlphaMax can pinpoint entry violations to a specific door or window. Security personnel are notified of activity even when they are on another part of the property.

Agriculture - An AlphaMax in a barn or other out-building can notify you of an unauthorized entry, temperature extreme, fire, low water pressure, pump operation, etc. With AlphaMax's remote control capability, you can operate door locks, security lights and pumps. With wide-area paging service, you can know the condition of your ranch or farm no matter where you are.

Configuration Software - Configuring AlphaMax from your PC is easy with the *new* T/Alpha for Windows^(tm) (T/AlphaW) software, that runs under Windows 95, Windows 98 or Windows NT. The software also monitors alarms and operates control relays.

ASCII Port Access - The AlphaMax 82S has all the features outlined above, plus the ability to remotely access the craft port of a nearby device. This allows you to download instructions and obtain status information from a PABX, server, radio, etc.

Mounting Accessories - A single connector block, a combination UPS and connector block and a wire wrap block are available to assist your AlphaMax installation.




Fig. 1 - AlphaMax reports alarms to a variety of devices.





Fig 2 - Mounting Accessories Simplify Installation

Chapter 2 - Hardware Setup

The following pages tell you how to install and connect your AlphaMax.

There are 6 variations of hardware setup. Go to the pages designated below for the type of installation you are doing:

Chapter 2 - Hardware Setup

AlphaMax 82A (model 245), single ended inputs, directly connected at J1 - - - - -	6
AlphaMax 82A (model 246), bipolar inputs, directly connected at J1 - - - - -	8
AlphaMax 82S (model 247), single-ended inputs, directly connected at J1 - - - - -	10
AlphaMax 82A with optional single connector block - - - - -	12
AlphaMax 82A with optional UPS connector block - - - - -	14
AlphaMax 82A with panel mounted wire wrap block - - - - -	16

AlphaMax 82A (model 245), single ended inputs, directly connected at J1

The installer provides alarm contacts, power source and wires to the alarm and control points.

1. Unpack the AlphaMax and all accessories. Check contents against the shipping list that is packed in the box.
2. Fill out and mail the postage prepaid registration card.
3. Use the enclosed mounting template and hardware to mount the AlphaMax.



The AlphaMax is shipped with all necessary cables for installation.


4. Connect a phone line to the RJ12 jack (J5) on the AlphaMax.
5. Connect alarm points and controls to J1 on the AlphaMax. A DB25 connector and hood are supplied in the AlphaMax cable kit. Refer to Fig 3.



To operate an alarm, there must be an electrical path from the Alarm (no.)A (input) pin to the Alarm (no.)B (return) pin. Example: (see Fig. 3) To operate alarm point 5, J1-pin 7 (Alarm 5A) connects to one terminal of a (normally-open) switch or relay contact. J1-pin 19 (Alarm 5B) connects to the other terminal of the switch or relay contact. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Do not connect power adaptor to the AlphaMax while "hot."

- 6a. **If you are using AC Power** - Connect the power adapter to J4 on the AlphaMax, then plug the adaptor into an AC outlet.
 - 6b. **If you are using DC Power** - A DC supply may be connected to J1 pins 1 (- gnd) and 14 (+) on the AlphaMax.
7. Go to Chapter 3 - Software Setup on page 19.



AlphaMax 82A

Model 245 (single-ended opto inputs)

PIN #	DESCRIPTION	PIN #	DESCRIPTION
1	Power Ground *	14	+ Power Input *
2	Not Connected (model 245)	15	Alarm 1B
3	Alarm 1A	16	Alarm 2B
4	Alarm 2A	17	Alarm 3B
5	Alarm 3A	18	Alarm 4B
6	Alarm 4A	19	Alarm 5B
7	Alarm 5A	20	Alarm 6B
8	Alarm 6A	21	Alarm 7B
9	Alarm 7A	22	Alarm 8B
10	Alarm 8A	23	Control 2-Normal Close
11	Control 1-Normal Close	24	Control 2-Normal Open
12	Control 1-Normal Open	25	Control 2-Common
13	Control 1-Common		

FEMALE DB25

Connect Alarm A points to Alarm B points through alarm contact.

Switch or Relay Contact

*** NOT REQUIRED WHEN AC WALL TRANSFORMER IS USED.**

Fig. 3 - Connect alarm and control points at the DB25 connector on the AlphaMax 82A.

AlphaMax 82A (model 246), bipolar inputs, directly connected at J1

The installer provides alarm contacts, power source and wires to the alarm and control points.

1. Unpack the AlphaMax and all accessories. Check contents against the shipping list that is packed in the box.
2. Fill out and mail the postage prepaid registration card.
3. Use the enclosed mounting template and hardware to mount the AlphaMax.



The AlphaMax is shipped with all necessary cables for installation.

4. Connect a phone line to the RJ12 jack (J5) on the AlphaMax.
5. Connect alarm points and controls to J1 on the AlphaMax. A DB25 connector and hood are supplied in the AlphaMax cable kit. Refer to Fig 4.



To operate an alarm, there must be an electrical path from the Alarm (no.)A (input) pin to the Alarm (no.)B (return) pin. This model AlphaMax can use switched ground or switched battery.

Example: (see Fig. 4) Switched ground: To operate alarm point 5, J1-pin 7 (Alarm 5A) connects to one terminal of a (normally-open) switch or relay contact. The other terminal of the switch or relay contact is connected to negative ground. J1-pin 19 (Alarm 5B) connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.


Switched battery: To operate alarm point 5, J1-pin 7 (Alarm 5A) connects to negative ground. J1-pin 19 (Alarm 5B) connects to one terminal of a (normally-open) switch or relay contact. The other terminal of the switch or relay contact is connected to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Do not connect power adaptor to the AlphaMax while "hot."

6a. **If you are using AC Power** - Connect the power adaptor to J4 on the AlphaMax, then plug the adaptor into an AC outlet.

6b. **If you are using DC Power** - A DC supply may be connected to J1 pins 1 (- gnd) and 14 (+) on the AlphaMax.

7. Go to Chapter 3 - Software Setup on page 19.



Chapter 2




Fig. 4 - Connect alarm and control points at the DB25 connector on the AlphaMax 82A.

AlphaMax 82S (model 247), single-ended inputs, directly connected at J1

The installer provides alarm contacts, power source and wires to the alarm and control points.

1. Unpack the AlphaMax and all accessories. Check contents against the shipping list that is packed in the box.
2. Fill out and mail the postage prepaid registration card.
3. Use the enclosed mounting template and hardware to mount the AlphaMax.



The AlphaMax is shipped with all necessary cables for installation.

4. Connect a phone line to the RJ12 jack (J5) on the AlphaMax.
5. Connect alarm points and controls to J1 on the AlphaMax. Connect ASCII reach-through port to J1 on the AlphaMax. A DB25 connector and hood are supplied in the AlphaMax cable kit. Refer to Fig. 5.



To operate an alarm, there must be an electrical path from the Alarm (no.)A (input) pin to the Alarm (no.)B (return) pin. Example: (see Fig. 5) To operate alarm point 5, J1-pin 7 (Alarm 5A) connects to one terminal of a (normally-open) switch or relay contact. J1-pin 19 (Alarm 5B) connects to the other terminal of the switch or relay contact. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Do not connect power adaptor to the AlphaMax while "hot."

- 6a. **If you are using AC Power** - Connect the power adapter to J4 on the AlphaMax, then plug the adaptor into an AC outlet.
 - 6b. **If you are using DC Power** - A DC supply may be connected to J1 pins 1 (- gnd) and 14 (+) on the AlphaMax.
7. Go to Chapter 3 - Software Setup on page 19.

AlphaMax 82A with optional single connector block




Fig. 5- On the AlphaMax 82S, the DB25 connector provides access for alarm points, control points and the ASCII reach-through port.

Chapter 2 - Hardware Setup

The installer provides alarm contacts, power source and wires to the alarm and control points.

1. Unpack the AlphaMax and all accessories. Check shipping list.
2. Fill out and mail the postage prepaid registration card.
3. Use the mounting template and hardware to mount the AlphaMax.
4. Mount connector block assembly within 3 feet of the AlphaMax.
5. Attach DB25 cable between connector block J1 and AlphaMax J1.
6. Connect a phone line to the RJ12 jack (J5) on the AlphaMax.
7. Connect all alarm and control points at the connector block. (Fig. 6)

An electrical path from the Alarm (no.)A pin to the Alarm (no.)B pin causes an alarm.

AlphaMax model 245 uses a “dry contact” switch.



Example: (see Fig.6) To operate alarm point 5, Alarm 5A connects to one terminal of a (normally-open) switch or relay contact. Alarm 5B connects to the other terminal. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

AlphaMax model 246 uses switched ground or switched battery.

Example: (see Fig. 6) Switched ground: To operate alarm point 5, Alarm 5A connects to one terminal of a (normally-open) switch or relay contact. The other terminal connects to negative ground. Alarm 5B connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Switched battery: To operate alarm point 5, Alarm 5A connects to negative ground. Alarm 5B connects to one terminal of a (normally-open) switch or relay contact. The other terminal connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Do not connect a “hot” power adaptor to the AlphaMax.

8a. **If you are using AC Power** - Connect the power adapter to J4 on the AlphaMax, then plug the adaptor into an AC outlet.

Do not remove the DB25 cable while power is applied.

8b. **If you are using DC Power** - A DC supply may be connected to pins J2-1 (+) and J2-2 (negative ground) on the connector block.

9. Go to Chapter 3 - Software Setup on page 19.





Fig. 6 - Single Connector Block comes with Screw Lug Terminals (non-UPS).

AlphaMax 82A with optional UPS connector block

The installer provides alarm contacts, power source and wires to the alarm and control points.

Do not remove cables from the AlphaMax or the UPS while power is applied.

Use only the batteries supplied with the unit. Other batteries will not provide the rated performance and may damage the charging circuitry.



1. Unpack the AlphaMax and all accessories. Check shipping list.
2. Fill out and mail the postage prepaid registration card.
3. Use the mounting template and hardware to mount the AlphaMax.
4. Mount Connector Block Assembly within 3 feet of the AlphaMax.
5. Jumpers are factory set. If it is absolutely necessary to change jumpers or to change the fuse, remove cover as follows:
 - a. Remove three screws.
 - b. Remove nut from PWR 1 jack.
 - c. Remove bolts from DB25 connector.
 - d. Rock cover back.
 - e. Change jumpers as needed. (See detail in Fig. 7.)
 - f. Reverse procedure to reinstall cover.
6. Connect the 3 foot DB25 cable between J1 on the UPS Connector Block and J1 on the AlphaMax.
7. Connect a phone line to the RJ12 jack (J5) on the AlphaMax.
8. Connect all alarm and control points at the connector block. (Fig. 7)

NOTE 

An electrical path from the Alarm (no.)A pin to the Alarm (no.)B pin causes an alarm.

AlphaMax model 245 uses a “dry contact” switch.

Example: (see Fig. 7) To operate alarm point 5, Alarm 5A connects to one terminal of a (normally-open) switch or relay contact. Alarm 5B connects to the other terminal. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

AlphaMax model 246 uses switched ground or switched battery.

Example: (see Fig. 7) Switched ground: To operate alarm point 5, Alarm 5A connects to one terminal of a (normally-open) switch or relay contact. The other terminal connects to negative ground. Alarm 5B connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Switched battery: To operate alarm point 5, Alarm 5A connects to negative ground. Alarm 5B connects to one terminal of a (normally-open) switch or relay contact. The other terminal connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Do not connect power adaptor to the AlphaMax while "hot."
Do not remove the DB25 cable while power is applied.

9a. **If you are using AC Power** - Connect the power adaptor to the PWR 1 jack on the UPS connector block assembly.

9b. **If you are using DC Power** - A DC supply may be connected to pins J2-1 (+) and J2-2 (negative ground) on the connector block.

10. Go to Chapter 3 - Software Setup on page 19.




Fig. 7 - UPS single Connector Block Provides up to 3 Hours of Battery Backup.

AlphaMax 82A with panel mounted wire wrap block

The installer provides alarm contacts, power source and wires to the alarm and control points.

1. Unpack the AlphaMax and all accessories. Check contents against the shipping list that is packed in the box.
2. Fill out and mail the postage prepaid registration card.
3. Use the enclosed mounting template and hardware to mount the AlphaMax.



If you are using a DPS rack mount panel, up to two AlphaMaxes and the wire wrap block can be mounted on a panel.

4. Remove the wire wrap block cover.
5. Mount block assembly to panel or other flat surface.
6. Plug cable into AlphaMax.
7. Connect a phone line to the RJ12 jack (J5) on the AlphaMax.
8. Connect all alarm and control points at the wire wrap block. (Fig. 8)



An electrical path from the Alarm (no.)A pin to the Alarm (no.)B pin causes an alarm.

AlphaMax model 245 uses a “dry contact” switch.

Example: (see Fig. 8) To operate alarm point 5, wire wrap block pin A-7 (Alarm 5A) connects to one terminal of a (normally-open) switch or relay contact. Wire wrap block pin B-9 (Alarm 5B) connects to the other terminal. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

AlphaMax model 246 uses switched ground or switched battery.

Example: (see Fig. 8) Switched ground: To operate alarm point 5, wire wrap block pin A-7 (Alarm 5A) connects to one terminal of a (normally-open) switch or relay contact. The other terminal connects to negative ground. Wire wrap block pin B-9 (Alarm 5B) connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Switched battery: To operate alarm point 5, wire wrap block pin A-7 (Alarm 5A) connects to negative ground. Wire wrap block pin B-9 (Alarm 5B) connects to one terminal of a (normally-open) switch or relay contact. The other terminal connects to positive battery. When the switch or relay contact closes, current flows in the circuit and an alarm is sensed.

Do not connect power adaptor to the AlphaMax while “hot.”
Do not remove the DB25 cable while power is applied.

9a. **If you are using AC Power** - Connect the power adaptor to J4 on the AlphaMax, then plug the adaptor into an AC outlet.

9b. **If you are using DC Power** - DC power may be taken through the wire wrap block at pins F-1 (+) and F-3 (negative ground). (This arrangement is only suitable for +24 V operation. It utilizes the fusing provided on the wire wrap block.)

10. Go to Chapter 3 - Software Setup on page 19.




Fig. 8 - Wire Wrap Block Supports One or Two AlphaMax 82As.

Chapter 3 - Software Setup

The following pages tell you how to prepare a configuration file and write (download) it to your AlphaMax.

Chapter 3 - Software Setup

T/AlphaW Software -	20
Tconfig -	20
Configuration Data (Fill In)-	21
Install T/AlphaW -	22
Start T/AlphaW -	23
Define a New Device -	24
Edit an Existing Device -	25
Pagers-	26
Alarms -	27
Relays-	28
Advanced - Site Definition -	29
Advanced - Pagers -	30
Advanced - Alarms -	31
Advanced - Relays -	32
Save your file -	33
Select your computer's modem. -	34
Write (Download) Configuration to AlphaMax -	35
Ring Bypass Feature -	36
Software Menu Chart -	38

NOTE  *The AlphaMax 82 A must be configured over a phone line through a central office because the AlphaMax modem must receive a ring signal to be activated. Two phone lines are required if the configuration is done on-site: one for the AlphaMax and one for a DOS-based PC running T/Alpha.*

NOTE  *The AlphaMax 82S may be configured over a phone line, as described above, or it can also be configured directly through the craft port.*

T/AlphaW Software

T/AlphaW software is used to configure the AlphaMax. T/AlphaW may also be used to monitor alarm and control point status and to operate control relays.



T/AlphaW software runs under Windows 95, 98 or NT.

Tconfig

Your T/AlphaW program and files will normally be located in a directory named Program Files\Tconfig\AlphaMax. (You can specify a different directory when you install T/AlphaW.) All other DPS configuration programs and files will also be located in the Tconfig (or your specified) directory.

Table A - Configuration Procedure

Step	Action	Page
1	Install T/AlphaW	22
2	Start T/AlphaW	23
3 Define a new device	Site	24
	Pagers	26
	Alarms	27
	Relays	28
4	Save your file	33
5	Select your Computer's modem	34
6	Download Configuration	35
7	Check Out	39



Always use the "Exit" function from the Edit Menu to quit the program. NEVER turn off the computer before exiting. Doing so can corrupt data files!

Configuration Data (Fill In)

Record information in the Table B before starting configuration:

Table B - Configuration Data

Site Definition					
Site Name					
Comment					
Site Number					
Phone Number					
Advanced	Use only to change parameters for the AlphaMax modem. See Fig. 19.				
Pagers					
User Number	Device Type	Dial String	Alpha Pager PIN	Password	
1					
2					
3					
4					
Advanced	Use only to change paging parameters like call out delay, redial attempts, TAP baud, word length, parity and stop bits. See Fig. 20.				
Alarms					
Alarm Number	Description	Primary Pager User Number	Time to wait to Acknowledge	Secondary Pager User Number	Number of times to report
1					
2					
3					
4					
5					
6					
7					
8					
Advanced	Use only to change the default settings for alarm qualification period, whether to call when an alarm clears, to change the polarity (alarm on closed contact to alarm on open contact) and the qualification period base time. See Fig. 21.				
Relays					
Relay Number	Description				
1					
2					
Advanced	Use only to define a derived control point. (Control point activated by an alarm or combination of alarm conditions.) See Fig. 22.				

Install T/AlphaW

1. Place the T/AlphaW disk in the A: drive.

2. Click the Start button.

3. Click Run.




Fig. 9 - Install T/AlphaW software from your Windows desktop.

4. Type A:\AMAX in the run box that appears.

5. A window titled “Win Zip Self-Extractor [AMAX.EXE]” will appear. Click on the setup button in this window.

6. The Installshield wizard will run. Follow the instructions on the screen.

7. When installation is completed, you may wish to create an AlphaMax icon on your desktop. Follow standard Windows procedure to do this.

8. Go to page 23.

Start T/AlphaW

You can launch the program file at the end of the installation or later by double clicking the Shortcut to AlphaMax icon on your desktop. If you have not created an icon, launch the program using one of the many ways provided by your windows desktop (use Windows Explorer or My Computer or click Start, Programs, AlphaMax, etc.)



Fig. 10 - Double click the AlphaMax icon to launch T/AlphaW.

If you have existing data files created under DOS versions of T/Alpha, use “Tools - Import Device” to convert to Windows format.

Enter your initials in the initials box.




Fig. 11 - Your initials are recorded for future reference.

The T/AlphaW screen will appear. The New Device definition box will be displayed.




Fig. 12 - Unique site information is entered in the Site Definition box.

Go on to page 24.

Define a New Device

Site - Use the information you entered in Table A to fill in the fields in the Site Definition box.




Fig. 13 - Record details about the site in the Site Definition box.

T/AlphaW can maintain several configurations. New configurations can be added and existing ones can be edited or deleted.

If you need to change parameters for the AlphaMax modem, click Advanced. See page 29.

Go on to **Pagers** on page 26.



For an explanation of any item, click on the field and press F1. The context-sensitive help screen will appear.

Edit an Existing Device

If you wish to edit an existing device, click File on the T/AlphaW menu bar.

T/AlphaW can maintain several configurations. New configurations can be added and existing ones can be edited or deleted.

Select Open Device from the drop down menu.

Select the desired file from the directory listing that appears.




Fig. 14 - You can open an existing configuration in the Open Device window.

The Site Definition box will appear. Edit information in the Site Definition box as necessary.




Fig. 15 - An existing configuration can be renamed to make a new one.

Click on the tab(s) for other parameter(s) you wish to edit, and change as needed. Go to pages 33-35 for save and download instructions.

Pagers

Click the Pager tab at the top of the Device Definition box.

Be sure to include a “1” if dialing long distance or “9” if dialing through a PABX*. Use the information you entered in Table A to fill in the fields in the Pager Definition box.




Fig. 16 - Define up to four “pager” devices for the AlphaMax to call.

Phone numbers for numeric pagers should be followed by 2 commas to provide delay.

To reduce the possibility of unauthorized access, change all User ID Numbers from the default.

If you need to change paging parameters, click Advanced. See page 30.

Go on to Alarms on page 27.



For proper Alpha pager operation you need your TAP terminal phone number and your PIN.*

*See Chapter 7 for definitions.

Alarms

Click the Alarms tab at the top of the Device Definition box.

If using the “UPS” battery-backup option, you may define point 2 or 8 for battery alarm, CLOSED NORMAL state.

Use the information you entered in Table A to fill in the fields in the Alarms Definition box.




Fig. 17 - Each alarm point can be assigned to a primary and secondary pager device.

If you need to change default settings for the Alarms, click Advanced. See page 31.

Go on to **Relays** on page 28.

Relays

Click the Relays tab at the top of the Device Definition box.

Use the information you entered in Table A to fill in the fields in the Relay Definition box.




Fig. 18 - Assign a description for each control point.

If you need to define derived controls, click Advanced. See page 32.

Go on to **Save your file** on page 33.

Advanced - Site Definition

The **Site Definition - Advanced** box is used to change the AlphaMax's modem parameters.




Fig. 19 - Set modem parameters in the Site Definition - Advanced window.

NOTE  For an explanation of any item, click on the field and press F1. The context-sensitive help screen will appear.

NOTE  If you are using the Ring Bypass Features, see pages 36 and 37.

After you have completed **Advanced - Site Definitions**, go to page 26.

Advanced - Pagers

The **Pagers - Advanced** box is used to set paging parameters, define alarm reporting messages and define the characters used for periodic status reporting.




Fig. 20 - Set pager details in the Pagers - Advanced window.

NOTE  Alarm and Clear Messages are used in COS reports to Alpha pagers. These reports show only the point that has changed.

NOTE  Alarm and Clear Characters are used in periodic status reports to Alpha pagers. These reports list all points.

After you have completed **Advanced - Pagers**, go to page 27.

Advanced - Alarms

The **Alarms - Advanced** box is used to set timing, polarity, repetition parameters and call when clear option. It is also used to define special applications for alarm point 1 and control relay 1.

Alarm Number	Description	Qual Period mm : ss	Call When Clear	Normally Closed	Repetition Count	Repetition Time hh : mm
1	FRONT DOOR	2 : 00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	3	0 : 15
2	TOWER LIGHT	0 : 00	<input checked="" type="checkbox"/>	<input type="checkbox"/>		— : —
3	EAST TRANSMITTER	0 : 10	<input checked="" type="checkbox"/>	<input type="checkbox"/>		0 : 00
4	WEST TRANSMITTER	0 : 10	<input checked="" type="checkbox"/>	<input type="checkbox"/>		— : —
5	POWER	0 : 10	<input checked="" type="checkbox"/>	<input type="checkbox"/>	2	1 : 00
6	HIGH TEMP	0 : 30	<input checked="" type="checkbox"/>	<input type="checkbox"/>		— : —
7	LOW TEMP	0 : 30	<input checked="" type="checkbox"/>	<input type="checkbox"/>		— : —
8	SWITCH	0 : 05	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		— : —

Qual Period Base Time: Seconds

Use Alarm 1 for local ack
 Activate Relay 1 on change-of state

Fig. 21 - Set alarm details in the Alarms - Advanced window.

NOTE  For an explanation of any item, click on the field and press F1. The context-sensitive help screen will appear.

After you have completed **Advanced - Alarms**, go to page 28.

Advanced - Relays

The Relay 1 - Advanced and Relay 2- Advanced boxes are used to define derived controls.




Fig. 22 - Program derived controls in the Relay 1 - Advanced or Relay 2 - Advanced window.



NOTE For an explanation of any item, click on the field and press F1. The context-sensitive help screen will appear.

This derived control screen is composed of two matrices that are logically “OR’d” Each matrix consists of 3 rows (alarm status) by 8 columns (alarm points). The alarm points in each set are logically “AND’d”, which means that “ALL” of the columns must evaluate “TRUE” in order for the matrix to be true.

Example 1: If you declare an alarm when points 1, 3, & 5 are set, then simply set those points under the “When these alarms are set” row. Be sure to mark all the other alarms as “These alarms don’t matter.” The “These alarms are clear” row would only be used if you wish to declare an alarm when those marked points are “not” in alarm.

Example 2: If you wish to declare an alarm when point 3 or point 5 fails, then you would do the following:

Mark point 3 in the “when these alarms are set” position of the FIRST matrix (Activate Relay). Make sure all other points in that matrix are set to the “These alarms don’t matter” row.

Mark point 5 in the “when these alarms are set” position of the SECOND matrix (OR Activate Relay). Make sure all other points in that matrix are set to the “These alarms don’t matter” row.

After you have completed **Advanced - Relays**, go to **Save your file**.

Save your file

When you have finished entering the configuration data, click File, Save Device As. Type a name in the Save As box and click OK.

Go on to **Select your computer’s modem** on page 34.




Fig. 23 - Select a directory and enter a name for your file before saving.

Select your computer's modem.

Before you can download a configuration file to the AlphaMax, you must select your computer's modem or serial port (AlphaMax 82S only).

AlphaMax 82A connects via dial modem. AlphaMax 82S can connect via dial modem or serial port at J1 (Fig. 5).

Click Connect. The Connect options box will appear. Click the down arrow in the Line Names field. Select the modem or serial port you are using. (The list will show only those modems or ports that are equipped on your computer. Most likely you have only one modem. If so, it will already be selected.) Do not change any modem or port settings unless you later have problems connecting to your AlphaMax.




Fig. 24 - Your computer's modem will be listed in the Line Name field.

To reduce the possibility of unauthorized access, change all User ID Numbers from the default.

The first time you write a configuration file to a new AlphaMax, you must enter the default "1" in the password box. Any time you write to an AlphaMax with a password change for user number 1, the old password must be entered in the password box.

Go on to **Write (Download) Configuration to AlphaMax** on page 35.

Write (Download) Configuration to AlphaMax

Click the Connect button. It will take several seconds to establish the connection.



If your modem does not connect to the AlphaMax, you may need to adjust the Baud. Click on the Line Properties button in the Connect Options box. If your modem is an older version that operates at 14.4 K Baud or less, change to 1200 Baud. If your modem is a newer one that operates at 19.2K Baud or greater, change to 19200 Baud.

If you still have problems, contact DPS tech support at 1-800-622-3314.

Click the “Write to AlphaMax” button to start writing the file. A box will show the progress.

Upon completion the Cancel button will say “Done.” Click on this button to begin the exit procedure.



If you click the Cancel button before the writing procedure is done, your AlphaMax may have an incomplete configuration file. You will need to perform a complete “write to” before it will work properly.

Click the disconnect button.

Exit T/AlphaW or proceed with other activities. (We recommend that you perform the checkout procedure beginning on page 40.)

Ring Bypass Feature

The AlphaMax 82A and 82S, ver. 2.1D offers an “answering machine bypass” feature not available on previous versions. This new feature allows the AlphaMax to share the phone line with an answering machine, modem, FAX or any other device that answers after a set number of rings. In this application, you let the phone ring a set number of times (2, for example) when calling the AlphaMax, then hang up. When you call back within another set time period (60 seconds, for example) the AlphaMax will answer on a specified ring (1, for example). The answering machine must be set to answer on a later ring (4, for example).

The Ring Bypass function is defined in the Site Definition - Advanced screen. Refer to the illustration below and Table C.






Fig. 25 - Ring Bypass parameters are defined in the Site Definition - Advanced window.

Return to page 29.

Table C - Ring Bypass Function is defined in the Site Definition / Advanced Screen

Field Name	Description
Ring Bypass (Check box to enable)	<p>Allows you to set conditions for the answering machine bypass feature. The following diagram shows an example of the time sequence for the bypass:</p> <p style="text-align: center;">Answering Machine On (Answering Machine set to answer in 5 rings) Bypass Rings = 1</p>  <p>Break sets the number of seconds between sets of rings before the bypass window opens (the minimum time you must wait before redialing). (5 to 15 sec. Set 0 to disable) This must be greater than the time between rings, which is typically 5 seconds.</p> <p>Active sets the time the bypass window is to remain open (the maximum time you have to redial). (20 to 90 sec).</p> <p>Rings sets the number of rings before the AlphaMax answers the second call (1 to 7 rings). <i>NOTE: This must be less than the number of rings before the answering machine answers.</i></p> <p><i>NOTE: If there is no break between sets of rings and if the answering machine is off, the AlphaMax will answer on the Number of Rings setting (6 in the example above).</i></p>
Squelch Time (Seconds)	AlphaMax 82S only. Delay after the dial-up craft port becomes active (1 to 90 sec.)

Software Menu Chart



For details about any item, click on the item and press F1.

Chapter 4 - Checkout

After hardware and software have both been set up, use the procedure on the following pages to verify that your AlphaMax is doing its job correctly.

Chapter 4 - Checkout

Connect - - - - -	40
Test Alarms - - - - -	41
Test Controls - - - - -	42
Test Pager - - - - -	43
Pager Test Feature - - - - -	44

Connect

After completing installation and configuration, the following routine is recommended to verify proper operation.

NOTE  *The AlphaMax 82A must be tested over a phone line because the modem must receive a ring signal to be activated. Two phone lines are required if the testing is done on-site: one for the AlphaMax and one for your PC. The AlphaMax 82S can be tested the same way or it can be tested locally with your computer's serial port connected to the RS232 port (See Fig. 5).*

NOTE  *Some of these tests require a person at the AlphaMax location.*

Proceed as follows:

1. Connect the configuration computer to the phone line (or serial port if you are testing an AlphaMax 82S locally).
2. Double-click the AlphaMax icon on your desktop.
3. Select the proper file for the AlphaMax.
4. Click on the Connect menu at the top of the screen.
5. Click on "connect." *The modem will dial the AlphaMax. An activity window will indicate progress. After the AlphaMax answers, the screen will show all function buttons solid.*
6. Click on the "Monitor" button. *The monitor screen shows the status of the 8 alarms. Points that are not alarmed will be listed as "Clear" on a green background. Points that are alarmed will be listed as "Alarm" on a red background. Points that are in alarm and waiting for a qualification time to pass will be listed as "Qualifying" on a yellow background. The point descriptions will also be listed. See Fig. 26.*

NOTE  *If you have any problems connecting, refer to Chapter 6.*

Test Alarms

1. Activate each point at the AlphaMax. (Alarms can be simulated by placing jumpers at the appropriate pins on J1. See Chapter 2.) *As each point is activated the monitor display will show “Alarm” on red next to the point number. If an alarm qualifying period has been specified for the point, “Qualifying” will show yellow. When the qualification period has passed, “Alarm” will show on red.*




Fig. 26 - The Monitor AlphaMax Alarms window shows alarmed points in red and cleared points in green.

2. Acknowledge each alarm by clicking the Ack button beside the point. All alarms can be acknowledged by clicking the Ack All button. *When an alarmed point is acknowledged, Ack goes away and the background remains red.*
3. Restore each point to normal. *The display will show “Clear” on green next to the point number.*
4. Acknowledge each normal by clicking the Ack button next to the alarm or acknowledge all by clicking the Ack All button. *Ack goes away and “Clear” remains green.*

Test Controls



Control points will be operated in this test. If any undesirable results will occur from operating a control point, it should be disconnected from the equipment and tested with a continuity indicator.

For definitions of control terminology, see Chapter 7

1. Click on the relays tab to highlight the Control Status window of the monitor screen. *Relays that are not operated will be listed as “Released” on a green background and relays that are operated will be listed as “Active” on a red background. The relay descriptions will also be listed.*




Fig. 27 - The Monitor AlphaMax Relays window shows active points in red and released points in green.

2. Click on Relay 1 “Latch.” *The status box will show “Active” on a red background.*

3. Click on Relay 1 “Latch.” *The status box will show “Released” on a green background.*

4. Click on Relay 1 “Mom.” *The status box will briefly show “Active” on a red background. It will automatically change to “Released” on a green background when the momentary control period has passed.*

5. Repeat the above steps for Relay 2.

6. Click on the Exit Monitor button.

7. Click on the Disconnect button.

8. Close T/AlphaW.

9. Disconnect computer from phone line.

Test Pager



1. Activate one alarm point. *“Alarms” LED on the AlphaMax should blink.*

NOTE  *On ASCII devices be sure to check alarm display at the ASCII terminal, as well as at pagers, if used.*

2. Observe alarm report on pager (or ASCII terminal). (This may take several minutes depending on how busy the pager service is.)

NOTE  *Refer to Chapter 5 for pager display information.*



3. Call the AlphaMax on a tone dial phone. When the AlphaMax has answered with two beeps, enter your device number (1 - 4) and password, then press #. You should hear two more beeps. Press the alarm point number plus # to acknowledge the alarm. (Refer to Chapter 5 for further operating instructions.) *“Alarms” LED on AlphaMax should be on solid.*



Control points will be operated in the rest of this test. If any undesirable results will occur from operating a control point, it should be disconnected from the equipment and tested with a continuity indicator.

4. Press 81# to latch control point 1.

5. Confirm control point 1 operation by having someone observe the controlled equipment for the proper reaction.

6. Press 80# to release the control point.

7. Confirm control point release.

8. Hang up the phone.

9. Test additional alarm and control points as desired. Be sure to wait for each alarm to be paged before attempting to call the AlphaMax to acknowledge.

10. Test complete. Restore all alarm and control point connections to normal.

Pager Test Feature



Fig. 28 shows a Pager test window that can be accessed while your computer is connected to the AlphaMax in the Monitor function. This function allows you to verify the phone numbers used for the last page and to issue a test message.

If you click in the Test box for a user number, a status page will be issued to that pager after you disconnect from the AlphaMax.

If your pager is working correctly, you should receive a status report on your pager within a short period of time. The actual time will depend on how soon your pager service can respond.




Fig. 28 - The pager Test window allows you to issue a test message to your pager.

Chapter 5 - Operation

Once your AlphaMax is on line, use the instructions on the following pages to learn how to read reports and send commands.

Chapter 5 - Operation

- AlphaNumeric Pager - - - - - 46
- Numeric Pager - - - - - 47
- ASCII Terminal- - - - - 48
- DTMF Direct Dial In - - - - - 49
- Advanced - Monitor Mode - - - - - 50
- Advanced - LED Display Status- - - - - 51
- Advanced - ASCII Through Port Access (82S) - - - - - 52
- Advanced - Flow Chart - - - - - 53

AlphaNumeric Pager



AlphaNumeric pagers show both Change of State (COS) and Status reports. Refer to Fig. 29. The COS report uses the alarm / clear messages defined in the Pager / Advanced screen (Fig. 20). The Status report uses the alarm and clear characters defined in the same screen. The appearance of the report may vary depending on the pager and pager company, but the order in which the information is presented will remain the same.




Fig. 29 - AlphaNumeric pagers show both change of state reports and status reports.

Numeric Pager



Numeric pagers also show Change of State (COS) and Status reports. Refer to Fig. 30. The appearance of the report may vary depending on the pager and pager company, but the order in which the information is presented will remain the same.

(Note: Point '00' = Power on)




Fig. 30 - Numeric pagers show Change of State and Status reports.

ASCII Terminal

ASCII output can be used to report alarms to computers running custom monitoring, capture files and printer logging.

The alarm message format for an ASCII device is:
SITE PNT-STATUS [ALM MSG / CLR MSG] DESCRIPTION
<CR><LF><CR><LF>

Example:



FRESNO 02-0 CLEAR Freezer Door Left Open

>

>

Explanation:

Site is **FRESNO**;

Point number is **02**;

Status is **0** (0 = no alarm, 1 = alarm)

There is no alarm message (because there is no alarm)

Clear message is **CLEAR**

Description is **Freezer Door Left Open**.

This message shows that a previous report of the freezer door being left open is now canceled because the freezer door is closed.



All responses in the ASCII alarm message format are automatically made up from the information in the configuration file.

DTMF Direct Dial In

How to Call In with a Tone Dial Phone



Dial the 7 or 8 digit phone number for the AlphaMax. The AlphaMax beeps twice when a call is answered. Enter your User Number (1-4) and Password as configured under 'pagers' (pg. 26), then press "#." If the password is valid, you will hear two beeps. *Any other response means the code was invalid. Two attempts are allowed before AlphaMax hangs up. Fifteen seconds are allowed between commands.*

NOTE  ASCII terminals, like all paging devices, have a "user number."

Enter any of the commands listed in Table D. You do not have to hang up and redial to enter additional commands.

When finished, press * before hanging up phone. This will reset the AlphaMax without waiting for time-out.

Table D - Tone Dialing Operating Commands

Command	Description
1#..8#	Acknowledge Point 1..8
80#	Release Relay 1
90#	Release Relay 2
81#	Latch Relay 1 *
91#	Latch Relay 2 *
82#	Momentarily Latch Relay 1 *
92#	Momentarily Latch Relay 2 *
66#	Request status report (sent to pager after phone is hung up.)
77#	Acknowledge all COS alarms
68#	Connect ASCII through port (82S only)
69#	Connect Modem

NOTE  *"Latch" is electrical, not magnetic. Relays will release if power is lost.

How to Acknowledge Alarms

Once logged into the AlphaMax, acknowledge alarm points by pressing the respective alarm point number, followed by "#." If the entry is valid, you will hear 2 beeps. Any other response means the entry was invalid.

How to Issue Controls

To activate controls, enter the desired control command from the DTMF Dial In list (i.e., 91# latches relay 2).

Advanced - Monitor Mode

Monitor Mode allows you to view the alarm and control point status with the configuration computer.

1. Click on the Connect menu at the top of the screen. *The Connect via Modem submenu appears.*

2. Click on Connect. Click on the Monitor function button. *After a short delay for the computer to dial the AlphaMax, the screen will show all of the connect function buttons solid.*

3. Click the Monitor function button. *The Monitor screen will appear showing the status of the 8 alarm points. "Alarm" denotes a point in alarm. "Clear" is a point not alarmed.*

4. Relays (Control points) can be viewed by clicking on the Relays tab.




Fig. 31 - Monitor mode shows the status of alarm points, relays and pagers.

"Released" denotes an inactive relay. "Active" is an operated relay.

5. To acknowledge an alarm click on the Ack button next to the point. To acknowledge all alarms at once click the Ack All button. *The Ack button goes away.*

6. To operate a control point click the Relays tab and click the Latch button next to the point. *The status box shows "Active" on red.*

7. To release, click Latch. *The status box changes to "Released" on green.*

8. To operate momentarily, click the Mom button next to the point. *The status box shows "Active" on red while the relay is on. The status box changes to "Released" on green when the relay goes off.*

Advanced - LED Display Status

Indicators on the front panel give maintenance personnel quick diagnostics of the AlphaMax. Refer to Table E for an explanation of the display.

Table E - LED Display Descriptions

LED	Status	Meaning
Status (Green)	On	Power On.
	Off	No power.
	The following apply only to the AlphaMax 82S, High Speed version:	
	Flashing slow Red	NVram not verifying (needs a download)
	Flashing slow Green	NVram verified (does not need a download)
	Flashing Red / Green	Shows modem receive/transmit activity.
On-line Listed in order of precedence.	Off	Modem inactive.
	Blink - blink - off / Repeat	Off hook and dialing device.
	Slow blink (equal on - off)	Waiting to redial.
	Rapid Blink (equal on - off)	Call-in for alarm ack'ing, relay control, status reporting or download.
	The following apply only to the AlphaMax 82A	
	Solid Red	Modem on-line.
	The following apply only to the AlphaMax 82S, High Speed version:	
	Solid Green	Connected to phone line for normal alarm reporting.
	Flashing Green	Connected to phone line for ASCII reach-through port activity.
	Solid Red	Invalid or unexpected response from Modem.
	Alarms (Red) Listed in order of precedence.	Blink - Mostly Off
Blink - Mostly On		Standing alarm and COS alarm, non-qualifying.
On Solid		One or more standing alarms.
Off		No existing alarms, no new alarms.
Blink - blink - off / Repeat		Qualifying alarm (no COS or standing alarms).




Fig. 32 - LEDs indicate AlphaMax' operational status.

Advanced - ASCII Through Port Access (82S)

To activate the ASCII through port on an AlphaMax 82S, dial the AlphaMax 82S from an ASCII terminal or from a P.C. programmed to emulate an ASCII terminal. The craft port connection will be established after 20 to 30 seconds of no activity. For faster access, add 68# to the end of the dial string.

NOTE  *The squelch time of the AlphaMax 82S has an adjustable delay of 1 to 90 seconds after the dial-up craft port becomes active. See Table C in Chapter 3.*

NOTE  *See Q12 in Chapter 7 for an explanation of the phone number/dial string to use to contact the AlphaMax.*

To change to normal operation at the completion of your craft port session enter + + + at the terminal. Then type ATH to hang up. The AlphaMax will revert to normal “TRIP” alarm reporting operation.

Example: 767-1234@11# accesses the craft port 20 to 30 seconds after connection.

767-1234@11#68# accesses the craft port as soon as modem connections are completed.


To activate the TRIP protocol for normal alarm reporting when you call the AlphaMax, enter #69 at the end of the dial string.

Table F - Enter access command to cut through to ASCII access port

Command	Description
20 to 30 seconds of no activity	Access craft port.
68#	Connects for ASCII through port access.
69#	Connect for normal alarm reporting via pagers or TRIP protocol. (Reset craft port access mode.)

Advanced - Flow Chart

The following Flow Chart shows how AlphaMax processes an alarm.



Chapter 6 - Correcting a Malfunction

The following pages tell you what to do when your AlphaMax doesn't seem to work right.

Chapter 6 - Correcting a Malfunction

How to Obtain Technical Support After Hours - - - - -	56
Troubleshooting - - - - -	57

How to Obtain Technical Support After Hours

1. Call DPS at 1-800-622-3314. If our office is closed, you will hear a short message. After the message, press #.
2. Record your message, including a brief description of the problem, your name, company and phone number. Press 1 to signify the end of your message.
3. Press 2 if you want to hear your message.
4. Press 3 if you want to erase and re-record your message.
5. You may forward your message to an on-call technician by pressing 1, followed by a 1 to be contacted on the next business day or by 2 to be contacted as soon as possible.
6. Hang up the phone.

Troubleshooting

Most AlphaMax problems are related to the modem connection, especially a mismatch in the data rate (baud). Connection problems also occur if your AlphaMax is trying to call out at the same time you are trying to call in to it. This can occur if you have an alarm being reported, if it's trying to issue a periodic status report or if it is trying to report power on after a power failure. If you have reason to believe that any of these events may be occurring, you should refrain from trying to call the AlphaMax until it has had time to complete the event. If this continues to be a problem for your method of operation, some of the functions that cause these events can be turned off in the Pagers - Advanced window.

The next most common problem is an incorrectly prepared configuration file. If you have changed any of the default values (most defaults will be affected only if you use the advanced windows), you could cause improper operation. Check your selections for modem data rate and the various timing and repetition times to be sure you haven't set your AlphaMax for excessively long time periods or an extremely large number of reporting attempts.

Other problems are related to the AlphaMax constantly calling out to report an alarm without leaving sufficient time for an acknowledgment to come in. This results in a constant "bumping of heads" between the AlphaMax and you trying to call in.

If problems persist in spite of the above suggestions, follow the trouble shooting procedure in Table G.

Table G - AlphaMax Trouble Shooting Procedure

Step	Verification	Correction Procedure
1. Verify Power	Green Status LED illuminates.	<p>If AC powered: Check AC outlet with a lamp or other device. Is the AC transformer properly connected at J4? Is the AC transformer plugged into an AC wall outlet?</p> <p>IF DC Powered: Check power at J1 or at the connector block. Be sure polarity is correct.</p>

Chapter 6 - Correcting a Malfunction

Step	Verification	Correction Procedure
2. Set an alarm to cause a dial out	First the Alarms LED will blink.	If no alarm LED, check alarm point connections at J1 or at the terminal block.
	Then the Online LED blinks while dialing, then goes to solid when connection is made. A report will occur at the device that is specified for the alarm point in the configuration file.	If no Online LED, make sure phone line is connected to J5. Connect regular phone at phone jack and lift handset to listen for dial tone. Is alarm properly defined to cause a dial out? Is the alarm properly defined for the reporting device?
3. Acknowledge the alarm	From a DTMF phone: Dial the 7 or 8 digit phone number for the AlphaMax. The AlphaMax beeps twice when a call is answered, . Enter your Device Number (1-4) and Password (see Table A), then press “#.” If the password is valid, you will hear two beeps. Then press the alarm point number followed by #.	If you get a busy signal, try calling again in about 15 seconds.
	From your computer: Connect your computer with T/AlphaW running in the monitor mode and ack the point. The Alarms LED comes on solid.	If you are not able to successfully call in to the AlphaMax, the timing parameters in the configuration file may be set for too many Times to Repeat or the Time to Wait for ACK may be too short. As a result, every time you try to call in to ack the alarm , the AlphaMax is trying to call out to report it. This can also be corrected by extending the Callout Delay period in the Pagers - Advanced window. If your “pager” is an ASCII terminal, you should check the “Auto Ack ASCII Pager” box in the Pagers - Advanced window.

Step	Verification	Correction Procedure
4. Set and ack other alarms	Results as in steps 2 and 3.	<p>If a particular alarm seems to be having a problem, while others pass steps 2 and 3, there could be an error in the settings for that point.</p> <p>Be sure the primary and secondary pagers are valid, properly defined and operational.</p> <p>Check the Wait for Ack time.</p> <p>If your “pager” is an ASCII terminal, you should check the “Auto Ack ASCII Pager” box in the Pagers - Advanced window.</p>
<p>5. Operate a control point from your computer running T/AlphaW software in the monitor mode or from a DTMF phone.</p>	<p>Appropriate response from controlled equipment or continuity indication on a meter.</p> <p>You will receive a pager report that shows the control point status only if it is time for a status report to be issued.</p>	<p>If your are using a phone, be sure you are getting an answer from the AlphaMax (two beeps) and that you are using the correct command (see Table D).</p> <p>The momentary activation period may be too short (set in the Relays window).</p>

Chapter 7 - Frequently Asked Questions

*Here are the answers to questions you might want to ask us
yourself.*

Chapter 7 - Frequently Asked Questions

Q1: Does the AlphaMax measure voltages and currents?

A: The AlphaMax requires that all voltage and current sources be converted to equivalent contact closures by an external device.

Q2: How do I confirm control point operation?

A: You can either observe the equipment being controlled for evidence of the control point's affect (generator starts, door unlocks, etc.) or, if operation of the controlled equipment may cause an unwanted action, you can disconnect the controlled equipment and substitute a continuity tester at the control point connection point and observe it for a change in continuity.

Q3: What does the term "Released" mean for a control point.

A: The control relay has been returned to the non-operated or normal state. Technically speaking, it means power is not applied to the relay coil, causing the normally open contacts to be "off" and the normally-closed contacts to be "on."

Q4: What about the term "Active?"

A: The control relay is in the operated or non-normal state. Technically speaking, it means power is applied to the relay coil, causing the normally open contacts to be "on" and the normally-closed contacts to be "off." This state is the opposite of "Released."

Q5: What does "Latch" mean for a control point?

A: The control point is in the "Active" state and will remain so until a command is sent to release it. When using T/AlphaW software in the monitor mode, a release command is sent by clicking on the Latch button a second time. When using a DTMF phone a release command is sent by pressing 80# for relay 1 or 90# for relay 2.

Q6: What does te term "PABX" mean?

A: Private Automatic Branch Exchange. This is an electronic telephone switch -board, which is usually located on your premises, as opposed to being located at the telephone company's central office.

Q7: What does "TAP" mean?

A: Telelocator Alphanumeric Protocol. This is a protocol used by many pager companies.

Q8: How many phone numbers can the AlphaMax page?

A: A total of 4 phone numbers can be entered in memory. Each of the 8 alarm points can be assigned to 2 of these phone numbers. There can also be a delay before each number is paged.

Q9: When did DPS start business?

A: DPS was started in 1986 by three principles, Bob Berry, Eric Storm and Ron Stover.

Q10: What kind of training does DPS Telecom offer?

A: We have scheduled classes in Fresno. We also offer an on-site turn up assistance package that is the best way to get your system up and running quickly. General on site training is also available.

Q11: How do I configure my modem to operate with the AlphaMax?

A: T/AlphaW software will automatically configure your modem to work with the AlphaMax. If you have communication problems, it could be due to an incorrect data (baud) rate. The procedure for correcting this is found in Chapter 6.

Q12: How is the AlphaMax's phone number constructed?

A: The Phone Number is used by outside devices (T/Alpha software running on a PC, ASCII terminal or T/MonXM alarm system master) to reach the AlphaMax. The phone number consists of the 7 or 10 digit phone number, @, a Device Number, the Password for the selected Device Number, #, a comma and the desired command. The syntax is:

[Phone Number]@[Device Number][Password]#[Command]#

When calling from an ASCII terminal to access the ASCII pass through port on an AlphaMax 82S, the command is 68.

NOTE  *Any device number can be used, but the Password must be the one assigned to that Device Number.*

NOTE  *The comma before the connect modem command causes a 2 second pause for the AlphaMax to respond to the call.*

NOTE  ***IMPORTANT: The first time an AlphaMax is configured the Phone Number must contain the factory default for the Password (1). After the first download, the phone number must be changed to use the downloaded Password for the selected Device Number.***

Q13: Can I still provision my AlphaMax, version 2.2B from my T/MonXM workstation or IAM?

A: Yes, following the provisioning instructions in your T/MonXM manual. The screens shown in this manual will not be the same in T/MonXM.

Chapter 8 - Specifications

For those of you who are so inclined, here is the technical run down on the AlphaMax.

Chapter 8 - Specifications

Features	66
AlphaMax Description	67
UPS Connector Block Description	69
Technical Description	70
AlphaMax Functional Schematic	71
AlphaMax 82A Specifications	72
AlphaMax 82S Specifications	73
UPS Connector Block Specifications	74
AlphaMax Part Numbers	75
Accessory Part Numbers	76

Features

- Pages you when critical events occur
- Eight alarm inputs, two relay outputs
- Reports to Alpha and Numeric Pagers, ASCII Terminals and T/Mon Masters
- DTMF phone control
- Configuration software runs under Windows 95 or Windows 98 or Windows NT^(tm)
- Derived controls automatically operate relays
- AC or DC Powered, 3 hour safety net with UPS
- Reach through craft port to another device



Fig. 33. AlphaMax communicates with pagers, telephones or ASCII terminals.

AlphaMax Description

Dial-up Alarm System

DPS' AlphaMax 82A and 82S are compact dial-up alarm system remotes with pager access. Featuring eight alarm inputs and two control outputs, AlphaMax brings economical and simple alarm access to small locations that might otherwise remain unalarmed.

AlphaMax 82S offers remote craft port access


The AlphaMax 82S is identical to the AlphaMax 82A, except that it may be used to access an external ASCII device via an RS232 virtual channel and that it operates on -48 VDC power. It may also be configured via the RS232 port.

Alarms sent to pagers or alarm center.

Reporting Devices - Alarms can be reported to a pager that displays either an alpha or a numeric message. They can also be forwarded to a monitoring center equipped with a DPS T/MonXM alarm system or an in-house custom monitoring system. The AlphaMax can also be configured to report alarms to an ASCII terminal.

Software Configuration

Configuration - The AlphaMax is configured with T/Alpha for Windows^(tm) (T/AlphaW) software (included at no extra charge) that operates on your P.C. under Windows 95^(tm) or Windows 98^(tm) or Windows NT^(tm). The AlphaMax 82A is configured via modem only. The AlphaMax 82S may be configured via modem or locally at the RS232 port. T/AlphaW software will also monitor the alarm inputs and operate control relays.



Alarm Inputs - AlphaMax's opto isolated alarm inputs are normally in the "active state" when grounded (current flowing). Alarm points can be individually "reversed" during the configuration process to assume the Active State when ungrounded (no current flowing). Each alarm input can be configured for unipolar operation (reports going to alarm state only) or bi-polar operation (reports both going to alarm state and returning to cleared state). Each point can also have a 30 character description, a qualification time period before dialing and a backup reporting device number. A redial option causes the unit to dial a reporting device up to 15 times or until the point is acknowledged. Up to four reporting device dial-out numbers can be stored. Model 246 features "bi-polar inputs" that have both sides of the opto input brought to the connector, permitting ground activation or battery activation.

Call AlphaMax - Personnel with passwords can call into the AlphaMax from a tone dial (DTMF) phone to acknowledge alarms, operate control points or request a status report.

Chapter 8 - Specifications

Derived Controls - Control relays may be activated internally by a combination of existing alarms, based on a programmable equation (derived control). Each control point may have up to two equations defined. The control relay outputs are Form "C" (single-pole, double-throw).

Internal Modem - The AlphaMax uses an internal 300/1200 Baud "AT212" modem.

Local ACK and COS Indication - One alarm point can be wired to a local acknowledge switch and one control point can be configured to operate a local change-of-state (COS) indicator.

Visual Status Indicators - LED indicators on the front of the AlphaMax provide on-site personnel with power, modem and alarm status information.

Connectors - A telephone jack on the top of the AlphaMax case interfaces the modem. A DB 25 connector is provided on the bottom for the alarm and control points. Power connects via a 3.5mm mono plug at the top of the case or via the DB 25 connector.

Unattended Operation - Once powered, the AlphaMax runs continuously without any other operator intervention.

Options - Quick-to-install connector blocks and battery backup (UPS) options are available.

UPS Connector Block Description

UPS works only with AlphaMax 82A



The Connector block mounts on any flat surface near the AlphaMax. A 3-foot cable is included for interfacing the AlphaMax. All alarm and control points connect at the wire wrap posts or screw lug terminals on the connector, making installation quick and clean. No soldering is required.

With the UPS Battery Backup, power can be connected at a screw-on jack or at the wire wrap pins or screw lug terminals. A 250 ma fuse is provided on the block assembly.

One or two batteries are mounted underneath the block P.C. board. One battery is standard, giving up to 3 hours of backup. A two-battery option may be ordered from DPS to extend the backup period.

The UPS generates an alarm at the AlphaMax's alarm point number 2 or 8 (strap option) when the main power supply fails or the fuse blows, indicating it is now running on battery. This alarm point should be configured for reverse indication (RVS or normal = Closed) because the alarm indicates that current is no longer flowing to charge the batteries. When the alarm is reported, the AlphaMax will operate for up to 3 hours on the batteries. Operating control point relays or much dialing activity during the discharge mode will shorten this period. When power is restored the alarm clears and the unit enters the charging mode. The AlphaMax is fully operational during the charging mode.

The batteries chosen for the UPS avoid the usual memory problems associated with nicad batteries. The life-cycle time period is unaffected by the discharge rate. Your battery will always deliver the same backup time from a full charge. A complete recharge from a full drain takes approximately 16 hours. Batteries will not be damaged by polarity reversal.

A green LED on the UPS signals that AC power is on. If this LED goes off, the unit is using battery power.

Technical Description

The AlphaMax uses a central microprocessor and appropriate interface circuitry for the various input and output ports.

Power Input - The AlphaMax uses 9 Volt DC power provided by the 120 VAC power adaptor. DC power up to 27 volts from a reliable source can be connected at J1, pins 1 and 14 (note that polarity is negative ground). A “UPS” battery backup accessory is available for the AlphaMax 82A (models 245 and 246). See page 69 for additional information. The AlphaMax 82 S (model 247) operates on -48 VDC only.

“Floating Ground” provides over-current protection.

Alarm Inputs - Models 245 & 247 alarm inputs are optically isolated, ground activated. *The return pins provided are over-current protected, therefore they should be used in preference to going directly to the power ground.* Model 246 alarm inputs are optically isolated, ground or battery activated. (See Fig. 34). Maximum input voltage is 50 VDC.

Control Outputs - Form C contacts are provided, with both normally open (N.O.) and normally closed (N.C.) contacts brought out to pins on connector J1.


Line Modem - A 212-type modem is provided, operating at 300 or 1200 Baud. Levels are fixed, therefore no level setting pots are included. Model 247 is 1200 or 2400 Baud.

Jumper J2 - This jumper overrides all configuration settings for answering parameters and forces an answer on the second ring. It is to be left in the position shown in Fig. 34, unless a DPS customer support technician directs that it is to be moved.

LEDs indicate power status, line status and alarm status. Refer to Fig. 32 and Table E on page 51 for a description of LED meanings.

Craft port reach-through - The AlphaMax 82S (model 247) features an RS232 port that can be accessed via the modem to remotely connect to the craft port of a device near the AlphaMax. The port uses pins 1, 2 and 14 - 17 of the DB 25 connector (J1 - see Fig. 5 on page 11).


AlphaMax Functional Schematic



Chapter 8

Fig. 34 - All AlphaMax functions are controlled by the central microprocessor.

AlphaMax 82A Specifications



- Dimensions - 5.3" (L) x 3.1" (W) x 1.25" (D)
- Mounting - The keyhole pattern on the back of the AlphaMax allows mounting on a wall, frame or rack.
Two mounting holes vertically spaced 1.75" apart.
- Power Input - Power input is +9 to +27 VDC, 133 mA @ 9VDC (1.2 W).
Use the AC adapter provided with the AlphaMax or power by DC input.
Battery Backup available on an external "UPS" connector block.
- Heat Dissipation - 4.1 BTU, maximum
- Interfaces - 1 DB25, 1 RJ12
- Modem - 212 "AT" Type 300/1200 baud DTMF/Pulse dial internal modem with DTMF receiver.
- Protocols - T/Mon Remote Interface Protocol (TRIP)
TAP Protocol (for Alpha pagers)
ASCII
- Operating Temperature Range -
0° to +60° Celsius (32° to 140° F) for -00 option
-30° to +70° Celsius (-22° to +150° F) for -20 option
- Humidity - 0% to 95% non-condensing
- Shipping Weight - 3 lbs.
- Control Output Relay Contacts - 2 each, form C
Maximum switching voltage = 60 VDC / 120 VAC
Maximum switching current = 1 Amp, AC or DC
- Connectors - Alarms and controls connect via DB25 female connector J1*
Power connects via a 3.5 mm mono jack*
Telephone line connects via RJ-12 type modular connector.
*Optional screw lug terminals with external connector block or wire wrap terminals with panel mounted wire wrap block.
- Alarm Point Inputs -
Maximum 50 volts on inputs.
Model 245: 8 optically-isolated inputs. Connect to dry contact closure to alarm.
Model 246: 8 opto-isolated bi-polar inputs. Connect to - ground and + battery to alarm.

AlphaMax 82S Specifications



- Dimensions - 5.3" (L) x 3.1" (W) x 1.25" (D)
- Mounting - The keyhole pattern on the back of the AlphaMax allows mounting on a wall, frame or rack.
Two mounting holes vertically spaced 1.75" apart.
- Power Input - Power input is -36 to -72 VDC,
11 mA @ -48 VDC idle (0.5 W).
80 mA @ -48 VDC maximum (3.8 W)
Use the AC adapter provided with the AlphaMax or power by DC input.
- External Fuse Recommendation:
250 mA (1/4 Amp)
- Heat Dissipation -
4.1 BTU, maximum
- Interfaces - 1 DB25, 1 RJ12
- Modem - 212 "AT" Type 300/1200 baud DTMF/Pulse dial internal modem with DTMF receiver.
Optional 2400 baud modem.
- Protocols - T/Mon Remote Interface Protocol (TRIP)
TAP Protocol (for Alpha pagers)
ASCII
- Operating Temperature Range -
0° to +60° Celsius (32° to 140° F) for -00 option
-30° to +70° Celsius (-22° to +150° F) for -20 option
- Humidity - 0% to 95% non-condensing
- Shipping Weight -
3 lbs.
- Control Output Relay Contacts - 2 each, form C
Maximum switching voltage = 60 VDC / 120 VAC
Maximum switching current = 1 Amp, AC or DC
- Connectors - Alarms and controls connect via DB25 female connector J1*
Power connects via a 3.5 mm mono jack*
Telephone line connects via RJ-12 type modular connector.
*Optional screw lug terminals with external connector block.
- Alarm Point Inputs -
Maximum 50 volts on inputs.
Model 247: 8 optically-isolated inputs. Connect to dry contact closure to alarm.
- Craft Port - Uses some pins of the
DB 25 connector. RS232, 1200 Baud.

UPS Connector Block Specifications

UPS Connector Block works with all AlphaMax 82A models




- Size: 6" H X 2.75" W X 2" D
- Shipping Weight: 5 lb.
- Fuse value: 250 mA (1/4 Amp), Type GMA (5 X 20 mm)
- Connectors: DB25 for connections to AlphaMax
Screw-on jack for AC adapter power
Screw lug Terminals for alarm and control points
- Battery: GP Silvacharge 8.4 volt, 150 mA/hr,
(Included) - capacity of 2, 1 equipped
- Battery operating time: 3 hours from full charge, no relays operated
- Battery recharge time: 16 hours, from a full discharge
- Battery Life Expectancy: 500 to 1000 recharge cycles
- Mounting: Mounts on a wall, frame or rack.
Two keyhole-shaped holes spaced 1.75" apart.
(Matches AlphaMax hole pattern.)

AlphaMax Part Numbers

AlphaMax Part Number	Inputs
D-PC-245-10C-00	8 optically-isolated inputs. Connect to dry contact closure to alarm.
D-PC-246-10C-00	8 opto-isolated bi-polar inputs. Connect to - ground and + battery to alarm.

AlphaMax part numbers are as follows:

- D-PC-245-22B-00 Single-ended inputs, pager, alarm center and ASCII reporting.
- D-PC-245-22B-20 Same as D-PC-245-10C-00, with extended temperature range.
- D-PC-246-22B-00 Bi-polar inputs, pager, alarm center and ASCII reporting.
- D-PC-246-22B-20 Same as D-PC-246-10C-00, with extended temperature range.
- D-PC-247-22B-00 AlphaMax 82S. Single-ended inputs, pager, alarm center and ASCII reporting, serial port “reach-through,” -48 VDC, 1200 Baud modem.
- D-PC-247-22B-02 As above, with 2400 Baud modem.




Accessory Part Numbers

AlphaMax accessories are as follows:

- D-RK-140-10A-00 19" Rack Mount Panel. Mounts 2 AlphaMaxes and Wire Wrap Block
- D-RK-150-10A-00 23" Rack Mount Panel. Mounts 2 AlphaMaxes and Wire Wrap Block



- D-PC-254-10A-10 AlphaMax Single Connector Block, Screw Lug terminals
- D-PC-254-10A-11 "UPS" Single Connector Block, Screw Lug terminals, e/w 1 Battery
- D-PC-254-10A-12 "UPS" Single Connector Block, Screw Lug terminals, e/w 2 Batteries



- D-PC-260-10A-00 Wire Wrap Block, fuses and DB25 connectors to support 2 AlphaMaxes

Index

A

AC Power	6, 8, 10, 12, 15, 17
Ack	41
Ack All	41
Acknowledge	41
activate control	49
Active	37, 42, 50, 62
Advanced	29
Site Definition	29
Pagers	30
Alarms	31
Relay 1	32
Relay 2	32
Alarm and Clear Characters	30
Alarm and Clear Messages	30
alarm points	6
alarm reporting messages	30
Alarms	21, 27, 40, 66
Alarms Definition	27
Alarms not reporting	57
Alpha Pager PIN	21
Alpha pagers	30
AlphaMax	26
AlphaMax 82A	2
AlphaMax 82S	2
AlphaNumeric Pager	46
answering machine bypass	36
ASCII terminal	43
ASCII Terminal	48

B

background	40
batteries	69
battery	69
Battery Backup	2
Baud	35
bipolar inputs	8
bi-polar inputs	67
Break	37

C

call when clear	31
Cancel	35
Change of State	46
Checklist	57
Checkout	39-44
Clear	40
Clear Characters	30
Clear Messages	30
configuration	21, 63
configuration computer	50
configuration file	34
Connect	10, 34, 40
Connect Options	35
Connect via Modem	50
contact closure	62
context-sensitive help	24
control points	7, 62
control relays	20
Control Status	42
controls	6
Controls not operating	57
COS	46
craft port	67
currents	62

D

DB 25	68
DC Power	6, 8, 10, 12, 15, 17
default	34
derived controls	28, 34
Derived controls	66
Description	67
device number	49
Device Number	49
Device Type	21
dial modem	34
Dial String	21

Index

disconnect	35	LED Display	51
Disconnect	42	LEDs not coming on	55
DOS	23	Line Name	34
download	25	Line Properties	35
DPS tech support	35		
DTMF	49	M	
DTMF Direct Dial In	49	model	
		245	5
E		246	5
Edit	20	247	5
Exit	20	model	5
Exit Monitor	42	modem	24, 63
Extended Warranty	ii	Mom	42
		momentary control period	42
F		monitor	40
FAX	36	Monitor	40, 50
Features	66	Monitor Mode	50
File	34		
Fixing It	55-60	N	
Flow Chart	52	New Device	23-24
Frequently Asked Questions	61-64	No ASCII reach through	57
Front panel	51	Not dialing out	57
Fuse	69	Number of Rings	37
		Number of times to report	21
G		Numeric Pager	47
green background	40		
		O	
H		Open Device	25
Hardware Setup	5-18	Operation	45-54
		Overview	1-4
I			
Installshield	22	P	
Issue Controls	49	PABX	63
		Pager	26
J		Pager Definition	26
Jumper (AlphaMax)	71	Pager Test	44
Jumper (UPS).	15	Pagers	21
		paging parameters	30
L		panel mounted wire wrap block	5
Latch	44, 62	Part Numbers	75
LED	44	password	34

Password	49	status report	44
periodic status reporting	30	T	
Phone Number	21, 62	T/AlphaW	20
PIN	26	T/Mon	66
point description	40	TAP	26
polarity	31	Tconfig	20
power adapter	6	tech support	35
Primary Pager User Number	21	Technical Support	56
Q		Test Alarm	41
qualification time	40	Test Controls	42
Qualifying	40	Test Pager	43
R		Time to wait to Acknowledge	21
red	40	timing	31
red background	40	tone dial	43
redial	67	training.	63
relay	20, 66	U	
Relay Definition	28	UPS	2
Relay Number	21	UPS connector block	5
Relays	21	User ID	34
Released	42, 50, 62	User Number	21
repetition parameters	31	V	
Ring Bypass	36	virtual channel	67
Rings	37	voltages	62
RS232	67	W	
S		Warranty	ii
save	25	wire wrap block	4, 5, 17, 76
Save As	33	write	34
Secondary Pager User Number	21	Y	
serial port	40	yello	
single connector block	5	w background	40
single-ended inputs	10		
Site Definition	21		
Site Name	21		
Site Number	21		
Software Menu	38		
Software Setup	19-38		
Specifications	65-76		
Squelch Time	37		

DTMF Quick Reference
(from page 49)

Command	Description
1#..8#	Acknowledge Point 1..8
80#	Release Relay 1
90#	Release Relay 2
81#	Latch Relay 1
91#	Latch Relay 2
82#	Momentarily Latch Relay 1
92#	Momentarily Latch Relay 2
66#	Request status report (sent to pager after phone is hung up.)
77#	Acknowledge all COS alarms
68#	Connect ASCII through port (82S only)
69#	Connect Modem



4955 E. Yale - Fresno, CA 93727 - Phone: (559) 454-1600 / (800) 622-3314 - FAX: (559) 454-1688

e-mail: sales@dpstele.com

Visit our Web site at <http://www.dpstele.com>