## Web Designer for Modicon M340, Premium and Quantum <sup>User Manual</sup>

02/2010



This document provided by Barr-Thorp Electric Co., Inc. 800-473-9123 www.barr-thorp.com



The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2010 Schneider Electric. All rights reserved.

### **Table of Contents**



	Safety Information	7
<b>.</b>		9
Chapter 1	Introduction 1	1
	Presentation	12
	Preparing for Web Designer installation	14
	Interface Presentation	15
Chapter 2	Getting Started 1	9
	Presentation	20
	Creating a New Project	21
		23
		25
	Variable Selection	-0 07
		21 20
		ະອ ວວ
		22 21
	Accessing the Website	24 26
Chanter 2	Accessing the website	20
Chapter 3		19
	Adding/Removing Targets	40
	Adding/Removing a Device	42
	Adding/Removing Items	44
	Opening/Closing a Project.	46
	Import	47
Chapter 4	Transfer	19
-	Transfer	50
	Project Validation	55
	Connecting/Disconnecting to/from the Module	58
Chapter 5	Simulation Mode	51
	Connecting/Disconnecting to/from the Simulator	62
		62
		55

Chapter 6	Managing Variables	67
	Namespace	68
	Importing from a Programmable PLC	69
		73
	Author Rights in Namespace	74
Chapter 7	Monitoring	77
7.1		78
	Data Editor.	79
	Creating a Data Template	80
		81
	Inserting a Symbol (Variable) in a Data Template	84
	Inserting a Direct Address in a Data Template	86
7.0		87
7.2	Graphic Editor	88
	Overview of the Graphic Editor	89
	Ligar Eurotions in the Diaplay Window	91
	Display window	90
	Socurity	101
	Granhic Editor Applet Parameters	102
	Granhic Objects	102
	Extended Granhic Objects	124
7.3	Creating Custom Web Pages	135
7.0	Installing FactoryCast Extension for Microsoft FrontPage	136
	Installing FactoryCast Extension for Microsoft Expression Web	141
	Inserting a LiveBeanApplet with FrontPage or Expression Web	143
	Inserting a LiveLabelApplet with FrontPage or Expression Web	151
	Internet Explorer 7 compatibility.	157
7.4	PLC Program Viewer	158
	PLC Program Viewer	158
Chapter 8	Setting Up an External Tool	165
•	Setting Up an External Tool	165
Chapter 9	Changing the Workspace Directory	169
	Changing the workspace directory.	169
Chapter 10	Formatting and Re-Starting a Module	171
enapter re	Be-start/Format a Module	171
Chanter 11	Security	173
Onapier 11	Internal Socurity	174
	External Security	174
	Variable Access Security Symbol Direct Address	173
	Changing Passwords	178
Annondicos		181
Abhemmices		101

Appendix A	Menu	183
	Menu	184
	Contextual Menu	186
Glossary		191
Index		199

## **Safety Information**



#### **Important Information**

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

## A DANGER

**DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

## **WARNING**

**WARNING** indicates a potentially hazardous situation which, if not avoided, **can** result in death or serious injury.

## **A** CAUTION

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

## CAUTION

**CAUTION**, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result in** equipment damage.

#### PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved.

## About the Book



#### At a Glance

#### **Document Scope**

This manual presents the Web Designer for Modicon M340, Premium and Quantum software and describes the installation and operation.

**NOTE:** In this manual, the term "Web Designer" will be used for "Web Designer for Modicon M340, Premium or Quantum".

#### Validity Note

This documentation is valid for Web Designer software.

#### **Related Documents**

Title of Documentation	Reference Number
FactoryCast for Modicon M340 User Manual	35015192
FactoryCast for Premium and Quantum User Manual	31001229
Communications Setup Manual	TLX DS COMPL7 V4
Ethernet Network - Reference Manual	TSX DR ETH
Modbus - User Guide	TSX DG MDB

You can download these technical publications and other technical information from our website at www.schneider-electric.com.

#### **Product Related Information**

All pertinent state, regional, and local regulations must be observed when installing and using this product. Only the manufacturer should perform repairs to this product to maintain system data.

When controllers are used for applications with technical requirements, please follow the relevant instructions.

## **WARNING**

#### UNINTENDED EQUIPMENT OPERATION

Use only Schneider Electric software or approved software with our hardware products.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Anyone who has access to a configuration tool and to your embedded server can override your security settings and download new settings to the server.

Unauthorized or incorrect changes to data may change the behavior of your application in ways that may be undesirable or even hazardous.

## 

#### UNINTENDED EQUIPMENT OPERATION

- Keep strict access to the embedded server by configuring passwords.
- Carefully select the symbols and direct addresses you authorize to be modified online.
- Do not authorize online modifications of critical process variables.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

#### **User Comments**

We welcome your comments about this document. You can reach us by e-mail at techcomm@schneider-electric.com.

## Introduction

# 1

#### Scope of this Chapter

This chapter introduces Web Designer. It shows you how to install it. It also provides you a description of the graphical interface.

#### What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Presentation	12
Preparing for Web Designer installation	
Interface Presentation	

#### Presentation

#### Introduction

Web Designer is a state-of-the-art software application with which you can create Web based operator panels and configure operating parameters for Web human machine interface (Web HMI) devices. It provides all the tools needed to design an HMI project, from the data acquisition to the creation and display of animated Web drawings.

Web Designer handles the following for the device website:

- editing,
- configuration,
- modification.

Web Designer offers two levels of personalization:

- the creation of a variable base of devices that can be viewed and modified in Web pages,
- the addition of your own Web pages on the device site.

#### Devices

In the Schneider product range, Web Designer unites website configuration with services carried out in the coupling unit or device. A project can simultaneously manage several devices.

Web Designer manages the following devices:

PLC Range	Device	
Modicon M340	BMX NOE 0110	
Premium	TSX ETY 5103	
Quantum	140 NOE 771 11	

#### Simulation

Web Designer enables you to simulate devices in order to debug the application. This means you can verify the behavior of Web pages and services without being physically connected to the device or to the module.

#### **Required configuration**

To use this software at an optimal level, we recommend that your PC has the following configuration:

- CPU 1GHz,
- 512 Mb RAM,
- 80 Mb Hard disk,
- 800x600 screen,
- Windows 2000 SP2, Windows XP Professional or Windows Vista Business 32bit,
- Java Virtual Machine 1.4.2 minimum.

**NOTE:** For Windows XP or Windows Vista, you need administration privileges to install the Web Designer Software. You also need administration privileges to run the software under Windows Vista.

#### Preparing for Web Designer installation

#### Foreword

If a previous version of Web Designer is already installed, it must be uninstalled first (Web Designer offers to perform the uninstall for you if this is the case).

**NOTE:** Once installed, you can access Web Designer by clicking Start  $\rightarrow$  All programs  $\rightarrow$  Schneider Electric  $\rightarrow$  Vijeo Designer Suite  $\rightarrow$  Web Designer.

#### Installation

The installation procedure is as follows: insert the CD-ROM into the CD drive. The CD is Auto-run, therefore if your PC is set up for this feature you should see the Web Designer main window. If Auto-run is disabled or does not work:

Step	Action
1	Click Start $\rightarrow$ Settings $\rightarrow$ Control panel.
2	Click Add/Remove Programs in the Control Panel.
3	Click <b>Add New Programs</b> in the menu on the left, then <b>CD-ROM</b> and follow the instructions.
4	The Install Tool will automatically find the WebDesigner.exe program on the CD and will also display the path and file name then prompt you to perform the installation.

#### **Importing Previous Projects**

Previous projects are visible in the navigator once Web Designer is reinstalled.

#### **Interface Presentation**

#### **Main Window Contents**

The following illustration describes the elements of the Web Designer main window:



6 main zones compose this screen which are:

Zone	Description
1	Menu (see page 184): list of options available.
2	Toolbar: shortcuts to frequently used functions.
3	Navigator (see page 16): display all the files related to the projects.
4	Editing zone: Web Designer uses this zone to edit, create or configure services associated with the project.
5	Console zone: list of the last detected errors.
6	Information zone: it displays the connection status and the available memory of the selected module.
7	Site Explorer View: it displays all the target files.

#### Navigator

This zone displays all the files and folders associated with existing projects. It provides an overall view of the application displayed as a file tree.

The following figure describes the navigator:



Zone	Description
1	This zone displays the name of the project as root directory. By clicking +, all the targets associated with the project appear.
2	This folder displays the name of the target associated with the project and its IP address. By clicking +, all the folders and files associated with the target appear.
3	<ul> <li>5 main directories are visible for each target associated with the project:</li> <li>Device: it displays the devices (CPUs connected to the module) associated with the target.</li> <li>GraphicScreens: it contains pages created using the Graphic editor (see page 89).</li> <li>DataTables: it contains tables created using the Data editor (see page 78).</li> <li>Service: it displays the services created by the user (availability depending on the target).</li> <li>Website: it contains all the website files for the project. You can therefore customize the website (see page 135) by changing these files or by adding your own pages.</li> </ul>

3 main zones compose the navigator which are:

#### Toolbar

The toolbar enables you to access the main functions of the program directly by clicking its icons.

The figure below shows you the toolbar:

📬 🔹   🚔 📄 🔞	🔏 🗈 📇	🤊 🏦 📄 🗍	육 월 월	] 🔒 🛔 💥 ] 🔟 🔳 🕨
-------------	-------	---------	-------	-----------------

The following table describes the elements of the toolbar:

lcon	Function	
<b>F</b> •	<ul> <li>New: by clicking the down arrow, you can:</li> <li>create a new project,</li> <li>add a target to the project,</li> <li>add a device to the target,</li> <li>create a new service,</li> <li>create a folder,</li> <li>create a file.</li> </ul>	
ĭ <b>≧</b>	Open an existing project.	
	Save: save the currently edited window.	
1 C	Save All: save all items modified in the project.	

lcon	Function
3k	Cut: destruction of the selected object and putting it on the clipboard.
à	Copy: copy the object to the clipboard.
1	Paste: paste the clipboard.
5	Undo: cancel last action.
孡	Find: open the <b>Search</b> window in which you can search for a text located in a file of the project.
	Lookup: open the <b>Lookup</b> window in which you can search a variable.
詽	Global Transfer: download all the project's modules (and all the files).
	Target -> PC: transfer a project from the target to the PC.
	PC -> Target: transfer a project from the PC to the target.
먣	Connection to the module: connect Web Designer to the target.
-	Connection to the local simulator: connect Web Designer to the simulator.
*	Disconnect: disconnect from the target or the simulator.
	Statistics: view statistics for the selected service (incoming messages, outgoing messages, etc.).
• o	Stop: shut down current service.
	Run: start current service.

## **Getting Started**

#### Scope of this Chapter

The purpose of this document is to show you the procedure for creating a Web Designer for Modicon M340 application.

#### What's in this Chapter?

This chapter contains the following topics:

Торіс	
Presentation	20
Creating a New Project	21
Device Selection	23
Target Properties	25
Variable Selection	
Data Editor	29
Graphic Editor	32
Transfer	34
Accessing the Website	36

#### Presentation

#### Introduction

This getting started covers from project creation to visualizing it on a PC with a browser. The project is made with a BMX NOE 0110 module and a Modicon M340 PLC connected on the same rack. The Web server will be hosted by the BMX NOE 0110 module, which will periodically scan the values of variables located in the PLC. The IP address for the module will be a.b.c.d.

#### Architecture

The following diagram shows the architecture of the getting started example:



The following table describes the elements of the example:

Reference	Туре	Description
BMX NOE 0110	Target	Ethernet module
Modicon M340	Device	PLC

#### **Creating a New Project**

#### Introduction

This section provides an example showing how to create a new project using a BMX NOE 0110 module.

#### **Creating a New Project**

Step	Action
1	Click $Project \rightarrow New \rightarrow Project$ <b>Result</b> : the Web Designer Project Creation Wizard window appears.
	💽 Web Designer Project Creation Wizard
	Web Designer Project Wizard Creation of a new Web Designer project
	Project [Modicon_M340_example Step 1: Add the target. Select the target and press the > button. Remove target. Select the target and press the < button.
	Edit Target detail. Click on the Name/Adress column to edit.
	Target List     Selected Target(s)       Image: Selected Target (s)     Image: Selected Target(s)       Image: Selected Target(s)     Image: Selected Target(s)
2	Enter the project name (Modicon_M340_example) in the Project field.
3	In the target box, scroll over the drop down menu of the FactoryCast and select the module you require (for example, BMX NOE 0110 v1.0) and click the > button. <b>Result</b> : the chosen module appears in the Selected Target(s) box on the right.
4	Enter the Name of the target (NOE) in the Selected Target(s) box.

Step	Action
5	Enter the IP Address (a.b.c.d) in the Selected Target(s) box. For more information about IP addressing, refer to the <i>Modicon M340 for Ethernet Communications Modules and Processors User Manual</i> .
6	Repeat steps 3 to 5 if you want to select more than one target.
7	Click <b>Next</b> . <b>Result</b> : The second window of the Web Designer Project Creation Wizard appears.

#### **Device Selection**

#### Introduction

For each target you can configure the devices that are connected to it.

#### **Device creation**

The following table shows how to attach devices to a target:

Step	Action
1	Select a device in the Device List box and click the > button. <b>Result</b> : The device appears in Selected Target(s) Device(s).
	💽 Web Designer Project Creation Wizard
	Web Designer Project Wizard Creation of a new Web Designer Project
	Project Modicon_M340_example Step 2 Add Device: Select the Target from the Target List, select the Device from the Device List and press the '>' button. Remove Device: Select the Device and press the '<' button. Edit Device Details : Click on the Name/Adress column to edit.
	Target List     Device List     Selected Target(s)/Device(s)       Image: Device List     Target/Device (s)       Image: Device List     Target/Device (s)<
	<back next=""> Finish Cancel</back>
2	In the selected Target(s)/Device(s) zone, enter the device name in the Name column and its address in the Address column. For more information about addressing refer to the <i>Modicon M340 for Ethernet Communications Modules and Processors User Manual.</i>
3	If the device supports several protocols, enter the desired protocol in the Protocol column.

Step	Action
4	If you want to attach more than one target, repeat steps 1 to 4 until you have selected all devices required.
5	Click End. Result: the project example appears in the browser.
6	Save your project by clicking:

#### **Target Properties**

#### Introduction

Target properties allow you to change the name of the target and its address.

This example shows you how to manually configure the IP parameters for a BMX NOE 0110.

#### Accessing the Target Properties Page

You can access the Target Properties page in one of the following ways:

- On the Web Designer browser, right-click the device name and click **Properties**.
- On the Target menu, click Properties.

**Result:** the Target Properties window appears.

🔮 Properties for BMX	NOE 0110-NOE					×
General Security	Target type : BM)	X NOE 0110				
	Name	NOE				
	Address	a.b.c.d				
	Symbol Access L	evel				
	Strict	c	Symbol	C Debug		
				ОКС	ancel	

#### Setting Up the IP Parameters

Use the IP parameters area to define the IP configuration of the module.

Having two devices with the same IP address can cause unpredictable operation of your network.

## **WARNING**

#### UNINTENDED OPERATION — DUPLICATE IP ADDRESS

- Make sure that this device will receive a unique IP address.
- Always obtain your IP address from your system administrator to avoid the possibility of duplicate addresses.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

**NOTE:** In this example, we manually assign the a.b.c.d address to the module. For details about managing IP address, refer to the *Modicon M340 for Ethernet Communications Modules and Processors User Manual.* 

The following table shows how to manually configure the BMX NOE 0110 module:

Step	Action
1	Access the Target Properties page.
2	Enter the IP address for the BMX NOE 0110 in the IP Address field.
3	Click <b>OK</b> to validate.
4	Save the new configuration by clicking:

#### **Variable Selection**

#### Introduction

The Select Symbol window lets you configure the variables for various devices that can be used in website pages.

All device variables used in a project are grouped in a file called **Namespace**. The Data Editors and Graphic Editors in a project use variables in this **Namespace**.

#### **Types of Symbols**

For Modicon M340, Premium and Quantum PLCs, symbols that can be used come from the PLC application (*.stu*, *.xvm*, *.prj* or *.fef* file type).

#### Selecting PLC Symbols

The following table shows how to select PLC symbols:

Step	Action	
1	In the browser, extend the menu tree in the exam	nple.
2	In the <i>Devices</i> directory, double-click a PLC type example). Result:	device (Modicon M340 in our
	😼 device1 : Mo *	8
	No. Topic Variable Type Access Persistent Rate	Delete
		Duplicate
		Import PLC Symbols
		Subscribe Variables
		Import from CSV
	<u> </u>	Export to CSV
3	Click Import PLC symbols. Result: the Open window appears.	
4	Select the (.stu or .xvm) file in which the application	ion symbols are.

Step	Action
5	Click <b>Open</b> . <b>Result</b> : the Select Variables to Import window appears.
	Selection of the variables to import     Select the variables to import in the service using double-click
	Address Comment  Address Comment  Address Comment  Address Comment  ReadOnly
	Import selected variables Cancel
6	Select the required symbols by double cliking the 1st column.
7	Click Import selected variables.
8	Save the project by using the menu $Project \rightarrow Save all$ .

#### Namespace

By clicking the Namespace file of the project in the browser, a table that groups all symbols previously selected for targets or devices appears.

#### **Data Editor**

#### Introduction

The Data Editor enables you to create Web pages in which the values of variables are displayed in table format. In certain cases these values can be modified by the user.

Allowing write access can change system behavior.

## **WARNING**

#### UNINTENDED OPERATION

- Make sure variables that can be written are accessible by trained personnel only (password protect).
- Do not give write access to critical control variables.

## Failure to follow these instructions can result in death, serious injury, or equipment damage.

#### **Selecting Editor Symbols**

Step	Action
1	In the browser, extend the menu tree in the example.
2	Right-click the <i>DataTables</i> directory to open the contextual menu and choose <b>New Table</b> .
3	In the Table Name field, enter a name for the data table.
4	Click <b>OK</b> . <b>Result</b> : An empty data table appears.

Step	Action
5	<ul> <li>To access the configuration zone:</li> <li>Double-click a line of the Table window,</li> <li>Or right-click the Table window to open the contextual menu and choose New.</li> </ul>
	Result: The configuration zone appears.
	H∎*TSX ETG 3000   ■ Namespace - Table ×
	Name     Image: Unit Id     1     Image: Unit Id     Image:
	Hesuit: The search panel for symbols appears.         Image: Cookup         Filter         Image: Cookup
	Apply OK Cancel
	<b>Note</b> : The list corresponds to the variables coming from the devices connected to the target.

Step	Action
7	Select the symbols that you wish to monitor.
8	Click OK.
9	Save your table by clicking:

#### **Graphic Editor**

#### Introduction

The Graphic Editor enables you to create Web pages in which the values of variables are displayed as graphic objects, such as VU meters, indicators, etc.

Some graphic objects allow values to be entered. In this case, the variable must be write authorized and, in order to be able to use it, the user must have entered the write authorization password.

In the configuration phase, the Graphic Editor allows you to edit and view screens at the same time. In the operation phase, you can only visualize one screen at a time in order to optimize memory resources.

#### **Selecting Graphic Objects**

The following table shows how to open the Graphic Editor:

Step	Action					
1	In the menu tree, select the target.					
2	Right-click the <i>GraphicScreens</i> directory to open the contextual menu and choose <b>New Graphic Page</b> . <b>Result</b> : the Graphic Editor panel appears.					
	Browser BMX NOE 0110 BMX NOE 0110 Crew> Save Delete Edt GraphoScens DataTables Web site Namespace					
3	Click Edit.					
4	Select graphic objects from the band on top of the screen.					
5	Click the sub-window under the main window to place them.					
6	Open the Properties window by double-clicking on the graphic object.					
7	You can specify a name, a label, the data type and many other parameters. Click on the right of the Address field to associate a variable with the object. <b>Result</b> : the Lookup Variables window appears.					
8	Select the variable that you want to associate with the object.					

Step	Action
9	Repeat steps 4 to 8 to add other objects.
10	Once you have finished, click <b>Done</b> .
11	Click Save and enter a name for the graphic (graph).

#### Transfer

#### Introduction

Once you have completed the site construction on the configuration PC, you should transfer it to a target.

#### Transfer the Website to a Target

эp	Actio	n				
1	Select	Select BMX NOE 0110 in the menu tree.				
2	Click T Resul	Target → Tra It: The Target	$nsfer \rightarrow PC$ Validation v	<b>; -&gt;Target</b> . vindow app	ears.	
	🔍 Va	lidation of the ta	rget BMX NO	E 0110- NOE	E	
		Validation of serv	ices in target. E	)ouble-click the s	ervice	
	0	L Target / i BMX NOE 0110	File	Validity OK	0	
	<u> </u>				ок	
					UK	

Step	Action
3	Click <b>OK</b> . <b>Result</b> : the Transfer Status window appears.
	● Transfer status
	i Status
	Direction Target name IP Address
	Target Type BMX NOE 0110 $\rightarrow$ BMX NOE 0110 Target Type BMX NOE 0110 $\rightarrow$ BMX NOE 0110 THTML version 1.4 $\rightarrow$ 1.4 Segment version 2.0 $\rightarrow$ 2.0
	Web Designer relision 2.0 2.0
	Select
	Transfer Destination     Transfer Only Modified Files.     Transfer rdt and gdt Files.
	Transfer Configuration Files.
	Transfer Cancel
	<b>Note</b> : if there are differences between the firmware version of the protocol the target, the transfer cannot be performed.
4	Click <b>Transfer</b> . <b>Result</b> : the Configuration Password window appears if a configuration password has already been set. Otherwise the project is transferred.
	🔮 Configuration Password 🗙
	Enter the configuration password for BMX NOE 0110-NOE
	Enter password here
	OK Cancel
5	Enter the configuration password and click <b>OK</b> . <b>Result</b> : the Progress Information window appears. The files are displated at a time in the Status Bar

#### Accessing the Website

#### Introduction

At this time, you have:

- created a project,
- selected the devices and the variables of your choice,
- created data and graphic table to monitor the installation,
- transferred your application from the PC to the target.

The last step consists of connecting to the website. The Data Editor and the Graphic Viewer are used to view graphic animation pages related to the device variables or internal module variables.

#### Accessing the Website

Step	Action						
1	Open a Web browser.						
2	Type the IP address of the module in the address bar. In this example, we set the IP address of the module to a.b.c.d <i>(see page 50)</i> . Therefore type a.b.c.d in the address bar.						
3	Click <b>Go</b> . <b>Result</b> : The module website appears.						
4	Click Monitoring on the horizontal menu bar of the website. Result: The monitoring home page appears. Scheele ctric BMX NOE 0110 Home Documentation Monitoring Data Editor Data Editor Data Editor Graphic Editor Graphic Viewer Custom Pages With password Without password Without password Copyright © 1998-2007, Schneider Automation SAS All Rights reserved.						
Step	Action						
------	---						
5	Click <b>Data Editor</b> on the vertical menu bar of the website to see the animation tables created with the Data Editor. Select the table created previously on the left side of the Data Editor applet and						
	click Click to launch the animation. The following figure shows the Data Table:						
	Schericier       BMX NOE 0110         Home       Documentation         Monitoring       Control       Diagnostics   Maintenanc  Setup         Data Editor       Image: Setup in the setup in						
	Click Graphic Viewer on the vertical menu bar of the website to see the						
	animation pages created with the Graphic Editor. The following figure shows the graphics page: Scheelectric BMX NOE 0110 Home Documentation Monitoring Data Editor Data Editor Graphic Editor Graphic Editor Graphic Viewer Custom Pages With password Without password						
	© 2000-2007 Schneider Electric. All Rights						

# **Project Management**

# 3

## Scope of this Chapter

This chapter explains how to manage a project. It concerns:

- Modifying a project,
- Opening and closing a project,
- Importing a project from a file.

## What's in this Chapter?

This chapter contains the following topics:

Торіс	
Adding/Removing Targets	
Adding/Removing a Device	
Adding/Removing Items	
Opening/Closing a Project	
Import	

## Adding/Removing Targets

## Adding a New Target

The following table shows how to add a target:

Step	Action
1	Select a project.
2	Click <b>Project</b> → <b>New</b> → <b>Target</b> . <b>Result</b> : The Web Designer Project Creation Wizard opens, initialized with targets that already exist in the project. <b>Web Designer Project Creation Wizard</b>
	Web Designer Project Wizard Creation of a new Web Designer project
	Project       Project_example         Step 1:
	Target List Selected Target(s)
	Image:
	<back next=""> Finish Cancel</back>
3	In the Target List, select the targets to add.
4	Click [>]. Result: The new target appears in the Selected Target(s) list.
5	Type a name and an address for that target.
6	Click Next. Result: The device selection wizard appears.

## Window Fields

The following table gives a description of the elements of the Web Designer Project Creation Wizard window:

Field	Function
Project	Project name.
Target List	List of available targets.
Target	Target types selected in the Module List.
Name	Target Name, to distinguish targets of the same type.
Address	IP address of the target.

The button > enables you to add one of the targets in the list. The button < enables you to remove a target in the list.

## **Removing a Target**

To remove a target from the project, right-click the target in the navigator to open the contextual menu and select **Delete**.

**NOTE:** If you delete a target of the project, all the files associated with that target (including devices) are also deleted.

### Number of Targets

A project can contain up to 16 targets. It's possible to select the same type of target several times, on condition that you attribute a different name and IP Address for each target.

## Adding/Removing a Device

## Adding a Device

The following table shows how to add a device:

Step	Action
1	select the Devices directory of your project.
2	Click <b>Project</b> $\rightarrow$ <b>New</b> $\rightarrow$ <b>Device</b> , or Right-click the <i>Devices</i> directory and then click <b>New Device</b> . <b>Result</b> : Web Designer Project Creation Wizard window appears, initialized with devices that already exist in the project.
	Web Designer Project Wizard Web Designer Project Wizard Creation of a new Web Designer Project
	Project New project Step 2 Add Device: Select the Target from the Target List, select the Device from the Device List and press the '>' button. Remove Device: Select the Device and press the '<' button. Edit Device Details: Click on the Name/Address column to edit.
	Target List       Device List       Selected Target(s)/Device(s)         BMXNOE0110       Modicon M340       I Target/Device. Name I Address I Protocol         BMXNOE0110       Modicon M340       I Modicon M340         >       I Modicon M340       PLC         I Modicon M340       I Modicon M340       I Modicon M340
	<back next=""> Finish Cancel</back>
3	Select the devices to add in the Device List field and validate with the button >.
4	Type a name and an address for that device.
5	Click End to validate the project targets and devices.

**NOTE:** If you have more than one target in your project, select the target in the Target List to which you want to attach the device before achieving step 3.

## Window Fields

The following table shows the fields in the Web Designer Project Creation Wizard for the Device window.

Field	Function
Target List	List of targets created in the previous panel.
Device List	List of available devices.
Selected Target(s)/Device(s)	Device selected (from the Device List).
Name	Name given to the device to distinguish it from other devices of the same type.
Address	Address of the target.
Protocol	Protocol supported by the device (the Protocol List is determined by the type of device).

## Removing a Device

To remove a device from the project, right-click the device in the navigator to open the contextual menu and select **Delete**.

**NOTE:** When you delete a device, all variables relating to the Namespace of the device are also deleted.

#### **Device Selection**

You can only select 1 device.

## Module Device

For a target in a rack, the default address is **localhost**.

#### Protocol

You can associate one or several protocols with each device. When a device supports several protocols, the protocol column is active and the user can choose one from the list. The address in the previous column depends on the protocol selected.

## Adding/Removing Items

## Presentation

The following pages show how to add elements of the following type to the project:

- Data Tables,
- Graphic Pages,
- Services,
- Folders,
- Files.

## Adding a Graphics Page

The following table shows how to add a graphics page:

Step	Action
1	Select the project.
2	Select the sub-directory GraphicScreens in the target directory.
3	Click <b>Project</b> $\rightarrow$ <b>New</b> $\rightarrow$ <b>Graphic</b> , or Right-click the <i>GraphicScreens</i> directory and click <b>New Graphic Page</b> . <b>Result</b> : The Graphic Editor opens with a blank page to edit.

## Adding a Data Table

The following table shows how to add a Data table:

Step	Action
1	Select the project.
2	Select the sub-directory DataTables in the target directory.
3	Click <b>Project</b> $\rightarrow$ <b>New</b> $\rightarrow$ <b>Data</b> , or Right-click the <i>DataTables</i> directory and click <b>New Table</b> . <b>Result</b> : The Data Editor opens with a blank table.

## Adding a Service

The following table shows how to add a service:

Step	
1	Select the target.
2	Click <b>Project</b> $\rightarrow$ <b>New</b> $\rightarrow$ <b>Service</b> , or Right-click the <i>Service</i> directory and click <b>New Service</b> . <b>Result</b> : A window opens with a list of services that can be created.
3	Select the desired service from the list.
4	Click <b>OK</b> . <b>Result</b> : The Service window opens.

#### Adding a Folder

The following table shows how to add a folder:

Step	Action
1	Select one of the Website folders or Website itself.
2	Click <b>Project</b> $\rightarrow$ <b>New</b> $\rightarrow$ <b>Folder</b> , or Right-click the <i>Website</i> directory and click <b>New</b> $\rightarrow$ <b>Folder</b> . <b>Result</b> : The Create a Folder window opens.

NOTE: you cannot create new folders outside of the Website menu tree.

## Adding a File

The following table shows how to add a file:

Step	Action
1	Select one of the Website folders or Website itself.
2	Click <b>Project</b> $\rightarrow$ <b>New</b> $\rightarrow$ <b>File</b> , or Right-click the <i>Website</i> directory and click <b>New</b> $\rightarrow$ <b>File</b> . <b>Result</b> : The Create a File window opens.

**NOTE:** You cannot create new files outside the *Website* menu tree.

#### **Removing Items**

To remove an item from the project, right-click the item in the navigator to open the contextual menu and select **Delete**.

## **Opening/Closing a Project**

## Presentation

This section shows how to:

- open/close a project,
- save a project,
- close Web Designer.

## **Opening an Existing Project**

The following table shows how to open an existing project:

Step	Action
1	Click <b>Project</b> $\rightarrow$ <b>Open Project</b> . <b>Result</b> : the Open Project window opens. This window displays the list of projects in the workspace.
2	Select a project.
3	Click End. Result: the project appears in the menu tree.

## **Closing a Project**

The following table shows how to close an existing project:

Step	Action	
1	Select the project.	
2	Click <b>Project</b> $\rightarrow$ <b>Close Project</b> . <b>Result</b> : the project disappears from the menu tree.	

#### **Saving all Modifications**

To save all modifications made, select Save All in the project menu or click the save all icon in the tool bar. This operation saves all modifications made in open windows. These modifications cover all open projects.

## **Closing Web Designer**

When you close Web Designer, it memorizes the open or close state of projects. Projects that are open when you close Web Designer will automatically reopen the next time you launch the software.

## Import

## List of sources

Web Designer can import a project from the following sources to recuperate previous developments:

- a .zip file exported by Web Designer,
- a Web Designer project outside the Workspace.

## Import

To import a project, click **Project**  $\rightarrow$  **Import**. Import window:

6 Import:	
Select Import the project from a zip file or convert it with another tool	
Select an import source: Select an import source: Sectory Cast HMI project Sectory Cast project Web Designer project Designer project Designer The Sector Sec	
<back next=""> End</back>	Cancel

After import, the project appears in the menu tree.

## Export

To export a project as a *.zip* file, click **Project**  $\rightarrow$  **Export**. This function is useful for saving a complete project before modifying it. The project stays open after being exported.

## Transfer

# 4

## Subject of this Chapter

This chapter describes how to transfer a website. You can transfer it from the configuration PC to the module or vice-versa. The transfer concerns the Web pages generated by Web Designer as well as those created by the user. The transfer can be more general and it can include files describing services.

## What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Transfer	50
Project Validation	55
Connecting/Disconnecting to/from the Module	58

## Transfer

## Introduction

These functions enable you to transfer the Data Editor tables, the Graphic Editor pages, the services, the website and its associated files, either from the configuration PC to the target, or from the target to the configuration PC. You must previously advise the target address. Web Designer carries out a validation on the structure of the project before transferring files to the target.

## Setting Up the IP Address

Having two devices with the same IP address can cause unpredictable operation of your network.



## UNINTENDED OPERATION — DUPLICATE IP ADDRESS

- Make sure that this device will receive a unique IP address.
- Always obtain your IP addresses from your system administrator to avoid the possibility of duplicate addresses.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

You must set the IP address of the module to perform a transfer. The following table shows how to advise the physical address of the module:

Step	Action	
1	Select the target in the browser.	
2	Click Target $\rightarrow$ Set Target Address. The following window appears:	
	Target Access	
	Enter the Target Address	
	Address 10.10.20.100	
	Site Explorer Validate Cancel	
3	Enter an IP Address.	
4	Click Validate.	

**NOTE:** You can also advise the address during the creation of the project with the Creation Wizard.

## Transferring from the PC to the Target

The following table shows how to transfer data to the module:

Step	Action				
1	In the browser, select the	target.			
2	Click Target $\rightarrow$ Transfer Result: the Target Validation	→ <b>PC -&gt;Target</b> . tion window appe	ears.		
	<b>Ualidation of the target B</b>	MX NOE 0110- NOE			
	Validation of services in target. Double-click the service to obtain details.				
	Target / Service	File	Validity	Errors	
	0 i BMX NOE 0110 -		OK	0	
			12		
				ОК	
			_		
	If there are detected error	s in your project,	the transfer car	not be performe	
	Refer to the Project Valida	ation part (see pa	<i>age 55)</i> for more	information.	
3	Click OK		•		
0	Note: if there are different	cas hatwaan that	version of firmw	are for the proje	
	and the target the transfe	ar cannot be porfe	version or milliw		

Step	Action
4	The Transfer Status window appears:
	Transfer status
	Direction     Target name     IP Address:       □     Download     BMX NOE 0110-     10.10.20.100       Image: Target Type     BMX NOE 0110     >     BMX NOE 0110       Image: Target Type     BMX NOE 0110     >     BMX NOE 0110       Image: Target Type     BMX NOE 0110     >     >       Image: Target Type     1.4     >     1.4       Image: Target Type     1.0     >     1.0       Image: Target Type     2.0     >     2.0
	Select  Transfer Transfer Destination  Transfer Only Modified Files.  Transfer rdt and gdt Files.  Transfer Configuration Files.
	Transfer Cancel
5	Select the files you want to transfer.
6	Click <b>Transfer</b> . <b>Result</b> : the Configuration Password window appears if a configuration password has already been set. Otherwise the project is transferred.
	Enter the configuration password for TSX BMX NOE 0110-NOE
	Enter password here
	OK Cancel
7	Enter the configuration password and click <b>OK</b> . <b>Result</b> : the Progress Information window appears. The files are displayed one at a time in the Status Bar.

## Transferring from the Target to the PC

The following table shows how to transfer data from the module to a PC:

ion
d.
layed one

## **Total Transfer of the Project**

This function lets you transfer the entire project to all the targets associated with it.
The transfer is done target by target. The global transfer only works in 1 way, you
can transfer from the PC to the targets but not from the targets to the PC. In the last
case, you have to manually transfer the files target by target.

To activate the transfer, click **Project**  $\rightarrow$  **Global transfer**. The procedure is exactly the same than a transfer from the PC to the target (see page 51).

## **Partial Transfer**

To save time, it's possible to do only a partial transfer. In the Website, gdt (graphic pages), rdt (data tables) and Service directories, the contextual menu authorizes a partial transfer limited to files located in these directories. In this way, you don't have to transfer the entire project if you just modified a small part.

### **Documentation**

To manage online documentation, the user can add Word (*.doc*) or Acrobat (*.pdf*) files to the website in the site directory. The Transfer function lets you copy these files to the target.

#### Site Explorer

The button **Site Explorer** displays all the target files in the lower window. This is especially useful before or after a data transfer, in order to analyze the contents of the target.

## **Project Validation**

## Introduction

Web Designer carries out a validation on the structure of the project before transferring files to the target. If the verification detects anomalies, the transfer is cancelled. Web Designer also performs a comparison between the PC configuration and the target configuration.

## Validating a Project

When you start a transfer, Web Designer performs a project validation. You can also validate a project at any time by selecting **Project Validation** in the Project menu.

The Project Validation window looks like this:

🚺 Vali	dation of the target BMX NC	DE 0110		
¢	Validating the services of the	project Double-click or	n a service to get further det	ails.
	Target / Service	File	Validity	Errors
0	i BMX NOE 0110-Targel0		OK	0
1				Þ
				ОК

The validation process monitors the following points:

- the available space on the target is bigger than the size of the website,
- the use of a user page or a service, with variables that will not be in the Namespace (file *Namespace.dat*),
- the number of variables is less that the maximum number authorized for the target (1000 variables),
- the detected errors related to services.

Click a line with a message to display the details of detected errors encountered.

## **Transfer Status**

The following figure shows the Transfer Status window:

0	Tr	ansfer status			×
		<b></b>			
	V	Status			
		Direction	Target name		IP Address:
	Do Do	wnload Target Type	BMX NOE 0110- BMX NOE 0110	$\rightarrow$	10.10.20.100 BMX NOE 0110
	. M.	HTML version	1.4 1.0	$\rightarrow$	1.4 1.0
	V	Web Designer version	2.0	$\stackrel{\scriptstyle \sim}{\rightarrow}$	2.0
Г	Selec	t			
	$\checkmark$	Transfer website.		Destination	FLASH 🔽
	_	Transfer Only Modified Files.			
	$\checkmark$	I ransfer rdt and gdt Hiles.			
		Trapefor Configuration Files			
		Transier Conliguration Thes.			
					Transfer
					Cancel

? The information has not been found on the remote target.

 $\bigwedge$  Inconsistent, non-blocking information between the target and the PC.

Inconsistent, blocking information between the target and the PC.

Consistent information between the target and the PC.

Use the Select area to specify the files you want to transfer:

Parameter	Action
Transfer Website	Select this box to transfer files located in the Website directory.
Transfer only Modified Files	Select this box to transfer only files of the website that have been modified since the last transfer.
Transfer rdt and gdt Files	Select this box to transfer data tables ( <i>rdt</i> directory) and graphic pages ( <i>gdt</i> directory).

## Connecting/Disconnecting to/from the Module

## Introduction

The information below explains the procedure for executing an application once the services have been created.

Transferring a project to the module permanently erases the existing project. When a project is transferred, the old project is overwritten.

Anyone who has access to Web Designer can modify the value of PLC variables that have been write enabled and also modify your security settings. Unauthorized or incorrect changes to data change the behavior of your application or your process in ways that can be undesirable or even hazardous.

# A WARNING

## UNAUTHORIZED SECURITY ACCESS

- Change or disable default passwords on all devices, since default settings are often easy to find in user manuals.
- Change your passwords monthly.
- Do not choose simple user names and passwords.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

# 

#### LOSS OF DATA

Backup important information before transferring a new application.

Failure to follow these instructions can result in injury or equipment damage.

**NOTE:** if an application is in RUN mode, the new project will be taken into account after a module reboot.

## Connecting to the Module and Recovering a Project from the Module

The following table shows the procedure for connecting to the module with a view to recovering its application:

Step	Procedure	
1	Select the target in the browser.	
2	Click <b>Target</b> → <b>Connect</b> → <b>Target</b> . Web Designer analyses the changes between your project and the module content. If you have modified the project, the software will ask you to transfer the project. Otherwise the application moves automatically to online mode. <b>Result</b> : the Configuration Password window appears if a configuration password has already been set. Otherwise Web Designer connects to the module.	
	Configuration Password     X       Enter the configuration password for BMX NOE 0110-NOE       Enter password here       OK	
3	Enter the configuration password and click <b>OK</b> . <b>Result</b> : Web Designer connects to the module.	

## **Disconnecting from the Module**

The following table shows the procedure for disconnecting from the module:

Step	Function	Procedure
1	Disconnecting from the module	Click Target $\rightarrow$ Disconnect. Result: Web Designer has just switched back to offline mode.

## **Simulation Mode**

## Scope of this Chapter

This chapter describes the simulation mode. This mode can be used for debugging data tables, graphic pages and services without being connected to the target.

## What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Connecting/Disconnecting to/from the Simulator	
Simulation	

## Connecting/Disconnecting to/from the Simulator

#### Introduction

The following information describes the operating mode for launching an application through the simulator.

The simulator enables you to execute an application without having to connect to a module. It is therefore possible to test the application from a PC before transferring it to the module.

**NOTE:** The graphic and data editors *(see page 77)* are both active in simulation mode. You can therefore modify these pages in simulation mode.

Once the changes are made, carry out a part transfer in order to reduce transfer time.

#### **Connecting to the Simulator**

The following table shows the procedure for connecting to the simulator and transferring the application:

Step	Procedure
1	Select a target in a project.
2	Click Target $\rightarrow$ Connect $\rightarrow$ Simulation. You are now connected to the simulator, the application is in simulation mode.

**NOTE:** Simulation does not work if a FTP server is running on the system.

#### **Disconnecting from the Simulator**

The following table shows the procedure for disconnecting from a module:

Step	Procedure
1	Click Target $\rightarrow$ Disconnect $\rightarrow$ Simulation. You have just switched
	back to configuration mode.

#### Animations

In simulation mode, the variables are animated as follows (value update frequency depends on the update frequency setting):

- bit: value change, 0 or 1,
- word: increment step 1.

## Simulation

## Introduction

You can simulate your website or your application without using actual devices. This allows you to verify your configuration and test the behavior of your application even if devices are not yet available.

## Simulation Mode

Simulation Mode is available with protocols:

- UMAS,
- UNITE,
- Modbus.

Simulation Mode enables you to test the behavior of your application without running it in the module. In this case, the application runs in the configuration PC.

The user can enter pertinent values for variables (symbols). The default values are set to zero. The values are entered manually in the window associated with the device (double-click the device in the menu tree) or they can be automatically incremented.

#### Using the Simulator Icon

Step	Action
1	In the task bar, right-click on the simulation icon
2	If you check <b>AutoIncrement</b> the variables will be automatically incremented. If you uncheck <b>AutoIncrement</b> , the variables will no longer be incremented and you can modify the value of R/W variables. If you check <b>StopServer</b> , the simulation stops.

#### Using the Simulator for Data Tables and Graphic Pages

Step	Action
1	Select a target in a project.
2	Extend the target directory.
3	Select a table in the <i>DataTables</i> directory or a graphic in the <i>GraphicScreens</i> directory.
4	Right-click and select <b>Open</b> . <b>Result</b> : an Internet Explorer window appears in which the selected table appears or the drop-down menu to select the graphic.



## Using the Simulator for Device windows

Step	Action
1	Double-click the desired device in the <i>Devices</i> directory. <b>Result</b> : the following window appears.
	1 Word10 %MW10 INT RW  10 Durbicate
	Import PLC Symbols
	Animate persistent
	Import from CSV Export to CSV Variables [Properties]
2	Click <b>Animate persistent</b> . If the <b>AutoIncrement</b> function is checked, the variables are automatically incremented. In the <b>Value</b> column, the simulated values are displayed. Else, the variables are no longer incremented. For R/W variables, double-click the <b>Value</b> column to modify the values.

## **Managing Variables**

# 6

## Subject of this Chapter

This chapter explains how Web Designer handles variables. This concerns importing variables, either from a file describing a piece of equipment, or from a file exported by software from the automated program, listing variables from the automated program.

This chapter also presents the file called *Namespace* which groups all these variables. The data and graphics publishers as well as services use these variables.

## What's in this Chapter?

This chapter contains the following topics:

Торіс	
Namespace	68
Importing from a Programmable PLC	
Manual Edit	
Author Rights in Namespace	

## Namespace

#### Introduction

*Namespace* groups all variables (symbols) previously selected for targets or devices. Data Editors, Graphic Editors, and services get symbols from *Namespace*.

Variables come from either connected devices or from PLC applications. If you connect a device type to the same target several times, compose the name as follows in order to have a unique name: *device.name, variable name*. If the device is a PLC, compose the names of variables declared in the PLC like this: *PLC device.name, PLC variable name*.

#### Accessing the Namespace

Step	Action						
1	Select the project.						
2	Extend the target directory.						
3	Double-click the Namespace icon. <b>Result</b> : the Namespace window appears.						
	Topic/Symbol V device Device0 Check U device Device0 Material_in U device Device0 Material_in U device Device0 Temp_fault_2 U device Device0 Iremp_fault_2 U device Device0 Robot_1.cvArm_2 U device Device0 Robot_1.cvArm_2 U device Device0 Robot_1.cvArm_2 U device Device0 Robot_1.cvArm_2 U device Device0 Robot_1.avArm_1 U device Device0 Cooling_monitoring U device Device0 cooling_monitoring U device Device0 cooling_monitoring U device Device0 Robot_1 init U device Device0 recipe[0] Add_atter Material_Symbol_1 init U device Device0 recipe[0] Add_atter % Variables	anable/Address INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED INLOCATED	Type EBOOL INT BOOL EBOOL BOOL BOOL BOOL BOOL BOOL BOO	Comments Result of conditi Internal bit for m Fault for temper Heating input p Internal vanable Maternal picked Minimum current Intialisation Email status	Access R R R R R R R R R R R R R R R W R	Unit	Scale/ada

## Importing from a Programmable PLC

## Introduction

It's possible to access a Unity Pro database with the function Import Symbols.

**NOTE:** Depending on the devices that you connect to the target, the type of variables you can access through the target might be different. Refer to the *FactoryCast for Modicon M340 User Manual* or *FactoryCast for Premium and Quantum User Manual* for more information on supported variables.

## Accessing the Software Database

The following table shows how to access the software database:



Step	Action
4	Click <b>Open</b> . <b>Result</b> : a window displaying symbols opens.
	Selection of the variables to import
	Select the variables to import in the service using double-click
	Name Type Address Comment
	-Actions
	Select all Invert selection 🔽 ReadOnly
5	Select desired symbols.
6	Select the variables you want to import by double clicking the variables in the list.
7	Click <b>Import selected variables</b> . <b>Result</b> : the variables appear in the Device window.

## **Description of the Window**

The following table shows the buttons in the preceding window:

Button	Function
Remove	Delete the variable.
Duplicate	Duplicate the variable.
Import PLC Symbols	Open a selection window of variables.
Import from CSV	Import all the variables from a CSV file.
Export to CSV	Export the variables to a CSV file.

## Accessing the Unity Pro Base

In order to access a Unity Pro database, you must install the Unity Pro software on your computer. Unity Pro database files have *.stu* extension. It's also possible to use an Unity Pro export file (extension *.xvm*). In the latter case, the installation of UnityPro is not mandatory.

### Synchronization with the PLC Program

Over the course of time, it's possible that you will modify the Unity Pro database from which you created your Namespace. The Web Designer Configuration Program will automatically alert you about the differences between the database and your Namespace when you open a configuration associated with the PLC database file.

## Synchronization

The following table shows how to synchronize with a PLC database:

Step	Action
1	Click Target $\rightarrow$ Synchronize with PLC database. Result: Inconsistencies will be shown in a window.
2	Click <b>OK</b> to start default resynchronization operations.
3	Transfer the project to the module.
## Manual Edit

#### Presentation

You can manually add variables by directly entering a symbol, an address, its type and define the access right in the Variables window of each device.

**NOTE:** Depending on the devices that you connect to the target, the type of variables you can access through the target might be different.

#### Automatic Input

Automatic Input is an option that makes easier the manual creation of variables by incrementing the value of the last record.

If you select this option, the value of the fields is automatically filled when you add a new variable. The values correspond to those of the previous line incremented by 1.

Activating / Desactivating Automatic Input:

**Options**  $\rightarrow$  **Automatic Input** 

## Author Rights in Namespace

#### Presentation

This table enables you to specify which variables can be accessed in read/write mode.

**NOTE:** Write access is controlled by a password (Security) whose default value is USER.

Unauthorized or incorrect changes to data may change the behavior of your application in ways that may be undesirable or even hazardous.

# A WARNING

#### UNAUTHORIZED CHANGES TO VARIABLES OR DIRECT ADDRESSES.

Carefully select the variables (symbols) and the direct addresses you authorize to be modified online, and the people authorized to do so.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

#### **Managing Author Rights**

Use the following procedure to manage author rights:

ер	Action			
1	In the navigator: • double-click th • rigth-click the I Result: the Windo	e NameSpace Write A NameSpace Write Ac	Access file or, ccess file and select Open. r rights in Namespace appears.	
	Start Address	End Address		
	✓ %MW1	✓ %MW2		
2	Define the interva	is at which variables c	an be written. Outside these interesting	erv

# Monitoring

# 7

#### Subject of this Chapter

This chapter presents the different ways provided by Web Designer to monitor your system.

#### What's in this Chapter?

This chapter contains the following sections:

Section	Торіс	Page
7.1	Data Editor	78
7.2	Graphic Editor	88
7.3	Creating Custom Web Pages	135
7.4	PLC Program Viewer	158

# 7.1 Data Editor

#### Overview

The Data Editor allows you to edit/create data monitoring tables or to display Data tables. Data tables provide read/write access to application data and devices registers. Write access is password protected.

Allowing write access can change system behavior.

# **WARNING**

#### UNINTENDED OPERATION

- Variables that can be written must be accessed by trained personnel only (password protect).
- Do not give write access to critical control variables.

# Failure to follow these instructions can result in death, serious injury, or equipment damage.

This section shows how to use the Data Editor to display and modify the values of the symbol variables and direct addresses.

#### What's in this Section?

This section contains the following topics:

Торіс	
Data Editor	79
Creating a Data Template	80
Data Editor Spreadsheet	81
Inserting a Symbol (Variable) in a Data Template	84
Inserting a Direct Address in a Data Template	
Using an Existing Data Template	

## **Data Editor**

#### Overview

Data Editor is a Java applet that enables you to create dynamic data tables that can be updated with run-time data from the PLC.

#### **Elements of Data Editor**

The following illustration shows you the Data Editor:

	Variable Name	Address	Data Type	Format	Status
1					
	Name		··· Address		<u>^</u>
2	Type registe	er	Format	DECIMAL	
			Read only		
					OK Reset

Number	Description
1	List of the variables included in this table.
2	<ul> <li>The configuration area makes it possible to:</li> <li>select and/or modify a symbol,</li> <li>select and/or modify an address,</li> <li>select the variable type,</li> <li>select the variable's display format,</li> <li>check the read-only option.</li> </ul>

# **Creating a Data Template**

#### Overview

To display some symbols (variables), you must create a new data template.

#### Creating a Data Template

Follow the steps in the table below to create a data template:

Step	Description		
1	Right click the <i>DataTables</i> directory in the navigator and select <b>New Table</b> . <b>Result</b> : the New Table window appears.		
	👫 New Table		
	Table Name		
	Protocol UMAS		
	OK Cancel		
2	Enter a name of the new Data template.		
3	Click OK.		

**NOTE:** Save the current spreadsheet before selecting a new spreadsheet. Selecting a new spreadsheet deletes the current spreadsheet.

## **Data Editor Spreadsheet**

#### Overview

Depending on the target, the Data Editor displays data in a spreadsheet with the following fields:

- name,
- address,
- type,
- read only,
- format,
- status.

This section describes the spreadsheet screen and gives an explanation of each field.

#### Spreadsheet

The following figure shows the Data Editor spreadsheet:

Variable Na	ame Address	Da	ata Type	Format	Status
					<b>^</b>
	[			ſ	
Name			Address		Ī
Туре	register		Format	DECIMAL	
			Read only		
					OK Reset

#### **Field Name**

The fields in the Data Editor screen are:

Fields	Function
Name	The Name column contains the names of symbolic variables from the Namespace. The symbolic variables which may be used in the Data Editor are those that have been predefined by the configuration tool. The symbolic variables are grouped in a file called <i>Namespace</i> .
Address	The Address column contains the addresses of the symbols. You can display any direct address by entering its reference in this field. This direct address does not need to be referenced in <i>Namespace</i> . However, a symbol must be associated with this direct address.
Туре	Data type (see page 82): input or output register, input or output bit.
Format	Format (see page 83) of the data value.
Read Only	If this box is selected the variable cannot be output directly.

#### **Type Field**

The Data Type field contains the data type of the symbol variable or direct address. The types of data of the symbolic variable appear automatically when the symbol variable is located. Direct address data types must be set by the user from a dropdown list.

The following data types are valid:

Abbreviation	Data type
INT	16-bit signed integer
UINT	16-bit unsigned integer
DINT	32-bit signed integer
UDINT	32-bit unsigned integer
REAL	32-bit IEEE floating point
TIME	32-bit unsigned integer (in ms)
DATE	Date (32-bit BCD)
TOD	Date/time (32-bit BCD)
BOOL	1 internal bit (boolean)

#### **Format Field**

The Format field contains the format type for displaying the value of the symbol variable or direct address. The following formats are accepted:

Abbreviation	Format Type
bool	Boolean
dec	Decimal
hex	Hexadecimal
binary	Binary
ASCII	Bytes displayed as ASCII characters
time	Day_hr_min_sec_ms
date	YYYY-MM-DD or HH:MM:SS

#### Status Field

The Status column contains messages about the status of communications with the symbol variable or direct address. If communications are normal, the status message is "OK".

If communication with a simple variable or a direct address is not operational, the Status column displays a message describing the event.

# Inserting a Symbol (Variable) in a Data Template

#### Overview

If you want to view or modify the value of a symbol (variable) in the Namespace, you must insert that symbol (variable) in a data template.

# 

#### UNINTENDED EQUIPMENT OPERATION

- Password-protect access to the embedded server.
- Carefully select the symbols and direct addresses you authorize to be modified online.
- Do not authorize online modifications of critical process variables.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

### Inserting a Symbol (Variable)

Follow the steps in the table below to insert a Symbol (variable):

Step	Action		
1	Double-click on an empty row in the spreadsheet. <b>Result</b> : The data editor's configuration area appears.		
2	In the configuration area, click on the button. <b>Result:</b> The <b>Lookup</b> window appears.		
	Filter:         Image: Cookup         Image		
3	Select the symbols (variables) you want to insert in the data template by clicking them in the list.		
4	Click <b>OK</b> . <b>Result</b> : New rows corresponding to the symbols (variables) you selected appear in the spreadsheet.		
5	Save your data table by clicking		

# Inserting a Direct Address in a Data Template

#### Presentation

If you want to view or modify the value of a direct address, you must insert that direct address in a data template.

Allowing write access can change system behavior.

# 

#### UNINTENDED EQUIPMENT OPERATION

- Limit embedded server access to qualified personnel.
- Password-protect access to the embedded server.
- Carefully select the symbols and direct addresses you authorize to be modified online.
- Do not authorize online modifications of critical process variables.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

#### **Inserting a Direct Address**

Step	Action
1	Double-click on an empty row in the spreadsheet. Result: The data editor's configuration area appears.
2	In the <b>Address</b> field of the configuration area, enter the variable's Direct address.
3	In the configuration area, click on <b>Apply</b> . <b>Result:</b> A new row that corresponds to the variable address is displayed in the spreadsheet.

# Using an Existing Data Template

#### Overview

Once you have created data templates, you may want to access or modify them.

#### Accessing a Data Template

The following procedure shows you how to access a existing data template.

1       Extend the DataTables directory in the naviga Result: The existing tables appear in the navi         2       • Double click the table you want to modify in • Right click the table you to modify and selet	
<ul> <li>Double click the table you want to modify in</li> <li>Right click the table you to modify and sele</li> </ul>	ator. vigator.
Result: The selected table appears in the edit	in the list or, lect <b>Edit</b> . liting zone.

# 7.2 Graphic Editor

#### Subject of this Section

This section describes the functions and characteristics of the Graphic Editor. The Graphic Editor is a Web page that enables the user to create dynamic graphic displays using a predefined set of graphic objects. The Graphic Editor is both a graphic editor that can be used to create and modify displays and a Runtime environment that allows the user to view animated displays using data from the PLC. To limit the size of the applet, only Viewer is accessible from the module's website.

#### What's in this Section?

Торіс	Page
Overview of the Graphic Editor	89
Graphic Editor Toolbar	91
User Functions in the Display Window	96
Properties Sheet	99
Security	101
Graphic Editor Applet Parameters	102
Graphic Objects	104
Extended Graphic Objects	124

This section contains the following topics:

# **Overview of the Graphic Editor**

#### Interface

The Graphic Editor is made up of three windows:

- **Top window**: features an area for presenting the user commands and dialog boxes for creating, saving, reading and editing a graphic display.
- **Display window**: presents the current graphic display. When you create a new graphic display, this window turns into a blank space into which you can add the graphic objects that will make up the required graphic display.
- Message window: contains messages generated by the Graphic Editor.

#### View of the Graphic Editor

The figure below shows the Graphic Editor with its initial top window and empty display and message windows.



#### **Graphic Objects**

All the graphic objects supplied with the Graphic Editor are able to communicate with the modbus devices from which the Graphic Editor was downloaded. There is no additional "wiring" between the graphic objects and the "communication objects". All the graphic objects are designed as standalone objects, which means that no connection is needed between the objects, and that each object is capable of operating on its own.

Allowing write access can change system behavior.

# A WARNING

#### UNINTENDED EQUIPMENT OPERATION

- Keep strict access to the embedded server by configuring passwords.
- Carefully select the symbols and direct addresses you authorize to be modified online.
- Do not authorize online modifications of critical process variables.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

**NOTE:** Write access is controlled by a password (Security) whose default value is USER.

#### **Creating and Modifying Graphic Displays**

To create and modify graphic displays, click **Edit...** The standard functions of the Graphic Editor are displayed. With these tools, you can select objects from a palette, position them in an area, move and resize them with the mouse and define their properties. You can immediately test the graphic display modified with the execution data from modbus devices by clicking **Done** to leave Edit mode. If you are satisfied with the graphic display you have created, you can save it in the module for later use by clicking **Save...**, provided that you have entered the correct password.

**NOTE:** Be careful when you modify and save a graphic page, the last modifications will be saved and will overwrite the existing page even if someone else has created it.

#### **User Functions**

Most of the user functions in the Graphic Editor can be found in the top window *(see page 91).* You can modify the size and position of a graphic object directly in the display window. All the properties of a graphic object (such as its scale, labels, colors and Uni-Telway execution data device addresses) are defined in the properties sheet *(see page 99).* 

# **Graphic Editor Toolbar**

#### Overview

The Graphic Editor toolbar is composed of several dialog panels, only one of which is shown at a time. Switching from one dialog to another is done by clicking the buttons on the current dialog. This section describes the dialog panels that comprise the top window.

#### **Top Dialog**

The **Edit Dialog** allows you to select a graphic object for placement in the display window, and provides access to all graphic editing functions. The available graphic objects are presented in a set of palettes, with one palette visible at a time. There are two palettes.

The standard palette:

standard 🔻		+ - 100 ABC			¥ 🏹 🎽		
Properties	Customize		Cut Copy	Paste	Layout	Options	Done

The extended palette:

extended 💌	⋭Ų⊈⊘	- 🖸 🖓 🖓 🚺 🎹 🚥 🃢	АЬ		
Properties	Customize	Cut Copy Paste	Layout	Options	Done

The controls in the top dialog box provide the following functions.

- **Drop-down List**. The drop-down list box shows all the graphic pages that have been saved, and are available for retrieving. When you select a graphic page from this list, the graphic display currently visible in the window is replaced with the one selected. If the current graphic page has been modified since it was last saved, you will be asked for confirmation that the changes are to be discarded. If the special entry <new> is chosen from the list, then the display window is cleared, and a new graphic page can be created.
- Save. The Save button causes the Save dialog box to become visible. This button is disabled until you have entered a correct write-enable password.
- **Delete**. The **Delete...** button causes the **Delete dialog box** to become visible. This button is disabled until you have entered a correct password, or if the current graphic display has not yet been saved.
- Edit. The Edit... button causes the Edit dialog box to become visible.
- Information display area. The information display area shows the name and version of the Concept, PL7 or Unity Pro program that is running in the connected PLC.

#### Save Dialog

The **Save dialog box** allows you to save the current graphic display.



When the **Save dialog box** is presented, the name of the current graphic page is shown in the dialog's text field. If the current graphic page has never been saved (i.e., a "new" graphic display), then the text field is blank. Once you have either accepted the current name (a "save" operation) or provided a new name (a "save as" operation), then you can click **OK** to save the contents of the current graphic display to the Web server module. The **Cancel** button will cause the **Top dialog box** to be shown again, with no action being taken.

#### **Delete Dialog**

The **Delete dialog box** allows you to delete the current graphic page.



If you click **Yes**, the existing graphic display window is cleared and the graphics file on the Web server module is deleted. Clicking **No** will cause the **Top dialog box** to be shown again, with no action being taken.

#### **Password Dialog**

The **Password dialog box** allows you to enter the password that enables those user functions that modify graphic display files or PLC run-time data values.

Password to allow write access:	
OK. Cancel	

If you enter the correct password and click **OK**, then you will be allowed to save and delete the current graphic display. Correct password entry also permits you to write new values to the PLC (via those graphic objects that support writing values to a PLC, if any). If you click **OK** when the text field is empty, then the current password permissions, if any, are cleared. The **Cancel** button will cause the **Top dialog box** to be shown again, with no changes made to current password permissions.

#### **Edit Dialog**

The **Edit dialog box** allows you to create or modify a graphic page, by selecting a graphic object for placement in the display window, and accessing all the graphic editing functions. The graphic objects available are presented in a single object palette.

standard 💌	í	سلسا چ		 100	ABC		$\square$		,	7 🏹 I		
Properties	] Cust	omize			Cut	(	Copy	Paste	е	Layout	Options	Done

The controls of the Edit dialog box provide the following functions:

- The **Drop-down List Box** shows the set of palettes that are available. When you select the name of a palette from the list, the palette area of the dialog displays the selected one's graphic objects.
- The **Palette** shows the graphic objects that are in the current palette with an icon that depicts each graphic object's type (meter, button, etc.). When you click any of the icons in the palette, a graphic object of the corresponding type becomes selected for insertion. While the Graphic Editor is in "insert mode," if you click in an open area of the display window, an instance of the selected graphic object is inserted into the graphic display.
- The **Information Area** shows the name and size of the graphic object that is currently selected.
- The **Cut** button causes the currently selected graphic object(s) to be removed from the graphic display and saved to a buffer (i.e., an internal clipboard), replacing any existing contents of the buffer.
- The **Copy** button causes the currently selected graphic object(s) to be copied to the buffer, replacing any existing contents.
- The **Paste** button causes the content of the clipboard to be inserted into the upper left corner of the graphic display. The pasted graphic objects can then be moved to the desired location in the display.
- The **Properties** button causes the properties sheet *(see page 99)* for the currently selected graphic object to be shown.
- The **Customize** button causes the Customizer for the currently selected object to be shown, if the graphic object has been provided with one.
- The Layout button shows the Layout dialog box.
- The Options button shows the Options dialog box.
- The **Done** button causes the **Top dialog box** to be shown again.

#### Layout Dialog

The **Layout dialog box** allows you to change the position and size of a group of graphic objects.

FactoryCast Graphic Editor - Microsoft Internet Explorer     Edit     Lile     Edit     View     Favorites     Iools     2	
Back Forward Stop Refresh Startup Search Favorites History Mail	r 🎒 🚯 T Print Edit
Address Attp://139.158.13.16/secure/system/gde.htm	] ∎OK  Links≫
Align edges:         Right         Down         Left         Up         Space regularly:         Horizontal         Ver           Align centers:         Horizontal         Vertical         Even dimensions:         Width         H	eight Done
Reference and the second secon	

The controls of the Layout dialog box provide the following functions.

- The **Right**, **Bottom**, **Left**, and **Top** buttons can be used to align the edges of the selected graphic objects so that their specified sides are at the same position. At least two graphic objects must be selected for these buttons to be enabled.
- The **Horizontal**, and **Vertical** buttons are used to align the centers of the graphic objects. At least two graphic objects must be selected for these buttons to be enabled.
- The **Horizontal** and **Vertical** buttons are used to space the selected graphic objects regularly, in order that the horizontal or vertical spacing between the objects is the same. At least three graphic objects must be selected for these buttons to be enabled.
- The **Width** and **Height** buttons are used to achieve parity in dimensions of the graphic objects, so the selected width or height corresponds. At least two graphic objects must be selected for these buttons to be enabled.
- The **Done** button causes the **Edit dialog box** to be shown again.

**NOTE:** For all layout operations (except **Space evenly**) one of the selected objects is considered the "reference object" to which all other selected objects refer in order to know their new position or dimension. For example, when the "Width" button is pressed, all of the selected objects will have their width changed to match the width of the reference object. The reference object is differentiated from the other selected objects by making its selection box a different color than the others.

#### **Options Dialog**

The **Options dialog box** is used to change the settings related to a grid drawn in the display window. The grid is solely for assistance in editing or creating a graphic display and is shown only when the Graphic Editor is in "edit mode."



The controls of the Options dialog box provide the following function.

- The cell size of the grid can be changed by the entering the grid's column width and row height into the dialog's text fields.
- If the **Show grid** check-box is checked, the grid will be drawn; otherwise, no grid will be shown.
- If the Snap to grid check-box is checked, then, when you change the size or position of a graphic object, the changed coordinate(s) or dimension(s) is automatically adjusted so that it coincides with a grid point.
- The OK button causes the current option settings to become active, and the Edit dialog box to be shown again.
- The **Cancel** button causes the **Edit dialog box** to be shown again, with no option settings being changed.

# **User Functions in the Display Window**

#### Overview

The user functions available in the **Graphic Editor** display window enable objects to be selected, moved and resized. To move or resize an object or objects, start by selecting the graphic object(s) to be modified. An object is selected when it is surrounded by a selection box. Conversely, objects that are not selected do not have selection boxes.

standard ٠ 100  $\sim \infty$ ABC ۲ 7 Properties... Rotary Slider Layout. Options.. Done Time\_1 50.0 +++50 75 25 100.0 0.0 100 7:16:45 AM . 15:04 AM 7-18-26 AM 7-20-07 AM 7-21-48 AM 100 0 -100 Count Value 0 . Motor Control Center А LT\_8 LT\_8

The figure below shows the Graphic Editor display window.

#### **Selecting Graphic Objects**

You can set the selection status (selected/deselected) for a graphic object using the following user actions:

- To select a graphic object, just click it with the mouse. If other objects have already been selected, they will immediately be deselected.
- You can select several graphic objects at a time using the selection box in the display window. If you press the mouse button in a free area of the display window (not on a graphic object) and move the mouse without releasing the button, a box bordered with dotted lines will appear. One corner of the box remains fixed where you first pressed the button, while the opposite corner follows the mouse cursor position. When you release the mouse button, all the objects within the selection box are selected. Objects outside the selection box are deselected.
- You can select/deselect a graphic object without altering the selection status of other objects. To do this, hold down the CTRL key when you click an object. This allows you to add or remove individual graphic objects in a group of selected objects.
- You can also select a graphic object without altering the selection status of other objects by holding down the SHIFT key when you click the object. When you select an object in this way, it becomes the reference object *(see page 94)* in the group of selected objects. The main purpose of this action is to modify the reference object in a group of selected objects before using one of the **Page layout** operations.
- You can deselect all the graphic objects by clicking the mouse button in a free area of the display window, not a graphic object.

#### Sizing Graphic Objects

To change the size of a graphic object, select it and then use the mouse to change the size of the selection box around the object. When you move the mouse cursor over the object's selection box, the cursor's appearance changes according to the type of resizing you may perform. If you press the mouse button while the cursor is over the object's selection box and move the mouse without releasing the button, a box bordered with dotted lines will appear. When you release the mouse button, the object is resized to fit the dimensions of the area you have defined. You can carry out different resizing operations depending on which part of the object's selection box you move. Each corner of the box enables the adjacent sides to be moved, and each side enables that side only to be moved.

#### **Moving Graphic Objects**

You can move a graphic object in the display window using the mouse. If you press the mouse button while the cursor is over an object and move the mouse without releasing the button, a selection box will appear. When you release the mouse button, the object is moved into the selection box.

To move several graphic objects, select them and then move the group of objects in the same way as you would a single object. When you move a group of objects, a selection box appears for each object in the group.

#### **Defining Graphic Object Properties**

You can define the properties of a graphic object using the property sheet *(see page 99).* If this window is displayed, you can modify the properties of the selected graphic object. You can display the property sheet by clicking **Properties...** or by double-clicking on the selected object in the display window.

#### **Customizing Complex Graphic Objects**

Certain complex graphic objects have a very wide range of properties. Configuring these objects using the properties sheet can be a long-winded process. You can use a customization module to make it easier to configure complex graphic objects. The customization module is a dialog box designed specially for configuring the graphic object with which it is associated. When the Graphic Editor detects a customization module associated with the selected graphic object, the **Customize...** button is enabled so that the module can be accessed. When you double-click a graphic object that has an associated customization module, the module is displayed instead of the properties sheet. If a graphic object has an associated customization module, only its name is displayed in the properties sheet.

#### **Display Background Image**

The Background image property of the Graphic Editor allows you to choose an image that will be used as the background for the display. The image may be a *.gif* file or a *.jpeg* file. Refer to the Adding Images part *(see page 127)* for information on adding images.

## **Properties Sheet**

#### Overview

The properties sheet is a floating (non-modal) dialog box which presents all the configurable properties of the selected graphic object:

Properties [Horizontal ]	Indicator]
Name	Horizontal Indicator 1
Address	•••
Data Type	
Background	
Label	
Label Color	
Label Font	Abcdefg
Major Scale Divisions	1
Minor Scale Divisions	5
Scale Color	
Scale Font	Abcdefg
	Done

The properties of a graphic object are specific to its type. They are contained in a drop-down list, and are identified by a name and value. The Graphic Editor provides a description of the graphic objects (*see page 104*).

#### Find variables dialog box

For each of the graphic objects provided with the Graphic Editor, a property editor is provided for its **Address** property. This property editor not only allows you to directly enter the address of a variable, but also provides access to the **Find variables dialog box**. The Lookup Dialog allows you to pick a symbol (variable) name from a list of symbol (variables) that have been "Web enabled" by Web Designer.

The Lookup Variable dialog box looks like this:

Lookup Variable	🔀
Show only variables starting with Hide structured variables device. Device2.11_MAX_AVG device. Device2.12_MAX_AVG device. Device2.12_MAX_AVG.7 device. Device2.P_MAX_AVG_PLUS device. Device2.Q_MAX_AVG_PLUS device. Device2.Q_MAX_AVG_PLUS device. Device2.Q_MAX_AVG_MINUS device. Device2.S_MAX_AVG	WORD WORD WORD WORD WORD WORD WORD WORD
OK	Cancel

## Security

#### Security

Your data is protected by three security devices:

- The HTML page which contains the Graphic Editor applet has been placed in the *secure* directory on the Web module. The Web browser user is therefore invited to enter a password which will allow him/her to download the HTML page.
- You must enter the correct password in the **Password** dialog box to be able to save/delete files or send data values. For the transfer of data values, the Graphic Editor reinforces the read only mode by deactivating all the graphic objects user commands.
- The Graphic Editor allows you to indicate if an element is read only. The **Graphic** Editor reinforces the read only attribute of a symbol (variable) or address by rejecting any request which would define a new data value and by informing the user via the **Graphic Editor** message window.



#### UNINTENDED EQUIPMENT OPERATION

Do not use graphic objects in situation where loss of communication to the FactoryCast module can affect human or material integrity. Graphic objects are not intended for use in safety critical machine functions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

For example, say you have programmed a pushbutton object to jog a motor when the button is depressed and to stop jogging when the button is released. If communications are lost while the button is depressed, the motor will continue to jog even when the button is released. Graphic objects should not be used to control situations such as this unless other interlock methods are installed in the system.

## **Graphic Editor Applet Parameters**

#### Overview

Three applet parameters allow the **Graphic Editor** behavior to be customized. These are defined by the <PARAM> tags inside the <APPLET> tag on the Graphic Editor HTML page. The parameters recognized by the **Graphic Editor** applet are as follows:

- LOAD: this parameter asks the **Graphic Editor** to automatically load a specific graphic file at start-up. If this file does not exist, a message is displayed. If this parameter does not appear in the <APPLET> tag, no file will be automatically loaded at start-up and you must choose an initial graphic file from the list proposed by the **Graphic Editor**.
- MODE: this parameter asks the Graphic Editor to start either in Edit (normal mode) or View mode (specific mode). When starting in View mode, the Graphic Editor only displays the display window. When this parameter is used with the LOAD parameter, you can design a website with HTML pages dedicated to specific graphic display. The user does not need to select a graphic file so the behavior of the HMI screen is more standard. This parameter may take the following values:
  - EDIT (default value): The Graphic Editor starts up in Edit mode (normal mode).
  - VIEW\_RO: The Graphic Editor starts up in View mode (read only). The Web browser user is not authorized to send data values to Modbus devices.
  - VIEW\_RW: The Graphic Editor starts up in View mode (read/write). The Web browser user is authorized to send data values to Modbus devices after having entered the password to allow write access.
- AUTO\_LOGIN: this parameter asks the Graphic Editor to automatically indicate the password which authorizes write access to Modbus devices. If the MODE parameter is set to VIEW\_RW or EDIT, and if you set AUTO\_LOGIN to TRUE, the Graphic Editor authorizes write access to Modbus devices without asking the user to enter a password. This parameter may take the values FALSE (default value) and TRUE.

#### Example

Here is an example of an <APPLET> tag which asks the **Graphic Editor** to start in View mode and automatically load a graphic file called **UNIT\_1**. In this case, the Web browser allows you to send values to Modbus devices via any graphic object handling the sending of values (providing that the password to allow write access has been entered).

```
<APPLET codebase="/classes"
archive="SAComm.jar,GDE.jar,Widgets.jar"
code="com.schneiderautomation.gde.GdeApplet"
width="700" height="514">
<PARAM name="LOAD" value="UNIT_1">
<PARAM name="LOAD" value="UNIT_1">
<PARAM name="MODE" value="VIEW_RW">
<PARAM name="MODE" value="FALSE">
</APPLET>
```

# **Graphic Objects**

#### Introduction

All graphic objects offered by the **Graphic Editor** help you to create graphic displays imitating conventional instrument panels. All the data control and monitoring objects have integrated communication functions and are designed as standalone graphic objects.

Be aware, however, that if communication to the device linked to the graphic object is lost, the object becomes inoperative without the end device's knowledge.

# A WARNING

#### UNINTENDED EQUIPMENT OPERATION

Do not use graphic objects in situations where loss of communication to the module can affect human or material integrity. Graphic objects are not intended for use in critical machine functions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

For example, say you have programmed a pushbutton object to jog a motor when the button is depressed and to stop jogging when the button is released. If communications are lost while the button is depressed, the motor will continue to jog even when the button is released. Graphic objects should not be used to control situations such as this unless other interlock methods are installed in the system.

In addition, all the objects in the **Graphic Editor** exist in the form of applets to help clients who wish to insert several simple applets into a single HTML page. When combined with the *LiveBeanApplet*, the graphic objects in the **Graphic Editor** can be used in the same way as the *LiveLabelApplet*.

#### **Horizontal Indicator**

A horizontal indicator gives an analogue representation of the value of a variable in a device. This is a horizontal bar which represents a percentage of its range in physical units. It is possible to display the value's digital indication in the centre of the bar.

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Major Scale Divisions	Number of major scale divisions (marked)	0 to 100
Minor Scale Divisions	Number of minor scale divisions (not marked)	0 to 100
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Scale Precision	Number of decimal places to be shown for the scale labels (set to -1 to use a general exponential format)	-1 to 6
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 (see page 134)
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 (see page 134)
Value Visible	Indicates if there should be digital display of the value on the scale	
Value Font	Font used for digital display of the value (where this exists)	
Bar Background	Background color of the indicator bar	

The table below describes the horizontal indicator's properties:

Property	Description	Limits
Bar Color	Color of the indicator bar (if the scale value is within the High/Low range)	
High High Limit Value	Value expressed in physical units of the "High High" limit.	
High High Limit Color	Color of the indicator bar if the scale value is greater than the "High High" limit	
High Limit Value	Value expressed in physical units of the "High" limit.	
High Limit Color	Color of the indicator bar if the scale value is greater than the "High" limit.	
Low Limit Value	Value expressed in physical units of the "Low" limit	
Low Limit Color	Color of the indicator bar if the scale value is less than the "Low" limit	
Low Low Limit Value	Value expressed in physical units of the "Low Low" limit	
Low Low Limit Color	Color of the indicator bar if the scale value is less than the "Low Low" limit	
Limit Deadband	Neutral range (as a percentage of the EU range) to apply to verification of the High/Low limit	0 to 10
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated gross starting value (without scale) for testing the graphic object	Note 3 (see page 134)

#### **Vertical Indicator**

A vertical indicator gives an analogue representation of the value of a variable in a device. This is a vertical bar which represents a percentage of its range in physical units.

The table below describes the vertical indicator's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 <i>(see page 134)</i>
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	

Property	Description	Limits
Label Color	Color of the label	
Label Font	Font used for the label	
Major Scale Divisions	Number of major scale divisions (marked)	0 to 100
Minor Scale Divisions	Number of minor scale divisions (not marked)	0 to 100
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Scale Precision	Number of decimal places to be shown for the scale labels (set to -1 to use a general exponential format)	-1 to 6
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 <i>(see page 134)</i>
Minimum Value	Gross minimum value (without scale) of the variable in the device	Note 3 <i>(see page 134)</i>
Bar Background	Background color of the indicator bar	
Bar Color	Color of the indicator bar (if the scale value is within the High/Low range)	
High High Limit Value	Value expressed in physical units of the "High High" limit.	
High High Limit Color	Color of the indicator bar if the scale value is greater than the "High High" limit	
High Limit Value	Value of the "High" limit expressed in physical units	
High Limit Color	Color of the indicator bar if the scale value is greater than the "High" limit.	
Low Limit Value	Value of the "Low" limit expressed in physical units	
Low Limit Color	Color of the indicator bar if the scale value is less than the "Low" limit	
Low Low Limit Value	Value of the "Low Low" limit expressed in physical units	
Low Low Limit Color	Color of the indicator bar if the scale value is less than the "Low Low" limit	

Property	Description	Limits
Limit Deadband	Neutral range (as a percentage of the EU range) to apply to verification of the High/Low limit	0 to 10
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated gross starting value (without scale) for testing the graphic object	Note 3 (see page 134)

#### **Horizontal or Vertical Slider**

A horizontal or vertical slider gives an analogue representation of the value of a variable in a device. This is a slider, whose position is indicated by the cursor, which represents a percentage of its range in physical units. Using the mouse, you can change the value of the slider by sending a new value to the device.

The table below describes the horizontal or vertical slider's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 <i>(see page 134)</i>
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Major Scale Divisions	Number of major scale divisions (marked)	0 to 100
Minor Scale Divisions	Number of minor scale divisions (not marked)	0 to 100
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Scale Precision	Number of decimal places to be shown for the scale labels (set to -1 to use a general exponential format)	-1 to 6
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 (see page 134)
Property	Description	Limits
-----------------	---	---------------------------------
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 <i>(see page 134)</i>
Block Increment	Amount by which the scale value is modified when the user clicks on the bar's slide area.	
Unit Increment	Amount by which the scale value is modified when the user clicks on the slider arrows	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

#### Horizontal or Vertical Selector

A horizontal or vertical selector allows you to choose from a number of options. Once the selection has been made, the value corresponding to the choice is sent to the device. The choices are represented by the marks on a "scale", the current selection being indicated by the position of the cursor on a slider.

The table below describes the horizontal or vertical selector's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Choices	Selector choices Each choice is indicated in the form of a "label=value" input (when you select a "label", the "value" is sent to the device).	At least two choices required
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Scale Visible	Indicates if a "scale", labeled with the choices should be displayed	
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

## **Digital Indicator**

A digital indicator gives a digital representation of the value of a variable in a device. The value may be displayed in different formats and may be set to change color when a predefined high or low limit is exceeded.

The table below describes the digital indicator's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Value Format	Format (decimal, hexadecimal, etc.) to be used to display the value on the scale	
Value Precision	Number of decimal places to be shown for the value on the scale (set to -1 to use a general exponential format)	-1 to 6
Value Background	Background color of the value's display zone	
Value Color	Color of the value's digital display text	
Value Font	Font used for digital display of the value	
Units	Label of the value's physical units (attached to the value's digital display)	
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 (see page 134)
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 (see page 134)
High High Limit Value	Value of the "High High" limit expressed in physical units	
High High Limit Color	Color of the indicator bar if the scale value is greater than the "High High" limit	
High Limit Value	Value of the "High" limit expressed in physical units	

Property	Description	Limits
High Limit Color	Color of the indicator bar if the scale value is greater than the "High" limit.	
Low Limit Value	Value of the "Low" limit expressed in physical units	
Low Limit Color	Color of the indicator bar if the scale value is less than the "Low" limit	
Low Low Limit Value	Value of the "Low Low" limit expressed in physical units	
Low Low Limit Color	Color of the indicator bar if the scale value is less than the "Low Low" limit	
Limit Deadband	Neutral range (as a percentage of the EU range) to apply to verification of the High/Low limit	0 to 10
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated gross starting value (without scale) for testing the graphic object	Note 3 (see page 134)

## Message Display

A message display shows a text message based on the value of a variable in a device. For each specified message, a set value triggers its display.

The table below describes the message display's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Messages	All messages to be displayed. A "value=text" input corresponds to each message (when the device value is equal to "value", the "text" message is diplayed).	At least one message required
Message Background	Background color of the message display zone	
Message Color	Message text color	
Message Font	Message text font	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	

Property	Description	Limits
Label Font	Font used for the label	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the border of the graphic object	
Value	Simulated input value for testing the graphic object	Note 3 (see page 134)

## **Push Button**

When activated with the mouse, a push button allows you to send one or more preset values to a device.

The table below describes the push button's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Background color of the graphic object	
Values	Values to send to the device	Note 4 (see page 134)
Reset Values	Values to send to the device once the reset delay has expired. If no reset value is given, the reset will not take place.	
Reset Delay	Delay (in milliseconds) that the push button must comply with between sending the values to the device and sending the reset values	0-2000
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Button Label	Text of the button label	
Button Background	Button color	0 to 100
Button Label Color	Color used for the button label	
Button Label Font	Font used for the button label	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

## **Direct Output Station**

The direct output station allows you to enter a digital value in a text zone directly from the keyboard. If the value entered is between the upper and lower preset limits, a **Set** button is activated. In this case, the value entered is sent to the device when you click **Set** or press **ENTER** (if keyboard input is authorized for the input zone).

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 (see page 134)
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 (see page 134)
Maximum Input	Maximum value, expressed in physical units, authorized for the value entered in input	
Minimum Input	Minimum value, expressed in physical units, authorized for the value entered in input	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

The table below describes the direct output station's properties:

## Indicator Light

The indicator light provides a double indication of the value of a variable in a device. If the Input Inverted property is not set to TRUE, a zero input value is declared as being OFF and a non-zero value is declared as being ON. If the Flash Interval property is set to a positive value, the indicator light will flash when the input value is equal to ON.

The table below describes the indicator light's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Off Word	Text to be displayed when the input value is OFF	
Off Word Background	Background color of the indicator light when <b>Off</b> <b>Word</b> is displayed	
Off Word Color	Color of the Off Word text	
Off Word Font	Font used for the Off Word text	
On Word	Text to be displayed when the input value is ON	
On Word Background	Background color of the indicator light when <b>On</b> <b>Word</b> is displayed	
On Word Color	Color of the On Word font	
On Word Font	Font used for the <b>On Word</b> text	
Flash Interval	The flashing time for the indicator light (expressed in milliseconds) when the input value is ON. Set to zero for no flashing.	200 to 2000
Shape	Shape (circular, rectangular, etc.) of the indicator light	
Input Inverted	On <b>TRUE</b> , inverts the input value. (The indicator displays <b>Off Word</b> when the input value is ON.)	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the border of the graphic object	
Value	Simulated input value for testing the graphic object	Note 3 (see page 134)

## **Motor Control Station**

The motor control station is designed to imitate the on/off push button standard station which is frequently used to control the motors. This graphic object is essentially compose of two push buttons and an indicator light. To facilitate the configuration of this object's many properties, a custom module is provided. It is by means of this module, and not the **Graphic Editor** properties sheet, that all the properties (apart from the name) are configured.

Property	Description	Limits
Name	Name of the graphic object	
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Indicator Light	Properties identical to those of the Indicator Light graphic object with the exception of the shared properties listed above	
Top Push Button	Properties identical to those of the Push Button graphic object with the exception of the shared properties listed above	
Bottom Push Button	Properties identical to those of the Push Button graphic object with the exception of the shared properties listed above	

The table below describes the motor control station's properties:

## **Analog Meter**

An analog meter gives an analog representation of the value of a variable in a device. It is represented by a pointer on a circular dial whose position corresponds to a percentage of its range in physical units. You can set the size of the meter's circular dial (circle degrees sweep), its colors and the style of the pointer.

The table below describes the analog meter's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	

Property	Description	Limits
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Major Scale Divisions	Number of major scale divisions (marked)	0 to 100
Minor Scale Divisions	Number of minor scale divisions (not marked)	0 to 100
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Scale Precision	Number of decimal places to be shown for the scale labels (set to -1 to use a general exponential format)	-1 to 6
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 (see page 134)
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 (see page 134)
Dial Degrees Sweep	Portion of circular arc to be used to draw the dial	60 to 300
Pointer Type	Type of pointer used (needle, arrow, etc.)	
Pointer Color	Color used for the pointer	
Dial Color	Color used for the dial (for the part in the High/Low range)	
High High Limit Value	Value of the "High High" limit expressed in physical units	
High High Limit Color	Color of the indicator bar if the scale value is greater than the "High High" limit	
High Limit Value	Value of the "High" limit expressed in physical units	
High Limit Color	Color of the indicator bar if the scale value is greater than the "High" limit.	
Low Limit Value	Value of the "Low" limit expressed in physical units	
Low Limit Color	Color of the indicator bar if the scale value is less than the "Low" limit	

Property	Description	Limits
Low Low Limit Value	Value of the "Low Low" limit expressed in physical units	
Low Low Limit Color	Color of the indicator bar if the scale value is less than the "Low Low" limit	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated gross starting value (without scale) for testing the graphic object	Note 3 (see page 134)

## **Rotary Slider**

A rotary slider gives an analog representation of the value of a variable in a device. It is represented by a knob on a circular dial whose position corresponds to a percentage of its range in physical units. You can set the size of the dial and the color of the knob. Using the mouse, you can change the position of the knob by sending a new value to the device.

The table below describes the rotary slider's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Major Scale Divisions	Number of major scale divisions (marked)	0 to 100
Minor Scale Divisions	Number of minor scale divisions (not marked)	0 to 100
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Scale Precision	Number of decimal places to be shown for the scale labels (set to -1 to use a general exponential format)	-1 to 6
Dial Degrees Sweep	Portion of circular arc to be used to draw the dial	60 to 300
Dial Color	Color of the dial	

Property	Description	Limits
Knob Color	Color used for the knob	
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 <i>(see page 134)</i>
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 <i>(see page 134)</i>
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

#### **Rotary Selector**

A rotary selector allows you to choose from a number of options. Once the selection has been made, the value corresponding to the choice is sent to the device. The choices are represented by the marks on a "scale", the current selection being indicated by the position of the knob. The size of the circular dial (circle degrees sweep) and the color of the knob can be configured.

The table below describes the rotary selector's properties:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 <i>(see page 134)</i>
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	
Choices	Selector choices Each choice is indicated in the form of a "label=value" input (when you select a "label", the "value" is sent to the device).	At least two choices required
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Scale Visible	Indicates if a "scale", labeled with the choices should be displayed	
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Dial Degrees Sweep	Portion of circular arc to be used to draw the dial	60 to 300

Property	Description	Limits
Knob Color	Color used for the knob	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

## **Trend Recorder**

A trend recorder enables you to obtain a continuous, time-based graphic of the values of a maximum of six variables in a device. It emulates a strip-chart recorder, with the pens on the right and the "paper" moving from right to left. A vertical scale to the left of the graphic indicates the range of registered values and a horizontal scale beneath the graphic displays the range's time frame. You can set the update frequency and the appearance of the graphic.

To facilitate the configuration of the many properties of this object, a custom module is provided. It is by means of this module, and not the **Graphic Editor** properties sheet, that all the properties (apart from the name) are set.

The table below describes the trend recorder's properties: The properties available for each of the pens are described in the second table:

Property	Description	Limits
Name	Name of the graphic object	
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Major Scale Divisions	Number of major scale divisions (marked)	0 to 100
Minor Scale Divisions	Number of minor scale divisions (not marked)	0 to 100
Scale Color	Color of the scale and its labels	
Scale Font	Font used for the scale labels	
Scale Precision	Number of decimal places to be shown for the scale labels (set to -1 to use a general exponential format)	-1 to 6
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Update Period	Graphic update interval (in seconds)	0.5 to 120

Property	Description	Limits
Time Scale Divisions	Number of divisions on the horizontal scale	0 to 6
Chart Background	Color of the graphic zone	
Grid Color	Color of the grid drawn in the graphic zone	
Vertical Grid Divisions	Number of vertical divisions in the grid	0 to 100
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

The following trend recorder properties are available for each pen:

Property	Description	Limits
Address	Direct address of the variable to monitor	Note 1 <i>(see page 134)</i>
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 <i>(see page 134)</i>
Minimum Value	Minimum gross value (without scale) of the device variable	Note 3 (see page 134)
Pen Color	Color of the "pen" which allows the value placed on the scale to be recorded	
Pen Label	Label used to identify the pen	

#### **Display Link**

A display link is a special graphic object which allows you to move to another graphic display by clicking it. To indicate that the object represents a link towards another display, the link's text label is underlined and the mouse cursor changes to a hand when it passes over it. This object is especially useful when the **Graphic Editor** is used in **View mode** which has no drop-down list of graphic displays.

A display link can also be used as an hypertext link to an HTML file. If you enter a URL such as Link Display Name, you can open it in a new browser window by pressing the SHIFT key while clicking the link. If you only click the link, the existing browser window is replaced by the URL.

If the Link Display Name is blank, the **label** is not displayed underlined and the object displayed becomes a simple text label.

Property	Description	Limits
Label	Label of the link	
Link Display Name	Name of the graphic display to load when the user clicks on the link, or URL of a web page	
Label Color	Color of the label	
Label Font	Font used for the label	

The table below describes the display link's properties:

## Datalogging History

A Datalogging History provides a continuous, time-based charting of the value of up to six symbols (variables) coming from the log file of the Datalogging service. A Datalogging History emulates a strip-chart recorder, with the pens on the right, and the "paper" moving from right to left. A vertical scale can be shown on the left side of the chart for showing the range of the values being recorded, and a horizontal scale can be shown below the chart for showing the time span of the chart.

**NOTE:** In order to plot the Datalogging History, you must select the Timestamp option in the Datalogging Service *(see Web Designer for TSX ETG 30••, User Manual)* configuration window.

In order to make it easier to set this object's many properties, a Customizer is provided. All properties (except Name) are set with its Customizer, not with the **Graphic Editor's** Property Sheet.

3 buttons are available in edition and animation mode:

- Reload: the Datalogging History object is a static widget. This button enables to refresh the value used to build the chart.
- +: zoom on the trend. It decreases the time scale in order to have a better vision of a part of the trend.
- -: zoom out on the trend. It increases the time scale in order to have a larger vision of the trend.

If you place the mouse cursor on a point of the trend, a tooltip appears displaying the exact value at that point. Stay pressed and rollover several points to display the tooltips of all of those points.

Releasing the mouse button and rolling over any point will cleanup existing tooltips and display a new one.

Right click on it to make it disappear.

The following table describes properties for the Datalogging History. Properties available for each pen are described in the next table:

Property	Description	Limits
Name	The name for the graphic object	
Background	The background color for the graphic object	
Label	The label to be displayed as part of the graphic object	
Label Color	The color for the label	
Label Font	The font for the label	
Major Scale Divisions	The number of major (labeled) scale divisions	0 to 100
Minor Scale Divisions	The number of minor (unlabeled) scale divisions	0 to 100
Scale Color	The color for the scale and its labels	
Scale Font	The font for scale labels	
Scale Precision	The number of fractional digits to be shown for scale labels (Set to -1 to use a general exponential format.)	-1 to 6
Maximum EU Value	The maximum value, in engineering units, of the symbol (variable)	
Minimum EU Value	The minimum value, in engineering units, of the symbol (variable)	
Update Period	The update interval (in seconds) for the chart	0.5 to 120
Time Scale Divisions	The number of horizontal scale divisions	0 to 6
Chart Background	The color for the chart area	
Grid Color	The color of the grid drawn in the chart area	
Vertical Grid Divisions	The number of vertical divisions for the grid	0 to 100
Border Width	The width (in pixels) for the graphic object's border	0 to 32
Border Color	The color for the graphic object's border	

Property	Description	Limits
Name of the CSV file	<ul> <li>The name of the CSV file used to build the trend. Location:</li> <li>Default (no path): the file is located on the FLASH memory.</li> <li>/CFA00/USERDATA/TABLEx: the file is located on the CF card.</li> <li>/USBHD/00/USERDATA/TABLEx: the file is located on the USB memory.</li> <li>/RAMDISK/USERDATA/TABLEx: the file is located on the saved RAM.</li> </ul>	
	(see Web Designer for TSX ETG 30••, User Manual).	
Address	The name of a symbol (variable) to monitor.	
Data Type	The data type of the symbol (variable). Note: the data type must be numerical.	
Maximum PLC Value	The maximum raw (unscaled) value of the symbol (variable) in the PLC.	Note 3 (see page 134)
Minimum PLC Value	The minimum raw (unscaled) value of the symbol (variable) in the PLC.	Note 3 <i>(see page 134)</i>
Pen Color	The color of the "pen" used to record the scaled value.	
Pen Label	The label used to identify the pen.	

These Datalogging History properties are available for each pen:

# **Extended Graphic Objects**

#### Introduction

The extended graphic objects available in the Graphic Editor are designed to help you to create graphic displays imitating advanced graphic display panels. All the data control and monitoring objects have integrated communication functions and are designed as standalone graphic objects.

Be aware, however, that if communication to the device linked to the graphic object is lost, the object becomes inoperative without the end device's knowledge.

# **WARNING**

### UNINTENDED EQUIPMENT OPERATION

Do not use graphic objects in situations where loss of communication to the module can affect human or material integrity. Graphic objects are not intended for use in critical machine functions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

For example, say you have programmed a pushbutton object to jog a motor when the button is depressed and to stop jogging when the button is released. If communications are lost while the button is depressed, the motor will continue to jog even when the button is released. Graphic objects should not be used to control situations such as this unless other interlock methods are installed in the system.

In addition, to help clients who wish to insert several simple applets into a single HTML page, all objects in the Graphic Editor exist in the form of applets. When combined with the *LiveBeanApplet*, the graphic objects in the Graphic Editor can be used in the same way as the *LiveLabelApplet*.

## **ASCII Text Editor**

The ASCII text editor is based on the message display graphic element. It enables new text to be entered.

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 <i>(see page 134)</i>
Max. Text Length	Maximum length of the text	
Text Color	Color of the text	

The properties of the ASCII text editor are as follows:

Property	Description	Limits
Text Font	Font of the text	
Swap Bytes	False if the target byte order is the same as that of the PC	
Value	The text itself	

## **Bar Graph**

A bar graph gives an analog representation of the value of a variable in a device. It draws a vertical bar whose length is proportional to the value and represents a percentage of its range in physical units.

The properties of the bar graph are as follows:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Maximum EU Value	Maximum value of the variable in physical units	
Minimum EU Value	Minimum value of the variable in physical units	
Maximum Value	Maximum gross value (without scale) of the device variable	Note 3 (see page 134)
Minimum Value	Minimum gross value (without scale) of the variable in the device	Note 3 (see page 134)
Bar Background	Background color of the indicator bar	
Bar Color	Color of the indicator bar (if the scale value is within the High/Low range)	
High High Limit Value	Value of the "High High" limit expressed in physical units	
High High Limit Color	Color of the indicator bar if the scale value is greater than the "High High" limit	
High Limit Value	Value of the "High" limit expressed in physical units	

Property	Description	Limits
High Limit Color	Color of the indicator bar if the scale value is greater than the "High" limit.	
Low Limit Value	Value of the "Low" limit expressed in physical units	
Low Limit Color	Color of the indicator bar if the scale value is less than the "Low" limit	
Low Low Limit Value	Value of the "Low Low" limit expressed in physical units	
Low Low Limit Color	Color of the indicator bar if the scale value is less than the "Low Low" limit	
Limit Deadband	Neutral range (as a percentage of the EU range) to apply to verification of the High/Low limit	0 to 10
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated gross input value (without scale) for testing the graphic object	Note 3 <i>(see page 134)</i>

## Bitmap

The bitmap interface graphic element displays a static bitmap on the screen.

The properties of the bitmap interface graphic element are as follows:

Property	Description	Limits
Name	Name of the graphic object	
Background	Graphic object background color	Note 1 (see page 134)
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Border Width	Width (in pixels) of the graphic object border	
Border Color	Color of the graphic object border	
Bitmap Choices	File names of custom bitmaps to display Refer to the next paragrah for information on adding images into the module.	

## Adding Images

You can add images into the module in one of the following way:

- Add your images into the *images.zip* file (path: /NAND/FLASH1/wwwroot).
- Create a directory into the module (i.e. /NAND/FLASH1/wwwroot/bitmaps). Copy your images into this directory. In this case, you need to specify the path of the images you want to use (i.e. /NAND/FLASH1/wwwroot/bitmaps/key.gif).

Step	Action
1	Create an <i>images</i> folder on your PC.
2	Copy the images you want to use in this folder.
3	Import the <i>user.jar</i> file from the TSX ETG 30•• to the PC (path: /NAND/FLASH1/wwwroot/classes) using a FTP client.
4	Open the user.jar file using a file archiver.
5	Drag and drop the <i>images</i> folder in the <i>user.jar</i> file. Make sure the relative path of the image files is 'images/'.
6	Transfer the user.jar file back to the module using a FTP client.

## **Generic Bitmap**

The generic Bitmap interface graphic element can display a static bitmap for each separate value of a variable. It can be used to display dynamic animations, such as the variation in level of a reservoir.

The properties of the generic Bitmap interface graphic element are as follows:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	Note 1 (see page 134)
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Bitmap Choices	File names of custom bitmaps to display Refer to the previous paragrah for information on adding images into the module.	

Property	Description	Limits
Border Width	Width (in pixels) of the graphic object border	
Border Color	Color of the graphic object border	
Value	Simulated starting value for testing the behavior of the graphic object	

#### **Graphic Link**

A graphic link is a special graphic object that moves to another graphic display when you click it with the mouse. Graphic links can also be recognized by their underlined labels, and by the fact that the mouse cursor changes to a hand when it passes over them. They are especially useful when the Graphic Editor is used in Display mode, in which there is no pull-down list of graphic displays.

A graphic link can also be used as a hypertext link to an HTML file. If you enter a URL such as **Link Display Name**, you can open the URL in a new browser window by pressing the SHIFT key while clicking on the link. If you only click the link, the URL will open in the existing browser window.

If the **Link Display Name** is not filled in, the label will not be underlined and the object displayed becomes a simple text label.

The properties of the graphic link are as follows:

Property	Description	Limits
Label	Label of the link	
Link Display Name	Name of the graphic display to load when the user clicks on the link, or URL of a Web page	
Label Color	Color of the label	
Label Font	Font used for the label	
Bitmap Choices	Name of the bitmap file to be clicked on	

## Indicator Light

The indicator light displays the value of a variable in a device. The input value of 0 is equal to OFF, and any value other than 0 is equal to ON. If the **Flash Interval** property is set to a positive value, the indicator light will flash when the input value is equal to ON. There is one bitmap for the ON state and another for the OFF state.

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 3 <i>(see page 134)</i>
Data Type	Variable data type	Note 2 <i>(see page 134)</i>
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
OFF Word	Text to be displayed when the input value is OFF	
OFF Bitmap Choice	Indicator bitmap when the OFF word is displayed	
OFF Word Color	Color of the OFF word text	
OFF Word Font	Font of the OFF word text	
ON Word	Text to be displayed when the input value is ON	
ON Bitmap Choice	Indicator bitmap when the ON word is displayed	
ON Word Color	Color of the ON word font	
ON Word Font	Font of the ON word text	
Flash Interval	The flashing time for the indicator light (expressed in milliseconds) when the input value is ON. Set to 0 for no flashing.	200 to 2,000
Input Inverted	On TRUE, inverts the input value. (The indicator displays the OFF word when the input value is ON.)	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated input value for testing the graphic object	Note 3 (see page 134)

The properties of the indicator light are as follows:

#### Motor

The Motor graphic interface element displays the value of a variable in a device. The input value of 0 is equal to OFF, the value 1 is equal to ON and other values are equal to DEFAULT. These three states are represented by different bitmaps.

The properties of the Motor graphic interface element are as follows:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 <i>(see page 134)</i>
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
OFF Word	Text to be displayed when the input value is OFF	
OFF Bitmap Choice	Motor bitmap when the OFF word is displayed	
OFF Word Color	Color of the OFF word text	
OFF Word Font	Font of the OFF word text	
ON Word	Text to be displayed when the input value is ON	
ON Bitmap Choice	Motor bitmap when the ON word is displayed	
ON Word Color	Color of the ON word font	
ON Word Font	Font of the ON word text	
DEFAULT Word	Text to be displayed when the input value is ON	
DEFAULT Bitmap Choice	Motor bitmap when the DEFAULT word is displayed	
DEFAULT Word Color	Color of the DEFAULT word font	
DEFAULT Word Font	Font of the DEFAULT word text	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated input value for testing the graphic object	Note 3 (see page 134)

A pipe displays the value of a variable in a device that has two possible states. The input value of 0 is equal to OFF, and any value other than 0 is equal to ON. There is one bitmap for the ON state and another for the OFF state.

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
OFF Word	Text to be displayed when the input value is OFF	
OFF Bitmap Choice	Pipe bitmap when the OFF word is displayed	
OFF Word Color	Color of the OFF word text	
OFF Word Font	Font of the OFF word text	
ON Word	Text to be displayed when the input value is ON	
ON Bitmap Choice	Pipe bitmap when the ON word is displayed	
ON Word Color	Color of the ON word font	
ON Word Font	Font of the ON word text	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated input value for testing the graphic object	Note 3 (see page 134)

The properties of the pipe are as follows:

## **Push button**

When activated with the mouse, a push button allows the user to send one or more preset values to a device.

The properties of the push button are as follows:

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 3 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Values	Values to send to the device	Note 4 (see page 134)
Reset Values	Values to send to the device once the reset delay has expired. If no reset value is given, the reset will not take place.	
Reset Delay	Delay (in milliseconds) that the push button must comply with between sending the values to the device and sending the reset values.	0-2000
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
Button Label	Button label text	
Button Label Color	Color used for the button label	
Button Label Font	Font used for the button label	
OFF Bitmap Choice	Button bitmap when the OFF state is displayed	
ON Bitmap Choice	Button bitmap when the ON state is displayed	
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	

## Distributor

A distributor displays the value of a variable in a device that has two possible states. The input value of 0 is equal to OFF, and any value other than 0 is equal to ON. There is one bitmap for the ON state and another for the OFF state.

Property	Description	Limits
Name	Name of the graphic object	
Address	Direct address of the variable to monitor	Note 1 (see page 134)
Data Type	Variable data type	Note 2 (see page 134)
Background	Graphic object background color	
Label	Label to be displayed as part of the graphic object	
Label Color	Color of the label	
Label Font	Font used for the label	
OFF Word	Text to be displayed when the input value is OFF	
OFF Bitmap Choice	Distributor bitmap when the OFF word is displayed	
OFF Word Color	Color of the OFF word text	
OFF Word Font	Font of the OFF word text	
ON Word	Text to be displayed when the input value is ON	
ON Bitmap Choice	Distributor bitmap when the ON word is displayed	
ON Word Color	Color of the ON word font	
ON Word Font	Font of the ON word text	
Flash Interval	The flashing time for the indicator light (expressed in milliseconds) when the input value is ON. Set to 0 for no flashing.	200 to 2,000
Border Width	Width (in pixels) of the graphic object border	0 to 32
Border Color	Color of the graphic object border	
Value	Simulated input value for testing the graphic object	Note 3 (see page 134)

The properties of the distributor are as follows:

## Notes

The notes relating to this section are as follows:

1.	The Data Type property must correspond exactly to the actual data type of the variable. If the Address property is the direct address of a binary PLC reference (reference 0x/1x Quantum for example), the Data Type property must be set to Coil for outputs or Discrete Input for discrete inputs.	
2.	The various values of the Data Type property have the following meanings:	
	Туре	Signification
	COIL	output bit (Boolean)
	DISCRETE INPUT	input bit (Boolean)
	REGISTER	16-bit signed integer
	INT32	32-bit signed integer
	INT32SWAP	32-bit signed integer with least significant and most significant words inverted
	INPUT REGISTER	16-bit signed integer for analog input
3.	The limits of the Maximum PLC Value and Minimum PLC Value properties are the natural limits of the configured Data Type property.	
4.	For a push button you must specify at least one value. If several values are entered, they will be assigned to an address table starting with the direct address indicated.	
5.	For the applet to display a numerical data value instead of a label, specify parameters in the HTML code as follows: name = "label" value = "\$data\$".	

# 7.3 Creating Custom Web Pages

## Scope of this Section

This part shows you how to create custom Web pages for your website using FrontPage 2000 or Microsoft Expression web.

**NOTE:** For other ways to create custom pages, refer to the *FactoryCast HMI Gateway TSX ETG 30•• Product Range user manual.* 

## What's in this Section?

This section contains the following topics:

Торіс	
Installing FactoryCast Extension for Microsoft FrontPage	
Installing FactoryCast Extension for Microsoft Expression Web	
Inserting a LiveBeanApplet with FrontPage or Expression Web	
Inserting a LiveLabelApplet with FrontPage or Expression Web	
Internet Explorer 7 compatibility	

# Installing FactoryCast Extension for Microsoft FrontPage

#### Overview

This section describes how to install/remove the FactoryCast Extension for Microsoft FrontPage 2000.

### Installing FactoryCast

During the installation of Web Designer, if FrontPage 2000 has been installed on the same PC, then the FactoryCast Extension for FrontPage 2000 is automatically installed as a FrontPage "Macro File". If this is the case, then proceed to the next section, which provides instructions for adding the Extension to FrontPage's menu.

However, if FrontPage 2000 is installed after Web Designer has been installed, then the Extension can be installed by either re-installing Web Designer or manually copying the macro file to FrontPage's macro folder. For manual installation, after installing FrontPage 2000, the following will install the Extension:

Copy the file *Microsoft FrontPage.fpm* from CD-ROM to the folder %USERPROFILE%\Application Data\Microsoft\FrontPage\Macros (create the final *Macros'* folder, if it does not already exist).

## Adding FactoryCast Extension

To add the FactoryCast Extension to the FrontPage Insert menu, do the following.

Step	Action
1	Start FrontPage 2000.
2	Click Customize on the Tools menu.
3	Click the Commands tab, and then select Macros from the Categories list.



Step	Action
6	Click Modify Selection again, and then choose Assign Macro.
	Macro
	Macro Name:
	FactoryCast_Applet OK
	FacioryCast_Appliet
	Macro In Microsoft FrontPage
7	Choose FactoryCast_Applet from the list, and then click OK.
8	Click <b>Close</b> .
	The FactoryCast Applet command is added to the insert menu.
	Microsoft FrontPage
	Views Symbol.
	Component
	Database
	Page Politi ► Advanced ►
	FactoryCast Applet
	Policiers <u>Picture</u> → <u>Hyperlink</u> ctrl+K
	Renots
	Navigatio
	A S m
	For Help, press F1

## **Removing FactoryCast Extension**

To remove the FactoryCast Extension from the FrontPage menu, do the following.

Step	Action
1	In FrontPage, click Customize on the Tools menu.
2	Click the Insert menu, and then select FactoryCast Applet.
3	Right click, and then select <b>Delete</b> from the popup menu.

## **Editing Applets**

There are two ways to edit an applet that has been inserted into your Web page. First, you can double-click on the object and make changes via dialog boxes. Or you can switch to the HTML editor in FrontPage and do your editing in this environment. It is suggested you edit via the first approach unless you are comfortable programming in the HTML language used to build Web pages.

# Installing FactoryCast Extension for Microsoft Expression Web

#### Overview

This section describes how to install/remove the FactoryCast Extension for Microsoft Expression Web.

## Installing FactoryCast

During the installation of Web Designer, if Expression Web has been installed on the same PC, then the FactoryCast Extension for Expression Web is automatically installed as a Expression Web "Macro File". If this is the case, then proceed to the next section, which provides instructions for adding the Extension to the menu of Expression Web.

However, if Expression Web is installed after Web Designer has been installed, then the Extension can be installed by either re-installing Web Designer or manually copying the macro file to the macro folder of Expression Web. For manual installation, after installing Microsoft Expression Web, the following will install the Extension:

Copy the file *Microsoft Expression Web.wdmacro* from CD-ROM to the folder %USERPROFILE%\Application Data\Microsoft\Expression\Web Designer\Macros (create the final 'Macros' folder, if it does not already exist).

#### Adding FactoryCast Extension

To add the FactoryCast Extension to the Expression Web **Insert** menu, do the following.

Step	Action
1	Start Microsoft Expression Web.
2	Click Customize on the Tools menu.
3	Click the Commands tab, and then select Macros from the Categories list.
4	Drag and drop the entry <b>Custom Menu Item</b> from the <b>Commands</b> list to the <b>Insert</b> menu, beneath the <b>Advanced</b> command. (The <b>Insert</b> menu will automatically drop down when you drag over it.)
5	Click <b>Modify Selection</b> , change the name to <b>FactoryCast Applet</b> , and then press ENTER key.
6	Click Modify Selection again, and then choose Assign Macro.
7	Choose FactoryCast_Applet from the list, and then click OK.
8	Click Close. The FactoryCast Applet command is added to the Insert menu.

## **Removing FactoryCast Extension**

To remove the FactoryCast Extension from the Expression Web menu, do the following.

Step	Action
1	In Expression Web, click Customize on the Tools menu.
2	Click the Insert menu, and then select FactoryCast Applet.
3	Right click, and then select <b>Delete</b> from the popup menu.

## **Editing Applets**

There are two ways to edit an applet that has been inserted into your Web page. First, you can double-click on the object and make changes via dialog boxes. Or you can switch to the HTML editor in Expression Web and do your editing in this environment. It is suggested you edit via the first approach unless you are comfortable programming in the HTML language used to build Web pages.

## Inserting a LiveBeanApplet with FrontPage or Expression Web

#### Overview

The *LiveBeanApplet* applet is included one time for each symbol (variable) or direct address monitored/controlled on the Web page. For instance, if you are monitoring three symbols (variables), you would include the applet three times. *LiveBeanApplet* allows any graphic object/Java Bean that was created with the Graphic Editor to be included on a Web page as a separate applet.

.Any graphic object that has been saved as part of a Graphic Editor graphic display can be retrieved from the graphic file and presented by the applet.Before any beans are inserted into a Web page, the special applet called *LiveBeanMgrApplet* must be inserted into the server.

**NOTE:** Prior to inserting a *LiveBeanApplet* into a Web page, you must create a JavaBeans library using the Graphic Editor. Generally a user will create a JavaBeans library that has one instance of every object that they would like to use in a Web page. Think of this library as a set of templates that are copied to and customized for your Web pages. For example a library may have one analog meter, one rotary selector, and one push button. Multiple instances of each bean can then be added to a Web page, each with a set of unique parameters such as an address.

## LiveBeanMgrApplet

The *LiveBeanMgrApplet* allows the Web page to display dynamic data from the controller. This applet must be included once on the page if any instances of *LiveBeanApplet* are included in the page.

The *LiveBeanMgrApplet* can be included on a Web page in two possible forms:

- Invisible applet—if the Web page is used only to monitor PLC values, then no input is needed from the user
- Icon of a key—if the Web page is used both to send new values and to monitor values to the PLC, then input is needed from the user in order to send new values.

## Inserting a LiveBeanApplet

Step	Action
1	In FrontPage or Expression Web, select <b>Tools</b> $\rightarrow$ <b>Macros</b> $\rightarrow$ <b>Macros</b> .
2	Select the macro that corresponds to the target.
3	Click Run.
4	Select the LiveBeanMgrApplet, then click <b>OK</b> .
	Microsoft FrontPage         File       Cit       View       Inset       Figmat       Lools       Table       Figmat       Tools       Tools

To insert a *LiveBeanApplet*, follow the steps below:
Step	Action
5	Configure the Mode and Auto-Login parameters, then click <b>OK</b> .
	Microsoft FrontPage
	Eile Edit View Insert Format Iools Table Frames Window 2
	│D ▼ 📂 ▼ 🖶 ७│ 🕮 📾 🕸 🦃 🖉 📴 📾 🛷 1 🐃 ™ 🗃 🔜 🐼 8│ ¶ 👻
	Target" Applets
	Targef applets available:
	Livel Parameters:
	LiveE AUTO_LOGIN. TRUE
	Gde,
	4
	Navigation
	Press F1 for Help
6	A window opens, showing the Java code which will be inserted in your HTML document.
	S Microsoft FrontPage
	Eile Edit View Insert Førmat Iools Table Frames Window 2
	FactoryCast Applet LiveBeanMgrApplet
	<pre>codebase= // " codebase= // " approximation of access (CDE is a classes / codebase // CDE is a classes / CDE is a classes</pre>
	Widgets.jar, images.zip"
	code="com.schneiderautomation.gde.LiveBeanNgrApplet" width="32" height="32">
	<param name="MODE" value="READWRITE"/> <param name="AUTO_LOGIN" value="TRUE"/>
	Insert
	Newgation M
	Click <b>insert</b> to complete insertion of this applet.
	while editing, the applet will only be displayed on your downloaded Web page if
	you have set the Mode parameter to <b>ReadWrite</b> . (Read/Write). It will appear in
	the form of a key when you visualize it with your browser. On the other hand, if
	the ReadOnly Mode is set (ReadOnly), the width and height of the applet will be
	set to 0 and will not be visible in your browser. To find out more about the
	operation of the Mode parameter, refer to the FactoryCast HMI Setup Manual.

Step	Action
7	Select the <i>LiveBeanApplet</i> in the Target applet selection window, then click <b>OK</b> .
	Microsoft FrontPage
	Eile Edit View Insert Format Tools Table Erames Window Help
	Available FactoryCast Applets
	Appet Class Description OK
	LiveLabelMgrApplet Live Label Manager Applet Cancel
	LiveTableApplet LiveTable Applet
	LiveBeanMgrApplet Live BeanManager Applet
	GdeApplet Graphic Data Applet
	× ×
	Normal HTML Preview 4
	For Help, press F1
8	Enter the name of a library and the name of the "bean" you wish to display in it.
	If you do not need to customize the bean properties (the address, for example),
	FactoryCast Applet
	Apple Parameters:
	Library:
	LiveL BEAN: Digital indicator 2 Cancel
	LiveT BACKGRND. LT_GRAY
	Gde/ ONONE:
	Object type Select an object type Edit

Step	Action		
9	In general, you will at least need to customize the Address property of your beans. Once you have entered the names of the library and bean, select the object type in the Object Type dialog box.		
	FactoryCast LiveBeanApplet		
	Parameters:		
	LIBRARY: Library.		
	BEAN: Digital indicator 2		
	BACKGRND: LT_GRAY		
	Digital indicator		
	Click <b>Edit</b> when you have finished.		
10	In the Edit window, only change parameters that are specific to this bean, such as the address. All other parameters will be set to the same values as for the bean saved in your library. Click <b>OK</b> when you have finished.		
	Ele         Edit         View         Insert         Format         Tools         Table         Frames         Window         2		
	Properties (Digital indicator)		
	Address 1000 Maximum PLC Value		
	Data Type         INT         Minimum PLC Value           Label         Time         High High Limit Value		
	Value format     DEC     High Limit Value       Value Precision     1     Low Limit Value		
	Units         Sec         Low Low Limit Value           Maximum EU value         Limit Deadband%i		
	Minimum EU value Border Width		
	OK Cancel		
	Normal HTML Preview		
	Press F1 for Help		

Step	Action
11	Click <b>OK</b> . A window opens, showing the Java code which will be inserted in your HTML document. Click <b>Insert</b> to complete the insertion of the applet.
	FactoryCast LiveBeanApplet <applet< td="">         codebase="/"         archive="classes.SAComm.jar,classes/GDE.jar,classes/         Widgets.jar,images.zip"         code="com.schneiderautomation.gde.LiveBeanApplet"         width="180" height="160" &gt;         <param name="EACKGRND" value="LT_GRAY"/> <param name="EACKGRND" value="LT_GRAY"/> <param name="EACKGRND" value="LT_GRAY"/> <param name="EACKGRND" value="LT_GRAY"/> <param name="EBCAKGRND" value="LT_GRAY"/>         (PARAM name="EBCAKGRND" value="LT_GRAY"&gt;         (PARAM name="EBCAKGRND" value="LT_GRAY"&gt;         (PARAM name="EBCAKGRND" value="LT_GRAY"&gt;         (PARAM name="EBCAKGRND" value="LT_GRAY"      &gt;</applet<>
	Cancel
12	Contracted inserting instances of <i>LiveDeanApplet</i> in your web page. Once you have inserted the last applet, click <b>Cancel</b> in the Web Designer applet selection window to return to editing your Web page.         Image: Image
	View Page Page Folders Reports Navigation W Normal HTML Preview M Preview M Prev
	Navigation     Normal     HTML     Preview       Press F1 for Help     Image: Contract of the second (s) at 28.8     Image: Contract of the second (s) at 28.8

Step	Action
13	Save your custom Web page.
14	Transfer the custom Web page to the Web server.
15	Test the application.

## LiveBeanApplet Parameters

The *LiveBeanApplet* uses parameters that allow you to specify the graphic object to be presented by the applet and to set the applet's background color.

The applet's parameters and their meanings are shown below.

Parameter	Defines
LIBRARY	The name of the graphic display which contains the graphic object that is to be presented by the applet (This will be the same name that was used when the graphic display was saved with the <b>Graphic Editor</b> ). <b>This parameter is required.</b>
BEAN	The name of the graphic object that is to be retrieved from the graphic display specified by the LIBRARY parameter (This will be the name that appears as the 'Name' property of the graphic object). This parameter is required.
BACKGRND	The background color for the applet. Acceptable values are WHITE, LT_GRAY, GRAY, DK_GRAY, BLACK, RED, PINK, ORANGE, YELLOW, GREEN, MAGENTA, CYAN, and BLUE. Also, a RGB color value can be entered using the format "0xRRGGBB" where RR, GG, and BB are the hexadecimal values for the red, green, and blue components, respectively. This parameter is optional but is normally set to match the color of the HTML page.

In addition to the above parameters, the <APPLET> tag for a *LiveBeanApplet* must include **width** and **height** attributes. Normally, the size of a *LiveBeanApplet* is set to match the size of the graphic object that it is presenting. To get the size of a graphic object, select the object while the **Graphic Editor** is in editing mode. The selected object's name and size are shown in the **Information Area** at the top of the **Graphic Editor** applet.

## Inserting a LiveLabelApplet with FrontPage or Expression Web

## Overview

Use one *LiveLabelApplet* applet for every symbol (variable) or direct-address monitored on the Web page used. For example, if you are monitoring three symbols (variables), you would include the applet three times.

Before any live labels are inserted into a Web page, the special applet called *LiveLabelMgrApplet* must be inserted into the page. The *LiveLabelMgrApplet* allows the Web page to display dynamic data from the controller. This applet must be included once on the page if any instances of *LiveLabelApplet* are included on the page.

**NOTE:** However, if a Web page contains both *LiveLabelApplet* and *LiveBeanApplet*, then that page must contain a single instance of *LiveBeanMgrApplet*, not *LiveLabelMgrApplet*. *LiveBeanMgrApplet* supports both *LiveLabelApplet* and *LiveBeanApplet*, while *LiveLabelMgrApplet* supports only *LiveLabelApplet*.)

## Inserting a LiveLabelApplet

Step Action 1 In FrontPage or Expression Web, select **Tools**  $\rightarrow$  **Macros**. 2 Select the macro that corresponds to the target. 3 Click Run. Select the LiveLabelMgrApplet associated with your target, then click OK. 4 FactoryCast Applets X Available Applets: OK Applet Class Description 42 LiveLabelMgrApplet Live Label Manager Applet LiveLabelApplet Live Label Applet Cancel LiveTableApplet Live Table Applet LiveBeanMgrApplet Live Bean Manager Applet LiveBeanApplet Live Bean Applet GdeApplet Graphic Data Applet Note: LiveLabelMgrApplet is a special applet, which should only be inserted into your Web page once. Although a gray box containing a blue letter "J" appears on your Web page while editing, the applet will not be displayed on the Web page from the built-in server module.

To insert a *LiveLabelApplet*, follow the steps below:

2	Action	
5	Select the <i>LiveLabelApplet</i> , then click <b>OK</b> . The Parameter editing window is displayed.	
6 Enter the label parameters, then click <b>OK</b> .		
	FactoryCast LiveLabelApplet	
	Parameters:	
	Data Description	
	ADDRESS: 400001	
	DATATYPE: INT FORMAT: DEC	
	LABEL: Reg 400001 LABEL_WIDTH: 5	
	UNITS: UNITS_WIDTH: 5	
	GAIN: 1.0 BIAS: 0.0	
	ON_WORD: ON OFF_WORD: OFF	
	Colors ————————————————————————————————————	
	FOREGRND: BLACK J LABEL_ALIGN: LEFT *	
	BACKGRND: LT GRAY WILVE_ALIGN: LEFT W	
	ERROR_COLOR: MAGENTA   UNITS_ALIGN: LEFT	
	Font	
	FONT_NAME: SANSSERIF FONT_BOLD	
	FONT_SIZE: 12 FONT_ITALIC	
	OK Cancel	

Step	Action
7	A window opens containing the HTML code that will be inserted into your HTML document. Click Insert to complete the insertion of the applet.
	Cancel
8	Continue to add additional instances of <i>LiveLabelApplet</i> to your Web page. Once the last applet has been inserted, click <b>Cancel</b> in the applet selection window to return to editing your Web page.

## LiveLabelApplet Parameters

The applet's parameters, their meaning, and the default values are shown below:

Parameter	Defines		With Default Value of
LABEL	A text label to identify the data item.		No label
UNITS	A text label to identify the value's engineering units.		No units displayed
ADDRESS	The name of Concept/PL7/Unity Pro symbol (variable) or Quantum/Premium/Micro direct address.		None
DATATYPE	The data type of address. Acceptable value	of the symbol (variable) or direct ues for this parameter are:	UNDEFINED
	UNDEFINED	No data type specified	
	SHORT	8-bit signed integer	
	USHORT	8-bit unsigned integer	
	INT	16-bit signed integer	
	UINT	16-bit unsigned integer	
	DINT	32-bit signed integer	
	UDINT	32-bit unsigned integer	
	REAL	32-bit IEEE floating point	
	TIME	32-bit unsigned integer (in ms)	
	BOOL	1-bit discrete (boolean)	
	NOTES: If the <i>J</i> address, and th specified, a defa REAL based on used. If ADDRESS is reference (Qua must be set to I BOOL only for <i>G</i> If the ADDRES Concept, PL7 of DATATYPE part is specified for <i>J</i> match its actual type for PL7 PC	ADDRESS parameter is a direct the DATATYPE parameter is not ault DATATYPE (BOOL,INT,DINT or the implied size of the data value) is a direct address for a discrete PLC ntum 0x/1x reference), DATATYPE BOOL. DATATYPE may be set to discrete PLC references. S parameter is the name of a or Unity Pro symbol (variable), the rameter is optional. If the DATATYPE a symbol (variable), it must exactly I data type,TIME is not a valid data emium	

Parameter	Defines		With Default Value of
FORMAT	The display format for the value. Acceptable values for this parameter are:		DEC for most data types
	DEC	decimal	TIME for data type
	HEX	hexadecimal	BOOL for data type
	BIN	binary	BOOL
	ASCII	bytes displayed as ASCII characters	
	TIME	'day_hr_min_sec_ms'	
	BOOL	ON_WORD or OFF_WORD (see below)	
	<b>NOTE:</b> If DATA than DEC will g cannot be conv	TYPE is REAL, a FORMAT other ive unpredictable results if the value erted to an integer.	
GAIN	The gain (multipy value to engine	plier) used for scaling the retrieved ering units.	1.0
	NOTE: Scaling BIAS is set and Linear scaling is SCALED_VAL	is to be performed only if GAIN or I FORMAT is DEC. s performed by the formula: JE=GAINxRAW_VALUE+BIAS	
BIAS	The bias (offset to engineering	0.0	
ON_WORD	A text value to be shown when value is non-zero (Use only if the FORMAT is BOOL).		ON
OFF_WORD	A text value to be shown when value is zero (Use only if the FORMAT is BOOL).		OFF
FOREGRND	Foreground color of the applet. Acceptable values are: WHITE, LT_GRAY, DK_GRAY, BLACK, RED, PINK, ORANGE, YELLOW, GREEN, MAGENTA, CYAN, and BLUE Also, a RGB color value can be entered using the format "0xRRGGBB" where RR, GG, and BB are the hexadecimal values for the red, green, and blue components, respectively.		BLACK
BACKGRND	Background co For acceptable	lor for the applet. values, see FOREGRND.	LT_GRAY
ERROR_ COLOR	Foreground color retrieve the value For acceptable	or of the VALUE field when unable to ue from the PLC. values, see FOREGRND.	MAGENTA

Parameter	Defines	With Default Value of
LABEL_ ALIGN	Alignment of the text in the LABEL field, if the width of the field is greater than the length of the text. Acceptable values are: LEFT, CENTER, and RIGHT.	LEFT
VALUE_ ALIGN	Alignment of the text in the VALUE field, if the width of the field is greater than the length of the text. Acceptable values are: LEFT, CENTER, and RIGHT.	LEFT
UNITS_ ALIGN	Alignment of the text in the UNITS field, if the width of the field is greater than the length of the text. Acceptable values are: LEFT, CENTER, and RIGHT.	LEFT
FONT_ NAME	Name of the font used by the applet. Acceptable values are: SERIF, SANSSERIF, and MONOSPACE.	SANSSERIF
FONT_ BOLD	If set, displays all text in the applet as bold. Acceptable values are: TRUE and FALSE.	FALSE
FONT_ ITALIC	If set, displays all text in the applet in italics. Acceptable values are: TRUE and FALSE.	FALSE
FONT_SIZE	Sets the point size of the font used by the applet.	12
LABEL_ WIDTH	The width of the LABEL field.	
UNITS_ WIDTH	The width of the UNITS field.	

## Internet Explorer 7 compatibility

## Presentation

Because of an Internet Explorer 7 limitation, it is recommended for this browser to manually insert the widgets in the pages using a Javascript provided on the CD-ROM (*Applets.js*).

## 7.4 PLC Program Viewer

## **PLC Program Viewer**

## Presentation

The PLC program viewer feature enables you to visualize and monitor UnityPro programs in run mode using a Web Designer. The PLC programs are displayed and animated as they are in UnityPro

PLC programs developed in any languages supported by UnityPro can be visualized:

- Ladder (LD)
- Instruction List (IL)
- Function Block Diagram (FBD)
- Structured Text (ST)
- Sequential Function Chart (SFC)

#### Accessing the PLC Program Viewer

Step	Action
1	Double click the PLC ( <i>Devices</i> directory) you want to monitor in the Web Designer navigator.
2	Click the PLC Programs tab.

## Importing PLC Programs

The following procedure shows you how to import PLC programs from UnityPro to Web Designer.

tep	Action	
1	Click <b>Import</b> on the right side of the PLC Progra <b>Result:</b> the Open window appears.	am window.
	Open	
	Look in: 🔯 Desktop 💽 🖛 🖻 🖄	T
	My documents My computer My documents My documents My documents My documents My computer My documents My documents My computer My documents My documents My computer My documents My documents My computer My documents My computer My documents My computer My documents My computer My documents My documents My documents My computer My documents My documents My computer My documents My computer My computer My computer	
	File name:         I         I           Network         places         Type offiles         *.xef         I	Open Cancel

Step	Action
2	Select the UnityPro file (.XEF) containing PLC Programs data. Click <b>Open</b> . <b>Result:</b> the Import PLC Programs window appears.
	Import of PLC Programs
	Import of selected PLC Programs
	Actions           Select All         Unselect All
	Application File C:\UnityPro\Process.stu
3	<ul> <li>Select the sections of the PLC program you want to monitor using the checkbox.</li> <li>Click Browse to select the STU or .XVM file associated to the .XEF for variables animation.</li> <li>Note: It is advised to import from .XVM for the import to be faster. As some elements are not available in the .XVM, a STU could be required to complete the import.</li> </ul>
	Click <b>Import</b> . <b>Result:</b> the sections of the PLC program selected appear in the navigation tree of the PLC Program tab.

## Accessing an Animated PLC Program

Step	Action
1	Select a target in a project.
2	<ul> <li>Click Target → Connect → Simulation (Alt + S) to switch to simulation mode or,</li> <li>click Target → Connect → Target (Alt + C) to switch to run mode.</li> </ul>
3	Extend the target directory.

Step	Action	
4	Select a device in the Devices directory.	
5	Right-click and select Open. <b>Result:</b> an Internet Explorer window in which the PLC program viewer window associated with the selected device appears.	
5	Select the PLC program section you want to visualize in the navigation tree. <b>Result:</b> the PLC program appears in the Display window.	

## **Representation and Color Convention**

The following figure shows you the PLC Program Viewer window:



- 1 Navigation tree: select the section of the PLC program you want to visualize
- 2 Display window: this zone display the animated PLC program

## Variables animation:

- Boolean are displayed in:
  - green if its value is true
  - red if its value is false
- Other types display the name or the value of the variable in yellow. Use the tool tip to see more information as the name of the variable, its type, its address and its comment.

## Links animation:

- Links connected to boolean variables are displayed in green or red depending on the value of the variable they are connected to (green if true red if false).
- Other links are displayed in black.

## SFC animation:

	initialisation of					•	• •		•
Start Robot	packaging robot								:
t# 15h_29in_3	1s_987ms		·			·			·
	L		:						:
	•		·			·			•
Data da cara da c	-		•			•			:
. Robol_drie.robo	Crunning ·		·			·			•
	step for rotation I	eft		• •	1	:	• •	1	:
Rotation						·			•
# 15h_28in_2	6s_450ms					:			:
• • • [- • •	<b>.</b>		 -			·			-

The colors used for the different elements are:

- for steps:
  - green if the step is active,
  - white if the step is inactive,
  - yellow if the activity time of the step is less than the minimum programmed time,
  - pink if the activity time of the step is greater than the minimum programmed time.
- for macro-steps:
  - when a macro-step becomes active the upper half is shown in green,
  - when the OUT step of the macro-step is active the whole of the macro-step is shown in green,
  - when the macro-step becomes inactive it is then shown in white.
- for transitions associated with a Boolean element or a simple Boolean expression:
  - green if the element or the expression is TRUE,
  - red if the element or the expression is FALSE.
- for transitions associated with a section:
  - black as long as the previous step remains inactive,
  - green if the conditions in the section are TRUE,
  - red if the conditions in the section are FALSE.

## **Tool Tip**

The tool tip function is a help bubble which is displayed when you move the cursor over a variable.

It displays information about the value of the variable only if its name is visible in the viewer.

Click on the variable to display the bubble permanently. Right click on it to make it disappear.

## Limitations

- Only PLC programs created using UnityPro 4.0 or later can be viewed.
- You can only monitor PLC programs, edition is not allowed.
- The following objects are not animated, they appear in black:
  - Objects for which the result depends on an expression
  - Function blocks without instance for which there is no information on input/output variables
  - Standard DFB (i.e. ALARM\_DIA)
  - Multiple dimension tables

## Setting Up an External Tool

## Setting Up an External Tool

## Overview

This function enables you to setup an external tool that will be used by Web Designer. For example, you can setup FrontPage to edit the files of your website.

The following part shows you how setup FrontPage to open the files of the website, however the procedure is the same if you use another software.

## Example

The following table shows how to set up a HTML editor. Here, hostname is used as an example:

Step	Action			
1	Click <b>Options</b> $\rightarrow$ <b>Configuration of an external tool</b> $\rightarrow$ <b>External tools</b> . <b>Result</b> : the setup window for external tools appears.			
	🗱 External Tools 🛛 🗶			
	Create, manage, and run configurations			
	Create a configuration that will run a program.			
	Configurations: Program Perspectives These settings associate a perspective with Program launch configurations. A different perspective may be associated with each supported launch mode, and can optionally be activated when a configuration is launched or when a breakpoint is encountered via the Debug prefer- ences. To indicate that a perspective switch should not occur, select "None".  Run : None Run : None Restore Default			
	New Delete Apply Revert			
	Run Close			

Step	Action				
2	Click <b>New</b> . <b>Result</b> : the following window appears.				
	🛃 External Tools 🛛 🗙				
	Create, manage, and run configuration				
	Configuration Name: FrontPage				
	C:\program_files\frontpage\frontpage.exe				
	Browse File System				
	Working Directory:				
	C:\workspace\WD_project\website				
	Browse File System				
	Argument				
	Variables Note: Enclose an argument containing spaces using double-quotes (").				
	New Delete Apply Revert				
	Run Close				
3	Enter a name for the external software (i.e. FrontPage).				
4	In the Location area, click Browse File System. Result: a file explorer opens.				
5	Select the path of the .exe file of the external software (i.e. C:\windows\frontpage\frontpage.exe).				
6	In the Working Directory area, click Browse File System. Result: a file explorer opens.				
7	Specify the directory that contains the files you want to open with your external tool (i.e. <i>C:\workspace\WD_project\website</i> .				

Step	Action
8	In the <b>Arguments</b> area, click <b>Variables</b> . <b>Result</b> : the Select Variables window appears.
	Select Variable
	Choose variable (? = any character, * = any string):
	build_project  build_type container_loc container_name container_path env var
	file_prompt folder_prompt project_loc project_name project_path ressource_loc
	ressource_name ressource_path selected_text string_prompt
	Edit Variables
	Configure Variable Description:
	Return the absolute file system path of the project currently being built, or the absolute file system path of the resource identified by an optional argument
	OK Cancel
9	Select the <i>ressource_loc</i> variable that returns the absolute file system path of a resource.
10	Click Apply.
11	Click Close.
12	Select a file of the website in your Web Designer navigator.
13	$\label{eq:click} \begin{array}{l} \mbox{Options} \rightarrow \mbox{Configuration of an external tool} \rightarrow \mbox{FrontPage}. \\ \mbox{Result: FrontPage opens automatically the selected file}. \end{array}$

# Changing the Workspace Directory

9

## Changing the workspace directory.

## Presentation

The workspace is the space where projects are stored. Only those located in the current workspace are accessible when open. Projects are automatically created in the current workspace. It's possible to have several workspaces and to pass from one to another.

This function enables you to change the path to the workspace.

To do this, select Change Workspace... in the Options menu.

## Formatting and Re-Starting a Module

10

## **Re-start/Format a Module**

## Introduction

Re-starting is necessary to take into account the modifications made to the application.

Formatting deletes the website on the module and restores the default website *(Website, gdt* and *rdt* directories). Formatting allows you to delete all the modifications made to the website of a module, in order to start a fresh one from a defined status. It does not modify the system configuration.

#### **Re-start the Module**

The following table shows how to re-start a module:

Step	Action
1	In the menu tree, select a module.
2	In the Target menu, click Reboot target.

## Format the Module

The following table shows how to format a module:

Step	Action			
1	In the menu tree, select a module.			
2	In the <b>Target</b> menu, click <b>Format target</b> . <b>Result</b> : the Configuration Password window appears if a configuration password has already been set. Otherwise the formatting starts.			
	Configuration Password			
	Enter the configuration password for BMX NOE 0110-NOE			
	Enter password here			
	OK Cancel			
3	Enter the configuration password and click <b>OK</b> .			

## Security

# 11

## Subject of this Chapter

This chapter explains how to manage the security for a website using firewall, access rights and password protection.

## What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Internal Security	174
External Security	175
Variable Access Security, Symbol, Direct Address	177
Changing Passwords	178

## **Internal Security**

## Overview

Web Designer provides 2 mechanisms to allow that only authorized users view and modify your data:

- password entry,
- write restrictions.

Anyone who has access to a configuration tool and to your embedded server can override your security settings and download new settings to the server. Unauthorized or incorrect changes to data may change the behavior of your application in ways that may be undesirable or even hazardous.

## A WARNING

#### UNINTENDED OPERATION

Keep strict control of access to the embedded server:

- Change passwords monthly,
- Do not use simple user names and passwords,
- Disable default passwords before commissioning the module.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

## **Password Entry**

Although you may add unprotected Web pages to the site, the default Web pages and any other pages you choose to protect can only be viewed by users who supply the correct user name and password.

## Restrictions

Restrictions are applied overall.

When you create a website and you want to protect it, you must place it in the folder called *secure*.

## **External Security**

## Overview

If your network has been configured to enable users to consult your Internet site, your security system is the same as that of an intranet site, only you have an additional security measure: a firewall.

## Architecture of a Firewall

A firewall forms a gateway between Internet and your embedded server. You can use a firewall to restrict or forbid access to your website.

A firewall can be configured to authorize network connections to a limited range of ports, or to authorize traffic to or from certain IP addresses.



## **Types of Firewalls**

There are two types of firewalls:

- Network firewalls
- Application firewalls

#### **Network Firewalls**

Network firewalls are often installed between the Internet and a single entry point to an intranet or internal protected network.

## **Application-Level Firewalls**

An application firewall works for an application, for example FTP. It intercepts all traffic sent to this application, and decides whether or not to transmit this traffic to the application. Application firewalls are located on individual host computers.

## **Firewall Configuration**

Web Designer uses HTTP, FTP and Schneider Electric Modbus application protocol (MBAP) to access embedded server pages and files. If you want viewers to be able to access your site from the Internet and your embedded server is protected by a firewall, you must configure the firewall to authorize HTTP, FTP and MBAP traffic.

Port	Protocol	Access to
21	FTP	Protected embedded server files
Higher than 1024		
80	HTTP	Web pages
502	MBAP	Operational data

## NOTE:

- The default FTP name and password are USER/USER.
- The FactoryCast client follows the "Firewall Friendly FTP" standard, RFC 1579. It issues an FTP PASV command to the FactoryCast server before any attempt to establish an FTP data connection.
- The online mode of the configuration tool is not operational if the module is protected by a firewall. The ports in this mode are dynamically assigned.

## Variable Access Security, Symbol, Direct Address

## Presentation

Users who enter the write password can only modify variables (symbols) and direct addresses which are write-enabled. When you create a Web-enabled database of variables and direct addresses, you can designate each element as read-only or write-enabled.

Unauthorized or incorrect modifications made to symbols and direct addresses may have undesirable or even dangerous effects on the behavior of your application.

## **WARNING**

## UNINTENDED EQUIPMENT OPERATION

- Carefully select the symbols and direct addresses you authorize to be modified online.
- Do not authorize online modifications of critical process variables.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

## **Changing Passwords**

## Introduction

This page enables you to modify the different user names and passwords that are used for identification.

## **Modify Passwords**

This table describes how to change passwords:

Step	Action		
1	In the browser, select the target.		
2	In the <b>Target</b> menu, click <b>Properties</b> . <b>Result</b> : the Target Properties window appears.		
3	Select Security. Result: the following window appears. Properties for TSX ETG 3000-ETG		
	Configuration Security		
	Secure HTTP Password Modify		
	Write Password Modify		
	Configurator Password Modify		
	FTP Passworc Modify		
	OK Cancel		

Step	Action	
4	Click <b>Modify</b> to change a password. Refer to next paragraph for a description of each passwords. <b>Result</b> : the Password window appears.	
	Secure HTTP Password	
	Set the secure HTTP Password	
	Type the new password and confirm it.	
	Login	
	New password	
	Confirm new password	
	OK Cancel	
5	Enter a new password and confirm it by typing it in the <b>Confirm new password</b> field. If it's an HTTP password, the login is also requested.	
6	Click <b>OK</b> in the Password window. <b>Note</b> : if you leave any fields empty during the modification, you will be asked to confirm the replacement of the current password by an empty password.	
7	Repeat actions 46 for each password to modify.	
8	Click <b>OK</b> in the Properties window of the target to close the window.	

## Function

This table shows the fields in the various windows used to modify passwords:

Window	Function
Secure HTTP Password	Required for connecting to the secure pages of the module website via a browser.
Write Password	Required to write variables in animation mode.
Configurator Password	Required to access the configuration parameters of the module.
FTP Password	Not available.
# Appendices



# Menu

# Α

#### Subject of this Chapter

This chapter describes the menus for Web Designer functions.

#### What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Menu	184
Contextual Menu	186

#### Menu

#### Overview

The following table shows the complete menu system when all functions are supported:

Menu	Sub-menu	Overview
Project	New	Create a new project: Creating a new module/device/data table/graphic page. Creating a service. Creating files and folders.
	Open project	Open an existing project.
	Close project	Close current project.
	Save	Save item modified in the project.
	Save all	Save all items modified in the project.
	Import	Importing an existing ( <i>.zip</i> ) project or converting a FactoryCast or FactoryCast HMI project.
	Export	Exporting the current project to a .zip file.
	Global transfer	Downloading all the project's modules (and all the files).
	Project Validation	Verifying the project before transfer.
	Refresh	Updating the window and menu tree.
	Properties	View/modify the project's properties (passwords, comments, etc.).
	Quit	Exit application
Edit	Undo	Cancel last action.
	Cut	Destruction of the selected object and putting it on the clipboard (the object can be a project, a module, a device, a graphic object, a file, a variable etc.).
	Сору	Copy the object to the clipboard.
	Paste	Paste the clipboard.
	Delete	Delete the selected object.
	Find	Search for text in the project.

Menu	Sub-menu	Overview
Target	Transfer	Transfer all files, either from your PC to the destination, or from the destination to your PC.
	Partial Transfer	Transfer only graphic pages, data tables and service directories, either from your PC to the destination, or from the destination to your PC.
	Connect	Connecting to the module (if the module authorizes the connection) or to the simulator.
	Disconnect	Disconnecting from the module or from the simulator
	Stop all services	Shutting down all the services (for targets using services).
	Start all services	Starting all the services (for targets using services).
	Site Explorer	Display a view of the website in the window on the bottom.
	Reboot target	Rebooting the connected module (for modules that authorize).
	Format target	Formatting the connected module (for modules that authorize).
	Set target address	Display/modify the IP Address, user name and password of the target.
	Synchronize with PLC database	Synchronize the namespace of your project with a PLC database. Not available for FactoryCast targets.
	Properties	View/modify the target's properties.
Service	Stop	Shut down current service.
	Run	Start current service.
	Operator screens	View operator screens.
	Print	Print current service.
	Statistics	View statistics for the selected service (incoming messages, outgoing messages, etc.).
Options	Configuration of an external tool	Set up an external tool (for example FrontPage).
	Change workspace	Changing a workspace directory.
	Default display	Restoring the three-dimensional view of the work window by default.
	Automatic input	Fill in automatically the values of a new variable by incrementing the values of the last record.
Help	Help	Access to Web Designer Help file.
	About	Information about the version, copyright etc. of Web Designer .

#### **Contextual Menu**

#### Table

The following table shows the contextual menu of the file tree.

File tree item	Menu (right-click)	Sub-menu	Comment
Project name	New	Project Target	Launch the wizard. 1st window.
	Edit		
	Paste		Paste project.
	Delete		Destroy project.
	Rename		Rename project.
	Global transfer		Transfer project.
	Properties		View the project properties.
Module name	New	Device Service	Launch the wizard. 2nd window.
	Edit		
	Cut		Cut module.
	Сору		Copy module.
	Paste		Paste module.
	Delete		Delete module.
	Rename		Rename module.
	Transfer	PC->Target Target->PC	Transfer web site.
	Connect	Target Simulation	Connect module.
	Disconnect		Disconnect module.
	Properties		View the module's properties.
Devices folder	New device		View the selection window of symbols.
	Paste		Paste device.

File tree item	Menu (right-click)	Sub-menu	Comment
Device element	Edit		Launch the device display window.
	Cut		Cut device.
	Сору		Copy device.
	Delete		Delete device.
	Rename		Rename device.
	Run		Start the service.
	Stop		Stop the service.
	Partial transfer	Target>PC	Transfer only the folder.
GraphicScreens	New Graphic Page		Launch Graphic Editor.
folder	Paste		Paste the graphic.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.
GraphicScreens item	Edit		Graphic Editor.
	Open		View graphic.
	Cut		Cut the graphic.
	Сору		Copy the graphic.
	Delete		Delete graphic.
	Rename		Rename gaphic.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.
DataTables folder	New data		Launch the data editor.
	Paste		Paste the data table.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.
DataTables item	Edit		Data Editor.
	Open		Data Viewer.
	Cut		Cut the data table.
	Сору		Copy the data table.
	Delete		Delete the data table.
	Rename		Rename the data table.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.
Services folder	New service		Create a new service.
	Paste		Paste a service.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.

File tree item	Menu (right-click)	Sub-menu	Comment
A <i>Services</i> folder calculation, email,	New		Launch the service wizard with the selected service.
database, data	Cut		Cut a service.
logging, active pages	Сору		Copy a service.
	Paste		Paste a service.
	Delete		Delete a service.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.
Services item	Edit		Launch the edit window of the service.
	Cut		Cut the service.
	Сору		Copy the service.
	Delete		Delete the service.
	Rename		Rename the service.
	Run		Start the service.
	Stop		Stop the service.
	Partial transfer	PC->Target	Transfer only the folder. See note.
Website folder	New	Folder File	Create a new file or folder.
	Paste		Paste a new file or folder.
	Import File		Importing an existing website.
	Partial transfer	Target>PC PC->Target	Transfer only the website. See note.
Folder in Website	New	Folder File	Create a new file or folder.
	Cut		Cut the folder.
	Сору		Copy the folder.
	Paste		Paste a new file or folder.
	Delete		Delete the folder.
	Rename		Rename the folder.
	Import File		Importing an existing file.
	Partial transfer	Target>PC PC->Target	Transfer only the folder. See note.

File tree item	Menu (right-click)	Sub-menu	Comment
File in WebSite	Open		Open the file.
	Open with System Editor		Launch another window with System Editor.
	Edit with	Notepad	Launch the HTML page in Edit mode with notepad.
		FrontPage	Launch the HTML page in Edit mode with FrontPage.
	Cut		Cut the file.
	Сору		Copy the file.
	Delete		Delete the file.
	Rename		Rename the file.
	Partial transfer	Target>PC PC->Target	Transfer only the file.
Namespace	Open		Launch the Namespace window.
Namespace Write Access	Edit		Launch the author rights Namespace window.

# Glossary



	Α
applet	Software component that runs in the context of another program, for example a Web browser.
ASCII	
	American Standard Code for Information Interchange.
	Pronounced "aski". This is an American code (but now an international standard) which allows all alphanumerical characters used in English, punctuation marks, some graphics characters and various commands to be defined with 7 bits.
AT commands	Also called <b>Hayes Commands</b> : Set of commands for various phone-line manipulations, dialing and hanging up for instance.
	B
bit	
	Contraction of Binary Digit.
	This is the binary unit of information content, which can represent two separate values (or states): 0 or 1.
	A field of 8 bits constitutes 1 byte.

ΒΟΟΤΡ	<b>Bootstrap Protocol</b> : Protocol for booting diskless terminals or stations by centralized management of network parameters.
	C
CF card	<b>CompactFlash card</b> : Type of data storage device, used in portable electronic devices.
communication inte	erruption Communication error detected by the module when the periodic exchanges with the PLC stop.
configuration	The configuration comprises all the data that defines the device (invariable) and that is necessary to the operation of the module.
CPU	<b>Central Processing Unit</b> : The microprocessor. This comprises the entire control unit and the arithmetic unit. The purpose of the control unit is to extract the execution instruction from the central memory along with the data needed to execute this instruction, to establish electrical connections in the arithmetic and logic unit and to start the processing of this data in the unit. <b>ROM</b> or <b>RAM</b> memories are sometimes included on the same chip, and sometimes even I/O interfaces or buffers.
CRC	<b>Cyclic Redundancy Check</b> : Type of hash function used to produce a checksum – a small, fixed number of bits – against a block of data, such as a packet of network traffic or a block of a computer file.
	D
DHCP	<b>Dynamic Host Configuration Protocol</b> : Protocol allowing a station connected to the network to obtain its configuration dynamically.

DNS	<b>Domain Name System</b> : It stores and associates many types of information with domain names, but most importantly, it translates domain names (computer hostnames) to IP addresses.
driver	Program which informs the operating system of the presence and characteristics of a peripheral.
	F
FactoryCast HMI	Active Web server that executes HMI functions integrated in a PLC module. The active Web server eliminates the need for communication via polling to update the HMI/SCADA database.
FDR	Faulty Device Replacement: Automatic configuration recovery service provided by the module.
firewall	Information technology (IT) security device which is configured to permit, deny or proxy data connections set and configured by the organization's security policy.
Flash memory	Form of non-volatile computer memory that can be electrically erased and reprogrammed.
FTP/TFTP	File Transfer Protocol/Trivial File Transfer Protocol: Network file transfer protocol.
	G
GPRS	<b>General Packet Radio Service</b> : A radio technology for GSM networks that adds packet-switching protocols and shorter set-up time for ISP connections.

Н

НМІ	<b>Human Machine Interface</b> : The aggregate of means by which people (the users) interact with a particular machine, device, computer program or other complex tool (the system).
HTML	<b>HyperText Markup Language</b> : the predominant markup language for the creation of web pages. It provides a means to describe the structure of text-based information in a document and to supplement that text with interactive forms, embedded images, and other objects.
НТТР	HyperText Transfer Protocol: Network transfer protocol for documents written in hypertext (links).
	I
IP	<b>Internet Protocol</b> : Data-oriented protocol used for communicating data across a packet-switched internetwork (i.e. the Internet).
IP Address	Unique address that devices use in order to identify and communicate with each other on a computer network utilizing the Internet Protocol standard (IP)—in simpler terms, a computer address.
ISO	International Standards Organization. The ISO code is the most widely used. Formats, symbols, transmission rules are all covered by ISO standards. AFNOR is a member of ISO.
ISP	<b>Internet Service Provider</b> : Business or organization that sells to consumers access to the Internet and related services.

#### Μ

#### MIB

**Management Information Base**: Database used by the SNMP protocol for network management and containing information on data transmission, station or router components, etc.

- MIB II: standard MIB
- Schneider Automation MIB: private MIB

## Ν

NAT

**Network Address Translation**: is the translation of an Internet Protocol address (IP address) used within one network to a different IP address known within another network.

NTP

**Network Time Protocol**: Protocol for synchronizing the clocks of computer systems over packet-switched, variable-latency data networks.

#### 0

operating mode The rules governing the behavior of the module when it is running.

#### Ρ

**Password Authentication Protocol**: Password identification protocol used for remote modem connections.

#### PL7

PAP

Schneider Automation PLC programming software.

PLC	<b>Programmable Logic Controller</b> : It is a small computer used for automation of industrial processes, such as control of machinery on factory assembly lines.
PPP	<b>Point-to-Point Protocol</b> : Point-to-point communication protocol used for modem connections.
Premium	Family of Schneider Automation PLCs.
PSTN/RTC	<b>Public Switched Telephone Network</b> : The network of the world's public circuit- switched telephone networks.
	Q
Quantum	Family of Schneider Automation PLCs.
	R
RGB	Additive model in which red, green, and blue (often used in additive light models) are combined in various ways to reproduce other colors.
RS232	<ul> <li>Serial communication standard that in particular defines the following operating voltage:</li> <li>A signal of +3 to +25V indicates a logic 0</li> <li>A signal of -3V to -25V indicates a logic 1</li> <li>Between +3V and -3V the signal is regarded as invalid.</li> <li>RS 232 connections are relatively sensitive to interference. The standard recommends not exceeding a distance of 15 meters and a speed of 20,000 baud</li> </ul>

RS485	Serial connection standard operates at +/-5V differential. The connection uses separate wires for transmission and receipt. Their "3-status" outputs allow them to switch to listening mode when transmission is completed.
RUN	Function used to start execution of the application program in the PLC.
	S
SCADA	<b>Supervisory Control And Data Acquisition</b> : Software that, interfacing with a programmable logic controller, gathers and analyzes information used to monitor and control commercial equipment.
SMTP	<b>Simple Mail Transfer Protocol</b> : Application protocol used to transmit messages via the Internet and direct them to a mailbox.
SNMP	<b>Simple Network Management Protocol</b> : Network management protocol for controlling a network remotely by polling the stations for their status and modifying their configuration, performing security tests and viewing information relating to data transmission. It can also be used to manage software and databases remotely.
SQL	<b>Structured Query Language</b> : Used to query (request data from) a relational database.
	т
ТСР	<b>Transmission Control Protocol</b> : Virtual circuit protocol that is one of the core protocols of the Internet protocol suite, often simply referred to as TCP/IP.

TCP/IP	The set of communications protocols that implement the protocol stack on which the Internet and most commercial networks run.
Time Out	<b>Expiry of a waiting time.</b> Stops the application or disconnects after a lengthy period of non-use.
	U
UDP	<b>User Datagram Protocol</b> : One of the core protocols of the Internet protocol suite. Using UDP, programs on networked computers can send short messages sometimes known as datagrams to one another.
URL	<b>Uniform Resource Locator</b> : The global address of documents and other resources on the World Wide Web.
	V
VPN	<b>Virtual Private Network</b> : A private network that is configured within a public network. It uses encryption and other security mechanisms so that only authorized users can access the network and that the data cannot be intercepted.
	X
XML	<b>Extensible Markup Language</b> : it is aimed to facilitate the sharing of data across different information system. It is a simplified subset of the SGML and is designed to be relatively human-legible.

# Index



# Α

automatic input, 73

# D

Data Editor spreadsheet, *81* symbol, *84* templates, *80* variable, *81, 84* data templates, *80* direct addresses, *86* 

# Ε

example see (getting started), *19* export, *47* Expression Web LiveBeanApplet, *143* LiveLabelAppet, *151* external tool configuration, *165* 

## F

format target, FrontPage LiveBeanApplet, LiveLabelAppet,

## G

getting started, 19 accessing the website, 36 configuring the module, 25 creating a new project, 21 Data Editor, 29 Graphic Editor, 32 presentation, 20 selecting devices, 23 selecting variables, 27 transfering a project, 34 Graphic Editor applet parameters, 102 presentation, 89 properties sheet, 99 security, 101 toolbar, 91 user functions, 96 Graphic objects extended, 124 presentation, 104

## 

import, 47 synchronization, 72 installation, 14 introduction, 12 IP address, 50

# Μ

module connecting/disconnecting, *58* FTP, *54* IP address, *50* 

# Ν

namespace, 68 write access, 74

# 0

online documentation, 54

## Ρ

password, 178 configuration, 179 HTTP, 179 write, 179 PC configuration, 13 PLC program viewer, 158 presentation, 12 project add devices, 42 add targets, 40 close, 46 device list. 43 global transfer, 54 open, 46 partial transfer, 54 remove devices, 43 remove items, 45 remove targets, 41 save, 46 target list, 41 transfer, 51 validation, 55

## R

reboot target, 171

## S

security access, 177 Security access, 174 firewall, 175 passwords, 174 service creation, 45 simulation, 62, 63 site explorer, 54 symbol name, 68 import from PLC, 70 manual selection, 73 synchronization, 72

# Т

transfer status, 56

### V

variable import from PLC, 70 manual selection, 73 name, 68 Unity Pro, 72

## W

Web Designer close, 46 Workspace directory, 169 write password, 179

200