



[www.zeeltronic.com](http://www.zeeltronic.com)  
[info@zeeltronic.com](mailto:info@zeeltronic.com)

updated 03.11.2011  
program version: 20.090311

## USER MANUAL PDCI-11 PROGRAMMABLE CDI IGNITION

### TECHNICAL DATA

#### Limit values:

- minimum revs	200 RPM
- maximum revs	20000 RPM
- minimum supply voltage	8 Volts
- maximum supply voltage	16 Volts
- stand-by current draw	< 0.05 Amp
- current draw at 1300 RPM	< 0.3 Amp
- current draw at 12000 RPM	< 1 Amp
- maximum continuous current for shift light and power jet output	1 Amp
- peak current for shift light and power jet output	5 Amp
- constant spark energy from idle to 20000 RPM	>35mJ

Circuit is protected against reverse supply voltage (wrong connection).

#### Features:

- fast power-up (also starts only with condenser)
- full power starting spark energy already at 8Volts power supply
- one isolated input for magnetic pickup
- store and load function for two ignition maps
- external switch for changing ignition map while riding
- TPS input (Throttle Position Sensor)
- shift light output
- power jet output
- duty cycle solenoid output (for regulating A/F ratio on some carburettors)
- quick shift (shift kill)
- soft rev limit (three stage rev limit)
- reduced spark at high revs with closed throttle (TCT mode)
- tachometer output
- easy and fast programming on the field, via hand held programmer
- programming with PC
- programming while machine running
- 3D interpolated ignition map, if TPS used
- signal delay compensation
- instant monitoring of rev's and angle, via LCD(hand held programmer)
- fast processing for high accuracy - delays from 1us

### Very important!

Resistor spark plugs must be used, because they produce less electromagnetic disturbances.

### Danger of electric shock!

Avoid connecting PDCI to 12V power supply, before connecting it to ignition coil. High voltage is generated and touching free wires can cause electric shock, or damage the unit.

## 1. HOW TO ENTER MENU

**PDCI** must be connected to power supply. Connect **programmer** to **PDCI** and wait few seconds for activation of **programmer** and then press . With pressing  , or  you can move through menu and with pressing  you can choose.

You can exit menu with choosing **Exit**.

## 2. MENU ORGANISATION

<i>Load Ign. Map</i>	- load (select) ignition map (from #1 to #2)
<i>Save Ign. Map</i>	- save new ignition map (from #1 to #2)
<i>Set Ignition Map</i>	- ignition map parameters submenu
<i>Advance</i>	- advance/retard whole ignition map on both ignition coil outputs
<i>Gear Shift Light</i>	- shift light
<i>Quick Shift</i>	- quick shift settings
<i>Rev Limit</i>	- rev limit
<i>Static Angle</i>	- static angle (stator position)
<i>Compensation</i>	- signal delay compensation (from pickup to spark plug)
<i>Power Jet 1</i>	- power jet 1
<i>Solenoid Output</i>	- solenoid output settings (power jet 2, or duty solenoid)
<i>TPS</i>	- enable, or disable TPS
<i>TPS close [0%]</i>	- calibrating TPS close position
<i>TPS open [100%]</i>	- calibrating TPS open position
<i>TCT mode</i>	- reduced spark at high revs with closed throttle
<i>Ign. Map SW</i>	- activating/deactivating external switch for selecting ignition map
<i>Pulses Per Rev</i>	- number pulses per revolution from pickup
<i>Stop SW mode</i>	- select low, or high level stop
<i>Ignition Test</i>	- sparks are generated for few seconds
<i>Exit</i>	

## 3. LOAD IGN. MAP

Move to **Load Ign. Map** with pressing  , or  and then press  .

Now you can select number of saved ignition map, with pressing  , or  and then press .

#### 4. SAVE IGN. MAP

Move to *Save Ign. Map* with pressing  , or  and then press  .

Now you can select number to which you want to save your ignition map, with pressing  , or  and then press  .

#### 5. SET IGNITION MAP (if TPS disabled)

Move to *Set Ignition Map* with pressing  , or  and then press  .

...you entered submenu for setting ignition map.

Submenu organisation:

*Nr. of Points* - number of ignition curve points (from 4 to 12)

1) - first ignition curve point

2) - second ignition curve point

... ..

... ..

*Exit* - exit submenu


#### **Important!**

To avoid wrong processing, don't make unreasonable curve course.

Every time you make any changes to ignition curve, it is automatically saved to number #0.

Later you can save it to any other number #1 or #2.

Curve Example with six curve points:



### 5.1. SET IGNITION MAP (if TPS enabled)

Three ignition curves must be programmed for different TPS positions. **PDCI** does not only switch between ignition curves, but also interpolate 3D map for all TPS positions above 33%.

Move to *Set Ignition Map* with pressing  , or  and then press .  
...you entered submenu for selecting ignition curve.

Submenu organisation:

- Nr. of Points** - number of ignition curve points (from 4 to 10)
- Curve 0-33%** - ignition curve from 0 to 33% TPS
- Curve 66%** - ignition curve for 66% TPS
- Curve 100%** - ignition curve for 100% TPS
- Exit** - exit submenu


#### **Important!**

To avoid wrong processing, don't make unreasonable curve course.

Every time you make any changes to ignition curve, it is automatically saved to number #0.

Later you can save it to any other number #1 or #2.

Ignition Map Example:



### 5.2. Change NUMBER OF IGNITION CURVE POINTS

Move to *Nr. of Points* with pressing  , or  and then press  .

Now you can select number of ignition points, with pressing  , or  and then press  .

### 5.3. Change PARAMETERS OF IGNITION CURVE POINT

Move to point you want to change, with pressing  , or  and then press  .

Now you can change rev point with pressing  , or  (in 100 rpm steps) and then press  .

Now you can change advance angle with pressing  , or  (in 0.1deg steps) and then press  .

## 6. ADVANCE

With this setting is possible to advance, or retard whole ignition map on both ignition coil outputs. When setting is positive, then ignition map is advanced and when setting is negative, than ignition map is retarded. Ignition map is unchanged, with setting **0.0deg**.

Move to **Advance**, with pressing  , or  and then press  .

Now you can set advance with pressing  , or  (in 0.1deg steps) and then press  .

## 7. GEAR SHIFT LIGHT

Move to **Gear Shift Light** with pressing  or  and then press  .

Now you can change rev point with pressing  or  (in 100 rpm steps) and then press  .

## 8. QUICK SHIFT

Move to **Quick Shift** with pressing  , or  and then press  .

...you entered submenu for quick shift settings.

Submenu organisation:

**Shift Kill Time** - basic kill time

**Smart Shift** - activating/deactivating automatic kill time for different revs

**Exit** - exit submenu

### 8.1. SHIFT KILL TIME

Enter **Quick Shift** menu and move to **Shift Kill Time** with pressing  , or  and then press  .

Now you can change kill time with pressing  , or  (in 10 ms steps) and then press  .

### 8.2. SMART SHIFT

Smart shift function automatically adjusts kill time for different revs. Shift kill time must be always set, as basic kill time.

Enter **Quick Shift** menu and move to **Smart Shift** with pressing  , or  and then press  .

Now you can enable, or disable function with pressing  , or  and then press  .

## 9. REV LIMIT

Move to **Rev Limit** with pressing  , or  and then press  .

Now you can change rev limit with pressing  , or  (in 100 rpm steps) and then press  .

## 10. STATIC ANGLE

Move to *Static Angle* with pressing  , or  and then press  .

Now you can set static angle with pressing  , or  (in 0.1deg steps) and then press  .

More information's about static angle you can find in section 21.

## 11. COMPENSATION

It is compensation of signal delay from pickup to spark plugs. You can check this delay with stroboscope lamp. Without this compensation, ignition advance angle decreasing with rising revs.

This compensation helps that advance angles in ignition curve are real (more accurate).

How to check, if compensation is correct:

First you must set flat ignition curve. Then measure with stroboscope lamp, if mark at flywheel moving when changing revs. If mark moving then you must change compensation delay.

Change Compensation:

Enter menu and move to *Compensation* with pressing  , or  and then press  .

Now you can change compensation delay with pressing  , or  and then press  .

## 12. POWER JET 1

Menu and move to *Power Jet 1* with pressing  , or  and then press  .

...you entered submenu for setting *Power Jet 1* parameters.

Submenu organisation:

<i>Power Jet 1 ON RPM</i>	- revs for activating power jet 1
<i>Power Jet 1 OFF RPM</i>	- revs for deactivating power jet 1
<i>Power Jet 1 ON TPS (if TPS enabled)</i>	- throttle position for activating power jet 1
<i>Power Jet 1 OFF TPS (if TPS enabled)</i>	- throttle position for deactivating power jet 1
<i>Exit</i>	- exit submenu

Example:

*Power jet 1 ON (RPM) = 8000rpm*

*Power jet 1 OFF (RPM) = 10000rpm*

*Power jet 1 ON (TPS) = 70%TPS*

*power jet 1 OFF (TPS) = 90%TPS*

*Power jet is switched on when revs are between 8000-10000rpm and throttle position is between 70-90%, otherwise power jet is switched off.*

## 12.1. POWER JET 1 ON RPM

Move to *Power Jet 1 ON RPM* with pressing  , or  and then press .

Now you can change *Power Jet 1 ON RPM* with pressing  , or  (in 100 rpm steps) and then press .

## 12.2. POWER JET 1 OFF RPM

Move to *Power Jet 1 OFF RPM* with pressing  , or  and then press .

Now you can change *Power Jet 1 OFF RPM* with pressing  , or  (in 100 rpm steps) and then press .

## 12.3. POWER JET 1 ON TPS (if TPS enabled)

Move to *Power Jet 1 ON TPS* with pressing  , or  and then press .

Now you can change TPS position with pressing  , or  (in 1% TPS steps) and then press .

## 12.4. POWER JET 1 OFF TPS (if TPS enabled)

Move to *Power Jet 1 OFF TPS* with pressing  , or  and then press .

Now you can change TPS position with pressing  , or  (in 1% TPS steps) and then press .

## 13. SOLENOID OUTPUT

Move to *Solenoid Output* with pressing  , or  and then press .

...you entered submenu for setting *Solenoid Output* parameters.

Submenu organisation:

***Output type***

- select output type (Power Jet 2, or Duty Solenoid)

***Power Jet 2 (if selected)***

- set Power Jet 2 parameters

***Duty Solenoid (if selected)***

- set Duty Solenoid parameters

***Exit***

- exit submenu

### 13.1. OUTPUT TYPE

Solenoid output function can be configured as Power Jet 2, or Duty Solenoid. Duty solenoid is used for adjusting A/F ratio on some carburettors.

Enter *Solenoid Output.* menu and move to *Output type* with pressing  , or  and then press .

Now you can change solenoid *Output type* with pressing  , or  and then press .

### 13.2. POWER JET 2 (if selected in Output Type menu)

Same settings as *Power Jet 1*...look at section 14.

### 13.3. DUTY SOLENOID (if selected in Output Type menu)

Three duty cycle curves for different throttle positions can be programmed. Each curve can be programmed in 8 rev points.

Enter *Solenoid Output* menu and move to *Duty Solenoid* with pressing  , or  and then press  .

...you entered submenu for setting *Duty Solenoid* parameters.

Submenu organisation:

- Curve 0-33%* - duty cycle curve from 0 to 33% TPS
- Curve 34-66%* - duty cycle curve from 34 to 66% TPS
- Curve 67-100%* - duty cycle curve from 67 to 100% TPS
- Exit* - exit submenu

#### 13.3.1 Set PARAMETERS FOR DUTY SOLENOID CURVE POINT

Move to point you want to change, with pressing  , or  and then press  .

Now you can change rev point with pressing  , or  (in 100 rpm steps) and then press  .

Now you can change duty cycle with pressing  , or  (in 1% steps) and then press  .

## 14. TPS

Enabling, or disabling Throttle Position Sensor.

Move to *TPS* with pressing  , or  and then press  .

Now you can enable or disable TPS with pressing  , or  and then press  .

## 15. Set TPS close [0%] (if TPS enabled)

For correct operation, TPS close position must be calibrated!

Move to *TPS close [0%]* with pressing  , or  and then press  .

Leave throttle at close position and confirm calibrating with pressing  , or exit calibration with pressing  . Displayed number should be between 0 and 500.



## 16. Set TPS open [100%] (if TPS enabled)

For correct operation, TPS open position must be calibrated!

Move to **TPS open [100%]** with pressing  , or  and then press .

Move throttle to maximum open position and confirm calibrating with pressing  , or exit calibration with pressing . Displayed number should be between 500 and 1010.

## 17. TCT mode

Throttle Close spark Termination mode, reduces number of sparks (spark is active every third revolution) above 8000rpm, when throttle is closed. TCT mode ensure better engine cooling.

Move to **TCT mode** with pressing  , or  and then press .

Now you can enable or disable **TCT mode** with pressing  , or  and then press .

## 18. IGN. MAP SW

Enabling, or disabling ignition map switch, for changing ignition maps while riding.

Move to **Ign. Map SW** with pressing  , or  and then press .

Now you can enable or disable external switch with pressing  , or  and then press .

## 19. PULSES PER REV

It is number of pulses per rev from pickup coil and is important for correct rev reading. Setting is 2 for all twins with wasted spark ignition system.

Move to **Pulses Per Rev** with pressing  , or  and then press .

Now you can change nr. of pulses per rev with pressing  , or  and then press .

## 20. STOP SW MODE

Selects stop switch operation mode. Engine can be stopped with low level (stop switch connected to the ground), or with high level (stop switch is opened).

Move to **Stop SW Mode** with pressing  , or  and then press .

Now you can select low level stop "0", or high level stop "1" with pressing  , or  and then press .

## 21. MECHANICAL SETTINGS (Static Angle)

**Static Angle** is ignition advance angle, set with stator (generator).

Measure this angle with dial gauge. This measured **Static Angle** is your maximum advance angle you can set with **PDCI**.

*Calculating mm to deg or vice versa:*

$\alpha$  = ignition advance in degrees

$T$  = ignition advance in mm

$R$  = engine stroke divided by 2 in mm

$L$  = conrod length in mm

$P = R + L - T$

$$\alpha = \cos^{-1} \left( \frac{P^2 + R^2 - L^2}{2 \cdot P \cdot R} \right)$$

$$T = L + R \cdot (1 - \cos \alpha) - \sqrt{L^2 - (R \cdot \sin \alpha)^2}$$

## 22. MONITORING

Connect **programmer** to **PDCI** and wait few seconds for activation of **programmer**. First information displayed on the **programmer** is software version.

With **programmer** you can watch revs, calculated advance ignition angle, TPS position...depends on setting in the menu.

### **Information!**

You can connect or disconnect **PDCI** unit from **programmer** any time you want, without any harm. It is not important, if motor running or not and if power supply is connected or not.

### **Important!**

Do not use too much force when connecting or disconnecting **programmer** unit!