



Allen-Bradley

***Classic PLC-5
Programmable
Controller***

***(Cat. No. 1785-LT, -LT2,
-LT3, and -LT4)***

Quick Start



Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or in part, without written permission of Allen-Bradley Company, Inc., is prohibited.

Throughout this manual we use notes to make you aware of safety considerations:



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss.

Attention statements help you to:

- identify a hazard
- avoid the hazard
- recognize the consequences

Important: Identifies information that is critical for successful application and understanding of the product.

Table of Contents

Important User Information	-1
Preface	P-1
Who Should Use This Manual	P-1
Purpose of This Manual	P-1
Related Documentation	P-2
Common Techniques Used in This Manual	P-3
Allen-Bradley Support	P-3
Local Product Support	P-3
Technical Product Assistance	P-3
Your Questions or Comments about This Manual	P-3
Overview	1-1
What You Need to Do	1-1
Components You Need	1-1
Set up the Hardware	2-1
Configure the I/O Chassis	2-2
Install the Hardware	2-2
Ground the I/O Chassis	2-3
Install the Power Supply	2-4
Install the PLC-5 Processor	2-5
Powerup the System	2-5
Install the I/O Modules	2-6
Connect the Programming Terminal and the PLC-5 Processor to the Communication Card	2-6
Set up the Software	3-1
Install the Software and Set Up the Programming System	3-1
Start the Programming Software	3-1
Powerup the System	3-2
Troubleshoot the Processor System	4-1
Use the PLC-5 Processor Status Indicators	4-1
Specifications	A-1
General	A-1
Processor Specific	A-3
Battery Specifications	A-4

Preface

Read this preface to familiarize yourself with the rest of the manual. This preface covers the following topics:

- who should use this manual
- the purpose of this manual
- how to use this manual
- conventions used in this manual
- Allen-Bradley support

Who Should Use This Manual

To use this manual, you should understand programmable controllers and be able to interpret the ladder logic instructions required to control your application. For more information, see the documents listed on the following page or contact your local Allen-Bradley representative.


Purpose of This Manual

This manual is for users of the classic PLC-5® processor. It:

- presents you with the basic information you need to get your system up and running
- provides “memory jogger” information, such as specific bit and switch settings for modules
- includes high-level procedures with cross-references to other manuals for more detail

Related Documentation

The following documents contain additional information concerning the products discussed in this manual.

For more information about:	See this document:	Publication number:
Classic PLC-5 programmable controllers	Classic PLC-5 Programmable Controllers User Manual	1785-6.2.1
<p>To obtain a free copy of this manual, complete and send in the User Manual Request Card that came packaged with this quick start.</p>		
		
Classic PLC-5 programmable controllers	Classic PLC-5 Programmable Controllers Hardware Installation Manual	1785-6.6.1
Universal 1771 I/O chassis	Universal I/O Chassis Installation Instructions	1771-2.10
power supply	Redundant Power Supplies (1771-P4R, -P6R) Installation Data	1771-2.166
DH+® network	Enhanced and Ethernet PLC-5 Programmable Controllers User Manual	1785-6.5.12
	Data Highway/Data Highway Plus/Data Highway II/Data Highway-485 Cable Installation Instructions	1770-6.2.2
communication cards	1784-KTx Communication Interface Card User Manual	1784-6.5.22
	Allen-Bradley Publication Index (for your specific communication card)	SD499
cables	Classic PLC-5 Programmable Controllers User Manual	1785-6.2.1
batteries	Allen-Bradley Guidelines for Lithium Battery Handling and Disposal	AG-5.4
grounding and wiring Allen-Bradley programmable controllers	Allen-Bradley Programmable Controller Wiring and Grounding Guidelines	1770-4.1
current Allen-Bradley documentation, including ordering instructions	Allen-Bradley Publication Index	SD499
terms and definitions	Allen-Bradley Industrial Automation Glossary	AG-7.1

Common Techniques Used in This Manual

We use the following conventions throughout this manual:

- Bulleted lists provide information, not procedural steps.
- Numbered lists provide sequential steps or hierarchical information.



We use this symbol to indicate additional references you can use when you need more information about a particular topic.

Allen-Bradley Support

Allen-Bradley offers support services worldwide, with over 75 sales/support offices, 512 authorized distributors, and 260 authorized systems integrators located throughout the United States alone, plus Allen-Bradley representatives in every major country in the world.

Local Product Support

Contact your local Allen-Bradley representative for:

- sales and order support
- product technical training
- warranty support
- support service agreements

Technical Product Assistance

If you need to contact Allen-Bradley for technical assistance, call your local Allen-Bradley representative.

Your Questions or Comments about This Manual

If you discover a problem with this manual, please notify us of it by completing and sending the enclosed Publication Problem Report (at the back of this manual).

If you have any suggestions about how we can make this manual more useful to you, please contact us at the address below:

Allen-Bradley Company, Inc.
Automation Group
Technical Communication
1 Allen-Bradley Drive
Mayfield Heights, OH 44124-6118
Telephone: (216) 646-5000
FAX: (216) 646-3083

Overview


This quick start is designed to provide you with the information you need to get your system up and running quickly. Use this document if you are knowledgeable about Classic PLC-5 products, but may not have used one or more of them recently. The information we provide is geared to “jog your memory.”

What You Need to Do

*Set up the hardware
(Chapter 2)*

*Set up the software
(Chapter 3)*

*Troubleshoot the
Processor System
(Chapter 4)*



Components You Need



Product name:	Catalog number:
Hardware	
Classic PLC-5 processor with 2 keys	1785-LT4, -LT3, -LT2, -LT
Lithium Battery (in a clear bag)	1770-XY
I/O chassis	1771-A1B, -A2B, -A3B1, -A4B (panel mount) 1771-A3B (rack or panel mount)
Memory modules	1785-MJ 1785-MK (PLC-5/25 only)
Power supply	1771-P1, -P2 -P3, -P4, -P4S, -P4S1, -P4R, -P5, -P6S, -P6S1, -P6R, -P7, -PS7
Programming System	
PC	Check your programming software documentation for system requirements, such as memory, etc.
PLC-5 programming software	Choose a programming software package that is compatible with Classic PLC-5 processors.
communication module	DH+ interface and interconnect cable

Important: In this manual, we assume you are using a brand-new Classic PLC-5 processor out of the box.

Set up the Hardware

- 1 Install the hardware
(page 2-2)
- 2 Connect the programming terminal
and the PLC-5 processor to the
communication card
(page 2-6)

PC with programming
software installed




For more information, see the Classic PLC-5 Programmable Controllers Hardware Installation Manual, publication number 1785-6.6.1.

Install the Hardware

Configure the I/O Chassis

1 Set the backplane switches.

- Pressed in at top ON (closed)
- Pressed in at bottom OFF (open)



Switch	Last State
1	
ON	Outputs of this I/O chassis remain in their last state when a hardware failure occurs. ¹
OFF	Outputs of this I/O chassis are turned off when a hardware failure occurs. ¹

Switches		Addressing
4	5	
OFF	OFF	2 - slot
OFF	ON	1 - slot
ON	OFF	1/2 - slot
ON	ON	Not allowed


Switches		EEPROM transfer
6	7	
OFF	OFF	EEPROM memory transfer to processor memory at powerup. ²
ON	ON	EEPROM memory transfers to processor memory if processor memory not valid.
ON	OFF	EEPROM memory does not transfer to processor memory. ³

Switch	RAM memory protection
8	
OFF	RAM memory protection disabled.
ON	RAM memory protection enabled. ⁴

1. Regardless of this switch setting, outputs are reset when any of the following occurs:
 - processor detects a runtime error
 - an I/O chassis backplane fault occurs
 - you select program or test mode
 - you set a status file bit to reset a local rack
2. If an EEPROM module is not installed and processor memory is valid, the processor's PROC LED indicator blinks, and the processor sets S:11/9, bit 9 in the major fault status word.
3. A processor fault occurs if processor memory (solid red PROC LED) is not valid.
4. You cannot clear processor memory when this switch is on.


19309

2 Set the power supply configuration jumper.



Set Y when you install a power supply module in the chassis; set N (the default) when you use an external power supply.


3 Install the keying bands.



For more information, see the Universal I/O Chassis Installation Instructions, publication number 1771-2.10.


Ground the I/O Chassis

(for remote I/O systems)



15561

(for extended-local systems)




18585




For more information, see the Allen-Bradley Programmable Controller Wiring and Grounding Guidelines, publication number 1770-4.1.

Install the Power Supply




1 Set the jumpers on the back side of the power supply like this:



2 Connect the power cord to the 120V ac connector of the power supply module.

This side plugs into connector on the module.




3 Install the power supply in the chassis and snap the module-locking bar over the modules.




For more information, see the Redundant Power Supplies (1771-P4R, -P6R) Installation Data, publication number 1771-2.166.

Install the PLC-5 Processor



- 1 Define the DH+ Station Address of Channel 1A by setting switch assembly SW-1 on the back of the processor.



- 2 To install the battery, slide the battery-side connector into the processor-side connector until you hear them snap together, and attach the battery cover.

- 3 If you plan to install an EEPROM, install it now.

- 4 Install the processor.



ATTENTION: Do not insert or remove the EEPROM under power. Insertion or removal under power can result in loss of program memory and a processor fault.



For detailed information about handling and disposing of the battery as well as other important guidelines, see publication AG-5.4.




For more information, see the Classic PLC-5 Programmable Controllers Hardware Installation Manual, publication number 1785-6.6.1.

Powerup the System

Powerup the system. Check the LED display on the processor. If your system is operating properly, the PROC LED should be steady red. If the PROC LED is not red, see chapter 4 for troubleshooting information before you install the I/O modules.

Install the I/O Modules




For more information, see the installation instructions or user manual for the particular module you are installing.

Connect the Programming Terminal and the PLC-5 Processor to the Communication Card

1 Connect the industrial terminal end of the CP cable to the communication card.


2 Connect the CP cable to the connector on the PLC-5 processor.



For more information, see:

- Classic PLC-5 Programmable Controllers Hardware Installation Manual, publication number 1785-6.6.1
- 1784-KTx Communication Interface Card User Manual, publication number 1784-6.5.22
- Data Highway/Data Highway Plus/Data Highway II/Data Highway 485 Cable Installation Manual, publication 1770-6.2.2

Set up the Software



The following instructions are general. For specific information, see the documentation set for your particular software package.

Install the Software and Set Up the Programming System

Before you install your programming software, make certain you meet the system requirements for that software – sufficient disk space, memory, etcetera. Then, follow the procedures outlined in the software documentation to install the software and configure communication.

Start the Programming Software

Start the programming software by following the procedures described in your programming software documentation.

If you have difficulty, verify that the power supply is turned on.

To monitor your system as you configure and run it, check the LED display for the following indicators:


This LED:	lights when:
COMM	you establish DH+ communication
BATT	no battery is installed or the battery voltage is low
REM I/O	you establish Remote I/O communication
ADAPT	the processor is in adapter mode
FORCE	forces are present in your ladder program

Powerup the System

Powerup the system if you have not done so already. Check the LED display on the processor. If your system is operating properly, the PROC LED should be steady red. See the following table to proceed. If the PROC LED is not red, turn to chapter 4 for troubleshooting information.


If your keyswitch is in this position:	you see this message:	and then this occurs:
PROGRAM	Processor RAM is faulted. Press <Enter> to clear memory.”	After you clear memory, the PROC LED turns off. The software is in Program mode.
REMOTE	Processor RAM is faulted. Press <Enter> to clear memory.”	After you clear memory, the PROC LED turns off. The software is in Remote Program mode.
RUN	No access or privilege violation.	You see this message because you cannot clear memory in Run mode. Change the keyswitch position to Program or Remote and powerup the system again.

Troubleshoot the Processor System



1 Use the PLC-5 Processor Status Indicators (page 4-1)

Use the PLC-5 Processor Status Indicators



Indicator	Color	Description	Probable Cause	Recommended Action
PROC	green (steady)	processor in RUN mode and fully operational	normal operation	no action required
	green (blinking)	Processor memory being transferred to EEPROM	normal operation	no action required
	red (blinking)	major fault	run-time error	Check major fault bit in status file (S:11) for error definition. Clear fault bit, correct problem, and return to RUN mode.
	red (steady)	major fault	<ul style="list-style-type: none"> user RAM has checksum error memory module error 	<ul style="list-style-type: none"> Clear memory and reload program. Check backplane switch settings and/or insert correct memory module.
	off	processor in program load or TEST mode or is not receiving power		Check power supply and connections.
PROC REM I/O	all red (steady)		internal diagnostics have failed	Power down, reseal processor and power up. Then, clear memory and reload your program. Replace EEPROM with new program. Then, if necessary, replace the processor.
FORCE	amber (steady)	forces enabled	normal operation	no action required
	amber (blinking)	forces present, but not enabled	normal operation	no action required
	off	no forces present	normal operation	no action required
BATT	red (steady)	battery low		Replace battery within 1-2 days (typical).
	off	battery is good	normal operation	no action required
ADPT (continues)	green (steady)	processor is in adapter mode	normal operation	no action required







Indicator	Color	Description	Probable Cause	Recommended Action
ADPT	off	processor is in scanner mode	normal operation	no action required
REM I/O (in adapter mode)	green (steady)	active remote I/O link	normal operation	no action required
	green (blinking)	remote I/O active and host processor is in program load or TEST mode	normal operation	no action required
	red (steady)	no communication with host processor	duplicate station address selected	Correct station address.
	green (sporadic)	bad communication with host processor		Check connections.
	off	no communication with host processor		no action required
REM I/O (in scanner mode)	green (steady)	active remote I/O link	normal operation	no action required
	red (steady)	remote I/O link fault	wiring, adapter module(s)	<ul style="list-style-type: none"> • Check all connections, check adapter module(s). • If you have programming software, put the processor in PROG mode and do an autoconfigure for remote racks.
	green/red (blinking)	partial remote I/O link fault	one or more remote I/O chassis faulted	<ul style="list-style-type: none"> • Check status bits in status file (element #7) to identify faulted chassis number; check wiring, adapter module(s), power supplies. • If you have programming software, put the processor in PROG mode and do an auto configure for remote racks.
	off	no remote I/O selected		no action required
COMM	green (blinking rapidly or slowly)	processor is transmitting or receiving on DH+ link	normal operation	no action required
	red (steady)	watchdog timeout	hardware error	Turn power off, then on. Check that the software configurations match the hardware set-up. Replace the processor.
	red (sporadic)	bad communication on DH+ link	duplicate station address selected	Correct station address.
	off	<ul style="list-style-type: none"> • If directly connected to processor, no communication on DH+ link • If last processor on DH+ link, no communication on DH+ link 		<ul style="list-style-type: none"> • no action required • Check DH+ wiring connections.

Specifications

General

This table lists general specifications.

Weight	PLC-5/10 (1785-LT4)	1336 g (47.12 oz.)
	PLC-5/12 (1785-LT3)	1337 g (42.15 oz.)
	PLC-5/15 (1785-LT)	1339 g (47.23 oz.)
	PLC-5/25 (1785-LT2)	1337 g (42.15 oz.)
Backplane Current	2.5A	
Environmental Conditions:		
operating temperature	0° to 60° C (32° to 140° F)	
storage temperature	-40° to 85° C (-40° to 185° F)	
relative humidity	5 to 95% (without condensation)	
Vibration (operating and non-operating)	1 g @ 10 to 500 Hz 0.012 inches peak-to-peak displacement	
Shock		
operating	30 g peak acceleration for 11±1 ms duration	
non-operating	50 g peak acceleration for 11±1 ms duration	
Time-of-Day Clock and Calendar		
maximum variations at 60° C	± 3 min per month	
typical variations at 20° C	± 20 s per month	
timing accuracy	one program scan	
Typical Discrete I/O Scan	<ul style="list-style-type: none"> • 1ms/local I/O rack • 10 ms/remote I/O adapter communication at 57.6 kbps 	
I/O Modules	Bulletin 1771 I/O including 8-, 16-, 32-pt., and intelligent modules	
Hardware Addressing:		
2-slot	<ul style="list-style-type: none"> • any mix of 8-pt modules • 16-pt modules must be I/O pairs • no 32-pt modules 	
1-slot	<ul style="list-style-type: none"> • any mix of 8- or 16-pt modules • 32-pt modules must be I/O pairs 	
1/2-slot	any mix of 8-,16-, or 32-pt modules	
Communication	<ul style="list-style-type: none"> • DH+ 3,048 cable-m (or 10,000 cable-ft) max • DH using 1785-KA 	
Location	1771-I/O chassis, left-most slot	
Keying	<ul style="list-style-type: none"> • between 40 and 42 • between 54 and 56 	
Agency Certification (when product is marked)	<ul style="list-style-type: none"> • CSA certified • CSA Class I, Division 2, Groups A, B, C, D • UL listed 	
User Manual	publication 1785-6.2.1	

<p>CSA Hazardous Location Approval</p>	<p>Approbation d'utilisation dans des emplacements dangereux par la CSA</p>
<p>CSA certifies products for general use as well as for use in hazardous locations. Actual CSA certification is indicated by the product label as shown below, and not by statements in any user documentation.</p>	<p>La CSA certifie les produits d'utilisation générale aussi bien que ceux qui s'utilisent dans des emplacements dangereux. La certification CSA en vigueur est indiquée par l'étiquette du produit et non par des affirmations dans la documentation à l'usage des utilisateurs.</p>
<p>Example of the CSA certification product label</p> 	<p>Exemple d'étiquette de certification d'un produit par la CSA</p> 
<p>To comply with CSA certification for use in hazardous locations, the following information becomes a part of the product literature for CSA-certified Allen-Bradley industrial control products.</p> <ul style="list-style-type: none"> • This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D, or non-hazardous locations only. • The products having the appropriate CSA markings (that is, Class I Division 2, Groups A, B, C, D), are certified for use in other equipment where the suitability of combination (that is, application or use) is determined by the CSA or the local inspection office having jurisdiction. 	<p>Pour satisfaire à la certification de la CSA dans des endroits dangereux, les informations suivantes font partie intégrante de la documentation des produits industriels de contrôle Allen-Bradley certifiés par la CSA.</p> <ul style="list-style-type: none"> • Cet équipement convient à l'utilisation dans des emplacements de Classe 1, Division 2, Groupes A, B, C, D, ou ne convient qu'à l'utilisation dans des endroits non dangereux. • Les produits portant le marquage approprié de la CSA (c'est à dire, Classe 1, Division 2, Groupes A, B, C, D) sont certifiés à l'utilisation pour d'autres équipements où la convenance de combinaison (application ou utilisation) est déterminée par la CSA ou le bureau local d'inspection qualifié.
<p>Important: Due to the modular nature of a PLC control system, the product with the highest temperature rating determines the overall temperature code rating of a PLC control system in a Class I, Division 2 location. The temperature code rating is marked on the product labels as shown.</p>	<p>Important: Par suite de la nature modulaire du système de contrôle (PLC), le produit ayant le taux le plus élevé de température détermine le taux d'ensemble du code de température du système de contrôle d'un PLC dans un emplacement de Classe 1, Division 2. Le taux du code de température est indiqué sur l'étiquette du produit.</p>
<p>Temperature code rating</p> 	<p>Taux du code de température</p> 
<p>The following warnings apply to products having CSA certification for use in hazardous locations.</p>	<p>Les avertissements suivants s'appliquent aux produits ayant la certification CSA pour leur utilisation dans des emplacements dangereux.</p>
 <p>ATTENTION: Explosion hazard —</p> <ul style="list-style-type: none"> • Substitution of components may impair suitability for Class I, Division 2. • Do not replace components unless power has been switched off or the area is known to be non-hazardous. • Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous. • Do not disconnect connectors unless power has been switched off or the area is known to be non-hazardous. Secure any user-supplied connectors that mate to external circuits on an Allen-Bradley product using screws, sliding latches, threaded connectors, or other means such that any connection can withstand a 15 Newton (3.4 lb.) separating force applied for a minimum of one minute. 	 <p>AVERTISSEMENT: Risque d'explosion —</p> <ul style="list-style-type: none"> • La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de Classe I, Division 2. • Couper le courant ou s'assurer que l'emplacement est désigné non dangereux avant de remplacer les composants. • Avant de débrancher l'équipement, couper le courant ou s'assurer que l'emplacement est désigné non dangereux. • Avant de débrancher les connecteurs, couper le courant ou s'assurer que l'emplacement est reconnu non dangereux. Attacher tous connecteurs fournis par l'utilisateur et reliés aux circuits externes d'un appareil Allen-Bradley à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens permettant aux connexions de résister à une force de séparation de 15 newtons (3,4 lb. - 1,5 kg) appliquée pendant au moins une minute.

Processor Specific

This table lists specifications of each Classic PLC-5 family processor.

Processor	Maximum Local Racks Supported	Maximum Remote Racks Supported	I/O Capacity	Memory (Words)	Program Scan Time	Communication	Memory Modules (optional)	Battery
PLC-5/10	4 (1 resident chassis)	none	<ul style="list-style-type: none"> • 128 I/O with 8-pt modules ¹ • 256 I/O with 16-pt modules ¹ • 512 I/O with 32-pt modules ¹ 	6 K	2 ms/K words (bit logic) 8 ms/K words (typical)	standalone DH+	8K EEPROM (1785-MJ)	1770-XY
PLC-5/12	4 (1 resident chassis)	none	<ul style="list-style-type: none"> • 128 I/O with 8-pt modules ¹ • 256 I/O with 16-pt modules ¹ • 512 I/O with 32-pt modules ¹ 			standalone, adapter DH+	8K EEPROM (1785-MJ)	
PLC-5/15	4 (1 resident chassis)	3 (up to 12 physical devices)	<ul style="list-style-type: none"> • 512 I/O ¹ • 512 inputs and 512 outputs using 16- or 32-pt modules ² 	6K (expands to 14K)		standalone scanner (local and remote I/O) adapter DH+	<ul style="list-style-type: none"> • 4K RAM expansion, 1785-MR • 8 K RAM expansion, 1785-MS • 8K EEPROM (1785-MJ) 	
PLC-5/25	4 (1 resident chassis)	7 (up to 28 physical devices)	<ul style="list-style-type: none"> • 1024 I/O ¹ • 1024 inputs and 1024 outputs using 16- or 32-pt modules ² 	13 K (expands to 21K)	2 ms/K words (bit logic) 8 ms/K words (typical)	standalone scanner (local and remote I/O) adapter DH+	<ul style="list-style-type: none"> • 4K RAM expansion (1785-MR) • 8 K RAM expansion (1785-MS) • 8K EEPROM (1785-MJ) • 16K EEPROM backup, 1785-MK 	

¹ Any mix of I/O.² Maximum I/O possible using 16-pt modules with 2-slot addressing or 32-pt modules with 1-slot addressing. Modules must alternate IOIOIO in the chassis slots.

Battery Specifications

Battery Type

Classic PLC-5 processors use 1770-XY batteries, which contain less than 1/2 gram of lithium, or 3.6V, "AA" size Tadiran TL 5104 type AEL/S lithium batteries with pressure contact terminals.

Average Battery Lifetime Specifications

At this temperature:	Power off 100%:	Power off 50%:
60°C	329 days	1.4 yrs

Symbols

Empty, [-1](#), [3-1](#)

B

Backplane current, [A-1](#)

Battery, [A-3](#)

lifetime specifications, [A-4](#)

C

Certification, [A-1](#)

Clock, processor, [A-1](#)

E

EEPROM, [A-3](#)

Environment specifications, [A-1](#)

I

I/O addressing, [A-1](#)

I/O scan, discrete, [A-1](#)

P

Processor, specifications, [A-1](#)

Processor memory, [A-3](#)

R

Rack addressing capability, [A-3](#)

S

Shock specifications, [A-1](#)

Specification, battery, [A-4](#)

Specifications, [A-1](#)

V

Vibration specifications, [A-1](#)



Allen-Bradley Publication Problem Report

If you find a problem with our documentation, please complete and return this form.

Pub. Name Classic PLC-5 Programmable Controller Quick Start for the Experienced User

Cat. No. 1785-LT, -LT2, -LT3, -LT4 Pub. No. 1785-10.3 Pub. Date October 1996 Part No. 955126-54

Check Problem(s) Type:	Describe Problem(s):	Internal Use Only
<input type="checkbox"/> Technical Accuracy	<input type="checkbox"/> text <input type="checkbox"/> illustration	
<input type="checkbox"/> Completeness What information is missing?	<input type="checkbox"/> procedure/step <input type="checkbox"/> illustration <input type="checkbox"/> definition <input type="checkbox"/> example <input type="checkbox"/> guideline <input type="checkbox"/> feature <input type="checkbox"/> explanation <input type="checkbox"/> other	<input type="checkbox"/> info in manual (accessibility) <input type="checkbox"/> info not in manual
<input type="checkbox"/> Clarity What is unclear?		
<input type="checkbox"/> Sequence What is not in the right order?		
<input type="checkbox"/> Other Comments Use back for more comments.		


Your Name _____ Location/Phone _____

Return to: Marketing Communications, Allen-Bradley Co., 1 Allen-Bradley Drive, Mayfield Hts., OH 44124-6118 Phone: (216)646-3176
FAX: (216)646-4320


PLEASE FASTEN HERE (DO NOT STAPLE)

Other Comments

PLEASE FOLD HERE



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 18235 CLEVELAND OH

POSTAGE WILL BE PAID BY THE ADDRESSEE

 **Rockwell** Automation

Allen-Bradley

PLEASE REMOVE



Allen-Bradley, a Rockwell Automation Business, has been helping its customers improve productivity and quality for more than 90 years. We design, manufacture and support a broad range of automation products worldwide. They include logic processors, power and motion control devices, operator interfaces, sensors and a variety of software. Rockwell is one of the world's leading technology companies.



Worldwide representation.

Argentina • Australia • Austria • Bahrain • Belgium • Brazil • Bulgaria • Canada • Chile • China, PRC • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Ecuador • Egypt • El Salvador • Finland • France • Germany • Greece • Guatemala • Honduras • Hong Kong • Hungary • Iceland • India • Indonesia • Ireland • Israel • Italy • Jamaica • Japan • Jordan • Korea • Kuwait • Lebanon • Malaysia • Mexico • Netherlands • New Zealand • Norway • Pakistan • Peru • Philippines • Poland • Portugal • Puerto Rico • Qatar • Romania • Russia-CIS • Saudi Arabia • Singapore • Slovakia • Slovenia • South Africa, Republic • Spain • Sweden • Switzerland • Taiwan • Thailand • Turkey • United Arab Emirates • United Kingdom • United States • Uruguay • Venezuela • Yugoslavia

Allen-Bradley Headquarters, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414 382-2000 Fax: (1) 414 382-4444