

BJ192M Panel Mounting Energy Meter

User Manual

Version: 1.1

Read me

When you use BJ192M-9X4 series Energy Meter, be sure to carefully read this user manual, and be able to fully understand the implications, the correct guidance of operations in accordance with user manual, which will help you make better use BJ192M-9X4 series Energy Meter, and help to solve the various problems at the scene.

1. Before the meter turning on the power supply, be sure that the power supply within the provisions of the instrument;
2. When installation, the current input terminal must non-open, voltage input terminals must Non-short circuit;
3. Communication terminal (RS232 or RS485) is strictly prohibited to impose high pressure;
4. Be sure the instrument wiring consistent with the internal system settings;
5. When communicating with the PC, instrument communication parameters must be consistent with the PC



- **Please read carefully before using this user manual**
- **Please save this document**

Directory

CONTENTS

Page

1. SUMMARIZE-----	3
2. APPLICATIONS -----	3
3. FEATURES -----	4
3.1. - Electricity metering -----	4
3.2. - Specifications -----	5
4.- INSTALLATION AND START-UP -----	7
4.1. – Installation -----	7
4.2. - Connection Terminal (see label on the rear part) -----	8
4.3. - Connection Drawing for the BJ192M-9X4 -----	10
5. SCREEN DISPLAY -----	12
5.1. - Panel Diagram -----	12
5.2. - Display Summary -----	12
6. OPERATING INSTRUCTIONS -----	13
7. SETUP PROCEDURE -----	14
7.1. - Password Enter -----	14
7.2. - System Display Settings -----	14
7.3. - Input Signal Selection -----	16
7.4. - Communication Preferences -----	20
7.5. - Menu Structure -----	22
7.6. - Display Character instructions -----	23
8. SAFETY CONSIDERATIONS -----	24
9. MAINTENANCE -----	24
10. TECHNICAL SERVICE -----	25

1. - SUMMARIZE

BJ192M-9X4 Series Energy Meter is used for power quality monitoring, factory automation and building automation.

It can measure all of the power parameters in power grid:

Current,
Voltage,

Active Energy,
Reactive Energy.

BJ192M-9X4 also can provide 2 channel pulse output. Used in generators, motors of the distributed detection and any other three phase AC grid energy measurement, automatic control system, on-line monitoring display.

It can replace the traditional mechanical type energy meter, with higher measurement accuracy, convenient on-site wiring, improve system reliability. BJ192M-9X4 Energy Meter has serial port, can connection to PC; Uses Modbus to set programming and read the data.

Based on this energy meters, can simply set up a monitoring system, that only use the IPC and central software.

2. - APPLICATIONS

- ◆ Basic electrical parameter measurement;
- ◆ Energy Measurement;
- ◆ Replace the mechanical type three-phase energy meter;
- ◆ Medium and low pressure systems;
- ◆ SCADA, EMS, DCS integrators.

3. - FEATURES

3.1. - Electricity metering

By means of an internal microprocessor it simultaneously measures:

Parameter	Symbol	A-phase	B-phase	C-phase	Total
Single phase voltage	V	x x	x x	x x	
*Phase-phase voltage	V	x x	x x	x x	
Current	A	x x	x x	x x	
Active energy	Wh	x	x	x	x x
Reactive energy	Varh	x	x	x	x x

Notes: Phase-phase voltage is Uab, Ubc, Uca, voltage data determined by the different wiring
 Available: **x**: Display and communications **xx**: Communications.

The 192M-9X4 delivers the visualization of above listed parameters by means of three line 4-digit, led type displays. Upper line for parameter indicate, lower tow line total 8 digital for energy data read in the screen.

“▽”Indicator LED shows currently displayed the parameters, “○ K” means in thousands, “○ M” means in million.

OTHER FEATURES

- Low-size (96 x 96 mm), panel-mounting meter.
- True R.M.S. measuring system.
- Energy measurement (indication through two line 8 led)
- Optional display total energy in the display
- RS-485 or RS-232 type communication to a PC (optional)

3.2. - Specifications

1. - Reference standard:

Basic electricity: GB/T13850-1998 (IEC688-1992)

Active power: GB/T17215-2002 (IEC61036:2000)

Reactive power: GB/T17882-1999 (IEC61268:1995)

2- Accuracy standards

Parameter	Accuracy	A phase	B phase	C phase	All
Voltage	0.5%fs	V1	V2	V3	
Current	0.5%fs	A1	A2	A3	
Active Energy	1%rd	Wh	Wh	Wh	Wh
Reactive Energy	2%rd	varh	varh	varh	varh

3. - Input

Voltage: Rated 400V (optional 100V)

Current: Rated 5A (optional 1A)

Frequency: 45-65Hz

4. - Load

Voltage: <0.5VA / phase (rated 220V)

Current: <0.5VA / phase (rated 5A)

5. - Overload

Current: 1.2 times rated continuous; 10 seconds for 10 times the rated

Voltage: 1.2 times the rated continuous; 10 seconds for 800V

6. - Dielectric strength

IEC 688 / IEC 255-3 (1989)

2kV AC RMS 1 minute, between input / output / case / power supply

7. - EMC Test

	standard	Test voltage
Electrostatic discharge immunity test:	IEC-61000-4-2 level 4	8Kv
Electrical fast transient burst immunity test	IEC61000-4-4 level 3	Input 1kV; Power supply 2kV
Surge (Shock) immunity test	IEC61000-4-5 level 4	common mode test voltage 4kV

8. - Work environment

Temperature: -20℃~ +60℃

Humidity: RH 20%~95% (No condensation)

9. - Protection

Panel: IP40

10. - Storage Conditions

Temperature: -25℃~+70℃

Humidity: RH 20%~95%

11. - Working Power

AC 80-265V, 45-65Hz, DC 80-380V

DC 20-60V (Optional)

Maximum power consumption 6W

12. - Dimensions

L × W × H =96mm×96mm×128mm

13. - Installation hole size

L × W = (91+0.8mm) × (91+0.8mm)

4.- INSTALLATION AND START-UP



The manual you hold in your hand contains information and warnings that the user should respect in order to guarantee a proper operation of all the instrument functions and keep its safety conditions. The instrument must not be powered on and used until its definitive assembly on the cabinet's door.

If the instrument is not used as manufacturer's specifications, the protection of the instrument will be damaged.

When any protection failure is suspected to exist (for example, it presents external visible damages), the instrument must be immediately powered off. In this case contact a qualified service representative.

4.1.- Installation

Mounting

Instrument is to be mounted on panel (cut-out $91+0.8 \times 91+0.8 \text{ mm}$). All connections keep inside the cabinet.

Note that with the instrument powered on, the terminals could be dangerous to touching and cover opening actions or elements removal may allow accessing dangerous parts. Therefore, the instrument must not be used until this is completely installed.

Notes:

Input signal: BJ192M using a separate acquisition calculate for each measurement channel, to ensure consistent in use, for different load forms, its a variety of connection mode.

A. Voltage input:

Input voltage should not exceed the rated input voltage products (100V or 400V), Otherwise, should use external CT, the input voltage to be installed in the 1A fuse.

B. Current Input:

Standard input current is 5A, if greater than 5A should use external CT.

Even if you are using on the CT are connecting with other instruments, wiring methods should be used in series. Before remove the current input connection, must be sure to disconnect the primary circuit or shorted secondary circuit of CT. Suggest using the terminal block, please not directly connect to CT, in order to facilitate disassembly.

C. Please make sure that the input voltage and current corresponding to the same phase

**sequence, and the same direction; Otherwise, the Values and symbols will wrong!!
(Power and Energy)**

The input network configuration of instrument depends on the CT number of the system:
in the condition of 2 CT, select the three-phase, three-lines two components;
in the condition of 3 CT, select the three-phase, four-lines three component mode.

Instrument connection mode, set of the instrument (programming input network NET) should be the same load wiring as measured wiring. Otherwise, the measurement instrument will lead to incorrect voltage or power.

In three-phase three-wire mode, the measurement and shows the line voltage;
In three-phase four-wire mode, the measurement and shows the phase voltage.

Auxiliary power:

BJ192M Series Energy Meter with universal (AC / DC) power input, if not for a special statement, we provide the 220VAC/DC or 110VAC/DC power interface for standard products. Instruments limit work power supply : AC / DC :80-270V, please ensure that the auxiliary power can match for BJ192M series meter to prevent damage to the product.

- A. Suggest install 1A fuse in the fire line side.
- B. For the areas with poor power quality, suggest install lightning surge suppressor and rapid burst suppressor to prevent lightning strikes.

4.2. - Connection terminal (see label on the rear part)

Terminal description

Upper connection terminal

1	2		58	59	60	46	47	48	49
Power supply			RS485A	RS485B	GUD	AP+	AP-	RP+	RP-

1. *Supply voltage input: 0 V

2. *Supply voltage input: 220 Va.c.

58. RS-485 (+)

59. RS-485 (-)

60. RS-485 (GND)

46. Active energy Pulse output +

47. Active energy Pulse output -

48. Reactive energy Pulse output +

49. Reactive energy Pulse output -

Lower connection terminal

Three-phase network.- 4 wires

4	5	6	7	8	9	11	12	13	14
A-phase Current	B-phase Current			C-phase Current		Ua	Ub	Uc	Un

- 4. Current A-phase - S1 input
- 5. Current A-phase - S2 input
- 6. Current B-phase - S1 input
- 7. Current B-phase - S2 input
- 8. Current C-phase - S1 input
- 9. Current C-phase - S2 input
- 11. Voltage A-phase input
- 12. Voltage B-phase input
- 13. Voltage C-phase input
- 14. Neutral Voltage input


Three-phase network.- 3 wires

4	5	6	7	8	9	11	12	13	14
A-phase Current				C-phase Current		Ua		Uc	Ub


- 4. Current A-phase - S1 input
- 5. Current A-phase - S2 input
- 8. Current C-phase - S1 input
- 9. Current C-phase - S2 input
- 11. Voltage A-phase input
- 13. Voltage C-phase input
- 14. Voltage B-phase input

4.3. - Connection Drawing for the BJ192M-9X4

a. - Three-phase network.- 4 wires (low voltage) :



b. - Three-phase network.- 3 wires (low voltage) :




IMPORTANT REMARK!

If power = -0.01 is shown for any of the phases and voltage and current are not zero for this phase, check out following points:

- Assure that A, B and C phases coincide in voltage and current.
- Correct polarity? Reverse the current transformer placed at this phase.

5. SCREEN DISPLAY

5.1. - Panel diagram



5.2. - Display Summary

No.	Display	Explanation
1	Digital display module	Three lines 4 digital LED show power data, include voltage, current, power, power factor, frequency, etc.; And the contents of the programming menu
2	Indicator of the data Unit	"K" means thousand; "M" means million
3	Indicator of the current display data	4 LED show the display module reading data
4*	Enter key	For menu selection and confirmation
5*	Menu key	Used to open the menu and return to previous menu
6*	Up and Down key	Set the programming value

Note: Please see detail instructions of “*” items at “**OPERATION MODE**”.

6. - OPERATION MODE

The instrument has three line displays. Each one has also a LED type indicator (red colour). Every led will be on according to the parameter presently shown in screen.

When the 192M-9X4 is powered up, all the LED indicator will on, and meter start self- test, after some seconds, the meter is ready for operation and shows one of the available screens.



Parameters on display can be switch by pressing the key  or . LED on the right indicates the parameters shown on screen at any moment.

When the first led (red) is on, it means that VOLTAGE values are shown on screen, that is, the user can read the voltage of the A-phase (Va), voltage of the B-phase (Vb) and voltage of the C-phase (Vc).

Whether the key  is press, the next led will be on, so indicating that for this screen CURRENT values of each phase are now shown.

Pressing again the key , the next led will be on, and the screen will shown following parameters, and so successively.

At programming display mode, press  and  to increase or decrease the value, pressing the key  and  or  and  the instantaneous at the same time, value can increase or decrease number "x10".



Pressing the "Manu" key can open the programming menu and return to previous menu.



Pressing the "Enter" key, you exit it with saving any modification that you might have done, in menu operation press "Enter" key ,user can go to the next menu.

7. - SETUP PROCEDURE


The SETUP procedure of the BJ192M-9X4 is performed by means of several SETUP options. Once into the SETUP, use the keyboard to select different options and enter required variables:

1. Password enter;
2. Choice of default initial screen;
3. Input signal selection;
4. Communication preferences.

7.1. - Password enter

A 4-figure password is required to be entered (in case that this password is not correct, will not be set on the meter).

At normal display mode, press **(Manu)** to enter the programming mode, meter display, then press **(←)**;

Meter display “”,


Ask for the password. Press **(V)** and **(^)** to increase or decrease the number, to switch password. After password switch press **(←)** to confirm the input.


If password is correct, meter can enter next setting.

7.2. - System display settings

7.2.1. - Choice of default initial screen


This option allows choice among **fixed or rotary screen**:

After password, you will see the meter show “Set” like this:



Press  to go to the level 2 menu, use  and  to choose item "DISP",

You will see the meter show "Display" like this:



Press , then enter the level 3 menu, user can use  and  to choose number 0-6, meaning as the following:

0. Rotary screen display:

Meter can show data as this cycle: Current; Voltage; Active power, Reactive Power, Power factor; Frequency; Active Energy; Reactive Energy.

All 5 screens are successively shown at intervals of 5 s.

1-5 Fixed screen:

1. Three-phase current display:

Meter display always three-phase current data in 3 line LED display, shows each phase current data.

2. Three-phase voltage display

Meter display always three-phase voltage data in 3 line LED display, shows each phase voltage data.

3. Active/reactive power and power factor display:

On line 1 LED, meter shows total active power data;

On line 2 LED, meter shows total reactive power data;

On line 3 LED, meter shows total power factor.

4. Frequency display:

Meter display frequency data on line 1 LED.

5. Active energy display:

Meter display active energy on 2 line LED, show 8 digital data, 2 decimal.


6. Reactive energy display:

Meter display reactive energy on 2 line LED, show 8 digital data, 2 decimal.


7.2.2. - Clear energy counters

In “Set” menu, user can deleting energy counters.

Enter “Set” menu, in level 2 menu, use  and  to choose item “CLr.E”, meter show like this:



Press  to confirm clear all the energy data, meter display:



And then press  again, to save the operation and exit.

7.3. - Input signal selection

Press , return to level 1 menu.

In this section, user will set:

1. Input net mode;
2. Voltage measure range select;
3. Current measure range select;
4. Voltage transformation ratio;
5. Current transformation ratio.

7.3.1.- Choice the input net mode

In level 1 menu, use  and  to choose item “INPT”, meter show like this:



then press , enter the level 2 menu, choose “NET”, meter show:

1n.Pf
nEf

then press  again, enter the level 3 menu.

Use  and  to select the right wiring mode, meter show like this:

1n.Pf	Or	1n.Pf
nEf		nEf
n3.4		n3.3

N.3.4: Three-phase four-wire, wiring reference section **4.3 a.**

N.3.3: Three-phase three-wire, wiring reference section **4.3 b.**

Note: Select the wiring mode must match actual wiring, or the reading data will go wrong.

7.3.2.- Choice voltage measure range

In level 1 menu of “INPT”.

Choose item “U.SCL”, meter show like this:

1n.Pf
U.SCL

then press , enter the level 3 menu, user can change the voltage range:

1n.Pf	Or	1n.Pf
U.SCL		U.SCL
400		100

400V: Maximum measured value is 400V

100V: Maximum measured value is 100V

Note: Select a different range will affect the accuracy of measurements, if the accuracy is 0.5.


Select 100V range, means the minimum scale value is 0.5V (100 x 0.5%);

Select 400V range, means the minimum scale value is 2V (400 x 0.5%).


7.3.3.- Current measure range select

In level 1 menu of "INPT".

Choose "I.SCL", meter show like this:



then press  , enter the level 3 menu, user can change the current range:



5A: Maximum measured value is 5A.

1A: Maximum measured value is 1A.

Note: Select a different range will affect the accuracy of measurements, if the accuracy is 0.5.


Select 1A range, means the minimum scale value is 0.005A (1 x 0.5%);

Select 5A range, means the minimum scale value is 0.025A (5 x 0.5%).


7.3.4- Voltage transformation ratio

In level 1 menu of "INPT".

Choose item "T.U" , meter show like this:



then press , enter the level 3 menu, allowing us to set the current transformer.



To write or modify the value just repeatedly press  or , pressing the key  and  or  and  the instantaneous at the same time, value can increase or decrease the number “x10”, Input value is 1~9999.


Note: The input values represent the voltage transformer (primary side voltage) / (secondary side voltage) .

Secondary side voltage is 100V or 400V; user set it at section **7.3.2**


7.3.5. - Current transformation ratio

In level 1 menu of “INPT”.

Choose the item “T.I”, meter show like this:



then press , enter the level 3 menu, allowing us to set the current transformer.



To write or modify the value just repeatedly press  or , pressing the key  and  or  and  the instantaneous at the same time, value can increase or decrease the number “x10”, Input value is 1~9999.

Note: The input values represent the current transformer (primary side voltage) / (secondary side current) .

Secondary side current is 1A or 5A, user set it at section **7.3.3**.

7.4. - Communication Preferences

Press , return to level 1 menu.

In this section, user will set:


1. Meter communication address;
2. Baud rate;
3. Communication format.
4. Data format

Note: Not all the meter have communication function, please make sure your purchase meter first, if no communication mode, you can skip this section.


7.4.1. - Meter communication address setting

One or some BJ194...meter can be connected to a P.C. With this system we can get all the parameters in one central point of reading. The BJ194..., has a serial RS-485 or RS-232 type output (according to the model). If we connect more than one device to the same communication line (RS-485), we have to assign to each of them a different code or direction (from 1 to 247), since the P.C. needs the identification of every measuring point.

In level 1 menu, choose the item "CONN", the meter show like this:



Then press , enter the level 2 menu, choose the item "SN", meter show like this:




Then press  to level 3 menu, to write or modify the value just repeatedly press  or , pressing the key  and  or  and  the instantaneous at the same time, value can increase or decrease the number "x10", Input value is 1~247.


7.4.2.- Communication Baud rate setting

In level 1 menu of “CONN”.

Choose item “BAUD”, meter show like this:




then press , enter the level 3 menu, allowing us to set the Baud rate 4800 or 9600.


 Or
 


7.4.3.- Choose communication format

In level 1 menu of “CONN”.

Choose item “Protocol”, meter show like this:



then press , enter the level 3 menu, allowing us to set the Word communication or Byte communication. **(Factory setting word communication)**



7.5. – Menu Structure

level 1	Level 2	Level 3	Description
(Password) CODE	—	Password data 9999	Only when the correct password to enter programming)
			(The default password is 0001)
(System set) SET	DISP	0-6	Select the display mode, automatic or individual
	CLR.E	—	Energy will clear after confirmed
(Signal input) INPT	(Net) NET	N.3.4 and N.3.3	Select the input signal network measurement
	(Voltage Range) U.SCL	400V and 100V	Select the range of measured voltage signal
	(Current Range) I.SCL	5A and 1A	Select the range of measured current signal
	(Voltage transformation ratio) T.U	1-9999	Setting voltage signal transformation ratio = 1 / 2 scale
	(Current transformation ratio) T.I	1-9999	Setting current signal transformation ratio = 1 / 2 scale
(Communication Parameters) CONN	(Address) SN	1-247	Instrument address range 1-247
	(Communication speed) BAUD	4800~9600	Baud Rate 4800、9600
	Protocol PROT	Word or Byte communication	Factory default communication mode for the word

7.6. - Display Character instructions

Abbreviation	Panel Display	Specification	Abbreviation	Panel Display	Specification
Code		Code	r.l		Current Transformation Ratio
Set		Set	Conn		Communication
disp		Disply	Sn		Communication Address
b.LED		Bright	baud		Baud Rate
Clr.E		Clear	DATA		Data Format
In.pt		Input	protocol		Protocol Format
net		Net	word		Word Mode
n.3.3		Three-phase Three-Line Net	byte		Byte Mode
n.3.4		Three-phase Four-Line Net	Wh		Active Power
U.scl		Voltage Range	Varh		Reactive Power
r.U		Voltage Transformation Ratio	Save yes		Save Way
I.scl		Current Range			

8. - SAFETY CONSIDERATIONS



All installation specification described at the previous chapters named:
INSTALLATION AND STARTUP, INSTALLATION MODES and SPECIFICATIONS.

Note that with the instrument powered on, the terminals could be dangerous to touching and cover opening actions or elements removal may allow accessing dangerous parts. This instrument is factory-shipped at proper operation condition.

9. - MAINTENANCE

The 192M does not require any special maintenance. No adjustment, maintenance or repairing action should be done when the instrument open and powered on, should those actions are essential, high-qualified operators must perform them.

Before any adjustment, replacement, maintenance or repairing operation is carried out, the instrument must be disconnected from any power supply source.

When any protection failure is suspected to exist, the instrument must be immediately put out of service. The instrument's design allows a quick replacement in case of any failure.

10. - TECHNICAL SERVICE

FAQ's

1. The BJ-192M Energy Meter, once cabled and connected is seen to give a correct voltage and current reading, but shows negative values for active power (generation).

This is an error with the cabling for the current transformer secondary; the direction of the transformer current has to be respected as shown in the connection diagram. The current transformers have a two face primary; the current must pass from P1 to P2 giving the result in secondary (S1 and S2) of 5 amps.

The error stems from:

a). The current transformers have been incorrectly installed. As a result it gives the direction of the current as passing from P2 to P1; to resolve this problem, the current transformer does not have to be dismantled and installed again, but the transformer secondary (S1 and S2) just has to be inverted.

b). The connection of the current secondary in the current transformers have been incorrectly connected; to resolve this problem just connect the S1 transformer secondary to the S1 on the meter and the S2 on the current transformer to the S2 on the meter

2. The BJ-192M, once cabled and connected, is seen to give an incoherent Power factor and $\cos\Phi$ reading (-0.01 or similar).

This is again a current transformer and voltage phase connection error phase A, must correspond to the current transformer installed in phase A; phase B, must correspond to the current transformer installed in phase B; and phase C, must correspond to the current transformer installed in phase C.

This connection is clearly shown on the back of the analyzer.

3. The BJ-192M is measuring in average voltage and is displaying the secondary voltage (for example 110 volts).

Ensure that the voltage Transformer ratio has been correctly set (see section on **7.3.4**).

4. The BJ-192M does not correctly display the current reading. It shows values varying between 0 to 5 amps of current.
Ensure that the Transformer ratio has been correctly set; once correctly set the current measurement shall be shown correctly (see section on **7.3.5**).

For any inquiry about the instrument performance or whether any failure happens, contact to Blue Jay's technical service.

Blue Jay - After-sales service

*Building 13, 2-8, Jialing third village Pioneer Park,
Jiangbei District , 400020 Chongqing*

*Tel - + 0086 023 86850812
Fax - + 0086 023 67636974
E-mail : tech@cqbluejay.com*