Troubleshooting FlowLink

Polar FlowLink is a plug-in product. You computer should automatically recognize it without additional driver installation.

In Windows:

If the computer does not recognize the device for some reason a notice **USB Device not Recognized** is shown in the computer taskbar.

Try these troubleshooting tips to enable connection.

1. Check that you have installed the latest Windows drivers correctly by opening the **Device Manager**.

On Windows XP: Start → Control panel → System → Hardware → Device Manager On Windows Vista: Start → Control panel → System and Maintenance → Device Manager. On Windows 7: Start → Control panel → Device Manager.

If you are prompted for an administrator password or confirmation, type the password or provide confirmation.

2. In Device Manager, go to **Human Interface Devices** \rightarrow double click **USB Human Interface Device.**

Picture 1. Device Manager on Windows XP.




Picture 2. Device Manager on Windows 7.




3. Check that the device is working properly.

Picture 3. Device Properties on Windows XP.



Picture 4. Device Properties on Windows7.




Windows Vista and Windows 7: To find FlowLink from all the listed HID-compliant devices, please select Details tab. Select Hardware Ids from Property drop-drow list. Check device VID (vendor id) and PID (product id). FlowLink has them as follows:

- VID 0DA4
- PID 0003

If the USB Human Interface Device is marked with an error and device status states '*This device cannot start*', try plugging the FlowLink into another USB port / using an USB extension cable or HUB. If these do not help, click **Troubleshoot**. For error code explanations, see Microsoft

Help and Support (e.g. <u>Code 10-related errors</u> / <u>error codes generated by Device Manager in Windows XP Professional</u>).

Picture 5. Device status: 'cannot start'.




In Mac OS X:

Also in Mac the FlowLink should be automatically recognized and the needed drivers are included in Mac OS X itself.

If the yellow Data light does not lit and FlowLink is not detected rebooting the computer, so that the FlowLink is kept plugged in USB port, should help.

Check also from System Profiler that FlowLink is recognized in USB devices.

To enter to the System Profiler, go to the Apple menu and select About this Mac and then More info.



Graphics/Displays Hardware RAID

PC Cards PCI Cards Parallel SCSI Power Printers SAS

Memory

Serial-ATA

USB ▼ Network

> AirPort Card Firewall

USB Device Tree

▼USB Bus

FLOWLink

Apple Internal Keyboard / Trackpad

IR Receiver

▼USB Bus

▼ BRCM2046 Hub

Bluetooth USB Host Controller

▼USB High-Speed Bus

Built-in iSight

▼USB High-Speed Bus

Internal Memory Card Reader

FLOWLink:

 Product ID:
 0x0003

 Vendor ID:
 0x0da4

 Version:
 0.00

 Serial Number:
 C943P7060198027

 Speed:
 Up to 12 Mb/sec

 Manufacturer:
 POLAR Electro Oy

 Location ID:
 0x04100000

Current Available (mA): 500 Current Required (mA): 64