




深圳开源通信有限公司

OpenVox -Best Cost Effective Asterisk® Cards

OpenVox® B800P User Manual



Written by: James.zhu

Email: james.zhu@openvox.cn, zhulizhong@gmail.com

Date: 7/11/2007

Version: 0.01



深圳开源通信有限公司

OpenVox -Best Cost Effective Asterisk® Cards

OpenVox Communication Co. Ltd.

Address: F/2, Building No.14, Shangsha Science & Technology Park,
No. 9283, Binhe Road, Futian District, ShenZhen , Guangdong 518048, China

Tel: +86-755-82535095, 82535461 Fax: +86-755-82535174

E-Mail: sales@openvox.com.cn

IM for Sales: betty_yljiang@hotmail.com rubyzhang1217@hotmail.com

IM for Technical Support: support@openvox.com.cn, zhulizhong@gmail.com, zhulizhongum@hotmail.com

Business Hours: 9:30AM-17:30PM from Monday-Friday

URL: www.openvox.com.cn

Thank You for Choosing OpenVox Products!

Table of Contents

Chapter 1	Overview.....	4
Chapter 2	Card Installation and Configuration.....	6
Chapter 3	F&Q.....	14
Chapter 4	References	20
Chapter 5	Hardware Setting.....	21

Chapter 1 Overview

1. What is B800P

B800P is a PCI 2.2 compliant card supporting 8 BRI S/T interfaces, with an onboard multi NT power feeding circuits. NT/TE mode can be individually configured on each of the 8 interfaces.

B800P can be implemented for building Open Source Asterisk® based systems such as ISDN PBX and VoIP gateway.

Target Applications:

High Performance ISDN PC Cards
ISDN PABX for BRI
VoIP Gateways
ISDN LAN Routers for BRI
ISDN Least Cost Routers for BRI
ISDN Test Equipment for BRI

Main Features:

Eight integrated S/T interfaces
ITU-T I.430 and TBR 3 certified and S/T ISDN supporting in TE and NT mode
Integrated PCI bus interface (Spec.2.2) for 3.3V and 5V signal environments
DTMF detection on all B-channels
Multiparty audio conferences bridge
Onboard power feeding for 8 NT interfaces
PCM bus connectors daisy chaining
Each of the 8 interfaces can be independently configured for TE or NE mode
Full software and hardware compatible with Junghanns.NET™ Bristuff driver and mISDN® driver
Application ready: use Asterisk® to build your IP-PBX/Voicemail system
RoHS compliant
Certificates: CE, FCC

2. What is Asterisk®:

The Definition of Asterisk® is described as follow:

Asterisk® is a complete PBX in software. It runs on Linux, BSD, Windows (emulated) and provides all of the features you would expect from a PBX and more. Asterisk® does voice over IP in four protocols, and can interoperate with almost all standards-based telephony equipment using relatively inexpensive hardware.




Figure 1: Asterisk® Setup

Source (<http://www.siriusit.co.uk/uploads/images/consulting/Asterisk®Setup.gif>)

Asterisk® provides Voicemail services with Directory, Call Conferencing, Interactive Voice Response, Call Queuing. It has support for three-way calling, caller ID services, ADSI, IAX, SIP, H.323 (as both client and gateway), MGCP (call manager only) and SCCP/Skinny(voip-info.org).

Chapter 2 Card Installation and Configuration

1. Hardware Installation and Setup

1) Configure the Jumper Settings

Please check the jumper setting first. To install B800P, user should follow these steps:

A. Setting Card ID Switch

User should pay attention to the card id switch, if user wants to install more than one cards of B800P in one pc. Please follow these produces:

1. The card id of the first card should be set to 0, and the second card should be set to 1, and so on.
2. The first card is a card that will be initialized (i.e installing driver) first when system is booting.
3. At most of cases, Linux will initialize PCI devices according to PCI slot order. The slot is nearest to the CPU will be initialized first; the slot at the far end from CPU will be initialized at last. That is to say that if user has more than one cards of B800P in pc, the one is nearest to CPU should be set to card id 0.
4. For more details about Card ID, please check F&Q section.

B. Adjusting Termination of S/T Interface (100 ohm)

1. If a port works on NT mode, user should set jumper to CONNECT (ON).
2. If a port works on TE mode, Theoretically it should be to OPEN(OFF), but user might connect to some non-standard isdn terminal equipments that do not have terminal resistors. If you have such equipments, you should set it to CONNECT(ON).

C. Power Feeding Connector

These jumpers control whether the card will feed power to the external isdn terminal. User should adjust accordingly based on these produces:

- ✧ If the port will work on TE mode, user MUST set the jumper to OPEN(OFF)
- ✧ If this port will work on NT mode, the ISDN terminal requires ISDN power supply, user should set the jumper to CONNECT(ON).
ISDN terminal does not require ISDN power supply, user should set the jumper to OPEN(OFF).

D. Power Feeding Input

If one of the eight power feeding connectors is CONNECT(ON), user should connect a D-type connector from pc power supply to this jack, the D-type connector is used to provide power to your CDROM and 3.5" HDD.

E. Power Supply Selection

Some newest model PCs do not provide +5V on the PCI slots, at those cases, use has to set the jumper to 3.3V.

F. PCM IN/PCM OUT

These are for future usages.

- 2) Power off PC, remembering unplug the AC power cable
- 3) Insert B800P card into a 3.3V or 5.0V PCI slot
- 4) Plug the hard disk power supply cable(D style) to power feeding input jack if needing providing power to external equipments, please refer jumper setting section for the detail
- 5) Plug back the AC power cable, and power on PC

If user wants to know the details about hardware configuration of B800P, please refer hardware setting section.

2. Software Installation and Setup

B800P supports original Bristuff driver form [junghanns.net](http://www.junghanns.net)[™]. Users can download it from <http://www.junghanns.net/>. There are few steps to install the driver drivers.

- 1) Checking the B800P hardware by command: `lspci -vvvvvvvvv`. The card information should be found like figure 2.

```
02:04.0 ISDN controller: Cologne Chip Designs GmbH ISDN network Controller [HFC-8S] (rev 01)
Subsystem: Cologne Chip Designs GmbH Unknown device e998
Control: I/O+ Mem+ BusMaster- SpecCycle- MemWINV- VGASnoop- ParErr- Stepping- SERR- FastB2B-
Status: Cap+ 66MHz- UDF- FastB2B- ParErr- DEVSEL=medium >TAbort- <TAbort- <MAbort- >SERR- <PERR-
Interrupt: pin A routed to IRQ 169
Region 0: I/O ports at a000 [size=8]
Region 1: Memory at f7004000 (32-bit, non-prefetchable) [size=4K]
Capabilities: [40] Power Management version 2
Flags: PMEClk- DSI+ D1+ D2+ AuxCurrent=0mA PME (D0+,D1+,D2+,D3hot+,D3cold-)
Status: D0 PME-Enable- DSel=0 DScale=0 PME+
```

Figure 2: PCI_B800P

2) Checking the supporting packages

If there is no kernel source in the system, user should install it. User can run `yum` again: `yum install kernel-devel`. If user runs this command `yum` will install the sources for your current version of the kernel.

Please check the availability of some other packages:

```
rpm -q bison
rpm -q bison-devel
rpm -q ncurses
rpm -q ncurses-devel
rpm -q zlib
rpm -q zlib-devel
rpm -q openssl
rpm -q openssl-devel
rpm -q gnutls-devel
rpm -q gcc
rpm -q gcc-c++
```

If any of those packages is not installed, install them by using `yum`

```
yum install bison
yum install bison-devel
yum install ncurses
yum install ncurses-devel
yum install zlib
yum install zlib-devel
yum install openssl
yum install openssl-devel
yum install gnutls-devel
yum install gcc
yum install gcc-c++
```

3) Downloading, unzipping and compiling driver

- A. Download the stable version of bristuff drivers from <http://www.junghanns.net/>, and copy the tar file to `/usr/src/`:

```
cp bristuff-<version>.tar.gz /usr/src/
cd /usr/src/
tar -xvzf bristuff-<version>.tar.gz
```

- B. Download OpenVox patch called `qozap.c` from www.openvox.com.cn. It contains a patched `qozap.c` file. User overwrites the original `qozap.c` file with the new `qozap.c` under `/usr/src/bristuff-<version>/qozap`.

C. Make links with kernel source:

```
ln -s /usr/src/kernels/2.6.18-8.el5-i686/ /usr/src/linux-2.6
```

Here, under /usr/src there is kernel source, user must create link linux-2.6 under /usr/src/. There are many files under /usr/src/bristuff-0.3.0-PRE-1y-j, please check:

```
[root@new-host bristuff-0.3.0-PRE-1y-j]# ls
asterisk          CHANGES      download.sh   ISDNguard     libpri
asterisk-1.2.23   compile.sh    INSTALL      libgsmat      libpri-1.2.4
asterisk-1.2.23.tar cwain         install.sh    libgsmat-0.0.2 libpri-1.2.4.tar
[root@new-host bristuff-0.3.0-PRE-1y-j]# cd ..
[root@new-host src]# cd bristuff-0.3.0-PRE-1y-j/
[root@new-host bristuff-0.3.0-PRE-1y-j]# ls
asterisk          CHANGES      download.sh   ISDNguard     libpri
asterisk-1.2.23   compile.sh    INSTALL      libgsmat      libpri-1.2.4
asterisk-1.2.23.tar cwain         install.sh    libgsmat-0.0.2 libpri-1.2.4.tar
[root@new-host bristuff-0.3.0-PRE-1y-j]# ls -l
total 27188
lrwxrwxrwx 1 root root      15 Sep 19 13:36 asterisk -> asterisk-1.2.23
drwxr-sr-x 25 root root    4096 Sep 20 12:14 asterisk-1.2.23
-rw-r--r-- 1 root root 19005440 Aug 20 16:50 asterisk-1.2.23.tar
-rw-r--r-- 1 root root   18405 Jul 25 15:40 CHANGES
-rwxrwxrwx 1 root root    2181 Jun  9 2006 compile.sh
drwxr-xr-x 3 root root    4096 Sep 20 12:08 cwain
-rwxrwxrwx 1 root root    781 Sep 20 09:45 download.sh
-rw-r--r-- 1 root root   2377 Apr 27 2005 INSTALL
-rw-r--r-- 1 root root    40 Jul 12 2004 install.sh
drwxr-xr-x 2 root root    4096 Sep 19 12:18 ISDNguard
lrwxrwxrwx 1 root root      14 Sep 19 13:36 libgsmat -> libgsmat-0.0.2
drwxr-xr-x 2 root root    4096 Sep 20 12:08 libgsmat-0.0.2
lrwxrwxrwx 1 root root      12 Sep 19 13:36 libpri -> libpri-1.2.4
drwxr-xr-x 2 1000 1000    4096 Sep 20 12:08 libpri-1.2.4
-rw-r--r-- 1 root root 348160 Sep 19 10:23 libpri-1.2.4.tar
drwxr-xr-x 2 root root    4096 Sep 19 12:18 patches
drwxr-xr-x 3 root root    4096 Sep 20 12:08 qozap
-rwxr-xr-x 1 root root    558 Sep 19 13:36 run_download.sh
drwxr-xr-x 4 root root    4096 Sep 19 12:18 SAMPLES
drwxr-xr-x 3 root root    4096 Sep 19 12:18 TESTING
drwxr-xr-x 3 root root    4096 Sep 20 12:09 zaphfc
lrwxrwxrwx 1 root root      13 Sep 19 13:36 zaptel -> zaptel-1.2.19
drwxr-xr-x 10 root root   12288 Sep 20 12:07 zaptel-1.2.19
-rw-r--r-- 1 root root 8345600 Sep 19 10:23 zaptel-1.2.19.tar
drwxr-xr-x 3 root root    4096 Sep 20 12:08 ztgsm
[root@new-host bristuff-0.3.0-PRE-1y-j]#
```

Figure 3: Files_underbri

D. Compiling Bristuff

```
cd /usr/src/usr/src/bristuff-0.3.0-PRE-1y-j
chmod 777 install.sh
./install.sh
```

Those steps will install zaptel, libpri, qozap and Asterisk®. After finishing those steps, if user installs Asterisk® for first time, under the source of Asterisk® directory, running: **make samples**.

- E. Modifying and loading modules for zaptel and qozap
vi /etc/zaptel, and edit the zaptel.conf like this:

```
loadzone=nl
defaultzone=nl
span=1, 1, 1, ccs, ami
# termtype: te
bchan=1-2
dchan=3
```

```
span=2, 2, 1, ccs, ami
# termtype: te
bchan=4-5
dchan=6
```

```
span=3, 3, 1, ccs, ami
# termtype: te
bchan=7-8
dchan=9
```

```
span=4, 4, 1, ccs, ami
# termtype: te
bchan=10-11
dchan=12
```

```
span=5, 5, 1, ccs, ami
# termtype: te
bchan=13-14
dchan=15
```

```
span=6, 6, 1, ccs, ami
# termtype: te
bchan=16-17
dchan=18
```

```
span=7, 7, 1, ccs, ami
# termtype: te
bchan=19-20
```

```
span=8, 8, 1, ccs, ami
# termtype: te
bchan=22-23
dchan=24
```

vi /etc/Asterisk®/zapata.conf, and edit the zapata.conf like this:

```
;
; Zapata telephony interface
;
; Configuration file

[channels]
;
; Default language
;
; language=en
;
; context=demo
;
;
switchtype = euroisdn

; p2mp TE mode (for connecting ISDN lines in point-to-multipoint mode)
signalling = bri_cpe_ptmp
; p2p TE mode (for connecting ISDN lines in point-to-point mode)
; signalling = bri_cpe
; p2mp NT mode (for connecting ISDN phones in point-to-multipoint mode)
; signalling = bri_net_ptmp
; p2p NT mode (for connecting an ISDN pbx in point-to-point mode)
; signalling = bri_net

pridialplan = local
prilocaldialplan = dynamic
nationalprefix = 0
internationalprefix = 00

priindication = passthrough

echocancel = yes
context=demo
group = 1
; S/T port 1
```

```
channel => 1-2
```

```
group = 2  
; S/T port 2  
context=demo  
channel => 4-5
```

```
group = 3  
; S/T port 3  
context=demo  
channel => 7-8
```

```
group = 4  
; S/T port 4  
context=demo  
channel => 10-11
```

```
group = 5  
; S/T port 5  
context=demo  
channel => 13-14
```

```
group = 6  
; S/T port 6  
context=demo  
channel => 16-17
```

```
group = 7  
; S/T port 7  
context=demo  
channel => 19-20
```

```
group = 8  
; S/T port 8  
context=demo  
channel => 22-23
```

```
cd /usr/src/bristuff-0.3.0-PRE-1y-j/qozap  
modprobe zaptel  
insmod qozap.ko (for kernel 2.6)
```

`ztcfg - vvvvvvvvvvvvvvvv`

- F. If user wants to modify the dialplan for particular needs, user can edit `zaptel.conf`, `zapata.conf` and `extensions.conf` file under `/etc/Asterisk`, and makes sure Asterisk runs successfully

`Asterisk - vvvvvvvvvvvc`

Notes:

Test environments:

OS: Centos 5

Kernel version: 2.6.18-8.15

Bristuff version: Bristuff-0.3.0-PRE-1y-j

Hardware: OpenVox® B800P under TE mode

Chapter 3 F&Q

How to set the ports under NT mode?

Please adjust the interface into NT status first, and load qozap.ko like this:

```
modprobe zaptel
```

```
insmod qozap.ko ports=X
```

```
ztcfg -vvvvv
```

Here, X is bitmap associating with port configuration of B800P. The example here is:

User sets 1, 2 and 3 are NT mode, 4, 5, 6, 7 and 8 are TE mode.

X (binary) = 00000111

X (Decimal) = 7

Therefore, **insmod qozap.ko ports=7**, refer figure 4 and figure 5 to check the NT setting.




Figure 4: NT_mode

```
Zapata Telephony Interface Registered on major 196
Zaptel Version: 1.2.19
Zaptel Echo Cancellor: MG2
qozap: no version for "zt_receive" found: kernel tainted.
ACPI: PCI Interrupt 0000:02:04.0[A] -> GSI 18 (level, low) -> IRQ 169
dips = 0x3f cid = 63
qozap: OpenVox B800P card configured at io port 0xa000 IRQ 169 HZ 1000
qozap: S/T ports: 8 [ NT NT NT TE TE TE TE ]
qozap: 1 multiBRI card(s) in this box, 8 BRI ports total, bloop 0, pcmlslave 0.
```

Figure 5: Show_NT

How to adjust the card id?

User can switch Card ID from S5 labeled in figure 13. The default is ON(1), therefore the value will be **0x3f**. if user wants to insert more than one cards in pc slot, user should adjust the CardID.

An example is given here. user sets 5 and 6 with off status. Therefore, the dips should be 0xf and cid=15. Figure 6 shows that if user runs: **dmesg**, the dips and cid are shown as what user has configured before.

```
Zapata Telephony Interface Registered on major 196
Zaptel Version: 1.2.19
Zaptel Echo Cancellor: MG2
PCI: Enabling device 0000:02:04.0 (0000 -> 0003)
ACPI: PCI Interrupt 0000:02:04.0[A] -> GSI 18 (level, low) -> IRQ 169
dips = 0xf cid = 15
qozap: OpenVox B800P card configured at io port 0xa000 IRQ 169 HZ 1000
qozap: S/T ports: 8 [ NT NT NT TE TE TE TE ]
qozap: 1 multiBRI card(s) in this box, 8 BRI ports total, bloop 0, pcmlslave 0.
Registered tone zone 0 (United States / North America)
```

Figure 6: Show_cardid

Figure 7 shows that the 5 and 6 are switched to be off, the value should be **001111**.




Figure 7: Cardid_setting

How to check the pin assignment for RJ-45?

To connect with ISDN equipments, RJ-45 is used to make connection. User should know about RJ-45 standard. Here, figure 9 and figure 10 show cables and jacks for B800P.




Figure 9: Cable

(Source: http://www.ertyu.org/steven_nikkel/images/tpcable.jpg)




Figure 10: Cable_RJ45

(Source: http://www.prsol.com/images/cpd/ethernet_568b.jpg)

Figure 11 shows the pin assignments.




Figure 11: Pin_assignment

Figure 12 shows the connection in **TE mode**. The Jack will be split into two jacks. The one is for 3,4,5,6 and second one is for 1,2,7,8.




Figure 12: TE_mode Connection

How to monitor the LEDs of B800P?

The style of LEDs of B800P is different with B200P/B400P. If the system loads zaptel, qozap and Asterisk® successfully, in B200P/B400P, the LEDs will start blinking, but in B800P, it will not turn to be active. until ISDN cable plug into ports, the LEDs will be turned into green.

Chapter 4 References

www.openvox.com.cn

www.Asterisk.org

www.voip-info.org

www.misdn.org

<http://www.junghanns.net/de/download.html>

http://www.ertyu.org/steven_nikkel/images/tpcable.jpg

http://www.prsol.com/images/cpd/ethernet_568b.jpg

Trademarks and Copyrights in this user manual:




- Asterisk® is a registered trademark of Asterisk.
- Junghanns.NET™ is trademark of Gesellschaft für Internet-Services und Software-Development mbH.
- mISDN© is copyright of mISDN.org.
- OpenVox® is a registered trademark of ShenZhen OpenVox Technologies LTD.

Chapter 5 Hardware Setting

6693mil

B800P Jumper Setting

NT/TE Settings



Set jumper to the left
Select NT modeSet jumper to the right
Select TE modeTermination of S/T
Interface (100 ohm)

Connect: Termination = ON



Open: Termination = Off

Power feeding Connector















Connect: Power feeding to feed
S/T interfaces enableOpen: Power feeding to feed
S/T interfaces disable

S/4+5

S/3+6

S/2+7

S/1+8






OpenVox

Copyright(C) 2007

B800P

Ver:1.0



Power Supply Selection


3.3V supply from the PCI Slot
(only available in 3.3V PCI Slot)

3.3V Supply from the Regulator(default)

Power feeding Input

12V Input of Power feeding

State Indicator Led



4201mil