

USER'S MANUAL

VUT 350 PE EC
VUT 600 PE EC
VUT 1000 PE EC



**HEAT RECOVERY
AIR HANDLING UNIT**



CONTENTS

Safety requirements	3
Introduction	5
Use	5
Delivery set	5
Designation key	5
Technical parameters	5
Design and operating logic	7
Mounting and set-up	8
Condensate drain	9
Connection to power mains	11
Unit control	12
Maintenance	12
Troubleshooting	14
Storage and transportation rules	14
Manufacturer's warranty	15
Acceptance certificate	16
Seller's information	16
Mounting certificate	16
Warranty card	17









SAFETY REQUIREMENTS

- Read the user's manual carefully prior to the operation and installation of the heat recovery air handling unit, hereinafter the unit.
- Installation and operation of the unit shall be performed in accordance with the present user's manual as well as the provisions of all the applicable local and national construction, electrical and technical codes and standards.
- The warnings contained in the user's manual must be considered most seriously since they contain vital personal safety information.
- Failure to follow the safety regulations may result in an injury or unit damage.
- Read the manual carefully and keep it as long as you use the unit.
- While transferring the unit control the user's manual must be turned over to the receiving operator.











Symbol legend used in the manual:

	WARNING!
	DO NOT!

UNIT MOUNTING SAFETY PRECAUTIONS

	The unit must be disconnected from the power supply prior to every installation or repair operation.		The unit must not be operated outside the temperature range stated in the user's manual or in aggressive or explosive environments.
	Do not position any heating devices or other equipment in close proximity to the unit power cord.		Do not use damaged equipment or conductors to connect the unit to power mains.
	While installing the unit follow the safety regulations specific to the use of electric tools.		Unpack the unit with care.
	Do not change the power cord length at your own discretion. Do not bend the power cord. Avoid damaging the power cord.		Use the unit only as intended by the manufacturer.

UNIT OPERATION SAFETY PRECAUTIONS

	Do not touch the unit control speed or the control panel with wet hands. Do not carry out the unit maintenance with wet hands.		Do not wash the unit with water. Protect the unit electric parts from water ingress.
	Do not block the air duct when the unit is on.		Disconnect the unit from power supply prior to maintenance.
	Do not let children operate the unit.		Do not damage the power cable while operating the unit. Do not put any objects on the power cable.
	Keep combustible gases and inflammable products away of the unit.		Do not open the operating unit.
	In case of unusual sounds, smoke disconnect the unit from power supply and contact the service centre.		Do not let air flow from the unit be directed to the open flame devices or candles.

INTRODUCTION

This user's manual includes technical description, operation, installation and mounting guidelines, technical data for the heat recovery air handling unit VENTS VUT PE EC, hereinafter referred as the unit.

USE

The unit with heat recovery and electric heater is designed to save heat energy by means of heat recovery and is one of the energy saving components used in the buildings and premises. VUT PE EC is a component unit and is not designed for independent operation.

The unit is designed to provide permanent controlled air exchange by means of mechanical ventilation in houses, offices, hotels, cafés, meeting halls and other mechanically ventilated premises as well as utilization of extract air heat energy to warm up supply purified air.

Transported air must not contain any flammable or explosive mixtures, evaporation of chemicals, coarse dust, soot and oil particles, sticky substances, fibrous materials, pathogens or any other harmful substances.



THE UNIT IS NOT INTENDED TO BE USED BY CHILDREN, PHYSICALLY OR MENTALLY DISABLED PERSONS, PERSONS WITH SENSORY DISORDER, PERSONS WITH NO APPROPRIATE QUALIFICATION.
ANY OPERATIONS WITH THE UNIT MUST BE PERFORMED ONLY BY PROPERLY QUALIFIED PERSONNEL AFTER THE APPROPRIATE SAFETY BRIEFING.
THE UNIT INSTALLATION SITES MUST PREVENT ACCESS BY UNATTENDED CHILDREN.

DELIVERY SET

Unit - 1 item
 Control panel - 1 item
 User's manual for the air handling unit - 1 item

User's manual for the control panel - 1 item
 Packing box 1 item
 Outdoor temperature sensor - 1 item.

DESIGNATION KEY

VUT XXX PE EC X X

Unit type

VUT - heat recovery ventilation

Air capacity [m³/h]

Mounting option

P - suspended mounting

Heater type

E - electric heater

Motor type

EC - electronically commutated motor

Service side

L - left service side

R - right service side

Control panel

— PU SENS 01 with a sensor display

A7 — PU JK 01 with LCD display

TECHNICAL PARAMETERS

The unit is designed for indoor application with the ambient temperature ranging from +1 °C up to +40 °C and relative humidity up to 80%.

The unit is classified as a class I electric appliance.

Hazardous parts access and water ingress protection standard:

- IP 44 for the unit motors;
- IP 22 for the assembled unit connected to the air ducts.

The unit design is regularly being improved, so some models can slightly differ from those ones described in this manual.

UNIT OVERALL DIMENSIONS, MM




Fig. 1. VUT 350 PE EC overall dimensions




Fig. 2. VUT 600 (1000) PE EC overall dimensions

Model	VUT 350 PE EC	VUT 600 PE EC	VUT 1000 PE EC
Ø D	160	200	250
B	485	827	1351
B1	415	723(712)	1120(1216)
B2	554	-	608
B3	135,5	294	431
B4	214	345	655
H	281	280	318
H1	152	120	143
L	1238	1238	1349
L1	1291	1291	1402
L2	924	-	-

UNIT TECHNICAL DATA

Voltage, 50/60 Hz [V]		1 ~ 230		
Max. fan power [W]		200	270	400
Max. fan current [A]		1,62	1,6	2,26
Electric heater power [kW]		1,5	2	3,3
Electric heater current [A]		6,5	8,7	14,3
Total unit power [kW]		1,7	2,27	3,7
Total unit current [A]		8,12	10,3	16,56
Air capacity [m³/h]		400	700	1100
Rotation speed [min ⁻¹]		3560	3060	2780
Noise level, 3 m [dB(A)]		48	53	52
Transported air temperature [°C]		-25 ... +40	-25 ... +60	
Casing material		Aluzinc		
Insulation		20 mm mineral wool		
Filter:	extract	G4		
	supply	G4 (F7)		
Connecting air duct dia. [mm]		Ø160 (Ø150)*	Ø200	Ø250
Weight [kg]		67	75	95
Heat recovery efficiency		up to 90%		
Heat exchanger type		Counter-flow		
Heat exchanger material		Polystyrene		

* in case of using a Ø 160 to Ø 150 mm air duct. Not included into the delivery set.

DESIGN AND OPERATING LOGIC

The unit operates as follows:


Warm stale extract air from the room flows through the air ducts to the unit, where it is filtered, then air flows through the heat exchanger and is exhausted outside by the extract fan through the air ducts.

Clean cold air from outside is moved by the supply fan to the unit, where from it is directed to the supply filter. Then filtered air flows through the heat exchanger and moves to the room through the air ducts.

Heat energy of warm extract air is transferred to clean intake fresh air from outside and warms it up. Heat recovery minimizes thermal energy losses, energy demand and operating costs for air heating accordingly.

The unit is equipped with a detachable service panel for repair works and preventive maintenance and a cover enabling access to the control system components.

UNIT OPERATING LOGIC based on VUT 600 PE EC unit example




The basic unit delivery set includes a remote control panel for connection to the control system inside the unit casing.

The unit comprises a supply and an extract centrifugal single-inlet fan with forward curved blades and maintenance-free EC motors with external rotor and built-in overheat protection, a plate counterflow heat exchanger and an electric heater.

The supply G4 filter cleans supply air flow and prevents contamination of the unit parts. The extract G4 filter prevents contamination of the unit components.

Some condensate may be generated during heat recovery. The condensed fluid is collected in the drain pan and is removed from the unit through the drain hoses.


UNIT DESIGN BASED on VUT 350 PE EC



MOUNTING AND START-UP

MINIMUM ACCESS TO THE UNIT

While mounting the unit provide enough space for its servicing and maintenance.



Modell	VUT 350 PE EC	VUT 600 PE EC	VUT 1000 PE EC
min A, mm	500	850	800

min A depends on the filter

VUT 350 PE EC - 441 mm;


VUT 600 PE EC - 784 mm;

VUT 1000 PE EC - 650 mm (less than VUT 600 PE EC).

UNIT MOUNTING

The unit is designed for suspended mounting by means of the threaded rod fixed in the threaded dowel pin.

Example



To attain the best performance of the unit and to minimise turbulence-induced air pressure losses while mounting connect a straight air duct section on both sides of the unit.


Minimum straight air duct length:

- equal to 1 air duct diameter on intake side.
- equal to 3 air duct diameters on outlet side.

If the air ducts are not connected or the connected air ducts are too short, protect the unit parts from ingress of foreign objects by covering the spigots with a protecting grille or other protecting device with mesh width not more than 12.5 mm to prevent uncontrollable access to the fans.

UNIT MODIFICATIONS

The unit is available with the service side located on the left and on the right of the unit to facilitate mounting and provide minimum service access.



Safety precautions

The unit is designed for mounting on a rigid and stable structure.

The unit is mounted with anchor bolts. Make sure that a mounting construction has sufficient load capacity matching the unit weight. Otherwise reinforce an installation place by beams, etc.


If the threaded bolts used for the unit mounting are too short, the unit can generate abnormal noise and resonate with the ceiling. The suspended bolts must be long enough to prevent resonating.

If the unit connection place to the spiral seam air duct is supposed to be the source of abnormal noise, replace the spiral seam air duct with the flexible one. Optionally the flexible connectors may be used to prevent resonating.

CONDENSATE DRAINAGE

The condensate drain pan in the heat recovery section is equipped with two hoses for extracting the condensed fluid outside the unit. Connect the pipe, U-trap (not included in delivery package) and sewage collection system with metal, plastic or rubber connecting pipes. The pipe slope downwards must be at least 3° . Fill up the system with water before connecting the unit to the power mains! The U-trap must always be filled with water during the unit operation. Make sure that the water flows freely into the sewage collection system or otherwise condensed water may build up in the unit during the heat exchanger operation and cause equipment failure and condensed water outflow into the premises.

The condensate drainage system is designed for normal operation in premises with air temperatures above 0°C . If the expected ambient air temperatures are below 0°C the condensate drainage system must be equipped with heat insulation and pre-heating facilities.




OUTDOOR TEMPERATURE SENSOR INSTALLATION AND CONNECTION

The air handling unit is equipped with an outdoor temperature sensor.

Mounting of the outdoor temperature sensor:


1. Remove two screws from the sensor cover.
2. Take off the cover from the sensor.
3. Install the sensor on the outside wall. The wall must not be exposed to direct sunlight.
4. Install the sensor cover back.
5. Connect the sensor to the terminal block X1 in compliance with the external wiring diagram at page 12.






DUCT HUMIDITY SENSOR INSTALLATION AND CONNECTION

HV1 duct humidity sensor is a special accessory that is not included into the delivery set. To install the sensor connect the humidity sensor socket connector to the socket connector inside the unit. Then fix the sensor with the clamp and the holder in the extract air duct upstream of the heat exchanger.


Duct humidity sensor installation place
VUT 350 PE EC



Duct humidity sensor installation place
VUT 600(1000) PE EC



Duct humidity sensor connection



CONNECTION TO POWER MAINS




DISCONNECT THE UNIT FROM POWER MAINS PRIOR TO ANY ELECTRIC INSTALLATION OPERATIONS. CONNECT THE UNIT TO A CORRECT INSTALLED SOCKET WITH A GROUNDED TERMINAL.

THE RATED ELECTRICAL PARAMETERS OF THE UNIT ARE GIVEN ON THE MANUFACTURER'S LABEL. ANY INTERNAL CONNECTION MODIFICATIONS ARE NOT ALLOWED AND RESULT IN WARRANTY LOSS.

The unit is designed for connection to 230 V / 50/60 Hz single-phase AC mains by using the pre-wired power cord with a Euro Plug. Connect the unit to power mains through the external automatic circuit breaker with magnetic trip integrated into the fixed wiring system with the rated current not below the rated current consumption (refer to page 6).

The terminal block with the prewired control unit is located inside the control unit compartment. To connect the power and the ground cable route the cables through the airtight electric lead-in in the unit casing and connect these to the terminal block. The wiring diagram for connection of the air handling unit to power supply is on back side of the lid.


FUNCTIONAL DIAGRAM



Designation	Name	Designation	Name
D1*	Supply air damper	RK1	Plate heat exchanger
D2*	Extract air damper	SM1*	Supply damper actuator
F1	Supply filter	SM2*	Extract damper actuator
F2	Extract filter	SM3	Bypass damper electric actuator
M1	Supply fan	TE1	Outer air temperature sensor
M2	Exhaust fan	TE2	Temperature sensor at heat exchanger outlet
P1	Control panel	TE5	Duct temperature sensor
Q1	Electric air heater	TE6	Room air temperature sensor
HV1*	Duct humidity sensor	TS1	Overheat protection thermostat actuated at +50°C with automatic reset
HV2	Indoor humidity sensor	TS2	Overheat protection thermostat actuated at +90°C with manual reset

* Not included into the delivery set, available on separate order.

EXTERNAL WIRING DIAGRAM



– ELECTRIC SHOCK HAZARD!

1. The unit delivery set includes P1 and TE1 only.
2. ** Maximum connecting cable length is 20 m!

Design.	Name	Type	Wire**
Cooler	DX cooler	N0	2x0,75 mm ²
SM1	Supply air damper actuator	LF 230	2x0,75 mm ²
SM2	Extract air damper actuator	LF 230	2x0,75 mm ²
PK1	Contact from fire alarm panel	NO	2x0,75 mm ²
P1	Remote control		4x0,75 mm ²
TE1	Outdoor temperature sensor		3x0,75 mm ²

UNIT CONTROL

The unit is operated with the control panel. For detailed information, read the user's manual for the control panel. The remote control is not included into the delivery set.


MAINTENANCE

The recommended maintenance periodicity is 3-4 times per year. The maintenance and servicing routines include regular cleaning and the following operations:

1. Filter maintenance.

Contaminated filters increase air resistance thus impairing supply air volume into the premises.

Clean the filters as these get dirty, but at least 3-4 times a year. Use a vacuum cleaner to remove the contamination or use new filters. Change the filters after the second cleaning. New filters can be purchased from the unit seller.




Filter removing:

- Remove the side panel.
- Pull the filters until they disengage the guide bars. Install the filters in the reverse order.

2. Heat exchanger maintenance (once a year).

Even regular filter technical maintenance may not completely prevent dirt accumulation on the heat exchanger unit. Clean the heat exchanger on a regular basis to ensure its high heat recovery efficiency. To clean the heat exchanger remove it from the unit and wash it with warm neutral detergent solution. Re-install the dry heat exchanger back into the unit.



Removing the heat exchangers:

- Take off the front cover.
- Pull the heat exchanger and withdraw it from the unit.
- Disconnect the socket connector on the bypass wall and remove the bypass.
- For VUT 600 PE EC and VUT 1000 PE EC: remove the second heat exchanger in the same way as the first one.
- Install the heat exchangers in the reverse order.

3. Fan inspection (once a year).

Even regular technical maintenance of the filters and heat exchangers may not completely prevent dust accumulation in the fans which reduces the fan capacity and impairs supply air volume into the premises.



Clean the fans with a cloth or a soft brush. Do not use water, aggressive solvents, sharp objects etc. for cleaning not to damage the impeller.

Access to the fan motors:

Step 1

- Remove the bottom panel.
- Disconnect the drain hoses and remove the drain pan;
- Remove the screws and intake diffusers.

Installation place for 4 fixing screws of the motor



Step 2

- Unscrew fixing screws of the electric motor;
- Push the motor inside the unit through the fan inlet and disconnect the socket connector to enable access to the motor socket connector.
- Turn the motor as shown in the picture, then remove it from the unit.

4. Condensate drain maintenance (once a year).

The drain pipes may get clogged with the extracted particles. Pour some water inside the drain pan and check the pipe for clogging. Clean the U-trap and drain pipe if required.

5. Extract and supply diffuser maintenance (as required).

Remove the diffusers and louver shutters and wash these with warm mild detergent solution.

6. Air intake maintenance (twice a year).

Leaves and other pollutions can clog the supply air grille and reduce the unit performance and supply air volume. Check the supply grille twice per year and clean it as required.

7. Duct system maintenance (every 5 years).

Even regular fulfilling of all the prescribed above maintenance operations may not completely prevent dust accumulation in the air ducts which reduces the unit performance. The air duct maintenance includes regular cleaning or replacement.

TROUBLESHOOTING

Possible faults and troubleshooting

Fault	Possible reasons	Fault handling
The fan does not start up during the unit start-up.	No power supply.	Make sure the unit is properly connected to power mains, otherwise troubleshoot a connection error.
	Motor is jammed, the impeller are clogged.	Turn the unit off. Troubleshoot the motor jam and the impeller clogging. Clean the blades. Restart the unit.
	System alarm.	Turn the unit off. Contact the service centre.
Circuit breaker tripping following the unit turning on.	Overcurrent as a result of short circuit in the electric circuit.	Set higher speed.
Low air flow.	Low set fan speed.	Set higher speed.
	The filters, the fans or the heat exchanger are contaminated.	Clean or replace the filters, clean the fans and the heat exchanger.
	The air ducts, diffusers, louver shutters, grilles are clogged or contaminated.	Clean or replace air ducts, diffusers, louver shutters, grilles.
	The air dampers, diffusers or louver shutters are closed.	Make sure the air dampers, diffusers or louver shutters are fully opened.
Low supply air temperature.	The extract filter is soiled.	Clean or replace the extract filter.
	The heat exchanger is frozen.	Check the heat exchanger condition. Turn the unit off and restart it after the heat exchanger freezing danger is no longer imminent.
	Electric heater malfunction.	Contact the unit seller for troubleshooting.
High noise, vibration.	The impeller is soiled.	Clean the impeller.
	The fan or casing screw connection is loose.	Tighten the screw connection in the fan or the casing against stop.
	No anti-vibration dampers.	Install anti-vibration rubber mounts.
Condensate leakage.	The drain line is clogged, damaged or wrong mounted.	Clean the drain line, if necessary. Check the drain line slant, inspect the U-trap and make sure the drain line is equipped with frost protection.

STORAGE AND TRANSPORTATION RULES

Store the unit in the manufacturer's original packing box in a dry ventilated premise at the temperatures from +5 °C up to +40 °C and relative humidity up to 80%.

Storage environment must not contain aggressive vapours and chemical mixtures provoking corrosion, insulation and sealing deformation.

Use hoist machinery for handling and storage operations to prevent the unit damage. Fulfil the handling requirements applicable for the applicable freight type.

Transportation with any vehicle type is allowed provided that the unit is protected against mechanical and weather damage.

Avoid any mechanical shocks and strokes during handling operations.

MANUFACTURER'S WARRANTY

The manufacturer hereby warrants normal operation of the unit over the period of 24 months from the retail sale date provided the user's observance of the transportation, storage, installation and operation regulations.

Should any malfunctions occur during the unit operation through the manufacturer's fault during the warranty period the user is entitled to elimination of faults by means of warranty repair performed by the manufacturer.

The warranty repair includes work specific to elimination of faults in the unit operation to ensure its intended use by the user within the warranty period. The faults are eliminated by means of replacement or repair of the complete unit or the faulty part thereof.

The warranty repair does not include:

- Routine maintenance;
- Unit installation / dismantling;
- Unit setup.

To benefit from warranty repair the user must provide the unit, the user's manual with stamped sale date and the payment document certifying the purchase.

The unit model must comply with the one stated in the user's manual.

Contact the unit Seller for warranty service.**The manufacturer's warranty does not apply to the following cases:**

- User's failure to provide the unit with the entire delivery package as stated in the user's manual or with missing component parts previously dismantled by the user;
- Mismatch of the unit model and make with the respective details stated on the unit packing and in the user's manual;
- User's failure to ensure timely technical maintenance of the unit;
- External damage to the casing (excluding external modifications of the unit as required for its installation) and the internal components of the unit;
- Alteration of the unit design or engineering changes of the unit;
- Replacement and use of the unit assemblies, parts and components not approved by the manufacturer;
- Unit misuse;
- User's violation of the unit installation regulations;
- User's violation of the unit management regulations;
- Unit connection to the power mains with a voltage different from the one stated in the user's manual;
- Unit breakdown due to voltage surges in the power mains;
- User's discretionary repair of the unit;
- Unit repair performed by any persons without the manufacturer's authorization;
- Expiry of the unit warranty period;
- User's violation of the established regulations specific to the unit transportation;
- User's violation of the unit storage regulations;
- Wrongful acts against the unit committed by third persons;
- Unit breakdown due to circumstances of insuperable force (fire, flood, earthquake, war, hostilities of any kind, or blockade);
- Missing seals if provided by the user's manual;
- Failure to provide the user's manual with the sale date stamp;
- Missing payment document certifying the unit purchase.



FOLLOWING THE REGULATIONS STIPULATED HEREIN WILL ENSURE A LONG AND TROUBLE-FREE OPERATION OF THE UNIT.




USERS' CLAIMS SHALL BE SUBJECT TO REVIEW ONLY UPON PRESENTATION OF THE UNIT, THE PAYMENT DOCUMENT AND THE USER'S MANUAL WITH THE SALE DATE STAMP.

ACCEPTANCE CERTIFICATE

Product Type	Heat recovery air handling unit
Model	VUT ____ PE EC ____
Serial Number	
Manufacturing Date	
<p>is compliant with the technical specifications and is hereby declared ready for service. We hereby declare that the product complies with the essential protection requirements of Electromagnetic Council Directive 2004/108/EC, 89/336/EEC and Low Voltage Directive 2006/95/EC, 73/23/EEC and CE-marking Directive 93/68/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.</p> <p>This certificate is issued following test carried out on samples of the product referred to above.</p>	
Quality Inspector's Stamp	


SELLER'S INFORMATION

Shop name	
Address	
Phone number	
E-mail	
Sales date	
<p>This is to certify delivery of the complete unit with the user's manual. The warranty terms are acknowledged and accepted.</p>	
Customer's signature	




MOUNTING CERTIFICATE

VUT ____ PE EC ____ unit has been connected to power mains pursuant to the requirements stated in the present user's manual.		
Company name		
Address		
Phone number		
Installation technician's full name		
Installation date:	Signature:	
<p>This is to certify that the work specific to the unit installation has been performed in accordance with all the applicable provisions of local and national construction, electrical and technical codes and standards. The unit operates normally as intended by the manufacturer.</p>		
Signature:		



WARRANTY CARD

Product type	Heat recovery air handling unit
Model	VUT_____PE EC _____
Serial number	
Manufacturing date	
Sales date	
Warranty period	
Sales company	



Seller's seal





