


GROHE Blue[®] Starter Kit


GB Technical product information......2


Design & Quality Engineering GROHE Germany


GROHE
ENJOY WATER®


99.083.031/ÄM 217520/02.10







































Carbonate hardness (°dH)	Carbonate hardness (mval/l)	Carbonate hardness (mmol/l)	Bypass setting
7 – 9	2,50 - 3,38	1,25 – 1,69	70 %
10 – 11	3,39 – 4,09	1,70 – 2,05	60 %
12 – 13	4,10 – 4,82	2,06 – 2,41	50 %
14 – 17	4,83 – 6,25	2,42 – 3,12	40 %
18 – 24	6,26 - 8,75	3,13 – 4,37	30 %
25 – 35	8,76 – 12,50	4,38 – 6,24	20 %



Fold out pages:



Please pass this Technical Product Information and the user manual for the filter cartridge on to the kitchen fitting user.

Delivery specification (see fold-out page I)

- Kitchen fitting (1)
- Wall holder (2)
- Filter head (3)
- Filter cartridge (4)
- User manual for filter cartridge (5)
- Escutcheon (6)
- Connection tube (7)
- Bag with installation materials (8)
- Control unit (9)
- Glass decanter (10)
- Technical Product Information (TPI) (11)

Tools required:

Open-end spanner, socket spanner, Allen key, screwdriver, possibly also drill (depending on substrate).

Screws and plugs are not included.

Applications

The kitchen fitting supplies filtered GROHE Blue® water in addition to hot and cold tap water. Filtered and unfiltered water flows into the GROHE Blue® kitchen fitting through two separate pipes and through two separate areas of the mousseur. The filter cartridge reduces the water hardness of the GROHE Blue® water as a function of the hardness of the tap water. The proportion of unsoftened water can be set using the integrated bypass. Furthermore the cartridge binds heavy metal ions such as lead, copper and cadmium. It also reduces cloudiness as well as organic and taste-impairing constituents and chlorine residues. The filter head is fitted with a type-tested non-return valve.

The water filtrate is classified as Category 2 per EN 1717.

The filter fitting can be operated in conjunction with:

- pressurised storage heaters,
- thermally controlled instantaneous heaters,
- hydraulically controlled instantaneous heaters,
 Operation with unpressurised storage heaters is not possible.

Safety notes

- Avoid dangers resulting from damaged power cords. If damaged, the control unit must be replaced.
- The plug-in connectors for the control unit must not be directly or indirectly sprayed with water when cleaning.
- The fitting must be connected to a permanent power supply with a dedicated power switch.
- For hygiene reasons, the filter system must be flushed before using for the first time. It is only permitted to operate the filter system with cold water of fooodstuff grade.
- At the installation location the filter system must be protected from mechanical damage and heat (e.g. from sunlight). Do not install near heat sources or an open fire.

Technical data

· Flow pressure:

min. 1 bar/recommended 2 - 5 bar

· Operating pressure

Fitting: max. 8.6 bar
Filter cartridge and filter head: 2 – 8.6 bar

• Test pressure of fitting: 16 bar

A pressure-reducing valve must be fitted if static pressures exceed 5 bar.

Avoid major pressure differences between the hot and cold water supply.

• Flow rate at 3 bar flow pressure

- Fitting (tap water): approx. 9 l/min

- Filter cartridge

(GROHE Blue® water): approx. 4 l/min

• Ambient temperature: $4-30 \, ^{\circ}\text{C}$

Temperature

Hot water supply: max. 70 °C
 Recommended (energy saving): 60 °C

 Voltage supply: 100 - 240 V AC, 50/60 Hz

• Power consumption: 9 W

Type of protection

- Control unit: IP 65

– Mains plug: IP 40

Adjustable bypass, factory setting: 30 %

• Filter capacity: max. 500 litres

or max. 6 months

• Water connection: cold – blue

hot - red

Electrical test data

- · Software class:
- · Contamination class:

• Rated surge voltage:

2500 V 100 °C

Α

• Temperature for ball impact test:

The test for electromagnetic compatibility (interference emission test) was performed at the rated voltage and rated current.

Approval and conformity

This product conforms to the requirements of the relevant EU guidelines.

The conformity declarations can be obtained from the following address:

GROHE Deutschland Vertriebs GmbH

Zur Porta 9

D-32457 Porta Westfalica (Germany)

Installation



Important: Risk of damage:

- Installation of the fitting and filter cartridge is only permitted in frost-free rooms
- Flush pipes thoroughly before and after installation in compliance with EN 806.
- The control unit is only suitable for indoor use.
- » Install kitchen fitting, see Figs. 1 and 2 on fold-out page II.

When installing on the sink, use the enclosed support plate (1), see Fig. 1. Insert fitting into sink (for hole diameter see fold-out page VI). Feed through hoses one at a time. Do not damage hoses, see Fig. 2.

- » Install wall holder, see (1) in Fig. 3.
 Choose suitable screws and plugs if necessary.
- » Set water hardness at filter head, see (1) in Fig. 4.

Set water harness at bypass setting to local conditions, see table on fold-out page IV. The relevant water supplier can provide information on the water hardness.

- » Insert filter head, see (2) in Fig. 4.
- » Insert filter cartridge, see Fig. 5:

The filter head (2) can be swivelled forwards by up to 90° in the wall holder (1) to install the cartridge.

- Remove protective cover (5) and insert filter cartridge (4) into filter head to the stop. Note the installation position of the filter cartridge.
- 2. Turn locking handle (3) until filter cartridge is felt locking into place.
- » Install control unit, see Fig. 6 on fold-out page III.
- » Connect plug-in connector of fitting to plug-in connector of control unit, see Fig. 7.
- » Connect fitting, see Figs. 2 and 8:
 - 1. Connect the pressure hose marked red to the left service valve (hot water).
- Fit connector (2) onto service valve on right (cold water).
- Connect the two short pressure hoses marked blue (arrows point towards the fitting) to connector.
- Connect the long pressure hose marked blue (arrow points towards the filter) to filter head (1) [IN].
- Connect the long pressure hose marked blue (arrow points away from the filter towards the fitting) to filter head (1) [OUT].
- » Open hot and cold water supply and check that connections are watertight.

Putting into service

- » Flush filter cartridge, see Fig. 9:
 - 1. Place collecting vessel (at least 2-litre capacity) under filter to collect the water flowing out of the hose (3).
 - 2. Open rotation handle (1).
 - 3. Press flush valve (2) on filter head and flush filter system.
 - 4. Continue flushing until the water emerging from the hose is clear and free of bubbles (at least 2 litres).
 - 5. Close rotation handle.
- » Connect power supply, see Fig. 10 on fold-out page IV.

The red and green indicator lamps flash on and off a number of times and then remain on.

- » Set the flow rate (factory setting: 4.5 l/min), see Fig. 10:
 - 1. Place measuring beaker (1 litre) under the spout.
 - With a finger, cover red (2) and green (3) indicator lamps on control unit simultaneously for 6 seconds.

The indicator in the rotation handle (1) of the fitting flashes red.

- 3. Open rotation handle fully within 2 minutes and draw off exactly **1.0 litre** of filtered water.
- 4. Close rotation handle.
- Quickly tap one of the two indicator lamps twice with a finger.

Both indicator lamps flash on and off 4 times and then remain on.

Repeat the entire process if the indicator lamps do not flash on and off. Possible causes:

- Time expired (2 minutes)
- Flow rate too slow or too fast (< 1 l/min or > 6 l/min)
- Tapping did not register

The fitting is now fully installed and ready for operation.

Operation, see Fig. 11

- » Open lever (3) to draw mixed water.
- » Open rotation handle (1) to draw off filtered water. The indicator in the rotation handle indicates the filter capacity:

Filter capacity indicator (2) in rotation handle:

Flashing signal	Meaning	
	Filter capacity of more than 10%	
	Filter capacity of less than 10%	
	» Order filter cartridge	
	Filter capacity of less than 1%	
	» Change filter cartridge soon	
	» No filter capacity» Change filter cartridge immediately	

Note:

Replacement filter cartridges can be ordered at www.grohe.com or from your supplier.

Maintenance

Inspect and clean all components and replace if necessary.

Important: Risk of damage:

Always disconnect the power supply before carrying out maintenance work on the fitting. The plug-in connectors can then be disconnected, see Fig. 7 on fold-out page III.

Cartridge, see Fig. 12 on fold-out page IV.

- 1. Shut off hot and cold water supply.
- 2. Lever out plug (6) and remove set screw (5).
- 3. Remove lever (4) and cap (3).
- 4. Remove screw coupling (2) and take out cartridge (1).

When installing the cartridge, ensure that the seals are correctly seated. Screw in screw coupling and tighten.

Ceramic headpart, see Fig. 13 on fold-out page IV.

- 1. Shut off hot and cold water supply.
- Close rotation handle (1) and remove.
- 3. Remove display component (6).
- 4. Remove snap insert (2) and stop (3).
- 5. Replace complete ceramic headpart (5) or O-ring (4).

Assemble in reverse order. Note the installation position of the stop.

Mousseur


Remove and clean mousseur (64 374), see fold-out page V.


Power supply fuse of control unit:


Remove and replace fuse (3A) if the red and green indicator lamps does not light, see fold-out page V (available from electrical retailers).


Replacement parts

Replacement parts, see fold-out page V.









(**D**)

Grohe Deutschland Vertriebs GmbH Zur Porta 9 32457 Porta Westfalica Tel.: +49 571 3989-333 Fax: +49 571 3989-999



GROHE Ges.m.b.H. Wienerbergstraße 11/A7 1100 Wien Tel.: +43 1 68060 Fax: +43 1 6884535



GROHE nv - sa Diependaalweg 4a 3020 Winksele Tel.: +32 16 230660 Fax: +32 16 239070

Търговско представителство Grohe AG България Бизнес център Слатина Ул. Слатинска 1

1574 София Тел. : +359 2 9719959 +359 2 9712535 Факс.: +359 2 9712422

CDN

GROHE Canada Inc. 1230 Lakeshore Road East Mississauga, Ontario Canada, L5E 1E9 Tel.: +1 905 2712929 Fax: +1 905 2719494

(CH)

Grohe Switzerland SA Oberfeldstrasse 14 8302 Kloten Tel.: +41 44 8777300 Fax: +41 44 8777320

(CN)

高仪(上海) 卫生洁具有限公司 宁桥路615号 201206 上海 中华人民共和国 电话: +86 21 50328021 传真: +86 21 50550363

(CY)

GROME Marketing (Cyprus) Ltd. 195B, Old Nicosia-Limassol Road Dhali Industrial Zone P.O. Box 27048 1641 Nicosia Tel.: +357 22 465200 Fax: +357 22 379188

(CZ)(SK)

Grohe ČR s.r.o. Zastoupení pro ČR a SR V Oblouku 104, Čestlice 252 43 Průhonice Tel.: +420 22509 1082 Fax: +420 22509 1085

(DK)

GROHE A/S Walgerholm 11 3500 Vaerløse Tel.: +45 44 656800 Fax: +45 44 650252



GROHE España S.A. C/ Botanica, 78 - 88 Gran Via L'H - Distr. Econòmic 08908 L'Hospitalet de Llobregat (Barcelona) Tel.: +34 93 3368850

Fax: +34 93 3368851

(EST) (LT) (LV) GROHE AG Eesti filiaal

Tartu mnt 16 10117 Tallinn Tel.: +372 6616354 Fax: +372 6616364



GROHE s.à.r.l. 60, Boulevard de la Mission Marchand 92400 Courbevoie - La Défense Tel.: +33 1 49972900 Fax: +33 1 55702038



Oy Teknocalor Ab Sinikellonkuia 4 01300 Vantaa Tel.: +358 9 8254600 Fax: +358 9 826151



GROHE Limited GROPE LIMITED
Blays House, Wick Road
Englefield Green
Egham, Surrey, TW20 0HJ
Tel.: +44 871 200 3414 Fax: +44 871 200 3415



N. Sapountzis S.A. 86, Kapodistriou & Roumelis Str 142 35 N. Ionia - Athens Tel.: +30 210 2712908 Fax: +30 210 2715608



GROHE Hungary Kft. Röppentyü u. 53. 1139 Budapest Tel.: +36 1 238 80 45 Fax: +36 1 238 07 13



GROHE AG - Predstavništvo Štefanovečka 10 10000 Zagreb Tel.: +385 1 2989025 Fax: +385 1 2910962

GROHE S.p.A. Via Castellazzo Nr. 9/B 20040 Cambiago (Milano) Tel.: +39 2 959401 Fax: +39 2 95940263

(IND)

Grohe India Private Limited The Great Eastern Centre Gesco Corporate Centre 70 Nehru Place New Dehli 110019 Tel.: +91 11 5561 9423 / 9513 Fax: +91 11 5561 9451

(IS)

BYKO hf. Skemmuveai 2 200 Kópavogur Tel.: +354 515 4000 Fax: +354 515 4099



Grohe Japan Ltd. TRC Building, 3F 1-1 Heiwajima 6-chome, Ota-ku Tokyo 143-0006 Tel.: +81 3 32989730 Fax: +81 3 37673811



GROHE A/S Nils Hansens vei 20 0667 Oslo Tel.: +47 22 072070 Fax: +47 22 072071



GROHE Nederland BV Metaalstraat 2 2718 SW Zoetermeer Tel.: +31 79 3680133 Fax: +31 79 3615129



GROHE Portugal Componentes Sanitários, Lda Rua Arq. Cassiano Barbosa, 539 1.° Frente Esquerdo 4100-009 Porto Tel.: +351 22 543 29 80 Fax: +351 22 543 29 99



GROHE Polska Sp. z.o.o. Pulawska 182 Street 02-670 Warszawa Tel.: +48 22 5432 640 Fax: +48 22 5432 650

RUS

Представительство Grohe AG Москва,ул.Русаковская 13,стр.1 1107140

тел.: +7 495 9819510 факс: +7 495 9819511

(RO)

Grohe AG Reprezentanta Strada Nicolae lorga 13, 010432 Bucuresti (Sector 1) Tel.: +40 21 2125050 Fax: +40 21 2125048



GROHE A/S Kungsängsvägen 25 753 23 Uppsala Tel.: +46 771 141314 Fax: +46 771 141315



GROSAN inženiring d.o.o. Slandrova 4 1000 Ljubljana Tel.: +386 1 5633060 Fax: +386 1 5633061



GROME Ic ve Dis Ticaret Ltd. Sti. Bagdat Cad. Ugras Parlar Is Merkezi No: 605, B Blok D: 12 - 15 34846 Cevizli - Maltepe-Istanbul Tel.: +90 216 4412370 Fax: +90 216 3706174

(UA)

Представництво Grohe AG в Україні Вул. Івана Франка, 18-А 01030 Київ тел.: +38 044 537 52 73 факс: +38 044 590 01 96

GROHE America Inc. 241 Covington Drive Bloomingdale Illinois, 60108 Tel.: +1 630 5827711 Fax: +1 630 5827722

Eastern Mediterranean Middle East - Africa Area Sales Office:

GROME Marketing (Cyprus) Ltd. 195B, Old Nicosia-Limassol Road Dhali Industrial Zone P.O. Box 27048 1641 Nicosia Tel.: +357 22 465200

Fax: +357 22 379188 Far East Area Sales Office: GROHE Pacific Pte. Ltd.

438 Alexandra Road # 06-01/04 Alexandra Point Singapore 119958 Tel.: +65 6376 4500 Fax: +65 6378 0855



www.grohe.com