




Overload Warning System DS 50



Trouble Shooting Manual Level 3 - Calibration Adjustments -

NOTICE

The information in this document is subject to change without notice. PAT makes no warranty of any kind with regard to this material, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose.

PAT shall not be liable for errors contained in this manual or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual. This document contains proprietary information which is protected by copyright. All rights are reserved.

No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of PAT.

Table of contents

Item	Content	Page
1.	Introduction to troubleshooting the PAT Overload Warning System DS50	
1.1	System outline	5
1.2	System operation	7
1.3	Troubleshooting care	8
2.1	The hand terminal	10
2.2	The hand terminal connection	12
3.1	The start up menu	16
3.2	Displaying data and messages	17
3.3	The test program	19
3.4	The on-line mode	21
4	Adjusting calibration data	23
5	Identify the problem	24
6	Adjusting overload cut off factor	25
7	Adjusting empty hook load display	27
8	Adjusting radius display under load	29
9	Adjusting load display	31
10	Transferring EEPROM data	33
11	Error code messages	40
12	Removing test and calibration Equipment	48

CAUTION !

The use of the equipment and the procedures in the following sections allow data change of the microprocessor system DS50 and its calibration.

Therefore only trained and authorized service personnel shall proceed with the procedures and data adjustments described in this manual. Incidental errors in the calibration or software change may result in a fatal accident. Always verify software change or calibration change results.

NOTICE

THIS TROUBLE SHOOTING MANUAL "DS 50 - LEVEL 3" IS DESIGNED TO ASSIST THE SERVICE OR MAINTENANCE PERSONNEL IN ADJUSTING THE EXISTING CALIBRATION DATA AND TRANSFERRING CALIBRATION DATA INTO A REPLACEMENT DS 50 CENTRAL UNIT.

THIS TROUBLE SHOOTING MANUAL DOES NOT REPLACE ANY CALIBRATION INSTRUCTION. THEREFORE IT SHOULD NOT BE USED AS A CALIBRATION MANUAL.

IN ORDER TO PERFORM THE ADJUSTMENTS IN THIS TROUBLE SHOOTING MANUAL YOU REQUIRE A SPECIAL TOOL SET. THE TOOL SET CONSISTS OF THE PROFORT 803 HAND TERMINAL, THE DATAMAN S4 EPROM PROGRAMMER, THE INTERFACE BOARD, A SET OF CABLES AND A PRE-PROGRAMMED E-PROM. WE ASSUME THAT REGULAR MAINTENANCE AND SERVICE TOOLS AND A DIGITAL VOLTMETER ARE AVAILABLE ON SITE.

THIS TROUBLE SHOOTING MANUAL DS 50 - LEVEL 3- IS THE CONTINUATION OF TROUBLE SHOOTING MANUAL DS 50 - LEVEL 1- AND -LEVEL 2- AND ASSUMES THE KNOWLEDGE OF THE CONTENT OF THE PREVIOUS LEVELS .

WE SUGGEST THAT ONLY TRAINED MAINTENANCE AND SERVICE PERSONNEL PROCEED WITH THE TROUBLE SHOOTING DESCRIBED IN THIS MANUAL.

1. INTRODUCTION TO TROUBLESHOOTING THE PAT DS 50

1.1. SYSTEM OUTLINE

The PAT Overload Warning System Model DS 50 is designed to disable the boom down and up, hoist up and tele out crane functions when the crane attempts to lift over its limits. These limits are specified in the load capacity chart provided by the crane manufacturer.

When the DS 50 system detects an overload condition the following crane functions are disabled immediately.

- a. telescope out
- b. boom up and boom down
- c. hoist up


To remove the overload condition the operator must achieve a safe working condition. This can be achieved by lowering the load and repositioning the crane or decreasing the radius by telescoping in. Observe that the radius can not be decreased by lifting the boom. The boom up function is disabled while attempting to overload the crane.

The system design allows you to operate the crane in an emergency situation or system failure without the DS 50 system in operation . In this situation leave the crane electric switch in the off position and press the override button while you operate the crane manually. The DS 50 Overload Warning System is not operative and can not warn the operator with the electric power switch in off position.

Warning
**Bypassing the DS 50 Overload Warning system
may results in property damage, injury or death.**

The DS 50 system contains a central unit with integrated length and angle sensor. The load cell is supporting the hoist drum and used to measure the load on hook.

1. INTRODUCTION TO TROUBLESHOOTING THE PAT DS 50



DRAWING 1.1 - SYSTEM LOCATION (FMTV-WRECKER)

1. INTRODUCTION TO TROUBLESHOOTING THE PAT DS 50**1.2 SYSTEM OPERATION**

The Microprocessor Central Unit operates as the control center of the system. The length cable is connected to the boom nose. During telescoping the length cable spools off a drum which turns the length potentiometer using a gear assembly. The length potentiometer is a variable resistor which varies linearly with the boom length. An angle sensor is built into the central unit which senses the boom angle. The load cell provides the signal to calculate the load on hook. The proximity switch located on the hoist drum switches to a different calibration factor during spooling off the hoist rope. This will allow a steady load calculation and compensates for the difference in the lever arm. All together the signals get processed in the central Microprocessor unit where actual and rated load are compared. The system de-energizes a relay and disables the appropriate crane functions when the actual load exceeds the rated load by more than 10%.

1. INTRODUCTION TO TROUBLESHOOTING THE PAT DS 50


1.3. Troubleshooting Care

- Keep in mind while troubleshooting high quality electronic components to use caution and necessary care while testing and measuring DS 50 components and circuits of the crane electric's.
- Tools and test equipment must be in good order and shall be inspected on a regular basis.
- Follow all safety instructions according to crane manufacturer's handbooks and safety instructions. Obey recommended practice and safety standards applying to the job site.
- Secure the working area prior to testing and servicing the system.
- Never remove the load cell without firm support holding the hoist drum.
- Never let the length cable snap back to the central unit. The length sensor drum is under high tension.

Warning

DS 50 Overload Warning System service and repair work shall be performed by trained and authorized personnel only.

1. INTRODUCTION TO TROUBLESHOOTING THE PAT DS 50



Caution !
Crane is shown folded for transportation.
For lifting operations the mast has to be in full upright position
and the hook lifted out of the transportation storage.

2.1 THE HAND TERMINAL

The key board of the Profort 803 hand terminal is divided in three main areas. Refer to drawing 2.1.1 and locate the keys which are described in the text below.

- Numerical key pad: Used to enter numerical data.
- Alphabetical key pad: Used to enter commands (letters).
- Function keys: Used to correct, delete or confirm an entry or display.

Some keys are assigned to special hand terminal functions.


- Internal battery check key: By pressing the key the red LED on the left top row lights up to indicate that the internal battery is charged. If the LED does not light up the internal battery is not charged or is defective. The hand terminal shall not be used until the battery is replaced.
- Memory recall key: With the green key on the top right of the key board the last entry can be reviewed - but not changed.
- Control LEDs: The LEDs above the numerical key pad light up to confirm the on-line status and various key function. In example the green File LED lights up after the shift key was pressed.
- The display (LCD): Indicates data and messages.

The use of the hand terminal in connection with the DS 50 System is described in the course of the following instructions.

Part of the hand terminal is a cable. The DB 9 connector at the end of the cable shall be connected to the interface ribbon cable which is connected into the DS 50 main board. Refer to section 2.2 and drawing 2.2.1 and 2.2.2 for hand terminal connection.

CAUTION: The DB 9 connector is wired especially for the DS 50 interface. Do not attempt to connect the hand terminal to any device other than the DS 50.

2.1 THE HAND TERMINAL



Drawing 2.1.1

2.2 THE HAND TERMINAL CONNECTION

In order to connect and use the hand terminal for data read-out or data adjustment the DS 50 hardware must be prepared as follows:


- Switch the truck power off and remove the DS 50 central unit cover carefully as described in manual level 1&2.
- Carefully insert the interface board into the interface board socket on the main board.

CAUTION: The hole location in the interface board must match the hole location on the main board. Otherwise you may damage the interface and main board when powering the system up. Do not break, bend or skip any pins on the interface board while you plug the board into the socket.

Refer to drawing 2.2.1 for installation of the interface board.


- The 'plug in' jumper J2 next to the interface board socket must be closed (mid & top position of the 3 pin connector). Refer to drawing 2.2.2. Note the hand terminal will not function with J2 not in the correct position.
- Plug the small ribbon cable adapter with the 10 conductor female plug into the male interface connector on the main board next to the interface board socket.
- Plug the female DB 9 connector of the hand terminal cable into the male DB 9 connector at the other end of the ribbon cable. Refer to drawing 2.2.3 for cable connection.
- Secure the ribbon and hand terminal cable with cable ties to avoid cable stress or pulling off connections while operating the crane.

2.2 THE HAND TERMINAL CONNECTION




Drawing 2.2.1

2.2 THE HAND TERMINAL CONNECTION




For operation with hose terminal the jumper J2 must be plugged into the top and red pin of the three pin connector.



Drawing 2.2.2

2.2 THE HAND TERMINAL CONNECTION



Drawing 2.2.3

3.1 THE START UP MENU

Follow the instructions described in section 2.2 to connect the on-line equipment. Switch the truck power on. A cursor appears on the top left of the hand terminal display and the red 'online' LED lights up. After the DS 50 system has passed the selftest routine, the display shows the start up menu. Refer to drawing 3.1.

The following letters allow the user to select the desired program.

- D = Data output to PC terminal mode. Not used for hand terminal operation.
- H = Data output to hand terminal Profort 803.
- O = Select the on-line mode. The on-line mode must be selected to adjust calibration data.
- T = Select the test mode. The test mode allows the user to initialize the EEPROM prior to a new calibration only and to test the digital inputs such as the function of the hoist layer switch.

Caution: Do not initialize a calibrated system. Incidentally initialization of the EEPROM results in loss of calibration data and a recalibration becomes necessary.

Refer to the appropriate section in this manual to distinguish what letter key of the start up menu to select.

Start up menu after system is powered:



Drawing 3.1.1

3.2 DISPLAYING DATA AND MESSAGES

Follow the instructions in section 2.2 and 3.1

In order to identify the need for a data adjustment, internally calculated data must be compared with the actual measured data.

The DS 50 is an overload shut down system and is not classified as a scale. The consideration of government specified tolerances is part of the trouble shooting process. Crane and truck manufacturing tolerances do not allow calibrating an overload shut down system with 0% tolerance.

To select the read out of geometrical data, load data and error messages press the >H< key of the alphabetical key pad. The following information is now displayed. Refer to drawing 3.2.1 to identify the displays described in the text below.


- Utilization of the lifting capacity in percentage. Overload cut off should be active between 100% and 110%. The sample drawing 3.2.1 indicates an utilization of 84%.
- Maximum load capacity (in lb/1000) for the actual boom position. The sample drawing 3.2.1 indicates a maximum load capacity of 5,000 lb.
- Actual load on hook (in lb/1000). Note that the hook is not part of the load. The sample drawing 3.2.1 indicates an actual load of 4,200 lb.
- Main boom length (in ft). The distance between the center of the boom pivot pin and the center of the sheave wheel pin. The sample drawing 3.2.1 indicates a main boom length of 14.2 ft.

Refer to table below for fully retracted and fully extended boom length indication.

Crane model:	Indicated length	
	retracted	extended
FMTV Cargo	7.3	15.7
FMTV Wrecker	7.3	18.4

- Main boom angle (in degree) in reference to the horizontal line. The sample drawing 3.2.1 indicates a boom angle of 65.5 degree.
- Radius (in ft.). Radius is defined as the distance between center line of crane rotation and the center line of the load freely suspended. The sample drawing 3.2.1 indicates a radius of 15.7 ft.
- In the event of a malfunction, an overload condition, or an out of loadchart condition, the radius display becomes replaced by the Error message. Refer to the error code list to decode the message.

3.2 DISPLAYING DATA AND MESSAGES



Drawing 3.2.1

3.3 THE TEST PROGRAM

The test program is designed to initialize the E-EPROM prior to a new calibration and to test the function of the digital inputs such as the hoist layer switch function.

Press the key >T< to start the test program. Refer to drawing 3.3.1 and 3.3.2. The program allows to select the test routine:

- Press 4 to initialize the E-EPROM

CAUTION: DO NOT INITIALIZE A CALIBRATED SYSTEM. YOU WILL LOOSE ALL CALIBRATION DATA IF YOU PRESS THE >Y< KEY AFTER THE MESSAG “OVERWRITE ? (Y/N)”. ALWAYS CONFIRM WITH THE >N< KEY IF YOU ENTERED THE ROUTINE BY MISTAKE. WHEN TRANSFERRING DATA TO A REPLACEMENT SYSTEM IT MAY BECOME NECESSARY TO INITIALIZE THE REPLACEMENT SYSTEM BEFORE DATA TRANSMISSION.

- Press 8 to test digital inputs

The hand terminal display indicates the actual status of three digital inputs.

DI 1	DI 2	DI 3
1	0	0

A >1< means the digital input is powered on and a >0< means the digital input is not powered on.

In the example above the DI 1 is powered by the hoist layer switch. Switch off the hoist layer switch by lowering the hoist and you can see the >1< changing to >0<.. For correct adjustment of the switch refer to documentation in level 1 &2.

Note: No other digital input is used for the DS 50 FMTV application.

To return to the main menu press the >ESC< key or the letter key for the program you wish to select.

3.3 THE TEST PROGRAM

Test menu (refer to text):



Drawing 3.3.1

Submenu to test (4):



Drawing 3.3.2

3.4 THE ON-LINE MODE

The calibration equipment and the system must be switched into on-line mode for calibration adjustments. From the start up menu, select the on-line mode by pressing the >O< key. The hand terminal displays the message >SYSTEM READY<. The operating mode code and the actual length step >OM= 0101, LS = 7.33< confirms the operation of the on-line mode.

Refer to the example in drawing 3.4.1.

A calibration adjustment is possible for a length step only. A length step is the main boom length shown in each loadchart column.

You can exit the on-line mode any time. Exit the on-line mode by pressing the >SHIFT< key and then the > ^ < key. The hand terminal confirms with the message >End online mode<.

Once in the start up display of the on-line mode there are two calibration functions available.

- Press the >U< key to change calibration data for the actual length step.
- Press the >V< key to change load calibration data for the actual length step.

Refer to the flowchart diagrams of this manual for detailed information how to use the two calibration functions.

- Press the >K< key to return to the start up menu. Message > End online mode<.
- Press either >U< or >V< key to switch between the two calibration functions.

3.4 THE ON-LINE MODE



Drawing 3.4.1

4. ADJUSTING CALIBRATION DATA

Use the flowcharts in the continuation of this manual to locate the section appropriate for your adjusting needs.

Remember you must be fully familiarized with section 2 and 3 in order to proceed with section 4.

Test the hardware, using trouble shooting manual 2 & 3, before you consider adjusting the calibration data.

Always consider that the system left the crane manufacturer fully calibrated and passed the quality tests. Always consider calibration and crane specification during the adjusting procedure.


Ensure a safe environment. Secure the crane and the surrounding area. Do not overload the crane and truck during the adjusting process. Always consider and refer to the crane load chart. Always measure actual geometrical values. Use only tested, inspected and known test weights for load testing. The load must be freely suspended and lifted in a vertical straight line. Always initially hoist the load off the ground. The use of a “dead eye” (hook in the ground) is not permitted for any adjusting methods.

Use a tested inclinometer (level indicator) with a minimum resolution of 0.25 degree to measure the boom angle.


Ensure that your measuring tape is in good condition.

When testing the radius mount the beginning of the tape exactly on the center line of rotation. Note the display indicates the radius or boom length in resolution of 1/10 ft. - not in inches.


5. IDENTIFY THE PROBLEM




6. ADJUSTING OVERLOAD CUT OFF FACTOR




6. ADJUSTING OVERLOAD CUT OFF FACTOR




7. ADJUSTING EMPTY HOOK LOAD DISPLAY




7. ADJUSTING EMPTY HOOK LOAD DISPLAY




8. ADJUSTING RADIUS DISPLAY UNDER LOAD




8. ADJUSTING RADIUS DISPLAY UNDER LOAD



9. ADJUSTING LOAD DISPLAY



9. ADJUSTING LOAD DISPLAY



10. TRANSFERRING EEPROM DATA

In the event of DS 50 main board failure it becomes necessary to install a replacement central unit.

Note: All calibration data is stored in the E-EPROM which is installed on the main board and not removable.

By removing the defective central unit the calibration data becomes removed. Extract the data prior to disconnecting the defective DS 50 central unit. Truck voltage is required to extract the data.

Additional equipment required to transfer calibration data:

- Eprom programmer >DATAMAN S4< - Drawing 10.1.1 on the next page shows the DATAMAN S4.
- The serial interface cable which comes with the DATAMAN S4.
- The charging unit which comes with the DATAMAN S4.
- The DS 50 System Software Version >DS 50 1.4C < and higher.

Preparation:

- Carefully read the user manual for the DATAMAN S4.
- Before removing the defective DS 50 install the interface board and the ribbon cable with the DB 9 connector at the end. Refer to section 2.2 for installation instructions.
- Set up the DATAMAN S4
 - > Press the red key >SETUP<.
 - > Enter the following

File:	Intel	>ENTER<
Baud:	9600	>ENTER<
Handshake:	None	>ENTER<
Download sound:	On	>ENTER<
UL Byte/line:	10	>ESC<
 - > Display returns with the prompt.

10. TRANSFERRING EEPROM DATA



Drawing 10.1.1

10. TRANSFERRING EEPROM DATA

- Select the PROM type
 - > Press the green key >PROM< (Display indicates a Prom type)
The cursor should flash on the first digit of the reference number.
 - > Enter the reference number >0C04< using the keyboard and press >ENTER<
The display indicates:
Microchip 27C256
13.00V Burn pin 1
100us No Overprog
Alg 7E, Ref 0C04
 - > Press the >ENTER< key to confirm.
 - > Display returns with the prompt.
- Reset the RAM (memory)
 - > Press the white >FILL< key.
Display indicates in example 00000,0FFFF,FF.
 - > Enter: 00000,07FFF,FF using the keyboard of the DATAMAN and confirm with the >ENTER< key.
DATAMAN S4 answers with one short tone and returns to the prompt.

10. TRANSFERRING EEPROM DATA

Receive data from EEPROM:

- Switch the truck power off (No power to DS 50)
- Switch DATAMAN S4 off.
- Connect the serial interface cable into the connector of the DATAMAN S4. Connect the DB 9 connector of the interface cable into the DB 9 ribbon cable connector of the DS 50 interface.
- Switch DATAMAN S4 on and switch the truck power (DS 50 power) on. Wait for minimum of 10 seconds. The display will prompt twice (>) and the cursor flashes.
- Switch DATAMAN S4 off and immediately on again. The DATAMAN S4 will now receive the data out of the EEPROM. Note: The DATAMAN S4 will transmit the data one more time to the DS 50 to test the received data. Please be patient as the transmission can take a little while.
- At the completion of receiving and testing data the DATAMAN S4 responds with:
 - 2 dual tones = DATA received correctly
 - 6 dual tones = Error in the data transmission
- The prompt and the cursor flashes to continue transferring data or to repeat the receiving function.

10. TRANSFERRING EEPROM DATA

At this point it is possible to burn and secure the data into an EPROM (27C256 PAT tested and approved EPROMS only). The EPROM can be downloaded to a PC file using the DATAMAN S4.

Note: Either a copy EPROM or a PC file must be forwarded immediately after calibration adjustment to

**PAT-Equipment Corp.,Inc.
Attn. Software Dept.
1665 Orchard Drive
Chambersburg, PA 17201
U.S.A.**

If no adjustment has changed the data and no EPROM copy is desired skip to “Transmit data to the DS 50” in this section.

Copy data into EPROM

- Switch the truck power off (No power to DS 50)
- Disconnect the serial interface cable from the DB 9 ribbon cable connector of the DS 50 interface.
- Plug the blank EPROM into the DATAMAN S4 EPROM socket. Refer to the user manual for correct insertion.
- Press the green key >BURN<
The display indicates :

Microchip 27C256
13.00V Burn pin 1
00000 - 07FFF=00000

if not

- > Enter >00000 - 07FFF=00000< on the last line and press >ENTER<
- > The display scrolls through the addresses while burning the EPROM.
- > Display returns with the prompt and a tone.

10. TRANSFERRING EPROM DATA

To read the EPROM with the calibration data back into the DATAMAN S4 follow the procedure below. If the data is already in the memory of the DATAMAN S4 skip to “Transmit data to the DS 50” in this section.

Read EPROM data into the DATAMAN S4

- Switch the truck power off (No power to DS 50)
- Disconnect the serial interface cable from the DB 9 ribbon cable connector of the DS 50 interface.
- Switch the DATAMAN S4 on.
- Plug the EPROM with the calibration data into the DATAMAN S4 EPROM socket. Refer to the user manual for correct insertion.
- Press the green key >LOAD<
The display indicates:

LOAD 27C256
00000 - 07FFF=00000

if not

--> Enter >00000 - 07FFF=00000< on the last line and press >ENTER<

--> Display returns with the prompt and a tone.

10. TRANSFERRING EEPROM DATA

Transmit data to the EEPROM of the replacement unit:

- Switch the truck power off (No power to DS 50)
- Switch DATAMAN S4 off.
- Connect the serial interface cable into the connector of the DATAMAN S4. Connect the DB 9 connector of the interface cable into the DB 9 ribbon cable connector of the DS 50 interface.
- Switch DATAMAN S4 on and switch the truck power (DS 50 power) on. Wait for minimum of 10 seconds. The display will prompt twice (>) with two tones and the cursor flashes.
- Press the white key >send< the display indicates:

>SEND INTEL
00000,0FFFF (in example)

--> enter 00000,000FF using the key board

--> Press the >ENTER< key to confirm

- The DATAMAN S4 checks the data and responds with a single tone and the prompt.
- At the completion of the transmission the DATAMAN S4 responds with:

1 dual tones = DATA transmitted correctly
5 dual tones = Error in the data transmission

After completion of the data transfer refer to section 2.1 and 2.2 to verify the system function and calibration. Also refer to Trouble Shooting Manual 1 and 2 for basic set up of the PAT DS 50 Overload Warning System.

11. ERROR CODE MESSAGES

Error Code Table (DS50) for Cranes FMTV-C, FMTV-W, LVS

System program: **DS50 V1.4C** Parts list No. .: 71 050 14 0005

Error Code	Error	Cause	Remedy
O	Overload	Cutoff due to overload.	Reduce load moment.
P	Pre-warning	Approaching an overload condition.	Slow crane operation and be alert.
E0 1	No loadchart radius or angle available with high boom angle.	Boom is elevated too high into a non rated radius or angle range.	Boom down the boom to a radius or angle specified in the load chart.
E0 2	No loadchart radius or angle available with low boom angle.	Boom is lowered too low into a non rated radius or angle range.	Raise the boom to a radius or angle specified in the load chart.

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
E0 5	Forbidden length range of the main boom.	<p>Boom has been extended too far or not enough,</p> <p>The length sensor adjustment was modified, e.g. length cable spooled off the length sensor reel and the length sensor was not adjusted after the problem was corrected.</p> <p>Clutch between length sensor pot and drive is defective.</p> <p>Failure of the +5V-supply for the length sensor.</p> <p>Length potentiometer defective.</p>	<p>Retract or extend boom to the correct length.</p> <p>Retract the boom. Check the pretension of the cable reel (refer to documented instruction). Refer to the instruction in the manual and adjust length sensor carefully clockwise.</p> <p>Completely replace the clutch with the drive wheel and adjust length sensor pot (refer to instruction in the manual).</p> <p>Check +5V-voltage as described in the troubleshooting manual. Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.</p> <p>Replace length potentiometer. Refer to the troubleshooting manual for instructions.</p>

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
E0 7	No acknowledgment from the overload relay in the OSS to the microprocessor input.	Overload relay defective, printed circuit board defective or microprocessor input defective. Could also be caused by an external short circuit in the wiring.	Use the instructions in the troubleshooting manual and the test box to identify the location of the problem. Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.
E1 1	Length channel voltage is lower than the minimum limit.	<p>Cable between length sensor and main board defective or disconnected.</p> <p>Length sensor potentiometer defective.</p> <p>Analog channel on main board defective.</p>	<p>Check cable and connectors and replace if necessary. Refer to troubleshooting manual.</p> <p>Replace length sensor potentiometer. Refer to instructions in the troubleshooting manual.</p> <p>Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.</p>

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
EI 4	Load cell channel voltage is lower than the minimum limit.	<p>Cable leading from the central unit to the load cell is defective or moisture in the connector.</p> <p>Load cell defective.</p> <p>Analog channel on main board defective.</p>	<p>If the cable or connector is damaged replace connector or load cell. Refer to troubleshooting manual.</p> <p>Follow the instruction in the troubleshooting manual and use the test unit to identify clearly a load cell defect. If in doubt contact the PAT service support. In the event of a load cell defect replace load cell referring to the troubleshooting manual and the crane service documentation.</p> <p>Warning: Support the hoist drum while replacing the load cell.</p> <p>Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.</p>
EI 5	Angle channel voltage is lower than the minimum limit.	Angle sensor or electronic component defective on main board.	Replace main board or central unit and transfer E-Eprom data. Load test system after.

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
E2 1	Length channel voltage is higher than the maximum limit.	<p>Cable between length sensor and main board defective, shorted or disconnected.</p> <p>Length sensor potentiometer defective.</p> <p>Analog channel on main board defective.</p>	<p>Check cable and connectors and replace if necessary. Refer to troubleshooting manual.</p> <p>Replace length sensor potentiometer. Refer to instructions in the troubleshooting manual.</p> <p>Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.</p>

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
E2 4	Load cell channel voltage is higher than the maximum limit.	<p>Cable leading from the central unit to the load cell is defective or moisture in the connector.</p> <p>Load cell defective.</p> <p>Analog channel on main board defective.</p>	<p>If the cable or connector is damaged replace connector or load cell. Refer to troubleshooting manual.</p> <p>Follow the instruction in the troubleshooting manual and use the test unit to identify clearly a load cell defect. If in doubt contact the PAT service support. In the event of a load cell defect replace load cell referring to the troubleshooting manual and the crane service documentation.</p> <p>Warning: Support the hoist drum while replacing the load cell.</p> <p>Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.</p>
E2 5	Angle channel voltage is higher than the maximum limit.	Angle sensor or electronic component defective on main board.	Replace main board or central unit and transfer E-Eprom data. Load test system after.
E3 1	Error in the Eprom (system part)	The Eprom on the main board is defective.	Follow the instruction in the troubleshooting manual and replace the Eprom which is plugged into the Eprom socket on the main board. Refer to the Eprom label to affirm the same Eprom version. Function and load test the system after.

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
E3 7	Error in the logic of the software in the Eprom.	The Eprom on the main board is defective. LMI board defective.	Follow the instruction in the troubleshooting manual and replace the Eprom which is plugged into the Eprom socket on the main board. Refer to the Eprom label to affirm the same Eprom version. Function and load test the system after. Identify clearly a main board defect by referring to the troubleshooting manual. If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.
E4 1	Error in the internal write/ read memory (RAM) of the microprocessor.	Microprocessor components defective on main board.	If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.
E4 2	Error in the external write/ read memory (RAM)	External RAM defective on main board.	If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.
E4 8	Cyclic internal RAM test failed.	Microprocessor components defective on main board.	If in doubt contact PAT service support. Replace main board or central unit and transfer E-Eprom data. Load test system after.
E5 1	Error in the Eprom (data part)	The Eprom on the main board is defective.	Follow the instruction in the troubleshooting manual and replace the Eprom which is plugged into the Eprom socket on the main board. Refer to the Eprom label to affirm the same Eprom version. Function and load test the system after.

11. ERROR CODE MESSAGES

Error Code	Error	Cause	Remedy
E5 7	E-Eprom Error.	<p>E-Eprom was not initialized. Sometimes prior to calibration or prior to transferring data into a replacement unit.</p> <p>Defective E-Eprom - when the E-Eprom was loaded with calibration data previously.</p>	<p>Follow the instruction of the troubleshooting manual level 3 to initialize the system.</p> <p>Caution: The initializing procedure erases all existing calibration. The system must be re-calibrated or other valid data transferred. Refer to troubleshooting manual level 3.</p> <p>If in doubt contact PAT service support. Replace main board or central unit and transfer original E-Eprom data. A copy of the original calibrated data file must be obtained from the Crane manufacturer or PAT - Service department. Caution: In some cases a re-calibration of the system is necessary.</p> <p>Load test system after.</p>

Remark

If an error message is displayed that is not listed, please immediately contact the competent PAT service department.

12. REMOVING TEST AND CALIBRATION EQUIPMENT

Use the following procedure to remove the test equipment after you completed the adjustments or transfer of data.

- Unhook any load and move the boom into a safe position. Select a boom position that allows you to disconnect the calibration equipment safely.
- Switch off the truck power. Disconnect the interface cable from the ribbon cable connector [DB9]. Disconnect the interface cable from the Dataman S4 and store cable and Dataman S4 in a secured and protected location. If you used the hand terminal the interface cable remains connected to the hand terminal. Store cable and hand terminal in a secured and protected location.
- Carefully disconnect the ribbon cable from the main board interface socket. Refer to drawing 2.2.3 in section 2.2. Store cable in a secured and protected location.
- Carefully unplug the interface board. Use both hands to lift the board straight out of the socket. The pins on the connector are extremely sensitive. Try to avoid bending the pins. Use anti-static storage material to store the interface board. Refer to drawing 2.2.1 in section 2.2.
- Remove jumper plug J2 if used for the hand terminal operation. Store the jumper plug in a safe and secure area. The jumper plug is needed for whenever you connect the hand terminal to the DS 50.
- Disconnect the external cables from the Mil type connectors.

12. REMOVING TEST AND CALIBRATION EQUIPMENT

- Mount the small cover.

Caution: Check the O-rings on the four studs for wear and tear. The cover will not seal without the O-ring being on the threaded part of the stud.

Use the washers and tighten the nuts. While you tighten the cover you should check the proper position of the rubber gasket. Do not tighten one nut completely before you proceed with the next nut. Distribute the force while tightening. Finally tighten all nuts. Be careful to not over-tighten the nuts and brake off the threaded part of the studs.

- Mount the large cover and carefully tighten the four nuts.
- Re-connect the external cables with the Mil type plugs to the connectors. Refer to the manual level 1 and level 2 for orientation of those connectors. Be sure the plugs are tightened to seal against water ingress.
- Check the system performance by lifting a known test load and a cut off test.
- If the test fails then you should verify the correct removal of test equipment or calibration equipment or repeat trouble shooting as described in Troubleshooting Manual level 1,2 and 3.