SIEMENS

SIJECT 16i Start-Up

Technical Manual

08.2004 Edition

Manufacturer Documentation

SIJECT 16i Document Structure



SIEMENS

SIJECT 16i Start-Up

Technical Manual

Valid for

Control System Firmware Version SIJECT 16i

1.12

08.2004 Edition

SIJECT16i Control System	1
Installation of Control System	2
Start-up	3
Programming Tool	4
Technical Appendix	5

SIJECT[®] Documentation

Key to editions

The editions listed below have been published prior to the current edition.

The column headed "Note" lists the amended sections, with reference to the previous edition.

Marking of edition in the "Note" column:

- A New documentation.
- B Unchanged reprint with new order number
- **C** Revised edition of new issue.

Edition	Order No.	Note
12.2000	6AT1931-5AB61-0BA0	А
01.2004	6AT1931-5AB61-0BA1	А
08.2004	6AT1931-5AB61-0BA1	С

Copyright SIEMENS AG 2004. All right reserved

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model, are reserved.

Exclusion of liability

We have checked that the contents of this document correspond to the hardware and software described. Nonetheless, differences might exist and we cannot therefore guarantee that they are completely identical. The information contained in this document is reviewed regularly and any necessary changes will be included in the next edition. We welcome suggestions for improvement.

© SIEMENS AG, 2004

Subject to technical changes without notice.

Safety Guidelines

This Manual contains notices intended to ensure your personal safety, as well as to protect products and connected equipment against damage. Safety notices are highlighted by a warning triangle and presented in the following categories depending on the degree of risk involved:



Danger

Indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury or in substantial property damage.



Warning

Indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury or in substantial property damage.



Caution

Used with the safety alert symbol indicates a potentially hazardous situation which, if not avoided, **may** result in minor or moderate injury or in property damage.

Caution

Used without safety alert symbol indicates a potentially hazardous situation which, if not avoided, **may** result in property damage.

Notice

Indicates important information relating to the product or highlights part of the documentation for special attention.

Qualified Person

The unit may only be started up and operated by a **qualified person or persons**. Qualified persons as referred to in the safety guidelines in this document are those who are authorized to start up, earth and label units, systems and circuits in accordance with relevant safety standards.

Proper use

Please note the following:



Warning

The unit may be used only for the applications described in the catalog or the technical description, and only in combination with the equipment, components and devices of other manufactures as far as this is recommended or permitted by SIEMENS.

This product must be transported, stored and installed, and maintained and operated with care to ensure that it functions correctly and safely.

Contents

1	SIJ	IECT 1	6i Control System	1-2
	1.1	Comp	onents of SIJECT 16i	1-2
	1.2	Techr	ical Data	1-4
	1.3	Order	Number	1-6
2	Ins	talling	the Control System	2-7
	2.1	Install	ing and Dismantling	2-7
	2.2	Interfa	ices and Cabling	2-12
	2.3	Conne	ecting the Individual Components of CI	2-19
	2.3	3.1	Connecting the Operator Panel (X11)	2-20
	2.3	3.2	Pin assignments of the RS232/MPI Interface (X12)	2-21
	2.3	3.3	Pin assignments of the P_BUS Interface (X14)	2-22
	2.3	3.4	Pin assignments of the Profibus Interface (X15)	2-23
	2.3	3.5	Connecting the digital inputs (X203, X204, X205, X206)	2-24
	2.3	3.6	Connecting the thermocouples (X200, X201)	2-27
	2.3	3.7	Connecting the linear scale (X202)	2-29
	2.3	3.8	Fast analog inputs (X207)	2-31
	2.3	3.9	Connecting the digital outputs (X300, X301, X302, X303, X304)	2-33
	2.3	3.10	Connecting the analog outputs (X305)	2-37
	2.3	3.11	Connecting the proportional valve current output (X306)	2-38
	2.4	Powe	^r Supply	2-40
	2.5	Grour	ding	2-41
	2.5 2.6	Grour LEDs	ding and Mode selector S1	2-41 2-43
3	2.5 2.6 Sta	Grour LEDs a rt-up	ding and Mode selector S1	2-41 2-43 3-47
3	2.5 2.6 Sta 3.1	Grour LEDs a rt-up. . Genei	dingand Mode selector S1	2-41 2-43 3-47 3-47
3	2.5 2.6 Sta 3.1 3. 1	Grour LEDs art-up Gener 1.1	idingand Mode selector S1 and Mode selector S1 al Access levels	2-41 2-43 3-47 3-47 3-48
3	2.5 2.6 Sta 3.1 3.1 3.1	Grour LEDs art-up Gener 1.1 1.2	and Mode selector S1 al Access levels Structure of recipe data	2-41 2-43 3-47 3-47 3-48 3-49
3	2.5 2.6 Sta 3.1 3.1 3.1 3.1	Grour LEDs art-up Gener 1.1 1.2 1.3	and Mode selector S1 and Mode selector S1 al Access levels Structure of recipe data Handling of recipe data	2-41 2-43 3-47 3-47 3-48 3-49 3-50
3	2.5 2.6 Sta 3.1 3.1 3.1 3.1 3.1	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4	and Mode selector S1 and Mode selector S1 and Mode selector S1 and Mode selector S1 and Access levels Access levels Acc	2-41 2-43 3-47 3-47 3-48 3-49 3-50 3-51
3	2.5 2.6 Sta 3.1 3.1 3.1 3.1 3.1 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch	and Mode selector S1 and Mode selector S1 and Mode selector S1 and <i>Access levels</i> <i>Access levels</i>	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-51 3-52
3	2.5 2.6 Sta 3.1 3.1 3.1 3.1 3.1 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1	and Mode selector S1 and Mode selector S1 and Mode selector S1 and Mode selector S1 and <i>Access levels</i> . <i>Access levels</i> . <i>Structure of recipe data</i> . <i>Structure of recipe data</i> . <i>Handling of recipe data</i> . <i>Recipe data saving</i> . <i>Recipe data saving</i> . <i>Boot messages</i> .	2-41 2-43 3-47 3-47 3-47 3-49 3-50 3-51 3-52 3-53
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2	and Mode selector S1 and Mode selector S1 and Mode selector S1 and Mode selector S1 and Example the control system <i>Access levels</i> <i>Structure of recipe data</i> <i>Handling of recipe data</i>	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-51 3-52 3-53 3-53
3	2.5 2.6 Sta 3.1 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.3	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check	and Mode selector S1 and Mode selector S1 al <i>Access levels.</i> <i>Structure of recipe data</i> <i>Handling of recipe data</i> <i>Recipe data saving.</i> ning on and Booting the control system <i>Boot messages</i> <i>Alarm</i>	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-51 3-52 3-53 3-53 3-56 3-59
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.3 3.4	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin	and Mode selector S1 and Mode selector S1 and Mode selector S1 and Mode selector S1 and <i>Access levels</i> . <i>Access levels</i> . <i>Structure of recipe data</i> <i>Handling of recipe data</i>	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-51 3-52 3-53 3-56 3-59 3-61
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1	and Mode selector S1 and Mode selector S1 and Mode selector S1 and Mode selector S1 and Access levels. Access levels. Structure of recipe data Handling of recipe data Recipe data saving. Ning on and Booting the control system Boot messages Alarm ting I/Os. g important parameters. Language selection	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-51 3-52 3-53 3-55 3-59 3-61 3-62
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.3 3.4 3.4 3.4 3.4 3.4	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1 4.2	Idingand Mode selector S1 and Mode selector S1 ral Access levels Structure of recipe data Handling of recipe data Handling of recipe data Recipe data saving ning on and Booting the control system Boot messages Boot messages Alarm cing I/Os g important parameters Language selection Service selection	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-51 3-52 3-53 3-56 3-59 3-61 3-62 3-63
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1 4.2 4.3	Idingand Mode selector S1	2-41
3	2.5 2.6 Sta 3.1 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1 4.2 4.3 4.4	Idingand Mode selector S1	2-41 2-43 3-47 3-47 3-47 3-48 3-49 3-50 3-50 3-52 3-53 3-55 3-61 3-62 3-65 3-67
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1 4.2 4.3 4.4 4.5	Idingand Mode selector S1	2-41 2-43 3-47 3-47 3-47 3-47 3-49 3-50 3-50 3-51 3-52 3-53 3-56 3-61 3-63 3-65 3-67 3-68
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1 4.2 4.3 4.4 4.5 4.6	ding and Mode selector S1 and Access levels Structure of recipe data Handling of recipe data Handling of recipe data Recipe data saving ning on and Booting the control system Boot messages Alarm sting I/Os g important parameters Language selection Setvice selection Setting linear scale Setting password Save/load setting	2-41
3	2.5 2.6 Sta 3.1 3.1 3.1 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2 3.2	Grour LEDs art-up Gener 1.1 1.2 1.3 1.4 Switch 2.1 2.2 Check Settin 4.1 4.2 4.3 4.4 4.5 4.6 4.7	ding and Mode selector S1 al Access levels Structure of recipe data Handling of recipe data Recipe data saving ning on and Booting the control system Boot messages Alarm cing I/Os g important parameters Language selection Setting linear scale Setting password Save/load setting Proportional valve adjustment Pump Combination Setting	2-41

	3.4	4.9	Temperature setting	3-73
	3.4	4.10	Setting the ramp data	3-75
	3.5	Up-/Do	ownloading and Deleting PLC Program	3-77
	3.5	5.1	Up-/Downloading and Deleting PLC Program	3-77
	3.5	5.2	Automatic uploading of PLC application to PLC module	3-79
4	Pro	ogramn	ning Tool	4-81
	4.1	SIMAT	FIC Manager	4-81
5	Тес	chnical	Appendix	5-83
	5.1	Definit	ion of DB1	5-83
	5.2	Glossa	ary abbreviation	5-92

Operator Panel



1 SIJECT 16i Control System

1.1 Components of SIJECT 16i

What is SIJECT 16i?

The SIJECT 16 is a controller for injection molding machine. It offers solutions for injection molding machines from low-end applications to high-end applications.

Hardware components

It consists of the following hardware components, in which the parts marked with a star symbol (*) can be ordered separately:

- CI: Compact interface, main controller, i.e., CPU and I/O board.
- OP: Operator panel, with LCD display and membrane keyboard, i.e. CPU, LCD, and membrane Keyboard
- Cable: Communication cable between CI and OP.
- Multimedia card (MMC card*):

The memory space of MMC card is 32 Mbytes. It can install PLC application programs, maximum 50 sets recipe data, OP-menus and a customer specific picture (max.16KB).



Fig 1-1 Hardware components of SIJECT 16i

Software components

- System software on the permanent Flash-EPROM of the CI:
 - Loading kernel (SIJECT Sijload): loads all the remaining part of the software of micro-controller. It is available in PRODIS system that can be free downloaded from Internet (Please refer to Notice on next page for details).
 - PLC application program: executes the Integrated PLC User Program cyclically. Before machine set-up, customers should firstly install PLC application program by themselves.

Programming tool:

SIMATIC STEP7 V5.x*;

 OP15B menu editor tool (MECO program): for OP15B, there is a HMI engineering tool for menu editor. MECO program is also in PRODIS system together with Sijload program (Refer to Notice below).

User data User data are:

- Customer specific picture
- Recipe data
- PLC program

PLC program The STEP7 PLC program for CI 16i/16iP is backed up by battery. The delivered CI 16i/16iP does not include any STEP7 PLC program, and the battery is not plugged in. The customer should prepare PLC program , first plug in battery then download STEP7 PLC program to CI16i/16iP unit.

Please see section **3.5.2 Automatic uploading of PLC application to PLC module** for detailed function descriptions.

Notice

Actual information, documentation (only English) and application examples in STEP 7 are on Internet available.

Actual Link: <u>http://www4.ad.siemens.de/</u> (Please input "SIJECT" in Search box.)

For more information or proposals, you can link:

http://www.siemens.com/motioncontrol

http://www.ad.siemens.de/csinfo

Or contact (Europe):

Email: wolfgang.radermacher@siemens.com Email: wolfgang.zapf@siemens.com

Technical support

Email: dietmar.antwerpen@siemens.com

1.2 Technical Data

Connected load

Connected load Table 1-1

Parameter	Min	Туре	Max	Unit	Remarks
Supply voltage	20.4	24	28.8	V	
Power of CI and OP		20	35	W	
Current consumption of each output		2		A	
Digital input/output		24		V	
Proportional valve		24/38		V	*

* It depends on the resistance of proportional valve.

Weight	Table 1-2 Weight	
	Component	Weight (Kg)
	CI component	4.1
	OP component	1.8

Dimensions

Table 1-3Component Dimensions

Component	Dimensions: H×W×D (mm)
CI component	390×288×84.5
OP component	392×202×36

Environmental

operating conditions Table 1-4 Environmental operating conditions

Parameter	Description
Temperature range	0 ~ +50°C
Permissible relative humidity	595% without condensation
Air pressure	7001,060hPa

Transport and storage conditions

Table 1-5Transport and storage conditions

	. –
Parameter	Description
Temperature	Transport: -40~+70°C Storage: -20~+55°C
Permissible relative air humidity	595% without condensation
Air pressure	7001,060hPa
Transport height	-1,0003,000 m

Free fall in transport package	500mm
--------------------------------	-------

Protective quality and degree of protection Class of protection level to IEC 536, CI: IP20, OP: IP54 PE terminal required. Foreign matter and water protection to IEC 529.

System characteristics

Table1-6 System characteristics

Sys	tem	SIJECT CI 16i	SIJECT CI 16iP
PLC module		314	314-2DP
Programming		SIMATIC STEP 7	SIMATIC STEP 7
Guaranteed	Load memory	256 Kbytes	524 Kbytes
memory	Work memory	163 Kbytes	460 Kbytes
Prog. memory	Load memory	_*	498 Kbytes
(after loaded technology)	Work memory	_*	437 Kbytes
Timer		128	256
Counter		64	256
Digital input (DC	24V)	31	31
High speed cour	nter	1	1
Digital output (2	A)	40	40
Short-circuit pro-	tection	Yes	Yes
Thermocouple in	nput (16 Bit)	8	8
Inputs for linear scales $(1k\Omega \sim 10k\Omega, 12 \text{ Bit})$		4	4
Inputs for fast analog signals (0~10V, 14-Bit resolution)		-	2 (X207)
Analog output (+/-10V, 12 Bit)		4	4
Proportional valve current output (+24~38V / 0.75~1.4A, 12Bit)		2 (X306) **	-
OP interface (se	rial)	1	1
MPI interface		1	1
P_Bus interface		1	1
Profibus-DP inte	erface	-	1
Memory card slo	ot	1	1
System power s	upply	DC 24V	DC 24V

* No correspondent technology blocks for CI 16i.

** For CI16i, two outputs can only be used alternatively as voltage output (+/- 10V) or as current outputs (0.75-1.4A).

1.3 Order Number

General

The SIJECT series product can be ordered in the form of package. But you also can receive the components separately if you only order the option. It depends on the configuration and can meet your requirements. Please see the order number of all components in the following table.

Table			
No.	Component	MLFB (Order No.) / SNC No.	
1	SIJECT15+ (OP15B)	185010901900 China only	
2	SIJECT 16i (CI16i+OP15B)	6AT1131-6CD21-0XB0	
3	SIJECT OP15B FV1 (English, Chinese, Turkish, Russian)	6AT1131-5BB20-0XB0	
	SIJECT OP15B FV2 (English, Chinese, Spanish, Reserve)	6AT1131-5BC20-0XB0	
4	SIJECT CI16i	6AT1131-6DD21-0AB0	
5	SIJECT CI16iP	6AT1131-6DE21-0AB0	
6	Communication cable	185010900200 China only	
7	SIJECT adapter	6AT1131-0FA00-0AA0	
8	Multimedia Card (MMC card)	6AT1131-0GA00-0AA0	
9	SIJECT PTPS (SIJECT Project Tool), English Version (SW)	185010901800 China only	
10	SIJECT Sijload (SIJECT Loader), English Version (SW)	185010755002 China only	
11	SIMATIC Manager V5.2	6ES7810-4CC06-0YX0	
12	Short Guide for Start-up	18400000060 China only	
13	Operation Manual (OP15B) SIJECT 16i, English	184000000059 China only	
14	Operation Manual (OP15B) SIJECT 16i, Chinese	18400000062 China only	
15	Start Up Manual (OP15B) SIJECT 16i, English	184000000058 China only	
16	Start Up Manual (OP15B) SIJECT 16i, Chinese	18400000061 China only	
17	P_BUS cable (2.5m)	6ES7368-3BC51-0AA0	
18	P_BUS cable (5.0m)	6ES7368-3BF01-0AA0	
19	Profi_bus cable	6XV1830-0EH10-1AB0	
20	Profi_bus Connector 1	6ES7972-0BA40-0XA0	
21	Profi_bus Connector 2	6ES7972-0BB40-0XA0	
22	Lithium battery for SIJECT CI boards	6FC5247-0AA18-0AA0	

Table 1-7 Order Number

2 Installing the Control System

2.1 Installing and Dismantling

A	
<u>!</u>	Warning
	Do not install when the equipment is live! Do not dismantle when the equipment is live!
	The modules contain electrostatically sensitive devices. It must be ensured that persons without ESD protection never touch printed circuit boards or components when handling operator panel (OP) and CI unit.
Procedure	Prior to installation, you should prepare 4 nuts (M3) for OP installation and 4 cross-head screws (M4) for CI installation. The sheet metal can not have any paint. The thickness of a sheet metal for mounting shall not be less than 2 mm.
	1. Install the CI within the electrical cabinet;
	 Install the Operator Panel on the control rack of injection molding machine;
	3. Connect CI and OP with communication cable;
	 Connect the wiring of periphery circuit (I/Os, thermocouple, linear scale, proportional valve, etc.);
	5. Connect entry wire of power supply.
Dismantling the control system	The control components are dismantled as described above in the reverse order.
$\boldsymbol{\wedge}$	Danger
<u> </u>	Install grounding connection before plug-in of screw-terminal block to DC24V mains.
	Make sure that all delivered interface connectors (female) are plugged in before operation.
Battery set-up	The back-up battery is not connected to the CI board in original package. If is necessary to connect the back-up battery to CI board and reset the memory prior to the system start-up. Please refer to operation sequences of battery set-up as follows.
	Operating sequence:
	 When the system is firstly power on, observe the status of LEDs: BATF (red), DC5V (green) and SF (red) are lighting on, and STOP (yellow) is flashing. PLC should be reset;
	 Switch the mode selector S1 to position MRES by screwdriver and observe the status of LEDs: BATF (red) and DC5V (green) are still on SF (red) is off; STOP (yellow) will flash rapidly at first, then stay on;

3. Switch the mode selector S1 to **RUN_P**, and you will find that STOP (yellow) is off and RUN_P (green) is on;

- 4. Put the plug at the end of the battery cable into the connector of the CI board (pay attention to the pole of battery!), and BATF (red) is off; ;
- 5. Insert the battery into the battery holder, and the battery installation is finished. You can download the PLC program.

Caution

In case that SF (red) keeps bright and STOP (yellow) is always flashing in the above-mentioned process, you should repeat step 2 and step 3 until both LEDs go dark.

Battery Replacement

Operating steps:

- 1. When battery alarm occurs (a flag (DB1.DBX59.1) will be set to 1), the lithium battery must be replaced;
- 2. Pull out the used lithium battery;
- 3. Replace it with a new one;



Warning

- 1. Exchange battery with power on. Otherwise program will be lost.
- 2. There is risk of fire, explosion or combustion. Do not recharge, disassemble, crush, heat above 212 °F (100°C), or incinerate.

Mounting dimensions

The dimensions shown below are important when installing the control components:



Fig. 2-1 Mounting dimensions of OP15B



Fig. 2-2 Mounting dimensions of CI



Fig. 2-3 Section dimension for OP15B

2.2 Interfaces and Cabling

Position of interfaces and front panel elements



Fig.2-4 User interfaces for SIJECT CI16i (for reference)



Fig.2-5 User interfaces for SIJECT CI16iP (for reference)

Interfaces	CI
	 Power supply connector (DC24V) * 3 – pin screw-terminal block for connecting the power supply.
	 X11 — OP interface 9 – pin sub-D male connector for connecting OP and providing power supply for OP.
	 X12 — MPI / RS232 interface 9 – pin sub-D female connector for communicating with PC/PG and other standard OP.
	 X14 — P_BUS 25 – pin sub-D female connector for periphery extension.
	 X15¹ — Profibus 9 - nin sub-D female connector for connecting controller (Profibus)

- 9 pin sub-D female connector for connecting controller (Profibus protocol).
- X200, X201 Temperature input *
- 8 pin male connector (2 sets) for connecting thermocouple inputs.
- X202 Analog input * 12 – pin male connector (1 set) for connecting linear scale inputs.
 - X203, X204, X205, X206 Digital input * 10 – pin male connector (4 sets) for connecting digital inputs, 1 pin of them (DI3.7/X206) is adapted for connecting high-speed input including proximity switch.
 - X207² Fast Analog Inputs *
 6 pin male connector (1 set) for two fast analog inputs (10V) and for the reference power output supplied by the system (DC 10V).
- X300, X301, X302, X303, X304 Digital output * 10 pin male connector (5 sets) for connecting digital outputs.
- X305 Analog output * 8 – pin male connector (1 set) for connecting analog output for proportional pressure and flow valve with external driver card.
- X306³ Current output for proportional pressure and flow valve * 6 – pin male connector (1 set) for connecting power output for proportional pressure and flow valve with integrated driver card.

Notice

Temperature rating of field-installed conductor shall be 75° C only for the Digital Outputs (X300, X301, X302, X303 and X304), and Analog Output (X306). No marking is required when intended for connection to control circuit conductors only.

For the parts marked with a star symbol (*), please use terminal blocks made by PHOENIX CONTACT GMBH & CO (E60425), catalog number MVSTBR2.5/X-ST-5.08, where X can be 6, 8, 10 OR 12.

¹ It is only applicable for SIJECT CI 16iP.

² It is only applicable for SIJECT CI 16iP.

³ It is only applicable for SIJECT CI 16i.

	OP
	 X21 — Cl interface 9 – pin sub-D female connector for connecting Cl.
LEDs	10 LEDs for fault and status displays
Operating elements	Mode selector S1
Connecting cables	The components are wired up as shown in the following Connection Diagram. Please refer to this figure for the type of cables required.
\wedge	Warning
	In practical use, the length of those wires transmitting digital and analog input/output signals should be less than 30 meters. In case the wire length is more than 30 meters, corresponding measures should be taken against surge interference.



Fig. 2-6 Cable diagram for SIJECT 16i



Fig. 2-7 Connection Diagram for CI16i



Fig.2-8 Connection diagram for CI16iP

2.3 Connecting the Individual Components of CI

Connecting the Components

Please note the following:

Caution

Use only shielded cable and make sure that the shield is connected with the metal or metal plated connector casing on the control side.

The cable offered as accessories provides optimum protection against interference.

Proceed as follows to connect the individual components:

- 1. Connect the lines to the components as shown in Fig.2-7/2-8;
- 2. Fix the sub-D connector using screws.

2.3.1 Connecting the Operator Panel (X11)

Pin assignments
for connector on
CI side

Operator panel interface Connector designation:
Connector type:

X11 OP15B 9 – pin sub-D male connector

	0	
	X11	
Pin	Signal	Туре
1	М	V
2	XBOOT	I
3	TXD+	0
4	RXD+	I
5	P24	V
6	XRES	I
7	RXD-	I
8	TXD-	0
9	M24	V

Table 2-1 Pin assignments of connector X11

Pin assignments
for connector on
OP side

CI interface

Connector designation:

Connector type:

X21 CI 16i/16iP 9 – pin sub-D female connector

Table 2-2	Pin assignments of connector X21

	X21	
Pin	Signal	Туре
1	М	V
2	XBOOT	I
3	RXD+	0
4	TXD+	I
5	P24	V
6	XRES	I
7	TXD-	I
8	RXD-	0
9	M24	V

2.3.2 Pin assignments of the RS232/MPI Interface (X12)

Pin assignments	
for connector	

MPI (RS232) interface	
Connector designation:	

Connector type:

X12 RS232 / MPI 9 – pin sub-D female connector

|--|

X12 (MPI)		
Pin	Signal	Туре
1	RS232_RXD_DIAG	Ι
2	M24	М
3	MPI_P	V
4	RS232_TXD_DIAG	0
5	М	М
6	P5	V
7	P24	V
8	MPI_N	М
9	MPI_RTS	I

2.3.3 Pin assignments of the P_BUS Interface (X14)

Pin assignments for connector

P_BUS interface	
Connector designation:	X14
-	P BUS
Connector type:	25 – pin sub-D female

connector

Table 2-4Pin assignments of connector X14

X14		
Pin	Signal	Туре
1	RS_ALARM_N	1
2	IM_ADR0_N	0
3	IM_ADR1_N	0
4	IM_ADR2_N	0
5	М	V
6	KBUS_B_N	В
7	RS_OD_N	0
8	RS_DIDO_N	В
9	RS_CLK_N	0
10	RS_COM_N	0
11	RS_LST_N	0
12	RS_READY_N	I
13	No connection	N.C
14	RS_ALARM	I
15	IM_ALARM0	0
16	IM_ALARM1	0
17	IM_ALARM2	0
18	K<2>	0
19	KBUS_B	В
20	RS_OD	0
21	RS_DIDO	В
22	RS_CLK	0
23	RS_COM	0
24	RS_LAT	0
25	RS_READY	Ι

Notice

For CI 16i, this interface can not be used as K-BUS interface (SIMATIC K-BUS), because the internal pin 6 and 19 have no wire.

For CI 16iP, this interface is K_BUS integrated.

2.3.4 Pin assignments of the Profibus Interface (X15)⁴

Pin assignments	5
for connector	

Profibus interface Connector designation:

Connector type:

X15 Profibus 9 – pin sub-D female connector

Table 2-5	Pin assignments of connector X15
-----------	----------------------------------

X15		
Pin	Signal	Туре
1	No connection	N.C.
2	No connection	N.C.
3	DP_P	В
4	No connection	N.C.
5	Μ	V
6	P5	V
7	No connection	N.C.
8	DP_N	В
9	No connection	N.C.

⁴ Profibus interface (X15) is only applicable for CI16iP.

2.3.5 Connecting the digital inputs (X203, X204, X205, X206)

Pin assignments for connector

Interface for digital inputsConnector designation:X203, X204, X205, X206InputInputConnector type:10-pin plug connector

X203		
Pin	Name	Туре
1	DI0.0	1
2	DI0.1	Ι
3	DI0.2	1
4	DI0.3	1
5	DI0.4	1
6	DI0.5	1
7	DI0.6	1
8	DI0.7	1
9	4L+/4M	V
10		
	X204	
Pin	Name	Туре
1	DI1.0	I
2	DI1.1	I
3	DI1.2	I
4	DI1.3	I
5	DI1.4	I
6	DI1.5	I
7	DI1.6	I
8	DI1.7	1
9	5L+/5M	V
10		
X205		
Pin	Name	Туре
1	DI2.0	
2	DI2.1	I
3	DI2.2	1
4	DI2.3	1
5	DI2.4	I
6	DI2.5	1
7	DI2.6	1
8	DI2.7	I
9	6L+/6M	V
10		

X206		
Pin	Name	Туре
1	DI3.0	1
2	DI3.1	1
3	DI3.2	1
4	DI3.3	1
5	DI3.4	1
6	DI3.5	1
7	DI3.6	1
8	DI3.7	1
9	7L+/7M	V
10		

Input voltage

Signal 1 Signal 0 ±15V~30V 0~±5V

Input current Signal 1

6mA

Connecting sensors and actuators





Signal description The

The digital inputs are assigned with the following signals:

DI 0.0	(spare)
DI 0.1	(spare)
DI 0.2	(spare)
DI 0.3	(spare)
DI 0.4	(spare)
DI 0.5	(spare)
DI 0.6	(spare)
DI 0.7	(spare)
DI 1.0	Safety door 2 (short-cut available)
DI 1.1	Rear safety door (short-cut available)
DI 1.2	Emergency stop (short-cut available)
DI 1.3	Carriage advance end
DI 1.4	Carriage retract end
DI 1.5	Ejector advance end
DI 1.6	Ejector retract end
DI 1.7	Mold lock end
DI 2.0	Mold adjustment advance end
DI 2.1	Mold adjustment retract end
DI 2.2	Core 1 in end / Screwing 1
DI 2.3	Core 1 out
DI 2.4	Core 2 in end / Screwing 2
DI 2.5	Core 2 out
DI 2.6	Injection door (short-cut available)
DI 2.7	Motor overload
DI 3.0	Safety door 1
DI 3.1	Lubrication error
DI 3.2	Mold adjustment photo-sensor
DI 3.3	Full-auto photo-sensor
DI 3.4	Robot
DI 3.5	Core 3 in end / Screwing 3
DI 3.6	Core 3 out
DI 3.7	Screw speed sensor

2.3.6 Connecting the thermocouples (X200, X201)

Pin assignments	
for connector	

Interface for thermocouple	
Connector designation:	X200, X201
-	Input
Connector type:	8-pin male c

8-pin male connector

X200		
Pin	Name	Туре
1	TI1+	V
2	TI1-	V
3	TI2+	V
4	TI2-	V
5	TI3+	V
6	TI3-	V
7	TI4+	V
8	TI4-	V
X201		
	X201	
Pin	X201 Name	Туре
Pin 1	X201 Name TI5+	Type V
Pin 1 2	X201 Name TI5+ TI5-	Type V V
Pin 1 2 3	X201 Name TI5+ TI5- TI6+	TypeVVVV
Pin 1 2 3 4	X201 Name TI5+ TI5- TI6+ TI6-	TypeVVVVV
Pin 1 2 3 4 5	X201 Name TI5+ TI5- TI6+ TI6- TI7+	Type V V V V V V V V V V
Pin 1 2 3 4 5 6	X201 Name TI5+ TI5- TI6+ TI6- TI7+ TI7-	Type V V V V V V V V V V V V V V V V
Pin 1 2 3 4 5 6 7	X201 Name TI5+ TI5- TI6+ TI6- TI7+ TI7- TI8+	Type V

Sensor	
Thermocouple	K/J
Temperature range	0~700 °C
Absolute accuracy	±3K
A/D-characteristics	
Resolution	16Bit

2s

Resolution Sampling rate

Connecting sensor and actuators



Fig. 2-10 Connection of the thermocouple

Signal description The analog inputs are assigned with the following signals:

TI1+, TI1-	Nozzle
TI2+, TI2-	TC : 2
TI3+, TI3-	TC : 3
TI4+, TI4-	TC : 4
TI5+, TI5-	TC : 5
TI6+, TI6-	Oil temperature
TI7+, TI7-	(spare)
TI8+, TI8-	(spare)
2.3.7 Connecting the linear scale (X202)

Pin assignments	
for connector	

Interface for linear scale
Connector designation:

Connector type:

X202 Input 12-pin male connector

|--|

X202		
Pin	Name	Туре
1	LS1+	V
2	LS1	V
3	LS1-	V
4	LS2+	V
5	LS2	V
6	LS2-	V
7	LS3+	V
8	LS3	V
9	LS3-	V
10	LS4+	V
11	LS4	V
12	LS4-	V

Sensor

Туре	Linear scale
Resistance value	1KΩ~10KΩ
Accuracy	±1%

A/D-characteristics

Resolution	12Bit
Sampling rate	2ms

Connecting sensor and actuators



Fig.2-11 Connection of the linear scales

Signal description The analog inputs are assigned with the following signals:

LS1+, LS1, LS1-	linear scale 1 (0-10V): Mold
LS2+, LS2, LS2-	linear scale 2 (0-10V): Screw
LS3+, LS3, LS3-	linear scale 3 (0-10V): Ejector
LS4+, LS4, LS4-	linear scale 4 (0-10V): Carriage

2.3.8 Fast analog inputs (X207)⁵

Pin	assignments	
for o	connector	

Interface for fast analog input (FAI)		
Connector designation:	X207	
	Input	
Connector type:	6-pin male connector	

Table 2-9	Pin assignments of connector

X207		
Pin	Name	Туре
1	V _{ref}	V
2	M _{analog}	V
3	M0+	V
4	M0-	V
5	M1+	V
6	M1-	V

A/D-characteristics

Resolution	14Bit
Polarity	Unipolar

Signal description

The Fast Analog Inputs are assigned with the following signals:

M0+, M0-	first channel FAI (0~10V)
M1+, M1-	second channel FAI (0~10V)
V _{ref} , M _{analog}	reference power output (DC 10V)

Connecting sensor and actuators





⁵ Fast analog inputs (X207) are only applicable for CI16iP.

Remarks:

DBW1226	Filter for analog_in_fast 0	Filter for analog_in_fast 1	Filter configuration:
			Bit 7 to 4: always "0000"
			Bit 3 to 0: 0 – Filter is disabled, 1 to 15 – different Filter characteristics
			Filter configuration:
DBW1228	Filter for analog_in_fast 2	Filter for analog_in_fast 3	Bit 7 to 4: always "0000"
			Bit 3 to 0: 0 – Filter is disabled, 1 to 15 – different Filter characteristics
DBW1230	X207: analog_in_fast 0		In Volts (010), process data to PLC
DBW1232	X207: analog_in_fast 1		In Volts (010), process data to PLC
DBW1234	analog_in_fast 2		In Volts (010), process data to PLC
DBW1236	analog_in_fast 3		In Volts (010), process data to PLC

Example:

If the second channel of Fast Analog Inputs is connected with Pressure Sensor, the actual value of Pressure Sensor can be read out in DB1.DBW1232, the correspondent software Filter can then be set in DB1.DBB1227, where 0 refers to disabling of Filter while 1 to 15 refer to enabling of different Filter characteristics. The Filter is intended for noise removal.

2.3.9 Connecting the digital outputs (X300, X301, X302, X303, X304)

Connector type:

Pin assignments	
for connector	

Interface for digital outputs Connector designation:

X300, X301, X302, X303, X304 Output 10-pin male connector

Table 2-10Pin assignments of connector

X300		
Pin	Name	Туре
1	1L+	V
2	1M	V
3	DQ0.0	1
4	DQ0.1	1
5	DQ0.2	1
6	DQ0.3	1
7	DQ0.4	1
8	DQ0.5	1
9	DQ0.6	1
10	DQ0.7	1
	X30	1
Pin	Name	Туре
1	2L+	V
2	2M	V
3	DQ1.0	1
4	DQ1.1	1
5	DQ1.2	1
6	DQ1.3	Ι
7	DQ1.4	Ι
8	DQ1.5	Ι
9	DQ1.6	1
10	DQ1.7	Ι
X302		
Pin	Name	Туре
1	3L+	V
2	3M	V
3	DQ2.0	1
4	DQ2.1	1
5	DQ2.2	
6	DQ2.3	1
7	DQ2.4	1
8	DQ2.5	1
9	DQ2.6	1
10	DQ2.7	

X303		
Pin	Name	Туре
1	8L+	V
2	8M	V
3	DQ3.0	1
4	DQ3.1	1
5	DQ3.2	1
6	DQ3.3	1
7	DQ3.4	
8	DQ3.5	1
9	DQ3.6	1
10	DQ3.7	1
	X30)4
Pin	Name	Туре
Pin 1	Name 9L+	Type V
Pin 1 2	Name 9L+ 9M	Type V V
Pin 1 2 3	Name 9L+ 9M DQ4.0	Type V I
Pin 1 2 3 4	Name 9L+ 9M DQ4.0 DQ4.1	Type V I I
Pin 1 2 3 4 5	Name 9L+ 9M DQ4.0 DQ4.1 DQ4.2	Type V I I I
Pin 1 2 3 4 5 6	Name 9L+ 9M DQ4.0 DQ4.1 DQ4.2 DQ4.3	Type V I I I I I I I
Pin 1 2 3 4 5 6 7	Name 9L+ 9M DQ4.0 DQ4.1 DQ4.2 DQ4.3 DQ4.4	Type V I I I I I I I I I
Pin 1 2 3 4 5 6 7 8	Name 9L+ 9M DQ4.0 DQ4.1 DQ4.2 DQ4.3 DQ4.4 DQ4.5	Type V I I I I I I I I I I I I I
Pin 1 2 3 4 5 6 7 8 9	Name 9L+ 9M DQ4.0 DQ4.1 DQ4.2 DQ4.3 DQ4.4 DQ4.5 DQ4.6	Type V I I I I I I I I I I I I I

Voltage

Rated load voltage	24V
Max. load voltage	28.8V

Current	
Rated load current	2A
Max. load current	2.4A
Short-circuit protection	Yes
Simultaneity factor	50%

Connecting sensor and actuators



Fig.2-13 Connecting the digital outputs in SIJECT 16i

Signal description The digital outputs are assigned with the following signals:

DQ 0.0	Core 1 in
DQ 0.1	Core 1 out
DQ 0.2	Core 2 in
DQ 0.3	Core 2 out
DQ 0.4	Carriage advance
DQ 0.5	Carriage retract
DQ 0.6	Charging
DQ 0.7	Injection
DQ 1.0	Mold close
DQ 1.1	Mold close fast
DQ 1.2	Mold open
DQ 1.3	Mold open fast
DQ 1.4	Mold adjustment advance
DQ 1.5	Mold adjustment retract
DQ 1.6	Ejector advance
DQ 1.7	Ejector retract
DQ 2.0	Suck back
DQ 2.1	Pump 2
DQ 2.2	Zero back pressure
DQ 2.3	Robot
DQ 2.4	Core 3 in
DQ 2.5	Core 3 out
DQ 2.6	Air blow 1
DQ 2.7	Air blow 2

DQ 3.0	Heater nozzle
DQ 3.1	Heater output 2
DQ 3.2	Heater output 3
DQ 3.3	Heater output 4
DQ 3.4	Heater output 5
DQ 3.5	(spare)
DQ 3.6	(spare)
DQ 3.7	(spare)
DQ 4.0	Motor star start
DQ 4.1	Motor triangle start
DQ 4.2	Motor start
DQ 4.3	Alarm light
DQ 4.4	Lubrication pump
DQ 4.5	Alarm buzzer
DQ 4.6	(spare)
	(Sparc)
DQ 4.7	(spare)

Notice

The 24VDC power supply should meet the requirements of the safe separation in accordance with DIN EN 50178.

The terminal M in the 24VDC power supply for the digital output (Signals 1M, 2M, 3M, 8M and 9M) are to be earthed additionally



Danger

The positive terminal of digital outlet lines (terminal $1L^+ - 3L^+$, $8L^+$, $9L^+$) must be protected through a 10A fuse (See Fig.2-16).

The connection from 24VDC power supply to the line L^+ and M may not be exchanged, otherwise it can bring about a destruction in the CI board!

2.3.10 Connecting the analog outputs (X305)

Pin assignments	
for connector	

Interface for analog outputs	
Connector designation:	Х

Connector type:

X305 Output 8-pin male connector

Table 2-11 Pin assignments of connector

X305		
Pin	Name	Туре
1	AQ1+	V
2	AQ1-	V
3	AQ2+	V
4	AQ2-	V
5	AQ3+	V
6	AQ3-	V
7	AQ4+	V
8	AQ4-	V

Output characteristics

Voltage range	-10V~+10V
Max. output current	±5mA
Gain error	±1%
Offset error	±100mV
Resolution	12Bit

Connecting sensor and actuators



Fig. 2-14

Connecting the analog outputs

Signal description

The analog outputs are assigned with the following signals:

AQ1+, AQ1-:	Pressure valve (0-140bar)
AQ2+, AQ2-:	Flow valve (0-100%)
AQ3+, AQ3-:	Back pressure valve (0-140bar)
AQ4+, AQ4-:	4 th proportional valve

Pin assignments for connector

2.3.11 Connecting the proportional valve current output (X306)⁶

Interface for proportional valve current output		
Connector designation:	X306	
-	Output	
Connector type:	6-pin male connector	

onnector
o

X306			
Pin	Name	Туре	
1	PV1+	V	
2	PV1-	V	
3	V1+	V	
4	V1-	V	
5	V2+	V	
6	V2-	V	

Output characteristics

Voltage range	+24V~38V
Current output	0.75~1.4A
Resolution	12 Bit

Notice

The output current for proportional valve depends on the inner resistance of valve and the external supplied DC power voltage. For instance, if the inner resistance of valve is 200hm, the supplied voltage is 24V; then the maximum output current for valve is 1.2A. The output current for other type valve should comply with Ohm's Law.

Connecting sensor and actuators



Fig. 2-15 Connecting the proportional valve current output

⁶ The interface for proportional valve current output (X306) is only applicable for CI16i.

 Signal description
 The proportional valve current outputs are assigned with the following signals:

 V1:
 Proportional pressure valve

 V2:
 Proportional flow valve

2.4 Power Supply

Screw-terminal For SIJECT 16i system, DC24V power supply unit required for supplying CI and OP is wired to screw-terminal block and should be from an isolated secondary circuit.

The minimum cross section of the wire is $0.75m^2$.

Terminal assignments

Table 2-13Terminal assignments of terminal board

Terminal		
1	P24	DC24V+
2	Μ	DC24V-
3	PE	Protective earth

Characteristics of the load power supply

Table 2-14 Input specification

Parameters	Min.	Max.	Units
Rated input voltage	20.4	28.8	V
Fuse	On board fusing		
Ripple	Input filter		

Operator panel The operator panels does not have separate power supply terminals. It is supplied via the signal cable from the CI.

Digital input/output The digital inputs/outputs require an external DC24V switch power.

Proportional valve The proportional valves need a separate switch power. It can be chosen in accordance with the type of proportional valve.



Caution

Power supply cable and signal cable should be seperated, i.e., linear scale and thermocouple signal cable can not be assigned to the same conduit with power supply cable.

Notice

The 24VDC power supply should meet the requirements of the safe separation in accordance with DIN EN 50178.

The terminal M in the 24VDC power supply for the digital output (Signals 1M - 3M, 8M, 9M) are to be earthed additionally.

2.5 Grounding

Grounding The following grounding connections must be implemented: **Connections**

- OP15B
- CI16i/iP

The grounding connection for the OP must be taken into account when installing the machine.



Fig.2-16 Grounding diagram for OP and CI

To ensure the normal operation of equipment, good grounding is required. Users are recommended to take following actions (according to GB/T5226.1-1996, eqv IEC204-1:1992):

- The grounding wire should be Yellow/Green wire with cross section of 2.5 mm²;
- 2. Linear scale and both sides of the shield of thermocouple signal wire must be grounded well on the injection molding machine;
- 3. Metal sheet embedded underground can be used as earth wire. Water pipe or metal frame of building which are grounded well can also be used as earth wire;
- 4. To ensure the reliability of the grounding, copper lead should be welded with earth wire.



Danger

The grounding wiring must be finished prior to connecting the power supply!

2.6 LEDs and Mode selector S1

Error and status LEDs There are 10 LEDs on the front panel of the CI.

• DP_SF* DP_STAT * STAT 0 STAT 1 1:MRES 2:STOP 3:RUN S1 $(\hat{\mathbb{I}})$ 4:RUN_P BATF DC5V SF FORCE STOP RUN Note: The symbol * means that this LED is only used in SIJECT CI16iP.

Fig. 2-17 Position of LEDs and mode selector S1

LED	Meaning	Description	Remarks
DP_SF (red)	System Fault	Lights up if system is fault.	For CI16iP
DP_STAT (green)	System Normal	Lights up if system works normally.	For CI16iP
STAT0 (green)	CI Normal	Flashes at 1 second interval if CI is normal.	
STAT1 (red)	CI Fault	Lights up if CI is fault.	
BATF (red)	Battery Fault	Lights up if the battery is defective or not inserted.	
DC5V (green)	Power Supply Error	The LED will be bright all the time if the DC 5V circuit is normal.	Check DC5V circuit.

LED	Meaning	Description	Remarks
SF (red)	System Error/Fault	 LED flashes when there is: Hardware faults Firmware errors Programming errors Parameter assignment errors Arithmetic errors Timer errors Defective memory card Battery failure or no backup on power on I/O fault/error (external I/O only) 	You must use a programming device and read out the contents of the diagnostics buffer to determine the exact nature of the error/fault.
FORCE (yellow)	Force job	Lights up if a force job is active	
STOP (yellow)	STOP Mode	Lights up when CPU is not scanning the user program. Flashes at 1 second interval when CPU requests a memory reset.	
RUN (green)	RUN Mode	 Flashes at 2Hz during CPU restart: At least continue 3 seconds; however, CPU restart can be shorter after CPU restart During the CPU restart, the STOP LED always lights up; when the STOP LED goes dark, the outputs are enabled. 	

Mode selector S1 Mod

Mode selector S1 has 4 different positions. It depends on the Gray code.

Table 2-16Mode selector S1

	GRAY 2	GRAY 1
MRES	0	1
STOP	0	0
RUN	1	0
RUN_P	1	1

Position	Designation	Meaning
MRES	Memory Reset	Momentary-contact position of the mode selector for resetting the CPU memory.
		A special sequence must be observed when resetting the CPU memory with the mode selector (refer to section 3.5).
STOP	STOP Mode	The CPU does not scan user programs.
		Programs can:
		 Be read out of the CPU with a programming device (CPU→PG)
		 Be loaded into the CPU with a programming device (PG→CPU)
RUN [*]	RUN Mode	For internal use only! The PLC stops any communication in this mode. Don't use this mode on customer side.
RUN-P	RUN- Program	The CPU scans the user program. Programs can:
	Mode	 Be read out of the CPU with a programming device (CPU→PG)
		 Be loaded into the CPU with a programming device (PG→CPU)

Table 2-17 Meaning of Mode selector S1

* Note: This mode is inapplicable to CI16iP. If in CI16iP, the Mode Selector S1 is set in RUN position, CPU will NOT work in order.

Meanings

3 Start-up

3.1 General

Start-up requirements

The following is required:

- User Manual: Operation Manual SIJECT 16i
- PC/PG: Data exchange with control system
 - With MPI adapter and SIMATIC S7-300 programming tool: for down-/upload PLC-program for SIJECT16i;
- MMC card: can be used to store customer specific picture (CSP), recipe data and PLC application program. Detailed operation steps can be found in Operation Manual section 3.1.10. The PLC / menus / CSP can be saved/loaded to/from MMC card.

The mechanical and electrical installation of the equipment must be completed.

Notice

For installation, refer to the installation description provided in the Chapter Two of this manual.

The control system with its components boots without errors.

Start-up Sequence

A possible start-up sequence for the SIJECT 16i is as follows:

- 1. Check whether the CI boots
- 2. Check the diverse versions of PLC, CI and OP
- 3. Check the I/Os via display and the LEDs in CI
- 4. Set recipe data
- 5. Optimize the data
- 6. Save the data



Warning

For SIJECT CI 16iP, PLC module can not run normally when Mode Selector S1 is indicated to **RUN** mode at power-on. Therefore, make sure that S1 is not at **RUN** position when electrifying the system.

3.1.1	Access levels	
User c	lass	The SIJECT 16i implements a user class concept to enable certain data areas. The user classes have protection level 1 and 2.
User class 1		When setting the parameters via operator panel, the screen will display "Enter Password, XXXX". User should enter the password of class 1. Factory setting for the password class 1 is 1111 . Then push the Enter key to confirm the entry.
		After Switch-On of the control system, if there is no action for 5 minutes, the system will require password entry for the second time when you operate again.
User c	lass 2	User class 2 requires the password 2 (2000) on the Service screen. It is set up so as to avoid the accidental modification of function parameters by the operator. They are the most important parameters with the influence on the machine function. Only the service engineer has the accessible right.
^		Caution
<u>_i</u> ,	7	When changing the recipe parameters, every machine movement must be stopped!

Notice:

Protection level 1 and 2 are only for OP15B (not for SIMATIC OP's).

3.1.2 Structure of recipe data

Definition	Recipe data is consisted of diverse values with different units. Usually, one set of recipe data contains the following parameters:							
	 Hydraulic pressure P 							
	 Hydraulic flow F 							
	 Movement position S 							
	 Set time and actual time T 							
	 Set temperature value and actual temperature value 							
	– Counter number							
	 Mode selection number 							
User class	To set and change the general r Start-up of the service paramete	ecipe data, user class 1 must be activated. ers generally requires user class 2.						
Unit	The physical units of the recipe data are set as follows:							
	Table 3-1 Recipe data uni	t						
	Parameter	Unit						
	Pressure P	bar						
	Flow F	%						
	Position S	mm						
	Timer T	second						
	Temperature	°C						

Standard data For convenience of the user, we deliver the controller with the integrated PLC-program. You should set and adjust the recipe data in compliance with the program.

Counter

Mode selection

No default recipe data exist in the control system with the version of the control supplied unless otherwise programmed.

No unit No unit

3.1.3 Handling of recipe data

Display:						
Input via keys and MMC card.						
Making back-up copies and saving to MMC card						
Loading the recipe data from MMC card						
If the process of loading recipe data from MMC card has errors, there will be system message to inform the error.						
User can execute related operation according to the alarm.						
Notice						
You should press Enter key to confirm your setting whenever any parameter has been changed.						

3.1.4 Recipe data saving

Internal data saving The recipe data on the screen can be automatically saved in the memory during operation. After power on for the next time, the saved recipe data will be recovered.

To avoid loss of the setting parameters, the recipe data should be saved internally before the control system is switched off. In the permanent memory, max.30 sets of recipe data with the relevant mould number can be saved.

It is recommended to carry out internal data saving whenever important data changes have been made.

Saving data internally:

Use the Save/Load key to enter save screen, and use Selection key

to select "system", then input recipe number (from 1 to 30)⁷, then

press Enter key to confirm your entry. Lastly, press soft key F3 to load the recipe data.

External data saving Apart from internal data saving, the recipe data can also be saved externally, i.e. in MMC card. Max.50 sets of recipe data with the relevant mould number can be saved.

External data saving should be performed whenever series start-up has to be done.

Saving data externally:

- Plug the MMC card in the slot after the controller is switched off;
- Use the Save/Load key to open the save/load screen;
- Use Selection key to select MMC card;
- Enter the value with the recipe number(in the range from 1 to 50);
- Press Enter key to confirm your entry;
- Press soft key F3 to do the saving. The system will display a message when saving operation is finished.

Press et acknowledge it.

⁷ If the number exceeds 30, the data can only be displayed and can not be saved. The screen will give message during operation.

3.2 Switching on and Booting the control system

Procedure

Visual inspect the system for:

- proper mechanical installation with tight electrical connections;
- power supply connection;
- connection for shielding and grounding.

Turn on the control system.

Notice

If memory and Mode selector S1 are set correctly, the control system boots.

Mode selector S1
(hardware)The CI is provided with the Mode selector to assist start-up of the
control system. This switch can be operated by a screwdriver.

Table 3-2 Mode selector setting

Position	Status	Meaning
1	MRES	Reset CPU memory
2	STOP	STOP mode
3	RUN	RUN mode
4	RUN_P	RUN PROGRAM mode

When starting up the control system, Mode Selector S1 should be at RUN_P position. Do not use RUN mode! RUN mode is only for internal debugging. The PLC stops any communication in RUN mode.

The position **RUN_P** must be held during the down-/uploading PLC-program.

Booting the control system When the control system is turned on for the first time, an initial state of the control system is established automatically. All memory areas are initialized and loaded with previously-stored default data.

This initial state is the precondition for error-free start-up of the control system.

3.2.1 Boot messages

Displays on
the screenWhen the control system is booting, the booting process will be
displayed on the screen as follows:

- 1. At first the customer specific picture is displayed for 3 seconds;
- 2. Then on the screen shows the "Information" menu for 3 seconds;
- 3. After this the "Monitoring" screen will be opened.

LED signal If the control system has booted without errors, the green DC5V LED will light up and the green STAT1 LED (in Cl 16i) flash at 1 second interval or the green DP_STAT LED (in Cl 16iP) lights up.



Fig. 3-1 LED signal

For any other case you can refer to Table 2-15 in section 2.6.

You can also check the booting status on the **Information screen 2** as follows:

- 1. Use the Information key to open the Information screen 1
- 2. Push the PgDn key 1 = 1 to call the Information screen 2
- 3. Check the messages on the screen:
 - PLC Switch:
 - PLC Startup:
 - PLC LifeCnt:
 - OP Communication:
 - CI EEPROM:
 - CI type

ContrastIn case that the display contrast doesn't match with the environment,
you can adjust the contrast using the Function key.

Steps are as follows:

- 1. Press Function key ^F to enter function picture;
- Press softkey F3 U to increase the contrast, and press softkey F4
 to decrease contrast.

In addition, screen back light can also be set on this screen. If selected, then back light will be turned off automatically if there is no key pressed during 3 minutes; otherwise, back light will be turned off if there is no key pressed during 10 minutes.



For the first operation, password class 1 (1111) should be entered.

	SIJECT 16i
	Tel. +86-25-52101888
	Fax +86-25-52101666
	Siemens Numerical Control Ltd.,
	Nanjing, P.R.China
	Starting, please wait

Fig. 3-2 Customer Specific Picture (CSP)

This picture is presented for 3 seconds. SIEMENS can make every specific picture according to the requirements of users.

Menu 2: Information screen 1 400 Ð /// l i Ē t. 555 **SIJECT-OP15B System Information OP** Version 1.10 **CI** Version 1.10 **PLC Version** 2.08 Siemens Numerical Control Ltd. OEM @ (DI) | i

Fig 3-3 Information screen 1

This picture will last 3 seconds.

Menu 3: Monitoring screen

	t)- 🖒			7	₿	i					
	1 4	14	l0 bar	10)0 %						
	▼ □1 T □		□ 21 >⊗□	t ∎≪	¹ 3 1 ≫ □						
MidPos	1500).0 mm	PartCou	unt [6553	35					
ScwPos	999).9 mm	CurStar	tup [6553	5					
EjePos	999) <u>9</u> mm	CycTim	ie	99	9 s					
ScwSpd 1200.0 rpm RecipeNo. 50											
	-										
		Lube					≣1∣				

Fig.3-4 Monitoring screen

This screen is the main picture of the system. This screen is always displaying until it is switched to the desired menu by pressing the other keys.

The operator can supervise the production process with reference to the parameters displayed on the screen. The current operation state is

displayed in the status field. In case of malfunction, the alarm symbol will flash and user can enter alarm picture to check the alarm.

Notice:

For the meaning of each indicator on this screen, please refer to Chapter Two of Operation Manual for details.

3.2.2 Alarm

General Up to 32 alarms can be displayed in SIJECT16i. The active alarm will pop up on the Alarm screen.

Alarm list

You can see the alarm text and remedy in following table:

Table 3-3	Alarm list				
Alarm Name	Description / Remedy				
	Mold adjustment is over limit				
AdjLimit	1. Check the limit switch				
	2. Readjust the mold				
	Auto-mold adjustment finished.				
AutAdjFin	1. Manual operation is permitted.				
	Photo-sensor for mold adjustment is invalid				
AdjSenErr	1. Photo-sensor is invalid in mold adjustment advance/retract.				
	2. Check if the photo-sensor is damaged.				
	Temperature is not in permitted range.				
TmpLimit	1. Check the heating status of barrel.				
	2. Check if the heating LED lights up.				
	Oil temperature is out of the range.				
OilTmp	1. Check the oil temperature.				
	2. Check the oil thermocouple.				
	Hydraulic pump is overload.				
MotLoad	1. Check the hydraulic system.				
	2. Check the circuit breaker.				
	Safety door is not closed.				
MldSg	1. Check the limit switch of safety door.				
	2. Close the safety door.				
	Product counter is full.				
PartCount	1. Enter a big value.				
	2. Set the part counter to zero.				
	Actual cycle time surpasses the setting.				
TmCyc	1. One step occupies too much time during the cycle.				
	2. Cycle time is too short.				
	Cycle photo-sensor is covered.				
CycSenCov	1. The photo-sensor is damaged.				
	2. The photo-sensor is covered by the workpiece.				
	Cycle photo-sensor has error.				
CycSenErr	1. The photo-sensor is damaged.				

Alarm Name	Description / Remedy					
	Can not open mold to end position.					
MldOpnErr	1. Check the limit switch.					
	2.Adjust the position/pressure/flow and tolerance.					
	Mold can not be locked.					
TmMldLck	1. Clear the obstacle in the mold.					
	2. Adjust pressure/flow.					
	Ejector is not in the back position.					
EjeNotBck	1. Check if the ejector is at end limit switch.					
	2. Check pressure/flow.					
	Cores are not back to the start position.					
CorNotBck	1. Check the limit switch for core in/out.					
	Charging is not finished.					
TmCha	1. No material in hopper.					
	2. Check if the backpressure is too high.					
	Low-pressure mold protection time is up.					
TmMldPro	1. Clear the obstacle in the mold.					
	2. Extend the mold protection time.					
	Injection safety door is not closed.					
InjSg	1. Close the safety door when injection.					
	2. Check the switch of safety door.					
	Lubrication oil level is too low.					
LubeErr	1. Check the setting of lubrication.					
	Waiting for robot.					
Alarm 20	1. Waiting for robot downward.					
	Robot is failed.					
RobErr	1. Check the sensor of robot.					
	2. Check the setting of robot.					
	Injection time has been exceeded.					
Tclnj	1. Check the material.					
	2. Check the nozzle.					
	Screw speed is abnormal.					
ScwSenErr	1. Check if there is any material in the barrel.					
	2.					
	Power supply of linear scale is failure.					
LS PS Err						
	i nermocouple of channel 1 (nozzle) is broken.					
Fault						
	Ζ					

Alarm Name	Description / Remedy
	Thermocouple of channel 2 (heater) is broken.
TC2 Fault	1
	2
	Thermocouple of channel 3 (heater) is broken.
TC3 Fault	1
	2
	Thermocouple of channel 4 (heater) is broken.
TC4 Fault	1
	2
	Thermocouple of channel 5 (heater) is broken.
TC5 Fault	1
	2
	Thermocouple of channel 6 (oil) is broken.
TC6 Fault	1
	2
Alarm 31	
Alarm 32	

3.3 Checking I/Os

Overview After booting without any error, the control system can be put into operation. Check I/Os status prior to setting the parameters, which can avoid the unnecessary troubleshooting.

Operating sequences



Press Information Key to enter information screen.

Then press softkey F3 or F4 to check the actual status of digital input/output.



Fig. 3-5 Information Screen 1

Then, press softkey F3 to enter DI screen (digital input) :

® 1	•	t)-	26	4000 555	Ð	₿	i	
X2	03:		X204:		X205:	X206:		
DI	0.0		DI 1.0		DI 2.0	DI 3.0		
DI	0.1		DI 1.1		DI 2.1	DI 3.1		
DI	0.2		DI 1.2		DI 2.2	DI 3.2		
DI	0.3		DI 1.3		DI 2.3	DI 3.3		
DI	0.4		DI 1.4		DI 2.4	DI 3.4		
DI	0.5		DI 1.5		DI 2.5	DI 3.5		
DI	0.6		DI 1.6		DI 2.6	DI 3.6		
DI	0.7		DI 1.7		DI 2.7	DI 3.7		
<u>ه</u>								≣t

Fig. 3-6 Information screen 1.2 --- DI

Use current parameters to check the LED status.

Press different button in manual mode to observe the changing status.

On information screen 1 (Fig. 3-5 Information Screen 1), press softkey F4 to enter DO screen (digital output); or, on information screen 1.2 (Fig. 3-6 Information Screen 1.2 --- DI), press softkey F1 to enter DO screen.

0	I ∎	t)-	` }	000 555	Ē	Ň	₽	i	
X30):	X301	:	X30:	2:	X30	3:	X304	l:
DQ0	.0	DQ1.(D 🔳	DQ2	.0 🔳	DQ3	.0 🔳	DQ4.	0 🔳
DQ0	.1	DQ1.1	1 🗆	DQ2	.1 🗆	DQ3	.1 🗆	DQ4.	1 🗆
DQ0	.2	DQ1.3	2 🔳	DQ2	.2 🔳	DQ3	.2 🔳	DQ4.	2 🔳
DQ0	.3	DQ1.:	3 🗆	DQ2	.3 🗆	DQ3	.3 🗆	DQ4.	3 🗆
DQ0	.4	DQ1.4	4 🔳	DQ2	.4 🔳	DQ3	.4 🔳	DQ4.	4 🔳
DQ0	.5	DQ1.	5 🗆	DQ2	.5 🗆	DQ3	.5 🗆	DQ4.	5 🗆
DQ0	.6	DQ1.(6 🔳	DQ2	.6 🔳	DQ3	.6 🔳	DQ4.	6 🔳
DQ0	.7	DQ1.7	7 🗆	DQ2	.7 🗆	DQ3	.7 🗆	DQ4.	7 🗆
			Fa	rce out	put 🗌	3.7			
	R	Force Output							∎t

Fig. 3-7 Information Screen 1.3 --- DO

Use current parameters to check the LED status.

Press different button in manual mode to observe the changing status.

On Fig. 3-7 Information Screen 1.3 --- DO, "Force Output" is for the force output of certain point. For example, enter 3.4 and press F2 "Force Output", then the box will backlight. At this moment, DQ3.4 is backlighting on the screen, and in the system this point will have output and LED lights up.

3.4 Setting important parameters

In this chapter, we will give a description of how OEMs set the most important parameters for injection molding machine. It contains how to select language and service, how to set each parameter, such as linear scale, password, saving mode, start-up of proportional valve, combination of pumps, lubrication, temperature and ramp.



Warning

Never pull out or plug in the connector while the equipment is live! Otherwise this can result in the damage of data loss or control failure.

Caution

Password of level 2 (2000) must be entered prior to parameter setting! During operation, do not transfer the parameter!

3.4.1 Language selection

General

It is very important for operators to find the desired menus as soon as possible. As the first step you should select the appropriate language. You can select the language on this screen.



Fig. 3-8 Function Screen

Notice:

2.

For SIJECT OP15B FV1, English, Chinese, Turkish and Russian are available for your selection.

For SIJECT OP15B FV2, English, Chinese, Spanish and one reserved language are available for your selection.

Operating Sequences



Change language: first move the cursor to the third line, then press softkey F1 to choose the desired language and confirm with Enter Key.

Refer to Fig. 3-8 Function Screen, language can be changed. Steps are as follows:

- 1. Press cursor key \blacksquare or \checkmark to enter language selection box;
 - Press selection key (if it is the first entry, then input passward of level one of 1111, then press Enter key to return to Function Screen);
- 3. The cursor moves to left, and choose by key \mathbf{A} or \mathbf{V}
- 4. Select one language;
- 5. Press Enter Key to confirm.

3.4.2 Service selection

General

Users can execute some basic setting and selections by this function.

۵ì	T,	t)-	1	- 000 555	•		Œ	i	
CarRetMod			Time	V	ScrewCam			55	
CycSenNSTD			NOpn	▼	Motor Shut			99	s
LubErrNSTD			NOpn	▼	Heat Off			off T	7
FastMldOpn			Norm	▼	EjeRetTol			.9	mm
MotStrPro			On	▼	MidOpnTol			0.0	mm
SpecSel 1			Off	V	SpecPar 3		0)	
SpecSel 2			Off	▼	SpecPar 4				
		_							
	l		,	Ð]	PV		⊒ 1

Fig. 3-9 Service Screen 1

Operating Sequences



Press Service Key to enter Service screen 1. See Fig.3-9.

Carriage retract mode (CarRetMod) --- Carriage retract can select position mode or time mode.

Cycle sensor not standard (CycSenNSTD) --- Sensor can be set as Normal Open mode (Nopn) mode or Normal Close (NClo) mode.

Lubrication error not standard (LubErrNSTD) --- Switch contact in the alarm circuit can be set as Normal Open mode (Nopn) mode or Normal Close (NClo) mode.

Fast mold open (FastMidOpn) --- It can be set as Normal mode (fast mold open) and special mode (slow mold open).

Motor protection (MotStrPro) --- Motor protection can be selected, i.e., whether to extend time during the start-up of star triangle. Motor protection also can be deselected.

Special selection 1 (SpecSel 1) --- Spare.

Special selection 2 (SpecSel 2) --- Spare.

Screw cam number (ScrewCam) --- During screw speed measurement, cam numbers set on the screw. Range: 1~ 255.

Motor shut --- When there is alarm, it is the time passing by from alarm occurring to motor shut. Range: 30~999.

Heat Off --- When alarm occurs, user selects whether to switch off the heater.

Ejector retract tolerance (EjeRetTol) --- When ejector selects linear scale, the tolerance of ejector retract can be set from 0.1~9.9 mm.

Mold open tolerance (MIdOpnTol) --- The tolerance of mold open can be set from $1.0 \sim 99.9$.

	Special parameter 3 (SpecPar 3) Spare.							
	Special parameter 4 (SpecPar 4) Spare.							
Operation Example	o select position in carriage retract mode, you can do as follows:							
	1. Press cursor key 🔺 or 🔻 to	o enter CarRetMod selection;						
	2. Press selection key 🔲 , and the cu	rsor moves to left;						
	 Press cursor key or to Confirm by Enter key. 	o select "Pos";						
3.4.3 Setting linear scale

General

Users can select two linear scales or three linear scales, and set reference point and length.



Fig. 3-10 Service Screen 2 --- linear scale setting

Operating sequences Press softkey F2 to enter the next screen. See Fig. 3-10 Service screen 2 --- linear scale setting.

Linear Scale mold:

Switch --- Proximity switch signal. When mold close is at position, the box will backlight, showing the reference point of linear scale.

Reference point --- setting value. Mold lock end should be the reference of linear scale.

 \mbox{Length} --- setting value. The length of linear scale can be set here, ranged from 1 ${\sim}6553\mbox{mm}.$

Actual value --- displayed value. Display the actual value of linear scale.

Current value --- displayed value. It is the difference from actual value to reference point.

Linear scale injection:

Reference point --- setting value. Reference point of linear scale can be set here.

 \mbox{Length} --- setting value. The length of linear scale can be set here, ranged from 1 ${\sim}6553\mbox{mm}.$

Actual value --- displayed value. Display the actual value of linear scale.

Current value --- displayed value. It is the difference from actual value to reference point.

Linear scale ejector:

Switch --- Proximity switch signal. When ejector retract is at position, the box will backlight, showing the reference point of linear scale.

Reference point --- setting value. Ejector retract end should be the reference of linear scale.

 \mbox{Length} --- setting value. The length of linear scale can be set here, ranged from 1 ${\sim}6553\mbox{mm}.$

Actual value --- displayed value. Display the actual value of linear scale.

Current value --- displayed value. It is the difference from actual value to reference point.

Linear scale ejector --- Linear scale ejector can be selected or deselected here.

3.4.4 Setting password

General

The password has three levels. Password level 1 of factory setting is 1111 and level 2 is 2000. Refer to manufacturer for password of the highest level.

0		t) –	26	• 00 0 <u>555</u>	ė		(₿	i	
ŀ	ligher P	wd			New	Pwd 2			
					Rety	/pe Pwo	12		
_			_						
ł	ligher P	wd			New	Pwd 1			
					Rety	/pe Pwo	11		
									⊒₁t
									≡ıı

Fig. 3-11 Service Screen 1.1 --- password setting

Operating sequences Press softkey F3 to enter password setting screen. See Fig. 3-11 Information screen 1.1 --- password setting, and password can be set and changed on this screen.

Upper:

Higher password --- the highest level. The default value of this system is xxxx (please ask the manufacturer), then confirm by Enter Key.

New Password 2 --- A new password 2 can be set here, then confirm it by Enter Key. The default value of this system is 2000.

Retype Password 2 --- retype the new set password 2, and confirm it by Enter Key.

When the password has been successfully changed, the screen will display \Box

a message. Press Acknowledgment Key Key to finish the operation.

Lower:

Higher password --- it is the password level 2. The default value of this system is 2000, then confirm by Enter Key.

New password 1 --- a new password 1 can be set here, then confirm by Enter Key. The default value of this system is 1111.

Retype password 1 --- retype the new set password 1, then confirm it by Enter Key.

When the password has been successfully changed, the screen will display a message. Press Acknowledgment Key

3.4.5 Save/load setting

General

Users can save/load the PLC, menus and CSP (customer specific picture) by this function. It can save/load information to/from MMC.

} t)- ^6 9		3 1 (
Program Types	PLC	•	
		, i	
MMC PLC vers	ion 2.00		
PLC .			
Ver → 🕻	⊒∥≮⊡		

Fig. 3-12 Service Screen 1.2 --- save/load setting

Operating sequences Press softkey F4 **b** to enter save/load screen. The PLC/menus/CSP can be saved/loaded to/from MMC.

Program types --- User can select PLC, menus or CSP.

MMC PLC version --- displayed value. Press softkey F2 "PLC version" to show the PLC version in MMC.

- **Operating examples** To select Menus in Program types. Steps are as follows:
 - 1. Press cursor key A or V to enter program type selection;
 - 2. Press Selection Key 🔳 , and the cursor moves to the left;
 - 3. Press cursor key **A** or **V** to select "Menus";
 - 4. Press Enter Key to confirm the entry.

Download Menus from MMC. Steps are as follows:

- 1. Plug in MMC card in the CI (the operation should be done after turning off the power);
- 2. Select "Menus" in Program Type;
- 3. Press softkey F4 to start data transfer;
- 4. Restart the system after the transfer process is finished. The operation is over.

3.4.6 Proportional valve adjustment

General	
---------	--

Users can adjust the proportional valve and test it.



Fig. 3-13 Service Screen 1.3 --- proportional valve adjustment

Operating sequences Press softkey F5 to enter proportional valve adjustment screen. See Fig. 3-13 Service Screen 1.3 --- proportional valve adjustment. Proportional valve can be adjusted here, and you can test pressure, flow and backpressure under force output mode.

Adjust Valve --- select On/Off to start valve adjustment.

Valve Type --- select the type of valve: flow / pressure / back-pressure / reserved.

Valve Limit --- select min. / max. value.

Pressure Test --- in force output mode, input pressure value, ranged from $0{\sim}140 \text{bar}.$

Flow Test --- in force output mode, input flow value, ranged from 0~100%.

BackPressure Test --- in force output mode, input pressure value, ranged from 0 \sim 140bar.

Operating sequences Firstly, start valve adjustment:

Select "ON" in Adjust Valve mode:



4. Press Enter key to confirm.

Secondly, select valve type, such as pressure valve; then select valve limit, such as maximum:

Choose "Max." in valve limit, and change its value by softkey:



- 4. Confirm it with Enter Key;
- 5. Press softkey F3 "+" to increase the "Max."; or use softkey F4 "-" to reduce "Max.". This process can be observed by external amperemeter.

After finishing the adjustment of the valves, select "OFF" to stop valve adjustment.

Lastly, check the adjustment result:

In the "Force Output" mode, implement the "Pressure Test":

- 1. Press softkey F2 "Force Output", and the upper box will backlight;
- 2. Set the value of 140bar in Pressure Test;
- 3. Check if the external amperemeter reaches the maximum, such as 1Amp.



Caution

The handling with the Proportional valve is subject to the prerequisites that all the electrical wiring is completed and the power supply DC 24V / DC 38V is connected.

We describe the commisioning process as an example provided that the resistance of the proportional valve is 10Ω and 24VDC power supply is adopted. Therefore, it means that the max.output value of PV is reached when the pointer in the amperemeter indicates the maximal value of 1A, and the min. output value is reached when the pointer indicating 100mA (proportional flow valve) and 0 mA (proportional pressure valve).

3.4.7 Pump Combination Setting

General

User can set the pump combination according to different machine type, so as to optimize the energy.



Fig. 3-14 Service Screen 2.1 --- pump combination setting

Operating sequences On service screen 1, press softkey F2 to enter service screen 2 --linear scale setting. Then, press softkey F2 to enter pump combination setting screen. See Fig. 3-14 Service Screen --- pump combination setting. Pump2/pump3/pump4 can be selected here and the flow can be set accordingly.

> Pump2 Flow ---- flow range $0 \sim 100\%$. Pump3 Flow ---- flow range $0 \sim 100\%$. Pump4 Flow ---- flow range $0 \sim 100\%$.

3.4.8 Lubrication setting

<u>له</u> ا	• t)- `}∆ 6	000 <u>555</u>	·E		€	i	
	Lub Time		999	s	999	S	
	Lub Count		32767		32767		
	Lub Status						
	LubOilLevel						
Lube							⊒†

General User can set the time and interval of lubrication.

Fig. 3-15 Service Screen 2.2 --- lubrication setting

Operating sequences On service screen 1, press softkey F2 to enter service screen 2 --linear scale setting. Then press softkey F3 to enter lubrication setting screen. See Fig. 3-15 Service Screen 2.2 --- lubrication setting. Lubrication time and lubrication count can be set here.

Lubrication Time --- every lubrication time can be set here, ranged from $0{\sim}999\text{sec.}$

Lubrication Count --- set numbers of injection cycle. The system will be lubricated automatically when the set injection cycles have been finished. The range is from 1 to 32767.

Lubrication Status --- Press softkey F1 "manual lubrication" to start the

lubrication, then the box will backlight, and is flashing.

Lubrication Oil Level --- Inform the user to add lubrication oil when the oil

level is very low, then the box will backlight and alarm occurs, i.e., is flashing.

3.4.9 Temperature setting

User can set temperature channel and temperature tolerance.

	t)- 🕍 🚥		
TmpTolPlus	3 ° C	Channel 1	Off 🔻
TmpTolMinus	5 °C	Channel 2	Off 🔻
Oil Upper	99 ° C	Channel 3	Off 🔻
Oil Lower	30 ° C	Channel 4	Off 🔻
TmpCompen	399.9 ° C	Channel 5	Off 🔻
Nozzle Mode	CloLoop 🔻	Oil TmpAlm	Off 🔻

Fig. 3-16 Service Screen 2.3 --- Temperature setting

Operating sequences On service screen 1, press softkey F2 to enter service screen 2 --linear scale setting. Then, press softkey F4 F so as to enter temperature setting screen. Temperature channel can be set from 1 to 5, and temperature can be set accordingly.

Temperature Tolerance Plus --- set the tolerance plus for each temperature channel.

Temperature Tolerance Minus --- set the tolerance minus for each temperature channel.

Oil Upper --- set the upper limit of hydraulic oil temperature.

Oil Lower --- set the lower limit of hydraulic oil temperature.

Temperature Compensation --- set the temperature compensation. The system has been set compensation before delivery, and it is unnecessary for users to set it.

Nozzle Mode --- two modes are available, it can be assigned as close-loop or open-loop.

Channel 1 --- select or deselect

Channel 2 --- select or deselect

Channel 3 --- select or deselect

Channel 4 --- select or deselect

Channel 5 --- select or deselect

Oil Temperature Alarm --- If oil temperature alarm is selected: when the upper/lower limit of oil temperature has been set, there is no alarm if oil temperature is within the specification and alarm occurs if it is out of specification.

Notice

The default type of the thermocouples is K unless otherwise programmed in the PLC application.

Normally the themperature compensation is intended only for the controller manufacturer to calibrate the offset of the electronic measurement device on the controller and every SIJECT is delivered in a compensated state. In case it should be necessary to re-compensate the thermocouple, i.e., the displayed temperature is different from the actual temperature value, please perform the following steps:

- 1. Measure the outside temperature with a thermometer before starting the heater;
- 2. Type in the outside temperature value;
- 3. Check the heater temperature on Temperature Screen. The displayed value must be exactly the measured outside temperature.



Caution

The thermocouple input is scanned every 80ms at intervals and the displayed temperature values on the screen will be refreshed every 720ms for all 8 thermocouple inputs and the ambient temperature.

The broken wire detection is done every 40 seconds at intervals. It makes a clicking sound at the same time.

3.4.10 Setting the ramp data

General

All the ramp data are assigned in order to moderate the running shake of the machine during the movement switch, so that the product service life can be extended.

Users should observe the machine movement diversification when adjusting the setting data and optimizing the parameters, until the machine can run smoothly.



Fig 3-17 Service Screen 2.4 --- setting ramp data

Operating Sequences On service screen 1, press softkey F2 to enter service screen 2 ---

linear scale setting. Then, press softkey F5 $\frac{1}{1-1}$ to enter ramp setting screen. See Fig. 3-17 Service Screen 2.4 --- setting ramp data. The ramp data for every movement can be set accordingly.

Mold Close --- there are four ramps to be set: pressure and flow for each ramp, and ranged from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Carriage ---- it refers to the ramps during carriage advance and carriage retract: set pressure and flow for each, and ranged from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Inject --- it refers to the ramps when injection starts and injection completes: set pressure and flow for each, and the range is from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Charge --- it refers to the ramps when charging starts and charging completes: set pressure and flow for each, and the range is from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Mold Open --- there are four ramps to be set: pressure and flow for each ramp, and ranged from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Ejector --- it is the ramp before and after the actions of ejector: set pressure and flow for each, and the range is from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Decompression --- they are the ramps when decompression begins and decompression completes: set pressure and flow for each, and the range is from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch:

Core 1 ---- it is the ramp for core 1 in/out: set pressure and flow for each, and the range is from 0 to 99. The values should be the differences for pressure and flow between every two PLC cycles when there is action switch.

Core 2 / Core 3 --- the operating sequence is same as Core 1.

3.5 Up-/Downloading and Deleting PLC Program

3.5.1 Up-/Downloading and Deleting PLC Program

General The highlight of SIJECT16i consists in that the PLC program can be up/downloaded whenever you wish. In addition, users can clear the memory of PLC CPU memory as required. You can modify the program in your PC/PG after you are in the programming environment.

SIMATIC Manager is the basic programming and configuration software for SIMATIC. It is made up of a series of applications intended to create and test user program.

- **Preconditions** To up-/download the PLC program you need the following:
 - A PC/PG with RS232 interface;
 - MPI adapter and an appropriate cable;
 - SIMATIC STEP7 programming tool in CD;
 - MMC card.

The **Mode Selector S1** must be set in **RUN_P** position prior to up-/downloading PLC program!

Notice

The MMC card can be used to save/load the PLC program. Carry out external data saving before you up-/download the program. See 3.1.4 "recipe data saving".

Up-/DownloadUploading and downloading of PLC program should be done by use of
SIMATIC Manager.

Upload PLC program in SIJECT16i:

- 1. Start the SIMATIC Manager in PC/PG;
- 2. Choose the menu **PLC** in the tool bar;
- 3. Select the menu command Upload;
- 4. Press on the symbol and then release.

Now the Uploading process is finished.

Download PLC program in SIJECT 16i:

- 1. Start the SIMATIC Manager in PC/PG;
- 2. Click the menu **PLC** in the tool bar;
- 3. Select the menu command **Download**;
- 4. Press on the symbol Download and then release.

Now the Downloading process is finished.

Deleting PLC program	If you want to delete PLC program, two choices are available:			
	Ме	thod One: Use SIMATIC STEP7		
	1.	Open STEP7 (V5.2+SP1);		
	2.	From PLC menu in the tool bar, choose command Start > Diagnostic/Setting > Clear/Reset.		
	Ме	thod Two: Use screwdriver		
	1.	Switch the mode selector S1 to position MRES by screwdriver;		
	2.	Hold the switch at this position until the yellow STOP LED (on CI module) lights up for the second time and stays on (when switch S1 from RUN_P position to MRES, S1 will pass by STOP position, and the STOP LED will light on once). Then turn the mode selector S1 to position STOP ;		
	3.	After 3 seconds, switch the mode selector S1 back to MRES. The STOP LED will flash rapidly and the CPU memory is reset;		
	4.	Turn the mode selector S1 to STOP . When the STOP LED lights up permanently, the CPU memory reset is finished;		
	5.	Switch the mode selector S1 to RUN_P .		

Note: Sometimes, there will be message to inform system error when PLC program has been deleted. Under the circumstances, you can use screwdriver to clear CPU memory once more as mentioned above.

3.5.2 Automatic uploading of PLC application to PLC module

General In addition to save/load PLC application by OP menu stated in Section 3.4.5, PLC application can also be uploaded to PLC module from MMC card automatically when there is no PLC application in PLC module.

Operating sequence

- 1. Switch the machine off;
- 2. Plug in a MMC card with PLC application in it;
- 3. Switch the machine on;
- 4. Set the Mode Selector S1 in RUN-P position;
- 5. The PLC application can only be uploaded automatically, if:
 - PLC module does not contain any PLC application;
 - Green Run-LED should be on stably at least for 6 seconds to give the PLC application enough time to startup;
 - A PLC application matching the used type of PLC module is stored on the MMC card.
- 6. Switch the machine off;
- 7. Remove the MMC card from the CI;
- 8. Switch the machine on again and continue the normal operation.

Notice: Same as downloading a new PLC program from MMC, after downloading PLC application from PC/PG, also be sure to switch the machine off, then switch on again.

Note:

Since the uploading operation is not triggered by the OP, there will be no indication of the progress of uploading on an OP15 or OP15B operator panel and any request from those OP's will be ignored. On a Simatic-OP connected to the MPI, there will be no indication anyway, since the PLC module is kept in RESET and no MPI service available. In both cases, termination of the upload can be detected only by monitoring the LED's of the PLC module on the CI board.

4 Programming Tool

4.1 SIMATIC Manager

Introduction STEP7 is the basic programming and configuration software for SIMATIC. It is made up of a series of applications, each of which does a specific job within the scope of programming an automation task, such as:

- configuring and assigning parameters to the hardware
- creating and debugging user programs
- configuring networks and connections

The basic package can be extended by a range of optional packages, for example, additional programming language packages, such as SCL, S & Graph, or HiGraph.

The graphic user interface provided for these tasks is known as the SIMATIC Manager. The SIMATIC Manager collects all the data and the settings necessary for an automation task together in a project. Within this project the data are structured according to their function and represented objects.

Notice

To operate the **SIMATIC Manager**, please order the software and program.

5 Technical Appendix

5.1 Definition of DB1

Address	Туре	Description
DB1.DBX0.0	Кеу	Cycle stop
DB1.DBX0.1	Кеу	Heater start
DB1.DBX0.2	Кеу	Heater stop
DB1.DBX0.3	Кеу	Mold open
DB1.DBX0.4	Key	Mold close
DB1.DBX0.5	Key	Ejector retract
DB1.DBX0.6	Key	Ejector advance
DB1.DBX0.7	Key	Carriage advance
DB1.DBX1.0	Кеу	Semi-auto mode
DB1.DBX1.1	Кеу	Photo-sensor full-auto mode
DB1.DBX1.2	Кеу	Timer full-auto mode
DB1.DBX1.3	Кеу	Cycle run
DB1.DBX1.4	Кеу	Manual mode
DB1.DBX1.5	Key	Mold adjustment mode
DB1.DBX1.6	Кеу	Motor start
DB1.DBX1.7	Кеу	Motor stop
DB1.DBX2.0	Кеу	Air blow 1
DB1.DBX2.1	Кеу	Air blow 2
DB1.DBX2.2	Кеу	Mold adjustment retract
DB1.DBX2.3	Кеу	Mold adjustment advance
DB1.DBX2.4	Кеу	Lubrication
DB1.DBX2.5	Key	Purge (start)
DB1.DBX2.6	Key	Purge (stop)
DB1.DBX2.7	Key	ACK
DB1.DBX3.0	Key	Carriage retract
DB1.DBX3.1	Key	Injection
DB1.DBX3.2	Key	Decompression
DB1.DBX3.3	Key	Charge
DB1.DBX3.4	Кеу	Core 1 in
DB1.DBX3.5	Кеу	Core 1 out
DB1.DBX3.6	Кеу	Core 2 in
DB1.DBX3.7	Кеу	Core 2 out
DB1.DBX4.0	Key	Core 3 in
DB1.DBX4.1	Key	Core 3 out

Address	Туре	Description
DB1.DBX4.2	Key	Auto mold adjustment start
DB1.DBX4.3	Key	Auto mold adjustment stop
DB1.DBX4.4	Кеу	Product counter reset
DB1.DBX4.5	Кеу	Injection reset
DB1.DBX4.6	Кеу	Confirm update time
DB1.DBX4.7	Кеу	Force output
DB1.DBB5	Type of value:	0: recipe byte1: recipe word2: actual value252: packed variable
DB1.DBB6		DB1.dummy1
DB1.DBB7		DB1.val_index
DB1.DBW8	Data from OP to PLC	DB1.op_value
DB1.DBB10		DB1.op_spare1
DB1.DBB11		DB1.read_or_write
DB1.DBB12	DB1.op_comm	Semaphore "OP_COMM" FF = data from OP are in DBW0—DBW10 00 = PLC has read the data and stored in DBW20DBW24
DB1.DBB13		Dummy 2
DB1.DBW14		Dummy 3
DB1.DBW16		Dummy 4
DB1.DBW18		Dummy 5
DB1.DBB20		Spare for LED
DB1.DBX21.0	LED	Motor start
DB1.DBX21.1	LED	Mold adjustment mode
DB1.DBX21.2	LED	Manual mode
DB1.DBX21.3	LED	Cycle run
DB1.DBX21.4	LED	Photo-sensor full-auto mode
DB1.DBX21.5	LED	Timer full-auto mode
DB1.DBX21.6	LED	Semi-auto mode
DB1.DBX21.7	LED	Heater start
DB1.DBW22	Data from PLC to OP	DB1.plc_value
DB1.DBW24	DB1.plc_spare	
DB1.DBW26		Dummy6
DB1.DBB28		00 = type "J" thermocouple FF = type "K" thermocouple
DB1.DBB29		00 = no process alarm FF = have process alarm
DB1.DBW30		Life counter (incremented by PLC program)
DB1.DBB32		00 = PLC start up not finished and ready FF = PLC start up finished and ready
DB1.DBB33		Screw pulses/round

Address	Туре	Description
DB1.DBB34		PLC version-number YY
DB1.DBB35		PLC version-number XX
DB1.DBB36		Dummy 8
		Bit0: Machine ready (0: ready 1: running);
DB1.DBW37		Bit1: OP selection (0:OP15 1:Simatic OP);
		Bit2: PV selection (0:OP15 1:Simatic OP);
DB1.DBW38		Shot counter actual value
DB1.DBX40.0	X301: DQ1.0	Mold close valve
DB1.DBX40.1	X301: DQ1.1	Mold close fast valve
DB1.DBX40.2	X301: DQ1.2	Mold open valve
DB1.DBX40.3	X301: DQ1.3	Mold open fast valve
DB1.DBX40.4	X301: DQ1.4	Mold adjustment advance valve
DB1.DBX40.5	X301: DQ1.5	Mold adjustment retract valve
DB1.DBX40.6	X301: DQ1.6	Ejector advance valve
DB1.DBX40.7	X301: DQ1.7	Ejector retract valve
DB1.DBX41.0	X300: DQ0.0	Core 1 in valve
DB1.DBX41.1	X300: DQ0.1	Core 1 out valve
DB1.DBX41.2	X300: DQ0.2	Core 2 in valve
DB1.DBX41.3	X300: DQ0.3	Core 2 out valve
DB1.DBX41.4	X300: DQ0.4	Carriage advance valve
DB1.DBX41.5	X300: DQ0.5	Carriage retract valve
DB1.DBX41.6	X300: DQ0.6	Charge valve
DB1.DBX41.7	X300: DQ0.7	Injection valve
DB1.DBX42.0	X303: DQ3.0	Heater Nozzle
DB1.DBX42.1	X303: DQ3.1	Heater output 2
DB1.DBX42.2	X303: DQ3.2	Heater output 3
DB1.DBX42.3	X303: DQ3.3	Heater output 4
DB1.DBX42.4	X303: DQ3.4	Heater output 5
DB1.DBX42.5	X303: DQ3.5	
DB1.DBX42.6	X303: DQ3.6	
DB1.DBX42.7	X303: DQ3.7	
DB1.DBX43.0	X302: DQ2.0	Decompression valve
DB1.DBX43.1	X302: DQ2.1	Pump 2
DB1.DBX43.2	X302: DQ2.2	Zero back pressure valve
DB1.DBX43.3	X302: DQ2.3	Robot
DB1.DBX43.4	X302: DQ2.4	Core 3 in valve
DB1.DBX43.5	X302: DQ2.5	Core 3 out valve
DB1.DBX43.6	X302: DQ2.6	Air blow 1

Address	Туре	Description
DB1.DBX43.7	X302: DQ2.7	Air blow 2
DB1.DBX44.0	X304: DQ4.0	Motor star start
DB1.DBX44.1	X304: DQ4.1	Motor triangle start
DB1.DBX44.2	X304: DQ4.2	Motor start
DB1.DBX44.3	X304: DQ4.3	Alarm LED
DB1.DBX44.4	X304: DQ4.4	Lubrication pump
DB1.DBX44.5	X304: DQ4.5	Alarm buzzer
DB1.DBX44.6	X304: DQ4.6	
DB1.DBX44.7	X304: DQ4.7	
DB1.DBX45.0	Analog output 0 type	0 = unipolar (0-10V), 1 = bipolar(-10V-10V)
DB1.DBX45.1	Analog output 0 type	0 = unipolar (0-10V), 1 = bipolar(-10V-10V)
DB1.DBX45.2	Analog output 0 type	0 = unipolar (0-10V), 1 = bipolar(-10V-10V)
DB1.DBX45.3	Analog output 0 type	0 = unipolar (0-10V), 1 = bipolar(-10V-10V)
DB1.DBX45.4		
DB1.DBX45.5		
DB1.DBX45.6		
DB1.DBX45.7		
DB1.DBW46	X305: AQ1	Analog output 1: pressure (0-140 Bar)
DB1.DBW48	X305: AQ2	Analog output 2: flow (0-100%)
DB1.DBW50	X305: AQ3	Analog output 3: back pressure (0-140 Bar)
DB1.DBW52	X305: AQ4	Analog output 4: spare (0-100%)
DB1.DBW54		Dummy10
DB1.DBW56		Dummy11
DB1.DBB58		Dummy12
DB1.DBX59.0		0 = OK 1 = failure of power supply of the linear scale
DB1.DBX59.1		0 = battery normal 1 = battery alarm
DB1.DBX59.2		
DB1.DBX59.3		
DB1.DBX59.4		
DB1.DBX59.5		
DB1.DBX59.6		
DB1.DBX59.7		
DB1.DBX60.0	X204: DI1.0	Safety door 2
DB1.DBX60.1	X204: DI1.1	Back door
DB1.DBX60.2	X204: DI1.2	Emergency stop

Address	Туре	Description
DB1.DBX60.3	X204: DI1.3	Carriage advance end
DB1.DBX60.4	X204: DI1.4	Carriage retract end
DB1.DBX60.5	X204: DI1.5	Ejector advance end
DB1.DBX60.6	X204: DI1.6	Ejector retract end
DB1.DBX60.7	X204: DI1.7	Mold close end
DB1.DBX61.0	X203: DI0.0	
DB1.DBX61.1	X203: DI0.1	
DB1.DBX61.2	X203: DI0.2	
DB1.DBX61.3	X203: DI0.3	
DB1.DBX61.4	X203: DI0.4	
DB1.DBX61.5	X203: DI0.5	
DB1.DBX61.6	X203: DI0.6	
DB1.DBX61.7	X203: DI0.7	
DB1.DBX62.0	X206: DI3.0	Safety door 1
DB1.DBX62.1	X206: DI3.1	Lubrication error
DB1.DBX62.2	X206: DI3.2	Mold adjustment photo-sensor
DB1.DBX62.3	X206: DI3.3	Full-auto photo-sensor
DB1.DBX62.4	X206: DI3.4	Robot
DB1.DBX62.5	X206: DI3.5	Core 3 in end / counter sensor
DB1.DBX62.6	X206: DI3.6	Core 3 out end
DB1.DBX62.7	X206: DI3.7	Screw speed sensor
DB1.DBX63.0	X205: DI2.0	Mold adjustment advance end
DB1.DBX63.1	X205: DI2.1	Mold adjustment retract end
DB1.DBX63.2	X205: DI2.2	Core 1 in end / counter sensor
DB1.DBX63.3	X205: DI2.3	Core 1 out end
DB1.DBX63.4	X205: DI2.4	Core 2 in end / counter sensor
DB1.DBX63.5	X205: DI2.5	Core 2 out end
DB1.DBX63.6	X205: DI2.6	Injection safety door
DB1.DBX63.7	X205: DI2.7	Motor overload
DB1.DBW64		Screw speed actual value
DB1.DBW66	X200: TI1	Analog input TC: 1(nozzle)
DB1.DBW68	X200: TI2	Analog input TC: 2
DB1.DBW70	X200: TI3	Analog input TC: 3
DB1.DBW72	X200: TI4	Analog input TC: 4
DB1.DBW74	X201: TI5	Analog input TC: 5
DB1.DBW76	X201: TI6	Analog input TC: 6 (oil)
DB1.DBW78	X201: TI7	

Address	Ту	ре	Description	
DB1.DBW80	X201: TI8			
DB1.DBW82			Dummy13	
DB1.DBW84	X202	2: AI1	Analog input linear scale 1 (0-10V): mold	
DB1.DBW86	X202	2: Al2	Analog input linear scale 2 (0-10V): screw	
DB1.DBW88	X202	2: AI3	Analog input linear scale 3 (0-10V): ejector	
DB1.DBW90	X202	2: Al4	Analog input linear scale 4 (0-10V): carriage	
DB1.DBB92			Semaphore "MEM_COMM" 0 = finished 1 = put recipe into DB2 2 = get recipe from DB2	
DB1.DBB93	DB1.re	cipe_nr	Recipe-number	
DB1.DBW94	DB1.red	cipe_len	Length of recipe (unit: byte)	
DB1.DBW96	DB1.recipe_data ARRAY[01023] of byte		The starting address for recipe DB1.DBB96—DB1.DBB1119	
DB1.DBW1120—	DB1 comm_err	m errors	Error	
DB1.DBW1150	ARRAY[0	ARRAY[015] of word	(for internal use only! Don't use on customer side.)	
DB1.DBW1152	DB1.io_errors		Error (for internal use only! Don't use on customer side.)	
DB1.DBW1154	DB1.perf_errors		Error (for internal use only! Don't use on customer side.)	
		Filter for analog_in_fast 1	Filter configuration:	
DBW1226	Filter for		Bit 7 to 4: always "0000"	
	analog_in_fast 0		Bit 3 to 0: 0 – Filter is disabled, 1 to 15 – different Filter characteristics	
			Filter configuration:	
	Filter for analog_in_fast 2	Filter for analog_in_fast 3	Bit 7 to 4: always "0000"	
DBW1228			Bit 3 to 0: 0 – Filter is disabled, 1 to 15 – different Filter characteristics	
DBW1230	X207: analog in fast 0		In Volts (010), process data to PLC	
DBW1232	X207: analog in fast 1		In Volts (010), process data to PLC	
DBW1234	analog in fast 2		In Volts (010), process data to PLC	
DBW1236	analog in fast 3		In Volts (010), process data to PLC	
DB1.DBB1188	Virtual communication		Rx flag, the PLC sets this flag to indicate to the IO software that there is a new instruction in Rx meaning, Rx length and Rx buffer. The IO software resets this flag after processing the buffer.	

Address	Туре	Description
DB1.DBB1189	Virtual communication	Rx meaning, instruction according to the protocol specification
DB1.DBB1190	Virtual communication	Rx length, length of valid data in Rx buffer
DB1.DBB1191 DB1 DBB1206	Virtual communication	Rx buffer
DB1.DBB1207	Virtual communication	Tx flag, the IO software sets this flag to indicate to the PLC that there is a new message in Tx meaning, Tx length and Tx buffer. The PLC resets this flag after processing the buffer
DB1.DBB1208	Virtual communication	Tx meaning, instruction according to the protocol specification
DB1.DBB1209	Virtual communication	Tx length, length of valid data in Tx buffer
DB1.DBB1209	Virtual communication	Tx length, length of valid data in Tx buffer
DB1.DBB1210 DB1.DBB1225	Virtual communication	Tx buffer

Comparator Mode

DB1 Location	Function		Description	
DBW1238	Enable Comparator #1	Exit status of Comparator #1 (Status)	0x00=disable comparator #1, 0x01= enable comparator #1.	0x00=o.k. 0x01= threshold #1 already reached when starting. 0x02= Time out. 0x03= Invalid configuration.
DBW1240	Timer		Timer value in multiples interrupt (multiples of 1 0= Timer disabled.	s of the the periodic timer ms)
DBW1242	Define which LS-AI/FAI to read (poll)	Dummy 15	An selected analog input for comparator's polling by PLC. 0x00=no selection; 0x01= LS_AI0, 0x02= LS_AI1, 0x03=LS_AI2, 0x04=LS_AI3, 0x11=FAI0, 0x12=FAI1.	
DBW1244	Define which AQ is the first AQ to write	Define which AQ is the second AQ to write	The first AQ selected by PLC 0x00=no selection; 0x01=AQ1; 0x02=AQ2; 0x03=AQ3; 0x04=AQ4.	The second AQ selected by PLC must be different from the first AQ. 0x00=no selection; 0x01=AQ1; 0x02=AQ2; 0x03=AQ3; 0x04=AQ4.
DBW1246	Define first DQ to write	Define second DQ to write	0x00=no selection 0x010x28= selects DQ1DQ40.	0x00=no selection 0x010x28= selects DQ1DQ40.
DBW1248	Define third DQ to write	Define fourth DQ to write	0x00=no selection 0x010x28= selects DQ1DQ40.	0x00=no selection 0x010x28= selects DQ1DQ40.
DBW1250	Comparator value threshold #1		Value for starting Comparator Mode	
DBW1252	Comparator value threshold #2		Value for triggering outputs	
DBW1254	AQ output value #1		Value for first AQ selected above	
DBW1256	AQ output value #2		Value for second AQ selected above	
DBW1258	DQ output value	DQ output value	Value for first DQ selected above	Value for second DQ selected above
DBW1260	DQ output value	DQ output value	Value for third DQ selected above	Value for fourth DQ selected above

DB1 Location	Function		Description		
DBW1264	Enable Comparator #2	Exit status of Comparator #2 (Status)	0x00=disable comparator #2, 0x01= enable comparator #2.	0x00=o.k. 0x01= threshold #2 already reached when starting. 0x02= Time out. 0x03= Invalid configuration	
DBW1266	Timer		Timer value in multiples interrupt (multiples of 1 0= Timer disabled	s of the the periodic timer ms)	
DBW1268	Define which LS-AI/FAI to read (poll)	Dummy 17	An selected analog input for comparator's polling by PLC. 0x00=no selection; 0x01= LS_AI0, 0x02= LS_AI1, 0x03=LS_AI2, 0x04=LS_AI3, 0x11=FAI0, 0x12=FAI1.		
DBW1270	Define which AQ is the first AQ to write	Define which AQ is the second AQ to write	The first AQ selected by PLC 0x00=no selection; 0x01=AQ1; 0x02=AQ2; 0x03=AQ3; 0x04=AQ4.	The second AQ selected by PLC must be different from the first AQ. 0x00=no selection; 0x01=AQ1; 0x02=AQ2; 0x03=AQ3; 0x04=AQ4.	
DBW1272	Define first DQ to write	Define second DQ to write	0x00=no selection 0x010x28= selects DQ1DQ40.	0x00=no selection 0x010x28= selects DQ1DQ40.	
DBW1274	Define third DQ to write	Define fourth DQ to write	0x00=no selection 0x010x28= selects DQ1DQ40.	0x00=no selection 0x010x28= selects DQ1DQ40.	
DBW1276	Comparator value threshold #1		Value for starting Comparator Mode		
DBW1278	Comparator value	Comparator value threshold #2		Value for triggering outputs	
DBW1280	AQ output value #1		Value for first AQ selected above		
DBW1282	AQ output value #2		Value for second AQ selected above		
DBW1284	DQ output value	DQ output value	Value for first DQ selected above	Value for second DQ selected above	
DBW1286	DQ output value	DQ output value	Value for third DQ selected above	Value for fourth DQ selected above	

5.2 Glossary abbreviation

AC	Alternating current
AI	Analog input
AQ	Analog output
ADC	Analog-digital conversion
BATF	Battery fault
CORA	Coupling RAM Arbiter
CI	Compact interface
CPU	Central processing unit
CSP	Customer specific picture
DAC	Digital –analog conversion
DC	Direct current
DI	Digital input
DQ	Digital output
DPSF	CPU 3xxDP system fault
DPSTAT	CPU 3xxDP system status
DRAM	Dynamic RAM
FRCE	Force
HW	Hardware
LCD	Liquid crystal display
LED	Light Emitting Diode
LS	Linear scale
MMC	Multi-media card
MPI	Multi-port input
MRES	Reset memory
OP	Operator panel
PC/PG	Programming device
PV	Proportion valve
PROFIBUS	Profi_Bus
P_BUS	Periphery Bus
PLC	Program logic controller
RECIPE	Recipe
RUN-P	Program run
SRAM	Static RAM
SF	System fault
SW	Software
ТІ	Temperature input

TO SIEMENS NUMERICAL CONTROL LTD., NANJING, CHINA	Suggestions
	Corrections
	For Publication/Manual:
R&D Division	
No.18, Siemens Road, Jiangning Development Zone	SIJECT 16i
211100 Nanjing	Start-up
People's Republic of China	Manufacturer Documentation
From	Technical Manual
Name	Order No.: 18400000058 Edition: 08.2004
Company/Dept.	
	Should you come across any printing errors
Address	when reading this publication, please notify us on this sheet.
Telephone:	Suggestions for improvement are also welcome.
Fax:	

Suggestions and/or corrections: