



SmartGUI Configuration Guide



Revision V1.40

February 2012

www.fibrenetix.com

Limitations of Warranty and Liability

Limitations of Warranty and Liability

Fibrenetix has tested the hardware described in this User Guide and reviewed its contents. In no event will Fibrenetix, or its distributors, be liable for direct, indirect, incidental, or consequential damage resulting from any defect in the hardware or User Guide, even if they have been advised of the possibility of such damages. In particular, they shall have no liability for any program or data stored in or used with Fibrenetix products, including the costs of recovering or reproducing these programs or data.

During the specified warranty period, Fibrenetix guarantees that the product will perform according to specifications determined by the manufacturer, and will be free of defects. Parts and labor of the received product, and replacement parts and labor are guaranteed during the specified warranty period. The warranty covers defects encountered in normal use of the product, and does not apply when damage occurs due to improper use, abuse, mishandling, accident, sand, dirt, excessive dust, water damage or unauthorized service. The product must be packed in its original packing material when shipped, or the warranty will be void. In all cases, proof of purchase must be presented when a warranty claim is being made.

Fibrenetix operates a Return to Factory warranty. The period of this warranty is three (3) years. Warranty registration for your Fibrenetix system should be completed electronically via the web. Please register for the Return to Factory warranty at www.fibrenetix.com.

Technical Support Policy

If you have a problem installing your system or suspect it is malfunctioning, please contact Fibrenetix Support via email: support@fibrenetix.com, or register your support issue via our website: www.fibrenetix.com. Please have the model, serial number, date of purchase and the distributor/reseller's name available, as you will need to provide this information to our support team.

Return of Product

If a distributor or Fibrenetix deems it necessary for a system to be returned for testing or servicing, a Return Materials Authorization (RMA) number will be issued. The RMA number must be placed on the outside of the carton in large, visible letters near the address label. Return the complete system including all cables and software. The system must be packed in the original packing materials and shipped prepaid. Fibrenetix will repair the system and return it prepaid by similar common carrier and priority. Please record the RMA number and make reference to it when enquiring on the status of the system.

Contents

Chapter 1 Introduction	1-1
Product Applicability.....	1-1
Initial Setup.....	1-1
Browser Configuration via the serial port	1-1
Browser Configuration via LAN	1-2
Text Configuration via RS-232	1-3
Text Configuration via LAN	1-3
Chapter 2 Browser Configuration.....	2-1
Quick Functions	2-2
RAID Set Functions.....	2-2
Create a RAID Set	2-3
Delete RAID Set	2-3
Expand RAID Set	2-4
Activate Incomplete RAID Set.....	2-4
Create Hot Spare.....	2-5
Delete Hot Spare.....	2-5
Rescue RAID Set.....	2-6
Volume Set Functions	2-6
Create a Volume Set	2-7
Delete Volume Set.....	2-9
Modify Volume Set	2-10
Check Volume Set	2-12
Stop Volume Set Check.....	2-12
Physical Drives	2-12
Create Pass Through.....	2-12
Modify Pass Through	2-13
Delete Pass Through.....	2-14
Identify Drive	2-15
System Controls.....	2-15
System Configuration	2-16
Fibre Channel Config	2-17
Ethernet Config.....	2-18
Alert By Mail Configuration	2-19
SNMP Configuration.....	2-20
NTP Configuration	2-21
View Events/Mute Beeper.....	2-22
Generate Test Event.....	2-22
Clear Event Buffer.....	2-23
Modify Password	2-23
Upgrade Firmware.....	2-24
Restart Controller	2-25
Information	2-25
RAID Set Hierarchy	2-25
System Information	2-26
Hardware Monitor	2-26

E8 GUI Screen.....	2-27
Modifying and mapping E88 based volumes	2-27
Viewing the dual controller status	2-29
Chapter 3 Text Based Configuration.....	3-1
Keyboard Navigation	3-1
Login.....	3-1
Main Menu.....	3-1
Quick Volume/Raid Setup	3-1
RAID Level:	3-1
Select Capacity:	3-1
Stripe size	3-1
Raid Set Function.....	3-2
Create Raid Set	3-2
Delete Raid Set	3-3
Expand Raid Set	3-3
Activate Incomplete Raid Set	3-4
Create Hot Spare.....	3-4
Delete Hot Spare.....	3-5
Raid Set Information	3-5
Volume Set Function	3-6
Create Volume Set.....	3-6
Delete Volume Set.....	3-9
Modify Volume Set	3-9
Check Volume Set.....	3-11
Stop Volume Set Check.....	3-11
Display Volume Set Info.	3-11
Physical Drive.....	3-12
View Drive Information	3-12
Create Pass-Through Disk.....	3-13
Modify Pass-Through Disk	3-14
Delete Pass-Through Disk.....	3-14
Identify Selected Drive	3-15
RAID System Function.....	3-15
Mute The Alert Beeper.....	3-16
Alert Beeper Setting	3-16
Change Password.....	3-17
RAID/JBOD Function.....	3-17
Background Task Priority.....	3-18
Maximum SATA Mode.....	3-18
HDD Read Ahead Cache.....	3-19
Stagger Power On.....	3-19
HDD SMART Status Polling	3-20
Capacity Truncation	3-20
Terminal Port Config.	3-21
Update Firmware	3-21
Restart Controller	3-22
U320 SCSI Target Config.....	3-23

Fibre Channel Config	3-23
Ethernet Configuration.....	3-24
DHCP Function	3-24
Local IP address.....	3-25
Http Port Number	3-25
Telnet Port Number	3-25
Ethernet Address.....	3-25
View System Events	3-25
Clear Events Buffer.....	3-26
<i>Hardware Monitor</i>	3-26
System Information.....	3-27

Chapter 1 Introduction

SmartGUI is a flexible intuitive configuration program for management of Fibrenetix RAID systems. This User Guide is generic in nature as a range of Fibrenetix products use SmartGUI for configuration purposes. Even though the menus shown in this guide may not be an exact match for your particular Hardware System, it should be relatively straightforward to navigate the options with the help of this manual.

Fibrenetix welcomes suggestions and feedback in relation to its products and guides.

Product Applicability

This guide is applicable to the Fibrenetix, FX, QX, VP and E series range of products.

Initial Setup

Systems may be configured from a browser based system through a series of hyper links or from a text menu. Both the browser menus and text menus can be accessed directly through either of two physical interfaces via an RJ-45 connection using TCP/IP protocol or through the serial port. The RJ-45 connection supports configuration via a browser or text configuration via telnet. The serial connection supports browser configuration using a proxy agent or text configuration via an RS-232 terminal emulation program.

Only one configuration method should be in use at any one time – for example do not have a telnet session active and an http connection running at the same time.

These connection methods are discussed in the following sections.

Browser Configuration via the serial port

The browser based RAID manager can be accessed via an http Proxy. The Fibrenetix RAID Systems comes with proxy software for Windows based host systems.


To run the proxy software, double click on the executable file `archhttp.exe`. The `archhttp` dialog box appears. This allows a http session to be established via the serial port. Connect the supplied serial cable to an unused com port on the server and enter the corresponding com port number in the dialog shown in the diagram below.

The Parameters for the General Setting are:

- TCP Port value = 1 ~ 65535.
- RAID Connected to value = 1 ~ 10 where 1 is for COM1, 2 for COM2 and so on...
- BaudRate value = {2400, 4800, 9600, 19200, 38400, 57600, 115200}

NOTE: The RAID controller default baud rate is 115200.

When the program starts running, the following window appears:



To start the ArchHttp Proxy Server web-browser management, click **Start**. Type the User Name and Password when prompted. The RAID controller default User Name is "**admin**" and the Password is "**0000**". After entering user name and password, press **Enter** to start-up the Http Proxy Server. The RAID Management software is now accessible.

Refer to page 2-1 for information on browser navigation.

Browser Configuration via LAN

The Firmware-embedded web browser RAID manager is an http-based application, which utilizes the browser installed on your operating system. You can use the Ethernet LAN port to configure the subsystem without any additional software or drivers.

To configure the RAID subsystem on a local or remote machine, you need to know its IP Address. The default IP address is detailed on the Product Documentation and Quality Sheet provided with the unit.

To launch the TCP/IP & Web Browser-based RAID manager, enter:

http://[IP Address]

NOTE: You must be logged-in as administrator with local admin rights on the workstation to remotely configure RAID subsystem. The user name and password are case sensitive. The default values are:

User Name: "admin"
Password: "0000"

NOTE: The following menus are mainly taken from the E4 product, other products will


differ slightly (mainly in the area of channel configuration and quantity of devices but the options should be readily understood. products will differ slightly (mainly in the area of channel configuration and quantity of devices but the options should be readily understood.

Refer to page 2-1 for information on browser navigation.

Text Configuration via RS-232

Connect the supplied serial cable to an unused com port on the server and enter the corresponding com port number in the dialog shown in the diagram below.

If using a program such as HyperTerminal enter the parameters shown below:



NOTE: The RAID controller default baud rate is 115200. The default password supplied is "0000".


Text Configuration via LAN

Attach a network cable from a hub to the system's RJ-45 port. To configure the RAID subsystem on a local or remote machine, you need to know its IP Address. The default IP address is detailed on the Product Documentation and Quality Sheet provided with the unit or may be displayed on the front panel for the models that utilize the LCD panel.

Start the telnet program by issuing the command `telnet <IP address>`. The default password supplied is "0000". Refer to page 3-1 for information on configuring the system using the text menu.

Chapter 2 Browser Configuration

When you log into SmartGUI for the first time (user name = “admin”, default password = “0000”) the overall display screen is shown:




There are six main functions in the RAID Management software:

- **Quick Functions** – allows you to quickly build a RAID system with minimal user input required.
- **RAID Set Functions** – allows you to create, delete, modify and expand a RAID set as well as create and delete hot spare drives and rebuild RAID sets.
- **Volume Set Functions** – allows you to create, delete, modify and check volume sets.
- **Physical Drives** – allows you to create, modify and delete pass through drives as well as identify physical drive locations in the enclosure.
- **System Controls** – allows you to configure system functions such as alarms, notifications and passwords, as well as upgrading controller firmware and restarting the controller.
- **Information** – allows you to view RAID set, hardware and system wide information.

Quick Functions

This function allows you to create a RAID Volume set with minimal input. When you click on the **Quick Create** link in the navigation panel the **Quick Create** screen is displayed in the information panel.



This screen contains the following fields:

Total Number of Disks	The total number of disk drives that are available for the RAID Volume set.
Select RAID Level	Select the RAID level to be applied to the RAID Volume set from the drop-down list
Maximum Capacity Allowed	The maximum capacity in Gigabytes that is available for the creation of the RAID Volume set.
Select Capacity	Select the capacity that you wish to apply to the RAID Volume set.
Volume Initialization Mode	Select whether you want the initialization of the Volume Set to take place in the Foreground (fastest) or run in the Background (slow).
Select Stripe Size	Select the stripe size to apply to the RAID Volume Set from the drop-down list.

To create a Volume Set using the Quick Create function, follow the procedure below:

1. Enter the information in the screen as described in the table above.
2. Select the **Confirm The Options** check-box.
3. Click **Submit** to create the RAID Volume Set.


RAID Set Functions

This section describes the RAID Set functions of the RAID Management software. These functions allow you to create, delete, modify and expand a RAID set as well as create and delete hot spare drives and rebuild RAID sets.

Create a RAID Set

This function allows you to create a new RAID Set. To create a new RAID Set, follow the procedure below:

1. From the navigation panel, select **Create RAID Set**. In the information panel, the list of the disk drives available for inclusion in the RAID set is displayed.




2. Use the check boxes to select the drives to be included in the RAID Set and then check the **Confirm The Operation** check box and click **Submit**.
3. The RAID Set is created from the selected disk drives.

Delete RAID Set

This function allows you to delete a RAID Set. To delete a RAID Set, follow the procedure below:

1. From the navigation panel, select **Delete RAID Set**. In the information panel a list of available RAID Sets is shown.




2. Using the check box, select the RAID Set to be deleted and then check the **Confirm**

3. **The Operation** check box and click **Submit**.
4. You will be asked to confirm the deletion.

Expand RAID Set

This function allows you to expand a RAID Set by adding one or more disk drives to it. This means that you do not have to delete an existing RAID Set and recreate it with more drives. To Expand a RAID Set, follow the procedure below:

1. From the navigation panel, select **Expand RAID Set**. In the information panel the list of previously created RAID Sets is displayed.



2. Using the check boxes, select the RAID Set to be expanded and then click **Submit**.
3. The list of disk drives that are available to be added to the RAID Set is displayed.
4. Using the check boxes, select the disk drive to be added to the RAID Set, then check the **Confirm The Operation** check box and click **Submit** to expand the RAID Set.


Activate Incomplete RAID Set

This function allows you to activate RAID Sets that are currently not active.

When a drive is removed while the RAID subsystem is powered-off, the raid set state will change to *Incomplete State*. To continue to work when the RAID subsystem is powered on, you can use the **Activate Raid Set** option to activate the raid set. When this process is complete, the Raid State will change to *Degraded Mode*.

Follow the procedure below to activate a RAID Set:


1. From the navigation panel, select **Activate RAID Set**. A list of the RAID Sets that can be activated is displayed in the information panel.
2. Using the check boxes, select the RAID Sets to be activated, and then click **Submit**, to make the RAID Sets active.



Create Hot Spare

This function allows you to create a Hot Spare drive. The hot spare drive will always be ready to instantly be used in the event of a disk drive failing in a RAID Set. To create a Hot Spare drive, follow the procedure below:

1. From the navigation panel, select **Create Hot Spare**. The list of disk drives that are available to create a hot spare is shown in the information panel.




2. Using the check boxes, select the drive you wish to use to create the hot spare drive, then check the **Confirm The Operation** check box and then click **Submit**.
3. The Hot Spare drive is created.

Delete Hot Spare

This function allows you to delete a hot spare drive. Once the hot spare drive is deleted, the disk drive's status is set to Free, and it can be used to create new RAID sets, expand existing RAID sets etc. To delete a hot spare drive, follow the procedure below:

1. From the navigation panel, select **Delete Hot Spare**. The list of hot spare drives is shown in the information panel.




2. Using the check boxes, select the hot spare drive to be deleted, then check the **Confirm The Operation** check box and then click **Submit**.
3. Confirm the deletion, and the hot spare is deleted.

Rescue RAID Set

This function allows you to rebuild a RAID set if it has gone off-line. To rescue the RAID set, follow the procedure below:

1. From the navigation panel, click **Rescue RAID Set**. In the information panel you are asked to enter one of the following parameters:
 - **RESCUE** – use this option to recover a missing or off-line RAID Set.
 - **SIGNAT** – use this option to regenerate a RAID set signature, if a RAID Set has been recovered.



2. In the Enter The Keyword text box, type the keyword as required (see 1 above), then check the **Confirm The Operation** check box and then click **Submit**.

Volume Set Functions

This section describes the Volume Set functions of the RAID Management software. These functions allow you to create, delete, modify and check a Volume. A volume set is seen by the host system as a single logical device. It is organized in a RAID level with two or more


physical disks. RAID level refers to the level of data performance and protection of a volume set.

A volume set capacity can consume all or a portion of the disk capacity available in a raid set. Multiple volume sets can exist on a group of disks in a raid set. Additional volume sets created in a specified raid set will reside on all the physical disks in the raid set. Thus, each volume set on the raid set will have its data spread evenly across all the disks in the raid set.


Create a Volume Set

This function allows you to create a new Volume Set. To create the new Volume Set, follow the procedure below:

1. From the navigation panel, select **Create Volume Set**. The list of RAID sets from which a Volume Set can be created is displayed in the information panel.



2. Using the check boxes, select the RAID Set that the Volume Set is to be created from then click **Submit**.
3. You must then set the attributes to be applied to the Volume Set.



fibrenetix e4 series
CONFIGURATION MANAGER
www.fibrenetix.com

open all | close all

Raid System Console

- Quick Function
 - Quick Create
- RAID Set Functions
 - Volume Set Functions
 - Create Volume Set
 - Create Raid30/50/60
 - Delete Volume Set
 - Modify Volume Set
 - Check Volume Set
 - Schedule Volume Check
 - Stop Volume Check
 - Volume Set Host Filters
- Physical Drives
- System Controls
- Information

Enter The Volume Attribute

Volume Name	E4F41A1-VOL#000
Member Disks	2
Volume Raid Level	Raid 1
Max Capacity Allowed	500 GB
Select Volume Capacity	500 GB
Volume Initialization Mode	Foreground Initialization
Volume Stripe Size	64 KBytes
Volume Cache Mode	Write Back
Tagged Command Queuing	Enabled
Fibre Channel:LUN Base:LUN	0 : 0 : 0
Volumes To Be Created	1

☐ **Confirm The Operation**

Submit Reset

4. This screen has the following attributes that must be assigned:

Member Disks	Displays the number of disks in the RAID set that the Volume Set is being created from.
Volume RAID Level	Select the RAID Level to apply to the Volume Set from the drop down list.
Max Capacity Allowed	The maximum capacity allowed for the Volume Set. This value will vary depending on the number of disks available and the RAID Set selected.
Select Volume Capacity	Enter the Volume in Gigabytes that you wish to assign to the Volume Set.
Volume Initialization Mode	Select the Initialization Mode to be applied to the Volume Set. You can choose between Foreground (fastest) and Background (slowest).
Volume Stripe Size	Select the Stripe Size to be applied to the Volume Set from the drop down list.
Volume Name	Enter a name for the Volume Set
Volume Cache Mode	Select the Cache Mode to be applied to the Volume Set from the drop down box.
Tagged Command Queuing	Select whether you want Tagged Command Queuing enabled or disabled.
Fibre Channel:LUN Base¹:Lun	Using the drop down lists, select the FibreChannel, LUN base number and LUN offset to be assigned to the Volume Set.
Volumes to be created	Enter the number of volumes to be created.

5. When all the above attributes have been assigned, check the **Confirm The Operation** check box then click **Submit**.

¹ LUN Base allows an offset to be used to avoid excessively long lists of IDs

6. The Volume Set is created.

NOTE: This operation may take some time depending on the RAID type selected and the size of the Volume Set.

NOTE: If the capacity of the set is greater than 2 TB the following options become available:

1. “No” All Volumes will be under 2TB in size
2. “64Bit LBA” Volumes will be created Greater than 2TB in size. Operating System and HBA must be capable of addressing Over 2TB. This option is not supported in Fibrenetix U4 Systems.
3. 4K / For Windows This will create a Volume which will use a 4096Byte Block Size rather than using the standard 512Byte Block Size. It can allow a Volume Over 2TB in size to be accessible by an Operating System which cannot normally address over 2TB



fibrenetix e4 series CONFIGURATION MANAGER

www.fibrenetix.com

open all | close all |

- Raid System Console
 - Quick Function
 - RAID Set Functions
 - Volume Set Functions
 - Create Volume Set**
 - Create Raid30/50/60
 - Delete Volume Set
 - Modify Volume Set
 - Check Volume Set
 - Schedule Volume Check
 - Stop Volume Check
 - Volume Set Host Filters
 - Physical Drives
 - System Controls
 - Information
 - RAID Set Hierarchy
 - System Information
 - Hardware Monitor

Enter The Volume Attribute

Volume Name	E4F41A1 -VOL#002		
Member Disks	4		
Volume Raid Level	Raid 0		
Max Capacity Allowed	3000 GB		
Select Volume Capacity	3000	GB	
Greater Two TB Volume Support	No		
Volume Initialization Mode	64bit LBA (dropdown menu open)		
Volume Stripe Size	4K Block		
Volume Cache Mode	Write Back		
Tagged Command Queuing	Enabled		
Fibre Channel:LUN Base:LUN	0	:	0 : 1
Volumes To Be Created	1		


☒ **Confirm The Operation**

Submit Reset

Delete Volume Set

This function allows you to delete a Volume Set. To delete a Volume Set, follow the procedure below:


1. From the navigation panel, select **Delete Volume Set**. The list of previously created Volume Sets is shown in the information panel.
2. Using the check boxes, select the Volume Set that is to be deleted, then check the
3. **Confirm The Operation** check box and then click **Submit**.
4. Confirm the deletion when prompted to delete the Volume Set.




Modify Volume Set

This function allows you to modify a previously created Volume Set. To modify a Volume Set, follow the procedure below:

1. From the navigation panel, select **Modify Volume Set**. The list of created Volume Sets is shown in the information panel.



2. Using the check boxes, select the Volume Set that you wish to modify then click **Submit**. The attributes for the selected Volume Set are displayed.



This screen has the following attributes that can be modified:

Volume Name	Enter a name for the Volume Set
Max Capacity Allowed	The maximum capacity allowed for the Volume Set. This value will vary depending on the number of disks available and the RAID Set selected.
Volume Capacity	Enter the Volume in Gigabytes that you wish to assign to the Volume Set.
Volume Initialization Mode	Select the Initialization Mode to be applied to the Volume Set. You can choose between Foreground (fastest) and Background (slowest).
Volume RAID Level	Select the RAID Level to apply to the Volume Set from the drop down list.
Volume Stripe Size	Select the Stripe Size to be applied to the Volume Set from the drop down list.
Volume Cache Mode	Select the Cache Mode to be applied to the Volume Set from the drop down box
Tagged Command Queuing	Select whether you want Tagged Command Queuing enabled or disabled.
Fibre Channel:LUN Base²:LUN	Using the drop down lists, select the FibreChannel, LUN base number and LUN offset to be assigned to the Volume Set.

When you have made the modifications to the Volume Set attributes, check the Confirm The Operation check box and then click Submit. The changes are applied to the Volume Set.

² LUN Base allows an offset to be used to avoid excessively long lists of IDs

Check Volume Set

This function allows you to verify the correctness of the redundant data in a volume set. For example, in a system with dedicated parity, volume set check means computing the parity of the data disk drives and comparing the results to the contents of the dedicated parity disk drive. The checking percentage can also be viewed by clicking on **Raid Set Hierarchy** in the main menu.

To carry out the consistency check, follow the procedure below:

1. From the navigation panel, select **Check Volume Set**. The list of available Volume Sets is displayed in the information panel.
2. Using the check boxes, select the Volume Set to do the consistency check on and click **Submit** to start the check.

Schedule Volume Check

Use this option to schedule a volume check. This is normally done during off peak times.

Stop Volume Set Check

This function allows you to stop a consistency check on a Volume Set. To stop a consistency check on a Volume Set, follow the procedure below:

1. From the navigation panel, select **Stop Volume Set Check**. The list of Volume Sets that have consistency checks running is displayed in the information panel.
2. Using the check boxes, select the Volume Set that you wish to stop the consistency check for. Click **Submit** to stop the consistency check.

Physical Drives


This section describes the Physical Drives functions of the RAI Management software. These functions allow you to create, modify and delete Pass Through Drives and also allow you to identify the location of the physical disk drive in the enclosure.

Create Pass Through

This function allows you to create a Pass Through Disk Drive. A Pass Through Disk is not controlled by the internal RAID subsystem firmware and thus cannot be a part of a volume set. The disk is available to the operating system as an individual disk. It is typically used on a system where the operating system is to be on a disk not controlled by the RAID firmware.

To create a pass through drive, follow the procedure below:

1. From the navigation panel, select **Create Pass Through**. The list of disk drives that are available to create pass through disks is displayed in the information panel.
2. Using the check boxes, select the disks that you want to assign as a pass through disk.



3. Assign the attributes to the pass through drive by specifying the following information:

Volume Cache Mode Select the Cache Mode to be applied to the Pass Through Drive using the drop down list.

Tagged Command Queuing Select whether to enable or disable tagged command queuing using the drop down list.

Fibre Channel:LUN Base³:Lun Using the drop down lists, select the FibreChannel, LUN base number and LUN offset to be assigned to the Volume Set.


4. Once the attributes have been set, check the **Confirm The Operation** check box and then select Submit to create the Pass Through Disk.

Modify Pass Through

This function allows you to modify the attributes of an existing Pass Through Disk. To modify a Pass Through Disk, follow the procedure below:

1. From the navigation panel, select **Modify Pass Through**. The list of available Pass Through Disks is displayed in the navigation panel.
2. Using the check boxes, select the Pass Through Drive you wish to modify and click **Submit**.
3. The attributes for the selected Pass Through Drive are displayed in the information panel.
4. The following attributes can be modified on this screen:

³ LUN Base allows an offset to be used to avoid excessively long lists of IDs

**Volume Cache Mode**

Change the Cache Mode to be applied to the Pass Through Drive using the drop down list.

Tagged Command Queuing

Change whether to enable or disable tagged command queuing using the drop down list.

Max SCSI Speed

Change the maximum SCSI speed to be applied to the Pass Through Drive using the drop down list.

Fibre Channel:LUN Base⁴:Lun


Using the drop down lists, select the FibreChannel, LUN base number and LUN offset to be assigned to the Volume Set.

- Once the changes have been made to the attributes of the Pass Through Drive, check the **Confirm The Operation** check box and then click **Submit** to make the changes to the Pass Through Drive.

Delete Pass Through

This function allows you to delete a Pass Through Drive. Once the Pass Through Drive has been deleted the disk status is set to Free and it is again available to be used in the creation of RAID Sets, Hot Spare Drives etc. To delete a Pass Through Drive, follow the procedure below:

- From the navigation panel, select **Delete Pass Through**. The list of available Pass Through Drives is shown in the information panel.




- Using the check boxes, select the Pass Through Drive you wish to delete. Check the **Confirm The Operation** check box and then click **Submit** to delete the Pass

⁴ LUN Base allows an offset to be used to avoid excessively long lists of IDs

Through Drive.

Identify Enclosure


This option may be used to identify a particular subsystem when multiple enclosures are used such as an E4 system configured with one or more JBOD units.



Identify Drive

This function allows you to see where a disk drive is physically located within the storage enclosure by making the drives LED flash on the front of the enclosure. To identify a drive, follow the procedure below:

1. From the navigation panel, select **Identify Drive**. The list of all available disk drives is shown in the information pane.




2. Using the check boxes, select the drive you wish to identify, and then click **Submit**. The LED for the disk drive will start to flash red on the front of the storage enclosure.
3. To stop the LED from flashing, click on any function in the navigation panel.

System Controls

This section describes the System Controls functions of the RAID Management Software. These functions allow you to configure alarms, notifications and passwords, as well as upgrading controller firmware and restarting the controller.

System Configuration

This function allows you to set system wide parameters. To set the system parameters, follow this procedure:



1. From the navigation panel, select **System Config**. The system configuration attributes are displayed in the information panel.

2.

The following system attributes can be set from this screen:

System Beeper Setting Select whether you want the audible alarm beeper enabled or disabled using the drop down list.

Background Task Priority Set the priority level you wish to apply to tasks running in the background such as Initialization etc. using the drop down list.

JBOD/RAID Configuration Set whether you want the system to run as a JBOD or a RAID system using the drop down list.

SATA NCQ Support Enable or Disable as appropriate.

HDD Read Ahead Cache Sets the drives to read in more data than requested in anticipation of a subsequent request for the data

Stagger Power On Control This setting allows the drives to spin up in 0.5 second increments (from 1 second onwards). The current default setting is 0.4 seconds

HDD SMART Status Polling This function will poll the drives for SMART status


Disk Capacity Truncation Mode Select how the disk capacity is to be truncated. For example, if you select Multiples of 10G, all disk capacities will be rounded down to the nearest 10G.

3. Once all the attributes have been set, check the Confirm The Operation check box and then click Submit to set the System Configuration parameters.

Fibre Channel Config⁵

The E1-652-FC product features dual 4 gigabit Fibre Channel host interfaces. They can be configured from the **Fibre Channel Config** option. Use this screen to set up Fibre Channel negotiation speeds. Choices are 1,2,4 or auto. Default setting is Auto-Negotiate. Each channel can be configured independently.

Fibre Channel topologies can be set up for Auto, Point to Point or Loop from this menu. Recommended settings are to hard set the speed to correspond to the HBA speed, set the topology to loop and distinct worldwide node names enabled. Each channel can also be set up for hard or soft addressing as appropriate for the user's host environment.



Modify Volume Set
Check Volume Set
Stop Volume Set Check
Volume Set Host Filters

Physical Drives

System Controls
System Config
Fibre Channel Config
EtherNet Config
Alert By Mail Config
SNMP Configuration
NTP Configuration
View Events/Mute Beeper
Generate Test Event
Clear Event Buffer
Modify Password
Upgrade Firmware
Restart Controller

Channel 0 WWPN:21-00-00-04-d9-80-00-00

Channel 0 Speed: Auto (Current Speed : Unknown)

Channel 0 Topology: Auto (Current Topology : None)

Channel 0 Hard Loop ID: 0 Disabled

Channel 1 WWPN:21-00-00-04-d9-80-00-01

Channel 1 Speed: Auto (Current Speed : Unknown)

Channel 1 Topology: Auto (Current Topology : None)

Channel 1 Hard Loop ID: 0 Disabled


View/Edit Host Name List
View/Edit Volume Set Host Filters

☐ Confirm The Operation

Submit Reset

Distinct WWNN Option

The Distinct WWNN option for each channel is used for Operating Systems/HBA configurations that require unique worldwide node names to distinguish between multiple channels.



fibrenetix e4 series
CONFIGURATION MANAGER
www.fibrenetix.com

open all|close all

Raid System Console
Quick Function
Quick Create
RAID Set Functions
Volume Set Functions
Physical Drives
System Controls
System Configuration
Fibre Channel Config
EtherNet Configuration
Alert By Mail Configuration
SNMP Configuration
NTP Configuration
View Events/Mute Beeper
Generate Test Event
Clear Event Buffer
Modify Password
Upgrade Firmware
Restart Controller
Information

Fibre Channel Configurations (WWNN:20-00-00-04-d9-80-00-01)

☒ Distinct WWNN for Each Channel

Channel 0 WWPN:21-00-00-04-d9-80-00-00

Channel 0 Speed: 4 Gb (Current Speed : Unknown)

Channel 0 Topology: Loop (Current Topology : None)

Channel 0 Hard Loop ID: 0 Disabled

Channel 1 WWPN:21-00-00-04-d9-80-00-01

Channel 1 Speed: 4 Gb (Current Speed : Unknown)

Channel 1 Topology: Loop (Current Topology : None)

Channel 1 Hard Loop ID: 0 Disabled

View/Edit Host Name List
View/Edit Volume Set Host Filters

☐ Confirm The Operation

Submit Reset

⁵ Fibre Channel Product only

Note: Earlier systems may need to use the following procedure to make the Distinct WWNN option visible:

From the Main Menu select the System Controls option then select Fibre Channel Config option. In the Channel 0 Hard Loop ID box type in the figure 911. Now move the cursor and click on another part of the screen. The Distinct WWNN option will now appear at the top of the Fibre Channel Config page. To enable a unique WWNN for each Fibre Channel Port at the rear of the Storage System, check the box beside the “Distinct WWNN for each Channel” option. Now check the Confirm the Operation box and then click on the Submit option. The parameter should now be updated. To ensure that the parameter has been successfully updated the RAID Controller should now be re-started.

World wide name filtering can be set up for SAN environments by selecting the **View/Edit Volume Set Host Filters** link:

Fibre Channel Volume Set Host Filters (Ch0/LUN:0)

None

Add or Delete Selected Host Filter Entry

☒ Select WWN From Host Name List

[View/Edit Host Name List](#)

Host WWN :

Range Mask : - - - - - - - Hex

Filter Type :

Access Mode :


Operation :

☐ Confirm The Operation

Ethernet Config

This function allows you to configure the Ethernet port for the enclosure. To configure the Ethernet port, follow the procedure below:

1. From the navigation panel, select **Ethernet Config**. The Ethernet parameters are displayed in the information panel.
2. The following parameters can be set from this screen:



DHCP Function

Select whether you want to enable or disable DHCP functionality on the enclosure using the drop down list.

Local IP Address

Enter the local IP address in the boxes (if DHCP is disabled)

Gateway IP Address

Enter the Gateway IP address in the boxes

Subnet Mask

Enter the Subnet Mask address in the boxes

HTTP Port Number

Enter the http Port Number in the box.

Telnet Port Number

Enter the Telnet Port Number in the box.

Current IP Address

Displays the current IP address.

Current Gateway Address

IP Displays the current Gateway IP address.

Current Subnet Mask

Displays the current Subnet Mask.

Ethernet MAC Address

Displays the MAC address of the unit.

- Once the parameters above have been set, check the Confirm The Operation check box and then click Submit.

Alert By Mail Configuration

This function allows you to configure the system to send an email to specified email addresses when an event occurs. To configure the Alert By Mail function, follow the procedure below:

- From the navigation panel, select **Alert By Mail Config**. The email alert parameters are displayed in the information panel.
- The following parameters can be set from this screen:

SMTP Server Address

IP Enter the IP address of the SMTP server to be used for email notifications.

Sender Name


Enter a name that will be displayed to the person receiving the email alert.

Mail Address

Enter the email address that will appear as the Mail From

- Account** address for the email alert.
Enter the account name (user name) for the email notification account on the email server.
- Password** Enter the password for the email notification account on the email server.
- MailTo Name 1 to 4** Enter up to 4 names that email event notifications will be sent to.
- Mail Address** Enter the email address of the person named in the Mail To Name X box.
- Event Notification Configuration** Select the level of events that will be notified to the specified email addresses.
- Notification For No Events** Check this check box if you want a notification sent when no events occur in a 24 hour period (could indicate that the system has stopped for some reason).

3. Once all the parameters have been set, check the **Confirm The Operation** check box and then click **Submit** to configure email notification.



The screenshot shows the 'fibrenetix e4 series CONFIGURATION MANAGER' interface. On the left is a navigation tree with options like 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. The 'Alert By Mail Configuration' option is selected. The main panel displays the 'SMTP Server Configuration' and 'Mail Address Configurations' sections. The 'SMTP Server Configuration' section includes fields for 'SMTP Server IP Address' (127.0.0.1). The 'Mail Address Configurations' section includes fields for 'Sender Name' (user), 'Mail Address' (user@mydomain.com), 'Account' (user), and 'Password' (masked). Below these are four 'MailTo' entries, each with a name and email address field. The 'Event Notification Configurations' section has radio buttons for 'Disable Event Notification', 'Urgent Error Notification', 'Serious Error Notification', 'Warning Error Notification', 'Information Notification', and a checked checkbox for 'Notification For No Event'. At the bottom, there is a 'Confirm The Operation' checkbox and 'Submit' and 'Reset' buttons.


4.

SNMP Configuration

This function allows you to configure SNMP settings for the RAID Controller. To configure the SNMP settings, follow the procedure below:

1. From the navigation panel, select **SNMP Configuration**. The SNMP attributes will be displayed in the information panel.
2. This screen contains the following fields:

SNMP Trap Configurations	Enter the IP Address and Port Number of the SNMP traps.
SNMP System Configurations	Enter the SNMP System parameters here. Enter a Community, Contact, Name and Location
SNMP Trap Notification Configurations	Select the level of events for which you wish SNMP traps sent using the check boxes.



The screenshot shows the 'fibrenetix e4 series CONFIGURATION MANAGER' interface. On the left is a tree view with categories like 'Quick Function', 'RAID Set Functions', 'Volume Set Functions', 'Physical Drives', 'System Controls', and 'Information'. The 'System Controls' category is expanded, showing 'SNMP Configuration' as the selected item. The main panel displays three configuration sections:


- SNMP Trap Configurations:** A table with three rows for 'SNMP Trap IP Address #1', '#2', and '#3'. Each row has four input fields for IP octets and a 'Port#' field set to '162'.
- SNMP System Configurations:** Fields for 'Community', 'sysContact.0', 'sysName.0', and 'sysLocation.0'.
- SNMP Trap Notification Configurations:** A list of notification types with radio buttons: 'Disable SNMP Trap' (selected), 'Urgent Error Notification', 'Serious Error Notification', 'Warning Error Notification', and 'Information Notification'. Each has a corresponding description of what events will be sent.

At the bottom, there is a 'Confirm The Operation' checkbox (unchecked), and 'Submit' and 'Reset' buttons.

Once the above information has been added, check the **Confirm The Operation** check box and then click **Submit** to set the SNMP Configuration parameters.


NTP Configuration

Use this screen to input the parameters of the Network Time Protocol (NTP) server to use for time synchronization.



View Events/Mute Beeper

This function allows you to view events generated by the RAID controller. Viewing events will also mute the alarm beeper. To view events, select **View Events/Mute Beeper** from the navigation panel. The event log is opened and you can view all the generated events.




This screen shows the date and time that the events took place, the device that the event was generated from and the type of the event etc.

Generate Test Event


This function allows you to generate a test event. This is used to ensure that your event notification process is working correctly. Select **Generate Test Event** from the navigation panel to bring up the Generate Test Event screen.

Generate the test event by checking the **Confirm The Operation** check box and then click **Submit**.



Clear Event Buffer

This function allows you to clear the event buffer. Select **Clear Event Buffer** from the navigation panel to bring up the Clear Event Buffer screen.




To clear the event buffer, check the **Confirm The Operation** check box and then click **Submit**.

Modify Password

This function allows you to change the password⁶ used to log into the RAID Controller. To modify the password, follow the procedure below:

1. From the navigation panel, select **Modify Password**. The Modify Password screen is displayed in the information panel.

⁶ If the password is changed from the default ensure that a note is kept in a safe secure place. Do not lose this password.




2. Enter the original password and then enter the new password twice.
3. Check the **Confirm The Operation** check box and then click **Submit**.

Upgrade Firmware

This function allows you to upgrade the firmware on the RAID controller. To upgrade the firmware, follow the procedure below:

1. From the navigation panel, select **Upgrade Firmware**⁷. The upgrade firmware screen is displayed in the information panel.




2. Enter the path and filename of the latest firmware image or click **Browse** and search for the file.
3. Check the **Confirm The Operation** check box and then click **Submit** to start the firmware upgrade.

⁷ The firmware consists of three files and should be loaded in the following filename extension order – MBR0, Boot, Firm.

Restart Controller

This function allows you to restart the controller. To restart the controller, select **Restart Controller** from the navigation panel and the restart controller screen is displayed in the information panel.




To restart the controller, check the **Confirm The Operation** check box and then click **Submit**.

Information

These functions allow you to view general information relating to the RAID sets, system and hardware.

RAID Set Hierarchy

This function allows you to view general information relating to the RAID sets created on the system. To view the RAID set hierarchy, select **RaidSet Hierarchy** from the navigation panel. Details about the RAID sets created on the system are displayed in the information panel.




This screen shows the list of RAID Sets created on the system along with details relating to these RAID sets, such as the disk drives used in the RAID set, Volume sets created from the RAID sets, the status of the Volume sets and the capacity of each RAID set.

At the bottom of the screen is a list of all the disk drives on the system showing what each disk is used for, its capacity and the model of the disk drive.

NOTE: For more detailed information on a RAID Set, Volume Set or Disk Drive, click on its hyperlinked name.

System Information

This function displays detailed information about the RAID Controller. To view the detailed information, select **System Information** from the navigation panel. The system information is displayed in the information panel.




The screenshot shows the 'fibrenetix e4 series CONFIGURATION MANAGER' interface. The left navigation panel has 'System Information' selected. The main panel displays 'Raid Subsystem Information' with the following details:

Controller Name	E4F41A1
Firmware Version	V1.43 2007-6-22
BOOT ROM Version	V1.43 2007-5-9
Agilent TSDK	V4.0
MPT Firmware Version	1.22.1.0
Serial Number	1100-2116-6633
Unit Serial #	09123407
Main Processor	800MHz IOP341
CPU ICache Size	32KBytes
CPU DCache Size	32KBytes/Write Back
CPU SCache Size	512KBytes/Write Back
System Memory	512MB/533MHz/ECC
Current IP Address	192.168.1.76

Hardware Monitor

This function allows you to view hardware information relating to the storage enclosure. To view the hardware information, select **Hardware Monitor** from the navigation panel. The hardware information is displayed in the information panel.




The screenshot shows the 'fibrenetix e4 series CONFIGURATION MANAGER' interface. The left navigation panel has 'Hardware Monitor' selected. The main panel displays 'Controller H/W Monitor' and 'Enclosure#1 : SAS RAID Subsystem V1.0' with the following details:

Controller H/W Monitor	
CPU Temperature	47 °C
Controller Temp.	36 °C
12V	12.038 V
5V	5.053 V
3.3V	3.312 V
DDR-II 1.8V	1.840 V
VCore 1.2V	1.216 V
DDR-II 0.9V	0.912 V
RTC 3.0V	3.280 V
Battery Status	Not Installed
Enclosure#1 : SAS RAID Subsystem V1.0	
Voltage#1	3.232 V
Voltage#2	4.872 V
Voltage#3	11.308 V
Fan#1	2518 RPM
Fan#2	1767 RPM
Fan#3	2836 RPM
Fan#4	1834 RPM
Power#1	OK
Power#2	OK
UPS Status	OK
Temperature#1	31 °C
Temperature#2	30 °C

E8 GUI Screen


The E8 system is similar, however there are a number of screen that differ. The opening menu is shown below:



Modifying and mapping E88 based volumes


One of the areas that differs with the E8 is the fact that dual controllers are used as opposed to single controller configurations. For redundancy volumes can be mapped to similar ports on each controller.

Fibre Channel ports and setting can be modified from the <System Controls> screen. The following screenshot is taken from the path <System Controls> → <Fibre Channel Config> and allows various settings to be changed.



The next screen shows (in dual controller mode) how the volume is mapped to corresponding ports across both controllers. For performance reasons different volumes can be spread across ports in a breadth first configuration (volume 1 → port 1, volume 2 → port 2, ...).

The port mapping is done during volume creation or by modifying the volume. To do this select <Volume Set Functions> → <Modify Volume Set>.



Select the volume to be modified and then select <Submit>.

On the next screen select corresponding ports and then check the <Confirm The Operation> box and select, Submit>.

Address  http://192.168.100.127

fibrenetix e8 series
CONFIGURATION MANAGER www.fibrenetix.com

|open all|close all|

- Raid System Console
 - Quick Function
 - RAID Set Functions
 - Volume Set Functions
 - Create Volume Set
 - Create Raid30/50/60
 - Delete Volume Set
 - Modify Volume Set
 - Check Volume Set
 - Schedule Volume Check
 - Stop Volume Check
 - Volume Set Host Filters
 - Physical Drives
 - System Controls
 - Information
 - RAID Set Hierarchy
 - SAS Chip Information
 - System Information
 - Hardware Monitor

Enter The Volume Attribute

Volume Name	E8F281B1-VOL#001
Max Capacity Allowed	1500.0 GB
Volume Capacity	1500.0 GB
Volume Initialization Mode	Foreground Initialization
Volume Raid Level	Raid 5
Volume Stripe Size	64 KBytes
Volume Cache Mode	Write Back
Tagged Command Queuing	Enabled
Controller#1 Fibre Port Mapping	☒ Port0 ☐ Port1 ☐ Port2 ☐ Port3
Controller#2 Fibre Port Mapping	☒ Port4 ☐ Port5 ☐ Port6 ☐ Port7
Fibre Channel:LUN_Base/MNID:LUN	0 : 0

☐ Confirm The Operation

Submit Reset

Viewing the dual controller status

Select <Information> → <System Information> to view information relating to dual controller operation.

fibrenetix e8 series
CONFIGURATION MANAGER www.fibrenetix.com

|open all|close all|

- Raid System Console
 - Quick Function
 - RAID Set Functions
 - Volume Set Functions
 - Physical Drives
 - System Controls
 - Information
 - RAID Set Hierarchy
 - SAS Chip Information
 - System Information
 - Hardware Monitor

Controller#1 System Information

Controller Name	E8F281B1
Firmware Version	V1.49DC 20110623
BOOT ROM Version	V1.49 2011-06-23
Agilent TSDK	V6.10
PL Firmware Version	9.0.2.0
Serial Number	A122EHC GFX300009
Unit Serial #	05880111
Main Processor	800MHz PPC440
CPU ICache Size	32KBytes
CPU DCache Size	32KBytes/Write Back
System Memory	2048MB/800MHz/ECC
Current IP Address	192.168.100.127
Dual Controller State	Dual Operational

Verification that controllers are sync'd

Controller#2 System Information

Controller Name	E8F281B1
Firmware Version	V1.49DC 20110623
BOOT ROM Version	V1.49 2011-06-23
Agilent TSDK	V6.10
PL Firmware Version	9.0.2.0
Serial Number	A121EHC GFX300002
Unit Serial #	05880111
Main Processor	800MHz PPC440
CPU ICache Size	32KBytes
CPU DCache Size	32KBytes/Write Back
System Memory	2048MB/800MHz/ECC
Current IP Address	192.168.100.128
Dual Controller State	Dual Operational

Note both IPs can be accessed for redundant management

Chapter 3 Text Based Configuration

This chapter describes how to configure the RAID Controller from the serial port using a VT100 terminal emulation program or through the Ethernet connector using telnet. For details on how to access the VT100 menus, refer to Chapter 1.

Keyboard Navigation

The following key-functions are used to navigate through the VT-100 RAID configuration utility.

Key	Function
Arrow Key	Move cursor
Enter Key	Submit selection function
ESC Key	Return to previous screen
L Key	Line draw
X Key	Re-draw

Login

Before accessing the main menu, you are required to enter a password. The default password is **0000**. Once you are logged in you can change the password via the **Change Password** option under the **RAID Set Function** menu item.

Main Menu

The main menu provides access to all the available functions. Refer to the SmartGUI manual for a view of the complete menu structure. Use the arrow keys to move up and down through the menu, and then press **Enter** to select a menu item or **Esc** to go back to the previous menu.

Main Menu
Quick Volume/Raid Setup
Raid Set Function
Volume Set Function
Physical Drives
Raid System Function
U320 SCSI Target Config
Ethernet Configuration
View System Events
Clear Event Buffer
Hardware Monitor
System Information

Quick Volume/Raid Setup	Create a default configuration based on the number of physical disks installed
Raid Set Functions	Create a customized raid set
Volume Set Functions	Create a customized volume set
Physical Drive Functions	View individual disk information
Raid System Function	Set the raid system configurations
U320 SCSI Target Config	Enable or Disable U320 SCSI Targets
Ethernet Configuration	Configure the Ethernet port for the RAID enclosure.
View System Events	View all system events in the system
Clear Event Buffer	Clear all system event information
Hardware Monitor	View all system hardware information
System Information	View the controller system information

Quick Volume/Raid Setup

Quick Volume/Raid Set-up is the fastest way to prepare a raid set and volume set. It can be completed with just a few keystrokes. Although drives of different capacity may be used in the raid set, the smallest capacity drive in the RAID set is used as the capacity of all disk drives in the RAID set.

RAID Level:

The total number of physical drives in a specific RAID set determines the RAID levels that can be implemented. Press **Enter** on **Quick Volume/Raid Set-up** from the main menu; all possible RAID levels will be displayed, as shown below:

Main Menu	
Quick Volume/Raid Setup	
Raid Set Function	
Volume Set Functi	
Physical Drives	Total 5 Drives
Raid System Funct	
U320 SCSI Target	Raid 0
Ethernet Configur	Raid 1+0
View System Event	Raid 1+0+Spare
Clear Event Buffe	Raid 3
Hardware Monitor	Raid 5
System Informatio	Raid 3 + Spare
	Raid 5 + Spare


Select Capacity:

A single volume set is created that consumes all or a portion of the disk capacity available in the RAID set. To define the capacity of the volume set, use the **Available Capacity** screen. The default value for the volume set is displayed. Use the arrow keys to modify the volume set capacity and press **Enter** to accept the value. If it only uses part of the raid set capacity, you can use the **Create Volume Set** option to define additional volume sets.

Main Menu		Available Capacity : 2000.0 GB	
Quick Volume/Raid Setup		Selected Capacity : 2000.0 GB	
Raid Set Function			
Volume Set Functi			
Physical Drives	Total 5 Drives		
Raid System Funct			
U320 SCSI Target	Raid 0		
Ethernet Configur	Raid 1+0		
View System Event	Raid 1+0+Spare		
Clear Event Buffe	Raid 3		
Hardware Monitor	Raid 5		
System Informatio	Raid 3 + Spare		
	Raid 5 + Spare		

Stripe size


This parameter sets the size of the stripe written to each disk in a RAID 0, 1, 0+1, 5, or 6 logical drive. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB. A larger stripe size provides better read performance, especially if your computer processes mostly sequential reads. However, if your computer processes a lot of random read requests, a small stripe size should be selected.



Press **Yes** in the **Create Vol/Raid Set** dialog box, the raid set and volume set will start to initialize.

Raid Set Function

RAID Sets can be configured manually from the RAID Set Function menu. From this function you can manually create, delete, expand and activate a raid set.



Create Raid Set

To create a RAID Set, follow the procedure below:

1. Select **Raid Set Function** from the main menu.
2. Select **Create Raid Set** from the **Raid Set Function** menu.
3. The **Select Drive For Raid Set** window is displayed listing the available drives. Use the arrow keys to select specific physical drives.
4. Press **Enter** to select the drives for inclusion⁸ in the RAID Set. Repeat this step, for all drives you want to include in the RAID set.
5. When you have finished selecting the drives to be included in the Raid Set, press **Esc**. Press **Yes** to confirm the creation.

⁸ Selected drives are shown by an asterix (*)

Ma	Raid Set Function
Qu	
Ra	Create Raid Set
Vo	
Ph	
Ra	
U3	
Et	
Vi	
Cl	
Hardwa	
System	

Select IDE Drives For Raid Set	
[*]Ch01	400.1GBST3400832AS
[*]Ch02	400.1GBST3400832AS
[*]Ch03	400.1GBST3400832AS
[]Ch04	400.1GBST3400832AS
[]Ch05	400.1GBST3400832AS

6. The Edit The Raid Set Name option appears. Enter a name for the RAID Set by entering 1 to 15 alphanumeric characters. The default raid set name is Raid Set #.

Ma	Raid Set Function
Qu	
Ra	Create Raid Set
Vo	
Ph	
Ra	
U3	
Et	
Vi	
Cl	
Hardwa	
System	

Select IDE Drives For Raid Set	
[*]	Edit The Raid Set Name
[*]	
[*]	Raid Set # 00
[]	
[]Ch05	400.1GBST3400832AS

Delete Raid Set

To delete a RAID set, select the raid set number you want to delete from the **Select Raid Set to Delete** option. The **Delete Raid Set** screen appears, select **Yes** to delete it. A second confirmation screen appears. Select **Yes** again to reconfirm the deletion.


Ma	Raid Set Function
Qu	
Ra	Create Raid Set
Vo	Delete
Ph	Expand
Ra	Activ
U3	Creat
Et	Delet
Vi	Raid Set Information
Cl	
Hardwa	
System	

Select Raid Set To Delete	
	Raid Set # 00

CAUTION: Deleting a Raid Set is a destructive action that will cause the loss of all data existing on the Raid Set.

Expand Raid Set

Instead of deleting a raid set and recreating it with additional disk drives, the **Expand Raid Set** function allows you to add drives to an existing raid set.



To expand a raid set, follow the procedure below:

1. Click **Expand Raid Set**. If there are available disks, the **Select Drives For Raid Set Expansion** menu appears.
2. Select the Raid Set and then select the disk.
3. A confirmation screen appears. Select **Yes** to confirm.


The new raid set capacity can be defined as one or more volume sets. Follow the instructions in the Volume Set Function to create volume sets.

NOTE: Once the Expand Raid Set process has started, you cannot stop it. The process must be completed.

NOTE: If a disk drive fails during raid set expansion and a hot spare is available, an auto-rebuild operation will occur upon completion of the raid set expansion.


Activate Incomplete Raid Set

When a drive is removed while the RAID subsystem is powered-off, the raid set state will change to Incomplete State. To continue to work when the RAID subsystem is powered on, you can use the **Activate Raid Set** option to activate the raid set. When this process is complete, the Raid State will change to Degraded Mode.



Create Hot Spare


Selecting the **Create Hot Spare** option from the Raid Set Function menu, brings up a list of all physical disks which are available:



1. Scroll to the required disk using the arrow keys.
2. Press **Enter** to select a disk.
3. Select **Yes** in “**Create Hot Spare?**” to designate the drive as a hot spare.

Delete Hot Spare


This option allows you to delete a hot spare drive.



1. Scroll to the hot spare drive to be deleted using the arrow keys.
2. Press **Enter** to select the drive
3. Select **Yes** in “**Delete Hot Spare?**” to delete the hot spare.

Raid Set Information

To display **Raid Set information**, scroll to the desired Raid Set number and press **Enter**. The Raid Set Information is displayed.



The following information is shown for the RAID set:

Raid Set Name	Shows the name of the Raid Set
Member Disks	Shows the number of disks belonging to the Raid Set.
RAID State	Shows the status of the Raid Set.
Total Capacity	Shows the total capacity available in the Raid Set.
Free Capacity	Shows the non-allocated capacity that can be used to define more Volume Sets.
Min Member Disk Size	Shows the capacity of the smallest disk drive in the Raid Set.
Member Disk Channel	Shows the disks that belong to the Raid Set by naming the channel/slot they are attached to.

Volume Set Function

A Volume Set is seen by the host system as a single logical drive. It is organized in a RAID level with two or more physical drives. RAID level refers to the level of data performance and protection of a Volume Set.

A Volume Set capacity can consume all or a portion of the drive capacity available in a Raid Set. Multiple Volume Sets can exist on a group of drives in a Raid Set. Additional Volume Sets created in a specified Raid Set will reside on all the physical drives in the Raid Set. Therefore, each Volume Set on the Raid Set will have its data spread evenly across all drives in the Raid Set.

Main Menu	
Qu	Volume Set Functions
Ra	
Vo	Create Volume Set
Ph	Delete Volume Set
Ra	Modify Volume Set
U3	Check Volume Set
Et	Stop Volume Check
Vi	Display Volume Info.
Cl	
Hardware Monitor	
System Information	

The volume set features are as follows:

- Volume sets of different RAID levels may co-exist on the same raid set.
- Up to 16 volume sets in total can be created.

Create Volume Set

To create a volume set, follow the procedure below:

1. Select **Volume Set Function** from the Main menu.
2. Choose **Create Volume Set** from Volume Set Function menu.

3. The Create Volume From Raid Set option appears. This screen displays the available raid sets. Scroll to the required raid set and press **Enter**.

Main Menu			
Qu	Volume Set Functions		
Ra			
Vo	Creat	Create Volume From Raid Set	
Ph	Delet		
Ra	Modif		
U3	Check		
Et	Stop		
Vi	Display Volume Info.		
Cl			
Hardware Monitor			
System Information			

4. The Volume Creation option is displayed showing the current settings for the volume set. The Volume Creation option allows you to select the Volume Name, RAID level, Capacity, Stripe Size, SCSI or FC ID/LUN, Cache Mode, Tag Queuing and Max Sync Rate. You can modify the default values in this menu by scrolling to the required option and pressing Enter. Press Esc to save the value and return to the menu.

Main Menu		
Qu	Volume Set Functions	
Ra		
Vo	Creat	Volume Creation
Ph	Delet	
Ra	Modif	
U3	Check	
Et	Stop	
Vi	Display	
Cl		
Hardware Mon		
System Infor		

Volume Name : QX-75061-VOL#00	
Raid Level	: 5
Capacity	: 160.0GB
Stripe Size	: 64K
SCSI Channel	: 0
SCSI ID	: 0
SCSI LUN	: 0
Cache Mode	: Write Back
Tag Queuing	: Enabled
Max Sync Rate	: 320 MB/sec

The following table shows the attributes that can be modified:

Volume Name	The default volume name will always appear as Volume Set. #. You can rename the volume set providing it does not exceed the 15-character limit.
RAID Level	To set the RAID level for a Volume Set, highlight Raid Level and press Enter. The available RAID levels for the current Volume Set are displayed. Select the required RAID level and press Enter to confirm.
Capacity	The maximum size of the volume is always the default setting. You can increase or decrease the capacity using the UP and DOWN arrow keys. Each volume set can have a capacity which is less than, or equal to, the total capacity of the raid set on which it resides.
Stripe Size	This parameter sets the size of the segment written to each disk in a RAID 0, 1, 0+1, 5 or 6 logical drive. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB.
SCSI Channel	Your system has an Ultra 320 SCSI channel ⁹ . The Select SCSI Channel option appears. Select the channel number and press Enter to confirm.
SCSI ID	Each SCSI device attached to the SCSI card, as well as the HBA card itself, must be assigned a unique SCSI ID number. An LVD SCSI channel can connect up to 15 devices. The Volume Set will appear as a large SCSI device. You must assign an ID from a list of SCSI IDs. ID 7 is normally reserved for the HBA.
SCSI LUN	Each SCSI ID can support up to 8 LUN's. Most SCSI host adapters treat each LUN like a SCSI disk.
Cache Mode	You can set the cache mode to: Write-Through Cache or Write-Back Cache.
Tag Queuing	Enabling Tag-Queuing is useful for enhancing overall system performance under multi-tasking operating systems. The Command Tag (Drive Channel) function controls the SCSI command tag queuing support for each drive channel. This function should remain enabled and should only be disabled when using older SCSI host cards that do not support command tag queuing.
Max Sync Rate	The RAID subsystem 320 MB/sec as the highest data transfer rate for the Ultra 320 system.

5. When the volume set parameters are modified, press **Esc** to confirm. A Fast Initialization option will be displayed.

- Select **Foreground** to start Fast Initialization of the volume set.
- Select **Background** to start Normal Initialization of the volume set.

⁹ SCSI model – FC model has dual 4 Gigabit FC links

Main Menu		
Qu	Volume Set Functions	
Ra		
Vo	Creat	Volume Creation
Ph	Delet	
Ra	Modif	Volume Name : F
U3	Check	Raid Level : 5
Et	Stop	Capacity : 8
Vi	Display	Stripe Size : 6
Cl		SCSI Channel : 0
Hardware Mon		SCSI ID : 0
System Infor		SCSI LUN : 0
		Cache Mode : Write Back
		Tag Queuing : Enabled
		Max Sync Rate : 320 MB/sec
		Initialization Mode
		Foreground (Faster Completion)
		Background (Instant Available)

- 6. Repeat steps 3 to 5 to create additional volume sets.
- 7. The initialization progress is displayed at the bottom of the screen.

Delete Volume Set

To delete a Volume set, select the **Delete Volume Set** option by pressing **Enter**. The list of all available RAID sets is displayed. Scroll to a RAID Set, then press **Enter** to show all Volume Sets in the raid set. Select the Volume Set number you wish to delete and press **Enter** to delete it.

Main Menu		
Qu	Volume Set Func	Select Volume To Delete
Ra		
Vo	Creat	QX-75061-VOL#00
Ph	Delet	Delete
Ra	Modif	
U3	Check	Raid Set # 00
Et	Stop	
Vi	Display Volume Info.	
Cl		
Hardware Mon		
System Infor		

CAUTION: Deleting a Volume Set is a destructive action that will cause the loss of data existing in the Volume Set.

Modify Volume Set

Use this option to modify a volume set. To modify a Volume Set, select the **Modify Volume Set** option, and then press **Enter**. The list of all available RAID sets is displayed. Scroll to the required Raid Set number and, press **Enter** to show all Volume Set associated with the RAID set.

Main Menu		
Qu	Volume Set Func	Select Volume To Modify
Ra		
Vo	Creat	QX-75061-VOL#00
Ph	Delet	
Ra	Modify	
U3	Check	Raid Set # 00
Et	Stop	
Vi	Display Volume Info.	
Cl		
Hardware Mon		
System Infor		

Select the Volume Set you which to modify from the list and press **Enter** to modify it.

Main Menu		
Qu	Volume Set Func	Select Volume To Modify
Ra		
Vo	Creat	Volume Modification Volume Name : QX-75061-VOL#00 Raid Level : 0 Capacity : 240.0GB Stripe Size : 64K SCSI Channel : 0 SCSI ID : 0 SCSI LUN : 0 Cache Mode : Write Back Tag Queuing : Enabled Max Sync Rate : 320 MB/sec
Ph	Delet	
Ra	Modify	
U3	Check	
Et	Stop	
Vi	Display	
Cl		
Hardwa		
System		

To change a Volume set attribute, scroll to the attribute and press **Enter**. Make the modification and then press **ESC** to save the change. The following attributes can be modified:

Volume Name	The default volume name will always appear as Volume Set. #. You can rename the volume set providing it does not exceed the 15-character limit.
RAID Level	To set the RAID level for a Volume Set, highlight Raid Level and press Enter. The available RAID levels for the current Volume Set are displayed. Select the required RAID level and press Enter to confirm.
Capacity	The maximum size of the volume is always the default setting. You can increase or decrease the capacity using the UP and DOWN arrow keys. Each volume set can have a capacity which is less than, or equal to, the total capacity of the raid set on which it resides.
Stripe Size	This parameter sets the size of the segment written to each disk in a

	RAID 0, 1, 0+1, 5 or 6 logical drives. You can set the stripe size to 4 KB, 8 KB, 16 KB, 32 KB, 64 KB, or 128 KB.
SCSI Channel	Select the SCSI channel number and press Enter to confirm.
SCSI ID	Each SCSI device attached to the SCSI card, as well as the HBA card itself, must be assigned a unique SCSI ID number. An LVD SCSI channel can connect up to 15 devices. The Volume Set appears as a large SCSI device. You must assign an ID from a list of SCSI IDs. ID 7 is normally reserved for the HBA.
SCSI LUN	Each SCSI ID can support up to 8 LUN's. Most SCSI host adapters treat each LUN like a SCSI disk.
Cache Mode	You can set the cache mode to: Write-Through Cache or Write-Back Cache.
Tag Queuing	Enabling Tag-Queuing is useful for enhancing overall system performance for multi-tasking operating systems. The Command Tag (Drive Channel) function controls the SCSI command tag queuing support for each drive channel. This function should remain enabled and should only be disabled when using older SCSI host cards that do not support command tag queuing.
Max Sync Rate	The RAID subsystem supports 320 MB/sec as the highest data transfer rate for the Ultra 320 SCSI system.

Check Volume Set

Use this option to verify the integrity of the redundant data in a volume set. For example, in a system with dedicated parity, volume set check means computing the parity of the data disk drives and comparing the results to the contents of the dedicated parity disk drive. To check a Volume Set, select **Check Volume Set**, then press **Enter**. Select a Raid Set from the list, and then press **Enter** to show all Volume Sets.

Select the Volume Set from the list and press **Enter** to select it. A confirmation screen is displayed. Press **Yes** to start the check.

Stop Volume Set Check

Use this option to stop all Check Volume Set requests.

Display Volume Set Info.

To display Volume Set information, scroll to the desired Volume Set, then press **Enter**. The Volume Set Information will be displayed as shown below. You can only view information for one Volume Set at a time.

Main Menu		
Qu	Volu	The Volume Set Information
Ra		
Vo	Crea	Volume Set Name : QX-75061-VOL#00
Ph	Dele	Raid Set Name : Raid Set # 00
Ra	Modi	Volume Capacity : 240.0GB
U3	Chec	Volume State : Normal
Et	Stop	SCSI Ch/Id/Lun : 0/0/0
Vi	Disp	RAID Level : 0
Cl		Stripe Size : 64 KB
Hardware		Block Size : 512 Bytes
System In		Member Disks : 3
		Cache Attribute : Write-Back
		Tag Queuing : Enabled
		Max. SCSI Speed : 320MB/sec
		Current Speed : 80.0MB/Sec(ST)

Physical Drive

Choose this option from the Main Menu to select a physical disk and perform operations (described below) on it.

Main Menu	
Qu	
Ra	Physical Drive Function
Vo	
Ph	View Drive Information
Ra	Create Pass-Through Disk
U3	Modify Pass-Through Disk
Et	Delete Pass-Through Disk
Vi	Identify Selected Drive
Cl	
Hardware Monitor	
System Information	

View Drive Information

This option allows you to view details about the physical disks in the RAID subsystem. Selecting the View Drive Information option displays a list of all disk drives attached to the controller. Scroll to the desired drive and press **Enter**. The following information about the drive is displayed:

Main Menu		Ch02
Qu		Model Name : Maxtor 6Y080M0
Ra	Phys	Serial Number : Y2DA20CE
Vo		Firmware Rev. : YAR51EW0
Ph	View	Disk Capacity : 82.0GB
Ra	Crea	Current SATA : SATA150
U3	Modi	Supported SATA : SATA150
Et	Dele	Device State : RaidSet Member
Vi	Iden	Timeout Count : 0
Cl		Media Errors : 0
Hardware		SMART Read Error Rate : N.A.(N.A.)
System In		SMART Spinup Time : 219(63)
		SMART Reallocation Count : 253(63)
		SMART Seek Error Rate : 253(0)
		SMART Spinup Retries : 253(157)
		SMART Calibration Retries : 253(223)

Create Pass-Through Disk

A Pass-Through Disk is not controlled by the RAID subsystem firmware and thus cannot be a part of a Volume Set. The disk is available to the operating system as an individual disk. It is typically used on a system where the operating system is to be on a disk not controlled by the RAID subsystem firmware.

To create a Pass Through Disk, select **Create Pass Through Disk** from the menu. The list of available disk drives is displayed.

Main Menu		
Qu		
Ra	Physical Drive Function	
Vo		
Ph	View	
Ra	Crea	Select The Drive
U3	Modi	
Et	Dele	Ch02 82.0GB Free Maxtor 6Y080M0
Vi	Iden	Ch03 82.3GB Free HDS722580VLSA80
Cl		Ch04 82.0GB Free Maxtor 6Y080M0
Hardware		
System Information		

Scroll to a disk drive and press **Enter** to set the attributes for the Pass Through Drive.

Main Menu		
Qu	Physical Drive Function	
Ra		
Vo		
Ph	View	Pass-Through Disk Attribute
Ra	Crea	
U3	Modi	SCSI Channel : 06Y080M0
Et	Dele	
Vi	Iden	SCSI ID : 080VLSA80
Cl		SCSI LUN : 06Y080M0
Hardware		Cache Mode : Write Back
System In		Tag Queuing : Enabled
		Max Sync Rate : 320 MB/sec

Scroll to the attribute you wish to edit and press **Enter**. Edit the attribute and then press **ESC** to save the change and return to the previous menu.

Modify Pass-Through Disk

This option allows you to modify the Pass-Through Disk Attributes. To modify Pass-Through Disk attributes, select the **Modify Pass-Through Drive** option and then press **Enter**. All Pass-Through Drives are displayed. Scroll to the required drive and then press **Enter** to show the Pass-Through Disk Attributes.

Main Menu		
Qu	Physical Drive Function	
Ra		
Vo		
Ph	View	Pass-Through Disk Attribute
Ra	Crea	
U3	Modi	SCSI Channel : 080VLSA80
Et	Dele	
Vi	Iden	SCSI ID : 06Y080M0
Cl		SCSI LUN : 1
Hardware		Cache Mode : Write Back
System In		Tag Queuing : Enabled
		Max Sync Rate : 320 MB/sec

Select the parameter from the list you which to change, press **Enter** to modify it, then press **ESC** to save the change and return to the previous menu.

Delete Pass-Through Disk

To delete a Pass-through drive select **Delete Pass-Through Drive**, then press **Enter**. A list of all Pass Through Drives is displayed. Select the drive you wish to delete and press **Enter**.

Main Menu		
Qu	Physical Drive Function	
Ra		
Vo		
PH	View	Select The Drive
Ra	Crea	
U3	Modi	
Et	Dele	Ch04 400.1GB Pass Through ST3400832AS
Vi	Idea	
Cl		
Hardware		
System In		

Identify Selected Drive

To allow you to identify a particular physical drive in the front of the enclosure, the selected drive LED will flash red to allow you to identify the correct physical drive in the front of the enclosure when the **Identify Selected Device** is selected.

Main Menu			
Qu	Physical Drive Function		
Ra			
Vo			
Ph	View	Select The Drive	
Ra	Crea		
U3	Modi		
Et	Dele	Ch01 400.1GB RaidSet Member ST3400832AS	
Vi	Iden	Ch02 400.1GB RaidSet Member ST3400832AS	
Cl			
Hardware		Ch03 400.1GB RaidSet Member ST3400832AS	
System In		Ch04 400.1GB Pass Through ST3400832AS	
		Ch05 400.1GB Free ST3400832AS	

RAID System Function

The Raid System Function menu allows you to manage the RAID controller.

Main Menu	
Qu	Raid System Function
Ra	
Vo	Mute The Alert Beeper
Ph	Alert Beeper Setting
Ra	Change Password
U3	JBOD/RAID Function
Et	Background Task Priority
Vi	Maximum SATA Mode
Cl	HDD Read Ahead Cache
Ha	Stagger Power On
Sy	HDD SMART Status Polling
	Capacity Truncation
	Terminal Port Config
	Update FirmWare
	Restart Controller

Mute The Alert Beeper

The Mute The Alert Beeper function allows you to control the RAID subsystem Beeper.

Main Menu	
Qu	Raid System Function
Ra	Mute The Alert Beeper
Vo	Alert Beeper Setting
Ph	Change Password
Ra	JBOD/RAID Function
U3	Background Task Priority
Et	Maximum SATA Mode
Vi	HDD Read Ahead Cache
Cl	Stagger Power On
Ha	HDD SMART Status Polling
Sy	Capacity Truncation
	Terminal Port Config
	Update FirmWare
	Restart Controller

Mute Alert Beeper	
	Yes
	No

Select **Yes** and press **Enter** in the dialog box to mute the beeper. The beeper will still activate on the next event.

Alert Beeper Setting

The Alert Beeper function allows you to Disable or Enable the RAID subsystem controller beeper.

Main Menu	
Qu	Raid System Function
Ra	Mute
Vo	Aler
Ph	Chan
Ra	JBOD
U3	Back
Et	Maximum SATA Mode
Vi	HDD Read Ahead Cache
Cl	Stagger Power On
Ha	HDD SMART Status Polling
Sy	Capacity Truncation
	Terminal Port Config
	Update FirmWare
	Restart Controller

Alert Beeper Setting	
	Disabled
	Enabled

Select **Disabled** and press **Enter** to turn the beeper off. Or, select **Enable** and press **Enter** to turn the beeper on.



Change Password

The password option allows you to set or clear the raid subsystem’s password protection feature. Once the password has been set, you can only monitor and configure the raid subsystem by providing the correct password.

Main Menu

Qu

Ra

Vo

Ph

Ra

U3

Et

Vi

Cl

Ha

Sy

Raid System Function

Mute The Alert Beeper

Alert Beeper Setting

Change Password

JBOD/RAID Function

Background Task Priority

Maximum SATA Mode

HDD Read Ahead Cache

Stagger Power On

HDD SMART Status Polling

Capacity Truncation

Terminal Port Config

Update FirmWare

Restart Controller


Enter New Password

The password is used to protect the RAID subsystem from unauthorized entry. The controller will check the password only when entering the Main menu from the initial screen. The RAID subsystem will automatically go back to the initial screen when it does not receive any command for twenty seconds.

To disable the password, press **Enter** (without entering any alphanumeric characters) in both the **Enter New Password** and the **Re-Enter New Password** column. The existing password will be cleared. No password checking will occur when entering the main menu from the starting screen.


RAID/JBOD Function

The RAID/JBOD Function allows you to instruct the system as to how it should handle the drives. **RAID** will give you the functionality of creating RAID sets and **JBOD** will treat all drives as individual drives with no Raid protection.




Background Task Priority

The Background Task Priority function allows you to specify how tasks that run in the background are prioritized. Select the amount of resources (in percent) to be allocated to background tasks.




Maximum SATA Mode

The Maximum SATA Mode function allows you to set the maximum SATA mode that the system can support as well as enabling Native Command Queuing (NCQ). Select the Max SATA mode from the list and press **Enter** to select.



HDD Read Ahead Cache

Select the read ahead function to enable pre-fetching of data that has not specifically been requested in anticipation of subsequent reads for this data. This function may improve sequential read throughput.



Stagger Power On

This function is used to prevent current surge when powering up all disks simultaneously. The interval selected is the interval between the power up command issued to each drive in turn. For example a two second interval ensures that commands are issued to individual drives every two seconds.

The setting should be set to a minimum of 2.5 seconds.

Main Menu		
Qu	Raid	Stagger Power On
Ra		
Vo	Mute	0.4
Ph	Aler	0.7
Ra	Chan	1.0
U3	JBOD	1.5
Et	Back	2.0
Vi	Maxi	2.5
Cl	HDD	3.0
Ha	Stag	3.5
Sy	HDD	4.0
	Capa	4.5
	Term	5.0
	Upda	5.5
	Rest	6.0

HDD SMART Status Polling

This features allows the controller to take advantage of monitoring SMART information from the disk drives.

Main Menu		
Qu	Raid System Function	
Ra		
Vo	Mute	HDD SMART Status Polling
Ph	Aler	
Ra	Chan	Disabled
U3	JBOD	Enabled
Et	Back	
Vi	Maximum SATA Mode	
Cl	HDD Read Ahead Cache	
Ha	Stagger Power On	
Sy	HDD SMART Status Polling	
	Capacity Truncation	
	Terminal Port Config	
	Update FirmWare	
	Restart Controller	

Capacity Truncation

The Capacity Truncation function allows you to select how the disk capacity is to be truncated. For example, if you select Multiples of 10G, all disk capacities will be rounded down to the nearest 10GB i.e. if a disk has capacity of 412GB then it will appear as having a capacity of 410GB on the system. Select the Capacity Truncation setting from the list and

press **Enter** to select it. This may be useful if mixing drive vendors with similar capacities (or newer revision models of similar capacity form the same vendor).

Main Menu	
Qu	Raid System Function
Ra	
Vo	Mute
Ph	Aler
Ra	Chan
U3	JBOD
Et	Back
Vi	Maxi
Cl	HDD Read Ahead Cache
Ha	Stagger Power On
Sy	HDD SMART Status Polling
	Capacity Truncation
	Terminal Port Config
	Update FirmWare
	Restart Controller

Truncate Disk Capacity	
	To Multiples Of 10G
	To Multiples Of 1G
	Disabled

Terminal Port Config.

The Terminal Port Config function allows you to configure the terminal port. From this screen you can set the Baud Rate and the Stop Bits values. Press **Enter** to select Baud Rate or Stop Bit and edit the settings. Press **ESC** to save the change and return to the previous menu.

Main Menu	
Qu	Raid System Function
Ra	
Vo	Mu
Ph	Al
Ra	Ch
U3	JB
Et	Ba
Vi	Ma
Cl	HDD Read Ahead Cache
Ha	Stagger Power On
Sy	HDD SMART Status Polling
	Capacity Truncation
	Terminal Port Config
	Update FirmWare
	Restart Controller

Terminal Port Config	
Baud Rate	: 115200
Stop Bits	: 1 bit

Update Firmware

NOTE: You can update the firmware through the VT100 terminal via the controller's serial port.

NOTE: You can update the firmware via the firmware-embedded web browser-based RAID manager through the controller's 10/100 Ethernet LAN port.

Main Menu

Qu
Ra
Vo
Ph
Ra
U3
Et
Vi
Cl
Ha
Sy

Raid System Function

Mute The Alert Beeper

Alert Beeper Setting

Change

JBOD/RA

Backgro

Maximum

HDD Rea

Stagger

HDD SMA

Capacity Truncation

Terminal Port Config

Update FirmWare

Restart Controller

Update The Raid FirmWare

Transfer File From Terminal Emulator By Zmodem Protocol
<< Five Ctrl-X To Abort >>

Restart Controller

This function allows you to restart the controller. Select **Restart Controller** from the menu and press **Enter**. The Restart Controller confirmation screen appears. Select **Yes** to restart the RAID controller.

NOTE: Ensure that there is no Host and Drive activity before restarting the

Main Menu

Qu
Ra
Vo
Ph
Ra
U3
Et
Vi
Cl
Ha
Sy

Raid System Function

Mute The Alert Beeper

Alert Beeper Setting

Change Password

JBOD/RAID Function

Background Task Priority

Maximum SATA Mode

HDD Read Ahead Cache

Stagger Power On

HDD SMART Status Polling

Capacity Truncation

Terminal Port Config

Update FirmWare

Restart Controller

Restart Controller?

Yes

No

controller.

U320 SCSI Target Config¹⁰

This function allows you to configure U320 SCSI targets. Select **U320 SCSI Target Config** from the Main Menu and press **Enter**.

Main Menu	
Qu	U320 SCSI Target Configuration
Ra	
Vo	
Ph	Channel 0 QAS : Enabled
Ra	
U320 SC	Channel 0 QAS
Etherne	Disabled
View Sy	Enabled
Clear E	
Hardwar	
System Information	

The list of available U320 SCSI targets is displayed. Scroll to the required SCSI target and press **Enter**. Select **Disable** to disable the SCSI target, or select **Enable** to enable the SCSI target.

Fibre Channel Config¹¹

The corresponding screen for the Fibre Channel system is shown below:

Main Menu	
Qu	Fibre Channel Configuration
Ra	
Vo	
Ph	Channel 0 Speed : Auto
Ra	
Fi	Channel 0 Speed
Et	
Vi	Auto
Cl	1 Gb
Ha	2 Gb
System	4 Gb

Each channel can be configured independently. Default speed is Auto Negotiate. The next screen shows how to change the topology for each channel. Available options are Auto, Loop or Point-to-Point.

¹⁰ SCSI unit only

¹¹ Fibre Channel unit only

Main Menu	
Qu	Fibre Channel Configuration
Ra	
Vo	
Ph	Channel 0 Speed : Auto
Ra	Ch
Fi	Channel 0 Topology
Et	Ch
Vi	Ch
Cl	Ch
Ha	Auto
System	Loop
	Point-Point

Ethernet Configuration

These functions allow you to set the controller Ethernet port configuration. You do not need to create a reserved space on the arrays before the Ethernet port and http service will function.

Main Menu	
Qu	EtherNet Configuration
Ra	
Vo	
Ph	DHCP Function : Disabled
Ra	Local IP Address : 192.168.100.098
U3	HTTP Port Number : 80
Et	Telnet Port Number : 23
Vi	EtherNet Address : 00.04.D9.60.3F.4A
Cl	
Hardware Monitor	
System Information	

Scroll to a parameter in the list and press **Enter** to open it for editing. Make the necessary changes and then press **ESC** to save the changes and return to the previous menu.

DHCP Function

DHCP (Dynamic Host Configuration Protocol) is a protocol that lets network administrators manage centrally and automate the assignment of IP (Internet Protocol) configurations on a computer network. When using the Internet's set of protocols (TCP/IP), in order for a computer system to communicate to another computer system it needs a unique IP address. Without DHCP, the IP address must be entered manually at each computer system. DHCP lets a network administrator supervise and distribute IP addresses from a central point. The purpose of DHCP is to provide the automatic (dynamic) allocation of IP client configurations for a specific time period (called a lease period) and to eliminate the work necessary to administer a large IP network.

To manually configure the IP address of the controller, scroll to the Ethernet Configuration Function and press **Enter**. The Ethernet Configuration menu appears on the screen. Scroll to the DHCP Function, then press **Enter** to show the DHCP setting. Select the **Disabled** or **Enabled** option to enable or disable the DHCP function.

Local IP address

If you intend to set up your client computers manually, make sure that the assigned IP address is in the same range as your default router address and that it is unique to your private network. However, we would highly recommend that if you have a network of computers and the option to assign your TCP/IP client configurations automatically, please do so. An IP address allocation scheme will reduce the time it takes to set-up client computers and eliminate the possibilities of administrative errors.

To manually configure the IP address of the controller, scroll to **Local IP Address** and press **Enter** to show the default address setting. You can now reassign the IP address of the controller. Press **ECS** when finished to save the IP address and return to the previous menu.

Http Port Number

This function allows you to set the port number to be used as the `http` port for the RAID controller. Select **http Port Number** and press **Enter**. Type a new port number and then press **ESC** to save the new Port Number and return to the previous menu.

Telnet Port Number

This function allows you to set the port number to be used as the Telnet Port for the RAID controller. Select **Telnet Port Number** and press **Enter**. Type a new port number and then press **ESC** to save the new Port Number and return to the previous menu.

Ethernet Address

A MAC address stands for Media Access Control address and is your computer's unique hardware number. On an Ethernet LAN, it's the same as your Ethernet address. When you are connected to the Internet from the RAID controller Ethernet port, a correspondence table relates your IP address to the RAID controller's physical (MAC) address on the LAN.

View System Events

This function allows you to view the RAID controller system events information. To view the events, select **View System Events**, then press **Enter**. The RAID subsystem events screen appears.

Main Menu
Quick Volume/Raid Setup

Time	Device	Event Type	ElapseTime Errors
2005-11-9 16:39:57	IDE Channel 2	PassThr. Created	
2005-11-9 16:38:2	Raid Set # 00	Delete RaidSet	
2005-11-9 16:37:50	QX-75061-VOL#00	Delete Volume	
2005-11-9 16:32:28	QX-75061-VOL#00	Create Volume	
2005-11-9 16:32:17	QX-75061-VOL#00	Complete Init	000:01:49
2005-11-9 16:32:17	QX-75061-VOL#00	Delete Volume	
2005-11-9 16:30:27	QX-75061-VOL#00	Start Initialize	
2005-11-9 16:30:27	QX-75061-VOL#00	Create Volume	

Choose this option to view the system events information: Time, Device, Event type, Elapse Time and Errors. The RAID system does not have a built in real time clock. The Time information is the relative time from the RAID subsystem being powered on.

Clear Events Buffer

This function allows you to clear the entire events buffer information. To clear the buffer, select **Clear Events Buffer** and press **Enter**, then select **Yes** and press **Enter**.

Main Menu
Quick Volume/Raid Setup
Raid Set Function
Volume Set Function
Physical Drives
Raid System Function
U320 SCSI Target Config
Ethernet Configuration
View System Events
Clear Event Buffer
Hardware Monitor
System Information

Clear Event Buffer ?
Yes
No

Hardware Monitor

The Hardware Monitor Information provides the temperature, of any drives present within the enclosure. It also provides the temperature, fan speed (chassis fan) and the voltage of the RAID subsystem. All items are read-only. The warning messages will be indicated through the Fault LED's or the alarm buzzer.

Select **Hardware Monitor** by pressing **Enter** to view Temperature information.

Main Menu															
Quick Volume	<table><tr><th colspan="2">The Hardware Monitor Information</th></tr><tr><td>HDD #1 Temp.</td><td>: 38</td></tr><tr><td>HDD #2 Temp.</td><td>: 41</td></tr><tr><td>HDD #3 Temp.</td><td>: 37</td></tr><tr><td>HDD #4 Temp.</td><td>: 35</td></tr><tr><td>HDD #5 Temp.</td><td>: --</td></tr><tr><td>HDD #6 Temp.</td><td>: --</td></tr></table>	The Hardware Monitor Information		HDD #1 Temp.	: 38	HDD #2 Temp.	: 41	HDD #3 Temp.	: 37	HDD #4 Temp.	: 35	HDD #5 Temp.	: --	HDD #6 Temp.	: --
The Hardware Monitor Information															
HDD #1 Temp.		: 38													
HDD #2 Temp.		: 41													
HDD #3 Temp.		: 37													
HDD #4 Temp.		: 35													
HDD #5 Temp.		: --													
HDD #6 Temp.		: --													
Raid Set Fun															
Volume Set F															
Physical Dri															
Raid System															
U320 SCSI Ta															
Ethernet Con															
View System															
Clear Event															
Hardware Mon															
System Infor															

Press **ESC** to return to the Main Menu. Select **Hardware Monitor** again to view further hardware information.

Main Menu	
Quick Volume	The Hardware Monitor Information Controller Temp. : 50 (Celsius) Power +12V : 12.585 Power +5V : 4.945 Power +3.3V : 3.264 Power +2.5V : 2.560 Power +1.3V : 1.312 Power +1.2V : 1.216 System Power : OK System Fan#1 RPM : 1240
Raid Set Fun	
Volume Set F	
Physical Dri	
Raid System	
U320 SCSI Ta	
Ethernet Con	
View System	
Clear Event	
Hardware Mon	
System Infor	

System Information

Choose this option to display details of the Main processor, CPU Instruction cache and data cache size, firmware version, serial number, controller model name, and the cache memory size. To view the system information, select **System Information** and then press **Enter**.