




Publicly traded on NASDAQ Symbol: NSSC

PROGRAMMING INSTRUCTIONS



FREEDOM F-64 CONTROL PANEL/COMMUNICATOR

Programming the F-64 Control Panel with the F-64PROG Programmer



F-64PROG Programmer

Quick Start using the F-64PROG:

1. Refer to the wiring diagram and connect the **Siren**, **Aux. Power**, **PGM Output**, **Remote Bus**, **earth ground**, **Zone** and **Telephone wiring**.

NOTE: See Installation Instructions (WI1501).

2. Connect AC power first and then the battery.
3. Configure the Touchpad (see page 40).

4. Access the **Easy Menu Driven Program Mode**:

Press **4** **5** **6** **7F** **8A** **9P** **MENU**
Default Dealer Code

☞ Press NO (**AWAY**) until "ACTIVATE PROGRAM Y/N" appears on the programmer display.

☞ Press YES (**STAY**) to Enter Dealer Program Mode. Go to page 5.

**THIS MANUAL INCLUDES FEATURES WHICH ARE ONLY AVAILABLE IN
CONTROL PANEL FIRMWARE VERSION 30 OR LATER.**

IMPORTANT PROGRAMMING INFORMATION

The following System and Keypad Options **must** be programmed for proper panel operation:

- Automatic Interior Bypass/Easy Exit (address 1424, option 1)
- Interior Normally Bypassed (address 1422, option 1)
- Disable Code Required for EZ Bypass (address 1424, option 8)
- Easy Arming (addresses 1440-1446, option 6)

IMPORTANT NOTICE

F-64 panel version 30 requires the use of the following version programmer:

- F-64PROG Version 01

Upon entering program mode, the programmer display will flash the control panel firmware version, followed by the programmer firmware version:

- F-64PROG : [3001]

If Gemini keypads are installed in the system (in addition to the required Freedom F-64TP or F-64TP-H Touch-pads), the following version keypads must be used:

- GEM-K1CA Version 9B
- GEM-K2AS, Version 7
- GEM-K3DGTL, Version 3
- GEM-K4/K4RF, Version 2

Differences between the GEM-P1664 and the Freedom F-64 Control Panels:

The GEM-P1664 control panel and the Freedom F-64 V30 control panel are identical, except for the following:

- The "Classic" Gemini RP-Series keypads cannot be used with the Freedom F-64 V30 control panel.
- The **Perimeter Group Bypass** zone feature is exclusive to the Freedom F-64 V30 control panel.



NAPCO Security Systems, Inc.

333 Bayview Avenue, Amityville, New York 11701

For Sales and Repairs, call toll free: (800) 645-9445

For direct line to Technical Service, call toll free: (800) 645-9440

Internet: <http://www.napcosecurity.com>

TABLE OF CONTENTS

CONTROL PANEL PROGRAMMING OPTIONS	4	ENTERING ZONE DESCRIPTIONS	12
OVERVIEW	4		
DEALER PROGRAM MODE	5	DIRECT ADDRESS PROGRAM MODE	13
Dealer Program - Preliminary Information	5	Direct Address Overview	13
Accessing Dealer Program Mode.....	5	Address Mode Displays	13
Customizing a Default Program	5	Binary (Bit) Format Example	13
Decimal Format Example	14	Decimal Format Example	14
Hexadecimal Format Example	15		
EASY MENU DRIVEN PROGRAM MENU	6	Programming Conventions Used in this Manual.....	16
Total Number of Zones in Area 1.....	6	SYSTEM DELAYS & TIMEOUTS	17
Panel Zone Doubling	6	SYSTEM OUTPUT TIMEOUTS	18
Fire Zones in Area 1	6	DOWNLOAD/CALLBACK OPTIONS	18
2-Wire Fire Zones in Area 1	6	PAGER FORMAT OPTIONS.....	18
Local or Central Station Reporting System.....	6	SYSTEM OPTIONS.....	19
Exit/Entry Zones in Area 1	6	CS RECEIVER OPTIONS	22
Interior Zones in Area 1	6	CS SUBSCRIBER ID OPTIONS	23
24 Hour Zones in Area 1.....	6	CS SYSTEM REPORTING OPTIONS	24
Chime Zones in Area 1	7	CS AREA & SYSTEM REPORTING OPTIONS	24
Chime 2 Zones in Area 1	7	CS ZONE REPORTING OPTIONS	25
Exit/Entry2 Zones in Area 1	7	CS USER REPORTING OPTIONS	26
50 mS Loop Response Zones	7	EZM GROUP OPTIONS	27
Aux Output Activated on Alarm Zones.....	7	AREA ARMING OPTIONS	27
Sensor Watch Zones	7	AREA BELL CONTROL OPTIONS	28
Keypad Sounder On Alarm Zones.....	7	KEYPAD / TOUCHPAD OPTIONS	29
Auto Bypass Re-entry Zones.....	7	MAPPING F-64TP DOORS AND PIR'S	29
Enable No EOLR Zones	7	ZONE OPTIONS - ZONES 1 TO 16	30
Enable Telco Line Fault Test?	7	ZONE OPTIONS - ZONES 17 TO 32	31
Enable Burg Output Chirp on Keyfob?	8	ZONE OPTIONS - ZONES 33 TO 48	32
Enable SIA CP-01 Features?	8	ZONE OPTIONS - ZONES 49 TO 64	33
Number of Keypads in Area 1	8	EXTERNAL RELAY CONTROL	34
Enter the Freedom Touchpad Number	8	RF RECEIVER & SUPERVISORY TIMER	
Enter the Touchpad PIR Zone Number	8	OPTIONS	37
Enter Door Number 1 Zone Number.....	8	CLEAR PROGRAM OPTIONS	38
Enter Door Number 2 Zone Number.....	8		
Chime 1 Zone Number	8	DEALER PROGRAM MODE OVERVIEW	39
Chime 2 Zone Number	8	Easy Menu Driven Program Mode	39
Aux 2 Zone Number.....	8	Direct Address Program Mode	39
Add Another Freedom Touchpad?	8		
Central Station Receiver 1 Telephone Number	9	TOUCHPAD CONFIGURATION MODE	40
Central Station Receiver 1 Account Number	9	Touchpad Installation	40
Central Station Receiver 1 Format	9	Configuring the Touchpads	40
Enter User Codes	9		
RF Transmitter Points	10	TOUCHPAD MENU MODE	43
Keyfob Transmitters as Arm/Disarm & Control			
Devices	10	EASY MENU PROGRAMMING WORKSHEETS	44-47
Keyfob Transmitters as Zone Input Devices	11		
Enter Zone Descriptions	11	ALPHABETICAL INDEX	48
Enter Date.....	11		
Enter Time	11	ADDRESS NUMBER INDEX	53
Dealer Code.....	11		
Test Timer.....	11	F-64 WIRING DIAGRAM	56
Clear Dealer Program	11		
Cold Start	11		

Refer to accompanying F-64 Installation Instructions (WI1501) for installation information.



CONTROL PANEL PROGRAMMING OPTIONS

OVERVIEW

The F-64 control panel may be programmed by various means, each of which will be covered in detail in the sections that follow. Keypad displays shown are for an F-64PROG programmer, the recommended device for programming.

- ✓ **DOWNLOADING FROM A COMPUTER.** This is the preferred method of programming. The panel may be downloaded from (or uploaded to) an IBM PC-compatible computer, either locally or remotely. Napco's PCD-Windows Quickloader software features context-sensitive help screens as well as an error-checking utility that prevents programming of incompatible or conflicting data to ensure proper panel operation. **Note:** Unattended downloading from a computer is not allowed for Fire Alarm or UL installations.

The control-panel program may be downloaded from the computer by any of the following methods.

Local Downloading - (Note: This procedure should be used after installation, after peripheral devices are connected).

For direct high-speed data transfer to the control panel from a desktop computer, connect the download jack (JP2) on the panel to the LOCAL jack (J3) on the Napco PCI2000/3000 computer interface using the supplied 6-conductor cable. (Refer to PCI2000/3000 Installation Instructions WI443 for wiring diagram and procedures).

Similarly, a high-speed local download may be made in the field using a notebook or laptop computer. Connect JP2 on the control panel to a Napco PCI-MINI computer interface using the 6-conductor cable supplied. (Refer to PCI-MINI Installation Instructions WI767).

Remote Downloading - (Also see PCI2000/3000 Installation Instructions WI443). Note: Unattended downloading from a computer is not allowed for Fire Alarm or UL installations.

Function Mode - (Also called **Touchpad Menu Mode** when using a freedom Touchpad, see page 43). Start by establishing a telco connection between the computer operator and the installer. During this procedure, voice contact will be lost, therefore both the installer and the computer operator should be familiar with the operation. When a steady high-pitched tone is heard at the site phone, access the "ACTIVATE DOWNLOAD" Function, then press the  button or the **NEXT/YES** button; the site phone will go dead. Hang up the phone and wait for a call from the central station confirming a successful download.

Callback Method - An installed, unattended panel may be programmed or reprogrammed remotely using the Callback-Method Download feature of the PCD-Windows software. Remote downloading requires a modem compatible with the PCI2000/3000. Upon answering the call from the computer, the panel will verify the Download Security Code and, if confirmed, will establish a connection. If a Callback Number is programmed into the panel, the panel will automatically disconnect and call the computer at this number before establishing a connection.

- ✓ **EASY MENU DRIVEN PROGRAM MODE Using the F-64PROG Programmer (see page 6).** Accessed after entering Dealer Program Mode, the Easy Menu Driven Program Mode is a menu-driven utility that prompts the installer to configure the system. The Easy Menu Driven Program Mode allows keypad programming of the Total Number of Zones in Area 1, Panel Zone Doubling, Fire Zones in Area 1, 2-Wire Fire Zones in Area 1, Local or Central Station Reporting System, Exit/Entry Zones in Area 1, Interior Zones in Area 1, 24 Hour Zones in Area 1, Chime Zones in Area 1, Chime 2 Zones in Area 1, Exit/Entry2 Zones in Area 1, 50 mS Loop Response Zones (**Note:** 750mS is required for Loop Response time in UL installations), Aux Output Activated on Alarm Zones, Sensor Watch Zones, Keypad Sounder On Alarm Zones, Auto Bypass Re-entry Zones, Enable No EOLR Zones, Enable Telco Line Fault Test?, Enable Burg Output Chirp on Keyfob?, Enable SIA CP-01 Features?, Number of Keypads in Area 1 , Enter the Freedom Touchpad Number, Enter the Touchpad PIR Zone Number, Enter Door Number 1 Zone Number, Enter Door Number 2 Zone Number, Chime 1 Zone Number, Chime 2 Zone Number, Aux 2 Zone Number, Add Another Freedom Touchpad?, Central Station Receiver 1 Telephone Number, Central Station Receiver 1 Account Number, Central Station Receiver 1 Format, Enter User Codes , RF Transmitter Points, Keyfob Transmitters as Arm/Disarm & Control Devices, Keyfob Transmitters as Zone Input Devices , Enter Zone Descriptions, Enter Date, Enter Time, Dealer Code, Test Timer, Clear Dealer Program and Cold Start. For new panels, a custom default program may be created at the keypad. Further detailed customization is accomplished in the Direct Address Program Mode.

- ✓ **DIRECT ADDRESS PROGRAM MODE Using the F-64PROG Programmer (see page 17).** The Direct Address Program Mode is an extension of the Dealer Program Mode wherein data is entered at the F-64PROG programmer by location. This mode is accessed from the Easy Menu Driven Program Mode by pressing the  button at any time.

DEALER PROGRAM MODE

DEALER PROGRAM - PRELIMINARY INFORMATION

Dealer Program Mode comprises two (2) operational states:

- EASY MENU DRIVEN PROGRAM MODE** - Used with new "out of the box" panels, this mode allows the dealer to customize the factory panel program to best suit the installation. The **Easy Menu-Driven Program Mode** is a menu-driven utility that prompts the installer to configure the system (see page 6). Press **RESET** at any time to exit, thus entering **Direct Address Program Mode**, detailed below.
- DIRECT ADDRESS PROGRAM MODE** - Additional programming changes, if necessary, can be made in the **Direct Address Program Mode**. In this mode, the programming address is accessed directly and re-configured by the installer.

- ☞ The factory default Dealer Code is **4 5 6 7F 8A 9P**. We recommend that you use this code to enter Dealer Program Mode and program a custom Dealer Code, replacing the factory default Dealer Code. If you clear your Dealer Code, use the Default Dealer Code once again to enter programming.
- ☞ After entering codes or data, press the save **ENTER** button. Data will not be stored into memory unless **ENTER** is pressed.
- ☞ If the programmer is in the Program Mode and no activity is detected for longer than 4 minutes, a steady tone will sound.
- ☞ Silence the sounder by the ***** button to continue, or by pressing the **RESET** button to exit.
- ☞ When programming a Multiple Area System, Direct Address Programming Mode must be used to complete the program.

ACCESSING DEALER PROGRAM MODE

- Press** **4 5 6 7F 8A 9P MENU**
Default Dealer Code
- Press PRIOR/NO** button until "ACTIVATE PROGRAM Y/N" appears on LCD screen.
- Press NEXT/YES** button to Enter Dealer Program Mode.
- Press RESET** to Exit Dealer Program Mode when finished.

CUSTOMIZING A DEFAULT PROGRAM

For new panels, you can design a default program that will best suit your application. Using this procedure, you will configure the panel for:

- Total Number of Zones in Area 1
- Panel Zone Doubling
- Fire Zones in Area 1
- 2-Wire Fire Zones in Area 1
- Local or Central Station Reporting System
- Exit/Entry Zones in Area 1
- Interior Zones in Area 1
- 24 Hour Zones in Area 1
- Chime Zones in Area 1
- Chime 2 Zones in Area 1
- Exit/Entry2 Zones in Area 1
- 50mS Loop Response Zones (Note: 750ms is required for Loop Response time in UL installations)
- Aux Output Activated on Alarm Zones
- Sensor Watch Zones
- Keypad Sounder On Alarm Zones
- Auto Bypass Re-entry Zones
- Enable No EOLR Zones
- Enable Telco Line Fault Test
- Enable Burg Output Chirp on Keyfob
- Enable SIA CP-01 Features
- Number of Keypads in Area 1
- Central Station Receiver 1 Telephone Number
- Central Station Receiver 1 Account Number
- Central Station Receiver 1 Format
- Enter User Codes
- RF Transmitter Points
- Keyfob Transmitters as Arm/Disarm & Control Devices
- Keyfob Transmitters as Zone Input Devices
- Enter Zone Descriptions
- Enter Date
- Enter Time
- Dealer Code
- Test Timer
- Clear Dealer Program
- Cold Start

This procedure will automatically set up system keypads/Touchpads, EZMs, wireless transmitters, etc. After your basic default program has been loaded, you may alter it as necessary in the Direct Address Program Mode.

NEW PANELS: The custom default program may be created for new panels only. Once the panel has been programmed by any means, the number zones will be suppressed and cannot be changed. Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press the **RESET** button to enter the Direct Address Program Mode; (b) access Location

2285 (Clear Program); (c) press **ENTER** and start over.

EASY MENU DRIVEN PROGRAM MODE

To create a custom program using the F-64PROG programmer, simply answer the following questions and record your information on the *Easy Menu Programming Worksheet* (see page 44). In each of the following steps, press **[MENU]** to set cursor, the **NEXT/YES** button to go forwards, the **PRIOR/NO** button to go backwards, **[ENTER]** to save and **[RESET]** twice to exit at any time.

of Zns in Area1
Enter # Zones XX

(Direct Entry)

Total Number of Zones in Area 1 (New Program Only)

- Enter the total number of zones to be programmed for Area 1.
- Valid entries are from 01 to 64. Directly enter the total number of zones, including leading zeros.
- The system is based on groups of 4 zones each (after the first 8 zones), and will automatically round up to the next group of 4. For example, if you enter 18, it will automatically convert this to 20 zones. Press **[ENTER]** to save. Press the **NEXT/YES** button to proceed.

EZ Zone Doubling Enabled? Y/N

(Press YES or NO)

Panel Zone Doubling (New Program Only)

- To double the number of hardwired panel zones from 8 to 16, press YES.
- If Panel Zone doubling is not desired, press the **PRIOR/NO** button.
- The 16 zones will remain EOL terminated zones, requiring Normally Closed devices only.
- Refer to Wiring Diagram and Installation Instructions for wiring instructions

Fire Zones
Enter Zone # ..

(Direct Entry)

Fire Zones in Area 1 (New Program Only)

- Enter the zone number of any Fire Zones (including 2-wire, 4-wire or wireless).
- Valid entries are from 01 to 64.
- Directly enter each zone number, including leading zeros, and press **[ENTER]** to save, and then repeat for any additional zone(s). Press the **NEXT/YES** button to proceed.

2-Wire Fire Zns
Enter Zone # ..

(Direct Entry)

2-Wire Fire Zones in Area 1 (New Program Only)

- Enter the zone number of any Fire Zone (from previous question) to be used with 2-wire smoke detectors.
- Valid entries are 07 and 08. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save, and repeat for any additional zone(s); press **NEXT/YES** to proceed.

NOTE: Only zones which have been designated as Fire Zones can be programmed as 2 Wire Fire zones. JP3 must be set to "2-WF" position for 2-wire fire. (refer to Installation Instructions).

Report All Zones To Central? Y/N

(Press YES or NO)

Local or Central Station Reporting System (New Program Only)

Press the **NEXT/YES** button for all zones to report; press the **PRIOR/NO** button for local system

Exit/Entry Zones
Enter Zone # XX

(Direct Entry)

Exit/Entry Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and repeat for any additional zone(s); press the **NEXT/YES** button to proceed.

NOTE: Exit/Entry Entry time of 30 seconds will automatically be programmed.

Interior Zones
Enter Zone # XX

(Direct Entry)

Interior Zones in Area 1 (New Program Only)

- Enter the zone numbers to be used as Interior Zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s).
- Press the **NEXT/YES** button to proceed.
- All Interior zones will also be automatically programmed as "Exit/Entry Follower" and as "Power Up Delay" zones.

24 Hour Zones
Enter Zone # ..

(Direct Entry)

24 Hour Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as 24 Hour zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and repeat for any additional zone(s); press the **NEXT/YES** button to proceed.

NOTE: 24 Hour Zones will automatically be programmed as audible (Burg Output).

Chime Zones
Enter Zone # **

(Direct Entry)

Chime Zones in Area 1 (New Program Only)

- Enter the zone numbers which are to be used as Chime Zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), press the **NEXT/YES** button to proceed.

NOTE: A chime time of 2 seconds will be automatically programmed.

Chime 2 Zones
Enter Zone # **

(Direct Entry)

Chime 2 Zones in Area 1 (New Program Only)

- Enter the zone numbers which are to be used as Chime 2 Zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), Press the **NEXT/YES** button to proceed.

NOTE: A chime time of 2 seconds will be automatically programmed.

Chime 2 zones give a distinct pulsating tone when zone is faulted.

Exit/Entry2 Zones
Enter Zone # **

(Direct Entry)

Exit/Entry2 Zones in Area 1 (New Program Only)

- Enter the zone numbers of zones to be used as Exit/Entry zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and repeat for any additional zone(s); press the **NEXT/YES** button to proceed.

NOTE: An Exit/Entry 2 Entry Time of 30 seconds will automatically be programmed.

50mS Loop Zones
Enter Zone # **

(Direct Entry)

50 mS Loop Response Zones (New Program Only) Note: 750mS is required for Loop Response time in UL installations.

- Enter the zone numbers of zones to have a 50mS loop response.
- Valid entries are from 01 to 08. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), Press the **NEXT/YES** button to proceed.

Note: Only panel zones 01-08 can be programmed for Quick Loop Response. All other zones can be programmed via their respective EZM's (hardwire). Time can also be adjusted via address 2280.

Aux Output Zones
Enter Zone # **

(Direct Entry)

Aux Output Activated on Alarm Zones (New Program Only)

- Enter the zone numbers of zones to activate the PGM2 upon alarm.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), Press the **NEXT/YES** button to proceed.

NOTE: A PGM2 Timeout of 15 minutes will automatically be programmed.

Sensor Watch Zns
Enter Zone # **

(Direct Entry)

Sensor Watch Zones (New Program Only)

- Enter the zone numbers of zones to be Sensor Watch zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), Press the **NEXT/YES** button to proceed.

NOTE: A Sensor Watch Time of 24 hours will automatically be programmed.

KP Sndr Alrm Zns
Enter Zone # **

(Direct Entry)

Keypad Sounder On Alarm Zones (New Program Only)

- Enter the zone numbers of all zones to activate the Keypad Sounder upon alarm.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), Press the **NEXT/YES** button to proceed.

Auto Byp REnt Zn
Enter Zone # **

(Direct Entry)

Auto Bypass Re-entry Zones (New Program Only) (Not Evaluated by UL)

- Enter the zone numbers of zones to be Auto Bypass Re-entry zones.
- Valid entries are from 01 to 64. Directly enter each zone number, including leading zeros.
- Press **[ENTER]** to save and then repeat for any additional zone(s), Press the **NEXT/YES** button to proceed.
- Auto Bypass Re-entry Zones allow the system to be armed with the zone faulted but come back into the system (armed) when the zone is subsequently closed.

Enable No EOLR
Zones Y/N

(Press YES or NO)

Enable No EOLR Zones (New Program Only)

- Press **YES** to program all zones except 24 Hr & fire zones for No End Of Line Resistor. Press **NO** to continue. Do NOT program this feature for UL installations.

Enable Telco
Line Test? Y/N

(Press YES or NO)

Enable Telco Line Fault Test?

- Press **YES** to enable Telco Line Fault Test.
- Press **NO** to continue. **NOTE:** If enabled, a Telco Line Fault Test Delay of 60 sec. will automatically be programmed.



Enable Burg Out Chirp? **Y/N**

(Press YES or NO)

Enable SIA CP-01? **Y/N**

(Press YES or NO)

Area 1 Keypads Enter # KPs **01**

(Direct Entry)

Prog a Freedom KP? **Y/N**

(Press YES or NO)

Enter Freedom KeyPad # **--**

(Direct Entry)

Enter KeyPad PIR Zone # **--**

(Direct Entry)

Enter Door1 Zone # **--**

(Direct Entry)

Enter Door2 Zone # **--**

(Direct Entry)

Chime 1 Zone # **--**

(Direct Entry)

Chime 2 Zone # **--**

(Direct Entry)

Aux2 Zone # **--**

(Direct Entry)

Add another Freedom KP? **Y/N**

(Direct Entry)

Enable Burg Output Chirp on Keyfob?

- Press the **NEXT/YES** button to enable Burg Output Chirp on Keyfob Arm / Disarm.
- Press the **PRIOR/NO** button to continue.

NOTE: The Burg Output will chirp once on Keyfob Arm and twice on Keyfob Disarm.**Enable SIA CP-01 Features?**

- Press the **NEXT/YES** button to enable.
- Press the **PRIOR/NO** button to continue.

The SIA CP-01 Features are designed to reduce the incidence of false alarms. **NOTE:** Do not enable unless reporting, otherwise system trouble *Fail to Communicate* may occur.**Number of Keypads in Area 1**

- Enter the total number of Keypads to be installed in Area 1.
- Valid entries are from 01 to 07. Directly enter the number of keypads, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**NOTE:** Area 2-4 keypads must be assigned in Direct Address Programming. See Keypad Options.**Program a Freedom Touchpad?**

- Press **YES** to add a Freedom Touchpad and to jump to the next selection, listed directly below.
- Press **NO** to skip this selection and jump to **Central Station Receiver 1 Telephone Number** (see next page)

Enter the Freedom Touchpad Number

- Assign to the panel an address number for the Touchpad to be installed.
- Valid entries are from 01 to 04. Directly enter the address number of the Touchpad, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Enter the Touchpad PIR Zone Number**

- Enter the zone number to associate with the Touchpad PIR.
- Valid entries are from 01 to 64. Directly enter the number of the zone, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Enter Door Number 1 Zone Number**

- Enter the zone number to associate with the Touchpad *primary* door.
- Valid entries are from 01 to 64. Directly enter the number of the zone, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Enter Door Number 2 Zone Number**

- Enter the zone number to associate with the Touchpad *secondary* door.
- Valid entries are from 01 to 64. Directly enter the number of the zone, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Chime 1 Zone Number**

- Enter the zone number to associate with the primary Touchpad Chime.
- Valid entries are from 01 to 64. Directly enter the number of the zone, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Chime 2 Zone Number**

- Enter the zone number to associate with the secondary Touchpad Chime.
- Valid entries are from 01 to 64. Directly enter the number of the zone, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Aux 2 Zone Number**

- Enter the zone number to associate with the PGM2 output (terminal 8 on the control panel).
- Valid entries are from 01 to 64. Directly enter the number of the zone, including leading zeros.

Press **ENTER** to save. Press the **NEXT/YES** button to proceed.**Add Another Freedom Touchpad?**

- Press **YES** to add a Freedom Touchpad and to jump up to the selection, "Enter Freedom KeyPad #" listed above.
- Press **NO** to skip this selection and jump to **Central Station Receiver 1 Telephone Number** (see next page).

Central Phone #

(Direct Entry)

Central Station Receiver 1 Telephone Number

- Enter telephone number of up to 16 digits.
- Press **1** through **9P** for digits 1–9; ***** **0** for a zero and **(•)** for a blank (•).
- Press ***** **1** through ***** **5** for letters B–F, respectively.
- Pre-Dial Delay = “D” (***** **4**); Dial-Tone Detection = “E” (***** **5**).
- Press **[ENTER]** to save and press the **NEXT/YES** button to proceed.

NOTE: Central Station Receiver 2 and 3 Telephone Numbers must be entered in Direct Address Programming. See CS Receiver Options.

Central Station Account # (____)

(Direct Entry)

Central Station Receiver 1 Account Number

- Enter an account number of up to four digits.
- Press **0** through **9P** for digits 0–9, and ***** **0** for a blank (•).
- Press **[ENTER]** to save and press the **NEXT/YES** button to proceed.

NOTE: Central Station Receiver 2 and 3 Account Numbers must be entered in Direct Address Programming. See CS Reporting Options.

**See WI for Info
Rcvr Format (0)**

(Direct Entry)

Central Station Receiver 1 Format

- From the table at the right enter the receiver format.
- Press **0** through **9P**, and ***** **0** for blank (•).
- Press ***** **1** through ***** **4** for letters B–E.
- Press **[ENTER]** to save and press the **NEXT/YES** button to proceed.

**Enter user code->
U01 123 - 9-**


User# User Code Area 1 Area 2

Enter User Codes (Press **[MENU] to set cursor.)**

For default program, enter up to 64 User Codes, with Area 1, 2, 3 & 4 Options.

- Press the (**[MENU]**) button once to set the cursor to the User Code.
- Press **0** through **9P** to enter a code from 3 to 6 digits, leave blank (•) any trailing boxes.
- Press **[MENU]** to set the cursor to the Area 1 Options Level. Refer to the table below for available options. For Area 2 Options, press **[MENU]** once again. For Area 3 & 4 Options, press **[MENU]** a third and fourth time.
- If “Enable Global Ambush Code” (Address 1422) is enabled and “Global Ambush Code” (Address 2045) is **not** left blank (•), *do not* program the first two digits of ANY User Code the same as the “Global Ambush Code”. See Address 2045 further in this manual for more information.
- Press **[ENTER]** to save. **Note:** Duplicate User Codes are not allowed; therefore a duplicate Code entered in the LCD Window will erase when **[ENTER]** is pressed. To proceed to the next User Code, press **[MENU]** to set the cursor to the User Number and change it using the number buttons. Press the **NEXT/YES** button to proceed.

USER OPTIONS				
USER CODE (UP TO 6 DIGITS)	AREA 1 OPTIONS	AREA 2 OPTIONS	AREA 3 OPTIONS	AREA 4 OPTIONS



USER AREA OPTIONS		
DATA ENTRIES		OPTION ENABLED
L	R	
blank(•)	blank(•)	Disabled
blank(•)	1	Arm/Disarm
blank(•)	2	Arm Only
blank(•)	3	Service
blank(•)	4	Access
blank(•)	5	Ambush
blank(•)	Add 8	* User Program
4	blank(•)	Bypass Enable

DATA ENTRY	CS RECEIVER 1 FORMAT
• (blank)	Ademco Slow, Silent Knight Slow
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow
5	Universal High Speed
B	SIA
C	Ademco Point ID
E	Pager

Example: Program a code of “2222” for user 02, with area 1 options of “Arm/Disarm” and “User Program”. Enter “2222” for a user code, “• (blank) 9” for area 1 options and “• (blank) •(blank)” for area 2 options.



AREA OPTIONS	EXPLANATION
Disabled	User Code not active in this area.
Arm/Disarm	Allows User Code to arm/disarm this area.
Arm Only	Prevents User Code from disarming this area.
Service	A Service Code has restricted arm/disarm rights; if an area is armed with a Service Code, a "MONITOR ON" appears in the LCD window and the area can be disarmed with any valid User Code, including a Service Code. If the area is armed with OTHER than a Service Code, it CANNOT be disarmed with a Service Code. This is typically used to allow tradesmen access to premises under control of the owner.
Ambush	GEM-K-Series keypads: There are two types of Ambush Codes: (1) A 2-digit code (prefix) entered immediately prior to (and as part of) the regular User Code and (2) A separate and unique User Code. Disarming with an Ambush Code causes a silent report to be sent to a central station, thus, should a user be forced to disarm, he can silently signal an emergency while appearing to be merely disarming the system. With Touchpads, Ambush operates differently. See "Ambush" glossary entry in the Installation Instructions, WI1501 for more information. Note: Do not program method 1 in CP-01 compliant systems.
Access	This is normally used to activate a door strike while an area is disarmed. Also program "Access Control on PGM2. Output" (Address 0719) and "PGM2 Output Access Control Timeout" (Address 0711).
* User Program	User Program Option is enabled. To enable User Program Option for any user, add 8 to the data entry for Area Option (see example). Then, User Programming can be performed at any keypad by a user code with user program enabled.
Bypass Enable	Security Bypass—Bypass is enabled only with a security code.

Related User Options: "Enable Global Ambush Code" (Address 1422), "Global Ambush Code" (Address 2045) & "Enable Manager's Mode" (Address 1421).

CHANGING OR CANCELING A CODE: To change any code, merely program over the existing code as described above and press **[ENTER]** to save. Similarly, to cancel a code, blank out each number of the code and press **[ENTER]** to save.

ZN#	XMIT#+CS	P	
Zn01 -	000000:0-0		
Zone #	Xmitter ID	Check Sum	Point #

RF Transmitter Points (Press **[MENU]** to set cursor.)

For each transmitter enter: (For wireless systems only. Also see Quick Method, which follows)

- The **zone number** (01–64) to which the transmitter will be mapped.
- The **6-digit RF ID # and 1-digit checksum number** printed on the transmitter and box,
- The **point number** (1–2); enter "9" for unsupervised (all points).
- Press **[ENTER]** to save and **NEXT/YES** button to proceed when all transmitters have been entered.

NOTE: When programming the ID Code number, "0" through "9" = **[0]** through **[9P]**; A = **[*] [0]**; B = **[*] [1]**; C = **[*] [2]**; D = **[*] [3]**; E = **[*] [4]** and "F" = **[*] [5]**.

ZN#	XMIT#+CS	P
Zn01 -	000000:0-0	
ZN#	XMIT#+CS	P
Zn01 -	ENROLL:A--	
KF	A	

Quick "Enroll" Method: If a receiver is already installed in the panel, transmitter wireless points can be programmed automatically ("enrolled") using the following procedure. **NOTE:** The transmitter point will be enrolled only if the signal strength is 3 or greater.

- Enter the zone number to which the transmitter point will be mapped.
- Press **[BYPASS]** to enter the Enroll Mode. The red and green LEDs on the programmer will flash and the window will display as shown at left.
- Open the loop of the point that is to be programmed (GEM-TRANS2 only).
- Install the transmitter battery. The programmer will beep to indicate that the point has been successfully enrolled. Multi-point transmitters can be mapped to successive zones simultaneously.

Example. A 2-point transmitter has the RF ID number 287613:1.

Map point 1 to Zone 6 and point 2 to Zone 9.

- Enter the Enroll mode as described above.
- Enter Zone "06".
- Open point-1 loop.
- Install the battery. The programmer will beep once to indicate that one point has been programmed. (Transmitter 287613:1,

point 1 will be mapped to Zone 6).

- Enter Zone "09".
- Close point-1 loop and open point-2 loop.
- Remove the transmitter battery, then re-install it. The programmer will beep once to indicate that one point has been programmed. (Transmitter 287613:1, point 2 is mapped to Zone 9).

KEYFOB ZONE ASSIGNMENT: Keyfobs can also be assigned to zones to allow multiple wireless panic buttons on one alarm system, each reporting to a central station, a pager or having a description in the LCD window that describes the person holding the keyfob, the location where the person holding the keyfob is stationed, or the special purpose of the keyfob button being depressed. See the next page on Keyfob Transmitters as Zone Input Devices.

KF	A	XMIT#+CS	OP	
01-0	000000:0	00		
KF	Area	Xmitter	Check	Aux
#	ID		Sum	1&2

Keyfob Transmitters as Arm/Disarm & Control Devices (Press **[MENU]** to set cursor).

Keyfobs can be programmed as "Arm/Disarm" devices using their On/Off buttons (refer to WI752). For each Keyfob Transmitter, enter:

- The **Keyfob Transmitter number** (01–8).
- The **area number** to which transmitter is assigned (0 to disable keyfob, 1 through 4).
- The **6-digit RF ID # and 1-digit checksum number** printed on the transmitter and box,
- The **Aux 1 Option** (see keyfob aux 1 & aux 2 options).
- The **Aux 2 Option** (see keyfob aux 1 & aux 2 options).
- Press **[ENTER]** to save and **NEXT/YES** button to proceed when all keyfobs have been entered.

NOTE: When programming the ID Code number, "0" through "9" = **[0]** through **[9P]**; A = **[*] [0]**; B = **[*] [1]**; C = **[*] [2]**; D = **[*] [3]**; E = **[*] [4]** and "F" = **[*] [5]**.

Keyfob Transmitters as Zone Input Devices

(Refer to display above: press the PRIOR button to go backwards).

Each of the 4 keyfob buttons can be assigned to a zone. For example, On button = point 1; Off button = point 2; A1 = point 3; A2 = point 4. Up to 64 keyfobs (using 1 button) or 32 keyfobs (using 2 buttons) or 16 keyfobs (using all 4 buttons) or any combination up to a maximum of 64 controlled zones can be assigned, providing multiple wireless panic buttons on a system, each reporting to a Central Station or a pager and/or annunciating on a keypad/Touchpad the keyfob zone number with a description. To assign a keyfob to a zone: program the keyfob as you would a transmitter, entering the keyfob's ID code, check sum and point number at the appropriate zone. The "Quick Method" is not allowed. The zone may be hardwired to an electrical sensor as well as assigned to a keyfob (either one will activate the zone alarm output). **NOTE:** If assigning a keyfob to a zone, the "ON/OFF" buttons on the keyfob will no longer arm/disarm the system. The keyfob is converted to a "panic only" device.

DATA ENTRY	AUX 1/AUX 2 OPTIONS
0	None
1	Relay Group 1 Toggle
2	Relay Group 2 Toggle
9	Keypad Panic
A	Keypad Aux.
B	Instant
C	PGM2 Outup Toggle
D	Access on PGM2 Output
E	Arm STAY
F	Interior Button

01-

(Direct Entry)

Enter Zone Descriptions

- For each zone, enter a description of up to two lines. Press to save each description.
- See next page for instructions for entering characters and numbers for the zone descriptions.
- To proceed to the next description, place the cursor under the Zone Number (e.g. "1") and press the number that corresponds to the zone. Program new description as above.

Enter Date

< / >

(Direct Entry)

Enter Date (Press to set cursor).

- Enter the current date in the format MM/DD/YY. (MM = month, DD = day and YY = year).
- Press to save. Press the **NEXT/YES** button to proceed.

Enter Time

< : >

(Direct Entry)

Enter Time (Press to set cursor.)

- Enter the current time in format HH:MMAP, where HH=hours (01–12); MM=minutes (00–59).
- Select AM or PM by pressing any number button.
- Press to save. Press the **NEXT/YES** button to proceed.

Dealer Code
456789DEALER CODE
RE-ENTERTEST TIMER
SMTWTFSS HH:MM**Dealer Code**

- Directly enter the Dealer Code (default = 456789), using through buttons.
- Press to save. Re-enter the Dealer Code to verify the previous code. Press to save.
- Press the **NEXT/YES** button to proceed.

Test Timer

- Select day(s) by simply erasing the unwanted days. Move the cursor over the day and press any number key to erase/restore the day. For example, "Monday" and "Friday" will appear as: " .
- Enter Time (in 24 hour format) by moving cursor under the left H and pressing two digits to overwrite the existing default of 00. **Note:** Midnight is 00:00. Enter minutes by continuing to enter data or if just updating minutes move the cursor under the left M and enter the two digits to overwrite the existing default of 00. Use as right cursor one position.

EXIT DEALER PROGRAM MODE: This completes the custom default program. Press to enter the Direct Address Program Mode for further programming or press once again to end all programming.

CLEAR PROGRAM: Should it be necessary to create a new custom default program, (a) from the Dealer Program Mode, press to enter the Address Program Mode; (b) access Location 2285 (Clear Program) or 2286 (Cold Start); (c) press and then (d) press to exit the Dealer Program Mode. A "SYSTEM TROUBLE/E09-00 SERVICE" will occur. Press to silence the programmer.

Clear Dealer Program (Erases Dealer Program)

Use this feature to erase the Panel Program, while maintaining Scheduled Data and Zone Descriptions. Access address 2285 and press . Data entry is not allowed. **NOTE:** Enter Easy Menu Driven Program Mode to reprogram system.

Cold Start (Erases Entire Program)

This erases all programmed data (Dealer Program, Zone Description Data and Schedules). Access address 2286 and press . Data entry is not allowed. **NOTE:** Some features (schedules) can only be programmed again with the Downloading Software.



ENTERING ZONE DESCRIPTIONS

01 -

Enter an identifying description for each zone. Characters are selected by pressing F-64PROG programmer buttons multiple times, "Cell Phone" style. Buttons **1** through **9P** plus **0** and ***** are used, as per the following table:

PRESS:	CHARACTERS DISPLAYED IN SEQUENCE	HOLD * AND PRESS:	CHARACTERS DISPLAYED IN SEQUENCE
[1]	ABC1	[1]	abc1
[2]	DEF2	[2]	def2
[3]	GHI3	[3]	ghi3
[4]	JKL4	[4]	jk14
[5]	MNO5	[5]	mno5
[6]	PQR6	[6]	pqr6
[7F]	STU7	[7F]	stu7
[8A]	VWXYZ8	[8A]	vwxyz8
[9P]	YZ90	[9P]	yz90
[0]	(SPACE)•- . () , / : ? #	[0]	(Reserved)

Press **MENU** to move cursor right.

Press **BYPASS** to move cursor left.

Notes:

1. After releasing the number button for 2 seconds, the character will be accepted and the cursor advanced to the right.
2. After releasing the number button, if a new number button is pressed before the 2 second window expires, the current character will be accepted and the cursor automatically advanced to the right. The first of the 4 characters of this new number button will be displayed.
3. To erase an existing entry, use **MENU** to move the cursor below the character to be changed. Enter a new character to overwrite the old, or press zero to delete the character.
4. To generate lowercase characters, the ***** button must be pressed and held down while pressing the number button. If the ***** button is released during the 2 second window, the current character will change to uppercase.


Press **[]** to save.

To advance to the next zone (or to any other zone), move the cursor to the displayed zone number (i.e., "01") using **MENU** and **BYPASS**. Change the zone number using keys **0** through **9P**. Enter two digits for the zone number (after entering the first digit, the cursor will automatically advance to the second digit). When the second zone number digit is entered, the cursor will automatically advance to the right, allowing the description locations to be entered. Always press **[]** to save each zone description.


DIRECT ADDRESS PROGRAM MODE

DIRECT ADDRESS OVERVIEW

Direct Address Programming allows you to go directly to the address locations (up to 2287) and change the data entries manually in order to customize your control panel options. Whereas the Easy Menu Driven Program Mode guides you through limited selections to get you started, **Direct Address Program Mode** allows you to change all options directly. It consists of up to 2287 address locations each with data entry locations as shown in the following diagram (below left). The data entry location accepts data in one of three formats: Binary, Decimal and Hexadecimal (explained below in "Address Mode Displays"). The following diagram (below right) illustrates a *Decimal* format data entry location (using an F-64PROG programmer).



F-64PROG Programmer Display Example




ADDRESS MODE DISPLAYS

There are three types of address displays when programming in Direct Entry Program Mode, as follows:

A) Binary (Bit) Format Example

Settings (such as Zone Features) display and accept data in "number" format. For example, Zone Features are turned on by the pressing of the programmer buttons 1 through 8, with the activated Zone(s) displaying the corresponding decimal digit (replacing deactivated zones which are signified by dashes).

EXAMPLE: BIT Format with the F-64PROG: Program Zones 2, 4, 5 and 7 as Exit/Entry Follower Zones.



DETERMINE THE DATA ENTRIES

1. Referring to ZONE FEATURES in the Programming Worksheets that follow, the Exit/Entry Follower for Zones 1 through 8 are located at address 0916.



ZONE FEATURES	ADDR	ZONES 1 → 8								ADDR	ZONES 9 → 16							
		Z1	Z2	Z3	Z4	Z5	Z6	Z7	Z8		Z9	Z10	Z11	Z12	Z13	Z14	Z15	Z16
		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8
Exit/Entry Follower	0916						6	7	8	0911								


PROGRAM THE DATA ENTRIES

1. Enter the panel's Dealer Security Code, then press **[MENU]**.
2. Answer NO to all questions until "ACTIVATE PROGRAM Y/N" is displayed; then press YES. **NOTE:** If you pass "ACTIVATE PROGRAM", scroll backward using **[BYPASS]**.
3. Press **[RESET]** to enter the Address Program Mode. Address "0000" will display.
4. Press **[0] [9 P] [1] [6]** to access Address 0916. *The existing data will display and the cursor will advance to the data field.*
5. Press **[6] [7F] [8A]**. The numbers 6,7 and 8 will appear on the programmer display indicating the zones activated.
6. Press **[ENTER]** to save. Address 0916 is now programmed with "6,7,8".
7. Press **[MENU]** and enter another 4-digit address to continue programming --or-- press **[RESET]** to exit.

B) Decimal Format Example

Settings (such as Entry and Exit Delay) display and accept data in decimal format, as a 3 digit number. Data is entered directly, by pressing keys 0 – 9, with the cursor automatically moving to the right upon each key press.

EXAMPLE: DECIMAL Format with the F-64PROG: Program Abort Delay to be 15 seconds.



DETERMINE THE DATA ENTRIES

1. Referring to SYSTEM DELAYS & TIMEOUTS in the Programming Worksheets that follow, the Abort Delay is located at address 1417:

ABORT DELAY (sec.)	ADDRESS 1417

[Default = 0 sec. = blank (*)]

PROGRAM THE DATA ENTRIES

1. Enter the panel's Dealer Security Code, then press **[MENU]**.
2. Answer NO to all questions until "ACTIVATE PROGRAM Y/N" is displayed; then press YES. **NOTE:** If you pass "ACTIVATE PROGRAM", scroll backward using **[BYPASS]**.
3. Press **[RESET]** to enter the Address Program Mode. Address "0000" will display.
4. Press **[1] [4] [1] [7F]** to access Address 1417. *The existing data will display and the cursor will ad-*

vance to the data field.


5. Press **0 1 5**. The numbers 015 will appear on the programmer display indicating the number of seconds entered.
6. Press **[ENTER]** to save. Address 1417 is now programmed with a 15-second Abort Delay.
7. Press **[MENU]** and enter another 4-digit address to continue programming--or--press **[RESET]** to exit.

C) Hexadecimal Format Example

Data such as Report Codes displays and accepts data by means of a Hexadecimal display. Data is entered directly, by pressing keys 1 – 9, ***** **0** for zero, and ***** **1** through ***** **5** for hex B through F (11-15), with the cursor automatically moving to the right upon key press. See table below.

HEXADECIMAL ENTRIES					
ENTRY TOTAL	PRESS	KEYPAD DISPLAYS	ENTRY TOTAL	PRESS	KEYPAD DISPLAYS
blank	0	.	8	8 A	8
1	1	1	9	9 P	9
2	2	2	10	* 0	0
3	3	3	11	* 1	B
4	4	4	12	* 2	C
5	5	5	13	* 3	D
6	6	6	14	* 4	E
7	7F	7	15	* 5	F

EXAMPLE: HEXADECIMAL Format with the F-64PROG: Program Chime Timeout to be 2 seconds.



1. Referring to SYSTEM DELAYS & TIMEOUTS in the Programming Worksheets that follow, the Chime Timeout is located at address 1418. In the "Chime Timeout Options" table, the data entries needed to assign a timeout of 2 seconds are "blank" and "8".

CHIME TIMEOUT (1/4sec.)	ADDRESS 1418
[Default = 2 1/4sec. = 1/2 sec.]	

CHIME TIMEOUT OPTIONS		
DATA ENTRIES		TIMEOUT
LEFT	RIGHT	
blank (*)	blank (*)	0 x 1/4sec. = 0 sec.
blank (*)	2	2 x 1/4sec. = 1/2 sec.
blank (*)	3	3 x 1/4sec. = 3/4 sec.
blank (*)	4	4 x 1/4sec. = 1 sec.
blank (*)	5	5 x 1/4sec. = 1.25 sec.
blank (*)	6	6 x 1/4sec. = 1.5 sec.
blank (*)	7	7 x 1/4sec. = 1.75 sec.
blank (*)	8	8 x 1/4sec. = 2 sec.
		255 x 1/4sec. = 63.25

← 2 seconds



PROGRAM THE DATA ENTRIES

1. Enter the panel's Dealer Security Code, then press **[MENU]**.
2. Answer NO to all questions until "ACTIVATE PROGRAM Y/N" is displayed; then press YES. **NOTE:** If you pass "ACTIVATE PROGRAM Y/N", scroll backward using **[BYPASS]**.
3. Press **[RESET]** to enter the Address Program Mode. Address "0000" will display.
4. Press **[1] [4] [1] [8A]** to access Address 1418. *The existing data will display and the cursor will advance to the data field.*
5. Since you wish the timeout to be for 2 seconds (and 8 multiplied by $\frac{1}{4}$ second equals 2 seconds), press **[0] [8A]**. The numbers 08 will appear on the programmer display indicating the number of seconds entered.
6. Press **[ENTER]** to save. Address 1418 is now programmed with a 2-second chime.
7. Press **[MENU]** and enter another 4-digit address to continue programming --or-- press **[RESET]** to exit.

PROGRAMMING CONVENTIONS USED IN THIS MANUAL

The Programming Worksheets in the back are provided as an address-programming reference to help the installer modify his custom default program or to make minor field alterations to an existing panel program. It is recommended that the panel be uploaded to NAPCO's PCD-Windows software following any F-64PROG programmer changes and that the PCD-Windows's error-check feature be utilized to reduce the possibility of programming omissions or conflicts.

Keep the Programming Worksheets on file for future reference.

General Programming Steps

- ☞ 1. Contact the central station to ascertain receiver format, data format, event codes, subscriber numbers and telephone number(s).
- ☞ 2. Select the desired features by circling (with a pencil) the respective "address" boxes. Refer to the Programming Options and Worksheets for guidance in selecting the "data" to be entered into those boxes.
- ☞ 3. Program the data entered in the boxes on the worksheets into the respective addresses. The display will show the entry numerically, but if hexadecimal format will display "0" for the number 10, and letters "B", "C", "D", "E", and "F" for the numbers 11 through 15, respectively. To program a 10, press **[*] [0]**. To program 11 through 15, press **[*] [1]** through **[*] [5]**, respectively.

The displays will appear after a brief delay.

- ☞ Use **[MENU]** to toggle the cursor between the 4-digit address field and the data entry locations.
- ☞ Enter the address directly using the number buttons.
- ☞ The contents of the address will be read automatically. The cursor will advance to the data field. Enter the required data directly using the number buttons.
- ☞ **IMPORTANT:** Press **[ENTER]** to save the contents of each address.

EXIT DIRECT ADDRESS PROGRAM MODE: When done, press **[RESET]** to exit. Disconnect the F-64PROG programmer and reconnect the Freedom Touchpad.

SYSTEM DELAYS & TIMEOUTS (ADDRESS 0000-0002, 1413, 1417, 2050 & 2055)

EXIT DELAY (sec.)	ADDRESS 0000		
[Default = 060]			

ENTRY DELAY 1 (sec.)	ADDRESS 0001		
[Default = 030]			

ENTRY DELAY 2 (sec.)	ADDRESS 0002		
[Default = 030]			

PGM2 Output Access Cntrl Timeout (sec.)	ADDRESS 1413		
[Default = 0 sec. = blank (*)]			

ABORT DELAY (sec.)	ADDRESS 1417		
[Default = 030]			

 Select delay/timeout (0-255 sec.).

EXIT/ENTRY DELAYS: Apply only to zones programmed with the following options "Exit/Entry 1, Exit/Entry 2, Exit/Entry Follower". For UL Installations, the maximum exit delay is 60 seconds and the maximum entry delay is 45 seconds. **NOTE:** Sensor Watch Time Options are similar to above, except in hours.

 Press  to save.

Sensor Watch Time (Hrs.)	ADDRESS 2050		
[Default = 024]			

Report Cancel Window (min.)	ADDRESS 2055		
[Default = 0 min. = blank (*)]			



WARNING: Timers have uncertainty of +/- 1 sec, so a "time" of 1 second may actually timeout IMMEDIATELY.

SYSTEM DELAYS & TIMEOUTS (ADDRESS 1418-1419)

CHIME TIME (1/4sec.)	ADDRESS 1418		
[Default = 008 x 1/4 sec. = 2 sec.]			

AC Fail Report Delay (min.)	ADDRESS 1419		
[Default = 060]			

DEFAULTS: The defaults shown on this page and on the following pages are automatically set after exiting the Easy Menu Driven Program Mode.

 1. Enter delay/timeout in corresponding address locations above.

Note: All entries for address 1418 are in quarter seconds (.25 seconds).
Therefore, the default of 008 results in a 2 second timeout.

 2. Press  to save.

SYSTEM OUTPUT TIMEOUTS (ADDRESS 1412 & 1414-1416)

PGM2 Output	ADDRESS 1412
Timeout (min.)	

[Default = 0 min. = blank (*)]

Alarm Output	ADDRESS 1414
Timeout (min.)	

[Default = 015]

Pulse Alarm Output	ADDRESS 1415
Timeout (min.)	

[Default = 015]

PGM1 Output	ADDRESS 1416
Timeout (min.)	

[Default = 0 min. = blank (*)]

DATA ENTRIES	DELAY/TIMEOUT
blank (*)	0 min.
001	1 min.
002	2 min.
003	3 min.
004	4 min.
005	5 min.
006	6 min.
016	16 min.
↓	↓
255	255 min.

- ☞ 1. Select delay/timeout (0-255 min.) from the table shown.
- ☞ 2. Enter in corresponding address locations above.
- ☞ 3. Press  to save.

OUTPUT TIMEOUTS: If a timeout of "0 min." is selected, then the output will remain active (ON) until the system is reset or disarmed. For UL Residential Installations, the minimum timeout is 4 minutes. Not UL listed for Commercial Installations. For Canadian Residential Fire, the minimum timeout is 5 minutes.

DOWNLOAD/CALLBACK OPTIONS (ADDRESS 2059 & 0526-0545)

No. Rings Before Pickup	ADDRESS 2059

[Default = 015]

NUMBER OF RINGS BEFORE PICKUP: Enter the number of rings before automatic pickup by the control panel when downloading from a computer (see Glossary at the back for more information).

- ☞ 1. Enter digit only.
- ☞ 2. Valid entries are: 003-015. **NOTE:** Default is 15 Rings.
- ☞ 3. Press  to save.

Callback Telephone Number (Digits 1-20)	ADDRESS 0526-0545 (RIGHT DIGITS 1-20)																			
	0526	0527	0528	0529	0530	0531	0532	0533	0534	0535	0536	0537	0538	0539	0540	0541	0542	0543	0544	0545

[Default = blank (*) for all digits 1-20]

CALLBACK TELEPHONE NUMBER: Enter telephone number to be used when downloading from a computer (see Glossary at the back for more information).

- ☞ 1. Enter digit only (right nibble).
- ☞ 2. Enter up to 20 digits from left to right. **NOTE:** Leave trailing boxes blank (*).
- ☞ 3. Valid entries are: 1-9, B = , C = , D = 3 sec. pause, E = Wait for dial tone, F = ignore location.
- ☞ 4. Press  to save.

PAGER FORMAT OPTIONS (ADDRESS 0546 & 0547)

Leading Digits for Pager Format (1st Digit)	ADDRESS 0546

LEADING DIGITS FOR PAGER FORMAT: In Pager Format reporting, the message typically begins with "00". However, for some pager services, this will cause the Pager's Voice Mail feature to activate. This option allows you to program these digits to any number desired. A typical Pager report is "003 22 1234", where 3 is the Event, 22 is the zone, and 1234 is the Subscriber ID number. For example, if the Leading Digits are programmed as "98", the Pager report will now appear as "983 22 1234". **NOTE:** See CS Receiver Options to select Pager Format.

Leading Digits for Pager Format (2nd Digit)	ADDRESS 0547

- ☞ 1. Enter in 1st and 2nd Leading Digits as shown (right nibble).

- ☞ 2. Valid entries are: 0-9. Press  to save.

SYSTEM OPTIONS (ADDRESS 0836-0871 & 2045)

SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/TROUBLE	ADDR	GLOBAL SYSTEM EVENT/TROUBLE							
		TEST TIMER	TELCO FAILURE	RF RCVR. TROUBLE	MEMORY FAILURE	LOW BATTERY	AC FAIL	EZM TAMPER	Bell Superv
		1	2	3	4	5	6	7	8
Alarm Output	0836								
Pulsed Alarm Output	0837								
PGM1 Output	0838								
PGM2 Output	0839								
Report Event Telco 1	0840								
Report Restore Telco 1	0841								
Report Event Telco 3	0842								
Report Restore Telco 3	0843								

[Default = blank (*) from address 0836-0843]. Note: If Test Timer is enabled (above), Digital Dialer Test is also enabled.

SYSTEM RESPONSE ACTIVATED BY AREA 1 EVENT/TROUBLE	ADDR	AREA 1 SYSTEM EVENT/TROUBLE							
		AMBUSH	KEYPAD PANIC	KEYPAD FIRE	KEYPAD AUX.*	KEYPAD TAMPER	FAIL TO OPEN	FAIL TO CLOSE	Keyfob Low Batt
		1	2	3	4	5	6	7	8
Pulsed Alarm Output	0856								
Alarm Output	0857								
PGM1 Output	0858								
PGM2 Output	0860								
Report Event Telco 1	0861								
Report Event Telco 3	0863								

[Default = blank (*) from address 0856-0863] * NOTE: Keypad Aux. is not to be selected for UL Installations.

SYSTEM RESPONSE ACTIVATED BY AREA 2 EVENT/TROUBLE	ADDR	AREA 2 SYSTEM EVENT/TROUBLE							
		AMBUSH	KEYPAD PANIC	KEYPAD FIRE	KEYPAD AUX.*	KEYPAD TAMPER	FAIL TO OPEN	FAIL TO CLOSE	Keyfob Low Batt
		1	2	3	4	5	6	7	8
Pulsed Alarm Output	0864								
Alarm Output	0865								
PGM1 Output	0866								
PGM2 Output	0868								
Report Event Telco 1	0869								
Report Event Telco 3	0871								

[Default = blank (*) blank (*) from address 0864-0871] * NOTE: Keypad Aux. is not to be selected for UL Installations.

☞ 1. Select the desired option entering the option number (1-8) for each digit.

☞ 2. Enter corresponding option number in address location.

☞ **NOTE:** Dark shaded data value box shows option not available. Press  to save.

Global Ambush Code	ADDRESS 2045	
	1st digit	2nd digit

[Default = blank (*) blank (*)]

GLOBAL AMBUSH CODE: For GEM-K Series keypads, it is the 2-digits entered immediately prior to the regular disarm code. If "Enable Global Ambush Code" (Address 1422) is selected and Address 2045 is left blank (*), then the 2-digit Global Ambush Code is "99". If "Enable Global Ambush Code" is selected and Address 2045 is not left blank (*), then the 2-digit Global Ambush Code is the two digits entered in address 2045. For Touchpads, see "Ambush" glossary entry in install instructions WI1501. Enter in address location (both 1st and 2nd digits); valid entries are 1-9. Press **ENTER** to save. **Note:** Do not program in CP-01 compliant systems.



SYSTEM OPTIONS (ADDRESS 0872-0887)

SYSTEM RESPONSE ACTIVATED BY AREA 3 EVENT/TROUBLE	ADDR	AREA 3 SYSTEM EVENT/TROUBLE							
		AMBUSH	KEYPAD PANIC	KEYPAD FIRE	KEYPAD AUX. *	KEYPAD TAMPER	FAIL TO OPEN	FAIL TO CLOSE	Keyfob Low Batt
		1	2	3	4	5	6	7	8
Pulsed Alarm Output	0872								
Alarm Output	0873								
PGM1 Output	0874								
PGM2 Output	0876								
Report Event Telco 1	0877								
Report Event Telco 3	0879								

[Default = blank (*) from address 0872-0879] * NOTE: Keypad Aux. is not to be selected for UL Installations.

SYSTEM RESPONSE ACTIVATED BY AREA 4 EVENT/TROUBLE	ADDR	AREA 4 SYSTEM EVENT/TROUBLE							
		AMBUSH	KEYPAD PANIC	KEYPAD FIRE	KEYPAD AUX. *	KEYPAD TAMPER	FAIL TO OPEN	FAIL TO CLOSE	Keyfob Low Batt
		1	2	3	4	5	6	7	8
Pulsed Alarm Output	0880								
Alarm Output	0881								
PGM1 Output	0882								
PGM2 Output	0884								
Report Event Telco 1	0885								
Report Event Telco 3	0887								

[Default = blank (*) blank (*) from address 0880-0887] * NOTE: Keypad Aux. is not to be selected for UL Installations.

☞ 1. Select the desired option entering the option number (1-8) for each digit.

☞ 2. Enter corresponding option number in address location.

☞ NOTE: Dark shaded data value box shows option not available. Press  to save.

SYSTEM OPTIONS (ADDRESS 2063)

2063 System Options		
Default		Option
OFF	1	RESERVED
OFF	2	RESERVED
OFF	3	RESERVED
OFF	4	RESERVED
OFF	5	RESERVED
OFF	6	RESERVED
OFF	7	Enable Low Security Fire Alarm Silence
OFF	8	RESERVED

SYSTEM OPTIONS:

When option 7, "Enable Low Security Fire Alarm Silence", is enabled, a fire alarm (pulsing Bell) will silence if **RESET** is pressed from a Freedom Touchpad (or GEM-K1CA keypad). The Touchpad must be in an area that allows silencing from the initiating area.

☞ 1. Select the desired option entering the option number (1-8) for each digit.

☞ 2. Enter corresponding option number in address location.

NOTE: Dark shaded data value box shows option not available. Press **Enter** to save.

SYSTEM OPTIONS (ADDRESS 1420-1424, 2051-2054)

1420 System Options		
Default		Option
OFF	1	Opening Report Only after Alarm Report
OFF	2	Closing Report Only on Conditional Close
OFF	3	Incl. Sel./Grp. Bypass in Cond. Close /Status
OFF	4	Status Report
OFF	5	RESERVED
OFF	6	Enable AutoArm if not closed at end of Window
OFF	7	Enable Keypad Time/Date Display
OFF	8	Disable Zone Fault Scrolling

1422 System Options		
Default		Option
OFF	1	Interior Normally Bypassed
OFF	2	Enable Global Ambush Code ***
OFF	3	Reset Day Zone with Arm/Disarm Only
OFF	4	Enable Residential Fire
OFF	5	Disable Keypad Function Mode Download
OFF	6	Disable Callback Download
OFF	7	Chirp Output on Keyfob Arm/Disarm
OFF	8	Change Pulse Output to Temporal Output§

§This feature must be programmed in Fire Alarm applications.

1424 System Options		
Default		Option
OFF	1	Automatic Interior Bypass/Easy Exit
OFF	2	Veri-phone Zones Trip PGM2 Output
OFF	3	Veri-phone Audio Priority Over Alarms
OFF	4	Resound on Wireless Smoke Low Battery
OFF	5	Don't Clear PGM2 Output with Disarm
OFF	6	Disable 2nd Call Ans. Machine Override
OFF	7	RESERVED
ON	8	Disable Code Required for EZ Bypass

2052 E15 Lug / System Options		
Default		Option
OFF	1	RESERVED
OFF	2	RESERVED
OFF	3	(V) Lug E15 Area 1 Armed Away Only****
OFF	4	(V) PGM on RF Transmitter Tamper
OFF	5	RESERVED
OFF	6	RESERVED
OFF	7	RESERVED
OFF	8	RESERVED

NOTE: Address 1423: Default depends on Easy Menu Driven Program Mode question :“EZ ZONE DOUBLING? Y/N”. If yes, then [Default = 1]. If no, then [Default = blank ()].

**NOTE: To select “Line-Fault Test only when Armed”, you must also select “Enable Line-Fault Test” at address 1423.

***NOTE: If “Enable Global Ambush Code” in Address 1422 is selected, then program the 2-digit “Global Ambush Code” in Address 2045. If Address 2045 is left blank (*), then, the 2-digit “Global Ambush Code” will be “99”.

****NOTE: If this feature is not selected, the E15 Lug will, by default, activate when the system is armed (all areas).

1421 System Options		
Default		Option
OFF	1	Auto Bell Test on Arming
OFF	2	Auto Reset after Burglary Output Timeout
OFF	3	Suppress Bypass Reminder when Armed
OFF	4	Enable Local Alarm on First Zone AND Trip
OFF	5	Access Control on PGM2 Output
OFF	6	Maintained Keypad Arming
OFF	7	Enable Manager's Mode
OFF	8	Disable Keypad Instant Mode

1423 System Options		
Default*		Option
OFF*	1	Enable Zone Doubling (Zones 9-16)
OFF*	2	Wireless Trouble Activates Telco 1
OFF*	3	Wireless Trouble Activates Telco 3
OFF*	4	Enable Alarm Output on Telco Fail only when Armed
OFF*	5	Line-Fault Test only when Armed**
OFF*	6	Enable Line-Fault Test**
OFF*	7	(V) Inhibit System Trouble Audible at Keypad
OFF*	8	Select Alarm Output for Keyfob Chirp

(V) Not for UL Installations.

2051 System Options		
Default		Option
OFF	1	Enable Keypad Set Time/Date Message
OFF	2	Enable Cancel Report to Telco 3
OFF	3	Disable [ON/OFF] as Easy Exit
OFF	4	Enable GEM-PRINT Module
OFF	5	RESERVED
OFF	6	RESERVED
OFF	7	(V) Disable System Trouble Audible Timeout
OFF	8	Enable "K Series" Style Keypads ††

†† NOTE: For reference only and cannot be changed.

NOTE: Option 7 required for UL Installations

2053 System Options		
Default		Option
OFF	1	Exit Time Restart
OFF	2	Sound Alarm On Exit Error
OFF	3	Rpt Exit Err/Recent Close
OFF	4	Enable CP-01 Limits
OFF	5	Digital Dialer Rpt Enter /Exit Test Mode
OFF	6	Disable Call Waiting on 1st Attempt
OFF	7	Enable Keypad 1 Only Programming
OFF	8	Enable CP-01 Egress Tones Only

2054 System Options		
Default		Option
OFF	1	(V) Enable TCP/IP Communications
OFF	2	RESERVED
OFF	3	RESERVED
OFF	4	RESERVED
OFF	5	RESERVED
OFF	6	RESERVED
OFF	7	RESERVED
OFF	8	RESERVED



CS RECEIVER OPTIONS (ADDRESS 0460-0525)

CS Receiver 1	ADDRESS 0460	CS Receiver 2	ADDRESS 0482	CS Receiver 3	ADDRESS 0504
Format		Format		Format	

Default for CS Receiver 1 Format depends on Easy Menu Driven Program Mode question "RCVR FORMAT".
[Default = •(blank) •(blank)] for CS Receivers 2 and 3 Formats.

CS RECEIVER FORMATS: Up to 3 CS Formats may be programmed.

1. Select the desired CS Receiver Format from the table shown.

2. Enter the corresponding digit in the address location for each CS Receiver. **NOTE:** Dark shaded data value box shows option not available. Press [Enter] to save.

DATA ENTRY	CS RECEIVER 1 FORMAT
blank (*)	Ademco Slow, Silent Knight Slow
2	Radionics Fast
3	Silent Knight Fast
4	Radionics, DCI, Franklin Slow
5	Universal High Speed
B	SIA
C	Ademco Point ID
E	Pager *

NOTE: * See Pager Format Options to program Leading Digits for Pager Format.

0461 CS Receiver Options - Telco 1		
Default		Option
OFF	1	1400Hz Handshake/Kissoff *
OFF	2	2300Hz Handshake/Kissoff *
OFF	3	Enable Zone Number on Pulse Alarm
OFF	4	Single Digit Only
OFF	5	Sum Check
OFF	6	3/1 with Extended Restores
OFF	7	RESERVED
OFF	8	RESERVED

0483 CS Receiver Options - Telco 2		
Default		Option
OFF	1	1400Hz Handshake/Kissoff *
OFF	2	2300Hz Handshake/Kissoff *
OFF	3	Enable Zone Number on Pulse Alarm
OFF	4	Single Digit Only
OFF	5	Sum Check
OFF	6	3/1 with Extended Restores
OFF	7	RESERVED
OFF	8	RESERVED

0505 CS Receiver Options - Telco 3		
Default		Option
OFF	1	1400Hz Handshake/Kissoff *
OFF	2	2300Hz Handshake/Kissoff *
OFF	3	Enable Zone Number on Pulse Alarm
OFF	4	Single Digit Only
OFF	5	Sum Check
OFF	6	3/1 with Extended Restores
OFF	7	RESERVED
OFF	8	RESERVED

CS RECEIVER OPTIONS:

Select options for any of the three CS Receivers.

- 1. Select the desired option entering the option number (1-8) for each digit.
- 2. Enter corresponding option number in address location.

NOTE: Dark shaded data value box shows option not available. Press [Enter] to save.

***NOTE:** If both are selected, 1400Hz has priority over 2300Hz.

ADDRESS 0462-0481 (RIGHT DIGITS 1-20)																				
Telephone Number (Digits 1-20)	0462	0463	0464	0465	0466	0467	0468	0469	0470	0471	0472	0473	0474	0475	0476	0477	0478	0479	0480	0481
(Digits 1-20)																				

ADDRESS 0484-0503 (RIGHT DIGITS 1-20)																				
Telephone Number (Digits 1-20)	0484	0485	0486	0487	0488	0489	0490	0491	0492	0493	0494	0495	0496	0497	0498	0499	0500	0501	0502	0503
(Digits 1-20)																				

ADDRESS 0506-0525 (RIGHT DIGITS 1-20)																				
Telephone Number (Digits 1-20)	0506	0507	0508	0509	0510	0511	0512	0513	0514	0515	0516	0517	0518	0519	0520	0521	0522	0523	0524	0525
(Digits 1-20)																				

Default for CS Receiver 1 Telephone Number depends on Easy Menu Driven Program Mode question "CENTRAL PHONE #".

[Default = blank (*)] across digits 1-20 for CS Receiver Telephone Numbers 2 and 3.

CS RECEIVER TELEPHONE NUMBERS: Enter telephone numbers for any of the three CS Receivers (Telco 1, 2 & 3).

1. Enter digit only.

2. Enter up to 20 digits from left to right. **NOTE:** Leave trailing boxes blank (*). Press [Enter] to save.

3. Valid entries are: 1-9, B = [X] button, C = [#] button, D = 3 sec. pause, E = Wait for dial tone, F = Ignore location

CS SUBSCRIBER ID OPTIONS (ADDRESS 0560-0667)

CS Telco 1 Sub- scriber Opening/ Closing ID Number (Area 1)				ADDRESS 0560-0563 (RIGHT DIGITS 1-4)			
0560	0561	0562	0563				

CS Telco 1 Sub- scriber Opening/ Closing ID Number (Area 2)				ADDRESS 0564-0567 (RIGHT DIGITS 1-4)			
0564	0565	0566	0567				

CS Telco 1 Sub- scriber Opening/ Closing ID Number (Area 3)				ADDRESS 0568-0571 (RIGHT DIGITS 1-4)			
0568	0569	0570	0571				

CS Telco 1 Sub- scriber Opening/ Closing ID Number (Area 4)				ADDRESS 0572-0575 (RIGHT DIGITS 1-4)			
0572	0573	0574	0575				

CS Telco 1 Sub- scriber Event ID Number (Area 1)				ADDRESS 0576-0579 (RIGHT DIGITS 1-4)			
0576	0577	0578	0579				

CS Telco 1 Sub- scriber Event ID Number (Area 2)				ADDRESS 0580-0583 (RIGHT DIGITS 1-4)			
0580	0581	0582	0583				

CS Telco 1 Sub- scriber Event ID Number (Area 3)				ADDRESS 0584-0587 (RIGHT DIGITS 1-4)			
0584	0585	0586	0587				

CS Telco 1 Sub- scriber Event ID Number (Area 4)				ADDRESS 0588-0591 (RIGHT DIGITS 1-4)			
0588	0589	0590	0591				

CS Telco 1 Sub- scriber Event ID Number (System)				ADDRESS 0592-0595 (RIGHT DIGITS 1-4)			
0592	0593	0594	0595				

CS Telco 2 Sub- scriber Opening/ Closing ID Number (Area 1)				ADDRESS 0596-0599 (RIGHT DIGITS 1-4)			
0596	0597	0598	0599				

CS Telco 2 Sub- scriber Opening/ Closing ID Number (Area 2)				ADDRESS 0600-0603 (RIGHT DIGITS 1-4)			
0600	0601	0602	0603				

CS Telco 2 Sub- scriber Opening/ Closing ID Number (Area 3)				ADDRESS 0604-0607 (RIGHT DIGITS 1-4)			
0604	0605	0606	0607				

CS Telco 2 Sub- scriber Opening/ Closing ID Number (Area 4)				ADDRESS 0608-0611 (RIGHT DIGITS 1-4)			
0608	0609	0610	0611				

CS Telco 2 Sub- scriber Event ID Number (Area 1)				ADDRESS 0612-0615 (RIGHT DIGITS 1-4)			
0612	0613	0614	0615				

CS Telco 2 Sub- scriber Event ID Number (Area 2)				ADDRESS 0616-0619 (RIGHT DIGITS 1-4)			
0616	0617	0618	0619				

CS Telco 2 Sub- scriber Event ID Number (System)				ADDRESS 0628-0631 (RIGHT DIGITS 1-4)			
0628	0629	0630	0631				

CS Telco 3 Sub- scriber Opening/ Closing ID Number (Area 1)				ADDRESS 0632-0635 (RIGHT DIGITS 1-4)			
0632	0633	0634	0635				

CS Telco 3 Sub- scriber Opening/ Closing ID Number (Area 2)				ADDRESS 0636-0639 (RIGHT DIGITS 1-4)			
0636	0637	0638	0639				

CS Telco 3 Sub- scriber Event ID Number (System)				ADDRESS 0664-0667 (RIGHT DIGITS 1-4)			
0664	0665	0666	0667				

Default for CS Telco 1 Subscriber Event ID Number (Area 1) depends on Easy Menu Driven Program Mode question "ACCOUNT #". [Default = blank (*) blank (*) blank (*) blank (*)] for all other ID Numbers.

CS TELCO SUBSCRIBER ID NUMBERS: Enter the Subscriber Opening/Closing and Event ID Numbers for any of the 3 CS Receivers.

- 1. Enter 3 or 4 digits (depending on the CS receiver format) for each subscriber number from left to right.

NOTE: Leave trailing boxes blank (*).

- 2. Valid entries are: 1-9, 0 and B-F. **NOTE:** A is not permitted. Press [Enter] or ON/OFF to save.



CS SYSTEM REPORTING OPTIONS (ADDRESS 0670-0705)

CS SYSTEM		ADDRESS 0670-0682	
		ADDR	
Alarm Restore	blank (*)	0670	
Trouble	blank (*)	0671	
Trouble Restore	blank (*)	0672	
Xmitter Low Battery	blank (*)	0673	
Xmitter Supervision	blank (*)	0674	
Xmitter Tamper	blank (*)	0675	
RESERVED	blank (*)	0676	blank (*)
Opening	blank (*)	0677	
Closing	blank (*)	0678	
Opening after Alarm	blank (*)	0679	
Conditional Close	blank (*)	0680	
Cancel	blank (*)	0681	
Test Timer		0682	

[Default = blank (*) blank (*) from address 0670-0682]

[Default = blank (*) blank (*) from address 0683-0705]

CS SYSTEM		ADDRESS 0683-0708	
		ADDR	
Telco Fail		0683	
RF Rec. Trouble		0684	
Memory Fail		0685	
Low Battery		0686	
Panel AC Fail		0687	
EZM Tamper		0688	
Alarm Output Superv.		0689	
Ambush		0698	
Panic		0699	
Fire		0700	
Auxiliary *		0701	
Tamper		0702	
Fail to Open		0703	
Fail to Close		0704	
Keyfob Low Battery		0705	

CS SYSTEM REPORTING CODES:

1. Enter in corresponding address location (left and right digits).

NOTE: Left digit is the first digit and right digit is the second digit in a two digit CS receiver format.

2. Valid entries are: 1-9, 0 and B-F.

NOTE: A is not permitted.

3. To disable a code leave boxes blank (*).

NOTE: Dark shaded data value box shows option not available.

4. Press  to save.

* **NOTE:** Keypad Aux. is not to be selected for UL Installations.

CS AREA & SYSTEM REPORTING OPTIONS (ADDRESS 0785, 0786 & 0788)

DISABLE OPENING REPORTS	
ADDRESS 0785	
LEFT DIGIT	RIGHT DIGIT (SUM OF DATA VALUES)
blank (*)	

[Default = blank (*) blank (*)]

RIGHT DATA VALUES (CIRCLE ALL THAT APPLY)		AREA
1		AREA 1
2		AREA 2
4		AREA 3
8		AREA 4

DISABLE CLOSING REPORTS	
ADDRESS 0786	
LEFT DIGIT	RIGHT DIGIT (SUM OF DATA VALUES)
blank (*)	

[Default = blank (*) blank (*)]

RIGHT DATA VALUES (CIRCLE ALL THAT APPLY)		AREA
1		AREA 1
2		AREA 2
4		AREA 3
8		AREA 4

OPENING REPORT OPTIONS:

- ☞ 1. Select the desired option by circling the data values for each digit (left and right).
- ☞ 2. Add the data values (ex: F=15=(1+2+4+8) from the selected options. See page 13).
- ☞ 3. Enter in address location (left and right digits).

NOTE: Dark shaded data value box shows option not available. Press  to save.

0788 CS System Report Options		
Default		Option
OFF	1	Backup Report on Telco 1 & 2
OFF	2	Touch-tone Dialing Only *
OFF	3	Touch-tone Dialing w/Rotary Backup *
OFF	4	RESERVED
OFF	5	Cancel Next Test Timer on any Report
OFF	6	Disable Wait for Silence (Pager Format)
OFF	7	Disable Wait for Handshake on Transmit
OFF	8	Disable Auto Dial Tone Detect

CS SYSTEM REPORTING OPTIONS:

- ☞ 1. Select the desired option entering the option number (1-8) for each digit.
- ☞ 2. Enter corresponding option number in address location.

NOTE: Dark shaded data value box shows option not available.

- ☞ 3. Press  to save.

* **NOTE:** If neither Touch-tone Dialing nor Touch-tone w/Rotary Backup is selected, then system defaults automatically to Rotary Dialing. Leave blank (*) to select Rotary Dialing.

CS ZONE REPORTING OPTIONS (ADDRESS 0720-0783)

ADDRESS 0720-0727 CONTROL PANEL ZONES REPORT CODE							
ZONE 1	ZONE 2	ZONE 3	ZONE 4	ZONE 5	ZONE 6	ZONE 7	ZONE 8
0720	0721	0722	0723	0724	0725	0726	0727

ADDRESS 0728-0731 ZONES REPORT CODE			
ZONE 9	ZONE 10	ZONE 11	ZONE 12
0728	0729	0730	0731

ADDRESS 0732-0735 ZONES REPORT CODE			
ZONE 13	ZONE 14	ZONE 15	ZONE 16
0732	0733	0734	0735

ADDRESS 0736-0739 ZONES REPORT CODE			
ZONE 17	ZONE 18	ZONE 19	ZONE 20
0736	0737	0738	0739

ADDRESS 0740-0743 ZONES REPORT CODE			
ZONE 21	ZONE 22	ZONE 23	ZONE 24
0740	0741	0742	0743

ADDRESS 0744-0747 ZONES REPORT CODE			
ZONE 25	ZONE 26	ZONE 27	ZONE 28
0744	0745	0746	0747

ADDRESS 0748-0751 ZONES REPORT CODE			
ZONE 29	ZONE 30	ZONE 31	ZONE 32
0748	0749	0750	0751

ADDRESS 0752-0759 CONTROL PANEL ZONES REPORT CODE							
ZONE 33	ZONE 34	ZONE 35	ZONE 36	ZONE 37	ZONE 38	ZONE 39	ZONE 40
0752	0753	0754	0755	0756	0757	0758	0759

ADDRESS 0760-0763 ZONES REPORT CODE			
ZONE 41	ZONE 42	ZONE 43	ZONE 44
0760	0761	0762	0763

ADDRESS 0764-0767 ZONES REPORT CODE			
ZONE 45	ZONE 46	ZONE 47	ZONE 48
0764	0765	0766	0767

ADDRESS 0768-0771 ZONES REPORT CODE			
ZONE 49	ZONE 50	ZONE 51	ZONE 52
0768	0769	0770	0771

ADDRESS 0772-0775 ZONES REPORT CODE			
ZONE 53	ZONE 54	ZONE 55	ZONE 56
0772	0773	0774	0775

ADDRESS 0776-0779 ZONES REPORT CODE			
ZONE 57	ZONE 58	ZONE 59	ZONE 60
0776	0777	0778	0779

ADDRESS 0780-0783 ZONES REPORT CODE			
ZONE 61	ZONE 62	ZONE 63	ZONE 64
0780	0781	0782	0783

DATA ENTRIES LEFT	MODEM CODE	
	1	2
	Fire	
	Panic	
	Burglary	
	Hold up	
	Gas Alarm	
	Heat Alarm	
	Auxiliary Alarm	
	24 Hour Auxiliary	

NOTE: If "Zone Doubling" (Address 1423) is **not** enabled, then Zones 1-8 are included in the control panel and Zones 9-64 are EZM Zones. If "Zone Doubling" is enabled, then Zones 1-16 are included in the control panel and Zones 17-64 are EZM Zones. See Address 1455-1468 to enable "EZM Group Options".

PULSE EVENT CODE will be the first digit of the 2 digit reporting code. The second digit will be the second digit of the reporting zone. For example, for zone 9 (address 0728), if the right digit is "3", then the reporting code is "39". For example, for zone 15 (address 0734), if the right digit is "4", then the reporting code is "45".

MODEM CODES determine the zone types reported for the following formats: SIA and ADEMCO Point ID.

1. Select the desired Modem Code for each zone from the table shown.

2. Press **[ENTER]** to save.



CS USER REPORTING OPTIONS (ADDRESS 0800-0835)

Enable Users to Report Opening and Closings	ADDR	USERS 1 → 8								ADDR	USERS 9 → 16							
		U1	U2	U3	U4	U5	U6	U7	U8		U9	U10	U11	U12	U13	U14	U15	U16
		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8
Enable Opening Report, Telco 1	0800									0801								
Enable Closing Report, Telco 1	0809									0810								
Enable Opening Report, Telco 3	0818									0819								
Enable Closing Report, Telco 3	0827									0828								

Enable Users to Report Opening and Closings	ADDR	USERS 17 → 24								ADDR	USERS 25 → 32							
		U17	U18	U19	U20	U21	U22	U23	U24		U25	U26	U27	U28	U29	U30	U31	U32
		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8
Enable Opening Report, Telco 1	0802									0803								
Enable Closing Report, Telco 1	0811									0812								
Enable Opening Report, Telco 3	0820									0821								
Enable Closing Report, Telco 3	0829									0830								

Enable Users to Report Opening and Closings	ADDR	USERS 33 → 40								ADDR	USERS 41 → 48							
		U33	U34	U35	U36	U37	U38	U39	U40		U41	U42	U43	U44	U45	U46	U47	U48
		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8
Enable Opening Report, Telco 1	0804									0805								
Enable Closing Report, Telco 1	0813									0814								
Enable Opening Report, Telco 3	0822									0823								
Enable Closing Report, Telco 3	0831									0832								

Enable Users to Report Opening and Closings	ADDR	USERS 49 → 56								ADDR	USERS 57 → 64							
		U49	U50	U51	U52	U53	U54	U55	U56		U57	U58	U59	U60	U61	U62	U63	U64
		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8
Enable Opening Report, Telco 1	0806									0807								
Enable Closing Report, Telco 1	0815									0816								
Enable Opening Report, Telco 3	0824									0825								
Enable Closing Report, Telco 3	0833									0834								

Enable Users to Report Opening and Closings	ADDR	USERS 65 → 68								User 65 = Auto Arming/Disarming User 66 = Quickloader Remote Arming/Disarming User 67 = Easy Arming (Opening not applicable) User 68 = Keypad Arming NOTE: These opening events will report as the User Number shown. Also, Keypads 1-8 (see Easy Menu Driven Program Mode) will report as Users 57-64, respectively. Freedom Touchpads 1-4 will report opening as Users 51-54 and will report closing as Easy Arming User 67, respectively.							
		U65	U66	U67	U68												
		1	2	3	4	5	6	7	8								
Enable Opening Report, Telco 1	0808									0807							
Enable Closing Report, Telco 1	0817									0816							
Enable Opening Report, Telco 3	0826									0825							
Enable Closing Report, Telco 3	0835									0834							

CS USER REPORTING OPTIONS: [Default = blank (*) from address 0800-0835]

- 1. Select the desired option entering the option number (1-8) for each digit.
- 2. At the F-64PROG programmer, enter corresponding option number in address location. **NOTE:** Dark shaded data value box shows option not available.
- 3. Press  to save.

EZM GROUP OPTIONS (ADDRESS 1455-1468)

EZM Group 1	ADDRESS 1455

EZM Group 2	ADDRESS 1456

EZM Group 3	ADDRESS 1457

EZM Group 4	ADDRESS 1458

EZM Group 5	ADDRESS 1459

EZM Group 6	ADDRESS 1460

EZM Group 7	ADDRESS 1461

EZM Group 8	ADDRESS 1462

EZM Group 9	ADDRESS 1463

EZM Group 10	ADDRESS 1464

EZM Group 11	ADDRESS 1465

EZM Group 12	ADDRESS 1466

EZM Group 13	ADDRESS 1467

EZM Group 14	ADDRESS 1468

Default depends on Easy Menu Driven Program Mode question "# OF ZNS IN AREA 1 ENTER # ZONES" and "EZ ZONE DOUBLING? Y/N". For example, if 64 Zones are used and Zone Doubling is **not** enabled, then all 14 Groups will be automatically enabled. If 64 Zones are used and Zone Doubling is enabled, then only Groups 1-12 will be automatically enabled.

NOTE: If "Zone Doubling" (Address 1423, option 1) is **not** enabled, then Zones 1-8 are included in the control panel and Zones 9-64 (Groups 1-14) are EZM Zones. If "Zone Doubling" is enabled, then Zones 1-16 are included in the control panel and Zones 17-64 (Groups 1-12) are EZM Zones (and Groups 13 and 14 must not be used).

EZM TYPE	
DATA ENTRIES	OPTION
blank (*)	Not used (No EZM present)
1	4-Zone EZM

EZM GROUP		
	NORMAL	DOUBLED
1	9-12	17-20
2	13-16	21-24
3	17-20	25-28
4	21-24	29-32
5	25-28	33-36
6	29-32	37-40
7	33-36	41-44
8	37-40	45-48
9	41-44	49-52
10	45-48	53-56
11	49-52	57-60
12	53-56	61-64
13	57-60	
14	61-64	

EZM GROUP OPTIONS: Up to 14 Groups of 4 Zones each may be programmed depending on the number of Zones used and which EZM modules are connected. Each Group represents 4 Zones.

1. Select EZM type from the table shown.

2. Enter either blank (*) or "1" in corresponding address locations above.

NOTE: Dark shaded data value box shows option not available.

3. Press  to save.

AREA ARMING OPTIONS (ADDRESS 1469-1472)

Priority Arming Area 1	ADDRESS 1469

[Default = blank (*)]

Priority Arming Area 2	ADDRESS 1470

[Default = blank (*)]

Priority Arming Area 3	ADDRESS 1471

[Default = blank (*)]

Priority Arming Area 4	ADDRESS 1472

[Default = blank (*)]

PRIORITY ARMING/AREA 1

DATA ENTRIES	OPTION
blank (*)	Not Used
1	Enabled

PRIORITY ARMING/AREA 2

DATA ENTRIES	OPTION
blank (*)	Not Used
1	Enabled

PRIORITY ARMING/AREA 3

DATA ENTRIES	OPTION
blank (*)	Not Used
1	Enabled

PRIORITY ARMING/AREA 4

DATA ENTRIES	OPTION
blank (*)	Not Used
1	Enabled

PRIORITY AREA ARMING:

1. Select option from the table shown.

2. Enter either blank (*) or "1" in corresponding address location.

NOTE: Dark shaded data value box shows option not available.

3. Press  to save.



AREA BELL CONTROL OPTIONS (ADDRESS 1473-1488)

1473 Burglary Output Turns Off upon Disarm			
Default		Option: Disarming Area 1:	
ON	1	Area 1 Burg Output Silenced	
OFF	2	Area 2 Burg Output Silenced	
OFF	3	Area 3 Burg Output Silenced	
OFF	4	Area 4 Burg Output Silenced	

1474 Burglary Output Turns Off upon Disarm			
Default		Option: Disarming Area 2:	
ON	1	Area 1 Burg Output Silenced	
OFF	2	Area 2 Burg Output Silenced	
OFF	3	Area 3 Burg Output Silenced	
OFF	4	Area 4 Burg Output Silenced	

1475 Burglary Output Turns Off upon Disarm			
Default		Option: Disarming Area 3:	
ON	1	Area 1 Burg Output Silenced	
OFF	2	Area 2 Burg Output Silenced	
OFF	3	Area 3 Burg Output Silenced	
OFF	4	Area 4 Burg Output Silenced	

1476 Burglary Output Turns Off upon Disarm			
Default		Option: Disarming Area 4:	
ON	1	Area 1 Burg Output Silenced	
OFF	2	Area 2 Burg Output Silenced	
OFF	3	Area 3 Burg Output Silenced	
OFF	4	Area 4 Burg Output Silenced	

1477 Pulsed Burg Output Turns Off upon Disarm			
Default		Option: Disarming Area 1:	
ON	1	Area 1 Pulsed Burg Output Silenced	
OFF	2	Area 2 Pulsed Burg Output Silenced	
OFF	3	Area 3 Pulsed Burg Output Silenced	
OFF	4	Area 4 Pulsed Burg Output Silenced	

1478 Pulsed Burg Output Turns Off upon Disarm			
Default		Option: Disarming Area 2:	
ON	1	Area 1 Pulsed Burg Output Silenced	
OFF	2	Area 2 Pulsed Burg Output Silenced	
OFF	3	Area 3 Pulsed Burg Output Silenced	
OFF	4	Area 4 Pulsed Burg Output Silenced	

1479 Pulsed Burg Output Turns Off upon Disarm			
Default		Option: Disarming Area 3:	
ON	1	Area 1 Pulsed Burg Output Silenced	
OFF	2	Area 2 Pulsed Burg Output Silenced	
OFF	3	Area 3 Pulsed Burg Output Silenced	
OFF	4	Area 4 Pulsed Burg Output Silenced	

1480 Pulsed Burg Output Turns Off upon Disarm			
Default		Option: Disarming Area 4:	
ON	1	Area 1 Pulsed Burg Output Silenced	
OFF	2	Area 2 Pulsed Burg Output Silenced	
OFF	3	Area 3 Pulsed Burg Output Silenced	
OFF	4	Area 4 Pulsed Burg Output Silenced	

1481 PGM1 Output Turns Off upon Disarm			
Default		Option: Disarming Area 1:	
ON	1	Area 1 PGM1 Output Silenced	
OFF	2	Area 2 PGM1 Output Silenced	
OFF	3	Area 3 PGM1 Output Silenced	
OFF	4	Area 4 PGM1 Output Silenced	

1485 PGM2 Output Turns Off upon Disarm			
Default		Option: Disarming Area 1:	
ON	1	Area 1 PGM2 Burg Output Silenced	
OFF	2	Area 2 PGM2 Burg Output Silenced	
OFF	3	Area 3 PGM2 Burg Output Silenced	
OFF	4	Area 4 PGM2 Burg Output Silenced	

1482 PGM1 Output Turns Off upon Disarm			
Default		Option: Disarming Area 2:	
ON	1	Area 1 PGM1 Output Silenced	
OFF	2	Area 2 PGM1 Output Silenced	
OFF	3	Area 3 PGM1 Output Silenced	
OFF	4	Area 4 PGM1 Output Silenced	

1486 PGM2 Output Turns Off upon Disarm			
Default		Option: Disarming Area 2:	
ON	1	Area 1 PGM2 Burg Output Silenced	
OFF	2	Area 2 PGM2 Burg Output Silenced	
OFF	3	Area 3 PGM2 Burg Output Silenced	
OFF	4	Area 4 PGM2 Burg Output Silenced	

1483 PGM1 Output Turns Off upon Disarm			
Default		Option: Disarming Area 3:	
ON	1	Area 1 PGM1 Output Silenced	
OFF	2	Area 2 PGM1 Output Silenced	
OFF	3	Area 3 PGM1 Output Silenced	
OFF	4	Area 4 PGM1 Output Silenced	

1487 PGM2 Output Turns Off upon Disarm			
Default		Option: Disarming Area 3:	
ON	1	Area 1 PGM2 Burg Output Silenced	
OFF	2	Area 2 PGM2 Burg Output Silenced	
OFF	3	Area 3 PGM2 Burg Output Silenced	
OFF	4	Area 4 PGM2 Burg Output Silenced	

1484 PGM1 Output Turns Off upon Disarm			
Default		Option: Disarming Area 4:	
ON	1	Area 1 PGM1 Output Silenced	
OFF	2	Area 2 PGM1 Output Silenced	
OFF	3	Area 3 PGM1 Output Silenced	
OFF	4	Area 4 PGM1 Output Silenced	

1488 PGM2 Output Turns Off upon Disarm			
Default		Option: Disarming Area 4:	
ON	1	Area 1 PGM2 Burg Output Silenced	
OFF	2	Area 2 PGM2 Burg Output Silenced	
OFF	3	Area 3 PGM2 Burg Output Silenced	
OFF	4	Area 4 PGM2 Burg Output Silenced	

OUTPUT TURNS OFF UPON DISARM:
Select options for any of the 4 Outputs. By default, the ability to turn off an output upon disarm is not allowed. For example, the ability to silence an Area 1 through Area 4 output via an Area 1 keypad is not enabled by default. To enable selected area output control, enter the number (1,2,3,4) accordingly. For example, if you wish to grant an Area 1 keypad the ability to turn off an Area 2 PGM2 output, enter "2" in Address 1485.

 Enter digit in address location. **NOTE:** Dark shaded data value box shows option not available. Press  to save.

KEYPAD/TOUCHPAD OPTIONS (ADDRESS 1425-1431, 1440-1446)

Enable Keypad/Touchpad Type & Activation	ADDR	ENABLE TYPE	AREA ASSIGNMENT
		Blank (*) = Burg Keypad 2 = Wizard *	Blank (*) = Disabled 1 = Area 1, 2 = Area 2, 3 = Area 3, 4 = Area 4
Keypad/Touchpad 1	1425		1
Keypad/Touchpad 2	1426		
Keypad/Touchpad 3	1427		
Keypad/Touchpad 4	1428		
Keypad/Touchpad 5	1429		
Keypad/Touchpad 6	1430		
Keypad/Touchpad 7	1431		

[Default = 1 for address 1425; blank (*) from address 1426-1431]

ENABLE TYPE: Up to 7 keypads/Touchpads may be programmed, if they are connected.

NOTE: See Touchpad Configuration Mode (see page 40).

1. Select keypad/Touchpad type for each keypad from the tables shown.
2. Enter data in corresponding address locations.
3. Press  to save.

Enable Keypad Options	ADDR	Enable Keypad Options							
		Keypad Fire	Keypad Aux.*	Keypad Panic	RSRVD	Ambush	Easy Arming	Panel Access	RSRVD
		1	2	3	4	5	6	7	8
Keypad 1 Options	1440	ON		ON			ON		
Keypad 2 Options	1441	ON		ON			ON		
Keypad 3 Options	1442	ON		ON			ON		
Keypad 4 Options	1443	ON		ON			ON		
Keypad 5 Options	1444								
Keypad 6 Options	1445								
Keypad 7 Options	1446								

[Default = blank (*) from address 1440-1446, except where specified in table above] * NOTE: Keypad Aux. is not to be selected for UL Installations.

ENABLE KEYPAD OPTIONS: Select options for any of the 7 keypads.

- ☞ 1. Select the desired option entering the option number (1-8) for each digit.
- ☞ 2. At the F-64PROG programmer, enter corresponding option number in address location. **NOTE:** Dark shaded data value box shows option not available. Press  to save.

MAPPING F-64TP DOORS AND PIR'S (ADDRESS 2090-2101)

Keypad address programming locations for mapping F-64TP Doors and PIR's to the F-64 control panel are displayed in the table at right:

In addition, in order for the F-64TP to function correctly on the F-64 panel, the following programming / installation rules are required:

1. A F-64TP must be wired and addressed as Keypad #1 for any F-64 Touchpads to work on the system.
2. Must program (map) at least 1 Door Zone and a PIR for each F-64 Touchpad.
3. All PIR's in the system, including the mapped Integral F-64 Touchpad PIR, must be programmed as interior to allow conversion from arming Stay to Away.
4. All zones programmed for interior must also be programmed for Auto Bypass.

5. Exit Delay time must first be programmed to allow conversion from arming Stay to Away.

- ☞ 1. Select the desired zone by entering the zone number (001-064) for each address.
- ☞ 2. At the F-64PROG Programmer, enter corresponding zone number in address location. Press  to save.

Enable Keypad Options		
MAPPING F-64TP Doors and PIR's	ADDR	Zone # (1-64)
Zone # of F64TP # 1 Door/Bolt TX #1	2090	9
Zone # of F64TP # 1 Door/Bolt TX #2	2091	10
Zone # of F64TP # 1 PIR	2092	11
Zone # of F64TP # 2 Door/Bolt TX #1	2093	
Zone # of F64TP # 2 Door/Bolt TX #2	2094	
Zone # of F64TP # 2 PIR \	2095	
Zone # of F64TP # 3 Door/Bolt TX #1	2096	
Zone # of F64TP # 3 Door/Bolt TX #2	2097	
Zone # of F64TP # 3 PIR	2098	
Zone # of F64TP # 4 Door/Bolt TX #1	2099	
Zone # of F64TP # 4 Door/Bolt TX #2	2100	
Zone # of F64TP # 4 PIR	2101	

[Default = blank (*) from address 2090-2101]



ZONE OPTIONS - ZONES 1 TO 16 (ADDRESS 0900-1016)

ZONE OPTIONS	ADDR	ZONES 1 → 8								ADDR	ZONES 9 → 16							
		Z1 1	Z2 2	Z3 3	Z4 4	Z5 5	Z6 6	Z7 7	Z8 8		Z9 1	Z10 2	Z11 3	Z12 4	Z13 5	Z14 6	Z15 7	Z16 8
50ms Loop Response ^(A)	0900									0964								
+→ Priority	0901									0965								
Priority with Bypass	0902									0966								
Auto-Bypass	0903									0967								
+→ Selective Bypass	0904									0968								
Keypad Arming	0905									0969								
Auto-Bypass Re-entry	0906									0970								
Pre-Alarm Warning	0907									0971								
Never Arm	0908									0972								
24-Hour Zone	0909									0973								
+→ Alarm Output	0910									0974								
+ Pulsed Alarm Output	0911									0975								
PGM1 Output	0912									0976								
PGM2 Output	0913									0977								
+ Entry/Exit 1	0914									0978								
+ Entry/Exit 2	0915									0979								
+ Exit/Entry Follower	0916									0980								
+★ Auto Reset	0917									0981								
+★ Swinger Shutdown	0918									0982								
+ Chime	0919									0983								
Abort Delay	0920									0984								
Power-up Delay	0921									0985								
Day Zone Open	0922									0986								
Day Zone Short	0923									0987								
+ Alarm on Day Zone	0924									0988								
Alarm Telco 1	0925									0989								
Alarm Restore 1	0926									0990								
Trouble Telco 1	0927									0991								
Trouble Restore 1	0928									0992								
Alarm Telco 3	0929									0993								
Alarm Restore 3	0930									0994								
Trouble Telco 3	0931									0995								
Trouble Restore 3	0932									0996								
No EOL Resistor	0933									0997								
Trouble on Open	0934									0998								
Trouble on Short	0935									0999								
+ Zone Area 1	0936									1000								
Zone Area 2	0937									1001								
Zone Area 3	0938									1002								
Zone Area 4	0939									1003								
Interior (Stay) Bypass	0940									1004								
+ Keypad Sounder on Alarm	0941									1005								
+ 2-Wire Smoke Detectors ^(B)	0942									1006								
+ Fire ^(C)	0943									1007								
Fire Alarm Verification ^(C)	0944									1008								
RESERVED	0945									1009								
Zone ANDing Group 1	0946									1010								
Zone ANDing Group 2	0947									1011								
Zone ANDing Group 3	0948									1012								
Zone ANDing Group 4	0949									1013								
Sensor Watch	0950									1014								
RESERVED	0951									1015								
Chime 2	0952									1016								
RESERVED	0953									1017								
Perimeter Group Bypass	0954									1018								

^(A) When the Easy Menu Driven Program Mode is used, these features are enabled by default.

^(B) Enabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu).

^(C) Disabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu). Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

ZONE OPTIONS: Select zone options for any zone.

- ☞ 1. Select the desired zone option by entering the option number (1-8) for each selected zone.
- ☞ 2. Enter corresponding option number in address location.

NOTE: Dark shaded data value box shows option not available. Press [Enter] to save.

Notes A, B and C are located on the bottom of the next page.

ZONE OPTIONS - ZONES 17 TO 32 (ADDRESS 1029-1144)

ZONE FEATURES	ADDR	ZONES 17 → 24								ADDR	ZONES 25 → 32							
		Z17 1	Z18 2	Z19 3	Z20 4	Z21 5	Z22 6	Z23 7	Z24 8		Z25 1	Z26 2	Z27 3	Z28 4	Z29 5	Z30 6	Z31 7	Z32 8
†◆ Priority	1029									1093								
Priority with Bypass	1030									1094								
Auto-Bypass	1031									1095								
†◆ Selective Bypass	1032									1096								
Keypad Arming	1033									1097								
Auto-Bypass Re-entry	1034									1098								
Pre-Alarm Warning	1035									1099								
Never Arm	1036									1100								
24-Hour Zone	1037									1101								
†◆ Alarm Output	1038									1102								
† Pulsed Alarm Output	1039									1103								
PGM1 Output	1040									1104								
PGM2 Output	1041									1105								
† Entry/Exit 1	1042									1106								
Entry/Exit 2	1043									1107								
† Exit/Entry Follower	1044									1108								
†★ Auto Reset	1045									1109								
†★ Swinger Shutdown	1046									1110								
† Chime	1047									1111								
Abort Delay	1048									1112								
Power-up Delay	1049									1113								
Day Zone Open	1050									1114								
Day Zone Short	1051									1115								
Alarm on Day Zone	1052									1116								
† Alarm Telco 1	1053									1117								
Alarm Restore 1	1054									1118								
Trouble Telco 1	1055									1119								
Trouble Restore 1	1056									1120								
Alarm Telco 3	1057									1121								
Alarm Restore 3	1058									1122								
Trouble Telco 3	1059									1123								
Trouble Restore 3	1060									1124								
No EOL Resistor	1061									1125								
Trouble on Open	1062									1126								
Trouble on Short	1063									1127								
† Zone Area 1	1064									1128								
Zone Area 2	1065									1129								
Zone Area 3	1066									1130								
Zone Area 4	1067									1131								
Interior (Stay) Bypass	1068									1132								
Keypad Sounder on Alarm	1069									1133								
† Fire (C)	1071									1135								
Fire Alarm Verification (C)	1072									1136								
Zone ANDing Group 1	1074									1138								
Zone ANDing Group 2	1075									1139								
Zone ANDing Group 3	1076									1140								
Zone ANDing Group 4	1077									1141								
Sensor Watch	1078									1142								
RESERVED	1079									1143								
Chime 2	1080									1144								
RESERVED	1081									1145								
Perimeter Group Bypass	1082									1146								

† When the Easy Menu Driven Program Mode is used, these features are enabled by default.

◆ Enabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu).

★ Disabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu). Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

NOTES: (A) 50ms Loop Response only available for zones 1-8. If Zone Doubling is enabled, Zones 9-16 will follow the loop response programming for Zones 1-8. For all other Zones, loop response is determined by jumpers on the GEM-EZM8 and/or the configuration on the F-64PROG.
(B) 2-wire Smoke Detectors only available for zones 7 & 8, and Fire must also be selected.
(C) If Fire Alarm Verification is selected, then Fire must also be selected.

DEFAULTS: The zone options indicated are automatically set after exiting the Easy Menu Driven Program Mode.

- Priority, Selective Bypass, Alarm Output, Auto Reset, Swinger Shutdown and Zone Area 1 are enabled for the total number of zones entered in "# OF ZONES IN AREA ENTER # ZONES".
- Alarm Telco 1 is enabled for the zone number(s) entered in "REPORT ALL ZONES TO CENTRAL ZONE(S) 1/N".
- Entry/Exit 1 and Chime are enabled for the zone number(s) entered in "ENTR/EXIT ZONES ENTER ZONE #".
- Exit/Entry Follower and Interior Bypass are enabled for the zone number(s) entered in "INTERIOR ZONES ENTER ZONE #".
- Pulse Alarm Output is enabled for the zone number(s) entered in "FIRE ZONES ENTER ZONE #" or "2-WIRE FIRE ZNS ENTER ZONE #".
- Fire is enabled for the zone number(s) entered in "FIRE ZONES ENTER ZONE #".
- 2-Wire Smoke Detector is enabled for the zone number(s) entered in "2-WIRE FIRE ZNS ENTER ZONE #".



ZONE OPTIONS - ZONES 33 TO 48 (ADDRESS 1157-1272)

ZONE OPTIONS	ADDR	ZONES 33 → 40								ADDR	ZONES 41 → 48							
		Z33 1	Z34 2	Z35 3	Z36 4	Z37 5	Z38 6	Z39 7	Z40 8		Z41 1	Z42 2	Z43 3	Z44 4	Z45 5	Z46 6	Z47 7	Z48 8
50ms Loop Response ^(A)																		
+♦ Priority	1157									1221								
Priority with Bypass	1158									1222								
Auto-Bypass	1159									1223								
+♦ Selective Bypass	1160									1224								
Keypad Arming	1161									1225								
Auto-Bypass Re-entry	1162									1226								
Pre-Alarm Warning	1163									1227								
Never Arm	1164									1228								
24-Hour Zone	1165									1229								
+♦ Alarm Output	1166									1230								
+ Pulsed Alarm Output	1167									1231								
PGM1 Output	1168									1232								
PGM2 Output	1169									1233								
+ Entry/Exit 1	1170									1234								
+ Entry/Exit 2	1171									1235								
+ Exit/Entry Follower	1172									1236								
+★ Auto Reset	1173									1237								
+★ Swinger Shutdown	1174									1238								
+ Chime	1175									1239								
Abort Delay	1176									1240								
Power-up Delay	1177									1241								
Day Zone Open	1178									1242								
Day Zone Short	1179									1243								
Alarm on Day Zone	1180									1244								
+ Alarm Telco 1	1181									1245								
Alarm Restore 1	1182									1246								
Trouble Telco 1	1183									1247								
Trouble Restore 1	1184									1248								
Alarm Telco 3	1185									1249								
Alarm Restore 3	1186									1250								
Trouble Telco 3	1187									1251								
Trouble Restore 3	1188									1252								
No EOL Resistor	1189									1253								
Trouble on Open	1190									1254								
Trouble on Short	1191									1255								
+ Zone Area 1	1192									1256								
Zone Area 2	1193									1257								
Zone Area 3	1194									1258								
Zone Area 4	1195									1259								
Interior (Stay) Bypass	1196									1260								
Keypad Sounder on Alarm	1197									1261								
+ 2-Wire Smoke Detectors ^(B)	1198									1262								
+ Fire ^(C)	1199									1263								
Fire Alarm Verification ^(C)	1200									1264								
RESERVED	1201									1265								
Zone ANDing Group 1	1202									1266								
Zone ANDing Group 2	1203									1267								
Zone ANDing Group 3	1204									1268								
Zone ANDing Group 4	1205									1269								
Sensor Watch	1206									1270								
RESERVED	1207									1271								
Chime 2	1208									1272								
RESERVED	1209									1273								
Perimeter Group Bypass	1210									1274								

[†] When the Easy Menu Driven Program Mode is used, these features are enabled by default.

[♦] Enabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu).

[★] Disabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu). Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

ZONE OPTIONS: Select zone options for any zone.

- 1. Select the desired zone option by entering the option number (1-8) for each selected zone.
- 2. Enter corresponding option number in address location.

NOTE: Dark shaded data value box shows option not available. Press [Enter] to save.

ZONE OPTIONS - ZONES 49 TO 64 (ADDRESS 1285-1400)

ZONE FEATURES	ADDR	ZONES 49 → 56								ADDR	ZONES 57 → 64							
		Z49 1	Z50 2	Z51 3	Z52 4	Z53 5	Z54 6	Z55 7	Z56 8		Z57 1	Z58 2	Z59 3	Z60 4	Z61 5	Z62 6	Z63 7	Z64 8
†♦ Priority	1285									1349								
Priority with Bypass	1286									1350								
Auto-Bypass	1287									1351								
†♦ Selective Bypass	1288									1352								
Keypad Arming	1289									1353								
Auto-Bypass Re-entry	1290									1354								
Pre-Alarm Warning	1291									1355								
Never Arm	1292									1356								
24-Hour Zone	1293									1357								
†♦ Alarm Output	1294									1358								
† Pulsed Alarm Output	1295									1359								
PGM1 Output	1296									1360								
PGM2 Output	1297									1361								
† Entry/Exit 1	1298									1362								
Entry/Exit 2	1299									1363								
† Exit/Entry Follower	1300									1364								
†★ Auto Reset	1301									1365								
†★ Swinger Shutdown	1302									1366								
† Chime	1303									1367								
Abort Delay	1304									1368								
Power-up Delay	1305									1369								
Day Zone Open	1306									1370								
Day Zone Short	1307									1371								
† Alarm on Day Zone	1308									1372								
† Alarm Telco 1	1309									1373								
Alarm Restore 1	1310									1374								
Trouble Telco 1	1311									1375								
Trouble Restore 1	1312									1376								
Alarm Telco 3	1313									1377								
Alarm Restore 3	1314									1378								
Trouble Telco 3	1315									1379								
Trouble Restore 3	1316									1380								
No EOL Resistor	1317									1381								
Trouble on Open	1318									1382								
Trouble on Short	1319									1383								
† Zone Area 1	1320									1384								
Zone Area 2	1321									1385								
Zone Area 3	1322									1386								
Zone Area 4	1323									1387								
Interior (Stay) Bypass	1324									1388								
Keypad Sounder on Alarm	1325									1389								
† Fire (C)	1327									1391								
Fire Alarm Verification (C)	1328									1392								
Zone ANDing Group 1	1330									1394								
Zone ANDing Group 2	1331									1395								
Zone ANDing Group 3	1332									1396								
Zone ANDing Group 4	1333									1397								
Sensor Watch	1334									1398								
RESERVED	1335									1399								
Chime 2	1336									1400								
RESERVED	1337									1401								
Perimeter Group Bypass	1338									1402								

† When the Easy Menu Driven Program Mode is used, these features are enabled by default.

♦ Enabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu).

★ Disabled when "Enable SIA CP-01 Features?" is activated (Answer "Yes" in the EZ Programming Menu). Disable Auto-Reset on non-fire zones for SIA CP-01 installations.

NOTES: (A) 50ms Loop Response only available for zones 1-8. If Zone Doubling is enabled, Zones 9-16 will follow the loop response programming for Zones 1-8. For all other Zones, loop response is determined by jumpers on the GEM-EZM8 and/or the configuration on the F-64PROG.

(B) 2-wire Smoke Detectors only available for zones 7 & 8, and Fire must also be selected.

(C) If Fire Alarm Verification is selected, then Fire must also be selected.

DEFAULTS: The zone options indicated are automatically set after exiting the Easy Menu Driven Program Mode.

Priority, Selective Bypass, Alarm Output, Auto Reset, Swinger Shutdown and Zone Area 1 are enabled for the total number of zones entered in "# OF ZONES IN AREA ENTER # ZONES".

Alarm Telco 1 is enabled for the zone number(s) entered in "REPORT ALL ZONES TO CENTRAL ZONE(S) Y/N".

Entry/Exit 1 and Chime are enabled for the zone number(s) entered in "ENTRY/EXIT ZONES ENTER ZONE #".

Exit/Entry Follower and Interior Bypass are enabled for the zone number(s) entered in "INTERIOR ZONES ENTER ZONE #".

Pulse Alarm Output is enabled for the zone number(s) entered in "FIRE ZONES ENTER ZONE #" or "2-WIRE FIRE ZNS ENTER ZONE #".

Fire is enabled for the zone number(s) entered in "FIRE ZONES ENTER ZONE #".

2-Wire Smoke Detector is enabled for the zone number(s) entered in "2-WIRE FIRE ZNS ENTER ZONE #".



EXTERNAL RELAY CONTROL (ADDRESS 1489-1648)

ADDRESS 1489-1493 (RELAY EVENT 1)				
1489	1490	1491	1492	1493
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1494-1498 (RELAY EVENT 2)				
1494	1495	1496	1497	1498
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1499-1503 (RELAY EVENT 3)				
1499	1500	1501	1502	1503
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1504-1508 (RELAY EVENT 4)				
1504	1505	1506	1507	1508
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1509-1513 (RELAY EVENT 5)				
1509	1510	1511	1512	1513
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1514-1518 (RELAY EVENT 6)				
1514	1515	1516	1517	1518
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1519-1523 (RELAY EVENT 7)				
1519	1520	1521	1522	1523
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1524-1528 (RELAY EVENT 8)				
1524	1525	1526	1527	1528
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1529-1533 (RELAY EVENT 9)				
1529	1530	1531	1532	1533
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1534-1538 (RELAY EVENT 10)				
1534	1535	1536	1537	1538
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1539-1543 (RELAY EVENT 11)				
1539	1540	1541	1542	1543
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1544-1548 (RELAY EVENT 12)				
1544	1545	1546	1547	1548
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1549-1553 (RELAY EVENT 13)				
1549	1550	1551	1552	1553
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1554-1558 (RELAY EVENT 14)				
1554	1555	1556	1557	1558
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1559-1563 (RELAY EVENT 15)				
1559	1560	1561	1562	1563
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1564-1568 (RELAY EVENT 16)				
1564	1565	1566	1567	1568
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1569-1573 (RELAY EVENT 17)				
1569	1570	1571	1572	1573
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1574-1578 (RELAY EVENT 18)				
1574	1575	1576	1577	1578
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1594-1598 (RELAY EVENT 22)				
1594	1595	1596	1597	1598
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1599-1603 (RELAY EVENT 23)				
1599	1600	1601	1602	1603
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1604-1608 (RELAY EVENT 24)				
1604	1605	1606	1607	1608
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1609-1613 (RELAY EVENT 25)				
1609	1610	1611	1612	1613
RELAY #	AREA	TIMEOUT	EVENT ID	COND.

ADDRESS 1614-1618 (RELAY EVENT 26)				
1614	1615			

To program, follow the 5 steps below.

RELAY EVENT OPTIONS				
RELAY #	AREA	TIMEOUT	EVENT ID	COND.
See Step 1 below	See Step 2 below	See Step 3 below	See Step 4 below	See Step 5 below

STEP 1

RELAY # OPTIONS: The F-64 supports 16 external relays from Relay Module RM3008. Multiple events may be "mapped" to each relay, up to a maximum of 32 events.

- ☞ Select the **relay number** from **Table 1** (next page); enter in corresponding address location.

STEP 2

AREA OPTIONS: Each relay event can be assigned to Area 1, 2, 3 and / or 4.

- ☞ Select the **area** from **Table 2** (on next page); enter in corresponding address location.

STEP 3

TIMEOUTS: Each relay event can be assigned a timeout depending on Alarm Type option.

- ☞ If Alarm Type is selected for timeout in minutes or seconds, enter the 3-digit **timeout duration** in corresponding address location. To choose seconds or minutes, see step 5A below. 254 is maximum entry.

STEP 4

EVENT ID CODES: Each relay event can be assigned any of the available event IDs from **Table 4**.

- ☞ Select 2-digit **Event ID** from **Table 4** (on next page); enter in corresponding address locations (left and right digit).


STEP 5

RELAY EVENT CONDITION OPTIONS: Each relay event can be assigned an alarm type; and an activation condition; also, select a timeout type for each. Enter 5A in left area, enter 5B in right area.

- ☞ 5A. Select **Alarm Type** and **Timeout Type** from **Table 5A** (on next page); enter in corresponding left address location.
- ☞ 5B. Select **Activation Conditions** from **Table 5B** (on next page); enter in corresponding right address location.

Continued 





RF RECEIVER & SUPERVISORY TIMER OPTIONS (ADDRESS 2029-2044 & 2056)

Number of RF Receivers	ADDRESS 2056	
	LEFT DIGIT	RIGHT DIGIT
	blank (*)	

Default for Number of Receivers depends on Easy Menu Driven Program Mode question for RF Transmitters.

DATA ENTRIES	RF RECEIVER(S)
blank (*)	None
1	1
2	2

RF RECEIVERS: Up to 2 RF Receivers may be programmed.

1. Select the number of receivers from the table shown.

2. Enter number in address location shown.

3. Press  to save.

RF SUPERVISORY TIMERS: RF Supervisory Timers may be programmed for each type of transmitter used. A transmitter will send a transmission every time it is tripped, when there is NO activity, the transmitter sends a status transmission about once an hour. If the receiver does NOT receive ANY signal (a trip or a status) from a transmitter in the time specified for transmitter type, a system trouble "WIRELESS TROUBLE/E04-NM SERVICE" will be displayed at the F-64PROG programmer.

1. Select timer delay from the table shown. Timers are programmed in increments of 30 minutes each. Valid entries are [3] through [F] (90 minutes-450 minutes).

2. Enter in corresponding address locations below (right nibble).

3. Press  to save.

RF SUPERVISORY TIMER	RF TRANSMITTER	ADDR	RF SUPERVISORY DELAY TIME (Select timer delay from the table at right)
Type 0	Window/Door, 2 Pt.	2029	
Type 1	Window/Door, 2 Pt.	2030	
Type 2	Window/Door, 2 Pt.	2031	
Type 3	Window/Door, 2 Pt.	2032	
Type 4	RESERVED		
Type 5	PIR	2034	
Type 6	PIR	2035	
Type 7	Smoke Detector	2036	
Type 8	Smoke Detector	2037	
Type 9	RESERVED		
Type A	Dual Tech.	2039	
Type B	RESERVED		
Type C	Window/Door, 4 Pt.	2041	
Type D	PIR	2042	
Type E	Smoke Detector	2043	
Type F	Napco Glass Break	2044	

RF SUPERVISORY TIMERS	
DATA ENTRIES	DELAY
3	90 min.
4	120 min.
5	150 min.
6	180 min.
7	210 min.
8	240 min.
9	270 min.
0	300 min.
B	330 min.
C	360 min.
D	390 min.
E	420 min.
F	450 min.

[Default = blank (*) from address 2029-2044]. Default = 8 (240 minutes)

NOTE: These timers apply only to Supervised RF Transmitters (see "RF Transmitters" in Easy Menu Driven Program Mode).



CLEAR PROGRAM OPTIONS (ADDRESS 2285 & 2286)

2285 XX

H

Clear Dealer Program (Erases Dealer Program)

This erases *the dealer program*. Use this feature to start a customized default program. Program Data and System Status Memory is erased where Scheduled Data and Zone Descriptions are maintained.

Access address 2285, then press . Data entry is not allowed.

NOTE: Enter Easy Menu Driven Program Mode to program system again.

2286 XX

H

***Cold Start (Erases Entire Program)***

This erases the entire program including Dealer Program by erasing Program Data, Zone Description Data and System Status Data (similar to a new panel).

Access address 2286, then press . Data entry is not allowed.

NOTE: Some features (schedules) can only be programmed again with the Downloading Software. If power fails, time and date restarts at 00:00:00 and a date of 01-01-04 (January 1, 2004).

DEALER PROGRAM MODE OVERVIEW

EASY MENU DRIVEN PROGRAM MODE	
#of Zns in Area1*	
EZ Zone Doubling Enabled?*	
Fire Zones*	
2-Wire Fire Zns*	
Report All ZonesTo Central?*	
Exit/Entry Zones*	
Interior Zones*	
24 Hour Zones*	
Chime Zones*	
Chime 2 Zones*	
Exit/Entry 2 Zones*	
50mS Loop Zones*	
Aux Output Zones*	
Sensor Watch Zns*	
KP Sndr Alrm Zns*	
Auto Byp REnt Zn	
Enable No EOLR Zones*	
Enable Telco Line Test?*	
Enable Burg Out Chirp?*	
Enable CP01 Programming?*	
# Area 1 Keypads	
Prog a Freedom KP?	
Enter Freedom KeyPad #	
Enter KeyPad PIR Zone #	
Enter Door1 Zone #	
Enter Door2 Zone #	
Chime 1 Zone #	
Chime 2 Zone #	
Aux2 Zone #	
Add Another Freedom Touch-Pad?	
Central Phone #	
Central Station Account #	
See WI for Info Rcvr Format	
Enter user code	
ZN# XMIT#+CS P	
KF A XMIT#+CS OP	
01 (ZONE DESCRIPTIONS)	
Enter Date	
Enter Time	
Dealer Code	
Test Timer	

Dealer Program Mode comprises two operational states:

- **EASY MENU DRIVEN PROGRAM MODE** - Used with new "out of the box" panels (or "Cold Started" panels, see address 2286), this mode allows the dealer to customize the factory panel program to best suit the installation. The **Easy Menu-Driven Program Mode** is a menu-driven utility that prompts the installer to configure the system. Press **RESET** at any time to exit, thus entering **Direct Address Program Mode**, detailed below.
- **DIRECT ADDRESS PROGRAM MODE** - Additional programming changes, if necessary, can be made in the **Direct Address Program Mode**. In this mode, the programming address is accessed directly and re-configured by the installer. For more information, see "DEALER PROGRAM - PRELIMINARY INFORMATION" on page 5.


TYPICAL USER: Dealers / Installers only.

TYPICAL INTERFACE: An F-64PROG programmer.

HOW TO ENTER: Press the factory-installed default Dealer Code:

4 5 6 7F 8A 9P MENU. Press AWAY ("NO") until "ACTIVATE PROGRAM Y/N" appears on LCD screen. Press STAY ("YES") to enter the **Easy Menu-Driven Program Mode**. See Programming Instructions (WI1502) for additional information regarding the **Easy Menu Driven Program Mode**.

To exit, press **RESET** to enter **Direct Address Program Mode** and press **RESET** once again to exit **Dealer Program Mode**.



* Initial Configuration Only (new or memory cleared panel); suppressed thereafter. Normal entry mode for previously programmed panel starts at "# AREA 1 KEYPADS".



TOUCHPAD CONFIGURATION MODE

This section will focus on configuring the Freedom 64 Touchpad.

TOUCHPAD INSTALLATION

See WI1499 for complete Freedom F-64TP, F-LTRANS and F-TAB installation instructions (see list below for the instructions of other Touchpad types). Each Touchpad must be assigned an address number (1-7). Each Touchpad requires its own configuration procedure because all Touchpad Configuration Mode changes are retained within each individual Touchpad only (see **CONFIGURING THE TOUCHPADS**, below). At least one (1) Touchpad must be used; only one is required for a single-area Commercial Burglary installation. The F-64TP Touchpad is one of four Touchpad designs within the NAPCO Freedom 64 Home Protection System. The three other Touchpad designs include:

- **F-64TPG:** Garage Door Touchpad (See WI1508)
- **F-64TPBR:** Bedroom Touchpad (See WI1505)
- **F-64TP-H:** Hardwired Touchpad (See WI1518)

CONFIGURING THE TOUCHPADS


Touchpad Configuration Mode provides an exclusive set of menu options used to change the properties of each individual Touchpad to suit each installation.

- **TYPICAL USER:** Dealers and installers only.
- **TYPICAL INTERFACE:** Touchpad only.

Each **Freedom Touchpad** must be configured for the following items: *Keypad Beep, Entry Sounder, Backlight Follow PIR, Backlight Brightness, Ambush Interval, Ambush Sounder, Keypad Address, EZM Address, Zone Response, Tamper Detect, Disable PIR, Pre Away/Stay, Learn Primary, Learn Secondary (transmitters), Clear All Learned Transmitters, Display RF Strength and Display RF Noise.*

To enter the Touchpad Configuration Mode:

1. Move jumper JP1 (located in the center of the F-64 control panel board) from pins 1-2 (top two "NORMAL") to pins 2-3 (bottom two "KEYPAD CONFIGURE"). **NOTE:** See wiring diagram at the end of this manual and the jumper configuration diagram at right.
2. Press the **STAY, BYPASS** and **YES** buttons simultaneously. After a short delay, the display will read "OUT OF SYSTEM XX", where "XX" indicates the keypad address.
3. Press **MENU** for 2 seconds on the installed Touchpad to enter **Touchpad Configuration Mode** and proceed as follows. (Repeat the following procedure for all Touchpads in the system).



Once the **Touchpad Configuration Mode** is accessed, all messages will display in the order shown below.

KEYPAD BEEP	YES
-------------	-----

Keypad Tactile Beep

Upon entering the Touchpad Configuration Mode, "KEYPAD BEEP YES" is displayed, indicating that the tactile beep, which sounds when any button is pressed, is on. To turn off the tactile beep, press the **NO** button; to turn on the tactile beep, press **YES**. Default is beep "ON". Press **MENU** to continue or press **RESET** to exit.

ENTRY SOUNDER	YES
---------------	-----

Entry Sounder

To turn off the Touchpad entry sounder during entry time, press the **NO** button; to turn on the entry sounder, press **YES**. Default is sounder "ON". Press **MENU** to continue or press **RESET** to exit.

BACKLIGHT FOLLOW PIR	YES
----------------------	-----

Backlight Follow PIR

Turns Touchpad backlight on when person is detected in front of the Touchpad (default). To turn off this backlight, press **NO**; to turn on the backlight, press **YES**. . Default is "ON". Press **MENU** to continue or press **RESET** to exit.

BACKLIGHT BRIGHTNESS	LOW
----------------------	-----

Backlight Brightness

To adjust the brightness of the LCD window, press **YES** to increase and **NO** to decrease. Selections are **LOW**, **MED** and **HIGH**. **Note:** Selections repeat if either the **YES** or **NO** buttons are pressed repeatedly. Default is "LOW". Press **MENU** to continue or press **RESET** to exit.

AMBUSH INTERVAL	000
--------------------	-----

Ambush Interval

Set the time interval (in seconds) during entry delay to simulate a need for a user to press **RESET** for two (2) seconds to silence sounder and send an Ambush signal. Press **ENTER** to move cursor to the left (press repeatedly to loop back), then press **YES** or **NO** to increment or decrement each digit. Default is "000" (not set). Also see next selection, *Ambush Sounder*. To enable Ambush, see address 1422 and 2045 in programming instructions (WI1502). Press **MENU** to continue or press **RESET** to exit.

AMBUSH SOUNDER	NO
-------------------	----

Ambush Sounder

Optional Touchpad sounder during entry delay to simulate a need for a user to press **RESET** for 2 seconds to silence sounder and send AMBUSH signal. During this time interval the Touchpad will beep. To turn off the sounder, press the **NO** button; to turn on the sounder, press **YES**. Default is "OFF". To enable AMBUSH, see address 1422 and 2045 in programming instructions (WI1502). Press **MENU** to continue or press **RESET** to exit.

KEYPAD ADDRESS	1
----------------	---

Keypad Address

If more than one Touchpad is installed, each must be assigned a unique Touchpad address--that is, no two Touchpads may be numbered alike. Touchpads must be numbered consecutively (missing numbers are not permitted).

To assign the Touchpad number, proceed as follows:

1. Press **YES** to increase and **NO** to decrease the assigned Touchpad number (valid entries are 1–7). **Note:** Default entry is "1". An entry of zero disables the Touchpad.
2. Press **MENU** to continue or press **RESET** to exit.

EZM ADDRESS	00
-------------	----

EZM Address

The Touchpad's internal EZM (Expansion Zone Module) may be utilized to provide four additional wired zones. Whether used alone or in conjunction with optional GEM-EZM series modules or other Touchpad EZMs, it must be assigned a unique address (or Group number) similar to its Touchpad address. If no other EZMs are to be used, designate the Touchpad as Group "01" at the "EZM ADDRESS 00" display. In multiple-EZM systems, enter an assigned group number "01" through "14". Each EZM must have a unique assigned Group number, starting with "01" and proceeding consecutively. Default is "00". Press **MENU** to continue or press **RESET** to exit.

ZONE RESPONSE	00
---------------	----

Zone Response

The normal (default) loop response of each Touchpad EZM expansion zone is 750mS. Changing this response time may be required when some devices require a faster loop response, such as *Glass Break* sensors, and thus 50ms can be programmed. Do not program in UL installations (UL requires 750ms be programmed). The response time of any zone can be reduced to 50mS as follows.

1. Of the following, circle the number(s) in parentheses associated with the zone(s) to be changed: Zone 1=(1); Zone 2=(2); Zone 3=(4); Zone 4=(8).
2. Add up the circled numbers.
3. At the Touchpad, enter the sum as a two-digit number "01" through "15" by pressing **YES** to increase and **NO** to decrease each digit. **Note:** Default entry is "00". Press **MENU** to continue or press **RESET** to exit.

Example: Change Zones 2, 3 and 4 to 50mS response.

1. Circle numbers for Zones 2, 3 and 4: Circle (2), circle (4) and circle (8).
2. Add up the circled numbers: $2 + 4 + 8 = 14$.
3. Enter "14" at the Touchpad. Press **MENU** to continue or press **RESET** to exit.

TAMPER DETECT	NO
---------------	----

Tamper Detect

Enable or disable the monitoring of the Tamper switch located on the Touchpad circuit board. The tamper monitors both the front Touchpad case and the rear Touchpad mounting surface. If the front case is opened or if the Touchpad is removed from the wall, the tamper switch is activated (displays Keypad Tamper system trouble "E11-XX", where XX is the address of the keypad detected by the panel). To disable the Tamper switch, press the **NO** button; to enable, press **YES**. Default is "NO" (disabled). Press **MENU** to continue or press **RESET** to exit.



DISABLE PIR

NO

Disable PIR

If **YES** is pressed, will disable the PIR as an intrusion detection device. Press **NO** to enable PIR. Default is "NO" (enabled). Press **MENU** to continue or press **RESET** to exit.

PRE-AWAY/STAY

060

Pre-AWAY / STAY

The **Pre-AWAY / STAY** period is the amount of time that the user has to complete the arming sequence. The arming sequence starts with pressing the **STAY** or **AWAY** buttons, and ends by closing the deadbolt. If the sequence is not completed, the system will remain in the previous state, or will be disarmed if a deadbolt is left open. Valid entries are 020 - 240 (seconds). Press **ENTER** to move cursor to the left (press repeatedly to loop back), then press **YES** or **NO** to increment or decrement each digit. Default is "060" (60 seconds). Press **MENU** to continue or press **RESET** to exit.

LEARN PRIMARY

Y/N

Learn Primary

Send command to the Touchpad's integral receiver module to learn the Primary transmitter ID. If **YES** is pressed, will display: PRESS/RELEASE TAMPER SWITCH. If learned successfully, displays: PRIMARY TXMIT LEARNED - SS##. If learned unsuccessfully, displays: LEARN FAILED TRY AGAIN? Y/N. See WI1499 for full instructions for installing and learning transmitters. Not used with the F-64TP-H Hardwired Touchpad. Press **NO** or **MENU** to continue or press **RESET** to exit.

LEARN SECONDARY

Y/N

Learn Secondary

Send command to the Touchpad's integral receiver module to learn the Secondary ID. Be sure to install the shunt on the Secondary transmitter address jumper to ensure the transmitter is identified as the Secondary transmitter and not the Primary transmitter. Install a Secondary transmitter to protect a second door that will be used only for *entry* or to disarm when armed Stay. If **YES** is pressed, will display: PRESS/RELEASE TAMPER SWITCH. If learned successfully, displays: SEC-ONDARY TXMIT LEARNED - SS##. If learned unsuccessfully, displays: LEARN FAILED TRY AGAIN? Y/N. See WI1499 for full instructions for installing and learning transmitters. Not used with the F-64TP-H Hardwired Touchpad. Press **NO** or **MENU** to continue or press **RESET** to exit.

CLEAR ALL

LEARNED TXS

Y/N

Clear All Learned TXS

Erase all learned transmitter ID's. If **YES** is pressed, displays: PLEASE WAIT. When complete displays: ALL TRANSMITTERS CLEARED. If unsuccessful, displays: XMITTER CLEAR FAILED TRY AGAIN?. See WI1499 for full instructions for installing and learning transmitters. Not used with the F-64TP-H Hardwired Touchpad. Press **NO** or **MENU** to continue or press **RESET** to exit.

DISPLAY

RF SS

Y/N

Display RF SS

Press **YES** to display the signal strength of the enrolled transmitters. See **Display RF Noise** option below. Press **NO** or **MENU** to continue or press **RESET** to exit.

DISPLAY

RF NOISE

Y/N

Display RF Noise

Indicates the ambient radio frequency noise on each of the enrolled transmitter frequencies. Typical measurements are below 100. If this level is too close to the signal strength ("Display RF SS" above) recorded for the Secondary transmitter, an additional F-64TP may be required to be mounted near the Secondary transmitter. The **RF SS** should be at least 50 points higher than the **RF NOISE** level. Press **YES** to display. Press **NO** or **MENU** to continue or press **RESET** to exit.

To exit Touchpad Configuration Mode, press **RESET**.

TOUCHPAD MENU MODE

ALL MESSAGES IN MENU	NOTES
ENTER BYPASS MENU Y/N	When bypassing a zone, press BYPASS to enter this menu.
DISPLAY ZN DIRECTORY Y/N	Allows individual zones to be bypassed. Press Yes or No to scroll through zone list.
BYPASS OPEN ZONES? Y/N	Disables monitoring of all faulted zones EXCEPT the PRIMARY Touchpad door.
DISPLAY ZN BYPASSED Y/N	Scrolls list of bypassed zones (cannot unbypass from this selection).
ACTIVATE CHIME Y/N	When activated, this selection reads "DEACTIVATE CHIME Y/N".
CHANGE KEYPAD BEEP VOLUME Y/N	Selections are LOW (default), MED, MED-HIGH, HIGH, and OFF (tactile or entry warning only).
CHANGE VOICE VOLUME Y/N	Selections are LOW, MED, MED-HIGH (default), HIGH, OFF (voice prompt volume).
ACTIVATE SIREN TEST Y/N	Press YES to activate burg relay output for 2 seconds.
DISPLAY FIRE ALARM Y/N	Displays list of shorted fire zones only when a fire alarm is tripped.
DISPLAY FIRE TROUBLE Y/N	Displays list of opened fire zones only when a fire trouble (open on a fire zone is detected).
ACTIVATE FAULT FIND Y/N	Activates <i>Fault Find</i> mode. The Master I-FOB MUST be inserted into the Touchpad for this menu item to appear.
RESET SYSTEM TBL Y/N	This message appears if a trouble is found.
ACTIVATE DIALER TEST Y/N	<i>Test Timer</i> must be programmed or this option will not appear.
ENTER LOG MENU Y/N	
DISPLAY ALARM LOG Y/N	Displays most recent alarm events.
DISPLAY TOTAL LOG Y/N	Displays most recent events of all types.
DISPLAY FIRE LOG Y/N	Displays most recent fire events.
DISPLAY SYSTEM LOG Y/N	Displays most recent system events.
ACTIVATE PROGRAM Y/N	Also called "User Program Mode". See Touchpad User Manual for more information.
CHANGE DATE Y/N	
CHANGE TIME Y/N	
ENROLL MASTER IFOB Y/N	The Master I-FOB is programmed at the factory to be the USER 01 ID code in all Areas. With the Master I-FOB, additional User I-FOB's may be created for any Areas.
ENROLL USER I-FOB Y/N	The Master I-FOB MUST be inserted into the Touchpad (when prompted) to allow the creation of a User I-FOB.
DELETE I-FOB Y/N	See Touchpad User Manual for more information.
ACTIVATE DOWNLOAD Y/N	Allows modem connection with PC Preset software.
ACTIVATE LOST KEY MODE Y/N	If the lost key mode is set to be ON , an I-FOB will be required to disarm the system when entering through any monitored door. When activated, this selection reads "DEACTIVATE LOST KEY MODE Y/N", and "Lost Key Mode" appears in the LCD Window with the "System Ready" message.
ACTIVATE PIR TEST Y/N	The Master I-FOB MUST be inserted into the Touchpad for this menu item to appear. (Press MENU to skip to the top of the list).

The Touchpad can provide access to a wide assortment of utility functions, each displayed on the Touchpad LCD window in a prompting "YES/NO" format. This Touchpad menu is not necessary for panel programming, but is included here for reference.

TYPICAL USER: Homeowner.

TYPICAL INTERFACE: Touchpad only.

HOW TO ENTER: At the installed Touchpad, insert the Master I-FOB and press **MENU** to enter. All messages in the **Touchpad Menu Mode** are listed below, but some messages may not appear in the Touchpad display unless a User or Master I-FOB is inserted in the Touchpad; if the required condition is not present; or if the F-64 control panel is configured in such a way as to remove the message from this Menu. For example, "DISPLAY ZN FAULTS Y/N" will only display if zones are faulted. With each message, press **YES** to proceed with the change or **NO** to skip to the next selection. **Note:** Highlighted messages are sub-menu selections.



EASY MENU PROGRAMMING WORKSHEET - 1 OF 4

Name:	Address:
Account Number:	Installer:

Area 1: # of Zones (1-64) =

Zone Doubling?: Yes No **Area 1: # of Keypads (1-7) =**

NOTE: Area 2-4 Zones and Keypads are selected in Direct Address Mode. See Zone Options and Keypad Options.

Enter Fire Zones (1-64): _____

2-Wire Fire Zones?: Zone 7 Yes No Zone 8 Yes No

Enter Entry/Exit Zones (1-64): _____

Enter Interior Zones (1-64): _____

Report all Zones to Central?: Yes No

Central Station Receiver 1 Telephone Number:

Central Station Receiver 1 Account Number:

Central Station Receiver 1 Format:

blank (*) = Ademco Slow, Silent Knight Slow

2 = Radionics Fast

3 = Silent Knight Fast

4 = Radionics, DCI, Franklin Slow

User Codes:

USER #	CODE (up to 6 digits)	AREA 1 OPTIONS	AREA 2 OPTIONS	AREA 3 OPTIONS	AREA 4 OPTIONS	CODE (up to 6 digits)	AREA 1 OPTIONS	AREA 2 OPTIONS	AREA 3 OPTIONS	AREA 4 OPTIONS	CODE (up to 6 digits)	AREA 1 OPTIONS	AREA 2 OPTIONS	AREA 3 OPTIONS	AREA 4 OPTIONS
1															
2															
3															
4															
5															
6															
7															
8															
9															
10															
11															
12															
13															
14															
15															
16															
17															
18															
19															
20															
21															
22															
23															
24															
25															
26															
27															
28															
29															
30															
31															
32															
33															
34															
35															
36															
37															
38															
39															
40															
41															
42															
43															
44															
45															
46															
47															
48															
49															
50															
51															
52															
53															
54															
55															
56															
57															
58															
59															
60															
61															
62															
63															
64															

EASY MENU PROGRAMMING WORKSHEET - 2 OF 4

RF Transmitter Points:

XMTR #	ZONE #	RF ID (printed on xmtr box)		CHECK SUM	POINT #
1					
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					

XMTR #	ZONE #	RF ID (printed on xmtr box)		CHECK SUM	POINT #
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					

XMTR #	ZONE #	RF ID (printed on xmtr box)		CHECK SUM	POINT #
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47					
48					

XMTR #	ZONE #	RF ID (printed on xmtr box)		CHECK SUM	POINT #
49					
50					
51					
52					
53					
54					
55					
56					
57					
58					
59					
60					
61					
62					
63					
64					

Keyfob Transmitters:

KEYFOB #	Area	RF ID (printed on xmtr box)		CHECK SUM	OPTION 1	OPTION 2
1						
2						
3						
4						
5						
6						
7						
8						



EASY MENU PROGRAMMING WORKSHEET - 3 OF 4**Zone Descriptions 1-32**

ZN #	CHARACTERS AVAILABLE (See below)																												
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
1																													
2																													
3																													
4																													
5																													
6																													
7																													
8																													
9																													
10																													
11																													
12																													
13																													
14																													
15																													
16																													
17																													
18																													
19																													
20																													
21																													
22																													
23																													
24																													
25																													
26																													
27																													
28																													
29																													
30																													
31																													
32																													

Characters Available for Zone Descriptions

! @ # \$ % ^ & * () _ + ! ! | { } [] ` , . < > ?
 1 2 3 4 5 6 7 8 9 0
 a b c e d f g h i j k l m n o p q r s t u v w x y z
 A B C D E F G H I J K L M N O P Q R S T U V W X Y

Dealer Code: For Zones 33-64,
see next page

EASY MENU PROGRAMMING WORKSHEET - 4 OF 4**Zone Descriptions 33-64**

ZN #	CHARACTERS AVAILABLE (See below)																												
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
33																													
34																													
35																													
36																													
37																													
38																													
39																													
40																													
41																													
42																													
43																													
44																													
45																													
46																													
47																													
48																													
49																													
50																													
51																													
52																													
53																													
54																													
55																													
56																													
57																													
58																													
59																													
60																													
61																													
62																													
63																													
64																													

Characters Available for Zone Descriptions

! @ # \$ % ^ & * () _ + ! ! | { } [] ` , . < > ?
 1 2 3 4 5 6 7 8 9 0
 a b c e d f g h i j k l m n o p q r s t u v w x y z
 A B C D E F G H I J K L M N O P Q R S T U V W X Y

For Zones 1-32,
see previous
page

Dealer Code:



NAPCO Security Systems

Freedom F-64 Programming Instructions

ALPHABETICAL INDEX

- 24 HOUR ZONES IN AREA 1, 6
2-WIRE FIRE ZONES IN AREA 1, 6
50 MS LOOP RESPONSE ZONES, 7
ABORT DELAY (ADDRESS 1417), 17
AC FAIL REPORT DELAY (ADDRESS 1419), 17
ACCESS CONTROL ON PGM2 OUTPUT (ADDRESS 1421), 21
ACTIVATE CHIME, 43
ACTIVATE DIALER TEST, 43
ACTIVATE DOWNLOAD, 43
ACTIVATE FAULT FIND, 43
ACTIVATE LOST KEY MODE, 43
ACTIVATE PIR TEST, 43
ACTIVATE PROGRAM, 43
ACTIVATE SIREN TEST, 43
ADD ANOTHER FREEDOM TOUCHPAD, 8
ADDRESS MODE DISPLAYS, 13, 14, 15
ALARM OUTPUT (ADDRESS 1414), 18
AMBUSH, 10
AMBUSH CODE, 19
AMBUSH INTERVAL, 41
AMBUSH SOUNDER, 41
AREA ARMING OPTIONS (ADDRESS 1469-1472), 27
AREA BELL CONTROL OPTIONS (ADDRESS 1473-1488), 28
AREA SYSTEM EVENT/TROUBLE, 19
AUTO ARMING/DISARMING, 26
AUTO BELL TEST ON ARMING (ADDRESS 1421), 21
AUTO BYPASS RE-ENTRY ZONES, 7
AUTO RESET AFTER BURGLARY OUTPUT TIMEOUT (ADDRESS 1421), 21
AUTOMATIC INTERIOR BYPASS/EASY EXIT (ADDRESS 1424), 21
AUX 2 ZONE NUMBER, 8
AUX OUTPUT ACTIVATED ON ALARM ZONES, 7
BACKLIGHT BRIGHTNESS, 40
BACKLIGHT FOLLOW PIR, 40
BINARY (BIT) FORMAT EXAMPLE, 13
BYPASS ENABLE, 10
BYPASS OPEN ZONES?, 43
CALLBACK METHOD, 4
CALLBACK TELEPHONE NUMBER, 18
CENTRAL STATION RECEIVER 1 ACCOUNT NUMBER, 9
CENTRAL STATION RECEIVER 1 FORMAT, 9
CENTRAL STATION RECEIVER 1 TELEPHONE NUMBER, 9
CHANGE DATE, 43
CHANGE KEYPAD BEEP VOLUME, 43
CHANGE PULSE OUTPUT TO TEMPORAL OUTPUT (ADDRESS 1422), 21
CHANGE TIME, 43
CHANGE VOICE VOLUME, 43
CHANGING OR CANCELING A CODE, 10
CHIME 1 ZONE NUMBER, 8
CHIME 2 ZONE NUMBER, 8
CHIME 2 ZONES IN AREA 1, 7
CHIME TIME (ADDRESS 1418), 17
CHIME ZONES IN AREA 1, 7
CHIRP OUTPUT ON KEYFOB ARM/DISARM (ADDRESS 1422), 21
CLEAR ALL LEARNED TXS, 42
CLEAR DEALER PROGRAM, 11
CLEAR DEALER PROGRAM (ADDRESS 2285), 38
CLEAR PROGRAM, 11
CLEAR PROGRAM OPTIONS (ADDRESS 2285 & 2286), 38
CLOSING REPORT ONLY ON CONDITIONAL CLOSE (ADDRESS 1420), 21
COLD START, 11
COLD START (ADDRESS 2286), 38
CONFIGURING THE TOUCHPADS, 40
CS AREA & SYSTEM REPORTING OPTIONS (ADDRESS 0785, 0786 & 0788), 24
CS RECEIVER 1 FORMAT, 9
CS RECEIVER OPTIONS (ADDRESS 0460-0525), 22
CS RECEIVER TELEPHONE NUMBERS, 22
CS SUBSCRIBER ID OPTIONS (ADDRESS 0560-0667), 23
CS SYSTEM REPORTING CODES, 24
CS SYSTEM REPORTING OPTIONS (ADDRESS 0670-0705), 24

ALPHABETICAL INDEX (CONT'D)

- CS SYSTEM REPORTING OPTIONS:, 24
- CS TELCO 1 SUBSCRIBER EVENT ID NUMBER, 23
- CS USER REPORTING OPTIONS, 26
- CS USER REPORTING OPTIONS (ADDRESS 0800-0835), 26
- CS ZONE REPORTING OPTIONS (ADDRESS 0720-0783), 25
- CUSTOMIZING A DEFAULT PROGRAM, 5
- DEALER CODE, 11
 - DEFAULT, 5
- DEALER PROGRAM ERASING, 11
- DEALER PROGRAM MODE, 4
- DEALER PROGRAM MODE, 5
- DEALER PROGRAM MODE ACCESSING, 5
- DEALER PROGRAM MODE OVERVIEW, 39
- DECIMAL FORMAT EXAMPLE, 14
- DELETE I-FOB, 43
- DIGITAL DIALER RPT ENTER /EXIT TEST MODE (ADDRESS 2053), 21
- DIRECT ADDRESS PROGRAM MODE, 4, 5, 13
- DISABLE [ON/OFF] AS EASY EXIT (ADDRESS 2051), 21
- DISABLE 2ND CALL ANS. MACHINE OVERRIDE (ADDRESS 1424), 21
- DISABLE CALL WAITING ON 1ST ATTEMPT (ADDRESS 2053), 21
- DISABLE CALLBACK DOWNLOAD (ADDRESS 1422), 21
- DISABLE CODE REQUIRED FOR EZ BYPASS (ADDRESS 1424), 21
- DISABLE KEYPAD FUNCTION MODE DOWNLOAD (ADDRESS 1422), 21
- DISABLE KEYPAD INSTANT MODE (ADDRESS 1421), 21
- DISABLE PIR, 42
- DISABLE SYSTEM TROUBLE AUDIBLE TIMEOUT (ADDRESS 2051), 21
- DISABLE ZONE FAULT SCROLLING (ADDRESS 1420), 21
- DISPLAY ALARM LOG, 43
- DISPLAY FIRE ALARM, 43
- DISPLAY FIRE LOG, 43
- DISPLAY FIRE TROUBLE, 43
- DISPLAY RF NOISE, 42
- DISPLAY RF SS, 42
- DISPLAY SYSTEM LOG, 43
- DISPLAY TOTAL LOG, 43
- DISPLAY ZN BYPASSED, 43
- DISPLAY ZN DIRECTORY, 43
- DON'T CLEAR PGM2 OUTPUT WITH DISARM (ADDRESS 1424), 21
- DOWNLOAD/CALLBACK OPTIONS (ADDRESS 2059 & 0526-0545), 18
- DOWNLOADING FROM A COMPUTER, 4
- EASY ARMING, 26
- EASY MENU DRIVEN PROGRAM MODE, 4, 5, 6 OVERVIEW, 39
- EASY MENU PROGRAMMING WORKSHEET, 44
- ENABLE "K SERIES" STYLE KEYPADS (ADDRESS 2051), 21
- ENABLE ALARM OUTPUT ON TELCO FAIL ONLY WHEN ARMED (ADDRESS 1423), 21
- ENABLE AUTOARM IF NOT CLOSED AT END OF WINDOW (ADDRESS 1420), 21
- ENABLE BURG OUTPUT CHIRP ON KEYFOB, 8
- ENABLE CANCEL REPORT TO TELCO 3 (ADDRESS 2051), 21
- ENABLE CP-01 EGRESS TONES ONLY (ADDRESS 2053), 21
- ENABLE CP-01 LIMITS (ADDRESS 2053), 21
- ENABLE GEM-PRINT MODULE (ADDRESS 2051), 21
- ENABLE GLOBAL AMBUSH CODE (ADDRESS 1422), 21
- ENABLE KEYPAD 1 ONLY PROGRAMMING (ADDRESS 2053), 21
- ENABLE KEYPAD OPTIONS, 29
- ENABLE KEYPAD SET TIME/DATE MESSAGE (ADDRESS 2051), 21
- ENABLE KEYPAD TIME/DATE DISPLAY (ADDRESS 1420), 21
- ENABLE LINE-FAULT TEST (ADDRESS 1423), 21
- ENABLE LOCAL ALARM ON FIRST ZONE AND TRIP (ADDRESS 1421), 21
- ENABLE LOW SECURITY FIRE ALARM SILENCE, 20
- ENABLE MANAGER'S MODE (ADDRESS 1421), 21

ALPHABETICAL INDEX (CONT'D)

- ENABLE NO EOLR ZONES, 7
 ENABLE RESIDENTIAL FIRE (ADDRESS 1422), 21
 ENABLE SIA CP-01 FEATURES, 8
 ENABLE TCP/IP COMMUNICATIONS (ADDRESS 2054), 21
 ENABLE TELCO LINE FAULT TEST, 7
 ENABLE ZONE DOUBLING (ZONES 9-16) (ADDRESS 1423), 21
 ENROLL MASTER IFOB, 43
 ENROLL MODE, 10
 ENROLL USER I-FOB, 43
 ENTER BYPASS MENU, 43
 ENTER DATE, 11
 ENTER DOOR NUMBER 1 ZONE NUMBER, 8
 ENTER DOOR NUMBER 2 ZONE NUMBER, 8
 ENTER LOG MENU, 43
 ENTER THE FREEDOM TOUCHPAD NUMBER, 8
 ENTER THE TOUCHPAD PIR ZONE NUMBER, 8
 ENTER TIME, 11
 ENTER USER CODES, 9
 ENTER ZONE DESCRIPTIONS, 11
 ENTERING ZONE DESCRIPTIONS, 12
 ENTRY DELAY (ADDRESS 0001), 17
 ENTRY DELAY (ADDRESS 0002), 17
 ENTRY SOUNDER, 40
 ERASING THE DEALER PROGRAM, 11
 ERASING THE ENTIRE PROGRAM, 11
 EXIT DEALER PROGRAM MODE, 11
 EXIT DELAY (ADDRESS 0000), 17
 EXIT TIME RESTART (ADDRESS 2053), 21
 EXIT TOUCHPAD CONFIGURATION MODE, 42
 EXIT/ENTRY ZONES IN AREA 1, 6
 EXIT/ENTRY2 ZONES IN AREA 1, 7
 EXTERNAL RELAY CONTROL (ADDRESS 1489-1648), 34
 EZM ADDRESS, 41
 EZM GROUP OPTIONS (ADDRESS 1455-1468), 27
 F-64 AND GEM-P1664 PANEL DIFFERENCES, 2
 FIRE ZONES IN AREA 1, 6
 FIRMWARE VERSION, 2
 FREEDOM F-64 WIRING DIAGRAM, 60
 FUNCTION MODE, 4
 GEM-P1664 AND F-64 PANEL DIFFERENCES, 2
 GLOBAL AMBUSH CODE, 19
 GLOBAL SYSTEM EVENT/TROUBLE, 19
 HEXADECIMAL FORMAT EXAMPLE, 15
 INCL. SEL./GRP. BYPASS IN COND. CLOSE / STATUS (ADDRESS 1420), 21
 INHIBIT SYSTEM TROUBLE AUDIBLE AT KEYPAD (ADDRESS 1423), 21
 INTERIOR NORMALLY BYPASSED (ADDRESS 1422), 21
 INTERIOR ZONES IN AREA 1, 6
 KEYFOB TRANSMITTERS AS ARM/DISARM & CONTROL DEVICES, 10
 KEYFOB ZONE ASSIGNMENT, 10
 KEYPAD ADDRESS, 41
 KEYPAD OPTIONS, 29
 KEYPAD SOUNDER ON ALARM ZONES, 7
 KEYPAD TACTILE BEEP, 40
 KEYPAD TYPE & ACTIVATION, 29
 KEYPAD VERSIONS ALLOWED, 2
 KEYPAD/TOUCHPAD OPTIONS (ADDRESS 1425-1431, 1440-1446), 29
 KEYSWITCH ARMING, 26
 LEADING DIGITS FOR PAGER FORMAT, 18
 LEARN PRIMARY, 42
 LEARN SECONDARY, 42
 LINE-FAULT TEST ONLY WHEN ARMED (ADDRESS 1423), 21
 LOCAL DOWNLOADING, 4
 LOCAL OR CENTRAL STATION REPORTING SYSTEM, 6
 LUG E15 AREA 1 ARMED AWAY ONLY (ADDRESS 2052), 21
 MAINTAINED KEYSWITCH ARMING (ADDRESS 1421), 21
 MAPPING F-64TP DOORS AND PIR'S (ADDRESS 2090-2101), 29
 MODEM CODES, 25
 NEW PANELS, 5
 NUMBER OF KEYPADS IN AREA 1, 8

ALPHABETICAL INDEX (CONT'D)

- NUMBER OF RINGS BEFORE PICKUP, 18
 OPENING REPORT ONLY AFTER ALARM REPORT (ADDRESS 1420), 21
 OPENING REPORT OPTIONS:, 24
 OUTPUT TIMEOUTS, 18
 OUTPUT TURNS OFF UPON DISARM, 28
 PAGER FORMAT OPTIONS (ADDRESS 0546 & 0547), 18
 PANEL ZONE DOUBLING, 6
 PCD-WINDOWS, 4
 PGM ON RF TRANSMITTER TAMPER (ADDRESS 2052), 21
 PGM1 OUTPUT (ADDRESS 1416), 18
 PGM2 OUTPUT (ADDRESS 1412), 18
 PGM2 OUTPUT ACCESS CNTRL TIMEOUT (ADDRESS 1413), 17
 PRE-AWAY / STAY, 42
 PRIORITY AREA ARMING, 27
 PROGRAM A FREEDOM TOUCHPAD, 8
 PROGRAMMING CONVENTIONS USED IN THIS MANUAL, 16
 PULSE ALARM OUTPUT (ADDRESS 1415), 18
 PULSE EVENT CODE, 25
 QUICK "ENROLL" METHOD, 10
 QUICKLOADER, 4
 QUICKLOADER REMOTE ARMING/DISARMING, 26
 REMOTE DOWNLOADING, 4
 REPORT CANCEL WINDOW (ADDRESS 2055), 17
 REPORTING OPTIONS, 26
 RESET DAY ZONE WITH ARM/DISARM ONLY (ADDRESS 1422), 21
 RESET SYSTEM TBL, 43
 RESOUND ON WIRELESS SMOKE LOW BATTERY (ADDRESS 1424), 21
 RF RECEIVER & SUPERVISORY TIMER OPTIONS (ADDRESS 2029-2044 & 2056), 37
 RF RECEIVERS, 37
 RF SUPERVISORY TIMERS, 37
 RF TRANSMITTER POINTS, 10
 RPT EXIT ERR/RECENT CLOSE (ADDRESS 2053), 21
 SECURITY BYPASS, 10
 SELECT ALARM OUTPUT FOR KEYFOB CHIRP (ADDRESS 1423), 21
 SENSOR WATCH (ADDRESS 2050), 17
 SENSOR WATCH ZONES, 7
 SOUND ALARM ON EXIT ERROR (ADDRESS 2053), 21
 STATUS REPORT (ADDRESS 1420), 21
 SUPPRESS BYPASS REMINDER WHEN ARMED (ADDRESS 1421), 21
 SYSTEM DELAYS & TIMEOUTS (ADDRESS 0000-0002, 1413, 1417, 2050 & 2055), 17
 SYSTEM DELAYS & TIMEOUTS (ADDRESS 1418-1419), 17
 SYSTEM OPTIONS (ADDRESS 0836-0871 & 2045), 19
 SYSTEM OPTIONS (ADDRESS 0872-0887), 20
 SYSTEM OPTIONS (ADDRESS 1420-1424, 2051-2054), 21
 SYSTEM OPTIONS (ADDRESS 2063), 20
 SYSTEM OUTPUT TIMEOUTS (ADDRESS 1412 & 1414-1416), 18
 SYSTEM RESPONSE ACTIVATED BY AREA EVENT/TROUBLE, 19
 SYSTEM RESPONSE ACTIVATED BY GLOBAL EVENT/TROUBLE, 19
 TAMPER DETECT, 41
 TEST TIMER, 11
 TOTAL NUMBER OF ZONES IN AREA 1, 6
 TOUCHPAD CONFIGURATION MODE OVERVIEW, 40
 TOUCHPAD INSTALLATION, 40
 TOUCHPAD MENU MODE, 4
 TOUCHPAD TYPE & ACTIVATION, 29
 TRANSMITTER WIRELESS POINTS, 10
 USER AREA OPTIONS, 9
 USER PROGRAM MODE, 43
 VERI-PHONE AUDIO PRIORITY OVER ALARMS (ADDRESS 1424), 21
 VERI-PHONE ZONES TRIP PGM2 OUTPUT (ADDRESS 1424), 21
 WIRELESS TROUBLE ACTIVATES TELCO 1 (ADDRESS 1423), 21
 WIRELESS TROUBLE ACTIVATES TELCO 3 (ADDRESS 1423), 21
 WIRING DIAGRAM, 60

ALPHABETICAL INDEX (CONT'D)

- ZONE DESCRIPTIONS
ENTERING, 12
- ZONE OPTIONS - ZONES 1 TO 16 (ADDRESS 0900-1016), 30
- ZONE OPTIONS - ZONES 17 TO 32 (ADDRESS 1029-1144), 31
- ZONE OPTIONS - ZONES 33 TO 48 (ADDRESS 1157-1272), 32
- ZONE OPTIONS - ZONES 49 TO 64 (ADDRESS 1285-1400), 33
- ZONE RESPONSE, 41

ADDRESS NUMBER INDEX

ABORT DELAY	(ADDRESS 1417).....	17
AC FAIL REPORT DELAY	(ADDRESS 1419).....	17
ACCESS CONTROL ON PGM2 OUTPUT.....	(ADDRESS 1421).....	21
ALARM OUTPUT	(ADDRESS 1414).....	18
AREA ARMING OPTIONS	(ADDRESS 1469-1472).....	27
AREA BELL CONTROL OPTIONS.....	(ADDRESS 1473-1488).....	28
AUTO BELL TEST ON ARMING	(ADDRESS 1421).....	21
AUTO RESET AFTER BURGLARY OUTPUT TIMEOUT	(ADDRESS 1421).....	21
AUTOMATIC INTERIOR BYPASS/EASY EXIT	(ADDRESS 1424).....	21
CHANGE PULSE OUTPUT TO TEMPORAL OUTPUT	(ADDRESS 1422).....	21
CHIME TIME	(ADDRESS 1418).....	17
CHIRP OUTPUT ON KEYFOB ARM/DISARM.....	(ADDRESS 1422).....	21
CLEAR DEALER PROGRAM.....	(ADDRESS 2285).....	38
CLEAR PROGRAM OPTIONS	(ADDRESS 2285).....	38
CLEAR PROGRAM OPTIONS	(ADDRESS 2286).....	38
CLOSING REPORT ONLY ON CONDITIONAL CLOSE.....	(ADDRESS 1420).....	21
COLD START.....	(ADDRESS 2286).....	38
CS AREA & SYSTEM REPORTING OPTIONS	(ADDRESS 0785).....	24
CS AREA & SYSTEM REPORTING OPTIONS	(ADDRESS 0786).....	24
CS AREA & SYSTEM REPORTING OPTIONS	(ADDRESS 0788).....	24
CS RECEIVER OPTIONS	(ADDRESS 0460-0525).....	22
CS SUBSCRIBER ID OPTIONS	(ADDRESS 0560-0667).....	23
CS SYSTEM REPORTING OPTIONS.....	(ADDRESS 0670-0705).....	24
CS USER REPORTING OPTIONS.....	(ADDRESS 0800-0835).....	26
CS ZONE REPORTING OPTIONS.....	(ADDRESS 0720-0783).....	25
DIGITAL DIALER RPT ENTER /EXIT TEST MODE	(ADDRESS 2053).....	21
DISABLE [ON/OFF] AS EASY EXIT	(ADDRESS 2051).....	21
DISABLE 2ND CALL ANS. MACHINE OVERRIDE.....	(ADDRESS 1424).....	21
DISABLE CALL WAITING ON 1ST ATTEMPT	(ADDRESS 2053).....	21
DISABLE CALLBACK DOWNLOAD	(ADDRESS 1422).....	21
DISABLE CODE REQUIRED FOR EZ BYPASS	(ADDRESS 1424).....	21
DISABLE KEYPAD FUNCTION MODE DOWNLOAD	(ADDRESS 1422).....	21
DISABLE KEYPAD INSTANT MODE	(ADDRESS 1421).....	21
DISABLE SYSTEM TROUBLE AUDIBLE TIMEOUT	(ADDRESS 2051).....	21
DISABLE ZONE FAULT SCROLLING	(ADDRESS 1420).....	21
DON'T CLEAR PGM2 OUTPUT WITH DISARM.....	(ADDRESS 1424).....	21
DOWNLOAD/CALLBACK OPTIONS	(ADDRESS 2059).....	18
DOWNLOAD/CALLBACK OPTIONS	(ADDRESS 0526-0545).....	18
ENABLE "K SERIES" STYLE KEYPADS.....	(ADDRESS 2051).....	21
ENABLE ALARM OUTPUT ON TELCO FAIL ONLY WHEN ARMED	(ADDRESS 1423).....	21
ENABLE AUTOARM IF NOT CLOSED AT END OF WINDOW	(ADDRESS 1420).....	21
ENABLE CANCEL REPORT TO TELCO 3.....	(ADDRESS 2051).....	21

ADDRESS NUMBER INDEX (CONT'D)

ENABLE CP-01 EGRESS TONES ONLY	(ADDRESS 2053).....	21
ENABLE CP-01 LIMITS.....	(ADDRESS 2053).....	21
ENABLE GEM-PRINT MODULE	(ADDRESS 2051).....	21
ENABLE GLOBAL AMBUSH CODE.....	(ADDRESS 1422).....	21
ENABLE KEYPAD 1 ONLY PROGRAMMING	(ADDRESS 2053).....	21
ENABLE KEYPAD SET TIME/DATE MESSAGE	(ADDRESS 2051).....	21
ENABLE KEYPAD TIME/DATE DISPLAY	(ADDRESS 1420).....	21
ENABLE LINE-FAULT TEST	(ADDRESS 1423).....	21
ENABLE LOCAL ALARM ON FIRST ZONE AND TRIP	(ADDRESS 1421).....	21
ENABLE MANAGER'S MODE.....	(ADDRESS 1421).....	21
ENABLE RESIDENTIAL FIRE	(ADDRESS 1422).....	21
ENABLE TCP/IP COMMUNICATIONS	(ADDRESS 2054).....	21
ENABLE ZONE DOUBLING (ZONES 9-16)	(ADDRESS 1423).....	21
ENTRY DELAY	(ADDRESS 0001).....	17
ENTRY DELAY	(ADDRESS 0002).....	17
EXIT DELAY	(ADDRESS 0000).....	17
EXIT TIME RESTART	(ADDRESS 2053).....	21
EXTERNAL RELAY CONTROL.....	(ADDRESS 1489-1648).....	34
EZM GROUP OPTIONS.....	(ADDRESS 1455-1468).....	27
INCL. SEL./GRP. BYPASS IN COND. CLOSE /STATUS	(ADDRESS 1420).....	21
INHIBIT SYSTEM TROUBLE AUDIBLE AT KEYPAD.....	(ADDRESS 1423).....	21
INTERIOR NORMALLY BYPASSED	(ADDRESS 1422).....	21
KEYPAD/TOUCHPAD OPTIONS	(ADDRESS 1425-1431).....	29
KEYPAD/TOUCHPAD OPTIONS	(ADDRESS 1440-1446).....	29
LINE-FAULT TEST ONLY WHEN ARMED	(ADDRESS 1423).....	21
LUG E15 AREA 1 ARMED AWAY ONLY	(ADDRESS 2052).....	21
MAINTAINED KEYSWITCH ARMING	(ADDRESS 1421).....	21
MAPPING F-64TP DOORS AND PIR'S	(ADDRESS 2090-2101).....	29
OPENING REPORT ONLY AFTER ALARM REPORT	(ADDRESS 1420).....	21
PAGER FORMAT OPTIONS	(ADDRESS 0546).....	18
PAGER FORMAT OPTIONS	(ADDRESS 0547).....	18
PGM ON RF TRANSMITTER TAMPER	(ADDRESS 2052).....	21
PGM1 OUTPUT	(ADDRESS 1416).....	18
PGM2 OUTPUT	(ADDRESS 1412).....	18
PGM2 OUTPUT ACCESS CNTRL TIMEOUT	(ADDRESS 1413).....	17
PULSE ALARM OUTPUT	(ADDRESS 1415).....	18
REPORT CANCEL WINDOW.....	(ADDRESS 2055).....	17
RESET DAY ZONE WITH ARM/DISARM ONLY	(ADDRESS 1422).....	21
RESOUND ON WIRELESS SMOKE LOW BATTERY	(ADDRESS 1424).....	21
RF RECEIVER & SUPERVISORY TIMER OPTIONS	(ADDRESS 2029-2044).....	37
RF RECEIVER & SUPERVISORY TIMER OPTIONS	(ADDRESS 2056).....	37
RPT EXIT ERR/RECENT CLOSE	(ADDRESS 2053).....	21

ADDRESS NUMBER INDEX (CONT'D)

SELECT ALARM OUTPUT FOR KEYFOB CHIRP	(ADDRESS 1423).....	21
SENSOR WATCH	(ADDRESS 2050).....	17
SOUND ALARM ON EXIT ERROR	(ADDRESS 2053).....	21
STATUS REPORT	(ADDRESS 1420).....	21
SUPPRESS BYPASS REMINDER WHEN ARMED.....	(ADDRESS 1421).....	21
SYSTEM DELAYS & TIMEOUTS	(ADDRESS 0000-0002).....	17
SYSTEM DELAYS & TIMEOUTS	(ADDRESS 1413).....	17
SYSTEM DELAYS & TIMEOUTS	(ADDRESS 1417).....	17
SYSTEM DELAYS & TIMEOUTS	(ADDRESS 2050).....	17
SYSTEM DELAYS & TIMEOUTS	(ADDRESS 2055).....	17
SYSTEM DELAYS & TIMEOUTS	(ADDRESS 1418-1419).....	17
SYSTEM OPTIONS.....	(ADDRESS 0836-0871).....	19
SYSTEM OPTIONS.....	(ADDRESS 2045).....	19
SYSTEM OPTIONS.....	(ADDRESS 0872-0887).....	20
SYSTEM OPTIONS.....	(ADDRESS 1420-1424).....	21
SYSTEM OPTIONS.....	(ADDRESS 2051-2054).....	21
SYSTEM OPTIONS.....	(ADDRESS 2063).....	20
SYSTEM OUTPUT TIMEOUTS.....	(ADDRESS 1412).....	18
SYSTEM OUTPUT TIMEOUTS.....	(ADDRESS 1414-1416).....	18
VERI-PHONE AUDIO PRIORITY OVER ALARMS.....	(ADDRESS 1424).....	21
VERI-PHONE ZONES TRIP PGM2 OUTPUT.....	(ADDRESS 1424).....	21
WIRELESS TROUBLE ACTIVATES TELCO 1	(ADDRESS 1423).....	21
WIRELESS TROUBLE ACTIVATES TELCO 3	(ADDRESS 1423).....	21
ZONE OPTIONS - ZONES 1 TO 16	(ADDRESS 0900-1016).....	30
ZONE OPTIONS - ZONES 17 TO 32	(ADDRESS 1029-1144).....	31
ZONE OPTIONS - ZONES 33 TO 48	(ADDRESS 1157-1272).....	32
ZONE OPTIONS - ZONES 49 TO 64	(ADDRESS 1285-1400).....	33

FREEDOM F-64 WIRING DIAGRAM

