



# WireLess Telnet 5250

User Manual

# TABLE OF CONTENTS

<b>CHAPTER 1 - WTN52 FEATURES .....</b>	<b>4</b>
1.I WTN52 FEATURES .....	4
1.II INSTALLING WTN52 .....	4
1.III USER MESSAGE FILE.....	6
1.IV BOOT SEQUENCE.....	7
<b>CHAPTER 2 – NETWORK CONFIGURATION.....</b>	<b>8</b>
2.I NETWORK.....	8
2.II HOST.....	9
2.III TERMINAL.....	9
<b>CHAPTER 3 – TERMINAL OPERATION.....</b>	<b>11</b>
3.I CONNECTING TO THE HOST .....	11
3.II ENDING SESSION.....	12
3.III CHANGING HOST IP ADDRESS .....	12
3.IV PRINTING .....	13
3.V SCANNING.....	14
3.VI KEYBOARD OPERATION.....	14
3.VII SCREEN AND DISPLAY.....	15
3.VIII TROUBLESHOOT .....	16
<b>CHAPTER 4 – LOCAL OPERATIONS.....</b>	<b>17</b>
4.I MAIN MENU .....	17
4.II WT CONFIGURATION .....	17
4.III VIEW OPTIONS .....	18
4.IV BOOT MENU .....	32
<b>CHAPTER 5 – CONFIGURATION FILE OPTIONS.....</b>	<b>33</b>
5.I FEATURES AND SYNTAX.....	33
5.II SECTIONS .....	34
5.III [TERMINAL] SECTION .....	36
5.IV [SESSIONS] .....	37
5.V [SESSION_X].....	37
5.VI [TELNET] SECTION.....	38
5.VII [EMULATION] SECTION.....	40
5.VIII KEYBOARD SECTIONS.....	42
5.IX [ERROR_MSG].....	45
5.X [BARCODES].....	45
5.XI [SCROLL] SECTION.....	47
5.XII [SCANNER] SECTION.....	48
5.XIII [<SYMBOLOLOGY>] SECTIONS .....	49
5.XIV [BC_EDIT_X].....	50
5.XV [PRINT_DATA].....	51
5.XVI [PRINTER] SECTION .....	52
5.XVII [DBGOPT] SECTION.....	54

<b>CHAPTER 6 – USER MESSAGE FILE.....</b>	<b>55</b>
6.I FEATURES AND SYNTAX.....	55
6.II COMMENTS.....	55
6.III SECTIONS.....	55
6.IV KEYS.....	55
6.V VALUES.....	55
<b>APPENDIX A – TERMINAL FUNCTIONS.....</b>	<b>56</b>
<b>APPENDIX B – CHARACTER SETS.....</b>	<b>59</b>
B.I ISO 8859_1 CHARACTER SET.....	59
<b>APPENDIX C – DOWNLOADING CONFIGURATION FILE.....</b>	<b>60</b>
C.I DOWNLOAD BY RSLINK.....	60
C.II DOWNLOAD BY WTDNL.....	60
<b>APPENDIX D – DOWNLOADING TERMINAL PROGRAM.....</b>	<b>61</b>
D.I DOWNLOADING PROGRAM BY NVMHEX.....	61
D.II DOWNLOADING PROGRAM BY RSLINK.....	62
D.III DOWNLOADING PROGRAM BY SENDHEX.....	62
<b>APPENDIX E - CFG24 / CFG11 UTILITY.....</b>	<b>63</b>
E.I PURPOSE.....	63
E.II DESCRIPTION.....	63
<b>APPENDIX F – KEYBOARD REFERENCE.....</b>	<b>71</b>
F.I KEYBOARD REFERENCE.....	71
F.II BOOT SEQUENCES.....	74

# Chapter 1 - WTn52 Features

---

## 1.I WTn52 Features

WireLess TelNet "WTN52" is a Telnet client for Symbol Technologies series 3000 PDT (PDT 3940, 3140, 3840, 1040) and 6000 PDT (PDT 6140, 6840) terminals.

WTn52 supports various terminal emulations: 5251-11, and 3270.

WTn52 is "fully-configurable" program by text configuration files that allows local language customization, and special adaptation to various Telnet implementations, and expected terminal behaviors.

The configuration file is composed of "sections", to adapt:

- Local languages (text customization and special characters set).
- Symbol Technologies specific PDT features.
- TCP level protocol.
- Telnet level protocol.
- Terminal Emulation features and behavior.
- Barcode reading.
- Printers.

WTn52 is shipped with standard configuration files that respond to the most popular configurations.

WTn52 includes a "message file" that contains all the messages shown by the PDT WT application to the user. You can translate or modify the messages to adapt or localize the emulation. The message file to be used by WTn52 is chosen by an option in the configuration file. (The WTn52 program has already got some message files in several languages).

The download process of the "message file" is the same as that of the "configuration file".

## 1.II Installing WTN52

WTN52 installation is done in following steps:

- Building static configuration files (optional)
- Installing WTN52 program into PDT Non Volatile Memory (NVM).
- Configuring Network Parameters
- Downloading dynamic configuration files (optional)

### 1.II.1 Static or Dynamic configuration files

Telnet application may require to modify standard WT parameters in configuration files. Those files may be downloaded into the terminal in several ways:

#### 1.II.1.1 Static

In static configuration, the needed files are included and downloaded *with the WTn52 program* at once into the PDT NVM. If "[Bios Boot](#)" is done, the terminal recalls the NVM parameters.

This option needs to rebuild a customized version of "WTn52xx.HEX" and needs to install WTn52 Build Kit (that includes some Symbol SDK utilities).

If you choose static configuration files, be sure to keep the special WtN52xx.HEX built version, if you need to download other terminals. If you modify some parameters you need to rebuild WtN52xx.HEX and download all the PDTs.

### 1.II.1.2 Dynamic

Using dynamic configuration needs downloading the configuration files to the PDT from a Host computer, at any time, and can be done in several ways:

- Serial download from a PC with [RSLINK](#) or PDTCOM file transfer programs. This option needs to install RSLINK in a Windows-based PC.
- Network download from a PC with [WTDNL](#) server utility installed into a Windows-based PC connected to the network.

If you choose dynamic configuration files, those files will be downloaded once. Dynamic download replaces the configuration files into the "Flash Memory" and they aren't lost when "Bios Boot" is done.

## 1.II.2 Building static configuration files

Modify the "\_WtN52.cfg" (See [Chapter 5](#)) file under the folder Wtn\52\Nvm\Cfg with a text editor.

You may modify the "message file" (\_Msg52xx.cfg) or create a new file (See [Chapter 6](#)).

Rebuild the cfg.zip file with WinZip (cfg.zip includes all the configuration files).

Rebuild the WtN52xx.hex file by "usrcfg" Symbol technologies utility.

## 1.II.3 Installing WTN52 program into PDT Non Volatile Memory (NVM)

To load **WtN52** in a Symbol Technologies series 3000 PDT, it is necessary to download to the PDT NVM two "DOT.HEX" files:

- **WS24\_xxx.HEX** Drivers Spectrum24 for 2Mb FH PDTs (PDTxx42)  
OR
- **WS11\_xxx.HEX** Drivers Spectrum24 for 11Mb DS PDTs (PDTxx46)  
AND
- **WtN52xx.HEX** Wireless Telnet 5250 Emulator Version X.X.

Using [NvmHex](#), [RsLink](#) or [Sendhex](#) utilities (See [Appendix D](#)). These utilities send the ".HEX" file to the PDT by writing the Non Volatile Memory.

1. Erase the PDT NVM (EEPROM).
2. Load **WS24\_xxx.HEX** (2Mb FH) OR **WS11\_xxx.HEX** ( 11Mb DS) first, *and boot the terminal*.
3. To the "Flash Erase" question, answer [Y] (Yes) to format the Flash disk. When boot, NVM (or EEPROM, or **B:**) contents are transferred to Flash Memory (or **E:** drive), the network and TCP/IP drivers are installed.
4. Erase the PDT NVM (EEPROM) (Yes, Yes...).
5. Load **WtN52xx.HEX** and boot the terminal.
6. After boot, the PDT Network configuration utility ([CFG24](#) or [CFG11](#)) allows to set the appropriate values.

You may load other configuration files (\_WTn52.Cfg, \_Msg52XX.Cfg) by the RsLink utility, or use those included in the standard **WTn52** NVM.

## 1.II.4 Configuring Network Parameters

Network parameters need to be configured into the Host and Client systems.

PDT network parameters may be configured by the CFG24 or CFG11 utility, called from the WTn52 main menu.

Ask your Network Administrator for:

- The Host Computer IP address.
- The Telnet port (standard is 23).
- The [Default Router](#) (if any).
- The [Subnet Mask](#).
- The [PDT IP](#) address (if [bootp](#) is not used).
- The [ESS Id](#) used by the 802.11 S24 radio network.

See [Chapter 2 – Network Configuration](#) and [Appendix E](#) for the CFG24 or CFG11 Utilities.

## 1.II.5 Downloading dynamic configuration files

If you choose dynamic configuration files, you need to download those files to the PDT. These files will be downloaded once. Dynamic download replaces the configuration files into the "Flash Memory" and they aren't lost when "[Bios Boot](#)" is done.

### 1.II.5.1 Serial download

Serial download needs to install the RSLINK utility into a Windows-based PC with Windows 95, 98, NT4, 2000 or Me.

After a "[Bios Boot](#)" the "[Boot Menu](#)" asks for the desired download. Choose "F1 By RsLink" option.

See [Appendix C – Downloading Configuration File](#) and follow the instructions for [RSLINK](#) download.

### 1.II.5.2 PC Network download

WireLess TelNet Download ([WTDnl](#)) is a TCP/IP server utility that allows downloading configuration files from a PC to the PDT. PC Network download needs installing WTnDnl utility into a Windows-based PC with Windows 95, 98, NT4, 2000 or Me.

The PC must be connected to the same network that the PDT uses. You need to enter the PC IP address that is running the WTDnl server on the PDT.

After a "[Bios Boot](#)" the "[Boot Menu](#)" asks for the desired download. Choose "F2 By Radio" option and supply the IP address.

See [Appendix C – Downloading Configuration File](#) and follow the instructions for [WTDnl](#) download.

## 1.III User Message File

The user message file contains all the messages the PDT displays. You can translate or modify the contents of the message file. The [message file](#) used by the terminal is set into the configuration file.

Several message files are stored in the PDT NVM (CFG zipped folder) and may be selected at run time by the configuration file.

The user message file (\_Msg52XX.cfg) is automatically downloaded with the configuration file if you use the RsLink download option.

See [Chapter 6 – Message File](#) for the syntax and features of this file.

Warning: The user message file uses the [font](#) indicated in the configuration file to display messages.

Some messages (those displayed **before** configuration download) are unique and should not be translated.

## 1.IV Boot sequence

When WTn52 boots, the following sequence is followed:

- 1) Driver installation test. Check if the S24 drivers are in the flash memory. If not, send the WS24\_XXX.HEX or WS11\_XXX.HEX file to install them (See [Appendix D](#)).
- 2) Recall parameters from NVM to flash, if the recall option is used ("Recall.Yes" file in CFG.ZIP). Overwrites the downloaded files and restores NVM defaults (usually with static files).
- 3) [CFG24](#) or [CFG11](#) utility call, to view or modify network parameters.
- 4) WTn52 Application:
  - 4.1) WTn52 [Boot Menu](#). Serial or Network download option (only at boot time).
  - 4.2) WTn52 [Main Menu](#).

If a dynamic download is performed, the new files are stored in the Flash memory to recall them at the next boot (usually with "Recall. No").

You may call the CFG24 or CFG11 utility from WTn52 application [Main Menu](#) later to modify network parameters.

You may exit to DOS with the F10 ([FUNC]+[0]) function from [Main Menu](#) to perform DIAG24 or DIAG11 "site survey" utility.

# Chapter 2 – Network Configuration

---

Network parameters need to be configured in the Host and Client systems, and sometimes in other network devices.

Ask your Network Administrator for:

Network parameters

- The [Default Router](#) (if any).
- The [Subnet Mask](#)

Host parameters

- The Host Computer IP address.
- The Telnet port (standard is 23).

Terminal parameters

- The [PDT IP](#) address (if [bootp](#) is not used).
- The [ESS Id](#) used by the 802.11 S24 radio network.

## 2.I Network

### 2.I.1 IP Addressing

IP addresses have 4 decimal numbers from 0 to 255. Addresses are provided in "dotted decimal" form. One part of the IP address (the left) is *"the subnet"* and the other part of the IP address (the right) is *"the computer"*.

The subnet Mask determines which numbers of the IP address belong to the left or the right part. The Subnet Mask must be **the same** across the network.

Subnet masking has 4 decimal numbers, usually 0 or 255. Subnet masking means the part of the IP address that is *"the subnet"*, and the part of the address that is *"the computer"*. **Usually** subnet mask is:

- 255.0.0.0 (The first number is *"the subnet"*, the three others are *"the computer"*).
- 255.255.0.0 (The two first numbers are *"the subnet"*, the two others are *"the computer"*).
- 255.255.255.0 (The three first numbers are *"the subnet"*, the other is *"the computer"*).

### 2.I.2 Router

See the address of the Host computer, the terminal and the subnet mask to determine if they are or not into the same subnet.

Host computer and PDT S24 terminals will be in the same subnet, in this case, no router is needed.

If Host computer and PDT S24 terminals are not in the same subnet, a router is needed. The router address **must** be in the same subnet as the terminal.

## 2.II Host

Start the Telnet host "service" or "daemon". You may verify the host address by the "ping" utility from a Windows-based PC. You may verify if the telnet service is available, using a "telnet" client program from any Windows-based PC.

## 2.III Terminal

The terminal is configured in two ways:

**The network and terminal parameters**, by the CFG24 or CFG11 utility:

- The [Default Router](#) (if any).
- The [Subnet Mask](#)
- The [PDT IP](#) address (if [bootp](#) is not used).
- The [ESS Id](#) used by the 802.11 S24 radio network.

The CFG24 utility is called at boot time in the terminal, or can be called from the main menu by the "F3 S24 Configuration" Option.

```
RR 10.10.10.99
RR Wireless Telnet
- WTn52 Ver X.X.XX -
-----
F1 EMULATION
F2 WT Configuration
F3 S24 Configuration
F4 See Options
```

[FUNC] [3]

See [Appendix E - CFG24 / CFG11 Utility](#).

**The Host parameters**, by the WTn52 configuration menu.

- The Host Computer IP address.
- The Telnet port (standard is 23).

This parameters are initialized by the configuration file ([\\_WTn52.Cfg](#)) and may be changed by the user, by the main menu option "F2 WT Configuration".

```
RR 10.10.10.99
RR Wireless Telnet
- WTn52 Ver X.X.XX -
-----
F1 CONNECT
F2 WT Configuration
F3 S24 Configuration
```

F4 See Options

[FUNC] [2] (The password is 248)

```
=====
SESSION-NAME
=====
Host IP Address
10.10.10.1|
Port : 23|

[F1]=Abort
```

[CLEAR] Clears the line

[ENTER] save and goes to the next field

[BKSP] Erases the last character

[FUNC] [1] Aborts, do not modify.

These modifications are stored in volatile memory, and are set to default configuration values when "[Bios Boot](#)".

# Chapter 3 – Terminal Operation

---

## 3.I Connecting to the host

### 3.I.1 Main Menu

The IP address shown in the top of display is the terminal IP address.

```
RR 10.10.10.99
RR Wireless Telnet
- WTn52 Ver X.X.XX -
-----
F1 EMULATION
F2 WT Configuration
F3 S24 Configuration
F4 See Options
```

Press [FUNC] [1] to go to connection screens.

### 3.I.2 Connecting

```
SESSION-NAME
10.10.10.1
Port : 23
[ENTER] Connect
[CLR] Exit
```


Press [ENTER] to connect, [ESC] to return to main menu, and any other key to go to the next session.

```
Connecting To
SESSION-NAME
10.10.10.1
Port : 23
```

While connecting to the host, wait for a few seconds. If the [IP address](#) or [Port](#) are not correct, from main menu press [\[F2\]](#) to change the configuration. The default [address](#) and [port](#) come from configuration file.

### 3.I.3 Connected

After Telnet connection:



```
Connected To
10.10.10.1:23
```

If the terminal is [selected by host](#), the current terminal type (*TERMINAL*) appears.

Following the application, enter the user name and password.

### 3.I.4 Out Of range

If the terminal is out of S24 radio network range, the terminal holds the connection and asks to retry or abort the session. The following screen appears:



```
***** ERROR *****
RADIO
OUT OF RANGE

[ENTER] To Retry
[CLEAR] To Abort
```

If the session is aborted, the Telnet connection may remain opened in the host side and you should manually shut it down in the host.

On retry, the terminal tries to send the current transaction. Move to a radio covered area to retrieve the host session.

### 3.II Ending session

While connected to a telnet session, the session will be closed by the host, or by the user. To close the Telnet connection, enter the [end sequence](#) (normally Ctrl-X), and the terminal returns to the [main menu](#).

### 3.III Changing Host IP Address

From the [Main Menu](#), press [FUNC] [2] to access to the [configuration](#). This is the active address, until a Bios Boot.

### 3.IV Printing

A printer may be attached to the serial port of the PDT. The 5250 special display allows redirecting the data flow to the printer. The printer driver in WTn52 is designed for "label" printers instead of "line" printers, and data is stored in the terminal to allow reprint operations.

While storing printer data, the terminal displays:

```
===== Loading =====
```

Before printing, the terminal connects to the printer and displays:

```
===== Connecting =====
```

```
===== Printing =====
```

If printer is not responding, the terminal displays:

```
***** ERROR *****  
PRINTER  
NOT CONNECTED  
  
[ENTER] To Retry  
[CLEAR] To Abort
```

- [ENTER] Retries the whole connection and printing operation.
- [CLEAR] Aborts operation and suppresses printing data.

After a print operation, the following screen appears:

```
===== PRINTING  
=====  
LABEL  
PRINTED
```



[ENTER] To Continue  
[F1] To Reprint

- [ENTER] restores the display and continues with terminal operations.
- [F1] Redo the last print operation.

### 3.V Scanning

The scanner activation is done through the trigger keys, depending on the terminal model. The scanner is [activated](#) and configured by the [SCANNER](#) section in the configuration file. Each barcode [symbology](#) has a specific section in the same file.

The behavior of the barcode readings in the emulated terminal is configured in the [BARCODES](#) section.

Barcodes will be edited to fit in the application fields. See the [BC\\_DEBIT](#) section in configuration file.

### 3.VI Keyboard Operation

The PDT Keyboard is **"one finger"** operating. When a keystroke needs a combination of several keys, those keys should be pressed sequentially (**not at the same time** like PC's Keyboard).

To make a "Function + Control + Up-Arrow" function (e.g. to do a logical scroll up), do the following sequence:

- Hit the [FUNC] key, then
- Hit the [CTRL] key, then
- Hit the  Key.

The displayed blinking cursor reflects the keyboard state.

The PDT Keyboard changes depending on the terminal. The same terminal may be shipped with different keyboards. The PDT keyboard has the following states:

Keyboard state	Key Sequence	Cursor Display
<i>Normal state</i> <b>locked</b> , (toggle with Alpha key).	[ALPHA] key	<b>v</b>
<i>Alpha state</i> (in 35 keys terminals) <b>locked</b> , (toggle with Alpha key).	[ALPHA] key	<b>^</b>
<i>Shift state</i> , <b>single</b> .	[SHIFT] key	<b>^</b>
<i>Control state</i> , <b>single</b> .	[CTRL] key	<b>c</b>
<i>Function state</i> , <b>single</b> .	[FUNC] key)	<b>f</b>
<i>Function-Control</i> or " <i>Alt</i> " state, <b>single</b> .	FUNC]+[CTRL] keys	<b>a</b>
<i>Shift-Function</i> state, <b>single</b> .	[SHIFT]+[FUNC] keys	<b>F</b>

**Locked**, means that the state remains locked, and changes each time the [ALPHA] key is pressed ("toggle" system).

**Single**, means that the state applies **only** for the next keystroke, and then returns to the normal previous state.

**WTn52** has terminal functions that are called by keyboard keystrokes. The scan codes assignments are done by the configuration file ([Chapter 5](#)) and may be changed. *Scan codes generated by PDT terminals may change following the terminal model or the keyboard model.*

Some function keys are trapped by the PDT operating system and perform some specific functions like "Lamp" (Backlight), "Dark" (dark LCD display), "Light" (dim LCD display), and **may not be used** for other functions.

See also [Appendix F – Keyboard Reference](#).

See also [Appendix A – Terminal Functions](#).

You can see the scan code for each key in the terminal by following "[F4] See Options / [F1] FN KEYS / [F1] SCAN CODES".

### 3.VII Screen and display

The displayed cursor reflects the keyboard state (see [Chapter 3.VI - Keyboard Operation](#)).

The emulated terminal normally has a 24 lines and 80 rows screen. WTn52 allows configuring non-standard display sizes emulation, up to 80 rows and 24 lines (See the [EMULATION](#) section).

The PDTs have a display with 8 or 16 lines and 20 or 21 rows. WTn52 allows to use it in "[double height](#)" (show 8 lines in a 16 lines terminal) to increase text visibility (and / or "[double width](#)").


For easy-to-use applications it is recommended to write or adapt them to the physical display size of the hand held terminal.

WTn52 has a "Logical Scroll" mechanism to allow large screen sizes to be mapped into the smaller PDT display (See the [SCROLL](#) section). The map may be fixed or moving, controlled by the [FixedMode=](#) option.

It is not recommended to use the moving option in an application, because users need to learn the function keys to scroll, and understand the "Logical Scroll" system.

The "Logical Scroll" system automatically moves the PDT display into the screen area, following "edges", to show a display area around the cursor position.

The user may move the display area into the screen by using "[Logical Scroll Keys](#)".



In the fixed mode, the position of the display in the emulated screen is fixed, even if the cursor goes out of the display area.

### 3.VIII Troubleshoot

The RF transmission is a complex program with many protocol layers (RF, Ethernet, IP, TCP) in the operating system and a user application (client). This protocol stack in hand held terminals is subject to unexpected power off conditions (batteries removed, shocks, etc) that may prevent the terminal software to manage correctly some protocol sequences and may "hang" the terminal.

To restart the terminal in proper conditions, it will be necessary to reboot it by a "Bios Boot" command. See [Appendix F.II - Boot Sequences](#).

# Chapter 4 – Local Operations

---

## 4.I Main Menu

The IP address shown at the top of display is the terminal IP address.

```
RR 10.10.10.99
RR WireLess TelNet
- WTn52 Ver X.X.XX -

-----
F1 EMULATION
F2 WT Configuration
F3 S24 Configuration
F4 See Options
```

- [\[F1\]](#) Press [FUNC]+[1] to go to connect screens (See [Chapter 3](#)).
- [\[F2\]](#) Press [FUNC]+[2] to modify the Host's IP address and port.
- [\[F3\]](#) Press [FUNC]+[3] to modify network parameters with the CFG24 or CFG11 utility (See [Appendix E](#)).
- [\[F4\]](#) Press [FUNC]+[4] to view the present configuration options.

You may exit to DOS with the F10 ([FUNC]+[0]) function to execute the DIAG24 or DIAG11 "site survey" utility.

## 4.II WT Configuration

[F2] WT Configuration

```
-----
SESSION-NAME
-----
Host IP Address
10.10.10.1
Port: 23

[F1]=Abort
```


- [CLEAR] Clears the line
- [ENTER] save and goes to the next field
- [BKSP] Erases the last character
- [FUNC] [1] Aborts, do not modify

These modifications are stored in volatile memory, and are set to default configuration values in "[Bios Boot](#)".

## 4.III View Options

### 4.III.1 Main Menu

[F4] See Options



```
F1 PDT TERMINAL
F2 TELNET
F3 EMULATION
F4 SCROLL
F5 SCANNER

[ENTER] Next
```

- [\[F1\]](#) PDT TERMINAL
- [\[F2\]](#) TELNET
- [\[F3\]](#) EMULATION
- [\[F4\]](#) SCROLL
- [\[F5\]](#) SCANNER



```
F1 KEYS
F2 PRINTER
F3 FONTS
F4 BEEPS
F5 DEBUG
F6 ERROR MSG

[ENTER] Previous
```

- [\[F1\]](#) KEYS
- [\[F2\]](#) PRINTER
- [\[F3\]](#) FONTS
- [\[F4\]](#) BEEPS
- [\[F5\]](#) DEBUG
- [\[F6\]](#) ERROR MSG

## 4.III.2 PDT TERMINAL

[F4] See Options / [F1] PDT TERMINAL  
[Terminal](#) section present Options.

```
<MsgFile>
<Font>
Backlight
BLAutoOn
UserTmout
KeyClick
LocalBeeps
BeepFreq
BeepDur
DoubleHeight
DoubleWidth
PwdWConf
PwdRfConf
PwdExit
```

MsgFile  
Font  
Backlight  
BLAutoOn  
UserTmout  
KeyClick  
LocalBeeps  
BeepFreq  
BeepDur  
DoubleHeight  
DoubleWidth  
PwdWConf  
PwdRfConf  
PwdExit

## 4.III.3 TELNET

### 4.III.3.1 TELNET / TELNET MENU

[F4] See Options / [F2] TELNET

```
***** TELNET *****
F1          SESSIONS
F2    BY    SESSION
F3          TELNET

[CLEAR] To End
```

- [\[F1\]](#) SESSIONS

- [\[F2\]](#) BY SESSION
- [\[F3\]](#) TELNET

#### 4.III.3.2 TELNET / SESSIONS

[F4] See Options / [F2] TELNET / [F1] [SESSIONS](#)

SESSIONS	
Max	X
KeyNext	XXXXh
KeyPrev	XXXXh

Max  
KeyNext  
KeyPrev

#### 4.III.3.3 TELNET / BY SESSION

[F4] See Options / [F2] TELNET / [F2] BY SESSION

SESSION	
No	X
XXXXXXXXXX	
000.000.000.000	
Port	23
TTypeSelByHost	
TTypePreferred	
Norm. XXXXXXXXXXXX	
Name XXXXXXXXXXXX	

No <X>  
<SessName>  
<HostIp> 000.000.000.000  
Port  
TTypeSelByHost  
TTypePreferred  
Norm.<name> (normalized name)  
Name <name>

#### 4.III.3.4 TELNET / TELNET

[F4] See Options / [F2] TELNET / [F3] TELNET  
Telnet section present options.

```
TelOpEchoHost
TelOpBinHost
TelOpBinTerm
TelOpEorHost
TelOpEorTerm
TelOpSgaHost
TelOpSgaTerm
TelOpNawsTerm
TelOpEnvTerm
TelOpTTypeTerm
DoTcpAlive
```

```
TelOpEchoHost
TelOpBinHost
TelOpBinTerm
TelOpEorHost
TelOpEorTerm
TelOpSgaHost
TelOpSgaTerm
TelOpNawsTerm
TelOpEnvTerm
TelOpTTypeTerm
DoTcpAlive
```

#### 4.III.4 EMULATION

[F4] See Options / [F3] EMULATION  
[Emulation](#) section present options.

```
Column
Underline
Bold
Blink
Caps
Lower
HostBeeps
BeepFreq
BeepDur
BeepTimes
TermWidth
TermHeigth
EndScanCode
UnlkScanCode
FreeCursor
SetKbdOnNum
SetKbdOnAlpha
CodePage
RcvTmout
```

Column  
Underline  
Bold  
Blink  
Caps  
Lower  
HostBeeps  
BeepFreq  
BeepDur  
BeepTimes  
TermWidth  
TermHeight  
EndScanCode  
UnlkScanCode  
FreeCursor  
SetKbdOnNum  
SetKbdOnAlpha  
CodePage  
RcvTmout

#### 4.III.5 SCROLL

[Scroll](#) section present options.  
[F4] See Options / [F4] SCROLL



FixedMode  
StartPosX  
StartPosY  
ScrollX  
ScrollY  
KeyUp  
KeyDown  
KeyLeft  
KeyRight  
EdgeLeft  
EdgeRight  
EdgeUp  
EdgeDown

FixedMode  
StartPosX  
StartPosY  
ScrollX  
ScrollY  
KeyUp  
KeyDown  
KeyLeft  
KeyRight  
EdgeLeft  
EdgeRight

EdgeUp  
EdgeDown

## 4.III.6 SCANNER

[F4] See Options / [F5] SCANNER

```
***** SCANNER *****
F1 SCANNER OPTIONS
F2 BARCODES
F3 SYMBOLOGIES
F4 BARCODE TEST
F5 BARCODE EDIT

[CLEAR] To End
```

- [\[F1\]](#) SCANNER OPTIONS
- [\[F2\]](#) BARCODES
- [\[F3\]](#) SYMBOLOGIES
- [\[F4\]](#) BARCODE TEST
- [\[F5\]](#) BARCODE EDIT

### 4.III.6.1 SCANNER / SCANNER OPTIONS

[Scanner](#) section present options.

[F4] See Options / [F5] SCANNER / [F1] SCANNER OPTIONS

```
Enable
TurnOffScan
Suffix
Prefix
BeepOnDecode
BeepFreq
BeepDur
ScanTmout
Redundancy
SpottingBeam
```

Enable  
TurnOffScan  
Prefix  
Suffix  
BeepOnDecode  
BeepFreq  
BeepDur  
ScanTmout  
Redundancy  
SpottingBeam

### 4.III.6.2 SCANNER / BARCODES

[Barcodes](#) section present options.

[F4] See Options / [F5] SCANNER / [F2] BARCODES

```
ClearField
EmbeddedAid
EscapeForAid
BcInField
WarnTrunc
DoFieldExit
DoEnter
```

ClearField  
EmbeddedAid  
EscapeForAid  
BcInField  
WarnTrunc  
DoFieldExit  
DoEnter

#### 4.III.6.3 SCANNER / SYMBOLOGIES

[F4] See Options / [F5] SCANNER / [F3] SYMBOLOGIES

```
XXXXXXXXX
On
Min
Max
Opt
```

Where:

XXXXXXXXX = Symbology  
See [\[<Symbology>\]](#) Sections.

On  
Min  
Max  
Opt

Hit any key to browse **all** the barcode symbologies.

#### 4.III.6.4 SCANNER / BARCODE TEST

[F4] See Options / [F5] SCANNER / [F4] BARCODE TEST

```
Scan      A      Barcode
[]
<Symbology>
<contents>

[CLEAR] To End
```

Scan a barcode.

Where:

<Symbology>: Is the barcode symbology of the scanned barcode.

<Contents>: Is the content of the scanned barcode.

#### 4.III.6.5 SCANNER / BARCODE EDIT

[BC\\_EDIT](#) section present options.

[F4] See Options / [F5] SCANNER / [F5] BARCODE EDIT

```
BARCODE      EDIT
No=X          On      X
MatchDo
MatchPos
<MatchStr>
<Filter>
<Insert>
```

No=X

On

MatchDo

MatchPos

<MatchStr>

<Filter>

<Insert>

### 4.III.7 KEYS

#### 4.III.7.1 KEYS / MENU

[F4] See Options / [F1] KEYS

```
*****  KEYS  *****
F1          SCANCODES
F2 TELNET  FN  KEYS

[CLEAR] To End
```

- [F1](#) SCANCODES
- [F2](#) TELNET FN KEYS

#### 4.III.7.2 KEYS / SCANCODES

[F4] See Options / [F1] KEYS / [F1] SCANCODES

```
SCANCODE          TEST
Press      any    Key
SC          [XXXXh]

[CLEAR] To End
```

Press any key to display the keyboard scan code.

#### 4.III.7.3 KEYS / TELNET FN KEYS

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS

```
** TELNET FN KEYS **
F1      AID      KEYS
F2      AID      PF01  PF12
F3      AID      PF13  PF24
F4      SIGNAL_KEYS
F5      CONTROL_KEYS
F6      CURSOR_KEYS
[CLEAR] To End
```

- [F1](#) AID KEYS
- [F2](#) AID PF01 PF12
- [F3](#) AID PF13 PF24
- [F4](#) SIGNAL KEYS
- [F5](#) CONTROL KEYS
- [F6](#) CURSOR KEYS

##### 4.III.7.3.1 KEYS / TELNET FN KEYS / AID KEYS

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS / [F1] AID KEYS

[AID\\_KEYS](#) section present options. The keyboard scan codes assigned to function keys.

```
Clear
Enter
Help
RollDown
RollUp
RollLeft
RollRight
Print
PA1
PA2
PA3
```

Clear  
Enter

Help  
RollDown  
RollUp  
RollLeft  
RollRight  
Print  
PA1  
PA2  
PA3

#### 4.III.7.3.2 KEYS / TELNET FN KEYS / AID PF01 PF12

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS / [F2] AID PF01 PF12

[AID\\_PF1\\_KEYS](#) section present options. The keyboard scan codes assigned to function keys.

AID	PF01	PF12
PF01		[XXXXh]
PF02		[XXXXh]
PF03		[XXXXh]
PF04		[XXXXh]
PF05		[XXXXh]
PF06		[XXXXh]
PF07		[XXXXh]
PF08		[XXXXh]
PF09		[XXXXh]
PF10		[XXXXh]
PF11		[XXXXh]
PF12	[XXXXh]	

PF01  
PF02  
PF03  
PF04  
PF05  
PF06  
PF07  
PF08  
PF09  
PF10  
PF11  
PF12

#### 4.III.7.3.3 KEYS / TELNET FN KEYS / AID PF13 PF24

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS / [F3] AID PF13 PF24

[AID\\_PF2\\_KEYS](#) section present options. The keyboard scan codes assigned to function keys.

AID	PF13	PF24
PF13		[XXXXh]
PF14		[XXXXh]
PF15		[XXXXh]
PF16		[XXXXh]
PF17		[XXXXh]

PF18	[XXXXh]
PF19	[XXXXh]
PF20	[XXXXh]
PF21	[XXXXh]
PF22	[XXXXh]
PF23	[XXXXh]
PF24	[XXXXh]

PF13  
PF14  
PF15  
PF16  
PF17  
PF18  
PF19  
PF20  
PF21  
PF22  
PF23  
PF24

#### 4.III.7.3.4 KEYS / TELNET FN KEYS / SIGNAL KEYS

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS / [F4] SIGNAL KEYS

[SIGNAL\\_KEYS](#) section present options. The keyboard scan codes assigned to function keys.

SIGNAL	
Attention	[XXXXh]
Help	[XXXXh]
SysReq	[XXXXh]
TestReq	[XXXXh]

Attention  
Help  
SysReq  
TestReq

#### 4.III.7.3.5 KEYS / TELNET FN KEYS / CONTROL KEYS

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS / [F5] CONTROL KEYS

[CONTROL\\_KEYS](#) section present options. The keyboard scan codes assigned to function keys.

CONTROL	
BkSp	[XXXXh]
Dup	[XXXXh]
FieldPlus	[XXXXh]
FieldMinus	[XXXXh]
FieldExit	[XXXXh]
Delete	[XXXXh]
EraseInput	[XXXXh]
ErrorReset	[XXXXh]
Home	[XXXXh]
Insert	[XXXXh]

ForwTab	[XXXXh]
BackTab	[XXXXh]
End	[XXXXh]
EraseEof	[XXXXh]
FieldMark	[XXXXh]
CursorSelect	[XXXXh]

BkSp  
Dup  
FieldPlus  
FieldMinus  
FieldExit  
Delete  
EraseInput  
ErrorReset  
Home  
Insert  
ForwTab  
BackTab  
End  
EraseEof  
FieldMark  
CursorSelect

#### 4.III.7.3.6 KEYS / TELNET FN KEYS / CURSOR KEYS

[F4] See Options / [F1] KEYS / [F2] TELNET FN KEYS / [F6] CURSOR KEYS

[CURSOR KEYS](#) section present options. The keyboard scan codes assigned to function keys.

CURSOR	
UP	[XXXXh]
DN	[XXXXh]
LE	[XXXXh]
RI	[XXXXh]

CursorUp  
CursorDown  
CursorLeft  
CursorRight

#### 4.III.8 PRINTER

[Printer](#) section present options.

[F4] See Options / [F2] PRINTER

Type
Port
Baud
Parity
DataBits
StopBits
FlowControl
Dsr

```
Cts
Cd
Tmout
AskReprint
```

Type  
Port  
Baud  
Parity  
DataBits  
StopBits  
FlowControl  
Dsr  
Cts  
Cd  
Tmout  
AskReprint

### 4.III.9 FONTS

[F4] See Options / [F3] FONTS

```
XXXXXXXXXXXXXXXXXXXX 0F
XXXXXXXXXXXXXXXXXXXX 1F
XXXXXXXXXXXXXXXXXXXX 2F
XXXXXXXXXXXXXXXXXXXX 3F
XXXXXXXXXXXXXXXXXXXX 4F
XXXXXXXXXXXXXXXXXXXX 5F
XXXXXXXXXXXXXXXXXXXX 6F
XXXXXXXXXXXXXXXXXXXX 7F

XXXXXXXXXXXXXXXXXXXX 8F
XXXXXXXXXXXXXXXXXXXX 9F
XXXXXXXXXXXXXXXXXXXX AF
XXXXXXXXXXXXXXXXXXXX BF
XXXXXXXXXXXXXXXXXXXX CF
XXXXXXXXXXXXXXXXXXXX DF
XXXXXXXXXXXXXXXXXXXX EF
XXXXXXXXXXXXXXXXXXXX FF
```

See [\[TERMINAL\]](#) section.

Displays each character of the current font. Each line contains 16 characters, from 00h to 0Fh. The address corresponds to the last displayed character of the line.

### 4.III.10 BEEPS

Beeps sounds. Hit any key to hear the beep. Hit [CLEAR] to change the beep.

[F4] See Options / [F4] BEEPS

```
XXXXXXXXXX
```



[CLEAR] To End

LOCAL BEEP  
HOST BEEP  
BARCODE BEEP

### 4.III.11 DEBUG

[Debug](#) section present options.  
[F4] See Options / [F5] DEBUG



InLog  
<InFile>  
OutLog  
<OutFile>

InLog  
<InFile>  
OutLog  
<OutFile>

### 4.III.12 ERROR MESSAGES

[ERROR\\_MSG](#) section present options.  
[F4] See Options / [F6] ERROR MESSAGES



ERROR MESSAGES  
BeepOnError  
BeepFreq  
BeepDur  
BeepTimes  
ResetByEnter  
ResetByAny  
ResetTime  
NoMsgLine

BeepOnError  
BeepFreq  
BeepDur  
BeepTimes  
ResetByEnter  
ResetByAny  
ResetTime  
NoMsgLine

## 4.IV Boot Menu

This Menu appears only after a "[Bios Boot](#)" and allows to download "[dynamic](#)" configuration files.

See [Appendix C](#). for download configuration files.

```
RR 10.10.10.99
RR Wireless Telnet
- WTnDnl Ver X.X.X -
=====
Config. Download ?
F1 = By RsLink
F2 = By Radio
ENTER = Use As Is
```

- [F1] Press [FUNC]+[1] to download the configuration files by [RsLink](#) (serial connection).
- [F2] Press [FUNC]+[2] to download the configuration files by [WTDnl](#) (network connection).
- [ENTER] press ENTER key to use the present PDT configuration files (no download) and fall down to the [main menu](#).

### 4.IV.1 WTDnl Configuration

[F2] By Radio

```
=====
= IP Server WTDNL =
=====
Server IP Address
10.10.10.1
Port : 3001

[F1] = Abort
```

Supply the IP address of the host computer that has the WTDnl program running, and the port.

[CLEAR] Clears the line  
[ENTER] save and goes to the next field  
[BKSP] Erases the last character  
[FUNC] [1] Aborts, do not modify and abort download.

This modifications are stored in flash memory if successful download, and are restored when "[Bios Boot](#)".

See APPENDIX C for [WTDnl](#).

# Chapter 5 – Configuration File Options

---

## 5.I Features and syntax

The WT configuration file is a text file containing the default values for the WT options and several keyboard sequences generated by the terminal. Some of those values could be dynamically modified by the Host system. The name of this file is always "**\_WTn52.Cfg**".

The WT configuration file is a "Windows dot-ini-Like" text file, with sections, keys and values.

Configuration file includes :

- Comments
- Sections
- Keys
- Values

Lines in configuration file must be: Comments, Sections, Keys + Values or empty lines.

### 5.I.1 Comments

Comments in WT configuration file are indicated by two "slash" characters and take effect to the end of the line. i.e.:

*// This is a comment*

*This is not a comment (must be a section, a key + value or an empty line)*

### 5.I.2 Sections

Sections group the options, keys and values. Section names are in capital letters surrounded by brackets. i.e.: [TELNET], denotes the Telnet section.

The order of the sections in the file is not relevant.

### 5.I.3 Keys

Keys are keywords that have sense into their own section, and can't be moved from one section to another. Case (lowercase or uppercase) is not relevant for keywords, but they may be more readable. Keys must be followed by "=" sign and the value of the parameter, i.e.: *LocalBeeps=Yes*.

### 5.I.4 Values

Values follow the keys and the "=" sign. Each parameter expects the value in a fixed format (indicated with the parameter definition like "<format>"). Values may be empty in some cases.

Formats are :

**<Yes/No>**

Needs a *Yes* or *No* value.

**<string / xxxx>**

Text ASCII characters, delimited or not by the " (inverted commas) character. If the string is delimited by ", the spaces (20h) are preserved, otherwise are ignored. xxx indicates the units or the meaning of the value.

**<hex-string>**

In this format, three characters represent one final character. There are three ways to supply "hex-strings" (each target character takes always 3 source characters) :

Mnemonic	Format	Description
"Escaped"	"/HH"	A slash ("/" or "\") and a two-digit hexadecimal value. i.e.: \1B for character 27.
"Numeric"	"999"	Three decimal digits, i.e.: 065 for character "A".
"Alphabetic"	".A"	Two dots and an alphabetic character, i.e.: .X for character "X"

Hex-strings may be delimited by " to be more readable.

**<num / xxxx>**

Decimal numeric value (0 - 9). xxx indicates the units or the meaning of the value.

**<word>**

Hexadecimal four-digits value, i.e.: A50F.

**<uppercase letter>**

One uppercase character, i.e.: N.

## 5.II Sections

### [/TERMINAL/](#)

This section groups the PDT-specific features.

### [/SESSIONS/](#)

This section allows to configure the host sessions available for the user.

### [/SESSION X/](#)

These sections (\_0 to \_3) group the Telnet connection options specific for each session.

### [/TELNET/](#)

This section groups the features for the Telnet level negotiation and options and network features.

### [/EMULATION/](#)

This section groups the Terminal emulation level features.

### **[AID KEYS]**

This section groups the functions that send the input data and an AID code to the host. Each function is associated to a configurable keyboard scan-code. Functions are not configurable, but keyboard is.

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [F1] SCAN CODES.

### **[AID PF1 KEYS]**

This section groups the F1-F12 AID+data functions.

### **[AID PF2 KEYS]**

This section groups the F13-F24 AID+data functions.

### **[SIGNAL KEYS]**

The signal keys send a signal frame w/o data or AID code.

### **[CONTROL KEYS]**

This function performs Local processing, and sometimes sends AID codes and input data.

### **[CURSOR KEYS]**

Local Cursor Movement Keys.

### **[ERROR MSG]**

This section groups the options that control the terminal behavior when an error occurs and the way to handle the user message line.

### **[BARCODES]**

This section groups the emulation options for Barcode reading.

### **[SCROLL]**

This section groups the "Logical scrolling" options to allow to map a standard 24x80 screen in a 8, or 16 PDT display.

### **[SCANNER]**

This section groups the global scanner operation options.

### **[UPC E0]**

**[UPC\_E1]**

**[UPC\_A]**

**[EAN\_8]**

**[EAN\_13]**

**[MSI]**

**[CODABAR]**

**[CODE\_39]**

**[CODE\_D25]**

**[CODE\_I25]**

**[CODE\_11]**

**[CODE\_93]**

**[CODE\_128]**

**[PDF\_417]**

These sections group the symbology-specific options.

**[BC\_EDIT\_X]**

These sections group the barcode editing sections.

**[PRINT\_DATA]**

This section groups the options of the display-to-printer system.

**[PRINTER]**

This section groups the options for the PDT-attached printer.

**[DBGOPT]**

This section groups the options for debugging files generation.

### 5.III [TERMINAL] Section

This section groups the PDT-specific features.

**MsgFile**=<string / name> (empty)

Country Local File messages, you could translate or modify the messages that appear in the PDT Display.

**Font**=<string / name> (empty)

Name of the PDT font file. the supplied files are : 8859\_1.fnt. See also [Appendix B](#).

You may modify or create new files for PDT with FontBld.exe (Included in Symbol Technologies Series 3000 SDK).

**BackLight**=<num / seconds> (4)

PDT's display backlight timeout (in seconds).

**BLAutoOn**=<Yes/No> (Yes)

Yes=backlight is on every time the user strikes a PDT key.

**UserTmout**=<num / seconds> (120)

Time after which, if there is no user action, the terminal enters in sleep mode. Terminal may be waken up by scanner trigger or [PWR] key at the same point.

**KeyClick**=<Yes/No> (No)

Yes=Striking a PDT key produces a short click.

**LocalBeeps**=<Yes/No> (Yes)

Some "Local" functions (internal to PDT) produce a beep.

**BeepFreq**=<num / Hertz> (1600)

Local beep frequency.

**BeepDur**=<num / milliseconds> (200)

Beep duration in milliseconds.

**DoubleHeight**=<Yes/No> (No)

Displays the characters in "Double Height". Each character takes a 2-Line height.

**DoubleWidth**=<Yes/No> (No)

Displays the characters in "Double Width". Each character takes a 2-character width.

**PwdWConf**=<string / name> (empty)

The password to access to the local WTn configuration menu. 248.

**PwdRfConf**=<string / name> (empty)

The password to access to the CFG24/CFG11 R.F. configuration program. 307.

**PwdExit**=<string / name> (empty)

The password to exit to DOS. 307.

## 5.IV [SESSIONS]

This section allows to configure the host sessions available for the user.

**Max**=<num / sessions> (4)

Maximal number of sessions, range 1-4.

**KeyPrev**=<word / scancode> (2D00 Fn-Ctl-Y)

Previous session key.

**KeyNext**=<word / scancode> (2C00 // Fn-Ctl-Z)

Next session key.

## 5.V [SESSION\_X]

These sections (\_0 to \_3) group the Telnet connection options specific for each session.

**SessName**=<string / name> (empty)

Is the name of the session, displayed to the user.

**HostIP**=<string / address> (0.0.0.0)

Host IP address or 0.0.0.0. This is the default Host IP Address. The user may overwrite this value. This value is recalled in a "Bios Boot Sequence".

**Port**=<num / port #> (23)

Telnet connection port at host IP address. The user may overwrite this value. This value is recalled in a "Bios Boot Sequence".

**TTypeSelByHost**=<Yes/No> (Yes)

In order to set this option to Yes, needs [TelOpTTypeTerm=Yes](#) too. If WT option [TelOpTTypeTerm](#) is No, set this option to No too.

Telnet protocol allows the host to select the most convenient terminal-type from a list (normally following host custom settings) indicating which types of terminal emulation are available in the client side and which type of terminal emulation is wished by the user.

\* If *TTypeSelByHost*=Yes: The final terminal type emulation done by WtN is selected by the Host.

\* If *TTypeSelByHost*=No: Terminal type emulation selected by user (*TTypePreferred*=) is not modifiable by the Host. (Information is only sent to the host for application purposes).

***TTypePreferred***=<number> (0)

0=5251-11

1=5291-1

2=5292-2

3=3179-2

4=3196-A1

5=3270

\* If *TTypeSelByHost*=Yes: This terminal is indicated to the host as the preferred by the user in the available terminal-type list.

\* If *TTypeSelByHost*=No : This terminal is indicated to be the only emulation possible by the terminal (no list).

***TTypeName***="<string / Name>" (empty)

Telnet terminal type negotiation uses "normalized" terminal types names, but some hosts may need other specific forms.

If this string is empty, WtN uses system "normalized" strings. If not empty, sends the string as the name of the user preferred terminal type (*TTypePreferred*=).

***DevName***="<string / Name>" (empty)

The Device Name (Or Workstation ID) negotiated with "environment" telnet option (see *TelOpEnvTerm* in [TELNET](#) section).

Using "[IP]", is a generic mask for last digits of IP address, (xxx[IP]yyy becomes xxx53yyy for a terminal with 999.999.999.53 IP address.

## 5.VI [TELNET] Section

This section groups the features for the Telnet level negotiation and options and network features. Telnet protocol has "Options" that can be negotiated between client (WT) and Host computer.

This options are global for all the (0-3) sessions.

***TelOpEchoHost***=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host for asking the host to do "remote echo". **Avoid in 5250.**

***TelOpBinHost***=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host for asking the host to perform a "binary" connection. (The host may send characters from 00h to FFh). **Needed for 5250.**

**TelOpBinTerm**=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host indicating that the terminal wants to perform a "binary" connection. (The terminal may send characters from 00h to FFh). **Needed for 5250.**

**TelOpEorHost**=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host for asking the host to send "End Of Record" tags. **Needed for 5250.**

**TelOpEorTerm**=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host indicating that the terminal wants to send "End Of Record" tags. **Needed for 5250.**

**TelOpSgaHost**=<Yes/No> (Yes)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host to suppress the "Go Ahead" system.

**TelOpSgaTerm**=<Yes/No> (Yes)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host indicating that the terminal wants to suppress the "Go Ahead" system. (terminal never sends "Go Ahead" signal).

**TelOpNawsTerm**=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host for indicating that the terminal wants to Send NaWS ([Window Size](#)). Set this option to =Yes only if the host really needs terminal window size information.

**TelOpEnvTerm**=<Yes/No> (No)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host for indicating that the terminal wants to Send "environment" values, like "Device Name" (Workstation ID). Set this option to =Yes only if the host really needs terminal environment information.

**TelOpTTypeTerm**=<Yes/No> (Yes)

(Telnet Option) During telnet connection negotiation, the terminal sends (=Yes) a request or not (=No) to the Host indicating that the terminal wants to send the Terminal Type (what kind of terminal is connected) information to the host. (If =No, no terminal type information is sent to the host and the emulation performed by WT is that indicated by *TTypePreferred*=).

**DoTcpAlive**=<Yes/No> (Yes)

Yes = WT periodically pings the Host to test the TCP connection state.

**Passive**=<Yes/No> (Yes)

Yes=WT waits for telnet host commands.

No=WT send telnet commands to host.

## 5.VII [EMULATION] Section

This section groups the Terminal emulation level features, and the way in which some emulation features are done by WTn.

**Column**=<Yes/No> (Yes)

Yes=Map Column separator character attribute to reverse video.

No=Ignore this attribute.

**Underline**=<Yes/No> (Yes)

Yes=Map underline character attribute to reverse video.

No=Ignore this attribute.

**Bold**=<Yes/No> (Yes)

Yes=Map bold character attribute to reverse video.

No=Ignore this attribute.

**Blink**=<Yes/No> (Yes)

Yes=Map blink character attribute to reverse video.

No=Ignore this attribute.

**Caps**=<Yes/No> (No)

Yes=Force the keyboard to caps lock.

No=Let the keyboard "as is".

**Lower**=<Yes/No> (Yes)

Yes=Force the keyboard to lowercase.

No=Let the keyboard "as is".

**HostBeeps**=<Yes/No> (Yes)

Yes=Make a beep when the order is received from the host.

**BeepFreq**=<num / Hertz> (2200)

Host Beep frequency.

**BeepDur**=<num / milliseconds> (300)

Host Beep duration.

**BeepTimes**=<num / milliseconds> (1)

The times to repeat the beep.

**TermWidth**=<num / columns> (0)

Logical width of the emulated screen in columns. 0=uses default (80). Top to 80.

**TermHeight**=<num / lines> (0)

Logical height of the emulated screen in lines. 0=uses default (24). Top to 25.

**EndScanCode**=<word / scancode> (0018 / Ctrl-X)

The scan code of the key that ends the current Telnet session. Ctrl-X is the default key to End session. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\] SCAN CODES](#)".

**UnlkScanCode**=<word / scancode> (2200 / Func-Ctrl-G)

Unlocks the keyboard or the scanner if the application misses to send the unlock escape sequence after the locking sequence. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\] SCAN CODES](#)".

**FreeCursor**=<Yes/No> (No)

No=Cursor moves only in input fields.

Yes=Cursor will move in all the display area, following host configuration (by SOH flag, byte 1, bit 3).

**SetKbdOnNum**=<num / KeyboardShift> (0)

When entering in numeric fields (Num-shift, Numeric-Only, Digits-Only and Signed-Numeric), set the keyboard shift to this position:

0=Normal

1=Right Shift

2=Left Shift

4=Control

8=Alt

16=Scroll

32=Num Lock

64=Caps Lock

128=Function Shift

255="As Is"

**SetKbdOnAlpha**=<num / KeyboardShift> (0)

When entering in alphabetic fields (Alpha-shift, Alpha-Only), set the keyboard shift to this position:

0=Normal

1=Right Shift

2=Left Shift

4=Control

8=Alt

16=Scroll

32=Num Lock

64=Caps Lock

128=Function Shift

255="As Is"

**CodePage**=<string / name> (empty)

The translation table used to translate from/to IBM charmaps and ISO 8859\_1 PDT font.

Available charmap tables are:

"37"= IBM037 Charmap, USA, Can, Netherlands, Portugal, Brazil, Austria.

"273"=IBM273 Charmap, Austria, Germany.

"277"=IBM277 Charmap, Denmark, Norway.

"278"=IBM278 Charmap, Finland, Sweden.

"280"=IBM280 Charmap, Italy.

"284"=IBM284 Charmap, Catalan, Spain, Latin America.

"285"=IBM285 Charmap, UK, Ireland.

"297"=IBM297 Charmap, France.

"500"=IBM500 Charmap, Ebedic 500 V1 (?).

"871"=IBM871 Charmap, Iceland.

**RcvTmout**=<num / seconds> (0)

The seconds between the send action and the "retry message" if no response.

**DoMandEnter**=<Yes/No> (Yes)

Yes=Check the MDT (Modified Data Tag) in the fields with Mandatory Enter attribute before send.

No=Do not check.

## 5.VIII Keyboard sections

These sections group the keyboard behavior options.

### 5.VIII.1 [AID\_KEYS]

This section groups the functions that send the input data and an AID code to the host.

Each function is associated to a configurable keyboard scan-code. Functions are not configurable, but keyboard is. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\] SCAN CODES](#)".

**Clear**=<word / scan-code> (0003 / Ctl-C)

**Enter**=<word / scan-code> (001B / Clear)

**Help**=<word / scan-code> (2300 / Fn-Ctl-H)

**RollDown**=<word / scan-code> (5100 / Fn-Dn)

**RollUp**=<word / scan-code> (4900 / Fn-Up)

**RollLeft**=<word / scan-code> (0019 / Ctl-Y)

**RollRight**=<word / scan-code> (001A / Ctl-Z)

**Print**=<word / scan-code> (0010 / Ctl-P)

**PA1**=<word / scan-code> (0015 / Ctl-1 (U))

**PA2**=<word / scan-code> (0016 / Ctl-2 (V))

**PA3**=<word / scan-code> (0017 / Ctl-3 (W))

### 5.VIII.2 [AID\_PF1\_KEYS]

This section groups the F1-F12 AID+data functions. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\] SCAN CODES](#)".

**PF01**=<word / scan-code> (3b00 / Fn-1)

**PF02**=<word / scan-code> (3C00 / Fn-2)

**PF03**=<word / scan-code> (3D00 / Fn-3)

**PF04**=<word / scan-code> (3E00 / Fn-4)

**PF05**=<word / scan-code> (3F00 / Fn-5)

**PF06**=<word / scan-code> (4000 / Fn-6)

**PF07**=<word / scan-code> (4100 / Fn-7)

**PF08**=<word / scan-code> (4200 / Fn-8)

**PF09**=<word / scan-code> (4300 / Fn-9)

**PF10**=<word / scan-code> (4400 / Fn-0)

**PF11**=<word / scan-code> (5400 / Sh-Fn-1)

**PF12**=<word / scan-code> (5500 / Sh-Fn-2)

### 5.VIII.3 [AID\_PF2\_KEYS]

This section groups the F13-F24 AID+data functions. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

**PF13**=<word / scan-code> (5600 / Sh-Fn-3)  
**PF14**=<word / scan-code> (5700 / Sh-Fn-4)  
**PF15**=<word / scan-code> (5800 / Sh-Fn-5)  
**PF16**=<word / scan-code> (5900 / Sh-Fn-6)  
**PF17**=<word / scan-code> (5A00 / Sh-Fn-7)  
**PF18**=<word / scan-code> (5B00 / Sh-Fn-8)  
**PF19**=<word / scan-code> (5C00 / Sh-Fn-9)  
**PF20**=<word / scan-code> (5D00 / Sh-Fn-0)  
**PF21**=<word / scan-code> (0021 / Sh-1 "!")  
**PF22**=<word / scan-code> (0040 / Sh-2 "@")  
**PF23**=<word / scan-code> (0023 / Sh-3 "#")  
**PF24**=<word / scan-code> (0024 / Sh-4 "\$")

### 5.VIII.4 [SIGNAL\_KEYS]

The signal keys send a signal frame w/o data or AID code. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

**Attention**=<word / scan-code> (0001 / Ctl-A)  
**Help**=<word / scan-code> (2300 / Fn-Ctl-H)  
**SysReq**=<word / scan-code> (0013 / Ctl-S)  
**TestReq**=<word / scan-code> (1400 / Fn-Ctl-T)

### 5.VIII.5 [CONTROL\_KEYS]

This functions perform Local processing, and sometimes send AID codes and input data. See [Appendix A](#) for a detail of terminal functions. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

**BkSp**=<word / scan-code> (0008 / BKSP)  
Back Space. Moves cursor one column left.

**Dup**=<word / scan-code> (2000 / Fn-Ctl-D)  
Duplicate. Fills the remains of the field with "dup" characters.

**FieldPlus**=<word / scan-code> (002B / +)  
Field Plus. In signed numeric fields, puts a positive sign, and performs a field exit function. In other fields, performs a field exit function.

**FieldMinus**=<word / scan-code> (002D / -)  
Field Plus. In numeric and signed numeric fields, puts a negative sign, and performs a field exit function. Not allowed In other fields.

**FieldExit**=<word / scan-code> (000D / Enter)  
Performs the pad and adjust functions and moves to the next field.

**Delete**=<word / scan-code> (0004 / Ctl-D)  
Deletes one character under the cursor. Scroll one position to the right the rest of the filed.

**EraseInput**=<word / scan-code> (0005 / Ctl-E)

Clear all modified files.

**ErrorReset**=<word / scan-code> (0002 / Ctl-B )

Resets the " X Input Inhibit" (X II) indicator. Puts the terminal in not-error state.

**Home**=<word / scan-code> (0007 / Ctl-G )

Moves the cursor to the home position (normally the first field).

If already in home position, sends an AID "record-backspace" code.

**Insert**=<word / scan-code> (0009 / Ctl-I / Fn-SP )

Toggles the insert/replace mode.

Insert, when inputting data, moves the right chars of the field (if possible) and inserts the keyed character.

Replace, when inputting data, puts the keyed character at cursor position (replacing the previous character).

**ForwTab**=<word / scan-code> (0014 / Ctl-T )

Moves to the next field.

**BackTab**=<word / scan-code> (1400 / Fn-Ctl-T)

Moves to the previous field.

**End**=<word / scan-code> (1200 / Fn-Ctl-E)

Moves to the last data position in the field.

**EraseEof**=<word / scan-code> (000F / 3270 Ctl-O)

Erase (null) all the characters in the field at right of cursor position.

**FieldMark**=<word / scan-code> (0011 / 3270 Ctl-Q)

3270, Same as Dup.

**CursorSelect**=<word / scan-code> (0000 / 3270)

3270, Not implemented.

## 5.VIII.6 [CURSOR\_KEYS]

Local Cursor Movement Keys. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [F1] SCAN CODES".

**CursorUp**=<word / scan-code> (4800 / Up)

In [FreeCursor](#)=Yes; Cursor one line Up.

In [FreeCursor](#)=No; Cursor to previous field.

**CursorDown**=<word / scan-code> (5000 / Dn)

In [FreeCursor](#)=Yes; Cursor one line Down.

In [FreeCursor](#)=No; Cursor to next field.

**CursorLeft**=<word / scan-code> (4B00 / Le)

In [FreeCursor](#)=Yes; Cursor one column left.

In [FreeCursor](#)=No; Cursor one column left, if beginning of field, cursor to previous field.

**CursorRight**=<word / scan-code> (4D00 / Ri)

In FreeCursor=Yes; Cursor one column right.

In FreeCursor=No; Cursor one column right, if end of field, cursor to next field.

## 5.IX [ERROR\_MSG]

This section groups the options that control the terminal behavior when an error occurs and the way to handle the user message line.

**BeepOnError**=<Yes/No> (No)

Yes=Beeps when an error occurs.

**BeepFreq**=<num / Hertz> (900)

Error message beep frequency.

**BeepDur**=<num / milliseconds> (0)

Beep Duration.

**BeepTimes**=<num / times> (1)

The times to perform the beep.

**ResetByEnter**=<Yes/No> (No)

Restore the terminal to non-error state (see ErrorReset function).

Yes=Reset by ENTER key.

**ResetByAny**=<Yes/No> (No)

Restore the terminal to non-error state (see ErrorReset function).

Yes=Reset by any key.

**ResetTime**=<num / seconds> (0)

Restore the terminal to non-error state (see ErrorReset function).

Auto-Reset error after x seconds.

0=Do not perform auto-reset.

**NoMsgLine**=<Yes/No> (No)

Yes= Don't show the user error message line in the PDT display line in "floating" mode.

No= Show the user error message line in the PDT display line in "floating" mode.

## 5.X [BARCODES]

This section groups the emulation options for Barcode reading.

**ClearField**=<Yes/No> (Yes)

Yes=Clears the present (under the cursor) field in barcode reads.

No=Append the barcode data at the present cursor position.

**EmbeddedAid**=<Yes/No> (No)

The barcode may contain AID embedded codes.

Yes=Handle embedded AID codes after ESC character.  
No=send barcode "as is".

The barcode has this form : <data><esc><aid>

<data>=Normal data.

<esc>=Special separator character (see `escapeForAid`).

<aid>=AID function to perform after barcode :

'A'=AID F1

'B'=AID F2

'C'=AID F3

'D'=AID F4

'E'=AID F5

'F'=AID F6

'G'=AID F7

'H'=AID F8

'I'=AID F9

'J'=AID F10

'K'=AID F11

'L'=AID F12

'M'=AID F13

'N'=AID F14

'O'=AID F15

'P'=AID F16

'Q'=AID F17

'R'=AID F18

'S'=AID F19

'T'=AID F20

'U'=AID F21

'V'=AID F22

'W'=AID F23

'X'=AID F24

'0'=AID ENTER

'1'=AID CLEAR

'2'=AID PGDN

'3'=AID PA1

'4'=AID PA2

'5'=AID PA3

**EscapeForAid**=<hex-string / character> (..#)

Character separator for "AID" keystroke.

**BcInField**=<char / tag> (T)

T=Oversized barcodes are Truncate

S=Oversized barcodes are Split in several fields (if possible)

R=Oversized barcodes are Rejected

E=Allows only barcodes that match Exactly the size of the field.

**WarnTrunc**=<Yes/No> (No)

Perform a warning (beep) when truncating a barcode.

**DoFieldExit**=<Yes/No> (No)

Performs a field-exit function after a barcode read.

**DoEnter**=<Yes/No> (No)

Performs an ENTER function after a barcode read.

## 5.XI [SCROLL] Section

This section groups the "Logical scrolling" options to allow to map a standard 24x80 screen (called "virtual screen") in a 8, or 16x20 PDT physical display.

See also "[Screen and Display](#)" figure in [Chapter 3](#).

**FixedMode**=<Yes/No> (No)

Yes="Fixed Screen Mode". The PDT display shows a part of the terminal virtual screen, and never moves, even if the cursor is out of the display. The "Logical Scroll Keys" has no effect.

No="Auto Scroll Mode". The PDT display always shows the screen area where the cursor is. The display moves following "edges" (see [EdgeXXX](#)=). In this mode, The "Logical Scroll Keys" manually moves the display into the screen (see [KeyXXX](#)=).

**StartPosX**=<num / row> (0)

When in "Fixed Screen Mode" (see [FixedMode](#)=), the left start position for terminal display in virtual screen. The first left position is 0.

**StartPosY**=<num / line> (0)

When in "Fixed Screen Mode" (see [FixedMode](#)=), the top start position for terminal display in virtual screen. The first top position is 0.

**ScrollX**=<num / rows> (0)

When in "Auto Scroll Mode" (see [FixedMode](#)=), the number of rows that the display moves (left or right side) when [KeyLeft](#)= or [KeyRight](#)= keys are pressed. If 0 the value is initialized to the display width.

**ScrollY**=<num / lines> (0)

When in "Auto Scroll Mode" (see [FixedMode](#)=), the number of lines that the display moves (up or down side) when [KeyUp](#)= or [KeyDown](#)= keys are pressed. If 0 the value is initialized to the display height.

**KeyUp**=<word> (3200 / Fn+Ctrl+Up)

When in "Auto Scroll Mode" (see [FixedMode](#)=), the scan code of the key that moves the display up in logical screen. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

**KeyDown**=<word / scancode> (3100 / Fn+Ctrl+Up)

When in "Auto Scroll Mode" (see [FixedMode](#)=), the scan code of the key that moves the display down in logical screen. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

**KeyLeft**=<word / scancode> (2500 / Fn+Ctrl+Left)

When in "Auto Scroll Mode" (see *FixedMode*=), the scan code of the key that moves the display left in logical screen. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\] SCAN CODES](#)".

**KeyRight**=<word / scancode> (2600 / Fn+Ctrl+Right)

When in "Auto Scroll Mode" (see *FixedMode*=), the scan code of the key that moves the display right in logical screen. You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\] SCAN CODES](#)".

**EdgeLeft**=<num / rows> (4)

When in "Auto Scroll Mode" (see *FixedMode*=), the minimum number of rows that can remain in the left cursor side before making an "auto scroll".

**EdgeRight**=<num / rows> (1)

When in "Auto Scroll Mode" (see *FixedMode*=), the minimum number of rows that can remain in the right cursor side before making an "auto scroll".

**EdgeUp**=<num / lines> (1)

When in "Auto Scroll Mode" (see *FixedMode*=), the minimum number of rows that can remain above the cursor before making an "auto scroll".

**EdgeDown**=<num / lines> (1)

When in "Auto Scroll Mode" (see *FixedMode*=), the minimum number of rows that can remain under the cursor before making an "auto scroll".

## 5.XII [SCANNER] Section

This section groups the global scanner operation options.

**Enable**=<Yes/No> (Yes)

Yes=The scanner is enabled by default.

No=The scanner is disabled by default.

**TurnOffScan**=<Yes/No> (Yes)

Yes=Disable scanner after a successful reading.

**Prefix**=<hex-string> (empty)

This string is sent before the barcode.

**Suffix**=<hex-string> (empty)

This string is sent after the barcode

**BeepOnDecode**=<Yes/No> (Yes)

Yes=generates a beep after a successful good barcode reading.

No=Do not beep.

**BeepFreq**=<num / Hertz> (888)

Good scan beep frequency (in hertz).

**BeepDur**=<num / milliseconds> (200)

Beep duration in milliseconds.

**ScanTmout**=<num / seconds> (10)

Time after which the scanner turns off if continuously holding the trigger.

**Redundancy**=<num / pass> (1)

Number of good barcode readings needed to successfully decode it.

May be required if using poor quality barcodes to prevent misreading.

Warning : redundancy increases the decode time.

1=No redundancy (one pass)

**SpottingBeam**=<Yes/No> (No)

Activates the "Double Trigger" feature for the Long Range scanners that allow to have an aiming spot (first position, fixed) and a scanning spot (second position, sweep).

Do not activate this option in a standard scanner.

Yes=The scanners uses the double trigger.

No=The scanner doesn't use the double trigger.

## 5.XIII [<Symbology>] Sections

The Available symbologies are :

UPC\_E0

UPC\_E1

UPC\_A

EAN\_8

EAN\_13

MSI

CODABAR

CODE\_39

CODE\_D25

CODE\_I25

CODE\_11

CODE\_93

CODE\_128

PDF\_417

These sections group the symbology-specific options.

**On**=<Yes/No> (most popular)

The scanner tries to decode this symbology.

Warning : Enabling too much symbologies should increase decode time and might generate misreads.

**Min**=<num / char number> (smart ...)

Minimum characters accepted in this barcode type.

**Max**=<num / char number> (smart ...)

Maximum characters accepted in this barcode type.

If *Min* = < *Max*, reads barcodes between *Min* and *Max* length.

If *Min* = > *Max*, reads barcodes that have *Min* OR *Max* length.

If *Min*=0 and *Max*=0, reads variable barcode length (minimum and maximum allowed depends on the barcode type).

Warning : Some barcode types may generate misreads with variable length.

**Opt**=<num> (0)

0=Option disabled.

1=Option Enabled.

Option are available in some barcodes (supplemental, check-digit, etc.).

## 5.XIV [BC\_EDIT\_X]

Four sections, [BC\_EDIT\_0] to [BC\_EDIT\_3].

This sections group the options for the "Barcode editing" processing. Barcode readings may be modified by performing an editing process before sending them to the input fields.

The editing process has three parts :

- 1) Evaluate the match conditions to determine if the process applies to this barcode reading. The barcode must match ALL the conditions switched to "Yes" (LenDo, MatchDo, TypeDo).
- 2) Filter the barcode to keep or eliminate data by the "Y/N" pattern (Filter).
- 3) Insert some characters by the "\*" mask (Insert).

**On**=<Yes/No> (No)

Yes=Evaluates this section, and performs Barcode Editing (if match).

No=Do not evaluate this section (all the following options are ignored).

**LenDo**=<Yes/No> (No)

Yes=Do match barcode length.

Edition is performed if this condition is satisfied.

**LenMin**=<number / length> (0)

The minimum length to match.

**LenMax**=<number / length> (0)

The maximum length to match.

**MatchDo**=<Yes/No> (No)

Yes=Do Match string.

Edition is performed if this condition is satisfied.

**MatchPos**=<num / position> (1)

The position in the barcode to perform the match test. (start at 1)

**MatchStr**="033"

The string to match in the barcode at given position.

**TypeDo**=<Yes/No> (No)

Yes=Do match Barcode type.

Edition is performed if this condition is satisfied.

**TypeBc**=<num / barcode> (0)

0=UPC\_E0, 1=UPC\_E1, 2=UPC\_A, 3=MSI, 4=EAN\_8, 5=EAN\_13, 6=CODABAR, 7=CODE\_39, 8=CODE\_D25, 9=CODE\_I25, 10=CODE\_11, 11=CODE\_93, 12=CODE\_128, 13=PDF\_417.

**Filter**=<string / pattern> (empty)

Editing; Filter the source barcode data with this pattern:

Y=Keep the character.

N=Ignore the character.

**Insert**=<string / mask> (empty)

Editing; After filter processing, apply this mask to the result data:

\*=Keep the character from the barcode

NNN=Insert a new char

## 5.XV [PRINT\_DATA]

This section allows to send data to an attached printer, via display screen commands, following the "Print Display Data" processing described below:

If **On**, Wtn looks for **StartPrintId** in the display area at the **IDRow** and **IDCol** position.

If found, the text between **StartPrintId** and **StopPrintId** (or end of screen) is sent to the terminal attached serial printer (following [printer](#) configuration).

*The whole text for a label to print must fit in a single screen.*

The following conversions are performed :

- The EBCDIC nulls (0x00) are not sent to the printer.
- The EBCDIC nulls (0x00) are converted to ASCII spaces and sent to the printer if the **NullToSpace** function is *Yes*.
- The EBCDIC display characters are converted to ASCII using the current IBM charmap [codepage](#).
- If the character to send is the ASCII **EscapeChar** the following (s) character is (are) converted to a single control character.

**On**=No

Performs "Print Display Data" processing.

**StartPrintId**=<string / pattern> ("PRN:")

The pattern to match when printing data ("PRN:").

The start print tag. The data between start and stop print tags are sent to the printer.

**StopPrintId**=<string / pattern> (":PRN")

The pattern to match when printing data (":PRN").

The stop print tag. The data between start and stop print tags are sent to the printer.

**IDRow**=<number / row> (3)

The row to look for the start print ID. Start at 1.

**IDCol**=<number / column> (1)

The column to look for the start print ID. Start at 1.

**NullToSpace**=Yes

Performs null to space conversion before performing the EBCDIC to ASCII conversion. If Yes, the null characters are sent to the printer as spaces. If No, the null characters are not sent.

**EscapeChar**=<hexstring / character> ("092" or "/5C" or "..\" / an "\")

ASCII character to look for in printer stream to perform character conversions.

For no "escape" conversion, use 000 or /00.

The character following the "EscapeChar" is converted to a control character and sent to the printer.

They follow the syntax detailed below :

- <EscapeChar><Char to Convert>
- <EscapeChar><EscapeChar>
- <EscapeChar><#><99>

**<EscapeChar><Char to Convert>**

(Char to Convert) should not be equal to <EscapeChar>.

The character following **EscapeChar** (Char to Convert) is converted to ASCII and converted to a "control character" by subtraction of 64.

"\@"=0x00, "\A"=0x01, "\B"=0x02, "\C"=0x03, ..., "\Z"=0x1A, "\["=0x1B, "\]"=1D, "\^"=0x1E, "\\_"=0x1F, "\"=0x20, "\a"=0x21, "\b"=0x22, ..., "\z"=0x3A.

**<EscapeChar><EscapeChar>**

To send an "EscapeChar", print it twice (the escape char is sent 1 time). "\\ "=0x5C.

**<EscapeChar><#><99>**

If the character following EscapeChar is "#", the two hex-digits (0 - F) are converted to a single hex control character.

"\#1C"=0x1C, "\#00"=0x00, "\#FF"=0xFF.

*For the characters higher than 0x7F, check if the serial link to the printer is configured in 8 bits mode.*

## 5.XVI [PRINTER] Section

This section groups the options for the PDT-attached printer.

**Type**=<string / Name> (PS1000)

Printer type connected.

**Port**=<num / Com#> (1)

1=Com1

2=Com2

Communication port. One digit.

**Baud**=<num> (96)

12=1200 Bauds

24=2400 Bauds

48=4800 Bauds

96=9600 Bauds

19=19200 Bauds  
38=38400 Bauds.  
Baud rate. Two digits.

**Parity**=<uppercase letter> (N)

O=Odd

E=Even

N=None

M=Mark

S=Space

Data parity.

**DataBits**=<num> (8)

7= 7 Data bits.

8= 8 Data bits.

Data bits.

**StopBits**=<num> (1)

1= 1 stop bit.

2= 2 stop bits.

Stop bits.

**FlowControl**=<uppercase letter> (N)

N=None (No flow control).

S=Software flow control (XON / XOFF).

H=Hardware flow control (CTS / RTS).

**Dsr**=<Yes/No> (Yes)

Yes=Data Set Ready (DSR) sensing signal for connection.

No=Ignore DSR.

**Cts**=<Yes/No> (No)

Yes=Clear To Send (CTS) sensing signal for connection.

Nop=Ignore CTS.

**Cd**=<Yes/No> (No)

Yes=Carrier detect (CD) sensing signal for connection.

No=Ignore CD.

**Tmout**=<num / seconds> (60)

Maximum time waiting for printer ready signal before failure.

If printer fails, a message alerts the user and allow to retry print operation or abort.

**AskReprint**=<Yes/No> (Yes)

Yes=After a successful print, asks the user to reprint the same label or to continue.

No=After a successful print, informs the user and continues.

## 5.XVII [DBGOPT] Section

This section groups the options for debugging file generation. This options may be used ONLY for debugging purposes. Full memory condition is not checked, and subsequent printing operations may fail. You MUST manually empty the files.

**InLog**=<Yes/No> (No)

Logs in a file all received data.

**InFile**=<string / name> (empty)

File Name.

**OutLog**=<Yes/No> (No)

Logs in a file all data sent.

**OutFile**=<string / name> (empty)

File Name.

# Chapter 6 – User Message File

---

## 6.I Features and syntax

The WTn User message file is a text file containing the text of the messages displayed by WTn52. The name of this file is "\_Msg52XX.Cfg".

The WT user message file is a "Windows dot-ini-Like" text file, with sections, keys and values.

Message file includes :

- Comments
- Sections
- Keys
- Values

Lines in configuration file must be: Comments, Sections, Keys + Values or empty lines.

This file may be loaded into the NVM with the configuration file (and zipped in CFG.ZIP). It may be dynamically loaded into PDT by RsLink or WTDnl.

## 6.II Comments

Comments in WT configuration file are indicated by two "slash" characters and take effect until the end of the line. i.e. :

*// This is a comment*

*This is not a comment (must be a section, a key + value or an empty line)*

## 6.III Sections

Sections group the text strings. Section names are in capital letters surrounded by brackets. i.e. : [CONFIG], denotes the user configuration screen.

The order of the sections in the file is not relevant.

## 6.IV Keys

Keys are two digit numbers that are used to order the texts into their own section. The order of those keys **must not** be modified. You should not add or suppress keys in a section. Keys must be followed by an "=" sign and the text string.

## 6.V Values

The values are the text strings displayed by WTn. The position of the lines in the display *is not modifiable*. The strings should not be longer than the PDT display size.

## Appendix A – Terminal Functions

---

The keyboard scan codes are assigned to the terminal keyboard functions by the configuration file (see \_WTn52.cfg, [Chapter 5](#) section [[CONTROL KEYS](#)]).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [F1] SCAN CODES".

See also [Appendix F – Control Keys Assignment](#) for default scan codes assignment.

<b><i>BackSpace</i></b>	Back Space. Valid in an unprotected field. If at first position of the field, moves the cursor to the last position of the previous field. Else, moves cursor one column left. <a href="#">Scan-code assignment.</a>
<b><i>BackTab</i></b>	Backward tabulation. Moves the cursor to the start of the field. If already at start position, moves the cursor to the previous field. <a href="#">Scan-code assignment.</a>
<b><i>CursorDown</i></b>	Cursor Down. In Free Cursor mode, moves the cursor one line Down. In no Free Cursor mode, moves the cursor to the next field. <a href="#">Scan-code assignment.</a>
<b><i>CursorLeft</i></b>	Cursor Left. In Free Cursor mode, moves the cursor one column left. In no Free Cursor mode, moves the cursor one column left. If already at begin of field, moves the cursor to the previous field. <a href="#">Scan-code assignment.</a>
<b><i>CursorRight</i></b>	Cursor Right. In Free Cursor mode, moves the cursor one column right. In no Free Cursor mode, moves the cursor one column right. If already at end of field, moves the cursor to the next field. <a href="#">Scan-code assignment.</a>
<b><i>CursorSelect</i></b>	3270, Not implemented.
<b><i>CursorUp</i></b>	Cursor Up. In Free Cursor mode, moves the cursor one line Up. In no Free Cursor mode, moves the cursor to the previous field. <a href="#">Scan-code assignment.</a>
<b><i>Data</i></b>	Data entry. Valid in an unprotected field. When a data character is keyed, the character is checked to be valid for the field type, and if it fits in the field (following replace / insert mode). If the field is filled, performs the pad and adjust functions following the field type.

	<p>If the field has set the "FER" attribute (<b>Field Exit Required</b>), it waits for the Field Exit key, or other editing keys (Back Space, Delete, Cursor Left, etc.).</p> <p>If the field has the Auto-Enter attribute set, it performs an Enter AID function.</p> <p>Else, it moves the cursor to the next non-bypass field.</p>
<b>Delete</b>	<p>Delete.</p> <p>Valid in an unprotected field.</p> <p>Deletes one character under the cursor.</p> <p>Scrolls one position to the right the rest of the field.</p> <p>Puts a null in the rightmost position.</p> <p><a href="#">Scan-code assignment.</a></p>
<b>Dup</b>	<p>Duplicate.</p> <p>Valid in an unprotected field.</p> <p>Valid if field allows Dup or Mark characters.</p> <p>Fills the remaining of the field with "dup" characters.</p> <p><a href="#">Scan-code assignment.</a></p>
<b>End</b>	<p>End of data.</p> <p>Moves the cursor to the last data position in the field.</p> <p><a href="#">Scan-code assignment.</a></p>
<b>EraseEof</b>	<p>Erase End Of Field.</p> <p>Erases (null) all the characters in the field to the right of the cursor.</p> <p><a href="#">Scan-code assignment.</a></p>
<b>EraseInput</b>	<p>Erase Input.</p> <p>Clears (sets to null) all modified fields.</p> <p>Sets the cursor to the first non-bypass field.</p> <p><a href="#">Scan-code assignment.</a></p>
<b>ErrorReset</b>	<p>Error Reset.</p> <p>Resets the " X Input Inhibit" (X II) indicator.</p> <p>Puts the terminal in not-error state.</p> <p>Resets the insert toggle (puts it in replace mode).</p> <p><a href="#">Scan-code assignment.</a></p>
<b>FieldExit</b>	<p>Field Exit.</p> <p>Valid in an unprotected field.</p> <p>Checks the mandatory fill and mandatory enter conditions.</p> <p>Performs the pad and adjust functions following the field type.</p> <p>If the field has the Auto-Enter attribute set, it performs an Enter AID function.</p> <p>Else, it moves the cursor to the next non-bypass field.</p> <p><a href="#">Scan-code assignment.</a></p>
<b>FieldMark</b>	<p>Field Mark.</p> <p>3270, Same as Dup.</p> <p>Valid in an unprotected field.</p> <p>Valid if field allows Dup or Mark characters.</p> <p>Fills the remaining of the field with "Mark" characters.</p> <p><a href="#">Scan-code assignment.</a></p>

<b><i>FieldMinus</i></b>	<p>Field Minus.  Valid in an unprotected field.  In numeric fields, puts a negative sign (the last numeric char carries the sign), and performs a field exit function.  In signed numeric fields, puts a negative sign ("- " dash), and performs a FieldExit function.  Not allowed In other fields.  The "-" key acts as a FieldMinus in numeric and signed numeric fields.  <a href="#">Scan-code assignment.</a></p>
<b><i>FieldPlus</i></b>	<p>Field Plus.  Valid in an unprotected field.  In signed numeric fields, puts a positive sign, and performs a field exit function.  In other fields, performs a field exit function.  The "+" key acts as a FieldPlus in numeric and signed numeric fields.  <a href="#">Scan-code assignment.</a></p>
<b><i>ForwTab</i></b>	<p>Forward tabulation.  Moves the cursor to the next field.  <a href="#">Scan-code assignment.</a></p>
<b><i>Home</i></b>	<p>Home.  Moves the cursor to the home position (normally the first field).  If already in home position, sends an AID "record-backspace" code.  <a href="#">Scan-code assignment.</a></p>
<b><i>Insert</i></b>	<p>Toggles the insert/replace mode.  Insert, when data input, moves the characters to the right of the cursor (if possible) and inserts the keyed character. Moves the cursor one character to the right.  Replace, when data input, puts the keyed character at cursor position (replacing the previous character). Moves the cursor one character to the right.  <a href="#">Scan-code assignment.</a></p>

# Appendix B – Character Sets

---

## B.I ISO 8859\_1 Character Set

The font 8859\_1.fnt uses the ISO-8859-1 character set (ASCII). See [Chapter 5 - Font](#).

The built-in translation routines translate host IBM EBCDIC characters. See [Chapter 5 - CodePage](#)



## Appendix C – Downloading Configuration File

---

The configuration files are :

- `_WTn52.Cfg` that contains the program parameters ([Chapter 5](#)).
- `_Msg52XX.Cfg` that contains the user messages texts ([Chapter 6](#)).

### C.I Download by RsLink

Install RsLinkOne or RslinkPlus in the PC. Create a folder that contains the configuration files to download. Start RsLink. In the "File" menu, select the "Settings" option. In the "Communication settings" dialog box:

- Select the path "**PC > PDT**" by browsing the folder that contains the configuration files.
- Select the appropriate COM: port.
- Select 2000 packet size.
- Select Baud rate 9600.
- Select protocol *RsLink*.

At [boot time](#), the terminal asks for "configuration download", choose "[F2] By RsLink" option. The terminal downloads the `_WTn52.Cfg` file, **and** the `_Msg52XX.Cfg` associated file (be sure that the TWO files are in the right place). After successful download, the terminal saves the files into the "Flash Memory" and prompts the main menu.

### C.II Download by WTDNL

Install WTDnl in the PC. Create a folder that contains the configuration files to download. Start WTDnl. In the "Edit Profile" menu, select the "Settings" option. In the "settings" dialog box:

- Leave the default IP address 0.0.0.0 (use all the IP interfaces in the host) and port (3001) if WTDnl is not a conflict with other protocols.
- Select the folder where the "DOT-CFG" files are, giving the path or browsing the folders.
- Accept with the "OK" button.

Save the configuration in the "File" menu, selecting the "Save" option. A ".wtdnl" file is created in a user selected folder that contains the present configuration. For further use, this file is in the MRU list or you can start the WTDnl program by selecting the ".wtdnl" file in the windows explorer.

At [boot time](#), the terminal asks for "configuration download", choose "[F1] By Radio" option. Supply the IP address of the host that has the WTDnl program running, and the port (3001 by default).

The terminal downloads the `_WTn52.Cfg` file, **and** the `_Msg52XX.Cfg` associated file (be sure that the TWO files are in the right place). After successful download, the terminal saves the files into the "Flash Memory" and prompts the main menu.

## Appendix D – Downloading Terminal program

---

To load **WTn52** in a Symbol Technologies series 3000 PDT, it is necessary to download **two** “DOT.HEX” files to the PDT’s NVM:

- **WS24\_xxx.HEX** Drivers Spectrum24 2Mb FH for PDTxx42.
- OR -
- **WS11\_xxx.HEX** Drivers Spectrum24 11Mb DS for PDTxx46.
- AND -
- **WTn52xx.HEX** WireLess TelNet 5250 Emulator Version x.x.

Using NvmHex, RsLink or Sendhex utilities. This utilities send the ".HEX" file to the PDT by writing the Non Volatile Memory.

1. Erase the PDT NVM (EEPROM).
2. Load **WS24\_xxx.HEX** (2Mb FH - PDTxx42) OR **WS24\_xxx.HEX** (11Mb DS - PDTxx46) first, *and cold boot the terminal*.
3. To the “Flash Erase” question, answer [**Y**] (Yes) to format the Flash disk. When boot, NVM (or EEPROM, or **B:**) contents are transferred to Flash Memory (or **E:** drive), the network and TCP/IP drivers are installed
4. Erase the PDT NVM (EEPROM) (Yes, Yes).
5. Load **WTn52xx.HEX** and cold boot the terminal.
6. After boot, the PDT Network configuration utility ([CFG24](#) or [CFG11](#)) allows to set the appropriate values.

You may load other configuration files ( **\_WTn52.Cfg**, **\_Msg52XX.Cfg** ) by RsLink utility, or use those included into standard **WTn52** NVM.

### D.I Downloading program by NVMHEX

This method requires installing NvmHex on the PC. NvmHex has on-line help to download "HEX" files and PDT boot sequences.

In the PC:

- Search for the file with "Windows explorer", and "double-click" the "HEX" file (NvmHex starts).
- Select the baud rate if necessary (38400 by default).

In PDT:

- Do a "[Command Boot](#)"
- Erase NVM with the "Program loader"
- Select speed (usually 38400)
- Select default data bits (7) and parity (Odd)
- Select flow control "Xon/Xoff"
- Start downloading
- After successful download boot the terminal ([Bios Boot](#)).

## D.II Downloading program by RSLINK

This method requires installing RsLink on the PC. RsLink has on-line help to download "HEX" files and PDT boot sequences.

In the PC

- Start RdsLinkOne or RsLinkPlus.
- Select the "Tools" Menu. Select the "Nvm Loader" Option in the Tools Menu.
- Select the ".HEX" file to download by the "select file" dialog box.

In PDT:

- Do a "[Command Boot](#)"
- Erase NVM by "Program loader"
- Select speed (usually 38400)
- Select default data bits (7) and parity (Odd)
- Select flow control "Xon/Xoff"
- Start download
- After good download boot the terminal ([Bios Boot](#)).

## D.III Downloading program by Sendhex

Sendhex is a DOS utility.

In PDT:

- Do a "[Command Boot](#)"
- Erase NVM by "Program loader"
- Select speed (usually 38400)
- Select default data bits (7) and parity (Odd)
- Select flow control "Xon/Xoff"
- Start download

In the PC:

- Type: SENDHEX *filename* 38 1 [ENTER]
- Hit [ENTER]

In PDT:

- After successful download boot the terminal ([Bios Boot](#)).

# Appendix E - CFG24 / CFG11 Utility

---

## E.I Purpose

The main purpose of this utility program is to enable the terminal operator to configure certain essential parameters for radio communications. This program must be run after the radio driver has been loaded as the configuration parameters are saved in the radio card flash memory which is accessed using radio driver services.

This program uses the text message file MSG.MSG which is read from the same drive and directory where the system found the executable, CFG24.COM (Or CFG11.COM).

Changing some parameters, e.g. terminal IP address, will have no effect until the stack is reloaded. Other parameters, e.g. Diversity, will have no effect until the radio driver is reloaded. The safest course is to re-initialize (warmboot) the terminal after changing any parameters by running CFG24 or CFG11 manually from a DOS prompt.

CFG24 is used for 2Mb FH terminals (PDTxx42), and CFG11 is used for 11Mb DS terminals (PDTxx46). There are some minor differences between these configurators.

Syntax:


```
CFG24 [ENTER]
CFG11 [ENTER]
```

## E.II Description

The program provides menus for editing many of the radio configuration parameters used to communicate in a Spectrum24 network. The values are saved in a buffer in the flash memory of the radio card. The current parameters are set in a text file, NET.CFG, on the RAMdisk. NET.CFG is used both by the radio driver and the TCP/IP stack to obtain their configuration parameters.

### E.II.1 Menu

Initially, the program presents a menu as shown below.



```
CONFIGURATOR 2.3x
View config
ESS Id
Subnet Mask
Default Router
MU IP Address
Diversity
MU Sleep Mode
Boot Mode
Pwr Management
Buffers
ReXmit Delay
Rate Control
Scan/RF Op
```

```
Int Roaming
Exit
▲▼, Clear, Enter
```

The up and down cursor keys are used to select an option from the menu. The current selectable option is indicated by reverse video. To return to the menu above use the Clear key and to select an option use the Enter key. Using the Clear key in this menu has the same effect as selecting Exit. The configurator terminates execution.

On terminals with small display screens, the top and bottom lines of the above menu are shown and the menu items scroll using the remaining lines of the display.

### E.II.2 VIEW CONFIG

```
VIEW CONFIG
Terminal IEEE addr
00:A0:F8:86:B5:3E
MU IP Address
10.10.10.12
FW: V4.57 991001
ESS Id = 101
CLR, Enter
```

If “View config params” is selected, the terminal IEEE address (also known as the MAC address), the terminal IP address, the radio firmware version number and date, and the net id, or ESS Id, are displayed. This is NOT a data entry screen. It is provided to display information frequently required in diagnostic situations. Clear or Enter returns to the main configuration menu.

### E.II.3 ESS ID

If the configurator is executing over a radio driver that uses the IEEE 802.11 protocol then this screen has the following format.

```
ESS ID
Enter ESS Id:
101

BkSp, CLR, Enter
```

If “ESS Id” is selected from the main configuration menu, the above screen is displayed. The current setting of the ESS Id is shown in up to 32 ASCII characters and may be changed by backspacing over the current value and typing a new value. Alternatively the current setting can be deleted using Ctrl-D and the new ESS Id entered in its entirety. Enter must be pressed to effect any changes typed.

The ESS Id identifies the radio network and differentiates between different radio networks. All equipment on one 802.11 network must use the same ESS Id.

## E.II.4 SUBNET MASK

```
SUBNET MASK
Enter Subnet Mask:
255.255.0.0

BkSp, CLR, Enter
```

If “Subnet Mask” is selected from the main configuration menu, the above screen is displayed. The current setting of the Subnet Mask is shown and may be changed by backspacing over the current value and typing a new value. Enter must be pressed for any changes to take effect. A new value is entered in decimal form and each part of the four-part address should be in the range 0 to 255.

## E.II.5 DEFAULT ROUTER

```
DEFAULT ROUTER
Enter Default Router
10.10.0.99


BkSp, CLR, Enter
```

If “Default Router” is selected from the main configuration menu, the above screen is displayed. The current setting of the Default Router is shown and may be changed by backspacing over the current value and typing a new value. Enter must be pressed for any

changes to take effect. A new value is entered in decimal form and each part of the four-part address should be in the range 0 to 255.

The default router address is the address of the node to which all packets, destined for remote networks, will be sent.


## E.II.6 MU IP ADDRESS



If “MU IP Address” is selected from the main configuration menu, the above screen is displayed. The current setting of the MU IP Address is shown and may be changed by backspacing over the current value and typing a new value. Enter must be pressed for any changes to take effect. A new value is entered in decimal form and each part of the four-part address should be in the range 0 to 255.

**NOTE:** It is only necessary to enter an IP address if the terminal is not going to be allocated an IP address from a boot server or DHCP server. Allocation of an IP address is part of the BOOTP and Dynamic Host Configuration Protocol (DHCP) process.

## E.II.7 DIVERSITY




If “Diversity” is selected from the main configuration menu, the above screen is displayed. The current setting of the Diversity is shown and may be changed by using the up and down arrow keys to toggle between the two valid settings. Enter must be pressed for any changes to take effect.

If diversity is set to “Yes”, the radio firmware will attempt to use both antenna ports for communications. This setting will give better communications if two antennas are used with the radio and distinctly worse communications if only one antenna is used. It is important to match the diversity setting with the number of antennas in use. The LRT3840, PDT3140 and PDT3540 are each equipped with two antennas. The wearable, PDT6140 and PDT6840 have only one antenna and the vehicle mount is frequently used with a single antenna. If there is only one antenna make sure that diversity is set to “No”. When using the standard start-up files the

diversity is defaulted on terminal type to the expected value as implied by the above hardware antenna configurations.

## E.II.8 MU SLEEP MODE




If “MU sleep mode” is selected from the main configuration menu, the above screen is displayed. The current setting of the sleep mode is shown and may be changed by using the up and down arrow keys to toggle between the two valid settings. Enter must be pressed for any changes to take effect.

If this switch is set ON, the radio is not powered off when an application powers down the terminal due to inactivity. This permits the terminal to be woken-up by a message being directed to the terminal. Broadcast messages will not wake-up the terminal.

If this switch is set to OFF, the radio is powered off when an application powers down the terminal due to inactivity.

The default value for this parameter is ON.

## E.II.9 BOOT MODE



If “Boot Mode” is selected from the main configuration menu, the above screen is displayed. The current setting of the Boot Mode is shown and may be changed by using the up and down arrow keys to toggle between the three valid settings. Enter must be pressed for any changes to take effect.

If boot mode is set to “Boot”, when the terminal is being initialized, a TCP/IP BOOTP request message will be broadcast to the network. Any boot servers on the network should respond if configured to do so. The terminal will accept the first valid response that it receives. The response contains an IP address to be used by the terminal and, optionally, other network parameters. Parameters received in a BOOTP response overwrite any that may have been entered using this configurator.

If boot mode is set to “DHCP”, when the terminal is being initialized, a similar process is performed as described above for BOOT mode, except that Dynamic Host Configuration Protocol is used.

Symbol's BOOTP program, which supports the obtaining of network parameters depending on the setting of this configuration parameter, supports the setting of the following network parameters from the BOOTP and DHCP responses:

Sub-net mask

Default router - the first address from the router list.


Terminal IP address

Additionally in DHCP, if both domain name (option 15) and domain name servers (option 6) are returned in the DHCP ACK then a RESOLV.CFG file will be generated which permits the stack to attempt to resolve network names from the domain servers offered.

If the boot mode is set to "Manual entry", then no configuration messages are broadcast to the network and the current values of the network parameters, saved in the radio flash, are used to connect to the network.

"Manual entry" is the default setting of this parameter.

## E.II.10 PWR MANAGEMENT




If "Pwr Management" is selected from the main configuration menu, the above screen is displayed. The current setting of power management is shown and may be changed by using the up and down arrow keys to toggle between the two valid settings. Enter must be pressed for any changes to take effect.

If power management is set to PSP, the default, the radio is powered up only when there is traffic on the network. This mode adapts to the radio activity to decide how long the radio will be powered down. Because the radio will not always be in a ready state when a message is available to be sent to it, this mode does slow down response times.

If power management is set to CAM, the radio is always ready to receive. In this mode, battery life is dramatically reduced. This mode is not recommended for any terminal that runs on integral nickel cadmium, metal hydride or alkaline batteries. Vehicle mount terminals should be set to CAM mode.

## E.II.11 BUFFERS




If "Buffers" is selected from the main configuration menu, the above screen is displayed. The current setting of the input buffer count is shown and may be changed by using the up and

down arrow keys to toggle between the three valid settings. Enter must be pressed for any changes to take effect.

This parameter is the number of buffers allocated for frames from the radio. It is recommended that this parameter be left at the default value (currently 8). Two other settings are allowed, 4 or 12. Increase the count to 12 to overcome performance issues if your application can bear this use of memory resources. Reduce the count to 4 if your application has memory resource problems.


## E.II.12 REXMIT DELAY



If “ReXmit Delay” is selected from the main configuration menu, the above screen is displayed. The current setting of the retransmission delay is shown and may be changed by using the up and down arrow keys to toggle between the two valid settings. Enter must be pressed for any changes to take effect.

This parameter is the minimum delay that the TCP/IP stack software will wait before retrying unacknowledged frames. There are two possible values “short” that equates to half a second and “long” that equates to a full second. These values are set high to allow for the radio technology. To preserve battery life, the radio is powered down as much as possible. These timeout values minimize spurious retries due to wireless responses being delayed until the terminal radio is powered up.

## E.II.13 RATE CONTROL



If “Rate Control” is selected from the main configuration menu, the above screen is displayed. The current setting of the transmission rate is shown and may be changed by using the up and down arrow keys to toggle between the three valid settings. Enter must be pressed for any changes to take effect.

With the new radio, there is potential for either fixing the radio transfer rate at 1Mbps or at 2Mbps. There is an adaptive setting that will use 2Mbps until it experiences difficulties when it will automatically back off to 1Mbps.

If the configurator senses that the radio is only capable of 1Mbps transmission, this parameter will display as “1Mb only” and will not permit any change.

## E.II.14 SCAN / RF OP



If “Scan/RF Op” is selected from the main configuration menu, the above screen is displayed. The current setting of the Scan/RF operating mode is shown and may be changed by using the up and down arrow keys to toggle between the two valid settings. Enter must be pressed for any changes to take effect.

The two options are concurrent operation and “Scan stops RF”. In this second mode the radio is locked out of transmitting while the scanner is being used. This has previously been the manner in which the 300 series terminals worked. The concurrent operating mode is new and the default. The concurrent mode should be more convenient for aggressive scanning applications where previously it was possible to lock out the radio for long enough to lose association with the AP.

# Appendix F – Keyboard Reference

---

## F.I Keyboard Reference

The shape of the blinking cursor reflects the keyboard state (See also [Chapter 3 - Keyboard Operations](#)).

The keystroke scan code assigned to the function is configured by the user file and may change.

This list is the "default" configuration file (see Chapter 5 – Configuration File Options).

### F.I.1 AID Keys assignment

The keyboard scan codes are assigned by the user file and may change (see \_WTn52.cfg file [Chapter 5](#)).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

AID keys send input data to host.

5250 Emulated Keys	
PDT Keystroke	5251 Terminal function
<a href="#">[Ctl]+[C] / [Ctl]+[BKSP]</a>	Clear
<a href="#">[CLR]</a>	Enter
<a href="#">[Fn]+[Ctl]+[H]</a>	Help
<a href="#">[Fn]+[Dn]</a>	Roll Down
<a href="#">[Fn]+[Up]</a>	Roll Up
<a href="#">[Ctl]+[Y]</a>	Roll Left
<a href="#">[Ctl]+[Z]</a>	Roll Right
<a href="#">[Ctl]+[P]</a>	Print
<a href="#">[Ctl]+[1] / [Ctl]+[U]</a>	Program Access 1 (PA1)
<a href="#">[Ctl]+[2] / [Ctl]+[V]</a>	Program Access 2 (PA2)
<a href="#">[Ctl]+[3] / [Ctl]+[W]</a>	Program Access 3 (PA3)

### F.I.2 FN AID Keys assignment

The keyboard scan codes are assigned by the user file and may change (see \_WTn52.cfg file [Chapter 5](#)).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

5250 Emulated Keys	
PDT Keystroke	5251 Terminal function
<a href="#">[FUNC]+[1]</a>	PF1

[FUNC]+[2]	PF2
[FUNC]+[3]	PF3
[FUNC]+[4]	PF4
[FUNC]+[5]	PF5
[FUNC]+[6]	PF6
[FUNC]+[7]	PF7
[FUNC]+[8]	PF8
[FUNC]+[9]	PF9
[FUNC]+[0]	PF10
[SHIFT]+[FUNC]+[1]	PF11
[SHIFT]+[FUNC]+[2]	PF12
<a href="#">[SHIFT]+[FUNC]+[3]</a>	PF13
[SHIFT]+[FUNC]+[4]	PF14
[SHIFT]+[FUNC]+[5]	PF15
[SHIFT]+[FUNC]+[6]	PF16
[SHIFT]+[FUNC]+[7]	PF17
[SHIFT]+[FUNC]+[8]	PF18
[SHIFT]+[FUNC]+[9]	PF19
[SHIFT]+[FUNC]+[0]	PF20
[SHIFT]+[1] / [!]	PF21
[SHIFT]+[2] / [@]	PF22
[SHIFT]+[3] / [#]	PF23
[SHIFT]+[4] / [\$]	PF24

### F.I.3 Signal Keys assignment

The keyboard scan codes are assigned by the user file and may change (see \_WTn52.cfg file [Chapter 5](#)).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

The signal keys do not send input data. Signal keys send a system frame.

5250 Emulated Keys	
PDT Keystroke	5251 Terminal function
<a href="#">[Ctl]+[A]</a>	Attention
[Fn]+[Ctl]+[H]	Help
[Ctl]+[S]	System Request
[Fn]+[Ctl]+[T]	Test Request

### F.I.4 Control Keys assignment

The keyboard scan codes are assigned by the user file and may change (see \_WTn52.cfg file [Chapter 5](#)).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [F1] SCAN CODES".

The control keys perform terminal functions, and may also send data to host.

<b>5250 Emulated Keys</b>	
<b>PDT Keystroke</b>	<b>5251 Terminal function</b>
<a href="#">[BkSp]</a>	Back Space
<a href="#">[Fn]+[Ctl]+[D]</a>	Duplicate
<a href="#">[+]</a>	Field Plus
<a href="#">[-]</a>	Field Minus
<a href="#">[ENTER]</a>	Field Exit
<a href="#">[Ctl]+[D]</a>	Delete
<a href="#">[Ctl]+[E]</a>	Erase Input
<a href="#">[Ctl]+[B]</a>	Error Reset
<a href="#">[Ctl]+[G]</a>	Home
<a href="#">[Ctl]+[I] / [Fn]+[SP]</a>	Insert
<a href="#">[Ctl]+[T]</a>	Forward Tab
<a href="#">[Fn]+[BkSp]</a>	Back Tab
<a href="#">[Fn]+[Ctl]+[E]</a>	End
<a href="#">[Ctl]+[O]</a>	Erase End Of Field
<a href="#">[Ctl]+[Q]</a>	Field Mark
<a href="#">Not implemented</a>	Cursor Select

## F.I.5 Cursor Keys assignment

The keyboard scan codes are assigned by the user file and may change (see \_WTn52.cfg file [Chapter 5](#)).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [F1] SCAN CODES".

The cursor keys perform terminal functions to move the input cursor.

<b>Local Functions</b>	
<b>PDT Keystroke</b>	<b>5251 Terminal function</b>
<a href="#">[Up Arrow]</a>	Cursor Up / Previous field
<a href="#">[Down Arrow]</a>	Cursor Down / Next field
<a href="#">[Left Arrow]</a>	Cursor Left / Previous field
<a href="#">[Right Arrow]</a>	Cursor Right / Next field

## F.I.6 Local Functions assignment

The keyboard scan codes are assigned by the user file and may change (see \_WTn52.cfg file [Chapter 5](#)).

You can see the scan code for each key in the terminal by "[F4] See Options / [F1] FN KEYS / [\[F1\]](#) SCAN CODES".

Local Functions	
KEYS	Function
<a href="#">[CTRL]+[X]</a>	End Session
<a href="#">[FUNC]+[CTRL]+[G]</a>	Unlock Keyboard
<a href="#">[FUNC]+[CTRL]+[Up Arrow]</a>	Logical <a href="#">Scroll</a> Up
<a href="#">[FUNC]+[CTRL]+[Down Arrow]</a>	Logical <a href="#">Scroll</a> Down
<a href="#">[FUNC]+[CTRL]+[Left Arrow]</a>	Logical <a href="#">Scroll</a> Left
<a href="#">[FUNC]+[CTRL]+[Right Arrow]</a>	Logical <a href="#">Scroll</a> Right
<a href="#">[FUNC]+[0]</a>	Return to DOS (From <a href="#">Main Menu</a> )

## F.II Boot Sequences

### F.II.1 "Command" boot

1) Put the terminal in **OFF** state by the [PWR] (or [ON / OFF]) key. If the terminal is already OFF by timeout, please put it ON and OFF by keyboard.

*If the terminal is "hang" (does not respond to the [PWR] key, displays unknown characters, etc.) press and hold the [PWR] key 40 seconds to force a power off.*

2) **Hold** at the same time the following keys (according to the PDT model).

Terminal Model	Sequence
PDT314x 46 Keys PDT 354x 47 Keys LRT 384x 46 Keys PDT 614x 46 Keys LRT 684x 46 Keys	Hold [F] + [I]
PDT314x 35 Keys LRT 384x 35 Keys PDT 614x 35 Keys LRT 684x 35 Keys	Hold [SHIFT] + [BKSP]
WSS 104x 27 Keys	Hold [FUNC] + [[ENTER]
VRC 394x 54 Keys VRC 694x 54 Keys	Hold [A] + [D]

3) **Press and release** [PWR] (or [ON/OFF]).

4) **Release** the previous keys.

## F.II.2 "Bios" boot (Cold Boot)

1) Put the terminal in **OFF** state by the [PWR] (or [ON / OFF]) key. If the terminal is already OFF by timeout, please put it ON and OFF *by the keyboard*.

*If the terminal is "hang" (does not respond to the [PWR] key, displays unknown characters, etc.) press and hold the [PWR] key 40 seconds to force a power off.*

2) **Hold** at the same time the following keys (according to the PDT model).

Terminal Model	Sequence
PDT 314x 46 Keys PDT 354x 47 Keys LRT 384x 46 Keys PDT 614x 46 Keys LRT 684x 46 Keys	Hold [A] + [B] + [D]
PDT 314x 35 Keys LRT 384x 35 Keys PDT 614x 35 Keys LRT 684x 35 Keys	Hold [SPACE] + [FUNC] + [Up_Arrow]
WSS 104x 27 Keys	Hold [Right_Arrow] + [[ENTER]
VRC 394x 54 Keys VRC 694x 54 Keys	Hold [F1] + [F4] + [ENTER]

3) **Press and release** [PWR] (or [ON / OFF]) key.

4) **Release** the *previous* keys.