

MCL II control unit

Installation Instructions

(Translation of the original installation instructions)

Foreword

Document revision history

| Version | Date | Modification, change |
|---------|-------|----------------------|
| (-) | 05/11 | First release |
| (a) | 07/12 | Second edition |
| (b) | 12/12 | RoHS, Toggle |

Disclaimer and Exclusion of Liability

DewertOkin is not responsible for damage resulting from:

- failure to observe these instructions,
- Changes made to this product which have not been approved by DewertOkin, or
- The use of replacement parts which have not been approved or manufactured by DewertOkin.

Address of manufacturer

DewertOkin GmbH
Weststraße 1
32278 Kirchlengern
Germany
Tel: +49 (0)5223/979-0
Fax: +49 (0)5223/75182
<http://www.dewertokin.de>
Info@dewertokin.de

Creation of a complete operating instruction manual for the entire end product

These instructions are only intended to be used by the end-product manufacturer. They should not be given to the operator of the end product. The factual information contained within may be used as a basis when creating the end-product manual.

The warning and danger notices are best suited for use in the end product's manual. However it is not sufficient to simply follow these notices. You should also carry out an internal risk assessment for your end product. This can then be used as the basis for the safety notices in your manual.

Usage in medical products

The MCL II control unit is not a medical product. If used in a medical end product, you (the end manufacturer) are obliged to ensure compliance with EC directives and to ensure that other pertinent medical product regulations are maintained.

Table of contents

| | |
|--|-----------|
| Foreword | 3 |
| Document revision history | 3 |
| Disclaimer and Exclusion of Liability | 3 |
| Address of manufacturer | 3 |
| Creation of a complete operating instruction manual for the entire end product | 3 |
| Usage in medical products | 3 |
| Table of contents | 4 |
| 1. General Information | 6 |
| 1.1 About these installation instructions | 6 |
| 1.2 Conventions used | 6 |
| 2. Safety Notices | 7 |
| 2.1 Proper and Intended Usage | 7 |
| 2.2 Selection and qualification of personnel | 8 |
| 2.3 Notice on safety during operations | 8 |
| 2.4 Product labelling | 9 |
| 3. Possible combinations | 11 |
| 3.1 Layout of system connections | 11 |
| 4. Device description | 12 |
| 4.1 Components | 12 |
| 5. Technical data | 15 |
| 6. Installation | 17 |
| 6.1 Safety notices to observe during installation | 17 |
| 6.2 Installation procedure | 18 |
| 7. Operating Notes | 28 |
| 7.1 General information | 28 |
| 7.2 Notice for operating with optional configuration | 31 |
| 8. Troubleshooting | 32 |



| | | |
|------------|------------------------------|-----------|
| 9. | Maintenance | 33 |
| 9.1 | Maintenance | 33 |
| 9.2 | Cleaning and care | 34 |
| 10. | Disposal | 35 |
| | EU Declaration of Conformity | 36 |
| | Additional information | 37 |

1. General Information

1.1 About these installation instructions

In order to install the MCL II control unit successfully and safely in the end product, these installation instructions must be observed. These instructions are not an operating manual for the end product.

These instructions will help you to minimize danger, repair costs and down times. They will also help you to maximize the reliability and lifespan of the end product.

| | |
|---|--|
|  |  CAUTION |
| | <p>The notices in these instructions must be followed! Following the guidelines during installation and connection procedures will help to minimize:</p> <ul style="list-style-type: none"> • the risk of accident and injury, and • damage to the MCL II control unit or the end product. |

These installation instructions have been written with due care and attention. However, we cannot guarantee that the data, images and drawings are complete and correct nor do we accept any liability for the information contained therein, unless required by law.



- ▶ We reserve the right to make unannounced technical changes in the course of our continual product improvement process!



1.2 Conventions used



Notices which do not relate to safety are indicated in these instructions with a symbol:


- ▶ Triangular notice symbol

Explanations of warning notices

| | |
|---|--|
|  |  DANGER |
| | <p>DANGER indicates a hazardous situation which, if not avoided, will result in serious injury or death.</p> |

| | |
|---|--|
|  |  WARNING |
| | <p>WARNING indicates a hazardous situation which, if not avoided, could result in serious injury or death.</p> |

| | |
|---|---|
|  |  CAUTION |
| | <p>CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.</p> |



| | |
|---|---|
|  | NOTICE |
| | <p>Notice about a harmful situation, possible consequences: the product itself or surrounding objects could be damaged.</p> |

2. Safety Notices

2.1 Proper and Intended Usage



The MCL II control unit is designed for use



- as a control unit and power supply for the appropriate DewertOkin drive systems.
- for care purposes,
- or in hospitals.



| |
|---|
|  CAUTION |
|  <p>The MCL II control unit should only be used for the applications described above. Any other form of usage is not permitted and can lead to accidents or destruction of the unit. Such non-approved applications will lead immediately to the expiration of all guarantee and warranty claims on the part of the end-product manufacturer against the manufacturer.</p> |

2.1.1 Improper usage

Be sure to follow the notices below concerning improper usage. You should include them in your product manual in order to inform the users of your end product.

| |
|---|
|  WARNING |
|  <p>The MCL II control unit should not be used:</p> <ul style="list-style-type: none"> • in any environment where combustible or explosive gases or vapours (e.g., anaesthesiology) may be present, • in the proximity of open fires or other heat sources (such as furnaces, ovens or direct sunlight), • as a power source for toys or games, • in any application that will be cleaned with an automated washing system, • in a moist environment, or • outdoors. |

| |
|--|
|  CAUTION |
|  <p>The MCL II control unit may not be operated by:</p> <ul style="list-style-type: none"> • by small children, • by frail or infirm persons without supervision, or • in the proximity of small children. |

| |
|---|
|  CAUTION |
|  <p>You should only use spare parts which have been manufactured or approved by DewertOkin. Only original or approved spare parts guarantee sufficient levels of safety.</p> |

Using the drive systems in medical applications

This DewertOkin product is in compliance with the safety requirements found in IEC 60601-1.

We strongly recommend that the end product (including all its components) which you are manufacturing for a medical application should also be in compliance with the safety requirements found in IEC 60601-1.

You should make sure that the mechanical movement of the motor in your end product poses no risk of injury. Conduct a risk analysis for the end product for this purpose. You should also include safety notices in the instructions for the end product and technical safeguards in your product to eliminate any risk.

2.2 Selection and qualification of personnel

This MCL II control unit should only be installed into the end product by someone who has completed training in electronic motor assembly or has equivalent qualifications.

You should only install the MCL II control unit when you are qualified to do so. Otherwise, a properly qualified person should be found for this task.

2.3 Notice on safety during operations

Basic safety rules must be followed in order to ensure that the end product can be continually operated in a safe manner. These rules must be observed while using the end product and while installing the MCL II control unit.


These rules and safety measures can be categorized as follows:

- Construction measures before the installation (refer to the "Ensuring operational reliability during installation" section in the chapter "Installation").
- Safety fundamentals during the installation of the MCL II control unit and during cable and wire routing (refer to the "Electrical connection" section in the "Installation" chapter)
- Basic safety rules during operation (refer to the "Operating Notes" chapter).
- The creation of a manual for the end product which contains these and other safety rules.

2.3.1 Creating a user's manual

The manufacturer of the end product must create a manual for the users of that product. The safety notices in the end-product manual must be written based on the end product's risk assessment.

2.3.2 Electrical safety

| | |
|--|-------------------------|
|  | <p>! WARNING</p> |
| <p>There is a danger of electric shock! Be sure to unplug the power cord on the MCL II control unit before you begin assembly!</p> | |

The MCL II control unit should not be opened! You must properly dispose of malfunctioning or broken units.

2.4 Product labelling

2.4.1 Type plate

A ratings plate (or type label) on each MCL II control unit specifies the exact name and serial number of the drive. It also states the technical specifications valid for that particular control unit. The following illustration shows where the specifications are located on the ratings plate of the MCL II control unit.

- ▶ The ratings plate shown is an example. The specifications for MCL II control unit may differ from this illustration.









Figure 1 Ratings plate example for the MCL II control unit

| | |
|---|--|
| MCL II | Model name |
| xxxxx | Article No: |
| 100V - 240V ~ 50/60Hz | Input voltage and frequency |
| max. 3.15A | Rating of fuse |
| Intermittent Operation 2min/18min | Intermittent operations: 2 minutes / 18 minutes |
| Prod.date | Calendar week / year |
| Serial No. | Serial number of the MCL II control unit |
| IPX6 | Protection degree |
| Vx.xx | Software version (optional) |
|  | Labelling in accordance with the directives IEC 60601-1 and EN 60601-1, 3rd edition. |

| | |
|---|---|
|  | Use in dry rooms only! |
|  | Protection class II |
|  | Follow all special disposal instructions! |
|  | Conformity mark |

3. Possible combinations

The MCL II control unit can be combined with one or more drives. The following basic combinations are possible:

- one Megamat MCZ drive or a MFZ with a handset attached to the MCL II control unit,
- one Megamat MCZ or MFZ drive and up to three further single drives with a handset attached to the MCL II control unit,
- A MCL II control unit as a stand-alone device,
- an additional Supervisor, Control Box or short-circuit plug can optionally be connected,
- an optional connection for a rechargeable battery.

Systems can be customized by combining drives, control units, handset and batteries as needed.

DewertOkin has separate system instruction manuals containing additional information and instructions needed for these systems.

3.1 Layout of system connections

Refer to the sticker on the control unit for details about layout and positioning of the connections. The sticker is located above the sockets. It indicates the proper type of connections. The layout of the connection scheme is individual and depends on the system specifications. Figure 2 is only an example and shows you where the label is attached.




Figure 2 An illustration of where the connection layout sticker is positioned on the control unit

A Layout of connections

| | |
|--|---|
| | NOTICE |
| | Only connect the components according to the specifications found on the sticker on the control unit. Any other arrangement of connections may damage the control unit. |

4. Device description

The MCL II control unit is a control unit and power supply for one or more DewertOkin drives. A pluggable power cord is used to connect the MCL II control unit to the mains power supply. The MCL II control unit has a non-referenced (unearthed) circuit which is separated from the supply voltage by means of doubled reinforced insulation.

The models vary according to the:

- orientation of the drive to be installed (different mounting brackets for mounting the drives Megamat MCZ and MFZ).
- ▶ We reserve the right to make unannounced technical changes in the course of our continual product improvement process!

4.1 Components

The housing of the MCL II control unit has a connection for the power feed-in and connections for the drives and handset. The connection for the drive/handset is fitted with a mechanism to guard against accidental unplugging. A Megamat MCZ or MFZ drive can be fitted to the MCL II control unit (depending on the type of mounting clips used, see Figure 4).




Figure 3 Components for the MCL II control unit

- | | |
|--|--|
| A Power supply via pluggable power cord | B MCL II control unit |
| C Optional: Power supply for external devices | D Connection sockets for drives and handset with mechanism to protect against pulling out |
| E Screw fixing point to the end product (bore diameter: 5 mm) | F Mounting clip |

4.1.1 Mounting clip variations

The mounting clip variations allow Megamat MCZ and MFZ drives to be fitted to the MCL II control unit.




Figure 4 Mounting clip variations

A Megamat MCZ mounting clip

B Megamat MFZ mounting clip

4.1.2 Optional grounding cable

The optional grounding cable (refer to Figure 5) can be used to connect the end product with the grounding conductor on the power supply cord. Attach the grounding cable to your application in compliance with all applicable standards and using state-of-the-art methods.






Figure 5 Grounding cable on the power supply cord of the MCL II control unit



A Optional grounding cable

B Power cord

4.1.3 Mains power supply

| | |
|---|---|
|  |  WARNING |
| | <p>Please follow these operating instructions carefully. You could be injured by fire or electrical shock if you do not follow these assembly instructions.</p> |

The appropriate power cord is included, depending on the regional version (USA, continental Europe, the UK, Australia or Japan).

| | |
|---|--|
|  |  WARNING |
| | <p>Only use the proper power cable that is permitted in your country. Be sure to use the correct plug shape (refer to Figure 6).</p> |




Figure 6 Power cord, regional variants

- | | |
|--|--|
| A MCL II control unit | B Power plug (USA version) |
| C Power plug (German version) | D Power plug (Australian version) |
| E Power plug (United Kingdom version) | F Power plug (Japan version) |

5. Technical data

| | |
|---|--|
| Mains power supply | 100 - 240V AC, 50/60Hz |
| Current consumption at nominal operations | Max. 4 A (depending on input voltage) |
| Mode of operations ¹ | Intermittent duty 2 min./18 min. |
| Protection class | II |
| Permitted current consumption of all additional drives ² | Max. 11 A (depending on version) |
| Protection degree | IPX6 |
| Colours | Refer to sales brochure. |
| Dimensions and weight | |
| Length x width x height | 175 mm x 145 mm x 94 mm (without mounting clip and shield cover) |
| Weight | Approx. 770 g |
| Ambient conditions for operation, storage and transport | |
| Transport / storage temperature | From -20 °C to +50 °C From -4 °F to +122 °F |
| Operating temperature | From +10 °C to +40 °C From +50 °F to +104 °F |
| Relative humidity | From 30% to 75% |
| Air pressure | From 800 hPa to 1060 hPa |
| Altitude | < 2000 m |

¹ Mode of operation: intermittent duty 2 min./18 min. This means that after the unit is operated with its rated load for up to two minutes it must then be paused for 18 minutes. The system can malfunction if this pause is not observed!

² No more than two drives may be operated at rated load simultaneously!




Figure 7 Dimensions of the MCL II control unit, top view (in mm)




Figure 8 Dimensions of the MCL II control unit, front view (in mm)




Figure 9 Dimensions of the MCL II control unit, side view (in mm)

6. Installation

6.1 Safety notices to observe during installation

Basic safety rules must be followed in order to ensure that the end product can be continually operated in a safe manner. These rules must be observed while using the end product and while installing the MCL II control unit.

6.1.1 Avoiding electrical faults



The power supply cord is designed to be connected to an outlet near the floor. Be sure to consider the length of the power cord when designing the dimensions for your end product in order to minimize the associated risks.

6.1.2 Ensuring operational reliability during installation

The safety and reliability of the end product containing DewertOkin components can be ensured by using the proper construction methods described below.

Overheating

A thermal fuse switches the MCL II control unit off if it overheats.

| | |
|---|--|
|  |  CAUTION |
| | The MCL II control unit is equipped with a thermal fuse that triggers when the unit overheats. If the temperature control has triggered, remove the control unit from the power supply, allow to rest for 20 - 30 minutes and try again. If the control unit still does not function, please contact your supplier / dealer. |

Installation dimensions of the Megamat drives.

The installation dimension of the Megamat drives may not be less than a certain level (installation length of Megamat drives with standard clevis). The drive or drive control unit could be mechanically damaged if the installation length is shorter than this. The standard installation dimensions are:

- Megamat MCZ: at least 285 mm
- Megamat MFZ: at least 276 mm

Mechanical construction

A shield covering the sockets protects the connections from mechanical damage and accidental unplugging.

6.2 Installation procedure

Before installing the MCL II control unit, make sure that you are observing all of the safety notices found in the "Safety notices to observe during installation" section.

6.2.1 Installation and dismounting for the control unit

There are four mounting holes in the MCL II control unit which can be used to attach it to the end product with the appropriate screws (for example, 4.5 mm x 30 mm screws). The MCL II control unit should be mounted so that it lies flat against its supporting material. In the end product, no mechanical forces (such as torsion) should be put on the MCL II control unit or its housing. Such forces could lead to damage (such as cracks) in the housing.





Figure 10 MCL II control unit mounting points (in mm)

6.2.2 Fitting the Megamat MCZ drive onto the MCL II control unit

| | |
|---|--|
| NOTICE | |
|  | <p>The installation length of the MCZ drive should not be less than 285 mm (installation length of MCZ drive with standard clevis). The drive or drive control unit could be mechanically damaged if the installation length is shorter than this.</p> |





Figure 11 Fitting the Megamat MCZ drive onto the MCL II control unit

- | | |
|---|------------------------------|
| A Power cord | B MCL II control unit |
| C Guide for the Megamat MCZ drive's motor casing cover | D Megamat MCZ drive |
| E Guidance profile | F Mounting clip |

The Megamat MCZ drive is fitted to the MCL II control unit by fixing the mounting clip to the control unit and tightening it in place.

| | |
|--|---|
|  CAUTION | <p>Assembly and disassembly should only be done where the drive is not supporting a load!</p> |
|--|---|





Figure 12 Mounting clip assembly

F Mounting clip

G Four tapping screws (3.5 mm x 19 mm, meeting DIN 7981)

- 1 Slide the MCZ drive's guide flange (E) into the mounting clip (F) so that the motor casing cover lies in the guide (C) as shown in Figure 11.
- 2 Screw the mounting clip (F) onto the MCL II control unit.
- 3 The drive can then be connected to the proper socket on the MCL II control unit (refer to the "Electrical connection" section).

6.2.3 Fitting the Megamat MFZ drive onto the MCL II control unit

| | |
|---|--|
| NOTICE | |
|  | <p>The installation length of the MFZ drive should not be less than 276 mm (installation length of MFZ drive with standard clevis). The drive or drive control unit could be mechanically damaged if the installation length is shorter than this.</p> |




Figure 13 Fitting the Megamat MFZ drive onto the MCL II control unit

- | | |
|---|------------------------------|
| A Power cord | B MCL II control unit |
| C Guide for the Megamat MFZ drive's motor casing cover | D Megamat MFZ drive |
| E Guidance profile | F Mounting clip |

The Megamat MFZ drive is fitted to the MCL II control unit by fixing the mounting clip to the control unit and tightening it in place.

| | |
|--|--|
| | CAUTION |
| | Assembly and disassembly should only be done where the drive is not supporting a load! |






Figure 14 Mounting clip assembly


F Mounting clip

G Four tapping screws (3.5 mm x 19 mm, meeting DIN 7981)

- 1 Slide the mounting clip (F) over the flange guide (E) of the MFZ drive as shown in Figure 13. To do this pull the mounting clip apart slightly.
- 2 The motor casing cover of the MFZ drive must lie in the guide (C) as shown in Figure 14.
- 3 Screw the mounting clip (F) onto the MCL II control unit.
- 4 The drive can then be connected to the proper socket on the MCL II control unit (refer to the "Electrical connection" section).

6.2.4 Electrical connection

| | |
|---|---|
|  |  CAUTION |
| | Electrical components should be connected or disconnected only when the power supply cord is unplugged. |

| | |
|---|--|
|  | NOTICE |
| | There is a delay after the supply voltage is applied before the device actually turns on. Wait at least 15 seconds before commissioning. |

Routing the electrical cables

When routing the cables, be sure that:

- the cables cannot get jammed,
- no mechanical load (such as pulling, pushing or bending) will be put on the cables, and
- the cables cannot be damaged in any way.

Fasten all cables (especially the connecting cables) to the end product using sufficient kink prevention methods. Be sure that the design of the end product prevents the connecting cables from coming into contact with the floor during transport.

Connecting the Megamat drives to the MCL II control unit

The electrical connection from the Megamat drive to the MCL II control unit is made by plugging the drive plug into the MCL II control unit.

Take off the shield cover (refer to the "Opening the shield cover" section) and plug the drive plug into the proper socket. Make sure that you use the proper connection position as specified in the connection layout illustration (refer to the "Layout of system connections" section).

Opening the shield cover








Figure 15 Opening the shield cover on the MCL II control unit

- 1 Pull out the mains plug from the outlet.



| | |
|---|--|
|  |  CAUTION |
| <p>You should only connect and disconnect the cables when they are completely disconnected from any live current!</p> | |

- 2 Use a suitable tool to press the three locking clips down in the notches as shown in Figure 15. At the same time, tilt the shield cover forward so that the clips come out of the notches.
- 3 Remove the shield cover.
- 4 You can now connect or disconnect a plug and socket. Be sure to use the proper socket. (The assignments of plugs to sockets is shown in the connection layout diagram. Figure 2 shows the connection positions.)

6.2.5 Connecting the pluggable power cord to the MCL II control unit

| | |
|---|--|
|  |  WARNING |
| <p>Please follow these operating instructions carefully. You could be injured by fire or electrical shock if you do not follow these assembly instructions.</p> | |

The appropriate power cord is included, depending on the regional version (USA, continental Europe, the UK, Australia or Japan).

| | |
|--|--|
|  |  WARNING |
| <p>Only use the proper power cable that is permitted in your country. Be sure to use the correct plug shape (refer to Figure 6).</p> | |




Figure 16 Connecting the pluggable power cord to the MCL II control unit

A MCL II control unit


B Locking cap

C Power plug

D Mains connection socket of the MCL II control unit


The pluggable power cord should be attached to the power socket (D) located on the rear of the control unit.

- 1 Pull out the mains plug from the outlet.

| | |
|---|--|
|  | CAUTION |
| | You should only connect and disconnect the cables when they are completely disconnected from any live current! |

- 2 Remove the cap (B) from the socket.
- 3 Plug the power plug from the power cord (C) into the socket.
- 4 Push the cap (B) onto the inserted plug until you hear the cap snap on.

Follow the notice below when plugging the power plug into the power outlet:

| | |
|---|--|
|  | NOTICE |
| | There is a delay after the supply voltage is applied before the device actually turns on. Wait at least 15 seconds before commissioning. |

6.2.6 Connecting the optional battery

An external rechargeable battery can be connected to the optional battery socket. The sticker above the sockets shows the position of the battery socket (refer to the "Layout of system connections" section in the "Possible combinations" chapter).

- 1 Pull out the mains plug from the outlet.
- 2 Use a suitable tool to press the three locking clips down into the notches as shown in Figure 15. At the same time, tilt the shield cover forward so that the clips come out of the notches.
- 3 Remove the shield cover.
- 4 Insert the battery plug into the battery socket on the MCL II control unit. Be sure to use the proper socket (the assignments of plugs to sockets is shown in the connection layout diagram). Figure 2 in the "Possible combinations" chapter shows the connection positions.
- 5 Push the shield cover on until the locking clips snap into the notches.



6.2.7 Connecting the optional, additional Supervisor or Control Box

The Supervisor or the Control Box can be connected to the optional Supervisor socket. The sticker above the sockets shows the position of the Supervisor socket (refer to the "Layout of system connections" section in the "Possible combinations" chapter).

- 1 Pull out the mains plug from the outlet.
- 2 Use a suitable tool to press the three locking clips down into the notches as shown in Figure 15. At the same time, tilt the shield cover forward so that the clips come out of the notches.
- 3 Remove the shield cover.
- 4 Insert the Supervisor, Control Box or short-circuit plug in the Supervisor socket of the MCL II control unit. Be sure to use the proper socket (the assignments of plugs to sockets in shown in the connection layout diagram). Figure 2 in the "Possible combinations" chapter shows the connection positions.
- 5 Push the shield cover on until the locking clips snap into the notches.

6.2.8 Removing the MCL II control unit



- 1 Pull out the mains plug from the outlet.

| | |
|---|--|
|  |  CAUTION |
| | You should only connect and disconnect the cables when they are completely disconnected from any live current! |

- 2 Open and remove the shield cover (refer to Figure 15).
- 3 Disconnect all connecting cables from the MCL II control unit.
- 4 Remove all the screws from the mounting clip (F) as shown in Figure 11 or Figure 13.
- 5 Remove the control unit from the Megamat MCZ or MFZ drive.

7. Operating Notes

The factual information contained within may be used when you are creating the end-product manual. The installation instructions do not contain all information required for the safe operation of the end product. They only describe the assembly and operation of the MCL II control unit as a partially assembled piece of machinery.


| | |
|---|--|
|  |  CAUTION |
| | When creating the operating instructions, remember that the installation instructions are intended for qualified specialists and are not for typical users of the end product. |

7.1 General information

- ▶ Only drives from DewertOkin should be connected to the MCL II control unit since they have already been verified to work together.

Delayed start-up

Follow the notice below when plugging the power plug into the power outlet:

| | |
|---|--|
|  | NOTICE |
| | There is a delay after the supply voltage is applied before the device actually turns on. Wait at least 15 seconds before commissioning. |


Power-on time / intermittent operations

The MCL II control unit has been designed for intermittent operations. Intermittent operation is an operational mode where the drive must pause after a specified maximum period of operation (power-on time). This protects the drive from overheating. In an extreme case, overheating can lead to a malfunction.



- ▶ The ratings plate on the drive specifies the maximum power-on time and the required pause intervals.

Avoiding toggle operations



You should avoid switching from one direction of travel to the opposite direction without first stopping the motor. – Make sure that you pause between motions! A pause (motor stop time) can be activated using the operating element or handset.



| | |
|---|--|
|  | NOTICE |
| | You should always avoid a quick change ("toggle") of directions. |

Avoiding electrical risks



| | |
|---|---|
|  |  WARNING |
| | <p>Be sure that all live (current-carrying) parts of the drive system and power supply cannot be touched. In particular, be sure that unused power and control unit connections are covered adequately.</p> |

Power cord


| | |
|---|---|
|  |  WARNING |
| | <p>Please follow these operating instructions carefully. You could be injured by fire or electrical shock if you do not follow these assembly instructions.</p> |

| | |
|--|--|
|  |  WARNING |
| | <p>Only use the proper power cable that is permitted in your country. Be sure to use the correct plug shape (refer to Figure 6).</p> |



Reducing the risk of overheating with the thermal fuse

| | |
|---|---|
|  |  CAUTION |
| | <p>The MCL II control unit is equipped with a thermal fuse that triggers when the unit overheats. If the temperature control has triggered, remove the control unit from the power supply, allow to rest for 20 - 30 minutes and try again. If the control unit still does not function, please contact your supplier / dealer.</p> |

Avoiding overheating



| | |
|---|--|
|  | NOTICE |
| | <p>No more than two drives may be operated at rated load simultaneously!</p> |

Emergency shut off of a connected drive or control unit

| | |
|---|--|
|  |  CAUTION |
| | <p>In an emergency, disconnect the MCL II control unit's power plug in order to shut off the connected drive. The power plug must always be accessible during operations so that it is possible to shut down the drive or control unit at any time.</p> <p>If the optional battery is connected, disconnect the battery plug from the socket on the MCL II control unit.</p> |

Avoiding cable damage

Be sure that your operating instructions inform the user about the possible cable risks.

| | |
|--|---|
|  |  CAUTION |
| | <p>The cables (particularly the connecting cable) should not be run over. In order to prevent injuries or damage to the drive and MCL II control unit, no mechanical strain should be placed on the cables.</p> |

7.2 Notice for operating with optional configuration

7.2.1 Option with Rechargeable battery with no integrated charging circuitry

If you have purchased an MCL II with no integrated charging circuitry then note the information below when operating with the optional external battery:

- Load the battery for at least 24 hours before first use.
- Using a suitable DewertOkin charger. Follow the instructions that come with the battery charger!
- The battery charge status is displayed on the handset when the handset is equipped with a battery display:
 - The battery is being loaded when the battery control light is blinking.
 - The battery is ready when the unit is plugged into the mains and the battery control light is continuously illuminated.
- After you have used the battery-operated reset function, be sure to charge the battery until the ready signal is displayed (the battery control light, when present, stays illuminated).
- ▶ Follow the additional information found in the rechargeable battery information sheet (ID No. 45564).



7.2.2 Option with rechargeable battery with integrated charging circuitry

If you have purchased the MCL II with the integrated charging circuitry and external battery, then you should note the following:

- Load the battery for at least 24 hours before first use.
- The battery charge status is displayed on the handset when the handset is equipped with a battery display:
 - The battery is being loaded when the battery control light is blinking.
 - The battery is ready when the unit is plugged into the mains and the battery control light is continuously illuminated.
- Optional: A warning tone is issued when the battery charge is low. Shortly after the tone, the battery is switched off so that it cannot be damaged by a drain discharge.
- After you have used the battery-operated reset function, be sure to charge the battery until the ready signal is displayed (the battery control light, when present, stays illuminated). The integrated charging circuitry in the MCL II control unit controls the charge automatically.
- ▶ Follow the additional information found in the rechargeable battery information sheet (ID No. 45564).

8. Troubleshooting

This chapter contains remedial actions should any malfunctions occur. If you experience an error that is not listed in this table, please contact your supplier.

| | |
|---|--|
|  |  CAUTION |
| | <p>Only qualified specialists who have received electrician training should carry out troubleshooting and repairs.</p> |

| Problem | Possible cause | Solution |
|--|--|---|
| The drive or control unit is not functioning. | There is no mains supply voltage. | Connect the mains power. |
| | The drive or control unit is defective. | Please contact your supplier or sales agent. |
| The drive is suddenly not capable of movement. | The overheating protection or system protection has been triggered. | Remove the overload (change or remove the load). Remove the power plug and allow the system to rest for 20 to 30 minutes. If this does not resolve the problem, contact your supplier or distributor. |
| | The unit's fuse may have been triggered. | Please contact your supplier or sales agent. |
| | There is no mains supply voltage. | Connect the mains power. |
| | A cable has been disconnected (mains power, lifting column or control keypad). | Check the cables and reinsert them, if required. |

9. Maintenance


- ▶ You should only use spare parts which have been manufactured or approved by DewertOkin. Only original or approved spare parts guarantee sufficient levels of safety.

9.1 Maintenance


| Type of check | Explanation | Time interval |
|---|---|---|
| Check the function and safety of the electrical system. | A qualified electrician should carry out this inspection. (Refer to the "Electrical connection" section in the "Installation" Chapter.) | Periodic inspections can be carried out at intervals based on the risk assessment which you conduct for your end product. |
| Look over the housing periodically for any signs of damage. | Check the housing for breaks or cracks. | At least every six months. |
| Look over the plug-in connections and electrical access points for signs of damage. | Check that all electrical cables and connections are firmly seated and correctly positioned. | At least every six months. |
| Look over the cables for any signs of damage. | Check the connecting cables for pinching or shearing. Also check the strain relief and kink protection mechanisms, in particular after any mechanical load. | At least every six months. |
| Check periodically to see if the rechargeable battery is ready and operational. (Battery is optional) | If you can no longer move the drive in both directions with a fully charged battery, then you should replace the battery. | At least every four weeks. |

9.2 Cleaning and care

The MCL II control unit was designed so that it would be easy to clean. The smooth surfaces can be conveniently cleaned.

| NOTICE | |
|---|--|
|  | Never clean the MCL II control unit in an automated washing system or with a high-pressure cleaner. Do not allow fluids to penetrate the lighting. Damage to the system could result. Do not use a cleanser that contains benzene, alcohol or similar solvents. |

- 1 Be sure to unplug the power cord on the MCL II control unit before you begin cleaning it!

| CAUTION | |
|---|--|
|  | For the optional rechargeable battery: Disconnect the battery plug from the socket on the MCL II control unit. |

- 2 Clean the MCL II control unit using a moist cloth
- 3 Be sure that you do not damage the connecting cables during the cleaning.

10. Disposal

The MCL II control unit consists of electronic components, cables and metal and plastic parts. You should observe all corresponding national and regional environmental regulations when disposing of the MCL II control unit.

The disposal of the end product is regulated in Germany by Elektro-G, internationally by the EU Directive 2002/95/EC (RoHS, from 1 Jul. 2006) and Directive 2011/65/EU (RoHS, from 3 Jan. 2013), or by any applicable national laws and regulations. (The end product is not regulated by the EU Directive 2002/96/EC (WEEE) and its amendment EU Directive 2003/108/EC.)



The MCL II control unit should not be disposed of with normal household waste!



The disposal of the rechargeable battery is regulated in the EU by the Battery Directive 2006/66/EC, in Germany by the BattG battery law of 25.6.2009, and internationally by any applicable national laws and regulations.



This battery should not be disposed of with normal household waste!



EU Declaration of Conformity

In compliance with Appendix IV of the EU EMC Directive 2004/108/EC
In compliance with Appendix III of the EU Low Voltage Directive 2006/95/EC
In compliance with Appendix VI of the EU RoHS Directive 2011/65/EU

The manufacturer:
DewertOkin GmbH
Weststraße 1
32278 Kirchlengern
Germany

declares that the following product

MCL II control unit

meets the requirements of the following EU directives:

Electromagnetic Compatibility Directive 2004/108/EC

Low Voltage Directive 2006/95/EC

RoHS Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment

Applied standards:

- EN 60335-1:2012
- EN 55014-1/A1:2009
- EN 55014-2/A2:2008
- EN 61000-3-2/A2:2009
- EN 61000-3-3:2008
- EN 62233:2008

This declaration of conformity is no longer valid if constructional changes are made which significantly change the control unit (i.e., which influence the technical specifications found in the instructions or the intended use)!

Kirchlengern, Germany on 15 December, 2012



Sascha Koltzenburg
Head of R & D

Additional information

MCL II drive control unit

In accordance with EN 60601-1:1990 +A1:1993 +A2:1995, "Electrical medicinal devices", the following standards are used:

| | |
|----------------------------|---|
| EN60601-1, Main section 2 | Ambient conditions Electrical shock protection |
| EN60601-1, Section 21 | Mechanical attachment |
| EN60601-1, Main section 7 | Overheating protection |
| EN60601-1, Main section 9 | Improper operations and malfunctions |
| EN60601-1, Main section 10 | Structural requirements |
| EN60601-1, Section 56.8 | Power supply indicator is, however, not present |

In accordance with EN1970:2000, "Beds for disabled persons", the following standards are used:

| | |
|-----------------------------|---|
| EN1970, Section 4 partially | Unintentional movement: Prevented by means of a locking mechanism (such as a control box) or IPROXX® The back section can be lowered by means of an optional battery |
| EN1970, Section 5.5.8 | Dimensions of the control unit (IPROXX®) |
| EN1970, Section 5.6 | Operational forces for the electrical functions (IPROXX®) |
| EN1970, Section 5.7 | Functional speeds (for adjusting the head and foot sections) |
| EN1970, Section 5.11 | Electrical requirements of protection degree: only for IPX4 |
| EN1970, Section 5.12 | Electromagnetic compatibility |

In accordance with EN60601-2-38:1996 +A1:2000, "Electrically operated hospital beds", the following standards are used:

| | |
|--------------------------------|---|
| EN60601-2-38, Section 5.2 | The classification of application parts |
| EN60601-2-38, Section 5.3 | System protection category, only for \geq IPX4 |
| EN60601-2-38, Section 22.2.102 | Only with locking device: Control box, Supervisor, or IPROXX [®] SE |
| EN60601-2-38, Section 22.4.101 | Control unit with button |
| EN60601-2-38, Section 36 | Electromagnetic compatibility |
| EN60601-2-38, Section 52.4 | Unintentional movement (locking device) |
| EN60601-2-38, Section 52.5 | First fault (electrical): Prevented by means of a locking mechanism or IPROXX [®] |
| EN60601-2-38, Section 52.5.9 | Component outages: Prevented by means of a locking device |
| EN60601-2-38, Section 52.5.101 | Outages of electrical components |
| EN60601-2-38, Section 52.5.102 | Inclination of the back section and the Trendelenburg during a power outage: by means of a battery |
| EN60601-2-38, Section 56.8 | Lighting (not required) |
| EN60601-2-38, Section 57.3a | Power cord (for example, EPR or similar) |
| EN60601-2-38, Section 57.3.101 | Mains plug |

The following standards have been used - according to IEC 60601-1, EN 60601-1, 3rd edition, medical electrical equipment (Label: **3E**), see ratings plate):

| | |
|-----------------------------|--|
| IEC/EN60601-1, Section 8 | Protection against electrical danger |
| IEC/EN60601-1, Section 11 | Protection against overheating and other risks |
| IEC/EN60601-1, Section 13 | Dangerous situations and error conditions |
| IEC/EN60601-1, Section 15 | Design |
| IEC/EN60601-1, Section 16.6 | Leakage current |

In accordance with IEC 60601-2-52, EN 60601-2-52, "Particular requirements for the safety and essential performance of medical beds", the following standards are used (Label: **3E** see ratings plate):

| | |
|---|--|
| IEC/EN60601-2-38, Section 201.6.2 | Protection against electrical shock: Protection class II |
| IEC/EN 60601-2-52, Section 201.7.6.3 | Control panel symbols (depending on model, customer requirements) |
| IEC/EN 60601-2-52, Section 201.8.11.3.2 | Power supply lead: only ≥ 2.5 m length Power supply lead: for example, EPR or similar |
| IEC/EN 60601-2-52, Section 201.9.2.2.5 | Continuous operations: Control unit only with button |
| IEC/EN 60601-2-52, Section 201.9.2.3.1 | Unintentional movement: Prevented by means of a locking mechanism (such as Control box, Supervisor, IPROXX [®] SE, IPROXX [®] , or Meditouch) |
| IEC/EN 60601-2-52, Section 201.11.1.1 | Temperatures |
| IEC/EN 60601-2-52, Section 201.11.6.5.101 | Protection against water ingress: only for \geq IPX4 |
| IEC/EN 60601-2-52, Section 201.11.8 | Power outage: for example, battery usage, depending on version (customer requirement) |
| IEC/EN 60601-2-52, Section 201.13.1.4 | Special mechanical hazards: Prevented by means of a locking mechanism (such as Control box, Supervisor, IPROXX [®] SE, IPROXX [®] , or Meditouch) |
| IEC/EN 60601-2-52, Section 201.15.3.4.1 | Mechanical attachment – handset |
| IEC/EN 60601-2-52, Section 201.15.4.4 | Displays: Ready indicator is not required |
| IEC/EN 60601-2-52, Section 201.17 | Electromagnetic compatibility |
| IEC/EN 60601-2-52, Section BB.3.3.3 | Dimensions: vary according to the model (customer requirement) |
| IEC/EN 60601-2-52, Section BB.3.4.1 | Operating forces |

DewertOkin GmbH
Weststraße 1
32278 Kirchlengern, Germany
Tel: +49 (0)5223/979-0
Fax: +49 (0)5223/75182
<http://www.dewertokin.de>
Info@dewertokin.de

ID-Nr.: 68008