



TOMOS

CLASSIC

OWNER' S NAME

ADDRESS

PHONE/E-MAIL

MODEL/TIP

VIN NO.

DATE OF DELIVERY

DEALER' S NAME

DEALER' S ADDRESS

All claims made within the warranty period should be submitted to an authorized service workshop, along with the warranty itself.

THE DEALER' S STAMP
AND SIGNATURE

TOMOS

CLASSIC

WARRANTY TABLE

KM
months

1.000
2

3.000
6

10.000
12

15.000
18

20.000
24

DATE	DATE	DATE	DATE	DATE
SERVICE	SERVICE	SERVICE	SERVICE	SERVICE

**TOMOS
USER'S MANUAL
CLASSIC**

CONTENTS

Warnings	3
Riding Safety Tips	3
Technical Specification	4-5
Technical Description	6-8
Vehicle operation	9
Fuel	9
Engine Starting	9
Riding	11
Engine Running-In	11
Maintenance	12
Maintenance Operations	12
Lubricants	12
Gearbox Oil change	12
Cleaning	13
Fuel System Cleaning	13
Exhaust System Cleaning	14
Vehicle Cleaning	15

Checks and Adjustments	15
Engine Oil Level Check	15
Bowden Adjustment	15
Transmission Chain Adjustment	16
Bolt and Nut Tightness	16
Maintenance Schedule	17
Troubleshooting	18
Fuel System Troubles	18
Ignition System Troubles	18
Troubles Causing Reduced Engine Power	18
Gearbox Troubles	19
Tomos warranty conditions	20

WARNINGS

Prior to operating the vehicle, carefully read this User's Manual in order to get acquainted with its operational characteristics and safe and proper operation.

1. Fuel is extremely flammable and explosive; therefore it requires special handling precautions:
 - Stop the engine prior to refilling the tank;
 - Fill the tank outdoors; never approach the tank with a lit cigarette, open flame or sparks; and
 - Thoroughly wipe off any spilled fuel
2. The engine should not be run in an enclosed space or nearby entrances to lower-level areas (cellars etc.). Engine exhaust gases are toxic and denser than normal atmospheric air.
3. When starting or running the engine, never touch the ignition coil, high voltage cable, ignition spark plug cap or other parts of the electrical system.
4. The vehicle is equipped with a catalysts exhaust system causing high temperatures. When the engine is running and for some time after it has stopped do not touch its hot parts: the cylinder, the cylinder head, exhaust silencer. Do not touch the brake components too.
5. When the engine is running beware of the engine's rotating parts. No modification of the vehicle, stripping-off any parts or installing non-original spare parts is permitted. The vehicle owner is specifically warned that any modification to the exhaust system can only result in the vehicle's deteriorated operation, without any positive effects on engine performance and causes higher air pollution.

RIDING SAFETY TIPS

Riding a two wheeler is simple, yet it requires some skills and experience which can only be accumulated progressively. Prior to each ride, observe the following rules:

1. Check the proper functioning of all vehicle assemblies.
2. When riding, wear light-colored, preferably light-reflective clothes; ride with your lights on; avoid riding in other drivers "blind spots" to prevent danger of other drivers "overlooking" you.
3. Abide by all traffic regulations; above all, adjust your riding speed to the road conditions and your skill level.
4. Do not hand the vehicle over to any inexperienced riders.
5. Prior to changing lanes, always check that this can be done safely, and signal your intention in time. Be careful when riding through road crossings or passing other vehicles (including parked vehicles)..
6. Always ride with your helmet on, be properly dressed and wear boots.
7. Pay due attention to what is going on in front of you and behind you (rear mirror) and try to anticipate events
8. The braking affects the loading on each wheel: the front braking increases; whereas braking with the rear brake only increases the braking distance while also reducing vehicle stability; hence use the rear brake with caution.

TECHNICAL SPECIFICATIONS

Model	Classic	
Variants	A34B – 45km/h A34C – 30km/h A34D – 25km/h A34E – 20km/h	
Engine	Type	single-cylinder, two-stroke air-cooled
	Displacement	49 cm ³
	Cylinder bore diameter	38 mm
	Piston stroke	43 mm
	VARIANT A34B:	
	Compression ratio	10 : 1
	Engine power	1,7 kW at 4800 min-1
	Torque	3,6 Nm at 3500 min-1
	Maximum speed	45 km/h
	Fuel consumption	1,8/100km

VARIANT A34C:	
Compression ratio	6 : 1
Engine power	1,0 kW at 3500 min-1
Torque	3,1 Nm at 2500 min-1
Maximum speed	30 km/h
Fuel consumption	2,2/100km

VARIANT A34D:	
Compression ratio	6 : 1
Engine power	1,0 kW at 3500 min-1
Torque	3,1 Nm at 2500 min-1
Maximum speed	25 km/h
Fuel consumption	2,5/100km

VARIANT A34E:	
Compression ratio	6 : 1
Engine power	1,0 kW at 3500 min-1
Torque	3,1 Nm at 2500 min-1
Maximum speed	20 km/h
Fuel consumption	2,8/100km

Starter Kick-starter or pedals

Fuel	Tank capacity	4 l (incl.0,5 l reserve)	Dimensions And weights	Wheelbase	1.080 mm
	Engine oil reservoir	1 l		Total length of vehicle	1.640 mm
Suspension	Front forks travel	70 mm		Vehicle mass (empty fuel tank)	60 +3 kg
	Rear shock absorber travel	35 mm		Maximum permitted total weight	160 kg
Wheels	Front tire dimensions	2 ¼ -16			
	Rear tire dimensions	2 ¼ -16			
	Front tire inflation pressure	2,2 bar			
	Rear tire inflation pressure	2,2 bar			
Electrical system	Magneto	12V 80W			
	Spark advance	preset			
	Spark plug-A24B	Bosna F75, BOSCH-W7AC			
	Spark plug-A24C, A24D, A24E	Bosna F75, Champion-L86			
	Spark plug electrode clear.	0,8 mm			
	Headlight	12V 25W			
	Tail light	12V 5W			
	Stop light	12V 15W			
	Speedometer illumination	12V 2W			
	Oil level signal light	12V 1,5W			

TECHNICAL DESCRIPTION

1. Fuel tank cap
2. Fuel petcock
3. Carburetor, choke
4. Kick starter lever or pedals
5. Prop stand
6. Rear brake lever
7. Front brake lever Electric start pushbutton (version)
8. Throttle lever
9. Horn switch
- 9a. STOP switch
10. Tool bag
11. Speedometer
12. Oil level signal light
13. Chain tension adjuster
14. Air filter
15. Engine oil reservoir, cap
16. Luggage carrier
17. Oil pump
18. Steering lock




Fig. 1




Fig. 2




Fig. 3




Fig. 4

VEHICLE OPERATION

Fuel

EUROSUPER 95 and two-stroke engine oil.

Your vehicle is equipped with an oil pump, which adds a specified amount of oil to the petrol (approx. 2%). Pour two-stroke oil into the separate oil reservoir (15, Fig. 1) - approximately 1 liter.

CAUTION!

See the Warning sticker for the max. oil level near to the oil reservoir.

Use only high quality fully synthetic two-stroke oil.

CAUTION!

Prior to starting the engine for the first time, fill the fuel tank (1, Fig. 1) with approx. 1 liter mixture of two-stroke oil and gasoline in the ratio of 1:50 (2%), then start the engine and let it run for at least 8 minutes in order to allow the oil pump to fill the suction pipe.

Before this take off the oil pump cover (17, Fig. 1) and unscrew the bolt on oil pump (A, Fig. 3) and wait till oil comes from reservoir. Tighten the bolt.

Engine starting

Open the fuel cock (Fig. 5). Note: A – fuel supply shot, B – fuel supply on, C - reserve.

If the engine is cold, press the cold start lever (B, Fig. 6).

Kick start version:

With the throttle fully closed, press the rear brake lever and press the kick-starter lever (4, Fig. 1) – without opening the throttle.

If starting the engine when it is still warm, the throttle must be fully opened.

Pedal version:

With the throttle fully closed, press the rear brake lever and press the pedals (4, Fig. 1) backwards – without opening the throttle.

If starting the engine when it is still warm, the throttle must be fully opened.

When using the choke, allow the engine to run for 10 to 20 seconds without opening the throttle. The choke start lever disengages automatically when the throttle is opened.

In the case the engine is hot do not use the choke lever.




Fig. 5




Fig. 5

Riding

The speed is controlled by the throttle lever (8, Fig. 2).

Engaging the first or second gear is done by opening or closing the throttle. Avoid switching too frequently between first and second gears. In such situation you should instead reduce the throttle opening and keep the vehicle in first gear. When descending a slope, shortly open the throttle from time to time in order to improve lubrication and headlight operation. The vehicle is shut down by closing the throttle lever and switching the STOP button to the position off (9a, Fig. 4). Then close the fuel cock (position A, Fig. 5)!

If the vehicle is to stay out of operation for a longer period (e.g. during winter), draining of the fuel from the carburetor cup in the following way is recommended: close the fuel cock and, by opening the throttle lever, let the engine run out automatically.

Engine Running-in

Do not run the engine at full throttle during the initial 100 km. Later increase the engine loading progressively.

MAINTENANCE

Maintenance Operations

The vehicle is easy to maintain, yet maintenance is imperative for perfect performance. Particularly important operations include regular lubrication of individual assemblies, gearbox oil changes, cleaning of parts affecting engine operation (spark plug, exhaust system, fuel system) and checking of safety-related riding components (tire pressure, operation of lights and brakes, tightness of bolts and nuts). The maintenance table defines maintenance works in certain intervals in km and months - consider whichever comes first - for the period up to 20.000 km or 24 months.

Lubricants

For the gearbox apply the automatic gearbox oil: ATF A or ATF F. For lubrication of other vehicle components (see the maintenance schedule), application of SAE 30 grade engine oil and LIS 2 grease is recommended.

Gearbox Oil Change

Oil should be changed when the engine is still warm. Remove the right side shield; release three threaded plugs (1, 2, 3, Fig. 7) on the right side of the engine casing, and let the oil drain completely. Retighten oil

draining plug (3, Fig. 7) and pour approx. 300 cm³ of oil through the refilling opening (1, Fig. 7), so that oil level reaches the control opening (2, Fig. 7). Then, retighten the oil refilling and control opening plugs.




Fig. 7

CLEANING

Fuel System Cleaning (Fig. 8)

As regards the fuel system, periodic cleaning of the main jet, air filter and fuel petcock filter is required. Do not use metal objects to clean the main jet; clean it with an air jet.

Filter – sponge should be washed thoroughly in gasoline. After washing, squeeze gasoline from the sponge (do not brush it) and dry the sponge in a dry air jet.




Fig. 8

Exhaust system cleaning (Fig. 9)

The build up of soot in the exhaust system obstructs the free passage of exhaust gas and thereby reduces engine power.

Periodically, clean the cylinder exhaust duct, exhaust pipe inlet opening, piston crown and cylinder compression chamber (Fig.10).

Caution: exhaust system is equipped with catalyts, so do not enter into the exhaust pipe with any tools, wires, do not pour in any fluid, etc. Any such intervention can cause damage of the catalyts.

We strongly suggest making exhaust system cleaning by an authorized service agent.




Fig. 9




Fig. 10

Vehicle cleaning

Vehicle exterior cleaning is also part of regular maintenance. After washing, wipe the vehicle dry. Protect painted surfaces with paint protection agents. After cleaning, check the operation of the engine, the lights and brakes.

CHECK AND ADJUSTMENTS

Engine Oil Level Check

Check regularly the oil level in the oil tank. Top up as required. Should the warning light fail to extinguish after starting the engine, this means the oil level is low and immediate topping up is required.

Caution:

Kick-starter and pedals version: the warning light lights few seconds after starting the engine. If does not, the fault should be remedied.

Bowden Adjustment

Bowden brakes are adjusted by means of the bolts on the wheels hubs. The Bowden is properly set when the brake lever free travel is 10-15 mm and the sleeve – lever gap is approx. 3 mm (Fig. 11). After adjusting, make sure the jam nut is retightened.




Fig. 11

Transmission Chain Adjustment

The chain tension should be adjusted so that the chain yields 10 mm up or down under pressure (Fig. 12). Adjust the chain tension by spinning the chain tension adjuster (13, Fig. 1) on the rear wheel axle. After the adjustment, retighten the nuts on the both side of axle that were party released for the adjusting.




Fig. 12

Bolt and Nut Tightness

Periodically check and retighten as necessary the bolts and nuts of the main vehicle components (wheels, handlebar, shock absorber, rear fork axis, engine to frame bolts, gearbox oil drain plug).

MAINTENANCE SCHEDULE

Interval (km)	1.000	3.000	10.000, 15.000, 20.000
Interval (months)	2	6	12, 18, 24
Oil lubrication			
1. Gearbox oil change	•	•	•
2. Bowdens (internal cables)		As necessary	
3. Chain	•	•	•
Greasing			
4. Rear fork bearing bushes		As necessary	
5. Steering bearings			•
Cleaning			
6. Spark plug		As necessary	
7. Air filter (oiling)		•	•
8. Cylinder head, piston head,			exhaustduct

Interval (km)	1.000	3.000	10.000, 15.000, 20.000
Interval (months)	2	6	12, 18, 24
Checks and adjustments			
10. Gearbox oil level	•	•	•
11. Horn and lights	•	•	•
12. Spark plug electrode clearance	•	•	•
13. Brake operation check and adj.	•	•	•
14. Steering bearing clearance	•	•	•
15. Wheel bearing clearance	•	•	•
16. Wheel track	•	•	•
17. Tire pressure (front and rear 2,2 bar)	•	•	•
18. Chain tension	•	•	•

-
-
- 19. Idle run and throttle
 -
 -
- 9. Cylinder and exhaust pipe
- 20. Bolt and nut tightness
 -
 -
 -

TROUBLESHOOTING

Fuel System Troubles

Possible causes of the engine failing to start or stopping during a ride

Include, but are not limited to:

- Fuel is not supplied to the carburetor:
Check the fuel tank level and the position of the fuel cock.
- Clogged fuel strainers:
Blow the strainers clean.
- Clogged carburetor main jet:
Remove and blow clean.
- Improper use of the choke lever:
Use the lever in accordance with the engine start instructions.
- Low engine idle speed setting:
Using the adjustment bolt (A, Fig. 6), increase the engine speed

Ignition System Troubles

Check the spark. Possible causes of the ignition spark plug failing to produce a spark include:

- Wet spark or electrodes in a short circuit:
- Spark plug electrodes frequently in a short circuit:
Clean soot build-up from the cylinder head and piston head.
- Spark plug electrodes are worn out:
Adjust the electrode clearance according to the specifications, or
Replace the spark plug with a new one.

- Spark plug cap improperly mounted or short-circuiting to the Ground mass:
Properly mount the cap on the spark plug or replace with a new cap.
- Ignition coil:
Have the trouble examined and remedied by an authorized service agent.

Troubles Causing Reduced Engine Power

Possible causes of reduced engine power and reduced vehicle road performance include:

- Inadequate spark plug or cylinder head tightness:
Tighten the spark plug or the cylinder head nuts.
- Clogged air cleaner on the carburetor:
Wash in gasoline, blow dry and oil lightly.
- Clogged exhaust system: clean.

Gearbox Troubles

- Following the start, the engine runs at idle speed. If opening the throttle fails to engage the clutch:
Release the throttle and attempt to start the vehicle again (the oil is still cold and thicker). When riding, open the throttle gradually to prevent engine jerks. If the problem is frequent, have it repaired by an authorized service agent.
- The clutch slides (particularly in cold weather):
Improper oil type in the gearbox - change with the specified oil.
- The clutch takes excessively long to switch to the second gear or does not switch at all:
Reduced engine power - clean the exhaust silencer;
The clutch is stuck - try to activate the clutch at higher engine revs, with the vehicle propped up on a stand;
Excessive amount of oil in the gearbox - check the oil level.
- After engaging the second gear, the clutch jerks:
Chain is too loose - adjust the chain tension;
Low gearbox oil level - top up to the specified level.
- With the engine shut down, it is difficult to move the vehicle forwards-backwards:
Have the trouble examined by an authorized service agent.

TOMOS WARRANTY CONDITIONS

Tomos d. o. o., motoindustrija guarantees the buyer:

- That the product shall operate fault-free during the warranty period, provided that the user follows the enclosed technical instructions;
- That the product has the required characteristics in terms of quality, as is defined in the instructions;
- That it will settle any and all repair costs arising from a defect in the material or from an error in assembly;
- That it will replace the product with a new one if, during the warranty period, the authorized service workshop fails to address the problem in 45 days from the date of notification;
- That the warranty period shall be extended for the entire duration of the repair period;
- That it will provide service and spare parts for at least 4 years after the date of purchase.

The warranty period shall cover 12 months from the date of sale. This warranty shall not apply:

- In cases of defects caused by the owner, defects due to improper maintenance and
- The TOMOS warranty shall not apply if proven that the defects have been caused by:
- Improper motorcycle maintenance and disregarding the instructions provided in the TOMOS overhaul manual;
 - Fitting parts on the motorcycle, or modifications or adaptations prohibited by TOMOS;
 - Motorcycle repairs performed by a workshop not authorized by TOMOS;
 - Improper use of the motorcycle (for example: participation in races, overload, non-use of the motorcycle for extended periods of time);
 - In case the vehicle is damaged to the extent where its repairs or mending to a full working order would amount to more than 15 % of the factory sale price.
 - Normal wear of parts.

The warranty does not cover parts with normal wear, such as: Tires, wiring, spark plugs, graphics (stickers), fuel tank cap, lights, chains, brackets, brake pads, air and oil filters, saddles and exhaust pipes (internal inspection); the same applies for the motorcycle frame, piston holes, yellowing of chrome plating, damage due to improper adjustments, bad oil/fuel mixture or low oil level, which is also not covered by this warranty.

Vehicle parts with limited warranty period (6 months)

- battery;
- footrests;
- stands.

This contract warranty does not cover the following expenses: costs of normal repair works, oil, grease etc., emergency repair costs, motorcycle immobilization costs, and costs of removal and damages of carried goods.

Warranty rights

The buyer can exercise their warranty rights on the basis of a duly filled in warranty certificate, verified by an authorized dealer and a confirmed coupon of a pre-delivery service by an authorized service workshop.

WARNING: If it is found that a silencer or an air filter was used that is not an original part of the motorcycle, or if the original parts were modified in any way in order to increase the motorcycle noise level, the warranty is cancelled. In addition, the abovementioned adjustments that increase the noise level, power and speed of the motorcycle are under total responsibility of the owner.

NOTE: In case of damage occurring in any of the neighboring countries, please present the warranty claim to your dealer, together with the relevant invoices for any defective parts.

*Depends on market



TOMOS