

Operating manual

Process Display with Bargraph
Contacts and Analogue Output
U / I Input



CIT 350

Read the user's manual carefully before starting to use the unit.
Producer reserves the right to implement changes without prior notice.

Table of Contents

1. Basic requirements and user safety	4
4. Device installation	7
4.1. Unpacking	7
4.2. Assembly	7
4.3. Connection method	9
4.4. Maintenance	15
5. Front panel description	15
6. Principle of operation	16
6.1. Measurement mode	16
6.2. Detection of the peak values	17
6.3. Control of the relay outputs	18
6.3.1. One threshold mode	20
6.3.2. Two thresholds mode	21
7. Device programming	22
7.1. Programming menu	22
7.2. Parameters edition	23
7.2.1. Numeric parameters (digit change mode)	23
7.2.2. Numeric parameters (slide change mode)	23
7.2.3. Switch parameters ("LIST" type)	24
7.3. Menu description	24
7.3.1. "rEL1" menu	25
8. "bEEP" menu	27
8.0.1. "inPt" menu	27
8.0.2. "OutP menu	30
8.0.3. "bAr" menu	31
8.0.4. "bri" parameter	32
8.0.5. "HOLd" menu	32
8.0.6. "SECu" menu	33
8.0.7. "rS" menu	33
8.0.8. "Edit" parameter	35
8.0.9. "dEFS" parameter	35
8.0.10. "SErv" menu	35
8.1. Menu structure	36
9. The alarm LED	38
10. Over-current protection	38
11. Displayed values calculation	38
11.1. Additional calculations (used conversion characteristic)	38
11.1.1. Linear characteristic	39
11.1.2. Square characteristic	39
11.1.3. Square root characteristic	40
11.1.4. User defined characteristic	40
11.2. Examples of calculations	41
12. The Modbus protocol handling	44
12.1. List of registers	45
12.2. Transmission errors description	50
12.3. Examples of query / answer frames	50
12. Default and user's settings list	53
13. Disposal	56
14. Warranty conditions	56

Explanation of symbols used in the manual:



This symbol denotes especially important guidelines concerning the installation and operation of the device. Not complying with the guidelines denoted by this symbol may cause an accident, damage or equipment destruction.

IF THE DEVICE IS NOT USED ACCORDING TO THE MANUAL THE USER IS RESPONSIBLE FOR POSSIBLE DAMAGES.



This symbol denotes especially important characteristics of the unit. Read any information regarding this symbol carefully

1. Basic requirements and user safety



- The manufacturer is not responsible for any damages caused by inappropriate installation, not maintaining the proper technical condition and using the unit against its destination.
- Installation should be conducted by qualified personnel . During installation all available safety requirements should be considered. The fitter is responsible for executing the installation according to this manual, local safety and EMC regulations.
- The unit must be properly set-up, according to the application. Incorrect configuration can cause defective operation, which can lead to unit damage or an accident.
- If in the case of a defect of unit operation there is a risk of a serious threat to the safety of people or property additional, independent systems and solutions to prevent such a threat must be used.
- The unit uses dangerous voltage that can cause a lethal accident. The unit must be switched off and disconnected from the power supply prior to starting installation of troubleshooting (in the case of malfunction).
- Neighbouring and mating equipment must meet the requirements of appropriate standards and regulations concerning safety and be equipped with adequate anti-overvoltage and anti-interference filters.
- Do not attempt to disassemble, repair or modify the unit yourself. The unit has no user serviceable parts. Units, in which a defect was stated must be disconnected and submitted for repairs at an authorized service centre



- In order to minimize fire or electric shock hazard, the unit must be protected against atmospheric precipitation and excessive humidity.
- Do not use the unit in areas threatened with excessive shocks, vibrations, dust, humidity, corrosive gasses and oils.



- Do not use the unit in explosion hazard areas.
- Do not use the unit in areas with significant temperature variations, exposed to condensation or icing.
- Do not use the unit in areas exposed to direct sunlight.
- Make sure that the ambient temperature (e.g. inside the control box) does not exceed the recommended values. In such cases forced cooling of the unit must be considered (e.g. by using a ventilator).



The unit is designed for operation in an industrial environment and must not be used in a household environment or similar.

2. General characteristics

The **CIT 350** meter is equipped with one current input 0-20 / 4-20 mA and one voltage input 0-5 / 1-5 / 0-10 / 2-10 V. Current input has additionally overcurrent protection circuit, which protects standard resistor. The selection of active input is realised by software, and selected input can be changed at any time. Additionally the **CIT 350** allows user to select a conversion characteristic of several kinds: linear, square, square root, and user defined (max. 20 points length). The measured value is displayed simultaneously on 4-digit LED display and 20-points, colour bargraph. Set relay thresholds can be displayed on bargraph together with the measure. Displayed values range can be selected by user, from -999 to 9999, plus decimal point.

The device can be equipped with two or four relay (or OC type) outputs. Optionally **CIT 350** with two relays outputs can be equipped with active current output. Device **CIT 350** is equipped with RS-485 / Modbus RTU communication interface and sensor supply output. The meter can be ordered in two power supply versions.

CIT 350 can be used for controlling and regulation of processes need proportional and threshold control like: temperature processes (heating or cooling), valves controlling or other.

3. Technical data

Power supply voltage	standard: 85 ... 260 V _{AC/DC} optional: 19 ... 50 V _{DC} ; 16 ... 35 V _{AC}
External fuse (required)	T - type, max. 2 A
Power consumption	max. 4.5 VA or W
Current / voltage input	0/4 ... 20 mA, 0/1 ... 5 V, 0/2 ... 10 V
Current input resistance	< 65 Ω (typical 55 Ω)
Voltage input resistance	> 50 kΩ
Accuracy (25 °C)	± 0.1 % FSO
	tolerance band (0 ... 50 °C): max. 0.25 % FSO

CIT 350

Display range	- 999 ... 9999, plus decimal point
Accepted prolonged input overload	20 %
Outputs (optional)	2 or 4 SPST-relay
Communication interface	RS-485 (Modbus RTU)
Transmission speed	1200 ... 115200 bit/sec
Display	4-digit LED display, red, 4 x 9 mm, multicolour 20-segment bargraph
Data memory	non-volatile memory, EEPROM type
Ingress Protection	IP 65 (front foil)
Housing type	Panel
Housing material	NORYL - GFN2S E1
Housing dimensions	48 x 96 x 98 mm
Mounting hole	93 x 43 mm
Assembly depth	102 mm
Panel thickness	max. 5 mm
Operating temperature	0 ... 50°C
Storage temperature	-10 ... 70°C
Screws tightening	max. torque 0.5 Nm
Max. connection leads diameter	2.5 mm ²
Electrical safety requirements	EN 61010-1
EMC	EN 61326



This is a class A unit. In housing or a similar area it can cause radio frequency interference. In such cases the user can be requested to use appropriate preventive measures.

4. Device installation

The unit has been designed and manufactured in a way assuring a high level of user safety and resistance to interference occurring in a typical industrial environment. In order to take full advantage of these characteristics installation of the unit must be conducted correctly and according to the local regulations.



- Read the basic safety requirements on page 3 prior to starting the installation.
- Ensure that the power supply network voltage corresponds to the nominal voltage stated on the unit's identification label.
- The load must correspond to the requirements listed in the technical data.
- All installation works must be conducted with a disconnected power supply.
- Protecting the power supply clamps against unauthorized persons must be taken into consideration.

4.1. Unpacking

After removing the unit from the protective packaging, check for transportation damage. Any transportation damage must be immediately reported to the carrier. Also, write down the unit serial number on the housing and report the damage to the manufacturer.

Attached with the unit please find:

- user's manual
- assembly brackets - 2 pieces

4.2. Assembly



- The unit is designed for mounting indoor inside housings (control panel, switchboard) assuring appropriate protection against electric impulse waves. Metal housing must be connected to the grounding in a way complying with the governing regulations.
- Disconnect the power supply prior to starting assembly.
- Check the correctness of the performed connections prior to switching the unit on.

In order to assembly the unit, a 43 x 93 mm mounting hole (Figure 4.1) must be prepared. The thickness of the material of which the panel is made must not exceed 5 mm. When preparing the mounting hole take the grooves for catches located on both sides of the housing into consideration (Figure 4.1). Place the unit in the mounting hole inserting it from the front side of the panel, and then fix it using the brackets (Figure 4.2). The minimum distances between assembly holes' axes - due to the thermal and mechanical conditions of operation - are 115 x 67mm (Figure 4.3).




Fig. 4.1. Mounting hole dimensions




Fig. 4.2. Installing of brackets, and dimensions of connectors




Fig. 4.3. Minimum distances when assembly of a number of units

4.3. Connection method

Caution



- Installation should be conducted by qualified personnel. During installation all available safety requirements should be considered. The fitter is responsible for executing the installation according to this manual, local safety and EMC regulations.



- The unit is not equipped with an internal fuse or power supply circuit breaker. Because of this an external time-delay cut-out fuse with minimal possible nominal current value must be used (recommended bipolar, max. 2 A) and a power supply circuit-breaker located near the unit. In the case of using a monopolar fuse it must be mounted on the phase cable (L).
- The power supply network cable diameter must be selected in such a way that in the case of a short circuit of the cable from the side of the unit the cable shall be protected against destruction with an electrical installation fuse.
- Wiring must meet appropriate standards and local regulations and laws.
- In order to secure against accidental short circuit the connection cables must be terminated with appropriate insulated cable tips.
- Tighten the clamping screws. The recommended tightening torque is 0.5 Nm. Loose screws can cause fire or defective operation. Over tightening can lead to damaging the connections inside the units and breaking the thread.
- In the case of the unit being fitted with separable clamps they should be inserted into appropriate connectors in the unit, even if they are not used for any connections.

- **Unused clamps (marked as n.c.) must not be used for connecting any connecting cables (e.g. as bridges), because this can cause damage to the equipment or electric shock.**
- If the unit is equipped with housing, covers and sealing packing, protecting against water intrusion, pay special attention to their correct tightening or clamping. In the case of any doubt consider using additional preventive measures (covers, roofing, seals, etc.). Carelessly executed assembly can increase the risk of electric shock.
- After the installation is completed do not touch the unit's connections when it is switched on, because it carries the risk of electrical shock.

Due to possible significant interference in industrial installations appropriate measures assuring correct operation of the unit must be applied. To avoid the unit of improper indications keep recommendations listed below.

- Avoid common (parallel) leading of signal cables and transmission cables together with power supply cables and cables controlling induction loads (e.g. contactors). Such cables should cross at a right angle.
- Contactor coils and induction loads should be equipped with anti-interference protection systems, e.g. RC-type.
- Use of screened signal cables is recommended. Signal cable screens should be connected to the earthing only at one of the ends of the screened cable.
- In the case of magnetically induced interference the use of twisted couples of signal cables (so-called "spirals") is recommended. The spiral (best if shielded) must be used with RS-485 serial transmission connections.
- In the case of interference from the power supply side the use of appropriate anti-interference filters is recommended. Bear in mind that the connection between the filter and the unit should be as short as possible and the metal housing of the filter must be connected to the earthing with largest possible surface. The cables connected to the filter output must not run in parallel with cables with interference (e.g. circuits controlling relays or contactors).

Connections of power supply voltage and measurement signals are executed using the screw connections on the back of the unit's housing.




Fig. 4.4. Method of cable insulation replacing and cable terminals



All connections must be made while power supply is disconnected!




Fig. 4.5. Terminals description (relay outputs, no current output version)




Fig. 4.6. Terminals description (relay outputs, device with current output version)




Fig. 4.7. Terminals description (OC-type outputs)




Fig. 4.8. Connection of 2-wire current converters




Fig. 4.9. Connection of 3-wire current converters




Fig. 4.10. Connection of voltage converters




Fig. 4.11. Connection of power supply and relays



Contacts of relay outputs are not equipped with spark suppressors. While use the relay outputs for switching of inductive loads (coils, contactors, power relays, electromagnets, motors etc.) it is required to use additional suppression circuit (typically capacitor 47 nF/min. 250 V_{AC} in series with 100R/5 W resistor), connected in parallel to relay terminals or (better) directly on the load. In consequence of using the suppression circuit, the level of generated electromagnetic disturbances is lower, and the life of relay contacts rises.




Fig. 4.12. Examples of suppression circuit connection:
a) to relay terminals; b) to the inductive load





Fig. 4.13. Example of OC-type outputs connection



*Fig. 4.14. Example of current outputs connection
(for device with current output only)*

4.4. Maintenance


The unit does not have any internal replaceable or adjustable components available to the user. Pay attention to the ambient temperature in the room where the unit is operating. Excessively high temperatures cause faster ageing of the internal components and shorten the fault-free time of unit operation.

In cases where the unit gets dirty do not clean with solvents. For cleaning use warm water with small amount of detergent or in the case of more significant contamination ethyl or isopropyl alcohol.



Using any other agents can cause permanent damage to the housing.

5. Front panel description



Symbols and functions of push-buttons:

Symbol used in the manual: **[ESC/MENU]**

Functions:

- enter to main menu (press and hold by at least 2 sec.)
- exit the current level and enter to previous menu (or measure mode)
- cancel the changes made in parameter being edited



Symbol used in the manual: **[ENTER]**

Functions:

- start to edit the parameter
- enter to the sub-menu
- confirmation of changes made in parameter being edited



Symbol used in the manual: **[^] [v]**

Functions:

- change of the present menu
- modification of the parameter value
- change of the display mode

6. Principle of operation

After turning the power supply on, device ID and software version are showed on the display, next the controller goes to the measurement mode.

6.1. Measurement mode

In the measure mode, the measurement results, converted over selected characteristic, are displayed on the LED display. The measurement range equal to the nominal range is called: **nominal measurement range**, and the measurement range equal to the extended nominal range is called: **permissible measurement range** (Figure 6.1, 6.2).




Fig. 6.1. Definitions of measurements ranges in mode 4 ... 20 mA

If the result of measurement exceeds the **permissible measurement range**, warning **”-Hi-”** or **”-Lo-”** is displayed rather than input signal, depends on exceeded value (see description of **”Lo r”** i **”Hi r”** parameters, paragraph **”inPt” menu**).




Fig. 6.2. Definitions of measurements ranges in mode 0 ... 20 mA

- ☞ If the measurement value do not exceeds **permissible measurement range** but displayed value exceeds range -999 ... 9999, the warning "-Ov-" is displayed rather than the calculated result.

In the measurement mode user can check main thresholds values. After pressing [^] or [v] button, name of the threshold (e.g. "rEL1") and his value will be displayed on the display in alternating mode. If [^] or [v] will be pressed in 5 sec again, the next threshold will be displayed, else the device comes back to the measurement mode. If a **free access** is enabled (see description of "SECu" menu), user can change the value of particular threshold pressing button [ENTER] (see: **PARAMETERS EDITION**).

Input type, range of displaying values, characteristic of conversion, decimal point position and measure filtering ratio, are user configurable parameters. All accessible parameters can be changed by entering the menu (see: **DEVICE PROGRAMMING**). Use the local keyboard or the remote controller to do it. (Note: all parameters can be remote changed via RS-485 interface).

- ☞ Configuration of the device (via menu or RS 485 interface) **do not stops measures.**

6.2. Detection of the peak values

The **CIT 350** controller is equipped with peaks detection function. It can detect a peaks of the input signal and display their values. Presets connected with this function are placed in "HOLD" menu (see description of "HOLD" menu). The detection of the peak can be done if the measured signal raises and drops of value at least equal to parameter "PEA". Detected peaks are displayed during the time defined by parameter "timE". If a new peak will be detected while one is displayed, this new peak will be displayed and display time counter will be cleared (Figure 6.3). If no peaks are detected while time "timE" elapses, device starts to show the current value of input signal again.

The relays/LEDs and the current output can be controlled depend on the current value of input signal or the peak value (see "HOLD" menu).





Fig. 6.3. Process of peaks detection

6.3. Control of the relay outputs

The control of the object (measured signal) is realized via relay outputs. Front panel LEDs named „R” indicates the state of particular relay output.

 If device is not equipped with one or more relay outputs, menus refer to this relays are available, but apply to LED indicators only. In such case LEDs indicates exceeding of particular thresholds.

Modes of the control can be changed depend on the values of parameters “SEtP”, “SEt2”, “HYSt”, “modE”, “t on”, “toFF”, “unit” and “AL”. Depend on “modE” parameter, relays can be not used or controlled over one or two thresholds values. If one threshold is used (Figure 6.4) the relay can be turned on (“modE” = “on”) or off (“modE” = “oFF”) when the input signal value is contained in **zone A**. If two thresholds are used (Figure 6.5) the relay will be turned on when value of input signal is contained in **zone A** (“modE” = “in”) or **zone B** (“modE” = “out”) and turned off if the signal is contained in the second one.




Fig. 6.4. One threshold control of the relay/LED outputs





Fig. 6.5. Two threshold control of the relay/LED outputs



The relay outputs and LEDs (named **R**) can be controlled depend on both - the current value and the peak value (when peak detection is active) of the input signal.

6.3.1. One threshold mode

Figure 6.6 presents the principle of relay outputs operation for one threshold mode, and an example values of other parameters.



Description:

- A, B, C, D** - points where measured signal exceeds border values (expected value \pm allowed deviation)
B_{ON}, B_{OFF}, D_{ON}, D_{OFF} - relays state changes moments: (for "t on" > 0, "toFF" > 0)
t_A, t_B, t_C, t_D - time periods while input signal is in zone A or zone B

Fig. 6.6. Principle of LED/relay output operation for one threshold mode


Parameter "**SEtP**" sets a **threshold** of the relay, and parameter "**HYSt**" sets a **hysteresis** of the relay (Figure 6.6 a). The relay can change his state only when input value exceeds (over or under) **border value** and t_A, t_B, t_C, t_D times (Figure 6.6) are bigger than the time defined by parameters "**t on**", "**toFF**" and "**unit**". **Border values** means values equal **threshold+hysteresis** and **threshold-hysteresis** respectively.

If "**t on**" and "**toFF**" parameters are set to "0", then the relay state will be changed as soon as input value exceeds any of the **border values** (see points A and C, Figure 6.6 a, b, c). If values of "**t on**" or/and "**toFF**" are positive, then relay state will be turned on if the input value exceeds the **border values** and stay bigger (or lower) during at least "**t on**" (see points B_{ON}, D_{ON}, Figure 6.6 a, d, e). Similarly, the relay will be turned off if time "**toFF**" elapse since the input signal value exceeds any of the **border values** (see points B_{OFF}, D_{OFF}, Figure 6.6 a, d, e).

If t_A , t_B , t_C or t_D (when input signal stay in **zone A** or **zone B**) are lower than parameters “**t on**” or “**toFF**”, the relay will not change his state (see points A and C, Figure 6.6 a, d, e). The state of relay output while the input value exceeds the **border values** (points A, B, C, D) is described by parameter “**mode**”. The relay can be turned on (“**mode**” = “**on**”), or turned off (“**mode**” = “**off**”) when input signal value is contained in **zone A** (Figure 6.6 a). The parameter “**AL**” allow user to set the relay output behaviour in critical situations (e. g. Input values exceeds **permissible measurement range**). User can select that the relays will be turned on, turned off, or not changed in critical situations.

All parameters connected with relay outputs are described in paragraph “**rEL1**” menu.

6.3.2. Two thresholds mode



Description:

A, B, C, D, E

- points where measured signal exceeds border values
(expected value \pm allowed deviation)

B_{ON}, B_{OFF}, C_{ON}, C_{OFF}, E_{ON}, E_{OFF}

- relays state changes moments: (for “**t on**” > 0, “**toFF**” > 0)


t_A, t_B, t_C, t_D, t_E

- time periods while input signal is in zone A or zone B

Fig. 6.7. Principle of LED/relay output operation for two thresholds mode

Figure 6.7 presents the principle of relay outputs operation for two thresholds mode, and an example values of other parameters. In this mode parameter “SEt2” is accessible in common with “SEtP”, this parameter describes a second threshold of the relay output. The parameters “HYSt”, “modE”, “t on”, “toFF”, “unit” and “AL” are connected with both “SEtP” and “SEt2” thresholds. While the controlling process, the relay output changes his state depends of both “SEtP” and “SEt2” thresholds in similar way as it was described in one threshold mode.


If two threshold mode is used, “modE” parameter defines state of the relay output when the input value occurs in a particular zone defined by **border values** of both **thresholds**. The relay can be turned on if the input value is contained in **zone A** (“modE” = “in”) or **zone B** (“modE” = “out”) and turned off if it is contained in the second one (Figure 6.7).

 The sequence of thresholds “SEtP” and “SEt2” can be set in any order, due to the control of relay outputs is done depend on difference between thresholds values (**zone A**) and outside of threshold values (**zone B**).

7. Device programming

The device menu allow user to set all parameters connected to operation of measurement input, control modes, critical situations behaviour, communication via RS-485 and access settings. The meaning of the particular parameters is described in paragraph **MENU DESCRIPTION**.

Some of the parameters can be accessed without menu entering (quick view mode). After pressing [^] or [v] button, name of the threshold (e.g. “rEL1”) and his value will be displayed on the display in alternating mode. If [^] or [v] will be pressed in 5 sec again, the next threshold will be displayed, else the device comes back to the measurement mode. If a **free access** is enabled (see description of “SECu” menu), user can change the value of particular threshold pressing button [ENTER] (see: **PARAMETERS EDITION**).

 If particular parameter has been changed and confirmed in quick view mode, its new value is displayed in alternating mode with parameter name by few seconds. Confirmed changes may be checked or user can switch viewed parameter pressing [^] or [v] button.

7.1. Programming menu

To enter main menu (being in the measurement mode) operator must to press and hold at least 2 sec. [ESC/MENU] button.

If the user password is defined (see parameter “Scod“, menu “SECu”), operator have to enter correct one before proceeding to menu options . Entering of the passwords is similar to the edition of numeric parameters (see: **PARAMETERS EDITION**), however presently editing digit is showed only on the display, other digits are replaced by “-” sign.

After entering of last digit of the password first menu position will be displayed (if the password is correct) or warning “Err” in other case.



Pay attention when device parameters are being changed. If it is possible, turn off controlled installation (machine).

Functions of the buttons while sub-menu and parameter choice:

Selection of sub-menu or parameter for editing. Name of selected item (sub-menu or parameter) is displayed.



Operation of **[ENTER]** button depend on present menu position:

- if the name of some sub-menu is displayed - enter this sub-menu; name of the first parameter (or next level sub-menu) is displayed
- if the name of some parameter is displayed - enter the edition of this parameter; present value of the parameter is displayed



[ESC/MENU] button allow user to exit present menu level and goes to upper level menu (or measurement mode).



After about 1 min. since last use of the buttons, device exits the menu mode and returns to the measurement mode (only if no parameters are in editing mode).

7.2. Parameters edition

To start edition of any parameter user should select name of desired one using **[^]** **[v]** buttons and then press **[ENTER]**.

7.2.1. Numeric parameters (digit change mode)

Numerical parameters are displayed as decimal numbers. The mode of its new value entering depends on chosen edit method (see parameter „**Edit**“).

In mode “by digit” („**Edit**”=“**dig**”) pressing one of the keys **[^]** or **[v]** causes change of current position (flashing digit) or the sign (+/-). Short pressing of the **[ENTER]** button causes change of the position (digit).

Press **[ENTER]** at least 2 seconds to accept the changes, after that question “**SEt?**” is displayed, and user must to confirm (or cancel) the changes. To conform changes (and store it in EEPROM) press **[ENTER]** button shortly after “**SEt?**” is displayed. To cancel the changes press **[ESC]** button shortly after “**SEt?**” is displayed. After that device returns to the menu.

7.2.2. Numeric parameters (slide change mode)

In “slide change” mode („**Edit**”=“**Slid**”), buttons **[^]** and **[v]** has different functions.

To increase edited value press (or press and hold) **[^]** button only, the increasing became quickest as long as button **[^]** is pressed. To slow down the increasing, button **[v]** can be used. If **[v]** is pressed shortly (and button **[^]** is still pressed), increasing slow down for a moment only, if **[v]** is pressed and held while button **[^]** is still pressed the increasing slow down and will be kept on lower speed.

To decrease edited value press (or press and hold) **[v]** button only. The decreasing became quickest as long as button **[v]** is pressed. To slow down the decreasing, button **[^]** can be used. If **[^]** is pressed shortly (and button **[v]** is still pressed), decreasing slow down for a moment only, if **[^]** is pressed and held while button **[v]** is still pressed the decreasing slow down and will be kept on lower speed.

Press **[ENTER]** at least 2 seconds to accept the changes, after that question **"Set?"** is displayed, and user must to confirm (or cancel) the changes. To conform changes (and store it in EEPROM) press **[ENTER]** button shortly after **"Set?"** is displayed. To cancel the changes press **[ESC]** button shortly after **"Set?"** is displayed. After that device returns to the menu.

7.2.3. Switch parameters ("LIST" type)

Switch parameters can be described as a sets of values (a lists) out of which only one of the options available on the list can be selected for the given parameter. Options of switching parameter are selected using **[^]**, **[v]** keys.

Short pressing of **[ENTER]** causes in displaying of the acknowledge question (**"Set?"**). If key **[ENTER]** is pressed again, the changes are accepted, stored in EEPROM end the edition process finished. Pressing the key **[ESC]** after **"Set?"** causes in cancelling of made changes and returning to menu.

Functions of buttons when editing numeric and switching parameters:



While editing numeric parameter:

- change of current (flashing) digit
- slide change of value (acceleration, deceleration, direction change)

While editing switch parameter - selection of switch parameter.



If numerical parameter is being edited, a short press of **[ENTER]** button change edited position. A long press of **[ENTER]** button (at least 2 sec.) causes of display a **"Set?"** ask, which allow user to make sure if change of the parameter value is correct. If switch parameter is being edited, a short press of **[ENTER]** button causes of display a **"Set?"** ask. When **[ENTER]** button is pressed again (while **"Set?"** is displayed) the new value of the parameter is stored in EEPROM memory.



Pressing this button operator can cancel the changes done up to now (if they were not approved by **[ENTER]** button after the **"Set?"** ask) and come back to menu.

7.3. Menu description

"- - -"


- password checking. If some password different from „0000” is set, then every enter to main menu follows the entering of password. If entered password is correct then first menu position will be displayed else warning **"Err"**, and unit returns to measurement mode.



Due to problem with direct displaying of **"m"** and **"K"** letters, they are exchanged with special signs **"m̄"** for **"m"** and **"K̄"** for **"K"** respectively. However, in user manual letters **"m"** and **"K"** are used to make it more readable (example: **"modE"**, **"tc K"**).

7.3.1. "rEL1" menu


This menu allows to configure the operation mode of relays and LEDs marked „R” (e.g. „R1”). If there are few relay outputs available, then every output has its own configuration menu (e.g. menu „rEL2” for relay (LED) „R2”). Principle of the relays operation is described in paragraph **CONTROL OF THE RELAY OUTPUTS**.

-  • The relay outputs and LEDs (named **R**) can be controlled depend on both - the current value and the peak value (when peak detection is active) of the input signal.
- If device is not equipped with one or more relay outputs, menus refer to this relays are available, but apply to LED indicators only. In such case LEDs indicates exceeding of particular thresholds.

“SEtP” - first threshold of the relay (range -999 ... 9999). Negative values can be input by selecting a “-” sign on first digit (to change value use [**^**] and [**v**] buttons). **Threshold is the medium value of relay hysteresis.**

“SEt2” - second threshold of the relay (range -999 ... 9999). Negative values can be input by selecting a “-” sign on first digit (to change value use [**^**] and [**v**] buttons). This threshold is accessible when “**modE**” parameter is set to „in” or „out” value. **Threshold is the medium value of relay hysteresis.**

“HYSt” - hysteresis of relay (range 0 ... 999). Full hysteresis of the relay is equal to 2x “**HYSt**” parameter. The relay state can change when an input signal is out of **threshold-hysteresis** to **threshold+hysteresis** zone.


-  Presented parameters should be set to ensure that “**SEtP**” + “**HYSt**”, “**SEt2**” + “**HYSt**”, “**SEtP**” - “**HYSt**” or “**SEt2**” - “**HYSt**” do not exceeds the measure range. Additionally, in two threshold mode (“**modE**”= „in” or „out”), the hysteresis for both thresholds must not cover each other (in other case relay cannot change his state).

“modE” - relay operation mode:

- “noAC”** - the relay is not active (permanent turned off)
- “on”** - one threshold mode, the relay is turned **ON** when input signal exceeds **SEtP + HYSt** value, and is turned off back when the input signal became lower than **SEtP – HYSt**
- “oFF”** - one threshold mode, the relay is turned **OFF** when input signal exceeds **SEtP + HYSt** value, and is turned on back when the input signal became lower than **SEtP – HYSt**
- “in”** - two threshold mode, the relay is turned **ON** when the input signal is bigger than “**lower threshold + HYSt**” and lower than “**bigger threshold – HYSt**”, and turned off when the input signal is contained in the second zone. The **bigger threshold** means bigger one of “**SEtP**” and “**SEt2**” thresholds, the **lower threshold** means lower one of “**SEtP**” and “**SEt2**” thresholds.


“out” - two threshold mode, relay is turned **ON** when the input value is bigger than “**bigger threshold + HYSt**” and lower than “**lower threshold – HYSt**”, and turned on when the input signal is contained in the second zone. The **bigger threshold** means bigger one of “**SEtP**” and “**SEt2**” thresholds, the **lower threshold** means lower one of “**SEtP**” and “**SEt2**” thresholds.

“modb” - the relay is controlled via RS-485 interface, independently on the input signal.

-  • **LEDs light when relays are closed**, independently of relays' mode.
- When power supply fail, unit do not store relays state selected by RS-485 interface.

“t on” - turn on delay time, the relay is turned on with delay equal “**t on**” if the input value exceeds appropriate **border value** (defined with **threshold** and **hysteresis**), at least “**t on**” time. “**t on**” range 0 ... 99.9, defined with 0.1 sec. resolution. Unit of this parameter is set by “**unit**” parameter.

“toFF” - turn off delay time, the relay is turned off with delay equal “**toFF**” if the input value exceeds appropriate **border value** (defined with **threshold** and **hysteresis**), at least “**toFF**” time. “**toFF**” range 0 ... 99.9, defined with 0.1 sec. resolution. Unit of this parameter is set by “**unit**” parameter.

-  If time when the input signal exceeds some border value is shorter than “**t on**” or “**toFF**” time, the relay do not change his state (see paragraph: **CONTROL OF THE RELAY OUTPUTS**).

“unit” - unit of time for “**t on**” i “**toFF**” parameters. Can be set on one of two values:


“min” - minutes
“SEC” - seconds

“AL” - this parameter defines the relay reaction when some critical situations occurs:

“noCH” - relay do not change his state
“on” - relay will be turned on
“oFF” - relay will be turned off

If parameter “**modE**” is set to “**on**”, “**oFF**”, “**in**” or “**Out**” the “critical situation” means that allowable measurement range is exceeded.

If parameter “**modE**” is set to “**modb**”, the “critical situation” means communication delay (when no data is received) longer than “**mbtO**” parameter (see description: “**rS**” menu).


-  • If option “**noCH**” is selected for “**AL**” parameter, behaviour of the relay may depend on “**FiLt**” parameter in some cases. If “**FiLt**” is set to big value and the input signal drops, result value of the measure will change slow, causes of turning on or off relay due to thresholds values. The critical situation is slowly detected, so it is impossible to predict the relay state in that situations.

- If parameter „**AL**” = „**on**”, the relay will be turned on in the critical situations, even if his parameter „**modE**” = „**noAC**”.

8. "bEEP" menu

This menu contains options connected with acoustic signal :


- "**AL**" - if this parameter is set to "**on**", any critical situation causes by acoustic signal
 "**r1**" - if this parameter is set to "**on**", activation of relay **R1** causes by acoustic signal
 "**r2**" - if this parameter is set to "**on**", activation of relay **R2** causes by acoustic signal
 "**r3**" - if this parameter is set to "**on**", activation of relay **R3** causes by acoustic signal
 "**r4**" - if this parameter is set to "**on**", activation of relay **R4** causes by acoustic signal

 Acoustic signal (turned on by e.g. relay) can be turned off by pressing of any button.

8.0.1. "inPt" menu

This menu presents the measurement input:

- "**tYPE**" - type of the input / sensor. This parameter can be set to values:
 "0 ... 20", "4 ... 20" - current inputs.
 "0 ... 10", "2 ... 10", "0 ... 5", "1 ... 5" - voltage inputs.
 Displayed values are defined by parameters "**Lo C**", "**Hi C**" (or by user defined characteristic points) and parameter "**Pnt**".
- "**CHAR**" - this option presents type of the conversion characteristic, and can be set to:
- | | | |
|-----------------|---------------|--|
| " Lin " | - linear | } When one of those characteristics is chosen display range is defined by " Lo C " and " Hi C ". |
| " Sqr " | - square | |
| " Sqrt " | - square root | |
- "**USER**" - user defined characteristic. Maximal length 20 points. Every point is defined by user. Adding, editing and deleting of points is done by options „**AddP**”, „**EdtP**”, „**dELP**” („**InPt**” menu) respectively.


 If user defined characteristic is selected, and if number of defined points is lower than 2 then warning "**Errc**" is displayed in measurement mode.

The process of displayed result calculation is described in details in **DISPLAY VALUES CALCULATION** paragraph.


- "**FiLt**" - this parameter sets filtration rate. It can be set to values from 0 (no filtration) to 5 (strongest filtration – time window about 2 sec).
- "**Pnt**" - decimal point position. It can be set to one of:
 "0", "0.0", "0.00", "0.000"

Decimal point position is changed by [^], [v] buttons.

"Lo C" These parameters describe the values displayed for minimum and maximum input current. For example, if input type is set to 4-20 mA **"Lo C"** parameter defines the value displayed when input current is equal 4 mA, and **"Hi C"** parameter defines the value displayed for 20 mA of input current. Available range for these parameters: -999 ... 9999. Negative values can be set by entering '-' sign on the first position (by use of [^], [v] buttons).


 Current output can be controlled depend on both present measured value and peak value (if peak detection is enabled).

"AddP" - this menu allow user to add single point to the user defined characteristic. After selection of this option device waits for „X” and „Y” coordinates of new point. Modification of the coordinates is done accordingly to numerical parameters edition. Coordinate „X” defines the percentage ratio of input current to selected current range. The „X” range: -99.9 ... 199.9. Coordinate „Y” defines displayed value for particular „X” value. The „Y” value can be changed in range: -999 ... 9999, decimal point position depend on „Pnt” parameter (menu **"inPt "**).

-  • User cannot enter two points with the same value of „X” coordinate. If user trays to do it, **"Err"** warning is displayed. To modify any defined point use **"EdtP"** option.
- To distinguish „X” and „Y” coordinates, if „X” coordinate is displayed an additional decimal point on utmost right position is displayed.
 - If user defined characteristic is selected, and if number of defined points is lower than 2 then warning **"Errc"** is displayed in measurement mode.

"dELP" - this option allows user to delete any of the points of the user defined characteristic. After selection current number of points of the user defined characteristic is displayed for about approx. 1.5 sec. After that device waits for selection of point being deleted (by [^], [v] buttons). The short pressing of [ENTER] button causes by switching between X and Y value of the displayed point. The long press (press and hold at least 2 sec) of [ENTER] button causes by displaying „dEL?” ask. If [ENTER] button is pressed again, current point is deleted and new updated number of points of the user defined characteristic is displayed.

"EdtP" - this option allows user to modify of particular point of the user defined characteristic. After selection current number of points of the user defined characteristic is displayed for about approx. 1.5 sec. After that device waits for selection of point being edited (by [^], [v] buttons). The short pressing of [ENTER] button causes by switching between X and Y value of the displayed point. The long press (press and hold at least 2 sec) of [ENTER] button causes by entering to edit the selected coordinate of the point. Modification of the coordinates is done accordingly to numerical parameters edition.

 **"AddP"**, **"dELP"** and **"EdtP"** options are available only if the user defined characteristic is used (it means when parameter **"CHAR"** = **"USER"**).

"Lo r" these parameters define the expansion of nominal range in percent. They determine the permissible range of input signal (Figure 8.1).
"Hi r" The permissible range allow user to exceed the **nominal range** of input signal. If input value is contained in the permissible range a proper result is displayed. If input signal exceeds this range (defined by **"Lo r"** and **"Hi r"**), **"-Lo-"** or **"- Hi-"** warning is displayed depend on input signal value.




Fig. 8.1. Example of definition of permissible range of input signal - **"Lo r"** and **"Hi r"** parameters (**"4-20"** mode)

The **"Lo r"** parameter is important if input is set to **"4-20"**, **"1-5"** or **"2-10"** mode only, and determines lower border of the permissible range. If input is set to **"0-20"**, **"0-5"** or **"0-10"** mode then lower border of the permissible range is always 0.

For example if input is set to **"4-20"** mode, then lower border is calculated due to expression:
 $I_{\min} = 4 \text{ mA} - 4 \text{ mA} \times \text{"Lo r"} \%$


The **"Lo r"** value can be set from 0 to 99.9 %.

Parameter **"Hi r"** determines the upper border of the permissible range accordingly to the expression (for all modes).

For example if input is set to **"4-20"** mode, then upper border is calculated due to expression:
 $I_{\max} = 20 \text{ mA} + 20 \text{ mA} \times \text{"Hi r"} \%$


The value of **"Hi r"** can be set from 0 to 19.9 %.

In example no 1 of the **DISPLAY VALUES CALCULATION** paragraph the procedure of the permissible input range determining is presented in details.

 If the measurement value do not exceeds **permissible measurement range** but displayed value exceeds range -999 ... 9999, the warning **"-Ov-"** is displayed rather than the calculated result.

8.0.2. "OutP menu

This menu contains parameters of current output control. Menu is available if the device is equipped with current output.

 Current output can be controlled depend on both present measured value and peak value (if peak detection is enabled).

"Omod" - current output mode, can be set to values:

- "oFF"** - current output disabled,
- "0-20"** - current output enabled with 0 ... 20 mA mode,
- "4-20"** - current output enabled with 4 ... 20 mA mode,
- "modb"** - current output controlled via RS-485 interface.

"OutL" - this parameter determines the input value for which the output current is minimal (0 mA or 4 mA depend of current output mode **"Omod"**).


"OutH" - this parameter determines the input value for which the output current is equal 20 mA.

The output current value is calculated due to formulas given below:

$$I_{out} = \frac{W - "OUtL"}{"OUtH" - "OUtL"} \times 16 mA + 4 mA \quad \text{for output range 4 ... 20 mA}$$

$$I_{out} = \frac{W - "OUtL"}{"OUtH" - "OUtL"} \times 20 mA \quad \text{for output range 0 ... 20 mA}$$

where **"W"** denotes the displayed value.

 **"OutL"** parameter can be greater than **"OutH"**. In this case the conversion characteristic is reversed, it means that if input value raises the output current falls.

"Lo r", "Hi r" - this parameters define the output current range (maximum range 0 ... 24 mA). If calculated output value I_{out} exceeds defined range then current output generates the current equal to upper or lower border of the defined range. The parameters define the percentage extension of nominal current range 4 ... 20 mA (with 0.1 % resolution).

Parameter **"Lo r"** defines lower border of the range due to formula:

$$I_{min} = 4 mA - 4 mA \times "Lo r" \%$$

This parameter can be set from 0 to 99.9 %.

Parameter **"Hi r"** defines upper border of the range due to formula:

$$I_{max} = 20 mA + 20 mA \times "Hi r" \%$$

This parameter can be set from 0 to 19.9%.

In example on page 42 of the **DISPLAY VALUES CALCULATION** paragraph the procedure of the current outputs determining is presented in details.

“AL” - this parameter determines the behaviour of current output if any critical situation occurs. The parameter can be set to one of the values:

- “noCH”** - current will not change,
- “22.1”** - current will be set to 22.1 mA,
- “3.4”** - current will be set to 3.4 mA,
- “0.0”** - current will be set to 0 mA.

When the critical situation goes, the current will be set to value calculated due to formulas given above.

8.0.3. "bAr" menu

This menu allows to configure the bargraph.

“tYPE” - display mode of the bargraph, can be set to one of the values.:

- “LinE”** - the line of lighting LEDs (from position 0 % to value depend on the measurement result – in percent of full scale range)
- “Pnt”** - the lighting point, single led indicates the percentage value of full scale range, depend on measured value. Due to resolution of bargraph (5 % of full scale), only led closest to calculated value lights.

“FCoL” - this parameter defines colours of the bargraph. Combination of red, green, orange, and black (dimmed segment) are used. Table 8.2 shows possible combinations.

Value of „FCoL”	Bargraph colours		
	measurement	background	thresholds' markers
„bLAc”	The bargraph off		
„grEE”	green	black	red
„rEd”	red	black	green
„g r”	green	red	orange
„r g”	red	green	orange
„b g”	black	green	red
„b r”	black	red	green


Fig. 8.2. Possible combinations of the bargraph colours

“Pr1P”... these parameters allows to define which one of the thresholds of the
“Pr4P” relay will be showed on the bargraph.

- "oFF" - no one thresholds will be marked
- "1St" - threshold refer to „SEtP”, will be marked only
- "2nd" - threshold refer to „SEt2”, will be marked only
- "botH" - both thresholds will be marked

"P1AL"... these parameters allows to define **the critical situation of the bargraph**
 "P4AL" depend on state of particular relays.


- "noC" - particular relay do not causes by critical situation on the bargraph
- "more" - critical situation will occur when measurement value will be greater than threshold value „SEtP” of this relay
- "LESS" - critical situation will occur when measurement value will be lower than threshold value „SEtP” of this relay
- "on" - critical situation will occur when particular relay will be closed
- "oFF" - critical situation will occur when particular relay will be opened

 **The critical situation of the bargraph** will occur in case when any of defined situation occur. **The critical situation of the bargraph** is signalized by inverting of colours (red to green, and green to red)

"Lo C", "Hi C" - these parameters define measurement range of the bargraph. The percentage value showed by the bargraph is calculated due to measured value (and showed on digital display). "Lo C" parameter defines the value appropriate to 0 % on the bargraph. "Hi C" parameter defines the value appropriate to 100 % on the bargraph. Measurements between "Lo C" and "Hi C" are recalculated due to formula:

$$P = \frac{W - "Lo C"}{"Hi C" - "Lo C"} \times 100 \%$$

where: „P” denotes percentage value showed by the bargraph,
 „W” - denotes value showed on digital display (the measurement value)

 Value of "Lo C" can be greater than value if "Hi C". In this case the conversion characteristic of the bargraph is upturned (it means that when measurement value raises then the bargraph value falls, and when measurement value falls the bargraph value raises).

8.0.4. "bri" parameter

This parameter allows user to set bright of the LED display, bright can be set to conventional values from 1 to 8.

8.0.5. "HOLd" menu

This menu contains parameters connected with peak detection function. See also full description of the peak detection function in paragraph:

DETECTION OF THE PEAK VALUES

"modE" - the type of detected changes of the input signal, can be set to values:

"norm" - peaks, peak and next drop of the input signal of value equal at least
"PEA"
"inv" - drops, drop and next peak of the input signal of value equal at least
"PEA"

"PEA" - minimal detected signal change classified as peak or drop (see Figure 6.3)

"timE" - maximum time of displaying of the peak (drop) value, can be set from 0.1 to 19.9 sec, with 0.1 sec. resolution

"HdiS" - type of displayed values:

"rEAL" - current value is displayed

"HOLd" - peak (drop) value is displayed

"H r1" - "H r4" - relay/LED outputs (R1-R4) operation mode:

"rEAL" - relay/LED operates depend on the current value

"HOLd" - relay/LED operates depend on the peak (drop) value.

"HOUt" - current output operation mode:

"rEAL" - current output operates depend on the current value


"HOLd" - current output operates depend on the peak (drop) value.

8.0.6. "SECu" menu

This menu contains presets connected with availability of other parameters:

"Scod" - user password (4-digits number). If this parameter is set at value **"0000"**, user password is turned off.

If the user do not remember his password, the access to the menu is possible by the "one-use password". To get this password please contact with Marketing Division. "Single use password" can be used only one time, after that it is destroyed. Entering this password causes in clearing of user password, it means sets the user password to „0000".

 The "one-use password" can be used **ONE TIME ONLY**, it is impossible to use it again! The "one-use password" can be restored by Service Division only.

"A r1 - A r4" - this option permits user (**"on"**) or prohibits (**"oFF"**) to modify the thresholds of the relays/LEDs R1 - R4 without knowledge about user password.

8.0.7. "rS" menu

This menu is connected with RS-485 interface, and sets his properties:

"Addr" - this parameter defines the address of the device, accordingly to Modbus protocol. It can be set in range from 0 to 199. If the value 0 is set then device, responds to frames with address 255 (FFh).


"bAud" - this parameter determines RS-485 interface baud rate. It can be set to one of 8 possible values: **"1.2"**, **"2.4"**, **"4.8"**, **"9.6"**, **"19.2"**, **"38.4"**, **"57.6"**, **"115.2"**, which respond to the baud rates of 1200, 2400, 4800, 9600, 19200, 38400, 57600 and 115200 bit/sec respectively.

"mbAc" - this parameter sets the access to the configuration registers of the device.

Possible values:

"on" - configuration registers can be set via RS-485 interface,

"oFF" - configuration registers can not be set via RS-485 interface.

 The access to registers no 04 h i 05 h cannot be denied by **"mbAc"** parameter (see: **LIST OF REGISTERS**).

"mbtO" - this parameter defines maximal time (sec) between following frames received by the device. If the delay will be greater than the value of **"mbtO"** parameter, the relays and the current output which are controlled via RS-485 interface, will set to alert state (see **"OUTP" menu**, **"rEL1" menu** description). Parameter **"mbtO"** can be set to values from 0 to 99 seconds. The value 0 means that the time will be not controlled.

"rESP" - this parameter defines minimal (additional) delay between the Modbus message and the answer of the device (received and sent via RS-485 interface). This additional delay allows the device to work with poor RS-converters which do not works properly on baud rates higher than 19200. This parameter can be set to one of values:

"Std" - answer as quick as possible, no additional delay

"10c"


"20c"

"50c"

"100c"

"200c"

- answer delayed of 10, 20, 50, 100 of 200 chars respectively, where one character time depends on selected baud rate

 In the most cases parameter **"rESP"** should be set to **"Std"** (no additional delay). Unfortunately for some third party RS-converters **"rESP"** should be adjusted experimentally. Table 8.3 contains most frequently used values.

"bAud" parameter	"38.4"	"57.6"	"115.2"
"rESP" parameter	" 10c"	" 20c"	" 50c"

*Fig. 8.3. Settings of **"rESP"** parameter*

8.0.8. "Edit" parameter

This parameter allows to change the edition mode of numerical parameters:

- "dig"** - the change to "by digit" mode,
- "Slid"** - slide change mode.


8.0.9. "dEFS" parameter

This setting allows to restore the factory settings of the device. To get the access to this option special password is required: „5465“, next the device displays acknowledge question „**SEt?**“. Press **[ENTER]** to acknowledge the restoring of factory settings or **[ESC]** to cancel.

8.0.10. "SErv" menu

This menu contains the parameters for authorized service only. To enter this menu proper service password must be entered. Improper settings can causes of damage of the device.

8.1. Menu structure





9. The alarm LED

Alarm LED (**AL**) lights in cases:

- exceeding of **permissible measurement range**
- detection of sensor malfunction (shortcut or break of measurement circuit)

10. Over-current protection

The current input of the device is equipped with over-current protection circuit. This circuit protects the standard resistor to damage. Maximum input current is set to 40 mA (typical). When temperature of the standard resistor falls, the protection circuit will turn off himself automatically, and the device will measure the input current again. Due to thermal phenomenon in the standard resistor, precision of the measurement may be lower, during few minutes (up to the standard resistor temperature will falls to the environment temperature).

11. Displayed values calculation


For simplicity of examples it is assumed that current input is selected, and all calculations are related to this input. When voltage input is selected calculations are similar (be sure of particular ranges and units).

The first step to compute the result of measure is the calculation of the normalized result (it means result of 0-1 range). To do it, the begin of the input range (0 mA for 0-20 mA range, and 4 mA for 4-20 mA range) must be subtracted from measured value. Next, received result must be divided by the width of the input range (it means 20 mA for 0-20 mA range, and 16 mA for 4-20 mA range). So normalized result can be expressed by expressions:

$$I_n = \frac{I_{inp.} - 4}{16} \quad \text{for } 4 \div 20 \text{ mA range}$$

$$I_n = \frac{I_{inp.}}{20} \quad \text{for } 0 \div 20 \text{ mA range}$$

where $I_{inp.}$ means input current (in mA), and I_n – normalized result.

 If measured value exceeds the nominal input range (0-20 mA or 4-20 mA), and do not exceed the permissible input range, then received normalized I_n result will exceed 0-1 range, e.g. input range 4-20 mA, input current = 3 mA – the normalized result is equal -0.0625, and for input current = 22 mA, the normalized result is equal 1.125. In such cases presented expressions are still correct.

11.1. Additional calculations (used conversion characteristic)


The manner of the additional computation of the displayed result depends on selected conversion characteristic. All presented charts are connected with the input range 4 ... 20 mA.

11.1.1. Linear characteristic

The normalized result is converted by fixed coefficients determined by “Lo C” and “Hi C” parameters (when the normalized results is equal 0, then value “Lo C” is displayed, and when the normalized results is equal 1, then value “Hi C” is displayed). Expression presented below shows the manner of result calculation:

$$W = I_n \times ("Hi C" - "Lo C") + "Lo C"$$

where **W** means the displayed value.

 The value of the “Lo C” parameter can be higher than the value of “Hi C” parameter. In such a case, for an increasing value of input current the displayed value decreases.




Fig. 11.1. Normal („Lo C” < „Hi C”) and inverted („Lo C” > „Hi C”) characteristic

11.1.2. Square characteristic

The normalized result is squared and further conversion is done as for linear characteristic. Conversion is made accordingly with the expression:

$$W = I_n^2 \times ("Hi C" - "Lo C") + "Lo C"$$

where **W** means the displayed value.




Fig. 11.2. Normal („Lo C” < „Hi C”) and inverted („Lo C” > „Hi C”) characteristic

11.1.3. Square root characteristic

The normalized result is rooted and further conversion is done as for linear characteristic. Conversion is made accordingly with the expression:

$$W = \sqrt{I_n} \times ("Hi C" - "Lo C") + "Lo C"$$

where **W** means the displayed value.

☞ Showed above expression is not valid when normalized result is negative. It is possible for 4-20 mode only. In this case ($I_n < 0$) the displayed result is equal "**Lo C**" (see graphs below).




Fig. 11.3. Normal („Lo C” < „Hi C”) and inverted („Lo C” > „Hi C”) characteristic

11.1.4. User defined characteristic

User defined characteristic is defined as set of X-Y points. Number of the points is variable and may be set from 2 to 20 points which make linear segments (see graph and see **Menu "inPt"**). Due to the normalized result I_n , the device computes specific segment, e.g. for characteristic from figure below, and $I_n = 0.65$ the segment between points X = "**50.0**." and X = "**70.0**." will be chosen.

Let's mark those points as PL (point low) i PH (point high) - in this example PL = "**50.0**." and PH = "**70.0**.", and the normalized result I_n for the point PL as I_p (in this example $I_p = I_n(PL) = 0.5$). The displayed result is calculated accordingly to the expression:

$$W = (I_n - I_p) \times \frac{Y(PH) - Y(PL)}{X(PH) - X(PL)} \times 100 + Y(PL)$$

where Y(PH), X(PH), Y(PL), X(PL) mean values of X and Y coordinates of PH i PL points.

☞ If the normalized result exceeds the user defined characteristic values, then specific utmost segment, defined by two next points, is used for calculations. If characteristic from figure below is used, and if $I_n > 1$ then segment defined by points X(PL) = "**90.0**.", X(PH) = "**100.0**." will be used.




Fig. 11.4. Example of user defined characteristic

11.2. Examples of calculations

Example 1: Selection of the permissible input range (“4-20” mode)

If in “4-20” mode the user sets “Lo r” = 20.0 % and “Hi r” = 10 %, then permissible input currents range will be equal: 3.2 mA ... 22 mA. Lower border of the range is the result of calculations: 4 mA - 4 mA × 20 %, and the higher : 20 mA + 20 mA × 10 %.

Example 2: The normalized I_n result calculation

Let the input mode = 4-20 mA. The normalized I_n result is calculated accordingly to the expression on page 35, so if $I_{in} = 10$ mA then 10 mA - 4 mA = 6 mA, and this result should be divided by the width of input range (16 mA). Finally the normalized result: $I_n = 6/16 = 0.375$.

In case when input current exceeds nominal measurement range, calculations are similar. For example if input current is equal 2.5 mA then $I_n = (2.5 - 4)/16 \cong -0.0938$, and if input current is equal 20.5 mA then $I_n = (20.5 - 4)/16 \cong 1.0313$.

Example 3: The linear characteristic

Let the input mode = 4-20 mA, and parameters “Lo C” and “Hi C” equal to -300 and 1200 respectively. The calculations will be done for there different input currents from example 2.

- a) $I_{in} = 10 \text{ mA}$ and $I_n = 0.375$

Accordingly to expression on page 38 for linear characteristic:

$0.375 \times [1200 - (-300)] \cong 562$ and next, the “**Lo C**” value is added to the result , so the displayed value:

$$W \cong 562 + (-300) = 262$$

- b) $I_{in} = 2.5 \text{ mA}$ and $I_n = -0.0938$. $W \cong -441$.

- c) $I_{in} = 20.5 \text{ mA}$ and $I_n = 1.0313$. $W \cong 1247$.

Example 4: The square characteristic

Let the input mode = 4-20 mA, and parameters “**Lo C**” and “**Hi C**” equal to -300 and 1200 respectively. The calculations will be done for there different input currents from example 2.

- a) $I_{in} = 10 \text{ mA}$ and $I_n = 0.375$

Accordingly to expression on page 36 for linear characteristic:

$(0.375)^2 \times [1200 - (-300)] \cong 211$. and next, the “**Lo C**” value is added to the result , so the displayed value:

$$W \cong 211 + (-300) = -89$$

- b) $I_{in} = 2.5 \text{ mA}$ and $I_n = -0.0938$.

$$W \cong -287.$$

- c) $I_{in} = 20.5 \text{ mA}$ and $I_n = 1.0313$.

$$W \cong 1295.$$

Example 5: The square root characteristic

Let the input mode = 4-20 mA, and parameters “**Lo C**” and “**Hi C**” equal to -300 and 1200 respectively. The calculations will be done for there different input currents from example 2.

- a) $I_{in} = 10 \text{ mA}$ and $I_n = 0.375$

Accordingly to expression on page 37 for linear characteristic:

$$\text{sqrt}(0.375) \times [1200 - (-300)] \cong 919$$

and next, the “**Lo C**” value is added to the result , so the displayed value:

$$W \cong 919 + (-300) = 619$$

- b) $I_{in} = 2.5 \text{ mA}$ and $I_n = -0.0938$, normalized result is negative, so the displayed value is equal to “**Lo C**” parameter:

$$W \cong \text{“Lo C”} = -300$$

- c) $I_{in} = 20.5 \text{ mA}$ and $I_n = 1.0313$

$$W \cong 1223$$

Example 6: The user defined characteristic

Let the input mode = 4-20 mA, and the user selected the 10 segment characteristic. To do this it is necessary to enter X and Y coordinates of 11 points (see **Menu "inPt"**).

The calculations will be done for three different input currents from example 2, so in calculations some of the segments will be used only.

Let the following points will be given:

X1 = "00.0.", Y1 = "-50.0",

X2 = "10.0.", Y2 = "-30.0",

....

X6 = "30.0.", Y6 = "30.0",

X7 = "40.0.", Y7 = "80.0",

....

X10 = "90.0.", Y10 = "900.0",

X11 = "100.0.", Y11 = "820.0",

Additionally all other points must to be defined and stored in the device memory.

a) $I_{in} = 10$ mA and $I_n = 0.375$

The segment defined by X6 = "30.0." and X7 = "40.0." for this I_n will be selected.

Accordingly to expressions given for user defined characteristic (see page 37)

X6(PL) = 30, Y6(PL) = 30, X7(PH) = 40, Y7(PH) = 80 and $I_p = 0.3$, the displayed value :

$$W = (I_n - I_p) \times \frac{[Y(PH) - Y(PL)]}{[X(PH) - X(PL)]} \times 100 + Y(PL) =$$

$$= (0.375 - 0.3) \times \frac{[80 - 30]}{[40 - 30]} \times 100 + 30 \simeq 67$$

b) $I_{in} = 2.5$ mA and $I_n = -0.0938$, because of the normalized I_n value is lower than 0, the segment defined by X1 and X2 will be selected. X1(PL) = 0, Y1(PL) = -50, X2(PH) = 10, Y2(PH) = -30 and $I_p = 0$. For these values the displayed value $W \simeq -69$.

c) $I_{in} = 20.5$ mA and $I_n = 1.0313$, because of the normalized I_n value is higher than 1, the segment defined by X10 and X11 will be selected, and X10(PL) = 90, Y10(PL) = 900, X11(PH) = 100, Y11(PH) = 820 and $I_p = 0.9$ for these values the displayed value $W \simeq 795$.

Example 7: Current output value calculation

Let the current output parameters be:

"mode" = "on", "OUTL" = 100, "OUTH" = 200, "Lo r" = 5.0, "Hi r" = 5.0

Parameters "Lo r" and "Hi r" define working range of current output to 3,8 ... 21 mA.

Output current will be calculated for three displayed values „D“:

a) D = „17.5“

According to formula from page 29:

$$I_{out} = (17.5 - 10.0) / (20.0 - 10.0) \times 16 \text{ mA} + 4 \text{ mA} = 0.75 \cdot 16 + 4 = 16 \text{ mA}$$

Calculated I_{out} do not exceeds the output working range (3 ... 21 mA).

b) $D = „20.5”$

According to formula from page 29:

$$I_{out} = (20.5-10.0) / (20.0-10.0) \times 16 \text{ mA} + 4 \text{ mA} = 1.05 \cdot 16 + 4 = 20.08 \text{ mA}$$

Calculated I_{out} do not exceeds the output working range (3 - 21 mA).

c) $D = „30.0”$

According to formula from page 29:

$$I_{out} = (30.0-10.0) / (20.0-10.0) \times 16 \text{ mA} + 4 \text{ mA} = 2 \cdot 16 + 4 = 36 \text{ mA}.$$

Calculated I_{out} exceeds the output working range (3 ... 21 mA), so current output will generate current equal to the upper border of range defined by parameter “**Lo r**” i “**Hi r**” (it means 21 mA).

12. The Modbus protocol handling

Transmission parameters: 1 start bit, 8 data bits, 1 or 2 stop bit (2 bits are send, 1 and 2 bits are accepted when receive), no parity control

Baud rate:selectable from: 1200 to 115200 bits/second

Transmission protocol: MODBUS RTU compatible

The device parameters and display value are available via RS-485 interface, as HOLDING-type registers (numeric values are given in U2 code) of Modbus RTU protocol. The registers (or groups of the registers) can be read by 03h function, and wrote by 06h (single registers) or 10h (group of the registers) accordingly to Modbus RTU specification. Maximum group size for 03h and 10h functions cannot exceeds 16 registers (for single frame).

 The device interprets the broadcast messages, but then do not sends the answers.

11.1. List of registers

Register	Write	Range	Register description
01h	No	-999 ... 9999	Measurement value (no decimal point)
02h	No	0h, A0h, 60h	The status of the current measurement; 0h - data valid; A0h - top border of the measurement range is exceeded; 60h - bottom border of the measurement range is exceeded;
03h	Yes	0 ... 3	" Pnt " parameter in " InPt " menu (decimal point position) 0 - " 0"; 1 - " 0.0"; 2 - " 0.00"; 3 - "0.000"
04h	Yes	see descr.	State of the relays and alarm LED (binary format) (1 - on, 0 - off): 00000000 000edcba a - relay R1; b - relay R2; c - relay R3; d - relay R2; e - alarm LED; if written, only a , b , c , d bits are important (others are ignored) these bits allows user to control the relays via RS-485 interface
05h ¹	Yes	0 ... 1800 h	State of current output, expressed in 1/256 mA units – it means that high byte express integer part, and low byte fractional part of desired output current.
06h	No	-999 ... 9999	Peak (drop) value (no decimal point)
10h	Yes	0 ... 5	" tyPE " parameter in " InPt " menu (nominal input range). 0 - 0-20 mA range; 1 - 4-20 mA range; 2 - 0-10 V range; 3 - 2-10 V range; 4 - 0-5 V range; 5 - 1-5 V range
11h	Yes	0 ... 3	" CHAr " parameter in " InPt " menu (characteristic type) 0 - linear; 1 - square; 2 - square root; 3 - user defined
12h	Yes	0 ... 5	" FiLt " parameter in " InPt " menu (measurement filtering rate)
13h	Yes	0 ... 3	" Pnt " parameter in " InPt " menu (the copy of 03h register, decimal point position) 0 - " 0"; 1 - " 0.0"; 2 - " 0.00"; 3 - "0.000"
14h	Yes	-999 ... 9999	" Lo C " parameter in " InPt " menu, no decimal point included
15h	Yes	-999 ... 9999	" Hi C " parameter in " InPt " menu, no decimal point included
16h	Yes	0 ... 999	" Lo r " parameter in " InPt " menu, in 0.1 %
17h	Yes	0 ... 199	" Hi r " parameter in " InPt " menu, in 0.1 %
20h ²	Yes	0 ÷ 199	Device address
21h	No	20A1h	Device identification code (ID)
22h ³	Yes	0 ... 7	" bAud " parameter in " rS " menu (baud rate); 0 - 1200 baud; 1 - 2400 baud; 2 - 4800 baud; 3 - 9600 baud; 4 - 19200 baud; 5 - 38400 baud; 6 - 57600 baud; 7 - 115200 baud
23h ⁴	Yes	0 ... 1	" mbAc " parameter in " rS " menu (permission to write registers via RS-485 interface); 0 - write denied ; 1 - write allowed
24h	Yes	see descr.	Parameters of " SECU " menu (binary format (0 - „ oFF “, 1 - „ on “): bit 0 - " A r1 " parameter; bit 1 - " A r2 " parameter bit 2 - " A r3 " parameter; bit 3 - " A r4 " parameter
25h	Yes	0 ... 5	" rESP " parameter in " rS " menu (additional response delay); 0 - no additional delay; 1 - "10c" option; 2 - "20c" option; 3 - "50c" option; 4 - "100c" option; 5 - "200c" option;

<i>Register</i>	<i>Write</i>	<i>Range</i>	<i>Register description</i>
27h	Yes	0 ... 99	"mbtO" parameter in "rS" menu (maximum delay between received frames); 0 - no delay checking; 1 ... 99 - maximum delay expressed in seconds
28h	Yes	0 ... 1	"AL" parameter in "bBEEP" menu: 0 - off; 1 - on
29h	Yes	0 ... 1	"R1" parameter in "bBEEP" menu: 0 - off; 1 - on
2Ah	Yes	0 ... 1	"R2" parameter in "bBEEP" menu: 0 - off; 1 - on
2Bh	Yes	0 ... 1	"R3" parameter in "bBEEP" menu: 0 - off; 1 - on
2Ch	Yes	0 ... 1	"R4" parameter in "bBEEP" menu: 0 - off; 1 - on
2Dh	Yes	1 ... 8	"bri" parameter (display brightness); 1 - the lowest brightness; 8 - the highest brightness
2Fh	Yes	0 ... 1	"Edit" parameter (numerical parameters edit mode); 0 - „dig" mode; 1 - „SLid" mode
30h	Yes	-999 ... 9999	"SEtP" parameter in "rEL1" menu, no decimal point included
31h	Yes	-999 ... 999	"HySt" parameter in "rEL1" menu, no decimal point included
32h	Yes	0 ... 3	"modE" parameter in "rEL1" menu: 0 - "noAC" mode; 1 - "on" mode; 2 - "oFF" mode; 3 - "in" mode; 4 - "out" mode; 5 - "modb" mode
33h	Yes	0 ... 999	"t on" parameter in "rEL1" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 35h)
34h	Yes	0 ... 999	"toFF" parameter in "rEL1" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 35h)
35h	Yes	0 ... 1	"unit" parameter in "rEL1" menu: 0 - seconds; 1 - minutes
36h	Yes	0 ... 2	"AL" parameter in "rEL1" menu: 0 - no changes; 1 - on; 2 - off
37h	Yes	-999 ... 9999	"SEt2" parameter in "rEL2" menu, no decimal point included
38h	Yes	-999 ... 9999	"SEtP" parameter in "rEL2" menu, no decimal point included
39h	Yes	-999 ... 999	"HySt" parameter in "rEL2" menu, no decimal point included
3Ah	Yes	0 ... 3	"modE" parameter in "rEL2" menu: 0 - "noAC" mode; 1 - "on" mode; 2 - "oFF" mode; 3 - "in" mode; 4 - "out" mode; 5 - "modb" mode
3Bh	Yes	0 ... 999	"t on" parameter in "rEL2" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 3Dh)
3Ch	Yes	0 ÷ 999	"toFF" parameter in "rEL2" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 3Dh)
3Dh	Yes	0 ... 1	"unit" parameter in "rEL2" menu: 0 - seconds; 1 - minutes
3Eh	Yes	0 ... 2	"AL" parameter in "rEL2" menu: 0 - no changes; 1 - on; 2 - off
3Fh	Yes	-999 ... 9999	"SEt2" parameter in "rEL2" menu, no decimal point included
40h	Yes	-999 ... 9999	"SEtP" parameter in "rEL3" menu, no decimal point included

Register	Write	Range	Register description
41h	Yes	-999 ... 999	"HySt" parameter in "rEL3" menu, no decimal point included
42h	Yes	0 ... 3	"modE" parameter in "rEL3" menu: 0 - "noAC" mode; 1 - "on" mode; 2 - "oFF" mode; 3 - "in" mode; 4 - "out" mode; 5 - "modb" mode
43h	Yes	0 ... 999	"t on" parameter in "rEL3" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 45h)
44h	Yes	0 ... 999	"toFF" parameter in "rEL3" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 45h)
45h	Yes	0 ... 1	"unit" parameter in "rEL3" menu: 0 - seconds; 1 - minutes
46h	Yes	0 ... 2	"AL" parameter in "rEL3" menu: 0 - no changes; 1 - on; 2 - off
47h	Yes	-999 ... 9999	"SEt2" parameter in "rEL3" menu, no decimal point included
48h	Yes	-999 ... 9999	"SEtP" parameter in "rEL4" menu, no decimal point included
49h	Yes	-999 ... 999	"HySt" parameter in "rEL4" menu, no decimal point included
4Ah	Yes	0 ... 3	"modE" parameter in "rEL4" menu: 0 - "noAC" mode; 1 - "on" mode; 2 - "oFF" mode; 3 - "in" mode; 4 - "out" mode; 5 - "modb" mode
4Bh	Yes	0 ... 999	"t on" parameter in "rEL4" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 4Dh)
4Ch	Yes	0 ... 999	"toFF" parameter in "rEL4" menu, expressed in tenth of seconds or tenth of minutes depend on "unit" parameter - register no. 4Dh)
4Dh	Yes	0 ... 1	"unit" parameter in "rEL4" menu: 0 - seconds; 1 - minutes
4Eh	Yes	0 ... 2	"AL" parameter in "rEL4" menu: 0 - no changes; 1 - on; 2 - off
4Fh	Yes	-999 ... 9999	"SEt2" parameter in "rEL4" menu, no decimal point included
50h	Yes	0 ... 1	"modE" parameter in "HOLD" menu (type of detected changes): 0 - peaks; 1 - drops
51h	Yes	0 ... 9999	"PEA" parameter in "HOLD" menu (minimum detectable change, no decimal point included)
52h	Yes	1 ... 199	"timE" parameter in "HOLD" menu, maximum peaks' (or drops') display time expressed in seconds
53h	Yes	0 ... 1	"HdiS" parameter in "HOLD" menu: 0 - "rEAL" mode ; 1 - "HOLD" mode
54h	Yes	0 ... 1	"H r1" parameter in "HOLD" menu : 0 - "rEAL" mode ; 1 - "HOLD" mode
55h	Yes	0 ... 1	"H r2" parameter in "HOLD" menu: 0 - "rEAL" mode ; 1 - "HOLD" mode
56h	Yes	0 ... 1	"H r3" parameter in "HOLD" menu: 0 - "rEAL" mode ; 1 - "HOLD" mode
57h	Yes	0 ... 1	"H r4" parameter in "HOLD" menu: 0 - "rEAL" mode ; 1 - "HOLD" mode

Register	Write	Range	Register description
58h	Yes	0 ... 1	" HOUT " parameter in " HOLD " menu: 0 - " rEAL " mode ; 1 - " HOLD " mode
70h ⁵	Yes	-999 ... 1999	The value of „ X “ coordinate of point no. 1 of the user defined characteristic, expressed in 0.1%
71h ⁵	Yes	-999 ... 9999	The value of „ Y “ coordinate of point no. 1 of the user defined characteristic, no decimal point included
72h ⁵ ... 95h ⁵			" HOUT " parameter in " HOLD " menu: 0 - " rEAL " mode ; 1 - " HOLD " mode
96h ⁵	Yes	-999 ... 1999	The value of „ X “ coordinate of point no. 20 of the user defined characteristic, expressed in 0.1%
97h ⁵	Yes	-999 ... 9999	The value of „ Y “ coordinate of point no. 20 of the user defined characteristic, no decimal point included
A0h ¹	Yes	0 ... 2	" Omod " parameter in " OUTP " menu (current output mode) 0 - current output disabled; 1 - current output enabled with 0 ... 20mA mode; 2 - current output enabled with 4 ... 20mA mode; 3 - current output controlled via RS-485 interface
A1h ¹	Yes	-999 ... 9999	" OUTL " parameter in " OUTP " menu, no decimal point included
A2h ¹	Yes	-999 ... 9999	" OUTH " parameter in " OUTP " menu, no decimal point included
A3h ¹	Yes	0 ... 499	" Lo r " parameter in " OUTP " menu, expressed in 0.1%
A4h ¹	Yes	0 ... 99	" Hi r " parameter in " OUTP " menu, expressed in 0.1%
A5h ¹	Yes	0 ... 3	" AL " parameter in " OUTP " menu (current output value on critical exception): 0 - no change; 1 - 22.1 mA; 2 - 3.4 mA; 3 - 0 mA
B0h	Yes	0 ... 1	Parameter " tyPE " of sub-menu " bAr " (display mode of the bargraph), 0 - line; 1 - point
B1h	Yes	0 ... 6	Parameter " FCol " of sub-menu " bAr " (colours of the bargraph) 0 - bargraph off; 1 - option " grEE "; 2 - option " rEd "; 3 - option " g r "; 4 - option " r g "; 5 - option " b g "; 6 - option " b r "
B2h	Yes	-999 ... 9999	Parameter " Lo C " of sub-menu " bAr ", no decimal point
B3h	Yes	-999 ... 9999	Parameter " Hi C " of sub-menu " bAr ", no decimal point
B4h	Yes	0 ... 3	Parameter " Pr1P " of sub-menu " bAr " (relay's R1 thresholds' markers): 0 – not showed; 1 - option " 1St "; 2 - option " 2nd "; 3 - option " both ";
B5h	Yes	0 ... 3	Parameter " Pr2P " of sub-menu " bAr " (relay's R2 thresholds' markers): 0 – not showed; 1 - option " 1St "; 2 - option " 2nd "; 3 - option " both ";
B6h	Yes	0 ... 3	Parameter " Pr3P " of sub-menu " bAr " (relay's R3 thresholds' markers): 0 – not showed; 1 - option " 1St "; 2 - option " 2nd "; 3 - option " both ";
B7h	Yes	0 ... 3	Parameter " Pr4P " of sub-menu " bAr " (relay's R4 thresholds' markers): 0 – not showed; 1 - option " 1St "; 2 - option " 2nd "; 3 - option " both ";

<i>Register</i>	<i>Write</i>	<i>Range</i>	<i>Register description</i>
B8h	Yes	0 ... 4	Parameter " P1AL " of sub-menu " bAr " (critical situation defined for relay R1): 0 - no change; 1 - option " morE "; 2 - option " LESS "; 3 - option " on "; 4 - option " oFF "
B9h	Yes	0 ... 4	Parameter " P2AL " of sub-menu " bAr " (critical situation defined for relay R2): 0 - no change; 1 - option " morE "; 2 - option " LESS "; 3 - option " on "; 4 - option " oFF "
BAh	Yes	0 ... 4	Parameter " P3AL " of sub-menu " bAr " (critical situation defined for relay R3): 0 - no change; 1 - option " morE "; 2 - option " LESS "; 3 - option " on "; 4 - option " oFF "
BBh	Yes	0 ... 4	Parameter " P4AL " of sub-menu " bAr " (critical situation defined for relay R4): 0 - no change; 1 - option " morE "; 2 - option " LESS "; 3 - option " on "; 4 - option " oFF "

- 1 - these registers are active only if device is equipped with active current output
- 2 - after writing to register no 20h the device responds with an "old" address in the message.
- 3 - after writing to register no 22h the device responds with the new baud rate.
- 4 - the value of the "**mbAc**" parameter is also connected to write to this register, so it is possible to block a writes, but impossible to unblock writes via RS-485 interface, The unblocking of the writes is possible from menu level only.
- 5 - the pairs of „**X** -**Y**“ coordinates may be defined for any free point. The pair is "free" (it means that particular point is not defined) if „**X**“ coordinate of this point is equal 8000h. After writing both X and Y coordinate the point is defined and used in calculation of result. The coordinates of any point can be changed at any time.

12.2. Transmission errors description

If an error occurs while write or read of single register, then the device sends an error code according to Modbus RTU specifications (example message no 1).

Error codes:

- 01h** - illegal function (only functions 03h, 06h and 10h are available),
- 02h** - illegal register address
- 03h** - illegal data value
- 08h** - no write permission (see: “**mbAc**” parameter)
- A0h** - exceed of upper border of input range
- 60h** - exceed of lower border of input range

A0h and 60h codes can appear only during reg. 01h is reading by 03h function (read of a single register).

12.3. Examples of query / answer frames

Examples apply for device with address 1. All values are represent hexadecimal.

Field description:

ADDR	Device address on modbus network
FUNC	Function code
REG H,L	Starting address (address of first register to read/write, Hi and Lo byte)
COUNT H,L	No. of registers to read/write (Hi and Lo byte)
BYTE C	Data byte count in answer frame
DATA H,L	Data byte (Hi and Lo byte)
CRC L,H	CRC error check (Hi and Lo byte)

1. Read of the displayed value (measurement), CIT 350 device address = 01h:

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
01	03	00	01	00	01	D5	CA

a) The answer (we assume that the measure result is not out of range):

ADDR	FUNC	BYTE C	DATA H,L		CRC L,H	
01	03	02	00	FF	F8	04

DATA H, L - displayed value = 255, no decimal point. Decimal point position can be read from reg. 03h.

b) The answer (if an error occur):

ADDR	FUNC	ERROR	CRC L,H	
01	83	60	41	18

ERROR - error code = 60h, bottom border of the measurement range is exceeded

2. Read of device ID code

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
01	03	00	21	00	01	D4	00

The answer:

ADDR	FUNC	BYTE C	DATA H,L		CRC L,H	
01	03	02	20	A1	60	3C

DATA - identification code (20A1h)

3. Change of the device address from 1 to 2 (write to reg. 20h)

ADDR	FUNC	REG H,L		DATA H,L		CRC L,H	
01	06	00	20	00	02	09	C1

DATA H - 0

DATA L - new device address (2)

The answer (the same as the message):

ADDR	FUNC	REG H,L		DATA H,L		CRC L,H	
01	06	00	20	00	02	09	C1

4. Change of baud rate of all devices connected to the net (BROADCAST message).

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
00	06	00	22	00	04	29	D2

DATA H - 0

DATA L - 4, new baud rate 19200 baud



Device do not reply to BROADCAST-type messages.

5. Read of the registers 1, 2 and 3 in one message (example of reading a number of registries in one frame):

ADDR	FUNC	REG H,L		COUNT H,L		CRC L,H	
01	03	00	01	00	03	54	0B

COUNT L - the count of being read registers (max.16)

The answer:

ADDR	FUNC	BYTE C	DATA H1,L1		DATA H2,L2		DATA H3,L3		CRC L,H	
01	03	06	00	0A	00	00	00	01	78	B4

DATA H1, L1 - reg. 01h (10 - displayed value "1.0"),

DATA H2, L2 - reg. 02h (0 - no errors),,

DATA H3, L3 - reg. 03h (1 - decimal point position " 0.0").



There is no full implementation of the Modbus Protocol in the device. The functions presented above are available only.

12. Default and user`s settings list

<i>Parameter</i>	<i>Description</i>	<i>Default value</i>	<i>User's value</i>	<i>Desc. page</i>
Parameters of relay R1 operation (“rEL1” menu)				
SEtP	Relay R1 threshold	20.0		24
SEt2	Relay R1 second threshold	30.0		24
HYSt	Hysteresis of relay R1	0.0		24
modE	Operation mode of relay R1	in		24
t on	Turn on delay of relay R1	0.0		25
toFF	Turn off delay of relay R1	0.0		25
unit	Unit of “t on”, “toFF” parameters of relay R1	SEC		25
AL	Reaction for critical situation of relay R1	oFF		25
Parameters of relay R2 operation (“rEL2” menu)				
SEtP	Relay R2 threshold	40.0		24
SEt2	Relay R2 second threshold	50.0		24
HYSt	Hysteresis of relay R2	0.0		24
modE	Operation mode of relay R2	in		24
t on	Turn on delay of relay R2	0.0		25
toFF	Turn off delay of relay R2	0.0		25
unit	Unit of “t on”, “toFF” parameters of relay R2	SEC		25
AL	Reaction for critical situation of relay R2	oFF		25
Parameters of relay R3 operation (“rEL3” menu)				
SEtP	Relay R3 threshold	60.0		24
SEt2	Relay R3 second threshold	70.0		24
HYSt	Hysteresis of relay R3	0.0		24
modE	Operation mode of relay R3	in		24
t on	Turn on delay of relay R3	0.0		25
toFF	Turn off delay of relay R3	0.0		25
unit	Unit of “t on”, “toFF” parameters of relay R3	SEC		25
AL	Reaction for critical situation of relay R3	oFF		25
Parameters of relay R4 operation (“rEL4” menu)				
SEtP	Relay R4 threshold	80.0		24
SEt2	Relay R4 second threshold	90.0		24
HYSt	Hysteresis of relay R4	0.0		24
modE	Operation mode of relay R4	in		24

<i>Parameter</i>	<i>Description</i>	<i>Default value</i>	<i>User's value</i>	<i>Desc. page</i>
t on	Turn on delay of relay R4	0.0		25
toFF	Turn off delay of relay R4	0.0		25
unit	Unit of “t on”, “toFF” parameters of relay R4	SEC		25
AL	Reaction for critical situation of relay R4	oFF		25
Activation of acoustic signal (menu “bEEP”)				
AL	Activation of acoustic signal by critical situation	oFF		26
r1	Activation of acoustic signal by relay R1	oFF		26
r2	Activation of acoustic signal by relay R2	oFF		26
r3	Activation of acoustic signal by relay R3	oFF		26
r4	Activation of acoustic signal by relay R4	oFF		26
Configuration of measurement input (“inPt” menu)				
tYPE	Input type	„Pt 1”		26
CHAr	Conversion characteristic mode	Lin		26
FiLt	Filtering ratio	0		26
Pnt	Decimal point position	0.0		26
Lo C	Minimum displayed value (for nominal range)	000.0		27
Hi C	Maximum displayed value (for nominal range)	100.0		27
Lo r	Extension of the bottom of the nominal input range	5.0 (%)		28
Hi r	Extension of the top of the nominal input range	5.0 (%)		28
Active current output configuration (“OUtP” menu)				
Omod	Current output mode	„0-20” (mA)		29
OUtL	Display value for 0 mA or 4 mA (depend „Omod”) current output	0.0		29
OUtH	Display value for 20 mA current output	100.0		29
Lo r	Extension of the bottom of the nominal output range	5.0 (%)		29
Hi r	Extension of the top of the nominal output range	5.0 (%)		29
AL	Current output value on critical exception	22.1 (mA)		30
Options connected with the bargraph (“bAr” menu)				
tYPE	Display mode of the bargraph	„LinE”		30
FCoL	Colours of the bargraphs	„g r”		30
Pr1P	Markers of the thresholds of relays R1	„1St”		30
Pr2P	Markers of the thresholds of relays R2	„1St”		30
Pr3P	Critical situation definition for relay R3	„oFF”		30
Pr4P	Critical situation definition for relay R4	„oFF”		30

Parameter	Description	Default value	User's value	Desc. page
P1AL	Critical situation definition for relay R1	„noC”		31
P2AL	Critical situation definition for relay R2	„noC”		31
P3AL	Critical situation definition for relay R3	„noC”		31
P4AL	Critical situation definition for relay R4	„noC”		31
Lo C	Measurement value appropriate to 0% on the bargraph	0		31
Hi C	Measurement value appropriate to 1000% on the bargraph	100.0		31
Display parameters				
bri	Display brightness	bri6		31
Configuration of peaks detection function ("HOLd" menu)				
modE	Kind of detected changes	norm		31
PEA	Minimum detected change	0.0		32
timE	Maximum time of peak displaying	0.0		32
HdiS	The type of displayed value	HOLd		32
H r1	Source of relay R1, and LED R1 control	rEAL		32
H r2	Source of relay R2, and LED R2 control	rEAL		32
H r3	Source of relay R3, and LED R3 control	rEAL		32
H r4	Source of relay R4, and LED R4 control	rEAL		32
HOUT	Source of current output control	rEAL		32
Settings of access to the configuration parameters ("SECu" menu)				
A r1	Permission to changes of relay R1 threshold without of the user password knowledge	on		32
A r2	Permission to changes of relay R2 threshold without of the user password knowledge	on		32
A r3	Permission to changes of relay R3 threshold without of the user password knowledge	on		32
A r4	Permission to changes of relay R4 threshold without of the user password knowledge	on		32
RS 485 interface configuration (menu "rS")				
Addr	Device address	0		32
bAud	Baud rate	9.6		33
mbAc	Permission to changes of configuration registers	on		33
mbtO	Maximum delay between received messages	0		33
rESP	Additional delay of answer transmission	Std		33
Configuration of numerical parameters edition				
Edit	Numerical parameters edit mode	dig		34

13. Disposal

The device must be disposed according to the European Directives 2002/96/EC and 2003/108/EC (on waste electrical and electronic equipment). Electrical and electronic waste equipment may not be disposed by domestic refuse.



14. Warranty conditions

The warranty conditions are subject to the legal warranty period of 24 months from the date of delivery. In case of improper use, modifications of or damages to the device, we do not accept warranty claims. Furthermore, defects due to normal wear are not subject to warranty services.

BD SENSORS GmbH

BD-Sensors-Str. 1

95199 Thierstein

Germany

Phone + 49 (0) 92 35 / 98 11- 0

Fax + 49 (0) 92 35 / 98 11- 11

The addresses of our 'Distribution Partners' are listed on our homepage **www.bdsensors.com**.

It is possible to download data sheets, operating manuals, ordering codes and certificates, as well.

further agencies in:

EUROPE

- Belgium
- Denmark
- Germany
- England
- France
- Greece
- Italy
- Lithuania
- Luxembourg
- Netherlands
- Norway
- Poland
- Romania
- Russia
- Sweden
- Switzerland
- Slovakia
- Spain
- Czech Republic
- Turkey
- Ukraine

ASIA

- Iran
- Israel
- Kazakhstan
- Taiwan
- Thailand

AUSTRALIA

- Queensland



The contents of this operating manual reflect the version available at the time of printing. It has been issued to our best knowledge and belief. However, errors may still be included. For incorrect statements and their consequences, liability cannot be assumed by BD SENSORS.

– Technical modifications reserved –