

SECURITY ALARM CONTROL UNIT

# Proxi**NET**

36-76-192

PROGRAMMING MANUAL

**INDEX**

<b>1 SYMBOLS AND GLOSSARY</b> .....	<b>PAG.</b>	2
<b>2 TECHNICAL MENU</b> .....	<b>PAG.</b>	3
ACCESSING THE TECHNICAL MENU .....		3
<b>2.1 PROGRAMMING MODE</b> .....		3
MENU ITEMS BELONGING TO OTHER MODES .....		3
SIMPLE MODE .....		4
MODE STANDARD .....		4
ADVANCED MODE .....		4
<b>2.2 INSTALLATION</b> .....		5
MODIFY SYSTEM .....		5
ADDRESSING KEYPADS .....		6
ADDRESSING INSERTERS .....		6
SYSTEM TEST .....		6
BUS RS485 .....		7
PXLAN/PXWEB CONFIGURATION .....		7
<b>2.3 SCENARIOS</b> .....		8
<b>2.4 AREAS</b> .....		9
<b>2.5 KEYPADS</b> .....		10
<b>2.6 INSERTERS</b> .....		11
<b>2.7 INPUTS MODULE</b> .....		12
<b>2.8 OUTPUTS MODULES</b> .....		12
<b>2.9 RADIO MODULES</b> .....		12
<b>2.10 INPUTS</b> .....		13
<b>2.11 OUTPUTS</b> .....		19
<b>2.12 TIMES</b> .....		20
<b>2.13 TELEPHONE NOTIFICATIONS</b> .....		22
<b>2.14 ASSOCIATING OUTPUT</b> .....		25
<b>2.15 CODES</b> .....		26
<b>2.16 KEYS</b> .....		28
<b>2.17 TELEPHONES</b> .....		29
<b>2.18 TELEPHONE OPTIONS</b> .....		30
<b>2.19 SPECIAL FUNCTIONS</b> .....		32
<b>2.20 PROGRAMMER</b> .....		33
<b>2.21 SCHEDULER CALENDAR</b> .....		34
<b>2.22 EVENTS</b> .....		34
<b>2.23 CLOCK</b> .....		35
<b>2.24 DEFAULT PARAMETERS</b> .....		36
<b>2.25 CONTROL UNIT VERSION</b> .....		36
<b>3 EVENTS MESSAGING</b> .....	<b>PAG.</b>	37
<b>4 REFERENCE LAWS</b> .....	<b>PAG.</b>	39
<b>5 DECLARATION</b> .....	<b>PAG.</b>	39

## 1 Symbols and glossary



This symbol means the parts which describe safety issues.



This symbol shows parts which must be read with care.



Permanently on warning light.



Warning light off.



Rapidly flashing warning light.

**INSTALLER:** any person or business responsible for designing and installing the system.



**USER:** any persons using the intruder alarm system.

## 2 Technical Menu

### ACCESSING THE TECHNICAL MENU


Depending on the **TEC MENU ACCESS** ( **CODES** -> **INSTALLER'S TECHNICAL CODE** ), parameters, access to the technical menu may be either preceded or not by the **User code**.

 Simultaneously accessing the technical menu or user from multiple keypads is not allowed.

ACCESS AFTER USER CODE	DIRECT ACCESS
<p>To access the technical menu enter the user code followed by the technical code. If the codes are less than the 6 digits confirm code insertion with <b>*</b>.</p> <div style="text-align: center;">  </div>	<p>To access the technical menu the system needs to be shut down, then enter the technical code. If the code is less than the 6 digits confirm code insertion with <b>*</b>.</p> <div style="text-align: center;">  </div>

### 2.1 Programming mode

For the burglar-proof alarm control unit to be as user-friendly as possible, from inexperienced installers to the most demanding professionals), the system features the “programming mode” concept. This can give either few or many parameters depending on the individual installer’s skill or needs.



### MENU ITEMS BELONGING TO OTHER MODES

This manual shows all of the menu items as if it were in **ADVANCED** mode.

To understand which menu item mode is viewable and therefore edited just look at which letters appear in the top right hand corner of each item’s description.



Item found in the three modes



Item found in standard and advanced modes



Item found only in advanced mode

Following are the main differences among the three types:

## SIMPLE MODE

The simple programming mode lets you quickly and simply start up low-complexity systems or is used with non highly skilled installing technicians.

The pre-configured settings are the following:

INDEX	AREA DESCRIPTION	INDEX	AREA DESCRIPTION
1	DAY AREA	3	PERIMETER AREA
2	NIGHT AREA		

INDEX	SCENARIO DESCRIPTION	ASSOCIATED AREAS	PROPRIETA'
1	GOING OUT	1, 2, 3	SWITCH ON+OFF.EXACT
2	GOING TO BED	1, 3	SWITCH ON+OFF.EXACT
3	STAYING INDOORS	3	SWITCH ON+OFF.EXACT

KEYPADS	ASSOCIATED SCENARIOS		INSERTERS	ASSOCIATED SCENARIOS	
ALL KEYPADS	A	GOING OUT	ALL INSERTERS	L1	GOING OUT
	B	GOING TO BED		L2	GOING TO BED
	C	STAYING INDOORS		L3	STAYING INDOORS

INDEX	OUTPUT DESCRIPTION	INDEX	OUTPUT DESCRIPTION
U1	<b>TC output</b> to disinhibit the detectors' microwave when system is off (associated to the NIGHT TIME area). From a positive with BEDING area switched off.	U3	<b>Yields a negative when something is out of order.</b>
U2	<b>System status</b> , yields a negative is at least one area is switched on.	U4	<b>Technical</b> , yields a negative when at least one technical alarm is switched on.
RELAY	<b>Relays 1 and 2</b> , is activated during the alarm time.		

CODES	CODE PROPERTIES	KEYS	DESCRIPTION OF PROPERTIES
all	SWITCHING ON + SWITCHING OFF of all areas.	all	SWITCHING ON + SWITCHING OFF of all areas.

TELEPHONE NUMBER	DESCRIPTION	TYPE	ATTEMPTS	ALARM	SABOTAGE	TECHNICAL	BURGLARY	SWITCHING ON	SWITCHING OFF	OUT OF ORDER	CODE ENTERING	KEY ENTERING	HELP	AUTO TEST	RESIDUAL CREDIT
1..7	Telephone 1..7	VOICE	2	x	x	x	x						x		
8..14	Telephone 8..14	SMS	1	x	x	x	x			x					x
15	Security firm	CONTACT-ID	1	x	x		x						x	x	
16	Technical	SMS	1	x	x	x	x			x			x		x

## MODE STANDARD

Same setting of the SIMPLE mode plus:

- Customise scenarios.
- Customised Keypads, inserters, codes, keys, ...
- Customised telephone calls.
- Restore default parameters and codes separately.

## ADVANCED MODE


The same settings of the SIMPLE and STANDARD modes plus:

- Customise keypad-specific voice messages.
- Advanced programming of radio, entrances, codes, keys, telephones, telephone options, special functions.
- Advanced programming of telephone functions.
- Time, calendar scheduler.
- Past Events print-out.


## 2.2 Installation

The system menu is for defining the system components (areas, keypads, inserters, ...), addressing them, and carrying out a series of tests. For programming move to the subsequent menu items.


### MODIFY SYSTEM




## ADDRESSING KEYPADS




## ADDRESSING INSERTERS




## SYSTEM TEST



BUS RS485



PXLAN/PXWEB CONFIGURATION



## 2.3 Scenarios

SCENARIOS 03

EDIT SCEN 01  
GOING OUT

ACTION AREAS 01  
SWITCH ON+OFF.EXACT

ASSOC. AREAS 01  
###-----

ACTION OUTPUT 01  
DISABLED

ASSOC. OUTPUT 01  
NO

DESCRIPTION 01  
GOING OUT

**Actions on areas:** (Default: SWITCH ON+OFF.EXACT)

**Associated areas:**

The parameter defines the action that the scenario is to carry out in the areas specified in ASSOC. AREAS.

**DEACTIVATED**      The scenario does not alter the switched on status of the areas.  
*Example: scenario deactivated or scenario for which you only want to manage the associated output on ASSOCIAT. OUTPUT .*

**SWITCH ON+OFF.EXACT**      The selected areas will switch on and those deselected will switch off in forced manner in the exact defined configuration.  
*Example: it is the most used one and it is so that Users may set the switching on state of the areas by selecting scenarios independently of the previous configuration.*  
**GOING OUT** ### ; time, night time and perimetral areas are on;  
**GOING TO BED** #-# ; only day time and perimetral set to on and night time set to off;  
**STAYING HOME** --# ; only the perimetral set to on.

**SWITCH ON SELECT AREAS**      Only the selected areas switch on, nothing changes about the status of the non selected areas.  
*Example: used for specifically switching on areas; for example a scenario that only inserts the perimetral areas (EXCHANGE PERIMETER --#).*

**SWITCH OFF SELECT.AREAS**      Only the selected areas switch off, nothing changes about the status of the non selected areas.  
*Example: used for specifically switching off areas; for example a scenario that only switches off the perimetral area (EXCHANGE PERIMETER --#).*

**EXCHANGES SEL AREAS**      The selected areas change status: if on the switch off and if off they switch on.  
*Example: used for joining into one scenario the switching on or off actions of some areas; for example a scenario that only switches on/off the perimetral area (EXCHANGE PERIMETER --#).*

**Output action and output association:** (Default: DISABLED)

If activated, it lets command an output from a scenario. Select the output to command in the ASSOC. OUTPUT.

**DISABLE**      The scenario does not command any output.  
*Example: scenario deactivated or scenario of which you want to only manage the areas.*

**ON**      The scenario activates the selected output.  
*Example: scenario which lets you open a lock commanded from a timed output. Or a scenario that switches on a light commanded by a stable-type output.*

**OFF**      The scenario deactivates the selected output.  
*Example: scenario that lets you switch off a light commanded by a stable output.*

**EXCHANGE**      The scenario exchanges the status of the selected output (if on it becomes off, if off it becomes on).  
*Example: scenario that joins the on and off commands of a light commanded by a stable output.*


**Scenario description:**

For editing the scenario description.


p. 8 - Technical Manual code 24805690/30-11-2012-319F82C ver 1.0 - The data and information in this manual may be changed at any time with no obligation on BRAHMS part to notify anyone of this.



## 2.4 Areas



## 2.5 Keypads





## 2.7 Inputs module

MODULES INPUTS 07

- EDIT INS MOD 01  
8 IN LOC MOD
- EDIT INS MOD 02  
8IN 01 REM MOD

**Module description:** For editing the module description. The module with index 1 is the control unit expansion, from the address 2 in then the input expansion modules on bus.

## 2.8 Outputs modules

MODULES OUTPUTS 08

- EDIT.MOD.OUT. 01  
MOD.REM.8OUT 01

**Module description:** For editing the module description.

## 2.9 Radio Modules

MODULES RADIO 09

- RADIO MODULES
  - EDIT RAD 01 MOD  
REMO RADIO 01
- JAMMING
  - JAMMING NO

**Module description:** For editing the module description.

**Jamming:** (Default: NO) Activating the JAMMING anti-screening, in case of systematic or permanent transmission disturbances, the control unit will trigger a 24 hour alarm notification.

## 2.10 Inputs

**Status:** (Default: EXCLUDED) F S A

EXCLUDED Inputs are excluded when they are unused.

INSERTED Inputs are inserted when they are used in the system.

TEST An input is a test when you want to monitor the behaviour of an input via the events log without triggering any alarms nor telephone calls.

*Example: following installation of a system the input continues to revert to alarm without any apparent reason. By placing it into test mode you can continue to monitor any alarms (though the events log) without generating any alarms.*

---

**Type:** (Default: IMMEDIATE) F S A

The type defines the input's functional characteristics.

IMMEDIATE This is a classic intruder-proof input, active when the control unit is up and inactive when the control unit is off. If unbalanced it triggers a general alarm.

*Example: Installing a magnetic radio contact onto a window.*

SERVICE It is active with control unit engaged or disengaged . It is not registered as an an alarm input, but only to be monitored via key pad or to activate outputs of calls regardless of control unit status. It is recorded in the event log.

BLCK PRG. IN. If closed, it enables the time schedule function, excluding it if open.

FAULT It remains enabled with control unit engaged and disengaged. The Fault Led light up for any malfunctions and breakdown output is enabled. The system displays the ANOMALY message followed by the input description.

DELAYED 01 It is active only when the control unit is on. If unbalanced, it triggers entrance time 1, during which a valid code must be entered to disengage the control unit. During this time the buzzer will sound continuously. If the control unit is not disengaged the general alarm will be triggered.

*Example: input associated with an input port.*

DELAYED 02 As DELAYED 1, but with entrance time 2.

24 HRS This instantaneous input is active either when the control unit is on or off. Unbalancing a 24 hour input triggers a general alarm.

*Example: input associated with external siren tamper.*

TECHNIC This instantaneous input is active either when the control unit is on or off. Unbalancing a technical input activates the TECHNICAL ALARM-defined output, sounding a continuous buzz (for the duration of the technical alarm) and the switching on of the alarm LED-light on the keypads.

*Example: an input associated with a fire or gas detection sensor.*

PATH Instantaneous input with control unit on. It performs like a delayed input if a control unit DELAYED input triggers the entrance time. And performs like an instantaneous input in all other situations.

*Example: input associated with an infrared detector placed in front of a delayed-type input. If users open the door, this triggers the entrance time and the detector also performs in the same way; whereas if an intruder break in through a window, the sensor performs instantaneously.*

**MEMORY**

Input active when control unit is on. If it is closed (i.e. balanced) once the entrance time elapses, it performs like a normal instantaneous input. Otherwise, if once the exit time is elapsed it is still open (i.e. unbalanced), it will be ignored until it is closed (i.e. balanced) and from that moment it behaves like a normal instantaneous input.

*Example: the memory inputs are defined as the memory inputs that the User wishes to leave open (dormer window, windows, ...) even when the system is engaged.*

**SWITCHING ON**

This input is used to switch on/off any areas associated to the input. The input's performance is defined by the action parameter. Total system switching off or partialisation via a SWITCHING ON input, simulates the entering of a code which blocks the telephone calls (if the parameter is programmed to STOP FROM CODE in the TELEPHONE OPTIONS).

ACTION	DESCRIPTION
Impulsive switching on	When input is unbalanced the associated areas switch on.
Impulsive switching off	When input is unbalanced the associated areas switch off.
Impulsive switching on+ off	When input is unbalanced the associated areas exchange status: when off they switch on and when on they switch off.
Stable switching on + off	When input is unbalanced the associated areas switch on and when balanced they switch off.

*Example: if switching on and off must be managed via a mechanical key, it is necessary to have a mechanical lock with C, NC and NO contacts.*


*Input programmed to be type SWITCHING ON, action STABLE SWITCH ON + SWITCH OFF and associated areas the areas to switch on/off.*

*Connect the input to the lock so that when the key is on "system on" the input is unbalanced (i.e. open) and when it is on "system off" the input is balanced (i.e. closed).*

**BURGLARY**

This instantaneous input is active either when the control unit is on or off. When unbalanced it does not triggers the keypad alarm LED lights to switch on and the alarm telephone call/s to numbers associated to the BURGLARY ALARM.

TYPE	Engaged status		Alarm relay	Telephone calls					Keypads/inserters			Times					
	Associated areas on	Always		Alarm	Sabotage	Technical	Burglary	Out of order	Led alarm	Faulty Led	Buzzer	Alarm	Sabotage	Technical	Burglary	Entrance 1	Entrance 2
Instantaneous	X		X	X					X		X	X					
PRG Lock-up																	
Service		X		X			X		X								
Out of order		X															
Delayed 1	X		X	X					X		X	X				X	
Delayed 2	X		X	X					X		X	X					X
24 hours		X	X		X				X		X		X				
Technical		X				X			X		X		X				
Path	X		X	X					X		X	X				X	X
Memory	X		X	X					X		X	X					
Switching on		X															
Burglary		X					X							X			
Tamper		X	X		X				X		X		X				




**Instantaneous:** (Default: **NEVER** ) E S A


Parameter viewable only if the input is a delayed one.  
 For managing the delayed input as instantaneous if partialised (that is, if associated to several areas and not all of them are switched on).


**NEVER** Standard setting, the input is always delayed.  
*Example: overhead garage door.*


**IF PARTIAL. ON** The input is delayed if all of the associated areas are switched on and is delayed if partialised (at least one area switched off and one switched on).  
*Example: this parameter is set when it is necessary for the door to be delayed-type when the User is not at home, and is instant when at home (partialised system).*  
*Area 1: Day time zone.*  
*Area 2: Night time zone.*  
*Area 3: perimetral.*  
*Scenario 1: Going out; Areas ###.*  
*Scenario 2: Going to bed; Areas #-#.*  
*Front door entrance: Instantaneous **DELAYED 1**; Type **IF PARTIAL. ON**.*  
*And / or areas: **INS. IF AREAS OR**; Areas -##.*





**Balancing:** (Default: **SINGLE BAL** ) E S A

**NORM.CLS** Input normally closed.  


**NORM.OPN** Input normally open.  


**SINGLE BAL** Single balanced input.  


**DOUBLE BAL.** Double balanced input.  


**SHUTTERS**  
**VIBRATION** Shutter and vibration input. When one of these types of inputs the **IMPULS.NUM** and **IMPULS.INTERV.** parameters are viewed.  


RADIO CHANNEL XXX  
[1..03]NUMBER 03

**Radio channel** (Default: ): E S A  
 Only available for multi-channel radio inputs (devices with several inputs), it lets you define which of the device's inputs will be associated to the input.  
**Example:** the radio magnetic contact has 3 channels:  
 1. Input 1.  
 2. Input 2.  
 3. Magnetic contact.

LEARN 001  
\*=OK #=ESC

**Radio device learning:** E S A  
 Only available for radio inputs, for associating a radio device to an input.

SUPERVISION 001  
NO

**Radio supervision** (Default: ): E S A  
 Only available for radio inputs, if activated in case of no operating-status signal reception for a period longer than that set in the SUPERVISION TIME, the control unit sends a technical alarm warning (no tamper).

IMPULS NUM 001  
[1..15] NUMBER 03

Parameters viewable only is the outputs is of the shutter or inertial-type.  
**Number of impulses:** (Default: ) S A  
 For setting the number of impulses to have within the  time to generate the alarm.

IMPUL.001 INTERV.  
[1..255] SEC 03

**Impulse interval:** (Default: ) S A  
 For setting the time interval within which if you have a number of impulses  the alarm is generated.  
**Example:** if on a shutter input you set 3 impulses and a 10-second interval, you can have both cases:  
 • Trigger alarm when at least 3 impulses within 10 seconds are manifested.  
 • No alarm is generated if there are 3 impulses in more than 10 seconds.

AREAS 001  
#-----


**Associated areas:** (Default: ) E S A  
 The inputs can be freely associated to one or more areas. The behaviour of an input which is associated to several areas depends on the value selected for the parameter .

AND/OR AREAS 001  
INS. IF AREAS OR

**And / or areas:** (Default: ) S A  
 If you associate several areas to an input the input's insertion status which is given by the switched on/off status of the associated areas depends on this parameter:  
 Input inserted if at least one associated area is switched on.  
**Example:** used when you wish to manage partialisations along with the areas that share several inputs.  
 Input inserted if all of the associated areas are switched on.  
**Example:** if there are two apartments that both share the same garage, usually two areas are associated to the garage (one for each apartment) and the AND function is enabled.







**And input:** (Default: ) | | A

An input, which is programmed in AND with another input, will alarm trigger only if the second one is in alarm state. This parameter is normally used to have a double consensus function to generate the alarm (via the x   Instantaneous you can set this input).

*Example: two sensors point to the same room and the user wants an alarm to be issued when both sensors go into alarm mode.*

INPUT 1 Type  ; And input  .  
 INPUT 2 Type  ; And input  .

**Auto exclude input:** (Default: ) | | S A

It defines the number of times that the input can switch to alarm, beyond which said input is automatically excluded. The alarm counter resets and the input re-includes itself if at least one of the associated areas switches off.

*Example: A traditional example are outside detectors.*

**Buzzer output:** (Default: ) | | S A

For choosing whether the input will activate the “buzzer output” or not, or the keypads activated to sound along with the buzzer output. Always active independent from the statuses of the associated areas.

*Example door open bell: a typical use of this function is to make the key pad sound after a shop door is opened.*

Area 1: indoors.  
 Area 2: perimetral.  
 Keypad 1: positioned loose to sound; Associated areas  .  
 Front door entrance: Buzzer output:  ;Associated areas  .  
 Keypad buzzer output:  .  
 Perimetral area buzzer time  seconds.

**Associating output:** (Default: ) | | S A

Assign the output to activate if the input is unbalanced. If the commanded output is stable, when the input unbalances the output activates, if it balances the output deactivates. If the output is impulsive, it activates and starts the timer when the input unbalances.

Depending on the  parameter, managing the output may be linked to the input’s inserted status.

**Output command:** (Default: ) | | S A

According to this parameter, managing the exit may be linked to the input’s inserted status.

     The output is always commanded by the input status. More precisely: the output is activated if the input is unbalanced and restored if the input is balanced.

     If the input is active, meaning one or more areas associated to it are inserted, the output is commanded by the input’s status. More precisely: the output is activated if the input is unbalanced and restored if the input is balanced.

     If the input is deactivated, meaning no area associated to it is inserted, the output is commanded by the input’s status. More precisely: the output is activated if the input is unbalanced and restored if the input is balanced.



ON ACTION 001  
PULSE ON+OFF



PULSE SWITCH ON

The control unit switches on the areas when the input is unbalanced.

PULSE SWITCH OFF

The control unit switches off the areas when the input is unbalanced.

PULSE ON+OFF

When the input is unbalanced the control unit inverts the the switch on status of the areas associated to the input.

STABLE ON+OFF

The switching on status of the areas associated to the input follows the input's balancing status. If the input is unbalanced the areas are switched on, if the input is balanced, the areas are switched off.

*Example: see the example shown on the type of input defined SWITCHING ON.*

F S A

DESCRIPTION 001  
INPUT 001




**Input description:**

For editing the input description.

F S A

## 2.11 Outputs



**Stato:** (Default: ) [ ] [ S ] [ A ]

**STABLE**

the output's activity follows the status of the associated event.  
*Example: the output is activated by the OPEN condition of the associated input.*

**IMPULSIVE**

the output's activity is determined by the associated event but not only for a certain time, the duration of which is selectable.

Parameter viewable only if the output is an impulsive one.

**Activation duration:** (Default: ) [ ] [ S ] [ A ]

Duration time of the impulsive output activation.

*Example: via a code you wish to open a door lock. An impulsive output is associated to a code, with a 3-second activation time.*

Parameters viewable only if the output is a stable one.

**Activation delay:** (Default: ) [ ] [ S ] [ A ]

Delayed time between the activation command and the output's activation.

**Deactivation delay:** (Default: ) [ ] [ S ] [ A ]


Delayed time between the deactivation command and the output's deactivation.

*Example: through an output you wish to view the switched on status of the system (switched on or off). In the outputs Association menu, assign the switching on status of the areas with one stable programmed output and zero second delay on activation and deactivation times.*


SECURITY 001 NEGATIVE	<p><b>Security:</b> (Default: <input type="text" value="NEGATIVE"/>) <span style="float:right">[ ] [S] [A]</span></p> <p><input type="text" value="NEGATIVE"/> The output is normally deactivated and is activated when it is commanded.  <i>Example:</i> By connecting a relay to NEGATIVE open collector output, the relay will be normally not-excited, but will excite when the output is activated.</p> <p><input type="text" value="POSITIVE"/> The output is normally active and is deactivated when it is commanded.  <i>Example:</i> By connecting a relay to POSITIVE open collector output, the relay will be normally not-excited, but will excite when the output is activated.</p>
ACT REMOTE 001 NO	<p><b>Activating from remote:</b> (Default: <input type="text" value="NO"/>) <span style="float:right">[ ] [S] [A]</span></p> <p>if activated (YES) it lets you remotely activate the output via voice guide or sms or...  <i>Example:</i> via SMS you wish to activate an impulsive-type output to give a start command for the heating.                  Code 1: password <input type="text" value="123456"/> ; telecontrol <input type="text" value="YES"/>.                  Output 2: <input type="text" value="IMPULSIVE"/> type; activating from remote <input type="text" value="YES"/>.                  Telephone options: telecontrol from SMS <input type="text" value="YES"/>.                  SMS to send: activate heating.CRSMS.123456.6002.</p>
OUT. 001 FOLLOWS NO	<p><b>Follows output:</b> (Default: <input type="text" value="NO"/>) <span style="float:right">[ ] [S] [A]</span></p> <p>For binding the activation status of one output as a function of another output.  <i>Example:</i> you wish to have two outputs on the general bus alarm.                  Output 10: <input type="text" value="STABLE"/> type                  Output 10: <input type="text" value="STABLE"/> type; follows output <input type="text" value="OUTPUT 10"/>.                  In the outputs Association menu, assign general alarm status of the <input type="text" value="OUTPUT 10"/> areas.</p>
DESCRIPTION 001 OUTPUT 01	<p><b>Output description:</b> <span style="float:right">[ ] [S] [A]</span></p> <p>For editing the output description.</p>

## 2.12Times


TIMES 12	<p><b>Autotest interval:</b> (Default: <input type="text" value="000"/>) <span style="float:right">[ ] [S] [A]</span></p> <p>It determines every how many hours the control unit should automatically perform a functional test. The first auto-test after switching on the control unit is done after the time defined by AUTOTEST INTERVAL.                  If the value is set to 000, the autotest is not performed.  <i>Example:</i> function is generally used by security firms as system survival.                  Telephone 15: security firm number; format <input type="text" value="CONTACT-ID"/>; system code <input type="text" value="XXXX"/>.                  Autotest interval <input type="text" value="24"/> hours.                  In telephone notifications: telephones for autotest notifications <input type="text" value="-----#-"/>.</p>
INTERV. AUTO TEST [0..255] HOURS 000	
INT.RADIO SUPERV. [0..255] HOURS 001	<p><b>Supervision time:</b> (default: <input type="text" value="001"/>)</p> <p>It determines after how long, with no auto-test reception by one or more devices, an anomaly will be notified.                  Non reception triggers a technical alarm.</p>



## 2.13 Telephone notifications













## 2.15 Codes






## 2.16 Keys



## 2.17 Telephones



**Telephone number:** [F] [S] [A]

Edit telephone number. Pressed the [\*] key, with the number key you write the numbers and with the [\*] key confirm and cancel with the [#] key. To deactivate the number just cancel it completely.

Besides the numbers you can also enter the letters C (PBX) and P (ppause when dialling), which are respectively used for the following functions:

C In case of GSM calls, all numbers prior to C will not be dialled  
 P to insert a pause during the dialling

The C and P are respectively selected using the [C] and [P] keys.

To insert a telephone number select the number to insert, press [\*] and insert the figures. Then finish with the [\*] key.

*Example: PSTN line connected to a pbx with possibility to make GSM calls.*

0 C 0 4 5 6 7 8 9 0 1 2

| | \_\_\_\_\_ Telephone number  
 | | \_\_\_\_\_ Means the pbx is on line  
 | \_\_\_\_\_ Number to request the line from the pbx

**Format of the telephone communication:** (Default: see table at beginning)

VOICE The telephone communications will be of the voice type.

SMS The telephone communications will be of the SMS type.

CONTACT-ID The telephone communications will be of the CONTACT-ID digital type.

*Example: notification to security firms.* [F] [S] [A]

**System code:** [ ] [ ] [A]

Used in CONTACT-ID format communications and defines the system code.

**Call attempts:** (Default: 02) [F] [S] [A]

Used in VOCAL and CONTACT-ID communication formats. It defines the number of telephone call attempts to the number. To interrupt press either 0 or 5 on the telephones keypad.

**Common message:** (Default: MESSAGE 01) [ ] [S] [A]

A voice message can be associated to each telephone number, which is then sent with each voice call.


*Example: you have 2 telephone numbers to which to send the system alarm status. For both, the home street number must be quickly given.*

Telephone 1: VOCAL format; Common msg: MESSAGE 01.

Telephone 2: VOCAL format; Common msg: MESSAGE 01.

Telephone notifications: Act.Sys.Alarm ##-----.

*Common message: The Rossi's residence 21 National Ave., Milan (automatic recording on PC software).*



**Listen to Telephone Line:** [F] [S] [A]

Activate/Deactivate Listen to Telephone Line

**Telephone description:** [F] [S] [A]

For editing the telephone description.





## 2.19 Special functions

FUNCTIONS 19  
SPECIAL

DISPLAY KEYPADS  
STATUS OF AREAS

PRINTER OUTPUT  
ACTIVATED

POWER ON CNTR U.  
PREVIOUS STATE

QUICK SWITCH ON  
DEACTIVATED

SEE AREA STATUS  
[0..30] SEC 000

KEYP BUZZ OUTPUT  
-----

PRE ENTER TEST  
DISARMED

**Display keypads:** (Default: **STATUS OF AREAS**) F S A


The keypads are made up of two 16-character lines. The date appears in the first, and in the second you can choose to view among the following information:

<b>KEYPAD NAME</b>	Keypad name.
<b>STATUS OF AREAS</b>	Switched on status of the single areas.
<b>SYSTEM STATUS</b>	System switched on status: OFF, COMPLETELY ON, PARTIALISED.
<b>ENTER CODE</b>	ENTER CODE fixed message.

**Printer output activated:** (Default: **ACTIVATED**) A

For activating the printer output for the continuous print outs of events on the RS-232. The serial setting is: Bits per second 9600; Data bits 8; Parity N; Bit stop 1.

*Example: connect the control unit to the PC via a direct rs-232 (male-female) cable. Open a reception programme from serial (Hyper Terminal for example) and set la porta COMand the serial.*



**Control unit switched on status after powering up the system (restarting it):** A

(Default: **PREVIOUS STATE**)

<b>TOTAL START UP</b>	All of the areas switch on.
<b>COMPLETELY OFF</b>	All of the areas switch off.
<b>PREVIOUS STATE</b>	The switching on status of the areas returns to that before the power off was given.

**Quick switch on:** (Default: **DEACTIVATED**) A

If activated it lets you start scenarios from the keypads without having to enter a code.

*Warning! When activated, prevents exclusion of open inputs during the start up phase.*

**Screening the status of the control unit from keypads and inserters:** A

(Default: **00**)

If switching on / off state of the areas is set to greater than 0, it is (hidden) after a preset amount of time.

**Buzzer on keypad output:** (Default: **-----**) A

If you activate the inputs to have buzzer properties, you can select the keypads that have to sound during the buzzer time. *Example: shop front door bell.*

**Pre-insertion Test:**(Default: **DISARMED**) F S A

**PRE-INSERTION TEST ACTIVATED:** the system can be forced activated when the system is activated and one of the following anomalies is present. The breakdown led blinks and the anomaly is stored in the event log. If this operation is performed by inserter, the same shall emit a beep and cancel the insertion.

*Breakdown messages:*

- BUS TAMPER: if one of the elements connected to the bus RS485 fails to communicate;
- BOX TAMPER: if a control unit or inserter tamper is in alarm mode;
- ANOMALY/BREAKDOWN: if one of the inputs defined as BREAKDOWN is open;
- INPUT TAMPER: if an input is in tamper mode;
- NO PSTN LINE: if line was activated but missing;
- NO GSM LINE: if line was activated but not registered;
- NO NETWORK: no network power available;
- BATTERY BREAKDOWN: if the control unit battery is down;
- FUSE BREAKDOWN: if fuses are out of order.

p. 32 - Technical Manual code 24805690/30-11-2012 319F82C ver 1.0 - The data and information in this manual may be changed at any time with no obligation on BRAHMS part to notify anyone of this.



**Description of assistance and company:** (Default: ) F S A  
 Here you can enter the name of the installing firm that will appear on the user menu below the INFO item.

## 2.20 Programmer

The control unit features a weekly scheduler plus 30 programmable holidays. For each day of the week and each holiday you can select one among the 8 available programmes. Each programme features 20 steps. Each step can have the starting HOUR and ACTION to carry out set. Each programmed step will be automatically carried out by the control unit ONLY WHEN IT COINCIDES WITH THE SET TIME (HOURS AND MINUTES). If for any reason a step programmed for a specific time is not carried out, this step will no longer be carried out within the same day. There is no need to follow an increasing time sequence when setting the steps.

**IMPORTANT:** it is vital to pay careful attention in choosing the action to be automatically carried out by the steps because, if wrongly programmed, they can generate unwanted results in the control unit.

PROGRAMMER 20

PROGRAMME A  
\* = EDIT # = ESC

PROG. STEP 01  
\* = NEW # = ESC

PROG. STEP 01  
HOURS:00

PROG. STEP 01  
MINUTES:00

PROG. STEP 01  
ACTION:NONE

PROG. STEP 01  
ADDRESS:---

PROG. STEP 01  
STATUS:OFF

PROG. STEP 01  
EXTENS.:NO

**Programme step:** (Default: ) F S A  
 To activate/edit a programme step press  and set the action.  
 To disable a programme step press  and set the action to  .

The programme step is deactivated.

The programme step is activated with the following programming:  
 HH:mm: hour and minutes;  
 A: action;  
 III: address;  
 S: status;  
 P: extension;

To see the meaning of the values, see the table below.  
**Example:** if you have programming step that activates output 3 at 08.30 hours, this will appear:  
  
 Hour: 08; Minutes: 30; Action: 2; Address: 3; Status: ON; Extension: NO.

**Hour and minutes:** (Default: ) F S A  
 For setting the hour and minute of the programme step action.

**Action, address and status:** (Default: ) F S A  
 Depending on how the action is set, the address and status change meaning:

ACTION	ADDRESS	STATUS
0 = <input type="text" value="NONE"/>	--	--
1 = <input type="text" value="CONT. UNIT"/>	--	0 = <input type="text" value="OFF"/> = total switching off 1 = <input type="text" value="ON"/> = total switching on
2 = <input type="text" value="OUTPUT"/>	Output index	0 = <input type="text" value="OFF"/> = output off 1 = <input type="text" value="ON"/> = output on
3 = <input type="text" value="AREA"/>	Area index	0 = <input type="text" value="OFF"/> = switching off 1 = <input type="text" value="ON"/> = switching on
4 = <input type="text" value="B. CODES"/>	Code group	0 = <input type="text" value="OFF"/> = release codes 1 = <input type="text" value="ON"/> = block codes

**Example:** if you want to activate output 3 at 08:30 you need to set:  
 Action: 2; Address: 3; Status: ON; Lengthening: NO; Hour: 08; Minutes: 30.

**Extension:** (Default: ) F S A  
 By activating the extension of a programme step you can postpone the action from the user menu.

**Example:** if you want to be able to postpone the switching on of the system programmed for 19:30, do the following settings:  
 Action: 1; Address: non influential; Status: 1; Extension: YES; Hour: 19; Minutes: 30.

**!** Exit time will be activated if a scheduler inserts into the system. An alarm will be generated independent of the Force Area parameter if outputs are open at the end of the exit time.

## 2.21 Scheduler calendar

**Weekly calendar:** [ ] [ ] [A]  
 You can associate one of the available programmes to each day of the week.  
 If a day of the week is the same as a holiday set on **HOLIDAY CALENDAR**, the programme executed on that day will be the holiday one.

**Day of the week programme:** (Default: [A]) [ ] [ ] [A]  
 Use the arrow to select the weekday and the [ ] [ ] keys to set the programme.  
 To deactivate the execution of programme, with [ ] [ ] select the programme [ ].

**Holiday calendar:** [ ] [ ] [A]  
 Up to 32 holidays can be associated to one of the available programmes.  
 Executing the holiday programme has priority status over that set **WEEKLY** **CALENDAR**.


**Month, day, schedule of holidays:** (Default: [00/00 PROG. -]) [ ] [ ] [A]  
 For setting the holiday's month and day and programme.  
 To deactivate a holiday set the month to 0 and day to 0.  
 ⚠ If you set an non existant day (for example 31/02, the programme will not be carried out and no error notification will be given).  
**Example:** if you want to set the programme to 31/12, do the following:  
 Month: 12; Day: 31; Programme: 3.

## 2.22 Events

**Event menu:** [F] [S] [A]  
 For viewing events as in the user menu. See user's manual for event viewing.


**Event printout:** [ ] [ ] [A]  
 Press [ ] to start print out of events on control unit RS-232.

## 2.23 Clock



If internal clock is not initialised, the key pad displays the message "INITIALISE DATE AND TIME" and the breakdown Led is on. Once the clock has been initialised, the Led switches off and the message will be cleared from the key pad.


## 2.24 Default parameters



PARAMETERS 24  
DEFAULT


DEFAULT PARAMET.?  
A=YES #=ESC

**Default parameters:**  
Press **A** to execute the default parameters.

 The default parameters do not erase the codes and keys you purchased.

**F S A**

## 2.25 Control unit version



CONTROL UNIT 25  
VERSION

VERSION  
PROXINET36 1.0.X

**Control unit version:**  
To know the model and version of the control unit in use

**F S A**

### 3 Events messaging

The events are composed by:

- TIME and DATE
- EVENT DESCRIPTION ( activation / restoring )
- EVENT INDEX
- EVENT DESCRIPTION (part 2)

ACTIVATION	RESTORE	DESCRIPTION 2	CAUSE	Telephone notifications group										
				Alarm	Sabotage	Technical	Burglary	Switching on	Out of order	Code	Key	Input	Various	
SWITCHING ON		TOTAL AREAS SWITCHED-ON	We have a switching on event when there are only switching on actions (total or partial). If switching on all of the areas managed by the control unit, the second description will read TOTAL, whereas partial switching on will indicated the switched on areas (example ##--#).					X						
PARTIALISAT		AREAS SWITCHED-ON	The partialisation even takes place when we have non-total area switching off actions (partial switching off). The second description will show the switched on or of status of the remaining areas (example ##--#).					X						
SWITCHING OFF			The switching off event takes place when the system is totally switched off.					X						
TAMPER ALRM xx	REP TAMPER xx	CONTROL UNIT DESCR.PWR SUPP	Control unit or auxiliary power supply unit opening or ripping tampering detected Check physical state and tamper.		X									
INPUT TAMPER ALARM xxx	REP INP xxx TAMP	DESCR. INPUT	Input xxx has been tampered with (either cut or short-circuited depending on its balancing), check continuity along the input's electrical line. If it has restored (by itself) anyhow check the input's electric line because there may some faulty connections.		X									
AREA ALARM xx	REP AREA xx ALRM	DESCR.AREA	When an input is in alarm state the associated areas will be too.	X										
INPUT ALRM xxx	RESTOR INP xxx	DESCR. INPUT	Input xxx is in alarm (in unbalanced state).										X	
KEYP.COM.ERR. xxx		DESCR. INPUT	Radio input xxx battery is run down. Replace asap.						X					
ERR.COM.TAST. xx		DESCR.KEYPAD	The xx keypad is no longer communicating with the control unit (read warning led on keypad is flashing). Check activation of keypad, bus cable and address.		X									
ERR. xx IN MODE		DESCR. MODULE	The inputs expansion module on bus xx no longer communicates with the control unit (the red led communication light is not flashing). Check activation of module, bus cable and dip switch address.		X									
ERR. xx OUT MOD		DESCR. MODULE	The outputs expansion module on bus xx no longer communicates with the control unit (the red led communication light is not flashing). Check activation of module, bus cable and dip switch address.		X									
ERR. xx RX MODE		DESCR. MODULE	The radio receiver module on bus xx no longer communicates with the control unit (the red led communication light is not flashing). Check activation of module, bus cable and dip switch address.		X									
JAM. xx MOD RX		DESCR. MODULE	The radio receiver module on bus xx has detected a radio transmission that could shut out any radio transmitters (JAMMING function activated in control unit).		X									
SUPERVIS.TX xxx		DESCR. INPUT	Radio input xxx has transmitted a person-detected communication.											
xx IN MOD TAMP.		DESCR. MODULE	The tamper of the inputs expansion module on the bus xx has been tampered with. Check module tamper.		X									
xx OUT MOD TAMP.		DESCR. MODULE	The tamper of the exits expansion module on the bus xx has been tampered with. Check module tamper.		X									

xx RX MOD TAMP.		DESCR. MODULE	The tamper of the radio receiver of bus xx has been tampered with. Check module tamper.	X															
xx KEYPAD TAMP.		DESCR. KEYPAD	The xx keypad's opening tamper has been tampered with. Check keypad tamper.	X															
TECH MENU OUTPUT			Exiting the technical menu is logged in the events log.																
BATT BREAK. xx	REP BATTERY xx	CONTROL UNIT DESCR. PWR SUPP	Battery breakdown in either control unit or the bus connected auxiliary power supply units									X							
LOCAL CONNECT.			The communication between control unit and PC (uploading - downloading programming and events) is logged in the events log.																
xx NETW. BREAK.	xx NETWORK BACK	CONTROL UNIT DESCR. PWR SUPP	230 Vac power outage of the control unit or of the bus connected auxiliary power supply units.										X						
AUTO TEST			The autotest is normally used to check whether the control unit is up and running via a telephone notification.																X
CODE N. xxx		DESCR. CODE	Entering a code (user or technician's) is logged in the events log.														X		
KEY N. xxx		DESCR. KEY	The action of approaching keys to inserters is logged in the events log.															X	
SYST BREAKDOWN	R. SYST BRK DWN		Generic system breakdown notification. The breakdown can be caused by the batteries, the 230 network, the power supply unit, or fuses).										X						
TECH ALRM ON	REP SYS TECH ALRM		Generic technical alarm event. It is generated with an area technical alarm (if it is not associated to an area's technical input, the system technical alarm is not generated).					X											
GEN SYST ALRM	REP GEN SYS ALRM		The generic general alarm event is generated with either an area alarm or a system tamper alarm.	X	X														
PWR SUPPLY BREAKDOWN xx		CONTROL UNIT DESCR. PWR SUPP	Notification of breakdown of control unit power supply unit - fuses and auxiliary power supply units on bus.										X						
POWER-ON			The event is logged when the control unit is powered up for the first time or it is reset (the re-start button is pressed on the control unit's board).																
24H ALARM ON	"REP 24H SYS"		Generic notification of tamper alarm (sabotage).	X															
24H ALARM xx	REP 24H ALRM xx	DESCR. AREA	When an input is in tamper state also the associated areas go into sabotage alarm mode. All tamper-type events which are not associated to any inputs, automatically trigger a tamper alarm of area 1.					X											
REM. CONT. xx		DES.REMOT.CTRL	Each time you act on the system's remote control, this is logged in the events log.																
REM. CODE N. xxx		DESCR.CODE	Entering a code (e.g. user) from remote (either voice guide or sms) is logged in the events log.															X	
TECH ALARM xx	REP.TECH ALRM xx	DESCR.AREA	When an input goes into alarm mode also the associated areas go into technical alarm mode.					X											
BURG ALARM xx	REP xx BRGLY ALRM	DESCR.AREA	When an input goes into alarm mode also the associated areas go into burglary alarm mode.						X										
COD CLR xxx		DESCR.CODE	Code xxx has been activated from the user menu. The chronologically previous <b>CODE N. xxx</b> event shows who has edited.																
COD RST xxx		DESCR.CODE	Code xxx has been activated from the user menu. The chronologically previous <b>CODE N. xxx</b> event shows who has edited.																
WRONG CODE		DESCR. KEYPAD	21 wrong codes have been inserted from keypads. The description is the one of the last keypad to have an insertion attempt.					X											
WRONG KEY		DESCR. INSERT.	21 invalid keys have approached inserters. The description is the one of the last inserter to have an insertion attempt.					X											

## 4 Reference laws

Below are the standards to bring the system up to code with standard EN 50131:

- The inserter buzzer notifications cannot be deactivated (EN50131-1 8.3.8.2);
- The "24H" and "Technological" inputs must not be used;
- The inputs configured as "Switch on" are compliant only if controlled from devices whose number of combinations exceeds 10000;
- If the system incorporates devices that report breakdowns, these must be connected to the breakdown input;
- The telephone combiner must be active;
- The system must contain a self-powered external siren to signal any intrusion alarms;
- The number of alarms for input auto-exclude must be set between 3 and 10;
- Power supply failure notification time must be set at one minute (1 min);
- Do not activate quick switching on;
- The "Stop Communication" option must not be activated when control unit is switched off;
- Input time 1 and 2 must be set to a maximum of 45 sec. (EN50131-1 8.3.8.2);
- The battery test time must be set above 5 minutes;
- Activate SEE SYSTEM STATUS setting at  $\leq$  than xx seconds;
- Deactivate the function 'QUICK SWITCHING ON'.

## 5 Declaration

CE



**BPT S.p.a a Socio Unico**  
 Head and Registered Office  
 Via Cornia, 1/b – 33079 – Sesto al Reghena (PN) - Italy  
<http://www.bpt.it> – <mailto:info@bpt.it>

Declares under its own responsibility that the following products for security alarm units:

**PROXINET36-PROXINET76-PROXINET192**

... comply with essential requisites and dispositions, given by the following Directives and applicable Regulations listed below.

--- DIRECTIVES---

2006/95/CE	LOW VOLTAGE DIRECTIVE
2004/108/CE	ELECTROMAGNETIC COMPATIBILITY DIRECTIVE
1999/05/EC	DIRECTIVE ON RADIO EQUIPMENT AND TELECOMMUNICATIONS TERMINAL EQUIPMENT AND MUTUAL ACKNOWLEDGEMENT OF THEIR COMPLIANCE TO STANDARDS.
EN 50130-4 + A1 + A2	ALARM SYSTEMS. PART 4: ELECTROMAGNETIC COMPATIBILITY.
EN 60950-1	INFORMATION - SECURITY TECHNOLOGY EQUIPMENT. PART 1: GENERAL REQUIREMENTS.
EN 61000-6-3	ELECTROMAGNETIC COMPATIBILITY (EMC). PART 6-3: GENERAL STANDARDS - EMISSION STANDARD FOR RESIDENTIAL, COMMERCIAL AND LIGHT INDUSTRY ZONES.
ETSI ES 203 021-1	TERMINAL EQUIPMENT (TE); ATTACHMENT REQUIREMENTS FOR PAN-EUROPEAN APPROVAL FOR CONNECTION TO THE ANALOGUE PUBLIC SWITCHED TELEPHONE NETWORKS (PSTNS) OF TE (EXCLUDING TE SUPPORTING THE VOICE TELEPHONY SERVICE) IN WHICH NETWORK ADDRESSING, IF PROVIDED, IS BY MEANS OF DUAL TONE MULTI FREQUENCY (DTMF) SIGNALLING.
EN 300 220-3	ELECTROMAGNETIC COMPATIBILITY AND RADIO SPECTRUM MATTERS (ERM); SHORT RANGE DEVICES (SRD); RADIO EQUIPMENT TO BE USED IN THE 25 MHz TO 1 000 MHz FREQUENCY RANGE WITH POWER LEVELS RANGING UP TO 500 MW; PART 3: HARMONIZED EN COVERING ESSENTIAL REQUIREMENTS UNDER ARTICLE 3.2 OF THE R&TE DIRECTIVE.
EN 301 489-3	ELECTROMAGNETIC COMPATIBILITY AND RADIO SPECTRUM MATTERS (ERM); ELECTROMAGNETIC COMPATIBILITY (EMC) STANDARD FOR RADIO EQUIPMENT AND SERVICES; PART 3: SPECIFIC CONDITIONS FOR SHORT-RANGE DEVICES (SRD) OPERATING ON FREQUENCIES BETWEEN 9 KHz AND 40 GHz.
EN 50130-5	ALARM SYSTEMS PART 5: ENVIRONMENTAL TEST METHODS.
EN 50131-1	ALARMS SYSTEMS - INTRUSION AND BURGLARY ALARM SYSTEMS. GENERAL REQUIREMENTS.
EN 50131-6	ALARMS SYSTEMS - INTRUSION AND BURGLARY ALARM SYSTEMS. PART 6: POWER SUPPLIERS.  COMPLIES WITH THE PRODUCT STANDARD CEI 79-2 SECOND LEVEL.

