

SANMOTION

AC SERVO SYSTEMS

R ***ADVANCED
MODEL***

TYPE S

R ADVANCED MODEL-SETUP

Setup Software

Instruction Manual

SANYO DENKI

Preface

Thank you for selecting our AC Servo Amplifier R ADVANCED MODEL. This User's Manual is a support tool explaining the use and specifications of the Setup Software in order to completely utilize all the functions of the servo amplifier.

- Keep this manual close when you start or adjust the Servo Amplifier so that it can be referred to at any time.
- Refer to the Instruction Manual for the AC Servo Amplifier R ADVANCED MODEL together with the Setup Software manual.

Note: Images of the message windows shown in this user's manual are for reference only and may not match actual windows of the set-up software on the screen.

Contents

1.	System Overview	1-1
1.1	Functions Overview	1-1
1.2	Corresponding devices	1-2
1.3	System Environment	1-2
1.4	Program Installation	1-3
1.5	Uninstall Program.....	1-9
2.	Connect to Servo Amplifier.....	2-1
2.1	Connection for Single Device.....	2-1
2.2	Connection (Multiple Devices)	2-2
3.	Basic Operation	3-1
3.1	Running Setup Software	3-1
1)	Running from Start Menu.....	3-1
2)	Running from Shortcut.....	3-1
3.2	Communication with Servo Amplifier.....	3-2
1)	Communication Setting	3-2
2)	Communication Confirmation	3-3
3)	End Communication	3-4
3.3	Basic Operation for Screen(s)/Window(s).....	3-4
1)	Main window.....	3-4
2)	Start Methods for Function Window	3-5
3)	Window Display Method	3-5
3.4	Project.....	3-7
1)	Project creation	3-7
2)	Project Window	3-7
3)	Project Setting	3-8
4)	Data Files	3-9
5)	Saving the Project	3-10
3.5	Operation Level.....	3-10
1)	Operation Level Selection	3-10
3.6	Password Function	3-11
1)	Password Setting Procedure	3-11
2)	Password Verification Procedure.....	3-12
3.7	Software Version Information	3-12
4.	Parameters	4-1
4.1	Parameter Editing, Function Overview.....	4-1
1)	Function List	4-1
2)	Types of Parameters	4-1
4.2	Parameter Setting	4-2
1)	Starting Parameter Setting	4-2
2)	Setting General and System Parameters	4-3
3)	Setting Motor Parameters.....	4-4
4.3	Parameter Transmission from Servo Amp to File.....	4-8
1)	Operating Procedure	4-8
4.4	Parameter Transmission from File to Servo Amp.....	4-9
1)	Operating Procedure	4-9
4.5	Parameter Verification.....	4-11
1)	Parameter Verification window	4-11
2)	Operating Procedure for Parameter Verification	4-11
3)	Parameter Copy	4-12
4.6	Saving to Backup Memory	4-13
1)	Operating Procedure	4-13
4.7	Restoring from Backup Memory.....	4-14
1)	Operating Procedure	4-14
5.	Monitor	5-1
5.1	Monitor Overview	5-1
1)	Operating Procedure	5-1
5.2	Start Monitoring	5-1
1)	Operating Procedure	5-1
5.3	Selecting Parameter(s) to Monitor	5-2
1)	Operating Procedure	5-2

6.	Alarm	6-1
6.1	Alarm History	6-1
1)	Alarm Histor display.....	6-1
2)	Alarm History Clear	6-2
6.2	Alarm Reset	6-3
7.	Test Operations	7-1
7.1	JOG Operation	7-1
1)	Operating Procedure	7-1
7.2	Positioning Operation.....	7-3
1)	Operating Procedure	7-3
2)	Notice	7-5
7.3	Magnetic Pole Position Presumption	7-5
1)	Operating Procedure	7-5
7.4	Serial Encoder Clear	7-7
1)	Operating Procedure	7-7
8.	Automatic Tuning	8-1
8.1	Automatic Notch Filter Tuning	8-1
1)	Operating Procedure	8-1
8.2	Automatic FF Vibration Suppression Frequency Tuning	8-3
1)	Operating Procedure	8-3
8.3	Save Result of Automatic Tuning	8-5
1)	Operating Procedure	8-5
9.	Adjustment.....	9-1
9.1	Automatic Offset Adjustment of V-REF Terminal	9-1
1)	Operating Procedure	9-1
9.2	Automatic Offset Adjustment of T-COMP Terminal.....	9-2
9.3	Manual Offset Adjustment of V-REF Terminal	9-2
1)	Operating Procedure	9-2
9.4	Manual Offset Adjustment of T-COMP Terminal.....	9-3
10.	Measurement	10-1
10.1	Operation Trace.....	10-1
1)	Operating Procedure	10-1
10.2	Operation Scrolling.....	10-7
1)	Operating Procedure	10-7
10.3	System analysis	10-9
1)	Operating Procedure	10-9
11.	Troubleshooting	11-1
11.1	Upon Installation.....	11-1
11.2	Wiring, Connection and Communication Status check	11-2
11.3	Parameter Setting	11-3
1)	Parameter Verification	11-3
2)	Parameter Transmission (To Amplifier).....	11-3
11.4	Support Functions	11-3
1)	Monitor	11-3
2)	Alarm.....	11-3
3)	Test Operation	11-4
4)	Automatic Tuning.....	11-4
5)	Adjustments.....	11-5
6)	Measurement	11-5
12.	Appendix	12-1
12.1	Wiring	12-1
1)	Servo Amplifier Connectors	12-1
2)	Connecting Cable A.....	12-2
3)	Connecting Cable B.....	12-3
4)	Network terminator	12-3
5)	Communication Converter	12-4

Reference Material

- Instruction Manual for Servo Amplifier R ADVANCED MODEL: M0008424

No Text on This Page.

1. System Overview

1.1 Functions Overview

R ADVANCED MODEL Setup Software (Setup Software hereafter) performs the following functions when connecting with the R ADVANCED MODEL Servo Amplifier (Servo Amp hereafter).

Table 1-1 Function List

No	Function		Explanation
1	Parameters	Parameter Setting	Edit each parameter of Servo Amp
		Parameter Transmission (Servo Amp to File)	Save the parameter values of Servo Amp in file
		Parameter transmission (File to Servo Amp)	Transmit values of parameter file to Servo Amp
		Parameter Verification	Verify parameter in parameter file with Servo Amp
		Save to Backup Memory*	Back up parameters in Backup memory built into Servo Amp
		Restore from Backup memory*	Restore parameters of Servo Amp with the values of Backup memory
2	Monitor		Monitor Servo Amp status
3	Alarm	Display alarm history	Displays the present and past seven (7) Alarm Histories
		Alarm Reset	Releases Alarm
4	Test Operation	JOG Operation*	Performs JOG Operation
		Positioning Operation	Performs Positioning Operation
		Serial Encoder Clear	Clears multi-turn data and the status of the motor serial encoder
		Magnetic Pole Position Presumption	Presumes the magnetic pole position of the linear motor
5	Automatic Tuning	Auto Notch Filter Tuning*	Detects the resonance frequency of mechanical devices and sets up the torque command notch filter automatically
		Auto FF Vibration Suppression Frequency Tuning	Detects the anti-resonance frequency of mechanical devices and sets the FF Vibration Suppression Frequency automatically
		Save Results of Auto Tuning	Saves proper gain calculated by the Auto tuning function of the Servo Amp as the parameter
6	Adjustment	Auto Offset Adjustment of V-REF Terminal	Adjusts the offset of Analog velocity/torque(force) command automatically
		Auto Offset Adjustment of T-COMP Terminal	Adjusts the offset of the Analog torque(force) compensation command automatically
		Manual Offset Adjustment of V-REF Terminal	Adjusts the offset of Analog velocity/torque(force) command manually
		Manual Offset Adjustment of T-COMP Terminal*	Adjusts the offset of the Analog torque(force) compensation command manually
7	Measurement	Trace Operation++	Displays the status of the Servo Amp in waveform
		System Analysis*++	Analyzes the characteristics of mechanical devices, such as frequency response, etc.
		Operation Scrolling	Displays multiple axes of the Servo Amp in waveform

- ✓ Some functions may not be used depending on the specifications of the Servo Amplifier.
- ✓ Functions with the * mark cannot be used together (simultaneously).
- ✓ Functions with the ++ mark cannot be used together (simultaneously).

1.2 Corresponding devices

This Setup Software corresponds to the following Servo Amp:

■ RS2_____*

- ✓ Some functions may be unable to be used depending on the Servo Amp model and/or the combined Servo motor and Encoder. You will not be able to select a menu and/or icon for the non-functioning items.

1.3 System Environment

The following system is required to utilize this Software Setup:

PC	IBM PC/AT Compatible machine
CPU	Minimum:Equivalent to Intel Pentium 600MHz or greater. Recommended:Equivalent to Intel Pentium 800MHz or greater. When executing Operation scrolling, a selection with additional reserve space is necessary.
Memory	128MB(More than 256MB is recommended)
Hard disk free space	400MB or greater (including Microsoft .NET Framework 2.0)
Display	Greater than 800x600, Colors: 256 colors or greater
Corresponding OS	Windows® 98/SE, Windows Me, Windows® 2000 Service Pack4 Windows® XP Service Pack2 or newer Windows® Vista Windows® 7 32bit/64bit
Necessary Software	Microsoft Internet Explorer 6.0 Service Pack 1
Other	A RS-232C connection(COM) port or more


1.4 Program Installation

Installation procedure of Setup Software is as follows:

- (1) Exit all active applications.
- (2) Insert the installation CD into the CD-ROM drive of the PC (name it E: drive)
- (3) From the Start menu on the task bar, select [Specify file name and Run(R)]. Click "Reference (B)" and select [E: Setup.exe]. Click "Open(O)".

After completing the specifying of the file name, click "OK".


The next window will appear and installation will begin.



1-1 Installation Preparation window


An alternate way to start the installation is to double-click [Setup] in the [E:¥] folder after Explorer is run.

- (4) Select the language for installation and click "OK".




1-2 Installation Selection window

- (5) The installer will detect the following modules and perform installation. Click “Install”.
- These required modules will be installed prior to the installation of the application. If these items are installed, then bypass this step.
- ◆ Crystal Reports For .NET Framework 2.0(X86)
 - ◆ Microsoft .NET Framework 2.0




1-3 Crystal Report Installation window




1-4 Microsoft .NET Framework 2.0 Setup Window

- (6) To start installing Setup Software, Click "Next".




1-5 Setup Software installation start window

- (7) This License Agreement window will be displayed. Please read the contents carefully and click "Next" if the terms and conditions are acceptable.




1-6 Software License Agreement

- (8) Select user for installation. Either select All Users or Administrator only and click "Next".




1-7 User Installation selection window

- (9) Specify the destination folder.
If you want to change the installing folder, click "Change" and specify the folder you want.
After completing this option, click "Next".




1-8 Destination folder selection window

- (10) If you use custom motor, input a keyword. If you use a standard product, click “Next” without inputting any keyword.




1-9 Keyword input window

- (11) Click “Install” to begin the installation.




1-10 Installation Confirmation window

(12) This window will appear during installation. Please wait.



1-11 Installation Progress window

(13) Installation has completed. Click "Finish".




1-12 Installation Completed window

1.5 Uninstall Program

Uninstall Setup Software as follows:

- (1) Exit all running applications before proceeding.
- (2) From Start Menu of windows, select the icon [Add/Remove Programs] and the next window appears.



1-13 Uninstall Window

- (3) Select "R ADVANCED MODEL Setup Software" and click "Remove".

✓ When uninstalling this Setup Software, the following applications will not be uninstalled automatically:
✓

- Microsoft .Net Framework 2.0
- Crystal Reports For .Net Framework 2.0 (X86)


No Text on This Page.

2. Connect to Servo Amplifier

2.1 Connection for Single Device

Connect the Servo Amplifier and computer using an exclusive cable. (Optional product: Model # AL-00689703-01)

- Connection to Servo Amp: Use the CN2 connector port on the front of the amplifier.
- Connection to PC: Use the RS232C connection port (Dsub9 pin).



For connector model and wiring, refer to [Chapter 12 Appendix].

Connect to COM port on PC side.


Connect to CN2 port on Servo Amplifier side. Do not connect to CN3.

2.2 Connection (Multiple Devices)

Connect PC and Servo Amplifier using the communication cables listed below, communication converter and final connector (All optional products).

A maximum of 15 Servo Amplifiers can be connected at the same time.

- Communication Converter: SAU-024-01
- Communication Cable A: General RS-232C cable (both straight and cross cable are available)
 - * CN3 of communication convertor (SAU-024-01) is a D-Sub 9pin male connector.
- Communication Cable B: AL-00695974-01 (0.2m)
AL-00695974-02 (3m)
- Network Terminator: AL-00695977-01



Follow the illustration above for CN2 and CN3 connection of Servo Amplifiers.

If you connect them in reverse order, communication will fail.

For accurate communication, connect SW1 to 422A side and set SW2 according to the type of cable (straight or cross) connected to the higher position device.


3. Basic Operation

3.1 Running Setup Software

There are two methods to run the Setup Software.

- Run from Start Menu.
- Run from Shortcut.

After the following image appears, the main window will appear regardless of running method.



3-1 Running window

1) Running from Start Menu

- (1) Click "Start" on the Windows task bar.
- (2) Select [All Programs] to open the programs folder.
- (3) Select [SANYO DENKI] to open the SANYODENKI folder.
- (4) Click "R ADVANCED MODEL-Setup Software".

2) Running from Shortcut


- (1) Double click the "R ADVANCED MODEL-Setup Software" Shortcut on the desktop.




3-2 Icon (Short-cut)

3.2 Communication with Servo Amplifier

1) Communication Setting

Set up the necessary settings from this Communication Setting window to communicate with the Servo Amplifier. The Communication Setting window appears upon running of the Setup Software. This window can also be opened from “Communication” >>> “Communication Setting” on the menu bar of the main window or from the Communication Setting Icon  on the toolbar.



3-3 Communication Setting window

- (A) Axis selection:
Check the correct axis selection box for communicating axis number.

 - (B) COM port selection:
Select COM port of computer to communicate with. COM port can be set up for each axis respectively.


 - (C) Baud Rate selection:
Select Baud rate from Baud rate selection list. Baud rate can be selected for each COM port respectively.

 - (D) Complete Communication Setting:
Communication setting is completed by clicking “Close”.
- ✓ Registered values in the Communication Setting in the New Project are recognized as initial values because the previously registered project values are read automatically when Setup Software is run.

2) Communication Confirmation


Following are the methods of establishing communication with the Servo Amplifier.


- (1) From the Communication Setting window:
 - ◆ Communication begins with a selected axis by clicking “Connect” at the right side of each axis selected.
 - ◆ Communication starts with all axes (checked axes in axis selection boxes) by clicking “On-Line” at the lower left of the window.



3-4 Communication Confirmation window

- ✓ When communication starts normally, a green light appears and amplifier models are displayed.

- (2) From Main Window
 - ◆ Communication starts with all selected axes (axes checked in axis selection boxes on the Communication Setting window) by selecting “Communication” >>> “On-Line” on the menu bar or by clicking the “On-Line” icon  on the toolbar.




3-5 Project window at the time of Communication Confirmation

- ✓ The Axis lamp on the Project window lights green when communication starts normally.

3) End Communication

The following methods are used to terminate communication with the Servo Amplifier.


- (1) From Communication Setting window
 - ◆ Communication with Servo Amplifier on selected axes/axis terminates by clicking “Disconnect” on the right side of each selected axis.
 - ✓ When communication terminates, the light goes off.
- (2) From Main Window
 - ◆ Communication terminates with all Servo Amp axes by selecting "Communication" >>> "Off-Line" on the menu bar or by clicking the "Off-Line" icon  on the toolbar.
 - ✓ When communication is terminated, the Axis light on the Project window goes off.

3.3 Basic Operation for Screen(s)/Window(s)

Setup screens consist of Main window, Project window and Individual Function screens/windows.

1) Main window

Can perform individual Function windows from the displayed function name in the menu (A) and/or the Project window (C) of the Main window.




3-6 Main Window (At the time of Communication On-Line)

- (A) Menu: Select function and perform.
- (B) Toolbar: Select function and perform.
- (C) Project window: Refer to [3.4 Project].

2) Start Methods for Function Window.

Can select from one of two methods to perform individual functions.

- (1) From Menu and Toolbar of Main window
 - ◆ Select the function you need from the Menu or Toolbar of the Main window.
 - ◆ Select an axis from the axis selection list. The function window starts after clicking “OK”.



3-7 Execute Function window


- (2) From Project window
 - ◆ Execute the Function window of the selected axis by double clicking the Function name in the tree of the Project window.

3) Window Display Method

Switches the display method of individual function window(s) between MDI (Multi Document Interface) and SDI (Single Document Interface).

- (1) MDI display


When you want function window to show the MDI display, select “Window” >>> “Window To MDI(M)” on the menu of the main window.



3-8 MDI Window

(2) SDI Display

When you want function window to show the SDI display, select "Window" >>> "Window To SDI(S)" on the menu of the main window.




3-9 SDI Window

3.4 Project


You can manage and save connecting axes values and/or individual data files as a Project.

1) Project creation

- (1) Create a new project.


To create a new project, select "Project" >>> "New(N)" or click the "New" icon  on the toolbar. Then, select the connecting axis of the amplifier on the "Communication Setting" window. Refer to [3.2.1 Communication Setting] for details.

- (2) Use an existing project.

If you use an existing project, select "Project" >>> "Open(O)" on the menu of the Main window or click the "Open" icon  on the toolbar.

2) Project Window

Once the project is created and communication has been established with the Servo Amplifier, axis/axes values, available functions and registered data files will be displayed as a tree.




3-10 Project Window

3) Project Setting

(1) Project property

Set Project name, Author and Project Contents.

To open the Project Property setting window, select the project name on the Project window and click right button, then select "Property" from the pop-up menu.




3-11 Project Property Window

(2) Axis Property

Set up the axis name. You can check software version for Servo Amplifier etc.

To open the Axis Property window, select the axis name on the Project window and click right button, then select "Property" on the pop-up menu.




3-12 Axis Property Window

4) Data Files

You can register data file(s) for Operation Trace, System Analysis and Operation Scrolling to the project.


- (1) Registering data to project:

To register data file(s) to the project, select “File” >>> “Addition To a Project” in the menu of each individual function.



3-13 Menu for “Add to a Project” in Operation Trace Window

- ✓ Registered data file is automatically saved under the following name format “date + consecutive number” and is displayed in the data file on the Project window.



3-14 Data file registered to >> project


Registered data file to project is saved to a sub folder containing the project file.

- ✓ Each data file can be saved without registering it to a project.
- ✓ The name of the data file can be changed later.

- (2) Retrieve data file(s)

You can retrieve saved data file(s) by double clicking the data file name on the Project window.

5) Saving the Project

Select "Project" >>> "Save" (or icon on toolbar  or "Save As". Set up project information and registered data file(s) are saved.

3.5 Operation Level


You Can limit/restrict editing parameters by setting the operation level. There are two operation levels: Basic and Advanced.

■ Basic : You can only edit Basic parameters of the Servo Amplifier.

■ Advanced : You can edit all parameters of the Servo Amplifier.


✓ Refer to the Instruction Manual for the Servo Amplifier in use for each parameter level.

1) Operation Level Selection

Select "Project" >>> "Operation Level", or click "Operation Level" icon .

Operation level selection window will be displayed.

Select the appropriate operation level and click "OK". If you need to stop the selection, click "Cancel".



3-15 Operation Level Selection Window

✓ Regarding Authority, make certain to select "Authority A". "Authority B" and "Authority C" are for our company maintenance staff only.

3.6 Password Function

Partially limiting functions of the Servo Amplifier is possible by setting a Servo amplifier password function. With the Servo Amplifier password set, you cannot edit parameters as well as some functions unless the password is released.


Table 3-1 Invalid or limited functions from setting the password

No	Function		Explanation
1	Parameters	Parameter setting	You can not edit parameters. Only viewing is possible.
		Parameter transmission from file to Servo Amp	Invalid.
		Parameter verification	You can not copy the value of files to Servo Amplifier.
		Save to Backup memory	Invalid.
		Restore from Backup memory	Invalid.
2	Alarm	Alarm History display	You can not clear alarm history. Only viewing is possible.
3	Test Operation	Serial encoder clear	Invalid.
4	Automatic Tuning	Auto notch filter tuning	Invalid.
		Auto FF vibration suppression frequency tuning	
		Save auto tuning results	
5	Adjustment	Auto offset adjustment of V-REF Terminal	Invalid.
		Auto offset adjustment of T-COMP Terminal	
		Manual offset adjustment of V-REF Terminal	
		Manual offset adjustment of T-COMP Terminal	

1) Password Setting Procedure

Password setting procedure is as follows:

- (1) Select "Password Setting" on the menu of the Parameter setting window. Password window will be displayed.
- (2) Input the password into each text box at "New Password" and "New Password (for a check)" and click "OK".
- (3) Make sure to use 4-digit hexadecimal alphanumeric characters.
- (4) Set "0000" to release the password.
- (5) You cannot use "FFFF".
- (6) Re-input power supply for Servo Amplifier to validate the new password.




3-16 Password Setting Window

2) Password Verification Procedure

While the Password to Servo Amplifier condition is already set, you want to execute the function , shown in figure 3-1, the Password Verification window appears.

If the entered password does not match the current password, the individual functions cannot be used.


- (1) Enter the correct password into the box and click "OK".
- (2) When you have entered the correct password for the Servo Amplifier, the function window will appear.



3-17 Password Enter Window

3.7 Software Version Information

When "Help" >>> "Version Information" is selected from the menu of the main window, the Software version of Setup Software, Database and Motor Parameters can be checked.



3-18 Version Information Window

4. Parameters

4.1 Parameter Editing, Function Overview

You can perform, edit, transmit, verify and backup Servo Amplifier parameters using this Setup Software.

1) Function List

The following parameter functions can be performed using the Setup Software:

No	Parameter Function	Explanation
1	Parameter Setting	Edit individual parameters of the Servo Amplifier.
2	Parameter Transmission Servo Amp to file	Save parameters of the Servo Amp in the file.
3	Parameter Transmission file to Servo Amp	Transmit the value of the parameter file to the Servo Amplifier.
4	Parameter Verification	Transmit the value of the parameter Servo Amp to the file.
5	Save to Backup memory	Backup parameters to the built in Backup memory of the Servo Amplifier.
6	Restore from Backup memory	Restore parameters of the Servo Amp with values from Backup memory

2) Types of Parameters

2) Types of Parameters

There are three (3) groups of parameters. These parameters can be modified from the Parameter Setting window:


- (1) General parameters:
Parameters to set each servo gain and I/O function arrangement according to use. These parameters outline the group 0 - F.
- (2) System parameters:
Basic system parameters such as those for classified power source, combining encoder, etc. These parameters outline the group "System Parameters".
- (3) Motor parameters:
Combining motor parameters.


4.2 Parameter Setting

The parameters of the Servo Amplifier can be changed using the Parameter Setting function.

1) Starting Parameter Setting

The Parameter Setting window can be executed by any of the three (3) following procedures:

- (1) Select "Parameter" >>> "Parameter Setting" on the menu of the main window and select the appropriate axis number from the axis selection window.
- (2) Click the "Parameter Setting" icon  on the toolbar of the main window and select the appropriate axis number from the axis selection window.
- (3) Double click "Parameter" >>> "Parameter Setting" >>> Parameter "Group Name" of the setting axis on the Project window.




4-1 Parameter Setting window

- (A) Menu : Select and perform each function.
- (B) Toolbar : Select and perform each function.
- (C) Model : Displays combined model of Servo Amplifier, Servo motor.
- (D) Combining motor : Displays currently combined motor model.
- (E) System information : Displays Servo Amplifier system information.
- (F) Group tab : Displays Parameter name and group number.
- (G) Parameter list : Displays selected group of Parameter.
- (H) Parameter edit history : Displays history of edited/changed parameter.
- (I) "Edit" : Opens edit window for general and system parameters.
- (J) "Select from the List" : Opens motor parameter selection window.

2) Setting General and System Parameters


Procedure for setting General and System Parameters is as follows:

- (1) Click the group tab where the parameter to be changed is displayed and click the specific parameter to be changed.




4-2 Parameters List Display Window


- (2) Open the Parameter Edit window by double clicking the selected parameter or by clicking "Edit". Inputs the setting values in the box provided (or select the setting value from the list box) and click "OK" or press the "Enter" key. The Edit window will close after the value is established and the new value will be displayed in the Input Value column of the parameter list.




4-3 Parameter Edit Window

- (3) Repeat the same procedures (1)-(2) for the other parameters to be changed.

- (4) Select “Amplifier” >>> “Write in amplifier” from the menu or click the “Write in Amplifier” icon  to begin writing to the amplifier. When the parameters have been completely written correctly, the parameter values, both before and after the change will be displayed on the Parameter Change History window.



4-4 Icon for Write in Amplifier




4-5 Parameter Change History display

3) Setting Motor Parameters

Following windows show how to set up motor parameters. If the motor with the absolute encoder type is used, parameters for that can be set automatically based on the information from its encoder. There are two options available to set up parameters for the motor - “Motor Automatic setting” and “Motor Manual setting” – as below.


(A) Choosing “Motor Automatic setting”

- (1) On the Parameters List Display Window, Click “Motor Automatic Setup”.




4-6 Parameters List Display Window (Motor Automatic Setting)

- (2) Then the dialog box appears as shown in the figure 4-7 and click "OK" button. Choosing "Cancel" button will stop its execution.




4-7 Motor Automatic Setting Confirmation Window

- (3) The dialog will pop up displaying the message for a few seconds during execution as shown in the figure 4-8.




4-8 Motor Automatic Setting Execution Window

- (4) When the setting is completed successfully, the appearing window will show the message as shown in the figure 4-9. Click "OK" to complete the setting, and then re-input control power supply of the servo amplifier.



4-9 Motor Automatic Setting Successful Completion Window

- (5) If an alarm is activated because the setting did not complete correctly for some reasons, "Motor Automatic Setting unsuccessful" window will appear. Resolve the problem of unsuccessful completion, and then restart execution.




4-10 Motor Automatic Setting Unsuccessful Window

Failure reasons for Motor Automatic Setting:

- The status of servo amplifier is "Servo-ON" or "Alarm".
 - The servo motor is not supported by the servo amplifier or set-up software. (It is not listed in the "Motor selection window" (Figure 4-11))
 - The motor is not supported by "Automatic setting".
 - Combination of the amplifier and the motor is not matched.
 - "Encoder clear" has already been executed.
- ✓ To validate the motor change parameter, Re-input the control power supply of the servo amplifier.


(B) Choosing “Motor Manual setting”

- (1) Open Motor Selection window by clicking “Select from the List” from the Parameter Setting window.
- (2) Select the motor to be combined and click “OK” or press the “Enter” key. The selected motor model number to be combined will be displayed in the Input Value column on the Parameter setting window.



4-11 Motor Selection window

- (3) Perform the writing of the selected motor parameter into the Servo Amp by clicking the “Write in Amplifier” icon on the toolbar.





4-12 Combining Motor display


- (4) When writing the value into the Servo Amplifier is complete, the motor model numbers, both before and after change, will be displayed on the Parameter Change History window. Refer to [4-5 Parameter Change History display].
- ✓ Re-input the power supply for the Servo Amplifier to validate the motor change parameter.

4.3 Parameter Transmission from Servo Amp to File

Parameters of Servo Amplifier can be saved in parameter file. This enables batch setting of parameters into the other Servo Amplifier(s) from the saved parameter file.


1) Operating Procedure

- (1) Perform any of the following three (3) methods to transmit parameters from Servo Amplifier to file:
 - (A) Select “Parameter” >>> “Parameter Transmission (To File)” from the menu or click the “Parameter Transmission (To File)” icon  on the toolbar on the main window. Then, after the Axis Selection window appears, select the axis number where the parameter transmission is located.
 - (B) Select “Disk” >>> “Parameter Transmission (To File)” from the menu or click the “Parameter Transmission (To File)” icon  on the toolbar of the Parameter Setting window.
 - (C) Double click “Parameter” on the transmitting axis >>> “Parameter Transmission (To File)” on the project window.




4-13 Parameter Transmission (To File) Window

- (2) When “Transmission” is clicked on the Parameter Transmission (To File) window, “Save As” is displayed. Specify the file name to be saved. The extension automatically becomes *.ap1. Click “Save” to save the file.



4-14 Save As Dialog Window

- (3) Wait for a few seconds until the transmission is complete.



4-15 Transmitting Window


- (4) The file will be created in the designated folder.

4.4 Parameter Transmission from File to Servo Amp

You can transmit saved parameter file to Servo Amplifier. Necessary parameters can be transmitted only to Servo Amplifier by selecting the type of parameters to be transmitted.


1) Operating Procedure

- (1) Perform any of the following three (3) methods to transmit parameters from the file to the Servo Amplifier.
 - (A) Select “Parameter” >>> “Parameter Transmission (To Amplifier)” from the menu or click the “Parameter Transmission (To Amplifier) icon” on the toolbar of the main window. Then, after the Axis Selection window appears, select the axis number where the parameter transmission is located.
 - (B) Select “Disk” >>> “Parameter Transmission (To Amplifier)” from the menu or click the “Parameter Transmission (To Amplifier)” icon on the toolbar of the Parameter Setting window.
 - (C) Double click “Parameter” on the transmitting axis >>> “Parameter Transmission (To Amplifier)” on the project window.




4-16 Parameter Transmission (To Amplifier) Window

- (2) Check the boxes of the types of parameters to be transmitted on the Parameter Transmission (To Amplifier) window and click "Transmission".
- (3) Select the file to be transmitted from the "Open File" dialog window and click "Open".



4-17 Open File Dialog Window

- (4) Wait for a few seconds until the transmission is complete.



4-18 Transmitting Window


- (5) When the Transmission window is disappeared, Transmission is completed. If necessary, re-power on.

4.5 Parameter Verification

You can verify the parameter value of the Servo Amp with that of the parameter file because it likely could be different. Copy the different parameters (if necessary) to the amplifier and/or the file.


1) Parameter Verification window

Open the Parameter Verification window using any of the following three (3) methods:


- (1) Select "Parameter" >>> "Parameter Verification" from the menu of the main window or click the "Parameter Verification" icon  on the toolbar of the main window.

The Axis number selection window will appear.

Select the Axis number to be verified.

- (2) Select "Disk" >>> "Parameter Verification" from the menu of the Parameter Setting window or click the "Parameter Verification" icon  on the toolbar of the Parameter Setting window.


- (3) Double click "Parameter" >>> "Parameter Verification" on the axis to be verified on the project window.




4-19 Parameter Verification window

- (A) Menu : Select and perform each function.
- (B) Toolbar : Select and perform each function.
- (C) Servo Amp Information : Display the connecting amplifier/motor model.
- (D) File Information : Display the amplifier/motor model of the file.
- (E) Verification Result : Display the parameters that differed after verification.

2) Operating Procedure for Parameter Verification


- (1) Select "File" >>> "Open" from the menu or click the "Open" icon  on the toolbar of the Parameter Verification window.

- (2) Select the file to be verified from the dialog window of “Open File” and click “Open”. Verification will begin. The following window will be displayed during verification.



4-20 Parameter Verification Window (Processing)





- (3) Displays the differing parameters from the Verification Results window after the verification has been completed.



4-21 Parameter Verification Results Window

3) Parameter Copy


Differing parameters can be copied to Servo Amp or file. The following are the types of copies:


- (1) Copy the value of the Servo Amplifier to file all parameters.
Select “Copy” >>> “Copy the value of amplifier to file (All)” or click the icon  on the toolbar.
 - (2) Copy the value of the Servo Amplifier to the file for selected parameters only.
Select parameters to be copied from the Parameter Verification Results window.
Select “Copy” >>> “Copy the value of amplifier to file (only in case of selection)” from the menu or click the icon  on the toolbar.
 - (3) Copy the value of the file to the Servo Amp for all parameters.
Select “Copy” >>> “Copy the value of amplifier to file (All)” or click the icon  on the toolbar.
 - (4) Copy the value of the file to the Servo Amp for selected parameters only.
Select the parameters to be copied from the Parameter Verification Results window.
Select “Copy” >>> “Copy the value of amplifier to file (only in case of selection)” from the menu or click the icon  on the toolbar.
- ✓ When the value of the file changes as a result of a copy, save the file before closing the application.
 - ✓ Parameters (such as motor parameters) that cannot be copied may be displayed in the Verification Results window. The background color of these parameters will be gray.

4.6 Saving to Backup Memory

You can save the current parameter values of the Servo Amplifier into the backup memory domain of the Servo Amplifier. Parameters can be restored at any time by saving the setup values of the parameters in the backup domain.


1) Operating Procedure

- (1) Perform Save to Backup memory using one of the following methods:
 - (A) Select "parameter" >>> "Save to the Backup Memory" from the menu of the main window or click the "Save to Backup Memory" icon  on the toolbar of the main window. The Axis selection window will appear. Select the axis number to be performed.
 - (B) Double click "Parameter" >>> "Save to Backup Memory" on the Project window for the axis to be performed.
- (2) Saving to Backup Memory will begin processing by clicking "OK" on the Save to Backup Memory window.




4-22 Confirmation Window (Save to the Backup Memory)

- (3) The following window will be displayed while executing the backup. It displays the remaining data number.



4-23 Processing Window (Save to the Backup Memory)

- (4) The following window is displayed when the backup process has been completed successfully. Click "OK".




4-24 Completed Window (Save to the Backup Memory)


- ✓ The standard value is saved in the backup memory domain at the time of shipment from our factory. The standard value cannot be restored after you perform this Save to Backup Memory operation once. Saving the parameters into a separate file prior to execution is strongly recommended.
- ✓ Refer to [4.3 Parameter Transmission from Servo Amp to File] for the save procedure.
- ✓ Do not power off until processing has been completed. Perform the program again in case of stoppage of the processing.

4.7 Restoring from Backup Memory

You can restore the parameters of the Servo Amplifier with the values stored in the Backup Memory.


1) Operating Procedure

- (1) Restore parameters from the Backup Memory using one of the following methods:
 - (A) Select "Parameter" >>> "Restoration from the Backup Memory" from the menu on the main window or click the "Restoration from the Backup Memory" icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis number to be performed.
 - (B) Double click "Parameter" >>> "Restoration from the Backup Memory" on the axis to be performed from the project window.
- (2) Parameter restoration with the value stored in the Backup Memory will begin after clicking "OK" on the Restoration window.




4-25 Confirmation Window (Restoration from the Backup Memory)

- (3) The following window appears while executing the restoration and displays the remaining data numbers.



4-26 Processing Window (Restoration from the Backup Memory)

- (4) The following window appears upon successful completion of the Restoration. Click "OK".



4-27 Completed Window (Restoration from the Backup Memory)

- ✓ Do not power off until processing has been completed. Perform the program again in case of stoppage of the processing.
- ✓ Some parameters only become valid after the power source has been re-input. Make certain to input the power source for the Servo Amplifier after execution of these procedures.


5. Monitor

5.1 Monitor Overview

You can check Data of each Servo Amplifier in real time. It is also possible to select specific parameters to be monitored from the list.

1) Operating Procedure

- (1) Select "Monitor"  from the menu or from the toolbar, then select the axis to be monitored.




5-1 Monitor Menu Window

5.2 Start Monitoring

Check the data of the Servo Amp in real time.

1) Operating Procedure

- (1) After clicking "Monitor Start" on the upper right of the window, a monitor data update will begin.



5-2 Monitor Window

- ✓ Displays "Monitor Stop" as in the above image.
- (2) To stop the monitor update,click "Monitor Stop"


5.3 Selecting Parameter(s) to Monitor

Parameters to be monitored can be selected when monitor is stopped.

1) Operating Procedure

- (1) Click "Parameter Selection" when monitor is stopped.

The following Parameter Selection window will be displayed.



5-3 Parameter Selection Window

- (2) Check the box (es) of the parameter(s) you want to monitor and click "OK".

6. Alarm


6.1 Alarm History


Alarm History display, Alarm History clear, and Alarm Reset can be performed from this window. It displays the last seven (7) alarms generated by the Servo Amplifier. It also indicates the state of the amplifier at the time the alarm is generated along with alarm generating time and alarm code name.




6-1 Alarm Menu Window

1) Alarm Histor display

- (1) Select "Alarm" >>> "Alarm History" from the menu or click the "Alarm History" icon  on the toolbar of the main window. The Axis Number selection window will appear. Select the axis to display the alarm history for and click "OK". Click "Cancel" to exit.
- (2) Alarm History is displayed.




6-2 Alarm History Window

- (3) Alarm History can be printed. Select "File" >>> "Print" from the menu or click the "Print" icon .
- (4) If you want to quit, Click Windows exit button.

2) Alarm History Clear


Alarm history generated in the past can be cleared from the Alarm History window.

- (1) Select "Amplifier" >>> "Alarm History Clear" from the menu.



6-3 Alarm History Clear Window

- (2) The confirmation window to perform the Alarm History Clear will be displayed. Click "OK" to perform and click "Cancel" to exit.




6-4 Alarm History Clear Confirmation Window

- (3) When Alarm History Clear has been completed successfully, click "OK".




6-5 Alarm History Clear Successfully Completed Window

6.2 Alarm Reset

- (1) Select "Alarm" >>> "Alarm Reset" from the menu or click the "Alarm Reset" icon  on the toolbar of the main window. The axis number selection window will appear.


Select the axis you want to display the alarm history and click "OK". Click "Cancel" to quit.

- (2) Displays confirmation window to perform Alarm Reset.



6-6 Alarm Reset Confirmation Window

- (3) Click "OK" to perform. Click "Cancel" to quit.
- (4) Alarm factors have all been removed and Alarm Reset was performed successfully. If not, a window will appear with the following: "Alarm Reset was not able to be performed".



6-7 Alarm Reset Completed Successfully Window



6-8 Alarm Reset Unsuccessful Window


No Text on This Page.

7. Test Operations

You can perform JOG Operation, Positioning Operation, Magnetic Pole Position Presumption and Serial Encoder Clear as test operations.


7.1 JOG Operation


In the JOG Operation, Servo motor's test run under constant velocity command can be performed easily by setting the rotation speed of the Servo motor. Secure the safety of the surroundings completely because the Servomotor runs during the JOG Operation. When the amplifier alarm occurs during the JOG Operation, motor excitation turns OFF. Prepare the control devices as ready to be used before execution of the JOG Operation.



7-1 Test Operation Menu Window


1) Operating Procedure

- (1) Select "Test Operation" >>> "JOG Operation" from the menu or click the "JOG Operation icon"  on the toolbar of the main window. The Axis number selection window will appear. Select the axis on which to perform the velocity JOG Operation and click "OK". Click "Cancel" to quit.




7-2 Axis Selection Window

- (2) Confirmation window for performing the JOG Operation will appear. Click "OK" to perform the JOG Operation. Click "Cancel" to quit the operation.



7-3 JOG Operation Confirmation Window


(3) Click "OK" for JOG Operation display.



7-4 JOG Operation Window


- (A) Selection of alarm function at the time of the JOG Operation is ended. Choose either "is selected" or "is not selected" at the time of end.
- (B) Selection of stopping method:
Choose either "It will stop if a button is pushed" or "It will stop, if the execution button (Positive/Negative direction) is detached."
- (C) Monitoring the current state of the Servo Amplifier including torque (force), velocity and actual position.
- (D) Setting the operation conditions. JOG acceleration/deceleration time constant and torque (force) command limit can be set as well as the JOG velocity command.
- (E) Editing operating conditions. Click "Edit" to edit the conditions. Click "Decision" when editing is complete. Click "Cancel" to cancel the editing.
- (F) ON/OFF operation of motor excitation: Servomotor does not run if this is not ON.
- (G) Execution buttons. Click either Positive/Negative Direction, depending on the direction needed to operate the device.
When the "It will stop, if a button is pushed" is selected as a stop method, the motor will not stop until a Stop button is clicked.

- (4) To end the JOG operation, click quit button of the Windows. When the following window appears, click "OK". To continue the JOG operation, click "Cancel".



7-5 End JOG Operation confirmation Window

- (5) When other factors prevent JOG operation from being performed during operation or at the start of operations (for example Communication errors, Amplifier alarm detection, etc.) the following window will be displayed and operation will stop.



7-6 Preparation incomplete for JOG Operation Window

- (6) Click "OK". You will return to main window.


7.2 Positioning Operation

In the Positioning Test Operation, by setting the feed velocity and the pulse number to be moved for the Servomotor moving the axis for a set number of the pulse can be performed easily.

Secure the safety of the surroundings completely because the Servomotor runs during the Positioning Operation. When the amplifier alarm occurs during the positioning operation, the motor excitation switches to OFF. Prepare the control devices as "Ready to use" before execution.


1) Operating Procedure

- (1) Select "Test Operation" >>> "Positioning Operation" from the main menu or click the "Positioning Operation icon" on the toolbar of the main window. The Axis number selection window will appear. Select the axis to be operated and click "OK". Click "Cancel" to stop the operation.
- (2) The Positioning Operation performing confirmation window will appear. Click "OK".



7-7 Positioning Operation performing Confirmation Window


- (3) The Following Positioning Operation window appears.



7-8 Positioning Operation Window


- (A) Selection of alarm function at the time of the Positioning Operation is ended. Choose either "is selected" or "is not selected" at the time of end.
- (B) Selecting operation mode. Single position operation or continuous round-trip positioning operation can be selected for a specified number of times.
- (C) Monitors the current state of the Servo Amplifier, including torque (force), velocity, actual position and the number of times of continuous repeating operation.
- (D) Setting the operating conditions. Acceleration/Deceleration time constant, torque (force) command limit, dwell time and the number of continuous repeating operations can be set to a value other than that of the number of the positioning pulse and feed velocity.
- (E) Edit the operating conditions. Click "Edit" to edit the conditions. Click "decision" when editing is complete. Click "Cancel" to stop the editing.
- (F) ON/OFF operation for motor excitation: The Servo motor will not run if the condition is OFF.
- (G) Execution buttons. Click either Positive/Negative Direction, depending on the direction needed to operate the device. The Positioning Operation is performed only once in a single direction when in Single Operation mode. The round-trip operation is repeated continuously for a specified number of times in Continuous Repeat Operation mode. When Zero (0) is specified as the number of operating times, the round-trip operation will repeat an unlimited number of times until "Stop" is clicked. Pause time during operation can also be set.

- (4) To quit the Positioning operation, click “quit” button of the Windows. When the following window appears, click “OK”. To continue the Positioning Operation click “Cancel”.



7-9 Positioning Operation End confirmation Window

- (5) When other factors prevent the Positioning Operation from being performed during operation or at the start of operations (for example Communication errors, Amplifier alarm detection, etc.) the following window will be displayed and operation will stop.



7-10 Preparation incomplete for JOG Operation Window

Click “OK” to return to the main window.


2) Notice


- (1) Pause time has a maximum 0.5 seconds margin of error.

7.3 Magnetic Pole Position Presumption

When you perform the Magnetic pole position presumption, the pole position is presumed without moving the motor at all. This function is performed for a linear motor.

1) Operating Procedure


- (1) Select “Test Operation” >>> “Magnetic Pole Position Presumption” from the menu or by clicking the “Magnetic Pole Position Presumption” icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to presume the magnetic pole position and click “OK”. Click “Cancel” to stop the operation.



7-11 Axis selection Window for Magnetic Pole Position Presumption


- (2) Confirmation window for execution will appear. Click “OK”. Secure the safety of your surroundings. Motor moves slightly.

- (3) Click "Cancel" to quit Magnetic Pole Position Presumption.




7-12 Magnetic Pole Position Presumption Execution Confirmation Window

- (4) Magnetic Pole Position Presumption is in progress.




7-13 Magnetic Pole Position Presumption Execution Window

- (5) When Magnetic Pole Position Presumption is complete, motor excitation will complete automatically.



7-14 Magnetic Pole Position Presumption Successful Completion Window

- (6) When the Magnetic Pole Position Presumption is not presumed successfully, the following window will appear. Check the status.
 - (A) Factors for incompleteness/malfunction:
 - ◆ Linear sensor feedback error.
 - ◆ Motor is sticking and cannot move.





7-15 Magnetic Pole Position Presumption Preparation Incomplete Window

7.4 Serial Encoder Clear

When the motor encoder is a serial encoder connected to the Servo Amplifier, a zero-clear of the multiple revolution data in the encoder as well as encoder status clear can be performed using this function.


1) Operating Procedure

- (1) Select "Test Operation" >>> "Serial Encoder Clear" from the menu or click the "Serial Encoder Clear" icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to perform the Serial Encoder Clear function on and click "OK". Click "Cancel" to stop the operation.
- (2) The confirmation window for execution of the Serial Encoder Clear will be displayed. Click "OK".




7-16 Serial Encoder Clear Execution Confirmation Window

- (3) Serial Encoder Clear execution window will appear. Click "Cancel" to quit.




7-17 Serial Encoder Clear Processing Window

- (4) After several seconds, the following window will be displayed after successful completion of the Serial Encoder Clear operation. Click "OK".



7-18 Serial Encoder Clear Successful Completion Window

- (5) When Serial Encoder Clear cannot be performed, the following window appears. Click "OK" and quit the operation.




7-19 Serial Encoder Clear Preparation Incomplete Window

- (6) Alarm (ALM_DF) will occur at the same time as step (5).
 - (A) Factors for incomplection/malfunction
 - ◆ Motor is operated externally.
 - ◆ Cannot perform zero-clear.
 - ◆ Alarm factors cannot be cleared.
 - ✓ A case could occur where only the encoder status is cleared and the multiple revolution data is not cleared, which will depend on the parameter settings of the Servo Amplifier.
 - ✓ There is a possibility that the encoder clear has already been performed when the operation was stopped by clicking "Cancel" and the window displayed "Serial Encoder Clear cannot be performed (Preparation un-completing)". Make certain to confirm Serial Encoder PS Data of Monitor window.

8. Automatic Tuning

Automatic tuning functions consist of Automatic Notch Filter Tuning, Automatic FF Vibration Suppression Frequency Tuning and Save Results of Automatic Tuning.


8.1 Automatic Notch Filter Tuning



8-1 Automatic Tuning Menu Window

1) Operating Procedure

- (1) Select "Auto Tuning" >>> "Auto Notch Filter Tuning" from the menu or click the "Auto Notch Filter Tuning" icon on the toolbar of the main window. The Axis number selection window will appear. Select the axis to perform the "Auto Notch Filter Tuning" and click "OK". Click "Cancel" to stop.
- (2) Confirmation window will appear. Click "OK".




8-2 Auto Notch Filter Tuning Execution Confirmation Window

- (3) Click "Servo ON" after checking the conditions shown in the window.




8-3 Auto Notch Filter Tuning Window

- (4) Click "Execute" to perform tuning.
Click "Servo OFF" to stop the motor excitation.
- (5) The following window will appear when executing the operation.



8-4 Auto Notch Filter Tuning Execution in Progress Window

- (6) When the tuning is completed successfully, the following window will appear. Check the frequency to be set. Also, secure the safety of the surroundings because Servo ON status continues until "OK" is clicked.
- (7) Auto Notch Filter Tuning window (3) will be displayed by clicking "OK".




8-5 Results of Auto Notch Filter Tuning Window

- (8) When you click "quit" button of the upper right of the Auto Notch Filter Tuning Windows (3), the following window will appear. Click "OK" to close. Click "Cancel" to return (3) window.



8-6 Close Auto Notch Filter Tuning Confirmation Window

- (9) When tuning cannot be performed or some irregularity occurs during tuning, the following window will appear and tuning will be closed involuntarily.




8-7 Auto Notch Filter Tuning Incomplete Window

8.2 Automatic FF Vibration Suppression Frequency Tuning

This function set the vibration suppression frequency automatically.


1) Operating Procedure

- (1) Select "Auto Tuning" >>> "Automatic FF Vibration Suppression Frequency Tuning" from the menu or click the Automatic FF Vibration Suppression Frequency Tuning icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to be tuned and click "OK". Click "Cancel" to stop operation.
- (2) Execution confirmation window will be displayed. Click "OK".



8-8 Automatic FF Vibration Suppression Frequency Tuning confirmation Window

- (3) Click "Servo ON" after checking the conditions displayed in the following window:




8-9 Automatic FF Vibration Suppression Frequency Tuning Window

- (4) Click "Execute" to perform tuning.
Click "Servo OFF" to servo off.

- (5) When tuning is performed, the following window will appear:


Click "Cancel" to stop.



8-10 Automatic FF Vibration Suppression Frequency Tuning in Progress Window

- (6) Results of the operation execution will appear in the following window:

To confirm the results of the tuning, click "OK".





8-11 Automatic FF Vibration Suppression Frequency Tuning Results Window

8.3 Save Result of Automatic Tuning

Saving the parameters adjusted by automatic tuning: Parameters can be saved five (5) different ways.


1) Operating Procedure

- (1) Select "Auto Tuning" >>> "Save Result of Auto Tuning" from the menu or click the "Save Result of Auto Tuning" icon  on the toolbar of the main window. The Axis number selection window will appear. Click "OK". Click "Cancel" to stop the operation.
- (2) Execution confirmation window will be displayed. Click "OK".




8-12 Save Result of Auto Tuning Execution Confirmation Window

- (3) After checking the conditions and selecting the parameter combination to be saved in the following window, Click "Save the Monitor Value".




8-13 Save Result of Auto Tuning Execution Window

- (4) Monitoring values from the auto tuning parameter monitor values are applied to the values for the selected parameters.



8-14 Save Result of Auto Tuning Parameter Selection Window


- (5) Click "Close" on the upper right of the window to close the application. The confirmation window for ending the operation will appear. Click "OK".



8-15 Save Result of Auto Tuning Ended Confirmation Window

9. Adjustment

With this function, Automatic offset adjustment of V-REF Terminal, Automatic Offset of T-COMP Terminal, and Manual offset adjustment of V-REF Terminal and Manual Offset of T-COMP Terminal can be performed.





9-1 Adjustment Menu Window

9.1 Automatic Offset Adjustment of V-REF Terminal

This is the function to operate the Automatic Offset Adjustment of analog velocity/torque(force) command input terminal.


1) Operating Procedure

- (1) Select "Adjustment" >>> "Automatic Offset Adjustment of V-REF Terminal" from the menu or click the "Automatic Offset Adjustment of V-REF Terminal" icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to be adjusted and click "OK". Click "cancel" to stop.
- (2) Confirmation window will appear. Click "OK".



9-2 Automatic Offset Adjustment of V-REF Terminal Execution Confirmation Window

- (3) The following window will be displayed when operation is completed normally:



9-3 Automatic Offset Adjustment of V-REF Terminal Successfully Completed Window

- ✓ Automatic offset cannot be completed normally when extremely high command voltage has been input. (Higher than 5v standard)


9.2 Automatic Offset Adjustment of T-COMP Terminal


This is the function to operate automatic offset adjustment for analog torque (force) compensation command input terminal. Refer to [9.1 Automatic Offset Adjustment of V-REF Terminal] for actual operation.

9.3 Manual Offset Adjustment of V-REF Terminal

This is the function for manual offset adjustment of analog velocity/torque command input terminal.


1) Operating Procedure

- (1) Select "Adjustment" >>> "Manual Offset Adjustment of V-REF Terminal" from the menu or click the "Manual Offset Adjustment of V-REF Terminal" icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to be adjusted and click "OK". Click "Cancel" to stop.
- (2) Confirmation window will appear. Click "OK".




9-4 Manual Offset Adjustment of V-REF Terminal Execution Confirmation Window

- (3) Set the offset value in the following window manually:



9-5 Manual Offset Adjustment of V-REF Terminal Execution Window

- (4) Click "End" to finish the offset adjustment. The following window will appear. Click "OK".



9-6 Manual Offset Adjustment of V-REF Terminal End Confirmation Window

9.4 Manual Offset Adjustment of T-COMP Terminal

This is the function for the manual offset adjustment of analog torque (force) compensation command input terminal. Refer to [9.3 Manual Offset Adjustment of V-REF Terminal for the actual operation].

No Text on This Page.

10. Measurement

You can display operation status in waveform (Operation Trace Function). You can also check the status in real time by scrolling operation data (Operation Scrolling Function) and check frequency characteristics of mechanical devices (System Analysis Function).




10-1 Measurement Menu Window

10.1 Operation Trace


You can display current operation status in waveform with the image of an oscilloscope.

1) Operating Procedure

You can display operation status in graphic form.

- (1) Select "Measurement" >>> "Operation Trace" from the menu or click the "Operation Trace" icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to be used and click "OK". Click "Cancel" to stop.


(2) The following window will be displayed. Click "Trace Conditions Setting" to change individual trace conditions.



10-2 Operation Trace Window

- (A) Add to Project : Register-Save current measurement data displayed in data file of Project.
- (B) Start Trace : Start trace operation under set conditions.
- (C) Stop Trace : Stop trace operation.
- (D) Trace Clear : Clear the measured waveform
- (E) CH Scale : Displays the selected channel scale. Attention is necessary here because this is the scale selected in "Scale CH" and does not link with the other scale channels.
- (F) Time-Axis : Setting for Time-Axis Range
- (G) Trigger Centering : Clicking displays the trigger position as the center of the waveform.
- (H) Cursor : Displays the data of the cursor position.
 The cursor moves to the clicked position: t1 = left click mouse
 t2 = right click mouse
 v1 = shift key + left click mouse
 v2 = shift key + right click mouse
- (I) Trigger Position : Indicates each vertical/horizontal trigger position.
- (J) Zero Level Position: Shows zero level for each channel.
- (K) Copy to Clipboard : Copy trace conditions and measured waveform to clipboard.


(3) After clicking “Trace Conditions Setting”, the following window appears. Setup/Input each condition in the window. Click “OK” after setting values. The changes will be invalidated by clicking “Cancel”.



10-3 Trace Conditions Setting Window

- ✓ The data below can only be selected on Channel 1,3 and 5. Also, Channels 2, 4 and 6 cannot be selected when the data below is selected.
 - Position Monitor (Motor)
 - Position Monitor (External)
 - Position Command Integrated Value
 - Motor Serial Encoder PS Data
- ✓ When the buffering point is 256, it is possible to select 6 analog channels, at 512 points 3 analog channels, and at 1024 points only 1 analog channel can be selected.


(4) This window shows the view when the Channel Information tab is opened.



10-4 Operation Trace Window (CH Information Tab)

- (A) Display section : Displays checked channel in graphic form.
- (B) Waveform Items : Displays selected signal name for each channel. Set range and offset of signals here.
- (C) Auto : Clicking "Auto" adjusts the range and offset automatically and displays the in graphic form.


(5) This window shows the view when the Measurement Value Tab is opened.



10-5 Operation Trace Window (Measurement Value Tab)

- (A) Effective Value : Calculates data between the t-axis cursors of the selected channel and displays the resulting value.
- (B) Cursor Position Data : Displays the data specified at cursor t1.
- (C) Cursor Differential Data : Displays the difference of data specified in cursors v1 – v2.

(6) This window displays the view when the Measurement Information Tab is opened.



10-6 Operation Trace Window (Measurement Information Tab)

- (A) Overwrite of Trace : Overwrite the measured state of this time in waveform over the waveform measured the previous time.
- (B) Measure Displayed on Top : Selected waveform is displayed as a solid line.


10.2 Operation Scrolling


You can display operating state of waveform in real time.

It is possible to display waveforms for multiple axes simultaneously when multiple axes Servo Amplifiers are connected.

- ✓ Sampling time is restricted depending on the processing capacity of the PC.

1) Operating Procedure

- (1) Select "Measurement" >>> "Operation Scrolling" from the menu or click on the "Operation Scrolling" icon  on the toolbar of the main window. The Axis number selection window will appear. Select "Online" at the axis number and click "OK". Click "Cancel" to stop.
- (2) The following Operation Scrolling window will appear. Click "Scrolling Conditions Setting" to change the individual scrolling conditions.




10-7 Operation Scrolling Window

- (A) Start Scrolling : Starts the scrolling operation under the set conditions.
- (B) Stop Scrolling : Stops scrolling operation.

Apply trace operation methods to other operations.

(3) The following is the Operation Scrolling Conditions window.



10-8 Operation Scrolling Conditions Setting Window


- (A) Axis Selection : Select the axis of the Servo Amplifier to be displayed.
- (B) Selection Items : Display signal(s) for each channel that has been selected.
- (C) Sampling Period : Set the period to request data for the Servo Amplifier.


Setting a short period for a low processing capacity PC results in extremely slow processing speed. So be careful.

10.3 System analysis

In system analysis, the system can be easily analyzed by operating the Servo Amp and Servo Motor for a duration of hundreds of ms to tens of seconds. Secure the safety; the Servo Motor runs during this function.


1) Operating Procedure

- (1) Select "Measurement" >>> "System Analysis" from the menu or click the "System Analysis" icon  on the toolbar of the main window. The Axis number selection window will appear. Select the axis to be analyzed and click "OK". Click "Cancel" to stop.
- (2) Confirmation window to perform System Analysis will appear. Click "OK" to proceed. Click "Cancel" to stop.




10-9 System Analysis Execution Confirmation Window

- (3) The following System Analysis Execution window will appear. Click "Data Measure & Analysis" to proceed. Click "Close" to stop.




10-10 System Analysis Execution Window

- (4) Window for setting conditions will appear. Set the conditions of data measurement.




10-11 System Analysis Data Measurement & Analysis Window

- (5) After setting the conditions, check the safety and surroundings of the motor to be operated. Then, click "Servo ON". Motor excitation starts and "Execute" button becomes effective.
- (6) Measurement will start by clicking "Execute". The progress will be displayed in the status bar.




10-12 System Analysis Data "Now Reading" Status bar Window

- (7) The following window will be displayed when the measurement and data reading has been completed. Click "OK". The motor excitation will continue until "OK" is clicked.




10-13 Data Analysis waiting Window

- (8) Data is being analyzed. Please wait.



10-14 Data Under Analysis Window


- (9) When analysis is complete, the results will be displayed in graphic form.



10-15 System Analysis Results Window

- ✓ Adjust the torque(force) command value so that the torque(force) restriction status incidence rate, while being measured, is 0%.

- (10) Antiresonance/resonance frequencies of a model control system can be set from analyzed graphs. Move cursor t1 (Green) to the frequency to be set for model control antiresonance frequency; cursor t2 (Yellow) to the frequency to be set for model control resonance frequency and click "Setting" in the analysis results window.
- (11) The Setting window will be displayed. Confirm the setting values for antiresonance/resonance frequencies and click "OK". Set parameters at this point.



10-16 Resonance/antiresonance Frequency Setting Window (System Analysis)

11. Troubleshooting

11.1 Upon Installation

No.	Error message	Major cause	Check points – Corrective Measures
1	Insufficient hard disk space	Not enough space on hard disk to install program	About 400MB of HD space is required because this application needs space for Microsoft .NET Framework 2.0 as well as the application itself to operate.
2	Cannot install	OS/IE versions are too old.	Installation cannot continue if the OS and IE(Internet Explorer) versions are too old. Please rebuild the environment by referring to 1.3 [System Environment].

11.2 Wiring, Connection and Communication Status check

No.	Malfunction-Error message	Major cause	Check points – Corrective measures
1	"Error occurred at the time of port opening."	Communication port cannot be used with this software.	Check if the communication port connected with a cable (PC side) has been used with other applications or if Setup Software has already been activated.
2	Communication status check results in "Receiving Data Error"	Error in the settings of the communication port.	Check if the communication port connecting cable (PC side) matches the "COM Port".
3	Communication status check results in "Timeout error".	Error in communication velocity setting. Note 1)	Check if the communication baud rate of the Servo Amp corresponds to the "Communication Velocity".
		Error in Axis selection setting. Note 1)	Check if the Communication axis number selection of the Servo Amp corresponds to the chosen "Axis Number Selection".
		Failure of the communication cable.	Check if the communication cable for the Servo Amp is connected correctly to both the PC side and the (D-sub9 pin). Check that there is no break in the communication cable.
		Control power supply	Check the Control Power supplied to the Amp.
		Wrong operation due to noise	Apply countermeasures. Note2)
4	Communication status check results in "Overlap". Note 3)	Setting error related to communication. (when multiple amps are connected)	Check if the communication axis number settings overlap in the connected amplifiers. Note 1)
		Wrong operation due to noise.	Apply countermeasures. Note 2)
5	Communication status check results in "Not-corresponding"	Version mismatch.	This Setup Software is not corresponding to the Servo Amplifier software version. Install the latest version of the Setup Software.
		Software mismatch.	R ADVANCED MODEL Setup Software cannot communicate with Amp,RS1, RR1. Use R-SETUP Software to communicate with those models. R ADVANCED MODEL Servo Amp cannot communicate with R-SETUP Software.
6	When executing the following, communication shuts down. -Write/Transmit parameter -Test Operation -Automatic Tuning -Adjustment -Measurement	"Parameter lock function" for password is set.	Permit "Parameter Edit". Refer to [3.6 Password Function].

Note 1) The communication baud rate (GroupA-20) and the communication axis number can be set at parameters. The initial value is #1 for the axis number and 38400bps for the baud rate. Changes for the baud rate and axis number become valid when re-input of the control power for the amplifier is accomplished. However, the initial value and the setting procedure are different or the setting cannot be changed due to the amplifier types.

Note 2) When communication cannot be performed correctly due to noise, the noise influence should be reduced by the following countermeasures:

- Ground the Servo Amplifier and PC appropriately.
- Keep the Servo Amplifier and PC away from the noise source.
- Install noise filter.

Note 3) When “Overlap” remains after countermeasures are implemented, take one of the following measures:

- Turn OFF the Servo Amplifier control power and turn it on again.
- Disconnect the communication cable (amplifier side) and reconnect it.

11.3 Parameter Setting

1) Parameter Verification

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	Because of mismatch in amplifier type and amplifier main ID file communication cannot be established.	The type of amplifier is different.	Cannot verify because connecting amplifier type is different than the parameter file to be verified.
2	“Amplifier ID is not supported”	Tried to verify with old version amplifier file.	Update Setup Software to latest version.

2) Parameter Transmission (To Amplifier)

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	Because of mismatch in amplifier and amplifier ID file communication cannot be established.	Type of amplifier is different.	Cannot transmit because connecting amplifier type is different than the parameter file to be transmitted.

11.4 Support Functions

1) Monitor

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	“Communication error occurred at Axis x. Cause: Timeout error”	Breaking of communication cable.	Check if the communication cable between Servo Amplifier and PC is connected correctly, has broken or disconnected.

2) Alarm

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	“Alarm reset could not be performed”	Alarm state is active.	Cannot reset because alarm state is active. Change the alarm state. An alarm that cannot perform alarm reset exists. Change the alarm state and re-input both the control power of the amplifier and the main circuit power source.

3) Test Operation

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	“*** cannot be performed (Preparation incomplete).”	Servo Amplifier is not ready. (Not in SRDY mode). Other support function is being performed.	Check if the Alarm state is active. Change the alarm state.
			Check if the main circuit power is supplied.
			Exit other support functions (Velocity JOG, Position JOG, Auto tuning, Adjustments, System analysis, etc.) if not already done.
			Communication error has occurred for some reason. Initiate Communication Confirmation again.
			Cannot perform when Test Operation, Auto Tuning, and Adjustment functions are initiated from Digital Operator.
			Cannot perform when switching control mode.
2	Encoder clear cannot be performed. (outputs ALM_DF).	Motor is operating externally.	Encoder clear cannot be performed if the motor is operating with more than 50min ⁻¹ (mm/s) externally from some factor.
3	Motor does not run in Positioning Operation or Velocity JOG Operation	Setting error. Over-travel, etc.	Check the Velocity Command setting or specified pulse number.
			Over-travel is still effective. Change the Over-travel status.
4	“Magnetic Pole Position Presumption has not been performed (completing abnormally)” (ALM_44h)	Could not successfully complete for some reason.	Check the operational range of the motor (approx.+10mm)
			Check the force command value for the Magnetic Pole Position Presumption. Magnetic Pole Position Presumption cannot be completed successfully if the value is not sufficient against stationary friction.
			Check if the polarity of the linear encoder signals or wiring of the motor power line has been reversed.

4) Automatic Tuning

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	“*** cannot be performed (Preparation incomplete).”	Servo Amplifier is not ready. (Not in SRDY mode). Other support function is being performed.	Check if the Alarm state is active. Change the alarm state.
			Check if the main circuit power is supplied.
			Exit other support functions (Velocity JOG, Position JOG, Auto tuning, Adjustments, System analysis, etc.) if not already done.
			Communication error has occurred for some reason. Initiate Communication Confirmation again.
			Cannot perform when Test Operation, Auto Tuning, and Adjustment functions are initiated from Digital Operator.
			Cannot perform when switching control mode.
			Cannot use Auto tuning when Over-travel has occurred. Change the status of Over-travel.
			Cannot perform correct measurement while holding brake release delay time (BOFFDLY) and perform at the same time.

5) Adjustments

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	“***Automatic Offset Adjustment cannot be performed. (Preparation incomplete)”	Specified analog voltage exceeds 5.2V.	Check analog voltage input. Automatic Offset cannot be performed if the voltage exceeds 5.2V in adjustment.
			Communication error occurred for some reason. Initiate Communication Confirmation again.
			Cannot perform when Test Operation, Auto Tuning and Adjustment functions are initiated from Digital Operator.
			Cannot perform when switching control mode.
2	Manual Offset Setting Value changed when Automatic Offset was performed.		The Offset values of auto-offset and manual offset are the same in value. The manual offset changed when auto-offset was performed.

6) Measurement

No.	Malfunction - Error message	Major cause	Check point – Corrective measure
1	“System Analysis cannot be performed. (Preparation incomplete)”	Servo Amplifier is not ready. (Not in SRDY mode). Other support function is being performed.	Check if the Alarm state is active. Change the alarm state.
			Check if the main circuit power is supplied.
			Exit other support functions (Velocity JOG, Position JOG, Auto tuning, Adjustments, System analysis, etc.) if not already done.
			Communication error has occurred for some reason. Initiate Communication Confirmation again.
			Cannot perform when Test Operation, Auto Tuning, and Adjustment functions are initiated from Digital Operator.
			Cannot perform when switching control mode.
			Cannot use Auto tuning when Over-travel has occurred. Change the status of Over-travel.
2	Window response is delayed or inactive during Scrolling Operation	Limited by PC processing capacity	Cannot perform correct measurement while holding brake release delay time (BOFFDLY) and perform at the same time.
			This depends on the processing ability/capacity of the PC because real time communication is implemented for the amplifier and displays its waveform on window. Adjust it either by closing other applications or by setting the sampling time of the Scrolling Operation longer.

No Text on This Page.

12. Appendix

12.1 Wiring

1) Servo Amplifier Connectors




Servo Amplifier Side : CN2	
MUF-RS8DK-GKXR J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	422RXD+
2	422RXD-
3	422TXD+
4	+5V
5	232RXD
6	422TXD-
7	232TXD
8	GND
Shell	Shield

Servo Amplifier Side : CN3	
MUF-RS8DK-GKXR J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	422RXD+
2	422RXD-
3	422TXD+
4	+5V
5	NC
6	422TXD-
7	NC
8	GND
Shell	Shield


- Use CN2 cable when connecting to the (first) PC.
- When connecting multiple axes, connect the cable from the first amplifier or (first) PC to CN2 and the cable from the last amplifier to CN3.

2) Connecting Cable A

Connect the (first) computer and the first Servo Amplifier (RS-232C Terminal).



Connecting Cable A : AL-00689703-01



PC Side (COM)	
JEZ-9S-3(LF)	
J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	DCD
2	RD
3	TD
4	DTR
5	SG
6	DSR
7	RS
8	CS
9	RI


Servo Amplifier Side : CN2	
MUF-PK8K-X	
J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	NC
2	NC
3	NC
4	NC
5	RXD
6	NC
7	TXD
8	SG
Case	Shield

- Use shielded wire for cable.
- Connect cable (shielded wire) to case of amplifier side connector.
Do not connect to the case of the PC connector.
- Do not wire except to the specified terminals shown on the wiring diagram.


3) Connecting Cable B

This is a cable to connect between Servo amplifiers for multiple axes connection of Servo amplifiers.

(RS422A connection)




Connecting Cable B : AL-00695974-01 (0.2m)
AL-00695974-02 (3m)



4) Network terminator

Connector to end RS422A communication for multiple axes connections of Servo Amplifier.




Network terminator: AL-00695977-01
(A resistor (120ohm) is inserted between 1pin and 2pin)

Connector model number
MUF-PK8K-X
J.S.T. Mfg. Co., Ltd.

5) Communication Converter

Module to convert RS232C communication to RS422A communication that is required for multiple axes connections of Servo Amplifiers.



Communication Converter: SAU-024-01

CN1	
MUF-RS8DK-GKXR J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	422TXD+
2	422TXD-
3	422RXD+
4	+5V
5	232TXD
6	422RXD-
7	232RXD
8	GND
shell	Shield

CN2	
MUF-RS8DK-GKXR J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	422TXD+
2	422TXD-
3	422RXD+
4	+5V
5	-
6	422RXD-
7	-
8	GND
shell	Shield

CN3	
DELIC-J9PAF-23L9E J.S.T. Mfg. Co., Ltd.	
Number of pins	Signal name
1	DCD
2	RD
3	TD
4	DTR
5	SG
6	DSR
7	RS
8	CS
9	RI
shell	Shield

SW Selection		
Number	Selection	
SW1	232C	422A
	RS232C signal of CN1 is valid	RS422A signal of CN1 is valid
SW2	STRAIGHT	CROSS
	Cable between PC-CN3 Under the straight cable spec.	Cable between PC-CN3 Under the cross cable spec.

A

Adjustment 1-1, 3-11, 9-1, 9-2, 11-2, 11-4, 11-5
Advanced 3-10
AL-00689703-01.....2-1, 2-2, 12-2
AL-00695974-01.....2-2, 12-3
AL-00695974-02.....2-2, 12-3
Alarm History.....3-11, 6-1, 6-2
Alarm History Clear 6-2
Alarm Reset 1-1, 6-1, 6-3
Amplifier ID..... 11-3
Authority A..... 3-10
Authority B..... 3-10
Authority C 3-10
Automatic FF Vibration Suppression Frequency Tuning
.....8-1, 8-3, 8-4
Automatic Notch Filter Tuning 8-1
Automatic Offset Adjustment of V-REF Terminal 9-1, 9-2
Automatic Tuning 1-1, 3-11, 8-1, 11-2, 11-4
Axis Property 3-8
Axis Selection.....4-8, 4-9, 7-1, 10-8

B

Basic3-1, 3-4, 3-10, 4-1
Baud Rate selection 3-2

C

Channel Information 10-4
Communication Cable A..... 2-2
Communication Cable B..... 2-2
Communication Confirmation 3-3, 11-4, 11-5
Communication Converter..... 2-2, 12-4
Communication Setting3-2, 3-3, 3-4, 3-7
Connecting Cable A 12-2
Connecting Cable B 12-3
Connection for Single Device 2-1
Cursor Position Data 10-5

D

Data File 3-9

E

Effective Value 10-5
End Communication 3-4

H

History 4-7, 6-1

I

Installation 1-3, 1-4, 1-6, 1-7, 1-8, 11-1

J

JOG Operation 1-1, 7-1, 7-2, 7-3, 7-5

M

Magnetic Pole Position Presumption1-1, 7-1, 7-5, 7-6,
11-4
Main Window..... 3-3, 3-4
Manual Offset Adjustment of T-COMP Terminal . 1-1, 9-3
Manual Offset Adjustment of V-REF Terminal.... 1-1, 9-2,
9-3
Measurement ... 1-1, 10-1, 10-5, 10-6, 10-7, 10-9, 10-10,
11-2, 11-5
Measurement Information Tab 10-6
Measurement Value Tab 10-5
Monitor 1-1, 5-1, 7-8, 8-5, 10-3, 11-3
Motor Parameter 3-12, 4-4

N

Network Terminator 2-2
Not-corresponding..... 11-2

O

Operation Level 3-10
Operation Scrolling..... 1-1, 3-9, 10-1, 10-7, 10-8
Operation Trace..... 3-9, 10-1, 10-2, 10-4, 10-5, 10-6

Index

Operation Trace Window..... 10-2, 10-4, 10-5, 10-6
Overlap..... 11-2, 11-3

P

Parameter Change History..... 4-4, 4-7
Parameter Edit 4-1, 4-3, 11-2
Parameter Setting 1-1, 4-1, 4-2, 4-7, 4-8, 4-9, 4-11, 11-3
Parameter Verification..... 1-1, 4-1, 4-11, 4-12, 11-3
Password Function..... 3-11, 11-2
Positioning Operation 1-1, 7-1, 7-3, 7-4, 7-5, 11-4
Project ... 3-2, 3-3, 3-4, 3-5, 3-7, 3-8, 3-9, 3-10, 4-2, 4-13,
10-2
Project Property..... 3-8
Project Setting..... 3-8
Project Window 3-7

R

Running Setup Software 3-1

S

Save Result of Automatic Tuning 8-5
Save to Backup Memory 1-1, 4-13

SDI Display..... 3-6
Selecting Parameter(s) to Monitor..... 5-2
Serial Encoder Clear 1-1, 7-1, 7-7, 7-8
Servo Amplifier Connectors..... 12-1
Software Version 3-12
SW1..... 2-2, 12-4
SW2..... 2-2, 12-4
System Analysis 1-1, 3-9, 10-1, 10-9, 10-10, 10-11, 10-12,
11-5
System Parameters..... 4-1, 4-3

T

Test Operation... 1-1, 3-11, 7-1, 7-3, 7-5, 7-7, 11-2, 11-4,
11-5
Troubleshooting..... 11-1

V

Velocity JOG Operation..... 11-4
Version Information 3-12

W

Wiring 11-2, 12-1

Release	
Revision A	Dec. 2008
Revision B	Feb. 2010
Revision C	Mar. 2012

Precautions For Adoption

Cautions

The possibility of moderate or minor injury and the occurrence of physical damage are assumed when the precautions at right column are not observed. Depending on the situation, this may cause serious consequences. Be sure to follow all listed precautions.

Cautions

- Be sure to read the instruction manual before using this product.
- Take sufficient safety measures and contact us before applying this product to medical equipment that may involve human lives.
- Contact us before adapting this product for use with equipment that could cause serious social or public effects.
- The use of this product in high motion environments where vibration is present, such as in vehicles or shipping vessels, is prohibited.
- Do not convert or modify any equipment components.

* Please contact our Business Division for questions and consultations regarding the above.

SANYO DENKI CO.,LTD.

1-15-1, Kita-Otsuka, Toshima-ku, Tokyo 170-8451, Japan

SANYO DENKI AMERICA,INC.

468 Amapola Avenue Torrance, CA 90501 U.S.A.

SANYO DENKI EUROPE SA.

P.A. Paris Nord II, 48 Allée des Erables-VILLEPINTE, BP57286, F-95958 ROISSY CDG Cedex, France

SANYO DENKI GERMANY GmbH

Frankfurter Strasse 92, 65760 Eschborn, Germany

SANYO DENKI KOREA CO.,LTD.

9F 5-2, Sunwha-dong Jung-gu Seoul, 100-130, Korea

SANYO DENKI SHANGHAI CO.,LTD.

Rm2107-2109, Bldg A, Far East International Plaza, No.319, Xianxia Rd., Shanghai, 200051, China

SANYO DENKI TAIWAN CO.,LTD.

Room 1208, 12F, No.96 Chung Shan N, Rd., Sec.2, Taipei 104, Taiwan, R.O.C.

SANYO DENKI (H.K.)CO., LIMITED

Room 2305, 23/F, South Tower, Concordia Plaza, 1 Science Museum Rd., TST East, Kowloon, Hong Kong

SANYO DENKI SINGAPORE PTE. LTD.

10, Hoe Chiang Road, #14-03A/04, Keppel Towers, Singapore 089315

<http://www.sanyodenki.com>

Phone: +81 3 3917 5157

Phone: +1 310 783 5400

Phone: +33 1 48 63 26 61

Phone: +49 6196 76113 0

Phone: +82 2 773 5623

Phone: +86 21 6235 1107

Phone: +886 2 2511 3938

Phone: +852 2312 6250

Phone: +65 6223 1071

The names of companies and/or their products specified in this manual are the trade names, and/or trademarks and/or registered trademarks of such respective companies.

*Remarks : Specifications Are Subject To Change Without Notice.