


SD Cards MDVR

SD CARDS MDVR

USER'S MANUAL



V1.0

Tips: please read this manual carefully before using, and we reserve the right of final interpretation

LIST

Preface -----	1-1
Section 1: Product Specifications -----	2-3
Section 2: Interface Definition and Function-----	4-10
Section 3: Common Shortcut Setting and Operation-----	11-15
Junction Test and Startup-----	11-11
Text Input-----	11-11
Video Setting-----	12-12
PTZ Connection and Settings-----	13-13
PC Playback of Video File-----	14-14
Fast Report from Vehicle gServer-----	15-15
Section 4: Instructions of Menu Functions-----	16-29
Device Start-up and User Login -----	16-16
Organizational framework – general settings-----	17-17
Time Settings – Network Settings – Vehicle Information – Password Settings ----	18-18
Video settings-General settings-Encoding settings-Sub-stream-Video plan--	19-20
Alarm settings – Sensor settings – Speed-----	21-21
Temperature Settings – Motion Detection settings-----	22-23
System Tools – Format-----	23-23
Configuration Management – Log Search-----	24-24
The Peripheral Management – System Upgrade – PTZ Settings-----	25-25
Wireless Broadband-----	26-26
Wifi Settings -----	27-27
Video Serching-----	27-28
System Information-----	29-29
Attachment 1: gServer Platform Interface-- -----	30-30
Attachment 2: Common Problems and Treatment- -----	30-31
Attachment 3: Memory Space Correspondence Table-----	32-32

PREFACE:

A:Features Introduction

MDVR is a kind of cost-effective device with strong functional scalability which is specially designed for vehicle video monitoring and remote monitoring. It is developed by high-speed processor and embedded Linux platform, combined with the most advanced H.264 video compression / decompression technology, network technology in the field of IT, and GPS positioning technology, using SD card as the storage medium; MDVR can realize four CIF \ HD1 \ D1 format of audio and video recording, vehicle driving information recording and GPS positioning signals uploading functions. MDVR with the center software can realize functions of alarm-linkage center monitoring, remote management and playback analysis. This product is with simple appearance and all-metal housing design; it is also with characteristics of scalability, super anti-vibration, flexible and convenient installment, powerful function, high reliability, good heat dissipation and stability. Four audio and video input, selectable resolution D1/HD1/CIF; H.264 video compression algorithm, Linux operating system, supporting dual-stream; Built-in 3G (WCDMA / EVDO / TD-SCDMA), WIFI, GPS module (highly scalable); Support two SD card (dual card storage longer); Support digital watermark function; Rich peripheral interface, Such as: RS485, RS232, RJ45, MIC, SPEAK interface; 3-8 second delay of power off to protect data, preventing loss of video data from momentary power failure; Vehicle black box function, recording speed, location (with GPS), acceleration and other information; Standard industrialization embedded design, low-power consumption, all-metal aluminum housing, anti-explosion, anti-vibration, good heat dissipation; DC8V ~ 36V wide voltage power supply

B:Notices

In order to ensure the safe use of MDVR to get satisfying performance, please consider the following factors completely in the installation of device:

1: Comply with the specifications of all electronic products, requirements of the vehicles and other connected devices when install and operate this device;

2: Power and Device Grounding:

Device power input range DC 8V-36V, please be careful not to reverse, the output cannot be short-circuited. Please pay attention to the power supply capacity of the power cord. Even if the device is turned off, the machine is also charged, please avoid a short circuit. Disconnect the device and the power before connecting to other external devices; Its output voltage is 12V, only can be used for the camera power supply. Please do not use on any other devices without permission. The sensor input mode is electric frequency mode, it is considered as low frequency electric when an external voltage is less than 4V, considered as high frequency electric when is less than 30V but greater than 4V, in case of 30V above, it will result in device damage when device grounding is recommended

3: Humidity requirement:

Install the device in a dry environment, avoiding wet, dripping, spray and other places. Do not install device in depression place or liquid dripping wet places; Do not touch the device with wet hands; Do not touch the device when stand in water or in water contact, which will have risk of electric shock;

4: Installation location:

In order to extend the life of device, please try to install the device in the location with less vibration on vehicle, such as the back of the driver's seat. It should be installed in the airy place inside the vehicle; it should keep 6 inches (15 cm) from other objects when installed in plane, in order to facilitate air circulation and heat dissipation; it cannot be installed in a closed space, such as the vehicle trunk. It is recommended to be put straight up which can extend the life of hard disk, while side-mounted can easily damage hard disk; external wire must have enough interval and protection by fire-retardant pipe, to ensure that the wire will not be bent or leakage due to vibration and wear; please ensure that the device is away from the heat source on the vehicle, and it is prohibited to place any debris on the device.

5: Device safety:

Make sure that the passenger or the driver cannot interfere and damage the piece of device, cameras, wires and other accessories, do not install the device near any restricted vehicle components; it may cause the damage of device when start the vehicle during the installation of device components, cameras, accessories and wires, must make sure that the vehicle is stationary during the installation process to prevent the device from falling.

1. This device includes electronic components, please handle with care during transportation.
2. Installation and maintenance must be performed by professionally qualified persons.
3. It cannot be installed in any eroded places by rain or other liquid
4. It cannot be put under any heavy stuffs
5. Keep it away from heat, dust, and strong magnetic field, do not directly flush
6. Do not replace any module when main body is powered on.
7. Do not open or disassemble the device without guidance of professionals.
8. Device output power shall not lap any non-recommended

Section 1: Product Specifications

1.1: Product Specifications

Table 1: MDVR Specifications

Project	Device parameters	Performance indicators
System	Operation Language	Chinese/English
	Operation Interface	Graphical menu interface (OSD menu)
	Password Security	Two Management Level--User password, administrator password
Video	Video Input	Four composite video inputs
	Video Output	Two video outputs (one ϕ 3.5 Phone Jack, the other one IN 24PIN)
	Video Display	Single-screen, four-screen display
	Video Standards	PAL, NTSC standard
	Image Compression	H.264 Main profile, compression resources to 100/s
Audio	Audio Input	Four Audio Input
	Audio output	Two Audio outputs (one ϕ 3.5 Phone Jack, the other one IN 24PIN)
	Recording Method	Sound and video synchronized recording
Image processing and storage	Image format	three resolution options CIF/HD1/D1
	V streaming standard	ISO14496-10
	Video bit rate	CIF: 1536Kbps ~ 128Kbps HD1: 2048Kbps-380Kbps D1:2048Kbps ~400Kbps 8 levels of optional quality, 1 this the highest, 8 this the lowest
	Audio bit rate	8KB/s
	Data Memory	Support 2pcs SD card, one of which can support 128GB
Alarm	Alarm input	Four alarm inputs, 4V above will be high frequency electric alarm
	Alarm output	One alarm output, output high frequency 12V
Interface	RS485	Two RS485
	RS232	One RS232
	Rj45	One Rj45, Which can be used for external WIFI,
Talkback	MIC	MIC+,MIC-
	SPEAK	SPEAK+,SPEAK-
Wireless	3G	built-in 3G(HSDPA/EVDO/TD-CDMA)(optional)
GPS	GPS coordinates, GPS speed etc. which can be written into code stream, and upload wirelessly as well (optional)	
Acceleration sensor	External, built-in acceleration sensor G-Sensor (optional)	
Supporting software	PC playback	PC playback of video files, and analyze the vehicle information in file
	gServer	Centralized management of software to achieve the preview, etc.
Software upgrades	This device supports the upgrading by SD card	
Work environment	Operating voltage	Input voltage DC8-36V, Out of range, the device is switched off.
	Power output	Output voltage 12V ($\pm$ 0.2V) , Maximum current 2A。
	Input impedance	Each input impedance is 75 Ω
	Operating Temperature	-25 $^{\circ}$ C - 70 $^{\circ}$ C
	Operating Humidity	20%-95%
	Impact limit	$\leq$ 2000G(19,600m/s ²)
	Vibration limit	$\leq$ 15mmp-p(5-22Hz)49m/s ² (5G)(22-500Hz)
	Power consumption	under normal working status $\leq$ 10W, when standby<0.5W。
Machine Size	Device size	170(W)mmx50(H)mmx142(L)mm
	With protective cover	170(W)mmx50(H)mmx187(L)mm



Note

With the constantly updating of our products, this technical specifications table will also have occasional updates. Our company reserves the right to change the product's technologyThe parameters without notifying customers!


Table 2: MDVR Product Specifications II (Economic type)

Project	Device parameters	Performance indicators
System	Operation Language	Chinese/English
	Operation Interface	Graphical menu interface (OSD menu)
	Password Security	Two Management Level--User password, administrator password
Video	Video Input	Four composite video inputs
	Video Output	One video outputs (one ϕ 3.5 Phone Jack, the other one IN 24PIN)
	Video Display	Single-screen, four-screen display
	Video Standards	PAL, NTSC standard
	Image Compression	H.264 Main profile, compression resources to 100/s
Audio	Audio Input	Four Audio Input
	Audio output	One Audio outputs
	Recording Method	Sound and video synchronized recording
Image processing and storage	Image format	three resolution options CIF/HD1/D1
	V streaming standard	ISO14496-10
	Video bit rate	CIF: 1536Kbps ~ 128Kbps HD1: 2048Kbps~380Kbps D1:2048Kbps ~400Kbps 8 levels of optional quality, 1 this the highest,8this the lowest
	Audio bit rate	8KB/s
Alarm	Data Memory	Support 2pcs SD card, one of which can support 128GB
	Alarm input	Four alarm inputs, 4V above will be high frequency electric alarm
	Alarm output	One alarm output, output high frequency 12V
Interface	RS485/RS232	One Rs485 One Rs232
GPS	GPS coordinates, GPS speed etc.	which can be written into code stream, and upload wirelessly as well (optional)
Acceleration sensor	External, built-in	acceleration sensor G-Sensor (optional)
Supporting software	PC playback of video files, and analyze the vehicle information in file	
Software upgrades	This device supports the upgrading by SD card	
Machine Size	Machine Size	154(W)MMx45(H)MMx125(L)MM

1.2: The MDVR products application connection diagram

Please refer to figure 1--1 This product can be used for video surveillance and remote monitoring which applies in common or special vehicles such as buses, logistic vehicles, trucks, long-distance coaches, taxis, tankers, cars, school buses, police cars, patrol cars. In front-end it mainly collects video signal by dedicated automotive camera, then transmits to the MDVR host via a special video cable to do the video compression and image processing, which is locally storage in SD card. It can also be remote monitored or remote video recorded and downloaded by the remote client if with 3G models. It can real-time locate the vehicle position; Figure 1-1 schematic diagram is a common mode of application, each function during actual use will vary with the presence of module.

Figure1-1



MDVR Schematic diagram

Section 2: Interface Definition and Functions

2.1: The MDVR overall appearance & structure diagram (model ONE)

Unit: mm




Figure 2-1 Device structure and Size diagram(1)




Figure2-2 Schematic diagram

2.2: MDVR Functional schematic of the front panel




Figure 2-5 SD/SIM card Installation




Figure 2-6 Indicators Illustration

Panel Lights Instruction:

AV-OUT: Audio and Video output

SD1/SD2: Video SD card indicator
light on when the SD card exists

REC: Light on when recording

GPS: Light on when GPS module exists

POWER: Light on when power supply on

ALM: Light on when the machine in abnormal

CAM: Light on when video input 1/2/3/4
has signals; otherwise light off

3G: Light on when 3G communication
module exists

IR: Infrared receiver receives the remote
signal

Installed SD card and SIM card:

Example Figure 2-3/4/5: Firstly host keys must turn to the UN-LOCK position, then push to open the SD card protection cover, insert SD card into slot by SD card face up, then close the protective cover; LOCK: It is necessary to shut down the electronic lock before normal starting up, the electronic lock of host is shut down only when key position twists from UN-LOCK to another position, and the host will start up when power on; If twist the electronic lock to UN-LOCK position when device is under normal working status, the system will uninstall the SD card and then extend 3-8 seconds to shut down. IM card: The host can be inserted by one SIM card under normal circumstances, two cards can be inserted when customized, SIM card insert way: metal side up, notch forward.



2.3: The MDVR Rear Panel Interface Definition




Figure 2-7 The MDVR back panel interface definition

Table 3: The MDVR rear panel interface description as follows:

Connector	Name	Explain
4PIN Audio output	AV-OUT	4PIN is made by four lines :red, black, yellow, white
GPS Antenna	GPS	GPS Antenna connector
3G Antenna	3G	3G Antenna connector
Power input	DC8-36V	Power input connector
MCU	MCU	The system debugging interface(R&D dedicated)
Sensor input	SENSOR IN	Switch input interface, valid when high level (>4V)
Alarm Output	SENSOR OUT	Alarm output (One output)
Vehicle Speed	SPEED	The device can get vehicle' s speed information
RS485	RS485	S485 data communication interface(two groups)
Rs232	RS232	RS232 serial data communication interface
Intercom	MIC	MIC intercom microphone interface
Amplifier	SPEAK	ntercom audio power amplifier output
5V Output	5V-OUT	DC 5V output (usually power for intercom speakers)

2.4: MDVR overall appearance & structure diagram (model Two)

Unit: mm




Figure 2-8 Device structure and Size diagram(2)

Unit: mm




Figure 2-9 Schematic diagram (2)

2.5: The MDVR Rear Panel Interface Definition(2)




Table 4: The MDVR rear panel interface description as follows(2):

Connector	Name	Explain
4PIN Audio output	AV-OUT	4PIN is made by four lines :red, black, yellow, white
GPS Antenna	GPS	GPS Antenna connector
Power input	DC8–36V	Power input connector
MCU	MCU	The system debugging interface(R&D dedicated)
Sensor input	SENSOR IN	Switch input interface, valid when high level (>4V)
Alarm Output	SENSOR OUT	Alarm output (two output)
Vehicle Speed	SPEED	The device can get vehicle' s speed information
RS485	RS485	S485 data communication interface
Rs232	RS232	RS232 serial data communication interface
Amplifier	SPEAK	ntercom audio power amplifier output
5V Output	5V-OUT	DC 5V output (usually power for intercom speakers)

2.6: Simple Instruction for Common Interface Wire

A: Power Cord

As shown by below pictures, one end is a 6PIN white plug, which will be connected to the 6PIN power input connector on the rear panel of the device, the red and black wires are connected directly to the vehicle battery or the gathered electric which go through battery and fuse; red wire links to positive while the black line links to negative, the yellow wire links to firing wire, the main device automatically start up when the vehicle's key is turned on, and shut off automatically after a delay when vehicle's key is turned off; yellow wire links to the position when vehicle's key turn on all dashboard lights (the position before vehicle starts the motor).



Figure 2-11 The MDVR Interface roughly wiring

B: Audio & Video wires

Above are the general ways of MDVR rear plate interface wiring, 4PIN testing wire is only used in the test which is not recommended to be used in installation, it is recommended to use 4PIN audio and video extension cord during installation; MDVR need dedicated 4PIN output wires when it is connected to the audio and video output, while the $\Phi 3.5$ Phone Jack interface in the front panel can also output audio and video. Its peripheral interface can be optional 3G/GPS, which then will need to use 3G antenna and GPS antenna, as shown in Figure 2-11

- Note**
- 1: Need to make sure the battery voltage is between 8V-36V before connecting, otherwise above voltage will burn out the device;
 - 2: Pay attention to the insulation among the power cord after connection to prevent the short circuit of the power cord which will burn out the battery and other electrical equipment in the vehicle;
 - 3: It is recommended to link the yellow wire to the firing wire, otherwise the device will not support the delayed shutdown;
 - 4: The installation of vehicle-mounted is recommended to directly take from battery positive and negative, or pick from the main electrical with fuse, do not use ground because ground will produce negative pulses which will interfere with the normal operation of the host. The diameter of positive and negative power cord must be more than $\Phi 1.5\text{mm}$;

C: Alarm input & output

This device has 4 alarm input and one alarm output interface, alarm input detection are all level detection which can be accessed by a variety of vehicles driving state, such as brakes, steering, keyless entry, an emergency alarm button etc. Brake, as shown in Figure 2-12, when the brake pedal is depressed, MDVR will be able to detect high level, otherwise low level is detected. Alarm output are all level output with drive capacity of 200mA, if you want to access the devices with larger power ratio, it is necessary to use external relay; alarm output photoelectric alarm wiring diagram in Figure 2-13 as below.




Figure 2-12




Figure 2-13

2.7: SIM Card Installation

If the MDVR supports 3G wireless communication module, you will need to install SIM card which is suitable for WCDMA / EVDO / TD-CDMA . SIM card is in the front motherboard of the host, when the host key swifts to UN-LOCK, open the SD card protective cover to left to expose the SD card slot and SIM card slot, Metal SIM card face up, and the gap aligned forward, mouth pressed into place, please remember to pay attention to the positive and negative as well as direction when inserting SIM card, after installation, cover protective cover, then lock keys.




Figure 2-14

2.8: Remote Control Function keys Description




Table 5: Remote Function Description:

LOGIN	When VCR has a password, press the LOGIN button to enter the password, Since the system does not have restoring or resetting function, please remember the password
INFO	Information Review
FOUR SCREEN-SPLIT NUMERIC KEYPAD	They are used to switch between the four-screen and single screen on the monitor screen; press screen-split key to display 4 screens, press the number 1/2/3/4 to correspondingly display channel 1 – channel 2 –channel 3 – channel 4
RETURN	Return to the upper layer of the sub-menu. Eventually exit the setup menu and return to the monitor screen;
PAUSE/STEP	Pause key when play back image & data and single-step play key as well, each press can play one step, press arrow keys to resume normal playback speed;
PLAY	Button of starting play(press this key to play when you have searched and selected the video file)
FORWARD	Fast forward key when play back video data , fourth gear: 2X, 4X, 8X, 16X
REW	Rewind key when play back video data , fourth gear: 2X, 4X, 8X, 16X
NEXT	Turn to next page/next one of searched files;
PREV	Turn to previous page/previous one of searched files;
PTZ FUNCTION KEYS	Automatic, preset, recall, zoom +, zoom – focus +, focus – aperture +, aperture –, PTZ PRESET, RECALL, BRUSH
F1、 F2、 F3	F1 F2 F3 is the function testing key

Section 3: Common quick setting and operation

3.1: The Junction Test and Start Up


The host's power cords are red, black and yellow, red and black wires connect directly to the vehicle battery or go through vehicle fuse, the red wire links to the positive, while black wire links to the negative, yellow wire links to firing wire ACC (the position before vehicle to start the motor). However, if under other testing environment without vehicle, following wiring method is needed: twist red and yellow wires to link to the positive, black wire links alone to the negative, then you can use the switch power supply above DC12V-5A to supply power to the host.

1: When power is supplied after correct wiring, the PWR blue light on the panel will keep on, standby

2: Connect the output wire AV-OUT to display and connect other according devices to the host, make sure the connection is correct.

3: Need to turn off electronic lock with a key to the LOCK position (required) is the normal starting up, the corresponding light turns yellow after starting up.

Below Figure 4-1 is testing wiring, as well as the power supply wiring during actual loading.



Note

- 1、The power supply voltage input range is DC8-36V, when there is only a blue light on, it is a standby state which is not really starting up; more than one light will be on under normal start up status.
- 2: The host can not be delayed shutdown when you use testing wires for the power supply of host.

3.2: Text Input

Need to use input method when input text, such as the company name, license plate number, driver's name, line number, and other text input needs when requires input method under other menu. Take inputting "Yue B95886" for example after entered the input interface to illustrate the input steps

Step One: in the state of Chinese input, as shown in Figure 4-2, Character YUE(GuangDong)'s Pinyin is YUE, move the cursor to press ENTER key to input the first Chinese letter y, it will display the corresponding PinYin combination 1-5, if there is no PinYin as YUE, please press the FWD key on the remote control to the next pages; when it shows 1.you 2.yu 3.yuan 4.yue 5.yun on the next page, please press the number 4 on the remote control which will show 1-5pcs of Chinese characters, if there is no YUE character, please use FWD button to turn the pages; when it shows 1 read 2 key 3 Yue 4 Guangdong Yue, please press 4 to input the first Chinese character YUE(GuangDong).

Step Two: Now you will need to input the letter B, move the cursor to press ENTER key to switch the input method to the state of capital letters, as Figure 4-3, then move the cursor onto the letter B to press ENTER key to input it.

Step Three: Next you will need to enter numbers, press it again to switch to Chinese input state, you can not input numbers under Chinese input state, then you need to move the cursor to the "in (middle)" word, press ENTER key to turn to EN, and then enter numbers 95886.

After the completion of above steps, press the RETURN key to go back and save, other text input under other menus will be more or less the same. Please press CANCEL to delete it when there is a typo during the input process.

1.ya 2.yan 3.yang 4.yao 5.ye										
0	1	2	3	4	5	6	7	8	9	
q	w	e	r	t	y	u	i	o	p	
a	s	d	f	g	h	j	k	l	Back	
中	z	x	c	v	b	n	m	.	↑S	

Figure 4-2

!	?	/	\	%	,	#	*	(	)	
Q	W	E	R	T	Y	U	I	O	P	
A	S	D	F	G	H	J	K	L	Back	
EN	Z	X	C	V	B	N	M	.	↑S	

Figure4-3

3.3: Video settings

1: Video Start Up

After the installation of a new SD card in the device, the formatting is recommended after normal boot into the system, in order for system to have better compatible relationship with its format. After the formatting, host will automatically start up the video when restart.

2: Timer recording

Firstly modify to be timing video under the System menu – Video Settings – General Settings – Video mode, save and return to the previous menu level to be video plan, and then set the time period of the video; save it after setting finished.


3: Alarm recording

Firstly modify to be alarm recording under the System menu – Video Settings – General Settings – Video mode, then set the alarm pre-record time (range 0 –60s) and alarm video delay (30–900s); alarm output delay (5S–255S), which can be set according to the actual external alarm device.

Secondly it is needed to install the corresponding external alarm input device, such as the emergency button set by sensor, power switch for open/close door, brakes lights and other sensors; the following are the several main alarm settings of this device:

A: The sensor input alarm system, system menu – alarm settings – sensor settings


Set the menu (in Figure 4–21) with high or low trigger level, and then turn on the alarm; this menu is corresponding with four external alarm input SENSOR IN (which can be for eight external alarm output), it must be connected to the corresponding external sensing switch device, such as door–magnet power supply, emergency button, turning signal switch, brake lights (Figure 2–12), etc; rough connections are shown in Figure 3–4.



B: speed alarm setting system menu – alarm settings – speed setting

If the vehicle selects the GPS to get speed information which requires normal status of the GPS signal, then we need to set a high threshold speed limits, such as 100km / h that is the maximum speed limit, alarm is opened when vehicle is started; vehicle will output alarm when the vehicle speed exceeds 100KM / H

If you choose to obtain speed information from the vehicle, it must be connected to the speed pulse sensor, which is used to calculate the speed ratio (coefficient = pulse/speed), the pulse sensor is connected to the two wires SPEED–A and SPEED–B of our device, the speed ratio will be measured according to the set speed and pulse during vehicle' s moving, which is a little complicated to operate; simple wiring in Figure 3–5.



C: The acceleration alarm recording system menu – alarm settings – acceleration

Impact acceleration can be understood to be for a three-dimensional XYZ coordinate axis which can denote three groups of status---up and down, left and right, front and rear; the bouncing up and down, accelerate, Emergent brake, rollover, sharp turns, etc. during the moving process of the vehicle can all be expressed in XYZ. Threshold needs to be set by an associated value, it is firstly needed a calibration after the installation onto the vehicle, the calibration means to clear parameters X / Y / Z, secondly measure the allowed range of emergent brake & acceleration & bouncing up and down as well as the change value of a sharp turn of the vehicle during the operation, thereby to determine which axis' s value changes a lot. These run status will be in real-time display and change. After setting the threshold, when the vehicle runs exceed above threshold, the alarm will be uploaded if the "alarm" opens.

D: Motion detection alarm recording System Menu – Alarm Settings – Motion Detection

Turn on the motion detection enabled switch, set the sensitivity level of high, medium and low based on the need, general settings is medium, and the next step is mostly to set the sensing area of the motion detection, motion detection area will use diagonal set, please refer to Figure 4–30. As long as you set the motion detection area and set the video mode as alarm recording, the image move will trigger the video to generate alarm recording files (Note: it can only take effect after setting and saving)

3.4: PTZ connection way and setting System Menu – Peripherals – PTZ settings


Setup steps:

Firstly, select the PTZ protocol: divided into PELCO-D and PELCO-P protocol, most of people will choose PELCO-D


Secondly, set the baud rate: there are four options 1200/2400/4800/9600 which must be corresponded with the baud rate on PTZ

Thirdly, set the address code: directly input the address value corresponding with PTZ setting, corresponding is required. Generally the defaulted PTZ address code is 1, PTZ address code has adjustable DIP, it is needed to set different address codes to identify when there is many PTZs.

Fourthly, wiring: Connect control wire 485 on the PTZ to the RS485-A positive pole, connect the other one to the RS485-B negative pole.



! Note After wiring and parameters setting of PTZ, users can only use remote to control PTZ after selecting the channel access to PTZ, for example, if PTZ connects through channel 2, then you need to switch to channel 2 maximize on the monitor interface to control it.



Fifthly, there are three ways of wiring, the first way is connecting the 485 control wire to the wire 485A and 485B on host, connecting the video cable to the host video input and then provide power to PTZ; this kind of wiring needs to set the MDVR host data be corresponding to PTZ data, and then use the remote controller or platform to remotely control PTZ.

The second way, the head of the 485 control wire directly connect to the three-dimensional control keyboard, do not need to connect the MDVR host, the video cable connects to the host video input, separately power supply to the PTZ and three-dimensional keyboard, and then set the keyboard parameters to be corresponding with PTZ. This wiring way is the most practical one, because it uses three-dimensional keyboard to control PTZ, which is faster, easier and more practical. It is recommended to use this way to install PTZ

The third way is to connect to both car host and three-dimensional control keyboard, so that both can be controlled and platform remote can also be controlled.

3.5: PC playback of the video file

Besides playback by the host side, video files can also be copied to your computer to be played by the player. Install the player

Double-click the installation file named MDVRPlayer V1.0.1.exe in the CD-ROM, and then select the installation language (supporting Chinese and English), click OK and then keep clicking 'Next', a player shortcut icon will show on the desktop after installation completion; installation steps shown in Figure 3-7




Figure 3-7

Remove the SD card from host and insert it into the card reader, then connect it to the computer's USB port, the computer automatically recognizes the newly installed hardware; video files are stored in the form of date folder, open the folder to display video file, video files are named with suffix ".264". As shown by Figure 3-8, the screen show of playing the file in Figure 3-9




Figure 3-8




Figure 3-9

3.6: Fast report by vehicle server gServer

Note: The following described is invalid to the host which is without 3G module, it is not needed to report to gServer platform
Step 1: Install the SIM card, 3G card which supports WCDMA / EVDO / TD-CDMA, detailed installation please refer to Chapter II, 2.2, and 2.7

Step 2: Enter into the system menu after starting up, firstly modify the host's device number, System Menu – General Settings – Vehicle Information – Device Number, device number range is from 00000 to 99999. Server identifies the host according to the device number, so it is very important to modify the device number.

If the modified device number cannot be reported sometimes, please check the server device number has been used or not.

Step 3: Modify the vehicle identification number; the vehicle information displayed on gServer platform is based on vehicle identification number. If it is not modified, it will display 00000 in default. If all are in default, it would cause inconvenience to find vehicles. So it is proposed to modify the vehicle identification number.

Step 4: Enter another menu settings, System Menu – General Settings – Network Settings, set the server IP and control port, the server

can be self-built, and can be affiliated to the manufacturer's server as well, enter the server IP and control port, which is typically 6608, the save by end.

The main process of gServer quick reporting is as Figure 3–10 below.




Figure 3–10: gServer reported to the server process

Step 5: Enter the system menu – peripheral – wireless broadband, which is with wireless settings inside.
A: wireless 3G settings

Please pay attention to the supporting type of network during wireless 3G setting: WCDMA, EVDO and TD-SCDMA. Also note the access point and the center number, The user name is in default in domestic which is basically not needed to modify, however there is also in some domestic places the 3G card needs to be entered by user name and password, and some foreign operators will need to enter user name and password as well, the access point and the center number will need to be modified too, which is required to input relevant information according to the local network data. You can press INFO key to query whether dialing is successful or not after setting.

CHINA WCDMA	CHINA EVDO	CHINA TD-SCDMA
ENABLE: ON	ENABLE: ON	ENABLE: ON
TYPE: WCDMA	TYPE: EVDO	TYPE: TD-SCDMA
APN: 3gnet	APN: Ctnet	APN: cmnet
CENTER NUM: *99#	CENTER NUM: #777	CENTER NUM: *99#
USER NAME: card	USER NAME: card	USER NAME: card
PASSWORD: ****	PASSWORD: ****	PASSWORD: ****

C: local IP settings

Local IP setting is the setting after the RJ45 port access the network cable, set the local IP and central server number to make it be linked from local area network to WAN through the network cable, which can also report to gServer server platform.

IP ADDA	192.168.000.018
NERMASK	255.255.255.000
GATEWAY	192.168.000.001
MAC ADDA	00:FD:00:00:00:SE
SERVER IP	192.168.000.208
CONTROL PORT	6608

Step 6: Previous steps are the network connecting ways. When the network is connected, the next step is the operation of software management on the PC gServer, which is divided into two steps. One step is the gServer Manage username allocation and vehicle adding, if it is a self-built server, this work can be done internally; if affiliated to manufacturer's server, this will need assist from the technical staff to add. The other step is to log in gServer Client by user name to review, which ultimately achieves gServer reporting, please refer to the CD-ROM gServer technical documentation for client's detailed operation

Section 4: Menu function instructions

4.1: Device Start-up and User Login In

After host is installed in vehicle environment according to the installation instructions, start it up by ensuring that power supply and other external devices are connected properly, normal start-up screen as Figure 4-1. The machine starts to enter the normal quad monitor interface, as shown in Figure 4-2.




Figure 4-1



Figure 4-2

Press the LOGIN button on remote control to go directly into the login screen as shown in Figure 4-3

Description:

1. Device No.: user set the unique device number to each device, which will automatically display on the right of the ID input box, it is required for unique device number for the same server, device number modifications please refer to section 4.3-2
2. Username: Include administrator and operator, the Administrator has the authority to operate on all menus. Operator has only view permissions.
3. Password: Enter the appropriate password according the selected username, select down key to move to "OK" and press "ENTER" to log in when the password is correct; when password is incorrect, prompts login password error message, press OK to reenter the password. The initial password for administrator is 111111. The system menu interface after login is as shown in Figure 4-4.




Figure 4-3




Figure 4-4

The system menu includes seven main menus: General settings, video settings, alarm settings, system tools, peripherals, video search, system information; as shown in Figure 4-4



Note

- 1、All of the following sub-menu settings must be confirmed to [save] to take effect, otherwise the setting is invalid.
- 2、The check box ☐ filled means this function is selected, unfilled means it is not selected.
- 3、Numbers can be inputted directly by the number keys on the remote control or using the soft keyboard. Letters input must be completed through the soft keyboard, Press [RETURN] for submenu to go back.

4.2: System Menu Organizational Framework




Figure 4-5

4.3: General settings




Figure 4-6



Figure 4-7

General settings is the first menu in system menu, the generic setting interface contains four function options: date and time, vehicle information, user management and network, as shown in Figure 4-7.

4.3-1: Date & Time

Set the system time and some other basic properties of the device, as shown in Figure 4-8

1. Date Format: Press "ENTER" drop-down menu to use the arrow keys to select the output format of date (year-month-day, day-month-year, and month-day-year).
2. The date and time settings: two ways for time proofreading ---GPS time proofreading and manual time proofreading, when select GPS time proofreading, the modified time will change because of reaching the GPS time proofreading point, so if you want to modify the time, it is suggested to choose manual time proofreading mode, which can be in normal after modifying time. Way of modifying the time and date: move the cursor to the number which needs modification and directly press the corresponding number keys on the remote control, press the save button after set.
3. Operating timeout: three options---1 minute, 5 minutes, 15 minutes for choosing to set how many minutes later will automatically exit the menu after entering the menu. General settings menu interface

General settings menu interface



Figure 4-8



Figure 4-9



Figure 4-10



Figure 4-11

4:When the GPS time proofreading opens, in the default time zone, such as the default GM +08:00 time zone, system will automatically proofread time by GPS when it reaches time proofreading point.

5:Switching machine: the ignition mode / timer mode, the ignition mode is that MDVR began to start up after vehicle starts its key, this operation is recommended as the preferred default starting-up. timer mode is the operating mode of startup and shutdown at the point of time set by the user.

6:Off delay: Either the ignition mode or timer mode, as long as the wiring is correct, you can set the delay off of host, delay off time range is from 5 minutes to 180 minutes, MDVR will continue to do the video recording by the delay off set time before shutting down when the vehicle is turned off.

4.3-2: Vehicle settings

1:Device No.: user sets a unique device number to each device, which will automatically display on the right of the number input box. The device number is 5 digits & characters, digits are effective. If it is 3G device, it is strongly suggested to set a unique device number, because a server requires only one device number.

2:Vehicle identification number: this number is recommended to be set during installation, because the vehicle identification number will be superimposed onto the video during video encoding to be strong video evidence. If you do not enter the vehicle identification number, then it will show 00000 in default. For detailed input method, please refer to Chapter 3.2

3:Line number, company name, the name of the driver can fill out as demand

4.3-3: User management settings

password setup interface is shown in Figure 4-10

1.Password effective settings to select on or off

2.Only administrators have permission to modify the passwords of users and administrators. Ordinary user's password is initially set as 000000, and the initial password for administrator is 111111.

When password change finishes and exit menu, it will need to use new password to log in again, the login screen shown in Figure 4-3.

4.3-4: Network Settings

Network setup interface is shown in Figure 4-11

1.IP address Mask Gateway etc are LAN network setting after plugging in the network cable, there is no need to input if you do not use them.

2.Server's IP address is the one MDVR host using 3G to report to gServer platform central server, which generally is the public fixed IP, the IP address must be set up, or else 3G host cannot report to platform; this requires our host can support 3G; this menu will no need of setting if the host is without 3G module.

3.Control port: set to be the port number of the gateway server, generally the default is set to "6608" port

4.4: Video settings

It is divided into four video settings menu, General Settings, encoding settings, sub-stream settings and video programs.

The MDVR needs settings in order to achieve the best video, video will start work after host start up in default, but in order for better video function of host, the relevant parameters can be modified. Video setting menu shown in Figure 4-13



Figure 4-12



Figure 4-13

4.4-1: General Settings



Figure 4-14

Description:

1. Selectable video format PAL / NTSC
2. Selectable video mode: startup recording / alarm recording and timer recording
3. Sectional Time options 15/30/45/60, that is to say, video file will be packaged per such period of time, due to the limitation of the SD card writing speed and to make the packaging of the video file segments faster, it is recommended to choose 15/30 minutes.
4. Automatically overwrite can be selectively turned on / off, when it is turned on, video file will automatically overwrite the earliest video when SD card is full.
5. Alarm pre-recorded time: when the alarm occurs, it will package the videos happened before alarm occurs to alarm recording (range 0~60S)

6. The alarm recording Delay: when the alarm stops, it will package the videos happened after alarm stops to alarm recording (delay range 30~900S) to form an alarm recording file.
7. Alarm output time: the continual alarm output time after the alarm occurs and connects to external alarm device: output time(5S ~ 255S)
8. Protection time of alarm recording, that is, storage time for alarm recording in SD card, in the protective period of time, even if the SD card is full alarm recording will not be overwritten, and the drop-down menu optional 1/3/5/7/10 days, it is recommended to set 1 or 3 days according to the current capacity of the SD card.

4.4-2: Encoding settings




Figure 4-15



Figure 4-16

Encoding settings interface as shown in Figure 4–16

Definition: Optional D1/HD1/CIF; Frame Rate: PAL is adjustable 1–25 frame, full frame rate of 25 is real-time video; NTSC is adjustable 1–30 frame, full frame rate of 30 is real-time video.
 Quality: optional level 1–8, among which level 1 is with the highest quality while level 8 is the lowest; quality setting will directly affect the effect of video playback. Under the same resolution, the higher quality level is, the clearer display effect it would have, of course, the video files will take up relatively large space. When some channels do not need video which means no need of video or recording, the channel switch can be closed in order to save the storage capacity of the SD card.
 Recording: here the volume is the volume switch for device recording, when the channel is connected with a pickup, it can open the recording of the channel.
 Preview: Preview is open by default, the function of preview is to make video normally show in the channel, if you turn off the preview, then the channel image cannot be seen, but in fact the image is still there and be video recorded.



4.4–3: Sub-stream settings

Sub-stream is important parameters when the video, audio and data are uploaded to the network via 3G, as shown in Figure 4–17, and its settings is related to whether the video displayed on gServer platform is clear and smooth. Of course, the most important factor for network transmission is the up and down rate of the local network broadband. Video resolution can be set as CIF and QCIF.

1. The corresponding relationship between bit rate setting and the frame rate changing is shown as below, the bit rate set here is the transmission rate of a channel.
2. The frame rate setting is changed according to the corresponding bit rate change; it can be set as bit rate 96 frame rate 10 in default. This setting is the current one that can guarantee fluency as well as a certain resolution when 3G network transmits audio and video, but you can set this based on your own network situation, if under good enough network bandwidth, it can be set with higher frame rate and bit rate and it can also be set automatically.

Bit rate 16–24–32–40–48–56–64–72–80–96–128–160–200–256–384–Auto
 Frame rate 01–02–3–4–5–6–7–8–9–10–11–12–13–14–15–25

Sub-stream set is a basic set of network transmission




Figure 4–17




Figure 4–18

4.4–4: Video plan (24-hour clock)

1: If you select timer recording mode in "video mode" as shown in Figure 4–14, you need to set what the timing period is.

Figure 4–18, move the cursor to the required time period; press the number keys on the remote control to input. Timer recording mode is not commonly used, customers can use it according to the actual situation, most of customers still choose the starting-up recording and alarm recording.

4.5: Alarm settings Alarm settings menu includes settings of sensor, speed, acceleration, temperature and motion detection, etc.




Figure 4-19




Figure 4-20

4.5-1: The sensor setting – (alarm input)

1. Users define the sensor name according to the different setting interface when install MDVR; take Figure 4-21 for example, to modify the name "INPUT" to be Chinese 'front door, brake', you can press the 'ENTER' key and then input under the soft keyboard Chinese input state; for specific input method please refer to the similar methods in Chapter 3.2.
2. Enable opens means start the sensor, the host has 4-channel sensor input; these alarm input is generally connected onto the circuit of vehicle, such as door switch button, brake lights, turn signals, etc., sensor input with high level is effective, users generally use above 5V to form back road, please refer to Figure 2-12 in Chapter II 2.6 for schematic diagram.



Figure 4-21

4.5-2: Speed setting



Figure 4-22



Figure 4-23

1. There are two choices of speed source "GPS" and "vehicle", if you select GPS, then the speed information of vehicle can only be transmitted to the device under the situation that device has GPS module and GPS signal, the vehicle can obtain the speed of the vehicle via GPS.
2. If you select the "vehicle" to get the speed, you will need pulse sensor to calculate the speed ratio (coefficient = pulse / speed), pulse sensor links to the two cords SPEED-A and SPEED-B on device port, and the speed ratio is determined according to the set speed and obtained pulse during the vehicle traveling.
3. The speed unit KM / MPH is switchable, the high speed limit threshold is the maximum speed limit, if alarm opens, the vehicle over speed alarm can also be seen on the platform.

4.5-3: Acceleration settings



Figure 4-24




Figure 4-25

As shown in FIG 4-23, it must be calibrated before setting acceleration, the calibration is clearing up X / Y / Z parameters. The acceleration can be understood as a 3D X / Y / Z axis, respectively stands for three-group status--- up and down, left and right, front and rear, the uniform is useless, the acceleration setting mainly set the threshold, which needs to be determined. Generally speaking, the instantly acceleration is relatively large when vehicle is under emergent brake, crash, acceleration and sharp turns situations, the intuitive reflect is the relatively large threshold beating which is in waveform display of three state X \ Y \ Z when playback on PC.

4.5-4: Temperature settings



Figure 4-26



Figure 4-27

1. emperature has two kinds of unit Celsius ° C and degrees Fahrenheit ° F
2. The temperature returns onto the device via temperature sensor, as long as you set the temperature alarm threshold and it begins to be enabled. When the temperature is higher than the threshold, the device will release alarm, and it can be transmitted to the center gServer platform to record the alarm information after alarm function is turned on.

4.5-5: Motion Detection Settings



Figure 4-28




Figure 4-29

Motion Detection Settings

Select the motion detection under alarm settings module to enter the motion detection settings interface, as shown in Figure 4-29

Within the area selected by the user, the system will release alarm information after detection when there are moving objects. The motion detection alarm events can be searched in the log with the name CHL MD Alarm, the user can review these logs under the System Tools – log search. When the channel acts as motion detection, the video of the channel will be packaged into alarm recording, which users can search and play back the videos during that period of time.

Motion detection area setup steps




Figure 4-30

Select the "Settings" and press ENTER on the remote control to enter the motion detection area setup interface, as shown in Figure 4-30. Firstly: select the first box (yellow), which will turn blue after pressing "ENTER", secondly: select the second box and press "ENTER", the rectangular area which takes the two box as diagonal is selected; Thirdly: "RETURN" to the higher level interface and save.

Sensitivity is divided into three levels— low, medium, and high. Under high sensitivity state, it is capable of sensing changes in light, while under the low sensitivity state, only can detect the moving objects; customers can set the sensitivity level according to the actual situation.

4.6: System Tools It is divided into four menus under System Tools: configuration management, device formatting, system upgrades, log search



Figure 4-31



Figure 4-32

4.6-1: The formatting – disk management




Figure 4-34




Figure 4-33

Formatted SD card operation

Start up after installing SD card, please format the SD card under normal circumstances, the formatting steps are as the above

charts, then press "Format" button to choose whether to format by the pop-up boxes. It will remind the successful formatting after formatting finished.

WARNING: Formatting will delete all the data storage on the device, please confirm whether there are other documents and important information when do the first-time formatting.

4.6-2: Configuration management and log search




Figure 4-35



Figure 4-36

Configuration management are mainly the importing and exporting system settings and the factory resetting; when execute exporting current configuration, the system will store the configuration information on the MDVR into the SD card, if other MDVR's configuration is the same with this device's configuration, then this SD card can be inserted into other MDVR to be executed by importing current configuration.

Restore the default settings: when you can not find the cause of the malfunction in the system which is set incorrectly or by artificial error, you can execute the restore default settings:, and then re-set the relevant parameters of the host, it will be asked to reboot the host after restoring the default settings.

Log Search



Figure 4-37

Log Search Results



Figure 4-38

Select start & end time, and select the type of event: all types, alarm log, system log, operation log before searching, the system will record the relevant information, such as system boot, user login, user settings, network settings, video loss, playback files, motion detection alarm, system settings, and other information.

4.6-3: Device Upgrade




Figure 4-39




Figure 4-40

Upgrade steps are as follows:

- Step 1: copy the "xxx.crc" upgrade program files to the root directory of the SD card, do not need to build any folder, copy directly to the SD card inside;
- Step 2: Insert the SD card into the SD card slot of the host, then power supply to the host, when host starts up, it will be prompted to enter the "Upgrading ..." interface upgrade, which will last about 1-2 minutes. (The equipment did not shut down, connect the device shutdown!)
- Step 3: after the success of the upgrade, the system will automatically enter monitoring four split screen. Press the INFO key on remote control to view system version information.



Note

- 1: During the upgrading process of host, do not power off or unplug the SD card, otherwise it will cause the system to crash;
- 2: Another upgrade way of host is remote upgrade through the gServer platform;
- 3: When the device does not start because of host' s upgrade misuse, it can only be suggested for depot repair;

4.7: Peripheral Peripheral settings include the PTZ setting, wireless broadband and WIFI setting.



Figure 4-41



Figure 4-42

4.7-1: PTZ setting

- 1. Agreement: divided into PELCO-D and PELCO-P protocol
 - 2. Baud rate: 1200/2400/4800/9600 four options, user can modify to different baud rate depending on different PTZ settings.
 - 3. data bit: data bits is generally to be 8, where you can select from 1 to 8, generally is 8 in default.
 - 4. Stop bit: Stop bit is generally to be 1 which is no need to modify in default.
 - 5. Parity: parity bit is to choose what kind of checking way, which is generally chosen None.
 - 6. Address Code: The address code is directly input by the address value which is corresponding with PTZ setting, they must be set in correspondence. Generally many PTZ set default address code by 1, PTZ has adjustable address code DIP, and it needs to set different address codes to identify when there are many PTZs.
 - 7. Wiring: PTZ positive pole connects to RS485-A, negative pole connects to RS485-B.
- After setting the related parameters of PTZ, PTZ can only be controlled by remote control after selecting the channel to access PTZ, for example, if PTZ connects through channel 2, then you need to switch to channel 2 maximize on the monitor interface to control it. For details, please refer to Chapter 3.4



Note

To the selected channel to access PTZ PTZ related parameters set with the remote control PTZ, for example PTZ pick on Channel 2, then monitor the interface you want to switch to a 2-channel to maximize in order to control it. Details, refer to Chapter 3.4

4.7-2: Wireless broadband

Description: When the MDVR will use 3G network to report to platform, related network settings in this menu should be done.

1. Insert the appropriate SIM card according to the communication configuration of the machine, supporting three: WCDMA (China Unicom), EVDO (China Telecom) and TD-SCDMA (China Mobile). SIM card slot is on the front panel, with a key to unlock it and open the protective cover by left, you can see two interfaces SIMA and SIMB. In regard to the SIM card installation, please refer to the second chapter of this manual 2.2 Figure 2-5, or the reference figure as follows.

2. Installed SIM card and then plug in the 3G antenna, to ensure that the system is able to receive good 3G signal.

3. Edit the following information on menu interface of wireless broadband :

A: set the module enable to be open.

B: select the type of communication, if the machine supports WCDMA type, then select

WCDMA; if supports EVDO type, then select EVDO; Press "ENTER" key to switch (it is decided by models whether it supports WCDMA / EVDO / TD-SCDMA, each model only support one type, because the internal module is unique.)




Figure 4-43




Figure 4-44

: domestic access point and the center number is generally in default, do not change; username and password in some provinces are not in default, and some do not need to enter which means they can be empty, most of the time use the settings in default will be ok. In regards to foreign 3G, it would need to be set according to the access point and the center number provided by operators, in some places abroad it must be entered by a user name and password for normal dial-up; When your host can not report, please make sure your 3G settings are correct (most of foreigners use the WCDMA device).

D: All set up needs to be saved.

4. Exit all menus, press the INFO button on the remote control, which is able to see the information of 3G communications, if the signal is good, it will display dial-up success, then the device can be reported to gServer platform with the server IP address settings, port settings, device number settings.

5. In regards to details of the three steps of reporting to gServer servers, please refer to Chapter 3.6.

EVDO



Figure 4-45




Figure 4-46

4.7-3: Built-in WIFI settings (optional)

Instructions:

Insert WIFI antenna to corresponding interface behind the host, edit the following information on WIFI setting interface as shown in Figure 4-48:

1. Set WIFI enabled and encrypted to be open. Authentication modes include WPA, WPA-PSK, WPA2-P SKOPEN and SHARED, with encryption type TKIP and AES; authentication mode is not in force yet, so only by selecting OPEN status (that's, open status does not require authentication) the WIFI can carry out normal communication, select the type of WEP encryption, which of course should be consistent with the encryption type of your router, as shown in Figure 4-48;
2. Enter separately the SSID and password (name and password of wireless network), and set up IP, mask and gateway, this setting needs to be in the same network segment as your current wireless LAN network settings. SSID / password can be set by pressing "ENTER", IP, mask and the gateway can be set by pressing the number keys;
3. View system information, shown in Figure 4-46, if the WIFI signal value is greater than -60db, then it means a relatively good WIFI signal.
4. If you want to report to the gServer server, please input gServer central IP and port number into the central IP field shown in Figure 4-11.



Figure 4-47



Figure 4-48



Note

The functionality of WIFI depends on the model, and this feature is optional, therefore, the mode to realize WIFI menu function may not be the same, which is subject to the actual development of the function.

4.8: Record Search




Figure 4-49



Figure 4-50

Enter into the video search menu, play back video files by searching for different video types (all types, conventional types, alarm types) and different storage media (SD1 and SD2). Specific files can be searched by date and time, when there is video files some day, the corresponding date will be displayed in green, as shown in Figure 4-50; searching results will be displayed after searching as shown in Figure 4-51.

Enter into the search results interface to display the related information of video file:

Firstly, there are two types--- "conventional" video and "alarm" video, conventional video is generally the video files recorded after setting up the start recording or timer recording but no alarms have occurred, while alarm video occurs when the host occurs alarm or alarm is input from external which cause host to record video files, for example, sensor settings, speed alarm settings, acceleration settings, motion detection settings have all been set parameters inside, and also connected to the peripherals externally, when the alarm signal is generated, the system will record the alarm file.

The resolution refers to the resolution of the video playback, which has three kinds D1/HD1/CIF; the starting time and ending time of the video file is the packaged time; and it will display the file size of the corresponding channel in behind, the file size has something to do with the resolution, video packaged time and quality, for detailed package file size, please refer to Appendix 3.

PLAYBACK MENU					
DATE 2012/11/02					
CH	TYPE	STIME	ETIME	RES.	SIZE
1	NORMAL	15:03:29	15:18:29	HD1	10M
2	NORMAL	15:03:29	15:18:29	HD1	10M
3	NORMAL	15:03:29	15:18:29	HD1	10M
4	NORMAL	15:03:29	15:18:29	HD1	10M
5	NORMAL	15:18:29	15:23:00	HD1	3M
6	NORMAL	15:18:29	15:23:00	HD1	3M
7	NORMAL	15:18:29	15:23:00	HD1	3M
8	NORMAL	15:18:29	15:23:00	HD1	3M
9	NORMAL	15:47:54	15:50:05	HD1	1M
10	NORMAL	15:47:54	15:50:05	HD1	1M

Figure 4-51




Figure 4-52

When the video file is selected, it will be highlighted in blue, press "▶" to play, as shown in Figure 4-51 and 4-52, the playback time, the history of the vehicle speed, GPS information and so on will be played during process. Commonly used keys are PLAY ▶, rewind REW ◀, Fast Forward FWD ▶, pause PAUSE / STEP ⏸, stop button STOP □, and "RETURN" key during playback; speed degree fast-forward and rewind can both use $\times 2$, $\times 4$, $\times 8$, $\times 16$ times the speed to play; if there is invoice during playback, the volume can be adjusted by pressing the arrow keys to the left or right after maximizing the channel; it can return to the search results interface during playback at any time by pressing the "RETURN" or "STOP". For the remote control's function please refer to Chapter 2.8.

Moreover, in regards to the playing of video files in the SD card on computer, please refer to Chapter 3.5.

4.9: System Information



Figure 4-53



Figure 4-54

Description:

System information played a significant role in viewing the device's status, it is very useful for the installation, commissioning and failure determine of the device. Firstly log into the system menu, the last one is **System Information**, which has two menus named **SD / HDD Status** menu and **Device Status** menu.

SD / HDD Status menu displays the related information, the total capacity and remaining capacity of SD card after entering.

SD CARD	STATUS	TOTAL	FREE
SD1	EXIST	7.41GB	405.50MB
SD2	NONE	0KB	0KB

Figure 4-55




Figure 4-56





Figure 4-57

Device Status View of System Information:

Under the status of four-screen monitoring on site, press the "INFO" button on the remote control to directly display device status information as shown in Figure 4-57, which includes the version information of hardware, software and the MCU, and will display related information of GPS module, WIFI module, 3G wireless module and SIM card at the same time. Device status information will be often used in viewing of system status and fault judgment. For example, when you use 3G to report to gServer server platform, here the status of 3G card signal and dial-up can be displayed intuitively, and here can also display whether the connecting to the server center is successful or not.

Appendix 1: gServer platform interface



Appendix 2: Common problems and treatment

Q: What can I do when I found a problem with the product, but I can not solve it by myself?

A: Take note of the model and software version number, then submit a detailed description of the problem to the technical supporting engineers to analyze; the more detailed you have submitted, the more convenient for us to analyze.

Q: How about when there is no video output from the vehicle host device?

A: 1. Check the host's turn-on status, if only a blue light on, it means the host is in standby status and has not been started up yet, meanwhile check whether the host's power cords red & yellow cords are in power supply status or not, if only one cord is supplying power, the device is unable to start up.

2. Check the power supply status of display screen, as well as check whether the display video has been switched to AV status.

3. Check the connecting status between the host's video output cable and display screen.

4. Check whether the lock status of the host's LOCK, it must be locked before normal starting up.

Q: How to do when the car host video input interface is different from the camera output interface?

A: The car uses 4PIN type while camera uses BNC or aviation head type, if not in correspondence, please use conversion head for connection or wiring based on standard corresponding according to the cable sequence defined by the car host.

Q: How to do when the device does not conduct video recording after it is turned on and SD card has already been installed?

A: 1. Check whether the SD card has been formatted or not after installation, because unformatted SD card cannot be used. Enter System Menu – System Tools – Device Format to format the newly installed SD card;

2. Check to see whether video channel is closed or not, whether set a timer recording or not, it will not take video when it is not within the video recording time period.

3. Check the SD card inserting status and whether the SD light on front panel is on or not.

Q: The video file is missing or there is no video file within a certain period of time, how to do?

A: 1. Determine the time period by analyzing the final video file before missing and the first video file after recovery.

2. Confirm whether the host is not on during that period of time, such as when the driver halfway parking, loading and unloading goods while the host is not set by video delay.

Q: When car PTZ cannot be controlled, it cannot rotate up and down, how to do?

A: Check whether PTZ protocols and baud rate are set correct, address codes are corresponding or not, whether have selected the video of the channel when control the PTZ, for example, when control the second channel, it must maximize the screen of the second channel image to control it.

GPS-related issues

Q: GPS module exists but no coordinate information?

A: 1. Check whether GPS module exists, if it does not exist, check whether the hardware is installed or in a good contact.
2. Make sure that the GPS antenna contacts are good, whether the antenna is broken, it is recommended to be located in places with strong signal, note that some car glass shielding film will block GPS signals;
3. If the test is in the room, the signal of GPS antenna in the room will be obscured, it is recommended that the GPS antenna is placed outdoor.

Q: Deviation of GPS location on map?

A: It means the signal is valid if the GPS module already positioned, there may many reasons for the deviation, such as government restrictions, permissible error, GPS signal interruption, etc; the actual satellite map may have deviation for security reasons, general map can solve the problem by using GPS correction.

3G wireless module

Q: If use the 3G wireless module for dial-up, what do I need to pay attention to?

A: 1. Choose the built-in wireless module WCDMA or EVDO, corresponding module settings are not the same, the modules supported by different machines models are not the same, so please make sure whether your module and SIM is in correspondence. Do not use telecom SIM card on WCDMA machine;
2. Check whether the settings of Server IP and port are correct, whether 3G signal is strong enough for dialing, and then check whether the 3G dial-up is successful or not.
3. When dialing is unsuccessful, please check 3G antenna is in good contact or not, the dial up may fail because of weak signal, moreover, please check whether the SIM card has enough traffic, if no traffic, dial-up will be unsuccessful.

Q: When 3G has neither report nor video, what should be done first?

A: Press INFO key to enter the system information page, check whether the SIM card exists and view the signal strength as well as dial-up status, whether the antenna is in good contact, and then check the SIM to see whether it is out of traffic, the most basic judgment is to replace the SIM card. If the dial up failed with signal, then check whether the settings of center number and the port are correct. Moreover check whether the device number of the product is already occupied.

Q: 3G signal is intermittent, video is jammed?

A: At present the signal coverage of WCDMA and EVDO is rather wide, however, there are some mountainous districts without signal coverage, and some suburban areas have weak signal due to the local network constraints, then it will be jammed during watching of video, or video cannot be watched at all, the greatest impact of this situation is from the local network; Moreover check whether the frame rate setting of sub-stream is too high, because the video may also occur such situation when the network is poor and frame rate setting is high.

Q: WIFI signals can not be connected when above -60db?

A: If your WIFI settings are correct, generally there is no problem for connection when signals are above -60db. If the host can not be found in a local area network (LAN), it will need to look up your SSID and password to see whether they are already set, of course, basic IP address also must be set ready, moreover check whether the type of encryption and authentication mode is set according to the requirements.

gServer related issues

Q: Why the vehicle and video cannot be seen in gServer client when the device has been started?

A: At first make sure the central registration server is switched on and on the net, then check whether the host device number has been occupied to cause conflict, secondly check whether the settings of server-centric IP and port are correct; devices report to the center via the built-in 3G module or via WIFI. If via built-in 3G, please check whether selected the correct type of built-in 3G module, for example, WCDMA and EVDO module needs the support from corresponding SIM card, check whether the antenna is in good contact; If it still can not report when above all are checked, enter into the system information page to view dial-up. If dial-up is not successful, look up whether the setting of data access point and center number is correct. If all ultimately fail, please collect as much information as possible to submit to the technical supporting staff for analysis, the more data provided, the more convenient for technicians to solve the problem.

Q: The device is online, but why can I not see the video image?

A: Please set lower sub-stream to transmit image, the blocked or slow transmission speed situation may occur when the sub-stream frame rate is set very high and be affected by network uploading limit; poor network signal or intermittent will seriously affect the video transmission.

Q: The device is properly reported on gServer, but the videos cannot be seen after using for some time?

A: Firstly check whether the host side displays dialing, if it keeps the dialing status, it may be because the flow of the SIM card has run out, replace the SIM card to test; Secondly query whether the host device number has been modified by the driver, the host with modified device number needs to be resubmitted to add vehicle information; thirdly, if it still does not work by changing the card, it will need to check whether the host's 3G module fails.

Appendix 3: storage space corresponding table

Appendix 3: storage space corresponding table

RECORDING SPACE M/H	Quality Resolution	1	2	3	4	5	6	7	8
	D1	900	670	540	450	390	350	315	280
	HD1	560	420	335	280	245	220	195	175
	CIF	350	260	210	175	150	135	120	110

The space occupying for each image video recording per hour is shown as above table which is for reference only, the actual video file size has something to do with light changes of the current channel, movement of object and many other factors, if the image is stationary, then video file size will be much smaller; in order to save space, it can be set to turn off the audio or turn off the channel without video.