


## ***INSTRUCTION MANUAL***

---

### ***PLANT GROWTH CHAMBER (SGC170)***

---



*SGC170*



# CONTENTS

Section	Heading	Page
1	<b>HEALTH AND SAFETY</b>	2
	Foreseen Use of Chamber	3
2	<b>UNPACKING AND CHECKING CONTENTS</b>	4
3	Additional Accessory List	4
3	<b>NAME AND FUNCTION OF PARTS</b>	5
4	<b>BEFORE USE</b>	
	Safety and Pre-Installation Checks	15
5	<b>INSTALLATION</b>	
	Lifting Instructions	16
	Positioning the Chamber	17
	Electrical Power Supply Connection	17
	Water Connection	18
6	<b>OPERATION</b>	
	Principles of Operation	19
	Re-Operational Checks (Before turning ON Switch)	20
	Start Up	21
	Shutdown	22
	Programming	23
	Data Acquisition	42
	Communication Function	43
7	<b>MAINTENANCE</b>	
	Preventative Maintenance	45
	Calibration of Temperature / Humidity sensor	46
	Purified Water Filter	46
	Vapour Phase Generator	47
	Torbeck Tank	48
	Replacing the Fluorescent Tube	49
	Electrical Wiring Schematic	50
	Refrigeration Wiring Schematic	51
8	<b>TROUBLESHOOTING</b>	52
9	<b>SPECIFICATION</b>	53
	Dimensions	55
10	<b>SPARE PARTS LIST</b>	56
11	<b>DISPOSAL/DECOMMISSIONING</b>	57

# 1. HEALTH AND SAFETY

Weiss Gallenkamp is required under the Health and Safety at Work, etc. Act. 1974 and other U.K. regulations as designers, manufacturers, suppliers and importers of articles for use at work to ensure that, as far as reasonably practicable, the product that we design, produce, supply or import are safe and without risk to health and safety, when properly used.

We are also required to provide information on the safety and handling precautions to be observed when installing, operating, maintaining and servicing our products. Such advice is contained in this manual.

We should also like to point out, however, that you as users have an important responsibility in the provision and maintenance of safe working practices and conditions. Accordingly we draw the following matters to your attention:

1. This apparatus should only be used as intended (see page 3), and within its design parameters by suitably qualified and trained personnel who have read and understood the relevant sections of this manual.
2. This manual should be readily available at all times.
3. In addition to that which is written in the manual, normal common sense safety precautions must be taken at all times to avoid the possibility of accidents. Particular care is required when working with apparatus at high temperatures or pressures.
4. Installation, maintenance, servicing and connection to electrical supplies, should only be carried out by suitably trained personnel. The Weiss Gallenkamp service department can provide these facilities if required.
5. If you are in any doubt whatsoever regarding the correct use of this apparatus, or if you require any technical data or assistance, please contact Weiss Gallenkamp Technical Support.

Weiss Gallenkamp Limited  
Units 37/38,  
The Technology Centre,  
Epinal Way  
Loughborough,  
Leicestershire, LE11 3GE  
United Kingdom

Tel: +44 (0) 1509 631595 Sales  
+44 (0) 1509 631590 Service  
Fax: +44 (0) 1509 211133  
E-mail: [sales@weiss-gallenkamp.com](mailto:sales@weiss-gallenkamp.com)  
[service@weiss-gallenkamp.com](mailto:service@weiss-gallenkamp.com)  
Website: [www.weiss-gallenkamp.com](http://www.weiss-gallenkamp.com)



**NOTE: CAUTION MUST BE ADHERED TO**

# 1. HEALTH AND SAFETY

## Foreseen Use of Chamber

The SGC170 chamber has been specifically designed for tissue culture and the growing of plants. The chamber shall be operating within the specification (see page 53). The chamber is not designed for any other purpose.


## 2. UNPACKING AND CHECKING CONTENTS

1. Carefully remove all exterior packing materials and check for any damage that may have occurred during transit. **DO NOT** discard packing material until the chamber is fully operational. Report any damage immediately to your supplier.

**NOTE:**

If the Shock Detection Indication shows red:

- Do not reject the unit.
- Notify the shipping company representative before signing for the unit. When signing for the unit, note any comments on the acceptance document. Demand a copy of the acceptance document. If this is not possible, notify the shipping company in writing as soon as possible after taking delivery.
- Notify the company who supplied the unit to you.
- Carefully unpack and inspect the unit for damage. Report any damage found immediately to the shipping company and the supplier.
- Do not discard packing material.




2. Remove additional accessories, check the contents with the table below, and put them in a safe place.
3. Check the interior of the chamber and remove any packing materials from the shelves.
4. Ensure the lamp is securely fitted; the two pins on each end of the fluorescent tube (FL) must line up with the entry holes in the holders.
5. Report any interior damage immediately to our local supplier.
6. The chamber is now ready for pre-installation check and installation (see page 15).

### Additional Accessories List


Following accessories are included:

No	Part Name	Description	Quantity
1	Instruction Manual	UM-SGC170	1
2	DAQSTANDARD Software CDROM		1
3	CX2000 User manual CDROM		1
4	CX2000 Operation Guide		1
5	100Mb Zip Disk		1
6	630mA Antisurge Fuse	E13033	1
7	Wire Mesh Shelves	K06607	2
8	Wire Mesh Support Rods	K06608	4
9	Main Door Key	K04346	1
10	Instrument Chamber Door Key		1


### 3. NAME AND FUNCTION OF PARTS




LHS VIEW



FRONT VIEW



RHS VIEW



REAR VIEW


### 3. NAME AND FUNCTION OF PARTS

1. **Air Inlet for Lamp Box**  
Air inlet For cooling of the lamps and ballasts
2. **Access Port**  
Situating on the left hand side of the chamber. See page 11
3. **Air Exchange**  
See page 7
4. **Control Panel**  
See page 8
5. **Inspection Door**  
Pull door open to view samples inside chamber
6. **Lamp Box**
7. **Main Chamber Doors**
8. **Refrigeration Air Inlet Grille**
9. **Instrument Panel Door**  
Remove/Open cover to gain access to the condensing unit/electrical components for servicing.
10. **Purified Water Inlet**  
See page 13
11. **Wastewater drain**  
See page 13
12. **Lamp Box Fans**  
See page 12
13. **Refrigeration Air Outlet Grille**
14. **Air Vent**
15. **Mains Electrical Cable Inlet**  
See page 15 and 17
16. **Lamp box Access Panel**  
Remove cover to gain access to the lamp ballasts for servicing



### 3. NAME AND FUNCTION OF PARTS


#### Air Exchange



An adjustable air vent is provided on the front of the chamber, the air vent is opened by slide the handle to the right hand side.

Up to 6 air changes per hour can be achieved with the air vent opened to its maximum.


The silicone bung of the air vent should be removed at the rear of the chamber.



REAR OF CHAMBER.

### 3. NAME AND FUNCTION OF PARTS


#### Control Panel Instrumentation



- 
- |   |  |
|---|--|
| 1 | Programmable Controller / Recorder - See Separate manual for Operation and Programming |
| 2 | Mains Button   |
| 3 | Reset Button   |
| 4 | Mute Button  |
| 5 | Mains Isolator   |
-

# 3. NAME AND FUNCTION OF PARTS

## CX2000 Controller



Item Number	Description
1	LCD Screen
2	Identification Labels
3	Keys
4	Operation Cover
5	Key Operation Cover

### LED Screen

Various screens appear in the LCD, such as the control group display and set up displays

### Identification Label


Used to identify each channel, write the appropriate label as needed

### Keys

Includes the directional arrow keys as well as the DISP/ENTER key. In operation mode, these keys are used to switch between the operation displays. In the set up screens where functions are configured, the keys are used to select parameters and to confirm new settings


### Operation Cover

The external storage medium - zip disk is situated behind the operation cover. To open the cover press down on the operation cover knob positioned at the top of the cover and then pull the cover forward. To remove the zip disk press the small eject button to the right of the zip disk. Note the disk can only be removed when there is power to the controller. Ensure that the operation cover is closed at all times except when handling the zip disk




### Key Operation Cover

This cover is opened to access to all of the other keys. The operation cover is opened by pulling the key operation cover knob at the centre left corner of the cover forward.



### 3. NAME AND FUNCTION OF PARTS

#### Key Operation




1. **Start Key** – Starts the data acquisition to the internal memory, and displays the waveform on the trend screen
2. **Stop Key** – Stops the data acquisition to the internal memory. Also stops the updating of the waveform on the trend screen.
3. **Esc Key** – Used when cancelling an operation. Also used when returning from the setting mode to operation mode
4. **Menu Key** – Used when switching from the operation mode to the setting mode. Also used when returning from setting mode to the operation mode
5. **User Key** – Used to execute the assigned action
6. **Func Key** – If the key is pressed in the operation mode, a soft key menu is displayed at the bottom of the screen enabling the execution of various functions. The key is also used when switching from setting mode to the operation mode.



7. **Soft Key** – When a soft key is displayed at the bottom section of the display in operation, setting, or basic setting mod, these soft keys are used to change the operation and set up information
8. **Character/Number Keys** – Used when entering characters or numbers.

### 3. NAME AND FUNCTION OF PARTS


Access Port



The access port is situated on the left-hand side of the chamber, the access port has two plugs fitted, and one inside and one outside, and both plugs need to be fitted to maintain the insulation of the chamber.


The plugs can be split or holes bored to enable wires or pipes to pass through the port. Care must be taken to prevent condensation forming inside the access port

### 3. NAME AND FUNCTION OF PARTS



### 3. NAME AND FUNCTION OF PARTS


#### Purified Water Supply



If an AquaRec re-circulation pure water system is provided, please refer to the AquaRec instructions for connection to this unit.

Connect a supply of purified water (see specification page 15) to the inlet pipe situated on the right hand side of the instrument compartment. Maximum allowable head is 1500mm (5ft) above the inlet pipe.


#### Waster Water Drain



Connect a pipe to the cabinet outlet to give a CONTINUOUS FALL to an OPEN DRAIN. Drainage restriction may cause airlocks and consequently flooding the chamber.

### 3. NAME AND FUNCTION OF PARTS

#### Combined temperature/humidity probe



The chamber is fitted with an electronic combined temperature/direct reading humidity probe, used for chamber condition control. The sensor is positioned on the right hand side on the inside of the chamber behind a removable plate



#### **CAUTION:**

1. It is important that the probe is not subjected to saturating humidity conditions (i.e. condensing).
2. It is probable that the probe, following a low temperature test, will form a dew point if the chamber door is opened to ambient conditions. This will cause condensation to form on the probe. To prevent this, reset the chamber temperature to the same as ambient but with a low humidity and run the chamber. Only after the probe has attained ambient conditions should the door be opened.
3. The combined temperature/humidity control and monitoring probes are delicate, precision instruments. Only suitably qualified personnel should attempt routine calibration checks in order to avoid damage to probes.



## 4. BEFORE USE

### Safety and Pre-Installation Checks

To ensure the chamber operates correctly please check the following items before using the chamber:

#### (1) Electrical Supply

Check that the electrical supply available conforms to the information on the power rating plate (found on the side of the chamber above the mains electricity supply cable) and is of sufficient power to run the product.

- Check that the power supply is of the correct phase configuration – either single phase or phase to phase as stated on the chamber rating plate, AC (alternating current) of the stated frequency with neutral nominally at earth potential.
- The supply voltage is within the stated range.
- The current rating is within the capacity of the supply inlet.
- The socket or outlet circuit is suitably fused.

#### (2) Facility checks

- Check that the purified water supply for the chamber is of sufficient volumetric capacity
- Check that a wastewater **open** drain or condense tray is available and is of sufficient capacity
- Check that the Purified water pressure is between 0.1-1.0 Bar (2-14 psi)
- Check that the Purified water has the correct conductivity between 5 - 20  $\mu\text{S cm}^{-1}$ .

#### NOTE:

If the water pressure is higher than 1.0 bar a pressure reducing valve must be fitted in the supply line.  
If required Weiss Gallenkamp Limited can supply a pressure reducing valve.



**CAUTION:** Ultra Pure Water will destroy the heater element and can cause irreparable damage to the plant growth chamber.

#### (3) Ambient temperature

- **Ambient temperature operating range: + 12°C to +25°C**

Check that the room where the chamber is to be installed is adequately ventilated, and ambient conditions do not exceed the specification in terms of temperature and humidity.

#### (4) Noise emissions


- The sound pressure level emitted by the chamber does not exceed 70dB(A)

#### (5) Areas for use

- This chamber is **not** intended to be used in potentially explosive areas

## 5. INSTALLATION


### Lifting Instructions.



The chamber should be lifted using a suitable fork lift truck at the positions show. Care should be taken when lifting the chamber not to damage the drain pipe that is positioned on the underside of the chamber.

# 5. INSTALLATION

## Positioning the Chamber



Position the chamber in a ventilated area, on a level stable surface with the following minimum distances from continuous obstructions.

### (1) Installation Checks

- If the chamber is sited onto a bench please ensure that the bench is capable of supporting the chamber weight and maximum chamber load combined. (See specification for weights page 53):
- Ensure that the chamber is levelled to +/- 2mm.
- Ensure the chamber is within easy reach of the power supply isolator.
- Ensure open door will not cause an access hazard.

## Electrical Power Supply Connection

The chamber should be installed by a competent person to **BS 7671:2000**, or your local wiring regulations.



**WARNING:** This product must be earthed.

Chambers of higher current requirements are designed to be hard wired to a suitable power outlet by a qualified electrician.

Consult a qualified electrician if in doubt or the supply has any of the following:


- no earth
- a colour code different from the above
- reversible plugs
- supply and return leads that are both above earth potential
- Machine is connected to a branch circuit that does not have a primary type of overcurrent protection (Since this machine utilises a supplementary type of overcurrent protection.

415V 50Hz	
Green/Yellow	Earth
Black	Live L1
Black	Live L2
Black	Live L3
Blue (2)	Neutral

## 5. INSTALLATION

### Water Connection

#### Purified water supply connection




Connect the purified water supply to inlet connector situated on the right side or at the rear of the chamber. Maximum allowable head is 1500mm (4ft 9ins above the inlet pressure). The purified water should have a conductivity range of  $5\text{-}20\mu\text{S cm}^{-1}$ , a pressure range of 0.1-1.0bar (2-14Psi)

Ideally any reservoir should have its own support to one side of the chamber.

If the chamber is supplied with an AquaRec, re-circulating pure water system, fill the reservoir as instructed and connect the water connections to the chamber water inlet and drain as shown.

#### Waste water drain connection



**CAUTION:** connect a pipe to give a **CONTINUOUS FALL** to the drain. Drainage restriction can cause an airlock and consequent flooding of the treatment chamber.



The outlet for the wastewater is situated at the rear of the chamber. The connection size is 12.7mm OD. It is important that the connection to the drain has a continuous fall to an open drain

## 6. PRINCIPLES OF OPERATION

The chamber is split into three different sections, a treatment chamber, growing chamber and the light box

Air is conditioned in the treatment chamber and is constantly recirculated around the growing chamber. The system is designed to give an airflow through the growing chamber with a high tolerance of temperature and humidity, which will allow the user to repeat tests under the same growing conditions. The air velocity through the growing chamber is fast enough to prevent micro climates but slow enough to prevent disturbing the specimen

The growing chamber is separated from the light box via a glass panel, fluorescent lamps are housed inside the lamp box to simulate daylight, incandescent lamps are fitted to supplement the red/far red end of the lighting spectrum.

### Temperature

Accurate, repeatable temperature control is achieved by balancing continuous heat extraction with modulated heat control by an electronic PID controller.

### Heating

An Inconel sheathed heating elements sited in the treatment chamber. The element operates at black heat for long life and excessive surface temperatures

### Cooling

The purpose of providing cooling with the treatment chamber is for the following:

To provide a continuous heat extraction to balance the heating load

To introduce a cold surface on which to control the relative humidity of the chamber

### Lighting

The light box houses the fluorescent tubes and incandescent lamps used to simulate daylight. The timing and the intensity of the photoperiods are controlled via the programmer situated on the front of the chamber.

The incandescent lamps can be manually switched or automatically programmed to turn ON or OFF

The fluorescent lamps can be manually switched or automatically programmed to turn ON or OFF and the intensity can be dimmed from 10% to 100% in steps of 1%.

The cooling fans inside the lamp box are switched on automatically when the lights are switched on. The inside walls of the chamber are coated white to minimise light loss and to maximise diffusion.

## 6. OPERATION

### Pre-Operational Checks (Before turning ON)

- The chamber door keys are available to designated users to restrict control and sample access to authorised personnel
- The sample load will not release flammable, noxious or otherwise hazardous vapours
- Avoid using any materials in the chamber that may corrode in the humid atmosphere e.g. mild steel baskets, and also avoid using Chlorine, Iodine or aggressive cleaning agent.
- It is recommended that a chamber log book is kept which details both use, service and calibration history of the chamber
- Users are familiar with the operation of the chamber, including, setting parameters, suitable samples, load distribution, safety aspects, alarms and shut-down procedure as detailed in this manual
- The chamber has been regularly maintained and calibration checked by suitably qualified engineers. It is recommended that the chamber is serviced annually by Weiss Gallenkamp or their approved dealers or service agents
- Standard operating procedures (SOP's) have been prepared and made available to the operators
- Copies of this manual are available to the operator of the chamber

# 6. OPERATION

## Start Up

1. Switch on the mains power at the mains power connector
2. Switch on the red/yellow mains power isolator
3. Press the Green Mains power switch on the main control panel
4. Power is now available to the controller

## For Steady state control

At the overview screen on the controller, use the cursor keys to move to temperature, humidity or the lighting channels

1. At the desired channel Press soft key [#2] **SP** and use the cursor keys to enter the required setpoint
2. Press **ENTER**
3. Ensure mode (soft key [#1]) is **AUTO**
4. Press soft key [#4] **RUN/STP** and set to **RUN**
5. Repeat for each channel


Loop selection cursor

Remote (REM) or local (LOC) Red indication when alarm is occurring

Run (RUN)/ Stop (STP)/ auto tuning (blinking AT)


Tag name	IN_LOOP81	IN_LOOP82	IN_LOOP83	IN_LOOP84	IN_LOOP85	IN_LOOP86
Auto/manual	MAN	AUT	AUT	MAN	MAN	MAN
PV input value	PV 29.4	PV 29.4	PV 29.6	PV 29.4	PV 29.4	PV 29.4
Target setpoint	SP 23.8	SP 26.3	SP 38.8	SP 26.4	SP 26.4	SP 26.4
Control output value	OUT 8.8	OUT 8.8	OUT 8.8	OUT 8.8	OUT 8.8	OUT 8.8
	TIC81	EXT_LOOP82	EXT_LOOP83	EXT_LOOP84	EXT_LOOP85	EXT_LOOP86
	AUT	AUT	AUT	AUT	AUT	AUT
	PV 458.8	PV 458.8	PV 458.8	PV 458.8	PV 458.8	PV 458.8
	SP 458.8	SP 458.8	SP 458.8	SP 458.8	SP 458.8	SP 458.8
	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2
	EXT_LOOP87	EXT_LOOP88	EXT_LOOP89	EXT_LOOP90	EXT_LOOP91	EXT_LOOP92
	AUT	AUT	AUT	AUT	AUT	AUT
	PV 458.8	PV 458.8	PV 458.8	PV 458.8	PV 458.8	PV 458.8
	SP 458.8	SP 458.8	SP 458.8	SP 458.8	SP 458.8	SP 458.8
	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2
	EXT_LOOP13	EXT_LOOP14	EXT_LOOP15	EXT_LOOP16		
	AUT	AUT	AUT	AUT		
	PV 458.8	PV 458.8	PV 458.8	PV 458.8		
	SP 458.8	SP 458.8	SP 458.8	SP 458.8		
	OUT 64.2	OUT 64.2	OUT 64.2	OUT 64.2		
	MODE	SP	OUT	RUN/STP	PRG/LOC	PROGRAM
						TUNING

Ensure that the Fridge switch is set to **ON**



## 6. OPERATION

To switch on the Fridge, Fluorescent lights or tungsten lights move the cursor to the required switch  
Press soft key [#1] Mode and set to Manual



Press soft key [#2] Out and set to 1 (0 is OFF 1 is ON)



Press the START button and the chamber will start to run and control at the required conditions

### For Programmable control

See page 24 to set up a program and page 32 to run a program

#### Shutdown

When the control is required to be terminated, press the MAINS POWER button. The push button will no longer be illuminated

Turn the red/yellow MAINS ISOLATOR to the OFF position. The chamber temperature will slowly drift to ambient conditions.

#### Emergency Shutdown

Turn the red/yellow MAINS ISOLATOR to the OFF position and switch off the main power supply to the chamber



## 6. OPERATION

### Automatic Defrost

The chamber is fitted with an automatic defrost system, which is controlled by the CX2000 controller. The defrost control switch can be seen on the overview screen along with the evaporator coil temperature. The defrost switch should always be left in the auto position so defrost period can be determined on demand by the controller.

The purpose of the defrost system is to allow ice on the evaporator to melt. Both the frequency and the length of the defrost period is automatically controlled.


The rate of build up of ice and hence the need for defrosting is determined by the automatic defrost system, by switching the refrigeration unit off, this will occur providing the evaporator coil has been below +2°C for over an hour. Once the evaporator coil temperature rises above +2°C the refrigeration system will switch back on. The system will not defrost again until the evaporator coil has been below 2°C for another hour.

## 6. OPERATION - PROGRAMMING

## Programming – Via the Controller

## Program Control Setup Procedure

To set up program control, follow the flow chart shown below.  
MENU key (switch to the setting mode (control)) > [Next 1/2] soft key



### Note

You cannot carry out setup related to program control that is explained in this chapter when communication command "FE4" (Output setup data file) is being executed.

## 6. OPERATION - PROGRAMMING

### Pattern Initial Setting

#### Opening the Settings Display

Press the keys in the following sequence:

MENU key (switch to the setting mode (control)) > #7 soft key (select [program-control parameters]) > #1 soft key (select [program parameter setting]) > #1 soft key (select [pattern initial setting])

Program parameter setting(Pattern initial setting)

Pattern number	1
Segments	5
Segment setting method	Time
Pattern name	Pattern 1

Remaining segments: 388  
Remaining events: 888

Action loop	
Loop 1	On
Loop 2	On
Loop 3	Off
Loop 4	Off
Loop 5	Off

Time Ramp

#### Setup Procedure

Use the arrow keys to move the cursor (blue) to the item box you wish to change. A soft key is displayed at the bottom of the screen

1. Press the soft key corresponding to the value you wish to select. The box for the item you changed turns yellow, and the cursor moves to the next item
2. Repeat steps 1 and 2 to change the value of all the terms you wish to change
3. Press the DISP/ENTER key to confirm the changes. The box for the items that have been changed turn from yellow to white, and the cursor returns to the first item
4. Press the ESC key to return to the [program parameter setting] menu. To continue with the program setting, press the [#1] to [#6] soft keys to display each setting display without carrying out step 6
5. Press the [End] soft key – A window appears for confirmation to save the new settings.
6. Select [Yes] and press the DISP/ENTER key and save the settings.

Note:      Loop 1 – Temperature  
              Loop 2 – Humidity  
              Loop 3 – Fluorescent Lights

## 6. OPERATION - PROGRAMMING

### Wait action setting

#### Opening the setting display

Press the keys in the following sequence:

MENU key (switch to the setting mode (control)) > #7 soft key (select [program-control parameters]) >

#1 soft key (select [program parameter setting]) > #1 soft key (select [pattern initial setting])



### Setup Procedure

1. Use the arrow keys to move the cursor (blue) to the item that needs to be changed. A soft key menu is displayed at the bottom of the display.
2. Press the soft key corresponding to the value you wish to select. The box for the item you change turns yellow, and the cursor moves to the next item.
3. Repeat steps 1 and 2 to change the value of all the terms you wish to change.
4. Press the DISP/ENTER key to confirm the changes. The box for the items that have been changed turn from yellow to white, and the cursor returns to the first item.

### Setup Items

#### Wait zone off/on

Turn off/on the wait zone for each loop

#### Wait zone values

Set the wait zones in the range of 0 to 100% of the measurement span

#### Wait Time

Set the wait time in [hh:mm:ss] format for each available zone. The setting applies to the same zone in each loop.

## 6. OPERATION - PROGRAMMING

### Pattern Start setting

#### Opening the Setting Display

Press the keys in the following sequence:

MENU key (switch to the setting mode (control)) > #7 soft key (select [program-control parameters]) > #1 soft key (select [program parameter setting]) > #1 soft key (select [pattern initial setting])



#### Setup Procedure

1. Use the arrow keys to move the cursor (blue) to the item that needs to be changed. A soft key menu is displayed at the bottom of the display.
2. Press the soft key corresponding to the value you wish to select. The box for the item you change turns yellow, and the cursor moves to the next item.
3. Repeat steps 1 and 2 to change the value of all the terms you wish to change.
4. Press the DISP/ENTER key to confirm the changes. The box for the items that have been changed turn from yellow to white, and the cursor returns to the first item.

#### Pattern Start Setting

Pattern Number – Displays the pattern number selected in the pattern initial settings

Start target setpoint – Set the SP, for each loop

## 6. OPERATION - PROGRAMMING

### Program Pattern Setting

#### Opening the Setting Display

Press the keys in the following sequence:

MENU key (switch to the setting mode (control)) > #7 soft key (select [program-control parameters]) > #1 soft key (select [program parameter setting]) > #1 soft key (select [pattern initial setting])



#### Setup Procedure

1. Use the arrow keys to move the cursor (blue) to the item that needs to be changed. A soft key menu is displayed at the bottom of the display.
2. Press the soft key corresponding to the value you wish to select. The box for the item you change turns yellow, and the cursor moves to the next item.
3. Repeat steps 1 and 2 to change the value of all the terms you wish to change.
4. Press the DISP/ENTER key to confirm the changes. The box for the items that have been changed turn from yellow to white, and the cursor returns to the first item.

#### Setup Items

##### Pattern Number

Displays the pattern number selected in the pattern initial settings

##### Segment number

Select the number of the segment to be changed from 1 to 99

##### Ramp/Soak select

Select the type to be specified ([Ramp] or [Soak])

##### Target Setpoint

Set the final SP of the ramp segment for each loop

##### Segment time

Set the segment time in [hh:mm:ss] format.


## 6. OPERATION - PROGRAMMING

### Event Setting

#### Opening the Setting Display

Press the keys in the following sequence:

MENU key (switch to the setting mode (control)) > #7 soft key (select [program-control parameters]) > #1 soft key (select [program parameter setting]) > #1 soft key (select [pattern initial setting])



#### Setup Procedure

1. Use the arrow keys to move the cursor (blue) to the item that needs to be changed. A soft key menu is displayed at the bottom of the display.
2. Press the soft key corresponding to the value you wish to select. The box for the item you change turns yellow, and the cursor moves to the next item.
3. Repeat steps 1 and 2 to change the value of all the terms you wish to change.
4. Press the DISP/ENTER key to confirm the changes. The box for the items that have been changed turn from yellow to white, and the cursor returns to the first item.

### Event Setting

#### Pattern Number

Displays the pattern number selected in the pattern initial settings

#### Segment number

Select the number of the segment to be changed from 1 to 99

#### Event Kind

Select the [TimeEvent]

#### On1/On2/On3/Off

Set the On/Off setting type for each event from the following. Select [Off] for vents that are not to be assigned.

On1 (On/Off) Use On time and Off time

On2 (On/\*\*) Use On time only

On3 (\*\*/Off) Use off time only

#### On-time/Off time

Set the on time/Off time of the time event in hh:mm:ss format. The selectable range is 00:00:00 to 99:59:59. Set Off time ≥ On time

Timed events are used to switch on and off the lights

- 1) SW001 – Fridge
- 2) SW002 – Defrost \*\*
- 3) SW003 - Fluorescent Lights
- 4) SW004 – Tungsten Lights

\*\* Always leave the defrost set to Off, and set to auto on the overview screen to ensure defrost on demand.

## 6. OPERATION - PROGRAMMING

### Repeat Action

#### Opening the Setting Display

Press the keys in the following sequence:

MENU key (switch to the setting mode (control)) > #7 soft key (select [program-control parameters]) > #1 soft key (select [program parameter setting]) > #1 soft key (select [pattern initial setting])



#### Setup Procedure

1. Use the arrow keys to move the cursor (blue) to the item that needs to be changed. A soft key menu is displayed at the bottom of the display.
2. Press the soft key corresponding to the value you wish to select. The box for the item you change turns yellow, and the cursor moves to the next item.
3. Repeat steps 1 and 2 to change the value of all the terms you wish to change.
4. Press the DISP/ENTER key to confirm the changes. The box for the items that have been changed turn from yellow to white, and the cursor returns to the first item.

#### Setup Items

##### Pattern Number

Displays the pattern number selected in the pattern initial settings

##### Repeat Action

Select the repeat function from [Off], [On] and [Repeat]

##### Repeat Frequency

Set the number of repetitions when the repeat function is turned ON in the range of [1] to [999]

##### Repeat start segment/Repeat end segment

Set the repeat start segment number and the repeat end segment number when the repeat function is turned ON or when the repeating in the range of 1 to 99.

**For more information please refer to the CX2000 User's Manual**



## 6. OPERATION - PROGRAMMING

### Programming – Via DAQSTANDARD

If the CX2000 is connected to a network then the controller can be programmed using the DAQSTANDARD software. Once the program has been written it can be downloaded to the controller. A maximum of four programs can be stored at once. **For more information please see the DAQSTANDARD manual included with the chamber**

#### Programming Information

##### Set points

Loop 1 – Temperature  
Loop 2 – Humidity  
Loop 3 – Fluorescent Lighting


##### Timed Event

Timed events are used to switch on and off the lights

- 1) SW001 – Fridge\*
- 2) SW002 – Defrost \*\*
- 3) SW003 - Fluorescent Lights
- 4) SW004 – Tungsten Lights


\* Always ensure that SW001 – Fridge is turned on

\*\* Always leave the defrost set to Off, and set to auto on the overview screen to ensure automatic defrost on demand



# 6. OPERATION - PROGRAMMING

## Program Operation



## 6. OPERATION - PROGRAMMING

### Switching the Pattern Number

1. Press the [PT NO.] soft key.

A pop-up window for switching the pattern number appears. The window shows the current pattern number.



2. Select the pattern number using the up and down arrow keys.
3. Press the DISP/ENTER key to confirm the changes.

To close the window without making any changes, press the ESC key.

### Setting Operation for Patterns That Start by Communications Command, DI/DO, or Internal Switches (Style Number S3 Or Later)

1. Press the [SET PTNO.] soft key.

The pattern number (the same number as the pattern number that can be started from this screen) selected by the PT NO. soft key above is set.

Even if you change the pattern number with the PT NO. soft key, if you do not press the SET PTNO soft key, the pattern numbers that start by communication commands, DI/DO/internal switches are not changed.

### Switching to the Overview Screen (Style Number S3 or Later)

1. Press the [OVERVIEW] soft key.

Among the loops of the displayed program patterns, the screen switches to the overview screen including loops with small numbers.

### Switching to the Control Group Screen (Style Number S3 or Later)

1. Press the [CNTRL GRP] soft key.

Among the loops of the displayed program patterns, the screen switches to the group's control group screen including loops with small numbers.

### Selecting Segments

- Press the left and right arrow keys.

The displayed pattern waveform shifts horizontally by one segment. The [SEGMENT NO], [SEGMENT TIME], and the target SPs of each group corresponding to the segment shown at the left end are displayed.

- To shift 10 segments at a time, press the [+10SEG] or [-10SEG] soft key.
- Press the up arrow key to show the pattern waveform overview window as shown in the figure below. You can select segments (as described above) while showing this pattern waveform overview window. To close the pattern waveform overview window, press the down arrow key.

Indicates the pattern waveform display area (move using the left and right arrow keys) using a rectangular frame

Display of the segment number/segment time at the left frame line position



## 6. OPERATION - PROGRAMMING

### Turning ON/OFF the Pattern Waveform Display of Each Loop

1. Press the [DSP LOOP] soft key.

A menu used to turn ON/OFF the pattern waveform display appears. The soft keys of each loop show the tag names of each loop ([INT-01] to [INT-06] in the figure below).

INT-01	INT-02	INT-03	INT-04	INT-05	INT-06	BACK
--------	--------	--------	--------	--------	--------	------

2. Press the soft key corresponding to the tag name of the loop you wish to turn ON/OFF.

INT-01	INT-02	INT-03	INT-01	=	OFF	INT-06	BACK
--------	--------	--------	--------	---	-----	--------	------

3. Select [ON] or [OFF] using the up and down arrow keys.
4. Press the DISP/ENTER key to confirm the changes.  
To close the window without making any changes, press the ESC key.  
Press the [BACK] soft key to return to the original soft key menu.

### Starting Program Control

1. Press the [RUN] soft key.

A pop-up window for starting the program control appears.

RUN	PT NO.	SET PTR RUN	=	RUN	UN PNL	NEXT 1/3
-----	--------	-------------	---	-----	--------	----------

2. Press the DISP/ENTER key.

### Selecting the Program Pattern Start Segment

1. Press the [NEXT 1/3] soft key.
2. Press the [ST SEG] soft key.

A pop-up window for selecting the start segment appears.

ALL/DIV	DSP LOOP	ST SEG	ST SEG	=	1	V KIND	NEXT 2/3
---------	----------	--------	--------	---	---	--------	----------

3. Select the segment number using the up and down arrow keys.
4. Press the DISP/ENTER key.

### Setting the Delay Time for Starting the Program Pattern Control

1. Press the [NEXT 1/3] soft key.
2. Press the [DELAY TM] soft key.

A pop-up window for setting the delay time appears.


ALL/DIV	DSP LOOP	ST SEG	DELAY TM=	00:00:00	V KIND	NEXT 2/3
---------	----------	--------	-----------	----------	--------	----------

3. Change the delay time using the up and down arrow keys.
4. Press the DISP/ENTER key.

## 6. OPERATION - PROGRAMMING

### Event Display Operation (Style Number S3 or Later)

1. Press the [Next 1/3] soft key.
2. Press the [EV ON/OFF] soft key.  
Time events and PV events are displayed.




3. Press the [EV KIND] soft key.  
A pop-up window for selecting event to be displayed appears.
4. Set the events to be displayed using the up and down arrow keys.
5. Press the DISP/ENTER key.

ALL/DIV DSP LOOP ST SE( EV KIND = GROUP V KIND NEXT 2/3

# 6. OPERATION - PROGRAMMING

## Displayed Information and Operations on the Program Control Display



## Running and Resetting Program Control

1. Press the [RUN/RST] soft key.  
A pop-up window for running and resetting the program control appears.
2. Select [RUN] or [RESET] using the up and down arrow keys.
3. Press the DISP/ENTER key to confirm the changes.  
To close the window without making any changes, press the ESC key.

## Advancing Segments

1. Press the [ADVANCE] soft key.  
A pop-up window for advancing segments appears.
- 
- The screenshot shows a pop-up window with a grid and several soft key menus. The main display area shows a grid with a cursor. The soft key menus include RUN/RST, ADVANCE, HOLD, ADVANCE #, GO, SEL PNL, and NEXT 1/2.
2. Press the DISP/ENTER key to execute the advance operation.  
To cancel the operation, press the ESC key.

## 6. OPERATION - PROGRAMMING

### Executing and Releasing the Hold Operation

1. Press the [HOLD] soft key.

A pop-up window for executing/releasing the hold operation appears.




2. Select [ON] (execute) or [OFF] (release) using the up and down arrow keys.
3. Press the DISP/ENTER key to confirm the changes.

To close the window without making any changes, press the ESC key.

### Changing the Remaining Segment Time When in Hold Operation

1. Press the [SEG TIME] soft key.

A pop-up window for changing the remaining segment time appears. The window shows the remaining segment time.



2. Change the remaining segment time using the up and down arrow keys.
3. Press the DISP/ENTER key to confirm the changes.

To close the window without making any changes, press the ESC key.

### Changing the Target SP When in Hold Operation

1. Press the [TSP CHG] soft key.

A menu for selecting the loop of which the target SP is to be changed appears.

The soft keys of each loop show the tag names of each loop ([INT-01] to [INT-06] in the figure below).



2. Press the soft key corresponding to the tag name of the loop you wish to change the target SP.

A pop-up window for changing the target SP appears. The window shows the current target SP.



3. Change the target SP using the up and down arrow keys.
4. Press the DISP/ENTER key to confirm the changes.

To close the window without making any changes, press the ESC key.


Press the [BACK] soft key to return to the original soft key menu.

### Turning ON/OFF the Pattern Waveform Display of Each Loop


The operation is the same as program selection display. For the operating procedure, see page 6-12.

### Event Display Operation (Style Number S3 or Later)

The operation is the same as program selection display. For the operating procedure, see page 6-13.



## 6. OPERATION - PROGRAMMING



### Executing Several Program Patterns

You can execute multiple program patterns whose loop numbers do not overlap.

#### Switching Pattern Numbers (see page 6-13)

1. Press the [PT NO.] soft key in the program selection screen.  
The pattern number switching pop-up window appears. The currently set pattern numbers are displayed in the window.
2. Select a pattern number using the up and down arrow keys.
3. Press DISP/ENTER key to confirm the changed settings.  
To close without saving, press the ESC key.

### Program Operation Start

1. Press the [RUN] soft key.  
The program operation start pop-up window appears.
2. Press the DISP/ENTER key. The screen changes to the program operation display.

### Displaying the Program Selection Display

1. Press the [SEL PNL] soft key.  
The screen changes to the program selection display.

### Executing a Separate Program Pattern

1. Repeat the above procedure as necessary.

### Switching the Displayed Pattern in the Program Operation Display

1. Press the left or right arrow keys to switch the displayed pattern.

### Switching from the Screen Selection Menu

1. Press DISP/ENTER key in the program operation display to display the display selection menu.
2. With Control selected, press the Right arrow key to display a submenu.
3. Press the up and down arrow keys to select the pattern to display.
4. Press the DISP/ENTER key to display the selected pattern.



## 6. OPERATION - PROGRAMMING

### Starting Program Control

Start program control by displaying the program selection display, selecting the pattern number ([PT NO.] soft key), and starting the control ([RUN] soft key). You can only start the program control on the program selection display.

When you start the program control, the program selection display switches to the program control display. On the program control display, run and reset the program control using a pop-up window that appears by pressing the [RUN/RESET] soft key.

### Selecting the Program Pattern Start Segment


If you wish to set the program control start segment to a value other than [1], select the start segment number using a number within [Segments]. Set the value on the program selection display before program control. The value is reset to [1] when you reset the program control.

### Setting the Delay Time for Starting the Program Pattern Control

If you wish to delay the starting of the program pattern control by a specified time, set the time from program control start to program pattern control in the range of [00:00:00] to [99:59:59]. Set the value on the program selection display before program control. The value is reset to [00:00:00] when you reset the program control.

### Operation Mode during Program Control

The following operation modes are available during program control. Of the operations shown in the figure below, [RUN/STOP] and [PRG/LOG] switch operations are carried out on the control group display. For these operations, see section 6.1, "Operations on the Control Group Display (Switching Displayed Information and Control Operation Modes)."



In the figure, "reset mode" refers to the status in which the program control of all loops is stopped. When program control is started, all loops enter "program control mode." When in "reset mode," you cannot set specified loops to "program control mode." However, you can switch specified loops to "local mode" or stop the operation after program control is started. In addition, even when certain loops are in "local mode," the operation of all loops stops when you set "reset mode."

### Display Update Rate on the Program Control Display

The update rate of the waveform section follows the settings specified by [Set mode] > [#3 Trend/Save interval, Message, File, USER key, DST] > [Time/div]. The update rate of other information is 1 s.

## 6. OPERATION - PROGRAMMING


### Displayed Preset Pattern Waveforms and Their Display Color

Only the preset pattern waveforms of loops that are set as follows are displayed:  
 [Control] > [#1 Control action, Input setting] > [Control mode] to a mode other than [Off]  
 and [Program control] to [On]. If cascade control loops are present, the secondary loops  
 are not displayed. The pattern waveform colors are red, green, blue, blue-violet, brown,  
 and orange for loops 1 to 6, respectively.

### Turning ON/OFF Preset Patterns and PV Waveforms


If viewing is difficult due to overlapping waveforms or if you wish to monitor only certain  
 loops, you can turn OFF the display of unneeded waveforms. For loops of which the  
 waveform display is turned OFF, the background color (waveform color) of the tag/tag  
 comment display in the numeric display section disappears.

#### When waveform display of 2, 4, 5, and 6 are turned OFF



### Split Waveform Display on the Program Selection Display and Program Control Display

If viewing is difficult due to overlapping waveforms on the full display, you can divide the  
 display area into sections. The waveform display position of each loop in split display is  
 set using [setting mode (control)] > [#7 Program-control parameters] > [#3 AUX (Auto  
 message, Display position)] > [Program display position]. For the procedure, see *section*  
*5.9, "AUX (Auto message, Display position)".* The figure below shows an example in  
 which the display area is divided into three sections.



#### Note

The scale displayed at the right edge of the waveform display section on the full display is the  
 scale corresponding to the smallest numbered loop. On the split display, the scale is that of  
 the smallest numbered loop in the divided area.

### Changing the Pattern Settings When in Hold Operation

You can change the following settings when in hold operation.

- The remaining time of the current segment
- Target SPs of each loop

When in hold operation, the soft key menu shows [SEG TIME] (display a window for  
 changing the remaining segment time) and [TSP CHG] (display a menu for selecting the  
 loop of which the target SP is to be changed).

## 6. OPERATION - PROGRAMMING

### Behavior of the Cursor Indicating the Program Execution Position

- Before program control is started, the cursor is at the left end of the waveform display section.
- After program control is started, the cursor moves to the right and indicates the program execution position.  
PV waveforms are not displayed until you press the START key to start the data acquisition to the internal memory.
- After the cursor moves near the center of the waveform display section, the cursor display position stops and the waveforms move. This is to display both the past and future sections of the waveforms.
- When the pattern end is neared, the cursor moves to the right.
- When the pattern ends, the cursor is at the right end of the waveform display section.

### Display When in Hold/Wait Operation and When Released


- When program control is in hold or in wait status, segment time stops and the preset pattern waveform no longer moves. However, PVs continue to be updated.
- When program control hold or wait is released, waveforms are redrawn for the past section based on the PVs and SPs. For the future section, waveforms are redrawn based on the pattern settings. If the pattern is changed while program operation is held, the corresponding preset pattern is redrawn.

### Event Display (Style Number S3 or Later)

- The screen splits into the program selection and program operation displays, and displays events. You can select an event display method from the following.
  - GROUP: The 5 events and event names specified for the group are displayed.
  - TIME EV: All time events and representative event names are displayed.
  - PV EVENT: All PV events and representative event names are displayed.
  - ALL: All events are displayed
- In the program operation display, time events scheduled from the current time are displayed.
- In the program operation display, the indicators that show whether events are ON or OFF are displayed.
  - ON: Displays in red
  - OFF: Displays in green
- When displaying events, waveform division display is unavailable.
- Shows upper and lower limit scale values only when events are displayed

### Display during Advance

When the [ADVANCE] soft key is pressed, the remaining segment time is cleared, and the program moves to the beginning of the next segment. Accordingly, the future section of the displayed preset pattern is shifted by an amount of the lost remaining segment time.



### Executing Multiple Program Patterns

You can run a program pattern when another program pattern is running. Patterns having overlapping loops may not be run simultaneously.


## 6. OPERATION – DATA ACQUISITION

### Data Acquisition – Internal Memory

#### Starting Data Acquisition to the Internal Memory.

Press the **START** button.

When the data acquisition to the internal memory starts, the memory operation indicator icon changes from stop indication to run indication as shown below.



#### Stopping Data Acquisition to the Internal Memory.

Press the **STOP** button

Use the left and right arrow keys to select [Memory] of [Mem+Math] in the confirmation window that appears



Press **DISP/ENTER** key. When the data acquisition to the internal memory stops, the memory operation indicator icon changes from run to stop indication.


## 6. OPERATION – COMMUNICATION FUNCTION

By using the Ethernet interface that is fitted to the controller data can be transferred on to a server in two methods:

### 1. FTP Server


The controller can be accessed from a PC to retrieve files from the external storage device

### 2. FTP Client – Automatic File Transfer



The display data file, event data file, and the report file can be automatically transferred to a remote FTP server. The result of the transfer is confirmed on the FTP log screen.

Up to two file destinations can be specified (primary and secondary). If the primary server is down, the file is transferred to the secondary file.



## 6. OPERATION – COMMUNICATION FUNCTION

### Web Server

The controller screen can be displayed on the browser applications of Microsoft Internet Explorer. Two screens are available. The screen can be updated at a constant period.


### 1. Monitor Page

Screen for dedicated monitoring. The following information can be displayed.

- Alarm Summary
- Measured/computed data of all channels
- Logs (Message summary, error log, FTP log, email log, Web operation log, setting change log)

### 2. Operator Page

In addition to the contents on the monitor page the controller screen can be switched to different views.



### Email Transmission

The controller can transmit emails to specified destinations at the following times:

- When an alarm is active/released
- During recovery from a power failure
- When memory end is detected
- When an error related to the external storage medium and FTP client occurs

**For more information on the controller communication functions and setup please refer to the communication manual included with the chamber**

# 7. MAINTENANCE

## **Preventive Maintenance.**

**All maintenance and servicing should only be carried out by suitably trained and qualified personnel.**

The cabinet has been designed and built for a long life and required minimal attention and maintenance. However, regular attention to the few points few points will ensure a long and trouble free operation.

If the cabinet does fail, the expertise of our service engineers is readily available for either diagnostic advice or non-site attendance. Service and calibration contracts are available from our service department.

## **Weekly or post test if longer.**

Cleaning. Do not use cleaning agents that contain 'hypochlorite' as these may attack stainless steel.

Check Drain Accumulation of contaminants from the test samples can block the treatment chamber drain. To inspect the drain, remove the two screws holding the treatment chamber cover and remove the panel. The drain in the base should be free from contaminants that could block it.

## **Monthly.**

### **Check Thermostat.**

Adjust the thermostat through the prevailing cabinet temperature. Check for the correct function. In the event of the thermostat being faulty Rectify the fault at once. The thermostat should switch the chamber OFF

### **Purified Water Inlet.**

The filter inside the clear plastic bowl is located inside the instrument compartment, after the water inlet nozzle, this can be inspected by looking through the viewing hole. The clear plastic bowl and filter can be unscrewed and removed for cleaning.

To clean the filter (see page 43), disconnect the water supply, open the instrument compartment door, unscrew the filter bowl and remove the filter. Clean or replace the filter and clean the bowl. Reassemble in reverse order. Care must be exercised so that water is not splashed onto other areas in the instrument compartment.

### **Float Valve.**

The float valve maintains the level of purified water for the vapour phase generator. The float valve, in the chamber should be checked for correct operation. Open the instrument door, remove the loose lid from the constant level device

### **Refrigeration Unit Cleaning.**

Switch off the mains power supply, remove the ventilation panels, gently brush/blow/vacuum dust etc from the fins and tubes of the condenser coils

## **Annually.**

Checking of the calibration, and if necessary of the combined temperature/humidity probe is recommended on a yearly basis. It is recommended that Weiss Gallenkamp service engineers perform the calibration as errors may be caused by other factors, such as humidity and temperature controllers.

## 7. MAINTENANCE



### Calibration of Electronic temperature/Humidity Probes

Combined electronic temperature and relative humidity probes carry a valid calibration certificate. Calibration should be checked after one year.

### Purified Water Filter

This is located below the purified water inlet, and can be inspected through the viewing hole in the rear of the chamber.

The clear plastic bowl and filter can be removed for cleaning.



**NOTE:**



Please check the filter once a month, if it looks dirty, or contaminated clean or replace.



## 7. MAINTENANCE

### Vapour Phase Generator (VPG)

Once a year inspect the VPG for signs of contamination




ITEM	DESCRIPTION
1	VPG Tank
2	Wade Coupling
3	Olive
4	1500W Heating Element
5	Washer
6	Nut
7	Bung
8	38mm Silicone Port
9	Thermostat

**NOTE:** Ultra pure water will destroy the heater element and can cause irreparable damage to the plant growth chamber. Ensure water of the correct quality is used (see page 15)

# 7. MAINTENANCE


## Torbeck Tank



Item Number	Description
1	Torbeck Welded Tank
2	Torbeck Tank Lid
3	Torbeck Valve
4	Torbeck Washer
5	Torbeck Back Nut
6	1/2" Adapter
7	Adapter
8	90°Bend
9	Nut
10	Washer
11	90°Bend
12	Float Switch
13	Float Switch Washer
14	Float Switch Back Nut


## 7. MAINTENANCE

### Replacing the Fluorescent Tube



## 7. MAINTENANCE

## Electrical Wiring Schematic



---

---

RELAY LIST		
RELAY NAME	PORT NO.	TYPE
RL A	COMB-1	PSD A/F
RL B	COMB-1	16150 JG
RL C	COMB-1	SHUNT
RL D	COMB-1	PSD A/F
RL E	COMB-1	PSD A/F
RL F	COMB-1	SHUNT


MCX (C3)		
NAME	RANK	SIZE
MC1	11,11,11	11,11,11
MC2	11,11,11	11,11
MC3	11,11,11	11,11
MC4	11,11,11	11,11
MC5	11,11,11	11,11
MC6	11,11,11	11,11,11
MC7	11,11,11	11,11,11
MC8	11,11,11	11,11,11
MC9	11,11,11	11,11,11

07	47	of	1	52000.01
SONO SCALE				

[illegible]

# 7. MAINTENANCE

## Refrigeration Schematic



## 8. TROUBLESHOOTING


All Maintenance And Servicing Should Be Carried Out By Suitably Trained And Qualified Personnel.

	FAULT SYMPTOM	POSSIBLE CAUSE
CONTROL PANEL	Power Switch on but not illuminated	Electricity power failure
	Power switch will not switch on	Indicator lamp failed Heater circuit fault Vapour phase generator fault Refrigeration fault
	Power switch in but controllers not illuminated	Safety thermostat faulty
		Safety thermostat set too low
INSTRUMENT COMPARTMENT	MCB trips and will not reset	Fan motor failure Air Heater failure VPG Heater failure Lighting Circuit failure Controller electrical failure Light Cooling Fan failure
TEMPERATURE CONTROL	Cabinet is tripped by safety thermostat (or over temperature drift)	Set point incorrect Thermostat set incorrectly or faulty If output on the controller is 0% then controller fault or a refrigeration fault
	Under temperature drift	Set point incorrect If output on the controller is 100% then controller fault or heater fault
	Chamber stable but below or above temperature set point	Chamber operated outside environmental specification See over and under temperature drift
HUMIDITY CONTROL	If the humidity control is too high or low:	Set points are incorrect Chamber is being operated outside environmental conditions Treatment chamber flooded – wastewater drain blocked Low water switch in the torbeck tank broken/damaged Thermostat on the Vapour Phase Generator tank tripped – press to reset Venting incorrect Vapour phase generator heating element failed

## 9. SPECIFICATION






### Plant Growth Chamber- Specifications

<b>MODEL</b>	<b>SGC170</b>
<b>PHYSICAL</b>	
	Floor Mounted
<b>External Dimensions WxDxH (mm)</b>	2285 x 1000 x 2150
<b>Working Chamber Dims. WxDxH</b>	1400x 800 x 1480
<b>Working Volume</b>	1700 litre
<b>Outer Case</b>	Zinc Coated Mild Steel with stoved acrylic textured finish
<b>Inner Chamber</b>	Type SUS 304 Stainless steel with a reflective coating
<b>Shelves</b>	2 off plastic coated steel half depth shelves
<b>Maximum Shelf Loading</b>	10kg
<b>Maximum Chamber Loading</b>	50kg
<b>Supports</b>	4 Castors – 2 front castors lockable
<b>Weight</b>	500 Kg
<b>Drain</b>	22mm diameter - provided for drainage of evaporator condensate
<b>Vent</b>	Rear silicone vent to allow for air volume expansion and contraction during temperature changes- and prevent vapour build-up
<b>ACCESS</b>	
<b>Air Exchange</b>	1 off Air exchange vent on the front of the chamber
<b>Cable Port</b>	1 off 66mm diameter silicone in left-hand side wall
<b>Doors</b>	Full width / height insulated double doors. Viewing window in LHS door with light shield Instrument, chamber and electrical compartment doors are lockable.
<b>ELECTRICAL</b>	
<b>Supply Voltage</b>	415V 50Hz 3 Phase 50Hz
<b>Maximum Current</b>	17 Amps
<b>WATER</b>	
<b>Purified Water Requirement</b>	For humidification system. Conductivity 5 to 20 $\mu$ S cm <sup>-1</sup> Supply pressure range 2-14p.s.i. (0.1-1bar). Water filter provided
<b>Drain</b>	22mm diameter - provided for drainage of evaporator condensate to open drainage point
<b>Heat Dissipation</b>	7.32kW
	* Heat Dissipation is calculated at 415 V
<b>CONTROLS</b>	
<b>Controllers</b>	Microprocessor controlled digital temperature and humidity controllers
<b>Sensors</b>	High specification solid-state capacitance humidity probes with PRT temperature sensing.
<b>Humidification</b>	Vapour phase humidity generator with low water level protection for prevention of water borne contamination.
<b>Heating</b>	'Inconel' electrical resistive heating operating at 'black heat'.
<b>Airflow System</b>	Vertical airflow direction upwards @ 0.2m/s.
<b>Lighting</b>	20 off 58W TLD 84 Fluorescent tubes plus 8 incandescent lamps air-cooled in a light box. Variable intensity from 10% to 100% of maximum.

<b>System Management</b>	Microprocessor based integrated system management for reliability and high energy efficiency and rapid condition recovery following sample loading
<b>PERFORMANCE</b>	
<b>Ambient Operating Range</b>	+12 °C to +25 °C
<b>Temperature Only Control Range</b>	+7 °C to +40 °C (lights on) 0 °C to +40 °C (lights off)
<b>Temperature Fluctuation (with time)</b>	±0.3 °C @40°C
<b>Temperature Uniformity (spatial)</b>	±1 °C
<b>Temperature &amp; Humidity Control Range</b>	25% to 88% @ +40°C 42% to 95% @ +20°C 50% to 95% @ +10°C
<b>Humidity Uniformity</b>	±3% relative humidity on average
<b>Air Velocity</b>	0.2m/sec (turbulent) (average within empty working chamber)
<b>SAMPLE LOAD PROTECTION</b>	
<b>Safety Thermostats</b>	Independent high safety thermostat capable of shutting down chamber.
<b>OPTIONAL ACCESSORIES</b>	
<b>Water Supply</b>	Self contained recirculating purified water system - with filtration, deionisation and UV sterilisation built-in.
<b>Compliance</b> 	Complies with the essential health and safety requirements of Machinery Directive 98/37/EC and its amendments Electromagnetic Compatibility Directive 89/336/EEC and its amendments Low Voltage Directive 73/23/EEC and its amendments



## 9. DIMENSIONS



SGC170 Dimensions

## 10. SPARE PARTS LIST

PART NUMBER	DESCRIPTION
K06517	Main Door Seal
K06541	Inspection Door Seal
E70118	2500W Chamber Heating Element
33100.221	1500W VPG Heating Element
K04648	Air Circulation Fan Motor
E20036	Fluorescent Tube
E20505	Tungsten Lighting
E22550	Lighting Ballast
K02191	Lamp Box Cooling Fan
E13033	Fuse Anti-Surge 630mA
E04041	Temperature and Humidity Sensor
K02302	Water Filter
36090.035	Float Switch For Torbeck Tank
37070.008	Thermostat For VPG Tank
E47027	Thermostat For Lamp Box
E47028	Thermostat For Chamber
K04346	Latch Key For Main Door
K06607	Replacement Mesh Shelf
K06608	Mesh Shelf Support Rods
K06719	38mm Port Plug
K06720	66mm Port Plug
72100.472	VPG Bung

## 11. Disposal/Decommissioning

The removal of components after their use should be environmentally friendly. The chamber should be delivered to a company that specialises in the complete removal.

The table below lists all details of removal and repeated use of individual parts of the chamber

Product	Material	Removal
Steel construction frames, Impellers, pipelines	Metals	Separation of materials  Melting procedure for repeated use (recycling)
Insulated case and doors	Metals, PU foam	Separation of materials Special incineration procedure
Cables casings and plugs	Rubber, PVC, silicone, PTFE and similar artificial materials	Separation of materials Recycling
Electronic Assemblies	Artificial materials, metals, electrolyse	To special waste dumps in compliance with all local regulations
Fluorescent Tubes	Glass, metals (inc. Mercury)	To special waste dumps in compliance with all local regulations

Products with coatings should be delivered for processing to enable their repeated use, depending on the type of coating, or be taken to special waste dumps in compliance with all local regulations



**WEISS GALLENKAMP LIMITED**

Unit 37/38

The Technology Centre

Epinal Way

Loughborough

Leicestershire

LE11 3GE

United Kingdom

Tel: +44 (0)1509 631595 Sales

+44 (0)1509 631590 Service

Fax: +44 (0)1509 211133

E-mail: [sales@weiss-gallenkamp.com](mailto:sales@weiss-gallenkamp.com)

[service@weiss-gallenkamp.com](mailto:service@weiss-gallenkamp.com)

Website [www.weiss-gallenkamp.com](http://www.weiss-gallenkamp.com)

UM-SGC170 Issue A

First Issued for S170PFXF10001