

HGM SERIES

DIGITAL WEIGHING & COUNTING SCALE

OPERATION MANUAL

PLEASE READ THIS MANUAL VERY CAREFULLY BEFORE
ATTEMPT TO OPERATE THE SCALE

AUGUST 1999 REV 2

Specifications subject to change without prior notice

CONTENTS

1. INSTALLATION INSTRUCTION
2. INSTALLATION DIAGRAM
3. SPECIFICATIONS
4. KEYBOARD LAYOUT
5. KEY AND SIGN DESCRIPTION
6. INTERNAL FUNCTIONS
7. OPERATING INSTRUCTION
8. TROUBLE SHOOTING
9. DAILY CARE AND MAINTENANCE APPENDIX

1. INSTALLATION INSTRUCTION

1.1 UNPACK THIS SCALE VERY CAREFULLY. Check and make sure that the following items are included.

This operation manual

HGM scale x 1

Plastic platter x 1

Stainless steel platter cover x 1 (option)

Dust cover x 1

AC adaptor x 1

Contact your dealer if any items are missing.

1.2 PLACING THE PLATTERS

1.2.1 Place the plastic platter into the scale either in longitude or latitude direction preferred. Always place the plastic platter into the scale gently, no excessive force is needed. Then place the stainless steel platter cover (if purchased) onto the plastic platter.

1.2.2 The stainless steel platter cover can be fixed permanently to the platter by putting a double side adhesive tape between the platter and the stainless platter cover.

1.3 POWER THE SCALE

1.3.1 This scale is powered by the built-in rechargeable battery and/ or by AC adaptor supplied.

1.3.2 Check and make sure that the voltage of the AC adaptor supplied matches with the voltage of the mains output.


1.3.3 Insert the output plug of AC adaptor firmly into the DC input jack of scale. The DC input jack is located at the left side of scale.

1.3.4 Before first time use, charge the built-in rechargeable battery until the charging indicator turns green.

1.3.5 For safety reasons, do not share the same mains outlet with other apparatus.

1.4 RETAIN ALL PACKING MATERIAL FOR FUTURE TRANSPORTATION OF SCALE.

2. INSTALLATION DIAGRAM



3. SPECIFICATIONS


General Specifications

Model Number	Capacity		Division	
	metric	Pound*	Metric	Pound*
HGM-2000	2000g	4.4lb	0.1g	0.0002lb
HGM-4000	4000g	8.8lb	0.2g	0.0005lb
HGM-10K	10kg	22lb	0.5g	0.001lb
HGM-20K	20kg	44lb	1g	0.002lb
Power Source	By Built-in Rechargeable Battery and / or, AC Adaptor output = DC9V/500mA (included)			
Platter	215 x 250mm			
Tare Range	Full Range			
RE-Zero Range	Maximum = 200 division			
Auto Piece Weight Enhancement Range:	Minimum = 4 pieces Maximum = 100% of max. counts previously achieved			
Temp. Range	0 ~ 40°C (32 ~ 104°F)			
Options:	Backlight, Stainless Steel Platter Cover, Rs232 and printer interface			

*To comply with the law of certain countries, the pound unit may be disabled. Contact your dealer for more information.

Specifications and functions subject to change without prior notice.

4. KEYBOARD LAYOUT



5. KEY AND SIGN DESCRIPTION

KEY

- | | | |
|---|----------------|--|
| 1 | OFF | Press this key to turn scale off. |
| 2 | ON/RE-ZERO | Press this key to turn scale on or set weight to zero (max. zero range = 200 division) |
| 3 | SAMPLE/SE
T | Press this key to select/confirm sample size and trigger the counting mode. |
| 4 | MODE | Press this key to shift between various weight unit and turn backlight on/off. |

SIGN

- | | | |
|----|--------|--|
| 5 | 0 | ZERO STATUS SIGN. When the weight detected is at true zero, an arrow will appear and point at this sign. |
| 6 | — | MINUS SIGN. When the weight detected is below zero, an arrow will appear and point at this sign. |
| 7 | | TARE STATUS SIGN. When the tare function is being employed, an arrow will appear and point at this sign. |
| 8 | PCS | COUNT SIGN. This sign appears when the scale is in counting mode. |
| 9 | | LOW BATTERY SIGN. When this sign is on, recharge the battery immediately by employing the AC adaptor |
| 10 | WEIGHT | 1. Weight being displayed is in |

UNIT decimal pound.
 INDICATOR 2. Weight being displayed is in lb and oz.
 3. Weight being displayed is in metric unit.

OTHERS

- 11 CHARGE INDICATOR RED: Built-in rechargeable battery is being recharged.
 GREEN: Rechargeable battery is completely charged.
- 12 PS232 Output Port RS232C OUTPUT PORT

6. INTERNAL FUNCTIONS

6.1 INTERNAL FUNCTION TABLE

Function	Symbol	Description	Note
1	Fun-1	Scale configuration setting and dealer calibration.	A
2	Fun-2	Display segment check.	
3	Fun-3	Read offset value, select weight unit(s) and enable/counting function.	
4	Fun-4	Auto power off setting.	

NOTE: A For dealer and authorized person only. Inappropriate setting may cause system failure. Contact your dealer for more information or service.

6.2 HOW TO ENTER THE REQUIRED FUNCTION MODE

- Turn scale off.
- Press and hold **SAMPLE/SET**, then turn scale on.
- Press **SAMPLE/SET** until the required function number appears.
- Press **MODE**.
- Press **MODE** until the required setting/value appears.

- f. Press **SAMPLE/SET** to confirm.
- g. Repeat step c through f for other function setting, or
- h. Press **ON/RE-ZERO** to save settings and return to normal operation.

6.3 INTERNAL VALUE DESCRIPTION

Fun-1 Contact your dealer for more information.

Fun-2 To check all display segment works properly

Fun-3 When scale displays F.3, press and hold **MODE** until Weight Unit Indicator appears then release **MODE** .
Press **MODE** again until the appropriate configuration is attained.
(The metric weight is default unit and cannot be disabled.)

Fun-4 To set the Auto Power Off Function.
Two modes are available: (Default = 4_OFF)
0_OFF = Auto Power Off Function is disabled.
4_OFF = Scale will be turned off after 4 minutes used.

7. OPERATING INSTRUCTION

7.1 PLACING THE SCALE

Place this scale on a hard and strong enough surface where is free from RF interference, vibration, fire, direct sunlight and excessive moisture.

For best weighing results, always place this scale on a level surface. This scale is equipped with a bubble level. If required, adjust the adjustable feet underneath the scale to obtain a level condition.

7.2 POWER ON/OFF THE SCALE

7.2.1 To Turn Scale On, Press **ON/TARE**.

7.2.2 To Turn Scale Off, Press **OFF**.

7.3 SELECT DESIRED WEIGHT UNIT

Press **MODE** during normal operation until the desired weight unit indicator appears.

7.4 ZERO & TARE FUNCTION

7.4.1 If Zero Status Sign does not appear when scale is unloaded, press **ON/TARE** to reset weight displayed to zero. Refer to general specification table for maximum zero range.

7.4.2 To tare Off the Weight of a Container
Place a container onto platter, then
press ON/TARE to tare off the weight of
it. After the TARE is pressed, the tare
sign will appear.

NOTE: If the weight of a container is less than
200 divisions of the scale, the Zero Status
Sign, instead of the TARE STATUS SIGN, will
appear when pressing ON/TARE.

**7.4.3 To Clear The Weight Of A Container From
Memory**

Remove all loads from the platter then
press **ON/TARE**.

7.5 PLACING A LOAD

Always place a load onto the platter gently.
Sudden shock, excessive force or
overloading the scale may cause damage to
the weight sensor inside.

It is a good practice to remove all load
from platter when not in used. This will
prolong the life time of weight sensor.

7.6 WEIGHING FUNCTION

a. Before weighing, make sure that the Zero
Status Sign is on.

- b. Press **MODE** until the desired Weight Unit
Indicator appears.
- c. Place subject matter on platter and the
weight of it will be displayed.
- d. For best weighing results, refer to
Appendix A for recommended minimum weight
to be applied.

7.7 COUNTING FUNCTION

7.7.1 Turn Scale On. Make sure that the Zero
Status Sign is on. Press **ON/TARE** to attain zero
status if required. If a container used, place
the container onto the platter first then press
ON/TARE to tare off the weight of it.

7.7.2 Sampling

Sampling is the first step of counting
transaction. By means of sampling process, the
unit piece weight is obtained. The unit piece
weight forms foundation of quantity
calculation

- a. Press **SAMPLE/SET** to trigger the counting
function. When SAMPLE/SET is pressed, S=10
appears.
- b. Press **SAMPLE/SET** to attain the desired
sample size of 10, 20, 50 or 100 pieces.
- c. Place the correct sample quantity onto the
platter.

- d. Press **SAMPLE/SET** to confirm.
- e. Wait until the **COUNT SIGN** and corresponding value appears.

NOTE: No value will be entered/accepted if the unit piece weights is too light.

- f. Sample process is now completed.

HINT: It is usually true that the larger the sample size, the more accurate the subsequent counting result.

NOTE: For best counting results, refer to Appendix A for recommended minimum piece weight.

7.8 COUNTING TRANSACTION

After the sampling process is completed, and additional pieces or remove pieces, the updated total quantity is shown on the display.

7.9 AUTO PIECE WEIGHT ENHANCEMENT FUNCTION

In order to obtain the best counting results and to avoid sampling error, this scale is equipped with Auto Unit Piece Weight Enhancement function.

This function will reside in memory when the unit piece is obtained by the sampling method as described in 7.7.2.

NOTE: Auto Unit Piece Weight Enhancement Function will be terminated if a zero weight is detected during the transaction process. It is strongly recommended that this function be employed when the unit piece weight is not consistent.

7.9.1 How Auto Piece Weight Enhancement Function Works.

7.9.1.1 After a unit piece weight is obtained by method as described in 7.7.2 then place more/remove sample pieces on the platter. The new quantity will be shown on the display.

7.9.1.2 The Auto Unit Piece Weight Enhancement Function will update the internal unit piece weight if both of the below requirements are met:

- a. The quantity added to platter is more than 4 pieces.
- b. The quantity added to platter is less than 100% of previous maximum counts previously attained from the same transaction

7.9.1.3 If the above requirements are met, a new unit piece weight will be entered internally and confirmed by an audio ;\$beep;

7.10 COMPUTER DATA OUTPUT (option) FUNCTION

7.10.1 Create a BASIC computer program file as below to enable the data from scale to be received by computer.

```
10 OPEN ;$OCM?2400, N,8,2,CS,DS,CD;" AS#
```

Remark: ?: Input 1 if the input port of computer is COM 1, or input 2 for COM 2;Ketc

```
20 LINE INPUT #1, AS
```

```
30 PRINT A$
```

```
40 GOTO 20
```

```
50 END
```

Save the above program file.

7.10.2 Connecting The Scale With A Computer

Follow the below steps to connect the scale with a computer.

- a. Turn scale off
- b. Turn computer off
- c. Connect the RS232C output of scale to computer by an appropriate data cable.
- d. Turn scale on
- e. Turn computer on
- f. Load and run the BASCIA program file

7.10.3 Computer Data Transmission

- a. Set all the parameters required.
- b. Conduct transaction as usual.
- c. Data will be transmitted to computer automatically when weight detected is stable.

- d. Refer to Appendix B, C and D for more information.

7.11 RECHARGING THE SCALE

When the LOW BATTERY sign appears, recharge the scale immediately by using the AC adaptor. Fail in doing so will damage the built-in rechargeable battery.

Scale can be recharged during normal operation. This charge status is displayed by the Charge indicator as below:

- a. RED: Rechargeable battery is being recharged.
- b. GREEN: Rechargeable battery is completely charged.

8. TROUBLE SHOOTING

SCALE CANNOT BE TURNED ON

Check Is the built-in rechargeable battery charged?

Action Recharge the battery for at least 8 hours if first time use or use the AC adaptor.

Check Is the right AC adaptor being used or is it inserted properly both in the wall outlet and into the scale.

Action Check AC adaptor and secure both ends of the AC adaptor into the wall outlet and DC input of the scale.

ZERO WEIGHT CANNOT BE ATTAINED WHEN TURNED ON

Check Is the platter placed correctly?

Action Check and insert the platter again.

Check Is any load applied to the platter?

Action Remove all load from platter. Turn scale off and turn on again.

Check Is the scale affected by air flow, vibration or RF interference?

Action Place scale away from all disturbances and try again.

RATED CAPACITY CANNOT BE ATTAINED

Check Is anything obstructing the platter?

Action Remove all obstacles between platter and scale.

SCALE DISPLAYS⁰⁰⁰⁰⁰

Check Is the scale overloaded?

Action Remove all load on platter and check again.

Check Is the platter inserted correctly into the scale?

Action Take off the platter and insert again.

Check Is the stainless steel platter (if purchased) placed onto the platter?

Action Place the stainless steel platter onto the plastic platter.

SCALE DOES NOT WEIGH CORRECTLY

Check Is the correct weight unit employed?

Action Select the correct weight unit.

Check Is the minimum weight being applied to the scale?

Action Refer to Appendix A for recommended minimum load applied and try again.

Check Is the scale placed on a level surface?

Action Check the bubble level and adjust the adjustable feet to obtain a level condition.

Check Is the scale effected by air flow,

vibration or RF interference?

Action Place scale away from all disturbances.

Check Is the scale calibrated correctly?

Action Contact your dealer.

SCALE DOES NOT COUNT CORRECTLY

Check Is the right sample size employed during sampling process?

Action Repeat the sampling process and try again.

Check Is the sample size employed during sampling process too small?

Action Increase the sample size, repeat the sampling process and try again.

Check Is the scale placed on a level surface?

Action Check too bubble level and adjust the adjustable feet to obtain a level condition.

Check Is the scale effected by air flow, vibration or RF interference?

Action Place scale away from all disturbances.

Check Is the scale calibrated correctly?

Action Contact your dealer.

Check Is the Auto Unit Piece Weight Enhancement function being employed?

Action Repeat sampling process according to paragraphs 7.7.2.

SCALE TURNED OFF AUTOMATICALLY

Check Is the AUTO POWER OFF function employed?

Action Disable the AUTO POWER OFF function.

Check Is the LOW BATTERY sign on?

Action Recharge the battery or employ the AC adaptor.

DATA TRANSMISSION ERROR

Check Is the BASICA Program file written correctly?

Action Refer to the operation instruction and check program file is correctly written.

Check Is the BASICA program file loaded and run?

Action Load and run the BASICA program file.

Check Are both end of the cable linking scale and computer/printer firmly secured?

Action Secure both ends firmly.

Check Is the right data cable used?

Action Contact your dealer or hardware engineer.

9. DAILY CARE AND MAINTENANCE

9.1 Do not open scale for any reason. Contact your dealer for servicing.

9.2 Avoid exposing scale to direct sunlight or excess moisture.

9.3 Do not lift/move scale by holding the platter.

9.4 Do not submerge scale in water.

9.5 Take platter away from scale before transportation.

9.6 Clean the scale with a soft and damp cloth, if necessary with a mild detergent.

9.7 Do not use any harsh, abrasive material, solvent thinner or alcohol for cleaning.

9.8 Verify the accuracy of scale periodically. Re-calibrate the scale when needed.

NOTE: In some countries, calibration is restricted to be done by qualified or authorized agents only. Contract your dealer for more information.

9.9 Store scale in a dry and cool place.

Appendix

Appendix A

Recommend Minimum Weight for various applications

Model No.	Recommended Minimum	
	Weight Applied	Piece Weight
HGM-2000	2g/0.0041b	0.1g/0.00021b
HGM-4000	4g/0.011b	0.2g/0.00051b
HGM-10K	10g/0.021b	0.5g/0.0011b
HGM-20K	20g/0.041b	1g/0.0021b

Appendix B

RS232C Interface Protocol

Type: EIA-RS-232C

Method: Half-duplex, asynchronous transmission

Baud rate: 2400

Data bit: 8

Parity bit: None

Stop bit: 2

Code: ASCII

Appendix C

RS232C Data Format

+		1	0	0	.	0	5							CR	LF
---	--	---	---	---	---	---	---	--	--	--	--	--	--	----	----

Position Code

1 2 3 4 5 6 7 8 9 10 11 12 13 14

Position Code Definition:

1

 = Polarity of value (Plus or Minus)

+ or blank = Positive value

- = Negative value

2	3	4	5	6	7	8
---	---	---	---	---	---	---

= Value of weight, pieces or percentage

9

 = Space

10	11	12
----	----	----

 = Unit

kg = kilogram

g = gram

lb = pound

Appendix D

RS232C Wiring Description

Pin 3 = RXD

Pin 7 = Ground