

SimpleID User Manual

Table Of Contents

Copyright notice	3	Schedules tab.....	18
Liability waiver	3	Schedule details panel.....	18
Introduction.....	4	Access levels tab.....	19
Overview.....	5	Access level details panel.....	19
General information.....	6	APB areas tab.....	20
Settings.....	7	APB area details panel.....	20
Security group.....	7	Users tab.....	21
Language group.....	7	General user details.....	21
Miscellaneous group.....	7	Credential details.....	22
Backup group.....	8	Automatic notifications window.....	23
Data Import/Export group.....	9	Filter window.....	23
Sounds group.....	9	Users list.....	24
System group.....	9	Card formats window.....	25
Card reader settings window.....	10	Holidays tab.....	26
Modules window.....	10	Holiday details.....	26
Modules window: API service.....	10	Monitoring tab.....	27
Modules window: occupancy.....	11	Monitoring tab overview.....	27
Export window.....	12	Events list.....	28
Data import window.....	13	Acknowledgment settings window.....	28
Submit logs window.....	14	Maps list.....	29
Doors tab.....	15	Inputs list.....	29
Door details panel.....	15	Doors list.....	30
Keypad formats window.....	16	Reports tab.....	31
Inputs tab.....	17	Option groups of reports tab.....	31
Input details panel.....	17		

Copyright notice

All rights reserved. This work or any of its parts may not be reproduced in any form and by any means (including, but not limited to copying, printing, photocopying and digitizing) without the written permission of UAB Midpoint Security.

Liability waiver

This document has been prepared with accuracy and care, however, UAB Midpoint Security assumes no responsibility for any errors or omissions and may not be held responsible for any damages resulting from the use of this document or from the use of software or hardware products described in this document. In no event shall UAB Midpoint Security be liable for lost profits, opportunities or any other damage caused or alleged to have been caused directly or indirectly by this document of the products described herein.

Introduction


SimpleID is an innovative access control software that supports HID Edge IP readers/controllers and VertX IP controllers and also Suprema's IP fingerprint readers .

SimpleID has been designed with the goal of providing a simple and at the same time highly effective interface to enable users of all levels to have a complete control over the system.

SimpleID is made and supported by UAB Midpoint Security located in Kaunas, Lithuania (EU).

For more product information and support, please visit our web site www.midpoint-security.com.

Overview


**Note:**
Default administrator password is: admin

SimpleID software consists of 2 packages:

1. SID Controller Communication Service
2. SID Graphical User Interface

SID Controller Communication Service communicates with hardware devices such as HID VertX controllers and Edge readers. It sends configuration, cards and commands, and receives events from hardware devices. There are no user adjustable settings in this program. It will start automatically every time your PC boots up. If you wish to verify whether SID Controller Console is functioning, you may do so by viewing Windows Task Manager and checking if SIDController.exe process is running. **SID Controller Console should be installed only on one computer. This computer should be always on.**

SID GUI is a Graphical User Interface which is used to configure communication settings, users, cards, doors, access groups, time schedules etc. It also has Monitoring feature, which is used for live monitoring of system events. Below is the main menu of the SimpleID software:




The main menu consists of 8 default tabs and an information panel. The tabs switch the inner windows. All inner windows except for Settings window, consist of 2 different panels:

List panel: displays a list of configuration objects, such as doors, time schedules, users, etc. You can search, select, add new or delete selected items.

Details panel: displays and allows to modify settings of a selected item.

List panel

Details panel



General information

General list controls

Mouse Click: you can select an individual item in the list by clicking on it with a mouse button. With simple mouse button click you can select only one item at a time.


Hold CTRL+Click: this combination allows you to add or remove a single item from the selection.

Hold SHIFT+Click: while holding the SHIFT key you can press on several items. The first item you clicked on will be the starting element of the selection and the last item you click on will be the ending element of the selection. If you release SHIFT button and then start holding it again the starting element of the selection will change to the next item you click on (each SHIFT key release will reset the starting element of the selection). This selection mode will deselect all other items, which will not belong to the range.

Hold CTRL&SHIFT+Click: this selection mode works the same as "**Hold SHIFT+Click**", but it will not deselect already selected items which do not belong in the range.

INSERT Key: when the list has focus clicking this button will insert a new item to the list.

DELETE Key: when there are selected items in the focused list, pressing this key will delete(or deactivate) all selected items at once (can be 1 or more items).



Settings

Security group



The Security settings dialog box has a title bar labeled "Security". It contains four password fields, each with a label on the left and a masked input field on the right. The labels are "Administrator password", "Reenter administrator password", "Operator password", and "Reenter operator password". The masked input fields show six asterisks for the administrator passwords and four asterisks for the operator passwords.

Administrator password: change the password for the SimpleID administrator. This account can change any settings in SimpleID. Default password is "admin".

Operator password: change the password for the SimpleID operator. This account is only used for monitoring purposes and can not change any settings in SimpleID. Default password is "Oper".


* **Note:** When you start SID, you can log-in with any of the two passwords. If you log-out while in administrator mode, you are automatically logged-in as an operator.

** **Note:** If you prefer not to enter password every time when you start the software, you may enter the password as a parameter. Add the password as a parameter to the program start command like this:

"C:\Program Files\Midpoint Security\Simple ID GUI\MDP.SID.Main.exe" **admin**

"C:\Program Files\Midpoint Security\Simple ID GUI\MDP.SID.Main.exe" **oper**

Language group



The Language settings dialog box has a title bar labeled "Language". It contains a "Language" dropdown menu with "en-US" selected. Below the dropdown are two buttons: "Export" and "Import". To the right of these buttons is a "Select encoding:" label followed by a dropdown menu with "UTF8" selected.


Language: SID supports user interface localization. Translation is performed "on the fly", directly in the GUI. Some settings can not be translated while the system is running, so after changing the language it is recommended to restart SimpleID GUI.

Export: writes the data for translation to other languages or update an existing language. Supported formats include MS Excel and CSV (comma separated values).

Import: imports translation data from the specified file. Supported formats include MS Excel and CSV (comma separated values).

Select encoding: the text encoding to use for exported file.

Miscellaneous group



The Miscellaneous settings dialog box has a title bar labeled "Miscellaneous". It contains three settings: "Offline event age" with a dropdown menu, "USB reader settings" with a button, and "Modules" with a button. Below the "Modules" button is a checkbox labeled "Ask for confirmation before exiting".

Ask for confirmation before exiting: select if you want to see a confirmation dialog when closing SimpleID GUI.

Offline event age: these events will not be shown on the map, only will be visible in the event list.

USB reader settings: opens the USB reader settings window.

Modules: opens the Modules window.

Backup group

Backup	
Database location	.\\SqlExpress\\SIDDB <input data-bbox="1129 212 1165 257" type="button" value="..."/>
Backup folder	C:\\SIDBackup <input data-bbox="1129 280 1165 324" type="button" value="..."/>
Backup interval (days)	14
Last backup time	10/21/2010 2:52:17 PM
Delete events older than (days)	365
Last events purge	10/21/2010 2:52:18 PM
Delete inactive users older than (days)	365
Date of the last purge of inactive users	10/21/2010 2:52:18 PM
Delete inactive cards older than (days)	365
Date of the last purge of inactive cards	10/21/2010 2:52:18 PM
Database version: 276 System ID: 14317	
<input type="button" value="Backup now"/> <input type="button" value="Restore"/> <input type="button" value="Create new"/>	

Database location: the path to the database in the MS SQL Server. Press the "... " button to open database connection configuration window.

Backup folder: the folder on the server computer, in which the backup files are saved. Press the "... " button to browse for a backup folder. Make sure this folder exists on the server computer!

Backup interval (days): the interval in days between each backup procedure.

Last backup time: the date when the last backup was performed.

Delete events older than (days): during the backup procedure, events older than the specified number of days will be automatically deleted. Enter '0' to disable this feature.

Last events purge: the date when the last message purging was done.

Delete inactive users older than (days): Users which have not used their identifications for the specified amount of days, will be deactivated automatically. Enter '0' to disable this feature.

Last purge of inactive users: the date when the last purging of inactive users was done.

Delete inactive cards older than (days): Identifications which were not used for the specified amount of days, will be deleted automatically. Enter '0' to disable this feature.

Last purge of inactive cards: the date when the last purging of inactive cards was done.

Database version: the number of the current database version used for technical support.

System ID: the unique number of this system.

Backup now: perform a backup of the database instantly.

Restore: perform a database restore from a selected backup file (can only be done from the workstation which is running the database server).

Create new: create a new database structure (wipe all user-created data from current database, a new [System ID](#) will be generated).

Data Import/Export group

Data Import/Export	
Import data	Export

Import data: imports user data from a CSV (comma separated value) or Excel files.

Export: exports user data to a CSV or Excel file.

Sounds group

Sounds			
Unacknowledged event		Acknowledged	
Sound	<input type="text"/>	Sound	<input type="text"/>
Continue	<input type="text" value="Never"/>	Continue	<input type="text" value="Never"/>
Pause	<input type="text"/>	Pause	<input type="text"/>
Acknowledge automatically	<input type="text" value="Never"/>	Close automatically	<input type="text" value="Never"/>

Continue: specifies if the sound should continue playing after it finishes for the first time.

Pause: specifies if there should be any pauses between the sound play-back.

Unacknowledged event	Acknowledged event
Sound: the sound file to be played when there is a new event matching one of the user-defined event filters.	Sound: the sound file to be played when there are acknowledged but not closed events.
Acknowledge automatically: specify if the events should be acknowledged automatically.	Close automatically: specify if the events should be closed automatically.

System group

System	
Upload data to all controllers	<input checked="" type="checkbox"/> Automatic upload
Submit logs	Show GUI logs
Show service logs	

Upload data to all controllers: uploads all configuration data to all controllers.


Automatic upload: once you change anything in the configuration, these changes will be uploaded to the controllers.

Submit logs: Allows you to archive and save application log files to the local computer or submit them to your support representative via e-mail.

Show GUI logs: opens the SimpleID GUI log file storage folder on the local computer.

Show service logs: opens the SimpleID Controller Configuration Service log file storage folder if it is installed on the local computer.

Card reader settings window




The 'Card reader settings' window is a small dialog box with a dark background. It contains three settings: 'Is active' with a checked checkbox, 'COM port' with a dropdown menu showing 'COM1', and 'Baud rate' with a dropdown menu showing '19200'. At the bottom are 'OK' and 'Cancel' buttons.

Is active: Enables the configuration of the card scanner.

COM Port: The COM port number where the card scanner is connected (for USB connected devices the COM port number usually starts from 5).


Baud rate: The speed of the communication line (bits per second).

Modules window



The 'Modules' window is a larger dialog box with a dark background. It features a search bar at the top left, a list of modules ('API service' and 'Occupancy') in the center, and a settings panel on the right. The settings panel includes a checked 'Enabled' checkbox, and fields for 'Host' (localhost), 'Port' (8080), and 'Name' (SID). Navigation buttons (back, forward, search, etc.) are located above the settings panel. At the bottom are 'OK' and 'Cancel' buttons.

Modules window: API service



The 'Modules window: API service' is a smaller dialog box with a dark background. It contains three settings: 'Enabled' with a checked checkbox, 'Host' with a text field showing 'localhost', 'Port' with a text field showing '8080', and 'Name' with a text field showing 'SID'.

Host: the name or IP address of the computer which is running the API Service.

Port: TCP protocol port number to run the API Service on.

Name: the subdirectory name which will be used to form the address of the API Service.

Modules window: occupancy

<input checked="" type="checkbox"/> Enabled <input type="radio"/> Serial port <input type="radio"/> LAN Encoding: Baltic (Windows) Department display time (s): 10 Display user name (s): 2 COM port: COM1 Baud rate: 9600 Data bits: 8 Stop bits: One Parity: None Number of retries: 3 Pause: 10 Hours to analyze: 24	<input checked="" type="checkbox"/> Enabled <input type="radio"/> Serial port <input checked="" type="radio"/> LAN Encoding: Baltic (Windows) Department display time (s): 10 Display user name (s): 2 Hours to analyze: 24 IP address: 192.168.1.123 Port: 50000
---	--

Enabled: if checked, enables the usage of this module.

Serial port/LAN: Select the connection type of the occupancy device.

Encoding:

Department display time (s): time limit in seconds for how long the department should be shown.

Display user name (s): time limit in seconds for how long the users name should be shown.

Hours to analyze: event history should be checked only this amount of hours back.

COM port: serial port number to be used.

Baud rate: serial port communication speed in bits per second.

Data bits: serial port communication line data packet size.

Stop bits: serial port communication line empty packet size.

Parity: serial port communication setting.

Number of retries: serial port communication setting.

Pause: serial port communication setting.

IP address: IP address of the display device.

Port: TCP port of the display device.

Export window

The screenshot shows a window titled "Export" with standard window controls (minimize, maximize, close) in the top right corner. Inside the window, there is a checked checkbox labeled "Export header row". Below this, the "Field options" section contains three dropdown menus: "Character set" set to "Unicode (UTF-8)", "Field delimiter" set to "; - Semicolon", and "Text delimiter" set to "\" - Double quote". The "Data options" section features a "Data to export:" dropdown set to "Users". Below this, there are two lists of fields. The "Available fields" list is empty. The "Exported fields" list contains: "ID", "First name", "Middle name", "Family name", "Employee number", "Phone", "Secondary phone", "Messenger", "Activation date", and "Expiration date". Between these two lists are seven arrow buttons: a right-pointing arrow, a right-pointing arrow, a left-pointing arrow, a left-pointing arrow, a left-pointing arrow, an up-pointing arrow, and a down-pointing arrow. At the bottom of the window are "OK" and "Cancel" buttons.

Export header row: the exported file will contain a header row with field captions.

Character set: file encoding to be used.

Field delimiter: different fields will be separated by this character.

Text delimiter: text strings will be enclosed by this character.

Data to export: type of data you would like to export.

Available fields: fields which will not be exported.

Exported fields: fields which will be exported.

Data import window

Data import

Import

Character set: Unicode (UTF-8)
☒ Has header row
 Table/Sheet: Export
 From row: 1

Duplicate record treatment

User data: Overwrite
 Access levels: Overwrite
 Cards: Overwrite
 PINs: Overwrite
 Fingerprints: Overwrite
 Deactivated users: Activate and update
 Same card/PIN issued to multiple users: Activate latest

Primary key

First and family name

Data binding

Bind selected column to: Not bound
Auto Reset

Preview

ID	FirstName	MiddleName	LastName	EmployeeNumber	Phone	SecondaryPhone	Email	IMessenger	ActivationDate
Column: ID Binding to: Not bound									

OK Cancel

Character set: the encoding of selected file.

Has header row: this should be checked if the file has a row with captions of the fields and this row will not be imported.

Table/Sheet: if selected file is in Ms Excel and has several worksheets, here you can select which one to use.

From row: allows you to select the first row to start importing from (skip importing of preceding rows).

Duplicate record treatment: allows you to select what to do in each case of detected duplicate data.

Primary key: field values to be checked against the current database (for duplicate records).

Data binding: shows which field of SimpleID to use when inserting data of the selected column in 'Preview' table.

Preview: this table shows a preview of the data in the file being imported and also allows you to select any data column (to be bound to a SimpleID field).

Submit logs window

Submit logs

Save logs as ZIP file Today

Size of uncompressed GUI logs 0MB

Size of uncompressed service logs 0MB

Add additional information here


-----System Info-----

CPU: AMD Phenom(tm) II X4 945 Processor
ScreenSize: {Width=1440, Height=900}
OS uptime 323 minutes
OS Version: Microsoft Windows NT 6.1.7600.0
OS Version number: 2.0.50727.4952
OS Time Zone: FLE Standard Time
Machine name: SIMPLEID-PC
.NET Framework 2.0.50727.4927
.NET Framework 3.0.30729.4926
.NET Framework 3.5.30729.4926
.NET Framework 4.0.30319 Full
Available physical memory 1398Mb

OK Cancel

In this window you can select whether you want to save the archived communication log files to your PC or send them to your support representative. You can also select the age of the log files to submit and enter some additional information.

Use this feature in case you encounter any problems with the software.



Doors tab

Door details panel

Strike time (s): indicates for how long the door lock must remain unlocked after the access granted decision.

Held open time (s): indicates the time given for closing the door. If the door is not closed within this time period, "Held open" alarm shall be generated.

Controller address: indicates IP and MAC addresses of the controller. Press the button right of this field to open the device configuration.

Controller type: indicates the type of the controller selected in the 'Device IP address' field.

Device type: indicates the type of the reader (card reader, fingerprint reader or exit button).

Reader address: indicates which reader to use if the controller has more than 1 reader attached to it (only available for VertX controllers: left reader or right reader).

Default mode: selects default reader mode (what type of credentials must be presented in order to unlock the door: card only, card or PIN, card & PIN, fingerprint only, card or fingerprint, card and fingerprint, PIN or fingerprint, PIN and fingerprint). Available options depend on which type of a controller is selected in Device IP/MAC address fields.

Keypad format: indicates which keypad format to use for the controller selected in the IP/MAC address fields. It is only visible for readers which have set to .

Schedule mode: Select a mode you want this reader to switch to during the selected schedule.

Schedule: Select a schedule during which the reader will change its mode to the one specified '**Schedule mode**' field.

Reader mode override: this is the mode set by the operator and will be valid until the operator clears it.

Time & Attendance: specifies if this door is used as clock in/clock out reader for Time & Attendance calculations.

The screenshot shows the 'Door details panel' configuration interface. At the top, there's a door icon with 'X' marks on either side. Below it, the 'Door name' is set to 'Cafeteria'. The 'Strike time (s)' is 3, and the 'Held open time (s)' is 10. There are 'Entry' and 'Exit' buttons. The 'Device IP address' is 172.16.0.135 00:06:8E:00:11:C2. The 'Controller type' is 'HID VertX V2000'. The 'Device type' is 'Reader'. The 'Reader address' is 'Left reader'. The 'Default mode' is 'Card & PIN'. The 'Keypad format' is 'HID 00'. The 'Schedule mode' is 'Not set'. The 'Schedule' is 'Night shift'. The 'Reader mode override' is 'Not set'. The 'Time & attendance' is 'None'. Below these fields is the 'Operation settings' section with four checkboxes: 'Automatically clear forced alarm when door is closed' (checked), 'Turn on beeper and LED if exit button is pressed' (checked), 'Disable forced open alarm' (checked), and 'Disable held open alarm' (checked).

Keypad formats window

Keypad formats

Search

Select all Total 4 Selected 1

HID 00
HID 09
HID 11
HID 20

This item is built-in and cannot be changed

Keypad format: HID 00

1 0x01	2 0x02	3 0x03
4 0x04	5 0x05	6 0x06
7 0x07	8 0x08	9 0x09
* 0x0a	0 0x00	# 0x0b

PIN length: 4
PIN entry timeout: 15
Number of retries: 3
Lockout time: 60
Enter button: #
Cancel button: *

OK Cancel

Keypad format: the name of the keypad format.

PIN length: length of PIN codes.


PIN entry timeout: time interval which is given for a user to enter his PIN number from first to last digits.

Number of retries: number of times the PIN can be entered incorrectly. After reaching this limit the reader will not accept PIN code entries for the time period entered in "Lockout time" field.

Lockout time: Time to lock the reader after several failed attempts to enter a PIN


Enter button: if a users PIN number is shorter than 'PIN length' he can press the specified button to send the PIN to the controller.

Cancel button: when pressed during the PIN entry this button will cancel the operation and nothing will be sent to the controller.



Inputs tab

Input details panel



Name

Tamper

Device IP address

192.168.1.101

Panel number

Ports 1 & 2, address 0

Input address

Tamper

Device type

Motion detector

Contact type

Normally opened

Name: indicates the name of this Input device.


Device IP address: indicates the controllers IP address which has the input device.

Devices MAC address: indicates the controllers MAC address which has the input device.

Input address: indicates the alarm input on the selected controller device.

Device type: indicates the type of the device connected to the input address.

Contact type: select the contact type used by the alarm input device (Normally open or normally closed).



Schedules tab

Schedule details panel

Schedule name:

Selected interval begins at: Ends at:

00:00 06:00 12:00 18:00 23:59

		Monday
		Tuesday
		Wednesday
		Thursday
		Friday
		Saturday
		Sunday
		National holidays
		Other holidays

New workday starts at: (Time & attendance setting)

Time schedule is a user-configured combination of time intervals for a duration of one week. It may be used to define at which times users will be able to access doors. Each schedule consists of 9 day-schedules: 7 weekday-schedules and 2 holiday-schedules. There are 2 time schedules that are built automatically. **Always** works all the time with all controllers. **Never** is for specifying some built-in values and it works the same for a user as if he did not have any schedule assigned to him.

Blue circles represent workdays. Usually from Monday to Friday, as defined in regional settings of the PC. Red circles represent weekends. Usually Saturday and Sunday, as defined in the regional settings of the PC.

Green circles represent holidays, which you can be defined in "**Holidays**" tab of SimpleID.

Schedule name: indicates the name of this schedule.


Selected interval begins at: indicates the start time of the selected interval. You can change this to get precise time.

Selected interval ends at: indicates the end time of the selected interval. You can change this to get precise time.

Weekday-schedules: you can add up to 5 intervals in for each day-schedule in SimpleID. These intervals indicate when a user will get 'access granted' from the readers.

Holiday-schedules: SimpleID allows you to configure 2 types of holidays: national and other holidays. If a certain day of month is marked as one of these holidays, the system will use holiday-schedules instead of normal weekday-schedules.

New workday starts at: indicates when the day ends and a new day starts. This option is used for Time & attendance calculations.



Access levels tab

Access level details panel

Access level details panel			
Name	Legal		
Assign schedules	(Same for all doors)		
South gate	Work time	Always	
Stockroom	Work time w/lunch	Always	
Training room	Work time w/lunch	Always	

An access level is like a set of keys. It is a selection of doors that may be assigned to a user, which in turn defines his/her access permissions.

After including a door into an access level, you may leave the default time schedule "Always", which means that the user having this access level will be able to open the door at all times. Or you may change to another time schedule if you want the user to be able to open the door only at certain times.

Name: indicates the name of this access level.

"Add door" button: opens a dialog to add more doors to this AL (only unused doors will be shown).

Assign schedules: assigns a selected schedule to all the doors in this access level (for all readers).

Door entry reader schedule: This shows the schedule of the entry reader for this door (you can set an individual schedule for each door's entry reader using this).

Door exit reader schedule: This shows the schedule of the exit reader for this door (you can set an individual schedule for each door's exit reader using this).

Remove door from AL: you can remove the door from this access level by pressing this button.



APB areas

APB areas tab

APB area details panel

Name	Inside				
APB exempt	<div></div>				
<div>+ Add door</div>					
Cafeteria	Anti-passback type	Soft	<div></div>	Leads from	Outside
	Anti-passback type	Soft	<div></div>	Leads to	Inside
North gate	Anti-passback type	Soft	<div></div>	Leads from	Outside
Training room	Anti-passback type	Soft	<div></div>	Leads from	Outside

APB (Anti-Pass-Back) areas are used for identification and/or prevention of using the same credentials for entering or leaving the zone several times.

For APB to operate correctly you need at least 2 zones and at least 2 readers. Doors which have an exit button can not be used for APB areas because the system could not track if a user has left that area or not.


Name: indicates the name of this APB area.


APB exempt: allows to select an access level. Users which have this access level will be excluded from this APB rule and will be able to enter/leave an area unlimited number of times.

"Add door" button: opens a dialog to add more doors to this APB area (only unused doors will be shown).

Anti-passback type: mode of anti-pass-back. It can either be "soft" (shows an event) or "hard" (shows an event and denies access).

"Leads from" and "Leads to": indicates which APB areas are connected by this door.


 **Remove door from APB area:** you can remove the door from this APB area by pressing this button.





Users tab

General user details


	
Family name	<input type="text" value="Jackson"/>
First name	<input type="text" value="Jack"/>
Middle name	<input type="text"/>
Phone	<input type="text"/>
Secondary phone	<input type="text"/>
E-mail	<input type="text"/>
Messenger	<input type="text"/>
Department	<input type="text" value="Sales"/>
Title	<input type="text" value="Clerk"/>
Employee number	<input type="text"/>
Access level	<input type="text"/>
	<div>Finance dept. </div> <div>Production dept. </div> <div>Sales dept. </div>


 **Load photo from disk:** load a picture from a local directory and use it as the users photo.


 **Capture photo from camera:** capture an image from a connected camera and use it as users photo.

 **Delete photo:** remove photo of the user.

 **Save photo:** Save current photo as an image into a local directory.

 **Reset APB status for this user:** clear any APB violations the user currently has.

 **Configuration of automatic notifications:** setup automatic notifications (you must enable them in the "Settings → Modules" window).

 **Send SMS:** Send an SMS to this user from a locally connected GSM device (GSM device must be enabled and configured correctly for this to work).

Credential details

Card 1 [Close]

Card [Close]

Card format: 26 bit format [Dropdown] [Configure]

Facility code: 0 [Text]

Number: 0 [Text] [Get number from scanner]

Hex code: 1 [Text]

Fingerprint [Close]

Template No. 1 [Fingerprint Icon] [Add] [Remove] [Trigger duress alarm]

Template No. 2 [Fingerprint Icon] [Add] [Remove] [Trigger duress alarm]

PIN [Close]

PIN: **** [Text]

Reenter PIN: **** [Text]

Activation: 4/23/2008 [Dropdown]

Expiration: 4/23/2009 [Text] [Close]

Add new card: add a new card for this user.

Add new fingerprint: add a new fingerprint template group for this user.

Add new PIN: add a new PIN code for this user.

Card format: select a card format from the list.

Configure card format: open card formats configuration window.

Facility code: the facility code number of the card.

Number: the number of the card.

Get number from scanner: scan card number from a locally attached USB or serial card reader.

Select a number from the list of unused cards: if any cards have been shown to any of configured card readers in the system and are not assigned to users, they will be shown when you press this button.

Hex code: hexadecimal expression of this card.

Add new fingerprint template: scan fingerprints from any fingerprint reader in the system or locally attached USB reader. One fingerprint template holds 2 fingerprints, so one fingerprint template group can store up to 4 different fingerprints.

Remove fingerprint template: delete this fingerprint template from the reader.


Trigger duress alarm: if this is checked, then using any fingerprint from that template will start a duress alarm.

PIN: enter PIN code in this field (and repeat it in "Reenter PIN").

Activation: date when this credentials group starts to work.


Expiration: date when this credentials group will stop working.

Automatic notifications window




Is active: this control activates the automatic notifications for the user.

Notification filter: currently selected notification filter (can't be empty).


 **New notification filter:** use this button to create a new notification filter.

 **Edit notification filter:** use this button to edit the selected notification filter.

 **Add new action:** use this button to create a new action for the selected notification filter.

 **Delete action:** use this button to delete the action from the notification filter.

Filter window




Is active: this control activates the automatic notifications for the user.

Filter name: enter a name for the filter in here. This is mandatory.

In the filter part you select a filter category (the tabs in the left side of the group) and mark filters with left mouse button click (filters are in the left side of the 'Filter' group).

Users list




The screenshot shows a web application interface for managing users. At the top is a search bar with a magnifying glass icon and the word 'Search'. Below it are two dropdown menus: 'Access level' set to 'Finance dept.' and 'Department' set to 'Accounting'. There is a checkbox labeled 'Show deactivated users' which is currently unchecked. Below these are three icons: a star (New user), a red X (Deactivate user), and a minus sign (Select all). To the right of these icons is a status bar showing 'Total 2 (2 cards / 0 fingerprints / 0 PINs)' and 'Selected 1 (1 card / 0 fingerprints / 0 PINs)'. The main area displays a list of users. The first user is 'Romeo, Alf' with title 'Director', department 'Accounting', and ID '0 - 504'. The second user is 'Swanson, Lisa'. A yellow user icon is visible next to the first user's details.


Search: you can filter the list by entering a keyword or just a part of it.

Access level: you may filter the list of users by selecting an access level from the drop-down-list. Only users who have the selected access level will be shown in the list.




Department: you may also filter the list of users by selecting a department from this drop-down-list.

Show deactivated users: if this check-box is checked, you will be able to see all the users (active and inactive) which exist in your database. Inactive users are shown in gray.

 **New user:** press this button to open the user details for new user enrollment.

 **Deactivate user:** press this button to deactivate the selected user.

Select all: toggle this check-box to select all, select none or restore previous selection of the users.

   **Count indicators:** SimpleID counts user credentials of all users in the list and also of currently selected users. This way you will know how many cards, fingerprint templates and PINs there are in the system and in the current selection.

Card formats window

Search

Select all Total 10 Selected 1

26 bit format

31 bit format

32 bit format

33 bit format

34 bit format

35 bit format

37 bit format

42 bit format

56 bit format

64 bit format

← → ✖ 📄 ↶ 📄 ✖

This item is built-in and cannot be changed

☒ Enabled

Name 26 bit format

Bits 26

Number

Facility code

Even parity CRC bit

Even parity bit

Odd parity CRC bit

Odd parity bit

E FC FC FC FC FC FC FC FC C C

C C C C C C C C C C C

C C C O

Default facility code 0

Default number 0 ☒ Increment automatically

✓ OK

✖ Cancel

Enabled: enables usage of this card format in the system.

Name: the name of this card format.

Bits: the number of bits this card format uses.

Number: marks the bits of the card number part.

Facility code: marks the bits of the facility code part.

Even parity CRC bit: the result of all even parity bits (used for error detection).

Even parity bit: bits belonging to even parity check-sum calculation.


Odd parity CRC bit: the result of all odd parity bits (used for error detection).

Odd parity bit: bits belonging to odd parity check-sum calculation.

Default facility code: the facility code number which will be filled in automatically when adding a card with this card format.

Default number: the card number with will be filled in automatically when adding a card with this card format.

Increment automatically: if this is checked, then the "Default number" field will be increased to the next unused card number of the same format.



Holidays tab

Holiday details

Name

Holiday starts on May, 2008

	Sun	Mon	Tue	Wed	Thu	Fri	Sat
18	27	28	29	30	1	2	3
19	4	5	6	7	8	9	10
20	11	12	13	14	15	16	17
21	18	19	20	21	22	23	24
22	25	26	27	28	29	30	31
23	1	2	3	4	5	6	7

Holiday ends on May, 2008

	Sun	Mon	Tue	Wed	Thu	Fri	Sat
18	27	28	29	30	1	2	3
19	4	5	6	7	8	9	10
20	11	12	13	14	15	16	17
21	18	19	20	21	22	23	24
22	25	26	27	28	29	30	31
23	1	2	3	4	5	6	7

Holiday type

☒ Repeat each year

Name: the name of the holiday.


Holiday starts on: start date of the holiday interval.

Holiday ends on: end date of the holiday interval. Select the same date as in 'Holiday starts on' field to make it a single-day interval.

Holiday type: Use 'National holidays' type for holidays defined for your country. Use 'Other holidays' type for any non country-wide holidays (e.g. holidays celebrated only in your company).

Repeat each year: mark this if this holiday should be repeated at the same date next year. SimpleID will automatically recalculate its date once the holiday ends.

If there are holidays configured in your system, they will override normal time schedule operation and will use day-schedules of "National holidays" or "Other holidays" for any weekday while the holiday is active.




Monitoring tab

Monitoring tab overview

Monitoring tab consists of 2 sections: map panel on the left side and events/maps/doors list panel on the right side.

Map panel



All doors

Events/maps/doors/inputs panel

EventsMapsDoorsInputs

Search

Select all Total 4 Selected 1

B3 All doors

B1 First floor

Ground floor

F1 Second floor

Map background

Map name All doors


Map icon B3


☒ Show in the quick navigation bar


OK

Cancel

Quick navigation bar: in here you can switch through maps quickly, turn edit mode for a map on/off, revert changes and also zoom in/out the map.

  **Edit map/Save button:** turns on edit mode or saves a map if already in edit mode.

 **Zoom to fit:** press this button to zoom the map so its height/width fits the window.

 **Revert changes:** press this button to discard the changes made to this map.

Maps canvas: maps, events and doors are drawn in here; also you edit maps in this area.

List panels: Here you can switch between "Events", "Maps", "Doors" and "Inputs" list panels.

Events list	
Search: enter text in here to filter the list by these keywords.	
Apply filter: select a predefined filter by which all events would be sifted out.	
New filter: press this button to create a new event filter (see "Filter window").	
Edit filter: press this button to edit the selected filter.	
Acknowledgment settings: opens the acknowledgment settings window.	
Display events of: limit the number of events to be displayed either by date/time or by amount.	
Events list: the events are shown in here.	

Acknowledgment settings window
Event acknowledgment filter: events which qualify for this filter will be automatically acknowledged.
New filter: press this button to create a new event filter (see "Filter window").
Edit filter: press this button to edit the selected filter.

Maps list

Search filter: filter the list by entered keywords.

New map: press this button create a new map.

Delete map: press this button to delete the selected map.

Select all: toggle this check-box to select all, select none or restore previous selection of list items.


Maps list: all of the configured maps are shown in this list.

Map background: this is the image you will be seeing. The doors and events will be drawn on this image in the “**Maps canvas**”. To add a new image click the button beside the image.


Map name: the events are shown in here.

Map icon: the icon is shown in the quick navigation bar and also in the maps list. Press the “+” sign to add a new icon from file.

Show in the quick navigation bar: when this is checked the map will be shown in the quick navigation bar for fast access of this map.




Inputs list



Search filter: filter the list by entered keywords.

Select all: toggle this check-box to select all, select none or restore previous selection of list items.


Doors list



Search filter: filter the list by entered keywords.

Select all: toggle this check-box to select all, select none or restore previous selection of list items.

Doors list: all of the configured doors are shown in this list. You can drag a door from this list onto a map in the "**Maps canvas**" when the map is in editing mode.



Reports tab

There are 7 different types of reports that may be generated by the software: Events, occupancy, users, devices, access levels, time & attendance and door access. Each of these report types have the same options groups for report customization.

Option groups of reports tab

Event report

Occupancy report

User report

Device report

Access level report

Time & attendance

Door access report

Header **Event report**

Subtitle **New event report**

☒ Page numbering

☒ Report date and time

☒ Show report header on each page

☒ eco-Friendly

Limit **50000**

Time interval **Today** From **00:00:00** To **23:59:59**

October, 2010

October, 2010

Available fields

Report fields

Filter

Event type

Event reason

Doors

Users

Access levels

Schedules

Holidays

Search

Select all Total 39 Selected 0

Access denied

Access granted

Access granted under duress

AC power failure

AC power restored

Battery failure

Battery working properly

Clear forced alarm

Controller menu

Controller locked

Controller offline

Controller online

Controller powered up

Controller unlocked

Door closed

Door forced open

Door forced open cleared

Turn off filters

Generate report

Report options group: here you can setup the look of the report: enter header, subtitle, specify if pages should be numbered or if the date and time should be printed and also you can select a limit for the number of events.

Report interval group: here you must select the first and the last dates, which will define a time interval to be used to generate the report.

Report fields group: in here you can include to or exclude fields from the reports. You can also change the sequence of the fields in the report. To include a field in the report select it in "Available fields" list and press a button with a single arrow pointing right. Buttons with double arrows include/exclude all fields.

Report filters group: here you can select which data filters should be applied for the report. Filters are grouped by type. Different report types can have more or less filter types available.

Report items: here you can select individual items which should be included in the report. All other items will be excluded from this report.