WeldEye® User guide. Page 1 of 74



1.	Genera	1	2
	1.1 S	ystem requirements	2
		ogin to WeldEye	
		efinitions	
	1.3.1	Left side menu	
	1.3.2	Top menu	
	1.4 Gener	ral use (Tip)	
2.		Administration	
	•	e users	
		the users needed access	
3	Admin	istration	21
	3.1	Change password	21
	3.2	Pop-up tables manager	
	3.3	Preferences	
4.	Welding	Procedures	27
		e new documents	
	4.1.1	Open a new document	
	4.1.2 E	xplanation of the buttons	29
	4.1.3	Explanation of the fields	29
	4.1.4	Copying of lines	34
	4.1.5	Save a procedure	35
	4.1.6	Sketches	36
	4.1.7	Lock a procedure	43
	4.1.8	Revise a procedure	44
	4.1.9	Search for procedures	45
	4.1.10	Print out of Welding Procedures	52
	4.1.11	Additional pages	58
5.	Tools		61
	5.1 SI	ketch library	62
	5.1.1	Open the sketch library	62
	5.1.2	Search for sketches	62
	5.1.3	Example 1	63
	5.1.4	Add sketches to the sketch library	65
	5.1.5	Example 2	65
	5.2 Pı	int tool	68
	5.2.1	Open the print tool directly	
	5.2.2	Print documents marked in a list	
	5.2.3	Print out of a Weld Summary List	
	5.2.4	Print out of a project	72
	525	Download	72



General

Introduction

This part of the manual describes system requirements to run WeldEye® and how to log on to the system. We also describes WeldEye® definitions and useful tip for you when using WeldEye®.

1.1 System requirements

Software:

- MS Windows
- Internet Explorer ver. 5.5 or higher
- Adobe Acrobat Reader

Hardware:

- Computer: Any computer supported by W98/2000/XP/Linux/ASP, with a

processor that is 300 MHz or higher.

- Memory: Min 128 MB (RAM)

- Free hard

disc space: Min. 10 MB.

- Line: Min double ISDN 128 k

- Monitor

colour depth: 256 colours (Millions of colours recommended)

- Mouse: Three buttons mouse with a scrolling function.



Login to WeldEye 1.2




Launch Internet Explorer Browser.lnk

icon on

Open Internet Explorer by clicking the your desktop or start menu. Click on Favorites

Start WeldEye



Insert the following in the field to the right of:

- To be given by Weldindustry AS Company:
- Signature: To be given by Weldindustry AS or System Administrator.
- Password: To be given by Weldindustry AS or System Administrator.



The following will appear on your screen:




You are now logged on to WeldEye Quality System as a System Administrator. System Administrator is usually the only person allowed to create users and give the users needed access to WeldEye. The marked field (1) in the picture tells you whom you are logged in as.

NB!! Normally, there is one person in your company that will be the System Administrator. This person got the authority to add users to WeldEye and give these users the needed rights for using WeldEye. How to add users and give users access to different parts of WeldEye is described in chapter 2.



1.3 Definitions



The figure above shows the WeldEye main menus and buttons.

1.3.1 <u>Left side menu</u>

The left side menu shows the main parts of WeldEye. The buttons in the left side menu which have icons with a "+", means that something more will be visible if you click on the button. You may be used to double-click to activate when using other applications. In WeldEye, you only click once to activate.

The parts visible on the left side menu depend on what kind of access you got in WeldEye. If you for example have no access to the *Project Administration*, this part will not be visible for you when you log on to WeldEye.

How the different parts of WeldEye are functioning is described in the chapters 2 to 10.




1.3.2 Top menu

The top menu shows one drop-down menu. The rest is buttons.

Drop-down menu:

If you click (Not double-click) at the down-arrow on the right side of the drop-down menu, you will see all the projects that are active. You can switch between these projects by click on the wanted project. See picture below



Buttons:

In the top menu there are two kinds of buttons. All buttons are links to a special function. In WeldEye, there are two kinds of buttons:

- 1. Link: You need to click on the link to perform an action.
- 2. Hot-link: A drop-down menu appears when your cursor touches the button.




Explanation to the buttons:


Name of button	Type of button	Explanation
Logout	Link	When you click on logout, you will log out of
8		WeldEye. You will then see a window showing the
		text "Thank you for running WeldEye". If you click on
		this text, you will come back to the WeldEye login
		window. This function is also available from the left
		side menu.
Language	Hot-link	To be used when you want to change language.
		Applicable languages today are English and
		Norwegian.
		When your cursor touches this button, the applicable
		languages will appear as a drop-down menu. Click on
		the preferred language. NB! You are required to click
		on the refresh button after changing language to switch
		to the chosen language. The refresh button is shown on
		the picture below.
About	Link	When you click on this button, information about
		current version number of WeldEye will appear.
		This function is also available from the left side menu.
Help	Hot-link	When your cursor touches this button a drop-down
		menu will appear. At this time the help function is
		limited. To be implemented later.
		This function is also available from the left side menu.
New	Hot-link	Can be used to create new documents. (Test reports,
		WPAR, WPS, WI, welder certificates, etc.)
		When your cursor touches this button a drop-down will
		appear. See picture below. Some of the fields in the
		drop-down menu show an arrow on the right. (a in the
		picture below) This arrow means that a sub-menu will
		open when your cursor touches this field. In the
		picture below, you can see the sub-menu of Welding
		Procedures is open. If you had clicked in the field for WPAR, a new WPAR would open. You also have the
		same function in the left side menu.
Open	Hot-link	Can be used when you want to open a Weld Summary
Орен	110t-IIIK	List or an Inspection Plan List.
		When your cursor touches this button, a drop-down
		menu appears. You will now have the choice to open
		the Weld Summary List (WSL) or the Inspection Plan
		List (IPL). If you click on Weld Summary List, the
		WSL for the current project will open. You are now
		able to search for WSL by drawing no, section, serial
		no, etc.
		Please notify that the WSL or IPL for the project
		showed in the project field will be opened. This field is
		shown as b in the picture below. If you want to see a
		WSL for another project, This is one way to do it:
		1. Click on the down-arrow to the left in the

Page 8 of 74

r	1	Page 8 of 74
Name of button	Type of button	Explanation
		project field
		2. Choose the wanted project
		3. Move your cursor to the <i>Open</i> button.
		4. Click on Weld Summary List.
		You can now load WSL from the chosen project.
Print	Hot-link	Can be used when you want to print or e-mail
		documents.
		When your cursor touches this button, a drop-down
		menu appears. This button gives you three
		opportunities.
		1. You can print the current document you are
		working on in WeldEye
		2. You can print documents you have marked in a
		list
		3. You can open the <i>Print Tool</i> to choose which
		documents to be printed. This option is
		normally used for printing final documentation
		for a project.
		Further explanations are given in chapter 8.
		This function is also available from the left side menu.
Find	Hot-link	Can be used when you want to search for documents.
		When your cursor touches this button a drop-down
		menu appears. If you click on the field Qualifications,
		the search window "Search for certificates" will show.
		You are now able to search for certificates. This
		function is also available from the left side menu.







The picture above shows a section of a new Welding Procedure Specification (WPS). This is what in WeldEye is called a document. A document can consist of:

- 1. Fields. This is where you can fill in information.
- 2. Fields with a drop-down menu. These fields have a mark to the right to show that this field is a drop-down field. The content in a field's drop-down menu is set in the *Popup Tables Manager*. How to administrate the content of the drop-down menus is described in chapter 3.
- 3. Button with hyperlink.
- 4. Term with hyperlink.
- 5. Term without hyperlink.




1.4 General use (Tip)

WeldEye® is build on new and modern technology. There are some general tips, which can make the use of WeldEye easier, and more time efficient.


Function key F11:

When you are logged on to WeldEye, you can press the F11 key on your keyboard. The result is a "bigger" screen. See the pictures below.





You can also get a "bigger" screen if you click on the arrow placed on the top, to the right in the left side menu. (Marked with an a on the pictures below) The left side menu will then disappear. If you click on the arrow again, the left side menu will appear.




Use of tabulator key and arrow keys


To move between fields in WeldEye documents, you can either use your mouse or your keyboard.

Use of your keyboard:

- <u>Tabulator key</u> is used to move between fields. When pressing the tabulator key you will move to the next field in the document.
- To move backwards, you can hold in the <u>Shift key</u>, and then press the <u>Tabulator-key</u>. You will then move back one field in the document.
- <u>Arrow keys</u> are used to move up and down in the drop-down menus.
- When using the keyboard to make documents, the drop-down menus will open when you come to a drop-down field. You then use the arrow keys to navigate in the drop-down menu. When the wanted text in the drop-down menu is highlighted (blue), hit the Tabulator key. You have now chosen the text and moved to the next field. (See picture below)







PS!! Always remember to save changes before leaving a document or other places information/data is inserted.




2. System Administration

2.1 Create users

Click on **System Administration** in the menu on your left. 2 boxes will show up as subtitles. (User manager and Access manager.)

Click on user manager. The following picture will be shown:



You are now able to create users.

Explanation to the fields:

Name: Insert the name of the user you want to create.

Company: This field is locked. The name of your company will be shown.

Default project: Insert the project you want as default for the user. This project will be active when the user starts WeldEye. If several projects are registered in WeldEye, you can choose a project from the pull-down menu.

Signature: Insert the signature of the user you want to create. This signature will be shown in the documents the user signs in WeldEye.

Password: Insert the users password in this field. A correct combination of a user's Company, Signature and Password are required to log on to WeldEye.



Active:

If System Administrator wants the user to be active, let the tag stay visible. (Active is default) If not, click in the field, and then the user is inactive. When a user is set to inactive, the user got no access to WeldEye at all. This is the method used in WeldEye instead of deleting users.

The main reason for no possibility to deleting users is that your company will need to keep the documents a certain user has signed. The documents will still be visible in a signed condition even if a user is made inactive.

There may be different reasons why a company will make a user inactive; The user got another position in the company, the user have left the company etc.

Full project access:

If the user shall have access to all active projects in WeldEye, check (mark) the check box when creating the user. If for example a client shall have read access in WeldEye, you may not want him to read information in all your projects in WeldEye. When you create your client as a WeldEye user, mark this check box and he will not see any other information than for the project you set him up to. To define users in project is described in chapter 9.

System access: If tagged, user got system access. This means that the user got the right to create users and give the created users access to WeldEye. If not tagged, user got no system access. (No system access is default)

NB!! Usually, there is one person in your company that got system access (System Administrator). This person got the authority to add users to the system, and give these users the needed rights for using WeldEye.

When you have finished create/edit a user, you are required to save to keep the changes. You save by clicking on the save button.



2.2 Give the users needed access

Introduction

Access to WeldEye can be given related to what function the user has in the organisation. Normally the Welding Engineer needs access to bigger parts of WeldEye than for example a person reporting NDE in production. WeldEye shall also secure that settings and documents in WeldEye cannot be made, edited, signed, deleted or red by unwanted personnel. Therefore WeldEye got an access manager used to set wanted/limited access at different levels for the personnel using WeldEye.

Usually there is one person in the organisation who is responsible for creating users, and give these users the access needed for them to perform their daily tasks. WeldEye call this person for a **System Administrator**.

The System Administrator got what in WeldEye is called a System Access.

This means that when purchasing WeldEye, the System Administrator with a System Access, is already set. The System Administrator needs to create new users and give these users access to WeldEye.

Give users needed access to WeldEye:

To open the Access Manager, please do the following:

- 1. Click on the System Administration button in left side menu (If not already open)
- 2. Click on the *Access Manager* button. The following picture will appear on your screen:



Click on the arrow to the right for Choose user. The drop-down menu will now show the created users.





Choose the wanted user. The following picture will appear on your screen:



The main topics of WeldEye are shown: *DOCUMENT REGISTER*, *INSPECTION PLANS*, *INSPECTION REPORTS*, etc.

As you can see, all of the topics got a + sign on their left. If you click on the + sign, a submenu will appear. This is where you set the wanted access for a user. *None* is the default access for a new created user.



Reset	Save	Back	Access M				•		
Reset	Save	Dack	DEMO US	FR (Г	ni i y				
			DEI110 05		,0)	ACC	ESS		
		MODULE	NAME	None	Read	Write	Sign	Delete	
DUCIIN	IENT RE	GISTER		('-')	('r')	('₩')	('s')	('d')	(s)
	nce Item			•	0	0		-	-
INSPE	CTION F	LANS							
Inspect	tion Plan	List		•	0	0			-
Master	Inspecti	on Plan			0	0	0	-	-
INSPE	CTION F	REPORTS							
Inspect	tion Rep	ort for Ma	agnetic Testing (MT)	•	0	0	0	-	-
Inspect	tion Rep	ort for Pe	netrant Testing (PT)	•	0	0	0	-	-
			rasonic Testing (UT)	•	0	0	0	-	-
			diographic Testing (RT)		0	0	0	_	-
			sual Testing (VT)	•	0	0	0	_	_
		al Identifi			0	0	0		
			IFICATIONS				~		
	nel Data	-	IFICATIONS	•	0	0		_	
Certific					0	0			
	ation To	al.			0	0			
		AGEMEN	T.			-			
	ummary		N I	•	0	0			
		on: Engir	ooring		0	0			
					0	0			
		on: Produ					-	-	-
Weld Ir	ntormati	on: Quali	ty Inspection	•	0	0	-	-	let.
Weld R	epair Re	port		•	0	0	0	-	's':
Requisi	tion: Mu	ltiple NDI		•	0	0			-
		Graphica		•	0			-	-
			Testing, and Repair	•	0				
		CEDURE							
			s cedure Specification	•	0	0	0	0	
			al Record		0	0	0	0	
					0	0	0	0	
		lure Spec	ancadon						-
	roductio			•	0	0	0	0	-
	g Instru			•	О	0	0	0	-
			S - TEST DOCUMENTS						
			Destructive Examination		0	0	0	-	-
			ructive Examination	•	0	0	0	-	-
Test D	ocument	for Hard	ness and Macro	•	0	0	0	-	-
			osin, Ferrite and Micro	•	0	0	0	-	-
			S - OTHER DOCUMENT						
	rocedur			•	0	0	-	-	-
Weld P	rocedur	e Addition	nal Page	•	0	0	-	-	-
TOOLS									
	ool (Bato			•	О	-	-	-	-
- ADMIN						,=			
		Manager		•	О	0	-	-	
		INISTRA	TION						
	: adminis			•	0	0	-	-	-
	: Manage			•	0	0	-	-	-
		NISTRA	TION						
System	n Log			•	0	0	-	-	-
	cal Repo			•	0				



Explanation to the different access levels:

- *None:* The user has no access to this part of WeldEye.
- *Read:* The user has the access to read the information in this part of WeldEye.
- Write: The user has access to write in to this part of WeldEye.
- Sign: The user has access to sign document(s) in this part of WeldEye.
- Delete: The user has access to delete documents in this part of WeldEye.
- Special:



Example:

Access M	umu	yeı				
Reset Save Back Choose user				-		
DEMO USI	ER (D	U)				
MODULE NAME	None	Read	ACC Write	ESS Sign	Delete	Specie
	('-')	('r')	('w')	('s')	(,q,)	(s)
DOCUMENT REGISTER	_					
Reference Item	•	0	0	-	-	-
INSPECTION PLANS						
Inspection Plan List	0	0	0	-	-	-
Master Inspection Plan	•	0	0	0	-	-
INSPECTION REPORTS						
Inspection Report for Magnetic Testing (MT)	0	0	0	•	-	-
Inspection Report for Penetrant Testing (PT)	0	0	C	•	-	-
Inspection Report for Ultrasonic Testing (UT)	0	•	0	0	-	-
Inspection Report for Radiographic Testing (RT)	0	0	C	•	-	-
Inspection Report for Visual Testing (VT)	0	0	C	•	-	-
Positive Material Identification	0	•	0	0	-	-
PERSONNEL AND QUALIFICATIONS						
Personnel Data	•	0	0	-	-	-
Certificates	•	0	0	-	-	-
Prolongation Tool	•	0	О	-	-	-
WELDING MANAGEMENT						
Weld Summary List	0	•	О	-	-	-
Weld Information: Engineering	0	•	О	-	-	-
Weld Information: Production	0	•	О		_	-
Weld Information: Quality Inspection	0	0	•			_
				_		'S':
Weld Repair Report	0	•	0	0	-	0
Requisition: Multiple NDE	0	0	•	-	-	-
Status Report: Graphical	•	0	-	-	-	-
Status Report: Welding, Testing, and Repair	•	0		-	-	-
WELDING PROCEDURES						
Preliminary Welding Procedure Specification	•	0	О	0	0	-
Weld Procedure Approval Record		0	0	0	0	_
Welding Procedure Specification		0	0	0	0	
Weld Production Test		0	0	0	0	
		0	0	0	0	-
Welding Instruction	٠	0	U	U	O	-
WELDING PROCEDURES - TEST DOCUMENTS Test Document for Non-Destructive Examination	•	_	_	_		
		0	0	0	-	-
Test Document for Destructive Examination	0	0	0	0	-	-
Test Document for Hardness and Macro	•	0	0	0	-	-
Test Document for Corrosin, Ferrite and Micro	•	0	0	0	-	-
WELDING PROCEDURES - OTHER DOCUMENTS						
Weld Procedure Layer	•	0	0	-	-	-
Weld Procedure Additional Page	•	0	0	-	-	
TOOLS						
Print Tool (Batch Print)	0	•	-	-	-	
ADMINISTRATION						
Pop-up Tables Manager	•	0	С	-	-	-
PROJECT ADMINISTRATION						
Project administration	œ	0	0	-	-	-
Project Manager	•	0	0	-	-	-
SYSTEM ADMINISTRATION						
System Log	•	0	0	-	-	

Page 20 of 74

System Administrator has set access to Demo User as shown above. The access can for example apply for an NDE operator.

When this user logs on to WeldEye, the user will see the following picture on the screen:



Please note that buttons in the left side menu disappears.

This user got access to:

- Sign Inspection Reports MT, PT, RT and VT.
- Read Inspection Reports UT and PMI
- Read information in Weld Summary Lists (WSL).
- Read information in Weld View (WV) Engineering and Production.
- Sign in WV Quality Inspection.
- Read Weld Repair Reports.
- Write NDE requisitions
- Access to the Print Tool.

Conclusion: The left menu will have an increased or decreased number of visible buttons depending on given access.



3 Administration

Introduction


In this part of WeldEye you will be able to:

- Change your password
- Edit pop-up tables
- Adjust your preferences

3.1 Change password

Click on the Administration button on the left side menu.

Click on the *Change password* button. The following will appear on your screen:



You are now able to change your password.

- Insert your old password.
- Press the tabulator key on your keyboard to move to the next field, which is *New password*.
- Insert your new password.
- Press the tabulator key on your keyboard to move to the next field, which is *Retype New password*.
- Insert new password one more time to confirm new password.
- Click on the *Save* button to save new password.

You have now changed your password.



3.2 Pop-up tables manager

Introduction

In this part of WeldEye you can administrate the content in the pop-up menus you will find in several documents available in WeldEye.

The purpose with the pop-up tables manager is to make it possible for your Company to standardize the content in the different documents in WeldEye. When you have added your information in the Pop-up Tables Manager, it will be much quicker for the users to make required documents.

Many fields in the different documents in WeldEye are made as pop-up fields. This means that you can add information into the Pop-up Tables Manager. The added information will then be available in the documents this pop-up is related to. If some pop-up fields are blank in a document, for example in a WPS, the reason is that you haven't added anything in the pop-up tables manager up front. More detailed explanations will be given later in this chapter.


Pop-up menus are available in different fields in several documents in WeldEye, pWPS, WPAR, WPS, WI, WPT, NDE reports, Weld Summary Lists, welders certificates etc.

How to open the Pop-up tables Manager: Click on the following on the left side menu:

- Administration
- Pop-up Tables Manager (Access is required. If the button Pop-up Tables Manager is not visible, you have no access to edit pop-up tables)



This will appear on your screen:




The pop-up Administrator is available, and you can now start editing the different pop-ups.

Click on the down-arrow to the right of Choose pop-up.
 The drop-down menu is open, and you will see all of the pop-ups available. If you click on "General: Filler Material Classes, the following will appear on your screen:



Page 24 of 74



3.3 Preferences

Preferences can be used to:

- Choose the project you want WeldEye to open when you log on to WeldEye.
- Choose what kind of date format to be shown when using WeldEye.
- Choose if WeldEye shall be in English or Norwegian.
- Choose which e-mail address you want as default in the print tool.

How to open the *Preferences*:

Click on the following on the left side menu:


- Administration
- Preferences

The following picture will appear on your screen:



Page 25 of 74





Explanation to the fields:

- Default project: This field contains a drop-down menu.

You can click on the down- arrow to the right of the field, and the content in the drop-down will be visible. (Depends on what projects is set in the *Project* manager)

From the drop-down menu you can choose one of the projects available.

You choose a project by clicking on it.

When you log in to WeldEye, the chosen project will be the active one.



Page 26 of 74



- Date format: This field contains a drop-down menu.

You can click on the down- arrow to the right of the field, and

the content in the drop-down will be visible.

You can choose between American date format and different

European date formats.

From the drop-down menu you can choose preferred date

format.

You choose a date format by clicking on it.

When you log in to WeldEye, the chosen date format will be

used in all documents in WeldEye.

- Language: This field contains a drop-down menu.

You can click on the down- arrow to the right of the field, and

the content in the drop-down will be visible.

You can choose between English and Norwegian languages.. From the drop-down menu you can choose preferred language.

You choose language by clicking on it.

When you log in to WeldEye, the chosen language will be used. *Note: You can also switch between languages by clicking the language button* (1), and then click on refresh (2 on the picture

above)

- E-mail address: This is where you set the wanted designation for printing of

documents. Inserted e-mail address will automatically show up

in the print tool.



4. Welding Procedures

Introduction

In this part of the user guide, it will be described how to:

- Create new documents
- Revise existing documents
- Use the sketch library
- Use the drawing tool
- Search for existing documents

Currently supported document layouts are:

- o EN 288 pWPS
- o EN 288 WPAR
- o EN 288 WPS
- o EN 288 WPT
- o EN 288 WI
- o ASME PQR
- o ASME WPS

4.1 Create new documents

4.1.1 Open a new document

To open a new document, you have two options:

- 1. From the left side menu
- 2. From the top menu
- 1. From the left side menu
 - a. Click on the Welding Procedure button.
 - b. Click on New
 - c. Click on the wanted document layout. In this case pWPS.

2. From the top menu

- a. Move your cursor to the New button. A sub menu will appear.
- b. Move your cursor to Welding Procedure. A sub menu will appear.
- c. Click on the wanted document layout. In this case pWPS.



WeldEye® User guide.

Page 28 of 74

An empty document (pWPS) will appear on your screen: Welding Procedure Reset Save Back Active: V 2 PRELIMINARY WELDING PROCEDURE SPECIFICATION (PWPS) 3 1 Client Ref. stand: rod, by H Welding process Shielding gas type Weaving (yes/no) Purging gas type Joint type loint prep Single/Double Back gouging Flux designation Flux handling Tungsten electrode 5 CE max: Identification of filler metal Welding Parameters Pass no. Index Dia [mm] |--| DD DD 00 0 7 6 Preheat min: "C Interpass temp. max: C Heat treatment proc.:

PWHT min: C max.: C Soaking: min/mm Heating rate: ₹ Temp. control: min/mm Heating rate: Reset Save Back



As shown above, only three buttons are visible in the top. (1). When saving the document, more buttons will appear. Note that the field Prod. by (2) is mandatory (must be filled in) before you are able to save.

In the document there are fields with and without drop-down menus. If a field not contains drop-down menu, no icon is showed to the right of the field. (2)

If the field contains a drop-down menu, an icon is shown to the right of these fields. (4)

There are also Go buttons in the document. The Go button is shown to the right of the field. (3). If a document number is referred to in a field, the document will open in a new window directly. The referred document must of course exist in WeldEye.

The documents includes an area for sketches (5)

4.1.2 Explanation of the buttons

Reset	Click here to remove the text inserted after last time you saved.
-------	---

Save	Click her to save the document	

Back	Click here to go to the previous page.
------	--

The document is set to *active*. Remove the tag by click on it. The document is then *inactive*. Instead of deleting the document, you can set it to inactive. The document is still in the database and it's possible to search for inactive documents.

4.1.3 Explanation of the fields

Active: 🔽

The fields in the different documents are very much the same. The following describes the terms in a general manner.

IIIDC	T 4 41 1 4	1 .	.1 *	C* 11
pWPS no	Insert the documents no	ımber ii	n tnis	пеіа.

Ref. If you need to insert any reference in the document, insert it here.

Date This field is not for editing. The date will automatically show when

you save the document. Requires that you have inserted a date in the

date field (6), and your signature in the signature field (7).

Rev. Insert the document revision number in this field.



WeldEye® User guide.

Page 30 of 74

Prod. by Enter who made this document. What you type in to this field is

optional. Usually your Company name or the name of the person who

make the document is entered.

Client Insert the name of the Client. If the document is to be made in a more

general manner, you can for example assign it as a general document or

an internal document.

Ref. standard Insert a reference to a standard. The procedure must fulfill the

requirements in the stated standard. Examples of standards to be filled

in can be:

EN 288-3, ASME IX, NORSOK M-601 etc.

Project Insert the name of the Project this procedure shall be used on. If the

document is to be made in a more general manner, you can for example

assign it as a general document or an internal document.

Ref. spec. Possibility to insert a reference to a specification. Many clients have

additional welding requirements in a project specific specification. Several companys have their own internal specifications. If so, you can insert a reference to the specification(s) in this field. The field can also

remain empty.

Exam. body If the procedure is approved by, or tested by a third party, you can enter

the name of the examination body in this field.

Location Insert your Company location. Usually the name and / or the location

of the company who welds the qualification test is inserted in this field.

Ref. WP If you want to refer to another welding procedure, insert the WP name

in this field. You can refer to four different documents. The fields have Go buttons (3) to the right, which means that the referred document will open directly in a new window when you click on the Go button. The referred document must of course exist in WeldEye.

Welding Process Insert the name of the welding process. Three processes for

each procedure are supplied.

Shielding gas type Insert the name of the shielding gas for each welding process.

Weaving (yes/no) State yes or no. If yes, state the width of the weaving.

Purging gas type State the name of the purging gas, if any.

Welding positions State the welding position(s) to be used for a qualification or to

be used in production.

Joint type State what type(s) of joint the welding procedure applies for.



Joint preparation Describe how to do the joint preparation.

Cleaning method Describe how to clean the joint before welding

Backing Describe if backing shall be / are used. If used, enter the type.

Single/Double State if the procedure applies for single sided welding, double

sided welding, or both.

Back gouging Describe how to do the back gouging, if any.

Flux designation State the flux designation, if used.

Flux handling Describe how to handle the flux. You can also refer to a

procedure for handling of filler/consumables in this field.

Tungsten electrode Describe what Tungsten type and size used or shall be used.

Torch angle State the torch angle used or shall be used. (Different torch

angles depending on welding processes.)

Stand off distance State the stand off distance

Nozzle diameter State the nozzle diameter here. Internal nozzle diameter is the

most correct diameter to enter.

Tack welding proc. If a procedure for the tack welding is or shall be used, enter the

name of the procedure here.

Identification of parent metal

C max: Max permitted carbon content in the parent material to be welded.

CE max: Maximum permitted carbon equivalent of parent metal to be welded on.

Value is based on actual CE at parent metal used for qualification of welding procedure and permitted variable given in standard the welding

has to take place in accordance with.

PCM max: Maximum permitted PCM of parent metal to be welded. Value is based

on actual PCM content at parent metal used for qualification of welding procedure and permitted variable given in standard the welding has to

take place in accordance with.

Part I and Part II are references to the two parent metals to be welded

together. Can also be referred to on the sketch. Information about the

two parts are given in the fields: Name/grade, Standard, Group,

Delivery cond., thickness (range) and diameter (range).



WeldEye® User guide.

Page 32 of 74

Name/grade Identify trade name of parent metal to be joined. (For Part I and Part II.

Standard Identify the standard that parent metal has been produced in accordance

with.

Group Identify what material group the material belong to. The material

group can be in accordance with EN 288 standard when using EN 288 document layout. When using ASME IX layouts, use the ASME IX $\,$

material group numbers. (P-no or S-no)

Note! If pop-up table manager "General: Materials" is filled in properly, it's only required to choose the name/grade from the drop-down menu. The fields Standard, Group and Delivery condition will be filled in automatically.

Delivery cond. Identify what delivery condition to the parent material welded.

Examples of delivery conditions: Normalized, Quenched and tempered,

Solution annealed etc.

Thickness

Range Insert the thickness range for this procedure. If a WPAR, insert the

thickness of the parent metal used for the qualification.

Diameter

Range Insert the diameter range for this procedure. If a WPAR and a tube,

insert the diameter of the tube used for the qualification. According to

EN 288, the outside diameter shall be stated.

Identification of filler metal

Index A number you are required to refer to in the area for welding

parameters. Index 1,2 or 3. This means that three different fillers can

be reported.

Trade name Insert the name of the filler name. The trade name is usually the name

given in the filler catalogue. Elgacore DWA 55 LSR and ESAB OK

48.08 are examples of fillers trade name.

Classification The fillers classification shall be entered in this field. The

classification is usually found in the filler catalogue.

Group

Filler

handling Enter how the filler belonging to actual index shall be handled. You

can also refer to a procedure or a specification for filler handling.

Note! If pop-up table manager "General: Filler Materials" and "General Filler Material (Wires) is filled in properly, it's only required to choose the trade name



from the drop-down menu. The fields Classification, Group and Filler handling will be filled in automatically.

Welding parameters

Equipment Insert type of equipment used or shall be used

Pass no Insert the pass number for the welding parameters this pass or passes

applies for. 9 lines are supplied.

Insert the index for the filler to be used. Must correspond with the

index given in Identification of filler material.

Dia [mm] Insert the diameter for the actual filler to be used.

Welding

process Insert the actual welding process to be used

Wire feed

speed [mm/min] Insert the wire feed speed if necessary. Applies for automatic or semi

automatic processes.

Current Insert the wanted current for this pass. You can insert a single current

value or a current range.

Voltage Insert the wanted voltage for this pass. You can insert a single value or

a range.

Current/

Polarity Identify what type of current used and the polarity. Examples of

current types are Alternating Current (AC) and Direct Current (DC) Examples of polarity are electrode negative (-) and electrode positive

(+)

Welding speed Insert the welding speed in this field. You can apply a single value or a

range.

Run out length When using the welding process 111 (EN 288) SMAW (ASME IX),

the run-out length can be entered.

Run out length: After welding one covered electrode, measure the

length of the weld metal.

Gas [l/min] Insert the gas flow for the shielding gas.

WeldEye® User guide.



Page 34 of 74

Heat input

The heat input is calculated automatically provided that the Current, Voltage and welding speed is entered. You can also enter the heat input manually by typing it in to the fields. It's also possible to set a factor for each welding process. To be done in the *Pop-up tables* manager, "Welding Procedures: Welding Process"

4.1.4 Copying of lines

It's possible to copy data from one line and paste the data into another line. This can be done by use of the buttons below.

Button for copying a line

Button for paste a copied line

- 1. Go to the line you want to copy from, and click on the button.
- 2. Go to the line you want to paste the data in to, and click on the button.

To delete a line, copy an empty line and paste it in to the line you want to delete.

Heat treatment

Method Insert method used or method to be used for the heat treatment.

(Electrical heating, propane etc.)

Preheat min. Insert the minimum preheat temperature for this procedure.

Interpass

Insert maximum permitted temperature before welding of the next pass temp. max

can start.

Heat treatment

In this field, you can refer to a heat treatment procedure, if any. proc.

Temp.control Identify how to perform the temperature control for the preheat

temperature and/or interpass temperature.

PWHT min. °C Identify the minimum temperature for the Post Weld Heat Treatment

Max. ℃ Identify the minimum temperature for the Post Weld Heat Treatment

Identify the PWHT temperature holding time. Soaking mm/min

Heating rate ℃/h Identify the speed of heating up to holding temperature.

Cooling rate ℃/h Identify the speed of cooling from holding temperature, after

PWHT holding time

Page 35 of 74

Remarks In this field you can enter additional information.

Date/Signature

Button for open the calendar

Button for inserting your signature

4.1.5 Save a procedure

To save a procedure, you need to fill in the field *Produced by*. This field is mandatory, which means that you are required to fill it in before saving. When the *Produced by* field is filled in, you can save the procedure, by click one time on the *Save* button.

When a procedure is saved, more buttons will appear on the top. See picture below.



Explanation to the buttons

Save As pWPS ▼

Gives you the opportunity to save the document as a new document. You can also save the document as an other document layout. For example save a WPAR as a WPS. All data in the WPAR will be saved in a WPS document. This is a kind of copy function. You are required to give the document a unique name. (A dialog box will open when you click on the *Save as* button.) Enter the name of the document and click OK.

Editor

The drawing tool will open when you click on this button.

Sketch

A sub menu will appear when drag the cursor over this button. Paste, Insert, Copy to clipboard and Copy to sketch library are the options. See also Chapter 7.1.6.

Delete

Delete the document. Documents can also be deleted from welding procedures survey. (See Chapter 7.1.9.1) You are able to delete more than one document from the survey. Please note that some documents cannot be deleted. If the document is referred to elsewhere in WeldEye, the document cannot be deleted. The option is then to make the document inactive.





Drop-down menu where you can open the documents related to this procedure. There are different numbers of "pages" depending of what kind of document you work in.

4.1.6 Sketches


To add a sketch to a procedure you have three options:

- 1. Open the editor and draw the sketch.
- 2. Copy a sketch from the sketch library.
- 3. Insert a sketch from an existing procedure.

4.1.6.1 Draw a sketch


To be able to draw a sketch, you need to open the drawing tool.

- Click on the Editor button. The drawing tool will open in a new window. The picture below shows menus in the drawing tool after click on the button for drawing lines





After drawing the sketch, you are required to click on File and Save to URL. See picture below:



The sketch is now saved in the procedure.

To do further editing of the sketch: Click on the editor button, and the drawing tool with the existing drawing opens. Edit the sketch and save to URL.

To save the changes you are always required to click on the **Save** button on the top or in the bottom of the procedure.

4.1.6.2 Copy a sketch from the sketch library

To copy a sketch from the sketch library, please do the following:

- Open the sketch library from the left side menu (Tools, sketch library) or from the top menu (Move your cursor to the will appear. Click on sketch. The sketch library are now open)
- o Search for the wanted sketch. Described in chapter 8.

Example:


We want to copy a sketch showing a butt weld and a V-groove in to the procedure. Please do the following:

- Insert BV% as a search criteria. To be entered into the field for sketch name.
- Click on the search button

All sketches in the sketch library starting with the name BV will be shown. See picture below:




$WeldEye \hbox{$\mathbb{R}$ User guide.}\\$



Click on the Copy button to copy the wanted sketch. In this case BV.





Drag your cursor to the *Sketch* button in the procedure. A sub menu will appear. Click on Paste. (1 in picture above) The sketch is now pasted into the procedure. If you want to edit the sketch, click on the *E*ditor button and the editor opens.


NB!!

You are always required to open the editor, click on File, Save to URL before saving the procedure. (Even if you don't have done any changes to the sketch) This to get the sketch saved in the document.

Also remember File and Save to URL when editing of the sketch is done.

4.1.6.3 Insert a sketch from an existing procedure

It's possible to insert a sketch from an existing procedure in WeldEye. To be able to do so, you need to know the Index number to the procedure you want to copy the sketch from. An Index number is a unique number for a document. WeldEye will create this number automatically when you save the document. This number will show up in the down left corner. See picture below:






To copy a sketch from an existing procedure, please do the following:

- 1. Drag your cursor to the *Sketch* button in the procedure. A sub menu will appear. Click on Insert. (1 in picture below) A dialog box will open.
- 2. In this dialog box, type in the Index number to the procedure you want to copy the sketch from.
- 3. Click on the *OK* button. The sketch is now copied.
- 4. Open the editor.
- 5. Click on the File button. (Upper left corner) and Save to URL.
- 6. Close the editor, and save the procedure by click on the Save button.

NB!!

You are always required to open the editor, click on File, Save to URL before saving the procedure. (Even if you don't have done any changes to the sketch) This to get the sketch saved in the document.

Also remember File and Save to URL when editing of the sketch is done.






4.1.6.4 Copy sketch to clipboard

In WeldEye there is a possibility to copy a sketch to clipboard for then be able to paste it in another document or an additional page. To copy sketch to clipboard, please do the following:


Drag your cursor to the *Sketch* button in the procedure. A sub menu will appear. Drag your cursor to Copy To and click on Clipboard. (1 in picture below).

The sketch in the procedure is now copied to your clipboard.



4.1.6.5 Copy sketch to Sketch Library

In WeldEye there is a possibility to copy a sketch from the procedure and into the sketch library. To copy a sketch from a procedure into the sketch library, please do the following: Drag your cursor to the *Sketch* button in the procedure. A sub menu will appear. Drag your cursor to Copy To and click on Sketch Library. (2 in picture above). A registration box will appear:



In this box you are required to give the sketch a name. Insert the name in the field *Sketch* name:

In addition to the sketch name, you are also able to register the sketch with keywords. This is optional. Sketch name and keywords are possible search criteria's in the Sketch Library.


When the sketch name (and keywords) is entered, click the OK button to copy the sketch from the procedure to Sketch Library.



4.1.6.6 Delete sketch from Sketch Library

In WeldEye there is a possibility to delete sketches from the sketch library. In the following example, the sketch with sketch name Test shall be deleted. To delete a sketch from the sketch library, please do the following:

- 1. Open Sketch Library (*Tools->Sketch Library* from the left side menu.)
- 2. Search for the Sketch to delete. The sketches searched for will open in Sketch Library. In this case all sketches with sketch name starting with Test was searched for:



- 3. Click the *Delete* button under the sketch you want to delete. In this case, Test.
- 4. A warning will appear on your screen.
- 5. Click OK to confirm, or Cancel to abort.




4.1.7 Lock a procedure

After a procedure is filled in properly, WeldEye require a date and a signature to lock the document for editing. When a procedure is signed and saved, only the personnel given access to revise are able to edit the procedure.

To lock a procedure, please do the following:

- 1. Insert the date by typing the date in or choose the date from the calendar.
- 2. Insert your signature by one click on the signature button.



In WeldEye there are two signatures, one signature for the user who made the procedure and one signature for the person who shall approve the procedure.

3. Save the procedure by clicking one time at the *Save* button.



4.1.8 Revise a procedure


After signing and saving a procedure, some buttons on the top will disappear. The procedure is locked for revising/editing. *To revise a procedure you need the required access to do so.* If you have the access, click on the *Revise* button. The document is now open for editing.





After click on the *Revise* button, the procedure is unlocked. As shown above, more buttons have appeared. You are now able to do the revision/editing.

After the revision is finished, you need to insert a date and your signature before saving. If date and signature is not inserted before saving, the procedure will remain unlocked.






4.1.9 Search for procedures

In WeldEye you have the possibility to search for documents in the database. To be able to perform search, you need to open the search picture. To open the search picture you have two options:


- 1. From the left side menu
- 2. From the top menu.
- 1. From the left side menu
 - a. Click on the Welding Procedures button.
 - b. Click on the Search button.
- 2. From the top menu:
 - a. Drag your cursor to the Find button. A sub menu will appear.
 - b. Drag your cursor down to Welding Procedures.
 - c. Click on Welding Procedures.

In both cases, the following will appear on your screen:





This is where you can apply your search criteria's. As shown in the picture above, two tabs are available: Standard and Extended. By click on the Extended tab, more fields for search criteria's appears:





Explanations to the buttons

Search

Click on this button when the search criteria's are entered.

Count

Click on this button to count the number of hits. Some companies got thousands of welding procedures (WPAR/WPS etc.) in the database. A search for all procedures will take a long time. To count the number of hits is done in seconds. Therefore it can be useful to count the number of hits before performing the search. If the number of hits is above approximately 100, it's recommended to enter one or more search criteria's, if possible.

Reset

Blank the search criteria fields.

Explanation to the fields

Index If you know the index number for the procedure you search for, type it

in to this field and click on the Search button. Since this is a search for

a unique procedure, the procedure will open directly.

WP no: Type in the number of the procedure to search for. You can also insert

% to search for more procedures. Example: You want to search for the procedures with names starting with 12. You then enter 12% in this

field.

Project Search for procedures related to a certain project.

WP type State what type of procedure you want to search for. WI, WPAR,

WPS, WPT or pWPS.

Process State which welding process(es) the procedure shall contain.

Preheat State if you want to search for procedures with preheat.

Parent metal State which parent metal(s) the procedures you want to search for

contains.

Thickness State the thickness of the parent metal the procedures you want to

search for contains. The search result will show all procedures

containing the inserted thickness.

Diameter State the diameter the procedures you want to search for contains. The

search result will show all procedures containing the inserted diameter.

Joint type Search for procedures related to a certain joint type.



WeldEye® User guide.

Page 48 of 74

Active

Possibility to search for active, inactive or both active and inactive procedures. Instead of deleting procedures, you have the opportunity to set them inactive. See chapter 7.1.2.

Yes, means that you search for active procedures.

No, means that you search for procedures set as inactive.

Blank, means that you search for both active and inactive procedures.

Order by Gives you the opportunity to decide how the procedures shall be sorted

when showing up in the survey. (Sorted by Index number or procedure

number)

Survey Gives you the opportunity to decide which survey type that shall appear

after search is performed.

Heading: The most common information is shown.

Miscellaneous: A more detailed survey is shown.

Sketches: The sketch for each procedure is shown. In addition to the

sketches, information for each procedure is shown.




Example:

I want to search for:

- WPS's that applies for the welding process 136
- For the parent metal 360 LT.
- I just want to search for active procedures.
- Order/sort the procedure by Index number
- I want the survey to appear as heading.

The search criteria's is to be entered as follows:



After your search criteria's are entered, you execute the search by click on the *Search* button. The survey appear on your screen:



4.1.9.1 Welding Procedure Survey

yperlinks to th actual WPS.	le Heading	Miscella	neous	Sket	ch \					
WELDING PROCEDURES SURVEY: HEADING Sign.: KET										
	WP NO:	INDEX NO.	WP TYPE	THICK	NESS	DIAM	ETER	PROCESS	MATERIAL GROUP	LAYOUT
	111	10500073	WPS	10,0 - 40,0	10,0 - 40,0	85,0 - 99999,0	85,0 - 99999,0	136	2 2	EN288
	WPS-2003-01	10500079	WPS	5,0 - 30,0	5,0 - 30,0	85,0 - 9999,0	85,0 - 9999,0	136	2 2	EN288
	300304	10500151	WPS	25,0 - 45,0	25,0 - 45,0	500,0 - 99999,0	500,0 - 99999,0	136	2 2	EN288
Co	opy Make	inactive	Delete							
									Produced by	y WeldEye

Three WPS's are shown. The Heading survey is opened. By click on the tabs Miscellaneous or Sketch, more information regarding this WPS's will appear.

Under the columns WP NO. and INDEX NO., the text is blue. This means that the WPS no and Index number are hyperlinks. You open the wanted WPS just by a click on the hyperlink.

Explanation to the buttons:



The checked (marked) documents will be copied to the project you currently work in. For example approved procedures for the project. (Not available for WeldEye WP)

Make inactive

Possibility to make more than one document inactive at the same time. Check (mark) the check box(es) to the left of WP NO. you want to make inactive, and click the *Make Inactive* button. If Inactive procedures are searched for, the *Make inactive* button is replaced with *Make active* button. This to have the opportunity to make more than one procedure active at the same time.


4.1.9.2 Deleting of procedures

Delete

Possibility to delete more than one procedure at the same time. Check (mark) the check box(es) to the left of WP NO. you want to delete, and click the *Delete* button. Please note that some documents cannot be deleted. If the document is referred to elsewhere in WeldEye, the document cannot be deleted. The option is then to make the document inactive. You are also able to delete a procedure from the procedure "front page". To delete a procedure that is open, just click the *Delete* button. See 1 below. Confirm the operation by clicking OK in the dialog box. The procedure is then deleted (If the procedure is not referred to elsewhere in WeldEye.)



WeldEye® User guide. Page 51 of 74





4.1.10 Print out of Welding Procedures


It is possible to print a single procedure or several procedures (a batch). The print job is sent to a mail address. This mail address is set in the *User Manager* or in the *Preferences* under the *Administration* button on the left side menu. You can also enter the e-mail address you want by typing it in yourself in the print tool.

4.1.10.1 Printing a single procedure


When a procedure is in the condition you want it, you can print the single procedure. This procedure can be the one you work on now, or it can be a procedure you need to search for.

When the procedure you want to print is opened, please do the following:

- Drag your cursor to the *Print* button on the top menu. A sub menu will appear. (See picture below)



- Click on *Print Document*. The following will appear on your screen:





Print Tool Reset Print Back DOCUMENT MODULE C Inspection Plan List for Project C Inspection Plans ☐ Include Master Inspection Plan C Master Inspection Plan: Index no.: \square Magnetic Testing Penetrant Testing C Inspection Reports Ultrasonic Testing Radiographic Testing ☐ Visual Testing \square Positive Material Identification C Qualifications Index no.: Include: ☐ Inspection Reports ☐ Welding Procedure Specification C Welding Management \square Welder Certificates ☐ Weld Repair Report € Single Welding Procedure: Number: Index no.: 10500171 All fields is C WPs listed in surve predefined due to ▼ Front Page chose of Test Document: NDE printout of • Welding Procedure ☐ Test Document: Destructive a single ☐ Test Document: Hardness & Macro procedure Test Document: Corrosion & Ferrite ☐ Weld Layer Parameters ☐ Additional Page C Welding Procedure Survey Heading Project: WeldEye Demo Section: Drawing: Line: 1. You can Spool: choose the print S. no.: out language. TARGET/JOB INFORMATION null English 🔽 🗲 2. You can choose Document Subheader: the e-mail address to karl.einar.tronrud@weldindustry.com cand the print ich to Message/reference in email: Produced by WeldEye Reset Print Back Click on the Print button

to start the print job




After a click on the *Print* button, the following will appear on your screen.:



If something isn't filled in properly, you will receive an error message. Then you are required to adjust your input in the print tool.

- When you click on the *Print* button, WeldEye converts all the data in the procedure and generate a PDF file.
- The PDF file is then sent to the E-mail address inserted in the print tool.
- Open the file from your mailbox and print it out.

To read a PDF file, you are required to have Acrobat Reader installed on your computer.






Page 55 of 74

4.1.10.2 Printout of several procedures (Batch print)

To print several procedures at the same time, you need to perform a search first. This example is based on the example shown in Chapter 7.1.9.

I want to print/mail:

- WPS's that applies for the welding process 136
- For the parent metal 360 LT.
- I just want to print the active procedures.
- 1. Search for the procedures as described in chapter 7.1.9. The survey will open as shown below.
- 2. Tag of the procedures you want to print/mail.
- 3. Drag your cursor to the Print button. A sub menu will appear.
- 4. Click on Print Documents in List





The following will appear on your screen:

	Print Tool										
	Reset Print Back										
	M	ODULE		DOCUMENT							
	C Inspection Plans			C Inspection Plan List for Project							
			ns	☐ Include Master Inspection Plan							
				C Master Inspection Plan:							
	C Inspection Reports			Index no.:							
				☐ Magnetic Testing							
				☐ Penetrant Testing							
			orts	☐ Ultrasonic Testing							
				☐ Radiographic Testing							
				☐ Visual Testing							
				Positive Material Identification							
	C Qualifications			Index no.:							
	C Welding Management			Include:							
				☐ Inspection Reports							
			jement								
				☐ Welder Certificates							
				Weld Repair Report							
Compared to printout	© Welding Procedure			C Single Welding Procedure: Number: Index no.:							
			/	€ WPs listed in survey							
				Include: ✓ Front Page							
of a single				✓ Front Page ☐ Test Document: NDE							
procedure, this time WPS listed in survey is				☐ Test Document: NDE							
			dure	☐ Test Document: Hardness & Macro							
				☐ Test Document: Corrosion & Ferrite							
				□ Weld Layer Parameters							
				☐ Additional Page							
				C Welding Procedure Survey							
				SOURCE INFORMATION							
	Project:		WeldEy	IEye Demo							
	Section:										
	Drawing:										
	Line:			hid >							
	Spool:			■							
	S. no.:			■							
	TARGET/JOB INFORMATION										
	null			English 🔽							
	Documen	t Subhea	der:								
	Email add										
	Message/reference in em			mail:							
	Produced										
	Reset	Print	Back	k							

Copyright© by Weldindustry AS



When click on the *Print* button, the procedures will be sent to the mail recipient for print out.

The print/mailing can also be performed manually. This is possible via the left side menu or the top menu.

From the left side menu:


- 1. Click on the *Tool* button
- 2. Click on the *Print Tool* button. The print tool will open.
- 3. Make your definitions.
- 4. Click on the *Print* button.

From the top menu:

- 1. Drag your cursor to the Print button. A sub menu will open.
- 2. Click on Print Tool
- 3. Make your definitions.
- 4. Click on the *Print* button

Print/mail of procedure related documents

In general there is also possible to choose what documents you want to print/mail in addition to the procedure front page. If a procedure contains more than a front page, it is possible to mail/print these pages. You are required to tag the document type you want to include in the print/mail. See picture below:



This is an example of a print/mail of a WPAR. The print/mail will include:

- Front page
- NDE test document
- Reports from destructive testing. (Tensile, bend, Charpy-V, CTOD.)
- Reports from hardness and macro examination.
- Additional pages. (Digital images i.e. macro pictures, additional information.) Attached files in additional pages will be available as separate files in the e-mail.



4.1.11 Additional pages

In a procedure you got a Drop down menu called "Choose document to go to". One of the options here is New Additional Page. NB! The document must be saved to make the drop-down menu available.

To navigate between documents in a procedure:

- Click on the arrow to the right of the drop down menu
- Choose the document to go to by click on the text. In this case we want to add a new Additional page:




Click on New Additional Page


The following will appear on your screen:

If you want to insert a digital image or a file:

- 1. Mark as shown below. This mark is default
- Browse for the file you want to insert. In this case a macro photo. The file
 must be available on your computer or network. It's also required to be a GIF
 or JPEG file. (Digital photos). Word, Excel and Adobe files can also be
 attached.
- 3. Click on the Save button. The file will then be inserted.







The chosen digital image is inserted in the additional page in the procedure

The field marked 4 on the picture on the previous page can be marked if you want some additional text or explanations to the procedure.

The field marked 5 on the picture on the previous page can be marked if you want to insert an additional drawing into the procedure. The editor will then be available.

Delete an additional page

To delete an additional page, please do the following:

- 1. Open the additional page you want to delete.
- 2. Click on the delete button. (Marked 1 picture above)




Name an additional page

The default name on an additional page is ADDITIONAL PAGE. It is possible to rename an additional page. To rename an additional page, please do the following:

- 1. Delete the content in field marked 2 in picture above.
- 2. Type in the text you want.
- 3. Click on the Save button.

To go back to the procedure, just click on the arrow to the right of the drop down menu "*Choose document to go to*". The content in the drop down list is shown. Click on *Welding Procedure* to go back to the procedure.





5. Tools

Introduction

In this part of WeldEye the sketch library and the mail/print functions are included.

Sketch library

In the sketch library, there are a number of sketches implemented as a standard. The sketch library is dynamic, which means that you can edit it. Some of the editing possibilities are:

- Add new sketches to the library
- Edit existing sketches
- Insert your own keyword to the sketches. (Search criteria)

There are a lot of documents with possibility to insert sketches:

- PWPS
- WPAR
- WI
- WPT
- Inspection reports

In this part of the manual it will be described how to

- Open the sketch library
- Search for sketches
- Edit a sketch
- Insert a sketch to a document

Print tool

In the print tool it is possible to:

- Print single documents
- Print documents marked in a list
- Print Weld Summary Lists.
- Print out a project
- Send documents by e-mail.

How to do this is described in this part of the manual.



5.1 Sketch library

5.1.1 Open the sketch library

To open the sketch library, you got two options:

- 1. From the left side menu
- 2. From the Top menu

From the left side menu:

- a. Click on Tools
- b. Click on Sketch library.

From the top menu:

- a. Drag your cursor to the New button. A sub menu will appear.
- b. Click on Sketch library.

In both cases, the following will appear on your screen:



The sketch library is now open.

Note that the sketch library opens in a new window. This means that it will be open even if you go to another part of WeldEye. The sketch library will close when you click on the $X\ (1)$ in the upper right corner.

5.1.2 Search for sketches

As shown in the picture above, you are now able to do a search for existing sketches, or you can add new sketches.

Explanation to the buttons:

Search Performs a search based on your search criteria's

Makes it possible to add a new sketch to the sketch library. When click on this button, a dialog box open. You need to type in the name to the new sketch you want to add. Then click OK. The drawing tool/editor

will then open.



Explanation to the fields:

Sketch name: Search criteria for the name of the sketch you want to search

for. If you type in "%" in the sketch name, all sketches in the sketch library will open. (4 sketches on each page. You need to

click on the *Next* button to show the 4 next sketches)


Keyword: Search criteria for the keyword to the sketch you want to search

for. Keyword can be a word you have added. A keyword can

be a word that is easy to remember


5.1.3 <u>Example 1</u>

We want to search for all sketches in the sketch library. Then we need to fill in the following search criteria's:





The search result will appear on the screen:



Explanation to the buttons:

Next

Open the survey with the next 4 sketches. When click on the *Next* button, a new button will appear. This button, *Previous*, will take you back to the previous shown sketches.

Edit

Open the drawing tool/editor. Editing of a sketch/drawing must be performed in the editor. After editing of a sketch, remember to save changes.

Save

After editing and saving a sketch in the editor, it is also required that you save the sketch here. This is required to store the changes in the sketch library.

Сору

Click on the *Copy* button to make a copy of the sketch to the clipboard. You can then paste the copied sketch in to a document. (WPAR, WPS, test reports etc.)



5.1.4 Add sketches to the sketch library


As mentioned earlier it is possible to add your own sketches in to the sketch library. To add a sketch to the library, please do the following:

- 1. Open the *Sketch library*
- 2. Click on the *Add* button
- 3. Insert the name of the sketch you want to add.
- 4. Click on OK. A window with a blank sketch will open.
- 5. Click on the *Edit* button. The editor will open.
- 6. Draw your sketch and save it.
- 7. Click on the *Save* button in the sketch library.

5.1.5 Example 2


Adding a drawing/sketch to the sketch library by following the steps described above:

The following picture will open after step 1, 2 and 3. The name of the sketch is set to Test 2. This will be the name of the new sketch in the sketch library. Please note that the sketch name must be unique.







A window with a blank sketch will open. The sketch name is created. The keywords is blank




The editor will open:










The sketch appears in the sketch library window. To make it easier to search for, let us give the sketch a keyword. In this case the keyword is Manual BV1. Then I know it's a sketch regarding the user \underline{Manual} , \underline{B} for butt weld, \underline{V} for type of joint and \underline{I} is just a serial number.



NB! To save changes to sketch library, you are required to click on the Save button. If not, the sketch will not be included in the sketch library.

Copyright©



5.2 Print tool

In the print tool it is possible to:

- Print single documents
- Print documents marked in a list
- Print final documentation.
- Send documents by e-mail.

The print tool can be opened directly, which means that the user defines which documents to be printed/mailed.

The print tool can also be opened with the print work pre-defined. This means that the documents to print automatically are defined by WeldEye. The user is allowed to do corrections regarding which documents to be printed. (Open from a document/list)

In the further explanations, examples of different kind of print-outs/mails will be shown.

5.2.1 Open the print tool directly

To open the print tool, you got two options:

- 1. From the left side menu
- 2. From the top menu

From the left side menu


- a. Click on the Tools button
- b. Click on the Print tool button

From the top menu

- a. Drag your cursor to the Print button.
- b. Click on *Print tool*.



The following will appear on your screen:





Page 70 of 74

As shown in the picture above, almost nothing is pre-defined. Project and language only. E-mail address will also be pre-defined if you have set it in *Administration*>*Preferences*.

Before print out is possible, you are required to choose a print module, and which documents to be included in the print out. If not chosen properly, you will receive an Error message when click on the *Print* button.

5.2.2 Print documents marked in a list


To be able to print documents in a list, a search must be performed.

Example:

Three WPS's are to be printed out. To print out these three WPS's, please do the following:

- 1. Open the search picture for WPS's by click on *Welding Procedures*->*Search*.
- 2. Insert your search criteria's.
- 3. Click on the *Search* button.

The survey over the searched WPS's is shown:



- 4. Mark the WPS's you want to print.
- 5. Drag your cursor to the Print button on the top menu.
- 6. Click on Print documents in list.

The print Tool will open with predefined settings.

7. Click on the *Print* button.

The WPS's marked in the survey will now be printed to the e-mail address inserted in the print tool.

See also chapter 7, Welding Procedures.



5.2.3 Print out of a Weld Summary List


Introduction

In WeldEye there is a possibility to print out a Weld Summary List with content based on your print selection. The print job will either go to the e-mail address set in the print tool, or to a catalogue. This depends on installation type. Normally the print job will be sent to an e-mail address.

To print out a list, please do the following:

- 1. Open the Weld Summary List you want to print. How to open WSL is described in chapter 10.
- 2. Drag your cursor to the print icon on top menu. A sub menu will appear.
- 3. Click on *Print document*.

The print tool will open with the module Welding Management marked:



- 1 Tag off in check boxes what to include in the print job.
- 2 Tag off the type of inspection reports you want to include in the print job.



This defined print job will result in print out of:

- The current Weld Summary List
- Inspection Reports referred to in current WSL/WV.
- WPS's referred to in current WSL/WV
- Certificates to the welders referred to in current WSL/WV
- Weld repair reports referred to in current WSL/WV

This is from the setting in area 1 on picture above.

In area 2 on picture above, it is set what type of inspection reports to include in the print job. (MT, PT, UT, RT and VT.)

5.2.4 Print out of a project


To print out documentation for a project pleas do the following:

- 1. Make sure that the project you want to print from is choosed in the project field on the top menu.
- 2. Open the print tool (*Tools->Print Tool* from left side menu. *Print button->Print Tool* from top menu) Print tool will open with only the project predefined.
- 3. Tag off the documents to be included in the print job.
- 4. Click on the print button.

5.2.5 Download

All print jobs will go to your email and to the server. If the size of the file is less than the pre-defined maximum file size, the file will be sent to e-mail and the sever. The default maximum file size is 3 MB. If required, you can change this maximum file size.

If the file size exceeds the maximum limit set in Print Tool (See 1 below), the print job will not be sent to your e-mail, but will be available from *Tools->Download* in the left side menu. Then you can open it from there for saving the file or print it.






5.2.5.1 Open Download Manager


To open the Download Manager, please do the following:

1. Click on Tools->Download in left side menu

The Download Manager will open:



Explanation to the buttons:






Explanation to the coloumns:

FILE NAME: The name of the file. You can give the file a name by insert the wanted name in Print Tool field: Message/reference in email. If nothing is inserted in this field, WeldEye will create a unique name for the file.

LAST MODIFIED: The date the file was last modified.

FILE SIZE: Information of the file size in kilobytes.

5.2.5.2 Handling of files in Download Manager



The file name marked 1 above is a hyperlink that will open your printout in Adobe Reader. When opened, you have the choice to print it out or save it to disk.

If you want to delete the file, just mark the check box and click on the *Delete* button. A confirmation message will appear. If you want to delete the checked file, click OK, if not click Cancel.