

Storage Video Recorder User's Manual

Table of Contents

1	FEATURES AND FUNCTIONS.....	8
1.1	Specification	8
1.1.1	SVR3016H	8
1.1.2	SVR3016G	8
1.1.3	SVR3016L	9
1.2	Installation.....	10
1.2.1	Preparation	10
1.2.2	Set Device	10
1.2.3	HDD Installation	10
1.2.4	Cable Layout.....	10
1.2.5	Boot up and Shut down.....	11
2	SYSTEM OPERATION	13
2.1	Preparation Work.....	13
2.2	Network Setup.....	13
2.2.1	Set Controller IP Address	13
2.2.2	Network Connection Test	14
2.2.3	Set IP Address	14
2.3	Boot up Device.....	15
3	WEB CONFIGURATION.....	17
3.1	Web Login.....	17
3.2	System Management.....	17
3.2.1	Information	17
3.2.2	Parameter	18
3.2.3	Organization	18

3.2.4	Group.....	19
3.2.5	User.....	20
3.2.6	Upgrade.....	22
3.2.7	Shut down System.....	22
3.3	Network Management.....	23
3.3.1	Network Configuration.....	23
3.3.2	Router Configuration	25
3.4	Disk Management.....	26
3.4.1	Disk Information	26
3.4.2	RAID Configuration.....	29
3.4.3	Storage Pool Configuration	32
4	SVR MONITOR SYSTEM CONFIGURATION	35
4.1	Operation Management.....	35
4.1.1	Parameter Setup.....	35
4.1.2	Storage Setup.....	35
4.1.3	Device Configuration	37
4.1.4	Storage Plan	39
4.1.5	Alarm Configuration.....	41
4.1.6	Configuration Management	44
4.2	System Status	45
4.2.1	Service Status	45
4.2.2	Device Status	46
4.2.3	Record Status.....	47
4.2.4	User Status	47
4.2.5	Log	48
4.2.6	Service Log	48
5	SVR STORAGE PLAN.....	50
5.1	Quickly Create Storage Plan Process	50
5.2	Admin user login	50

5.3	Create system user	50
5.4	RAID device configuration.....	51
5.5	Storage pool configuration	53
5.6	Storage Folder Configuration.....	54
5.7	Storage Parameter Configuration	54
5.8	Device Configuration.....	55
5.9	Storage Plan Configuration	55
5.10	Alarm Plan Configuration.....	56
5.11	Enable Storage Service.....	57
6	ESS3015A	58
6.1	ESS3015A and SVR	58
6.1.1	Disk Management.....	58
6.1.2	RAID Setup	59
6.1.3	Storage Plan Configuration	60
7	APPENDIX A ---TERMS EXPLANATION	62
8	APPENDIX B DISK HOT SWAP OPERATION	64
9	APPENDIX C COMMAND OPERATION	71

Welcome

Thank you for using our Storage Video Recorder (SVR)!

This user's manual is designed to be a reference tool for the installation and operation of your system.

How to use SVR User's Manual

- If it is your first time to use our SVR, please read
Chapter 1 ---Features and Functions
- After your installation, please refer to the following chapters for setup.
Chapter 2 ---System Operation
- If you want to know the basic system configuration, please read:
Chapter 3 ---Web Configuration
- If you want to know the SVR and front-end device monitor configuration, please read:
Chapter 4 ---SVR Monitor System Configuration
- If you want to quickly use our SVR, please read:
Chapter 5 ---SVR Storage Plan
- If you want to know SVR disk hot swap operation, please read:
Appendix B--Disk Hot Swap
- If you have installed the SVR, but you forgot the password or you want to restore factory default setup, please read:
Appendix C- Command Operation

Before installation and operation please read the following safeguards and warnings carefully!

Important Safeguard and Warnings

1 . Electrical Safety

All installation and operation should conform to your local electrical safety codes.

We assume no liability or responsibility for all the fires or electrical shock caused by improper handling or installation

2 . Installation

Keep upward. Handle with care.

Do not apply power to the unit before completing installation.

3 . Qualified Engineers Needed

All installation here should be done by the qualified engineers.

All the examination and repair should be done by the qualified service engineers.

We are not liable for any problems caused by unauthorized modifications or attempted repair.

4 . Environment

The server shall be installed in a cool, dry place away from direct sunlight, inflammable, explosive substances and etc.

5. About Accessories

Be sure to use all the accessories recommended by manufacturer.

Contact you local retailer ASAP if something is missing or damaged in your package.

1 Features and Functions

This series network storage video recorder (SVR) has installed all necessary software. It works in 1000M network environment (recommended) or 10/100Mbps Ethernet. You can use web browser to set network parameter, storage space, and manage device configuration, storage plan and etc.

1.1 Specification

1.1.1 SVR3016H

Please refer to the following sheet for SVR3016H specification.

Specification	SVR3016H
Network Port	Dual 10/100/1000Mbps Ethernet ports
Storage Media	16 SATA II HDDs
HDD Installation	Independent HDD bracket Support HDD hot swap
Data Protection	Support RAID0/ RAID1/ RAID5
Recommended Channel Amount	D1: 128 channels CIF: 256 channels
Server	Microsoft Windows 2000/XP/NT/Server2003 Linux/Unix
Fan	Redundant dual ball bearing fan MTBF>100 thousand hours
Redundant Configuration	Support 2+1 hot swap power
Power Consumption	100V~240VAC; 50Hz~60Hz;
Whole Unit Power Consumption (16 SATA HDDs)	280W~350W
Dimension (H*W*D)	133*450*650(mm)
Working Temperature	5℃~40℃
Working Humidity	10%~80% (Non condensation)
Storage Environment Temperature	-20℃~70℃
Storage Environment Humidity	5%~90% (Non condensation)
Extension Function	Max 2 ESS3015A, total 46 HDDS
Altitude	-60m~3000m
Unit Weight (Exclude HDD)	33Kg
Certificate and Security	China Compulsory Certificate
Unit Fan	Support on-line update

1.1.2 SVR3016G

Please refer to the following sheet for SVR3016G specification.

Specification	SVR3016G
Network Port	Dual 10/100/1000Mbps Ethernet ports
Storage Media	16 SATA II HDDs
HDD Installation	Independent HDD bracket Support HDD hot swap
Data Protection	Support RAID0/ RAID1/ RAID5
Recommended Channel Amount	D1: 96 channels CIF: 192 channels
Server	Microsoft Windows

	2000/XP/NT/Server2003 Linux/Unix
Fan	Redundant dual ball bearing fan MTBF>100 thousand hours
Redundant Configuration	Support 2+1 hot swap power
Power Consumption	100V~240VAC; 50Hz~60Hz;
Whole Unit Power Consumption (16 SATA HDDs)	280W~350W
Dimension (H*W*D)	133*450*650(mm)
Working Temperature	5℃~40℃
Working Humidity	10%~80% (Non condensation)
Storage Environment Temperature	-20℃~70℃
Storage Environment Humidity	5%~90% (Non condensation)
Extension Function	Max 2 ESS3015A, total 46 HDDS
Altitude	-60m~3000m
Unit Weight (Exclude HDD)	33Kg
Certificate and Security	China Compulsory Certificate
Unit Fan	Support on-line update

1.1.3 SVR3016L

Please refer to the following sheet for SVR3016L specification.

Specification	SVR3016L
Network Port	Dual 10/100/1000Mbps Ethernet ports
Storage Media	16 SATA II HDDs
HDD Installation	Independent HDD bracket Support HDD hot swap
Data Protection	Support RAID0/ RAID1/ RAID5
Recommended Channel Amount	D1: 64 channels CIF: 128 channels
Server	Microsoft Windows 2000/XP/NT/Server2003 Linux/Unix
Fan	Redundant dual ball bearing fan MTBF>100 thousand hours
Redundant Configuration	Support 2+1 hot swap power
Power Consumption	100V~240VAC; 50Hz~60Hz;
Whole Unit Power Consumption (16 SATA HDDs)	280W~350W
Dimension (H*W*D)	133*450*650(mm)
Working Temperature	5℃~40℃
Working Humidity	10%~80% (Non condensation)
Storage Environment Temperature	-20℃~70℃
Storage Environment Humidity	5%~90% (Non condensation)
Extension Function	Max 2 ESS3015A, total 46 HDDS
Altitude	-60m~3000m
Unit Weight (Exclude HDD)	33Kg

Certificate and Security	China Compulsory Certificate
Unit Fan	Support on-line update

1.2 Installation

1.2.1 Preparation

Before installation please prepare the following items:

- SATA HDD
- Tools for HDD installation
- Network cable

1.2.2 Set Device

If you want to configure setup, please follow the steps listed below.

- HDD installation. Please refer to chapter 1.2.3
- Connect power cable and network cable. Please refer to chapter 1.2.4.
- Boot up device and check self-diagnosis is OK or not. Please refer to chapter 1.2.5.

1.2.3 HDD Installation

You can use the HDD bracket in the chassis to install HDD.

First, pull out HDD bracket from the front panel.

Second, remove the bar that fixes the HDD bracket.

Third, use four screws to fix one HDD in the HDD bracket firmly.

The unit is shown as in Figure 1-1.

In the following figure, you can view HDD serial number. The value ranges from left to the right.

You can see the 13th to 16th at the bottom of the unit.



Figure 1-1

1.2.4 Cable Layout

In Figure 1-2, you can see SVR3016H rear panel interface.




Figure 1-2

You can refer to the following sheet for detailed information.

SN	Port	Function
1	Power Port	Connect to 220V AC
2	Mouse/keyboard port	Connect to mouse or keyboard to view device status.
3	USB port	Connect to USB device.
4	COM	Connect to RS232 COM to go to the command interface.
5	CRT Port	Connect to displayer.
6	Ethernet port	It is used to transmit data. 1000M Ethernet port.
7	Ethernet port	It is used to transmit data. 1000M Ethernet port.
8	Extension Connection Port	Connect to the extension disk rack.

1.2.5 Boot up and Shut down

Please follow the steps listed below to boot up the device.

- Connect the power cable to the system.
- Click the device power button to boot up the system. You can see power indication light becomes yellow and all channel read-write indication lights flashed once. Now the boot up completed.

If it is your first time to boot up system, you need to set network operation system manually.



Figure 1-3

SN	Name	Function
1	Power Alarm	If there is error in one of the three alarm sockets, the light becomes red.
2	Fan	If there is alarm from the system fan, the light becomes red.
3	Temperature	If there is alarm from the system temperature, the light becomes red.
4	NETb	It is network data channel 2 indication light. The yellow light flashes if the network port is working properly
5	NETa	It is network data channel 2 indication light. The yellow light flashes if the network port is working properly
6	System HDD Indication Light	The blue light flashes when current channel is reading or writing data.
7	Power Indication Light	It becomes yellow after you connect device to the power.
8	RESET	Click this button to reboot system.
9	System Button	After connected the device to the power, click it to boot up the device.
10	HDD Power Indication Light	The yellow light flashes when connect the HDD channel to the power.
11	HDD Read-write Indication Light	The blue light flashes when the system is reading or writing the HDD.

If you want to turn off unit power, please follow the following steps:

- In web interface, select option to shut down the system.
- Please wait until the blue HDD read-write light becomes off.
- Click PWR button to shut down the system.

Warning!

Do not click PWR button to shut down the system directly!

2 System Operation

2.1 Preparation Work

- 10/100Mbps or 1000Mbps Ethernet hub or switcher.
- Controller of the following configuration: Windows 2000/XP, IE 6.0.
- Check the real panel cable layout is O.K or not. (Power cable, network card and etc)

2.2 Network Setup

SVR default network setup is shown as below :

- IP: 192.168.0.111.
- Gateway: 192.168.0.1.
- Subnet mask: 255.255.0.0
- User name: admin
- Password : 888888888888(12-digit)

To configure device via WEB, you need to set controller panel IP first.

2.2.1 Set Controller IP Address

Right click My Network Places, select property. And then right click local connection and then click property, double click internet protocol (TCP/IP).

In Internet protocol interface (see Figure 2-1), you can modify IP setup and then click O.K button. Please note controller IP and device IP shall be in the same network segment.





Figure 2-1

2.2.2 Network Connection Test

In DOS environment, input the command: ping 192.168.0.111. If network connection is right, you can see the following interface. See Figure 2-2.



```
C:\WINNT\system32\cmd.exe
Microsoft Windows 2000 [Version 5.00.2195]
(C) Copyright 1985-2000 Microsoft Corp.

C:\>ping 192.168.0.111

Pinging 192.168.0.111 with 32 bytes of data:


Reply from 192.168.0.111: bytes=32 time<10ms TTL=128
Reply from 192.168.0.111: bytes=32 time<10ms TTL=128
Reply from 192.168.0.111: bytes=32 time<10ms TTL=128
Reply from 192.168.0.111: bytes=32 time<10ms TTL=128

Ping statistics for 192.168.0.111
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>_
```

Figure 2-2

If you see an interface is shown as in Figure 2-3, you need to check your network connection.



```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\James>ping 192.168.0.111

Pinging 192.168.0.111 with 32 bytes of data:

Request timed out.
Request timed out.
Request timed out.
Request timed out.

Ping statistics for 192.168.0.111:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Documents and Settings\James>_
```

Figure 2-3

2.2.3 Set IP Address

Please follow the steps below to set device IP address.

2.2.3.1 Input IP address

Open IE browser, input <http://192.168.0.111>(default IP address) you can see the login interface. See Figure 2-4.



Figure 2-4

2.2.3.2 Log in

System user name is admin and password is 888888888888(12-digit).

Admin is the system administrator account and has the highest priority.

For security reasons, please modify your password after first login (At least 12-digit).

2.2.3.3 Go to edit interface

In the main interface, from network to network and then click edit button. See Figure 2-5.




Figure 2-5

2.2.3.4 Input setup

The edit interface is shown as in Figure 2-6. Here you can input your new IP address information and then click save button.




Figure 2-6

2.3 Boot up Device

Open IE browser, and input http://10.12.5.9 in the address column (10.12.5.9 is a new IP address you modified after you first logged in.). Input your user name and password, you can log in. After you logged in, you can see an interface consisting of five parts. See Figure 2-7.

- System
- Network
- Disk
- Operation
- Status



Figure 2-7

3 Web Configuration

SVR software operation consists of four parts.

- Web login
- System management
- Network management
- Disk management

The recommended environment:

- Windows 2000/XP
- IE v6.0

3.1 Web Login

In windows OS, open IE browser and then input system IP address. Click Enter, you can see the following interface. See Figure 3-1.

Please input user name and password to login.



Figure 3-1

3.2 System Management

In this interface, you can see the following seven parts.

- System information
- System Parameter
- Organization
- Group
- User
- Upgrade
- Shut down

3.2.1 Information

After you logged in, you can see system information interface. Or you can click system and then select system information item to go to current interface. See Figure 3-2.

Here you can see the following information:

- System Time
- Start time
- Device model
- Software version
- Power status
- CPU temperature
- Fan speed

System displays three fan speeds here including one CPU fan speed.

Note:

If it is your first time to go to the system, please set system time.

When device internal temperature is higher than the threshold value (55 centigrade) or the fan speeds is lower than 1500r/m, system displays corresponding information in red font to alert you.




Figure 3-2

3.2.2 Parameter

Click parameter button, you can see the following interface. See Figure 3-3.

- Host name: Current SVR device name.
- Date: SVR device date.
- Time: SVR device time.
- Start auto synchronization setup: Please input server IP and synchronization interval.
- Start SVR maintenance service: Please check the box and then input auto maintain time and date. System can detect error and fix it through auto maintenance operation.

Please note, the time server IP and device IP shall be in the same network segment.

After you clicked update now button, system begins synchronizing time with the time server.




Figure 3-3

3.2.3 Organization

Click organization button, you can see the following interface. See Figure 3-4.

System default root name is “root” and it can not be removed.

In the following interface you can see there is a second-level organization “overseas”

There are two third-level organizations: Sales engineer and technical engineer.




Figure 3-4

3.2.3.1 Add Organization

If you want to add an organization, please click the add button after the corresponding organization. The interface is shown as in Figure 3-5. Please input the organization name and its note (optional), and then click save button to exit.




Figure 3-5

3.2.3.2 Remove Organization

Click the delete button after the corresponding organization; you can remove the selected organization. System pops up a dialogue box, please click OK to continue.

Note:

If there is lower-level organization in current organization, or there are devices belonging to the current organization, the remove operation fails.

3.2.4 Group

Click group button, you can see the following interface. See Figure 3-6.

Here you can view all operators' information: name, group type.

There are also configuration and delete button.

In the following interface, you can see there are two operators: “operator_group” and “overseas”.

Please note “operator_group” is system default operator group.




Figure 3-6

3.2.4.1 Group Configuration

Click configuration button after the corresponding operator group name, you can see the following interface. See Figure 3-7.

Here you can select the organization and view the device(s) belonging to it.

You can set monitor, play, PTZ and alarm right.

Note:

When you added a new device, system enable all rights by default.



Figure 3-7

3.2.4.2 Remove Group

In Figure 3-6, click the delete button after corresponding group, you can remove current group.

Note:

Once there is user belonging to current group, the remove operation fails.

3.2.5 User

Click user button, you can see the following interface. See Figure 3-8.

System consists of two-level users: admin level and operator level.

- Administrator: The admin can read, write or delete all storage data in current system. It can configure the whole system rights.
- Operator: The operator can use client-end software to begin operation such as user IPC device, search storage recorded files or playback key record.

Please note password initialization is for administrator only, admin can click it to restore operator factory default password (123456).



Figure 3-8

3.2.5.1 Add user

Click add button, you can see an interface is shown as in Figure 3-9.

Please input user name, password and then confirm password. Please check the corresponding box group name and then click save button, system goes back to account interface if the operation succeeded.

Please note:

The user name here can only contain character and number.

The added user here is operator user.




Figure 3-9

3.2.5.2 Edit User password

Click edit button of corresponding user, you can see the following interface. See Figure 3-10.

Please input new password and confirm, you can modify the user's password.

Please click save button, system goes back to account interface if the operation succeeded.




Figure 3-10

3.2.5.3 Remove User

In Figure 3-8, click the delete button of the corresponding user. You can remove current account. System deletes the user name and password, and you can not use current account to login any more.

3.2.6 Upgrade

From system to upgrade, here you can see a system upgrade interface is shown as in Figure 3-11.

Administrator can use this service to upgrade software.

Click browser button to select the upgrade file and then you can click upgrade button to begin update.

Note:

Before you upgrade the system, please go to our official website to download the latest version.




Figure 3-11

3.2.7 Shut down System

Click shut down system button; you can see the following interface. See Figure 3-12.

There are two options for you: shut down /reboot the system.

In each interface, you can see these two buttons on the top right corner. It is very convenient for you to shutdown the system or reboot it.




Figure 3-12

3.3 Network Management

In this interface you can set device network card and router in the LAN.

3.3.1 Network Configuration

Click network configuration button, you can view current network card information. See Figure 3-13.

- Network card name
- IP address
- Subnet mask
- Default gateway
- Mac address
- Status

You can also view network status, edit network information, binding or remove the binding. System provides default gateway setup function.




Figure 3-13

3.3.1.1 Set network card

In the above interface, click edit button you can see the following interface. See Figure 3-14.

You can modify IP address, subnet mask, default gateway.

Please note, in network binding status, bond0 is the exclusive port for the SVR. If you modify the network port information when SVR service has booted up, system needs to reboot to activate current setup.




Figure 3-14

3.3.1.2 View status

In Figure 3-13, click status button, you can see an interface is shown as in Figure 3-15. Here you can view current network port connection status; data send out status and receive status.

The screenshot shows the 'Network' tab with 'Network status' selected. The left sidebar is the same as in Figure 3-14. The main area displays two tables of network statistics.

Interface	Link	Speed	TX packets	Errors	Dropped	Overruns	Carrier	Collisions	Txqueuelen	TX bytes
bond0	yes	100Mb/s	6231	0	0	0	0	0	0	5.9MB
eth0	yes	100Mb/s	6231	0	0	0	0	0	100	5.9MB
eth1	yes	100Mb/s	0	0	0	0	0	0	100	0.0MB

Interface	Link	Speed	RX packets	Errors	Dropped	Overruns	Frame	RX bytes
bond0	yes	100Mb/s	188505	0	0	0	0	14.2MB
eth0	yes	100Mb/s	96571	0	0	0	0	7.4MB
eth1	yes	100Mb/s	91934	0	0	0	0	6.8MB

Figure 3-15

3.3.1.3 Remove binding.

Click remove binding button in Figure 3-13, you can see the interface is shown as in Figure 3-16. These two cards are displayed respectively. The independent network card eth0 information is the same as previous binding information.

If you want to view network card detailed information, please click status button.

If you want to configure the network card, please click corresponding edit button. The interface is similar to Figure 3-16.




Figure 3-16

3.3.1.4 Default gateway setup

In Figure 3-16, you can set default gateway. If you select eth0, then the devices in the WAN can access the SVR via the gateway of eth0. In Figure 3-16, the device can use the gateway of 10.10.0.1 to access.

3.3.1.5 Network card binding

In Figure 3-13, click network card binding button, you can go to the following interface. See Figure 3-17.

Please select two network cards first and then input IP address, subnet mask and default gateway. Click OK button you can complete the binding setup.

Please note, if current SVR service has booted up, system needs to reboot to activate current setup.



Figure 3-17

3.3.2 Router Configuration

From network, select router item, you can view current router setup. See Figure 3-18.

- No.
- IP address
- Gateway
- Network

- Interface

After you configured the following two routers as the network card, the system default router IP address may vary according to the network card IP address.

- The first router: The default router setup allows SVR to connect to the pc in the segment 10.12.0.0.
- The second router: The default router setup allows SVR to connect to the all pc in the segment except 10.12.0.0.



The screenshot shows a web-based configuration interface. On the left, there is a sidebar with 'Network' and 'Route' options. The main area displays a table with two routes. The first route has IP 10.12.0.0, Gateway 0.0.0.0, Netmask 255.255.0.0, and Interface bond0. The second route has IP 0.0.0.0, Gateway 10.12.0.1, Netmask 0.0.0.0, and Interface bond0. Each row has a 'Delete' button represented by an 'X' icon.

No.	IP	Gateway	Netmask	Interface	Delete
1	10.12.0.0	0.0.0.0	255.255.0.0	bond0	X
2	0.0.0.0	10.12.0.1	0.0.0.0	bond0	X

Figure 3-18

If the network card binding has removed, you can see an interface is shown as Figure 3-19.

Here you can view the eth0 and eth1 router information.

Please note, right now the eth0 network port is connected and eth1 is disconnected, so in the following figure, you can only see the LAN router and WAN router of eth0.



The screenshot shows the same web-based configuration interface as Figure 3-18, but the interface column now shows 'eth0' for both routes. The first route has IP 10.12.0.0, Gateway 0.0.0.0, Netmask 255.255.0.0, and Interface eth0. The second route has IP 0.0.0.0, Gateway 10.12.0.1, Netmask 0.0.0.0, and Interface eth0. Each row has a 'Delete' button represented by an 'X' icon.

No.	IP	Gateway	Netmask	Interface	Delete
1	10.12.0.0	0.0.0.0	255.255.0.0	eth0	X
2	0.0.0.0	10.12.0.1	0.0.0.0	eth0	X

Figure 3-19

3.4 Disk Management

Disk management is to display disk physical information in the system, configure multiple disks into RAID group and then create storage pool in the RAID group.

3.4.1 Disk Information

Please click disk button to view disk information. See Figure 3-20.

Here you can review the following information.

- Channel
- Disk name
- Disk space
- Status
- Group
- Use status
- Type

Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
1	disk1	233	running	md1	Used	ST3250310SV
2	disk2	233	running	md1	Used	ST3250310SV
3	disk3	233	running	md1	Used	ST3250310SV
4	disk4	233	running	md1	Used	ST3250310SV
5	N.A.	N.A.	N.A.		N.A.	N.A.
6	disk6	233	running	md1	Used	ST3250310SV
7	disk7	233	running	md1	Used	ST3250310SV
8	N.A.	N.A.	N.A.		N.A.	N.A.
9	N.A.	N.A.	N.A.		N.A.	N.A.
10	N.A.	N.A.	N.A.		N.A.	N.A.
11	N.A.	N.A.	N.A.		N.A.	N.A.
12	N.A.	N.A.	N.A.		N.A.	N.A.
13	N.A.	N.A.	N.A.		N.A.	N.A.
14	N.A.	N.A.	N.A.		N.A.	N.A.
15	N.A.	N.A.	N.A.		N.A.	N.A.
16	N.A.	N.A.	N.A.		N.A.	N.A.

Figure 3-20

3.4.1.1 Display disk S.M.A.R.T. Information

When disk channel number is blue, it means current channel disk is available. Now you can view disk S.M.A.R.T. information. Click one channel number; you can go to the following S.M.A.R.T.information interface. See figure 3-21.

It includes the following items:

- Channel
- Read error
- Boot up
- Reallocated
- Seek error
- Boot up
- Correct
- Temperature
- Rate

In the following interface, there are three buttons: return/detail information/initialization.

- Back: You can click it to go to previous interface.
- Initialization: it is to initialize the disk. Disk initialization is going to remove all data in current disk. So, do not use it causally unless there is a must.

- Detail information: You can click it to view more detail information in a new interface. Click return button you can go back to Figure 3-16.




Figure 3-21

3.4.1.2 Add hot spare disk

In Figure 3-20, click add hot swap disk button, you can see an interface is shown as in Figure 3-22.

Here you can view idle disk list. You can click the select button to select the hot spare disk. Then you can click save button to exit.

Please note one device can max have four disks.




Figure 3-22

3.4.1.3 Remove hot spare disk

In Figure 3-20, click remove hot spare disk button, you can see an interface is shown as in Figure 3-23.

Please note all the disks in the list are hot spare disks. You can click the select button and then click save to remove the hot spare disk. The specified disk now becomes idle.




Figure 3-23

3.4.2 RAID Configuration

Click raid button, you can see an interface is shown as in Figure 3-24.

Here you can see the following information:

- RAID name
- Type: RAID5, RAID0, RAID1.
- Status: It is in synchronization or not. If it is in synchronization, system can display current process.
- Member disk
- Total space(Unit: G)

The disk group status includes: “clean degraded, recovering” , “clean, recycling” and “clean”

RAID1 and RAID5 provide data restore function. But the function becomes valid after the synchronization.

When RAID device status is Inactive, it can not be used right now.

In the following interface, you can see:

There is only one Raid5 device, device name is md1.

Right now, md1 is in the synchronization process and has completed 0.1%.

It consists of three disks: disk2, disk1, disk9. Its total space is 932G.

You can refer to the following information for RAID device capacity calculation.

RAID5: Please refer to Appendix A for RAID5 definition. The RAID5 capacity is $(N-1) \times \min(\text{capacity}_N)$. CapacityN is the total amount of all disks. You can view the value in the Web.

RAID1: Please refer to Appendix A for RAID1 definition. The RAID5 capacity is $\min(\text{capacity}_N)$. CapacityN is the total amount of all disks. You can view the value in the Web.

RAID0: Please refer to Appendix A for RAID0 definition. The RAID5 capacity is the total amount of all disks. You can view the value in the Web.

Note:

If RAID device is in synchronization process now, system can display current percentage and speed (MB/S). Usually, please use the device after the synchronization completed. That is to say, do not create storage pool logic volume during the synchronization.




Figure 3-24

3.4.2.1 Edit RAID configuration

In Figure 3-24 click edit button after specified RAID, you can go to the edit interface. See Figure 3-25.

Here administrator can remove one RAID device or and a disk.

Please note, you can not add or remove RAID1/ RAID5 unless the RAID1/RAID5 group is damaged.




Figure 3-25

RAID5

Remove disk: System max supports one disk. All data are safe after remove. After removed the disk, RAID5 device is in degrading status. Please note RAID 5 is invalid once you remove more than one disk.

Note: Do not remove the disk casually unless there is a must! Do not remove the disk when RAID5 device is in synchronization process. If you find one RAID5 disk is malfunction, please remove the disk in the interface and then remove it from the chase.

Insert disk: This operation also needs to be done after synchronization. Before you add a disk, you first need to remove one disk. Otherwise you cannot add any disk. If you have removed one RAID5 device disk, you can add another one. Then you can see system begins synchronization after the add operation. All data in the device are safe.

RAID1


Remove: System max supports one disk. All data are safe after remove. RAID1 device can use properly.

Note: Do not remove the disk casually unless there is a must! Do not remove the disk when RAID1 device is in synchronization process. If you find one RAID1 disk is malfunction, please remove the disk in the interface and then remove it from the chase.

Insert disk: This operation also needs to be done after synchronization. Before you add a disk, you first need to remove one disk. Otherwise you cannot add any disk. If you have removed one RAID1 device disk, you can add another one. Then you can see system begins synchronization after the add operation. All data in the device are safe.

RAID0

You can not remove or add disk. See Figure 3-26.



The screenshot shows a RAID configuration window. On the left, there is a sidebar with 'Disks' expanded, showing 'Disk', 'RAID' (selected), and 'Pool'. The main area is titled 'Detailed RAID Information' and contains the following data:

Detailed RAID Information			
RAID Name : md4		RAID Type : raid0	
Total Space(G) : 1695.38		Member Disk Amount : 4	
Status : clean			
Member disk :			
SN	Disk	Disk Space(G)	Disk Status
1	disk10	465.76	in_sync
2	disk7	465.76	in_sync
3	disk4	465.76	in_sync
4	disk1	298.09	in_sync

Figure 3-26

3.4.2.2 Add RAID configuration

In Figure 3-24, click add button, you can see an interface is shown as below. See Figure 3-27. Here you can select RAID type (RAID0, RAID1, RAID5) Then you can select the RAID device disk. All disks listed below are available to be used. Last, you can click save button to complete the add operation.




Figure 3-27

3.4.2.3 Remove RAID configuration

The remove operation includes the following three environments. (See Figure 3-24)

- Current RAID group has not been used: That is to say, there is no storage pool. You can click remove button to delete RAID group directly.
- System is using current RAID group: That is to say, there is storage pool in current RAID group, but there is no share directory. You need to remove the storage pool first and then remove the RAID group. Otherwise the operation may fail.
- System is using current RAID group: That is to say, there is storage pool and there is share directory in the pool. You need to remove all directories in the storage pools first and then remove the storage pool. Finally, you can remove RAID group.

3.4.3 Storage Pool Configuration

From disk to storage pool item, you can see an interface is shown as in Figure 3-28.

Here you can view the storage pool information.

- Storage pool name
- Member device
- Total space
- Used space

Please note, if current storage pool is damaged. You can see the corresponding prompt saying current storage pool has been damaged. Now the total space and used space both are shown as 0.




Figure 3-28

3.4.3.1 Add storage pool

The storage pool device includes RAID device (RAID5 / RAID1 / RAID0), single disk (such as disk1), disk combination (such as disk 2,disk3). Usually we recommend RAD1 and RAID5.

You can select the device and then click save button to exit. See Figure 3-29.

Note:

We recommend to use RAID1/RAID5.




Figure 3-29

3.4.3.2 Edit storage pool

In Figure 3-28, click edit button, you can see an interface is shown as in Figure 3-30.

Here you can view all share folder information in the storage pool. If the storage directory does not exist or it has not been successfully mounted. You can view the use status is shown as “not available” and there is a corresponding remove button for you to remove current device.




Figure 3-30

3.4.3.3 Remove storage pool

The remove operation includes the following two environments. See Figure 3-28.

- There is no storage configuration: You can click remove button directly.
- There is storage configuration: You need to remove the storage configuration first and then you can remove the storage pool.

4 SVR Monitor System Configuration

SVR extension function includes:

- Operation management
- System status

4.1 Operation Management

Operation management is to manage storage plan and storage configuration, at the same time you can configure the device.

4.1.1 Parameter Setup

In parameter setup interface, you can set record pack duration, storage capacity information and log service. See Figure 4-1.

The pack duration is for you to specify file length. If you set five minutes here, then all recorded files are of five minutes video.

Reserved volume setup is very useful in case the system is down when the recorded files have occupied the whole storage capacity. If you set 10G here, then system automatically overwrites previous records when system free capacity is 10G.

Here you can also enable log service and set log saved path. The setup here applies to the SVR service log. Please note if there is no storage configuration, you can not select the log saved path.

Figure 4-1

4.1.2 Storage Setup

Click storage set button, the interface is shown as in Figure 4-2.

Here you can view storage directory, volume group, total space, free space, system status and configuration status.

In the following interface, you can see there are two storage setups.

Setup1: storage directory is 99, RAID5 group, total volume is 0 and free volume is 0. system now is bad. Configuration status is normal.

Setup2: storage directory is ew, poola group, total volume is 132.93, free volume is 132.90.

System is now running properly. Configuration status is normal.

You can refer to the following contents for system status and configuration status information.

- **System status:** It is the storage directory status in the system. If system status is normal then the storage directory can run properly. If there is abnormal phenomenon, then the data from the storage plan may be lost, it has a close relationship with the proper record operation of the storage plan, it affects the storage data security and integrity.
- **Configuration status:** It means configuration information of current storage directory can be saved in the system configuration file or not. If there is configuration file being saved, then configuration status is use, which means the recorded data of corresponding storage plan can be saved in the storage directory. If there is no corresponding information in the configuration file, then the recorded data can not be saved in the specified storage directory.

No.	Storage directory	volume group	Total vol(G)	Free vol(G)	system status	config status	Delete
1	99	RAID5	0.00	0.00	bad vg	use	×
2	ew	poola	132.93	132.90	normal	use	×

Figure 4-2

4.1.2.1 Storage configuration status in abnormal environment

If there is abnormal storage configuration, you can click the remove button to remove the storage configuration. But the remove operation will delete all record data in the storage configuration.

See Figure 4-3.

- For system status, there are two abnormal statuses: Storage pool is damaged/File system is abnormal.
- For use status, the abnormal status is configuration error.

Do not operate it casually unless there is a must!

No.	video directory	volume group	Total vol(G)	Free vol(G)	system status	config status	Delete
1	share	ss4	99.95	64.29	normal	use	×
2	66	ss4	99.95	38.99	normal	use	×
3	ss0	ss4	99.95	70.87	normal	config error	×

Figure 4-3

4.1.2.2 Add storage directory

In Figure 4-1, please click add button. You can see an interface is shown as in Figure 4-4.

Note:

In case there is abnormal device status, system usually reserves 5G from the total space for record space management. Please click save button to exit.

The screenshot shows the 'Storage Set' configuration page. On the left is a sidebar with 'Operation' selected, containing links for Parameter Set, Storage Set, Device Set, Sto. Policy, Alarm Policy, and Config Manage. The main area has input fields for 'name' and 'Volume(G)', a 'pool' dropdown, and a table with the following data:

pool	pool name	pooldevice	Total volume(G)	used volume(G)
☐	ss4	disk4	931	300

A 'Save' button is located at the bottom of the main area.

Figure 4-4

4.1.2.3 Remove storage directory

Before you remove storage directory, please disable SVR service (Figure 4-15) and then click remove button (Figure 4-4).

4.1.3 Device Configuration

Click device configuration button, the interface is shown as in Figure 4-5.

Here you can view device number, device name, device type, device channel amount, device IP address and its belonging organization.

You can use choose all/choose none button to quickly select all or cancel all devices.

The screenshot shows the 'Device Set' configuration page. On the left is a sidebar with 'Operation' selected, containing links for Parameter Set, Storage Set, Device Set, Sto. Policy, Alarm Policy, and Config Manage. The main area contains a table with the following data:

No.	Device No.	Device Name	Device Type	Channel Num	IP address	Owned Position	Edit	Delete
☐ 1	1001002	Overseas IPC	IPC	1	10.10.5.168	Overseas		

At the bottom of the main area are buttons for 'Add', 'Delete', 'Choose All', and 'Choose None'.

Figure 4-5

4.1.3.1 Add device

In Figure 4-5, click add button, you can see an interface is shown as in Figure 4-6.

Please input corresponding configuration parameter and then click save button.

- Device type: There are three options: DVR/IPC/NVS.
- Device name: You can input a self-defined name.
- Device manufacture: Please select a name from the dropdown list.
- Device channel amount: Device record channel amount. It includes: 1/2/3/4/8/16. Please note, once you input, the information here **can not** be modified any more.
- Alarm channel: You can select according to the device channel amount. Please note, once you input, the information here **can not** be modified any more.
- Device IP address: Please input device IP address here. Please input DDNS device name if you have enabled DDNS function.
- Device port: Default value is 37777.
- Device login name: Please input a name for your login. This name shall be reusable (Multiple users can use this account to login at the same time.).
- Device login password: The corresponding password for the login name.
- Device owner: You can select its belonging organization from the dropdown list.
- Device description: You can input device self-defined description information.
- Channel name: System generates the channel name here.
- Channel number: System generates the channel property information here.
- Channel type: You can select from the dropdown list. It includes: speed dome,/Half-shape camera/fixed camera.
- Codec type: you can select the corresponding resolution from the dropdown list.

Figure 4-6

4.1.3.2 Edit Device

In Figure 4-5 click edit button, you can go to the edit interface. See Figure 4-7.

Please input corresponding configuration parameter and then click save button to save.

You can refer to chapter 4.1.3.1 for more information. Please note channel name and channel number information here is generated automatically.

Figure 4-7

4.1.3.3 Remove Device

In Figure 4-5 click remove button, you can delete the mounted front-end device.

4.1.4 Storage Plan

Click storage plan button, you can go to the following interface. See Figure 4-8.

Here you can view the storage plan information such as serial number, storage plan name, camera, storage plan name (Content), storage position, status.

You can use choose all button to check all plans here.

You can use change status button to modify several plans at the same time.

In the following interface, you can see:

The first storage plan name is "100101301_2009072116550"

The device is DVR_10.12.8.71. It is schedule record and the record becomes valid in 00:00:00 to 23:59:00. The recorded file is in storage in folder 66 and current plan has been enabled.

Operation								
- Parameter Set - Storage Set - Device Set ► Sto. Policy - Alarm Policy - Config Manage		No.	Name	Camera	Strategy Name(Strategy Content)	Store Position	Status	EditDelete
		☐ 1	100101301_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 2	100101302_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 3	100101303_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 4	100101304_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 5	100101305_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 6	100101306_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 7	100101307_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 8	100101308_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 9	100101309_2009072116550	dvr_10.12.8.72--10010130	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		☐ 10	100101310_2009072116550	dvr_10.12.8.72--10010131	Schedule record (Mon,Tue,Wed.,Thu.,Fri.,Sat.,Sun. : 00:00:00--23:59:00)	66	Start	
		Add Delete Choose All Change Statu					Page Up 1 2 Page Down	

Figure 4-8

4.1.4.1 Add storage plan

In Figure 4-8, click add button, you can go to an interface shown as in Figure 4-9.

System can backup the corresponding device channel data of enabled storage plan in specified storage directory. Please input configuration parameter, then click save button, you can add a storage plan.

- Camera: Select the channel from the front-end device. There are four buttons: add one single device channel (“->”), add several device channel (“=>”), remove single device channel (“<-”), remove several device channel (“<=>”).
- Plan name: System auto creates the plan name. It consists of device number+channel number_ creation time.
- Storage position: Please select a created storage position.
- Store strategy: Here you can select the record type. It includes: full day record and schedule record.

Store Strategy : Schedule record

Week : From 0 Hour 0 Minute To 23 Hour 59 Minute

☐ All files ☐ Mon. ☐ Tue. ☐ Wed. ☐ Thu. ☐ Fri. ☐ Sat. ☐ Sun.

- Status: Here you can enable or disable storage plan.
- Note: Memorize corresponding event.




Figure 4-9

4.1.4.2 Edit storage plan

In Figure 4-8, click edit button, you can go to the following interface. See Figure 4-10. Please note, you just can edit plan name and status only.




Figure 4-10

4.1.4.3 Remove storage plan

In Figure 4-7, click remove button directly, you can remove one storage plan.

4.1.5 Alarm Configuration

Click alarm configuration button, you can see an interface is shown as in Figure 4-11.

Here you can view the following item:

- Serial number:1.
- Alarm device:dvr_10.12.5.36
- Device IP address:10.12.5.36
- Alarm name: Alarm test
- Alarm channel:100100301
- Alarm type: Video loss
- Storage position: The folder share
- Status: Current alarm policy has been enabled. You can click it to disable current policy.

You can use choose all button to check all alarm plans here.

You can use change status button to modify several alarm plans at the same time.



Figure 4-11

4.1.5.1 Add alarm plan

In Figure 4-11, click add button, you can see an interface is shown as below. See Figure 4-12.

- Alarm device: You can select a mounted front-end device. If there is external alarm channel, the alarm device name is shown as Device name+device ID+ACH+alarm channel.
- Alarm name: You can input self-defined information here.
- Alarm type: There are four options: video loss/camera masking/motion detection/external alarm. Please note, according to the device configuration information, if you have selected one alarm channel as alarm device, then you can only select external alarm here. If you have selected ordinary record channel as alarm device, then you can only select: video loss/camera masking/motion detection.
- Record device: You can view all configured device on the left side column. You can select the button “->” or “->>” to select device. And you can use “<-” or “<<-” to remove device. You can also move you mouse to the device and then you can see import option to add the device.
- Record time: You can input record duration here.
- Storage position: You can specify the folder to save the recorded file.
- Period: You can set the period for the record operation
- Status: You can click enable button to activate current record plan.

- Note: You can input self-defined information here.

Please note the storage position is for you to specify the path to save recorded file of one channel. For one channel, you can specify one path for both the storage plan and the alarm configuration.

Please input corresponding parameter and then click save button to add an alarm plan.

The screenshot shows the 'Alarm Policy' configuration window in the SVR Storage Video Recorder. The interface has a top navigation bar with tabs: System, Network, Disks, Configuration (highlighted), and Status. Below the navigation bar is a sub-header '>>> Alarm Policy'. On the left is a sidebar menu under 'Operation' with options: Parameter Set, Storage Set, Device Set, Sto. Policy, Alarm Policy (selected), and Config Manage. The main area contains the following fields and controls:

- Alarm Device :** A dropdown menu showing 'Overseas IPC--100100201'.
- Alarm name :** A text input field.
- Alarm Type :** A dropdown menu showing 'Video loss'.
- Record Device :** A list box containing 'Overseas IPC--100100201'. To its right are four buttons: '->', '=>', '<-', and '<='.
- Record Time :** A text input field with the label 'Second (Ten seconds at least)'.
- Store Position :** A dropdown menu showing '99'.
- action time :** A time range selector with 'From' and 'To' fields. The 'From' field is set to 0 Hour 0 Minute 0 Second, and the 'To' field is set to 23 Hour 59 Minute 59 Second.
- Status :** Radio buttons for 'Start' (selected) and 'Stop'.
- Remarks :** A text area for additional notes.
- Buttons:** 'Save' and 'Cancel' buttons at the bottom.

The bottom of the window has a blue bar with the text 'SVR Storage Video Recorder'.

Figure 4-12

4.1.5.2 Edit alarm plan

In Figure 4-11, click edit button, you can see an interface is shown as below. See Figure 4-13. Please note you can just modify alarm name, record time, period and status.




Figure 4-13

4.1.5.3 Remove alarm plan

In Figure 4-11, click remove button, you can delete the alarm plan.

4.1.6 Configuration Management

Click configuration management button, you can go to the following interface. See Figure 4-14.

In the following interface, you can import or export SVR system file.

When current SVR storage is abnormal, you need to remove the storage configuration and storage pool, and configure system. You can use this function.

Before remove configuration, please click export button, you can export current user configuration and device configuration. After you configured the storage pool and storage configuration, please import the configuration files again. Then you can get the user configuration and device configuration as before.




Figure 4-14

4.2 System Status

System status includes the following items: SVR service status, device management, record status, record status, and user status and log information.

4.2.1 Service Status

Click service status button, the interface is shown as in Figure 4-15.

Here you can view SVR configuration status, time synchronization server status and network protocol server status. The SVF configuration service includes database status, SVR service status and maintenance service status. You can click set button to set corresponding information.

Database status

SVR provides database service configuration function. It includes data service and database synchronization.

- Boot up database service: In Figure 4-15 click start button and then click set button.
- Disable database service: In Figure 4-15 click stop button and then click set button.
- Reboot database service: In Figure 4-15 click restart button and then click set button.

SVR service status

SVR service status includes: configuration service, device management service, transmission service and storage service. When it is in enabled status, it means current SVR service is available. If the SVR service is disabled and maintenance service is enabled, system can auto enable SVR service.

- Enable SVR service: In Figure 4-15 click start button and then click set button.
- Disable SVR service: In Figure 4-15 click stop button and then click set button.
- Reboot SVR service: In Figure 4-15 click restart button and then click set button.

Maintenance service status

SVR provides maintenance service.

Enable maintenance service: In Figure 4-15 click start button and then click set button.

Disable maintenance service: In Figure 4-15 click stop button and then click set button.

Reboot maintenance service: In Figure 4-15 click restart button and then click set button.

Time synchronization server

SVR provides the time synchronization function. Use this function; you can synchronize the other device to the SVR.

- Enable time synchronization service: In Figure 4-15 click start button and then click set button.
- Disable time synchronization service: In click Figure 4-15 click stop button and then click set button.
- Reboot time synchronization service: In Figure 4-15 click restart button and then click set button.

Network protocol server

SVR communicates with other front-end device via network protocol. The network protocol service is very important. If its status is abnormal, you need to reboot the network protocol service.

- Enable network protocol server service: In Figure 4-15 click start button and then click set button.
- Disable network protocol server service: In click Figure 4-15 click stop button and then click set button.
- Reboot network protocol server service: In Figure 4-15 click restart button and then click set button.




Figure 4-15

4.2.2 Device Status

Click device status, you can see an interface is shown as in Figure 4-16.

Here you can view all mounted devices. Here you can view device serial number, device name, device type, device channel amount, device IP address, device position and status.



Figure 4-16

4.2.3 Record Status

Click record status button, you can see an interface is shown as in below. See Figure 4-17.

Here you can view all valid record plan status. You can view device serial number, device name, device IP address, channel name, channel number, storage position and start time.

If the storage plan has not been enabled, the storage position and start time are shown as NA.



Figure 4-17

4.2.4 User Status

Click user status, the interface is shown as in Figure 4-18.

Here you can view all user account. It includes user name, alias, type and status.



Figure 4-18

4.2.5 Log

Click log button, the interface is shown as in Figure 4-19.

SVR provides log search function. It supports search all, search latest log and search the log in the specified period. It also provides log export function.

- Search all logs: Select search all log button and then click search button.
- Search the latest logs: Input the log amount you want to view. Then click search button. System can display the latest specified log in the screen.
- Search the log in the specified period: Please select the start time and end time. Then click search button, you can view the corresponding logs.
- Export log: Click export button, you can see a dialogue box shown as in Figure 4-20. Click save button, you can save logs in your local pc.

Note:

System max supports 1000 logs. Once it is full, the old log will be overwritten by default.

For administrator, he can download all logs in the pc

For ordinary user, he can only download his own operation logs.




Figure 4-19




Figure 4-20

4.2.6 Service Log

Click service log button, the interface is shown as below. See Figure 4-21.

The interface here is to provide system service log management function for the operators.

It includes five services: CMS/DMS/MTS/SS/RMS.

Here you can view log name, log time, length.

You can delete or download the specified logs.

System Network Disks Operation **Status**

>>> Service Log

Status

- ▶ Service Status
- ▶ Device Status
- ▶ Video Status
- ▶ User Status
- ▶ Log
- ▶ **Service Log**

Log retrieval

Choose log type : CMS

Choose All Delete Download

Index	Name	Time	Length (b)	Delete	Download
☐ 1	cms_32571_2009_10_23_09_24_55.log	Oct 23 09:26	144516	×	📄
☐ 2	cms_32571_2009_10_23_09_14_48.log	Oct 23 09:24	1048743	×	📄
☐ 3	cms_14553_2009_10_23_09_08_40.log	Oct 23 09:14	587739	×	📄
☐ 4	cms_14553_2009_10_23_08_58_51.log	Oct 23 09:08	1048808	×	📄
☐ 5	cms_14553_2009_10_23_08_49_03.log	Oct 23 08:58	1048797	×	📄
☐ 6	cms_14553_2009_10_23_08_39_19.log	Oct 23 08:49	1048727	×	📄
☐ 7	cms_14553_2009_10_23_08_29_28.log	Oct 23 08:39	1048729	×	📄
☐ 8	cms_14553_2009_10_23_08_19_45.log	Oct 23 08:29	1048713	×	📄
☐ 9	cms_14553_2009_10_23_08_09_56.log	Oct 23 08:19	1048783	×	📄
☐ 10	cms_14553_2009_10_23_08_00_14.log	Oct 23 08:09	1048693	×	📄

Page Up 1 2 3 4 5 6 7 8 9 10 Page Down

Figure 4-21

5 SVR Storage Plan

This chapter is to help you quickly create storage plan and provide storage management service.

5.1 Quickly Create Storage Plan Process

Here is a flow chart for your reference.




Figure 5-1

5.2 Admin user login

In the login interface, you can input administrator name and password to log in. See Figure 5-2.



Figure 5-2

Default account is:

- User name: admin.
- Password: 888888888888.

5.3 Create system user

From the system management, select user management. See Figure 5-3.



Figure 5-3

In user interface click add button, you can see an interface is shown as in Figure 5-4.




Figure 5-4

Create system user

Here you can create a user such as user1. See Figure 5-5.




Figure 5-5

5.4 RAID device configuration

Here we take RAID5 as an example.

From disk management, select RAID configuration. See Figure 5-6.

System Network Disks Operation Status

>>> User >>> Upgrade

System

- System
- Parameter
- Organization
- Group
- User
- Upgrade
- Shutdown

User name : User1

User type : Operator

User password : •••••

Confirm password : •••••

Select group : ☐ operator_group ☒ Overseas

Save

Figure 5-6

Now you can see an interface is shown as in Figure 5-7. Please click add button to go on.

Name	Type	Status	Member Disk	Total Space(G)	Edit	Delete
md4	raid5	clean	disk2,disk3,disk4,disk1	894.27		

Add

Figure 5-7

You can see an interface is shown as in Figure 5-8.
Here you can select RAID5 device (at least three disks)

RAID Type : RAID5

Select Disk :

Disk	Disk Space(G)	Type
☒ disk5	298.09	ST3320620SV
☒ disk6	465.76	ST3500641SV
☒ disk7	232.89	ST3250824SV
☒ disk8	232.89	ST3250824SV
☐ disk9	232.89	ST3250824SV
☐ disk10	232.89	WD2500AVBS-63TAA
☐ disk11	465.76	WD5000AVJS-63TRA
☐ disk12	232.89	WD2500AVBS-63TAA
☐ disk13	233.76	WD2500YD-01NVB1
☐ disk14	465.76	WD5000YS-01MPB0
☐ disk15	233.76	WD2500YD-01NVB1

Save

Figure 5-8

Note

Before using devices here, please enable RAID5 device synchronization process.

5.5 Storage pool configuration

From disk management, select storage pool configuration. See Figure 5-9.




Figure 5-9

Now you can see an interface is shown as in Figure 5-10.




Figure 5-10

Click add button. Now you can configure storage pool. See Figure 5-11.
Here you can see raid5 device disk15 constitutes storage pool1.




Figure 5-11

5.6 Storage Folder Configuration

From operation item, select storage set. Click add button, you can see the following interface. See Figure 5-12.




Figure 5-12

5.7 Storage Parameter Configuration

Click parameter button, you can set pack time, reserved volume, log path and then enable current function. See Figure 5-13.

System Network Disks **Operation** Status

>>> Parameter Set

Operation

- ▶ Parameter Set
- ▶ Storage Set
- ▶ Device Set
- ▶ Sto. Policy
- ▶ Alarm Policy
- ▶ Config Manage

Record pack duration : 5 minute

Reserve Volume : 10 G

Log of service enable : ☐ Enable ☒ Disable

Log path : /mnt/RAID5/77

Save

Figure 5-13

5.8 Device Configuration

And then in Figure 5-12, click device set button on the left side and then click add button. The interface is shown as in Figure 5-14.

Please input the corresponding information and then click save button to exit.

System Network Disks **Operation** Status

>>> Device Set

Operation

- ▶ Parameter Set
- ▶ Storage Set
- ▶ **Device Set**
- ▶ Sto. Policy
- ▶ Alarm Policy
- ▶ Config Manage

Device Type : DVR

Device Name : *

Device Factory : DAHUA

Device Channels : 1 *

Alarm channel : 0 *

Device IP Address : *

Device Port : 37777 *(1-65535)

Login name : *Please ensure current user can be reused on this device

Login Password :

Confirm Password :

Device Owner : root *

Description :

Chann Name : CH01 No. : Auto Type : General Can code type : D1

Save Cancel

Figure 5-14

5.9 Storage Plan Configuration

From operation item, select storage policy button. Then please click add button.

You can go to Figure 5-15 to set storage plan.

System Network Disks **Operation** Status

>>> Sto. Policy

Operation

- ▶ Parameter Set
- ▶ Storage Set
- ▶ Device Set
- ▶ **Sto. Policy**
- ▶ Alarm Policy
- ▶ Config Manage

Camera : Overseas IPC-100100201

Plan Name :

Store Position : 99

Store Strategy : Schedule record

Week : From 0 Hour 0 Minute To 23 Hour 59 Minute
☒ All files ☒ Mon. ☒ Tue. ☒ Wed. ☒ Thu. ☒ Fri ☒ Sat ☒ Sun.

Status : ☒ Start ☐ Stop

Remarks :

Save Cancel

Figure 5-15

5.10 Alarm Plan Configuration

From Operation to Alarm policy, and then click add button. You can go to Figure 5-16. Here you can set alarm plan.

System Network Disks **Operation** Status

>>> Alarm Policy

Operation

- ▶ Parameter Set
- ▶ Storage Set
- ▶ Device Set
- ▶ Sto. Policy
- ▶ **Alarm Policy**
- ▶ Config Manage

Alarm Device : Overseas IPC-100100201

Alarm name :

Alarm Type : Video loss

Record Device : Overseas IPC-100100201

Record Time : 99 Second (Ten seconds at least)

Store Position : 99

action time : From 0 Hour 0 Minute 0 Second To 23 Hour 59 Minute 59 Second

Status : ☒ Start ☐ Stop

Remarks :

Save Cancel

SVR Storage Video Recorder

Figure 5-16

5.11 Enable Storage Service

From Status to service status item, the interface is shown as in Figure 5-17.
Please enable SVR service and database service.




Figure 5-17

6 ESS3015A

ESS3015A is disk extension rack. It applies to extend network intelligent storage capacity.

6.1 ESS3015A and SVR

Disk rack connects to HBA via miniSAS cable. HBA connects to SVR via PCI or PCI-X slot. You can refer to Figure 6-1.




Figure 6-1

One SVR can connect to two HBA and one HBA can connect to two SVR devices. One ESS3015A can install 15 SATA disks. So ESS3015A device can effectively extend SVR capacity.

In this chapter, we talk about how to extend SVR capacity. Though ESS3015A (disk rack) is an extensible device, but for SVR device, it just adds some available disks in the system. The Web operation and share application is the same as SVR. Here we merely talk about the difference.

6.1.1 Disk Management

From disk management to disk management, you can see an interface is shown as in Figure 6-2. Here you can see there are five buttons. Host and expand 1/2/3/4. It shows current SVR connects to four disk racks.

When you go to disk information interface, system just shows host rack information by default. You can click expand rack button to view corresponding information.

>>> Disk

Disk

▶ Disk

▶ RAID

▶ Pool

Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
1	disk1	465.76	running	md15	Used	WD5001ABYS-01YNA
2	disk2	465.76	running	md15	Used	WD5001ABYS-01YNA
3	disk3	465.76	running	md15	Used	WD5001ABYS-01YNA
4	disk4	465.76	running	md15	Used	WD5001ABYS-01YNA
5	disk5	465.76	running	md15	Used	WD5001ABYS-01YNA
6	disk6	465.76	running	md16	Used	WD5001ABYS-01YNA
7	disk7	465.76	running	md16	Used	WD5001ABYS-01YNA
8	disk8	465.76	running	md16	Used	WD5001ABYS-01YNA
9	disk9	465.76	running	md16	Used	WD5001ABYS-01YNA
10	disk10	465.76	running	md16	Used	WD5001ABYS-01YNA
11	disk11	465.76	running	md17	Used	WD5001ABYS-01YNA
12	disk12	465.76	running	md17	Used	WD5001ABYS-01YNA
13	disk13	465.76	running	md17	Used	WD5001ABYS-01YNA
14	disk14	465.76	running	md17	Used	WD5001ABYS-01YNA
15	disk15	465.76	running	md17	Used	WD5001ABYS-01YNA

 Host

 Expand1

 Expand2

 Expand3

 Expand4

Figure 6-2

6.1.2 RAID Setup

From disk management to RAID setup, you can see an interface is shown as in Figure 6-3.

System displays host rack RAID configuration information by default. You can click expand disk rack button to view corresponding information.

Please note, though sometimes user interface just shows there is only disk rack1, you can not say there is only one disk rack connects to current SVR. If you have not created RAID device in disk rack 2, system just shows there is one host rack and one expand rack1.




Figure 6-3

● Add RAID Setup

In Figure 6-3, click add button, you can see an interface is shown as in Figure 6-4.

Here you can select RAID type (RAID0, RAID1, and RAID5), disk rack number (host, expand1/2/3/4) and then select disks to create a RAID device.

In this interface you can just see all the available disks, those used or malfunction disks will not be displayed.

Click save button after you complete adding RAID device operation.




Figure 6-4


6.1.3 Storage Plan Configuration

From disk management to storage pool configuration, you can see the storage pool information.

See Figure 6-5.

System displays host storage pool information by default. The Host button is blue. You can click Expand1 button to view the storage pool information in the rack 1.

Please note, the following figure does not mean there is only one Expand in current SVR. For example, current SVR connected to two rack (Expand 1 and Expand 2), but you only created storage pool in the Host and Expand 1. Then system does not display Expand 2 because there is no storage pool in it.



Pool	Component Device	Total Space(G)	Used Space(G)	Expand	Edit	Delete
pool0	md1	698	635	Host		
pool1	md3	447	425	Host		
pool2	md4	1863	1855	Host		



Figure 6-5

7 Appendix A ---Terms Explanation

Here are some terms explanations in this user's manual.

- SVR: It is the abbreviation for Storage video recorder. It adopts large capacity HDD, RAID technology to store large data and can guarantee high safety.
- DVR: It is the abbreviation for digital video recorder.
- SATA: It is the abbreviation for serial ATA. In current released Serial ATA 2.0, data transmission speed can reach 300MB/second.
- RAID: It is the abbreviation for redundant array of independent disks. It is to combine several independent HDDs (physical HDD) to form a HDD group (logic HDD) to provide more storage capacity and data redundancy. Now it consists of seven levels, ranging from RAID0 to RAID6. Besides, it has some basic RAID combination groups such as RAID10 (RAID0 and RAID1, RAID 50 (RAID 0 and RAID 5). Here is a comparison between RAID 0, RAID 1, RAID 5. In this manual, we call RAID5, RAID 1, RAID0 as RAID5 device, RAID1 device and RAID 0 device respectively.
- RAID0: RAID0 is so called Striped Disk Array without Fault Tolerance. It represents the highest storage performance in RAID level. RAID0 is to read-write continue data in several HDD. So, system data query will be performed in several HDDs at the same time.
- RAID1: It is also called Mirror or mirroring. Its aim is to maximally guarantee data safety and restorable. RAID1 is to automatically copy user input data fully to other RAID1 HDDs.
- RAID 5: RAID5 does not backup the storage data. Instead, it will memorize data and corresponding verification information to HDDs of RAID5. The data and verification information will be backed up in different HDDs respectively. When data in one of the HDDs is damaged, system can use the rest data and corresponding verification information to restore the lost data.

RAID	Advantage	Disadvantage	Min HDD Amount	Applied zone
RAID 0	● High read-write efficiency. ● No verification to occupy CPU resources. ● Easy to design, use and configure	● No verification or restore function. ● No data error tolerance. ● Not suitable for harsh environment.	2	Create and edit video
RAID 1	● Theoretically, it has double speed. ● 100% data redundancy function. ● Easy to design, use and configure.	● Low HDD use efficient. ● High storage cost. ● In soft RAID1 mode, performance descends gravely.	2	● Financing statistics and data base financing system. ● Need high maintenance work.

RAID 5	• High read transmission speed. • Medium write speed, • Considerable low ECC HDD data occupation.	• HDD error will affect the input and output speed. • The controller design is a little bit difficult.	4	• File and application server, database server.
--------	---	---	---	---

- Synchronization: After creating RAID 1 or RAID 5, before using, system needs to read-write the HDD at a fixed speed and adopts an algorithm to calculate. This process is so called synchronization. During the synchronization, system performance speed is very low.
- Hot spare disk: It is disk set as hot spare. When RAID 1 or RAID 5 lost disk, while the RAID configuration is OK, the hot spare disk can auto replace the lost disk. After it replaced the disk, it can become one of the RAID and does not have hot spare function any more.
- Storage pool: it is a virtual logic device. It can consist of several HDDs and RAID group. It is a main way to realized virtual storage.
- Storage folder: Local PC access the top path of the share storage space. You can create, remove, authenticate and set valid user at the storage device. It includes general record space and alarm record space to save different record types.
- Storage plan: The storage plan integrates the external connected device record and SVR record. It can specify the record device time and record data storage position.
- Reusable account: You need to use user name and password to access DVR, IPC or NVS. System allows the different operators to login the different devices by using the same account. The account is so-called reusable account.
- Management status: It is a device status when controller configure device via web. Actually, when there is no error or damage, device shall be always in management status.
- Working status: It is a device status when controller access HDD via network. System is ready to use after you configure correctly in accordance with this user's manual. Some non-device error (such as configuration error, hot swap error) may result in device failure. You can configure again to boot up the device. But **data loss** may occur during this process.

8 Appendix B Disk Hot Swap Operation

Hot swap operation instruction.

When device is in management mode (Please refer to appendix A---Terms Explanation), after dismantle or insert disk, system is still in management mode and no damage to the system and disk. Whether system is in working status (Please refer to the terms explanation), it depends on the administrator operation.

Here we talk about how to operate hot swap operation while at the same time guarantee device is always in working status.

Note:

Only RAID5 and RAID1 can guarantee data safety and support data restore function. So, before your operation, please make sure the disk group to be hot swapped is set to be the RAID1 or RAID5.

When RAID device is in working status, RAID1 and RAID5 support hot swap one disk. After hot swap, the working RAID 1 and RAID 5 become degrading level. If you dismantle one more disk, it may result in **data loss** in the whole group disk!

Now system only support hot swap in degraded RAID5/RAID1 group, and then RAID device becomes ready status. Device returns to working status after disk synchronization.

Note: please use SVR when RAID is in working status.

Hot swap only be operated when RAID is in working status, otherwise it may result in data loss in RAID device!

- **Ready status:** It only applies to RAID1/RAID5, e.g these disk groups are in RAID synchronization. When disk group are in ready status, in the web configuration interface, from disk management to RAID configuration, you can see the corresponding RAID group status is “clean, degraded, recovering” .
- **Working status:** it only applies to RAID1/RAID5. It is a RAID status after synchronization. When disk group are in ready status, in the web configuration interface, from disk management to RAID configuration, you can see the corresponding RAID group status is “clean, degraded, recovering” .
- **Degraded status:** It only applies to RAID1/RAID5. e.g the working RAID disk group status after hot swap a disk. When RAID is in degraded status, in the web configuration interface, from disk management to RAID configuration, you can see the corresponding RAID group status is “clean, degraded” .

Operation example

The RAID5 and RAID1 have the same hot swap operation steps. Now we take RAID5 as an example.

In SVR, there is a RAID5 disk group consists of four disks (disk1, disk2, disk3, disk4.). All these four disks are in working status.

Note: SVR max supports 16 SATA disks. But for performance and safety consideration, we recommend RAID 5 consists of four to six disks, RAID1 consists of two to three disks.

Note: Here we just take four disks as an example. When your disk amount is more than 4, the operation is just the same.

1). Disk hot swap example.

In web configuration interface, from disk management to disk information, you can see the information before hot swap. See Figure 8-1.

Here you can see the following information:

- In SVR, disk group has four disks.
- The four disks are: disk1, disk2, disk3, disk4.
- These four disks are corresponding to channel 1 to channel 4 respectively.
- All disks are in running status, which means there is no error.

Disk	Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
► Disk	1	disk1	465.76	running	md4	Used	ST3500630SV
► RAID	2	disk2	298.09	running	md4	Used	ST3320620SV
► Pool	3	disk3	465.76	running	md4	Used	ST3500630SV
	4	disk4	465.76	running	md4	Used	ST3500630SV

Figure 8-1

2) In web configuration interface, from disk management to RAID configuration, you can see current RAID device status.

Before hot swap, please **make sure** the disk to be hot swapped is in RAID5 (RAID1) and RAID5 (RAID1) is in working status. See Figure 8-2.

Name	Type	Status	Member Disk	Total Space(G)	Edit	Delete
md4	raid5	clean	disk2,disk3,disk4,disk1	894.27		

Figure 8-2

3). Log out disk to be hot swapped.

In Figure 8-2, click edit button of the corresponding RAID device. You can see an interface is shown as in Figure 8-3.

Here you can see the following information:

- RAID 5 device md0 total space is 698.66, and it consists of four disks.
- The RAID status is in working status. (Clean mode).
- The group consists of four disks: disk1, disk2, disk3, disk4.
- There is a newly added disk list.

Check remove button after disk1 and then click save button. Now you are about to remove disk1.

>>> RAID >>> Edit RAID

Disk

- Disk
- RAID**
- Pool

Detailed RAID Information

RAID Name : md4 RAID Type : raid5

Total Space(G) : 894.27 Member Disk Amount : 4

Status : clean

Member disk :

SN	Disk	Disk Space(G)	Disk Status	
1	disk1	465.76	in_sync	☒ Remove
2	disk4	465.76	in_sync	☐ Remove
3	disk3	465.76	in_sync	☐ Remove
4	disk2	298.09	in_sync	☐ Remove

Newly Added Disk

SN	Disk	Disk Space(G)	Disk Status	
1	disk5	298.09	running	☐ Add
2	disk6	465.76	running	☐ Add
3	disk7	232.89	running	☐ Add
4	disk8	232.89	running	☐ Add
5	disk9	232.89	running	☐ Add
6	disk11	465.76	running	☐ Add
7	disk12	232.89	running	☐ Add
8	disk13	233.76	running	☐ Add
9	disk14	465.76	running	☐ Add
10	disk15	233.76	running	☐ Add
11	disk10	232.89	running	☐ Add

Figure 8-3

4).In web configuration interface, from disk management to disk information, you can see the disk information after hot dismantle: disk1 is in free status. See Figure 8-4.

Now there are two options:

- You can remove the disk1 from the rack.
- You can insert the disk1 into other RAID5/RAID1 in degraded mode. And then create storage pool and share folder to provide share service.

Disk	Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
► Disk	1	disk1	465.76	running		Free	ST3500630SV
► RAID	2	disk2	298.09	running	md4	Used	ST3320620SV
► Pool	3	disk3	465.76	running	md4	Used	ST3500630SV
	4	disk4	465.76	running	md4	Used	ST3500630SV

Figure 8-4

5).In web configuration interface, from disk management to RAID configuration, you can see RAID device status. See Figure 8-5.

After hot swap disks, RAID5 device from working status to clean, degraded status. Current RAID5 disk group can still work properly.

Name	Type	Status	Member Disk	Total Space(G)	Edit	Delete
md4	raid5	clean, degraded	disk2,disk3,disk4	894.27		

Figure 8-5

6). Hot swap disk

In web configuration interface, from disk configuration to disk configuration, you can see the disk status. Disk3 corresponding channel number is channel 3(Please refer to Figure 8-4), now you can remove the corresponding disk from the rack.

7).In web configuration interface, from disk configuration to disk configuration, you can see the RAID status information. See Figure 8-6.

Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
1	disk2	298.09	running	md4	Used	ST3320620SV
2	disk3	465.76	running	md4	Used	ST3500630SV
3	disk4	465.76	running	md4	Used	ST3500630SV

Figure 8-6

8).from disk to RAID, you can view the RAID device status after hot swap. See Figure 8-7. The RAID status after hot swap is the same with that before hot swap.

Name	Type	Status	Member Disk	Total Space(G)	Edit	Delete
md4	raid5	clean, degraded	disk2,disk3,disk4	894.27		

Figure 8-7

Now you can refer to the following part for inserting a new disk.

Hot insert disk example.

Note: The hot insert operation only applies to the disk group that has been hot swapped. It is to guarantee data safety.

1). In web configuration interface, from disk configuration to disk configuration, you can see the following information. See Figure 8-8.

Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
1	disk2	298.09	running	md4	Used	ST3320620SV
2	disk3	465.76	running	md4	Used	ST3500630SV
3	disk4	465.76	running	md4	Used	ST3500630SV

Figure 8-8

2). Insert the disk directly to the idle disk channel of SVR and memorize the disk channel name (such as disk1). In this example, we are going to insert the disk1 that just was removed.

From disk management to disk information, you can review disk information before hot swap. And then check disk information again after hot swap.

Compare the information before and after hot swap. You can see before hot swap, there are three disks: dksk2, disk3, disk4. After hot swap, you can see the there are four disks: disk2, disk3, disk4, disk1. Now you can see the newly inserted disk name is disk1.

3). In web configuration interface, from disk configuration to disk information, you can see the disk information. See Figure 8-9.

Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
1	disk2	298.09	running	md4	Used	ST3320620SV
2	disk3	465.76	running	md4	Used	ST3500630SV
3	disk4	465.76	running	md4	Used	ST3500630SV
4	disk1	465.76	running		Free	ST3500630SV

Figure 8-9

4).In web configuration interface, from disk configuration to RAID configuration, you can see the following RAID device status. See Figure 8-10.

Since current disk group md4 is in degraded status, you can add disk now.

Name	Type	Status	Member Disk	Total Space(G)	Edit	Delete
md4	raid5	clean, degraded	disk2,disk3,disk4	894.27		

Figure 8-10

5). Insert hot swap disk.

In Figure 8-10, click edit button, you can see an interface is shown as in Figure 8-11.

Now please check the add button and then click save

Please note, hot swap operation only applies to degrade RAID1/RAID5

RAID begins synchronization again after hot swap.

Detailed RAID Information

RAID Name : md4 RAID Type : raid5

Total Space(G) : 894.27 Member Disk Amount : 4

Status : clean, degraded

Member disk :

SN	Disk	Disk Space(G)	Disk Status	
1	disk4	465.76	in_sync	☐ Remove
2	disk3	465.76	in_sync	☐ Remove
3	disk2	298.09	in_sync	☐ Remove

Newly Added Disk

SN	Disk	Disk Space(G)	Disk Status	
1	disk1	465.76	running	☒ Add
2	disk5	298.09	running	☐ Add
3	disk6	465.76	running	☐ Add
4	disk7	232.89	running	☐ Add
5	disk8	232.89	running	☐ Add
6	disk9	232.89	running	☐ Add
7	disk11	465.76	running	☐ Add
8	disk12	232.89	running	☐ Add
9	disk13	233.76	running	☐ Add
10	disk14	465.76	running	☐ Add
11	disk15	233.76	running	☐ Add
12	disk10	232.89	running	☐ Add

Figure 8-11

Note:

Since newly added disk information take “disk volume” as a symbol (such as disk1), so in the step (2) please memorize hot swap disk name.

6).In web configuration interface, from disk configuration to disk configuration, you can see the disk information. See Figure 8-12.

Channel	Disk	Disk Space(G)	Status	Group	Using status	Type
1	disk1	465.76	running	md4	Used	ST3500630SV
2	disk2	298.09	running	md4	Used	ST3320620SV
3	disk3	465.76	running	md4	Used	ST3500630SV
4	disk4	465.76	running	md4	Used	ST3500630SV

Figure 8-12

7) In web configuration interface, from disk configuration to RAID configuration, you can see the following RAID device status. See Figure 8-13.

Name	Type	Status	Member Disk	Total Space(G)	Edit	Delete
md4	raid5	clean, degraded, recovering (0.0%, 2.96M/s)	disk2,disk3,disk4,disk1	894.27		

Figure 8-13

Note: after hot swap, RAID5 device status is from “degrading” to “recovering” and begins synchronization.

During the hot swap process, system data will not be damaged.

9 Appendix C Command Operation

The command operation is very useful in case you forgot administrator password or IP address. This function applies to our all series SVR. Here we take SVR3016H as an example.

Please follow the steps listed below:

- Connect the SVR to the monitor via COM port.
- Login the system via “dh_admin” account and then go to the Debug command interface.
- Debug command operation.
- Login Debug command operation via “dh_admin”.

Input user name “dh_admin” and its password debug after the corresponding command prompt.

See Figure 9-1

```
login as: dh admin
dh admin@10.12.5.27's password:
Could not chdir to home directory /home/dh_admin: No such file or directory
#DEBUG>help
  help          display this message
  netshow       display net config
  netset        set net config.
                eg. netset bond0 ip netmask [gateway]
  adminpwdset   restore admin password
  reboot        system reboot
  sysreco       recover system conf with default conf
  ipreco        recover ipaddr with default ipaddr
#DEBUG>
```

Figure 9-1

- Debug command operation

Input command “help” after “#DEBUG>”

In Figure 9-1, you can see Debug command provides seven commands:

- ✧ **help**: Here you can view the corresponding information of the Debug command. Command format: **help**.
- ✧ **netshow**: Here you can view system current IP address. Command format: **netshow**
- ✧ **netset**: It is to reset system IP address. Command format: **netset bond IP netmask gateway (Optional)**.
- ✧ **adminpwdset**: Restore administrator (admin) factory default password (888888888888)
- ✧ **reboot**: Reboot system.
- ✧ **sysreco**: Restore system default configuration. Before the operation, please make sure you have exported current configuration.
- ✧ **ipreco**: Restore system default IP information.

Now we take **netshow** as an example.

Operation: Input “**netshow**” and then click the Enter button after the Debug command.

You can see the result in Figure 9-2.

```

#DEBUG>netshow
bond0      Link encap:Ethernet  HWaddr 00:30:48:92:2C:16
            inet addr:10.12.5.27  Bcast:10.12.255.255  Mask:255.255.0.0
            inet6 addr: fe80::230:48ff:fe92:2c16/64  Scope:Link
            UP BROADCAST RUNNING MASTER MULTICAST  MTU:1500  Metric:1
            RX packets:58184 errors:0 dropped:0 overruns:0 frame:0
            TX packets:8288 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:0
            RX bytes:4294310 (4.0 MiB)  TX bytes:1925579 (1.8 MiB)

eth0       Link encap:Ethernet  HWaddr 00:30:48:92:2C:16
            UP BROADCAST RUNNING SLAVE MULTICAST  MTU:1500  Metric:1
            RX packets:58184 errors:0 dropped:0 overruns:0 frame:0
            TX packets:8288 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:100
            RX bytes:4294310 (4.0 MiB)  TX bytes:1925579 (1.8 MiB)
            Base address:0x6000 Memory:e0500000-e0520000

eth1       Link encap:Ethernet  HWaddr 00:30:48:92:2C:16
            UP BROADCAST SLAVE MULTICAST  MTU:1500  Metric:1
            RX packets:0 errors:0 dropped:0 overruns:0 frame:0
            TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:1000
            RX bytes:0 (0.0 B)  TX bytes:0 (0.0 B)
            Base address:0x7000 Memory:e0600000-e0620000

lo         Link encap:Local Loopback
            inet addr:127.0.0.1  Mask:255.0.0.0
            inet6 addr: ::1/128  Scope:Host
            UP LOOPBACK RUNNING  MTU:16436  Metric:1
            RX packets:7512 errors:0 dropped:0 overruns:0 frame:0
            TX packets:7512 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:0
            RX bytes:945066 (922.9 KiB)  TX bytes:945066 (922.9 KiB)

#DEBUG>

```

Figure 9-2

You can refer to the information after the **bond0**. You can see the system current IP address is 10.12.5.27.

Important!

Please note, for command **netset**, the gateway item is optional. If you do not set the gateway in the COM operation, then you need to login the web interface to set system default gateway.

Slight difference may be found in user interface.

All the designs and software here are subject to change without prior written notice.

Please visit our website for more information.